

Foreword	0-1	6. Traveling of the machine	4-13
Before servicing this machine	0-2	7. Efficient working method	4-16
Table to enter S/No and distribution	0-3	8. Operation in the special work sites	4-20
Safety labels	0-4	9. Normal operation of excavator	4-22
Guide(Direction, S/No, Symbol)	0-14	10. Storage	4-23
SAFETY HINTS		11. RCV lever operating pattern	4-25
1. Before operating the machine	1-1	12. Switching hydraulic attachment circuit	4-26
2. During operating the machine	1-6	TRANSPORTATION	
3. During maintenance	1-13	1. Preparation for transportation	5-1
4. Parking	1-16	2. Dimension and weight	5-2
SPECIFICATIONS		3. Loading the machine	5-4
1. Major components	2-1	4. Fixing the machine	5-6
2. Specifications	2-2	5. Loading and unloading by crane	5-7
3. Working range	2-4	MAINTENANCE	
4. Weight	2-6	1. Instruction	6-1
5. Lifting capacities	2-7	2. Tightening torque	6-6
6. Bucket selection guide	2-10	3. Fuel, coolant and lubricants	6-9
7. Undercarriage	2-11	4. Maintenance check list	6-11
8. Specification for major components	2-13	5. Maintenance chart	6-16
9. Recommended oils	2-16	6. Service instruction	6-18
CONTROL DEVICES		7. Electrical system	6-38
1. Cab devices	3-1	TROUBLESHOOTING GUIDE	
2. Cluster	3-2	1. Engine	7-1
3. Switches	3-9	2. Electrical system	7-2
4. Levers and pedals	3-12	3. Others	7-3
5. Others	3-14	HYDRAULIC BREAKER AND QUICK CLAMP	
OPERATION		1. Selecting hydraulic breaker	8-1
1. Suggestion for new machine	4-1	2. Circuit configuration	8-2
2. Check before starting the engine	4-2	3. Maintenance	8-3
3. Starting and stop the engine	4-3	4. Precaution while operating the breaker	8-4
4. Mode selection system	4-7	5. Quick clamp	8-6
5. Operation of the working device	4-12	INDEX	
			9-1

