

A

Air cleaner	6-24
Air conditioner & heater	3-43
Air conditioner filter	6-48
Axle oil	6-39

B

Battery	6-45
Before starting engine	4-2
Belt tensioner	6-22
Boom kick out	4-22
Bucket leveler	4-22

C

Cab device	3-1
Camera	3-50
Charge air cooler	6-21
Cigar lighter	3-47
Cluster	3-2
Control device	3-40
Coolant level	6-17

E

Engine control unit (ECU)	3-50
Engine oil filter	6-15
Engine oil level	6-15

F

Fan belt	6-22
FNR remote control lever	3-41
Fuel filter	6-26
Fuel prefilter	6-25
Fuse box	3-49

G

Gear selector lever	3-41
---------------------------	------

H

Hydraulic oil changing	6-30
Hydraulic oil filling	6-30
Hydraulic oil level	6-29

L

LCD	3-11
-----------	------

Loading and unloading	5-6
Lubrication	6-40

M

Machine control unit (MCU)	3-49
Maintenance chart	6-13
Maintenance check list	6-10
Major components	2-1
Master switch	3-48
Monitor	3-12

P

Pilot cut off switch	3-37
Pilot line filter	6-32

R

Radiator and oil cooler	6-21
Recommended lubricants	6-9
Return filter	6-31
Radio and USB player	3-51

S

Safety hints	1-1
Safety labels	0-7
Seat	3-48
Specifications	2-2
Storage	4-25
Switches	3-33

T

Tightening torque	6-7
Tire	6-34
Towing the machine	5-7
Transmission cold starting	4-6
Transmission control unit (TCU)	3-50
Transmission oil filter	6-36
Transmission oil level	6-36
Transportation	5-1
Travelling machine	4-10
Troubleshooting guide	7-1

W

Warming up operation	4-8
Weight	2-6
Working method	4-15