EC declaration of conformity	0-1
Foreword ·····	0-2
Before servicing this machine	0-3
Table to enter S/No and distribution	0-4
EC regulation approved	0-5
Safety labels	0-6
Machine data plate	0-14
Guide (direction, S/No, symbol)	0-15

1. SAFETY HINTS

1. Before operating the machine	1-1
2. During operating the machine	1-15
3. During maintenance	1-24
4. Parking	1-28

2. SPECIFICATIONS

1. Major components	2-1
2. Specifications	2-2
3. Weight ·····	2-6
4. Specification for major components	2-7

3. CONTROL DEVICES

1. Cab devices ·····	3-1
2. Cluster ·····	3-2
3. Monitors	3-11
4. Switches ·····	3-25
5. Control device ·····	3-32
6. Air conditioner and heater	3-36
7. Others ·····	3-40

4. OPERATION

1. Suggestion for new machine	4-1
2. Check before starting the engine	4-2
3. Starting and stop the engine	4-3
4. Warming-up operation	4-8
5. Operation of the working device	4-9
6. Traveling of the machine	4-10
7. Efficient working method	4-15
8. Adjustment of the work equipment	4-22

9. Operation in the special work sites	4-23
10. Storage ·····	4-25

5. TRANSPORTATION

1. Road traveling	5-1
2. Preparation for transportation	5-2
3. Loading the machine	5-3
4. Fixing the machine	5-4
5. Loading and unloading by crane	5-6
6. Towing the machine	5-7

5 6. MAINTENANCE

1. Instructions ·····	6-1		
2. Tightening torque ·····			
3. Spec of fuel, coolant and lubricants	6-8		
4. Maintenance check list	6-10		
5. Maintenance chart ·····	6-13		
6. Service instruction	6-15		
7. Electrical system ·····	6-41		
8. Air conditioner and heater	6-44		

7. TROUBLESHOOTING GUIDE

7-1
7-2
7-3
7-4
•

6 8. OTHERS

1. Central grease lubrication system	
2. Quick coupler ·····	

INDEX	9-1
-------	-----

	EC Declaration of Conformity		
1.	HYUNDAI CONSTRUCTION EQUIPMENT EUROPE N.V VOSSENDAAL 11, 2440 GEEL (Belgium), authorized representative in the European Community of HYUNDAI CONSTRUCTION EQUIPMENT (Ltd.(Korea)		
	certifies that the construction equipment	machinery.	
	Machine Type : ******	Brand : HYUNDAI	
		Model : *****	
		Serial No: ***	
		Year of Manufacturing : 20**	
2.	Manufacturer	Hyundai Construction Equipment Co. Ltd. 12th, Fl., Hyundai Bldg. 75, Yulgok-ro, Jongno-Gu, Seoul, Republic of Korea	
	Authorized representative : Owner of the technical file for machine production	HYUNDAI CONSTRUCTION EQUIPMENT EUROPE N.V. VOSSENDAAL 11, 2440 GEEL BELGIUM	
3.	Harmonized European directives :	2006/42/EC (Machinery), 97/68/EC (Exhaust Gas Emission), 2004/108/EC (Electromagnetic Compatibility), 200/14/EC (Noise Emission)	
4.	Engine Manufacturer :	*****	
	Engine Type :	*****	
	Gross Power:	*** kW / **** rpm (SAE J1995)	
	Net Power :	*** kW / **** rpm (SAE J1349)	
5.	Noise level (Noise Emission Directive 200	00/14/EC)	
	Certificate No:	*********	
	Issue Date :	DD/MM/YYYY	
	Conformity Assesment Procedure :	************	
	Notified Body Involved :	**************	

	Measured Sound Power Level	** dB(A)	
	Guaranteed Sound Power Level :	** dB(A)	
6.	EMC Certification (EMC Directive 2004/1	08/EC)	
	Certificate No:	******	
	Issued Date :	DD/MM/YYYY	
	Notified Body Involved :	*****	
	Standard(s)	**************	
7.	Remarks		
	Place and date of issue		

FOREWORD

This manual contains a number of instructions and safety recommendations regarding driving, handling, lubrication, maintenance, inspection and adjustment of the wheel loader.

The manual is to promote safety maintenance and enhance machine performance.

Keep this manual handy and have all personnel read it periodically.

If you sell the machine, be sure to give this manual to the new owners.

This machine complies with EC directive "2006/42/EC".

1. Read and understand this manual before operating the machine.

This operator's manual may contain attachments and optional equipment that are not available in your area. Please consult your local Hyundai distributor for those items you require.

Improper operation and maintenance of this machine can be hazardous and could result in serious injury or death.

Some actions involved in operation and maintenance of the machine can cause a serious accident, if they are not done in a manner described in this manual.

The procedures and precautions given in this manual apply only to intended uses of the machine. If you use your machine for any unintended uses that are not specifically prohibited, you must be sure that it is safe for you and others. In no event should you or others engage in prohibited uses of actions as described in this manual.

- 2. Inspect the jobsite and follow the safety recommendations in the safety hints section before operating the machine.
- 3. Use genuine Hyundai spare parts for the replacement of parts.

We expressly point out that Hyundai will not accept any responsibility for defects resulting from nongenuine parts or non workmanlike repair.

In such cases Hyundai cannot assume liability for any damage.

Continuing improvements in the design of this machine can lead to changes in detail which may not be reflected in this manual. Consult Hyundai or your Hyundai distributor for the latest available information for your machine or for questions regarding information in this manual.

BEFORE SERVICING THIS MACHINE

It is the responsibility of the owner and all service and maintenance personnel to avoid accidents and serious injury by keeping this machine properly maintained.

It also is the responsibility of the owner and all service and maintenance personnel to avoid accidents and serious injury while servicing the machine.

No one should service or attempt to repair this machine without proper training and supervision.

All service and maintenance personnel should be thoroughly familiar with the procedures and precautions contained in this manual.

All personnel also must be aware of any federal, state, provincial or local laws or regulations covering the use and service of construction equipment.

The procedures in this manual do not supersede any requirements imposed by federal, state, provincial or local laws.

Hyundai can not anticipate every possible circumstance or environment in which this machine may be used and serviced.

All personnel must remain alert to potential hazards.

Work within your level of training and skill.

Ask your supervisor if you are uncertain about a particular task. Do not try to do too much too fast. Use your common sense.

* How to adjust the language of monitor

User can select preferable language and all displays are changed the selected language.



* Please refer to the page 3-12 for the monitor.

TABLE TO ENTER SERIAL NO. AND DISTRIBUTOR

Machine Serial No.	
Engine Serial No.	
Manufacturing year	
Manufacturer Address	Hyundai Construction Equipment co., Ltd. 12th, Fl., Hyundai Bldg. 75, Yulgok-ro, Jongno-Gu, Seoul, 03058, Korea
Distributor for Europe Address	Hyundai Construction Equipment Europe N.V. Vossendal 11 2240 Geel Belgium
Dealer Address	

EC REGULATION APPROVED

· Noise level (EN474-1 : 2006 and 2000/14/EC) are as followings.

LWA : 105 dB (EU only) LPA : 71 dB

• The value of vibrations transmitted by the operator's seat are lower than standard value of (EN474-1 : 2006 and 2002/44/EC)



SAFETY LABELS

1. LOCATION

Always keep these labels clean. If they are lost or damage, attach them again or replace them with a new label.



- Start motor 1
- 2 Turbocharger cover
- Hyd oil level 3
- Ride control (option) 4
- 5 Grease (A)
- 6 Grease (B)
- 7 Bucket stopper
- 8 Max h/reach
- Roll over 9
- 10 ROPS cab
- Steering warning-LH 11
- 12 Steering warning-RH
- 13 Reference manual
- 14 Control ideogram

- Air conditioner filter 15
- ECU connector 16
- Hammer 17
- Lift & tie 18
- 19 Air cleaner
- Radiator cap 20
- 21 Fueling
- 22 Battery accident
- Hyd oil lub 23
- High pressure hose 24
- 25 Falling
- 26 Stay fix
- 27 Shearing-Engine hood
- Emergency exit 28

- Low emission engine
- 29 30 Service instruction
- Fire extinguisher 31
- 32 Start procedure
- Grease (C) 33
- 34 Grease (D)
- 35 Grease-center
- Keep clear/Reflect 36
- 37 Name plate
- **ROPS** plate 38
- 39 Accumulator
- 40 Joystick steering (option)

0-6

2. DESCRIPTION

There are several specific warning labels on this machine please become familiarized with all warning labels.

Replace any safety label that is damaged, or missing.

1) START MOTOR (item 1)

This warning label is positioned on the left side of the engine side cover.

- ▲ Start the engine only from the operator's compartment. Never short across the starter terminals or across the batteries. Shorting could bypass the engine neutral start system. Shorting could also damage the electrical system.
- 2) TURBOCHARGER COVER (item 2) This warning label is positioned on the turbocharger cover.
- ▲ Do not touch turbocharger or it may cause severe burn.



77070FW05



21070FW02

- 3) HYDRAULIC OIL LEVEL (item 3) This warning label is positioned on the left side of hydraulic oil tank.
- A Place the bucket on the ground whenever servicing the hydraulic system.
- * Check oil level on the level gauge.
- Refill the recommended hydraulic oil up to specified level if necessary.



77070FW06

4) RIDE CONTROL (item 4)

This warning label is positioned on the front frame.

Before checking the boom operation system,

- 1. Bucket should be laid on the ground.
- Turn out the drain screw in ride control valve to release the charged oil in accumulators.

Before checking the boom operation system, 1.Bucket should be laid on the ground.

2.Turn out the Drain Screw in Ride Control Valve to release the charged oil in accumulators.

7707A0FW06

5) BUCKET STOPPER (Item 7)

This warning label is positioned on the middle of the boom.

A When working under or around the bucket or linkage, with bucket raised, proper support must be provided for the bucket and/or the linkage.



7803AFW05

6) MAX HEIGHT (item 8)

This warning label is positioned on the left side window of the cab.

▲ Serious injury or death can result from contact with electric lines.

An electric shock being received by merely coming into the vicinity of an electric lines, the minimum distance should be kept considering the supply voltage as page 1-6.

7) ROLL OVER (item 9)

This warning label is positioned on the left side window of the cab.

- ▲ Structural damage, an overturn, modification, alternation, or improper repair can impair this structure's protection capability thereby voiding this certification.
- Always use seat belt when operating your machine. Always check the condition of the seat belt and the condition of the mounting hardware before you operate the machine.



7803AFW16



77070FW14

- 8) STEERING WARNING (item 11, 12) The warning label is positioned on the side of the front frame.
- A No clearance for person in this area when machine turns.
- A Severe injury or death from crushing could occur.



77070FW07

- 9) REFERENCE MANUAL (item 13) This warning label is positioned on the right side window of the cab.
- A Study the operator's manual before starting and operating machine.



77070FW08

- **10) CONTROL IDEOGRAM** (item 14) This warning label is positioned on the right side window of the cab.
- A Confirm the operation of control lever and working device before operating the machine.
- * Refer to the page 4-7 for details.



- 11) AIR CONDITIONER FILTER (item 15) This warning label is positioned on the washer tank cover.
- * Periodic and proper inspection, cleaning and change of filter prolong air conditioner life time and maintain good performance.



12) ECU CONNECTOR (item 16)

This warning label is positioned on the side of the battery box.

A Before carrying out any electric welding on this machine

- Pull the connectors out of all electronic control units.
- Connect the ground lead of the welding equipment as close to the welding point as possible.
- * Refer to the page 6-43 for details.

13) LIFT & TIE (item 18)

This label is positioned on the both side of the front and rear frame.

- Lifting point

In order to lift the machine, attach the lifting devices to the lifting points.

- Tying point

In order to tie down the machine, attach the tie-downs to the tying points.

14) AIR CLEANER (item 19)

The warning label is positioned on the air cleaner.

A Periodic and proper inspection, cleaning and change of elements prolong engine life time and maintain the good performance of engine.

15) RADIATOR CAP (item 20)

This warning label is positioned on the radiator cover.

A Never open the filler cap while engine running or at high coolant temperature.





75790FW04



21070FW01



16) FUELING (item 21)

This warning label is positioned on the left side of fuel filler neck.

▲ Stop the engine when refueling. All lights or flames shall be kept at a safe distance while refueling.



21070FW04

17) BATTERY ACCIDENT (item 22)

This warning label is positioned on the battery box.

- ▲ Electrolyte containing sulfuric acid cause severe burns. Avoid being in contact with skin, eyes or clothes. In the event of accident flush with sufficient water, call a physician immediately.
- Maintain the electrolyte at the recommended level. Add distilled water to the battery only when starting up, never when shutting down.

With electrolyte at proper level, less space may cause the gases to be accumulated in the battery.

18) HYDRAULIC OIL LUB (item 23)

This warning label is positioned on the top of the hydraulic oil tank.

- * Do not mix with different brand oils.
- A Never open the filler cap while engine running or at high coolant temperature.
- Loosen the cap slowly and release internal pressure completely.



7577A0FW05



19) STAY FIX (item 26)

The warning label is positioned on the engine side door.

- A Be sure to support the stay when the door needs to be opened.
- A Be careful that the opened door may be closed by the external or natural force like strong wind.



21070FW14

- 20) SHEARING-ENGINE DOOR (item 27) This warning label is positioned on the left side of the engine side cover.
- A Don't open the engine door during the engine's running.



21070FW15

21) EMERGENCY EXIT (item 28)

This warning label is positioned on the right side window of the cab.

* The right door serves as an alternate exit.



22) START PROCEDURE (item 32)

This warning label is positioned on the right side window of the cab.

Start Procedure

- 1. Start ignition on.
- 2. Wait up to 4 seconds for grid heater operation in summer. (45 seconds in winter)
- 3. Start cranking.
- (Tier 3 QSB is equipped with mechanical fuel lift pump.)
- 4. If engine still does not start, turn the Keyswitch to OFF position.
- 5. Loosen fuel supply line at the outlet of pre-filter.
- 6. Do hand-priming repeatedly until air bubbles comes out from fuel supply line completely.
- 7. Tighten fuel supply line to its origin position.
- 8. Recranking.
- 9. If the engine still would not start,
- please contact the nearest HYUNDAI or Cummins dealers.

7607A0FW05

23) ACCUMULATOR (item 39)

This warning label is positioned on the accumulator of the solenoid valve.

- The accumulator is filled with high-pressure nitrogen gas, and it is extremely dangerous if it is handled in the wrong way. Always observe the following precautions.
- A Never make any hole in the accumulator expose it to flame or fire.
- A Do not weld anything to the accumulator.
- When carrying out disassembly or maintenance of the accumulator, or when disposing of the accumulator, it is necessary to release the gas from the accumulator. A special air bleed valve is necessary for this operation, so please contact your Hyundai distributor.
- 24) JOYSTICK STEERING (item 40)

This warning label is positioned on the left side of the cab.

- While traveling on public roads, the steering wheel must be used and joystick steering must be prohibited.
- * Please refer to the page 3-36 for details.



1107A0FW46



MACHINE DATA PLATE

Do NOT DEFACE OR REMOVE THIS PLATE 이 방문을 해야대하니 오늘시키지 해서요	CE हिं वि NOT DEFACE OR REMOVE THIS PLATE
MACHINE TYPE / MODEL	MACHINE TYPE / MODEL
PRODUCT IDENTIFICATION NUMBER	PRODUCT IDENTIFICATION NUMBER / VEHICLE IDENTIFICATION NUMBER
ENGINE POWER	ENGINE POWER MAX. AXLE LOAD (FRONT / REAR)
OPERATING MASS	OPERATING MASS / GROSS VEHICLE WEIGHT MFG. YEAR YEAR INTO SERVICE
	477. Bundangause-ro. Bundang-gu. Seorgam-ai. Oyeong-da. 1553. Korea 91LM-14142
For general	For EU only
DO NOT DEFACE OR REMOVE THIS PLATE	
AACHINE TYPE	
MODEL	
IAX. CERTIFIED WEIGHT	
STANDARDS ROPS : ISO 3471 FOPS : ISO 3449 (LEVEL 2)	
For ROPS	

HL0MD01

* The product identification number assigned to this particular machine should be used when requesting information or ordering service parts for this machine from your authorized HD Hyundai Construction Equipment dealer. The product identification number is also stamped on the frame.

GUIDE

1. DIRECTION

The direction of this manual indicate forward, backward, right and left, when machine is on the traveling direction.



2. SERIAL NUMBER

Inform following when you order parts or the machine is out of order.

1) MACHINE SERIAL NUMBER

The numbers are located on the left side of the rear frame.



2) ENGINE SERIAL NUMBER

The numbers are located on the engine name plate.



3. INTENDED USE

This machine is designed to be used mainly for the following work.

- Excavating work
- Leveling work
- Loading work
- Transporting work
- * Please refer to the section 4 (efficient working method) further details.

4. SYMBOLS

- ▲ Important safety hint.
- riangle It indicates matters which can cause the great loss on the machine or the surroundings.
- * It indicates the useful information for operator.

1. SAFETY HINTS

1. BEFORE OPERATING THE MACHINE

Think-safety first.

In special situation, wear protective clothing including a safety helmet, safety shoes, gloves, safety glasses and ear protection as required by the job condition.

Almost every accident are caused by disregarding the simple and fundamental safety hints.

Be sure to understand thoroughly the operator's manual before operating the machine.





Fully understand the details and process of the construction before starting the work. If you find anything dangerous on the job, consult with the job supervisor for preventive measures before operating the machine.



Do not operate when tired, or after drinking. Alcoholic beverages, or any type of drugs.



Check daily according to the operator's manual. Repair the damaged parts and tighten the loosened bolts.



Check for leakage of engine oil, hydraulic oil, fuel and coolant.



Do not operate the machine if it requires repairs. Operate after complete repair.



Make sure safety lock pin is removed before operating the machine.



PRECAUTIONS FOR ATTACHMENTS

When installing and using an optional attachment, read the instruction manual for the attachment and the information related to attachments in this manual.

Do not use attachments that are not authorize by or your distributor. Use of unauthorized attachments could create a safety problem and adversely affect the proper operation and useful life of the machine.

Any injuries, accidents, product failures resulting from the use of unauthorized attachments will not be the responsibility of Hyundai.

SAFETY RULES

Only trained and authorized personnel can operate and maintain the machine.

Follow all safety rules, precautions and instructions when operating or performing maintenance on the machine.

When working with another operator or a person on worksite traffic duty, be sure all personnel understand all hand signals that are to be used.

SAFETY FEATURES

Be sure all guards and covers are in their proper position. Have guards and covers repaired if damaged.

Use safety features such as the safety lock lever and seat belts properly.

Never remove any safety features. Always keep them in good operating condition.

Improper use of safety features could result in serious bodily injury or death.







SECONDARY CAB EXIT

The door on the right side of the cab, also serves as a secondary exit.

Only in case of emergency, use installed the hammer for breaking the windshield of cab, and then exit carefully.



7707FW12

73031SH10

FIRE EXTINGUISHER AND FIRST AID KIT

Be sure fire extinguishers have been provided and know how to use them.

Provide a first aid kit at the storage point.

Know what to do in the event of a fire.

Be sure you know the phone numbers of persons you should contact in case of an emergency.

UNAUTHORIZED MODIFICATION

Any modification made without authorization from Hyundai can create hazards.

Before making a modification, consult your Hyundai distributor. Hyundai will not be responsible for any injury or damage caused by any unauthorized modification.

SEAT BELT

Check the condition of the seat belt and mounting hardware before operating the machine. If the seat belt mounting hardware is worn or damage, replace the seat belt mounting hardware. Make sure that the mounting bolts are tight.

Replace the seat belt at least once every three years regardless of appearance.

Always use seat belts when operating your machine.





FIRE PREVENTION AND EXPLOSION PREVENTION

Regeneration

The exhaust gas temperatures during regeneration will be elevated. Follow proper fire prevention instructions and use the disable regeneration function when appropriate.

General

All fuels, most lubricants, and some coolant mixtures are flammable.

To minimize the risk of fire or explosion, the following actions are recommended.

Always perform a Walk-Around Inspection, which may help you identify a fire hazard. Do not operate a machine when a fire hazard exists. Contact your dealer for service.



```
3001SH01
```

Understand the use of the primary exit and alternative exit on the machine.

Do not operate a machine with a fluid leak. Repair leaks and clean up fluids before resuming machine operation. Fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire. A fire may cause personal injury or death.

Do not weld on or drill holes in the engine cover. Flammable material such as leaves, twigs, papers, trash may accumulate in engine compartment.

Remove flammable material such as leaves, twigs, papers, trash and so on. These items may accumulate in the engine compartment or around other hot areas and hot parts on the machine.

Keep the access doors to major machine compartments closed and access doors in working condition in order to permit the use of fire suppression equipment, in case a fire should occur.

Clean all accumulations of flammable materials such as fuel, oil, and debris from the machine.

Do not operate the machine near any flame.

Keep shields in place. Exhaust shields (if equipped) protect hot exhaust components from oil spray or fuel spray in a break in a line, in a hose, or in a seal. Exhaust shields must be installed correctly.

Do not weld or flame cut on tanks or lines that contain flammable fluids or flammable material. Empty and purge the lines and tanks. Then clean the lines and tanks with a nonflammable solvent prior to welding or flame cutting. Ensure that the components are properly grounded in order to avoid unwanted arcs.

Dust that is generated from repairing nonmetallic hoods or fenders may be flammable and/or explosive. Repair such components in a ventilated area away from open flames or sparks. Use suitable Personal Protection Equipment (PPE).

Inspect all lines and hoses for wear or deterioration. Replace damaged lines and hoses. The lines and the hoses should have adequate support and secure clamps. Tighten all connections to the recommended torque. Damage to the protective cover or insulation may provide fuel for fires.

Store fuels and lubricants in properly marked containers away from unauthorized personnel. Store oily rags and flammable materials in protective containers. Do not smoke in areas that are used for storing flammable materials.

Use caution when you are fueling a machine. Do not smoke while you are fueling a machine. Do not fuel a machine near open flames or sparks. Always stop the engine before fueling. Fill the fuel tank outdoors. Properly clean areas of spillage.

Never store flammable fluids in the operator compartment of the machine.



3001SH03

Battery and battery cables

The following actions are recommended to minimize the risk of fire or an explosion related to the battery.



3001SH04

Do not operate a machine if battery cables or related parts show signs of wear or damage. Contact your dealer for service.

Follow safe procedures for engine starting with jump-start cables. Improper jumper cable connections can cause an explosion that may result in injury.

Do not charge a frozen battery. This action may cause an explosion.

Gases from a battery can explode. Keep any open flames or sparks away from the top of a battery. Do not smoke in battery charging areas.

Never check the battery charge by placing a metal object across the terminal posts. Use a voltmeter in order to check the battery charge.

Daily inspect battery cables that are in areas that are visible. Inspect cables, clips, straps, and other restraint for damage. Replace any damaged parts. Check for signs of the following, which can occur over time due to use and environmental factors :

- Fraying
- Abrasion
- Cracking
- \cdot Discoloration
- \cdot Cuts on the insulation of the cable
- · Fouling
- \cdot Corroded terminals, damaged terminals, and loose terminals

Replace damaged battery cable (s) and replace any related parts. Eliminate any fouling, which may have caused insulation failure or related component damage or wear. Ensure that all components are reinstalled correctly.

An exposed wire on the battery cable may cause a short ground if the exposed area comes into contact with a grounded surface. A battery cable short produces heat from the battery current, which may be a fire hazard.

An exposed wire on the ground cable between the battery and the disconnect switch may cause the disconnect switch to be bypassed if the exposed area comes into contact with a grounded surface. This action may result in an unsafe condition for servicing the machine. Repair components or replace components before servicing the machine.

▲ Fire on a machine can result in personal injury or death. Exposed battery cables that come into contact with a grounded connection can result in fires. Replace cables and related parts that show signs of wear or damage. Contact your Hyundai dealer.

Wiring

Check electrical wires daily. If any of the following conditions exist, replace parts before you operate the machine.

- Fraying
- · Signs of abrasion or wear
- Cracking
- · Discoloration
- · Cuts on insulation
- · Other damage

Make sure that all clamps, guards, clips, and straps are reinstalled correctly. This action will help to prevent vibration, rubbing against other parts, and excessive heat during machine operation.

Attaching electrical wiring to hoses and tubes that contain flammable fluids or combustible fluids should be avoided.

Consult your Hyundai dealer for repair or for replacement parts.

Keep wiring and electrical connections free of debris.

Lines, Tubes, and Hoses

Do not bend high-pressure lines. Do not strike high-pressure lines. Do not install any lines that are bent or damaged. Use the appropriate backup wrenches in order to tighten all connections to the recommended torque.

Check lines, tubes, and hoses carefully. Wear Personal Protection Equipment (PPE) in order to check for leaks. Always use a board or cardboard when you check for a leak. Leaking fluid that is under pressure can penetrate body tissue. Fluid penetration can cause serious injury and possible death. A pin hole leak can cause severe injury. If fluid is injected into your skin, you must get treatment immediately. Seek treatment from a doctor that is familiar with this type of injury.

Replace the affected parts if any of the following conditions are present :

- · End fittings are damaged or leaking.
- Outer coverings are chafed or cut.
- \cdot Wires are exposed.
- · Outer coverings are swelling or ballooning.
- · Flexible parts of the hoses are kinked.
- · Outer covers have exposed embedded armoring.
- · End fittings are displaced.

Make sure that all clamps, guards, and heat shields are installed correctly. During machine operation, this action will help to prevent vibration, rubbing against other parts, excessive heat, and failure of lines, tubes, and hoses.

Do not operate a machine when a fire hazard exists. Repair any lines that are corroded, loose, or damaged. Leaks may provide fuel for fires. Consult your Hyundai dealer for repair or for replacement parts.

Ether

Ether (if equipped) is commonly used in cold weather applications. Ether is flammable and poisonous.

Do not spray ether manually into an engine if the machine is equipped with a thermal starting aid for cold weather starting.

Use ether in ventilated areas. Do not smoke while you are replacing an ether cylinder or while you are using an ether spray.

Do not store ether cylinders in living areas or in the operator compartment of a machine. Do not store ether cylinders in direct sunlight or in temperatures above 49°C(120.2 °F). Keep ether cylinders away from unauthorized personnel.

Fire Extinguisher

As an additional safety measure, keep a fire extinguisher on the machine.

Be familiar with the operation of the fire extinguisher. Inspect the fire extinguisher and service the fire extinguisher regularly. Follow the recommendations on the instruction plate.

Consider installation of an aftermarket Fire Suppression System, if the application and working conditions warrant the installation.

Fire Safety

- * Locate secondary exits and how to use the secondary exits before you operate the machine.
- * Locate fire extinguishers and how to use a fire extinguisher before you operate the machine.

If you find that you are involved in a machine fire, your safety and that of others on site is the top priority. The following actions should only be performed if the actions do not present a danger or risk to you and any nearby people. At all times you should assess the risk of personal injury and move away to a safe distance as soon as you feel unsafe.

Move the machine away from nearby combustible material such as fuel/oil stations, structures, trash, mulch and timber.

Lower any implements and turn off the engine as soon as possible. If you leave the engine running, the engine will continue to feed a fire. The fire will be fed from away damaged hoses that are attached to the engine or pumps.

If possible, turn the battery disconnect switch to the OFF position. Disconnecting the battery will remove the ignition source in the event of an electrical short. Disconnecting the battery will eliminate a second ignition source if electrical wiring is damaged by the fire, resulting in a short circuit.

Notify emergency personnel of the fire and your location.

If your machine is equipped with a fire suppression system, follow the manufacturers procedure for activating the system.

* Fire suppression systems need to be regularly inspected by qualified personnel. You must be trained to operate the fire suppression system.

Use the on-board fire extinguisher and use the following procedure :

- 1. Pull the pin.
- 2. Aim the extinguisher or nozzle at the base of the fire.
- 3. Squeeze the handle and release the extinguishing agent.
- 4. Sweep the extinguisher from side to side across the base of the fire until the fire is out.

Remember, if you are unable to do anything else, shut off the machine before exiting. By shutting off the machine, fuels will not continue to be pumped into the fire.

If the fire grows out of control, be aware of the following risks :

- Tires on wheeled machines pose a risk of explosion as tires burn. Hot shrapnel and debris can be thrown great distances in an explosion.
- Tanks, accumulators, hoses, and fittings can rupture in a fire, spraying fuels and shrapnel over a large area.

Remember that nearby all of the fluids on the machine are flammable, including coolant and oils. Additionally, plastics, rubbers, fabrics, and resins in fiberglass panels are also flammable.

Fire extinguisher Location

Make sure that a fire extinguisher is available. Be familiar with the operation of the fire extinguisher. Inspect the fire extinguisher and service the fire extinguisher. Obey the recommendations on the instruction plate.

Mount the fire extinguisher in the accepted location per local regulations.

If your machine is equipped with a ROPS structure, strap the mounting plate to the ROPS in order to mount the fire extinguisher. If the weight of the fire extinguisher exceeds 4.5 kg (10 lb), mount the fire extinguisher near the bottom of the ROPS. Do not mount the fire extinguisher at the upper one-third area on the ROPS.

Do not weld the ROPS structure in order to install the fire extinguisher. Also, do not drill holes in the ROPS structure in order to mount the fire extinguisher on the ROPS.

Consult your Hyundai dealer for the proper procedure for mounting the fire extinguisher.

THE EUROPEAN UNION PHYSICAL AGENTS (VIBRATION) DIRECTIVE 2002/44/EC

Vibration Data for Earth-moving Machines

Information Concerning Hand/Arm Vibration Level

When the machine is operated according to the intended use, the hand/arm vibration of this machine is below 2.5 m/s².

Information Concerning Whole Body Vibration Level

The highest root mean square value of weighted acceleration to which the whole body is subjected, is less than 0.5 m/s².

This section provides vibration data and a method for estimating the vibration level for earth moving machines.

Vibration levels are influenced by many different parameters. Many items are listed below.

- \cdot Operator training, behavior, mode and stress
- · Job site organization, preparation, environment, weather and material
- Machine type, quality of the seat, quality of the suspension system, attachments and condition of the equipment

It is not possible to get precise vibration levels for this machine. The expected vibration levels can be estimated with the information in below Table in order to calculate the daily vibration exposure. A simple evaluation of the machine application can be used.

Estimate the vibration levels for the three vibration directions. For typical operating conditions, use the average vibration levels as the estimated level. With an experienced operator and smooth terrain, subtract the Scenario Factors from the average vibration level. For aggressive operations and severe terrain, add the Scenario Factors to the average vibration level in order to obtain the estimated vibration level.

* All vibration levels are in meter per second squared.

ISO Reference Table A – Equivalent vibration levels of whole body vibration emission for earthmoving equipment.

Machine family Machine kind	Mashina kind	Typical operating	Vibration Levels			Scenario Factors		
	condition	X axis	Y axis	Z axis	X axis	Y axis	Z axis	
Excavator Compact crawler excavator Crawler	Compact	Excavating	0.33	0.21	0.19	0.19	0.12	0.10
	Hydraulic breaker app.	0.49	0.28	0.36	0.20	0.13	0.17	
	excavalor	Transfer movement	0.45	0.39	0.62	0.17	0.18	0.28
	Crawler excavator	Excavating	0.44	0.27	0.30	0.24	0.16	0.17
		Hydraulic breaker app.	0.53	0.31	0.55	0.30	0.18	0.28
Wheeled excavator		Mining application	0.65	0.42	0.61	0.21	0.15	0.32
		Transfer movement	0.48	0.32	0.79	0.19	0.20	0.23
	Wheeled	Excavating	0.52	0.35	0.29	0.26	0.22	0.13
	excavator	Transfer movement	0.41	0.53	0.61	0.12	0.20	0.19

ISO Reference Table A – Equivalent vibration levels of whole body vibration emission for earthmoving equipment.

Machine family Machine kind	Machina kind	Typical operating	Vibration Levels			Scenario Factors		
	condition	X axis	Y axis	Z axis	X axis	Y axis	Z axis	
Loader	skid steer loader (tracks)	V-shaped motion	1.21	1.00	0.82	0.30	0.84	0.32
	Wheel backhoe loader	Excavating	0.28	0.26	0.20	0.09	0.16	0.06
	Wheel loader	Load and carry motion	0.84	0.81	0.52	0.23	0.20	0.14
		Mining application	1.27	0.97	0.81	0.47	0.31	0.47
		Transfer movement	0.76	0.91	0.49	0.33	0.35	0.17
		V-shape motion	0.99	0.84	0.54	0.29	0.32	0.14

* Refer to "ISO/TR 25398 Mechanical Vibration-Guideline for the assessment of exposure to whole body vibration of ride on operated earthmoving machines" for more information about vibration. This publication uses data that is measured by international institutes, organizations and manufacturers. This document provides information about the whole body exposure of operators of earthmoving equipment.

Guidelines for Reducing Vibration Levels on Earthmoving Equipment

Properly adjust machines. Properly maintain machines. Operate machines smoothly. Maintain the conditions of the terrain. The following guidelines can help reduce the whole body vibration level :

- 1. Use the right type and size of machine, equipment, and attachments.
- 2. Maintain machines according to the manufacturer's recommendations.
 - a. Tire pressures
 - b. Brake and steering systems
 - c. Controls, hydraulic system and linkages
- 3. Keep the terrain in good condition.
 - a. Remove any large rocks or obstacles.
 - b. Fill any ditches and holes.
 - c. Provide machines and schedule time in order to maintain the conditions of the terrain.
- 4. Use a seat that meets "ISO 7096". Keep the seat maintained and adjusted.
 - a. Adjust the seat and suspension for the weight and the size of the operator.
 - b. Inspect and maintain the seat suspension and adjustment mechanisms.
- 5. Perform the following operations smoothly.
 - a. Steer
 - b. Brake
 - c. Accelerate
 - d. Shift the gears.
- 6. Move the attachments smoothly.
- 7. Adjust the machine speed and the route in order to minimize the vibration level.
 - a. Drive around obstacles and rough terrain.
 - b. Slow down when it is necessary to go over rough terrain.
- 8. Minimize vibrations for a long work cycle or a long travel distance.
 - a. Use machines that are equipped with suspension systems.
 - b. Use the ride control system on machines.
 - c. If no ride control system is available, reduce speed in order to prevent bounce.
 - d. Haul the machines between workplaces.
- 9. Less operator comfort may be caused by other risk factors. The following guidelines can be effective in order to provide better operator comfort:
 - a. Adjust the seat and adjust the controls in order to achieve good posture.
 - b. Adjust the mirrors in order to minimize twisted posture.
 - c. Provide breaks in order to reduce long periods of sitting.
 - d. Avoid jumping from the cab
 - e. Minimize repeated handling of loads and lifting of loads.
 - f. Minimize any shocks and impacts during sports and leisure activities.

Sources

The vibration information and calculation procedure is based on "ISO/TR 25398 Mechanical Vibration-Guideline for whole body vibration exposure of operators of earthmoving equipment. The method is based on measured vibration emission under real working conditions for all machines.

You should check the original directive. This document summarizes part of the content of the applicable law. This document is not meant to substitute the original sources. Other parts of these documents are based on information from the United Kingdom Health and Safety Executive.

MODIFICATIONS

Modifications to the machine, including use of unauthorized accessories and spare parts, may affect the machine's condition and its ability to function as it was designed. No changes of any kind may be performed without first obtaining written approval from Hyundai. Hyundai reserves the right to refuse all warranty claims that have resulted due to or can be attributed to unauthorized modifications.

Never modify the operator's cabin by welding, grinding, drilling holes or adding attachments unless instructed by Hyundai in writing. Changes to the cabin can cause loss of operator protection from roll-over and falling objects, and result in death or serious injury.

The person who performs unauthorized modifications assumes all responsibility for consequences that arise due to the modification or can be attributed to the modification, including damage to the machine.

Modifications may be considered to be officially approved, if at least one of the following conditions has been met :

- 1. The attachment, the accessory, or the spare part has been made or distributed by Hyundai and has been installed according to approved methods described in a publication available from Hyundai; or
- 2. The modification has been approved in writing by the Engineering Department at each product company within Hyundai.

2. DURING OPERATING THE MACHINE

Use the handle and footstep when getting on or off the machine.

Do not jump on or off the machine.



Sound the horn to warn nearby personnel before operating the machine.

KEEP RIDERS OFF MACHINE

Riders on a machine are subject to injury such as being struck objects and being thrown off the machine.

Only allow the operator on the machine. Keep riders off.



Operate carefully to make sure all personnel or obstacles are clear within the working range of the machine.

Place safety guards if necessary.



0

When using the work equipment, pay attention to jobsite.



Provide proper ventilation when operating engine in a closed area to avoid the danger of exhaust gases.



Check the locations of underground gas pipes or water line and secure the safety before operation.



The operating near the electrical lines is very dangerous. Operate within safe working range permitted as below.

Supply voltage	Min safe separation		
6.6 kV	3 m (10 ft)		
33.0 kV	4 m (13 ft)		
66.0 kV	5 m (16 ft)		
154.0 kV	8 m (26 ft)		
275.0 kV	10 m (33 ft)		

If the machine touches the electric power lines, keep sitting on the operator's seat and make sure the personnel on the ground not to touch the machine until turning off the electric current. Jump off the machine, do not contact the machine when you need to get off.





73031SH19

While traveling on public roads, lift the bucket 40~50 cm above the ground. Do not drive with the bucket loaded.

00

73031SH21

When the bucket is loaded, avoid sudden swinging or starting. Overloading is dangerous. Make sure the load does not exceed the permissible level.





Operate the machine after making ground flat when operation is required on a slope.



Avoid parking and stopping on a slope. Lower the bucket to the ground and block the tire when parking.



Avoid traveling in a cross direction on a slope as it can cause the danger of rolling over and sliding.



Traveling on the slope is dangerous.

Be sure to operate slowly when driving down a slope and maintain the bucket at a height of 20~30 cm (1 ft) above the ground so that it can be used as brake in an emergency.



Steering of the machine while traveling on a slope is dangerous.

When an inevitable turning of direction is required, turn on the flat and solid ground.



The engine angularity limits are 30°. Do not operate by more than the engine limits in any case.



Watch out for obstacles. Be particularly careful to check the machine clearance during steering.



Always operate machine with proper ROPS/ FOPS installed.

Do not attempt to repair a rollover protective structure (ROPS) after an accident.

Repaired structures do not provide the original structure and protection.

Test and approved as a protective CAB according to ROPS and FOPS standard.

Meets : ISO 3471 / 3449 / 3164

SAE J1040 / J231 / J397

Avoid operating on a cliff, or soft ground as there is danger of rolling over.

Take necessary precautions when working after rain, or blasting because the ground may not be firm enough.





This machine is intended to be used only for excavation and loading. Do not use this for pulling up materials. Unlike a crane, this machine is not equipped with devices needed to pull up things.

Slow down when traveling through obstacles or uneven ground.

When operating in water or when crossing shallows, check the bed soil condition and depth and flow speed of water, then proceed taking care that water is not above axle housing.

Never allow anyone near the center articulation pivot.

If the machine turned, they could be crushed.








Use lights at night or in dark areas.



О

73031SH37

0

0

73031SH38

0

٥

0

))

D

0

//o

o

0

0

0

/

0

0

Be careful in the condition of bad clearance of sight caused by cloud, snow or rain.

Put the chains on the tires when moving or working on the snowed and frozen road, and avoid doing sudden start, stop and swing.

When machine is used for snow removal, be alert for hidden objects.



0

О

σ

Be careful when traveling on icy surface. Keep bucket low to ground.



Be careful when driving under a height limited place, for instance, a tunnel, an overpass, and an overhead cable.



MOUNTING AND DISMOUNTING

Never jump on or off the machine. Never get on or off a moving machine.

When getting on or off the machine, face the machine and use the handhold and steps.

Never hold any control levers when getting on or off the machine.

Always maintain three-point contact with the handholds and steps to ensure that your support yourself.

If there is any oil, grease, or mud on the handholds, steps or nonslip tapes, wipe it off immediately. Inspect, and as necessary, repair or replace the damaged parts and tighten any loose bolts.

When carrying out inspection and maintenance with the mud guarder opened, pay attention to avoid the injury or damage by the mud guarder.





ALWAYS APPLY LOCK WHEN LEAVING OPERATOR'S SEAT

When standing up from the operator's seat, always place the pilot cut off switch to the **OFF** position. If you accidentally touch the RCV lever when they are not locked, the work equipment may suddenly move and cause serious injury or damage.

When leaving the machine, lower the work equipment to the ground, set the pilot cut off switch to the **OFF** position, then stop the engine and use the key to lock all the equipment. Always take the key with you.

* Refer to the page 3-26 for details.



3. DURING MAINTENANCE

During maintenance do not allow any unauthorized person to stand near the machine. Also, be careful of people in the vicinity.



Stop the engine immediately when the trouble of the machine is found.

Inspect immediately the cause of trouble such as vibration, overheating and trouble in the cluster then repair.



Park on a flat place for inspecting and repairing and properly TAG machine is not operational. (remove start key)

Extreme care shall be taken during maintenance work.

Parts may require additional safe guarding.



Do not remove the radiator cap from hot engine. Open the cap after the engine is cool, below 50°C (112°F) to prevent personal injury from heated coolant spray or steam.



Do not work below the machine.

When working under of around the bucket or linkage, with the bucket raised, proper support must be provided for the bucket and / or the linkage.



There is the danger of fire in fuel and oil.

Store in cool dry area, away from any open flames.

Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine.

Spilled grease and oil are dangerous to safety. Keep your machine always clean and dry.

Disassembly, reassembly and repair of tire requires special skills and equipment. Contact a tire repair shop.







Be prepared if a fire starts.

Keep a fire extinguisher handy and emergency numbers for a fire department near your telephone.



When servicing and checking engine compartment at the side door opened, be careful head against door.

Do not open the side door while engine is running.



Do not touch exhaust pipe, or it may cause severe burn.



Be sure to support stay, when the side door needs to be opened.

Be careful the external or natural force like strong wind.



The anti-slip protection should be replaced if they have become worn or have been printed over.



KEEP THE MACHINE CLEAN

Spilled oil or grease, or scattered tools or broken pieces are dangerous because they may cause you to slip or trip.

Always keep your machine clean and tidy.

If water gets into the electrical system, there is danger that the machine may not move or may move unexpectedly.

Do not use water or steam to clean the sensors, connectors, or the inside of the operator's compartment.

HANDLING TIRES

If tires are not used under the specified condition, they may overheat and burst or be cut and burst by sharp stones on rough road surfaces. This may lead to serious injury or damage. To maintain safety, always keep to the suitable conditions : See page 6-29, 30.

▲ Disassembly, reassembly, replacement and repair of tire requires special skills and equipment. Contact a tire repair shop.





4. PARKING

When leaving the machine lower the bucket to the ground completely and put the safety lever at parking position then remove the key. Lock the cab door.



Park the machine in the flat and safe place.



Hope you can work easily and safely observing safety rules.

For safe operation, observe all safety rules.



1. MAJOR COMPONENTS



75792SE01

2. SPECIFICATIONS

1) WITH BOLT-ON CUTTING EDGE TYPE BUCKET (HL760-9)





Unit Description Specification Operating weight kg (lb) 17900 (39460) Struck 2.8 (3.7) m³ (yd³) Bucket capacity Heaped 3.3 (4.3) Overall length А 8100 (26' 7") Overall width В 2900 (9' 6") С Overall height 3450 (11' 4") Ground clearance D 420 (1' 5") Wheelbase Е 3300 (10' 10") mm (ft-in) Tread F 2160 (7' 1") G Dump clearance at 45° 2970 (9' 9") Dump reach (full lift) Н 1220 (4' 0") I Width over tires 2770 (9' 1") Dump angle J 47 degree (°) Roll back angle (carry position) Κ 47 Lift (with load) 5.8 Cycle time Dump (with load) sec 1.2 Lower (empty) 3.1 Maximum travel speed km/hr (mph) 38.1 (23.7) Braking distance 13 (42' 7") m (ft-in) Minimum turning radius (center of outside tire) 5.73 (18' 9") Gradeability degree (°) 30 First gear 6.3 (3.9) Second gear 12.0 (7.5) Forward Third gear 24.0 (15.0) Travel speed Fourth gear km/hr (mph) 38.1 (23.7) First gear 6.7 (4.2) Second gear Reverse 12.6 (7.9) Third gear 25.2 (15.7)

WITH BOLT-ON CUTTING EDGE TYPE BUCKET (HL760XTD-9)





76092SE03-1

Description			Unit	Specification
Operating weight			kg (lb)	18700 (41230)
		Struck		2.8 (3.7)
вискет сараситу	/	Heaped	m³ (yɑ³)	3.3 (4.3)
Overall length		A		8660 (28' 5")
Overall width		В		2900 (9' 6")
Overall height		С		3450 (11' 4")
Ground clearan	се	D		420 (1' 5")
Wheelbase		E	mm (ft-in)	3300 (10' 10")
Tread		F		2160 (7' 1")
Dump clearanc	e at 45°	G		3460 (11' 4")
Dump reach (fu	III lift)	Н		1235 (4' 1")
Width over tires	;	I		2770 (9' 1")
Dump angle		J		47
Roll back angle (carry position)		K	degree ()	49
		Lift (with load)		5.8
Cycle time		Dump (with load)	sec	1.2
		Lower (empty)		3.1
Maximum trave	l speed		km/hr (mph)	38.1 (23.7)
Braking distanc	е		(6.1.)	13 (42' 7")
Minimum turnin	g radius (center	of outside tire)	m (n-m)	5.73 (18' 9")
Gradeability			degree (°)	30
		First gear		6.3 (3.9)
Travel speed	Formered	Second gear		12.0 (7.5)
	Forward	Third gear	km/hr (mph)	24.0 (15.0)
		Fourth gear		38.1 (23.7)
	Reverse	First gear		6.7 (4.2)
		Second gear		12.6 (7.9)
		Third gear		25.2 (15.7)

2) WITH TOOTH TYPE BUCKET (HL760-9)





76092SE02

Description		Unit	Specification	
Operating weight			kg (lb)	17900 (39460)
		Struck	- (- 1-)	2.7 (3.5)
Вискет сараситу	/	Heaped	m ³ (yd ³)	3.2 (4.2)
Overall length		A		8255 (27' 1")
Overall width		В		2950 (9' 8")
Overall height		С		3450 (11' 4")
Ground clearan	ce	D		420 (1' 5")
Wheelbase		E	mm (ft-in)	3300 (10' 10")
Tread		F		2160 (7' 1")
Dump clearance	e at 45°	G		2845 (9' 4")
Dump reach (fu	ll lift)	Н		1305 (4' 3")
Width over tires	;	I		2770 (9' 1")
Dump angle		J	dogroo (°)	47
Roll back angle (carry position)		К	uegree ()	47
		Lift (with load)		5.8
Cycle time		Dump (with load)	sec	1.2
		Lower (empty)		3.1
Maximum trave	l speed		km/hr (mph)	38.1 (23.7)
Braking distanc	е		m (ft-in)	13 (42' 7")
Minimum turnin	g radius (center	of outside tire)		5.73 (18' 9")
Gradeability			degree (°)	30
		First gear		6.3 (3.9)
Travel speed	Forward	Second gear		12.0 (7.5)
	FOIWAIU	Third gear	km/hr (mph)	24.0 (15.0)
		Fourth gear		38.1 (23.7)
		First gear		6.7 (4.2)
	Reverse	Second gear		12.6 (7.9)
		Third gear		25.2 (15.7)

WITH TOOTH TYPE BUCKET (HL760XTD-9)





76092SE02-1

Description		Unit	Specification	
Operating weight			kg (lb)	18700 (41320)
-		Struck	- (1-)	2.7 (3.5)
Bucket capacity	/	Heaped	m ³ (yd ³)	3.2 (4.2)
Overall length		A		8820 (28' 11")
Overall width		В		2950 (9' 8")
Overall height		С		3450 (11' 4")
Ground clearan	се	D		420 (1' 5")
Wheelbase		E	mm (ft-in)	3300 (10' 10")
Tread		F		2160 (7' 1")
Dump clearanc	e at 45°	G		3335 (10' 11")
Dump reach (fu	III lift)	Н		1330 (4' 4")
Width over tires	6	I		2770 (9' 1")
Dump angle		J		47
Roll back angle (carry position)		K	degree ()	49
		Lift (with load)		5.8
Cycle time		Dump (with load)	sec	1.2
		Lower (empty)		3.1
Maximum trave	l speed		km/hr (mph)	38.1 (23.7)
Braking distanc	e		m (ft in)	13 (42' 7")
Minimum turnin	g radius (center	of outside tire)	· · · (· · · · ·)	5.73 (18' 9")
Gradeability			degree (°)	30
		First gear		6.3 (3.9)
Travel speed	Earword	Second gear		12.0 (7.5)
	FOIWAIU	Third gear		24.0 (15.0)
		Fourth gear	km/hr (mph)	38.1 (23.7)
		First gear		6.7 (4.2)
	Reverse	Second gear		12.6 (7.9)
		Third gear		25.2 (15.7)

2-5

3. WEIGHT

Item		kg	lb
Front frame assembly		1652	3640
Rear frame assembly		1998	4410
Front fender (LH & RH)		31	68
Ocurrenterenerisehet	HL760-9	1050	2320
Counterweight	HL760XTD-9	1650	3640
Cab assembly		1050	2320
Engine assembly		485	1070
Transmission assembly		470	1040
Drive shaft (front)		44	97
Drive shaft (center)		46	101
Drive shaft (rear)		27	60
Front axle (include differential)		630	1330
Rear axle (include differential)		632	1390
Tire (23.5-25, 20PR. L3)		300	661
Hydraulic tank assembly		250	550
Fuel tank assembly		362	798
Main pump assembly		55	121
Fan & brake pump assembly		7	15
Main control valve (2/3 spool)		34/41	75/90
Steering valve (EHPS)		15	33
Poom oppombly	HL760-9	1200	2646
Doom assembly	HL760XTD-9	1360	3000
Bell crank assembly		360	794
Bucket link		57	126
3.3 m ³ bucket, with bolt on cutting edge		1670	3680
3.2 m ³ bucket, with tooth		1660	3660
Boom cylinder assembly		150	331
Bucket cylinder assembly		172	379
Steering cylinder assembly		25	55
Seat		40	88
Battery		55	121

4. SPECIFICATION FOR MAJOR COMPONENTS

1) ENGINE

Item	Specification
Model	Cummins QSB6.7 / HYUNDAI HE6.7
Туре	4-cycle turbocharged, charge air cooled diesel engine
Control type	Electronic control
Cooling method	Water cooling
Number of cylinders and arrangement	6 cylinders, in-line
Firing order	1-5-3-6-2-4
Combustion chamber type	Direct injection type
Cylinder bore $ imes$ stroke	$107 \times 124 \text{ mm} (4.2" \times 4.9")$
Piston displacement	6730 cc (410cu in)
Compression ratio	17.2 : 1
Rated horse power (Gross)	215 hp at 2100 rpm
Maximum torque at 1500 rpm	97 kgf · m (702 lbf · ft)
Engine oil quantity	18 / (4.8 U.S. gal)
Wet weight	485 kg (1062 lb)
High idling speed	2230 \pm 50 rpm
Low idling speed	800 ± 25 rpm
Rated fuel consumption (at rated)	234 g/kW ⋅ hr
Starting motor	Nippondenso 228000-7902 (24V-3.7kW)
Alternator	Delco Remy 24SI (24V-70Amp)
Battery	2×12V×130Ah

2) MAIN PUMP

Item	Specification		
	Steering	Loader	
Туре	Variable piston pump		
Capacity	60 cc/rev	51 cc/rev	
Maximum operating pressure	280 kgf/cm ² (3980 psi)		
Rated oil quantity	126 / /min (33.3 U.S.gpm)	107 l /min (28.3 U.S.gpm)	
Rated speed	2100 rpm		

3) FAN + BRAKE PUMP

ltom	Specification		
liem	Fan	Brake	
Туре	Fixed displacement tanderr	n gear pump	
Capacity	19.0 cc/rev	11.9 cc/rev	
Maximum operating pressure	120 kgf/cm ² (1710 psi)	150 kgf/cm ² (2130 psi)	
Rated oil quantity	43 / /min (10.8 U.S.gpm) 27 / /min (6.6 U.S.gpm)		
Rated speed	2100 rpm		

4) MAIN CONTROL VALVE

Item	Specification
Туре	2 spool
Operating method	Hydraulic pilot assist
System pressure	280 kgf/cm² (3980 psi)
Overload relief valve pressure	340 kgf/cm ² (4840 psi) / *300 kgf/cm ² (4270 psi)

* : Bucket dump

5) REMOTE CONTROL VALVE

Item		Specification
Туре		Pressure reducing type
	Minimum	6.5 kgf/cm ² (92.4 psi)
Operating pressure	Maximum	22 kgf/cm ² (312.9 psi)
Single operation stroke Lever		80 mm (3.4 in)

6) CYLINDER

	tem	Specification
Boom cylinder	Bore dia $ imes$ Rod dia $ imes$ Stroke	ø 140 \times ø 80 \times 757 mm
Bucket cylinder	Bore dia $ imes$ Rod dia $ imes$ Stroke	ø 160 \times ø 85 \times 530 mm
Steering cylinder	Bore dia $ imes$ Rod dia $ imes$ Stroke	ø 75 × ø 45 × 424 mm

7) DYNAMIC POWER TRANSMISSION DEVICES

Item			Specification
	Model		ZF4WG 210
	Time	Converter	Single-stage, single-phase
	туре	Transmission	Full-automatic power shift
Transmission	Converter stall ratio		2.121 : 1
	Gear shift		Forward fourth gear, reverse third gear
	Control		Electrical single lever type, kick-down system
	Pump rated flow		105 ℓ /min (27.7 U.S.gpm) at 2000 rpm
	Drive devices		4-wheel drive
Axle	Front		Front fixed location
	Rear		Oscillation $\pm 12^{\circ}$ of center pin-loaded
Wheels	Tires		23.5-25, 20PR (L3)
Drakes	Travel		Four-wheel, wet-disc type, full hydraulic
Brakes	Parking		Spring applied, hydraulic released brake on transmission
Chapting	Туре		Full hydraulic, articulated
Steering	Steering angle		40° to both right and left angle, respectively

1. CAB DEVICES

1) The ergonomically designed console box and suspension type seat provide the operator with comfort.

2) ELECTRONIC MONITOR SYSTEM

- (1) The centralized electronic monitor system allows the status and conditions of the machine to be monitored at a glance.
- (2) It is equipped with a safety warning system for early detection of machine malfunction.



75793CD01

2. CLUSTER

1) STRUCTURE

The cluster consists of gauges, lamps and LCD as shown below, to warn the operator in case of abnormal machine operation or conditions for the appropriate operation and inspection.

- · Gauges : Indicate operating status of the machine.
- $\cdot\,$ Warning lamps : Indicate abnormality of the machine.
- Pilot lamps : Indicate operating status of the machine.
- · LCD : Indicates selected the driving speed and direction.
- * The cluster installed on this machine does not entirely guarantee the condition of the machine. Daily inspection should be performed according to chapter 6, MAINTENANCE.
- * When the cluster provides a warning immediately check the problem, and perform the required action.



75793CD02

2) GAUGE

(1) Speedometer



- ① The speedometer displays the speed of machine in mph and km/h.
- The unit (km/h or mph) can be set by the display set up menu of the monitor and selected unit is displayed.
 Refer to page 3-23.

(2) Fuel gauge



- 1 This gauge indicates the amount of fuel in the fuel tank.
- ② Fill the fuel when the indicator moves red range or Blamp blinks in red, refuel as soon as possible to avoid running out of fuel.
- If the gauge indicates below red range even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(3) Engine coolant temperature gauge



- ① This gauge indicates the temperature of coolant.
 - White range : 40~104°C (104~219°F)
 - Red range : Above 104°C (219°F)
- 2 If the indicator is in the red range or 2 lamp blinks in red, turn OFF the engine and check the radiator and engine.

(4) Transmission oil temperature gauge



- ① This gauge indicates the temperature of transmission oil.
 - White range : 40~107°C (104~225°F)
 - Red range : Above 107°C (225°F)
- ② If the indicator is in the red range or amp blinks in red, it means the transmission is overheated. Be careful that the indicator does not move into the red range.

(5) Hyd oil temperature gauge



(6) Battery volt meter



- $\ensuremath{\textcircled{}}$ This gauge indicates the temperature of hydraulic oil.
 - White range : 40~105°C (104~221°F)
 - Red range : Above 105°C (221°F)
- ② If the indicator is in the red range or 🖾 🗍 lamp blinks in red, reduce the load on the system.
- ③ If the gauge stays in the red range, stop the machine and check the cause of the problem.
- ① This gauge indicates the voltage in the charging system when the engine is running.
- ② If the indicator is below 24V, it means that the electricity is being discharged. If the indicator is above 30V, an unusually high voltage may damage the alternator. Check the charging system in both cases.

3) WARNING LAMPS



(1) Emergency warning lamp



- ① This warning lamp blinks and the buzzer sounds when comunication error occur between monitor and MCU.
- ② When this warning lamp blinks, machine must be checked and service immediately.

(2) Engine overheat warning lamp



- ① This lamp is turned ON when the temperature of coolant is over the normal temperature (106°C, 223°F).
- ② Check the cooling system when the lamp is ON.

(3) Transmission oil temperature warning lamp



- ① This lamp informs the operator that transmission oil is above the specified temperature.
- ② When this lamp lights up during operation, stop the engine and check the machine.

(4) Hydraulic oil temperature warning lamp



- This warning lamp operates and the buzzer sounds when the temperature of hydraulic oil is over 105°C (221°F).
- ② Check the hydraulic oil level when the lamp is turned ON.
- ③ Check for debris between oil cooler and radiator.

(5) Fuel level warning lamp



① This warning lamp lights ON when the fuel level is low. Refuel the machine as soon as possible.

(6) Transmission error warning lamp



- ① This lamp lights ON and the LCD display show the error codes when an error occurs in the transmission.
- ② Immediately pull the machine to a convenient stop. Stop the engine. Investigate the cause.
- * Consult a HYUNDAI dealer to investigate the cause.
- $\ast\,$ Do not operate until the cause has been corrected.

(7) Air cleaner warning lamp



- ① This lamp lights ON when the filter of air cleaner is clogged.
- ② Check the filter and clean or replace it when the lamp is ON.

(8) Engine oil pressure warning lamp



- ① This lamp is comes ON after starting the engine because of the low engine oil pressure.
- ② If the lamp comes ON during engine operation, shut OFF engine immediately. Check engine oil level.

(9) Steering warning lamp





1) Primary

This lamp indicates that the primary steering has failed. When the indicator comes on and the action alarm sounds, steer the machine immediately to a convenient location and stop the machine. Stop the engine and investigate the cause.

* Do not operate the machine until the cause has been corrected.

② Emergency

This lamp indicates the emergency steering system is active.

- * Immediately pull the machine to a convenient stop and stop the engine.
- * The emergency steering system can be manually tested. Refer to page 3-28.

(10) Battery charging warning lamp



- ① This lamp is ON when key ON, it is turned OFF after starting the engine.
- ② Check the battery charging circuit when this lamp comes ON, during engine operation.

(11) Brake fail warning lamp



- ① The lamp lights ON when the oil pressure of service brake drops below the normal range.
- ② When the lamp is ON, stop the engine and check for its cause.
- * Do not operate until any problems are corrected.

4) PILOT LAMPS



75793CD10

(1) Warming up pilot lamp



- (1) This lamp is turned ON when the coolant temperature is below $30^{\circ}C$ (86°F).
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C, or when 10 minutes have passed since starting the engine.

(2) Seat belt pilot lamp



① This lamp lights ON for the first five seconds after starting the engine.

(3) Mirror defrost pilot lamp



- 1 This lamp comes ON when mirror defrost switch is pressed.
- * Refer to page 3-27 for details.

(4) High beam pilot lamp



(5) Preheat pilot lamp



- $\ensuremath{\textcircled{}}$ This lamp works when the illuminating direction is upward.
- ② This lamp comes ON when the dimmer switch is operated, e.g., when passing another vehicle.

- This lamp lights ON when start switch is turned clockwise to the ON position. Light will turn off after approximately 5~45 seconds, depending on engine temperature, indicating that preheating is completed.
- ② When the lamp goes out the operator should start cranking the engine.
- * Refer to page 4-5.

(6) Parking brake pilot lamp



- $(\ensuremath{\textcircled{}})$ When the parking brake is actuated, the lamp lights ON.
- * Check the lamp is OFF before driving.

(7) Maintenance pilot lamp



- ① This lamp will be ON when the consuming parts are needed to change or replace. It means that the change or replacement interval of the consuming parts remains below 30 hours.
- ⁽²⁾ Check the message in maintenance information of the monitor menu. Also, this lamp lights ON for 3 minutes when the start switch is ON position.

(8) Clutch cut off pilot lamp



- ① This lamp lights ON when the clutch cut off mode switch is positioned L, M, H.
- * Refer to page 3-29.

(9) FNR select pilot lamp (option)



- ① The lamp comes ON when FNR select button on the optional FNR remote control lever is pressed.
- * Refer to page 3-33.

(10) Joystick steering pilot lamp (option)



- This lamp lights ON when joystick steering is activated. It is then possible to steer the machine and select gears from the armrest to the left of the operator's seat.
- * Refer to page 3-35.

(11) Ride control pilot lamp (option)



① Auto ride control

This lamp lights ON when push in the bottom of the ride control switch (auto position).

* Refer to page 3-28.



② Manual ride control

This lamp lights ON when push in the top of the ride control switch (manual position)

* Refer to page 3-28.

(12) Fan reverse pilot lamp



① This lamp lights ON when the fan control switch is pressed.
* Refer to page 3-27.

(13) Fuel warmer pilot lamp



5) LCD



- ① This lamp is turned ON when the coolant temperature is below 10°C (50°F) or the hydraulic oil temperature 20°C (68°F).
- ⁽²⁾ The automatic fuel warming is cancelled when the engine coolant temperature is above 60°C and the hydraulic oil temperature is above 45°C since the start switch was ON position.
- (1) The LCD can be used with the gear selector. It indicates speed and driving direction.

No	Symbol	Meaning	Remark
	_, , , □		Forward, reverse, neutral
1	1, 2, 3, 4	Actual gear display	Actual gear
	Р		Parking brake mode active
2	^ , V	Forward, reverse	Automatic mode
3		Gear range display	Automatic mode

3. MONITOR

- \cdot The monitor is adjustable.
- Vertical : 14°
- Horizontal : 30°



- 1) BUTTONS
- (1) Menu button



- $\ensuremath{\textcircled{}}$ D Main display to main menu, main menu to main display.
- ② AEB cancel button in AEB setting.
- (2) Left move button



① Move in menu (left, up).

(3) Camera / ESC button



- ① Enter rear camera mode in main display.
- ② Cancel button except in main display (move previous menu).

(4) Right move/Buzzer stop button

① Move in menu (right, down).



② Buzzer stop.





- ① Select menu (enter).
- ② AEB cancel button in AEB setting.

2) MAIN MENU



- 3 Wiper speed
- 7 Transmission mode
- 4 Actual gear

1

2

- 8 Engine rpm
- * Display type can be changed by operator. See page 3-23.

(1) Structure

No	Main menu	Sub menu	Description
1	MODE 75793CD12	Engine speed Kick down Wiper speed Fan-auto mode AEB Speed meter Sensor calibration	Engine warming up, Engine speed Mode 1 (down/up), Mode 2 (down only) 4 steps Interval and time setting AEB setting Pulse setting Boom/bucket angle, Boom pressure calibration
2	MONITORING 75793CD13	Fault code Machine monitoring Record monitoring	Active, logged fault (machine, TCU, ECU, SCU) Hyd temp, Battery, Coolant temp T/M oil temp, Weighing system Hour meter, ODO meter
3	MANAGEMENT 75793CD14	Machine security Maintenance Machine information Service contact Service	ESL system setting, Change password Replacement, Change interval (oils and filters) Version, Status Service contact S/W download
4	DISPLAY SET UP	Clock Display Unit Rear camera Language	Clock Brightness setting (Manual/Automatic) Type display (A or B type) Temp (°F/°C), Distance (km/mile), Pressure (bar, Mpa, kgf/m², psi) Reverse mode, Active camera, Display order 18 languages

(2) Mode

① Engine speed MODE MODE MODE Engine Speed Engine Speed Engine Speed Engine Warming-Un **Engine Warming-Up** 0 Engine Speed EN Auto Mode OF 75793CD16 75793CD16B 75793CD16A Set low idling speed MODE MODE Engine Speed Engine Speed Engine Warming-Up **Engine Speed** 800 rpm 75793CD16C 75793CD16D 2 Kick down MODE MODE 1/2 Engine Setting **Cick Dow** κ MODE 1 :DOWN/UP uto Mode 2 DOWN ONL 75793CD17 Speed Meter Setting 75793CD17A

- Mode 1 (down/up) : Press kick down button once, shift down and press button again, shift up.
- · Mode 2 (down only) : Press kick down button every time, shift to lower gear respectively.
- * Refer to page 3-31.

③ Wiper speed



- · Select reverse interval or reverse time.
- · Set reverse interval (30~300 min) or reverse time (30~300 sec).
- * Default : Interval (60 min), time (120 sec)
- * Refer to page 3-27, fan control switch.

⑤ AEB

Actual gear window





- · AEB mode controls the disk clearance of the transmission, automatically.
- · To start AEB setting, press ♂ and hold for 3 seconds.
- · To cancel AEB setting, press MENU, ₪/ESC or ♂.
- · If "OK" in actual gear window, press MENU, I/ESC or & to complete AEB setting.
- · Display during AEB mode

Symbol	Meaning		
ST	Start AEB		
K1~K4, KV, KR	Calibrating clutch K1~K4, KV or KR respectively		
OK*	Calibration for all clutches finished		
Spanner and Kx*	Kx couldn't be calibrated, AEB finished		
ΔE	Engine speed too low - Raise engine speed		
∇E	Engine speed too high - Lower engine speed		
ΔT	Transmission oil temperature too low - Heat up transmission		
VT	Transmission oil temperature too high - Cool down transmission		
FO*	Output speed not zero		
FN*	Shift lever not in neutral position		
FP*	Parking brake not applied		

* : Transmission stays in neutral, you have to restart the TCU (ignition off/on).

(6) Speed meter



- · Press 𝔄 and hold for 3 seconds.
- To change the pulse value, press \blacktriangleleft or $\blacktriangleright/\mathfrak{M}$.
- To change the position, press $\mathbf{\mathfrak{S}}$.
- * Only for the serviceperson.

⑦ Sensor calibration



- Boom / Bucket angle calibration
- CPU get sensing signal from boom link angle and bell crank angle and calculate bucket cylinder stroke and boom link position angle from ground real time basis.
- Boom link angle position and bucket cylinder stroke is set by boom kickout & bucket leveler set switch in cab.
- Individual setting position is done by lever solenoid (detent, release operation).
- Angle sensor calibration is basically carried out before delivery of the machine.

When angle sensor is replaced or actual value is different compared to setting value, this function can be done.

- Bucket cylinder stroke Boom link angle Under stroke Bell crank angle Bell crank angle Doom kickout & bucket leveler set switch
- The calibration must be carried out as follows :
- ① Lower the boom at maximum low position and select *C* (bucket must be max tilting position).
- (2) Raise boom at maximum high position and select ${\bf C}$.
- ③ Position boom at -5° and select \bigcirc .
- 4 Retract bucket cylinder length (to minimum position) at -5° boom position and select C.
- ⑤ Extend bucket cylinder length (to maximum position) at -5° boom position and select ♂.
- ⑥ In case above steps are carried normally, "complete" message is shown. Then angle sensor calibration is finished after selecting 𝚱.
- * Boom down / boom up / bucket position setting : Refer to page 4-22.

· Boom pressure calibration

- It is used when bucket weight is changed or measured weight is inaccurate.
- The calibration must be carried out as follows :
- Increase hydraulic temperature (about 30 ~ 60°C).
- ② Select "Boom-pressure calibration".
- ③ Place the boom at low position with bucket completely rolled in (max tilting position).
- ④ Press 健.
- ⑤ Raise boom to maximum position. Boom up must be finished before stepping advance in "display A".
- ⑥ If it show "Succeed" message in a moment, press ♂.
- * Raise hydraulic temperature enough when checking work load / boom pressure sensor calibration (recommendation : about 30 ~ 60°C).
- * Check if pressure sensor or angle sensor is in normal condition for accurate work load algorism or pressure sensor calibration (pressure sensors at boom cylinder head area and rod area, boom link angle sensor (CD-80), bell crank angle sensor (CD-81).
- * Sensor error message during pressure sensor calibration : sensor need to be checked.



(3) Monitoring

2





· Monitor the fault code of the Machine/ECU/TCU/SCU.

* Not define will be indicated in case of that there's no fault.

2 Machine monitoring

MONITORING		MONITOR	MONITORING		MONITORING		
Ċ.	Fault Cada	Mach. Monitoring		Mach. Monitoring			
	Mach, Monitoring	HYD. Temp	75°C	HYD. Temp	75°C		
	Monitoring History	Battery	27.8 V 🔅	Battery	1.8 V 🔅		
		ENG. Coolant Temp	75°C 🍵	ENG. Cor	F 75°C 🔹		
		T/M Oil Temp	75 C	T/M Oil Temp	75 °C 💿		
	75793CD24	i i					
			7709S3CD24A		7709S3CD24B		

- · Monitor the status of the machine.
- $\cdot\,$ To check the item in main display, choose it and press ${\ensuremath{\mathfrak{C}}}$.
- · The right icon shows ON/OFF status.

* Priority in the main display



- · The priority of the weighing system is the highest.
- If selected the weighing system, the other items are not available.
- To check the other items, the weighing system should not be selected.

The example of the weighing system

* Weighing system

1. PRINCIPLE

- 1) The weight indication in bucket is calculated by measuring boom position and boom pressure.
 - The weight is '0.0 ton' when the boom is placed at below -15°.
 - (2) The weight is indicated when the boom is placed at the range (-5°→15°).
 - (3) The weight is calculated when the boom is placed at above -5° and boom is lowered below -15° after dumping operation.

In order to re check weight, go to the (2) after changing boom position (below -15°).

(The other way is to select \bigcirc of monitor and go to (2) in case boom is placed at above -5°).

2) Dump operation : It is checked by bucket cylinder's stroke change (below 250 mm).



2. MONITOR DISPLAY

1) When pressing work load button for over 2 seconds, the weight is shown sequence basis. (main display $1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 1$)



 Default accumulated value at memory A, B, C when pressing work load button for over 2 seconds (default : 0.0 ton).


③ Record monitoring





- \cdot Hour meter
- Total : total hour meter

To show the item in the main display, select "ON" and press *G* (this item could not reset).

- Latest : the latest hour meter after reset.

To show the item in the main display, select "ON" and press ♂.

To reset the latest hour meter, select "initializing" and press \mathfrak{G} .



75793CD25D



· ODO meter

- Total : total ODO meter

- Latest : the latest ODO meter after reset.

To show the item in the main display, select "ON" and press \mathbf{G}^{I} .

To reset the latest odometer, select "initializing" and press $\boldsymbol{\mathfrak{S}}$.



75793CD25J

(4) Management

① Machine security



· ESL system setting

- ESL : Engine Starting Limit
- ESL mode is designed to be a theft deterrent or will prevent the unauthorized operation of the machine.
- If the ESL mode was selected Enable, the password will be required when the start switch is turned ON.
- Disable : Not used ESL function
 - Enable : The password is required whenever the operator start engine.
 - Interval mode : The password is required when the operator start engine first. But the operator can restart the engine within the interval time without inputting the password.

The interval time can be set maximum 2 davs.



Interval setting

- If set interval setting to 5 minutes, ESL system is activated after 5 minutes.

Therefore, the password does not need to restart engine within 5 minutes.







75793CD26D



75793CD26K

· Change password

- Input 5 to 10 digits and press *.





Enter the current password.



Enter the new password.



The new password is stored in the MCU.



Enter the new password again.

② Maintenance



• Alarm (🔅) : Warning

Replacement : The elapsed time will be reset to zero.

Change cycle : The change or replace cycle can be changed in the unit of 50 hours.

- To change cycle, press \triangleleft or $\blacktriangleright/\mathfrak{M}$.
- · Change or replace interval

No	Item	Interval
1	Engine oil	500
2	Hydraulic oil	* ¹ 2000 * ² 5000
3	Pilot line filter element	1000
4	Hydraulic oil return filter	1000
5	Engine oil filter	500
6	Fuel filter element	500
7	Fuel pre-filter	500
8	Hydraulic tank air breather	250
9	Radiator coolant	2000
10	Transmission oil and filter	1000
11	Axle oil (front and rear)	1500

*1 : Conventional hydraulic oil

 \star^2 : Hyundai genuine long life hydraulic oil

③ Machine information

MANAGEMENT 1/2	MANAGEMENT	MANAGEMENT
Mach. Security Maintenance Machine Info. Service Contact Service Menu 75793CD28	Machine Info. Version Status Info. Status Info. 75793CD28A	Version MCU Version Software : 0.0 Cluster Version Software : 0.0 Monitor Version Software : 1.8 MODEL : HL757-9 75793CD28B
->	MANAGEMENT	MANAGEMENT
 Version Software versions of MC checked. Status info The machine status can 	CU, cluster and monitor can be be checked.	MANAGEMENT Status Info. Status Info. Bar Br.M.: 0 pm Brown in FDM: 0 pm
④ Service contact		
MANAGEMENT 1/2	MANAGEMENT Service Contact 08055558272 Change	MANAGEMENT Change → New Phone Number ******** 1 2 3 4 5 6 7 8 9 0 * #

 $\cdot\,$ The phone number of the service man can be checked and changed.

⑤ Service menu

	MANAGEMENT 1/2	MANAGEMENT	MANAGEMENT
Q	Machine Security	Service Menu	Service Menu
×	Maintenance	Current P/W	S/W Download
	Machine Info.	*******	
0	Service Contact		0
	Service Menu	0 1 2 3 4 5 6	
-	75793CD30	7890*#	₽ L
		75793CD30A	75793CD30B

75793CD29A

75793CD29B

4

· The software of monitor can be downloaded.

(5) DISPLAY SET UP



Auto (day/night)

If "Automatic" is chosen, brightness for day and night can be differently set up. Also by using the bar in lower side, users can define which time interval belongs to day and night. (in bar figure, gray area represents night time while white shows day time)

· Display type



	a final				7
	×	Clock			
-	\times	Disp	A Type		
		Unit	B Type	_	_
		Rear			
		Langua	age Selection		
				75793CD33	G

	10:23 pm	
	(Ē)	۲
	ECONO STD, POWER	MANUAL LIGHT NORMAL HEAVY
1200)rpm 🖕	83.5 °C
31.	7 HR ◊	61,5 °C
		75793CD33H

A type



B type

3 Unit



- · Temperature : $^{\circ}C \leftrightarrow ^{\circ}F$
- · Distance : km \leftrightarrow mile
- Pressure : bar \leftrightarrow Mpa \leftrightarrow kgf/m² \leftrightarrow psi

④ Rear camera					
DISPLAY SET	UP	DISPLAY S	ET UP 1e 75793CD35A	DISPLAY S	SET UP
		DISPLAY SI	ra 75793CD35C	DISPLAY S Active Camera Number of Active Camera Display Order Order 1st 2nd 3rd	Camera No, C1 C2 C3 75793CD35D
	—	DISPLAY S Active Camera Number of Active Camera Display Order Order 1st 2nd 3rd	ET UP < 2 > Camera No, C1 C2 C3 75793CD35E	DISPLAY S Active Camera Number of Active Camera Display Order Display Order 1st 2nd 3rd	Camera No. Camera No. C2 C3 75793CD35F

· Reverse mode

- If transmission engages the reverse gear (R1~R3), the camera mode is displayed automatically in main display.
- · Active camera
 - Three cameras can be installed on the machine.
 - The display order can be set by this menu.

75793CD36

- If the camera was not equipped, this menu is not useful.
- In main display, if the I/ESC button is pushed, the first ordered display camera will be viewed.





Swedish

2/2

DISPLAY SET UP

Arab

Language

ederland

· User can select preferable language and all display are changed the selected language.

75793CD36A

4. SWITCHES



1) STARTING SWITCH



(1) There are three positions, OFF, ON and START.

- $\cdot \bigcirc$ (OFF) : None of electrical circuits activate.
- (ON) : All the systems of machine operate.
- $\cdot \bigcirc$ (START) : Use when starting the engine.

Release key immediately after starting.

- If you turn ON the starting switch in cold weather, the fuel warmer is automatically operated to heat the fuel by sensing the coolant temperature. Start the engine in 1~2 minutes after turning ON the starting switch. More time may take according to ambient temperature.
- Key must be in the ON position with engine running maintain electrical and hydraulic function and prevent serious machine damage.

2) HAZARD SWITCH



3) PILOT CUT OFF SWITCH



- (1) Use for parking, or roading the machine.
- (2) Both turn signal lights will flash simultaneously.
- * If the switch is left ON for a long time, the battery may be discharged.
- (1) When the switch is pressed to OFF position, the hydraulic pilot line will be cut off, so the work equipment will not operate.
- (2) Press the ON position in order to unlock the hydraulic pilot line.
- * This switch can be set to ON or OFF position only when the safety button is pulled to the unlock position.

4) PARKING BRAKE SWITCH



- (1) When the switch is pressed to ON position, the parking brake will start to operate and the cluster warning lamp will comes ON.
- (2) Press the release position in order to disengage the parking brake.
- When operating the gear selector lever, be sure to release the parking brake. If the machine is operated with the parking brake engaged, the brake will overheat and may cause the brake system to go out of order.
- * This switch can be set to ON or Release position only when the safety button is pulled to the unlock position.

5) MAIN LIGHT SWITCH



- (1) This switch use to operates the clearance lamp and head light by two step.
 - First step : Clearance lamp and cluster illumination lamp comes ON. Also, all indicator lamp of switches come ON.
 - Second step : Head light comes ON.

6) WORK LAMP SWITCH



- (1) This switch use to operates the front and rear work lamps by two step.
 - First step : Front work lamp located on the cab comes ON.
 - \cdot Second step : Rear work lamp located on the cowl comes ON.

7) REAR WIPER AND WASHER SWITCH



8) FAN CONTROL SWITCH



- (1) This switch use to control the cooling fan.
- (2) This switch has three positions.

· First step

• AUTO : The fan automatically work in reverse according to set up interval and time.

(1) The switch use to operates the rear wiper and washer by two step.

• Second step : The washer liquid is sprayed and the rear wiper is

return to the first step position.

operated only while pressing. If release the switch,

: The rear wiper operates.

- * Refer to page 3-14.
- **OFF** : Only forward rotation is possible.
- MANUAL : The fan rotates reverse only while pressing this position. If release the switch, return to the OFF position.
- (3) On pressing the switch, the indicator lamp is turned ON.

9) DETENT SELECT SWITCH



- (1) This switch is used to select the detent functions.
- (2) This switch has three positions.
 - \cdot A : Detent functions are not operated.
 - \cdot **B** : Only boom detent function is operated.
 - \cdot C : Boom and bucket detent functions are operated.

10) MIRROR DEFROST SWITCH (option)



- (1) If the mirror defrost switch is pressed in condition of key ON, it operates for 15 minutes. After 15 minutes, the defrost function stops automatically.
- (2) One more pressing the switch in operation also stops defrost function.
- (3) On pressing the switch, the indicator lamp is turned ON.

11) BEACON SWITCH (option)



(1) This switch turns ON the rotary light on the cab.

12) RIDE CONTROL SWITCH (option)



(1) AUTO

Press in the bottom of the ride control switch in order to turn on the automatic ride control. The automatic ride control automatically turns on when the travel speed exceeds a preset speed of approximately 7 km/h. The automatic ride control automatically shuts off during low speed travel (below 7 km/h).

(2) MANUAL

Press in the top of the ride control switch in order to turn on the system for ride control regardless speed. The ride control will smooth the ride of the machine during travel.

(3) OFF

Press the ride control switch to the middle position in order to turn off the system for the ride control.

13) EMERGENCY TEST SWITCH (option)



- (1) The emergency steering system can be manually tested. Push the switch in order to determine if the emergency steering and the emergency steering lamp are functional.
- (2) When the switch is pressed, the emergency steering pump motor will run. The emergency steering lamp will light. If the emergency steering lamp does not light, do not operate the machine.

14) ATTACHMENT LOCK SWITCH (option)



- (1) Press this switch in order to engage the quick coupler pins.
- (2) If this switch is pressed for 5 seconds, the quick coupler pins move in the engaged position.

If the switch is released, the quick coupler pins will remain in the engaged position.

* This switch can be pressed only when the safety button is pulled to the unlock position.

* Check for engagement as followings.

- ① Put down pressure on the attachment.
- ② Back up the machine and make sure that there is no movement between the quick coupler and attachment.

15) ATTACHMENT UNLOCK SWITCH (option)



- (1) Press this switch in order to disengage the quick coupler pins.
- (2) If this switch is pressed for 5 seconds, the quick coupler pins move in the disengaged position.

If the switch is released, the quick coupler pins will remain in the disengaged position. (Machine serial No. : ~#0713)

If the switch is released, the quick coupler pins will slowly extend to the engaged/locked position. (Machine serial No. : #0714~)

* This switch can be pressed only when the safety button is pulled to the unlock position.

16) BOOM KICK OUT AND BUCKET LEVELER SET SWITCH



- (1) Press this switch in order to set the boom kickout and bucket leverer.
- * Refer to page 4-22.

17) ENGINE MODE SWITCH



- (1) The operator can adjust the machine's performance with this dial switch.
 - P (Power) : Maximum power output for hard digging operation or hill climb.
 - S (Standard) : General digging and loading operation.
 - E (Econo) : Maximum fuel efficiency for general loading.

18) CLUTCH CUT OFF MODE SWITCH



- (1) Four modes are available for operator's preference and job condition.
 - · OFF : The clutch cut off function is disable.
 - · L (Low) : The clutch is disengaged early for short-distance and rapid loading.
 - M (Medium) : The clutch is disengaged normally for general digging and loading operation.
 - H (High) : The clutch is disengaged lately for slope ground.
- (2) The clutch cut off functions of the left brake pedal depend on the position of the left brake pedal and the position of the clutch cut off mode switch.

Positions for clutch cut off function				
Clutch cut off mode switch L M H				
Left brake pedal	L, M, H	M, H	Н	

19) TRANSMISSION SHIFT MODE SWITCH



- (1) Four modes are available for operator's preference and job condition.
 - MAN (Manual) : Machine is operated by selected gear on lever.
 - AL (Auto Light) : Automatic shifting point is fast for long-distance transportation and fuel efficiency.
 - AN (Auto Normal) : Automatic shifting point is normal without automatic kick-down to 1st gear for general digging and loading operation.
 - AH (Auto Heavy) : Automatic shifting point is normal with automatic kick-down to 1st gear for more powerful operation.

20) HORN BUTTON



(1) If you press the button on the top of the multifunction switch, the horn will sound.

21) CAB LAMP SWITCH



- (1) This switch turns ON the cab room lamp.
- 1 DOOR

The lamp comes ON when the door is opened. When the door is closed the lamp is OFF.

2 ON

This switch is used to turn the lamp ON or OFF.

22) WORKLOAD BUTTON SWITCH



- (1) Press the button switch in order to set "Total" display at zero.
- * See page 3-16, weighing system.

23) USB SOCKET (machine serial No. : -#0601)



- (1) MP3 files are played when a USB device is connected to the USB port.
- (2) In addition, the AUX port enables headphone and other devices.

24) KICK DOWN SWITCH



(1) Manual mode

It is effective 2nd speed to 1st speed only and recover to 2nd speed quickly when push the switch one more time.

(2) Automatic mode

① Mode 1 (down/up)

It shifts down quickly from current gear to one step lower speed by pushing the switch and recover to current speed quickly when push the switch one more time.

② Mode 2 (down)

It shifts down from current gear to one step lower speed when push the switch every time.

The kick down function is released in only 1st speed.

- * Refer to page 3-13 for the kick down setting.
- * The normal autoshift function continues after the kick down switch is released.

25) MULTI FUNCTION SWITCH



(1) Front wiper and washer switch

- ${\ensuremath{\textcircled{}}}$ When the switch is in J position, the wiper moves intermittently.
- O When placed in I or II position, the wiper moves continuously.
- ③ If you push the grip of the lever, washer liquid will be sprayed and the wiper will be activated 2-3 times.
- * Check the quantity of washer liquid in the tank. If the level of the washer liquid is LOW, add the washer liquid (in cold, winter days) or water. The capacity of the tank is 1 liter.





(2) Dimmer switch

- ① This switch is used to turn the head lights direction.
- 2 Switch positions
 - Up : To flash for passing
 - Middle : Head lights low beam ON
 - · Down : Head lights high beam ON
- ③ If you release the switch when it's in up position, the switch will return to middle.

(3) Turning switch

- ① This switch is used to warn or signal the turning direction of the machine to other vehicles or equipment.
- ② Push the lever up for turning left, pull the lever down for turning right.

5. CONTROL DEVICE



75793CD28

1) REMOTE CONTROL LEVER



- (1) These joystick are used to control the boom and the bucket.
- (2) Refer to operation of working device in chapter 4 at page 4-9.

2) FNR REMOTE CONTROL LEVER (option)



- (1) This switch is used for froward and backward drive.
- * Gear range can be selected by gear selector lever.

(2) Select button

- ① If the select button is pressed, the indication lamp on the cluster will be ON and this FNR switch will start to operate.
- When the engine is running, the machine is on standstill(0 speed), parking brake is released, gear selector lever is in the neutral position, you can use this function after pressing the select button.

(3) FNR switch

- · F : Forward drive
- · N : Neutral
- \cdot R : Reverse drive
- If the upper side of this switch is pushed, the machine moves forward.
- 2 If the down side of this switch is pushed, the machine moves backward.
- ③ This function is automatically released when the engine is stopped, parking brake is ON or gear selector lever is out of neutral.
- (4) Kick down button : Refer to page 3-31.

3) GEAR SELECTOR LEVER



- (1) This lever is used for gear selection, forward 4 stages and reverse 3 stages.
- (2) If you push the gear selector lever, the machine moves forward, but if pull the gear selector lever, the machine moves backward.
- (3) If you turn the gear selector lever forward, the machine increases the speed, but if you turn the gear selector lever backward, the machine reduces the speed.

4) ACCELERATOR PEDAL



- (1) This pedal controls the engine speed. The engine speed will increase in proportion to the degree of force applied to this pedal.
- (2) Unless this pedal is pressed, the machine will run at low idling.

5) BRAKE PEDAL





6) STEERING WHEEL



- (1) Left brake pedal (service brake + clutch cut off function)
- ① If the pedal is pushed down, this will generate braking force and bring the machine to a stop.
- ② If the power train operation is to be cut off, set the clutch cut off mode switch to ON (L, M, H) and press the pedal.
- ▲ Even if the brake is applied while clutch cut off mode switch is OFF, power train will not cut off.
- * Do not operate the machine with foot the brake pedal unnecessarily, or bring premature wear of brake disc.
- ③ Clutch cut off function : Refer to page 3-29.
- (2) Right brake pedal (service brake function only) This pedal functions as service brake only.
- (1) Two multi-motion cylinders in the center of the machine will operate the steering function.
- (2) If the steering wheel is turned to left, the machine will move to the left and turn it to the right, the machine will move to the right.

7) STEERING WHEEL LEVER



- (1) By pulling down the lever, the wheel is adjustable to tilt. \cdot Tilting : 40 $^{\circ}$
- (2) By pulling up the lever, the wheel is adjustable to telescope.
 - Telescoping : 80 mm

8) JOYSTICK STEERING CONTROL LEVER (option)



- (1) The system has the following functions concentrated to a collapsible arm rest : steering, forward / reverse selection and kickdown function.
- (2) This means that during normal loading work, the operator does not need to touch the steering wheel.
- (3) The joystick steering pilot lamp on the cluster will be ON when the lever steering is activated.
- ▲ As a safety precaution, the joystick steering is functioned while pressing the steering ON button (C).
- ▲ When operating on a public road, the steering wheel should always be used and the joystick steering be disconnected. Also when operating at high speeds (above 20 km/h) on a work site, always use the steering wheel.

(4) Joystick (A)

① Activate the lever-controlled steering by pushing in the steering ON button (C).

The steering wheel works as usual, even if the joystick steering is activated.

② The joystick steering pilot lamp 🕲 on the cluster will be ON when the steering ON button (C) is pushed.

(5) Forward/reverse selection button

- F : Forward drive
- N : Neutral
- R : Reverse drive
- ① To be able to operate the forward/reverse selection and kick-down button the system must first be activated using select button (B).
- * The ordinary gear selector control should be in neutral.
- ② When this function is engaged, it is possible to operate the forward -reverse selection. If the ordinary gear selector control is activated at the same time as the joystick steering is activated, the ordinary gear selector control overrides any selection made by the joystick steering.

To reactivate the joystick steering, the ordinary gear selector control must first be moved to neutral and the system again be activated.

- ③ The FNR select pilot lamp ④ on the cluster will be ON when the forward/reverse selection is activated.
- (6) Kick-down button : Refer to page 3-31.

6. AIR CONDITIONER AND HEATER

■ FULL AUTO AIR CONDITIONER AND HEATER

Full auto air conditioner and heater system automatically keeps the optimum condition in accordance with operator's temperature configuration sensing ambient and cabin inside temperature.



75793CD37

1) POWER OFF SWITCH



(1) This switch makes the system and the LCD OFF. Just before the power OFF, set values are stored.

(2) Default setting values

Function	Air conditioner	In/outlet	LCD	Temperature	Mode
Value	OFF	Inlet	OFF	Previous sw OFF	Previous sw OFF

2) AUTO SWITCH



- (1) Turn the starting switch to ON position, LCD lights ON. Auto air conditioner and heater system automatically keeps the optimum condition in accordance with operator's temperature configuration sensing ambient and cabin inside temperature.
- (2) This switch can restart system after system OFF.

3) AIR CONDITIONER SWITCH (compressor switch)



- (1) This switch turns the compressor and the LCD ON.
- (2) In accordance with the temperature sensed by duct (evaporator) sensor, compressor turns ON or OFF automatically.
- * Air conditioner operates to remove vapor and drains water through a drain hose. Water can be sprayed into the cab in case that the drain cock at the ending point of drain hose has a problem.

In this case, exchange the drain cock.

4) FAN SPEED SWITCH



- (1) Fan speed is controlled automatically by setted temperature.
- (2) This switch controls fan speed manually.
 - · There are 8 up/down steps to control fan speed.
 - $\cdot\,$ The maximum step or the minimum step beeps 5 times.
- (3) This switch makes the system ON.

5) TEMPERATURE CONTROL SWITCH



- (1) Setting temperature indication
 - ① Type A : 17~32°C, scale : 1°C
 - ② Type B : Lo, 18~31°C, Hi, scale : 1°C

(2) Max cool and max warm beeps 5 times.

(3) The max cool or the max warm position operates as following table.

Temperature	Compressor	Fan speed	In/Outlet	Mode
Max cool	ON	Max (Hi)	Recirculation	Vent
Max warm	OFF	Max (Hi)	Fresh	Foot

- (4) Temperature unit can be changed between celsius (°C) and fahrenheit (°F)
- ① Default status (°C)
- ② Push Up/Down temperature control switch simultaneously more than 5 second displayed temperature unit change (°C → °F)

6) MODE SWITCH



 Operating this switch, it beeps and displays symbol of each mode in order. (Human → Human/Rear → Human/Def → Def/Rear)

Mode switch		Human	Human/Rear	Human/Def	Def/Rear
		ن ر-	-≁ [≞]	€ L	<u>ت</u> ر*
	А			•	•
Outlet	В	•	٠	•	
	С		•		•

- (2) When defroster switch operating, FRESH AIR/AIR RECIRCULA-TION switch turns to FRESH AIR mode and air conditioner switch turns ON.
- (3) When this switch ON, the system operates with previous configuration.

7) FRESH AIR/AIR RECIRCULATION SWITCH



- (1) It is possible to change the air-inlet method.
- Fresh air () Inhaling air from the outside.
- * Check out the fresh air filter periodically to keep a good efficiency.
- ② Air recirculation ()
- It recycles the heated or cooled air to increase the energy efficiency.
- * Change air occasionally when using recirculation for a long time.
- * Check out the recirculation filter periodically to keep a good efficiency.

8) SELF DIAGNOSIS FUNCTION

(1) Procedure



3607A3CD69

(2) Error check

- The corresponding error code flickers on the setup temperature display panel, the other symbol will turn OFF.
- · Error code flickers every 0.5 second.
- $\cdot\,$ If error code is more than two, each code flickers 2 times in sequence.
- · Error code

Error code	Description	Error code	Description
11	Cabin inside sensor	16	Mode actuator 1
12	Ambient sensor	17	Mode actuator 2
14	Duct (evaporator) sensor	18	Intake actuator
15	Temp actuator	-	-

(3) Fail safe function

Error description	Fail safe function
Cabin inside sensor (11) 25°C alternate value control	
Ambient sensor (12)	20°C alternate value control
Duct (evaporator) sensor (14)	1°C alternate value control
Temp actuator (15)	If opening amount is 0 %, the alternate value is 0 %
	If not, the alternate value is 100 %
Mode actuator 1, 2 (16, 17)	The alternate value is Vent

7. OTHERS



75793CD38

1) CIGAR LIGHTER



- (1) This can be used when the engine starting switch is ON.
- (2) The lighter can be used when it springs out in a short while after being pressed down.
- * Service socket

Use cigar lighter socket when you need emergency power. Do not use the lighter exceeding 24 V, 100 W.

2) SEAT

The seat is adjustable to fit the contours of the operator's body. It will reduce operator fatigue due to long work hours and enhance work efficiency.



(1) Forward/Backward adjustment

- ① Pull lever A to adjust seat forward or backward.
- ② The seat can be moved forward and backward over 210 mm (8 in) in 21 steps.
- (2) Reclining adjustment Pull lever D to adjust seat back rest.
- (3) Arm rest adjustment This can be adjusted by turning the handle F to right and left.
- (4) Weight adjustment (E) Adjusting handle to the operator's weight.
- (5) Heated seat switch (option) Press this switch in order to heat the seat.

3) 12V SOCKET (option)



(1) Utilize the power of 12 V as your need and do not exceed power of 12 V, 30 W.

4) MASTER SWITCH



- (1) This switch is used to shut off the entire electrical system.
- (2) I : The battery remains connected to the electrical system.O : The battery is disconnected to the electrical system.
- Never turn the master switch to O (OFF) with the engine running. Engine and electrical system damage could result.

5) FUSE BOX

· Machine serial no. : -#0054



75793CD40

Machine serial no. : #0055-



75793CD107

- (1) The fuses protect the electrical parts and wiring from burning out.
- (2) The fuse box cover indicates the capacity of each fuse and circuit it protects.
- * Replace a fuse with another of the same capacity.
- A Before replacing a fuse, be sure to turn OFF the starting switch.

6) MACHINE CONTROL UNIT (MCU)



(1) It consists of electronic parts and controls all lamps and buzzers on cluster in accordance with signals transmitted from the switches, the ECM, TCU, the engine and the hydraulic pressure sensors.

(2) Three LED lamps on the MCU	display as below.
--------------------------------	-------------------

LED lamp	Trouble	Service
G is turned ON	Normal	-
G and R are turned ON	Trouble on MCU	Change the MCU
G and Y are turned ON	Trouble on serial communication line	 Check if serial communication lines between controller and cluster are disconnected
Three LED are turned OFF	Trouble on MCU power	 Check if the input power wire (24V, GND) of controller is disconnected Check the fuse
G: green, R	: red, Y: vellow	

G: green, R∶rea,

7) TRANSMISSION CONTROL UNIT (TCU)



- (1) The control unit is shifting the required speeds fully-automatically under consideration of the following criteria.
 - · Gear selector lever position
 - · Driving speed
 - · Load level

8) ENGINE CONTROL UNIT (ECU)



(1) The engine control unit (ECU) is the control center of the engine system.

9) REAR CAMERA (option)



- (1) The rear camera is available as a option.
- * Refer to page 3-24.

10) RADIO AND USB / PLAYER (Machine serial No. : -#0366)



3-44

RADIO AND USB PLAYER +BLUETOOTH (Machine serial No. : #0367-#0729)



GENERAL

(1) Power and volume button



① Power ON/OFF button

Press power button to turn the unit ON or OFF shortly. When the power is ON, the previous mode (last memory) will appear.

② Volume up / down control

Turn volume up / down button right to increase the volume level. The level will be shown in VOLUME xx on the LCD display. Turn it left to decrease the volume level. After 5 seconds of volume indication, display will return to the previous mode.

(2) Sound function selection button (audio selection)



① This button is to adjust the sound. Each time you press power button shortly, LCD displays each mode as follows :

 $BASS \rightarrow TREBLE \rightarrow BAL \rightarrow BEEP \rightarrow LOUD \rightarrow VOLUME$

When this button is pressed, LCD display shows selected function for 5 seconds and then returns back to the previous mode. On selected function, level can be controlled by turning this button. The display will automatically return to normal indication in 5 seconds after the last adjustment is made or when another function is activated.

② Bass control

To adjust the bass level, first select the bass mode by pressing the select button sel

The bass level will be shown on the LCD display from a minimum of BASS -10 to a maximum of BASS +10.

The display will automatically return to the normal indication in 5 seconds after the last adjustment or when another function is activated.

③ Treble control

To adjust the treble level, first select the treble mode by pressing the select button select button select button select button select button select button for the treble indication appears on the LCD display. Within 5 seconds of choosing the treble mode, turn power button right / left to adjust the treble level as desired.

The treble level will be shown on the LCD display from a minimum of TREBLE -10 to a maximum of TREBLE +10.

The display will automatically return to the normal indication in 5 seconds after the last adjustment or when another function is activated.

④ Balance control

To adjust the left-right speaker balance, first select the balance mode by pressing the select button sel until the BAL indication appears on the LCD display.

Within 5 seconds of choosing the balance mode, turn power button right / left to adjust the balance as desired.

The balance position will be shown on the LCD display from BAL 10L (full left) to BAL 10R (full right).

When the volume level between the left and right speakers is equal, BAL L=R will be shown on the LCD display panel.

The display will automatically return to the normal indication in 5 seconds after the last adjustment or when another function is activated.

5 Beep control

The display will automatically return to the normal indication in 5 seconds after the last adjustment or when another function is activated.

Select BEEP ON when you wish to hear the BEEP sound whenever any function button is pressed.

Select BEEP 2ND when you wish to hear the BEEP sound whenever any tuner pre-set button and/or tune seek buttons are pressed for more than 3 seconds.

6 Loud control

When listening to music at low volume levels, this feature will boost the bass and treble response.

This action will compensate for the reduction in bass and treble performance experienced at low volume.

To select the loudness feature, press select button set until LOUD ON or LOUD OFF is displayed, then turn power button left or right to activate or deactivate loudness.

(3) Mode button



0 Press mode button to select RADIO / USB / AUX.

(4) Audio mute button



① Press mute button momentarily to mute volume and MUTE mark will blink on the LCD display.

Press the button again to return to the mode in use before the mute mode was activated.

RADIO

(1) AM / FM / LW band selector



① Each time this button is pressed, the radio button is changed. Each time this button is pressed, LCD displays each band as follows :

$$FM1 \rightarrow FM2 \rightarrow FM3 \rightarrow AM \rightarrow LW$$

* LW band is only available for Europe.

(2) Up / down tuning



To manually select a radio station, press the up tuning & down tuning button for longer than 3 seconds.

The radio frequency will move up or down step by step each time you press button.

(3) Station pre-set button

1	2
3	4
5	6

Pressing these buttons shortly will recall your favorite pre-set radio stations.

To store your favorite stations into any of the 6 pre-set memories in each band (AM/FM/LW), use the following procedure :

- a. Turn the radio ON and select the desired band.
- b. Select the first station to be pre-set using the manual up/ down or automatic seek tuning control button.
- c. Press the chosen pre-set button to store your selected station into and continue to hold it in. The beep sound will be momentarily heard and the pre-set number will apear on the LCD display indicating that the station is now set into that pre-set memory position and can be recalled at any time, by pressing that pre-set button.

(4) Pre-set scan (PS) / Best station memory (BSM) button

① Pre-set scan (PS)



Press BSM button shortly to scan the 6 pre-set station stored the memories on each band (AM/FM/LW).

The unit will stop at each pre-set station (the pre-set number on the LCD display will flash during pre-set scan operation) and remain on the selected frequency. Press the button momentarily again to remain on the station currently being heard.

② Best station memory (BSM)

Pressing BSM button for longer than 2 seconds will activate the BSM tuning feature which will automatically scan and enter each station into memory.

If you have already set the pre-set memories to your favorite stations, activating the BSM tuning feature will erase those stations and enter the new ones.

This BSM feature is most useful when traveling in a new area where you are not familiar with the local stations.

USB PLAYER

(1) USB function

There are two ways to play mp3 files in a USB device : using USB socket in the cab and the USB/ AUX cable connected to the front side of the player.

· Use of USB socket

- ① Connect a USB device, which saves mp3 files, to USB socket in the cabin.
- ② If a USB device has not been connected, MP3 files are automatically played when you insert it into the USB port.
- ③ If a USB device has connected, MP3 files are played when you press mode for USB.

· Use of USB/AUX cable (option)



75793CD81

- ① Connect the USB/AUX cable to the player in order to play MP3 files in a USB device.
- ② If a USB device has not been connected, MP3 files are automatically played when you insert it into the cable.
- ③ If a USB device has connected, MP3 files are played when you press mode for USB.

(2) File selection & cue / review button



1 File selection function

This button is used to select file up / down. Each time the forward file select \ll is pressed, file number is increased.

Each time the backward file select \backsim is pressed, file number is decreased.

2 Cue / review functions

High-speed audible search of file on a USB can be made by this button (the cue and review functions).

Press and hold the cue button \ll to advance rapidly in the forward direction or the review button \gg to advance rapidly in the backward direction.

(3) MP3 directory / file searching

① The power button is used to select a particular directory and file.

Press and hold for more than 3 seconds while playing MP3 file.

Turn right / left the power button to search the directory. Press the button when you find the wanted directory.

For example, the directory search generally changes in two methods depending on the order of writing as follows.

· Method 1 : ROOT \rightarrow Dir01 \rightarrow Dir02 \rightarrow Dir03 \rightarrow Dir04 \rightarrow Dir05 \rightarrow Dir06 \rightarrow Dir07

 $\cdot \text{ Method } 2: \text{ROOT} \rightarrow \text{Dir}01 \rightarrow \text{Dir}02 \rightarrow \text{Dir}05 \rightarrow \text{Dir}03 \rightarrow \text{Dir}06 \rightarrow \text{Dir}04 \rightarrow \text{Dir}07$

If you want to search the file in the located directory, turn right / left the power button consecutively. Press the button when you find the wanted file. The unit will then play the selected file. For instance, the file search changes in Dir01 as follows.

$$File01 \rightarrow File02 \rightarrow File03 \rightarrow File04$$

* MP3 direction / file configuration



(4) ID3 v2 display



① Disp button is used to change the display information.

While playing an MP3 file, you can change the file information shown on the LCD display.

Each time you press DISP (display), the display changes to show the following.

* If the MP3 disc does not have any ID3 information, the display will show NO ID3 on LCD display.



(5) File scan (SCN)



① During USB play, press SCN button to play the first 10 seconds of each file on the whole file on the USB (SCN mark will appear on the LCD display).

When a desired file is reached, press the SCN button again to cancel the function.

The unit will then play the selected file.

In case of playing MP3 file, when the SCN (scan) button is pressed and held for longer than 2 seconds, the SCN mark will blink on the LCD display and all files in the selected directory will be introduced until the file scan mode is cancelled by pressing the SCN button again or by activating the random or repeat functions.

(6) Repeat play selector (RPT)



① During USB play, press RPT button to play the selected file repeatedly (RPT will appear on the LCD display).

Play of the file will continue to repeat until this button is pressed again and the RPT disappears from the LCD display.

In case of playing MP3 file, when the RPT button is pressed and held longer than 2 seconds, the RPT mark will blink on the LCD display and play all files in the selected directory and will be repeated until the directory repeat mode is cancelled by pressing the repeat button again or by activating the scan or random functions (RPT mark will disappear from LCD display).

(7) Random play selector (RDM)



① During USB play, press RDM button to play the files on the USB in a random shuffled order (RDM will appear on the LCD display). The file select function will also select file in the random order instead of the normal process.

The random play mode can be cancelled by this button again.

In case of MP3 file, when the random button is pressed and held longer than 2 seconds, the RDM mark will blink on the LCD display and play all files in directory randomly until the directory random mode is cancelled by pressing the random button again or by activating the scan or repeat functions (RDM mark will disappear from LCD display).

(8) Directory down



(9) Directory up



located each time you press this button.

① Press D- button briefly while playing MP3. The previous directory is

- ① Press D+ button briefly while playing MP3 . The next directory is located each time you press this button.
- * If the MP3 file does not have a directory, the unit play MP3 at 10-file intervals.
- If any MP3 file does not exist in USB, this button can not operate.

AUX PLAYER

- (1) Aux function
- · Use of USB socket



- ① If you want to listen to music of a external audio device, connect a external audio device into the USB port.
- ② Press mode button to change a current mode for AUX. If audio file of audio device is playing, you can listen to music through speaker.

· Use of USB/AUX cable (option)



- ① If you want to listen to music of a external audio device, connect a external audio device through USB/AUX cable.
- ② Press mode button to change a current mode for AUX. If audio file of audio device is playing, you can listen to music through speaker.
■ BLUETOOTH (Machine serial No. : #0367-#0729)

(1) Introduce

The bluetooth radio supports bluetooth wireless technology. Bluetooth technology provides a wireless link between a bluetooth mobile phone or bluetooth music player and the hyundai bluetooth radio.

The bluetooth radio features a hands-free system so that you may talk on the telephone without taking your eyes off the road or your hands off the wheel. A microphone built into the front of the radio receives your voice and the calling party can be heard through the car speakers.

Additionally, a bluetooth music player can be wirelessly connected to be the bluetooth radio and playback music tracks in high quality sound through the speakers. Some bluetooth mobile phones include a music player and can provide both hands-free calling and music playback. Check your mobile phone owner's manual for details.

- * When the starting switch is in the ON position, the bluetooth radio is on standby to connect with your mobile phone even if the radio is switched off. The machine battery may therefore become drained if the ignition switch remains in the ON position for an extended period of time.
- Bluetooth technology uses low power radio transmission to connect to your bluetooth mobile phone or bluetooth music player. As radio signal strength reduces over distance, the quality of sound performance during phone calls and music playback may become poor if the distance between the radio and device widens. It is recommended that the mobile phone or music player is kept inside the cab for best results.
- * As a bluetooth wireless connection can extend to 10 meters, your bluetooth device may automatically connect to the bluetooth radio even if the device is not in the machine.
- * The bluetooth radio uses the latest digital noise & echo suppression system to provide the best sound clarity with little or no distortion, but in some conditions there may be some echo and noise experienced. It is recommended to keep the car windows closed during hands-free calls for best results.



① Bluetooth indicator

The bluetooth logo is displayed when a bluetooth device is connected, and not displayed, when no bluetooth device is connected. If the bluetooth mobile phone is connected but the connection is not of satisfactory quality, the bluetooth logo is not displayed.



② Battery strength indicator

This is an indication of your mobile phone battery condition. If your mobile phone is not unable to transmit battery condition level, the indicator is not displayed.



③ Single level indicator

This is an indication of the mobile phone network signal strength in your current location. If your mobile phone is not able to transmit signal level, the indicator is not displayed.

(2) Bluetooth function

① Registering a bluetooth mobile phone or music player

A bluetooth connection must first be established between your bluetooth mobile phone or bluetooth music player and the bluetooth radio. The first step to connecting the bluetooth radio and bluetooth device is to introduce or "Pair" the bluetooth radio and bluetooth device together.

It is recommended that you have the instruction manual for your bluetooth mobile phone or music player with you during the pairing process described below to understand how to set your device to pair with the bluetooth radio.

* It is recommended that all other bluetooth devices other than mobile phones are switched off during the registration or pairing process.

a. Connection method

- a) Press button 50 for 2 seconds in any mode, **PAIRING** appears on the bluetooth radio display.
- b) Browse your mobile phone or music player menu to find the **SETTINGS** or **CONNECTIVITY** section to find the bluetooth connection section.
- c) Find the command that may be called search for bluetooth device or discovery mode so that your bluetooth device can locate all the bluetooth devices within range that may be connected.
- d) After the search is complete, **HHI AUDIO** should appear on your mobile phone or music player screen.
- e) Select **CONNECT** or **SELECT** on your mobile phone or music player.
- f) The mobile phone or music player should now prompt you top enter a PIN code. Enter 0000 into your bluetooth device and select OK.
- g) The mobile phone or music player should confirm that it has established a new paired connection with the bluetooth radio.
- h) The connecting process is now complete.
- i) If the connecting process is successful, the bluetooth logo appears on the radio display and paired phone name (e.g. Samsung or Nokia) and CONNECTED appear on the display for 2 seconds.
- j) Your bluetooth device is now ready for use with the bluetooth radio.
- k) If the pairing failed, **FAIL** appears on the bluetooth radio display.
- * (a) The bluetooth radio allows a maximum of 6 bluetooth devices to be paired.
 - (b) Bluetooth technology only allows one phone to be connected to your bluetooth radio at one time.
 - (c) If a bluetooth music player is to be connected together with a mobile phone, refer to the page 3-63, PLAYING MUSIC USING BLUETOOTH AUDIO.
 - (d) Bluetooth connection with a mobile phone is normally established using the Hands-Free Profile (HFP). However, in some cases, the connection may use Head Set Profile (HSP) and some functions may not be available.
 - (e) As each mobile phone or music player brand and model has a different menu structure and control names, you may need to refer to the user manual of your bluetooth device for the correct procedure to connect to another bluetooth device.
 - (f) Once the bluetooth pairing is complete, automatic connection between mobile phone and the bluetooth radio is possible whenever the starting switch is switched ON.

The mobile phone must be set to automatically connect to the bluetooth radio to allow this automatic connection.

- (9) The bluetooth radio will give connection priority to the last connected mobile phone.
- (h) It is recommended that all other bluetooth devices other than mobile phones are switched off during the registration or pairing process.

2 Disconnecting a bluetooth device

If you need to disconnect your bluetooth mobile phone or music player with the bluetooth radio, follow the steps below.

- a. Press button $\textcircled{\begin{subarray}{c} \end{subarray}}$ for 2 seconds in any mode.
- b. When the bluetooth connection is lost, bluetooth logo disappears and the previously connected device name (e.g. Samsung or Nokia) and **DISCONNECTED** appear on the display.

③ Select a bluetooth device

The bluetooth radio can pair up to 6 bluetooth devices. A previously paired mobile phone or music player can be selected for connection using the method described below. Refer to the table 2-1 for examples.

Preset No.	Bluetooth device name
1	Samsung (for example)
2	Sony (for example)
3	Nokia (for example)
4	Motorola (for example)
5	EMPTY
6	EMPTY

Table 2-1

a. Press button 🔭, to select **PHONES** mode.

- b. Press SEL button. **SELECT PHONE** will appear on the display.
- c. Turn , until **SELECT PHONE** is displayed.
- d. When **SELECT PHONE** appears on the display, press SEL button.
- e. Press the preset button to display the name of the bluetooth device name of the mobile phones or music players previously paired. You may also turn to display the paired devices.
 - Each time you turn D, the LCD displays as follows :

 $1_SAMSUNG \rightarrow 2_SONY \rightarrow 3_NOKIA \rightarrow 4_MOTOROLA \rightarrow BACK$

- f. If the bluetooth mobile phone name is Samsung as in the example of table 2-1, then **Samsung** appears on the display. When preset button is pressed or knob is turned 1 click to the right.
- g. Once the name of the bluetooth device you wish to connect is displayed, in this example **Samsung**, press SEL button to have the Samsung device connected.
- h. If the connection is successful, the bluetooth logo appears on the display and paired phone name **Samsung** and **CONNECTED** appears on the display for 2 seconds.

④ Deleting a previously paired bluetooth device

If you no longer need to use a paired bluetooth device with the bluetooth radio, it can be deleted. It is from the registration assignment for another mobile phone. Refer to the example of paired devices shown table 2-1.

- a. Press knob 🛅 , to select **PHONES** mode.
- b. Press SEL button and **SELECT PHONE** appears on the display.
- c. Turn , until **DELETE PHONE** is displayed.
- d. When **DELETE PHONE** appears on the display, press SEL button.
- e. Press the preset button to display the name of the bluetooth device name of the mobile phones or music players previously paired. You may also turn like to display the paired devices.
- f. Once the name of the bluetooth device you wish to delete is displayed, in this example **Samsung**, press SEL button to have the Samsung device deleted.
- g. The display will then show DELETE NO or if knob
 is turned, DELETE OK on the display.
- h. To confirm your wish to delete the selected device, when **DELETE OK** appears on the display press SEL button.
- i. If the bluetooth device being deleted (in this example) was connected, the display will show **DISCONNECTED (Samsung)**.
- j. In the example above, the number of paired devices is now reduced to 3, leaving 3 vacant memory locations for additional devices. Table 2-2 shows the example.

Preset No.	Bluetooth device name
1	Sony (for example)
2	Nokia (for example)
3	Motorola (for example)
4	EMPTY
5	EMPTY
6	EMPTY

Table 2-2

5 Basic telephone operation

a. Using the bluetooth radio for hands-free calls

- a) When an INCOMING call arrives at the bluetooth radio via your connected bluetooth mobile phone, INCOMING CALL appears on the display for 3 seconds then the calling telephone number is shown.
- b) Press button 😇 to answer the INCOMING call. HANDSFREE appears on the display.
- c) To end the call, press button 🐻 and the call will end and END CALL is displayed.
- d) If you wish to reject an INCOMING call, press button \fbox .
- e) To make an OUTGOING call use the keypad of the connected bluetooth mobile phone to enter a number and press the OFF-HOOK button on your mobile phone.
- f) OUTGOING CALL is displayed on the bluetooth radio and the call continues in hands-free mode.
- g) The call can be ended by pressing button 😇 the **ON-HOOK** button of the connected mobile phone.
- * Some mobile phones may not reject an INCOMING call using the action of d) above. In this case, press the **ON-HOOK** button on the connected mobile phone to reject.

b. Last call number redials

Select **BLUETOOTH** mode by pressing button 🔭 . To making a call to the last dialed number, press button 🔭 again. **OUTGOING CALL** appears on the radio display for 1 second.

* Some mobile phones may require an additional press of button 50 to start the last number redial call.

c. Switching to private (headset) mode during a call

During an INCOMING or OUTGOING call started in hands-free mode, it is possible to switch to the private call mode using the mobile phone handset to speak and to hear the calling party in private.

a) Press button button button the conversation ; **PRIVATE** appears on the display.

- **b)** To switch back to hands-free mode using the bluetooth radio, press button 🔭 again during the private conversation ; **HANDSFREE** is shown on the display and hands-free call operation continues.
- * The above switching function may cause disconnection of the bluetooth link between the bluetooth radio and some mobile phones.

If button 📷 is pressed during the private conversation, the bluetooth connection will return automatically.

(3) Funtion of bluetooth audio player

Playing music using bluetooth audio

The bluetooth radio supports the bluetooth profile Audio Advanced Distribution Profile (A2DP). If your mobile phone or music player supports this profile then it is possible to listen to music tracks located on your bluetooth device through the bluetooth radio and speakers.

Additionally, the bluetooth radio supports the Audio Video Remote Control Profile (AVRCP).

If your bluetooth mobile phone or music player supports this profile then it is possible to advance to the next track or replay previous tracks on using the buttons on the front of the bluetooth radio your machine.

- a. Press MODE button until **BT AUDIO** is displayed.
- b. When **BT AUDIO** appears on the display, select the music player feature on your bluetooth device. And then bluetooth device play automatically to begin playback.
- c. To pauses the bluetooth audio playback, press SEL button for 2 seconds. Press the knob again for 2 seconds to resume playback.
- d. Press buttons (,) advance to the next or previous music track.
- * (a) Check your bluetooth device owner's manual for details of how to play music tracks via an external bluetooth audio system such as the bluetooth radio.
 - (b) Some bluetooth mobile phones cannot play music at all or may play music tracks in low-quality audio through the bluetooth radio.
 - (c) Some mobile phones require additional pairing to allow bluetooth audio playback.
 - (d) Information about songs (e.g. the elapsed playing time, song titles, song index, etc.) playing using bluetooth audio profile cannot be displayed on this bluetooth radio.

$\ensuremath{\textcircled{O}}$ Connecting a bluetooth music player and mobile phone simultaneously

It is possible to connect a bluetooth mobile phone and a separate bluetooth music player to the bluetooth radio at the same time. Phone calls can be sent and received using the hands-free feature while music is playing using the bluetooth audio feature.

(4) Bluetooth setting

① Setting the automatic call answer feature

If this function is selected, the bluetooth radio automatically answers all INCOMING calls. This feature enhances safety as the driver does not need to take their hands from the steering wheel to accept an INCOMING call.

Note that this feature cannot be set at different settings for each of the paired mobile phones.

a. Press button , **PHONES** is displayed.

b. Turn ountil SETTINGS is displayed.

ANSWER OFF → ANSWER 5 SECS → ANSWER 10 SEC → RETURN

c. Press SEL button until AUTO ANSWER is displayed.

- d. Press SEL button and turn 🔘 . The LCD then displays as follows :
 - \cdot ANSWER OFF = Automatic answer function is not active.
 - \cdot ANSWER 5 SEC = Automatic answers all INCOMING calls after a 5 second delay.
 - · ANSWER 10 SEC = Automatic answers all INCOMING calls after a 10second delay.
 - \cdot RETURN = Return to previous menu.
- e. After making your selection, press SEL button to store the selection.
- f. SETTINGS is then displayed for adjustment if required.
- g. If you do not wish to adjust any further bluetooth settings, press button •••• to return to the last selected mode.

② Setting calling voice volume

This function is to set the level of the mobile phone's calling voice volume to be heard through the bluetooth radio and speakers.

- a. Follow steps a. to c. of above setting below \bigcirc .
- b. When **VOICE VOL** appears on the display, press SEL button to display the current level of the calling voice. Turn
 right or left to adjust the calling voice volume as desired. This is the level the calling voice volume will be set to each time the bluetooth radio is used after the stating switch is turned off and then on again.
- c. After making your selection, press SEL button to store the selection.
- d. SETTINGS is then displayed for adjustment if required.
- e. If you do not wish to adjust any further bluetooth settings, press button 👸 to return to the last selected mode.

③ Setting the ring volume

This function is to set the level of the mobile phones ring tone volume to be heard through the bluetooth radio and speakers.

- a. After making your selection, press SEL button to store the selection.
- b. When **RING VOL** appears on the display, press the SEL button to display the current level of the ring tone. Turn pright or left to adjust the ring tone volume as desired. This is the level the ringer volume will be set to each time the bluetooth radio is used after the starting switch is turned off and then on again.
- c. After making your selection, press SEL button to store the selection.
- d. The press button 👸 to return to the last selected mode.

RADIO AND USB PLAYER (WITH BLUETOOTH) : MACHINE SERIAL NO.: #0730~



9403CD100

■ FRONT PANEL PRESENTATION

1		······· Power ON/OFF, Volume UP/DOWN button
2		······· Manual UP/DOWN Tuning, File search, SEL button
3	MODE	Mode button, Audio mute button
4	с	······ Call & Pair button
5	0	······ Call end button
6	1 DIS	······ Station preset 1 ······ Display button
7	2	······ Station preset 2
8	3 RPT RPT ····	······ Station preset 3 ······ Repeat play button
9	4 RDM	······ Station preset 4 ······ Random play button

10	5 dir- DIR- ···	 Station preset 5 Directory down button
11	6 dir+ DIR+ ·	 Station preset 6 Directory up button
12	SCAN	 Scan play button (SCAN) Best station memory (BSM) button
13	SEEK	 Auto tune up, Seek up button
14	TRACK	 Auto tune down, Track down button
15	AUX	 USB connector
16	4	 AUX IN Jack
17	MIC	 MIC hole

RADIO AND USB PLAYER (WITHOUT BLUETOOTH): MACHINE SERIAL NO.: #0730~



FRONT PANEL PRESENTATION

1		······· Power ON/OFF, Volume UP/DOWN button
2		······· Manual UP/DOWN Tuning, File search, SEL button
3	MODE	Mode button, Audio mute button
4	SEEK	······ Radio seek up button
5	SEEK	······ Radio seek down button
6	1 DIS DIS ····	······ Station preset 1 ······ Display button
7	2	······ Station preset 2
8	3 RPT RPT ···	······ Station preset 3 ······ Repeat play button
9	4 RDM	······ Station preset 4 ······ Random play button

10	5 dir- DIR- ···	Station preset 5 Directory down button
11	6 dir+ DIR+ ··	······ Station preset 6 ······ Directory up button
12	SCAN BGM	Scan play button (SCAN) Best station memory (BSM) button
13	TRACK	······ Track up button
14	TRACK	······ Track down button
15	AUX	······· USB connector
16	4	······· AUX IN Jack

GENERAL

(1) Power and volume button



① Power ON / OFF button

Press power button (1) to turn the unit on or off.

② Volume UP/DOWN control knob

Turn VOL knob (1) right to increase the volume level. Turn VOL knob (1) left to decrease the volume. After 5 seconds the display will return to the previous display mode.

③ Initial volume level set up

I-VOL is the volume level the unit will play at when next turned on. To adjust the I-VOL level, press and hold VOL button (1) for longer than 2 seconds. The current volume level displays on the display panel.

Then turn button (1) right or left to set the volume level as the I-VOL level.

④ Clock ON/OFF control

The CLOCK was default at off status. To turn CLOCK ON, press and hold VOL button (1) for longer than 2 seconds to display I-VOL, then short press VOL again, turn VOL knob while CLOCK OFF display, then the CLOCK ON will be displayed.

* Due to time tolerance, the clock display on the Audio unit might have little difference.

5 Clock adjustment

With CLOCK ON selected, press VOL knob again after CLOCK ON display, the hour will blink, turn VOL knob right or left to adjust hour. Simply press VOL again, the minute will blink, turn VOL knob to adjust minute. Then press VOL again to confirm the clock once finished.

(2) Menu Selection



This button can adjust the sound effect and other things.
 Each time you press this button (2), LCD displays as follows :

BAS \rightarrow TREB \rightarrow BAL L=R \rightarrow FAD F=R \rightarrow EQ \rightarrow LOUD ON \rightarrow BEEP 2ND

On each setting, the level can be controlled by turning TUNE knob (2). When the last adjustment is made, after 5 seconds, the display will automatically return to the previous display mode.

② Bass control

To adjust the bass tone level, first select the bass mode by pressing SEL button (2) repeatedly until BASS appears on the display panel. Then turn knob (2) right or left within 5 seconds to adjust the bass level as desired. The bass level will be shown on the display panel from a minimum of BASS-7 to a maximum of BASS+7.

③ Treble control

To adjust the treble tone level, first select the treble mode by pressing SEL button (2) repeatedly until TREB appears on the display panel. Then turn knob (2) right or left within 5 seconds to adjust the treble level as desired. The treble level will be shown on the display panel from a minimum of TREB -7 to a maximum of TREB +7.

④ Balance control

To adjust the left-right speaker balance, first select the balance mode by pressing SEL button (2) repeatedly until BAL indication appears on the display panel. Then turn knob (2) right or left within 5 seconds to adjust the balance as desired. The balance position will be shown by the bars on the display panel from BAL 10R (full right) to BAL 10L (full left).

5 Fader control

To adjust the front-rear speaker balance, first select the fader mode by pressing SEL button (2) repeatedly until FADER indication appears on the display panel. Then turn knob (2) right or left within 5 seconds to adjust the front-rear speaker level as desired. The fader position will be shown by the bars on the display panel from FAD 10F (full front) to FAD 10R (full rear).

6 EQ control

You can select an equalizer curve for 4 music types (CLASSIC, POP, ROCK, JAZZ). Press button (2) until EQ is displayed, then turn knob (2) right or left to select the desired equalizer curve. Each time you turn the knob, LCD displays as follows :

 $\mathsf{EQ}\:\mathsf{OFF}\to\mathsf{CLASSIC}\to\mathsf{POP}\to\mathsf{ROCK}\to\mathsf{JAZZ}$

When the EQ mode is activated, the BASS and TREBLE modes are not displayed.

⑦ Loud control

When listening to music at low volume levels, this feature will boost the bass and treble response. This action will compensate for the reduction in bass and treble performance experienced at low volume.

To select the loudness feature, press button (2) until LOUD is displayed, then turn knob (2) right or left to activate or deactivate loudness.

8 Beep control

To adjust the BEEP mode, first select the BEEP mode by pressing button (2) repeatedly until BEEP indication appears on the display panel. Then turn knob (2) left or right within 5 seconds to select BEEP 2ND, BEEP OFF or BEEP ON.

- BEEP 2ND : You will only hear the beep sound when the buttons are held down for more than 2 seconds.
- BEEP OFF : You can not hear the sound beep when you press the buttons.
- BEEP ON : You can hear the beep sound each time you press the buttons.

(3) Mute control

① Press and hold MUTE button (3) for over 2 seconds to mute sound output and MUTE ON will blink on the LCD. Press the button again to cancel MUTE function and resume to normal playing mode.

(4) Mode selection

- ① Repeat press MODE button (3) to switch between FM1, FM2, AM, USB, AUX, BT MUSIC.
- * If there is no USB, AUX, Bluetooth Phone connected, it would not display USB, AUX, BT when you press button (3).

RADIO

(1) Mode button



1 Repeat press MODE button to select FM1, FM2 or AM.

(2) Manual tuning button



① To manually tune to a radio station, simply turn encoder TUNE (2) left or right to increase or decrease the radio frequency.

(3) Auto tuning button





① To automatically select a radio station, simply press Seek up or Track down button.

(4) Station preset button



- In radio mode, pressing buttons (6) to (11) will recall the radio stations that are memorized. To store desired stations into any of the 6 preset memories, in either the AM or FM bands, use the following procedure :
 - a. Select the desired station.
 - b. Press and hold one of the preset buttons for more than 2 seconds to store the current station into preset memory. Six stations can be memorized on each of FM1, FM2, and AM.

(5) Preset scan (PS) / Best station memory (BSM) button



① Press BSM button (12) momentarily to scan the 6 preset stations stored in the selected band. When you hear your desired station, press it again to listen to it.

Press BSM button (12) for longer than 2 seconds to activate the Best Station Memory feature which will automatically scan and enter each station into memory.

If you have already set the preset memories to your favorite stations, activating the BSM tuning feature will erase those stations and enter into the new ones. This BSM feature is most useful when travelling in a new area where you are not familiar with the local stations.

USB PLAYER

(1) USB playback



① The unit was equipped with a front USB jack and also a rear USB Jack.

With a USB device plugged in the front USB jack, it will be detected as front USB mode. And with a USB device plugged in the rear USB jack, it will be detected as rear USB. To get to a USB mode, press MODE (3) button momentarily or insert the USB device in front or rear USB jack.

* If no mp3 or wma files in USB device, it will convert to the previous mode after display NO FILE.

(2) Track Up / Down button



① Press SEEK up (13) or TRACK down (14) to select the next or previous track. Press and hold the buttons to advance the track rapidly in the forward or backward direction.



(3) MP3 directory / File searching



 Button (2) is used to select a particular directory and file in the device. Turn button (2) right or left to display the available directories. Press button (2) momentarily when the desired directory is displayed, then turn button (2) right or left again to display the tracks in that directory. Press button (2) to begin playback when the desired file is displayed.

(4) Directory Up / Down button



- ① During MP3/WMA playback, simply press DIR- button (10) to select the previous directory (if available in the device); simply press DIR+ button (11) to select the next directory (if available in the device).
- If the USB device does not contain directories, it would play MP3/WMA tracks at 10- file when you press DIR- button (10), and play MP3/WMA tracks at 10+ file when you press DIR+ (11) button.

(5) Track Scan Play (SCAN) button



- SCAN playback : Simply press SCAN (12) button to play the first 10 seconds of each track.
- SCAN folder : Press and hold SCAN button for longer than 2 seconds to scan play the tracks in current folder.
- SCAN off : Simply press it again to cancel SCAN feature.

(6) Track Repeat Play (RPT) button



- REPEAT playback : Simply press RPT (8) button to play current track repeatedly.
- REPEAT folder : Press and hold RPT for longer than 2 seconds to repeat play the tracks in current folder.
- REPEAT off : Simply press it again to cancel REPEAT feature.

(7) Track Random Play (RDM) button



(8) ID3 v2 (DISP)



- RANDOM playback : Simply press RDM (9) button to play the tracks in the device in a random sequence.
- RANDOM folder : Press and hold RDM button for longer than 2 seconds to random play the tracks in current folder.
- RANDOM off : Simply press it again to cancel RANDOM feature.
- While a MP3 file is playing, press DISP button (6) to display ID3 information. Repeat push DISP button (6) to show directory name / file name and album name / performer / title.
- * If the MP3 disc does not have any ID3 information, it will show NO ID3.
- * USB Information and Notice
 - a. Playback FILE SYSTEM and condition allowance.
 - FAT, FAT12, FAT16 and FAT32 in the file system.
 - V1.1, V2.2 and V2.3 in the TAG (ID3) version.
 - b. Display up to 32 characters in the LCD display.
 - c. No support any of MULTI-CAED Reader.
 - d. No high speed playback but only playing with normal full speed.
 - * DRM files in the USB may cause malfunction to playback in the radio unit.
 - * The temperature below -10 Celsius, the audio unit with USB hook up would be affected to play well.

AUX OPERATION

It is possible to connect your portable media player to the audio system for playback of the audio tracks via the cab speakers.

To get the best results when connecting the portable media to the audio system, follow these steps :

- Use a 3.5 mm stereo plug cable to connect the media player headphone socket at each end as follows.
- Adjust the portable media player to approximately 3/4 volume and start playback.
- Press the MODE button (3) on the audio unit to change into AUX mode.
- The volume and tone can now be adjusted on the audio unit to the desired level.
- * The audio quality of your media player and the audio tracks on it may not be of the same sound quality as the audio system is CD Player.
- * If the sound of the media player is too low compared with the radio or CD, increase the volume of the player.
- * If the sound of the media player is too loud and/or distorted, decrease the volume of the player.
- * When in AUX mode, only the Volume, Bass, Treble, EQ and Mode functions of the audio unit can be used.

BLUETOOTH (if equipped)

1) Using a bluetooth wireless connection

- (1) Your audio unit supports bluetooth wireless technology. You can set up a wireless link with bluetooth cellular phone.
- (2) Keep PAIRING the cellular phone with audio unit in a few minutes as the phone are being switched on well enough.
- * Since this audio unit is on standby to connect with your cellular phone via bluetooth wireless technology, using this audio unit without running the engine can result battery drainage.
- $\ast\,$ This audio unit phone call reception is on standby when ignition switch is set to ACC OFF or ON.
- * The line-of-sight distance between this audio unit and your cellular phone must be 10 meters or less for sending and receiving voice and data via bluetooth wireless technology. However the transmission distance may become shorter than the estimated distance depending on the environment in use.
- * Digital Noise & Echo suppression system provides the best sound clarity with little or no distortion (Echo & side tone will happen depending on cellular phone or service network).
- * To ensure the quality of calling, you should select a proper bluetooth VR level. This audio unit has already set with the best bluetooth VR level.



1) Bluetooth icon

It will blink while establishing the bluetooth pairing. It will light after a bluetooth device connected.



② Battery icon

It indicates the battery status of the connected bluetooth device.



③ Single strength icon

It indicates the signal strength of the connected bluetooth device.

2) Pairing in hands free modes



- (1) Press and hold CALL button (4) for 2 seconds until you hear beep sound, then appears PAIR STR on the display.
- (2) For the next procedure, go to cellular phone pairing mode.
- (3) If it is in pairing status with audio unit and cellular phone, PAIRING will show on the display.
- (4) If you want to exit pairing mode, press CALL END button (5) briefly while pairing, then it will show PAIR CLR on the display.
- (5) Bluetooth Icon and PAIR OK appear on the display when pairing is successful.

3) Cellular phone pairing mode

- (1) Browse your cellular phone menu and find the connectivity or bluetooth connection section.
- (2) Select search for a new handsfree device function and allow the phone to find the mobile.
- (3) HYUNDAI should appear on your cellular phone screen.
- (4) Press connect menu among the handsfree option on your cellular phone.
- (5) The cellular phone should prompt for a pin code. Insert the pin code 1234.
- (6) The cellular phone should confirm that it has established a new paired connection.
- (7) Close the menu. The pairing is now completed. It appears PAIR FAIL on the display for 3 seconds.
- * Each cellular phone type has distinct phone menu so you may need to refer to your manufactures instruction for the correct procedure on how to connect a new bluetooth device.
- * Please retry to the pairing instruction if HYUNDAI does not appear on the cellular phone screen.
- * Please select authorized, if there is authorized menu in the menu of bluetooth connection in your cellular phone.
- * Once the bluetooth pairing is completed between your cellular pone and this audio unit, the both units will be automatically recognized on its paring and when you turn on the key in your car even though this audio unit is turned off.
- * This audio unit can store up to 6 phones pairings. If the memory is full, the first stored paired phone will be deleted.
- * The connecting priority will be given to the last connected cellular phone.
- * If you want to change the connecting priority, try to connect this audio unit from the cellular phone.

4) Bluetooth connection and disconnection



- (1) When established bluetooth connection between this audio unit and the cellular phone, bluetooth icon on the display appears and then the display shows HF/AV CONN when handsfree & AV profile connected.
- (2) To disconnect bluetooth link

Press and hold CALL END button (4) for 2 seconds, it shows DIS CON and disappears bluetooth Icon on the display.



(3) To disconnect bluetooth link

Press CALL button (3) briefly, it blinks bluetooth Icon on the display while bluetooth is being connected. If the connection is completed, it appears bluetooth Icon on the display.

- When your cellular phone battery is at low charge, the bluetooth connection may occasionally be lost. To maintain good connectivity ensure that your phone battery is adequately charged.
- * In case of failure of bluetooth pairing :
 - Delete item in paired list on your phone.
 - Reset both phone by power off/on and the audio unit by ACC off/ on.
- * Connecting priority of handsfree profile is higher than headset profile.
- * The headset mode does not support caller ID, reject call and call Transfer.

5) Using the audio unit as a handsfree device

(1) When the audio unit is ringing, it shows CALL and follows with the phone number ********* on the display.



(2) To accept call

Press CALL button (4), it appears ANSWER CALL and follows TALKING on the display.

(3) To end call

To end call, press CALL END button (5), it appears REJECT on the display.

* If reject call is activated in your phone, then your cellular phone does not support reject call function.

6) Audio transfer between the audio unit and phone

The audio transfer function is for switching the call from the audio unit to the cellular phone for private conversation.



- Press CALL button (4) briefly during conversation, it appears CALL TRANS on the display. To switch back to the audio unit, press button
 briefly during private conversation, then it appears CALL TRANS on the display again.
- * This function will be a cause of disconnection of bluetooth link in some nokia phones, but you do not worry just press button (4) during private conversation, then switch back to the audio unit automatically.
- * The quality of calling between cellular phone and audio unit is better than calling between one audio unit and another one.

7) Last call number dialing



(1) Press CALL button (4) briefly, it appears CALL TO, then simply press CALL button once again, it would make the last call with phone number display on LCD.

If Reject call is activated in your phone, then your cellular phone does not support Reject Call function.

If you are using SAMSUNG phone, then you may need to press once more send button. First press button shows phone contact list in your phone, then second press make the last call.

8) To make a call by cellular phone

The audio transfer function is for switching the call from the audio unit to the cellular phone for private conversation.

- (1) The audio unit activated automatically when you make a call by cellular phone.
- (2) When you make a call processing by cellular phone, it shows CALLING on the display.
- (3) When you receive a call, the phone number ******** appears on the display.

9) Using the audio unit as bluetooth music

The audio unit supports A2DP (Audio Advanced Distribution Profile) and AVRCP (Audio Video Remote Control Profile), and both profiles are available to listen music at the audio unit via cellular phone which is supporting the two profiles above.

- (1) To play music, search the menu on your cellular phone as below :
 i.e : Menu → File manager → Music → Option → Play via bluetooth.
 It appears BT MP3 on the display.
- (2) During BT MP3 playing, you could select the previous or next track by pressing SEEK up or TRACK down button on audio unit or operate via your cellular phone.
- (3) To stop music, press button (5) briefly and it will automatically switch into the previous mode.
- (4) To resume music playing, press the play button on your cellular phone.
- * This function maybe different depends on cellular phone. Please follow the cellular phone menu. Some kinds of phone need to pair once more for bluetooth MP3 connection.
- * This function will be caused to disconnect A2DP, AVRCP depends on cellular phone.
- * Information about songs (e.g.: the elapsed playing time, song title, song index, etc.) cannot be displayed on this audio unit.

■ RESET AND PRECAUTIONS

1) Reset function

Interfere noise or abnormal compressed files in the MP3 disc or USB instrument may cause extraordinary operation (or unit frozen/locking up). It's strongly recommended to use appropriate USB storage not cause any malfunction to the audio unit. In the unlikely event that the player fails to operate correctly, try out to reset unit by any of following two methods.

(1) press and hold



simultaneously for about 5 seconds. (without Bluetooth)

Press and hold SIR simultaneously for about 5 seconds. (with Bluetooth)

- (2) Take out the fuse for the audio system in the vehicle once and then plug again.
- * It will be necessary to re-enter the radio preset memories as these will have been erased when the microprocessor was reset.

After resetting the player, ensure all functions are operation correctly.

2) Precautions

When the inside of the car is very cold and the player is used soon after switching on the heater, moisture may form on the disc or the optical parts of the player and proper playback may not be possible.

If moisture forms on the optical parts of the player, do not use the player for about one hour. The condensation will disappear naturally allowing normal operation.

- (1) Operation voltage : 9~32 volts DC, negative
- (2) Output power : 40 watts maximum (20 watts x 2 channels)
- (3) Tuning range

Area	Band	Frequency range	Step
USA	FM	87.5~107.9 MHZ	200K
	AM	530~1710 KHZ	10K
EUROPE	FM	87.5~108.0 MHZ	50K
	AM	522~1620 KHZ	9K
ASIA	FM	87.5~108.0 MHZ	100K
	AM	531~1602 KHZ	9K
	FM	87.5~107.9 MHZ	100K
	AM	530~1710 KHZ	10K

- AREA Selection :
 - To select an area, press and hold related buttons at FM1 band for about 3 seconds.
 - USA Area: Press and hold mode + 1DIS buttons for 3 seconds
 - EUROPE Area: Press and hold mode + 2 buttons for 3 seconds
 - ASIA Area: Press and hold mode + 3RPT buttons for 3 seconds
 - LATIN Area: Press and hold mode + 4RDM buttons for 3 seconds.
- (4) USB version : USB 1.1
- (5) Bluetooth version : V2.1
- (6) Bluetooth supported profile :
 - A2DP : Advanced Audio Distribution Profile
 - AVRCP : Audio/Video Remote Control Profile
 - HFP : Hands-Free Profile

1. SUGGESTION FOR NEW MACHINE

- 1) It takes about 100 operation hours to enhance its designed performance.
- 2) Operate according to below three steps and avoid excessive operation for the initial 100 hours.

Service meter	Load
Until 10 hours	About 60%
Until 100 hours	About 80%
After 100 hours	100%

- * Excessive operation may deteriorate the potential performance of machine and shorten lifetime of the machine.
- 3) Be careful during the initial 100 hours operation.
- (1) Check daily for the level and leakage of coolant, engine oil, hydraulic oil and fuel.
- (2) Check regularly the lubrication and fill. Grease daily all lubrication points.
- (3) Tighten bolts.
- (4) Warm up the machine fully before operation.
- (5) Check the gauges during operation.
- (6) Check if the machine is operating normally during operation.
- 4) Replace followings after initial operation hours.

Checking items	Hours
Engine oil and filter	
Fuel filter element	
Fuel pre-filter	
Transmission oil and filter	250
Axle oil (front and rear)	
Hydraulic oil return filter	
Pilot line filter element	



2. CHECK BEFORE STARTING THE ENGINE

- 1) Make sure that the steering frame lock bar is stored in the unlocked position.
- A The steering frame lock bar must be removed in order to steer the machine.
- 2) Look around the machine and under the machine to check for loose nut or bolts, collection of dirt, or leakage of oil, fuel or coolant and check the condition of the work equipment and hydraulic system. Check also loose wiring, and collection of dust at places which reach high temperature.
- * Refer to the daily check on the chapter 6, Maintenance.
- Adjust seat to fit the contours of the operator's body for the pleasant operation.
- Make sure that the machine is equipped with a lighting system that is adequate for the job conditions. Ensure that all lights are in proper working condition.
- 5) Adjust the rear view mirror.
- 6) Make sure that there are no personnel in the area before you start the engine. Make sure that there are no personnel in area before you move the machine. Make sure that there are no personnel on the machine, underneath the machine, or around the machine.
- ▲ If a warning tag is attached to the starting switch or to the controls, do not start the engine. Also, do not move any controls.



3. STARTING AND STOPPING THE ENGINE

1) CHECK INDICATOR LIGHTS

- (1) Check if the parking brake switch is ON.
- (2) Check if the gear selector lever is in neutral position.
- (3) Check if the pilot cut off switch is OFF.
- (4) Turn the key to the ON position, and check followings.
- · Cluster
- If all the lamps light ON after sounding buzzer for 3 seconds.
- * If the lamps do not light or the buzzer is not sounded, check disconnection of wire.
- ② Only below lamps will light ON and all the other light will be turn OFF after 3 seconds.
 - Charging warning lamp (1)
 - Engine oil pressure warning lamp (2)
 - Brake fail warning lamp (3)
- · Monitor
- ① The buzzer sounds for 3 seconds with HYUNDAI logo on monitor.
- ② If the ESL mode is set to the enable, enter the password to start engine.
- ③ If the password has failed 5 times, please wait 30 minutes before re-attempting to enter the password.



2) STARTING ENGINE IN NORMAL TEMPERATURE

- * Sound the horn to warn the surroundings after checking if personnel or obstacles are in the area.
- (1) Check if the parking brake is locked (with the parking switch ON).
- (2) Check if the gear selector lever is in the neutral position.
- (3) Check if the pilot cut off switch is locked (with the switch OFF)
- (4) Turn the starting switch to START position to start the engine.
- Do not crank the engine for more than 20 seconds. If the engine does not start, allow the starter to cool for about 2 minutes before attempting to start the engine again.
- (5) Release the starting switch instantly after the engine starts to avoid possible damage to the starting motor.
- * Refer to the START PROCEDURE on the page 0-12.



3) STARTING ENGINE IN A COLD WEATHER

- Sound horn to warn surroundings after checking if there are obstacles in the area.
- * Replace the engine oil, coolant and fuel referring to recommended oils at page 6-9.
- Fill the anti-freeze solution to the coolant as required.
- If you turn ON the starting switch, the fuel warmer is automatically operated to heat the fuel by sensing the coolant temperature.
- Check if the parking brake is locked (with the parking switch ON).
- (2) Check if the gear selector lever is in the neutral position.
- (3) Check if the pilot cut off switch is locked (with the switch OFF)
- (4) Turn the starting switch to ON position, and wait 1~2 minutes. More time may take according to ambient temperature.
- (5) Start the engine by turning the starting switch to START position after the preheater pilot lamp OFF.
- (6) After the preheater pilot lamp goes out, wait 5 minutes more for heating of fuel heater.
- If the engine does not start, allow the starter to cool for about 2 minutes before attempting to start the engine again.
- (7) Release starting switch immediately after starting engine. The starting switch will automatically return to the ON position.
- * After engine started, the preheating function is actuated to reduce the white smoke.
- * Before the warming-up operation is completed, do not operate the equipment.
- * Operate machine at less than normal loads and at slow idle speed, right after engine warming-up.
- * Run the engine for 10~15 minutes at low idle when the ambient temperature is below -15°C.



4) INSPECTION AFTER ENGINE START

Inspect and confirm the following after engine starts.

- (1) Is the level gauge of hydraulic oil tank in the normal level?
- (2) Are there leakages of oil or water?
- (3) Are all the warning lamps (1-7) OFF?
- (4) Check the following after warming up operation.
- Is the indicator of water temperature gauge (8) in the operating range?
- ② Is the indicator of transmission oil temperature gauge (9) in the operating range?
- ③ Is the engine sound and the color of exhaust gas normal?
- 4 Are the sound and vibration normal?
- * Do not increase engine speed quickly after starting, it can make damage engine or turbocharger.
- If there are problems in the control panel, stop the engine immediately and correct problem as required.

5) TRANSMISSION COLD STARTING

- At an oil temperature in the shifting circuit < -12°C, the transmission must be warmed-up for some minutes.
- (2) This must be carried out in neutral with an increased engine speed.
- (3) Until this oil temperature is reached, the electronics remains in neutral, and the symbol of the cold start phase will be indicated on the display.
 Indication on the display : **
- (4) After the indication on the display is extinguished, the full driving program can be utilized out of NEUTRAL.





Symbol	Meaning	Remarks
LF, LR	Limp home gear	-
**	Oil temperature too low, no gear available	Warm up engine/transmission
WS	Warning sump temperature	Alternate between WS and actual gear/direction while driving, in neutral only displayed WS if no fault is detected * Cool down transmission
WT	Warning torque converter temperature	Alternate between WS and actual gear/direction while driving, in neutral only displayed WS if no fault is detected * Cool down transmission

* Transmission warning

6) TO STOP THE ENGINE

- If the engine is abruptly stopped before it has cooled down, engine life may be greatly shortened. Consequently, do not abruptly stop the engine apart from an emergency.
- In particularly if the engine has overheated, do not abruptly stop it but run it at medium speed to allow it to cool gradually, then stop it.
- (1) Place the gear selector lever in neutral.
- (2) Push the parking brake switch to the ON position.
- (3) Run the engine for five minutes at low idle with no load.
- (4) Return the key of starting switch to the OFF position.
- (5) Remove the key to prevent other people using the machine.
- (6) Push the pilot cut off switch to the OFF position.
- (7) Lock the cab door.



4. WARMING-UP OPERATION

- ** The most suitable temperature for the hydraulic oil is about 50°C (112°F). It can cause serious trouble in the hydraulic system by sudden operation when the hydraulic oil temperature is below 25°C (77°F). The temperature must be raised to at least 25°C (77°F) before starting work.
- 1) Run the engine at low idling for 5 minutes.
- 2) Speed up the idling and run the engine at midrange speed.
- 3) Push the pilot cut off switch to the ON position.
- 4) Lift the boom slightly and extend the bucket cylinder to the stroke end to relieve hydraulic pressure.
- * Do not leave hydraulic pressure relieved for more than 30 seconds.
- 5) Shorten the bucket cylinder to the stroke end to relieve hydraulic pressure.
- * Do not leave hydraulic pressure relieved for more than 30 seconds.
- 6) Repeat the procedure 4)-5) several times until warm-up operation is completed.



5. OPERATION OF THE WORKING DEVICE

- * Confirm the operation of control lever and working device.
- 1) Control lever operates the boom and the bucket.
- 2) When you release the control lever, control lever returns to neutral position automatically.
- 3) When the control lever operates to the position of boom float, boom kick out and bucket leveler ; these function is completed, then the control lever returns to the neutral position.
- * Control lever

Boom lower (1)

Push the control lever forward in order to lower the boom.



Boom raise (2)

Pull the control lever backward in order to raise the boom.

Bucket roll back (3)

Move the control lever toward the left in order to tilt the bucket back-ward.

√*D*>=

Bucket dump (4)

Move the control lever toward the right in order to dump a load from the bucket.



Boom float (5)

Push the control lever forward into the detent.

The boom will lower to the ground. The boom will float along the contour of the ground.



6. TRAVELING OF THE MACHINE

1) BASIC OPERATION

(1) Traveling posture

Lift the boom so that the bucket is placed 40-50cm above the ground.



(2) Traveling operation

When warm-up operation is completed after the engine is started, move the machine according to the following procedure.

- ① Push the pilot cut off switch to the ON position.
- 2 Release the parking brake.
- ③ Put the gear selector lever in the 1st stage of forward or backward direction and press gently the accelerator pedal to move the machine.



(3) Changing direction and speed

- ① The gear selector is designed for the mounting on the left side of the steering column.
- ② The positions (speeds) 1 to 4 are selected by a rotary motion, the driving direction Forward (F)-Neutral (N)-Reverse (R) by tilting the gear selector lever.
- ③ A neutral lock is installed as protection against inadvertent drive off.
 - Position N Gear selector lever blocked in this position
 - Position D Driving
- ④ When doing digging or dumping work, run the machine in the 1st or 2nd speed.



- When traveling at high speed, do not abruptly decelerate by using the transmission lever, to slow down instead press the brake pedal.
- When changing direction, check beforehand there is no obstacle in the direction you will be headed.
- * Avoid changing direction at high speed.

(4) Turning the machine

- ① Turn the machine by moving the steering wheel into the desired direction.
- ② You can turn the machine to the left or right by 40 degree.
- * Do not turn the machine abruptly when traveling at high speed and avoid turn on a slope.
- ▲ Steering does not function with engine OFF.

(5) Precautions when driving

- If the monitor warning lamp lights up, put the gear selector lever in the neutral position and stop the machine. Stop the engine after running it at low idling. Then resolve any problems regarding operation of the machine.
- ② When operating the machine, if the load is lighten rapidly, the speed of the machine will increase. So, be careful.
- ③ When the machine travels on uneven ground, keep the machine traveling at low speed.







(6) Stopping the machine

- 1 Press the brake pedal to stop the machine.
- O Put the gear selector lever in the neutral position.
- ③ Push the parking brake switch to the ON position.



4 Lower the bucket to the ground.



- 5 Push the pilot cut off switch to the OFF position.
- $\ast\,$ When parking on a slope, block the tires.



- (7) Stopping engine
- If the engine is abruptly stopped before it has cooled down, its service life may be shortened. Avoid sudden stop except an emergency.
- When the engine is overheated, do not stop immediately. Run the engine at a mid range speed to allow it to cool down, then stop it.
- ① Check if the parking brake switch is ON.
- ② Check if the gear selector lever is in the neutral position.
- ③ Check if the pilot cut off switch is OFF.
- ④ Run the engine at low speed without operating the equipment for about 5 minutes.
 Turn the starting key to the OFF position and remove the key.

(8) Checks after the engine stopped

- ① Check the leakage of oil and water, the work equipment and the exterior of the machine.
- 2 Refill the fuel tank.
- ③ Remove any debris inside of the engine room and attached to the machine.



2) TRAVELING ON A SLOPE

- (1) Never travel down a slope in neutral.
- (2) Lower the bucket 20-30 cm (1 ft) to the ground so that it can be used as a brake in an emergency.
- (3) If the machine starts to slide or loses stability, lower the bucket immediately and brake the machine.
- (4) When parking on a slope, use the bucket as a brake and place blocks behind the tires to prevent sliding.
- Machine cannot travel effectively on a slope when the oil temperature is low. Do the warming-up operation when it is going to travel on a slope.
- * Be careful when working on slopes. It may cause the machine to lose its balance and turn over.


7. EFFICIENT WORKING METHOD

1) GENERAL

- (1) Lift the bucket about 40-50 cm (2 ft) above the ground to ensure safety and to gain a good range of view.
- (2) Clear the jobsite and level the ground.
- (3) Be careful that excessive force is not applied to the bucket.
- (4) When handling hard materials, use bucket teeth or bolt on cutting edge.
- (5) When doing dumping work, put the control lever in the DUMP position, then return it to a former state. Repeat this procedure until the work is finished.
- (6) Position the machine with its back against the wind so that dust does not get into the engine.
- (7) Check if the proper bucket is used for the work. If the capacity of the bucket exceeds that of the machine, the machine's service life may be shortened.



2) EXCAVATION WORK

(1) Shovel work

As the machine loads on the bucket with traveling, tires may start to slip because of heavy load. Then lift the bucket slightly to reduce load.

- Keep the bucket shovel parallel to the ground (If the bucket is pushed in a non-horizontal position, power may be reduced, and the bucket cannot dig deeply into the heap of soil).
- ② When the bucket is sufficiently deep into the pile, advance the machine with the control lever pulled down. And by placing the control lever in the bucket roll-back position, fill the bucket with soil.

③ When it is difficult to dig into the soil, move the bucket control lever forward and backward to move the bucket teeth up and down.

If the machine operates with its front tires lifted, its driving force will deteriorate and excessive force will be applied to the rear tires. Avoid operating in that posture.









(2) Excavation on level ground

Advance the machine with the bucket lowered slightly and make sure that the bucket is evenly loaded on both sides.

1 Lower the bucket edge slightly.



⁽²⁾ Advance the machine and lift the bucket using the bucket control lever to dig out the soil.



- ③ Advance the machine while controlling the depth of digging with the control lever.
- * Do not press the bucket heavily into the ground. It may damage its driving force.
- * Use the bucket suitable to the working condition.
- When excavating, prevent the excavation force from applying only one side of the bucket.



3) LEVELING

- (1) Load the bucket with soil and dump gradually the soil while driving backward.
- (2) After dumping the soil, move backward with the bucket lowered to the ground to level the ground.

Load the bucket with soil and place the bucket in (3) the horizontal position.

Then put the control lever in the BOOM FLOAT position and move backward.

* Make sure that the machine moves always backward when doing leveling work.

4) TRANSPORTATION

- * Make sure that the traveling path is always cleared.
- When transportating material, lift the bucket 40-50 cm above the ground.





5) COMPACTION

When operating, keep the bottom of the bucket horizontal to the ground.

* Do not work with the bucket set in the DUMP position.



6) LOADING

Maximum efficiency can be attained by carrying out work in such a way that the swinging angle and the traveling distance are kept as small and short as possible in accordance with the terrain.

(1) I method

- After digging out the soil, move backward and position the dump truck between the heap of soil and the machine to load the soil into the truck.
- ② This is the fastest and most efficient way to load material.
- * The ground of the jobsite should be always level and do not swing or step on a brake pedal abruptly with the boom raised.



(2) V method

- Park the truck at an angle of 60 degrees toward the machine. After digging out, drive backward and position the machine at a right angle with the truck and load the truck with the soil.
- ② Position the machine so that the soil can be dumped in the center of the truck.

If the length of the truck is more than double the width of the bucket, perform the dumping work from forward to backward.

- ③ Move the control lever to the right and dump the bucket.
- ④ Shake the bucket to throw off the soil stuck inside. Move the bucket control lever to the left and right and attach the bucket to the stopper.
- ⑤ Shake the bucket before setting it to the DUMP position so that loaded materials are evenly distributed inside the bucket. This will prevent materials from slipping back when the bucket is placed in the DUMP position.





7) PRECAUTIONS DURING OPERATION

(1) Permissible water level

- ① Do not work in water or damp ground deeper than the permissible depth (Up to lower part of the axle housing).
- ② After the work is completed, grease parts which has been immersed in water.



(2) When the brake does not operate

- ① If the machine does not stop even though the brake pedal is applied, use the parking brake.
- * After using the parking brake as an emergency brake, ask Hyundai dealer to check complete brake system.



(3) Precautions when driving on a slope

 When turn on a slope, lower the work equipment to lower its center of gravity. Avoid turn on a slope if possible.

2 When traveling down a slope

- a. If the main brake is used to often when traveling down a slope, it may be overheated and damaged. So put the transmission lever in the low speed position and use the engine as a brake.
- b. If there is a mismatch of speed, torque converter oil temperature may be overheated. Set the speed in 1st speed position to allow the temperature to drop.
- c. When the gauge does not move into the green range at the 1st speed, stop the machine and put it in neutral. Run the engine at a mid range speed until the gauge moves into the green range.

③ When the engine stops

If the engine stops on a slope, press the parking brake switch immediately and lower the work equipment to stop the machine.

(4) Precautions when traveling

Do not travel a long distance at high speed. It may overheat tires and cause premature damage. If it is necessary to travel a long distance at high speed, observe the following.

- Comply with the regulations concerning this machine to ensure safety.
- 0 Do the pre-inspection before starting off.
- ③ As the optimum air pressure of tire and optimum driving speed is different according to the kinds of tires and road conditions, consult Hyundai dealer or tire distributor.
- ④ Check the air pressure of tire before driving.
- ⑤ After 1 hour driving, stop for 30 minutes to check any abnormality of tires and other parts, and level of oil and coolant.
- (6) Travel with the bucket empty.

8. ADJUSTMENT OF THE WORK EQUIPMENT

The bucket can be adjusted to a height desired by using the boom kick-out device.

- ▲ Park the machine on level ground and block the tires to prevent sudden movement of the machine.
- A Press the parking brake switch.
- ▲ Fix the front and rear frames by using the safety lock bar.
- ▲ Do not work underneath the work equipment.

1) ADJUSTMENT OF THE BOOM KICKOUT

(1) Lift kickout position

To set the lift kickout, raise the bucket to the desired position above the midway point (if boom is placed at below midway point, boom up position setting is not possible). Then depress the top of switch for 2~3 seconds. The boom will return to the programmed position when the raise detent is activated and the boom is below the kickout position.

(2) Lower kickout position

To set the lower kickout, lower the bucket to the desired position below the midway point (if boom is placed at above midway point, boom down position setting is not possible). Then depress the top of switch for 2~3 seconds. The boom will return to the programmed position when the float detent is activated and the boom is at least a foot above the kickout position.

(3) Bucket leveler position

To set the bucket leveler, roll back the bucket to the desired position. Then depress the bottom of switch for 2~3 seconds. The bucket will return to the programmed position when the roll back detent is activated and the bucket is below the leveler position.





9. OPERATION IN THE SPECIAL WORK SITES

1) OPERATION THE MACHINE A COLD WEATHER

- (1) Use proper engine oil and fuel for the weather.
- (2) Fill the required amount of antifreeze in the coolant.
- (3) Refer to the starting engine in cold weather. Start the engine and extend the warming-up operation.
- (4) Be sure to open the heater cock when using the heater.
- (5) Always keep the battery completely charged.
- * Discharged batteries will freeze more easily than fully charged.
- (6) Clean the machine and park on the wood plates.

2) OPERATION IN SANDY OR DUSTY WORK SITES

- Inspect air cleaner element frequently. Clean or replace element more frequently, if warning lamp comes ON and buzzer sounds simultaneously, regardless of inspection period.
- (2) Inspect radiator frequently, and keep cooling fins clean.
- (3) Prevent sand or dust from getting into fuel tank and hydraulic tank during refilling.
- (4) Prevent sand or dust from penetrating into hydraulic circuit by tightly closing breather cap of hydraulic oil tank. Replace hydraulic oil filter frequently.
- (5) Keep all lubricated part, such as pins and bushings, clean at all times.
- (6) If the air conditioner and heater filters clogged, the heating or cooling capacity will drop. Clean or replace the filters more frequently.





3) SEA SHORE OPERATION

- (1) Prevent ingress of salt by securely tightening plugs, cocks and bolts of each part.
- (2) Wash machine after operation to remove salt residue.

Pay special attention to electrical parts and hydraulic cylinders to prevent corrosion.

(3) Inspection and lubrication must be carried out more frequently.

Supply sufficient grease to replace all old grease in bearings which have been submerged in water for a long time.



10. STORAGE

Maintain the machine taking care of following to prevent the deterioration of machine when storing the machine for a long time, over 1 month.

- 1) CLEANING THE MACHINE Clean the machine. Grease each lubrication part.
- 2) LUBRICATION POSITION OF EACH PART Change all oil.
- * Be particularly careful when you reuse the machine.

As oil can be diluted during storage.

Apply an anticorrosive lubricant on the exposed part of piston rod of cylinder and in places where the machine rusts easily.

3) MASTER SWITCH

Turn OFF the master switch and store the machine.

4) Be sure to mix anticorrosive antifreezing solution in the radiator.

5) PREVENTION OF DUST AND MOISTURE

Keep machine dry. Store the machine setting wood on the ground.

- * Cover exposed part of piston rod of cylinder.
- * Lower the bucket to the ground and set a support under tires.



- 10 Boom and bucket connecting pin (2EA)
- 11 Bucket link connecting pin (2EA)
- 12 Boom cylinder pin (frame side, 2EA)



6) DURING STORAGE

Start engine and move the machine and working equipment once a month and apply lubrication to each part.

- * Check the level of engine oil and coolant and fill if required when starting engine.
- * Clean the anticorrosive on the piston rod of cylinder.
- * Operate the machine such as traveling, turning, and work equipment operation to make sure enough lubrication of all functional components.



*** BATTERY**

- ① Once a month, start the engine for 15 minutes (or use a charger) to charge the battery.
- ② Every 2 months, check the battery voltage and keep battery voltage over 25.08V.
- ③ If the machine stock period is over 6 months, disconnect the battery negative (-) terminal.

5. TRANSPORTATION

1. ROAD TRAVELING

If it is necessary to travel on a road, observe the followings.

- 1) Comply with regulations regarding this machine for the sake of safety.
- 2) Perform daily inspection before starting the machine.
- 3) Check the air pressure of tires and traveling speed limitations.
 - Air pressure : See page 6-29.
 - Maximum speed : 38.1 km/hr (23.7 mph)
- 4) When traveling for a long distance, stop every hour or every 40 km (25 mile) to allow tires and other components to cool down and check any abnormality.
- 5) Drive with the bucket empty.
- Travel at a mid-range speed and be careful to drive within the limited speed when driving on a public road.



2. PREPARATION FOR TRANSPORTATION

- 1) When transporting the machine, observe the various road rules, road transportation vehicle laws and vehicle limit ordinances, etc.
- 2) Make sure the cooling system has proper antifreeze if moving machine to a cold climate.
- 3) Select proper trailer after confirming the weight and dimension from the page 2-2~2-5.
- Check the whole route such as the road width, the height of bridge and limit of weight and etc., which will be passed.
- 5) Get the permission from the related authority if necessary.
- Overall width Overall beight Overall length Dverall length
- 6) Prepare gangplank for safe loading referring to the below table and illustration.

А	В
1.0	3.65 ~ 3.85
1.1	4.00 ~ 4.25
1.2	4.35 ~ 4.60
1.3	4.75 ~ 5.00
1.4	5.10 ~ 5.40
1.5	5.50 ~ 5.75



3. LOADING THE MACHINE

- 1) Load and unload the machine on a flat ground.
- 2) Use the gangplank with sufficient length, width, thickness and gradient.
- 3) Move slowly and carefully when the machine is on the gangplank.

Do not change the direction of the machine while it is on the gangplank.



- 4) Do the following after loading the machine to the trailer.
- (1) Lower the working equipment gently after the location is determined.
- * Place rectangular timber under the bucket cylinder to prevent the damage of it during transportation.
- A Do not operate any other device when loading.
- A Balance the load.



4. FIXING THE MACHINE

- 1) Fix front and rear frame by linking safety lock bar.
- 2) Push the parking brake switch.



- 3) Push the pilot cut off switch to the OFF position to prevent the hydraulic system from operating.
- 4) Stop the engine, turn the starting switch off and remove the key.



5) Secure all locks.



6) Block the tires and fix firmly with wire rope or chain to prevent the machine from moving during transportation.



5. LOADING AND UNLOADING BY CRANE

- 1) Check the weight, length, width and height of the machine referring to chapter 2, Specification when you are going to hoist the machine.
- 2) Use long wire rope and stay to keep the distance with the machine as it should avoid to touch with the machine.
- 3) Put a rubber plate contact with wire rope and machine to prevent damage.
- 4) Place crane on the proper place.
- 5) Install the wire rope and stay like the illustration.
- A Make sure wire rope is proper size.
- Place the safety lock bar and pilot cut off switch to the OFF position to prevent the machine moving when hoisting the machine.
- ▲ The wrong hoisting method or installation of wire rope can cause damage to the machine.
- ▲ Do not load abruptly.
- ▲ Keep area clear of personnel.
- ▲ Attach two wire ropes to the rear of the machine. Attach two wire ropes to the front of the machine. Connect the four wire ropes.



6. TOWING THE MACHINE

- Personal injury or death could result when towing a disabled machine incorrectly.
- ▲ Block the machine to prevent movement before releasing the brakes. The machine can roll free if it is not blocked.

Except for an emergency, do not tow this machine. If it is inevitable to tow this machine, observe the following.

1) GENERAL

 Parking brake cylinder of the machine is operated by the spring force and released by hydraulic pressure.

If the engine does not operate, the brake will be operated to stop the machine.

- (2) When the machine is towed move it for a repair to nearby place at the speed less than 2 km/hr (1.2 mph). Transport it on a trailer, if it has to be moved for a long distance.
- (3) When the steering device and the brake of the machine to be towed can not be operated, transport by trailer.
- A Be careful when towing.
- A Be careful that the brake will not work if there is any disorder in the braking system.
- (4) When you tow the machine from the front, attach the tow line to the tow eyes on the front frame (1).

When you tow the machine from the rear, use the tow rear eyes provided for lift & tie (2).

(5) Do not use a chain for pulling a disabled machine. A chain link can break. This may cause personal injury. Use a wire rope cable with ends that have loops or rings. Place an observer in a safe position in order to watch the pulling procedure. The observer can stop the procedure, if necessary. The procedure should be stopped if the cable starts to break. Also, stop the procedure if the cable starts to unravel. Stop pulling whenever the towing machine moves without moving the towed machine.



- (6) Keep the tow line angle to a minimum. Do not exceed a 30 degree angle from the straight ahead position.
- (7) Quick machine movement could overload the tow line or the tow bar. This could cause the tow line or the tow bar to break. Gradual, steady machine movement will be more effective.
- (8) Normally, the towing machine should be as large as the disabled machine. Make sure that the towing machine has enough brake capacity, enough weight, and enough power. The towing machine must be able to control both machines for the grade that is involved and for the distance that is involved.
- (9) You must provide sufficient control and sufficient braking when you are moving a disabled machine downhill. This may require a larger towing machine or additional machines that are connected to the rear of the disabled machine. This will prevent the machine from rolling away out of control.
- (10) All situation requirements cannot be listed. Minimal towing machine capacity is required on smooth, level surfaces. On inclines or on surfaces in poor condition, maximum towing machine capacity is required.
- (11) When any towed machine is loaded, this machine must be equipped with a brake system that is operable from the operator compartment.
- * Consult your HYUNDAI dealer for the equipment that is necessary for towing a disabled machine.

2) WHEN THE ENGINE WORKS

(1) When the transmission system or steering wheel is workable and the engine is running, the machine can be towed only for a short distance.

For example, pull the machine out of mud or pull the machine to side of the road.

(2) The operator of the towed machine should turn the steering wheel into the direction in which the machine is towed.

3) WHEN THE ENGINE DOES NOT WORK

When towing the machine with the engine stopped, do it in the following order.

(1) The transmission oil does not lubricate the system, so remove the front and rear drive shafts.

(2) Loosen the steering cylinder as the steering operation is not workable.

Even if the brake is in good condition, the brakes can only be used a limited number of times.

There is no change in the operating force for the brake pedal, but the braking force is reduce each time the pedal is depressed.

- (3) The parking brake is activated by spring and released by hydraulic pressure. If the engine does not work, the brake will be activated.
- 1 Release the screw cap(1) and unscrew.
- ② Release the lock nut(2) and turn the adjusting screw(3) with socket wrench(4) manually counter-clockwise until the brake disc is free.
- (4) Connect firmly between the traction machine and the towed machine.

Position each traction machine at the front and rear of the machine to be towed.









1. INSTRUCTIONS

1) INTERVAL OF MAINTENANCE

- (1) You may inspect and service the machine by the period as described at page 6-10 based on service meter of monitor.
- (2) Shorten the interval of inspect and service depending on site condition. (Such as dusty area, quarry, sea shore and etc.)
- (3) Practice the entire related details at the same time when the service interval is doubled.
 For example, in case of 250 hours, carry out all the maintenance 「each 250 hours, each 100 hours and daily service」 at the same time.



2) PRECAUTION

- (1) Start maintenance after you have the full knowledge of machine.
- (2) The cluster and monitor installed on this machine do not entirely guarantee the condition of the machine.

Daily inspection should be performed according to chapter 6, Maintenance.

- (3) Engine and hydraulic components have been preset in the factory.Do not allow unauthorized personnel to reset them.
- (4) Ask to your local dealer or Hyundai for maintenance advise if unknown.
- (5) Drain the used oil and coolant in a container and handle according to the method of handling for industrial waste to meet with regulations of each province or country.



3) PROPER MAINTENANCE

- (1) Replace and repair of parts
 It is required to replace the wearable and consumable parts such as bucket tooth, cutting edge, filter and etc., regularly.
 Replace damaged or worn parts at proper time to keep the performance of machine.
- (2) Use genuine parts.
- (3) Use the recommended oil.
- (4) Remove the dust or water around the inlet of oil tank before supplying oil.
- (5) Drain oil when the temperature of oil is warm.
- (6) Do not repair anything while operating the engine.Stop the engine when you fill the oil.
- (7) Relieve hydraulic system of the pressure by opening of breather when repairing the hydraulic system.
- (8) Confirm if the cluster is in the normal condition after completion of service.
- (9) For more detail information of maintenance, please contact local Hyundai dealer.
- * Be sure to start the maintenance after fully understand the chapter 1, Safety hints.

4) RELIEVING THE PRESSURE IN THE HYDRAULIC SYSTEM

- Spouting of oil can cause the accident when loosening the cap or hose right after the operating of the machine as the machine or oil is on the high pressure on the condition.
 Be sure to relieve the pressure in the system before repairing hydraulic system.
- (1) Place the machine in parking position, and stop the engine.



(2) Rotate the cap nut counter-clockwise by hand and push the rod to release the air pressure.



5) PRECAUTION WHEN INSTALLING HYDRAULIC HOSES OR PIPES

- Be particularly careful that the joint of hose, pipe and functioning item are not damaged. Avoid contamination.
- (2) Assemble after cleaning the hose, pipe and joint of functioning item.
- (3) Use genuine parts.
- (4) Do not assemble the hose in the condition of twisted or sharp radius.
- (5) Keep the specified tighten torque.

6) PERIODICAL REPLACEMENT OF SAFETY PARTS

- These are the parts which the operator can not judge the remained lifetime of them by visual inspection.
- (2) Repair or replace if an abnormality of these parts is found even before the recommended replacement interval.

Interval
Every 2 years

- * 1. Replace the O-ring and gasket at the same time when replace the hose.
- * 2. Replace clamp at the same time if the hose clamp is cracked when checking and replacing the hose.



2. TIGHTENING TORQUE

Use following table for unspecified torque.

1) BOLT AND NUT

(1) Coarse thread

Dolt size	8	зт	10T		
BOIL SIZE	kg·m lb·ft		kg∙m	lb∙ft	
M 6×1.0	0.85 ~ 1.25	6.15 ~ 9.04	1.14 ~ 1.74	8.2 ~ 12.6	
M 8×1.25	2.0 ~ 3.0	14.5 ~ 21.7	2.73 ~ 4.12	19.5 ~ 29.8	
M10 × 1.5	4.0 ~ 6.0	28.9 ~ 43.4	5.5 ~ 8.3	39.8 ~ 60	
M12 × 1.75	7.4 ~ 11.2	53.5 ~ 79.5	9.8 ~ 15.8	71 ~ 114	
M14 × 2.0	12.2 ~ 16.6	88.2 ~ 120	16.7 ~ 22.5	121 ~ 167	
M16 × 2.0	18.6 ~ 25.2	135 ~ 182	25.2 ~ 34.2	182 ~ 247	
M18 × 2.5	25.8 ~ 35.0	187 ~ 253	35.1 ~ 47.5	254 ~ 343	
M20 × 2.5	36.2 ~ 49.0	262 ~ 354	49.2 ~ 66.6	356 ~ 482	
M22 × 2.5	48.3 ~ 63.3	350 ~ 457	65.8 ~ 98.0	476 ~ 709	
M24 × 3.0	62.5 ~ 84.5	452 ~ 611	85.0 ~ 115	615 ~ 832	
M30 × 3.0	124 ~ 168	898 ~ 1214	169 ~ 229	1223 ~ 1655	
M36 × 4.0	174 ~ 236	1261 ~ 1703	250 ~ 310	1808 ~ 2242	

(2) Fine thread

Polt size	8	ЗТ	10T		
DOIL SIZE	kg∙m	lb ⋅ ft	kg∙m	lb∙ft	
M 8×1.0	2.17 ~ 3.37	15.7 ~ 24.3	3.04 ~ 4.44	22.0 ~ 32.0	
M10 × 1.25	4.46 ~ 6.66	32.3 ~ 48.2	5.93 ~ 8.93	42.9 ~ 64.6	
M12 × 1.25	7.78 ~ 11.58	76.3 ~ 83.7	10.6 ~ 16.0	76.6 ~ 115	
M14 × 1.5	13.3 ~ 18.1	96.2 ~ 130	17.9 ~ 24.1	130 ~ 174	
M16 × 1.5	19.9 ~ 26.9	144 ~ 194	26.6 ~ 36.0	193 ~ 260	
M18 × 1.5	28.6 ~ 43.6	207 ~ 315	38.4 ~ 52.0	278 ~ 376	
M20 × 1.5	40.0 ~ 54.0	289 ~ 390	53.4 ~ 72.2	386 ~ 522	
M22 × 1.5	52.7 ~ 71.3	381 ~ 515	70.7 ~ 95.7	512 ~ 692	
M24 × 2.0	67.9 ~ 91.9	491 ~ 664	90.9 ~ 123	658 ~ 890	
M30 × 2.0	137 ~ 185	990 ~ 1338	182 ~ 248	1314 ~ 1795	
M36 × 3.0	192 ~ 260	1389 ~ 1879	262 ~ 354	1893 ~ 2561	

2) PIPE AND HOSE (FLARE type)

Thread size	Width across flat (mm)	kgf ∙ m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

3) PIPE AND HOSE (ORFS type)

Thread size	Width across flat (mm)	kgf ∙ m	lbf ⋅ ft
9/16-18	19	4	28.9
11/16-16	22	5	36.2
13/16-16	27	9.5	68.7
1-3/16-12	36	18	130
1-7/16-12	41	21	152
1-11/16-12	50	35	253

4) FITTING

Thread size	Width across flat (mm)	kgf ∙ m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

Na	No. Descriptions		Delteine	Torque		
INO.			DOIL SIZE	kgf∙m	lbf ∙ ft	
1		Engine mounting bolt, nut (rubber, 2EA)		$57.9 \pm \ 8.7$	419 ± 63	
2		Engine mounting bolt (bracket, 8EA)		$10.7 \pm ~1.6$	77.4 ± 11.6	
3	Engino	Engine mounting bolt (T/C housing,12EA)	M10×1.5	$4.6 \pm \ 0.9$	$\textbf{33.3} \pm \textbf{6.5}$	
4	Engine	Engine mounting bolt (flywheel, 4EA)	M10×1.5	$4.5\pm~0.6$	$\textbf{32.5} \pm \textbf{4.3}$	
5		Radiator mounting bolt	M16×2.0	$29.7 \pm \ 4.5$	215 ± 32.5	
6		Fuel tank mounting bolt, nut	M16×2.0	$29.7 \pm \ 4.5$	215 ± 32.5	
7		Main pump housing mounting bolt	M16×2.0	$29.7 \pm \ 4.5$	215 ± 32.5	
8		Fan & Brake pump housing mounting bolt	M10×1.5	6.9 ± 1.4	50 ± 10.1	
9		Main control valve mounting bolt	M12×1.75	$12.8\pm~3.0$	92.6 ± 21.7	
10		Steering unit mounting bolt	M10×1.5	6.9 ± 1.4	50 ± 10.1	
11		Stop valve	M10×1.5	6.9 ± 1.4	50 ± 10.1	
12	Hydraulic	Steering valve (EHPS) mounting bolt	M8×1.25	$2.5\pm~0.5$	18.1 ± 3.6	
13	system	Cushion valve	M8×1.25	$2.5\pm~0.5$	18.1 ± 3.6	
14		Brake valve mounting bolt	M8×1.25	$2.5\pm~0.5$	18.1 ± 3.6	
15		Cut-off valve mounting bolt	M12×1.75	$12.8 \pm \ 3.0$	92.6 ± 21.7	
16	Remote control lever mounting bolt		M6×1.0	1.1 ± 0.2	8.0 ± 1.4	
17		Safety valve	M10×1.5	6.9 ± 1.4	50 ± 10.1	
18		Hydraulic oil tank mounting bolt	M16×2.0	29.7 ± 4.5	215 ± 32.5	
19		Transmission mounting bolt, nut (rubber, 2EA)	M24×3.0	100 ± 15	723 ± 108	
20		Transmission mounting bolt (bracket, 6EA)	M20×2.5	46.3 ± 7.0	335 ± 50.6	
01	Power	Front axle mounting bolt, nut (-#0279)	M27×2.0	$135\pm~15$	976 ± 108	
21	train	Front axle mounting bolt, nut (#0280-)	M33×2.0	$225\pm~20$	1630 ± 144	
22	system	Rear axle support mounting bolt, nut	M36×3.0	$308 \pm \ 46.2$	2227 ± 334	
23		Tire mounting nut	M22×1.5	$79\pm~2.5$	571 ± 18.1	
24	Drive shaft joint mounting bolt		1/2-20UNF	15 ± 2.0	108 ± 14.5	
25		Counterweight mounting bolt	M30×3.5	199 ± 30	1439 ± 216	
26		Additional counterweight mounting bolt	M24×3.0	100 ± 15	723 ± 108	
27	Others	Operator's seat mounting bolt	M8×1.25	$\textbf{3.4}\pm\textbf{0.8}$	24.6 ± 5	
28	B ROPS Cab mounting bolt (4EA)		M20×2.5	58 ± 8.7	419 ± 63	

5) TIGHTENING TORQUE OF MAJOR COMPONENT

3. SPECIFICATION OF FUEL, COOLANT AND LUBRICANTS

1) NEW MACHINE

New machine used and filled with following lubricants.

Description	Specification
Engine oil	SAE 15W-40(API CH-4)
	Hyundai genuine long life hydraulic oil (ISO VG46, VG68 only)
	Conventional hydraulic oil (ISO VG15)
Transmission oil	SAE 15W-40
Axle oil	*Refer to below list
Grease	Lithium base grease NLGI No. 2
Fuel	ASTM D975-No. 2
Coolant	Mixture of 50% ethylene glycol base antifreeze and 50% water

· SAE : Society of Automotive Engineers

· API : American Petroleum Institute

· ISO : International Organization for Standardization

· NLGI : National Lubricating Grease Institute

· ASTM : American Society of Testing and Material

* Recommended oil list

- BP TERRAC SUPER TRANSMISSION 10W-30
- CASTROL AGRI TRANS PLUS 10W-30
- MOBILFLUID 426
- SHELL DONAX TD 10W-30
- TOTAL DYNATRANS MPV

2) RECOMMENDED LUBRICANTS

Use only oils listed below or equivalent.

Do not mix different brand oil.

		Capacity		Ambient temperature °C (°F)							
Service point	Kind of fluid	ℓ (U.S. gal)	-50 (-58)	-30 (-22	0 -2 2) (-	20 -1 4) (1	0 (3 4) (3) 1 32) (5	10 2 50) (6	20 30 38) (86)	40 (104)
					* 1ç	SAE 5W	-40				
									SAF	= 30	
Engine	Engino oil	10 (1 0)				SVE	10\//		-		
oil pan		10 (4.0)				JAL	1000		-		
				-			Si	AE 10W-	30		
								SAE 1	5W-40		
							S	AF 10W-	30		
Transmission	Engine oil	32 (8.5)		1							
					_			SAE 1	5W-40		
		Front :									
Axle	UTTO	38 (10.0)		*Refer to below list							
		Rear : 31 (8.2)									
		Tank:				^ 150 v	G 15				
Hydraulic tank	Hydraulic oil	170 (47) Svotomi						ISO VG	46		
ter in t		252 (66.6)								8	
								-	50 VU 0		
				★1	ASTM D	975 NO	1				
Fuel tank	Diesel fuel	334 (88.2)		Т							
								AST	M D975	NO.2	
Fitting						±1 к⊔ ∠					
(grease	Grease	As required		Т		^ ' INL(al INO. I				
nipple)		1						1	NLGI NO.	2	
	Mixture of										
Radiator (reservoir	antifreeze	30 (10 3)			E	thylene	glycol ba	se perma	anent typ	e (50 : 50)	
tank)	and soft water* ²		* ¹ Ethyl	ene (glycol base p	permanent	ype (60 : 40)				

- · SAE : Society of Automotive Engineers
- · API : American Petroleum Institute
- · ISO : International Organization for Standardization
- · NLGI : National Lubricating Grease Institute
- · ASTM : American Society of Testing and Material
- \cdot UTTO \div Universal Tractor Transmission Oil
- * Recommended oil list
 - BP TERRAC SUPER TRANSMISSION 10W-30
 - CASTROL AGRI TRANS PLUS 10W-30
 - MOBILFLUID 426
 - SHELL SPIRAX S4 TXM
 - TOTAL DYNATRANS MPV
- \star^1 Cold region
 - Russia, CIS, Mongolia
- *2 Soft water City water or distilled water

4. MAINTENANCE CHECK LIST

Scheduled maintenance is the normal maintenance necessary to provide proper and efficient machine operation. To protect your investment and prolong the service life of your machine, follow the scheduled maintenance list below.

1) EVERY 10 HOURS SERVICE

Check items	Service	Page	
Hydraulic oil level	Check, Add	6-26	
Engine oil level	Check, Add	6-15	
Radiator coolant level	Check, Add	6-17	
Belt tension & damage	Check	6-21, 22	
Fuel pre-filter	Clean	6-24	

2) EVERY 50 HOURS SERVICE

Check items	Service	Page
Attachment pins	Lubricate	6-39
Tire (air)	Check, Add	6-29
Drive shaft (front, center)	Lubricate	6-36
Steering cylinder pins	Lubricate	6-36
Rear axle pivot	Lubricate	6-36

3) INITIAL 200 HOURS SERVICE

Check items	Service	Page
Brake pressure filter element (-#0607)	Replace	6-28

4) INITIAL 250 HOURS SERVICE

Check items	Service	Page	
Engine oil	Change	6-15, 16, 17	
Engine oil filter	Replace	6-15, 16, 17	
Fuel filter element	Replace	6-24	
Fuel pre-filter	Replace	6-24	
Transmission oil	Change	6-32, 33	
Transmission oil filter	Replace	6-32, 33	
Front axle oil	Change	6-34, 35	
Rear axle oil	Change	6-34, 35	
Hydraulic oil return filter	Replace	6-27	
Pilot line filter element	Replace	6-27	

5) EVERY 250 HOURS SERVICE

Check items	Service	Page
Wheel nuts	Check, Tight	6-30, 31
Fuel tank (water, sediment)	Drain	6-23
Battery (voltage)	Check	6-41, 42
Hydraulic tank air breather element	Replace	6-27
Air conditioner and heater outer filter	Check, Clean	6-44
Brake line filter (strainer) : #0608-	Check, Clean	6-28

6) EVERY 500 HOURS SERVICE

Check items	Service	Page	
Engine oil	Change	6-15, 16, 17	
Engine oil filter	Replace	6-15, 16, 17	
Fuel filter element	Replace	6-24	
Fuel pre-filter	Replace	6-24	
Radiator, oil cooler, change air cooler	Check, Clean	6-20	
Air cleaner element (primary)	Clean	6-23	

7) EVERY 1000 HOURS SERVICE

Check items	Service	Page	
Brake pressure filter element (-#0607)	Replace	6-28	
Hydraulic oil return filter	Replace	6-27	
Pilot line filter element	Replace	6-27	
Center pivot pin	Lubricate	6-36	
Transmission oil	Change	6-32, 33	
Transmission oil filter	Replace	6-32, 33	
Aircon and heater outer filter	Replace	6-44	

8) EVERY 1500 HOURS SERVICE

Check items	Service	Page
Front axle oil	Change	6-34, 35
Rear axle oil	Change	6-34, 35

9) EVERY 1500 HOURS SERVICE

Check items	Service	Page
Front axle oil	Change	6-34, 35
Rear axle oil	Change	6-34, 35

10) EVERY 2000 HOURS SERVICE

Check items	Service	Page	
Hydraulic oil *1	Change	6-26	
Radiator coolant	Change	6-17, 18, 19, 20	
Hydraulic oil suction strainer	Check, Clean	6-27	
Hoses, fittings, clamps (fuel, coolant, hydraulic)	Check, Retighten, Replace	-	

*1 Conventional hydraulic oil

11) EVERY 5000 HOURS SERVICE

Check items	Service	Page
Hydraulic oil *2	Change	6-26

*2 Hyundai genuine long life hydraulic oil

12) WHEN REQUIRED

Check items	Service	Page	
Air cleaner element			
· Safety	Check, Clean, Replace	6-23	
• Primary	Check, Clean, Replace	6-23	
Air conditioner and heater			
Outer filter	Check, Clean, Replace	6-44	
Inner filter	Check, Clean, Replace	6-44	

5. MAINTENANCE CHART



76096MI10

Caution

- 1. Service intervals are based on the hour meter reading.
- 2. The number of each item shows the lubrication point on the machine.
- 3. Stop engine while filling oil, and use no open flames.
- 4. For other details, refer to the service manual.

Service interval	No.	Description	Service action	Oil symbol	Capacity l (U.S.gal)	Service points No.
	1	Hydraulic oil level	Check, Add	HO	178 (47)	1
	2	Engine oil level	Check, Add	EO	18 (4.8)	1
10 Hours or daily	4	Radiator coolant level	Check, Add	С	39 (10.3)	1
or daily	5	Fan belt tension & damage	Check, Adjust	-	-	2
	20	Fuel pre-filter	Clean	-	-	1
	6	Attachment pins	Lubricate	PGL	-	13
	7	Tire (air)	Check, Add	-	-	4
50 Hours	8	Drive shaft (front, center)	Lubricate	PGL	-	2
or weekly	9	Steering cylinder pin	Lubricate	PGL	-	4
	10	Rear axle pivot	Lubricate	PGL	-	2
	11	Wheel nuts	Check, Tight	-	-	64
	12	Fuel tank (water, sediment)	Drain	-	334 (88.2)	1
	13	Brake line filter (strainer) : #0608-	Check, Clean	-	-	1
250 Hours	14	Battery (voltage)	Check, Add	-	-	2
	16	Hydraulic tank air breather element	Replace	-	-	1
	27	Air conditioner and heater outer filter	Check, Clean	-	-	1
	2	Engine oil	Change	EO	18 (4.8)	1
	3	Engine oil filter	Replace	-	-	1
500 110	19	Fuel filter element	Replace	-	-	1
500 Hours	20	Fuel pre-filter element	Replace	-	-	1
	21	Radiator, oil cooler, charge air cooler	Clean	-	-	3
	28	Air cleaner element (primary)	Clean	-	-	1
	13	Brake pressure filter element (-#0607)	Replace	-	-	1
	15	Hydraulic oil return filter	Replace	-	-	1
	17	Pilot line filter element	Replace	-	-	1
1000 Hours	22	Center pivot pin	Lubricate	PGL	-	2
	23	Transmission oil	Change	EO	32 (8.5)	1
	24	Transmission oil filter	Replace	-	-	1
	27	Air conditioner and heater outer filter	Replace	-	-	1
1500 Houro	25	Axle oil (front)	Change	UTTO	38 (10.0)	3
1500 Hours	26	Axle oil (rear)	Change	UTTO	31 (8.2)	3
2000 Hours	1	Hydraulic oil *1	Change	HO	178 (47)	1
	4	Radiator coolant	Change	С	39 (10.3)	1
	18	Hydraulic oil suction strainer	Check, Clean	-	-	1
	-	Hoses, fittings, clamps (fuel, coolant, hydraulic)	Check, Retighten, Replace	-	-	-
5000 Hours	1	Hydraulic oil *2	Change	HO	178 (47)	1
	07	Air conditioner and heater outer filter	Replace	-	-	1
When	27	Air conditioner and heater inner filter	Clean, Replace	-	-	1
required	28	Air cleaner element (safety and primary)	Clean, Replace	-	-	2

*1 Conventional hydraulic oil *2 Hyundai genuine long life hydraulic oil

* Oil symbol

Refer the recommended lubricants for specification.

- EO : Engine oil
- · HO : Hydraulic oil
- · GO : Gear oil

- · PGL : Grease
- · C : Coolant
- · UTTO : Refer to page 6-9.

6. SERVICE INSTRUCTION

1) CHECK ENGINE OIL LEVEL

Check the oil level with the machine on a flat ground before starting engine.

- (1) Pull out the dipstick and wipe with a clean cloth.
- (2) Check the oil level by inserting the dipstick completely into the hole and pulling out again.
- (3) If oil level is LOW, add oil and then check again.
- If the oil is contaminated or diluted, change the oil regardless of the regular change interval.
- * Check oil level after engine has been stopped for 15 minutes.
- A Do not operate unless the oil level is in the normal range.



- Operate the engine until the coolant temperature reaches 60°C (140°F). Shut off the engine.
- (2) Turn the stopper to the open position and allow the oil to drain.
 - · Wrench size : 10 mm
- * A drain pan with a capacity of 30 liters (6.6 U.S.gallons) will be adequate.
- (3) Clean the area around the oil filter head.
- (4) Use oil filter wrench to remove the oil filter.
- (5) Clean the gasket surface of oil filter head.
- * The O-ring can stick on the filter head; make sure it is removed.






- (6) Apply a light film of lubricating oil to the gasket sealing surface before installing the filter.
- * Fill the filter with clean lubricating oil.

- (7) Install the filler to the filter head.Tighten the filter until the gasket contacts the filter head surface.
- * Mechanical over-tightening may distort the threads or damage the filter element seal.

(8) Turn the stopper to the close position.

(9) Fill the engine with clean oil to the proper level.Quantity : 18 / (4.8 U.S.gallons)









- (10) Operate the engine at low idle and inspect for leaks at the filter and the drain plug.Shut the engine off and check oil level with dipstick. Allow 15 minutes for oil to drain down before checking.
- * Do not overfill the engine with oil.



3) CHECK COOLANT LEVEL

- (1) Check the coolant level at the sight gauge.
- (2) Add the mixture of antifreeze and water if coolant is not sufficient.
- (3) The sight gauge should indicate the middle position.
- (4) Replace gasket of radiator cap when it is damage.
- ▲ Do not remove the radiator cap from a hot engine. Wait until the coolant temperature is below 50°C (120°F) before removing the radiator cap. Heated coolant spray or steam can cause personal injury.
- * Do not add cold coolant to a hot engine ; engine castings can be damaged. Allow the engine to cool to below 50°C (120°F) before adding coolant.





4) FLUSHING AND REFILLING OF RADIATOR

- (1) Change coolant
- ▲ Avoid prolonged and repeated skin contact with used antifreeze. Such prolonged repeated contact can cause skin disorders or other bodily injury.

Avoid excessive contact-wash thoroughly after contact.

Keep out of reach of children.

▲ Protect the environment : Handling and disposal of used antifreeze can be subject to federal, state, and local law regulation.

Use authorized waste disposal facilities, including civic amenity sites and garages providing authorized facilities for the receipt of used antifreeze.

If in doubt, contact your local authorities for guidance as to proper handing of used antifreeze.

▲ Wait until the temperature is below 50°C (120°F) before removing the coolant system radiator cap. Failure to do so can cause personal injury from heated coolant spray.

Drain the cooling system by turning the stopper to the open position.

A drain pan with a capacity of 45 liters (11.9 U. S.gallons) will be adequate in most applications.

(2) Flushing of cooling system

- Fill the system with a mixture of sodium carbonate and water (or a commercially available equivalent).
- * Use 0.5 kg (1.0 pound) of sodium carbonate for every 23 liters (6.0 U.S. gallons) of water.
- * Do not install the radiator cap. The engine is to be operated without the cap for this process.







② Operate the engine for 5 minutes with the coolant temperature above 80°C (176°F). Shut the engine off, and drain the cooling system.

- ③ Fill the cooling system with clean water.
- * Be sure to vent the engine and aftercooler for complete filling.
- * Do not install the radiator cap or the new coolant filter.





- ④ Operate the engine for 5 minutes with the coolant temperature above 80°C (176°F).
 Shut the engine off, and drain the cooling system.
- * If the water being drained is still dirty, the system must be flushed again until the water is clean.



(3) Cooling system filling

- ① Use a mixture of 50 percent soft water and 50 percent ethylene glycol antifreeze to fill the cooling system. Refer to the page 6-9.
- Never use water alone for coolant.
 This can result in damage from corrosion.
- * Do not use hard water such as river water or well water.



② Install the radiator cap. Operate the engine until it reaches a temperature 80°C (176°F), and check for coolant leaks. Check the coolant level again to make sure the

system is full of coolant.

5) CLEAN RADIATOR AND OIL COOLER

Check, and if necessary, clean and dry outside of radiator and oil cooler. After working in a dusty place, clean radiator more frequently.

- (1) Visually inspect the radiator for clogged radiator fins.
- (2) Use 550 kPa (80 psi) air pressure to blow the dirt and debris from the fins.Blow the air in the opposite direction of the fan

air flow.

- (3) Visually inspect the radiator for bent or broken fins.
- If the radiator must be replaced due to bent or broken fins which can cause the engine to overheat, refer to the manufacturer's replacement procedures.
- (4) Visually inspect the radiator for core and gasket leaks.



 Inspect the charge air cooler for dirt and debris blocking the fins. Check for cracks, holes, or other damage. If damage is found, please contact hyundai distributor.









7) DRIVE BELT

 Inspect the belts daily. Check the belts for intersecting cracks. Transverse (across the belt width) cracks are acceptable.

Longitudinal (direction of belt length) cracks that intersect the transverse cracks are not acceptable. Replace a belt if is frayed or has pieces of material missing.



8) INSPECTION OF COOLING FAN

- ▲ Personal injury can result from a fan blade failure. Never pull or pry on the fan. This can damage the fan blade and cause fan failure.
- * Rotate the crankshaft by using the engine barring gear.
- * A visual inspection of the cooling fan is required daily.

Check for cracks, loose rivets, and bent or loose blades.

Check the fan to make sure it is securely mounted. Tighten the capscrews if necessary. Replace any fan that is damaged.

9) BELT TENSIONER, AUTOMATIC ADJUSTMENT

- (1) Every 1000 hours, or 1 year, whichever occurs first, inspect the automatic belt tensioner.
 With the engine turned off, check that neither the top nor bottom tensioner arm stop is touching the cast boss on the tensioner body. If either of the stops is touching a boss, the alternator belt must be replaced. Check to make sure the correct belt part number is being used it either condition exists.
- (2) Check the tensioner pulley and body for cracks. If any cracks are noticed, the tensioner must be replaced. Refer to a Cummins Authorized Repair facility. Check the tensioner for dirt buildup. If this condition exists, the tensioner must be removed and steam-cleaned.







(3) Check that the bottom tensioner arm stop is in contact with the bottom tensioner arm stop boss on the tensioner body. If these two are not touching, the tensioner must be replaced.

(4) Inspect the tensioner for evidence of the pivoting tensioner arm contacting the stationary circular base. If there is evidence of these two areas touching, the pivot tube bushing has failed and the tensioner must be replaced.





- (5) A worn tensioner that has play in it or a belt that "walks" off its pulley possibly indicates pulley misalignment.
- Maximum pulley misalignment is three degrees. This measurement can be taken with a straightedge and an inclinometer.
- (6) Install the belt.



10) CLEANING OF AIR CLEANER

(1) Primary element

- 1 Loosen the wing nut and remove the element.
- 2 Clean the inside of the body.
- 3 Clean the element with pressurized air.
 - Remove the dust inside of the element by the pressurized air (below 3 kgf/cm², 40 psi) forward and backward equally.
- ④ Inspect for cracks or damage of element by putting a light bulb inside of the element.
- (5) Insert element and tighten wing nut.
- * When the air cleaner warning lamp is ON, clean the primary element.
- * The primary element should be replaced if the warning lamp is ON after installation of a clean primary element, or if the exhaust smoke is still black.
- * Replace the primary element after 4 times cleanings.



(2) Safety element

- * The safety element should be replaced at the time the primary element is replaced.
- * Always replace the safety element. Never attempt to reuse the safety element by cleaning the element.



11) FUEL TANK

- (1) Fill fuel fully when system the operation to minimize water condensation, and check it with fuel gauge before starting the machine.
- (2) Drain the water and sediment in the fuel tank by opening the plug.
- * Be sure to LOCK the cap of fuel tank.
- Remove the strainer of the fuel tank and clean it if contaminated.
- ▲ Stop the engine when refueling. All lights and flames shall be kept at a safe distance while refueling.



12) REPLACEMENT OF FUEL FILTER

- (1) Clean around the filter head, remove the filter and clean the gasket surface.
 Wrench size : 90~95 mm (3.5~3.8 in)
- (2) Replace the O-ring.
- (3) Apply engine oil on the gasket of filter when mounting, and tighten 3/4 to 1 turn more after the gasket touches the filter head.
- (4) Relieve the air after mounting.
- Do not pre-fill an on-engine fuel filter with fuel. The system must be primed after the fuel filter is installed. Pre filling the fuel filter can result in debris entering the fuel system and damaging fuel system components.
- * Check for fuel leakage after the engine starts.
- If air is in the fuel system, the engine will not start. Start engine after bleeding the air according to the method of bleeding air.



13) PREFILTER * Inspect or drain the collection bowl of water daily and replace the element every 500hours.

- (1) Drain water
- ① Open bowl drain valve to evacuate water.
- 2 Close drain valve.



(2) Replace element

- ① Drain the unit of fuel. Follow "Drain water" instructions above.
- ② Remove element, fuel warmer and bowl from filter head.
- * The bowl is reusable, do not damage or discard.
- ③ Separate element from bowl. Clean bowl and seal gland.



- ④ Lubricate new bowl seal with clean fuel or motor oil and place in bowl gland.
- (5) Attach bowl to new element firmly by hand.
- ⑥ Lubricate new element seal and place in element top gland.
- ⑦ Attach the element, fuel warmer and bowl to the head.



14) BLEEDING THE FUEL SYSTEM

- (1) Loosen fuel supply line plug at the outlet of prefilter.
- (2) Do hand-priming the lift pump repeatedly until air bubbles comes out from fuel supply line completely.
- (3) Tighten fuel supply line to its origin position.
- ▲ The fuel pump, high-pressure fuel lines, and fuel rail contain very high-pressure fuel. Do not loosen any fittings while the engine is running. Personal injury and property damage can result. Wait at least 10 minutes after shutting down the engine before loosening any fittings in the high-pressure fuel system to allow pressure to do decrease to a lower level.



15) LEAKAGE OF FUEL

▲ Be careful and clean the fuel hose, injection pump, fuel filter and other connections as the leakage from these part can cause fire.



16) HYDRAULIC OIL CHECK

- Lower the bucket on the ground at a flat location as in the illustration.
 Stop the engine and then leave for about 5 minutes.
- (2) Check the oil level at the sight gauge. The sight gauge is located on the left side of the hydraulic oil tank.
- (3) The sight gauge should indicate the middle position.
- * Add hydraulic oil, If necessary.

17) FILLING HYDRAULIC OIL

- (1) Stop the engine to the position of level check.
- (2) Rotate the cap nut counter-clockwise by hand and push the rod to release the air pressure.
- (3) Remove the breather on the top of oil tank and fill the oil to the specified level.
- (4) Start engine after filling and operate the work equipment several times.
- (5) Check the oil level at the level check position after engine stops.

18) CHANGE THE HYDRAULIC OIL

- (1) Lower the bucket on the ground extend the bucket cylinder to the maximum.
- (2) Loosen the cap and relieve the pressure in the tank by pushing the top of the air breather.
- (3) Prepare a suitable container.
- (4) To drain the oil loosen the drain plug at the fuel tank block.
- (5) Tighten the drain plug.
- (6) Fill proper amount of recommended oil.
- (7) Put the breather in the right position.
- (8) Start engine and run continually. Release the air by full stroke of control lever.
- * The oil must be free of bubbles. If bubbles are present in the oil, air is entering the hydraulic system. Inspect the suction hoses and hose clamps.







19) CLEANING AND REPLACING RETURN FILTER

Clean and replace the return filter in the following manner.

- (1) Remove the cover.
- (2) Remove spring, by-pass valve and return filter from the tank.
- (3) Replace element with new one and assemble spring and by-pass valve after cleaning.
- (4) Install the cover on the tank.
 - Tightening torque : $6.9 \pm 1.4 \text{ kgf} \cdot \text{m}$ (50 ± 10 lbf • ft)



20) REPLACEMENT OF ELEMENT IN HYDRAULIC TANK BREATHER

- (1) Loosen the cap and relieve the pressure in the tank by pushing the top of the air breather.
- (2) Loosen the lock nut and remove the cover.
- (3) Pull out the filter element.
- (4) Replace the filter element new one.
- (5) Reassemble by reverse order of disassembly.
 Tightening torque : 0.2~0.3 kgf · m (1.4~2.1 lbf · ft)

21) REPLACE OF PILOT LINE FILTER

- (1) Loosen the bowl positioned on the safety valve.
- (2) Pull out the filter element and clean the bowl.
- (3) Install the new element and tighten the bowl using spanner.
 - Spanner size : 27 mm





22) REPLACE OF BRAKE PRESSURE FILTER

- (1) Loosen the nut on the filter body.
- (2) Pull out the filter element and clean filter housing.
- (3) Install the new element and tighten the nut using the spanner (36 mm).



23) LUBRICATE RCV LEVER

Remove bellows and grease the joint (A) and the sliding parts (B).



24) TIRE PRESSURE

- (1) Inappropriate tire pressure is a primary cause for tire damage. Insufficient tire pressure will damage internal carcass of tire. Repeated excessive bending will damage or break the carcass. Excessive pressure will also cause premature damage of tire.
- (2) Recommended tire pressure (When tire is cooled)

Size	Pressure
23.5-25, 20PR (L3)	3.9 bar (55 psi)
23.5 R25, ★(L3)	4.2 bar (60 psi)

- (3) Continuous operation will produce heat and increase pressure on tire. But such phenomenon was already taken into account when designing a tire. Do not try to remove normally increased air because tires may be crushed or overinflated.
- (4) The three major causes for excessive heat and pressure of tire are insufficient pressure, excessive load and overspeed. Avoid excessive load and overspeed in order to keep tires in good shape.
- ▲ Do not inflate tires using flammable gases or alcohol injector.

This cause explosion or personal injury.

- ▲ Inflate tires at the pressure level recommended by the manufacturer, and check periodically pressure and wear of tires.
- A When replacing the inflated tire, do not stand near the tire.
- * Check the tire when the tire is at normal temperature and the machine is not loaded.
- ▲ Do not use recycled wheel parts.
- ▲ When removing lockering or inflating tire, use safety cable or chain to ensure safety.
- Be sure to bleed air before removing lockering. Never inflate tires unless the lockering is assembled in its place.
- ① Avoid the followings when traveling.
- ② Rubbing tires against road bank or rack at cargo-unloading spot.
- ③ Tires slippage during working.
- 4 Abrupt starting of machine.

When oil, grease or gasoline smeared on tire, clean those. Otherwise it may cause of permanent deformation.



25) REPLACEMENT OF TIRE

- ▲ Disassembly, reassembly, replacement and repair of tire requires special skills and equipment. Contact a tire repair shop.
- (1) Tires to be replaced
- ① Tires with broken or bent bead wires
- 0 Tires exposed more than 1/4 of carcass fly.
- ③ Tires whose carcass is damaged more than 1/3 of the tire width.
- ④ Tires which show fly separation.
- ⑤ Tires which has a radial crack near the carcass.
- ⑥ Tires which are judged to be unsuitable for use because of deformation or damage.



(2) Separation of tire

① After moving the machine to flat ground, lower the bucket to the ground and turn the parking brake switch ON.



- ② Loosen slightly all wheel mounting.
 - Tools : Socket 32 mm

Torque wrench

- Extension bar
- 3 Lift the machine with a jack.
- ④ Loosen all wheel mounting nuts and replace the tire.



(3) Direction of tire to be installed

① Be careful that the valve should be facing the outside.



(4) Mounting of tire

- $(\ensuremath{\underline{1}})$ Lightly tighten nuts as shown in the illustration.
- 2 Lower the jack after tire is replaced.
- ③ Tighten nuts according to the specified tighten torque.
 - \cdot Tightening torque : 79 \pm 2.5 kgf \cdot m

(571±18 lbf · ft)



26) STORING TIRES AFTER REMOVAL

As a basic rule, store the tires in a warehouse which unauthorized persons cannot enter. If the tire are stored outside, always erect a fence around the tires and put up "No Entry" and other warning signs that even young children can understand.

Stand the tire on level ground, and block it securely so that it cannot roll or fall over.

If the tire should fall over, get out of the way quickly. The tires for construction equipment are extremely heavy, so trying to hold the tire may lead to serious injury.



27) CHECK TRANSMISSION OIL LEVEL

- The oil level check must be carried out as follows; oil level check (weekly).
- (2) Before the oil level check, transmission must have been running to warm up enough.
- (3) When the oil level is checked, machine must be on flat ground and engine must be at idling speed, transmission must be in neutral position.
- (4) Check the oil level on level (sight) gauge.
- (5) Oil level

- Operating temperature (about 80~90°C) :The Oil level must be lying in zone HOT

(between two red lines).

- Cold phase (about 40°C)

: The Oil level must be lying near cold mark (blue line).

A When checking, press the parking brake switch and fix the front and rear frames with the safety lock bar.

28) REPLACEMENT OF TRANSMISSION OIL AND FILTER ELEMENT

- (1) Operate the machine for a few minutes in order to warm the transmission oil.
- (2) Move the machine to flat ground. Lower the bucket to the ground and slightly apply downward force.
- (3) Press the parking brake switch and stop the engine.
- (4) Open transmission air breather to relieve internal air pressure.
- (5) Remove the transmission drain plug. Allow the transmission oil to drain into a suitable container.





- (6) Remove the transmission oil filter cartridge. Dispose of the used transmission oil filter cartridge properly.
- (7) Clean the filter cartridge mounting base. Remove any part of the filter cartridge gasket that remains on the filter cartridge mounting base.



- (8) Apply a light coat of oil to the gasket of a new transmission oil filter cartridge.
- (9) Install the new transmission oil filter cartridge. Screw the filter in until contacts with the sealing surface is obtained and tighten it now by hand about 1/3 to 1/2 turn.



- (10) Fill the oil through filler cap and check if the oil is at the appropriate level.
- (11) The proper oil amount is 32 liters. (8.5 U.S. gallons)
- A As the machine is hot after operation wait until the temperature has dropped.

It is imperative to pay attention to absolute cleanliness of oil and filter.
 Binding is in any case the marking on the oil level gauge.



29) CLEANING TRANSMISSION AIR BREATHER

- (1) Remove dust or debris around the air breather.
- (2) Remove the air breather and wash it with cleaning oil.



30) CHECK AND SUPPLYING AXLE OIL

- (1) Move the machine to flat ground.
- (2) Open the axle air breather to relieve internal air pressure.
- (3) Remove the plug and check the oil amount. If the oil level is at the hole of the plug, it is normal.
- * Provide fill & level plug with O-ring and install it.
- ▲ When checking the oil level, press the parking brake switch and fix front and rear frames using the safety lock bar.
- ▲ As the machine is hot after operation, wait until the temperature has dropped.
 Set the plug of planetary gear in parallel to the ground.



31) CHANGE THE AXLE OIL

- (1) Place a case under drain plug to catch oil.
- (2) Remove the air breather to relieve internal pressure.
- (3) The basic condition for a correct oil change of the axle is horizontal plane of installation in every direction.

Place machine in a horizontal position

- (4) All plugs must be cleaned carefully before opening.
- (5) Loosen drain plugs and drain oil.
- (6) Provide drain plugs with new O-ring and install them.
- (7) Fill up oil to the overflow on fill & level plug.
 Oil amount
 Front axle : 38 l (10.0 U.S. gal)
 Rear axle : 31 l (8.2 U.S. gal)
- ▲ As the machine is hot after operation, wait until the temperature has dropped.
- If a work requires frequent use of brake, replace it earlier than normal change interval.



32) CLEANING AXLE BREATHER

- (1) Remove dust or debris around the breather.
- (2) Remove the breather and wash it with cleaning oil.



33) LUBRICATION

- (1) Supply grease through the grease nipple, using grease gun.
- (2) After lubricating, clean off spilled grease.
- ▲ Press the parking brake switch and fix front and rear frames using the safety lock bar.
- ▲ Set the work equipment in a stable position and turn the hydraulic safety lock valve into the lock position.
- (3) Rear axle pivot : 2EA
- (4) Steering cylinder pin : 4EA





- (5) Center pivot pin : 2EA
- (6) Drive shaft
 - Front (flange bearing) : 1EA
 - Center (slip yoke) : 2EA



34) REPLACEMENT OF BOLT ON CUTTING

Replace the cutting edge before it has worn out



(2) Replacement method

EDGE

(1) Replacement time

to the end of bucket.

- ▲ Make sure the work equipment does not move when replacing the cutting edge. Set the work equipment in a stable position, put the hydraulic safety lock lever in the LOCK position and stop the engine.
- ① Lift the bucket to a proper height and insert blocks so that the bucket does not fall down.
- ② Loosen bolts and nuts, and remove the cutting edge.
- ③ Clean the contacted surface.
- ④ Turn the cutting edge and install on the bucket.
- If both sides have worn out, replace it with new ones.
- If the contacted face of cutting edge has worn out, repair the contacted face of it.
- ⑤ Tighten evenly bolts and nuts to remove the clearance between bucket and cutting edge.
 - Tightening torque : $77 \pm 11.6 \text{ kgf} \cdot \text{m}$ (557±84 lbf • ft)
- ⑥ After a few hours of operation, retighten bolts.

35) REPLACEMENT OF BUCKET TOOTH

(1) Replacement time

Replace the bucket tooth before it has worn out to the end of the bucket.







- (2) Replacement method
- ▲ Make sure the work equipment does not move when replacing the bucket tooth. Set the work equipment in a stable position, put the pilot cut off switch in the OFF position and stop the engine.
- ① Lift the bucket to a proper height and insert blocks so that the bucket does not fall down.
- ② Loosen bolts and nuts, and remove bucket tooth.
- ③ Clean the contacted surface.
- If the contacted face of bucket tooth has worn out, repair the contacted face of it.
- ④ Install new bucket tooth on the bucket, and tighten bolts and nuts.
 - \cdot Tightening torque : 77 ± 11.6 kgf \cdot m

 $(557\pm84 \text{ lbf} \cdot \text{ft})$

⑤ After a few hours of operation, retighten bolts.





36) MAINTENANCE OF WORK EQUIPMENT

Lubricate to each pin of working device.
 Lubricate the grease to grease nipple in accordance with lubrication intervals.

No.	Description	Qty
Α	Bucket cylinder (front frame side) pin	1
В	Boom cylinder (front frame side) right pin	1
С	Boom-front frame right connection pin	1
D	Boom-front frame left connection pin	1
E	Boom cylinder (front frame side) left pin	1
F	Boom cylinder-boom connection pin	2
G	Bucket cylinder-bell crank connection pin	1
Н	Boom-bell crank connection pin	1
1	Bell crank-bucket link connection pin	1
J	Bucket-Bucket link connection pin	2
K	Bucket-boom connection pin	2

* Shorten lubricating interval when working in the water or dusty place.



- (2) Check for wear and tear of work equipment pins and bushings.
- (3) Check for damage of boom and bell crank.



- (4) Dust seal are mounted on the rotating part of working device to extend the lubricating interval.
- * Mount the lip to be faced out side when replace the dust seal.
- If it is assembled in wrong direction, it will cause fast wear of pin and bushing, and create noise and vibration during operation.
- * Make sure the seals are not damaged or deformed.



37) WORK EQUIPMENT SUPPORT

When carrying out inspection and maintenance with the equipment raised, fit a stand under the lift arm securely to prevent the work equipment from coming down. In addition, set the work equipment control levers to the Hold position and Lock with the safety lock.



7. ELECTRICAL SYSTEM

1) WIRING, GAUGES

Check regularly and repair loose or malfunctioning gauges when found.



2) BATTERY

(1) Clean

- Wash the terminal with hot water if it is contaminated, and apply grease to the terminals after washing.
- A Battery gas can explode. Keep sparks and flames away from batteries.
- Always wear protective glasses when working with batteries.
- ▲ Do not stain clothes or skin with electrolyte as it is acid.

Be careful not to get the electrolyte in eyes. Wash with clean water and go to the doctor if it enters the eyes.

- Avoid short-circuiting the battery terminals through accidental contact with metallic objects, such as tools, across the terminals.
- ▲ Do not store tools, bucket tooth and other flammable things in battery box. They could cause a fire.
- ▲ Tighten the battery terminals securely. Loosened terminals can generate sparks and lead to explosion.
- A Make sure that the battery terminal's caps always are installed.



7579A0FW30

(2) Recycle

Never discard a battery. Always return used batteries to one of the following locations. •A battery supplier •An authorized battery collection facility •Recycling facility

(3) Method of removing the battery cable

Remove the cable from the ground connection first (\ominus terminal side) and reconnect it last when reassembling.

* Pay attention to the correct polarity.



3) STARTING THE ENGINE WITH A BOOSTER CABLE

Keep following order when you are going to start engine using booster cable.

(1) Connection of booster cable

* Use the same capacity of battery for starting

- Connect the red terminal of booster cable to the battery(+) terminal between exhausted and new battery.
- ② Connect the black terminal of the booster cable to the battery (-) terminal between exhausted and new battery.
- * Keep firmly all connection, the spark will be caused when connecting finally.

(2) Starting the engine

- 1 Start engine with starting key.
- ② If you can not start it by one time, restart the engine after 2 minutes.





(3) Taking off the booster cable

- Take off the booster cable (black).
- ② Take off the booster cable (red) connected to the (+) terminal.
- ③ Run engine with high idle until charging the exhausted battery by alternator, fully.
- ▲ Explosive gas is generated while using the battery or charging it. Keep away flame and be careful not to cause the spark.
- * Charge the battery in the well ventilated place.
- * Place the machine on the earth or concrete. Avoid to charge the machine on the steel plate.
- * Do not connect (+) terminal and (-) terminal when connecting booster cable because it will be shorted.

4) Welding repair

Before start to welding, follow the below procedure.

- (1) Shut off the engine and remove the starting switch.
- (2) Disconnect ground cable from battery by master switch.
- (3) Before carrying out any electric welding on the machine, the battery cables should be disconnected and the connectors pulled out of the electronic control units (MCU, TCU, ECU, cluster, monitor etc).
- (4) Connect the earth (ground) lead of the welding equipment as close to the welding points as possible.
- * Do net weld or flame cut on pipes or tubes that contain flammable fluids. Clean them thoroughly with nonflammable solvent before welding or flame cutting on them.
- ▲ Do not attempt to welding work before carry out the above.

If not, it will caused serious damage at electric system.





8. AIR CONDITIONER AND HEATER

1) CLEAN AND REPLACE OF OUTER FILTER

- * Always stop the engine before servicing.
- (1) Open the door, loosen the wing bolt and remove the outer filter.



- (2) Clean the filter using a pressurized air (below 2 kgf/cm², 28 psi).
- \triangle When using pressurized air, be sure to safety glasses.
- (3) Inspect the filter after cleaning. If it is damaged or badly contaminated, use a new filter.



2) CLEAN AND REPLACE OF INNER FILTER * Always stop the engine before servicing.

- (1) Open the cover.
- (2) Remove the inner filter.



- (3) Clean the inner filter using a pressurized air (below 2 kgf/cm², 28 psi) or washing with water.
- \triangle When using pressurized air, be sure to wear safety glasses.
- (4) Inspect the filter after cleaning. If it is damaged or badly contaminated, use a new filter.
- * Dry off after washing with water.



3) PRECAUTIONS FOR USING AIR CONDITIONER

- (1) When using the air conditioner for a long time, open the window once every one hour.
- (2) Be careful not to overcool the cab.
- (3) The cab is properly cooled if the operator feels cool when entering there from outside (about 5°C lower than the outside temperature).
- (4) When cooling, change air occasionally.

4) CHECK DURING SEASON

Ask the service center for replenishment of refrigerant or other maintenance service so that the cooling performance is not damaged.

5) CHECK DURING OFF-SEASON

Operate the air conditioner 2 or 3 times a month (each for a few minutes) to avoid loss of oil film in the compressor.

6) REFRIGERANT (R134-a) AMOUNT : 850±30 g (with receiver drier)

1. ENGINE

* This guide is not intended to cover every conditions, however many of the more common possibilities are listed.

Trouble	Service	Remark
Engine oil pressure lamp fails to go off immediately after the engine is started.	· Add the oil to the specified level.	
	· Replace the oil filter.	
	\cdot Check oil leakage from the tube or the joint.	
Steam is emitted from the top part of	· Supply the cooling water and check leakage.	
the radiator (The pressure valve).	· Adjust fan belt tension.	
indicates red range.	· Wash out inside of cooling system.	
	· Clean or repair the radiator fin.	
	· Check the thermostat.	
	· Check the engine coolant temperature gauge.	
	 Tighten the radiator cap firmly or replace the gasket of it. 	
Engine does not start when the	· Add fuel	
starting motor is turned over.	· Repair where air is inhaled into fuel system.	
	· Check the injection pump or the nozzle.	
	 In cold weather, check if fuel warmer system is working normal. 	Refer to the pages 4-5.
	· Check the valve clearance.	
Exhaust gas is white or blue.	· Adjust to specified oil quantity.	
	· Replace with specified fuel.	
Exhaust gas occasionally turns	· Clean or replace the air cleaner element.	
black.	· Check the nozzle.	
	· Check engine compression pressure.	
	· Check or replace the turbocharger.	
Combustion noise occasionally	· Check the nozzle.	
changes to breathing sound.	· Check the injection pump.	
Unusual combustion noise or	· Check with specified fuel.	
mechanical noise.	· Check overheating.	
	· Check the muffler.	
	· Adjust valve clearance.	

2. ELECTRICAL SYSTEM

Trouble	Service	Remark
Voltmeter fluctuates largely even with the engine running at a constant speed. Lamp does not glow brightly even when engine runs at high speed. Lamp flickers while engine runs.	 Check for loose terminals open-circuit wiring. Adjust belt tension. 	
Voltmeter does not fluctuate even with an increase in the engine speed.	 Check the alternator. Inspect and repair wiring. 	
Starting motor does not turn when starting switch is turned on.	 Inspect and repair the wiring. Charge the battery. Check starting switch. Check battery relay switch. Place the gear selector lever in the neutral. 	
Starting motor turns the engine sluggishly.	 Charge the battery. Check the starting motor. 	
Starting motor disengages before the engine starts up.	 Check and repair the wiring. Charge the battery. 	
Engine oil pressure lamp does not light up when engine is stationary (When the starting switch is in ON position).	 Check the lamp. Check the oil pressure switch. 	
Charge lamp does not light up when the engine is stationary. (When the starting switch is in ON position.)	 Check the lamp. Check and repair the wiring. 	

3. POWER TRAIN SYSTEM

Trouble	Service	Remark
Engine is running but machine will not move.	· Release parking brake.	
	· Put gear selector lever in position properly.	
	• Add oil to transmission case to the specified level.	
Even at full throttle, machine	· Add oil to transmission case to the specified level.	
moves slowly and lacks power.	· Disassemble transmission strainer and clean.	
Transmission oil overheats.	Add oil to transmission case to the specified level or drain oil.	
	· Use a suitable gear speed.	
	 Reduce time using torque converter at stall speed. Check engine. 	
Abnormal noise is produced.	\cdot Add oil to transmission case to the specified level.	
	· Add oil to axle case to the specified level.	
Brake does not work when pedal	· Raise hydraulic oil pressure to specified level.	
is depressed.	· Add brake oil.	
	[•] Bleed hydraulic oil from brake system.	
Brake drags or stay when applied.	· Clean breather and bleed air from brake system.	
Brake slips.	· Raise hydraulic oil pressure to the specified level.	
Brake does not work properly.	· Adjust linkage.	
	· Clean brake pad.	
	· Replace spring in hydraulic oil cylinder.	
	· Adjust or replace brake pad.	
Steering wheel is heavy.	· Repair or replace the pump.	
	· Repair, clean and reset the relief valve.	
	 Coat a grease to connections and bearings of steering gear. 	
	· Check the mounting of the steering column.	
Steering wheel turning by itself.	· Replace leaf springs.	
Slow steering.	· Clean spool and sleeve.	
	· Replace leaf springs.	
Impossible to turn the steering wheel into neutral position.	· Check the monitor.	
	\cdot Check and repair the wiring.	

4. HYDRAULIC SYSTEM

Trouble	Service	Remark
Bucket lacks lifting power. Bucket lifting speed is slow.	 Check the hydraulic oil level and add if necessary. Replace filter in hydraulic tank. 	
Bubbles in oil.	 Replace with specified oil. Add oil if needed. 	
Oil pressure is too low.	 Bleed air from oil line. Add oil and bleed air. 	
Cylinder vibrates when operating.	· Add oil.	

1. CENTRAL GREASE LUBRICATION SYSTEM

1) MAJOR COMPONENT



5

To attachment and flange bearing To rear axle and steering cylinder

75798CG01

- 1 Grease tank
- 2 Grease pump
- 3 Control unit
- 4 Push button

- 5 Central grease lubrication switch
- 6 Pump element
- 7 Relief valve
- 8 Pressure indicator

(1) Central grease lubrication switch



- (1) This switch is used to operate the central grease lubrication system.
- (2) When this switch turned ON, the central grease lubrication system is operated for 16 minutes once.
- (3) Please turn the switch OFF.

2) ELECTRONIC CONTROL UNIT



8007A8CG18

(1) Lubricating period setting dial



This dial use to set the greasing period from 1 to 16 minutes.

- ② Default period is 16 minutes.
- * Use a minus(-) screw driver to change settings.

(2) Pause period setting dial



This dial is use to set the pause period from 0.5 to 8 hours.
 Default period is one hour.

(3) Control LED



3) PUSH BUTTON



- ① This LED indicates operating status of the central grease lubrication system.
- ② Turn the starting switch ON, the LED will light up for 1.5 seconds.
- ③ During the central grease lubrication system is operated, it will blink at 0.5 second intervals.
- ④ When the lubrication system is failed, the LED is light up continuously.
- $\ensuremath{\textcircled{}}$ This button use to operate the central grease lubrication system.
- ② Pushing the button, the central grease lubrication system is operated for 16 minutes once.
4) FILLING THE GREASE TANK

- (1) Standard filling via lubrication nipple with manual or pneumatic grease gun.
- * Lubricate the grease until it flows out to the grease vent.
 - · Capacity : 4 kg (8.8 lb)
- (2) Manual hand grease gun.





(3) Pneumatic grease pump (option).



5) REPAIR INSTRUCTIONS

(1) Case of system blockage

- ① A creased or clogged lubricant pipe
- ② Grease points overfilled or clogged by lubricant
- $\ensuremath{\textcircled{}}$ S Lubricant not suitable for central lubrication system
- ④ Distributor outlet closed
- ⑤ Blocked distributor

(2) Message signalling a blockage

The system pressure is exceeded (265 kgf/cm²), a blockage may exist in the system and will be signalled by one of the followings.

- ① The pressure indicator at grease pump.
- 0 The pressure indicator at secondary distributor.

(3) Repair of a distributor when blocked :

- ① Remove the main distributor from the system, nothing the sequence of removal.
- ② Remove the plugscrews from the piston holes and move the pistons to and fro (don't expel them); re-insert the plug-screws.
- ③ If the main distributor is not blocked, do the secondary distributor as above mentioned.
- ④ Push the piston of the blocked distributor outside and check the drilling and the piston surface for scratches and deficiencies.
- (5) Renew the distributor affected by serious deficiencies.
- * Pistons are not interchangeables for main and secondary distributor.
- Deposits of hardened grease detected at pistons and drillings of distributor must be eliminated by washing and blowing. The drillings in distributor must be free of residues of grease. This should be checked by use of some thin wire.
- * Hardening of grease indicates that the lubricant being used is not suitable for the central grease lubrication system. Ask for advice by the supplier of the lubricant. After having checked both distributor, re-assemble the distributor complying with the sequence noted down previously. In order to preclude jamming of pistons, tighten the plug-screws to the specified tightening torque.
 - Tightening torque : 1.2 kgf·m (8.7 lbf·ft)
- ① Check the distributor for correct operation, using oil or grease.
- $\textcircled{\sc 0}$ Install the distributor in the system.
- ③ Start the machine and check it for correct operating pressure (150kgf/cm²).
- * The repair work has to be done under maximum cleanliness.

6) TROUBLESHOOTING

Category	Applications	Service
Pump does not work	Defective electronic control unit Electric cable is broken Pump is defective	Replace the control unit Renew the electric cable Replace the pump
Pump is working, but does not supply of lubrication	Air in the feed piston filling Grease level dropped below minimum level Defective pump element	Bleed the pump Refill the grease tank Replace the pump element
No grease at all points of lubrication	Pump does not work. Inoperative time is too long or period of lubrication is too short. System is blocked.	Refer to "Pump does not work". Reduce the inoperative time or increase the period of lubrication. Refer to "Excessive pressure (above 265 kgf/cm ²) of the pressure indicator".
No grease at some points of lubrication	Some pipes are burst or leakage Leakage at screwed unions	Renew the pipes Retighten or renew the screwed union
No grease at one point of lubrication	The lubrication pipe is burst or leakage Leakage at screwed unions	Renew the pipe Retighten or renew the screwed union
Reduced pump speed	High pressure in the system Low ambient temperature	Check the system / bearing points Not a defective (1 or 2 intermediate lubrication cycles may be useful)
Excessive pressure (above 265 kgf/cm ²) of the pressure indicator	Excessive pressure in the system Progressive distributor is blocked System is blocked Defective valve spring	Check the system Replace the distributor Repair clogged / seized greasing points Replace the pressure relief valve
Signal of the LED	The LED of control unit is light up continuously	Check electrical system and control unit

2. QUICK COUPLER

1) FIXING BUCKET WITH QUICK COUPLER

(1) Release the lock pins by pressing the attachment unlock switch.

(2) Tilt quick coupler forward and align the upper attaching points of the quick coupler with upper attaching points on the bucket. Raise the boom until the bucket rests in the quick coupler and tilt the quick coupler rearward until the bucket is level.





- (3) Lock the bucket with the attachment lock switch. The quick coupler pins move in the engaged position and buzzer sounds.
- * Check for engagement as followings.
- a. Put down pressure on the attachment.
- b. Back up the machine and make sure that there is no movement between the quick coupler and attachment.
- * Check that the indicator is lock position.



- Always check that the attachment is properly secured to the quick coupler by pressing the front part of the attachment against the ground.
- A Never use an attachment before you have checked its mounting.
- * If you are uncertain if the attachment is securely locked, you must visually check that the lock pins of the quick coupler are in the lock position.

2) REMOVE BUCKET FROM QUICK COUPLER

- (1) The attachment should be in a level position on the ground.
- (2) Release the lock pins by pressing the switch.
- (3) Lower the boom so that it disengage from the attachment.
- (4) Reverse away from the attachment.

3) PRECAUTION OF USING QUICK COUPLER

A When operating the machine with quick coupler, confirm that the attachment lock switch is lock position.

Operating the machine with attachment lock switch unlock position can cause the bucket to drop off and bring about the accident.

▲ Serious injury or death can result from this accident.

Α

Air cleaner ·····	6-23
Air conditioner & heater	3-36
Air conditioner filter	6-44
Axle oil ·····	6-34

В

Battery	6-41
Before starting engine	4-2
Belt tensioner ·····	6-21
Boom kick out ······	4-22
Brake line filter	6-28
Bucket leveler ·····	4-22

С

Cab device	3-1
Camera	3-43
Charge air cooler	6-20
Cigar lighter ·····	3-40
Cluster ·····	3-2
Control device	3-32
Coolant level	6-17

Е

Engine control module (ECM) ······	3-43
Engine oil filter ·····	6-15
Engine oil level ·····	6-15

F

Fan belt	6-21
FNR remote control lever	3-33
Fuel filter ·····	6-24
Fuel prefilter	6-24
Fuse box ·····	3-42

G

Gear selector lever	3
---------------------	---

Η

Hydraulic oil changing	6-26
Hydraulic oil filling	6-26
Hydraulic oil level	6-26
J	

Joystick steering control lever ------ 3-35

L

LCD	3-10
Loading and unloading	5-6
Lubrication	6-36

Μ

Machine control unit (MCU) 3-	42
Maintenance chart ······6-	13
Maintenance check list 6-	-10
Major components	2-1
Master switch ······ 3-	41
Monitor 3-	-11

Ρ

Pilot cut off switch	3-26
Pilot line filter	6-27

R

Radiator and oil cooler	6-20
Recommended lubricants	6-9
Return filter ·····	6-27
Radio and USB/MP3 player	3-44

S

Safety hints	1-1
Safety labels	0-5
Seat ·····	3-41
Specifications	2-2
Storage ·····	4-25
Switches	3-25

Т

Tightening torque ·····	6-5
Tire	6-29
Towing the machine	5-7
Transmission cold starting	4-6
Transmission control unit (TCU)	3-43
Transmission oil filter	6-32
Transmission oil level	6-32
Transportation	5-1
Travelling machine	4-10
Troubleshooting guide	7-1

W

Warming up operation	4-8
Weight ·····	2-7
Working method	4-15