

A

Air cleaner	6-24
Air conditioner & heater	3-33
Air conditioner filter	6-46
Axle oil	6-36

B

Battery	6-43
Before starting engine	4-2
Belt tensioner	6-23
Boom kick out	4-22
Brake line filter	6-30
Bucket leveler	4-22

C

Cab device	3-1
Camera	3-40
Charge air cooler	6-22
Cigar lighter	3-37
Cluster	3-3
Control device	3-30
Coolant filter (corrosion resistor)	6-17
Coolant level	6-18

E

Engine oil filter	6-15
Engine oil level	6-15

F

Fan belt	6-22
Fuel filter	6-25
Fuel prefilter	6-26
Fuse box	3-39

G

Gear selector lever	3-31
---------------------------	------

H

Hydraulic oil changing	6-28
Hydraulic oil filling	6-28
Hydraulic oil level	6-28
Hydraulic safety lever	3-31

L

LCD	3-10
Loading and unloading	5-6
Lubrication	6-38

M

Machine control unit (MCU)	3-39
Maintenance chart	6-13
Maintenance check list	6-10
Major components	2-1
Master switch	3-38
Monitor	3-10

P

Pilot line filter	6-29
-------------------------	------

R

Radiator and oil cooler	6-22
Recommended lubricants	6-9
Return filter	6-29
Radio and USB player	3-41

S

Safety hints	1-1
Safety labels	0-5
Seat	3-38
Specifications	2-2
Storage	4-26
Switches	3-24

T

Tightening torque	6-5
Tire	6-31
Towing the machine	5-7
Transmission cold starting	4-6
Transmission control unit (TCU)	3-40
Transmission oil filter	6-34
Transmission oil level	6-34
Transportation	5-1
Travelling machine	4-10
Troubleshooting guide	7-1

W

Warming up operation	4-8
Weight	2-7
Working method	4-15