

A

Air cleaner	6-23
Air conditioner & heater	3-48
Air conditioner filter	6-48
Axle oil	6-39

B

Battery	6-45
Before starting engine	4-2
Belt tensioner	6-22
Boom kick out	4-22
Bucket leveler	4-22

C

Cab device	3-1
Camera	3-55
Charge air cooler	6-20
Cigar lighter	3-52
Cluster	3-2
Control device	3-44
Coolant filter	6-26
Coolant level	6-17
Crankcase ventilation filter	6-30

D

DPF (diesel particulate filter)	6-25
---------------------------------------	------

E

Electro hydraulic control unit (EHCU)	3-55
Engine control unit (ECU)	3-55
Engine oil filter	6-15
Engine oil level	6-15

F

Fan belt	6-21
FNR remote control lever	3-45
Fuel filter	6-24
Fuel prefilter	6-29
Fuse box	3-54

G

Gear selector lever	3-45
---------------------------	------

H

Hydraulic oil changing	6-31
Hydraulic oil filling	6-31
Hydraulic oil level	6-31

J

Joystick steering control lever	3-47
---------------------------------------	------

L

LCD	3-12
Loading and unloading	5-6
Lubrication	6-41

M

Machine control unit (MCU)	3-54
Maintenance chart	6-13
Maintenance check list	6-10
Major components	2-1
Master switch	3-53
Monitor	3-13

P

Pilot cut off switch	3-36
Pilot line filter	6-33

R

Radiator and oil cooler	6-20
Radio and USB player	3-56
Recommended lubricants	6-9
Regeneration system	4-27
Return filter	6-32

S

Safety hints	1-1
Safety labels	0-6
Seat	3-53
Specifications	2-2
Steering control unit (SCU)	3-55
Storage	4-25
Switches	3-35

T

Tightening torque	6-5
Tire	6-34
Towing the machine	5-7
Transmission cold starting	4-6
Transmission control unit (TCU)	3-55
Transmission oil filter	6-37
Transmission oil level	6-37
Transportation	5-1
Travelling machine	4-10
Troubleshooting guide	7-1

W

Warming up operation	4-8
Weight	2-6
Working method	4-15