

A

Air cleaner	6-23
Air conditioner & heater	3-34
Air conditioner filter	6-43
Axle oil	6-35

B

Battery	6-40
Before starting engine	4-2
Belt tensioner	6-21
Brake line filter	6-29

C

Cab device	3-1
Camera	3-40
Charge air cooler	6-20
Cigar lighter	3-37
Cluster	3-3
Control device	3-31
Coolant filter (corrosion resistor)	6-25
Coolant level	6-18

E

Engine control unit (ECU)	3-40
Engine oil filter	6-15
Engine oil level	6-15

F

Fan belt	6-21
Fuel filter	6-24
Fuse box	3-39

G

Gear selector lever	3-32
---------------------------	------

H

Hydraulic oil changing	6-27
Hydraulic oil filling	6-27
Hydraulic oil level	6-28
Hydraulic safety lever	3-32

L

LCD	3-10
Loading and unloading	5-6
Lubrication	6-37

M

Machine control unit (MCU)	3-39
Maintenance chart	6-13
Maintenance check list	6-10
Major components	2-1
Master switch	3-38
Monitor	3-11

P

Pilot line filter	6-29
-------------------------	------

R

Radiator and oil cooler	6-20
Recommended lubricants	6-9
Return filter	6-28

S

Safety hints	1-1
Safety labels	0-5
Seat	3-38
Specifications	2-2
Storage	4-24
Switches	3-25

T

Tightening torque	6-5
Tire	6-30
Towing the machine	5-7
Transmission cold starting	4-6
Transmission control unit (TCU)	3-40
Transmission oil filter	6-33
Transmission oil level	6-33
Transportation	5-1
Travelling machine	4-10
Troubleshooting guide	7-1

W

Warming up operation	4-8
Weight	2-3
Working method	4-15