

A

Air cleaner	6-24
Air conditioner & heater	3-53
Air conditioner filter	6-49
Axle oil	6-39

B

Battery	6-46
Before starting engine	4-2
Belt tensioner	6-23
Boom kick out	4-22
Bucket leveler	4-22

C

Cab device	3-1
Camera	3-60
Charge air cooler	6-21
Cigar lighter	3-55
Cluster	3-2
Control device	3-49
Coolant level	6-17
Crankcase ventilation filter	6-27

D

DEF/AdBlue® tank	6-29
------------------------	------

E

Engine control module (ECM)	3-60
Engine oil filter	6-15
Engine oil level	6-15

F

Fan belt	6-22
FNR remote control lever	3-47
Fuel filter	6-26
Fuel prefilter	6-25
Fuse box	3-58

G

Gear selector lever	3-50
---------------------------	------

H

Hydraulic oil changing	6-32
Hydraulic oil filling	6-31
Hydraulic oil level	6-31

L

LCD	3-12
-----------	------

Loading and unloading	5-6
Lubrication	6-44

M

Machine control unit (MCU)	3-59
Maintenance chart	6-13
Maintenance check list	6-10
Major components	2-1
Master switch	3-57
Monitor	3-13

P

Pilot cut off switch	3-45
Pilot line filter	6-33

R

Radiator and oil cooler	6-21
Radio and USB player	3-61
Recommended lubricants	6-9
Return filter	6-32

S

Safety hints	1-1
Safety labels	0-6
Seat	3-56
SCR system cleaning	4-27
Specifications	2-2
Storage	4-25
Switches	3-44

T

Tightening torque	6-5
Tire	6-34
Towing the machine	5-7
Transmission cold starting	4-6
Transmission control unit (TCU)	3-60
Transmission oil filter	6-37
Transmission oil level	6-37
Transportation	5-1
Travelling machine	4-10
Troubleshooting guide	7-1

W

Warming up operation	4-8
Weight	2-6
Working method	4-15