

A

Accel dial switch	3-14
After engine start	4-5
Air breather element	6-33
Air cleaner filter	6-26
Air conditioner & heater	3-19
Air conditioner filter	6-44
Alternate exit	0-12
Attachment lowering	4-24

B

Battery	6-41
Before starting engine	4-2
Boom lowering	4-24
Booster starting	6-42
Bucket clearance adjustment	6-39
Bucket replacement	6-37
Bucket selection guide	2-10
Bucket tooth replacement	6-38

C

Cab air filter	6-44
Cab device	3-1
Changing machine control pattern	4-27
Cigar lighter	3-32
Cluster	3-2
Coolant	6-20
Cooling fan	6-24

D

Dimension and weight	5-2
Drain filter	6-33

E

Engine oil filter	6-18
Engine oil level	6-18
Engine starting & stop	4-3
Engine starting by booster	6-42
Engine stop	4-6

F

Fan belt	6-24
Fixing the machine	5-6

Fuel filter	6-28
Fuel leakage	6-30
Fuel system bleeding	6-29
Fuel tank	6-26
Fuse & relay box	3-33

G

Gauge	3-3
-------------	-----

H

Hydraulic breaker	8-1
Hydraulic oil changing	6-31-1
Hydraulic oil filling	6-31
Hydraulic oil level	6-31

L

Levers & pedals	3-17
Lifting capacities	2-6
Loading the machine	5-4
Loading and unloading by crane	5-7
Lubricant specification	6-9

M

Machine data plate	0-18
Maintenance check list	6-11
Major component	2-1
MCU (Machine Control Unit)	3-33
Mode selection system	4-8
Mounting and dismounting	1-21

N

New machine operation	4-1
-----------------------------	-----

O

Oil cooler	6-23
Operating pattern	4-27

P

Pedals	3-17
Periodical replacement parts	6-5
Pilot line filter	6-33
Pin & bushing lubrication	6-40
Prefilter	6-27
Pilot lamps	3-10

Q

Quick clamp	8-6
-------------------	-----

R

Radiator flushing	6-20
Radio & USB player	3-23
RCV lever lubricate	6-36
Recommended oils	2-16, 6-10
Relieving pressure	6-3
Reservoir tank	6-20
Return filter	6-32
RCV lever operating pattern	4-27

S

Safety hints	1-1
Safety labels	0-5
Safety parts	6-5
Seat	3-32
Seat belt	3-32
Service meter	3-34
Service socket	3-32
Specification for major component	2-13
Specification	2-2
Start switch	3-13
Storage	4-25
Suction strainer	6-32
Swing bearing grease	6-34
Swing gear & pinion grease	6-35
Swing reduction gear oil	6-34
Switch panel	3-11
Switches	3-11, 3-13

T

Torques-major component	6-8
Torques-fastener	6-6
Towing machine	4-16
Track adjustment	6-36
Track shoe selection	2-12
Transportation	5-1
Travel reduction gear oil	6-35
Traveling machine	4-14
Troubleshooting guide	7-1

U

Undercarriage	2-11
USB port	3-29

W

Warming up operation	4-6
Warning lamps	3-9
Weight	2-5
Welding repair	6-43
Windshield	3-34
Working device operation	4-13
Working method	4-17
Working range	2-4