Table of Contents

Foreword0-1		
AE	EM Safety Manual (North America Only)0-6	
Fe	deral and California Emission Control Systems0-7	
Safety.	1-1	
Sa	afety Decals1-2	
Ge	eneral	
Tr	ansportation1-31	
Op	peration 1-33	
Ma	aintenance 1-49	
Er	vironment and Circumstances 1-65	
Operati	ng Controls2-1	
Co	pmponent Locations	
Op	perator's Area2-6	
Op	perational Controls and Panels 2-9	
Di	splay Monitor	
Us	ser Menu 2-52	
He	eater and Air Conditioner Control Panel	
St	ereo	
Mi	scellaneous Electrical Devices2-93	
Se	eat Adjustment	
Er	ngine Emergency Stop Switch2-98	
Er	nergency Exit Glass Breaking Tool (STD Cabin Only)	
Mi	scellaneous Convenience Devices	
Mi	scellaneous Access Covers and Doors	

Operation3-1			
To Operate a New Forestry Machine			
Starting and Stopping Engine			
Safety Lever 3-17			
Travel			
Operating Instructions			
Operating Precautions			
Parking Forestry Machine			
Towing Procedure			
Operation Under Abnormal Conditions 3-47			
Long Term Storage 3-55			
Inspection, Maintenance and Adjustment4-1			
Maintenance Information 4-1			
Machine Setup Position for Maintenance 4-5			
Maintenance Handling Access 4-7			
Handling Oil, Fuel, DEF (AdBlue), Coolant			
Electrical System Maintenance 4-14			
Recommend Fuel, Coolant, and Lubricant			
Fluid Capacities			
Table of Recommended Lubricants 4-21			
Maintenance Intervals			
10 Hour / Daily Service 4-26			
50 Hour / Weekly Service 4-39			
250 Hour / Monthly Service 4-44			
500 Hour / 3 Month Service 4-46			
1,000 Hour / 6 Month Service 4-57			
2,000 Hour / Yearly Service 4-68			
4,000 Hour / Biennial Service 4-74			
4,500 Hour / Biennial Service 4-75			
12,000 Hour / 6 Year Service 4-78			

Air-conditioning System	4-79
Electrical System	4-80
Engine Cooling System	4-85
Fuel Transfer Pump (Optional)	4-89
Handling of Accumulator	4-92
Track Tension (If Equipped Type 1)	4-93
Track Tension (If Equipped Type 2)	4-95
Venting and Priming Hydraulic System	4-97
Maintenance in Special Conditions	4-99
Transportation	5-1
Loading and Unloading	5-2
Lifting Machine	5-8
Specification	6-1
Standard Specification	6-1
Overall Dimensions	6-2
Disassembled Parts, Dimension and Weight	6-5
Ground Pressure	6-7
Working Range	6-8
Forestry Machine RATED Lift Capacity Tables	6-11
Approximate Weight of Workload Materials	6-16
Index	7-1

Foreword

This Operation & Maintenance Manual was written to give owner or operator instructions on safe operation and maintenance of HYUNDAI equipment. READ AND UNDERSTAND THIS OPERATION AND MAINTENANCE MANUAL BEFORE OPERATING YOUR HYUNDAI EQUIPMENT. Keep this manual in the cabin so it is always available. If it is lost, order another one from your HYUNDAI distributor.

If there are any questions, contact your HYUNDAI distributor. This manual may illustrate options and accessories not installed on your equipment.

Any modification made without written authorization or approval from HYUNDAI can create a safety hazard.

Always replace parts with genuine HYUNDAI parts or HYUNDAI authorized replacement parts.

Intended Use

The machine is intended to be used under normal conditions for applications described in this manual. If it is used for other purposes, or in potentially hazardous environments, special precautions must be followed and the machine must be equipped for such use. Examples include, but are not limited to, are: falling object guards, work lights, etc. Do not engage in prohibited uses as described in this manual. Contact your HYUNDAI distributor for further information.

Engine and Emission Control System Maintenance

Proper inspection, maintenance and repair is essential to keeping engine and machine systems properly operating. This includes proper inspection and maintenance of the machine's emission control system. This could include machine and engine components, such as an EGR (Exhaust Gas Recirculation) system, fuel system, turbocharger, electrical system, air intake system and/or cooling system.

As a heavy-duty off-road diesel engine owner, you are responsible for performing required maintenance. The required maintenance procedures are outlined in this Operation & Maintenance Manual, or Shop Manual. Do not remove, alter, or render inoperative, any emission control system.

Machine Capacity

Do not exceed machine capacity by modifying machine or using unapproved attachments.

Exceeding machine capacity can adversely affect machine performance characteristics such as: stability, system certifications such as brakes and steering, the Roll-over Protective Structure (ROPS) and can result in death or serious injury. Contact your HYUNDAI distributor for further information.

California Proposition 65

Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a wall-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information go to www.P65Warning.ca.gov.

Product Identification Number (PIN)

A PIN number is stamped on upper frame under boom foot (Figure 1). It is also stamped on a product identification plate (Figure 2) on outside of cabin on right-hand side.

NOTE: Record these numbers and their locations. These will be required whenever warranty or service work is requested. Keep these numbers on file in case machine is stolen.











Figure 3

Component Serial Numbers

There are many serial numbers on each traceable component of the machine. Record these numbers and their locations. These will be required whenever warranty service work is requested.

Engine Data Plate

The engine data plate provides important facts about the engine. The engine serial number (ESN) and control parts list (CPL) provide information for service and ordering parts. The engine data plate must not be changed unless approved by HYUNDAI.

The engine data plate and engine serial number are located on the head cover. Have the following engine data available when communicating with a HYUNDAI Authorized Repair Location. The following information on data plate is mandatory when sourcing service parts:

Reference Number	Description
1	Engine Data Plate
2	Engine Serial Number



Your Machine Serial Numbers

Product Identification Number (PIN)	
Machine Serial No.	
Engine Serial No.	
Main Pump	
Swing Motor	
Travel Motor	
Main Control Valve	

Safety Messages

Safety messages and safety decals included in this manual and on the machine provide instructions how to operate, service and maintain the machine. Safety messages and safety decals indicate potential hazards and describe safety precautions required to avoid hazards. Operator and maintenance personnel should read and understand these safety messages and decals before beginning operation or maintenance.



Be Prepared - Get to Know All Operating and Safety Instructions.

This is a Safety Alert Symbol. Wherever it appears in this manual or on safety decals on the machine, you must be alert to the potential for personal injury or accidents. Always observe safety precautions and follow recommended procedures.

Signal Words

The signal words "DANGER", "WARNING", "CAUTION" are used throughout safety messages and safety decals in this manual or on the machine. They indicate an existence of, and the relative seriousness of, a hazard. All three indicate that a safety risk is involved. Observe the precautions indicated whenever a Safety Alert Symbol is present, no matter which signal word appears next to it.



DANGER - This signal word is used on safety messages and safety labels and indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING - This signal word is used on safety messages and safety labels and indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION - This signal word is used on safety messages and safety labels and indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.

Other Signal Words

In addition to safety signal words, the following signal words are used to indicate proper and effective use of machine.



This signal word identifies procedures which must be followed to avoid damage to machine.

NOTE: The word "NOTE" identifies information for effective use.

AEM SAFETY MANUAL (NORTH AMERICA ONLY)

The AEM Safety Manual delivered with the machine gives general safety information.

The AEM Safety Manual must be read and understood before beginning operation or maintenance and is not intended to replace the Operation & Maintenance Manual delivered with the machine.



Figure 5

FG020060

FEDERAL AND CALIFORNIA EMISSION CONTROL SYSTEMS

Limited Warranty for Non-road Engines (CI) (FDICL05.8LEA (DL06P))

Owner's Warranty Rights and Obligations

The U.S. Environmental Protection Agency (EPA), the California Air Resources Board (ARB), and HYUNDAI are pleased to explain the Federal and California Emission Control System Warranty on your 2015MY to 2017MY non-road engine. HYUNDAI has designed, built and equipped the engine so as to conform at the time of sale with all applicable regulations of the EPA and of the California ARB. In California, new heavy-duty off-road engines must be designed, built and equipped to meet the State's stringent anti-smog standards.

HYUNDAI must warrant to the initial owner, and each subsequent owner, the emission control system on your engine for the periods of time listed below provided there has been no abuse, neglect, improper maintenance or unapproved modifications of your engine. Your emission control system may include those parts listed below:

1. Fuel Metering System

Fuel Supply Pump (HP Pump), Injector, Common Rail, Glow Plug

2. Air-Induction System

Intake Manifold, Turbocharger System

3. Exhaust Gas Recirculation (EGR) System

EGR Valve, EGR Cooler

4. Catalyst or Thermal Reactor System

Diesel Oxidation Catalyst (DOC), Exhaust Manifold, SCR System, Catalyst, NOx Sensor

5. Positive Crankcase Ventilation (PCV) System

Right Head Cover

6. Electronic Control System

ECU, Cam/ Crank Sensor, Coolant Temperature Sensor, MAF Sensor, MAP Sensor (Manifold Pressure Sensor), Inlet Boost Temperature Sensor, Fuel Temperature Sensor, Common Rail Pressure Sensor

7. Miscellaneous Items Used In Above Systems

Temperature and time sensitive valve and switches

Solenoids and wiring harnesses

Hoses, clamps, fittings and tubing, sealing gasket

- Pulleys, belts and idlers
- Emission control information labels

Where a warrantable condition exists, HYUNDAI CONSTRUCTION EQUIPMENT will repair your heavy-duty off-road engine at no cost to you including diagnosis, parts, and labor.

Manufacturer's Warranty Coverage

The 2015MY to 2017MY heavy-duty off-road engines are warranted for <u>five years or 3,000 hours</u> of operation, whichever occurs first. If any emission-related part on your engine is defective, the part will be repaired or replaced by HYUNDAI.

The warranty period shall begin on the date the machine is delivered to the first retail customer.

Owner's Warranty Responsibilities

As the heavy-duty off-road engine owner, you are responsible for the performance of the <u>required maintenance</u> <u>listed in the Operation and Maintenance Manual</u>. HYUNDAI recommends that you retain all receipts covering maintenance on your heavy-duty off-road engine, but HYUNDAI cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the heavy-duty off-road engine owner, you should however be aware that HYUNDAI may deny you warranty coverage if your heavy-duty off-road engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

Your engine is designed to operate on **Ultra Low Sulfur Diesel Fuel Only.** Use of any other fuel may result in your engine no longer operating in compliance with the EPA's emissions requirements.

You are responsible for initiating the warranty process. The EPA and California ARB suggest that you present your heavy-duty off-road engine to a dealer as soon as a problem exists.

The warranty repairs should be completed by the dealer as expeditiously as possible.

If you have any questions regarding your warranty rights and responsibilities, you should contact your nearest authorized Hyundai dealer.



SAFETY DECALS

Safety decals are attached to the machine to alert the operator or maintenance person about potential hazards, the consequences of potential injury, and instructions and/or actions required to avoid the hazard. The location of the safety decals and the description of the decals are reviewed in the following section. Please become familiarized with all safety decals and their messages.

Make sure that all the safety decals are in their correct location and legible. Clean or replace the safety decals if they are damaged, missing, or the texts and pictorials are not legible. When you clean the safety decals, use a soft cloth, water, and soap. Do not use solvent, gasoline, or other harsh chemicals to clean the safety decals because this could loosen the adhesive that secures the decals to the machine. Remember, if a safety decal is attached to a part that is replaced, install a new safety decal on the replacement part.

This machine uses safety decals with and without text. The type and number of safety decals can vary depending upon geographical regions and machine models.

Safety Decals With Text

Safety decals with text consist of a signal word, pictorial and a text message panel. In some cases, a pictorial panel may not be part of the safety decal.

Safety Decals Without Text (No-Text)

Safety decals without text consist of a hazard panel(s) and avoidance panel(s). Hazard panels are located at the top or left side and the avoidance panels are located at the bottom or right side of the decal depending on its configuration. The hazard panels use a black triangular band and a pictorial to identify the hazard and the potential consequences of failure to follow the instructions. Avoidance panels use pictorials and/or prohibition signs to identify the actions necessary to avoid the hazard.

A safety decal may contain more than one hazard panel and more than one avoidance panel.

Hazard Panel Avoidance Panel Horizontal Configuration Hazard Avoidance Panel Panel





Figure 1

Information and Location for Safety Decals

STD Cabin



Figure 2

DS1801364



Figure 3

DS1801365



Figure 4



EX1301176



AVOID DEATH OR SERIOUS INJURY

- Never use forestry machine without instructions.
- Read Operation & Maintenance Manual before operation.
- Sound the horn to alert bystanders before operating.
- Always fasten your seat belt.
- Explosion or electrocution can occur if machine contacts utility lines or pipes. Check for overhead or underground lines before operating.
- Secure and lock front window when it is in raised position.
- Attachment interference can cause death, serious injury or machine damage. Check attachment to machine clearance through full working cycle before operation.
- Keep bystanders out of swing area and travel path and always look in travel direction.
- Ensure mirrors and rear view camera are clean and working properly.
- Never operate machine from outside the operator's position.
- TO LEAVE THE FORESTRY MACHINE:
 - 1) Lower the attachment and dozer blade (if equipped) to the ground and make sure all controls are in neutral.
 - 2) Stop engine and remove key.
 - 3) Lower safety lever to LOCK position.



AVOID DEATH OR SERIOUS INJURY

- Stop engine and remove key.
- Attach "DO NOT OPERATE" warning tag to the controls before servicing the machine.
- Do not operate when performing inspection or maintenance.
- 3. Keep Bystanders Away (950205-03803)



AVOID DEATH OR SERIOUS INJURY

- Keep out of swing area and travel path.
- Always look in travel direction.
- Make sure swing area is clear of bystanders and objects.
- 4. Hot Pressurized Fluid (950205-03781)



HOT PRESSURIZED FLUID CAN CAUSE SERIOUS BURNS

- Do not loosen or open cap when hot.
- Before opening:
 - 1) Turn engine off.
 - 2) Allow machine to cool.
 - 3) Tip cap and open slowly to relieve pressure.
- 5. Entanglement in Rotating Parts (950205-03791)



ROTATING PARTS CAN CAUSE DEATH OR SERIOUS INJURY

Keep away from belt and rotating parts. Stop engine before servicing.



EX1301177



EX1301178



EX1301180





CONTACT WITH ROTATING FAN CAN CAUSE DEATH OR SERIOUS INJURY

Keep away from fan and rotating parts. Stop engine before servicing.



EX1301182

7. Battery Explosion (950205-03785)



AVOID DEATH OR SERIOUS INJURY

- Read and follow instructions in Operation & Maintenance Manual for battery maintenance.
- Keep arcs, sparks, flames, and lighted tobacco away.
- Do not store metal tools or flammable materials on or around batteries.
- Wear safety goggles and rubber gloves when working with batteries.
- If battery acid contact occurs:
 - 1) Flush your skin with water immediately and apply baking soda or lime to neutralize the acid.
 - 2) Flush your eyes with water for 10 15 minutes.
 - 3) Get medical attention immediately.
- 8. Battery Disconnection (950205-03784)



AVOID ELECTRICAL COMPONENT DAMAGE

Disconnecting the battery while the engine is running can cause damage to electrical components.

Disconnect battery only when the engine is turned OFF.



EX1301184





HIGH-PRESSURE GREASE CAN CAUSE DEATH OR SERIOUS INJURY

- Track adjusting systems use grease under highpressure which can penetrate body if improperly serviced.
- NEVER LOOSEN track tension grease valve more than one complete turn from the fully tightened position.
- Bleed off pressure slowly and keep body away from grease valve.
- Wear eye protection.
- Read and follow instructions in Operation & Maintenance Manual for more information on track adjustment.
- 10. Crush Hazard (950205-03805)



AVOID DEATH OR SERIOUS INJURY

Stay clear of the boom, arm, and attachment.



EX1301185



EX1301186

11. Pressurized Gas and Fluid (950205-03782)



AVOID DEATH OR SERIOUS INJURY

- Heat or impact can cause the accumulator to explode.
- Keep away from flame.
- Do not weld on or drill into accumulator.





AVOID DEATH OR SERIOUS INJURY

Do not step in this area.



EX1301188

13. Hot Surface (950205-03777)



HOT SURFACE CAN CAUSE SERIOUS BURNS

- Do not touch hot surface.
- Allow to cool before servicing.



EX1301189

- 14. Emergency Exit (950205-03810, 950205-05761)
 - STD Cabin



If primary exit is blocked, use glass breaking tool to break glass for secondary exit.



EX1301190

Oregon Cabin



If primary exit is blocked, escape through the emergency door at the roof of cabin.





AVOID INJURY OR DEATH

Read and understand the Operation & Maintenance Manual for more information.

Refer to "Operating Instructions" section of this manual for details regarding the work levers (joysticks) control functions.

BHL Control Pattern (US Only) (950205-03868A)



AVOID INJURY OR DEATH

Read and understand the Operation & Maintenance Manual for more information.

Refer to "Operating Instructions" section of this manual for details regarding the work levers (joysticks) control functions.

17. Ultra Low Sulfur Diesel Fuel (Optional) (950205-03863)



Only use Ultra Low Sulfur Diesel (ULSD) fuel with this machine.



EX1301191



EX1503819



18. ROPS Warning (Oregon Cabin Only) (950205-03861)



AVOID DEATH OR SERIOUS INJURY

- Do not weld on or drill holes in the protective structure.
- Replace ROPS, if damaged or modified.



EX1301197

19. Falling Object (950205-03786)



UNSUPPORTED DOOR CAN FALL CAUSING DEATH OR SERIOUS INJURY

- To open door:
 - 1) Hold door firmly.
 - 2) Lift door slowly until locking device engages.
- To close door:
 - 1) Hold door firmly.
 - 2) Press locking device to disengage.
 - 3) Lower door slowly.



20. Hydraulic Oil Check (Optional) (950205-06281, 950205-03965, 950205-06282)



INCORRECT OIL LEVEL OR INCORRECT FLUID CAN CAUSE HYDRAULIC SYSTEM DAMAGE

Place the machine with the boom and arm fully extended with the attachment on the ground before checking hydraulic fluid level.

Use hydraulic oil which is suitable for machine.



EX1505097



EX1505098





AVOID HYDRAULIC SYSTEM DAMAGE

To adjust breaker impact, see Operation & Maintenance Manual for additional instructions.



EX1301200

22. Lift/Tie down (950205-03815)

23. Tie down (950205-03816)

Identifies tie down point location.

Identifies lift point and tie down point location.



EX1301201

950205-03816

EX1301203

24. Electric Welding Attention (950212-02440)



Electrical welding on the frame can damage the engine's electronic control unit (ECU) and dosing control unit (DCU).





AVOID DEATH OR SERIOUS INJURY

Not a lift point for machine.

Refer to "Lifting Machine" section of this manual for details regarding the lifting point.

26. DEF (AdBlue) (950205-01489A)



- Use only the specified diesel exhaust fluid.
- See the Operation & Maintenance Manual for more information.





27. Lifting Capacity (950205-05450)



AVOID DEATH OR SERIOUS INJURY

Whenever you handling and lifting objects, ensure operator manual available on the station and refer lifting chart.



WE1500865



AVOID INJURY OR DEATH

Read and understand the Operation & Maintenance Manual for more information.

Refer to "Operational Controls and Panels" section of this manual for details regarding the Rotating/Shear switch control functions.

29. Crush Harzard (950205-03787)



AVOID DEATH OR SERIOUS INJURY

- Keep out of cabin tilting area.
- Make sure cabin tilting area is clear of bystanders and objects.



DS1601292



EX1402207

30. Cabin Tilting Warning (950205-05648)



AVOID DEATH OR SERIOUS INJURY

- Keep out of cabin tilting area.
- When you are tilting the cabin, pay attention to the move of the cabin.



DS1601293

31. California Proposition 65 (950205-07650)



DS1801347

Safe Operation is Operator's Responsibility

Only trained and authorized personnel should operate and maintain the machine.

Follow all safety rules, regulations and instructions when operating or performing maintenance on machine.

- Do not operate machine if you are under the influence of drugs or alcohol. An operator who is taking prescription drugs must get medical advice to determine if he or she can safely operate a machine.
- When working with other personnel on a work site, be sure that all personnel know nature of work and understand all hand signals that are to be used.
- Be sure that all guards and shields are installed in their proper location. Have guards and shields repaired or replaced immediately if damaged.
- Be sure that you understand the use and maintenance of all safety features such as safety lever and seat belt. Use them properly.
- Never remove, modify or disable any safety features. Always keep them in good operating condition.
- Always check for and know the location of underground and overhead utility lines before working.
- Failure to use and maintain safety features according to instructions in this manual, Safety Manual and Shop Manual can result in death or serious injury.

Know Your Machine

Know how to operate your machine. Know the purpose of all controls, gauges, signals, indicators and monitor displays. Know the rated load capacity, speed range, braking and steering characteristics, turning radius and operating clearances. Keep in mind that rain, snow, ice, loose gravel, soft ground, slopes etc., can change operating capabilities of your machine.

Proper Work Tools and Attachments

Only use work tools and attachments that are recommended by HYUNDAI for use on HYUNDAI machines. When installing and using optional attachments, read instruction manual for attachment, and general information related to attachments in this manual. Because HYUNDAI cannot anticipate, identify or test all attachments that owners may want to install on their machines, contact HYUNDAI for written authorization and approval of attachments, and their compatibility with optional kits.

Attachments and attachment control systems that are compatible with the machine are required for safe and reliable machine operation. Do not exceed maximum operating weight (machine weight plus attachment) that is listed on ROPS certification plate.

Make sure that all guards and shields are in place on machine and on work tool. Depending on type or combination of work equipment, there is a potential that work equipment could interfere with the cabin or other parts of machine. Before using unfamiliar work equipment, check if there is any potential of interference, and operate with caution.

While you are performing any maintenance, testing, or adjustments to attachments, stay clear of the following areas: cutting edges, pinch points, and crushing surfaces.

Never use attachment as a work platform or manlift.

Contact your HYUNDAI distributor about auxiliary hydraulic kits for attachments installation. If you are in doubt about compatibility of a particular attachment with a machine, consult your HYUNDAI distributor.

Pressurized Fluids

Pressurized air or fluids can cause debris and/or fluids to be blown out. This could result in death or serious injury.

Immediately after operations are stopped, coolant, engine oil, and hydraulic oil are at their highest temperatures and the radiator and hydraulic tank are still under pressure. Always wait for temperature to cool down. Follow specified procedures when attempting to remove caps, drain oil or coolant, or replacing filters. Always wait for temperature to cool down, and follow specified procedures when performing these operations. Failure to do so can result in death or serious injury.

When pressurized air and/or pressurized water is used for cleaning, wear protective clothing, protective shoes, and eye protection. Eye protection includes goggles or a protective face shield.

Pressure can be trapped in a hydraulic system and must be relieved before maintenance is started.

Releasing trapped pressure can cause sudden machine movement or attachment movement. Use caution if you disconnect hydraulic lines or fittings.



Figure 5

FG018457

High-pressure oil that is released can cause a hose to whip or oil to spray. Fluid penetration can result in death or serious injury. If fluid enters skin or eyes, get immediate medical attention from a physician familiar with this injury.

Obey all local laws and regulations for disposal of liquids.

To prevent hot coolant from spraying out, stop engine and wait for coolant to cool. Using gloves, slowly loosen cap to relieve pressure.

Flying or Falling Objects

On work sites where there is a potential hazard that flying or falling objects can hit operator's cabin, select and use a guard to match operating conditions for additional operator protection.

Working in mines, tunnels, deep pits, and loose or wet surfaces, could produce hazard of falling rocks or flying objects. Additional protection for operator's cabin could be required such as an Operator Protection Guard (OPG) or window guards. Contact your HYUNDAI distributor for information on available protective guards.

To prevent personnel from being struck by flying objects, keep personnel out of work area.







Figure 7

HAOA100L

Personal Protective Equipment (PPE)

Do not wear loose clothing and accessories. Secure long hair. These items can snag on controls or on other parts of equipment.

Do not wear oily clothes. They are highly flammable.

Do not forget that some risks to your health may not be immediately apparent. Exhaust gases and noise pollution may not be visible, but these hazards can cause disabling or permanent injuries. Breathing masks and/or ear protection may be required.

Wear a hard hat, safety shoes, safety goggles, mask, leather gloves, earplugs and other protective equipment, as required.

While working on machine, never use inadequate tools. They could break or slip, or they may not adequately perform intended functions.

Correction of Machine Problems

If any machine problems are found during operation and maintenance (noise, vibration, smell, incorrect gauges, smoke, oil leakage, etc.), or if any abnormal warning alerts are displayed on display monitor, stop the machine and take the necessary corrective actions. Do not operate machine until problem has been corrected.

Crushing and Cutting

Keep objects away from moving fan blades. Fan blades can throw and cut objects.

Do not use a wire rope that is kinked or frayed, or a wire rope with any loss of diameter. Wear leather gloves when handling a wire rope.

When striking a loose retainer pin, it can fly out and can cause a serious injury. Make sure that area is clear of personnel when striking a retainer pin. To avoid injury to your eyes, wear safety goggles when striking a retainer pin.

Do not put your hand, arm or any other part of your body between movable parts. If going between movable parts is necessary, always position and secure work equipment so it cannot move. Properly support equipment before performing any work or maintenance under raised equipment.

If control levers are operated, clearance between machine and work equipment will change and this may lead to serious damage or can result in death or serious injury. Stay clear of areas that may have a sudden change in clearance with machine movement or equipment movement. Stay clear of all rotating and moving parts. Unless instructed, never attempt adjustments while machine is moving or while engine is running.



Figure 8

Do not depend on hydraulic cylinders to support raised equipment. Equipment can fall if a control is moved, or if a hydraulic line breaks, is loosened or disconnected.

If it is necessary to remove guards to perform maintenance, always install guards after maintenance is completed.



HDO1010L

Figure 9

Hot Coolant and Oils - Burn Prevention

Do not touch any part of an operating engine. Immediately after operations are stopped, coolant, engine oil, and hydraulic oil are at their highest temperatures. The radiator and hydraulic tank are still under pressure. Always wait for temperature to cool down. Attempting to remove caps, drain oil or coolant, or replacing filters may lead to serious burns, if done when hot. Relieve all pressure in air system, hydraulic oil system, lubrication system, fuel system, and cooling system, before any lines, fittings or related items are disconnected.

To prevent hot oil or coolant from spraying out, stop engine, wait for oil and coolant to cool. Using gloves, slowly loosen cap to relieve pressure.







Figure 11

Fire and Explosion Prevention

All fuels, most lubricants and some coolant mixtures are flammable and can cause a fire resulting in death or serious injury, and property damage. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause fire.

Inspect for and remove all flammable materials such as spilled fuel and oil, and debris from machine. Do not allow any flammable materials to accumulate on machine.

Always observe the following:

- Add fuel, oil, antifreeze and hydraulic fluid to machine only in a well ventilated area. Machine must be parked with controls, lights and switches turned "OFF". Engine must be "OFF" and any flames, glowing embers, auxiliary heating units or spark causing equipment must be extinguished, or turned "OFF" and kept well clear of machine.
- Dust that is generated from repairing or grinding nonmetallic hoods or nonmetallic fenders can be toxic, flammable and explosive. Repair these components in a well ventilated area away from flames or sparks and wear dust mask when grinding painted parts.

Maintenance

The machine and some attachments have components that are at high temperatures under normal operating conditions. The primary source of high temperatures are the engine and exhaust system. If damaged or incorrectly maintained, the electrical system can be a source of arcs or sparks.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it can cause a fire hazard. Clean machine often to avoid this accumulation. Flammable debris in an engine compartment is a potential fire hazard.

The operator's area, engine compartment and engine cooling system must be inspected every day and cleaned. This is necessary to prevent fire hazards and overheating.

Operation

Do not use machine where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.

Do not operate machine near any flame.

Exhaust shields (if equipped) protect hot exhaust components from oil spray or fuel spray in case of a break in a line, hose, or seal. Exhaust shields must be correctly installed.



Figure 12

FG018458

Figure 13

Safety 1-23

Electrical

Check all electrical wiring and connections for damage daily.

Keep battery terminals clean and tight. Repair or replace any damaged part or wires that are loose or frayed. Clean all electrical connections and tighten all electrical connections.

Never check battery charge by placing a metal object across terminal posts. Use a voltmeter or a hydrometer.

Battery gas can explode and can result in death or serious injury. Follow procedures in this manual for connecting battery and for jump-starting. Do not jump-start or charge a frozen or damaged battery. Keep any flames or sparks away from batteries. Do not smoke in battery charging area.

Improper jumper cable connections can cause an explosion that can result in death or serious injury. Refer to "Starting Engine with a Booster Cable" on page 3-12, for proper procedure in this manual.

Do not charge a frozen battery. This can cause an explosion.

After market radios or other electric operated equipment in cabin must have a fuse in the electrical circuit.

Hydraulic System

Check hydraulic tubes, hoses and fittings for damage, wear or for leaks. Hydraulic lines and hoses must be properly routed and have adequate support and secure clamps. Leaks can cause fires. Never use a flame or bare skin to check for leaks.

Tighten or replace any parts that show leakage.

Check that all hose and tube clamps, guards, and cushions are securely attached. If they are loose, they can vibrate during operation and rub against other parts. This can cause damage to hoses and cause high-pressure oil to spray on hot surfaces, causing a fire and death or serious injury.

Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.



Figure 14
Fueling

Use caution when you are refueling a machine.

Fuel is flammable and can catch fire if it is brought close to a flame.

Stop engine and let it cool before adding fuel. Do not smoke while you are refueling a machine. Do not refuel a machine near flames or sparks. Fill fuel tank outdoors.

Keep fuel and other fluid reservoir caps tight and do not start engine until caps have been secured.

Store fuels and lubricants in properly marked containers away from unauthorized personnel. Store oily rags and any flammable materials in protective containers.

Static electricity can produce dangerous sparks at fuel filling nozzle. In very cold, dry weather or other conditions that could produce a static discharge, keep tip of fuel nozzle in constant contact with neck of fuel filling nozzle, to provide a ground.

Always place plastic fuel containers on the ground before filling.

Never Use Ether Starting Aids

Do not use ether or starting fluids on any engine that has glow plugs, or an electric grid type manifold heater. These starting aids can cause an explosion and result in death or serious injury.

Use procedures in this manual for connecting battery and for jump-starting.



Figure 15





Welding and Grinding

Always clean machine and attachment, set battery disconnect switch to "OFF" position, and disconnect wiring from electronic controllers before welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near machine when welding.

Toxic dust or gas can be produced when grinding or welding painted parts. Grinding or welding painted parts must be done in a well ventilated area. Wear dust mask when grinding painted parts.

Dust generated from repairing nonmetallic parts such as hoods, fenders or covers can be flammable or explosive.

Repair such components in a well ventilated area away from flames or sparks.

Do not weld on lines or on tanks that contain flammable fluids. Do not flame cut lines or tanks that contain flammable fluid. Clean any such lines or tanks thoroughly with a nonflammable solvent before welding or flame cutting.

If a Fire Occurs

If a fire occurs:

- Do not attempt to move machine or continue operations.
- Turn starter switch to "O" (OFF) position to stop engine.
- Use handrails, guardrails and steps to get off machine.
- Immediately call for help or fire station.
- When using a fire extinguisher, always aim extinguisher at base of fire.
- If an optional fire extinguishing system is in place, be familiar with its operating procedures.
- **NOTE:** Depending on job conditions, other procedures could be necessary if a fire occurs.

Fire Extinguisher and First-aid Kit (Emergency Medical Kit)

To be prepared in the event of a fire:

- Be sure that fire extinguishers have been provided and read labels to ensure that you know how to use them. It is recommended that an appropriately sized (2.27 kg [5 lb] or larger) multipurpose A/B/C fire extinguisher be mounted in cabin. Check and service fire extinguisher at regular intervals and make sure that all work site crew members are adequately trained in its use.
- Inspect fire extinguisher and service fire extinguisher regularly.
- Follow instructions on extinguisher instruction plate.
- Keep a first aid kit in cabin and keep another kit at work site. Check kit periodically and keep it properly supplied.
- Keep emergency numbers for doctor, ambulance service, hospital and fire department readily available.



FG018459

Figure 17





HDO1009L

Electrical System and Electrical Shock

Never short across starter terminals or across batteries. Shorting could damage electrical system and engine neutral start system.

When engine is running or immediately after it has stopped, high voltage is generated at injector terminal and inside engine controller, so there is a potential for an electrical shock. Never touch injector terminal or inside of engine controller.

NOTE: If it is necessary to touch injector terminal or inside engine controller, contact your HYUNDAI distributor.

Operator Protective Guards and Structures (Optional)

The machine may have different types of guards for operator protection. the type of guards might be vary on the applications and work demands.

Inspect and check the guards daily to ensure no cracks, bent or loose. DO NOT modify the protective structure, guards by welding, grinding, drilling holes or adding attachments. Changes to the cabin can cause loss of operator protection from roll-over and falling objects, and result in death or serious injury.

Always wear your seat belt when operating machine.

Logging operation required the protection from flying debris and / or objects. When use a work tool create flying debris, install a front guard. Close the window and wear safety goggles.

Protecting Cabin from Flying or Falling Objects (Optional)

In a work site where additional operator protection is necessary from falling or flying objects, install adequate protective guards on the cabin.

For breaker operation, install a front guard and apply a laminated coating sheet to front glass. Contact your HYUNDAI distributor for recommendations.

When performing demolition or cutting operation, install a front guard and top guard.

Apply a protective laminated coating sheet to outside of front window. This will prevent glass from being scratched by dust when cleaning it or running wipers.

Never attempt to alter or modify any protective structure reinforcement system, by drilling holes, welding, remounting or relocating fasteners. Any serious impact or damage to system requires a complete inspection of the structure. Reinstallation, recertification and/or replacement of system may be necessary.

Contact your HYUNDAI distributor for available safety guards and/or recommendations to protect against objects that could strike operator's cabin. Make sure that all other work site crew members are kept away from machine when operating.

If any glass on machine is broken, replace it with new glass immediately.

NOTE: The preceding instructions assume that conditions are for standard operations, but it may be necessary to add additional guards depending on operating conditions or local rules or regulations for the work site. Always contact your HYUNDAI distributor for advice.



Figure 19

EX1503837

Emergency Exit from Operator's Station

STD Cabin

This machine is equipped with a glass breaking tool. It is found on left pillar of cabin. This tool can be used to break the glass to exit from cabin in an emergency. Grip handle firmly and use sharp point to break glass.

• Be careful also not to slip on broken pieces of glass on ground.



AVOID DEATH OR SERIOUS INJURY

Protect your eyes when breaking the glass.

Oregon Cabin

This model is equipped with an emergency exit on the roof of the cabin, through which you can escape when the regular door is blocked.

NOTE: In case the operator is not able to open the emergency door, another person can open it from outside.



Figure 20



Figure 21



Regulation 8.35(2) of the Mines Safety and Inspection Regulations (1995)

A person who has possession at a mine of any electrical detonators must ensure that those detonators are kept at a safe distance from sources of electromagnetic radiation to prevent the possibility of induced ignition of the detonators by such sources.

Information in regard to the determination of 'Safe Separation Distances' should be available from respective explosives manufacturers/suppliers, and may also be referenced from:

British Standard BS6657:1991 - Guide to Prevention of inadvertent initiation of electro-explosive devices by radio-frequency radiation.

TRANSPORTATION

Obey State and Local Over-the-Road Regulations

Check federal, state and local laws and regulations regarding weight, width and length of a load before making preparations for transporting on public roads or highways.

The hauling vehicle, trailer and load must be in compliance with applicable regulations for the shipping route.

Partial disassembly of machine may be necessary to meet travel restrictions or particular conditions at work site. See Shop Manual for information on partial disassembly.

Refer to "Transportation" on page 5-1, for information on loading, unloading and towing.

The machine can be disassembled into parts for transporting. Contact your HYUNDAI distributor for assistance with disassembly.

Loading and Unloading

To prevent machine tipping or roll-over when loading or unloading machine, always do the following:

- Perform loading and unloading only on firm and level ground. Maintain a safe distance from edge of road or drop-off.
- Never use work equipment to load or unload machine. The machine may fall or tip over.
- Always use loading ramps of adequate strength and capacity. Be sure that ramps are wide, and long enough to provide a safe loading slope. Take steps to prevent ramps from moving out of position or coming off.
- Clean ramp surfaces so they are free of grease, oil, ice and loose materials. Remove dirt from machine tracks and undercarriage. On a rainy day, be careful since ramp surfaces can be slippery.
- Turn auto idle switch "OFF".
- Run engine at low speed and travel slowly.
- When on ramps, do not operate any control lever except for travel lever.
- Never correct your steering on ramps. If necessary, drive off ramps, correct machine direction, then drive back onto ramps.
- When driving up or down ramps, the center of gravity of machine will change suddenly causing the tracks to drop down to the ramps or trailer. This will occur at the joint between the ramps and trailer. Travel slowly over this point.

• For machines equipped with a cabin, always lock door after loading machine to prevent door from suddenly opening during transportation.

Transporting Machine

When transporting machine on a trailer or truck, do the following:

- The weight, transportation height, and overall length of machine may change depending on work equipment attached to it. Always check the machine dimensions and work equipment's dimensions before transporting.
- When passing over bridges or structures on private land, check that structure is strong enough to support weight of machine. Before traveling on public roads, check with appropriate authorities and follow their instructions.

OPERATION

Always make sure that the machine is properly maintained.

Before Engine Starting

Machine Condition

Every day before starting engine for first time, perform the following checks and repair machine before operating, as necessary. If these checks are not properly done death or serious injury could result.

- Check coolant, fuel, and hydraulic tank oil levels, and check for clogged air cleaner and damage to electrical wiring.
- Check operation of gauges, cameras (if equipped) and angle of mirrors, and check that safety lever is in LOCKED position.
- Check that work equipment and travel controls move freely, and work controls return to "NEUTRAL" when released.
- Check that attachment is properly attached and locked.

Make sure that the machine is equipped with a lighting system that is adequate for job conditions and lights are working properly.

Before moving machine, check position of undercarriage. The normal travel position is with idler wheels to front under cabin and drive sprockets to rear. When undercarriage is rotated in reversed position, directional or travel controls must be operated in opposite directions.

Before performing checks, move machine to an area where there are no obstructions, and operate slowly. Do not allow personnel near machine.

Know maximum operating dimensions of your machine.

Work Site

Before starting operations, thoroughly check work area for any hazards, such as underground utility lines, overhead electrical lines, unstable ground, excessive slopes, etc.

Before starting engine and moving machine, make sure that no one is underneath machine, around machine, or on machine.

Know width and length of your machine and work equipment to maintain proper clearance when you operate machine or work equipment near fences or near boundary obstacles.

Know appropriate work site hand signals and personnel that are authorized to give hand signals. Follow hand signals from only one person.



Figure 23

Mounting/Dismounting

Before getting on or off machine, if there is any oil, grease, or mud on handrails, guardrails, steps, or track shoes, wipe it off immediately. Always keep these parts clean. Repair any damage and tighten any loose bolts.

Never jump on or off machine. In particular, never get on or off a moving machine. These actions can result in death or serious injury.

When getting on or off machine, always face machine. Maintain three-point contact (both feet and one hand or one foot and both hands) with handrails, guardrails, steps, and track shoes to ensure that you support yourself securely.

Never hold onto any control levers when getting on or off machine.

Securely latch door. If you grip handrail inside door when moving on top of track shoes, and door latch is not securely engaged, door may move and cause you to fall.

Use points marked by arrows in diagram when getting on or off machine.

Do not carry tools or supplies when you mount or dismount the machine.



Figure 24





DS1602712

Cleaning

Remove all straw, wood chips, leaves, grass, paper and other flammable debris accumulated in engine compartment, mufflers and around battery. Remove any dirt from window glass, mirrors, handrails, and steps.

Do not leave tools or spare parts in operator's cabin. Vibration of machine during operation can cause tools or spare parts to fall and damage or break control levers or switches. Tools and spare parts can also get caught in spaces between control levers and cause accidental movement of work equipment causing death or serious injury.

When entering operator's cabin, always remove all mud and oil from your shoes. If you operate travel pedal with mud or oil stuck to your shoes, your foot could slip off the control, or dirt and debris may interfere with proper operation of control levers.

After using ashtray, make sure that any matches or cigarettes are properly extinguished, and be sure to close ashtray.

Clean window glass and working lights for good visibility.

Do not stick suction pads to window glass. Suction pads act as a lens and can cause fire.

Never bring flammable or explosive items into operator's cabin. Do not leave cigarette lighters laying around operator's cabin. If temperature inside operator's cabin becomes too high, there is a potential hazard that lighter could explode.

Secure all loose items such as lunch boxes, and other items that are not a part of equipment.

Operator Station

Inspect condition of seat belt and mounting hardware. Replace any parts that are worn or damaged. Do not use a seat belt extension on a retractable seat belt.

Adjust seat so full pedal travel can be achieved with operator's back against back of seat.

Keep all windows and doors closed on machine.

Adjust operator's seat to a position where it is easy to perform operations, and check that there is no damage or excessive wear to seat belt or mounting clamps.

Adjust and clean mirrors so area to rear of machine can be seen clearly from operator's seat.

When standing up from operator's seat, always place safety lever securely in "LOCK" position. If you accidentally move work equipment levers when they are not locked, the machine could suddenly move and cause damage, death or serious injury.

Seat Belt

Check seat belt daily for correct function.

Inspect seat belt system more often if machine is exposed to severe environmental conditions or applications. Conduct the following inspections and replace seat belt system as necessary:

- 1. Check webbing. If system is equipped with a retractor, pull webbing completely out and inspect full length of webbing. Look for cuts, wear, fraying, dirt and stiffness.
- 2. Check buckle and latch for correct operation.
- 3. Make sure latch plate is not excessively worn, deformed or buckle is not damaged or casing is broken.
- 4. Check retractor web storage device (if equipped) by extending webbing and checking that it spools out and retracts correctly.
- 5. Check webbing in areas exposed to ultraviolet (UV) rays from sun or extreme dust or dirt. If original color of webbing in these areas is extremely faded and/or webbing is packed with dirt, webbing strength may be reduced.

NOTE: Contact your HYUNDAI distributor for seat belt system replacement parts.



AVOID DEATH OR SERIOUS INJURY

Failure to properly inspect and maintain seat belt and seat belt system can cause lack of operator restraint and can result in death or serious injury.

Before fastening seat belt, check that there is no problem in belt mounting bracket. If it is worn or damaged, replace seat belt. Fasten seat belt so it is not twisted.

Always wear seat belt when operating machine.

Visibility Information

A rear/side view cameras (if equipped) and mirrors provide the operator with additional means to see the work area.

NOTE: These devices may vary from one region to another, depending upon local and regional regulations. If a machine is moved or sold into another region or marketplace, it is the owner's responsibility to make sure it complies with all applicable regulations.



AVOID DEATH OR SERIOUS INJURY

Failure to check for and clear people from the surrounding area of a machine can result in death or serious injury. The operator should make sure that visual aids (mirrors and camera(s)) are in proper working condition.

Your machine may be equipped with visual aids such as mirrors or a rear view camera. Even with these aids, there still may be areas around the machine which cannot be seen from the operator's seat. Always keep personnel and bystanders out of the work area. Be careful when operating and always look in direction of travel.

Adjust visual aids for best visibility around machine.

When swinging work equipment or backing up, press camera button (if equipped) to change display mode on display monitor so you can check rear and side of machine.

Before moving machine, look around work site and use mirrors and display monitor to confirm that no one is in the work area.

While operating or traveling in places with poor visibility it may be impossible to confirm condition of work site. Inspect and remove any obstacles around the machine that could be damaged and keep other personnel out of the work area.

Inspect equipment and repair immediately if there are problems with visual aids. If machine cannot be fixed immediately, DO NOT use the machine. Contact your HYUNDAI distributor and arrange for repairs.

Work Site Rules

- If visibility cannot be sufficiently assured, use a flagman. The operator should pay careful attention to signals and follow instructions from flagman.
- Signals should only be given by one flagman.
- When working in dark places, turn "ON" work lights and front lights on the machine. Set up additional lighting in area.
- Stop operations if there is poor visibility, such as fog, snow, rain, or sandstorms.
- Check mirrors and rear/side view cameras (if equipped) on machine before starting operations. Clean off any dirt and adjust view for good visibility.

When operating or traveling during poor visibility conditions, follow the preceding work site rules.

It may not be possible to adjust all visual aids to see all the way around the machine. Therefore, additional precautions such as flagman, barricades, etc., must be taken to keep other personnel out of the work area.

Boost Starting or Charging Engine Batteries

Follow these instructions to prevent an explosion or fire when connecting booster cables to batteries:

- Turn "OFF" all electric equipment before connecting leads to battery. This includes electric switches on battery charger or battery booster equipment.
- When boost starting from another machine or vehicle do not allow two machines to touch. Wear safety goggles and gloves while battery connections are made.
- 24 volt battery units consisting of two series connected 12 volt batteries have a cable connecting one positive (+) terminal on one of the 12 volt batteries to a negative (-) terminal on the other battery. Booster or charger cable connections must be made between the nonseries connected positive (+) terminals and between the negative (-) terminal of the booster battery and metal frame of the machine being boosted or charged. The final booster cable connection, at metal frame of the machine being charged or boost started, must be as far away from the batteries as possible. Refer to "Starting Engine with a Booster Cable" on page 3-12, for proper procedure in this manual.
- Connect positive (+) cable first when installing cables and disconnect negative (-) cable first when removing them.

Starting Engine

Only operate the machine from the operator's seat with your seat belt fastened.

Only operate controls while engine is running.

Check for proper operation of all controls and all protective devices while you operate the machine slowly in an open area.

- Read and understand control pattern before operating. Check that movement of the machine matches display on control pattern label. If it does not match, replace it immediately with correct control pattern label.
- Check operation of work equipment, travel system and swing system.
- Check for any problem with machine. Check for unusual sounds, vibration, heat, odor, or improper readings from gauges. Check for any oil or fuel leaks.
- If any problem is found, stop operation and perform repairs immediately.



Figure 26

EX1301191

Do not use cellular telephones inside operator's cabin when driving or operating the machine.

When operating the machine, do not extend your hands or head out of window.

The boom and arm linkage can allow work tool or attachment to contact undercarriage or cabin. Be aware of position of work tool.

- Do not attempt to start engine by short-circuiting engine starting circuit. This can result in death or serious injury, or fire.
- When starting engine, sound horn as a warning to alert personnel in the work area.

If there is a warning tag or "DO NOT OPERATE" tag hanging from work levers (joysticks) or travel control levers, do not start engine or move levers.

- Prevent personnel from walking or standing under raised boom, unless it is properly supported.
- **NOTE:** When starting engine in cold temperatures, "white engine exhaust smoke" from the tail pipe can occur until engine reaches normal operating temperatures.

Also, a white residue, because of water vapor inside engine, can form at the engine oil fill location. These conditions will not affect engine performance or damage the engine or other exhaust system components.



Figure 27

EX1503819

Swinging or Traveling

As a machine operator, you should know and follow local, state and federal laws and regulations when operating on public roads or highways.

It is important to keep in mind that the machine, in comparison with the rest of traffic, is a slow moving and wide vehicle which can cause traffic delays. Pay attention to traffic behind you and allow traffic to pass you.

Before operating the machine or work equipment, always observe the following precautions to prevent death or serious injury.

- When changing travel direction from forward to reverse or from reverse to forward, reduce speed and stop machine before changing travel direction.
- Sound horn to alert people in area.
- Check that there is no one in area around machine. There are restricted visibility areas behind machine so, if necessary, swing upper structure slowly to check that there is no one behind machine before traveling in reverse.
- When operating in areas with poor visibility, designate a flagman to direct work site traffic.
- Keep unauthorized personnel away from turning radius or travel path of the machine.

Be sure to observe above precautions even if a travel alarm or mirrors are installed.

- Check that travel alarm works properly and that mirrors are clean, not damaged and properly adjusted.
- Always latch door and windows of operator's cabin in position (open or closed).
- On work sites where there is a hazard of flying or falling objects, or of objects entering operator's cabin, check that door and windows are securely closed. Install additional guards, if work site application requires them.



EX1400131

Never turn starter switch to "O" (OFF) position when traveling. This can lead to a loss of steering control.

Do not operate attachments while traveling.

Do not change selected travel mode (FAST/SLOW) while traveling.

Never travel over obstacles or excessive slopes that will cause machine to tilt severely. Avoid slopes or obstacles where the machine is tilted more than 10° to the right or left or beyond its maximum gradeability.

Do not operate steering controls suddenly. Work equipment can hit ground and this can damage machine or structures in area.

When traveling on rough ground, travel at low speed, and avoid sudden changes in direction.

Always operate within permissible water depth. Permissible water depth is up to centerline of upper track roller(s).

When passing over bridges or structures on private land, check that structure is strong enough to support weight of machine. Before traveling on public roads, check with appropriate authorities and follow their instructions.

Never exceed maximum permitted load for bridges.

Always operate machine with idler wheels to front under cabin and drive sprockets to rear.

Know permitted ground pressure. Ground pressure of the machine may change depending on attachment and load.

Keep height and length of attachment in mind.

Travel Posture





Lifting and Logging

The operator is responsible for any load carried when traveling on public roads and while working with the machine.

- Keep loads secure so they do not fall off while operating.
- Do not exceed maximum load for the machine. Machine operation will be affected when center of gravity changes, caused by extended loads and different attachments.

To lift loads safely the following must be evaluated by the operator and work site crew.

- Condition of ground support.
- Forestry machine configuration and attachments.
- Weight, lifting height and swing radius.
- Safe rigging of load.
- Proper handling of suspended load.

Always watch load. Bring load close to the machine before traveling any distances or swinging load. Logs must be held securely within the grapple. Do not pinch with the grapple tines. It would lead to loss of control and dropped loads.

Lifting capacity decreases as load is moved further from the machine.

Set tracks at right angles to road shoulder or drop-off with sprocket at rear when performing operations to make it easier to move away from the work area.

Lifting and handling loads over the front and rear, rather than either side, has better stability of the machine.

Do not suddenly lower, swing, or stop work equipment. Haste can cause loss of stability and control. If tracks leave the ground, immediately lower the load and return the machine slowly to the ground.

• Do not move work tool over head of other personnel or over the operator's seat of dump trucks or other hauling equipment. The load may spill or work tool can hit dump truck causing property damage or cause death or serious injury.



EX1300849



Operation on Slopes

If the machine has to be used on a slope, pile soil to make a platform that will keep the machine as horizontal as possible.

Improper traveling on steep slopes could result in machine tipping, roll-over or sliding down the slope. Always fasten your seat belt.

When possible, operate machine up slopes and down slopes. Avoid operating machine across slope.

On hills, banks or slopes, carry work tool approximately $20 \sim 30$ cm (8 ~ 12 in) above ground. In case of an emergency, quickly lower work tool to ground to help stop machine.

Do not travel on grass, fallen leaves, or wet steel plates. Even slight slopes can cause machine to slide down a slope. Travel at low speed and make sure that the machine is always traveling directly up or down slope.

Do not change travel direction on a slope. This could result in tipping or sliding sideways of machine.

Improper operation when working on slopes can cause a tip over. Use caution when swinging or operating work equipment on slopes.

Do not swing work equipment from uphill side to downhill side when work tool is loaded. This could cause machine to tip or rollover.

In addition, lower work tool as far as possible, keep it pulled into front, and keep swing speed as slow as possible.

On slope, locate the drive sprockets downward the slope. Head the heaviest side of the machine uphill, as possible.

DO NOT mount a wire cable.

If the machine begins to slide down on a grade, immediately dump load and turn the machine downhill.

Be careful to avoid any ground condition which could cause the machine to tip. Tipping can occur when you work on hills, on banks, or on slopes. Tipping can also occur when you cross ditches, ridges, or travel over unexpected obstructions.

Keep the machine under control. Do not overload the machine beyond capacity.

- When traveling up a steep slope, extend work equipment to front to improve balance, keep work equipment approximately 20 ~ 30 cm (8 ~ 12 in) above ground, and travel at low speed.
- Do not turn on slopes or travel across slopes. Always go down to a flat place to change position of the machine, then travel backup the slope again.



Figure 31



Figure 32

EX1300663

Towing

To prevent death or serious injury when towing, always do the following:

- Follow the instruction given in this manual.
- When performing preparation work for towing with two or more personnel, determine signals to use and correctly follow these signals.
- Always attach wire rope onto left and right hooks and secure in position.
- If engine on problem machine will not start or there is a failure in brake system, always contact your HYUNDAI distributor.
- Never go between towing machine and towed machine during towing operation.
- Do not perform towing on steep slopes, so select a place where slope is gradual. If there is no place where slope is gradual, perform operations to reduce angle of slope before starting towing operation.
- When towing a machine, always use a wire rope with a sufficient towing capacity.
- Do not use a wire rope that is kinked or frayed, or a wire rope with any loss of diameter. Wear leather gloves when handling a wire rope.
- Do not use lightweight towing hook for towing another machine.
- Make sure that towing eyes and towing devices are adequate for towing loads.
- Only connect wire rope to a drawbar or to a hitch.
- Operate the machine slowly and be careful not to apply any sudden load to wire rope.





Attachment

Never let anyone ride on any work attachment, such as crusher, grapple, or clamshell. This creates a falling and crushing hazard, and can result in death or serious injury.

The clamshell, grapple, or magnet can swing in all directions. Move work levers (joysticks) in a continuous motion. Failure to move work levers (joysticks) in a continuous motion can cause clamshell, grapple, or magnet to swing into cabin or into a person in work area. This can result in death or serious injury.

- When using a fork or grapple, do not attempt to pick up an object with its tips. This could damage the machine or cause personal injury, if picked-up object slips off attachment.
- Do not use impact force of work equipment for demolition work. This could damage work equipment, cause broken materials to fly off or tipping. This could result in death or serious injury.
- Do not use work equipment or swing mechanism to pull load in any direction. This could cause the work equipment to move suddenly if the load releases and can result in death or serious injury.

Equipment Lowering with Engine Stopped

Before lowering any equipment with the engine stopped, clear the area around the equipment of all personnel and bystanders. The procedure to use will vary with the type of equipment to be lowered. Keep in mind most systems use a high-pressure fluid or air to raise or lower equipment. The procedure can cause high-pressure air, or hydraulic pressure, or some other media to be released to lower the equipment.

Wear appropriate personal protective equipment and follow the established procedure in the Operation Section of the manual.



Engine Stop

Turn engine starter switch to "O" (OFF) position and remove engine starter switch key.

Before lowering any equipment with engine stopped, clear area around equipment of all personnel and bystanders. This procedure will cause high-pressure air or hydraulic pressure to be released to lower equipment.

Do not stop engine immediately after the machine has been operated under load. This can cause overheating and accelerated wear of engine components.

After the machine is parked, allow engine to run for five minutes before stopping the engine. This allows hot areas of engine to cool gradually.

• Do not leave operator's seat when there is a raised load.

Parking Machine

Avoid making sudden stops, or parking machine wherever it happens to be at end of workday. Park machine on firm and level ground away from traffic and away from high walls, drop-offs and any area of potential water accumulation or runoff. If parking on inclines is unavoidable, block crawler tracks to prevent movement. Lower other working attachment completely to ground, or to an overnight support saddle. To prevent unintended or accidental movement.

When parking on public roads, provide fences, signs, flags, or lights, and put up any other necessary signs to ensure that passing traffic can see machine clearly. Park machine so machine, flags, signs and fences do not obstruct traffic.

After front attachment has been lowered to an overnight storage position and all switches and operating controls are in "OFF" position, safety lever must be moved to "LOCK" position. This will disable all pilot control functions.

Always close door of operator's cabin and lock all equipment to prevent any unauthorized person from operating the machine.

The hydraulic system remains pressurized, provided accumulator, is charged even when engine is not running. Accumulator pressure should decrease in a short time (approximately one minute). While hydraulic system maintains a charge, hydraulic work tools and machine controls remain functional.

Machine movement will occur if any controls are moved. This can result in death or serious injury.

Always move safety lever to "LOCK" position before stopping off engine or immediately after engine stops running.







EX1300554

Preservation/Storing Machine

Perform the following if storing machine for more than one month.

Conditions	Maintenance Required
Cleaning	Pressure wash undercarriage and track assemblies. Inspect for damage or loose or missing parts.
Lubrication	Perform all daily lubrication procedures.
	Apply a coating of light oil to exposed plated metal surfaces, such as hydraulic cylinder rods, etc.
	Apply a coating of light oil to all control linkages and control cylinders (control valve spools, etc.)
Battery	Turn "OFF" the battery disconnect switch.
Cooling System	Inspect coolant recovery tank to make sure that antifreeze level in system is at correct level.
	Every 90 days, use a hydrometer to measure protection level of coolant. Refer to "Antifreeze Concentration Tables" on page 4-87, to determine amount of protection cooling system requires. Add coolant as required.
Hydraulic System	Once a month, start engine and follow procedures in "Hydraulic System Warm-up" on page 3-13, listed in this manual.

- 1. Complete the preceding steps.
- 2. Wash machine and touch up paint finish to avoid rusting.
- 3. Treat exposed parts with antirust agent, lubricate machine thoroughly and apply grease to unpainted surfaces like lifting and tilting cylinders etc.
- 4. Fill fuel tank and hydraulic oil tank to "FULL" marks.
- 5. Cover exhaust pipe (parking outside).
- 6. Make sure that coolant is at proper concentration for expected lowest temperatures.
- 7. Park machine on level, firm ground where there is no risk of freezing, landslide or flooding. Avoid parking machine on a slope.

Keep in mind that theft and burglary risk can be minimized by:

- Removing starter key when the machine is left unattended.
- Locking doors and covers after working hours.
- Turning off electrical current with battery disconnect switch.
- Park machine where risk of theft, burglary and damage is minimized.
- Removing valuables from cabin such as cellular phone, computer, radio and bags.

See "Long Term Storage" on page 3-55, for more information.

Check After Long-term Parking

- All oil and fluid levels.
- Tension of all belts.
- Air pressure.
- Air cleaner.
- Batteries and electrical connections.
- Lubricate all greasing points.
- Wipe off grease from piston rods.
- Inspect for signs of nests (i.e. birds, rodents, etc.)
- Inspect safety labels (decals). Replace if damaged, worn, or missing.

MAINTENANCE

Improper operation and maintenance can result in death or serious injury. Read manual and safety decals before operating or maintaining the machine. Follow all instructions and safety messages.



AVOID DEATH OR SERIOUS INJURY

Follow instructions before operating or servicing machine. Read and understand the Operation & Maintenance Manual and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can result in death or serious injury.

- Never service HYUNDAI equipment without instructions.
- Always lower work tool and blade to ground before doing any maintenance.
- Use correct procedure to lift and support machine.
- Cleaning and maintenance are required daily.
- Welding or grinding painted parts must be done in well ventilated areas.
- Wear a dust mask when grinding painted parts. Toxic dust and gas can be produced.
- Vent exhaust to outside when engine must be running for service.
- Exhaust system must be tightly sealed. Exhaust fumes are hazardous and can cause death or serious injury.
- Stop and allow engine to cool and clean engine of flammable materials before checking fluids.
- Never service or adjust machine with engine running unless instructed to do so in this manual.
- Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate skin or eyes.
- Never fill fuel tank while engine running, while smoking, or when near open flame.
- Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
- Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for welding.

- Lead-acid batteries produce flammable and explosive gases.
- Keep arcs, sparks, flames and lighted tobacco away from batteries.
- Batteries contain acid which burns eyes or skin on contact.
- Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention from a physician familiar with this injury.
- The maintenance procedures which are given in this manual can be performed by the owner or operator without any specific technical training. Maintenance procedures which are not in this manual must be performed ONLY BY QUALIFIED SERVICE PERSONNEL. Always use genuine HYUNDAI replacement parts.
- Only authorized personnel should service and repair the machine. Do not allow unauthorized personnel into work area.
- Lower work equipment and stop engine before performing maintenance.
- Park machine on firm and level ground.
- Turn starter switch to "ON' position and keep safety lever in "UNLOCK" position. Cycle work levers (joysticks) back and forth, left and right at full stroke 2 to 3 times to eliminate remaining internal pressure in hydraulic circuit. Then move safety lever to "LOCK" position.
- Check that battery relay is "OFF" and main power is shut off. (Wait for approximately one minute after turning "OFF" engine starter switch key and press horn switch. If horn does not sound, the main power is shut off.)
- Put blocks under track to prevent the machine from moving.
- To prevent injury, do not perform maintenance with engine running. If maintenance must be done with engine running, perform maintenance with at least two workers and do the following:
 - One worker must always sit in the operator's seat and be ready to stop engine at any time. All workers must maintain contact with other workers.
 - When maintenance operations are near fan, fan belt, or other rotating parts, there is a potential hazard of being caught in rotating parts. Keep hands and tools away.
- Never drop or insert tools or other objects into rotating fan or fan belt. Parts can break off and hit someone.
- Do not touch any control levers or control pedals. If any control levers or control pedals must be operated, always give a signal to other workers and instruct them to move away.

- When performing maintenance of engine and you are exposed to engine noise for long periods of time, wear hearing protection while working.
- If noise from the machine is too loud, it can cause temporary or permanent hearing problems.
- Do not smoke when you service an air conditioner or if refrigerant gas is present.
- Inhaling fumes either from a flame or gas from a cigarette that has contacted air conditioner refrigerant can cause death or serious injury.
- Never put maintenance fluids into glass containers. Drain all liquids into a suitable containers.
- Unless instructed otherwise, perform maintenance with equipment in servicing position. Refer to this manual for procedure for placing equipment in servicing position.

Warning Tag

Alert others that service or maintenance is being performed by attaching a "DO NOT OPERATE" warning tag to the operator's cabin controls – and other machine areas, if required. Use of a chain or cable to keep the safety lever in the fully lowered "LOCK" position, complies with OSHA's lockout requirements.

"DO NOT OPERATE" warning tags, are available from your HYUNDAI distributor.

- Always attach "DO NOT OPERATE" warning tag to work equipment control lever in the operator's cabin to alert others that you are performing service or maintenance on the machine. Attach additional warning tags on the machine, if necessary.
- Keep warning tags in tool box while it is not used. If there is not tool box or in the owner manual storage pocket.
- If any other person starts engine, and operates control levers or control pedals while you are performing service or maintenance, it can result in death or serious injury.

Attach a "DO NOT OPERATE" warning tag to starter switch or to controls before servicing or repairing equipment. Warning tags are available from your HYUNDAI distributor.





EX1301177

Cleaning

Clean machine before performing inspection and maintenance.

If inspection and maintenance are done when machine is dirty, it will become more difficult to locate problems, and you could slip on steps and work platform areas and injure yourself.

When washing machine, do the following:

- Wear shoes with nonslip soles to prevent slipping and falling.
- Wear safety goggles and protective clothing when washing machine with high-pressure steam or water.
- Do not spray water directly on electrical components (sensors, connectors). If water gets into electrical system, it can cause operation problems.
- Pick up any tools or hammers that are laying in workplace. Wipe up any grease or oil to prevent slippery substances, that can cause tripping or slipping.
- When cleaning cabin top window which is made of polycarbonate material, use tap water. Avoid use of organic solvents for cleaning, such as benzene, toluene or methanol. These solvents can cause a chemical reaction that will dissolve and damage the window.

Proper Tools and Clothing

Only use tools that are intended for the type of service to be done. Metal pieces from low quality or damaged tools, such as chisels or hammers, can break off and hit a service person in the eyes or face causing serious injury.

Disassembling Precautions

When using a hammer to remove pins, pins can fly out or metal particles may break off. Always do the following:

• Hitting hard metal pins or bearings with a hammer, can cause metal pieces to break or fly off resulting in serious injury. Always wear safety goggles and leather gloves. Keep other personnel away.

Use of Lighting

When checking fuel, oil, battery electrolyte, window washer fluid, or coolant, always use proper lighting equipment to prevent arcs or sparks that could cause a fire or explosion resulting in death or serious injury.



Figure 38

Fire and Explosion Prevention

Fuels, most lubricants and some coolant mixtures are flammable. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire resulting in property damage or death or serious injury.

Store all fuels and all lubricants in properly marked and approved containers and keep away from all unauthorized personnel.

Store oily rags and other flammable material in a protective container.

Tighten all fuel and oil caps.

Do not smoke while you refuel machine or while you are in a refueling area.

Do not smoke in battery charging areas or in areas that contain flammable material.

Clean all electrical connections and tighten all electrical connections. Check electrical wires daily for wires that are loose or frayed. Tighten all loose, and repair or replace all frayed, electrical wires before operating machine.

Remove all flammable materials and debris from the engine compartment, exhaust system components and hydraulic lines.



Figure 39

FG018458

Figure 40

Burn Prevention

When checking radiator coolant level, stop engine, let engine and radiator cool down, then check coolant recovery tank. If coolant level in coolant recovery tank is near upper limit, there is enough coolant in radiator.

Using gloves, loosen radiator cap slowly to release internal pressure before removing radiator cap.

If coolant level in coolant recovery tank is below lower limit, add coolant.

Cooling system conditioner contains alkali which can cause personal injury. Do not allow alkali to contact skin, eyes, or mouth.

Allow cooling system components to cool before draining cooling system.

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact skin.

Vent hydraulic tank only after engine has been stopped and hydraulic tank is cool. Using gloves, slowly tilt hydraulic tank air breather to relieve pressure.

Relieve all pressure in hydraulic oil system, in fuel system, or in cooling system before disconnecting any lines, hoses, fittings, or related components.

Batteries give off flammable fumes that can explode and start a fire.

Do not smoke while you are checking battery electrolyte level.

Electrolyte is an acid. Electrolyte can cause personal injury. Do not allow electrolyte to contact skin or eyes.

Always wear safety goggles and face protection when working with batteries.





Figure 41

haae2090

Rubber That Contains Fluorides

Observe extra great care when it is suspected that you may have to handle rubber that contains fluorides.

Certain seals which have to withstand high operating temperatures (e.g. in engines, transmissions, axles, hydraulic motors and pumps) may be made from rubber that contains fluorides, which, when exposed to high heat (fire), forms hydrogen fluoride and hydrofluoric acid. This acid is very corrosive and cannot be rinsed or washed off from the skin. It causes very severe burns which take a long time to heal.

It usually means that damaged tissue must be surgically removed. Several hours may pass after contact with the acid, before any symptoms appear and therefore one is not given any immediate warning. The acid may remain on the machine parts for several years after a fire.

If swelling, redness or a stinging feeling appears and one suspects that cause may be contact with heated rubber that contains fluorides, contact a medical doctor immediately. If a machine, or part of a machine, has been exposed to fire or severe heat, it must be handled by specially trained personnel. In all handling of machines after a fire, thick rubber gloves and protective goggles must be used.

The area around a part which has been very hot and which may be made of rubber that contains fluorides must be decontaminated by thorough and ample washing with limewater (a solution or suspension of calcium hydroxide, i.e. slaked lime in water). After the work has been completed, the gloves must be washed in limewater and then discarded.

Rubber and Plastics

Polymer materials when heated, can form compounds that create a health hazard and can harm the environment. Scrapped rubber and plastics must never be burned. Extra precautions must be taken when servicing machines that have been in a fire or exposed to extreme heat.

If gas cutting or welding is to be done near such materials, the following safety instructions must be followed:

- Protect the material from heat.
- Use protective gloves, protective goggles and an approved respirator.

Waste Hazardous to the Environment

Painted parts or parts made of plastic or rubber which are to be scrapped must never be burned, but must be taken care of by an approved refuse handling plant.

Batteries, plastic objects and anything else which is suspected of being dangerous to the environment must be taken care of in an environmentally safe way.

Check List After Fire

When handling a machine which has been damaged by fire or been exposed to intense heat, the following protective measures must under all circumstances be followed:

Use thick, gloves made of rubber and wear goggles which are certain to protect your eyes.

Never touch burned components with your bare hands, as there is a risk that you may come into contact with melted polymer materials. First wash thoroughly with plenty of limewater (a solution or suspension of calcium hydroxide, i.e. slaked lime in water).

As a precaution, seals (O-rings and other oil seals) should always be handled as if they were made of rubber that contains fluorides.

Treat skin, which is suspected of having touched burned rubber that contains fluorides, with Hydrofluoric Acid Burn Jelly or something similar. Seek medical advice. Symptom may not appear until several hours afterwards.

Discard gloves, rags etc. which are suspected of having touched burned rubber that contains fluorides.



When disconnecting or connecting connectors between ECU/DCU and engine, or connector between ECU/DCU and the machine, always disconnect the battery to prevent damage to ECU/DCU.

If you do not follow this procedure, the ECU/DCU will be damaged and/or the engine will not operate properly.

When performing welding repairs, perform welding in a properly equipped place. Repairs must be performed by a qualified welder. Welding operations, can create potential hazards, including generation of gas, fire, or electric shock. Never let an unqualified welder do welding.

A qualified welder must do the following:

- To prevent battery explosion, turn battery disconnect switch to "OFF" position.
- Disconnect the connector between ECU/DCU and machine, and the connector between ECU/DCU and engine.
- Disconnect the negative (-) cable of battery.
- To prevent generation of gas, remove paint from location of the weld.
- If hydraulic equipment, piping or component ports close to them are heated, a flammable gas or mist could result in an explosion or fire. To prevent this, protect and insulate components from excessive heat.
- Do not weld on pipes or on tubes that contain flammable fluids. Do not flame cut pipes or tubes that contain flammable fluids. Before welding on pipes or tubes, or before flaming cut pipes or tubes, clean them thoroughly with a nonflammable solvent. Make sure pressure inside pipes or tubes does not cause a rupture of the component parts.
- If heat is applied directly to rubber hoses or piping under pressure, they may suddenly break, so cover and insulate them with a fireproof covering.
- Wear protective clothing.
- Make sure there is good ventilation.
- Remove all flammable objects and make sure a fire extinguisher is available.

Preparation for Electrical Welding on Body Structure

To prevent damage to ECU by electrical welding, observe the following procedures:

- 1. Turn battery disconnect switch to "OFF" position.
- Disconnect the connector between ECU/DCU and machine, and the connector between ECU/DCU and engine.
- 3. Disconnect the negative (-) cable of battery.
- 4. Proceed with welding.
- 5. After welding, connect the connector between ECU/DCU and machine, and the connector between ECU/DCU and engine.
- 6. Connect the negative (-) cable of battery.
- 7. Clean battery compartment.
- 8. Turn battery disconnect switch to "ON" position.
- 9. Close battery compartment door.

Warning for Counterweight and Front Attachment Removal



AVOID DEATH OR SERIOUS INJURY

Removal of the machine counterweight, front attachment or any other part can affect the stability of the machine. This could cause unexpected movement, and result in death or serious injury.

Never remove counterweight or front attachment unless the upper structure is in-line with the lower structure.

Never rotate the upper structure once the counterweight or front attachment has been removed.



EX1500481

EX1500889

Figure 42



Figure 43

Lock Inspection Covers

When performing maintenance with inspection cover open, use lock bar to secure cover and prevent accidental lowering of the cover caused by wind or movement of the machine.

Working on Machine

When performing maintenance operations on machine, prevent tripping and falling by keeping area around your feet clean and free of objects and debris. Always do the following:

- Do not spill oil or grease.
- Do not leave tools laying around.
- Watch your step when walking.
- Never jump down from machine. When getting on or off machine, use steps and handrails, and maintain a three-point contact (both feet and one hand or both hands and one foot) to support yourself.
- If job requires it, wear protective clothing.
- To prevent injury from slipping or falling, when working on hood or covers, never stand or walk on areas except areas equipped with nonslip pads.
- If it is necessary to work under raised equipment or the machine, support work equipment and machine securely with blocks and stands strong enough to support weight of work equipment and machine.
- Do not work under the machine if track shoes are lifted off ground and the machine is supported only with work equipment. If any control levers are moved, or there is damage to hydraulic system, work equipment or the machine will suddenly drop causing death or serious injury.

ARO1380L Figure 44

Accumulator

The pilot control system is equipped with an accumulator. For a short period of time after engine has been stopped, accumulator will store a pressure charge that allow hydraulic controls to be activated. Activation of any controls will allow selected functions to operate under force of gravity.

When performing maintenance on pilot control system, release hydraulic pressure in system as described in "Handling of Accumulator" on page 4-92.

The accumulator is charged with high-pressure nitrogen gas. If it is improperly handled it can explode causing death or serious injury. Always observe the following precautions:

- Do not drill or punch holes in accumulator or expose it to any flames, fire or external heat source.
- Do not weld on accumulator.
- When performing disassembly or maintenance of accumulator, or when disposing of accumulator, charged nitrogen gas must be properly released. Contact your HYUNDAI distributor for assistance.
- Wear safety goggles and leather gloves when working on an accumulator. Hydraulic oil under pressure can penetrate skin and result in death or serious injury. If fluid enters skin or eyes, get immediate medical attention from a physician familiar with this injury.

Compressed Air

- When cleaning filters, radiator or other components with compressed air, there is a hazard of flying particles that can result in serious injury.
- Always wear safety goggles, dust mask, leather gloves, and other protective devices.



Figure 45
Track Tension Adjustments

Track adjusting systems use grease under high-pressure to keep track under tension. Grease under high-pressure can penetrate body and result in death or serious injury. Watch track or track spring to see if track is being loosened.

NEVER LOOSEN track tension grease valve. To release pressure from crawler frame track tension assembly, you should NEVER attempt to disassemble track adjuster or attempt to remove track tension grease valve assembly.

Keep your face and body away from grease valve. Refer to "Track Tension (IF EQUIPPED TYPE 1)" on page 4-93, for proper procedure in this manual or Shop Manual.



Figure 46

Supports and Blocking for Work Equipment

Do not allow weight or equipment loads to remain suspended and unsupported.

Lower work group to ground before leaving operator's seat.

Do not use hollow, cracked or unsteady wobbling supports.

Do not work under any equipment supported only by a lifting jack.



Figure 47

HDO1042L

High-pressure Lines, Tubes and Hoses

When inspecting or replacing high-pressure piping or hoses, check to verify that pressure has been released from circuit. Failure to release pressure can result in death or serious injury. Release pressure as described in "Handling of Accumulator" on page 4-92.

Always do the following:

- Wear eye protection and leather gloves.
- Fluid leaks from hydraulic hoses or pressurized components can be difficult to see but has enough force to pierce skin and can result in death or serious injury. Always use a piece of wood or cardboard to check for suspected hydraulic leaks. Never use your hands or expose your fingers. Wear safety goggles.
- Do not bend high-pressure lines. Do not strike high-pressure lines. Do not install lines, tubes or hoses that are bent or damaged.
- Make sure that all clamps, guards and heat shields are correctly installed to prevent vibration, rubbing against other parts, and excessive heat during operation.
- Replace hose or components if any of the following problems are found:
 - Damage or leakage from hose end fitting.
 - Wear, damage, cutting of hose covering, or wire braiding is exposed on any hose.
 - Cover portion is swollen in any section.
 - The hose is twisted or crushed.
 - Foreign material is embedded in hose covering.
 - Hose end is deformed.
 - Connection fittings are damaged or leaking.
 - **NOTE:** Refer to "Hose In-service Lifetime Limit (European Standard ISO 8331 and EN982 (CEN))" on page 4-78, for additional European regulations.

High-pressure is generated inside engine fuel lines when engine is running. Before performing inspection or maintenance of fuel line system, wait for at least thirty seconds after stopping engine to let internal pressure drop and tip breather cap up to release residual pressure.

Oil or fuel leaks from high-pressure hoses can cause fire or improper operation, which can result in death or serious injury. If any loose bolts are found, stop work and tighten to specified torque. If any damaged hoses are found, stop operations immediately and contact your HYUNDAI distributor for replacement parts.



Battery

Battery Hazard Prevention

Battery electrolyte contains diluted sulfuric acid and generates hydrogen gas. Hydrogen gas is highly explosive, and improper handling can cause death or serious injury, or fire. Do not allow electrolyte to contact skin or eyes. Always wear safety goggles and protective clothing when servicing batteries. Wash hands after touching batteries and connectors. Use of acid-resistant gloves is recommended. Always observe the following precautions.

- Do not smoke or bring any flame near battery.
- When working with batteries, Always wear safety goggles, protective clothing, and acid-resistant gloves.
- If you spill battery electrolyte on yourself or your clothes, immediately flush area with water.
- If battery electrolyte gets into your eyes, flush them immediately with large quantities of water and get immediate medical attention from a physician familiar with this injury.
- If you accidentally drink battery electrolyte, call a poison prevention center immediately and get immediate medical attention from a physician familiar with this injury.
- When cleaning top surface of battery, wipe it with a clean, damp cloth. Never use gasoline, thinner, or any other organic solvent or detergent.

Figure 49

- Tighten battery caps.
- If battery electrolyte is frozen, do not charge battery or start engine with power from another source. This could cause the battery to explode and start a fire.
- When charging battery or starting with power from another source, let battery electrolyte thaw and check that there is no leakage of battery electrolyte before starting operation.
- Always remove battery from machine before charging.
- Do not use or charge battery if battery electrolyte level is below LOW LEVEL line. This can cause an explosion. Periodically check battery electrolyte level and add distilled water to bring electrolyte level to FULL LEVEL line.
- Before maintaining or working with batteries, turn starter switch to "O" (OFF) position.

Since there is a potential hazard that sparks could be generated, always do the following:

- Do not let tools, rings or other metal objects make any contact between battery terminals. Do not leave tools or other metal objects lying near battery.
- When disconnecting battery terminals, wait for approximately one minute after turning engine starter switch key to "O" (OFF) position, and be sure to disconnect grounding terminal; negative (-) terminal first. Conversely, when connecting them, begin with positive (+) terminal and then grounding (-) terminal, Make sure that all terminals are connected securely.
- Flammable hydrogen gas is generated when battery is charged. Remove battery from machine, take it to a well ventilated place, and remove battery caps, before charging it.
- After charging, tighten battery caps securely.
- After charging, secure battery back in machine.

When repairing or welding electrical system, wait for approximately one minute after turning engine starter switch key "OFF". Then disconnect negative (-) terminal of battery to stop flow of electricity.

ENVIRONMENT AND CIRCUMSTANCES

Work Site Areas Requiring Extra Caution

- Do not operate too close to edge of a quay, ramp, etc.
- Do not operate too close to edge of a steep slope or drop-off. Take care when working in a place where machine may tip over.
- Do not operate on soft ground or near riverbanks that could collapse or where ground may not support weight of machine.
- Observe changes in ground and traction conditions after a rain or other changes in weather.

Drop-off or Edge

When working at edge of a machine or near a drop-off, the machine could tip over, which can result in death or serious injury. Always fasten your seat belt. Check ground conditions of work site before operating to prevent the machine from falling or roll-over, and to prevent ground, stockpiles, or banks from collapsing.

Do not travel too close to edge of a drop-off.

Poor Visibility

For good visibility, always do the following:

- When working in dark areas, attach working lights and front lights to the machine. If necessary, set up additional lighting at work site.
- Stop operations when visibility is poor, such as in fog, mist, snow, and rain. Wait for visibility to improve before starting operation.

To avoid hitting work equipment and damaging other property, always do the following:

- When working in tunnels, on bridges, under electrical wires, or when parking the machine or performing other operations in places with limited height, be careful not to hit and damage other equipment or property.
- To prevent hitting objects, operate machine at a slow speed when working in confined spaces, indoors, or in crowded areas.
- Do not swing work tool over the top of personnel or over operator's cabin of truck.

Loose or Soft Ground

Do not operate on soft ground or near edge of drop-offs, overhangs, and deep ditches. The ground can collapse because of the weight of the machine causing the machine to fall or roll-over.

Check ground conditions before beginning work with the machine. If ground is soft, reposition the machine before operating.

Do not panic and do not raise work tool, if ground should begin to collapse. Lower work equipment to improve stability of machine.

High-voltage Cables

Do not travel or operate machine near electrical cables or overhead power lines. There is a hazard of electric shock, which can cause property damage and result in death or serious injury. The other attachment does not have to make physical contact with power lines for current to cause an electrocution.

Use a spotter and hand signals to stay away from power lines not clearly visible to operator. On work sites where machine may operate close to electrical cables, always do the following:

• Remember that electrical voltage determines what the minimum distance is to stay away from the power line. See the following table for minimum distances when working near electrical power lines. Electrical flashover can occur and damage machine and cause death or serious injury.

Voltage	Minimum Distance
6.6 kV	3 m (9' 10")
33.0 kV	4 m (13' 1")
66.0 kV	5 m (16' 5")
154.0 kV	8 m (26' 3")
275.0 kV	10 m (32' 10")

 Always contact the power company responsible before beginning work near high voltage power lines.





EX1300598

Roll-over Protective Structure (ROPS), Falling Object protective Structure (FOPS) (Oregon Cabin Only)

The operator's cabin is a ROPS/FOPS certified structure for protecting the seat-belted operator. It absorbs the impact energy of a rollover impact. Do not allow machine weight (mass) to exceed certified value on certification plate. If weight is exceeded, the ROPS/FOPS structure will not be able to fulfill its safety function.

Do not increase machine weight beyond certified value by modifying machine or by installing attachments on machine. If weight limit of protective equipment is exceeded, protective equipment will not be able to protect operator, and operator may suffer death or serious injury. Always observe the following:

- This machine is equipped with a protective structure. Do not remove protective structure and perform operations without it.
- Never modify the operator's cabin by welding, grinding, drilling holes or adding attachments unless instructed by HYUNDAI. Changes to the cabin can cause loss of operator protection from rollover and falling objects, and operator may suffer death or serious injury.
- When protective structure is damaged or deformed by falling objects or by rolling over, its strength will be reduced and it will not be able to properly fulfill its function. In these cases, always contact your HYUNDAI distributor for advice. Never repair a ROPS/FOPS cabin.
- Always wear your seat belt when operating machine.

ROPS/FOPS Certification (Oregon Cabin Only)

This HYUNDAI forestry machine has an operator's cabin that meets ROPS/FOPS requirements. The seat belt must be worn for rollover protection.

The ROPS/FOPS certification plate (Figure 51) is found on the left side of the cabin on most models. It may vary slightly in its location on some models.

Check the ROPS/FOPS cabin, mounting, and hardware for damage.

Never modify the ROPS/FOPS cabin. Replace the cabin and hardware if damaged. See your HYUNDAI dealer for parts.

ROPS Roll-over Protective Structure complies with ISO 8082:2003, WCB G602.

FOPS Falling Object Protective Structure complies with ISO 8083:2006, WCB G608.



AVOID DEATH OR SERIOUS INJURY

Never modify the operator cabin by welding, grinding, drilling holes or adding attachments unless instructed by HYUNDAI. Changes to the cabin can cause loss of operator protection from rollover and falling objects, and result in death or serious injury.

Working in Water



Do not exceed maximum permissible water depth. The water level must not reach higher than centerline of upper track roller(s) (1, Figure 52).

After working in water, lubricate all lubrication points on undercarriage, which have been underwater so water is removed. Check that no water has entered travel gearboxes and undercarriage components.

Working in Contaminated Environment

When working within area which is contaminated or where there is a health risk, check local regulations and contact your HYUNDAI distributor for assistance with identifying what additional safety precautions need to be taken.





Operation in Extreme Conditions

Operation In Extreme Cold

In extremely cold weather, avoid sudden travel movements and stay away from even slight slopes. The machine could slide down the slope.

Snow accumulation could hide potential hazards and slippery surfaces.

Warming up engine for a short period may be necessary to avoid operating with sluggish or reduced working capacity. The jolting shocks and impact loads caused by bumping or bottoming boom or attachment could cause severe stress in very cold temperatures. Reducing work cycle rate and workload may be necessary.

If machine is to be operated in extremely cold weather temperatures, certain precautions must be taken. The following paragraphs detail checks to be made to be certain machine is capable of operating at these temperatures.

1. Keep batteries fully charged to prevent freezing. If distilled water is added to batteries, run engine at least one hour to mix electrolyte solution.

When temperature drops below -10°C, efficacy of the battery is reduced accordingly. Insulation of the battery prevents reduction of efficacy, and supports improvement of starting power of the starter.



AVOID DEATH OR SERIOUS INJURY

Explosion of the battery can cause death or serious injury. Never attempt to directly heat the battery with open fire.

- 2. Keep engine in good mechanical condition for easy starting and good performance during adverse weather.
- 3. Use engine oil with proper specifications for expected temperatures. Refer to "Table of Recommended Lubricants" on page 4-21, in this manual or Shop Manual for details.
- 4. Always keep the fuel tank fully filled after completion of the operation. Always drain water from the fuel tank before and after the operation. In addition, check the water separator, and drain it if required. The fuel filter, if frozen, may interrupt the flow of fuel. Periodically remove water from the fuel tank, drain water from the filter, and replace the filter upon regular basis. To prevent fuel from being clogged because of formation of wax in fuel, make sure that wax formation point of fuel is lower than atmospheric temperature.



AVOID DEATH OR SERIOUS INJURY

Explosion of the fuel tank can cause serious injury or death. Never attempt to directly heat the fuel tank with open fire.

- 5. Lubricate entire machine according to "Lubrication and Service Chart" on page 4-18, in this manual or lubrication chart on machine.
- 6. Start engine and allow it to reach normal operating temperature before operating.
 - If mud and ice collects and freezes on any of moving parts while machine is idle, apply heat to thaw frozen material before attempting to operate machine.
 - Operate hydraulic units with care until they have reached a temperature which enable them to operate normally.
 - Check all machine controls and functions to be sure they are operating correctly.
- 7. An extra outer air filter must be kept in operator's cabin to replace element that could become iced and cause restricted airflow to engine.
- 8. Clean off all mud, snow and ice to prevent freezing. Cover machine with a tarp if possible, keep ends of tarp from freezing to ground.

Operation in Extreme Heat

Continuous operation of machine in high temperatures can cause machine to overheat. Monitor engine and hydraulic system temperatures and stop machine to let it cool, when necessary.

- 1. Make frequent inspections and services of fan and radiator. Check coolant level in radiator. Check grilles and radiator fins for accumulation of dirt, debris and insects which could block cooling passages.
 - Formation of scale and rust in cooling system occurs more rapidly in extremely high temperatures. Change antifreeze each year to keep corrosion inhibitor at full strength.
 - If necessary, flush cooling system periodically to keep passages clear. Avoid use of water with a high alkali content which increases scale and rust formation.
- 2. Check level of battery electrolyte daily. Keep electrolyte above plates to prevent damage to batteries. Use a slightly weaker electrolyte solution in hot climates. Batteries self-discharge at a higher rate if left standing for long

periods at high temperatures. If machine is to stand for several days, remove batteries and store in a cool place.



Do not store acid type storage batteries near stacks of tires. Acid fumes can damage rubber.

- 3. Service fuel system as directed in "Check Fuel Level" on page 4-29 and "Check for Leaks in Fuel System" on page 4-28, of this manual. Check for water content before filling fuel tank. High temperatures and cooling off cause condensation in storage drums.
- 4. Lubricate as specified in "Lubrication and Service Chart" on page 4-18, in this manual or Lubrication Decal on machine.
- 5. Do not park machine in sun for long periods of time. If possible, park machine under cover to protect it from sun, dirt and dust.
 - A. Cover machine if no suitable shelter is available. Protect engine compartment and hydraulics from dirt and debris.
 - B. In hot, damp climates, corrosion will occur on all parts of machine and will be accelerated during rainy season. Rust and paint blisters will appear on metal surfaces and fungus growth on other surfaces.
 - C. Protect all unfinished, exposed surfaces with a film of preservative oil. Protect cables and terminals with ignition insulation compound.
 Apply paint or suitable rust preventive to damaged surfaces to protect them from rust and corrosion.

Operation In Dusty and Sandy Areas

Operation of machine can cause dust in almost any area. However, when in predominantly dusty or sandy areas, additional precautions must be taken.

1. Keep cooling system fins and cooling areas clean. Blow out with compressed air, if possible, as often as necessary.



AVOID DEATH OR SERIOUS INJURY

Wear goggles when using compressed air to prevent face or eye injury.

2. Use care when servicing fuel system to prevent dust and sand from entering tank.

- 3. Service air cleaner at frequent intervals, check air restriction indicator daily and keep dust cup and dust valve clean. Prevent dust and sand from entering engine parts and compartments as much as possible.
- 4. Lubricate and perform services outlined on current lubrication chart on machine and "Lubrication and Service Chart" on page 4-18. Clean all lubrication fittings before applying lubricant. Sand mixed with lubricant becomes very abrasive and accelerates wear on parts.
- 5. Protect machine from dust and sand as much as possible. Park machine under cover to keep dust and sand from damaging unit.

Operation in Rainy or Humid Conditions

Operation under rainy or humid conditions is similar to that as in extreme heat procedures previously listed.

1. Keep all exposed surfaces coated with preservative oil. Pay particular attention to damaged or unpainted surfaces. Cover all paint cracks and chip marks as soon as possible to prevent corrosive effects.

Operation in Saltwater Areas

Saltwater and saltwater spray is very corrosive. When operating in saltwater areas, or in or around snow, observe the following precautions:

- 1. When exposed to saltwater, dry machine thoroughly and rinse with freshwater, as soon as possible.
- 2. Keep all exposed surfaces coated with preservative oil. Pay attention to damaged paint surfaces.
- 3. Keep all painted surfaces in good repair.
- 4. Lubricate machine as prescribed on lubrication chart on machine or "Lubrication and Service Chart" on page 4-18, in this manual. Shorten lubricating intervals for parts exposed to salt water.
- 5. Check operating controls to ensure proper functionality and that they return to "NEUTRAL" when released.

Operation at High Altitudes

Operation instructions at high altitudes are the same as those provided for extreme cold. Before operating at high altitudes, engine fuel and air mixture may have to be adjusted according to appropriate engine manual.

- 1. Check engine operating temperature for evidence of overheating. The radiator cap must make a perfect seal to maintain coolant pressure in cooling system.
 - Perform warming-up operation thoroughly. If machine is not thoroughly warmed up before control levers or

control pedals are operated, reaction of machine will be slow.

- If battery electrolyte is frozen, do not charge battery or start engine with a different power source. There is a potential hazard that could cause a battery explosion or fire.
- Before charging or starting engine with a different power source, thaw battery electrolyte and check for any leakage of electrolyte before starting.

Operation During Electrical Storms

During electrical storms, do not enter or exit machine.

- If you are off machine, keep away from machine until storm passes.
- If you are in cabin, remain seated with machine stationary until storm passes. Do not touch controls or anything metal.

Exhaust Ventilation

Engine exhaust gases can cause unconsciousness, loss of alertness, judgment and motor control. This can result in death or serious injury.

Make sure there is adequate ventilation before starting engine in any enclosed area.

Check for and be aware of any open windows, doors or ductwork where exhaust may be carried, or blown by wind, exposing others to hazardous exhaust gases.

Ventilation for Enclosed Area

If it is necessary to start engine within an enclosed area, or when handling fuel, flushing oil, or paint; open doors and windows to ensure that adequate ventilation is provided to prevent gas poisoning.

Diesel engine exhaust contains products of combustion which can be harmful to your health.

Always run engine in a well ventilated area. If you are in an enclosed area, vent exhaust to outside.



Figure 53

Safety 1-73



AVOID DEATH OR SERIOUS INJURY

Avoid exposure to dust containing asbestos as it can cause death or serious injury to the lungs and other organs (mesothelioma, lung and other cancers, and asbestosis).

Asbestos dust can be HAZARDOUS to your health if it is inhaled. Materials containing asbestos fiber can be present on work sites. Breathing air that contains asbestos fiber can ultimately cause serious or fatal lung damage or diseases such as mesothelioma, lung and other cancers, and asbestosis. To prevent lung damage from asbestos fiber, observe the following precautions:

- Use an approved respirator that is approved for use in an asbestos-laden atmosphere.
- Use water for cleaning to keep down dust.
- Always observe any regulations related to work site and working environment.
- Avoid brushing or grinding materials that contain asbestos.
- A vacuum cleaner that is equipped with a high efficiency particulate air filter can also be used.
- Comply with applicable laws and regulations for workplace.
- Stay away from areas that might have asbestos particles in air.

Silica Dust Information



AVOID DEATH OR SERIOUS INJURY

Avoid exposure to dust containing crystalline silica particles as it can cause serious injury to the lungs (silicosis).

Cutting or drilling concrete containing sand or rock containing quartz can result in exposure to silica dust. Do not exceed Permissible Exposure Limits (PEL) to silica dust as determined by OSHA or other work site rules, laws and regulations. Use a respirator, water spray or other means to control dust. Silica dust can cause lung disease and is known to the state of California to cause cancer.

Disposal of Hazardous Materials

Physical contact with used motor oil or gear oil could create a health risk. Wipe oil from your hands promptly and wash off any remaining residue.

Used motor oil or gear oil is an environmental contaminant and should only be disposed of at approved collection facilities. To prevent pollution of environment, always do the following:

- Never dump waste oil in a sewer system, rivers, etc.
- Always put drained oil from your machine in approved, leak • proof containers. Never drain oil directly onto ground.
- Obey appropriate laws and regulations when disposing of harmful materials such as oil, fuel, solvent, filters, and batteries.

Improperly disposing of waste can threaten environment. Potentially harmful fluids must be disposed of according to local regulations.

Use all cleaning solutions with care. Report all necessary repairs.





Operating Controls

The "Operating Controls" section consists of the following groups:

- 1. "Component Locations" on page 2-2
- 2. "Operator's Area" on page 2-6
- 3. "Operational Controls and Panels" on page 2-9
- 4. "Display Monitor" on page 2-27
- 5. "User Menu" on page 2-52
- 6. "Heater and Air Conditioner Control Panel" on page 2-87
- 7. "Stereo" on page 2-92
- 8. "Miscellaneous Electrical Devices" on page 2-93
- 9. "Seat Adjustment" on page 2-95
- 10. "Engine Emergency Stop Switch" on page 2-98
- 11. "Emergency Exit Glass Breaking Tool (STD Cabin Only)" on page 2-99
- 12. "Miscellaneous Convenience Devices" on page 2-100
- 13. "Miscellaneous Access Covers and Doors" on page 2-109

Each group is explained with a point location drawing or photo and a brief description of each control, switch, gauge or valve.

Warning symbols will appear above the gauges on the display monitor when a problem with the machine is detected. The operator should monitor machine functions on the display monitor to ensure the machine is operating properly.



When any one or more of the warning symbols on the control console comes "ON", immediately stop operation. Investigate and correct the problem before proceeding with operation.

COMPONENT LOCATIONS



Figure 1

Reference Number	Description
1	Cabin
2	Hoist Cylinder
3	Stick Cylinder
4	Hoist
5	Arm
6	Heel Cylinder
7	Heel Rack
8	Track Link and Shoe
9	Idler

Reference Number	Description
10	Track Adjuster
11	Track Guard
12	Upper Roller
13	Lower Roller
14	Sprocket
15	Travel Motor
16	Counterweight
17	Hood

EX1505172



Reference Number	Description
1	Engine
2	Radiator
3	Precleaner
4	Air Cleaner
5	Main Pump

Reference Number	Description
6	Gear Pump (Rotating)
7	SCR Muffler
8	SCR Catalyst
9	Engine Oil Filter
10	Main Fuel Filter



Reference Number	Description
1	Battery
2	Fuel Tank
3	Fuel Cap
4	Urea Tank
5	DEF (AdBlue) Filter
6	Hydraulic Oil Tank

Reference Number	Description
7	Air Breather
8	Return Filter
9	Suction Filter
10	Water Separator and Pre Fuel Filter (Fuel Prefilter)
11	Pilot Filter



Reference Number	Description
1	Solenoid Valve
2	Center Joint
3	Swing Bearing

Reference Number	Description
4	Swing Device
5	Control Valve

OPERATOR'S AREA

STD Cabin



Oregon Cabin



Reference Number	Description
1	Seat
2	Suspension
3	Arm Rest
4	Left-hand Work Lever (Joystick)
5	Right-hand Work Lever (Joystick)
6	Travel Lever
7	Travel Pedal
8	Footrest
9	Safety Lever
10	Air Conditioner Unit
11	Display Monitor
12	Storage Space (Large)
13	Storage Net
14	Storage Space (Heating and Cooling)
15	Fuse Box
16	Storage Compartment (1)

Reference Number	Description
17	Storage Compartment (2)
18	Storage Compartment (3)
19	File Case
20	Sunglass Case
21	Cup Holder (PET)
22	Defroster Vent
23	Face Vent
24	Rear Vent
25	Foot Vent
26	Stereo
27	Hour Meter
28	Joystick Height Adjustment Knob
29	Mat
30	Step
31	Seat Belt
32	Engine Emergency Stop Switch
33	Straight Travel Pedal (Optional)

OPERATIONAL CONTROLS AND PANELS

STD Cabin



Figure 7

DS1604122

Oregon Cabin



Reference Number	Description
1	Starter Switch
2	Heater and Air Conditioner Control Panel
3	Power Socket for 12 V
4	Cigarette Lighter
5	Smart Power Control Switch (Road Builder Only)
6	Engine Speed Control Dial
7	Travel Speed Selector Switch
8	Light Switch
9	2-Pump Flow Control Switch
10	Cabin Work Light Switch (Optional)
11	Audio Control Panel
12	Wiper Control Panel
13	Quick Coupler Switch (Road Builder Only)
14	Travel/Swing Alarm Switch (Optional)
15	Power Socket for 12V

Reference Number	Description
16	Horn Button
17	Booster Button
18	Rotating Switch
19	Shear Switch
20	Display Monitor
21	Photo Sensor
22	Safety Lever
23	Auxiliary Mode Switch
24	Hour Meter
25	One Touch Deceleration Button
26	Selector Switch Control Panel
27	Jack Assembly
28	Micro Phone
29	DeSOx Switch
30	Wiper Switch (Oregon Cabin Only)
31	Washer Switch (Oregon Cabin Only)
32	Fan Switch (Oregon Cabin Only)

1. Starter Switch

A three-position starter switch is used to start or stop engine for equipment operation.

- Turning switch to this position turns engine "OFF" О. with its electrical system. In this position, engine is "OFF" but interior cabin light and fuel tank transfer pump (if equipped) are functional.
- ACC.Without starting engine, you can operate some electronic devices.
 - Video, MP3 _
 - Stereo
 - Power Socket for 12 V
- I. Turning switch to this position turns engine electrical system "ON". When the switch is first turned "ON", six indicator/warning symbols across top of the display monitor, will turn "ON" for approximately two seconds. The battery warning symbol and engine oil pressure warning symbol should remain "ON" after the other four have turned "OFF".
- \odot . Moving switch to this position will crank engine. When engine starts, release key and allow it to return to "I" (ON) position. Do not operate the starter switch for more than fifteen seconds at a time. This will help prevent damage to starter.



AVOID DEATH OR SERIOUS INJURY

DO NOT USE STARTING FLUIDS. The starting fluids may explode.

2. Heater and Air Conditioner Control Panel

This panel is used to control air conditioner and heater in operator's cabin. Refer to "Heater and Air Conditioner Control Panel" on page 2-87, for more information.





DS2100103







3. Power Socket for 12 Volt

This is a power socket for only 12V DC devices.

This socket can be used for charging a cellular phone or powering a small 12V DC electrical device.

Open the cap when using it.

NOTE: Avoid damage to electrical system. This socket is designed for small electrical capacity devices only. Do not use this socket for large electrical capacity devices.





4. Cigarette Lighter

Push the lighter all the way into the socket and release. After pushing it in, it will be ejected when it is heated. If it does not eject after a short time, pull it out and have it serviced.

NOTE: This cigarette lighter is for 24V only. Never connect a 12V electrical device to the lighter.





5. Smart Power Control Switch (Road Builder Only)

This switch activates when the engine starter switch is turned "I" (ON).

When this switch is activated, the engine rpm is dropped by 100 rpm in the work mode.

This function is designed to reduce fuel consumption depending on the workload of the engine rpm by adjusting the variable.

- O. The switch is automatically returned to this position when it is released.
- I. In this position, used for smart power control function. The smart power control symbol on display monitor will turn "ON".



6. Engine Speed Control Dial

The engine speed is controlled by the dial. Rotating it clockwise increases engine speed (rpm) and rotating it counterclockwise decreases engine speed.

- A Low Idle (Lowest engine speed).
- B High Idle (Highest engine speed).
- **NOTE:** The auto idle system will automatically reduce engine speed to "LOW IDLE" approximately four seconds after all the control levers are in the "NEUTRAL" position. This system is designed to reduce fuel consumption and noise. See "4. Auto Idle Selector/Buzzer Stop Button" on page 2-23.





AVOID DEATH OR SERIOUS INJURY

Do not operate the travel speed selector switch when machine is in motion. Temporary loss of control could result.

This switch activates the automatic speed range for travel.

- O. In this position, "LOW" travel speed is selected.
- I. In this position, "HIGH" travel speed is selected.
- II. In this position, "AUTOMATIC" travel speed is selected. The travel speed automatically changes between "LOW" or "HIGH" range, depending on engine speed and travel motor loads.

8. Light Switch

This switch is used to turn "ON" the lights.

- O. In this position, all lights are "OFF".
- I. In this position, all illumination lights of the display monitor and the control switches are turned "ON".
- II. In this position, all illumination lights and work lights are turned "ON".



Do not leave display monitor or work lights "ON" when the engine is not running. Leaving lights "ON" with the engine stopped will discharge batteries.







Figure 15



FG016017



9. 2-Pump Flow Control Switch

This switch is used to activate one or two optional pumps for heel operating.

- O. In this position, one pump is activated for use with an attachment.
- I. In this position, two pumps are activated for use with an attachment.





10. Cabin Work Light Switch (Optional)

This switch is used to control the cabin work lights, if unit is equipped with them.

- O. In this position, all cabin work lights are turned "OFF".
- I. In this position, the front cabin work lights on the front top of cabin will turn "ON".
- II. In this position, the front cabin work lights on the front top of cabin and rear cabin work lights on rear top of cabin will turn "ON".





11. Audio Control Panel

The audio system can be remotely controlled using this panel.



Power Button

Each time this power button is pressed, the audio system is turned either "ON" or "OFF".

If the audio system turns "ON", an indicator light above the button turns "ON".



FG000019

Figure 20

Increase Volume

Press the up button, to "INCREASE" volume.



FG000020

Decrease Volume

Press the down button, to "DECREASE" volume.

Figure 22

Figure 21

Scan Button

Manual Scan: When pressing scan button once, for less than half-a-second, the frequency will be moved up in sequence to the next available signal.

Auto Scan: When pressing scan button for more than a half-a-second, the frequencies are automatically scanned to the next higher one and will continue until button is again pressed to stop the scan.



FG000022

FG000021



12. Wiper Control Panel

This panel is only for operation of the upper windshield wiper. When the wiper stops running, it moves to right side of the cabin, resting in its support.

NOTE: When the front window is lifted, the wiper motor will not operate.





Constant Speed Button

Pressing the button turns "ON" the windshield wiper. An indicator light above the button will turn "ON" indicating that wiper is "ON". The wiper will run at a constant speed.

Pressing the button again, turns "OFF" the windshield wiper.



Figure 25

FG000241

Intermittent Speed Button

Pressing button once (first time):

Windshield wiper runs approximately on a three second intermittent cycle. The left side indicator light will turn "ON".

Pressing button again (second time):

Windshield wiper runs approximately on a six second intermittent cycle. The right side indicator light will turn "ON".

Pressing button again (third time):

Turns "OFF" the windshield wiper. Both indicator lights will **Figure 26** be turned "OFF".

Windshield Washer Button

Pressing the washer button will spray windshield washer fluid onto the windshield. Use only the proper windshield washer fluid in the system.

- **NOTE:** Do not operate the windshield washer without any fluid. If operated without any fluid, the washer motor may be damaged. Check level in washer tank and add fluid as required.
- **NOTE:** Using soapy water or synthetic detergent instead of window cleaning fluid can damage the wiper blade or painted surfaces. Use standard window cleaning fluid: SSK703



FG000242





FG000243

13. Quick Coupler Switch (Road Builder Only)

This switch is used for engaging or releasing the attachment.

See "Quick Coupler Operation" for further information.





Figure 28

AVOID DEATH OR SERIOUS INJURY

DO NOT OPERATE machine and attachment if quick coupler switch is in "I" (UNLOCKED) position.

Failure to fully engage and lock attachment to the quick coupler can allow attachment to fall off causing death or serious injury.

14. Travel/Swing Alarm Switch (Optional)

If unit is equipped with a travel/swing alarm, push this switch to active it whenever swinging or traveling.

- O. In this position, the travel/swing alarm system is turned "OFF".
- I. In this position, the travel alarm will only sound when the machine is traveling (moving).
- II. In this position, the travel alarm will sound while traveling and, if equipped with a swing alarm device, will also sound while swinging.
 - **NOTE:** If machine is only equipped with a travel alarm device, the alarm will not sound when swinging even if the switch is in the "II" position.

15. Power Socket for 12 Volt

This is a power socket for only 12V DC devices.

This socket can be used for charging a cellular phone or powering a small 12V DC electrical device.

Open the cap when using it.

NOTE: Avoid damage to electrical system. This socket is designed for small electrical capacity devices only. Do not use this socket for large electrical capacity devices.





FG017015



DS1903332

16. Horn Button (Left-hand Work Lever)

Press the right button on the top of the left-hand work lever (joystick) to sound horn.

NOTE: The starter switch must be "ON".



Figure 31

DS1601527

17. Booster Button (Right-hand Work Lever)

Press the left button on the top of the right-hand work lever (joystick) to boost the hydraulic pressure. Refer to the "Boost Mode" on page 3-33.

NOTE: This button works with the breaker/boost/shear selector switch.



Figure 32

18. Rotating Switch

For a machine equipped with an attachment that rotates, move the thumb wheel switch on top of left-hand work lever (joystick) to rotate the attachment.

Rotating switch "RIGHT" is for "CLOCKWISE ROTATION".

Rotating switch "LEFT" is for "COUNTERCLOCKWISE ROTATION".



Figure 33

DS1601529

Before using any attachment in a work application, be sure to check its functional control.

AVOID INJURY

Make sure that desired movement or action is being activated by the control, e.g. opening/closing, clockwise/counterclockwise, crowd/dump, etc.

19. Shear Switch

For a machine equipped with a shear, move the thumb wheel switch on top of right-hand work lever (joystick) to open or close the shear. Shear switch "RIGHT" is for "OPENING (DUMP)" and shear switch "LEFT" is for "CLOSING (CROWD)".

NOTE: This switch also interacts with the jog switch. See "3. Work Mode Selector Button" on page 2-23.





Figure 34

DS1601530

AVOID INJURY

Before using any attachment in a work application, be sure to check its functional control. Make sure that desired movement or action is being

activated by the control, e.g. opening/closing, clockwise/counterclockwise, crowd/dump, etc.

20. Display Monitor

See "Display Monitor" on page 2-27.





21. Photo Sensor

The photo sensor detects the radiant energy of the sun.

In "AUTO MODE" the air conditioner will automatically adjust the air temperature based on detected radiant energy.



Figure 36
22. Safety Lever

See "Safety Lever" on page 3-17.





23. Auxiliary Mode Switch

When the control system is out of order, the pump system can be controlled manually.

- O. In this position, the manual pump control is "OFF".
- I. In this position, the manual pump control is "ON".



Be sure to turn pump control to "O" (OFF) position, after the control system is operating properly.



Figure 38

24. Hour Meter

The hour meter is used to indicate the total number of operating hours on the engine. The meter will flash every four seconds when the engine is running to indicate that it is functioning properly.



Figure 39

HAOA601L

25. One Touch Deceleration Button

Press the left button on the top of the left-hand work lever (joystick) to reduce engine speed to "LOW IDLE".

When the button is pressed, the engine speed is immediately reduce to "LOW IDLE" rpm.

When the button is pressed again, the engine speed will return to the setting of the engine speed control dial.



DS1601552

Reference Number	Description
1	Jog Switch
2	Power Mode Selector Button
3	Work Mode Selector Button
4	Auto Idle Selector/ Buzzer Stop Button
5	Camera Mode Selector/ Escape (ESC) Button
6	Multimedia Button



26. Selector Switch Control Panel

1. Jog Switch

Press or turn the switch to select the menu or to change figures.

Engine speed can be changed according to the setting on the display monitor.

When a pop-up occurs, press the jog switch to remove it.

If this switch is pressed while on the camera screen, the screen will be divided into the windows according to the number of cameras. (Optional)

2. Power Mode Selector Button

Used for selecting the power plus mode, power mode, standard mode, or the economy mode.

Pressing the power mode selector button will display the available modes on the main window.

Place the selection bar by turning the jog switch and select the mode by pressing the jog switch.



Figure 42

FG018103



Figure 43

FG018104

3. Work Mode Selector Button

Pressing the work mode selector button will display the available modes in the main window.

Place the selection bar by turning the jog switch and select the mode by pressing the jog switch.

4. Auto Idle Selector/Buzzer Stop Button

Auto Idle Function: When the auto idle system is activated, the engine will automatically reduce speed to "LOW IDLE" approximately four seconds after all the control levers are in the neutral position. This system is designed to reduce fuel consumption and noise.

When the auto idle selector button is pushed to "ON" position, an indicator symbol on display monitor turns "ON".

When the auto idle selector button is pushed again, it is turned "OFF" and the engine speed will return to the setting of the engine speed dial and will remain at this speed despite control lever position, until engine speed dial is moved.

Buzzer Stop Function: When warning light appears and the buzzer sounds, use this button to "STOP" buzzer from sounding.

5. Camera Mode Selector/Escape (ESC) Button

Camera window will appear when the button in the main window is operated.

The window will go back to the previous window when the button is operated in any other window than the main window (ESC).

If a pop-up window appears, pressing the button will remove pop-up.



Used to select window for video and music (MP3).



AVOID DEATH OR SERIOUS INJURY

Listening to entertainment clips, such as video, music, etc., can cause an accident resulting in death or serious injury. Do not play entertainment files when operating the machine.

Figure 47

Figure 46





FG018107



FG018108



Figure 44

Figure 45

FG018105



FG018106

27. Jack Assembly

1. Hands-free Connector Jack

This jack is applied to Korean models only.

2. USB Port

Used for playing a video or MP3 file on the display monitor.





28. Micro Phone

Used for alerting people around machine when starting up or operating the machine.

How to use the microphone:

A. Siren

Turn switch (1, Figure 49) on the top to "ON" and set switch (2) on the bottom to "ON" position, the siren will be triggered.

A. Microphone

Turn switch (1, Figure 49) on the top to "ON" and then press switch (3).

Turn switch (4, Figure 49) clockwise or counterclockwise to increase or decrease the volume.



29. DeSOx Switch

Used for manual (forced) DeSOx or the inhibition (non-DeSOx) of SCR DeSOx.

NOTE: Run machine at "LOW IDLE" and do not stop engine until DeSOx cycle is completed. See "DeSOx" on page 3-28, for more information.



Move safety lever to "LOCK" position for manual (forced) DeSOx.

If the equipment is moved or switched off while manual (forced) DeSOx is in process, the DeSOx will need to be restarted.

- O. The switch automatically returns to this position when it is released.
- I. In this position, SCR DeSOx is inhibited (non-DeSOx).

The inhibition (non-DeSOx) symbol will light up on the display monitor.

Pressing on the switch to this position when already in SCR DeSOx inhibition (non-DeSOx) relieves the inhibition.

II. In this position, manual (forced) DeSOx is conducted for the SCR system.

Use this function when the DeSOx warning symbol has lit up on the display monitor.

NOTE: Turn "OFF" cutoff switch before you start forced DeSOx.

If the machine is moved or stopped while manual (forced) DeSOx is in process, the DeSOx cycle will need to be restarted.

If the switch is pressed to position II when in SCR DeSOx inhibition (non-DeSOx) mode, the warning lamp will light up on the display. Be careful.



Figure 50

FG018280

30. Wiper Switch (Oregon Cabin Only)

This switch is used to control the front window wiper.

- O. In this position, windshield wiper is "OFF".
- I. In this position, windshield wiper runs at an intermittent speed.
- II. In this position, windshield wiper runs at a constant speed.
- **NOTE:** Operating wiper without washer fluid or when there is sand or dirt present will damage the window and wiper.

31. Washer Switch (Oregon Cabin Only)

- O. In this position, windshield washer is "OFF".
- I. In this position, windshield washer fluid sprays onto the windshield while running the wiper. When released, the switch returns to "O" (OFF) position.





DS1601339



FG017855

Figure 52

32. Fan Switch (Oregon Cabin Only)

If unit is equipped with a warning light, push this switch to activate it.

- O. In this position, the Fan is turned "OFF".
- I. In this position, the Fan turns "ON" and will start flashing.





DISPLAY MONITOR



DS1601532

Figure 54

Reference Number	Description	
1	Fuel Gauge	
2	DEF (AdBlue) Level Gauge	
3	Engine Coolant Temperature Gauge	
4	Hydraulic Oil Temperature Gauge	
5	Multifunction Gauge and Graphic Information Area	
6	ECO Gauge	
7	Trip Meter	
8	Digital Clock	

Reference Number	Description	
9	Display Warning Symbols	
10	Warning Light	
11	Function Buttons	
12	Mode Selector Buttons	
13	Selector Function Display	
14	Jog Switch	
15	Camera Mode Selector/ ESC Button	
16	Multimedia Selector Button	

Functional Check

When the engine starter switch is turned to "I" (ON) position, all gauge bands, switch/button indicator lights and warning lights will turn "ON" and the alarm buzzer will sound for about two (2) seconds.

During this functional check, a LOGO will appear on the multifunction gauge in the graphic information area (3 and 4, Figure 54).

Password Activated

If a password has already been set and the system has been "LOCKED", the password display will appear on the screen once the functional check has been completed. Enter the password into the text area and then engage the starter.

NOTE: Refer to "Password Setting" on page 2-72, for further details.



If the password does not match the stored password, the engine will not start.

1. Fuel Gauge

Shows remaining fuel quantity in tank.

WHITE ZONE () - Indicates a normal fuel quantity.

RED ZONE () - Indicates that fuel level is low.

If the gauge pointer moves into the red zone, the fuel level symbol will turn "ON", and be displayed in the screen. Stop operation and immediately add fuel.



Check the fuel level on firm and level ground.

2. DEF (AdBlue) Level Gauge

Shows remaining DEF (AdBlue) quantity in DEF (AdBlue) tank.

WHITE ZONE (____) - Indicates a normal DEF (AdBlue) quantity.

RED ZONE () - Indicates that DEF (AdBlue) level is low.

If gauge pointer moves into red zone, SCR gauge symbol will turn "ON," and be displayed in screen. Stop operation and immediately add DEF (AdBlue).

Check DEF level on firm and level ground.







3. Engine Coolant Temperature Gauge

The colored bands indicate the temperature of the engine coolant.

WHITE ZONE (____) - Indicates temperature is within the normal operating range.

RED ZONE () - Indicates temperature is too high.

During operation, the pointer must be in the white zone.

If the gauge pointer moves into the red zone, the engine coolant temperature warning light will turn "ON", a warning buzzer will sound, and the engine speed will be automatically reduced. Allow the engine to run at "LOW IDLE" until temperature gauge registers in the white zone again. When the white zone is reached, allow the engine to idle for an additional three - five minutes before stopping the engine. If not allowed to idle, heat surge may develop which will damage the engine. Allowing the engine to idle will dissipate heat. Check the coolant level, look for a loose fan belt, inspect for debris around radiator, etc.

When the temperature reaches the normal range, the engine speed will automatically recover.

4. Hydraulic Oil Temperature Gauge

The colored bands indicate the temperature of the hydraulic oil.

WHITE ZONE () - Indicates temperature is within the normal operating range.

RED ZONE () - Indicates temperature is too high.

During operation, the pointer must be in the white zone.

If the gauge pointer moves into the red zone, the hydraulic oil temperature symbol will turn "ON", and be display in the screen. Allow the engine to run at "LOW IDLE" until temperature gauge registers in the white zone again.

NOTE: See "9. Display Warning Symbols" on page 2-32, for location of this warning symbol and others.



EX1301000





Figure 58

EX1301001

5. Multifunction Gauge and Graphic Information Area

When the engine starter switch is turned to "I" (ON) position, a LOGO will appear on the display screen for about two seconds.

When the LOGO disappears, the multifunction gauge and graphic information screen will appear.

The engine rpm is normally displayed at the bottom of the screen when the starter switch is first turned "ON". A digital clock is located at the top of the display.

By using a combination of the mode selector buttons, information for filters and oils can also be displayed.

The display can also be set for the desired language.

Refer to the "User Menu" on page 2-52 for the language selection and information display sequences.

Communication Indicator

Indicates the condition of communication between main controller and display monitor.

1. Normal Condition:

The symbol (Figure 60) will sequentially move like lightening.



Figure 59



Figure 60

FG000047

EX1301002

2. Abnormal Condition:

If a communication error is generated between EPOS controller and display monitor, communication error warning symbol (Figure 61) will be displayed.

When this symbol is displayed, contact a HYUNDAI distributor.

NOTE: When starter switch is turned to "I" (ON) position during a state of communication error failure, the EPOS controller will default to the following modes.

Power mode: Standard mode Working mode: Attachment mode Auto idle: "ON" (Selection state)

Engine Speed

The engine speed is numerically displayed.



FG000048

Figure 61

Figure 62

	rpm

EX1301378

6. ECO Gauge

- A. ECO symbol: shows the workload when using the equipment.
 - Green color: the green colored ECO symbol indicates that equipment is in normal operating condition.
 - Amber color: the amber colored ECO symbol indicates that equipment is a state of idling.
 - Red color: the red colored ECO symbol indicates rapid engine load or working with the equipment under load.
 - Gray color: the gray colored ECO symbol is displayed in other cases than above 3 color symbols.
- B. ECO gauge: shows the average fuel efficiency for 1 minute's operation.

A higher fuel consumption rate will drive this gauge closer to the max position.

- Green color gauge: fuel efficiency is in the economy mode.
- Amber color gauge: fuel efficiency is in the standard/power mode.
- Red color gauge: fuel efficiency is in the power plus mode.

7. Trip Meter

Real time fuel rate is numerically displayed.

A trip meter keeping track of fuel usage, operation time and average mileage and average daily mileage can be displayed through the trip meter settings.



8. Digital Clock

A digital clock, shows the current time. The displayed contents are as follows.

Display	Description
HH	Hour
mm	Minute

HH:mm

FG018262

Refer to the "User Menu" on page 2-52 for time setting.

9. Display Warning Symbols

Reference Number	Description	
1	Charge Warning Symbol	
2	Engine Oil Pressure Warning Symbol	
3	Engine Coolant Temperature Warning Symbol	
4	Engine Check Warning Symbol	
5	Hydraulic Oil Overheat Warning Symbol	
6	Fuel Shortage Warning Symbol	
7	Return Filter Clogged Warning Symbol	
8	Air Cleaner Clogged Warning Symbol	
9	Water in Fuel Warning Symbol	
10	Quick Coupler Release System Activated Warning Symbol (Road Builder Only)	
11	DEF (AdBlue) Low Level Warning Symbol	
12	SCR Failure Warning Symbol	
13	Engine Stop Warning Symbol	
14	Machine Check Symbol	
15	Machine Stop Symbol	
16	DeSOx Warning Symbol	
17	SCR High Temperature Warning Symbol	
18	TMS Terminal Fault	
19	Engine Speed Limitation	
20	Engine Start Limitation	
21	GPS Antenna Failure	
22	GSM Antenna Failure	
23	Satellite Antenna Failure	



Figure 67

Figure 66

NOTE: Symbols will appear across the top of display screen.



Figure 68

1. Charge Warning Symbol

This symbol indicates when the engine starter switch is turned "ON", and should go "OFF" after the engine starts. If it does not turn "OFF", stop engine immediately and determine the cause of the problem.





HAOA610L

2. Engine Oil Pressure Warning Symbol

This symbol indicates when the engine starter switch is turned "ON", and should go "OFF" after the engine starts. For example, if the engine oil pressure becomes too low, the light will turn "ON" and a warning buzzer will sound. If this happens, stop engine immediately and determine the cause of the problem. If work is continued when this light is "ON", it will result in serious engine damage.



If work is continued when this light is "ON", it will result in serious engine damage.



Figure 70

HAOA620L

Operating Controls

2 - 34

5.

3. Engine Coolant Temperature Warning Symbol

If engine coolant overheats, this symbol appears on the screen an alarm will sound, and the engine speed will be automatically reduced, until coolant temperature drops. Do not turn engine "OFF" because this will cause coolant temperature to rise and can cause engine to seize up because of heat surge.

NOTE: Check the engine coolant temperature gauge. If the gauge pointer moves into the red zone, the engine coolant temperature warning light will turn "ON", a warning buzzer will sound, and the engine speed will be automatically reduced. Allow the engine to run at "LOW IDLE" until temperature gauge registers in the white zone again. When the white zone is reached, allow the engine to idle for an additional three - five minutes before stopping the engine. If not allowed to idle, heat surge may develop which will damage the engine. Allowing the engine to idle will dissipate heat. Check the coolant level, look for a loose fan belt, inspect for debris around radiator, etc. When the temperature reaches the normal range, the engine speed will automatically recover.

4. Engine Check Warning Symbol

This symbol indicates when the engine needs to be check.

NOTE: If this symbol turns "ON" stop the machine and repair the cause of the fault.

If the hydraulic oil temperature is too high, this

Hydraulic Oil Overheat Warning Symbol

symbol appears on the screen.



HAOD350L



Figure 72

Figure 71

FG000045

Figure 73

FG000056

6. Fuel Shortage Warning Symbol

If the fuel quantity is too low, this symbol appears on the screen.

If this symbol turns "ON", add fuel as soon as possible.



FG000057

7. Return Filter Clogged Warning Symbol

This symbol indicates when the hydraulic return filter is clogged.

If this symbol is displayed, immediately stop operation and replace the return filter.

After the return filter has been serviced, restart machine operation to remove warning symbol.



FG000054

Figure 75

Figure 74

8. Air Cleaner Clogged Warning Symbol

This symbol indicates when the air cleaner is clogged.

If this symbol is displayed, immediately stop operation and replace or clean the air filter.

After the air filter has been serviced, restart machine operation to remove warning symbol.



FG000053

Figure 76

9. Water In Fuel Warning Symbol

This symbol indicates when the water is full in the fuel prefilter.

When this symbol appears, drain water from fuel prefilter as soon as possible.

NOTE: If operator leave the machine with no measure for 30 minutes after the water in fuel warning light up, the engine power will be derated.



DS1603475

10. Quick Coupler Release System Activated Warning Symbol (Road Builder Only)

This symbol indicates when the quick coupler release system is activated. A buzzer will also sound when the quick coupler release system is activated.



AVOID DEATH OR SERIOUS INJURY

DO NOT OPERATE machine and attachment if quick coupler switch is in "I" (UNLOCKED) position. Failure to fully engage and lock attachment to the quick coupler can allow attachment to fall off causing death or serious injury.



Reductant Level	Warning Symbol	Torque Reduction [*]
20%	Constant Symbol	
10%	Flashing Every 2 sec.	Torque is reduced by 25%.
5%	Flashing Rapidly Every 0.5 sec.	Torque is reduced to 0% (low idling).

FG002195



Figure 79

Figure 78

FG019175

DEF (AdBlue) Low Level Warning Symbol - EU

Reductant Level	Warning Symbol	Torque Reduction [*]
20%	Constant Symbol	None
10%	Flashing Every 2 sec.	Torque is reduced by 25%.
5%	Flashing Rapidly Every 0.5 sec.	Torque is reduced by 50% and rated speed by 60%.

The engine resumes normal torque after reductant has been filled to a level of at least 20%.

12. SCR Failure Warning Symbol

This symbol indicates when SCR system needs to be checked.

NOTE: If this symbol turns "ON", stop machine and repair cause of the problem.

Reaction to Faults in SCR System - EPA

Time	Warning Symbol	Torque Reduction [*]
Fault Detected	Constant Symbol	
After 30 minutes	Constant Symbol	Torque is reduced by 25%.
After 1 hour	Flashing Every 2 sec.	Torque is reduced by 50%.
After 4 hours	Flashing Rapidly Every 0.5 sec.	Torque is reduced to 0% (low idling).

If a new problem occurs within 40 hours of operation since first problem, warning symbol will turn "ON". After 30 minutes of operation, warning symbol will flash rapidly and torque will be reduced to 0% (low idling) within 30 minutes.

Reaction to Blocked EGR Valve and Malfunction of the Monitoring - EU

Time	Warning Symbol	Torque Reduction [*]
Fault Detected	Constant Symbol	
36 hours	Constant Symbol	Torque is reduced by 25%.
100 hours	Flashing Rapidly Every 0.5 sec.	Torque is reduced by 50% and rated speed by 60%.

Reaction to Interruption of Dosing and Reagent Quality - EU

Time	Warning Symbol	Torque Reduction [*]
Fault Detected	Constant Symbol	
10 hours	Constant Symbol	Torque is reduced by 25%.
20 hours	Flashing Rapidly Every 0.5 sec.	Torque is reduced by 50% and rated speed by 60%.



Figure 80

FG019176

Once the problem has been corrected and the engine control unit has received indication that it is working, torque will return to normal levels.



If torque is reduced to 0% (low idling), engine control unit will not detect that SCR system is functioning. A service technician must reset system so normal torque levels can be obtained.

13. Engine Stop Warning Symbol

If this warning symbol appears on the screen and a warning buzzer sounds, stop engine and service the emission control system immediately.



Figure 81

FG019003

14. Machine Check Symbol

Respective symbols light up when functions of the machine are not operating.

NOTE: If a symbol is lit up, after moving the machine to a safe location, find the cause of the malfunction and perform necessary repairs.



EX1301379



HECK

Figure 83

EX1301380

15. Machine Stop Symbol

A symbol will light up when there is a major defect with the machine.

NOTE: If this symbol is lit up, immediately shut off the machine and call for the machine to be serviced.

16. DeSOx Warning Symbol

The left-hand DeSOx symbol (Figure 84) turns "ON" when forced DeSOx is required, or during the manual (forced) DeSOx process. When the operator inhibits the DeSOx, the symbol will be displayed as shown in the right-hand view (Figure 84).

NOTE: Run machine at "LOW IDLE" and do not stop engine until DeSOx cycle is completed. See "Emission Control System" on page 3-25 for more information.



FG018399

Figure 84



Move safety lever to "LOCK" position for manual (forced) DeSOx.

If the equipment is moved or switched off while manual (forced) DeSOx, the DeSOx will need to be restarted.

- **NOTE:** If the machine is moved or switched off during DeSOx, the DeSOx process will need to be restarted.
- 17. Selective Catalytic Reduction (SCR) High Temperature Warning Symbol



AVOID DEATH OR SERIOUS INJURY

Exhaust gas temperature and exhaust system components are very hot during DeSOx. This can cause a fire or burn hazard and result in death or serious injury or damage to property. Keep flammable material and explosive gases away from exhaust system during DeSOx.

This SCR high temperature warning symbol is shown when DeSOx is in process.

Forced DeSOx - The symbol is amber color.

Active DeSOx - The symbol is green color.

NOTE: Run machine at "LOW IDLE" and do not stop engine until DeSOx cycle is completed. See "Emission Control System" on page 3-25, for more information.



FG018398

18. TMS Terminal Fault

This symbol indicates when TMS Terminal failure occurs.



DS1702302

Figure 86

19. Engine Speed Limitation

This symbol indicates when engine speed is limited by TMS.



DS1702302



20. Engine Start Limitation

This symbol indicates when engine start is limited by TMS.



DS1702302

Figure 88

21. GPS Antenna Failure

This symbol indicates when GPS antenna has failed or it is disconnected.



DS1702303

22. GSM Antenna Failure

This symbol indicates when GSM antenna has failed or it is disconnected.



DS1702304

Figure 90

23. Satellite Antenna Failure

This symbol indicates when satellite antenna has failed or it is disconnected.



Figure 91

DS1702305

10. Warning Light

This warning light appears when the machine or engine needs to be checked.



If warning light appears, stop the machine and repair the cause of the problem.



If necessary depending on the type of problem, contact your HYUNDAI distributor for repairs.

NOTE: For explanation of warnings see "Warning Pop-up Window" on page 2-49.



11. Function Buttons





1. Auto Idle Selector Button

When the auto idle system is activated, the engine will automatically reduce speed to "IDLE" approximately four seconds after all the control levers are in the "NEUTRAL" position. This system is designed to reduce fuel consumption and noise.

When the auto idle selector button is pushed to "ON" position, an indicator light above it turns "ON".

When the auto idle selector button is pushed again, it is turned "OFF" and the engine speed will return to the setting of the engine speed dial and will remain at this speed despite control lever position, until engine speed dial is moved



EX1301010



2. Up Arrow Button

Up arrow button (◀), is used to move a menu item "Up" or to "Left".





Figure 95

3. Down Arrow Button

Down arrow button (►), is used to move a menu item "Down" or to "Right".



Figure 96

EX1301012

4. Selector Button

Selector button (\checkmark) , is used to move a menu or clear the operating hour of filter/oil.



EX1301013



5. Display Selector Button (ESC - Escape)

Display selector button (), is used to change the displayed information on the screen. Each time the display selector button is pressed, the digital readout changes.

NOTE: When this button is used for menu/exit button, it is used to access to main menu or return to a previous screen from each submenu.



EX1301014

EX1301015



6. Camera Mode Selector

Camera window will appear when the button in the main window is operated.



12. Mode Selector Buttons





DS1601533

Figure 100

1. Power Mode Selector Button

Used for selecting power plus mode, power mode, standard mode, or economy mode.

Pressing power mode selector button will display available modes on main window.

Scroll through selection bar by turning jog switch and select mode by pressing jog switch.





DS1601534

2. Work Mode Selector Button

Used to select the attachment mode.

Pressing the "Work Mode" selector button will display the available modes in the main window.

Scroll through selection bar by turning the jog switch and select the mode by pressing the jog switch.





3. Auto Idle Selector Button

When the auto idle system is activated, the engine will automatically reduce speed to "IDLE" approximately four seconds after all the control levers are in "NEUTRAL" position. This system is designed to reduce fuel consumption and noise.

When the auto idle selector button is pushed to "ON" position, an auto idle symbol will be displayed on the display monitor.

When the auto idle selector button is pushed again, it is turned "OFF" and the engine speed will return to the setting of the engine speed dial and will remain at this speed despite control lever position, until engine speed dial is moved.

13. Selector Function Display

See "Switch Operation Indication" on page 2-85.

14. Jog Switch

See "1. Jog Switch" on page 2-22.

See "Launch Menu" on page 2-46.



FG018106



Figure 104

Figure 103

15. Camera Mode Selector/ESC Button

See "5. Camera Mode Selector/Escape (ESC) Button" on page 2-23.



FG018107

FG018103

16. Multimedia Selector Button

See "6. Multimedia Button" on page 2-23.



FG018108

Launch Menu

Items that are frequently used from the display monitor are configured into a launch menu to improve accessibility of features of the equipment.

1. User Menu

Use this to access the user menu from the display monitor.



EX1301394



Figure 108

Figure 106

2. Entertainment Video

Use this launcher symbol to access the Video menu when using the video feature among the entertainment features.

NOTE: This menu is activated when the USB device is connected to jack assembly.



EX1301395

Operating Controls 2-46

3. Entertainment MP3 Player

Use this launcher symbol to access the MP3 menu when using the MP3 feature among the entertainment features.

NOTE: This menu is activated when the USB device is connected to jack assembly.



EX1301396



4. Confirmation of Warning Sign

Activated when the equipment malfunctions. Use this to see details of the equipment malfunction and how to deal with it.

NOTE: This menu is activated when the failure information is displayed on the screen.



EX1301397



5. Power Mode

Power plus mode, power mode, standard mode and economy mode can be selected.



EX1301399



6. Work Mode

Used to select the work mode.



EX1301400

7. Trip Meter

Use this to see fuel usage according to operation time, operation period, average mileage and daily average mileage.

Fuel usage and operation period are based on the last clear time.



EX1301401





Figure 114

Warning Pop-up Window

When an alarm or warning is triggered, a pop-up window appears to describe it.

The pop-up window disappears when the warning symbol has disappeared or the ESC button or jog switch is pressed.

For multiple warnings and/or alarms, turn the jog switch to select the warning/alarm and read the relevant message.



AVOID DEATH OR SERIOUS INJURY

If a warning pop-up window appears, stop operation and check the message. Do not read message while traveling or operating machine.

1. Go to Warning Display

Turn the jog switch left or right or press the up and down arrow buttons on the dashboard to activate the launch menu.



Figure 115

2. Enter Checking Mode

Move the cursor over the Confirmation of Warning Sign using the jog switch and click the jog switch to see details of the malfunction.





EX1301405

3. Read Warning Message

Check the warning message by moving the jog switch.



EX1301405



4. Delete Warning Pop-up

Press escape or jog switch to delete the warning pop-up window.





	Warning	Description
1	Charge	Check the battery charging system.
2	Low E/G Oil Pressure	Check the engine oil system.
3	Coolant Overheat	Coolant is overheated. Service/repair the cooling system after fully cooled down.
4	E/G Warning	Check the engine system.
5	Water in Fuel	Drain the water in the fuel filter.
6	Hydraulic Oil	Hydraulic oil is overheated. Service/repair the oil system after fully cooled down.
7	Fuel Empty	Refuel.
8	Air Cleaner Clogged	Air cleaner is clogged. Check the air cleaner.
9	Return Filter	Return filter is clogged. Check the return filter.
10	Brake Oil Pressure Low	Brake oil pressure is too low. Check the brake system.
11	DEF Low Level	Refill DEF (AdBlue).
12	SCR Failure	Check the SCR system.
13	Machine Warning	Check the machine system.
14	TMS Terminal Fault	Due to TMS terminal fault, engine start will be limited. Please contact HYUNDAI service.
15	Engine Speed Limitation	Due to TMS, engine speed will be limited. Please contact HYUNDAI service.
16	Engine Start Limitation	Due to TMS, engine start will be limited. Please contact HYUNDAI service.
17	GPS Antenna Failure	GPS antenna not recognized; antenna has failed, or it is disconnected.
18	GSM Antenna Failure	GSM antenna not recognized; antenna has failed, or it is disconnected.
19	Satellite Antenna Failure	Satellite antenna not recognized; antenna has failed, or it is disconnected.

USER MENU

User Menu - Access and Escape Methods

Access Method

- 1. On the normal display screen, click on the jog switch to access the user menu screen.
- 2. Proceed to the user menu using the menu/esc button on the front of the dashboard.
- 3. Select the user menu from the launch menu.



<Normal Indication Monitor>



<Main Menu Monitor>

DS1601342

Figure 119

Escape Method

- 1. Press the ESC button to move to the normal display screen.
- 2. If 20 seconds have passed without the operation of the button, the normal display screen will be displayed.
- 3. Turning "OFF" the starter switch to cut off power, you will move to the normal display screen.

User Menu

Turn the jog switch and move the cursor to see a reversed display on the desired menu. Then, click on the jog switch to select the menu.

Press the ESC button to return to the previous screen.





DS1601343



AVOID DEATH OR SERIOUS INJURY

Do not use machine state menu when traveling or operating.

1. Machine State

This is used to check the current machine state, filter/oil information, machine information, etc.

Turn the jog switch and move the cursor to see a reversed display on the desired menu. Then, click on the jog switch to select the menu.

$\begin{array}{rcl} \text{Monitoring} & \leftrightarrow & \text{Filter/Oil} & \text{Information} & \leftrightarrow & \text{Machine} \\ \text{Information} & \leftrightarrow & \text{Fuel Efficiency Data} \end{array}$

Press the ESC button to return to the previous screen.

A. Monitoring

The monitoring screen displays the information on machine pump pressure, voltage, fuel level, etc.

At the machine state, if the cursor is placed on Monitoring, click on the jog switch to display the Monitoring screen.

Press the ESC button to return to the previous screen.













B. Filter/Oil Information

The screen displays the information on filter/oil use time, replacement period, and remaining time.

At the machine state, if the cursor is placed on the filter/oil information, click on the jog switch to display the filter/oil information.





Reset Method/Replacement Period Change Method

Move the cursor over the filter/oil item you wish to change using the jog switch or the \blacktriangleleft and \blacktriangleright buttons on the front of the dashboard and click the jog switch or press the 'Enter' button on the front of the dashboard. A window for resetting/changing the filter/ oil time will pop-up.

To reset the use time, move the cursor over 'clear' and click the jog switch or press the 'Enter' button on the front of the dashboard.

Turn the jog switch to locate it at YES. Then, click on the jog switch to reset the operation hour.

Turn the jog switch to locate it at NO. Then, click on the jog switch to allow the pop-up window to disappear without resetting the operation hour.













 The filter/oil use time shows the hours of operation after initializing the engine. It begins again with 0 hr after initialization the following the replacement of filter/oil.











To change the filter/oil exchange period, move the cursor over 'change' in the window for resetting/ changing the filter/oil time and click the jog switch or press the 'Enter' button on the front of the dashboard.

After the exchange period change screen pops up, click the jog switch or press the 'Enter' button on the front of the dashboard and the exchange time will start flashing.

Next, change the exchange period using the jog switch or the \blacktriangleleft and \blacktriangleright buttons on the front of the dashboard.

Then, turn the jog switch counterclockwise to reduce the period. Turn clockwise to extend the period.

With the replacement period change being completed, click on the jog switch to create a pop-up window to select the period change.

Turn the jog switch to locate it at YES. Then, click on the jog switch to change the replacement period.

Turn the jog switch to locate it at NO. Then, click on the jog switch to allow the pop-up window to disappear without the replacement period not being changed.

Filter/Oil Period Setup Table





Unit: hr

	Replacement Period			
Kind	Basic Setup Value	Minimum Available Setup Value	Change Value By Step	
Fuel Filter	500	100	50	
Air Cleaner	2,000	1,000	50	
Engine Oil Filter	500	100	50	
Return Filter	1,000	100	50	
Pilot Filter	1,000	100	50	
Engine Oil	500	100	50	
Hydraulic Oil	2,000	1,000	50	
Coolant	2,000	1,000	50	

Symbol Description

Filter/ Oil Name	Fuel Filter	Air Cleaner	ENG Oil Filter	Return Filter	Pilot Filter	ENG Oil	HYD. Oil	Coolant
lcon		₹ 		R 6	₽ <u> </u>	ଡ	6	

Figure 129

DS1701749

If the remaining time for filter/oil replacement is less than 10 hours, this pop-up window will be created. Press the ESC button or the jog switch to allow the pop-up window to disappear.



DS1601352

Figure 130

Figure 131

If the filter/oil replacement period is exceeded, this pop-up window will be created. Press the ESC button or the jog switch to allow the pop-up window to disappear.



AVOID DEATH OR SERIOUS INJURY

Do not use machine state menu when traveling or operating.

C. Machine Information

This is used to check the machine name, engine type and attachment options.

At the machine state, if the cursor is placed on the machine information, click the jog switch to access the machine information screen.

Click the ESC button to return to the previous screen.



DS1601353





WE1500736



Machine Information					
Engine					
Attachment Option					
Machine Number					
	Machine Machine Machine Machine Number	Machine Information Engine Attachment Option Machine Number			


D. Fuel Efficiency Data

It is possible to check the weekly fuel efficiency data, daily fuel efficiency data, weekly operation history data and daily operation data.



DS1601355

Figure 134



Figure 135



Figure 136

Weekly Operation History Data						
Days Before	Amount of Fuel Used	Operation Period	Daily Average Fuel Efficiency			
1	0 l	9.1 hr	0.0 ℓ/hr			
2	0 l	16.6 hr	0.0 ℓ/hr			
3	0 l	0.0 hr	0.0 ℓ/hr			
4	0 l	0.0 hr	0.0 ℓ/hr			
5	0 l	0.0 hr	0.0 ℓ/hr			
6	0 l	0.0 hr	0.0 ℓ/hr			
7	0 l	0.0 hr	0.0 ℓ/hr			

EX1402172

Figure 137

1) Weekly Fuel Efficiency Data

The amount of fuel used by each operating mode in a week can be checked.

2) Daily Fuel Efficiency Data

The amount of fuel used in a day can be checked.

3) Weekly Operation History Data

The amount of fuel used, operating period and daily average fuel efficiency in a week can be checked.

4) Daily Operational Data

The operation period, average fuel efficiency and amount of fuel used in a day can be checked.

Daily Operational Data			
	1		
Operation Period	150.3 hr		
Average Fuel Efficiency	0.0 ℓ/hr		
Amount of Fuel Used	0 ℓ		



2. Machine Configuration

This is used when selecting the functions such as camera setting, forced dial input and auto shut-off setting.

Turn the jog switch and move the cursor to see an reversed display on the desired menu. Then, click the jog switch to select the menu.



DS1601356

EX1402173



Press the ESC button to return to the previous screen.



A. Camera Setting

The camera setting screen is designed to set up various cameras "ON/OFF" and normal/mirror.

From the machine configuration, select camera setting to access the camera setting list screen.

Machine Configuration



DS1601357

Figure 141

The camera setting list screen displays various camera states (ON/OFF, NORMAL/MIRROR).

Select a camera and click the jog switch to access the relevant camera setting screen.

Press the ESC button to return to the previous screen.

Camera Setting
No 1 Camera No 2 Camera No 3 Camera

DS1601359

Figure 142

On the camera setting screen, set up the camera state (ON/OFF, NORMAL/MIRROR).

Also, see the actual image of the currently installed camera.





Figure 143

If a camera is not installed, the camera image section is shown as a blue screen.

If the cursor is placed on "ON/OFF", click on the jog switch to set up "ON" \leftrightarrow "OFF".

Turn the jog switch to locate the cursor at normal/ mirror. Then, click on the jog switch to set up normal \leftrightarrow mirror.

NOTE: The No 1 camera is fixed with the mirror mode. Therefore, normal/mirror mode selection is impossible.





B. Emergency Engine Speed Control Dial

The emergency engine speed control dial screen provides a method whereby to use the jog switch and control the engine rpm, replacing the engine control dial.

From the machine configuration, select the emergency engine speed control dial to access it.

If you access the emergency engine speed control dial screen, the initial cursor is located at the selector dial.

If the selector dial is shown as disable, the cursor cannot be moved.

Machine Configuration Camera Setting Emergency Engine Speed Control Dial Auto Shut-off Setting Option Operation Setting Other Settingt

DS1601360







Figure 146

When the cursor is placed at the selector dial, if you click on the jog switch, a pop-up window will be created, saying "Do you want to use manual Dial Control for Engine rpm?".

Operate the jog switch and select "YES/NO" to determine whether to use jog shuttle for dial.

If you select "YES", then selector dial is enabled, causing the pop-up window to disappear.

If you select "NO", then selector dial remains disabled, causing the pop-up window to disappear.

If the selector dial is shown as enable, operate the

jog switch clockwise and move the cursor to the setting rpm dial. When the cursor is placed at the setting rpm dial, click on the jog switch to cause the

cursor to flicker, changing into an editing mode to set up the rpm dial. When the cursor is placed at the

editing mode, operate the jog switch clockwise/

When the cursor is at the editing mode, press the ESC button to disable the editing mode. When the

cursor is not at the editing mode, press the ESC

counterclockwise, thus setting up the engine rpm.

button to return to the previous screen.



Emergency Engine Speed Control Dial







Before reboot the gauge panel or disabling the selector dial, control the engine rpm only with the shuttle of the gauge panel's jog shuttle.

C. Auto Shut-off Setting

In the auto shut-off setting screen, the engine of the equipment can be set to shut off automatically when the equipment is not operated for a preset time.

Select auto shut-off setting in the machine settings and proceed to the setting screen.



Figure 149

Figure 150

In the auto shut-off setting screen, the cursor will initially be over auto shut-off function in use.

NOTE: This feature is off in factory defaults.

To use the feature, place the cursor over auto shut-off function in use and click the jog switch to select the feature.

The engine can be set to shut off automatically after a maximum of 60 minutes to a minimum of 3 minutes.

In factory defaults, the time is set to 5 minutes. Further, this feature is off in factory defaults.

The following conditions must be met if this feature is to be used.

Auto Shut-off (ASD) Active Condition

able	
60	5 Min
60	

DS1601365

		Input						Output					
	Gauge Panel Menu	Auto Idle Mode	DeSOx Switch (SCR Regen Signal)	Pilot Cutoff Switch	Engine rpm	Coolant Temp.	Hydraulic Temp.	Dial Status	Time	Signal	Symbol	Pop-up	Alarm
Active	ON	ON	OFF	OFF	Low rpm	More than 50°C	More than 20°C	Normal	at Setting Time	Engine Stop Signal	ASD Operating Indicator "ON"	1 minute Before Stopping	10 seconds Before Stopping
Deactive		Except Above Condition						Time Cou	nt Reset				

When this feature is activated and the above conditions are met, "Engine will shut off" will pop up 1 minute before the engine shuts off.

Further, 10 seconds before the engine shuts off, the pilot buzzer will be activated to alert the user.



AVOID DEATH OR SERIOUS INJURY

When the auto shut-off feature is used, the engine shuts off automatically after the preset time, and thus particular care must be taken that no safety problems occur when it is used. D. Option Operation Setting (Option) This menu is not used in the machine.



DS1601366

EX1301429

DS1601787

Figure 151

Option Motion Setting				
Option Motion	Joystick Thumb Wheel Option Pedal			

Figure 152

E. Breaker Operation Time Setting (Road Builder Only)

This machine limits the continuous operation time of the breaker in order to prevent damages to its components.



Figure 153

You can adjust this time limit in the page of Breaker Operation Time Setting.

- Setting Time Range: 10 ~ 60 sec
- Default Time: 15 sec

Breaker Operat	ion Time	Setting
Breaker Operation Time	10	[15] Sec
		DS160178



F. Emergency Code (TMS)

This menu enables authorized personnel to temporarily unlock those machines that have been locked by the TMS server (Ignition lock or RPM limitation) but are currently located where they cannot receive an unlocking command from the server.

If you enter the menu when the machine is not

Pressing the Enter key without a 8-digit password

typed in will prompt a pop-up as shown in Figure 158.

locked, the screen will be shown as in Figure 157.



Figure 155

Emerg	ency Code(TMS)
0 1 2 3 4 5 6	789ABCDEF2~
	Enter Password

Figure 156



DS1702205

Emergency Code(TMS) Vehicle Operation is not locked.



Emergency Code(TMS) Please enter all 8 digits of password! **0** 1 2 F | ⊋ | ← Enter Password



DS1701752





If you type in a 8-digit password and press Enter and that results in "Unlock Success" data from the TMS server, then a pop-up will appear as shown in Figure 159.







If you type in a 8-digit password and press Enter and that results in "Unlock Fail" data from the TMS server, then a "Password Error" pop-up will appear as shown in Figure 160.



Figure 160

3. Entertainment

This menu is used to replay videos and MP3.

Turn the jog switch and move the cursor to see a reversed display on the desired menu. Then, click on the jog switch to select the menu.





$\textbf{Video}\leftrightarrow \textbf{MP3}$

Press the ESC button to return to the previous screen.



DS1601368



If the use of entertainment is limited, this pop-up window will be created.

To lift the use limits, you should change the limit setup in the Gauge Panel configuration.

The pop-up window will automatically disappear in 3 seconds. Press the ESC button or the jog switch to remove pop-up window.

For details, See "Gauge Panel Configuration" on page 2-72.

If the use of entertainment is not limited, this pop-up window will be created. The pop-up window will automatically disappear in 3 seconds.

Press the ESC button or the jog switch to remove pop-up window.



AVOID DEATH OR SERIOUS INJURY

Listening to entertainment clips, such as video, music, etc., can cause an accident, resulting in death or serious injury. Do not play entertainment files when operating the machine.











A. Video

From the entertainment screen, select video to access it.

	Entertainment	
Video		r.
MP3		
	DS1601	368

Figure 165

When there is no USB storage system, a pop-up window is displayed for 3 seconds, saying "USB" Storage is not installed". and the video is not played.





When initially accessing the video player, the USB storage system file tree is displayed on the screen, operate the jog switch clockwise/counterclockwise to select and play a video.

If there is a video file that played last, it will automatically be replayed.





If the format is not supported, a pop-up window is displayed for 3 seconds, saying "This file is not available!" and the video is not played.





Formats that can be supported are given below.

Formats that can be supported			
File Type	AVI, MP4, MKV, MOV		
Supported Resolution	720*480, 720*384, 720*304, 704*448, 704*304, 640*480, 640*360, 640*272, 640*352, 672*288, 512*384, 576*432, 480*320, 480*360, 320*240		
Supported Video Codec	H.264, MPEG4, Xvid, MPEG1/2		
Supported Audio Codec	MP3		
Supported File Size	Under 1.7 GB		
Supported USB Format	FAT32		

The screen composition of the video player is given below.

The top section displays the current playing time of the total playing time.

The screen center shows the video being played.

The bottom displays the video player function operation symbol and cursor.

The video player function operation symbol and jog switch are operated in the following order.

$\begin{array}{l} Play/Pause \leftrightarrow \mbox{Replay the Previous File} \leftrightarrow \mbox{Video} \\ Progress \mbox{Bar} \leftrightarrow \mbox{Replay the Next File} \leftrightarrow \mbox{Video} \\ Files \mbox{List} \end{array}$

If no operation continues for more than 5 seconds, the video will automatically be converted into the whole screen.

On the whole screen, click on the jog switch or the ESC button to remove whole screen.









Play/Pause

Locate the cursor on the play/pause symbol and click on the jog switch to execute the video's play/pause functions.

With the play being on, click on the jog switch to display the pause symbol at the center of the screen, thus allowing the video to pause.

With the pause being on, click on the jog switch to cause the pause symbol at the center of the screen to disappear, resuming the video playing.





Replay the Previous File

Locate the cursor at the replay the previous file symbol and click on the jog switch to replay the previous file.





Locate the cursor at the video progress bar and click on the jog switch to convert into the fast forward/ rewinding mode.

On the fast forward/rewinding mode, operate the jog switch clockwise/counterclockwise to conduct fast forward/rewinding.

Fast forward/rewinding can be conducted at an interval of 30 seconds per click during which the jog switch is turned.

On the fast forward/rewinding mode, press the ESC button to disable the fast forward/rewinding mode.

Replay the Next File

Locate the cursor at the replay the next file symbol and click on the jog switch to replay the next file.









Video Files List

Locate the cursor at the video files list symbol and click on the jog switch to move to the video file list screen.





	Video
	₩Hard Disk₩MOVIE₩
•	 □(3) □ Video(1).avi □ Video(2).avi □ Video(3).avi □ Video(4).avi

FG018557



B. MP3

From the entertainment screen, select MP3 to access it.





If there is no USB storage system, a pop-up window is displayed for 3 seconds, saying "USB Storage is not installed". and the MP3 player is not run.





When initially accessing the MP3 player, the file tree screen of USB storage system is displayed. Operate the jog switch clockwise/counterclockwise to select and play an MP3 file.

If there is an MP3 file played last, the file will automatically be played.





The screen composition of MP3 player is given below.

The top section displays the name of the file being played and the current playing time of the total playing time.

The screen center shows the album image of the file being played, the album name, the song name and the name of the next file to be played.

The bottom displays the MP3 player function operation symbol and cursor.

The MP3 player function operation symbol and jog switch are operated in the following order.

$\begin{array}{l} \mbox{Play/Pause} \leftrightarrow \mbox{Replay the Previous File} \leftrightarrow \mbox{MP3} \\ \mbox{Progress Bar} \leftrightarrow \mbox{Replay the Next File} \leftrightarrow \mbox{MP3 Files} \\ \mbox{List} \leftrightarrow \mbox{Background MP3 Play} \end{array}$

Play/Pause

Locate the cursor at the play/pause symbol and click on the jog switch to execute the MP3 play/pause functions.

With play being on, click the jog switch to display the pause symbol at the center of the screen, causing the MP3 to pause.

With pause being on, click on the jog switch to cause the pause symbol at the center of the screen to disappear, resuming the MP3 playing.



Locate the cursor at the replay the previous file symbol, and click on the jog switch to replay the previous file.











Fast Forward/Rewinding

Locate the cursor at the video progress bar and click on the jog switch to convert into the fast forward/ rewinding mode.

On the fast forward/rewinding mode, operate the jog switch clockwise/counterclockwise to conduct fast forward/rewinding.

Fast forward/rewinding can be conducted at an interval of 30 seconds per click during which the jog switch is turned.

On the fast forward/rewinding mode, press the ESC button to disable the fast forward/rewinding mode.

Replay the Next File

Locate the cursor at the replay the previous file symbol and click on the jog switch to replay the next file.









MP3 Files List

Select a file and replay the MP3.

Locate the cursor at the MP3 files list symbol and click on the jog to move to the file list screen.



Figure 185



FG018560



Background MP3 Play

Position the cursor on the "HOME" button and pressing the jog switch, MP3 is played by the initial screen.







DS1601374

Figure 188

4. Gauge Panel Configuration

This menu is used to set up password, brightness, default screen and time, and to input service phone number. Turn the jog switch and move the cursor to see an reversed display on the desired menu. Then, click on the jog switch to select the menu.

Password Setting \leftrightarrow Brightness Setting \leftrightarrow Default Power Mode Setting \leftrightarrow Default Screen Setting \leftrightarrow Time Setting \leftrightarrow Service Phone Number Setting \leftrightarrow Unit Setting \leftrightarrow Language Setting \leftrightarrow Notification Setting \leftrightarrow Entertainment Use Setting

Press the ESC button to return to previous screen.

A. Password Setting

Password Setting

An owner passwords and operator passwords can be set (Only the owner password is selected in the default shipment state).

By using the password setting function, you can manage usage of operations and functions of the machine.



D51601





DS1601376



Owner Password Setting

1) Selection

An owner password can be set for managing functions of equipment and use privileges of the equipment for different operators.

To set an owner password, place the cursor over Owner Password Setting in the settings screen and click the jog switch (or press "Enter" on the keypad).

Password Setting
Owner Password Setting
Operator Password Seeting
DS1603033

Figure 191

2) Password entry

When the password entry screen appears, use the jog switch (or the keypad) to enter the password and move to the settings screen.

The default password is "1111".

How to enter the password

Rotate the jog switch to select digits from 0 to 9 below, and click Enter on the jog switch to input the password.

If the password is input incorrectly, use the \bigcirc button on the lower right to delete the input password.



If the password is input incorrectly three times in a row, you will be redirected to the main screen and the system will not start for the next 10 minutes.



EX1301416









Owner password settings include password change, start-up restriction settings, function item settings, operator password use settings, and operator password change.





Password change

To change the owner password, select password change with the jog switch (or the keypad).

	Owr	ner P	assv	vord	l Ch	ange	Э		
		1	_	0	-	0	0		
0	23	4	5	6	1	8	9	\square	ł
		E	nter F	assw	ord				







When the owner password has been changed, "Password Set!" will pop-up.



Figure 196

Item setting

Operator privileges and settings for engine start-up, attachment settings, and entertainment use settings can be set.

NOTE: Permission, which gives certain operators permission to use certain features, can only be checked when use is checked. In this case, the operator has the same privileges as the owner, and the operator's settings take precedence in equipment settings.

NOTE: This setting is off by default.

- a) Engine startup Setting of password input upon operation of equipment.
- Attachment setting b) Setting of password input for attachment setting.
- Entertainment use setting C) Setting of password input for entertainment (video/MP3) use setting.

Item Setting				
Item	Enable Operator Password	Permission		
Engine Startup				
Attachment Setting				
Entertainment Use Setting				

DS1603036

Figure 197

Operating Controls 2-74

Engine start-up setting

By selecting "Engine Start-up" among item settings the reentry time for password entry upon start-up of the equipment can be set.

- **NOTE:** No password for start-up of the equipment is setby default.
- a) Always Password is entered with each start-up.
- b) 1 min

If the system is started again within 1 minute from key-off after the password is input, the password is not requested again.

c) 5 min

If the system is started again within 5 minutes from key-off after the password is input, the password is not requested again.

Operator password setting

- a) Operator password use setting Sets use of the operator password.
- b) Operator password change After setting use privileges for the operator password, the owner can change the operator password.

	Password S	Setting	
	Password Cha	ange	
Owner	Always	© 1min	© 5min
	Item Setting		
Operator	Enable Ope	erator Passwoi	rd
	Password Cha	ange	

DS1603037

DS1603038



	Password Setting
Owner	Password Change
	Engine Startup Lock has not been set!
	Item Setting
Onerster	Enable Operator Password
Operator	Password Change

Figure 199

Operator Password Setting

1) Selection

If the owner checks operator password use in owner password setting, operator password setting will appear in the password setting screen so operator password can be set. (refer to "Owner Password Setting" on page 2-73).

To set a operator password, place the cursor over Operator Password Setting in the Password Setting screen and click the jog switch (or press "Enter" on the keypad).

2) Password entry

When the password input screen appears, input the password with the jog switch (or keypad) and move to the settings screen. (refer to "Owner Password Setting 2" on page 2-71.)

The default password is "1111".





3) Structure

Operator password settings include password change, start-up restriction settings, and function item settings.

	Password S	etting	
	Password Char	nge	
Operator	Always	© 1min	© 5min
	Item Setting		
	Item Setting		
			DS1603



Password change

To change the operator password, select password change, and change the operator password using the jog switch (or keypad).



Figure 202

When the operator password is changed, "Password Set!" will pop-up.





Item setting

Use of engine start-up, attachment setting, and entertainment use setting can be set.

- **NOTE:** This is only possible when permitted by the owner.
- a) Engine startup Setting of password input upon operation of equipment.
- Attachment setting Setting of password input for attachment setting.

Item Setting	
Item	Enable Operator Password
Engine Startup	
Attachment Setting	
Entertainment Use Setting	

Figure 204

DS1603043

Operating Controls 2-76

 c) Entertainment use setting Setting of password input for entertainment (video/MP3) use setting.

Engine start-up setting

By selecting "Engine Start-up" among item settings the reentry time for password entry upon start-up of the equipment can be set.

- a) Always Password is entered with each start-up.
- b) 1 min

If the system is started again within 1 minute from key-off after the password is input, the password is not requested again.

- c) 5 min If the system is started again within 5 minutes from key-off after the password is input, the password is not requested again.
- **NOTE:** If the owner uses the engine start-up feature but does not permit the operator to use it, the operator cannot select whether to use the feature, but can select the password reentry time.
- B. Brightness Setting

On the Gauge Panel configuration screen, when cursor is placed on brightness setting, click on the jog switch to display the screen brightness setting and camera brightness setting screen. Password Setting

 Operator
 Password Change

 Operator
 Imin © 5min

 Item Setting
 Item Setting





DS1601379

Figure 206

If you want to change the screen brightness, select the screen brightness setting to display the brightness adjustment screen.



Turn the jog switch and adjust the brightness of 0 - 100% at an interval of 10%.

The screen brightness when manufactured is set as 80%.

Press the ESC button to return to the previous screen.

NOTE: It automatically adjusts the screen brightness to prevent overheating of the monitor.

When the warning pop-up window appears, the change of the brightness setting menu is disabled.

When the monitor temperature drops below 90°C (194°F), the brightness of the monitor returns to the set brightness.

If you want to change the camera screen brightness, select the camera brightness setting to display the camera screen brightness adjustment screen.



EX1404972







EX1404851



Turn the jog switch to adjust the brightness of 0 - 100% at an interval of 10%.

The camera screen brightness at the machine release time is set as 80%.

Press the ESC button to return to the previous screen.

	80 %	

C. Default Power Mode Setting

On the Gauge Panel configuration screen, when cursor is placed on default power mode setting, click on the jog switch to access the default power mode setting.

Fuel Saving Mode is Enable



Fuel Saving Mode is Disable



	Gauge Panel Configuration	
	Password Setting	
-	Default Power Mode Setting	ĺ
	Time Setting Service Phone Number Setting	





Figure 211

DS1601382

D. Default Screen Setting

Sets the main screen display on the instrument panel.

Gauge Panel Configuration	
Default Power Mode Setting Default Screen Setting Time Setting Service Phone Number Setting Unit Setting	

Figure 213

The initial screen shows basic information, including the fuel level, coolant temperature and hydraulic oil temperature.



DS1601385

DS1601384

Figure 214

Enter the "Default Screen Setting" menu and select "Enable" for this function. Then, the main screen shows the camera view next time the starter switch is turned to the ON position.







Figure 216

E. Time Setting

On the Gauge Panel configuration screen, when cursor is placed on time setting, click the jog switch to access the time setting.

Turn the jog switch and locate the cursor at a target of change. Then, click on the jog switch to change the target.



DS1601386

EX1301447

Figure 217

Turn the jog switch to change numbers of each item.

If the setup is completed, click on the jog switch to store the setup details.

When the time setting is completed, locate cursor to 'SET' and press the job switch.

If the SET button is not pressed, time setting would not be completed.

Press the ESC button to return to the previous screen.

Time Setting			
TIME	09 : 47 : 24 PM		
DATE	2013 / 10 / 29 SET		

Figure 218

F. Service Phone Number Setting

On the Gauge Panel configuration screen, when cursor is placed on service phone number setting, click on the jog switch to access the service phone number setting.



Figure 219

Turn the jog switch and locate the cursor at a desired number. Then, click on the jog switch to input the number. If number input is completed, press the \checkmark key to enter the input phone numbers.

Use the \bigcirc key and delete erroneously input numbers.





When you input service phone numbers, if warning/ alarm is issued, check the input phone numbers in the pop-up window.



Figure 221

G. Unit Setting

On the Gauge Panel configuration screen, when cursor is placed on unit setting, click the jog switch to access the unit setting.

Gauge Panel Configuration	
Default Power Mode Setting Default Screen Setting Time Setting Service Phone Number Setting Unit Setting	

Figure 222

On the unit setting screen, change the units of Unit Setting temperature, pressure, flow rate, and speed. These figures at the machine release time are set as below:

Temperature	● <u></u> ©
Pressure	● bar
Flow	● lpm ◎ gpm
Speed	● kph ◎ mph

DS1603048

Figure 223



Temperature: °C Pressure: bar Flow rate: lpm Speed: kph

On the Gauge Panel configuration screen, when cursor is placed on language setting, click on the jog switch to access the language setting.





DS1601389

On the language selection screen, turn the jog switch and move the cursor to select a language. Then, click on the jog switch to adopt the selected language.

Press the ESC button to return to the previous screen.

Language

Korean, English, Chinese, Persian, Turkish, Indonesian, Polish, Arabic, Russian, Thai, Hindi, Japanese, French, German, Nederlands, Italian, Portuguese, Spanish, Finnish, Swedish, Norwegian, Danish, Vietnamese, Greek

I. Notification Setting

On the Gauge Panel configuration screen, when cursor is placed on notification setting, click on the jog switch to access the notification setting.

Language Setting				
	0	한국어		
	۲	English		
	\odot	中文		
	$^{\odot}$	Francaise		
	$^{\odot}$	Deutsch		
	$^{\odot}$	Nederlands		
	$^{\odot}$	Italiano		
	$^{\odot}$	Portugues		





DS1601391

EX1301062

Figure 226

Depending on the notification setting screen details, pop-ups are created on the main screen when warning/alarm is issued, when the switch is operated, and when the supplies replacement period expires.

On the notification setting screen, turn the jog switch and move the cursor to a desired location. Then, click on the jog switch to select enable or disable.

All notice items at the machine release time are set as Enable.

Warning Alarm Pop up	D Enable
Maintenance Notification Pop up	Enable



Operating Controls 2-83

J. Entertainment Use Setting

On the Gauge Panel configuration screen, when cursor is placed on entertainment use setting, click on the jog switch to access the entertainment use setting.



DS1601392

Figure 228

Depending on the entertainment use setting details, the use of video and MP3 is limited.

	Entertainment Use Setting
۲	Prohibition on Engine Running
0	Prohibition on Working or Travel
	E)/4004000



Switch Operation Indication

Enable

During the operation of switches for pressure increase, breaker, shear, travel, working light, parking, ram lock and quick coupler, this function indicates a relevant switch symbol at the left top or bottom. It displays the operation state on the screen.

Operation Indication Examples

1. Power Plus Mode Selection



Figure 230

2. Power Mode Selection

Standard Mode Selection

З.



Figure 231







5. Auto Idle Selection







Figure 235

6. Power Boost Selection

HEATER AND AIR CONDITIONER CONTROL PANEL

Location of Controls and Vents



Figure 236

EX1300842

The heater and air conditioner are combined into one unit in the rear cover behind the operator's seat.

The operator can control cabin temperature using the control panel installed in the switch panel.



Figure 237

Reference Number	Description	Reference Number	Description
1	Automatic Temperature Control	5	Air Inlet Selector Button
	Button	6	Fan Speed Selector Button
2	Off Button	7	Air Conditioner Button
3	Temperature Control Button	8	Defroster Button
4	Air Outlet Selector Button	9	LCD Display

DS2100099

NOTE: When the light switch is turned to "I" or "II" position, the LED for illuminating in the control panel will turn "ON".

1. Automatic Temperature Control Button

This button is used to control the temperature level in the cabin, according to the temperature setting of the operating panel.

When the system is in "AUTO" mode, specifications can be manually changed by pushing another button.

If a function is manually changed, the word "AUTO" does not appear in the LCD display, but the unchanged functions will remain in "AUTO" mode.

NOTE: To change the temperature unit, press the auto temperature adjustment button and the system stop button simultaneously for three seconds.

2. Off Button

This button is used to stop the fan and air conditioner.

3. Temperature Control Button

These buttons are used to control the cabin temperature.

Temperature is adjustable from $17^{\circ}C$ (62°F) to 32°C (90°F) by 0.5°C (1°F) increments.

Temperature setting is displayed on the LCD.

When the system is turned "ON", the previously set temperature is used as a starting point.

4. Mode Selector Button

This button is used to select which combination air outlets will be used.

A. Used to direct airflow to upper portion of operator's cabin from both the front and rear.



Figure 238

B. Used to direct airflow to upper portion of operator's cabin from both the front and rear. It will also deliver air to the lower portion of operator's cabin from under the operator's seat.



Figure 239

C. Used to direct airflow to lower portion of operator's cabin and feet. This mode is mainly used for heating.



D. Used to direct airflow to the front window and to operator's feet.





5. Air Inlet Selector Button

This button is used to select fresh air from outside the cabin, or recirculate air within the cabin.

Pressing this switch enables the choice between fresh air and recirculating air within the operator's cabin. The select mode is displayed on the LCD.

- Outside air introduction: When wishing to ventilate internal air. When wishing to remove moisture condensed on the glass window. (winter/rainy season)
- Internal air circulation: In the event that the interior needs to be warmed up or cooled down quickly. In the event of internal air circulation, the symbol shown on the right of the display will light up.

NOTE: Press the internal/outside air selection button for three seconds to display the outside air temperature.

6. Fan Speed Selector Buttons

These buttons are used to control the speed of the blower fan. Momentarily, pressing a button, changes the speed one stage.

Continuously pressing and holding a button, repeatedly changes the speed.

7. Air Conditioner Button

This button is used to turn the air conditioner "ON" or "OFF". When this function is activated, an "A/C" is displayed in the upper left corner of the LCD.

8. Defroster Button

Used to direct airflow to front window.

9. LCD Display

This display shows the current setting.



DS2100104

Memory Function

The air conditioner panel has a memory function. When the starter switch is turned "OFF", the settings for the panel will be stored. When the forestry machine is started, the last stored setting will be used.

Additional Operating Instructions

A proper indoor temperature in summer is 5 ~ 6°C (10 ~ 12°F) lower than the outdoor temperature.

Operate the air conditioner for twenty - thirty minutes a week to circulate the refrigerant in the system.

NOTE: The blower button must be on "Three Bars".

If operating the air conditioner or heater for a long time, operate the air inlet selector button and, when smoking, vent the air to the outside to prevent irritation to eyes.

STEREO

Before operating the stereo, read operation manual enclosed with stereo.

Stereo



Reference Number	Description
1	Power/Volume Control
2	Preset Station
3	Tuning Up/Down
4	USB Loading Port
5	Menu

Reference Number	Description
6	LCD
7	AM Selection
8	FM Selection
9	USB Selection
10	Auxiliary Mode
MISCELLANEOUS ELECTRICAL DEVICES

Cabin Light

A light is installed on the top of the operator's cabin.

The light will work despite starter switch position.

NOTE: If light is left "ON" for a long time while the engine is not running, the battery will be discharged.





0



EX1300566

Figure 244

Unlock •

Figure 245

244

- - - -

Pilot Cutoff Switch

When the safety lever is moved into "LOCK" position, the switch deactivates the work and travel levers. With the work and travel levers deactivated, no digging/operational work can be done.



A main circuit breaker is in the battery box. It will automatically cut off in case of an electrical short circuit or overload. This will prevent the electrical wiring and components from being burned or damaged.

If the circuit breaker is cut off, check all related circuits. This means something is wrong in the electrical circuit and it needs to be repaired.

After maintenance, press the red button for normal operation of circuit breaker.



Lock

Figure 246

Circuit Breaker (30 A)

A circuit breaker (30 A) is in the battery box.

If the engine does not crank, first check that starter switch is turned "ON" and no power is available (No indicator lights will light.).

If the circuit breaker is cut off, check all related circuits. This means something is wrong in the electrical circuit and it needs to be repaired.

After maintenance, press the red button for normal operation of circuit breaker.

Replace the circuit breaker if damage and investigate cause.



AVOID DEATH OR SERIOUS INJURY

Using the wrong circuit breaker could cause a wire harness short resulting in a fire, death or serious injury.

Fuse Boxes

There are two fuse boxes (Figure 248) on the left side of the heater box. The fuses prevent electrical devices from overloading or shorting.

A decal attached inside the fuse box access cover indicates the function and amperage of each fuse.

NOTE: For a further explanation see "Fuse Boxes" on page 4-82.

Spare fuses are mounted on the inside of fuse box access cover.

Change a fuse if the element separates. If the element of a new fuse separates, check the circuit and repair the circuit.



AVOID DEATH OR SERIOUS INJURY

Always replace fuses with the same type and capacity fuse that was removed. Improper fuses can cause electrical damage and result in a fire, death or serious injury.



Figure 247



Figure 248

SEAT ADJUSTMENT



AVOID DEATH OR SERIOUS INJURY

Adjust the seat position before starting operation or after changing the operator.

Do not adjust the seat position while the machine is moving because a loss of control can occur. Always stop the machine, apply the parking brake, and then adjust the seat.

Always fasten your seat belt while operating machine.

Adjust the seat so the control levers and pedals can be operated freely and easily with the operator's back against the backrest.

1. Forward/Backward Adjustment

Holding lever (1, Figure 249), raise it up, move the seat to the desired position. Release lever to lock the seat in the selected position. Adjustment range is 180 mm (7.1 in).

2. Adjusting Height of Seat and Depth of Cushion

Forward Tilt

Press the adjustment lever (3, Figure 249) to adjust the seat cushion angle. (0"/+4"/+8")

Cushion Slide

Press the adjustment lever (4, Figure 249), and adjust the seat cushion forward/backward by max. 50 mm, to fit with the length of the operator's thigh.

Seat Height

It is possible to move the seat up or down by combining adjustments forward and rear tilt. Height adjustment is 60 mm (2.4 in).

Adjust height of seat by moving adjustment lever (2, Figure 249) up or down. Seat height can be adjusted by referring to the weight indication window (A, Figure 249) on the right.

- Green: Standard weight
- Red: Underweight or overweight



Figure 249

Operating Controls 2-95

3. Reclining Position Adjustment

Pulling up left lever (3, Figure 250) allows seat backrest to be moved forward or backward.

Sit with your back against the seat back when adjusting it. If your back is not touching the seat back, the seat back may suddenly move forward.

4. Lumbar Support Adjustment

A lumbar support is located in the seat back.

Turn the dial (4, Figure 250) counterclockwise to increase the force of the lumbar support.

5. Headrest

The headrest (5, Figure 250) can be adjusted forward/ backward and up/down. Move it by holding both sides.



FG015815

Figure 250

6. Seat Belt



AVOID DEATH OR SERIOUS INJURY

The seat belt is for the operator's safety and must be worn for operator restraint. Before operating the machine, adjust the seat to the desired position for maximum comfort and machine control, fasten the seat belt. Seat belts must be worn across the pelvic region and adjusted snugly. Never fasten a seat belt across the abdomen.

Only operate the forestry machine while seated in the operators position.

Do not adjust the seat position while the machine is in motion as it could lead to a loss of control. Stop the machine, apply the parking brake, and then adjust the seat.

Always check the condition of seat belt and belt bracket before fastening it. Do not use seat belt with twists in it or with damaged or with missing hardware. Replace belt or bracket if damaged or worn.

Seat Belt Locking and Unlocking

Insert belt end (1, Figure 251) into buckle (2, Figure 251). Pull belt to check that belt end is locked into buckle.

Adjust belt length so it is comfortably tight against operator's pelvic region (hipbone).



Figure 251

HAOB140L

Press button (3, Figure 252) in center of buckle (2, Figure 252) and pull out belt (1, Figure 252) to unlock.



Figure 252

7. Left and Right Control Stand Adjustment

For operator's convenience, the right and left control stands and seat can slide together, within a 160 mm (6.3 in) forward or backward travel distance.

Holding lever (1, Figure 253), raise it up, set the seat to desired position. Release lever to lock seat in selected position.



8. Left and Right Control Stand Height Adjustment

The left and right dials (2, Figure 253) at the lower part of the seat can be turned to adjust the elevation height of each control stand. (\pm 1.2 in (\pm 30 mm))

It can be used to adjust the height of the control joystick.

9. Adjusting Height/Angle of Armrest

It is possible to adjust height of armrest by removing three bolts (2, Figure 254) holding armrest to driver's seat, and moving armrest up or down by intervals of 0.8 in (20 mm), and then installing armrest. Lift armrest slightly (1, Figure 254) and rotate dial on bottom of support to left and right to adjust angle of armrest.





10. Heating Operator's Seat

The air suspension seat can be heated. The heater switch is found on left-hand side of seat back. To heat the seat, press and hold switch until desired heat level is obtained. When heating is not needed or seat is warmed, turn switch to "OFF" position.

The seat warmer has a primary thermostat that allows it to operate between $28^{\circ} \sim 37^{\circ}C$ ($82^{\circ} \sim 99^{\circ}F$). At $37^{\circ}C$ ($99^{\circ}F$) the primary thermostat stops heating the seat.

NOTE: If the primary thermostat fails, there is a secondary (safety) thermostat that operates between 32° ~ 41°C (90° ~ 106°F). At 41°C (106°F) the secondary (safety) thermostat stops heating the seat. If the seat is heating up to a higher than normal temperature, have seat serviced immediately.

ENGINE EMERGENCY STOP SWITCH

If the engine cannot stop when using the starter switch, it can be stopped by moving the engine emergency stop switch to "I" (EMERGENCY STOP) position.

- O. In this position, the engine emergency stop system is "OFF".
- I. In this position, "EMERGENCY STOP" is selected. The engine will stop.





EMERGENCY EXIT GLASS BREAKING TOOL (STD CABIN ONLY)

This machine is equipped with a glass breaking tool. It is found on left pillar of cabin. This tool can be used to break the glass to exit from cabin in an emergency. Grip handle firmly and use sharp point to break glass.

• Be careful not to slip on broken pieces of glass on ground.



AVOID DEATH OR SERIOUS INJURY

Protect your eyes when breaking the glass.



MISCELLANEOUS CONVENIENCE DEVICES

Ceiling Cover (STD Cabin Only)

NOTE: If machine is equipped with an optional transparent ceiling cover, never use any chemical cleaners on its surface. Only use warm water to wash dust and dirt from its surfaces and dry it with a soft fabric towel.

Opening Ceiling Cover

- 1. Lower work tool to ground.
- 2. Move safety lever (Figure 37) to "LOCK" position.
- 3. Pull lock (1, Figure 259) in front center of ceiling cover and push it up with handle.



Figure 258

Closing Ceiling Cover

- 1. Lower work tool to ground.
- 2. Move safety lever (Figure 37) to "LOCK" position.
- 3. Pull down cover with handle (Figure 259) so lock (1, Figure 259) can be locked into bracket in ceiling frame.



Figure 259

Front Windows (STD Cabin Only)



AVOID DEATH OR SERIOUS INJURY

When leaving operator's seat, move safety lever to "LOCK" position (Figure 260) and stop engine to prevent accidental activation of the work levers and controls.

Front Upper Window

The front upper window can be housed in cabin's ceiling.

Opening Window

WARNING

AVOID DEATH OR SERIOUS INJURY

When storing front window in cabin roof, make sure both lock levers (2, Figure 261) are securely latched.

- 1. Lower work tool to ground.
- 2. Move safety lever (Figure 260) to "LOCK" position.
- 3. Set engine speed control dial to "LOW IDLE". Allow engine to idle for three five minutes.
- 4. Stop engine by turning key to "O" (OFF) position.
- 5. Hold window handles (1, Figure 261), then pull lock levers (2, Figure 261) to release lock. The top of front window will come out.
- 6. Pull window up, and push it against lock pin at the rear of cabin. Make sure that it is securely latched.
- 7. Check that lock levers are securely latched in locked position.
 - **NOTE:** When front upper window is open, never extend your head or body through window frame.
 - **NOTE:** If window happens to fall against machine, while some part of your body is extended outside cabin, it can result in serious personal injury.
 - **NOTE:** The front window is spring loaded to aid in opening it. To fasten rear lock pin, hold handle and fasten rear lock pin.



Figure 260







AVOID DEATH OR SERIOUS INJURY

Keep hands away from window frame when opening or closing window.

- 1. Lower work tool to ground.
- 2. Move safety lever (Figure 260) to "LOCK" position, and stop engine.
- 3. Holding upper handles (1, Figure 262) of front window with left and right-hand, pull lock levers (2, Figure 262) to release lock.
- 4. Push window forward, and lower it slowly.
- 5. When bottom of window, reaches top of the front bottom window, push front window to engage lock (2, Figure 262).
- 6. Check that lock levers are securely latched in lock position.

Front Bottom Window

Opening Window

The front bottom window can be removed and stored in rear of cabin.

- 1. Open front top window and secure it to ceiling. Press button to open levers on both sides (left and right), and lift bottom window (1, Figure 263) in direction of arrow.
- 2. Set bottom window in rubber holders (2, Figure 264) behind operator's seat. Secure window with left and right levers (3, Figure 264) with push button (4, Figure 264).



Keep hands dry when handling a window. Never drop window or let it come into contact with other parts of machine.







FG018574





Figure 264

2.

seat.

Reverse the removal procedure.



Make sure that bottom window is properly seated in bottom of the front cabin window opening. Closing upper window with bottom window unattached can damage bottom window.

Door Side Latch (STD Cabin Only)

- 1. The door side latch (1, Figure 265) is used to secure door to side of cabin when it is opened.
 - **NOTE:** Keep door closed and locked when machine is not in use.

To release door from side of cabin, push latch lever (2, Figure 266) down. The latch lever is to the left of operator's



Figure 265



Figure 266

Cabin Riser Access Door

This compartment allows access to cabin tilt bolts and cylinder.



Tilt Cabin

A tilt cabin is provided for transportation or maintenance purposes. Refer to "Transportation" on page 5-1 for operational information.

- 1. Loosen the 8 bolts in cabin riser. (Figure 268)
- **NOTE:** For the storage of removed bolts, you can screw them into the nuts (1, Figure 268) attached nearby.



Figure 268

- 2. Loosen the 2 bolts on right side of cabin riser. (Figure 269)
- **NOTE:** For the storage of removed bolts, you can screw them into the nuts (1, Figure 269) attached nearby.



3. Move electric switch (Figure 270) at "I" (ON) position and turn tilting lever (Figure 271) to the left during movement.

This operation should be controlled simultaneously.



AVOID DEATH OR SERIOUS INJURY

Normally switch must be at "O" (OFF) position. Unless, hot pressured oil may spurt.







Cabin Storage Compartments

There are three storage compartments behind the operator's seat.

The large compartment (1, Figure 272) is for storing nonperishable items.

The covered other one (2, Figure 272) is interconnected with the air conditioner. It can be supplied with either warm or cool air when air conditioner is turned "ON". The small compartment (3, Figure 272) is for storing small items. A net storage bag (4, Figure 272) is added.

There is a separate small tray on left side (5, Figure 273) and right side (6, Figure 273) of operator's seat.

A document storage case (7, Figure 273) which can store up to A4-size documents is prepared.



Figure 272





Sunglasses Case (STD Cabin Only)

The sunglasses storage case (1, Figure 274) is on the center top of the rear wall of the operator cabin.

Keep this case lid closed before and after use.





FG018579

Sun Visor (STD Cabin Only)

The machine has two sun visors.

Front Window Visor

The sun visor can be used to reduce the amount of sunlight coming through the front window and ceiling.

When wanting to reduce the amount of sunlight coming in the front window, pull bar (1, Figure 275) down.

When not wanting protection, hold bar with left-hand and push release button (2, Figure 275) with right-hand. This will allow visor to retract.

NOTE: Do not allow visor to roll backup without holding it. Not holding it can result in damage to visor and retract mechanism.



AVOID INJURY

Keep your head away from the retracting area of visor.

Ceiling Window Visor

When you wish to use visor, pull handle on bar (1, Figure 276) to middle holders (2, Figure 276) or the end holders (3, Figure 276). Hook bar on holders to secure visor in place.



Figure 275



Figure 276

EX1300816

Pull visor to release it. It will return to its original position.

NOTE: Do not allow visor to roll backup without holding it. Not holding it can result in damage to visor and retract mechanism.



AVOID INJURY

Keep your head away from the retracting area of visor.



Cup Holder

There is a rubber cup holder inside operator's cabin. Use it to keep your cup firmly in place.



When using cup holder, keep the cap closed to prevent spilling.

STD Cabin



Figure 280

Oregon Cabin

Operator can change a position of the cup holder. (Figure 280)

DS1601703

Mirror (Oregon Cabin Only)

There is a mirror inside operator's cabin. It is used to check front lower part of machine.



Figure 281

Document Delivery Hole (Oregon Cabin Only)

It is possible to pass a simple paper through a document delivery hole (Figure 282).



Figure 282

MISCELLANEOUS ACCESS COVERS AND DOORS

Side Door

Open side access door and slide prop rod (1, Figure 283) in slot (2) until it locks at end of slot.

Battery Box Door

Opening

Open cover and slide rod (1, Figure 284) in slot (2) until it locks in notch at end of slot to support cover.

Closing

To close cover, move end of prop rod out of notch so it can slide in slot.



UNSUPPORTED DOOR CAN FALL CAUSING DEATH OR SERIOUS INJURY

- To open door:
 - 1) Hold door firmly.
 - 2) Lift door slowly until locking device engages.
- To close door:
 - 1) Hold door firmly.
 - 2) Press locking device to disengage.
 - 3) Lower door slowly.





Engine Cover

Open cover and slide prop rod (1, Figure 285) in slot (2) until it locks in notch at end of slot to support cover.

To close cover, move end of prop rod out of notch so it can slide in slot.



Operation

TO OPERATE A NEW FORESTRY MACHINE

All HYUNDAI forestry machine are inspected before leaving the factory. However, it is required that operator follow these steps during the initial break-in period. Failure to follow these steps can result in damage to the equipment or reduced performance.

Hour	Load
For first 50 hours of operation	Maintain about 80% load of full capacity (Engine rpm: 80% of rated rpm)
After first 50 hours of operation	Full load

If machine is used at full load before it is broken in, it could affect the overall performance and service life of the machine.

- **NOTE:** 1. Check daily for leakage of coolant, fuel, engine oil and hydraulic oil.
 - 2. Inspect all lubricants daily and add appropriate lubricants as required.
 - 3. During operation, monitor all instruments and gauges from time to time.
 - 4. Avoid an extreme engine load.
 - 5. Operate unit at 80% load until engine and all other components are at operating temperatures.
 - 6. Check that work equipment is operating normally.
 - 7. Check machine for loose parts or for damage that may have occurred during shipping.
 - 8. Check for loose wiring or terminals, check gauge operation and battery electrolyte level.
 - 9. After the machine is newly installed or replaced, some of its components are to be initially and only once lubricated/greased or replaced. For details, refer to "Inspection, Maintenance and Adjustment" on page 4-1 of this manual.

STARTING AND STOPPING ENGINE

Inspection Before Starting Engine

Walk Around Checks



AVOID DEATH OR SERIOUS INJURY

If flammable materials such as leaves, paper, etc. are allowed to accumulate on high temperature components, such as the engine muffler and turbo, a fire can occur. Fuel, lubricant, and hydraulic oil leaks can cause a fire. Clean machine, remove all flammable materials from machine, and repair machine before operating.

Before starting engine, inspect the following items. If any problem is found, repair it before machine operation.

1. Overall

- Check for damage, wear, crack, oil leakage, play in work equipment, cylinders, linkages and hoses.
- Check the undercarriage for damage, wear, crack, oil leakage and loose bolts.
- Check for problems in doors, handrails, guardrails, steps and loose bolts.
- Clean and check cabin glass, rearview mirrors, rear view camera and lights.
- Clean and check monitor, switches and gauges in the cabin.
- 2. Cleaning
 - Remove dirt and debris from around engine, radiator, oil cooler and battery.
 - Check and remove flammable material around muffler, turbocharger, battery or other high temperature components.
 - Clean and inspect fins of radiator, oil cooler, CAC (Charged Air Cooler), fuel cooler and condenser.
- 3. Engine system
 - Check for coolant and oil leakage around the engine and cooling system.
 - Check engine emission control system.

- 4. Fuel system
 - Drain water and sediment from fuel tank and water separator.
 - Check for fuel leakage in fuel system.
- 5. Hydraulic system
 - Check for hydraulic oil leaks, damaged tubing and hoses and interference points of components.
- 6. Electric system
 - Check for damaged electrical cables and loose or missing connectors.
- 7. Lubrication
 - Perform all daily and periodic maintenance services. Perform services according to reading shown on hour meter.
- 8. Safety
 - Perform a machine walk-around. Make sure that no one is under the machine or performing any maintenance on it before starting engine.
- 9. After starting machine
 - Check that all operational controls and components are in proper operating condition and are functioning correctly. Stop operation and correct any problems before continuing work.

Checks Before Starting Engine

Before starting engine, inspect the following items. If any problem is found, repair it before machine operation. If the oil, fuel or coolant level are below the "LOW" mark, add it. For detail method, see "10 Hour / Daily Service" on page 4-26.

- 1. Grease boom, arm and front attachment pins.
- 2. Check engine oil level.
- 3. Check level of hydraulic oil tank.
- 4. Check fuel level.
- 5. Check DEF (AdBlue) level.
- 6. Check oil level of swing reduction gear.
- 7. Clean dust net in front of oil cooler and intercooler.
- 8. Check cooling system and refill as required.
- 9. Check level of window washer liquid.
- 10. Inspect engine fan blade.
- 11. Check air intake system.
- 12. Inspect seat belt for any damage and proper operation.
- 13. Inspect the structure for cracks and faulty welds.
- 14. Check the operation of all switches.
- 15. Check the operation of all exterior lights, horn, travel alarm/ swing alarm (if equipped), rear view camera and control console indicator and monitor lights.

Operational Checks Before Starting Engine

1. Turn battery disconnect switch to "ON" position (Figure 1).



Figure 1



AVOID DEATH OR SERIOUS INJURY

When leaving operator's seat, move the safety lever to "LOCK" (Figure 2) position and stop engine to prevent accidental activation of the work levers and controls.

- 2. Move safety lever to "LOCK" position (Figure 2).
- 3. Fasten seat belt. Check for proper operation and condition.
- 4. Set all operation levers in "NEUTRAL".

NOTE: Be careful not to move any switches when starting engine.

- Rotate the starter switch to "I" (ON) position (Figure 3). Check all indicator lights. Warning buzzers will sound for about two seconds. After two seconds, all lights except the following will turn "OFF".
 - Charging warning light
 - Engine oil pressure warning light
 - Engine coolant temperature gauge
 - Fuel gauge
 - Hydraulic oil temperature gauge
 - Engine rpm (0 rpm) digital readout





EX1500481





AVOID DEATH OR SERIOUS INJURY

Sound the horn before starting the engine and make sure there are no people or obstacles in the operating area.

- 1. Perform all steps in "Operational Checks Before Starting Engine" on page 3-5.
- 2. Set engine speed control dial to "LOW IDLE" (Figure 4). If control dial is at "HIGH IDLE", the engine will accelerate suddenly and cause damage to the engine.
- 3. Sound horn.





Figure 5

- 4. Turn starter switch to "I" (ON) position.
- 5. Enter password.
 - **NOTE:** If the security system is "LOCKED", a four-digit password will be required to start the engine. If the system is "UNLOCKED", no password will be required and this display screen will not appear.







If the engine does not start after approximately fifteen seconds of cranking, release the starter switch. Wait about five minutes and repeat above steps.

- After engine has started, release key. Key will return to "I" (ON) position (Figure 6).
- 8. Follow procedures in "Hydraulic System Warm-up" on page 3-13.



9. After warming unit, check all operating indicators to make sure that all engine systems (oil pressure, coolant, etc.) are in the normal operating range. If any problems are noticed, stop engine and correct the problem.

Normal	indicators	are:
--------	------------	------

No.	Instrument Panel Light or Gauge	Indicator Reading
1	Engine Coolant Temperature Gauge	White Range
2	Fuel Gauge	White Range
3	Hydraulic Oil Temperature Gauge	White Range
4	DEF (AdBlue) Level Gauge	White Range
5	Charging Warning	OFF
6	Engine Oil Pressure Warning	OFF
7	Engine Coolant Temperature Warning	OFF
8	Engine Check Warning	OFF



Figure 7

- 10. Check color of exhaust smoke.
 - No color or light blue Engine is running in good condition.
 - Black Incomplete combustion. Check cause.
 - White or dark blue Engine is burning engine oil. Check cause.
- 11. Check for usual engine vibration and noises. If any are heard or felt, investigate cause.
 - NOTE: If engine coolant temperature gauge pointer moves into the red zone, the engine coolant temperature warning light will turn "ON", a warning buzzer will sound, and the engine speed will be automatically reduced. Allow the engine to run at low idle speed until temperature gauge registers in the white zone again. When the white zone is reached, allow the engine to idle for an additional three - five (3 - 5) minutes before stopping the engine. If not allowed to idle, heat surge may develop which will damage the engine. Allowing the engine to idle will dissipate heat. Check the coolant level, look for a loose fan belt, inspect for debris around radiator, etc.

12. Even if the engine starts, wait for the engine oil pressure monitor light to turn "OFF". Do not touch the control levers or control pedal while the engine oil pressure monitor light is "ON".



If the engine oil pressure monitor light does not turn "OFF", after 4 to 5 seconds have passed, stop engine immediately. Check the oil level, check for leakage of oil, and take necessary corrective action.



HAOA620L

Figure 8

After start limit logic

When engine oil temperature is below -10°C, machine has the limit logic of the engine rpm to protect the engine. When the logic is activated, engine rpm is limited to be low idle.

Engine Temp. (°C)	-10	-15	-20	-30
Time After Start (sec.)	8	15	25	30



OVERHEATING STARTER CAN CAUSE DAMAGE

If the engine does not start after approximately fifteen seconds of cranking, release the starter switch. Wait about five (5) minutes for starter to cool and repeat above steps.

Engine Coolant Heater (Optional)

The engine coolant heater helps start-up and operation of the engine and equipment at temperatures below -20°C (-4°F).

- 1. Operating environment
 - A. Operating temperature of the engine coolant heater: $-40^{\circ} \sim 75^{\circ}$ C (-40° ~ 167°F).
 - B. Digital switch display temperature range: -20° ~ 75°C (-4° ~ 167°F).
- 2. Digital switch
 - A. Outline

The digital switch shown in Figure 9 operates the engine coolant heater.

The operator can turn "ON" or "OFF" the engine coolant heater with the digital switch, or set up 3 desired operating time bands.

The time is indicated by hours and minutes, while the day is indicated with two letter characters.

NOTE: The timer display may not work properly at temperatures below -20°C (-4°F).

When the battery is replaced or battery disconnection switch is turned "ON" or "OFF", the display will blink until button 1 (\bigcirc) is pressed. Pressing button 1 (\bigcirc) will reset system to normal condition. (Wake up function)

B. Button description

Button 1 (\bigcirc): Time setting and wake up function.

- Button 2 (**P**): Preset query time activation and program.
- Button 3 ($\underbrace{\ddagger t } \underbrace{t} \\ \vdots \\ instantaneous heating and switch off.$
- Button 4 (►): The mode to reduce the time, setup time and power on time. Reduce operating time.
- Button 5 (◀): The mode to increase the time, setup time and power on time. Increase operating time.
- C. Time and date setup

Pressing the button 1 (\bigcirc) for 2 seconds will enter clock setting mode, where time and date can be set up. When the time/date blinks, use the left (\blacktriangleleft) or right (\blacktriangleright) button to do the setting.

Pressing the left (\blacktriangleleft) or right (\triangleright) button for longer than 2 seconds, fast setting is enabled.

No pressing of buttons for 5 seconds will enter and save the time and date setting automatically.



Figure 9 Engine Coolant Heater Digital Switch

3. Operation

While the battery disconnection switch is "ON", the engine coolant heater can be started-up by the following modes:

A. Manual mode: The operator operates the heater by switching "ON/OFF" directly.

Pressing the $(\underline{\sharp}\underline{\dagger}\underline{\dagger})$ button turns on the heater, and pressing it once again will turn it off.

B. Auto mode: The heater turns on or off at preset time.

Pressing the (\mathbf{P}) button will make the program number blink. Set up the starting time using the left (\blacktriangleleft) or right (\blacktriangleright) button.

Keep pressing the (**P**) button to set up program numbers 2 and 3, or switch to time mode.

C. Operating mode: The heater will operate for desired time.

With the heater off, press the left (\triangleleft) button for 3 seconds. While the operating time is blinking, set up the desired operating time using the left (\triangleleft) or right

(►) button. (10 ~ 120 minutes).

D. Residual time setting

While the heater is operating, set up the required residual time using the left (\triangleleft) or right (\blacktriangleright) button. (1 ~ 120 minutes).

4. Digital timer error code

If there is a problem in the engine coolant heater, the digital switch will display an error code. Call the nearest service center and inform the center of the error code.

Error Code (Digital Timer)	Description
F 00	Control unit error
F 01	Failure to operate (after 2 successive trial for starting)
F 02	Ignition failure (3 or more failures)
F 03	Over or under current
F 04	Early flame detected
F 05	Combustion monitor broken or short-circuited
F 06	Temperature sensor line broken or short-circuited
F 07	Fuel pump line broken or short-circuited
F 08	Fan motor line broken, short-circuited, overloaded, or blocked
F 09	Ignition plug line broken or short-circuited
F 10	Overheated
F 11	Circulation pump line broken or short-circuited

Plug Heater (Optional)

- **NOTE:** When temperature drops below -25°C, recommend to Use the Plug Heater.
- 1. Mounting the plug heater
 - A. Drain the cooling system.
 - B. Remove existing plug. Keep the bolts and lock washers.
 - C. Apply teflon tape or thread sealant to heater threads.



The element should not touch any cavity walls. Contact with the walls can cause the element to fail during operation.

NOTE: The plug heater element is formed to fit the water passage without touching the walls.

- D. Thread the heater into the engine opening and tighten securely.
- 2. Attaching the cord
 - A. Align the cord and element pins on the heater. Press the cord onto the heater using even pressure across the cord cap. Place the clamp around bottom of cord cap and squeeze closed with pliers.
 - B. Route the cord to any convenient point and tie cord down to prevent damage and strain. Keep cord away from hot surfaces and moving objects.
- 3. Testing the plug heater
 - A. Refill the coolant system. Run engine until internal thermostat opens and continue running engine for 15 to 20 minutes to eliminate air pockets. Allow engine to cool. Check for leaks and proper coolant level.



AVOID INJURY

Do not connect plug heater to power supply before installation.

Handling the plug heater while connected to a power supply could cause burns.

- B. Connect plug heater to power supply and test for proper operation. The block near the heater should get hot.
 - **NOTE:** Do not test plug heater before installation. This will cause the heater to fail and void the warranty.



Figure 10



AVOID DEATH OR SERIOUS INJURY

- 1. An explosive gas is produced while batteries are in use or being charged. Keep flames or sparks away from the battery area.
- 2. Charge batteries in a well ventilated area.
- 3. Always wear eye protection when starting a machine with jumper cables.
- 4. Improper jump-starting procedures can cause an explosion resulting in death or personal injury.
- 5. Jump-start vehicles on dry ground or concrete. Do not jump-start the machine on a steel floor because the floor is always grounded.
- 6. When starting from another machine, make sure the machines do not touch.
- 7. Always connect the auxiliary battery positive (+) terminal to the depleted battery positive (+) terminal first. Then connect the auxiliary battery negative (-) terminal to the frame of the depleted battery machine second.
- 8. Connect positive cables first when installing cables and disconnect the negative cables first when removing.



The machine has a 24V (-) negative ground electrical system. Use the same capacity 24V booster batteries when jump-starting engine.

If the batteries are drained during starting procedures, jump-start engine using auxiliary or booster batteries according to the following procedure:

Connecting Booster Batteries

- 1. Stop engine before booster batteries (3, Figure 12) are mounted.
- Connect one end of red cable (1, Figure 12) to the positive (+) terminal of the machine batteries (4), and the other end to the positive (+) terminal of the booster batteries. Booster or charger cable connections must be made between the nonseries connected positive (+) terminals.
- 3. Connect one end of black cable (2, Figure 12) to the negative (-) terminal of the booster batteries (3), and then make ground connection to the upper frame (5) of the



HAOA440L







machine to be started with the other end of black (-) cable (2, Figure 12).

When making the last connection to upper frame, be sure to connect the cable end as far away from the machine batteries as possible. DO NOT CONNECT DIRECTLY TO THE NEGATIVE BATTERY TERMINAL.

4. Start the engine.

Disconnecting Booster Batteries

- 1. Disconnect black negative (-) cable (2, Figure 12) from the machine frame (5) first.
- 2. Disconnect the other end of black negative (-) cable (2, Figure 12) from the booster batteries (3).
- 3. Disconnect red positive (+) cable (1, Figure 12) from the booster batteries (3).
- 4. Disconnect red positive (+) cable (1, Figure 12) from the machine batteries (4).

Hydraulic System Warm-up



If a problem or abnormal operation occurs, immediately stop engine. Allow forestry machine to reach normal operating temperature before starting work, especially in cold weather.

The correct operating temperature of the hydraulic oil is $50^{\circ} \sim 80^{\circ}$ C (120° ~ 175°F). Make sure to follow the procedures listed here for hydraulic fluid warm-up.

1. Run engine for approximately five (5) minutes set at the middle of the speed range, without a load.





- 3. Slowly cycle boom, arm and heel cylinders about five times without a load to circulate the oil through the system. Do this for five (5) minutes.
- 4. Check for clearance and fully raise the front attachment. Swing clockwise three (3) revolutions. Swing counterclockwise three (3) revolutions.
- 5. Travel forward and reverse at low speed for two (2) revolutions of the drive sprocket.









Hydraulic System Warm-up - Cold Weather

1. Run engine at "LOW IDLE" (no load) for five (5) minutes (Figure 16).

Run engine for approximately five (5) minutes set at the middle of the speed range, without a load (Figure 17).



FG018152

Figure 16







2.

3. Move safety lever (Figure 18) to "UNLOCK" position.





5. Set engine speed control dial to "HIGH IDLE" (Figure 20).

- 6. Repeat Step 4 for five (5) minutes. If working speeds continue to be slow, continue to operate but use extreme caution because machine function may be erratic.
- 7. Check for clearance and fully raise the front attachment. Slowly swing clockwise three (3) revolutions. Slowly swing counterclockwise three (3) revolutions.
- 8. Travel forward and reverse at low speed for two (2) revolutions of the drive sprocket.



Figure 19

FG018384

FG018154





Stopping Engine

- NOTE: Allow engine to idle for three ~ five (3 ~ 5) minutes before stopping the engine. If not allowed to idle, heat surge may develop which will damage the engine. Allowing the engine to idle will allow the engine to cool down.
- 1. Park machine on firm and level ground.
- 2. Lower front end attachment to ground and make sure all operating controls are in "NEUTRAL".
- 3. Move safety lever to "LOCK" position (Figure 22).

- Set engine speed control dial to "LOW IDLE" (Figure 23). 4. Allow engine to idle for three ~ five $(3 \sim 5)$ minutes.

- 5. Stop engine by turning key to "O" (OFF) position (Figure 24).
- 6. Remove key from starter switch.







Figure 22



FG018152

EX1300557





Checks and Maintenance After Stopping Engine

- 1. Park the machine on dry and hard ground.
- 2. Repair forestry machine if there are any coolant or oil leaks.
- 3. Inspect front attachment and undercarriage for abnormal appearances. Check that attachment is secure. Correct any problems.
- 4. Fill fuel tank and drain any water collected in the fuel system to prevent it from freezing.
- 5. Inspect and remove accumulated flammable materials, such as leaves, paper etc., in engine compartment.
- 6. Clean all mud, debris, etc. from undercarriage and tracks. Make sure that all steps and handholds are clean, and that operator's cabin is clean.

SAFETY LEVER



AVOID DEATH OR SERIOUS INJURY

When leaving operator's seat move the safety lever to "LOCK" position and stop engine to prevent accidental activation of the work levers and controls.

Be careful not to move the work levers (joysticks) when moving safety lever.

- 1. Move safety lever (Figure 25) down into "LOCK" position. When safety lever is in the "LOCK" position, the front attachment, work controls, swing and travel movement will be disabled.
 - **NOTE:** Lower work tool (front attachment) to ground. Place all control levers in "NEUTRAL" and stop engine, before moving the safety lever.
- Move safety lever (Figure 25) to "UNLOCK" position, by pulling it up before starting work.
 - **NOTE:** When the engine is not running, but the safety lever is in "UNLOCK" and the starter key is turned "ON", moving the work levers (joysticks) can result in movement of the work equipment. The charged accumulators in the system will provide pilot pressure for control valve spool movement.



TRAVEL

WARNING

AVOID DEATH OR SERIOUS INJURY

- 1. When moving travel controls forward, tracked forestry machine will move in the direction of the idlers. Wheeled forestry machine will move in the direction of steering axle.
- 2. Before moving, make sure there are no persons or property in the way or on the machine. No riders. Sound the horn to alert workers and bystanders that you are about to move the machine.
- 3. Always be sure the path is clear during travel.
- 4. Use extreme caution when reversing travel. Be sure there is a clear path behind the machine.
- 5. Operate the travel control levers smoothly to avoid sudden starts or stops.
- 6. Before leaving the operator's seat, make sure to lock out all control systems and stop engine to avoid accidental activation of controls.

Automatic Travel Speed Control



AVOID DEATH OR SERIOUS INJURY

Do not change the travel mode while traveling. Always use speed mode "O" when traveling down a slope. Do not change to speed modes indicated "I" or "II" while going down a slope. Only change travel mode after coming to a complete stop.

Two travel speed ranges can be selected by using the travel speed selector switch on the control panel (Figure 26).

"O" (LOW) - In this position low travel speed and a higher torque are selected.

"I" (HIGH) - In this position high travel speed and a lower torque are selected.

"II" (AUTOMATIC) - Setting the control at the "II" position enables the machine to change to a different speed range automatically. This change happens automatically depending on the hydraulic oil pressure in the travel circuit. When hydraulic oil pressure rises, the travel speed is automatically set to low. An example is if the machine is traveling on a flat, solid surface, the higher speed range would be used. When a slope is encountered, the speed drops and the travel circuit hydraulic pressure rises, causing the control circuit to shift to the higher torque, lower speed range.


Travel Control Lever Operation

- 1. To travel straight (Figure 27), push both travel control levers/pedals fully forward or backwards. The farther the levers/pedals are pressed, the faster the travel speed.
 - **NOTE:** "X" is the sprocket end of the track.



Figure 27

- 2. Pivot turns (Figure 28) are made by rotating only one track forward or backward. The machine will pivot on the nonmoving track.
 - **NOTE:** "X" is the sprocket end of the track.



NOTE: "*X*" is the sprocket end of the track.





NOTE: "*X*" is the sprocket end of the track.











General Travel Instructions

1. Set engine speed control dial (Figure 31) on desired speed.



Figure 31

2. Move safety lever to "UNLOCK" position, and folding the front, raise it 40 \sim 50 cm (16 \sim 20 in) above ground. See Figure 32.



4. When traveling on rough ground, travel at a slow speed $(1.0 \sim 1.5 \text{ km/h} (0.62 \sim 0.93 \text{ MPH}))$. Reduce engine speed, to avoid shock loading the equipment. Be careful that an excessive force is not added to equipment by climbing on rocks.









AVOID DEATH OR SERIOUS INJURY

When traveling, keep attachment raised from $20 \sim 30$ cm (8 ~ 12 in) above the ground. Fasten your seat belt.

Operator should pay attention when traveling backward on a slope.

Never turn or travel across a slope.

Travel straight up or down the slope.

Choose a safe alternate route before climbing a slope.

If forestry machine starts to slip or becomes unstable, lower the work tool immediately into the ground, using it as a brake.

Avoid working on slopes, because there is a risk of roll-over while swinging and performing front attachment operations.

Do not swing towards bottom of slope with a loaded work tool.

In unavoidable cases, level the slope with fill soil to make the machine as horizontal as possible. See Figure 34.

Do not travel on slopes more than 30° because of risk of roll-over.

- 6. Travel straight up or down slopes, never diagonally across the slope. See Figure 35 and Figure 36. Extend the arm and lower the boom to keep the heel about 20 ~ 30 cm (8 ~ 12 in) off the ground. If the machine starts to slide or becomes unstable, lower the work tool to regain control. If the engine stalls, lower the work tool, make sure that all controls are in the "NEUTRAL" position and restart the engine.
 - **NOTE:** Even though engine stops on a slope, do not operate swing control. The hydraulic accumulators can cause the unit to swing.
 - **NOTE:** Do not open or close operator's door on a slope. Make sure door is latched.



EX1300663

EX151079





Figure 35





7. If dirt or mud builds up in the track frame, raise each track and rotate and clean that track.



When you raise the lower part by the boom and arm, support it with the bottom side of the heel, and keep the angle between the boom and arm at $100^{\circ} - 120^{\circ}$.





DS1602714

EX1300535

Make sure that material buildup has been cleared. See Figure 37 and Figure 38.



- 8. The forestry machine can travel in water that comes up to center of upper carriage rollers. Make sure that footing is solid so the machine will not sink. See "Working in Water" on page 3-40.
 - **NOTE:** If the machine is submerged to the point that water or mud gets into the swing bearing or center joint, stop machine operation. Remove machine from the submerged location to firm, dry ground. Do not operate until proper inspection and maintenance have been completed. Refer to the Shop Manual or contact your HYUNDAI distributor.



AVOID DEATH OR SERIOUS INJURY

- When moving the straight travel pedal forward, the 1. forestry machine will move forward in the direction of the idlers. When the pedal is moved backwards, the forestry machine will move backward in the direction of the drive sprocket.
- 2. Before moving, make sure there are no persons or property in the way or on the machine. No riders. Sound the horn to alert workers and bystanders that you are about to move the machine.
- 3. Always be sure the path is clear during travel.
- Use extreme caution when reversing travel. Be sure 4. there is a clear path behind the machine.
- Operate the travel control pedal smoothly to avoid 5. sudden starts or stops.
- 6. Before leaving the operator's seat, make sure to lock out all control systems and stop engine to avoid accidental activation of controls.

Operating

- 1. Forward
- 2. Reverse

NOTE: "X" is the sprocket end of the track.



Figure 39

Locking Pedal

When straight travel pedal in not needed, the pedal can be locked by using the prop rod (1, Figure 40) locking device.



Locking is completed when the top end of the prop (1) is positioned into pedal hole.

- A. Location for "UNLOCKING" (Figure 41).
- B. Location for "LOCKING" (Figure 41).



Figure 41

OPERATING INSTRUCTIONS

Engine Speed Control

Engine speed can be manually adjusted using the engine speed control dial. Increase engine speed by rotating the control knob clockwise. Decrease engine speed by rotating the control knob counterclockwise.



The engine speed control system has been set at the factory and should not require adjustment as part of routine maintenance.



FG018094

Emission Control System

This machine is equipped with an engine exhaust emission control system that meets applicable engine EPA/CARB exhaust emission regulations. The owner/operator is responsible for proper operation and maintenance of the emission control system as provided in this manual and the emissions-related warranty provisions. The system provides a warning if there are faults in the Selective Catalytic Reduction System (SCR) system or if the level of reductant in the reductant tank is too low. For example, if doser cooling is not working, the engine torque is reduced.

Reaction at Low Reductant Level

Reductant Level	Warning Symbol	Torque Reduction [*]
20%	Constant Symbol	
10%	Flashing Every 2 sec.	Torque is reduced by 25%.
5%	Flashing Rapidly Every 0.5 sec.	Torque is reduced to 0% (low idling).

DEF (AdBlue) Low Level Warning Symbol - EPA



Figure 43

Figure 42

FG019175

DEF (AdBlue) Low Level Warning Symbol - EU

Reductant Level	Warning Symbol	Torque Reduction [*]
20%	Constant Symbol	None
10%	Flashing Every 2 sec.	Torque is reduced by 25%.
5%	Flashing Rapidly Every 0.5 sec.	Torque is reduced by 50% and rated speed by 60%.

The engine resumes normal torque after reductant has been filled to a level of at least 20%.

Reaction to Faults in SCR System - EPA

Time	Warning Symbol	Torque Reduction [*]
Fault Detected	Constant Symbol	
After 30 minutes	Constant Symbol	Torque is reduced by 25%.
After 1 hour	Flashing Every 2 sec.	Torque is reduced by 50%.
After 4 hours	Flashing Rapidly Every 0.5 sec.	Torque is reduced to 0% (low idling).

If a new fault occurs within 40 hours of operation since the first fault, the warning symbol will come on. After 30 minutes of operation, the warning symbol will flash rapidly and engine torque will be reduced to 0% (low idling) within 30 minutes.

Reaction to Blocked EGR Valve and Malfunction of the Monitoring - EU

Time	Warning Symbol	Torque Reduction [*]
Fault Detected	Constant Symbol	
36 hours	Constant Symbol	Torque is reduced by 25%.
100 hours	Flashing Rapidly Every 0.5 sec.	Torque is reduced by 50% and rated speed by 60%.

Reaction to Interruption of Dosing and Reagent Quality - EU

Time	Warning Symbol	Torque Reduction [*]
Fault Detected	Constant Symbol	
10 hours	Constant Symbol	Torque is reduced by 25%.
20 hours	Flashing Rapidly Every 0.5 sec.	Torque is reduced by 50% and rated speed by 60%.

Once the fault has been corrected and the engine control unit received indication that it is working, engine torque returns to the normal level.



If the engine torque was reduced to 0% (low idling), the engine control unit will not detect that SCR system is functioning. Reset the system so normal torque is available.

DeSOx

Sulfur contained in fuel and oil degrades NOx reduction performance of SCR (Selective Catalytic Reduction) catalyst after combustion. Therefore, to ensure high efficiency for NOx reduction, the temperature of exhaust gas needs to be increased periodically to eliminate sulfur content, and this process is called as DeSOx.

The DeSOx process is automatically performed by the ECU periodically based on the operating time of the machine. If the process is not successfully performed according to the operating condition, the corresponding "Warning Light" comes on.

In this case, park the vehicle in a safe place and perform the DeSOx process manually according to the following procedure. If the process is successfully performed, the warning light goes off.



AVOID DEATH OR SERIOUS INJURY

Exhaust gas temperature and exhaust system components are very hot during DeSOx. This can cause a fire or burn hazard and result in death or serious injury or property damage. Keep flammable material and explosive gases away from exhaust system during DeSOx.



AVOID DEATH OR SERIOUS INJURY

The engine power can be degraded unless performing the DeSOx process manually after the warning light is turned on.

1. DeSOx light: light turns "ON" when DeSOx is required, or during the DeSOx process. When the operator inhibits DeSOx, the symbol will be displayed as shown in the right-hand view of Figure 44.





FG018399

2. The high temperature warning light turns "ON" as shown in Figure 45 to alert the operator of hot engine exhaust gases.

- 3. Manual (forced) DeSOx and inhibit switch: the upper symbol in Figure 46 is shown when the operator selects manual (forced) DeSOx with the switch. When the operator inhibits DeSOx, the lower symbol will be displayed as shown in Figure 46.
 - NOTE: If manual (forced) DeSOx is necessary after the inhibited DeSOx switch is turned "ON", press inhibited DeSOx switch again to turn "OFF" the inhibit symbol. Press switch to manual (forced) DeSOx position to activate system.

Active DeSOx

No action by the operator is required to start active DeSOx. DeSOx is automatically activated by the engine control unit (ECU). Contact your HYUNDAI distributor for more information.

Active DeSOx can occur anytime the engine is running, while operating the machine or when the machine is parked. During DeSOx, the DeSOx light and the high temperature warning light turn "ON" to alert the operator of hot engine exhaust gases. Machine operation can continue, but the operator should keep engine exhaust away from flammable materials. The operator can choose to "inhibit" active DeSOx, if operating conditions are not favorable to hot engine exhaust temperatures (e.g. working near flammable materials).

When completed, the regeneration lights on the monitor will turn "OFF".

NOTICE





FG018398

Figure 46

Figure 45

FG018400



Manual (Forced) DeSOx

The DeSOx is manually (forced) activated by the operator when the operator chooses to start the DeSOx process. Manual (forced) DeSOx may be required if the operator "inhibits" the active DeSOx process for an extended period of time because the operating conditions are not favorable to hot engine exhaust temperatures (e.g. working near flammable materials).

Procedures for manual (forced) DeSOx by the operator.

- 1. Park machine in a well ventilated area and away from flammable materials.
- 2. Set up machine in the following manner:
 - A. Operate machine until engine coolant and oil temperatures are above 40°C (104°F).
 - B. Set engine speed to "LOW IDLE".
- 3. Move safety lever to "LOCK" position.
- 4. Activate DeSOx switch (Figure 47) to start DeSOx process.

NOTE: DeSox switch should be pushed 3 - 8 sec for DeSOx. If puch time is over 16 sec, fault code would be displayed on monitor.

Engine speed will gradually increase from "LOW IDLE" to 1,800 rpm and DeSOx process will then start.





During DeSOx, high temperature warning light will be "ON".

When DeSOx stops, DeSOx and high temperature warning lights will turn "OFF".

NOTE: Operator can stop manual (forced) DeSOx by raising safety lever to "UNLOCK" position.



Figure 48

NOTE: Regeneration light on monitor (Figure 48) will be "ON".

Mode Selection

More efficient work can be done by choosing a proper power and work mode combination, suitable to type of work and conditions. Use the mode selection according to the following guide.

Power Mode

- 1. When the starter switch is turned "ON" the power mode is automatically defaulted to the standard setting.
- 2. Select a proper power mode using button (1, Figure 49) before starting work.
- 3. When the power mode button (1, Figure 49) is pressed, instrument panel displays a power mode selection pop up menu (2, Figure 50).

When power mode is selected, symbol (3, Figure 50) shows on screen.







Mode	Selection Point
Power Plue Mode	Heavy work.
Fower Flus Mode	Maximize production with full Power.
Power Mede	Fast work.
Fower Mode	• Work in a short period of time.
Standard Moda	General work.
Standard Mode	Optimize speed and fuel consumption.
	Light work.
Economy Mode	Minimize fuel consumption.
	Reduce noise.

Work Mode

- 1. When the starter switch is turned "ON" the work mode is automatically defaulted to attachment mode.
- 2. Select a proper work mode using button (4, Figure 51) before starting working.







Figure 52

Auto Idle Mode

- 1. The system will automatically reduce engine speed to idle speed approximately four (4) seconds after all the control levers are in the "NEUTRAL" position. When any lever is operated, engine speed is automatically returned to the preselected range.
- 2. When the starter switch is turned "ON", the work mode is automatically defaulted to "AUTO IDLE".
- 3. When the symbol is turned "ON", the auto idle function is activated. Deactivate the auto idle function by again pressing the auto idle selector button (5, Figure 53). Now the symbol will be turned "OFF".



AVOID DEATH OR SERIOUS INJURY

Turn "OFF" auto idle function when performing work in close operating areas, i.e., working in a narrow area and loading/unloading on or off a trailer.





Boost Mode

- 1. Power boost switch is used to achieve maximum force.
- 2. The power boost is activated when the left button is pressed on the top of right-hand work lever (joystick).
 - **NOTE:** Power boost mode does not affect forward and reverse travel.
 - **NOTE:** Do not use this switch for more than seven (7) seconds.



Figure 54 Right-hand Work Lever (Joystick)

Work Levers (Joysticks) (ISO Pattern)



AVOID DEATH OR SERIOUS INJURY

Check surrounding area before swinging. When operating a lever while in auto idle, proceed with caution because the engine speed will increase rapidly. Keep bystanders away.

NOTE: When starting work, move work levers (joysticks) slowly and check movement of swing and front attachment.

This equipment is manufactured using the lever control pattern described in ISO standards. Do not change valving, hoses, etc., that would change this control pattern. The boom, arm and work tool movements and swing direction of work levers (joysticks) are as follows:

Left-hand Work Lever (Joystick) (Figure 55 and Figure 56)

- 1. Arm dump
- 2. Arm crowd
- 3. Left swing
- 4. Right swing
- NOTE: The swing brake is spring applied and hydraulically released. It is always engaged when the work lever (joystick) is in "NEUTRAL" or the engine is stopped.
- NOTE: When operating the arm, it may stop momentarily. When the arm is operated, the weight of the arm can cause it to move faster than the amount of oil being supplied.









EX1300590



Right-hand Work Lever (Joystick) (Figure 55 and Figure 58)

- 5. Boom down
- 6. Boom up
- 7. Heel rack in
- 8. Heel rack out
- NOTE: Even after stopping the engine, the front can be lowered to the ground by the operating work lever (joystick) by moving safety lever to "UNLOCK" position and turning starter switch "ON".





EX1300591

Change Machine Control Pattern By Selector Valve (If Equipped)



AVOID DEATH OR SERIOUS INJURY

Check surrounding area before swinging. When operating a lever while in auto idle, proceed with caution because the engine speed will increase rapidly. Keep bystanders away.

NOTE: When starting work, move work levers (joysticks) slowly and check movement of swing and front attachment.

The machine control pattern can easily be changed to the ISO pattern or to the BHL pattern by changing the position of the selector valve (if equipped). Use the following procedure to change the position of the select valve.

The selector valve is located in the rear of the cabin.

- 1. Rotate spool to the ISO position or to BHL position.
- 2. A control pattern symbol shows on the display screen.





Figure 60









EX1301158

Work Levers (Joysticks) (BHL Pattern)

Left-hand Work Lever (Joystick) (Figure 59 and Figure 61)

- 1. Boom down
- 2. Boom up
- 3. Left swing
- 4. Right swing
- **NOTE:** The swing brake is spring applied and hydraulically released. It is always engaged when the work lever (joystick) is in "NEUTRAL" or the engine is stopped.



Figure 61

Right-hand Work Lever (Joystick) (Figure 59 and Figure 62)

- 5. Arm dump
- 6. Arm crowd
- 7. Heel rack in
- 8. Heel rack out
- **NOTE:** Even after stopping the engine, the front can be lowered to the ground by the operating work lever (joystick) by moving safety lever to "UNLOCK" position and turning starter switch "ON".
- **NOTE:** When operating the arm, it may stop momentarily. When the arm is operated, the weight of the arm can cause it to move faster than the amount of oil being supplied.







EX1300589

OPERATING PRECAUTIONS



AVOID DEATH OR SERIOUS INJURY

Do not rest your feet on the travel pedals during normal machine operation. Unexpected machine travel can occur in this situation.

- 1. Before starting work, inspect terrain and soil conditions. Level ground and drain area if necessary.
- 2. Install window guards when working where there is a possibility of falling rocks or other objects.
- 3. Check strength of supported structures in advance before working on them. If insufficient, reinforce it. If any doubt exists about structural strength, refuse to operate unit.
- 4. It is possible that boom, arm or work tool may come into contact with the upper or lower structure of the machine. There are working conditions which could allow this to happen.
- 5. Do not continually "bottom out" the hydraulic cylinders. Machine damage can occur if the cylinders are fully extended or retracted.
- 6. When working on soft or muddy ground, make sure that the machine is not sinking.







- - 8. Make sure there is adequate clearance from overhead electrical supply lines. See Figure 67.

9. If the working is in an underground location or in a building, make sure there is adequate overhead clearance and there is adequate ventilation. See Figure 68.

- 10. Do not use the grapple as a hammer or ramming device. This is dangerous and causes damage to the front attachment. See Figure 69.
- 11. Do not attempt to lift the machine by forcing the boom down. In some cases it may be necessary to lift the machine for track extension. This is permissible but, the grapple assembly must always be vertical to the ground and aligned with the arm so there is no bending of the grapple shaft.
- 12. Do not attempt to use the loader to pull heavy objects or stumps by use of the machine drive.











EX1501285



- 13. Do not use the grapple rotation control to stop the rotation of large logs or loads. This circuit is protected by crossover reliefs which do allow stopping the rotation of the empty grapple, but continuous use of this feature for large loads can cause rotation motor failures.
- 14. Do not swing hoist or brake unnecessarily fast. All can cause accidents.
- 15. ADDITIONAL PRECAUTIONS MAY BE NECESSARY, DEPENDING ON CONDITIONS AT THE WORK SITE. The manufacturer has no direct control over machine application, operation, inspection lubrication, or maintenance. Therefore conformance with GOOD SAFETY PRACTICE in these areas are the responsibility of the user.
- 16. Do not swing a log out of bind or swing-hammer a log into the saddle of a load. This can cause sever structural damage.
- 17. Do not allow anyone to ride the attachment or the load. This is an extremely dangerous practice.

Always Observe These Precautions

If the hydraulic fluid escapes, the attachment can fall immediately, endangering anything below. Make sure the blocking or solid ground (not the hydraulic oil) is actually supporting the attachment (or loader).

Release system pressure before attempting to make adjustments or repairs. Consult the manufacturer's instructions for procedures. PRESSURE MUST BE RELEASED CORRECTLY. REMEMBER, Pressure can be maintained in the hydraulic and air circuits long after the engine has been stopped.

Working in Water



When working in water, do not exceed a slope of more than 15° . If the slope is over 15° , the rear part of the upper structure will be immersed in water, resulting in radiator fan and engine damage.





EX1300601

When working in water, do not operate in water higher than the center of upper track roller(s) (1, Figure 71).

If swing bearing gets wet, immediately grease it until all the old grease is purged from bearing.

If water gets into swing gear housing, drain water immediately by removing lower inspection cover. Apply new grease.

After working in water, purge old grease from work tool pins.



Figure 71

Escaping From Mud

Be very careful to avoid getting stuck in mud.

Track On One Side Stuck

NOTE: When using the boom or arm to raise the machine, always have the end of heel in contact with the ground. The angle between the boom and arm must be 100° - 120°.

When only one side is stuck in mud, use the heel to raise the track and then lay boards or logs and drive the machine out.

Tracks On Both Sides Stuck

When the tracks on both sides are stuck in mud and slipping, making it impossible for the machine to move, lay boards or logs as explained above and dig the heel into the ground in front. Then pull in the arm and put the travel levers in the FORWARD position to pull the machine out.







DS1602718

Figure 73

PARKING FORESTRY MACHINE



AVOID DEATH OR SERIOUS INJURY

Park machine on firm and level ground. Avoid parking on slopes. If forestry machine must be parked on a slope, block tracks and place heel in ground. See Figure 74.

120° Block EX1300553



1. Park machine on firm and level ground. Lower work tool to ground as shown in Figure 75.



EX1300554



2. Set engine speed control dial on "LOW IDLE".









TOWING PROCEDURE



AVOID DEATH OR SERIOUS INJURY

Never use a damaged wire rope or chain. They could brake and cause a serious accident.

Always wear gloves when handling a chain or wire rope (cable).

When towing the forestry machine, use a wire rope (cable) or chain capable of handling the load.

Attach chain or wire rope (cable) to track frame.

Insert protective material such as thick cloths between track frame and wire rope (cable) to prevent the wire rope from being damaged.



AVOID DEATH OR SERIOUS INJURY

Only use shackle hook on track frame to haul objects that weigh less than 5 metric tons (5.51 U.S. Tons). Never use shackle hook to haul objects over 5 metric tons (5.51 U.S. Tons).



Figure 78



AVOID DEATH OR SERIOUS INJURY

Do not operate or work on this work tool unless you have read and understand the instructions and warnings given in this manual for both the work tool and the machine.

Failure to follow the instructions or heed the warnings could result in death or serious injury.

Contact your HYUNDAI distributor for replacement manuals. Proper care and maintenance is your responsibility.

NOTE: Selection of a hydraulic shear must be done with extra care.

Use of a hydraulic shear not recommended by HYUNDAI could result in structural damage to the machine.

Consult your HYUNDAI distributor for hydraulic shear information.

Be sure that no one is near the work tool to prevent injury. Keep the work tool under control always to prevent injury. When a demolition tool is used, all personnel should maintain a minimum distance of 10 m (33 ft).

Close all windows. Make sure that all required operator protective guards are in place. Wear all required personal protective equipment. Follow the instructions given in this manual for the work tool.



AVOID DEATH OR SERIOUS INJURY

Death or serious injury could occur from the demolition of pipes, vessels, tanks or other containers that may contain gas, flammable materials, or hazardous chemicals.

Do not perform any demolition work on these items until all of their contents have been removed.

Follow all laws and regulations for the removal and disposal of these materials.

To Activate Shear (Road Builder Only)

1. Set work mode to "SHEAR" position using button (1, Figure 79)





- 2. Move the thumb switch on the top of the right-hand work lever (joystick) to shear. Moving thumb wheel to the right will "OPEN" the work tool.
- Move the thumb switch on the top of the right-hand work lever (joystick) to shear. Moving thumb wheel to the left will "CLOSE" the work tool.



Figure 80





Operation 3-44

Two-way Valve Operation (Optional)

Activating Shear with Pedal Valve

- 1. Set work mode to "SHEAR" position using button.
- 2. Make sure that stopper (Figure 84) is in "SHEAR" position.

NOTE: When stopper is in "SHEAR" position, pedal valve can be moved/rocked in both directions.

- 3. Two-way operation is possible by rocking pedal back and forth between positions (1 and 2, Figure 82). When pedal is in its center (at rest) position, valve is in "NEUTRAL" and hydraulic oil flow is stopped.
- 4. Before operating attachment, be sure to check function controlled by direction of pedal movement.

Stopper Positions

The stopper has three positions;

- Shear
- Breaker
- Locked
- Rotate knob (3, Figure 84) clockwise in direction of arrow. The stopper (4) then engages or disengages the pedal bracket (5). The pedal can then function according to displayed symbol shown by knob rotation.



AVOID INJURY

When only operating breaker or shear using joystick button(s), and it is not being controlled by pedal, make sure stopper is in "LOCKED" position to prevent pedal from being activated.







Figure 83



Figure 84

DS1701784

Rotating Operation

For a machine equipped with an attachment that rotates, move the thumb wheel switch on top of left-hand work lever (joystick) to rotate the attachment.

Rotating switch "RIGHT" is for "CLOCKWISE ROTATION".

Rotating switch "LEFT" is for "COUNTERCLOCKWISE ROTATION".



Figure 85

DS1601529

AVOID DEATH OR SERIOUS INJURY

Before using any attachment in a work application, be sure to check its functional control. Make sure that desired movement or action is being activated by the control, e.g. opening/ closing, clockwise/counterclockwise, crowd/dump, etc.



OPERATION UNDER ABNORMAL CONDITIONS

NOTE: See "Maintenance in Special Conditions" on page 4-99 for other recommendations.

Operation In Extreme Cold

In extremely cold weather, avoid sudden travel movements and stay away from even slight slopes. The machine could slide down the slope.

Snow accumulation could hide potential hazards and slippery surfaces.

Warming up engine for a short period may be necessary to avoid operating with sluggish or reduced working capacity. The jolting shocks and impact loads caused by bumping or bottoming boom or attachment could cause severe stress in very cold temperatures. Reducing work cycle rate and workload may be necessary.

If machine is to be operated in extremely cold weather temperatures, certain precautions must be taken. The following paragraphs detail checks to be made to be certain machine is capable of operating at these temperatures.

- **NOTE:** When temperature drops below -25°C, recommend to Use the Plug Heater.
- 1. Keep batteries fully charged to prevent freezing. If distilled water is added to batteries, run engine at least one hour to mix electrolyte solution.

When temperature drops below -10°C, efficacy of the battery is reduced accordingly. Insulation of the battery prevents reduction of efficacy, and supports improvement of starting power of the starter.



AVOID DEATH OR SERIOUS INJURY

Explosion of the battery can cause death or serious injury. Never attempt to directly heat the battery with open fire.

- 2. Keep engine in good mechanical condition for easy starting and good performance during adverse weather.
- 3. Use engine oil with proper specifications for expected temperatures. Refer to "Table of Recommended Lubricants" on page 4-21, in this manual or Shop Manual for details.
- 4. Always keep the fuel tank fully filled after completion of the operation. Always drain water from the fuel tank before and after the operation. In addition, check the water separator, and drain it if required. The fuel filter, if frozen, may

interrupt the flow of fuel. Periodically remove water from the fuel tank, drain water from the filter, and replace the filter upon regular basis. To prevent fuel from being clogged because of formation of wax in fuel, make sure that wax formation point of fuel is lower than atmospheric temperature.



AVOID DEATH OR SERIOUS INJURY

Explosion of the fuel tank can cause serious injury or death. Never attempt to directly heat the fuel tank with open fire.

- 5. Lubricate entire machine according to "Lubrication and Service Chart" on page 4-18, in this manual or lubrication chart on machine.
- 6. Start engine and allow it to reach normal operating temperature before operating.
 - If mud and ice collects and freezes on any of moving parts while machine is idle, apply heat to thaw frozen material before attempting to operate machine.
 - Operate hydraulic units with care until they have reached a temperature which enable them to operate normally.
 - Check all machine controls and functions to be sure they are operating correctly.
- 7. An extra outer air filter must be kept in operator's cabin to replace element that could become iced and cause restricted airflow to engine.
- 8. Clean off all mud, snow and ice to prevent freezing. Cover machine with a tarp if possible, keep ends of tarp from freezing to ground.

Operation in Extreme Heat

Continuous operation of machine in high temperatures can cause machine to overheat. Monitor engine and hydraulic system temperatures and stop machine to let it cool, when necessary.

- 1. Make frequent inspections and services of fan and radiator. Check coolant level in radiator. Check grilles and radiator fins for accumulation of dirt, debris and insects which could block cooling passages.
 - Formation of scale and rust in cooling system occurs more rapidly in extremely high temperatures. Change antifreeze each year to keep corrosion inhibitor at full strength.

- If necessary, flush cooling system periodically to keep passages clear. Avoid use of water with a high alkali content which increases scale and rust formation.
- 2. Check level of battery electrolyte daily. Keep electrolyte above plates to prevent damage to batteries. Use a slightly weaker electrolyte solution in hot climates. Batteries self-discharge at a higher rate if left standing for long periods at high temperatures. If machine is to stand for several days, remove batteries and store in a cool place.



Do not store acid type storage batteries near stacks of tires. Acid fumes can damage rubber.

- 3. Service fuel system as directed in "Check Fuel Level" on page 4-29 and "Check for Leaks in Fuel System" on page 4-28, of this manual. Check for water content before filling fuel tank. High temperatures and cooling off cause condensation in storage drums.
- 4. Lubricate as specified in "Lubrication and Service Chart" on page 4-18, in this manual or Lubrication Decal on machine.
- 5. Do not park machine in sun for long periods of time. If possible, park machine under cover to protect it from sun, dirt and dust.
 - A. Cover machine if no suitable shelter is available. Protect engine compartment and hydraulics from dirt and debris.
 - B. In hot, damp climates, corrosion will occur on all parts of machine and will be accelerated during rainy season. Rust and paint blisters will appear on metal surfaces and fungus growth on other surfaces.
 - C. Protect all unfinished, exposed surfaces with a film of preservative oil. Protect cables and terminals with ignition insulation compound. Apply paint or suitable rust preventive to damaged surfaces to protect them from rust and corrosion.

Operation In Dusty and Sandy Areas

Operation of machine can cause dust in almost any area. However, when in predominantly dusty or sandy areas, additional precautions must be taken.

1. Keep cooling system fins and cooling areas clean. Blow out with compressed air, if possible, as often as necessary.



AVOID DEATH OR SERIOUS INJURY

Wear goggles when using compressed air to prevent face or eye injury.

- 2. Use care when servicing fuel system to prevent dust and sand from entering tank.
- 3. Service air cleaner at frequent intervals, check air restriction indicator daily and keep dust cup and dust valve clean. Prevent dust and sand from entering engine parts and compartments as much as possible.
- 4. Lubricate and perform services outlined on current lubrication chart on machine and "Lubrication and Service Chart" on page 4-18. Clean all lubrication fittings before applying lubricant. Sand mixed with lubricant becomes very abrasive and accelerates wear on parts.
- 5. Protect machine from dust and sand as much as possible. Park machine under cover to keep dust and sand from damaging unit.

Operation in Rainy or Humid Conditions

Operation under rainy or humid conditions is similar to that as in extreme heat procedures previously listed.

1. Keep all exposed surfaces coated with preservative oil. Pay particular attention to damaged or unpainted surfaces. Cover all paint cracks and chip marks as soon as possible to prevent corrosive effects.

Operation in Saltwater Areas

Saltwater and saltwater spray is very corrosive. When operating in saltwater areas, or in or around snow, observe the following precautions:

- 1. When exposed to saltwater, dry machine thoroughly and rinse with freshwater, as soon as possible.
- 2. Keep all exposed surfaces coated with preservative oil. Pay attention to damaged paint surfaces.
- 3. Keep all painted surfaces in good repair.
- 4. Lubricate machine as prescribed on lubrication chart on machine or "Lubrication and Service Chart" on page 4-18, in this manual. Shorten lubricating intervals for parts exposed to salt water.
- 5. Check operating controls to ensure proper functionality and that they return to "NEUTRAL" when released.

Operation at High Altitudes

Operation instructions at high altitudes are the same as those provided for extreme cold. Before operating at high altitudes, engine fuel and air mixture may have to be adjusted according to appropriate engine manual.

- 1. Check engine operating temperature for evidence of overheating. The radiator cap must make a perfect seal to maintain coolant pressure in cooling system.
 - Perform warming-up operation thoroughly. If machine is not thoroughly warmed up before control levers or control pedals are operated, reaction of machine will be slow.
 - If battery electrolyte is frozen, do not charge battery or start engine with a different power source. There is a potential hazard that could cause a battery explosion or fire.
 - Before charging or starting engine with a different power source, thaw battery electrolyte and check for any leakage of electrolyte before starting.

Operation During Electrical Storms

During electrical storms, do not enter or exit machine.

- If you are off machine, keep away from machine until storm passes.
- If you are in cabin, remain seated with machine stationary until storm passes. Do not touch controls or anything metal.

Equipment Lowering with Engine Stopped

To lower the boom, place the safety lever in the "UNLOCKED" position and turn starter switch to "I" (ON) position. Move the joystick to "BOOM LOWER" position. If the accumulator is still charged, the boom will lower. Turn key to "O" (OFF) position and remove from starter switch.

If the boom does not lower, the accumulator is empty. Use one of the following methods to lower the boom.

Machine without a Boom Lock Valve



AVOID DEATH OR SERIOUS INJURY

Boom weight can cause cylinder oil pressure to reach relief pressure of the boom lowering control device when the boom is supported by one cylinder. Boom can lower suddenly, causing death or serious injury.

To avoid death or serious injury, be sure no one is under or near the work tool before manually lowering the boom.

Keep all personnel and bystanders away from the boom area when lowering the boom with the engine stopped.

When you must manually lower the boom if the engine has stopped and cannot be started, use the following procedure:

- Relieve the pressure in the hydraulic system before 1. manually lowering the boom.
 - Α. Turn starter switch to "I" (ON) position.
 - Β. Move the safety lever to "UNLOCKED" position.
 - C. Move the joysticks and travel levers/pedals forward and backward to relieve accumulator pressure.
 - D. Turn key to "O" (OFF) position and remove from starter switch.
- 2. Allow hydraulic oil to cool. Tip breather cap up (1, Figure 86) on the top of the hydraulic tank until internal pressure in the hydraulic tank has been completely relieved.



Figure 86

- 3. Open the oil tank cover.
- 4. Connect an end of hose (2, Figure 88) to screw of poppet (3, Figure 88).
- 5. Slowly loosen screw of poppet (3, Figure 88) by 4 ~ 5 turns. This allows the hydraulic oil in the boom circuit to drain into the hydraulic tank. The boom will now start to lower.



NOTE: Refer to "Disposal of Hazardous Materials" on page 1-75 for information on containing fluid spillage.



AVOID DEATH OR SERIOUS INJURY

To prevent rapid boom lowering, slowly loosen poppet screw.

- 6. Make sure that work tool has lowered all the way to the ground. Tighten screw of poppet (3, Figure 88) to a torque of 1.96 N.m (0.2 kg.m, 1.45 ft lb).
- 7. Disconnect hose (2, Figure 88) from screw of poppet (3, Figure 88). Do not allow the oil that is contained in hose (2, Figure 88) to spill.
- 8. Connect hose (2, Figure 88) to the original position on the hydraulic tank and install the oil tank cover (1, Figure 88).

After completion of the manual boom lowering, make necessary repairs before you operate the machine again.

NOTE: For additional information, contact your HYUNDAI distributor.







AVOID DEATH OR SERIOUS INJURY

Boom weight can cause cylinder oil pressure to reach relief pressure of the boom lowering control device when the boom is supported by one cylinder. Boom can lower suddenly, causing death or serious injury.

To avoid death or serious injury, be sure no one is under or near the work tool before manually lowering the boom.

Keep all personnel and bystanders away from the boom area when lowering the boom with the engine stopped.

When you must manually lower the boom if the engine has stopped and cannot be started, or the hydraulic system is disabled, the operator can still lower the boom, using the following procedure, when machine is equipped with a boom lock valve.

- 1. Relieve the pressure in the hydraulic system before manually lowering the boom.
 - A. Turn starter switch to "I" (ON) position.
 - B. Move the safety lever to "UNLOCKED" position.
 - C. Move the joysticks and travel levers/pedals forward and backward to relieve accumulator pressure.
 - D. Turn key to "O" (OFF) position and remove from starter switch.
- 2. Loosen locknut (1, Figure 89) of the lock valve.
- 3. Slowly turn check valve (2, Figure 89) clockwise until check valve stops. The boom will lower to the ground.
- 4. Make sure that front attachment has been completely lowered onto the ground. Tighten check valve (2, Figure 89).
- 5. Tighten locknut (1, Figure 89) to a torque of 39.2 N.m (4 kg.m, 28.9 lb ft).

After completion of the manual boom lowering, make necessary repairs before you operate the machine again.

NOTE: For additional information, contact your HYUNDAI dealer.


LONG TERM STORAGE

When a machine is taken out of service and stored for a time exceeding 30 days, steps must be taken to protect the machine. Leaving equipment outdoors exposed to the elements will shorten its life.

An enclosure will protect the machine from rapid temperature changes and lessen the amount of condensation that forms in hydraulic components, engine, fuel tank, etc. If it is not possible to put the machine in an enclosure, cover it with a tarpaulin.

Check that storage site is not subject to flooding or other natural disasters.

After the machine has been positioned for storage and the engine stopped, perform the following operations:

Before Storage

Keep the forestry machine in the position shown in Figure 90 to prevent rust of the hydraulic piston rods.

- Inspect for damaged, loose or missing parts.
- Repaint necessary areas to prevent oxidation.
- Wash and clean all parts of machine.
- Store the machine in an indoor, stable place. If stored outside, cover with a waterproof tarp.
- Perform lubrication procedures on all grease points.
- Apply a coating of light oil to the exposed plated metal surfaces (such as hydraulic cylinder rods, etc.) and to all the control linkage and control cylinders. (Control valve spools, etc.)
- Remove battery from the forestry machine to be fully charged and stored.
- Inspect the coolant recovery tank and radiator to make sure the antifreeze level in the system is correct. Make sure that antifreeze concentration is enough for the lowest temperature anticipated during storage.
- Seal all external openings (i.e. engine exhaust outlet, crankcase and hydraulic breather, fuel vent line, etc.) with tape wide enough to cover the opening, regardless of size.
 - **NOTE:** When sealing with tape, be sure to extend tape approximately one inch (25 mm) beyond opening to insure a good seal.



EX1300557

During Storage

- Once a month, start the engine and follow the "Hydraulic Oil Warm-up" procedures listed in this manual.
 - **NOTE:** Remove all seals from the machine (i.e. crankcase and hydraulic breathers, engine air intake, fuel tank vent lines, etc.).

Operate hydraulic functions for traveling, swing and front operation two or three times for lubrication after "Hydraulic Oil Warm-up". Coat all the moving parts and surfaces of the components with a new oil film after operating. At the same time, charge the battery. Rotate track to prevent track seizing".

• Every 90 days, use a hydrometer to measure the protection of the coolant. Refer to the antifreeze/coolant protection chart to determine protection of the cooling system. Add coolant as required.

After Storage

- Before operating the work equipment, remove all grease from the hydraulic cylinder rods.
- Add grease and oil at all lubrication points.
- Adjust fan and alternator belt tension.
- Connect the charged battery.
- Check condition of all hoses and connections.
- Check the levels of engine oil, fuel, coolant and hydraulic circuit oil. If there is water in the oil, change all the oil.
- Change all filters.
- Inspect for signs of nests. (i.e. birds, rodents, etc.)
- When starting the engine after long-term storage, follow the "Hydraulic Oil Warm-up" procedures listed in this manual.

Inspection, Maintenance and Adjustment

MAINTENANCE INFORMATION

This section deals with information for proper maintenance of the machine. Therefore, ensure that all safety information, warnings, and instructions are read and understood before any operation or any maintenance procedures are performed.

Operational Hour Meter Reading

Check operational hour meter reading every day to see if necessary maintenance is scheduled to be performed.

HYUNDAI Genuine Replacement Parts

Use HYUNDAI genuine parts specified in Parts Book as replacement parts.

HYUNDAI Genuine Lubricants

For lubrication of the machine, use HYUNDAI genuine lubricants. Use oil of specified viscosity according to ambient temperature.

Windshield Washer Fluid

Use automobile window washer fluid, and be careful not to let any dirt get into it.

Fresh and Clean Lubricants

Use clean oil and grease. Keep containers of oil and grease containers clean and keep foreign materials away.

Check Drained Oil and Used Filter

After oil is changed or filters are replaced, check oil and filters for metal particles and foreign materials. If large quantities of metal particles or foreign materials are found, take corrective action.

Fuel Strainer

If your machine is equipped with a fuel strainer, do not remove it while fueling.

Welding Instructions

- Cut off power. Wait for approximately one minute after turning off engine starter switch key, and then turn battery disconnect switch to "OFF" position.
- Do not apply more than 200 V continuously.
- Connect grounding cable within 1 m (3.3 ft) of area to be welded. If grounding cable is connected near instruments, connectors, etc., instruments can be damaged.
- If a seal or bearing happens to come between part being welded and grounding point, change grounding point to avoid these types of parts.
- Do not use area around work equipment pins or hydraulic cylinders as grounding point.

Do Not Drop Things Inside Machine

• When opening inspection windows or oil filler port of tank to perform inspection, be careful not to drop nuts, bolts, or tools inside the machine.

If parts are dropped inside machine, it can cause damage and/or improper operation of the machine. If you drop anything inside the machine, always remove it immediately.

Dusty Work Site

When working at a dusty work site, do the following:

- Clean radiator fins and other parts of heat exchange equipment more frequently, and take care not to let fins become clogged.
- Replace fuel filter more frequently.
- Clean electrical components, especially starting motor and alternator, to avoid accumulation of dust.
- When checking and replacing oil or filters, move the machine to a place where there is no dust and take care to prevent dust from entering system.

Avoid Mixing Lubricants

If a different brand or grade of oil has to be added, drain all old oil before adding new brand or grade of oil.

Never mix different brands or grades of oil.

Locking Inspection Covers

Lock inspection cover securely into position with lock bar. If inspection or maintenance is performed with inspection cover not locked in position, it could fall and cause injury.

Hydraulic System - Air Bleeding

When hydraulic equipment has been repaired or replaced, or hydraulic piping has been removed and installed again, air must be bled from circuit. For details, see "Venting and Priming Hydraulic System" on page 4-97.

Hydraulic Hose Installation

• When removing part at locations with O-rings or gasket seals, clean mounting surface and replace with new parts.

When doing this, be careful not to forget to assemble O-rings and gaskets.

• When installing hoses, do not twist them or bend them sharply. This will extend service life and prevent damaging hoses.

Checks After Inspection and Maintenance Works

Perform checks after inspection and maintenance to prevent operation problems. Always do the following:

- Checks after operation (with engine stopped).
 - Have any inspection and maintenance points been forgotten?
 - Have all inspection and maintenance items been performed correctly?
 - Have any tools or parts been dropped inside the machine? If parts are dropped inside the machine and get caught in lever linkage mechanism, and this could cause improper operation of the machine.
 - Are there any coolant or oil leaks? Have all nuts and bolts been tightened?
- Checks when operating engine.
 - For details of checks when operating engine, see "Safety Precautions" on page 4-4 and pay careful attention to safety.
 - Are inspection and maintenance items working properly?
 - Is there any leakage of fuel or oil when engine speed is raised?

Coolant, Oil, Fuel - Drain and Change

The engine must be turned off when draining, replacing, or adding fluid to the machine.

Change Wiper Blade and Front Cabin Light

When changing wiper blade or front cabin light, tilt a cabin and then replace with new one.

See "Tilt Cabin" on page 2-104 for cabin tilting.



Figure 91

Safety Precautions

- 1. Make sure to lock out hydraulic controls and place a "DO NOT OPERATE" Warning Tag on the machine to indicate that the machine is being serviced and to prevent any unauthorized operation.
- 2. Clean up any fluid spills, especially around engine.
- 3. Inspect all fuel lines to make sure that fittings, lines, filters, O-rings, etc. are tight and are not showing signs of leakage, wear or damage.
- 4. If inspection or test procedure requires that engine be running, make sure to keep all unauthorized personnel away from the machine.

MACHINE SETUP POSITION FOR MAINTENANCE

Before beginning any service work, park the machine using the following procedure (except for service work requiring the machine to be positioned differently).

1. Position the machine on even, firm and level ground.

Move safety lever to "LOCK" position.

2. Put attachment on ground.

3.



Figure 1

EX1300554



Figure 2



Figure 3

4. Allow engine to run at "LOW IDLE" for a minimum of five minutes to allow engine to cool, If this is not done, heat surge can occur.

5. Stop engine by turning key to "O" (OFF) position. After releasing hydraulic system and tank pressure, remove starter switch key.



Figure 4

6. Before starting maintenance work, place a "DO NOT OPERATE" Warning Tag on cabin door or work lever.



AVOID DEATH OR SERIOUS INJURY

If engine must be running while performing maintenance, use extreme care. Always have one person in cabin at all times. Never leave cabin with engine running.



Figure 5

MAINTENANCE HANDLING ACCESS

Entering/Leaving/Climbing On Machine

AVOID DEATH OR SERIOUS INJURY

Do not jump ON/OFF a machine. Never get ON/OFF when the machine is running.

Never grasp control lever to get ON/OFF.

Use handholds and steps when entering, leaving or climbing the machine.

Use three-point grip, i.e. two hands and one foot or two feet and one hand.

Always face machine.

Always wipe mud and oil off all footboards, handrails, guardrails and your footwear, especially when cleaning windows, rearview mirrors and lights.

Clean your boots and wipe your hands before getting on the machine. Always wear proper footgear.

Do not use hand grip (A, Figure 6) of cabin door as a support when entering, leaving or climbing the machine. It is not strong enough to be used as a support. It should only be used for closing the door.



Figure 6

FG021268









HANDLING OIL, FUEL, DEF (ADBLUE), COOLANT

Oil

- Oil is used in the engine and hydraulic equipment under extremely severe conditions (high temperature, high-pressure, etc.) and deteriorates with use. Always use oil that matches the grade and maximum and minimum ambient temperatures recommended in this manual. Even if oil is not dirty, always change oil at specified interval.
- Always be careful when handling oil to prevent any impurities (water, metal particles, dirt, etc.) from getting in.
- Operating problems with the machine can be caused by impurities in oils.
- Take particular care not to let any impurities get in when storing or adding oil.
- Never mix oils of different grades or brands.
- Always add specified amount of oil.
- Having too much or too little oil can cause operational problems.
- If oil in work equipment is not clear, there may be water or air getting into circuit. In such cases, contact your HYUNDAI distributor.
- When changing oil, always replace related filters at same time.

Fuel

To ensure good fuel consumption characteristics and exhaust gas characteristics, the engine mounted on this machine uses an electronically controlled high-pressure fuel injection device. This device uses high precision parts and lubrication. If low viscosity fuel with reduced lubricating ability is used, the durability of the fuel injection device could be affected.

- To prevent moisture in air from condensing and forming water inside fuel tank, always fill fuel tank after completing day's work.
- The fuel pump is a precision instrument and if fuel containing water or dirt is used, it cannot work properly.
- Be careful not to let impurities get in when storing or adding fuel.
- Always use fuel specified for temperature given in this manual.

- If fuel is used at temperatures lower than specified temperature (particularly at temperatures below -15°C (5°F), the fuel will gel-up and solidify.
- If fuel is used at temperatures higher than specified temperature, the viscosity will drop, and this can cause performance problems.
- Before starting engine, or when 10 minutes have passed after adding fuel, drain sediment and water from fuel tank.
- If engine runs out of fuel, or if filters have been replaced, it is necessary to bleed air from circuit.
- If there is any foreign material in fuel tank, wash tank and fuel system.



Ultra Low Sulfur Diesel (ULSD) fuel 0.0015 percent (S \leq 15 ppm (mg/kg)) sulfur is required by regulation for use in engines certified to nonroad Tier 4 standards (U.S. EPA Tier 4 certified) and that are equipped with exhaust aftertreatment systems.

European ULSD 0.0010 percent (\leq 10 ppm (mg/kg)) sulfur fuel is required by regulation for use in engines certified to European Nonroad Stage IIIB and newer standards and are equipped with exhaust aftertreatment systems.

Using fuels of higher sulfur level can have the following negative effects:

- Shorten the time interval between aftertreatment device service intervals (cause the need for more frequent service intervals)
- Adversely impact the performance and life of aftertreatment devices (cause loss of performance)
- Reduce regeneration intervals of aftertreatment devices
- Reduce engine efficient and durability
- Increase the wear.
- Increase the corrosion.
- Increase the deposits.
- Lower fuel economy.
- Shorten the time period between Oil drain intervals (more frequent oil drain intervals)
- Increase overall operating costs.

Failures that result from use of improper fuels are not HYUNDAI factory defects. Therefore the cost of repairs would not be covered by a HYUNDAI warranty.

DEF (AdBlue)

- Use the AdBlue indicated at DIN 70070.
- DEF (AdBlue) is a harmless, colorless and odorless liquid.
- The freezing point of DEF is -11°C (12.2°F). Because the volume of DEF (AdBlue) may expand about 9% when it is frozen, it's recommended to leave 10% of the total volume of the tank empty after filling.
- DEF (AdBlue) may have a foul odor if the temperatures of the DEF (AdBlue) is high.
- HYUNDAI recommends that temperature of the DEF (AdBlue) is between 4°C (39°F) to 60°C (140°F).
- If the temperature rises above 60°C (140°F), the DEF (AdBlue) concentration might be high because of the evaporation.
- In the worst case, the circulation line of DEF (AdBlue) might be clogged by the DEF (AdBlue) crystallization.

Non-permitted Container Materials for Storing DEF (AdBlue)

Materials forming compounds because of reaction with ammonia, which may negatively interfere with the SCR system: carbon steels, zinc coated carbon steels, mild iron

Non ferrous metals and alloys (copper, copper alloys, zinc, lead)

Solders containing lead, silver, zinc or copper

Aluminium, aluminium alloys

Magnesium, magnesium alloys

Plastics or metals coated with nickel

Allowable DEF (AdBlue) Storage Days							
Constant Ambient Storage Temperature °C (°F)	Minimum Shelf Life (months)						
10 (50)	36						
25 (77)	18						
30 (86)	12						
35 (95)	6						

Engine Oil

HYUNDAI engine oils have been developed and tested to provide the full performance and life that has been designed and built into HYUNDAI engines.

HYUNDAI engine oils that meet API CJ-4 are required for use in the applications listed below.

HYUNDAI engine oils meeting the API CJ-4 and ACEA E9 oil categories have been developed with limited sulfated ash, phosphorus, and sulfur.

These chemical limits are designed to maintain the expected aftertreatment device list, performance, and service interval.

If oils meeting the API CJ-4 specifications are not available, oils meeting ACEA E9 may be used.

ACEA E9 oils meet the chemical limits designed to maintain aftertreatment device life.

Failure to meet the listed requirements will damage aftertreatment-equipped engines and can negatively impact the performance of the aftertreatment devices.

The cost of repairs caused by improper engine oils will not be covered by the HYUNDAI warranty for your machine.

Other systems may apply.

Therefore the cost of repairs would not be covered by a HYUNDAI warranty.

Grease

- Grease is used to prevent seizure and noises at joints.
- This construction equipment is used under heavy-duty conditions. Always use recommended grease and follow change intervals and recommended ambient temperatures given in this manual.
- Always wipe off all old grease that is pushed out when greasing.

Wipe off old grease where sand or dirt sticking in the grease can cause wear of rotating parts.



Figure 9

Coolant and Water for Dilution

System" on page 4-85.

- The coolant has the important function of preventing corrosion and preventing freezing.
 Even in areas where freezing is not an issue, use of antifreeze coolant is essential.
 HYUNDAI machines are supplied with HYUNDAI coolant. HYUNDAI coolant has excellent anticorrosion, antifreeze and cooling properties and can be used continuously for 1 year or 2,000 hours. Therefore, it is recommended to use authorized genuine HYUNDAI antifreeze solution.
 When using HYUNDAI coolant, there is no need to use a corrosion resistor. For details, see "Engine Cooling
- When diluting antifreeze coolant, use distilled water. Natural water, such as a river water or well water (hard water), contains large amounts of minerals (calcium, magnesium, etc.), and this makes it easier for scale to form inside engine or radiator. Once scale is deposited inside engine or radiator, it is extremely difficult to remove. If tap water needs to be used, refer to "Engine Cooling System" on page 4-85 for further information on standards and precautions.
- When using antifreeze, always observe precautions given in this manual.
- Antifreeze coolant is flammable, so be sure to keep it away from any flame.
- The ratio of HYUNDAI coolant to water differs according to ambient temperature.
 For details of ratio when mixing, see "Antifreeze Concentration Tables" on page 4-87.
 HYUNDAI coolant may be supplied premixed. Never add distilled water.
- If engine overheats, wait for engine to cool before adding coolant.
- If coolant level is low, it will cause overheating and corrosion problems because of air entering coolant.
- Never mix lime (hard water), salt or water contained metal material with coolant.
- If a HYUNDAI pure antifreeze is not available, the antifreeze specification provided on the "Type of antifreeze" page must be used.

Filters

• Filters are extremely important safety parts. They prevent impurities in hydraulic oil, fuel and air circuits from causing problems.

Replace all filters periodically. See details given in "Lubrication and Service Chart" on page 4-18.

When working in severe conditions, replace filters at shorter intervals according to oil and fuel (sulfur content) being used.

- Never try to clean filter (cartridge type) and use them again. Always replace with new filters.
- When replacing oil filters, check if any metal particles are attached to oil filter. If any metal particles are found, contact your HYUNDAI distributor.
- Do not open packages of spare filters until just before they are to be used.
- Always use HYUNDAI genuine filters.

ELECTRICAL SYSTEM MAINTENANCE

- If electrical equipment becomes wet or covering of wiring is damaged, this will cause an electrical short circuit and result in improper machine operation. Do not wash inside of operator's cabin with water. When washing the machine, be careful not to let water get into electrical components.
- Service relating to the electrical system is: checking fan belt tension, checking damage or wear to the fan belt, and checking battery electrolyte level.
- Never install any electric components other than those specified by HYUNDAI.
- External electromagnetic interference can cause malfunction of the control system controller. Before installing a radio receiver or other wireless equipment, contact your HYUNDAI distributor to prevent electromagnetic interference.
- When working in saltwater areas or in or around snow, carefully clean the electrical system to prevent corrosion.
- When installing electrical equipment, connect it to the special power source connector. See "15. Power Socket for 12 Volt" on page 2-18.

Do not connect the optional power source to a fuse, starter switch, or battery relay.

RECOMMEND FUEL, COOLANT, AND LUBRICANT

- Lubrication is an important part of preventive maintenance. To keep your machine in the best condition for long periods of time, it is essential to follow the instructions given in this manual.
- Failure to follow these recommendations can result in shortened life or excess wear of the engine, power train, cooling system, and/or other components.
- Commercially available lubricant may be good for the machine, but it can also cause harm. HYUNDAI does not recommend any commercially available lubricant additive.
- When starting the engine in temperatures below 0°C (32°F), be sure to use recommended multigrade oil, even if the ambient temperature may become higher during the course of the day.
- If the machine is operated at temperatures below -20°C (-4°F), a separate device is needed, so discuss with HYUNDAI distributor.
- Only use Ultra Low Sulfur Diesel (ULSD) fuel and API CJ-4/ACEA E9 grade engine oil.

Lubrication

Lubrication is an important part of preventive maintenance. If the machine is lubricated in a specified way, the life of equipment and components can be considerably extended. The "Lubrication and Service Chart" on page 4-18 makes lubrication work much easier and reduces the risk of forgetting lubrication intervals.



Wipe off grease fittings and grease gun before greasing to prevent sand and dirt particles from penetrating into components.

Symbols for "Lubrication and Service Chart"

The lubrication and service chart is on the inside of the battery box cover. The symbols used in the lubrication and service chart are illustrated in the following table.

Symbol	Description
~ ~ 7	Lubrication
\bigcirc	Gear Oil (Swing Device, Travel Device)
6	Engine Oil
<u></u>	Engine Oil Filter
6	Hydraulic Oil
<u>[]</u>	Hydraulic Oil Filter
[제	Hydraulic Oil Tank Breather
	Coolant
	Air Cleaner Filter

Symbol	Description
Ē	Fuel Filter
	Water Separator
-	Air Conditioner Filter
L ^û	Drain Water
	Fuel Cap Filter
Ŵ	DEF (AdBlue)
	DEF (AdBlue) Filter
\triangleright	Level Check

Lubrication and Service Chart



SERVICE DATA										
Na		Oomice	0	Service Interval (hr)						
NO.	Items to Check	Service	Qty.	10	50	250	500	1000	2000	4500
1	Front Joint Pin	Grease	14	F100	W10					
2	Swing Bearing	Grease	2		W10					
3	Engine Oil	Engine Oil (10W40)	27 L	V						
4	Water Separator and Pre Fuel Filter (Fuel Prefilter)	Cartridge	1	D, V						
5	Track Spring	Grease	2				W10			
6	Pinion Gear (Swing)	Grease	1							
7	Engine Oil Filter	Cartridge	1							
8	Main Fuel Filter	Cartridge	1							
9	Swing Reduction Gear	Gear Oil (80W90)	5 L	V			F			
10	Hydraulic Oil Return Filter	Element	1			F				
11	Pilot Filter	Element	1			F				
12	Travel Reduction Gear	Gear Oil (80W90)	2 x 6 L				F, V			
10	Air Conditioner Filter (Outer)	Element	1				С			
13	Air Conditioner Filter (Inner)	Element	1				С			
14	Swing Reduction Gear	Grease	1					W10		
15	Air Breather Filter*	Element	1							
16	Fuel Cap Filter	Element	1							
17	Hydraulic Oil Tank**	Hydraulic Oil	131 L	V						
18	Radiator	Coolant (Antifreeze)	38.4 L	V						
10	Air Cleaner (Outer)	Element	1				С			
19	Air Cleaner (Inner)	Element	1							
20	DEF (AdBlue) Filter	Element	1							
21	Fuel Tank	Diesel	1,000 L	V	D					
22	DEF (AdBlue) Tank	DEF	31.5 L	V						
23	Hydraulic Oil Suction Strainer	Strainer	1						С	
	Radiator Core	Core	1				С			
	Oil Cooler Core	Core	1				С			
	Intercooler Core	Core	1				С			
	Aircon Condenser Core	Core	1				С			
V: Mair	ntenance and Refill. / C : Cleani	ng. / D : Drain V	Nater. / F:	First T	ime Ex	change	Only.			
F100: I	Every 10 Hours For First 100 H	lours. / W10 : E	very 10 H	ours If (Operati	ng In W	/ater.			
Beplacement On Every Interval										
NOTE: For additional service items see list of "Maintenance Intervals" on page 4-24										
*: Whe	n the machine is operated und	er dustv work	sites, the	air brea	ther filt	er neer	ds to be	cleane	ed or re	placed
on a	regular basis even before the	expected repla	cement da	ate.						
used	e replacement intervals of hydr	be followed as	opposed	a upon to regu	amoun larly sc	t of tim	e nydra d maint	aulic bre enance	eaker is	being

FLUID CAPACITIES

C	Component	Capacity				
Engine	Oil Pan with Filter	27 L (7.1 U.S. gal.)				
Engine	Cooling System	38.4 L (10.1 U.S. gal.)				
Fuel Tank		1,000 L (264 U.S. gal.)				
DEF (AdBlue) Tank		31.5 L (8.3 U.S. gal.)				
	Tank Level	131 L (34.6 U.S. gal.)				
Hydraulic Oli	System	280 L (73.9 U.S. gal.)				
Travel Reduction Gear (Each)		6 L (1.6 U.S. gal.)				
Swing Reduction Ge	ar	5 L (1.3 U.S. gal.)				

NOTE: If the level is between lower limit line and upper limit line of the gauge, the level is correct. If the level is low, open the cover on the tank and add hydraulic oil.

TABLE OF RECOMMENDED LUBRICANTS



It is highly recommend to use HYUNDAI Genuine Products or products which meet the following specifications. Using other products can damage the equipment.

NOTE:	Refer	to	the	"Lubrication	and	Service	Chart"	on
	page 4	4-18	8 for I	locations.				

		Ambient Temperature																		
Reservoir	Kind of Fluid	-58	-4	0 -2	22	-4	1	4	32	50	68	86	104	122 °F						
		-50	-4	0-3	30	-20	-1	0	0	10	20	30	40	50 °C						
			SAE 10W-30																	
					Г			6		/_30										
								3		-30										
		SAE 0W-30																		
Engine Oil																				
Pan	⁵⁾ Engine Oil		ļ			-		SA	E 0W-4	40										
					Г				²⁾ SA	E 5W-4	0									
											<u> </u>									
									³⁾ SA	AE 10W	-40									
										⁴⁾ SAE 1	15W-40)								
Swing Drive										SAE 90) and A	PI GL5	5							
Case																				
	Gear Oil						l						¹⁾ SAE 80W-90 and API GL5							
Final Drive																				
Case											SAE 14	0 and /	API GL	5						
			IS	O VG.	15															
								ISC		32	_									
Hydraulic Oil	⁶⁾ Hvdraulic Oil							.00												
Tank	,								IS	O VG. 4	16		1							
													-							
											ISO V	'G. 68								

								1)	ASTM C) 975 No	b. 2]	
Fuel Tank	Diesel Fuel				ASTM D	975 No. 1								
							1 51 50		<u> </u>					
						וט	N 5150	2 КР-11	K-30 / r		D. I			
Grease	Grease						ום	N 5150	2 KP-2	K-10/N	II GI No	2	1	
Fitting	Greater													
							DI	N 5150	2 KP-3	K-10/N	ILGI No	. 3	1	
					•		Add An	tifreeze						
Coolina		(NIc	¹⁾ (50% antifreeze - 50% distilled water)											
System	Coolant		(Note that mixing ratio is for reference purpose only, and is not an absolute standard.)											
		Ma	ke sure	to use	genuine ot availa	e antitre able, see	eze. It g e the "T	vpe of	antifree Antifree	eze is ze" pac	ie.			
¹⁾ Installed a	at factory.					,		,		1.0	,			
²⁾ (5W40) -	Recommended	for ι	use at e	xtreme	ly low te	emperat	ure bel	ow -20°	C.					
³⁾ (10W40)	- Filled at factor	y. H`	YUNDA	l genui	ne engi	ne oil is	recom	nendec	for use	э.				
⁴⁾ (15W40)	- HYUNDAI gen	uine	e engine	e oil is r	ecomm	ended f	or use.							
5) (Engine o	oil) - Engine oil m	nust	meet A	PI CJ-4	1/ACEA	E9.								
⁶⁾ Hydraulic is used, g	oil change inter juaranteed chan	val i ge i	is 4,000 nterval) hours, is 2,000	only wi) hours.	hen HY Note th	JNDAI at oil gr	Genuin ade is f	e Oil is or refer	used. If ence pu	ⁱ other b urpose c	rands c only, an	of oi d is	
not an ab	solute standard.													
API: American Petroleum Institute.														
ACEA: Associa	ation des Constr	ructe	eurs Eu	ropens	d'Auton	nobiles.								
ASTM: Americ	an Society of Te	estin	g and N	<i>l</i> aterial	s.									
ISO: International Organization for Standardization.														
NLGI: National Lubricating Grease Institute.														
SAE: Society of	SAE: Society of Automotive Engineers.													
Deutsche	Industrie Norme	en												

Do not mix oils from different manufacturers. HYUNDAI does not endorse specific brands but recommends that owners select quality oils whose manufacturers provide assurance that required standards will always be met or exceeded.



Fluctuating daily or weekly extremes of temperature, or operation in subzero freezing temperatures, may make it impractical to use straight weight lubricants. Select lubricants that are appropriate for climate conditions.



We recommend using genuine HYUNDAI products for the grease applied to this equipment.

In areas where the use of genuine products is restricted, greases of at least the following specifications should be used.

- DIN 51502 Specification
 - Extreme Cold Area : KP-1K-30 / NLGI No. 1
 - Normal Area : KP-2K-10 / NLGI No. 2
 - Extreme Heat Area : KP-3K-10 / NLGI No. 3

• EP (Extreme Pressure) Specification

- Normal : 250 kgf or more
- Front Pin-Bush : 315 kgf or more

MAINTENANCE INTERVALS

SERVICE ITEM	PAGE						
10 Hour / Daily Service							
Grease Boom, Arm and Front Attachment Pins (for First 100 Hours)	4-26						
Check Engine Oil Level	4-26						
Check for Leaks in Hydraulic System	4-27						
Check Level of Hydraulic Oil Tank	4-28						
Check for Leaks in Fuel System	4-28						
Check Fuel Level	4-29						
Check DEF (AdBlue) Tank	4-30						
Check Water Separator and Pre Fuel Filter (Fuel Prefilter) and Drain Water As Required	4-31						
Check Oil Level of Swing Reduction Gear	4-32						
Clean Dust Net in Front of Oil Cooler and Radiator	4-33						
Check Cooling System and Refill As Required	4-34						
Check Level of Window Washer Liquid	4-34						
Inspect Cooling Fan Blade	4-35						
Check Air Intake System and Emission Control System Components	4-35						
Inspect Seat Belt for Proper Operation	4-36						
Inspect Rear View Camera for Proper Operation (If Equipped)	4-36						
Inspect Mirrors for Damage and Adjust and Clean as Required	4-36						
Inspect Structure for Cracks and Faulty Welds	4-36						
Check Operation of All Switches and Travel Alarm (If Equipped)	4-36						
Check the Operation of Pilot Cutoff Switch	4-37						
Check Operation of All Exterior Lights, Horn and Control Console Indicator and Display Monitor	4-38						
Start Engine, Check Starting Ability, and Observe Exhaust Color at Start-up and at Normal Operating Temperature. Listen for Any Abnormal Sounds.	4-38						
Check Operation of All Controls and Linkages	4-38						
50 Hour / Weekly Service							
Perform All Daily Service Checks	4-39						
Grease Arm and Heel Joint Pins	4-39						
Grease Swing Bearing	4-43						
Drain Water and Sediment from Fuel Tank	4-43						
Check Engine Fan Belt for Cracks, Wear and Correct Tension (After First 50 Hours)	4-43						
Inspect the Track Assemblies for Proper Tension and Loose, Worn or Damaged Parts (Links, Shoes, Rollers, Idlers)	4-43						
250 Hour / Monthly Service							
Perform All Daily and 50 Hour Service Checks	4-44						
Check Engine Fan and Alternator Belt Tension	4-44						
Replace Hydraulic Oil Return Filter (After First 250 Hours)	4-45						
Change Pilot Filter (After First 250 Hours)	4-45						
Inspect Pins and Bushings of the Front End Attachments for Signs of Wear	4-45						
Check Fluid Levels in Batteries	4-45						
Inspect for Any Loose or Missing Nuts and Bolts	4-45						
Inspect Fuel System Hose Clamps	4-45						

SERVICE ITEM	PAGE					
500 Hour / 3 Month Service						
Perform All Daily, 50 and 250 Hour Service Checks	4-46					
Grease Swing Gear and Pinion	4-46					
Change Engine Oil and Filter	4-47					
Clean Air-conditioning Outer Filter	4-48					
Check and Clean Air-conditioning Inner Filter	4-49					
Clean Radiator, Oil Cooler, Intercooler, Fuel Cooler and Air Conditioner Condenser Cores	4-51					
Clean Outer Filter of Air Cleaner	4-52					
Change of Water Separator and Pre Fuel Filter (Fuel Prefilter)	4-54					
Change Main Fuel Filter	4-55					
Check Oil Level in Travel Reduction Gear (One on Each Side of Unit)	4-56					
Change Oil in Travel Reduction Gear (One on Each Side of Unit) (After First 500 Hours)	4-56					
Change Oil in Swing Reduction Gear (Drain and Refill After First 500 Hours)	4-56					
1,000 Hour / 6 Month Service						
Perform All Daily, 50, 250 and 500 Hour Service Checks	4-57					
Grease Swing Reduction Gear	4-57					
Change Hydraulic Oil Tank Breather Filter	4-57					
Change Pilot Filter	4-59					
Change Oil in Travel Reduction Gear (One on Each Side of Unit)	4-60					
Change Oil in Swing Reduction Gear	4-61					
Change Air-conditioning Outer Filter	4-62					
Change Air-conditioning Inner Filter	4-64					
Check Air Conditioner Refrigerant	4-65					
Change Fuel Cap Filter	4-66					
Check and Adjust Engine**	4-67					
2,000 Hour / Yearly Service						
Perform All Daily, 50, 250, 500 and 1,000 Hour Service Checks	4-68					
Replace Outer and Inner Air Cleaner Filters	4-68					
Change Radiator Coolant	4-70					
Hydraulic Oil Exchange and Suction Strainer Cleaning	4-71					
Check Alternator and Starter**	4-73					
Check All Rubber Antivibration Shock Mounts	4-73					
Perform and Record Results of Cycle Time Tests	4-73					
Inspect Machine to Check for Cracked or Broken Welds or other Structural Damage	4-73					
Check, Adjust Valve Clearance**	4-73					
Check Head Bolt Torques	4-73					
4,000 Hour / Biennial Service	4 7 4					
Major Parts - Periodic Replacement	4-74					
4,500 Hour / Biennial Service	4 75					
Change DEF (AdBlue) Fliter	4-75					
12,000 Hour / 6 Year Service	4 70					
Hose In-service Litetime Limit (European Standard ISO 8331 and EN982 (CEN))	4-78					

** These checks need to be completed by an authorized HYUNDAI distributor.

10 HOUR / DAILY SERVICE

Grease Boom, Arm and Front Attachment Pins (for First 100 Hours)

Grease every 10 hours for first 100 hours and every 50 hours thereafter (See page 4-39).

NOTE: If the unit has been running or working in water, the front attachment must be greased on a 10 hour/daily basis.

Check Engine Oil Level



AVOID DEATH OR SERIOUS INJURY

Allow engine to cool before checking oil level to avoid burn injury.

- **NOTE:** When checking level, use a dipstick and always remove and wipe it clean before making final level check.
- 1. Stop engine and wait for fifteen minutes. This will allow all oil to drain back to oil pan.
- 2. Remove dipstick (1, Figure 11) and wipe the oil off with a clean cloth.
- 3. Insert dipstick fully in oil gauge tube, then take it out again.
- 4. Engine oil level must be between "HIGH" and "LOW" marks on dipstick.

NOTE: If oil is above "HIGH" mark on dipstick, oil must be drained to return oil to proper level.

5. Add oil through engine oil fill cap (2, Figure 11), if the oil level is below the "LOW" mark.



Figure 11





FG000616

Check for Leaks in Hydraulic System

1. Perform a daily walk-around inspection to make sure that hoses, piping, fittings, cylinders and hydraulic motors are not showing any signs of leakage. If any is noted, determine the source of the leak and repair.



AVOID DEATH OR SERIOUS INJURY

The hydraulic oil will be hot after machine operation. Allow system to cool before attempting to service any hydraulic components.

The hydraulic tank is pressurized. Tip breather cap up slowly to allow the pressurized air to vent. After the pressure has been released, remove service covers.

- 1. Park machine on firm and level ground. Lower boom and position work tool on ground as shown in Figure 14.
- 2. Move engine speed to "LOW IDLE".



Figure 13





EX1300555

ARO1760L

- 3. Move safety lever to "LOCK" position.
- 4. Have a second person, check hydraulic oil level gauge by opening right access door. Oil level must be between marks on sight gauge.



FG020182



- 5. If the level is below "L" mark add oil.
 - A. Stop engine.
 - B. The hydraulic tank is pressurized. Tip breather cap up slowly to allow the pressurized air to vent.
 - C. Remove upper cover of the hydraulic tank and add oil.



Do not fill above "H" mark on sight gauge. Overfilling can result in damage to equipment and oil leaking from hydraulic tank because of expansion.



FG020183



When refilling the oil, use the same hydraulic oil as the system is filled with.

- 6. If oil level is above the "H" mark drain oil.
 - A. Stop engine and wait for the hydraulic oil to cool down.
 - B. Drain the excess oil from drain plug (Figure 17) at the bottom of the tank into an approved container, using a hose at the point (plug).



Dispose of waste oil/liquids in compliance with all applicable environmental laws and regulations.

Disconnect the drain hose and install the protecting cap.

Check for Leaks in Fuel System

1. Perform an inspection of engine compartment to verify that fuel system is not leaking. If any is noted, determine source of leak and repair.



Figure 17

EX1505182



AVOID DEATH OR SERIOUS INJURY

Use extreme safety precautions while refueling to prevent explosions or fire.

Immediately clean up any spilled fuel.



AVOID DEATH OR SERIOUS INJURY

Stop engine when refueling.

Turn engine coolant heater "OFF" before filling fuel, to prevent a fire or explosion.

- At end of each workday, fill fuel tank. Add fuel through fuel fill tube (1, Figure 18). When working at a temperature of 0°C (32°F) or higher, use ASTM No. 2-D or its equivalent. At temperatures below 0°C (32°F) use ASTM No. 1-D or its equivalent.
- 2. Make sure that fuel fill hose is grounded to the forestry machine before fueling begins.



Figure 18

3. Check the amount of fuel in the tank by fuel gauge of gauge panel.

NOTE: See "Fluid Capacities" on page 4-20 for capacity.

4. The forestry machine may be equipped with the optional battery operated fuel fill pump. The pump assembly is in the hydraulic pump compartment. Put the suction hose of the pump into the fuel resupply tank. Turn the switch in the pump compartment "ON", and the fuel will be pumped into the forestry machine fuel tank.

NOTE: See "Fuel Transfer Pump (Optional)" on **F** page 4-89, for further information.

5. Do not overfill the tank.



- 6. Securely tighten cap after fueling.
 - **NOTE:** If breather holes (3, Figure 20) in cap are clogged, a vacuum may form inside the tank preventing proper fuel flow to engine. Keep holes in fuel cap clean.
 - **NOTE:** Be careful not to damage the fuel level gauge on the fuel tank by allowing it to becoming stained from thinner or oil.



Figure 20

Check DEF (AdBlue) Tank

1. At end of each workday, fill DEF (AdBlue) tank. Add the DEF (AdBlue) through DEF (AdBlue) fill cap (1, Figure 21).



Do not let impurities get in when storing or adding DEF (AdBlue).

If impurities get in the tank, drain the whole DEF (AdBlue) through the drain hole (2, Figure 22).

2. Securely tighten cap after filling.





Check Water Separator and Pre Fuel Filter (Fuel Prefilter) and Drain Water As Required

- **NOTE:** If water in fuel warning symbol (Figure 23) on display monitor comes "ON", drain the collected water in fuel prefilter.
- **NOTE:** If operator leave the machine with no measure for 30 minutes after the water in fuel warning light up, the engine power will be derated.





- 1. A fuel prefilter is inside the left rear side access door.
- 2. Open the access door on left rear side of the machine.



4. Position a small container under fuel prefilter. Drain water or sediment by opening drain valve (2, Figure 25) on bottom of bowl (1).

NOTE: Dispose of drained fluids in compliance with all applicable environmental regulations.

5. Close drain valve.



open

close

FG000438





AVOID DEATH OR SERIOUS INJURY

The gear oil is very hot after the machine has been operating. Shut all systems down and allow them to cool. Before fully removing any motor case inspection, port plug, etc., loosen the plug slightly to allow pressurized air to escape.

- **NOTE:** When checking level, use a dipstick and always remove and wipe it clean before making final level check.
- 1. Remove dipstick (1, Figure 26) and wipe the oil from the dipstick with a cloth.
- 2. Insert dipstick (1, Figure 26) fully into dipstick tube.
- 3. When dipstick is pulled out, oil level must be between "HIGH" and "LOW" marks on dipstick.

NOTE: If oil is above "HIGH" mark on dipstick, some must be drained to proper level.

4. If the oil does not reach the "L" mark on the dipstick, add oil through fill port (2, Figure 26).



NOTE: Dispose of drained fluids in compliance with all applicable environmental laws and regulations.











Clean Dust Net in Front of Oil Cooler and Radiator



If running machine in dusty area, check dust net everyday and clean it if dirty.



AVOID DEATH OR SERIOUS INJURY

If using compressed air or water to clean the dust net, wear safety goggles for proper eye protection.

- Open rear left door and engine cover. 1.
- 2. Loosen wing bolt(s) and remove dust net.
- 3. Clean with compressed air or water.



Check Cooling System and Refill As Required



AVOID DEATH OR SERIOUS INJURY

Allow the engine to cool before releasing the radiator cap. Loosen the cap slowly to release any remaining pressure.

Radiator cleaning is performed while the engine is running. Lock out and tag the controls alerting personnel that service work is being performed. Do not remove radiator cap unless it is required. Check the coolant level in the coolant recovery tank.

- **NOTE:** Do not mix ethylene glycol and propylene glycol antifreeze together. See "Engine Cooling System" and "Types of Antifreeze" page for further details.
- 1. When the engine is cold, remove radiator cap and check the coolant level inside the radiator. Do not rely on the level of coolant in the coolant recovery tank. Refill radiator as required. Refer to coolant concentration table. (See page 4-87)
- 2. Check to make sure that coolant transfer line from the coolant recovery tank to the radiator is free and clear of obstructions, or is not pinched.
- 3. Check the level of coolant in the coolant recovery tank. The normal cold engine fluid level must be between "FULL" and "LOW" marks on tank.
- 4. If the coolant is below the "LOW" mark, add genuine part of 50% concentration coolant to the tank.

Check Level of Window Washer Liquid

- 1. Open left front access door and check fluid level in windshield washer tank.
- 2. Open fill cap and add fluid.
 - **NOTE:** Use a washer liquid that is rated for all seasons. This will prevent freezing during cold weather operation.



FG020184




AVOID DEATH OR SERIOUS INJURY

Death or serious injury can result from a fan blade failure. Never pull or pry on the fan. This can damage the fan blade(s) and cause fan failure.

NOTE: Manually rotate the crankshaft by using a wrench on the accessory drive pulley nut.

1. An inspection of the cooling fan is required daily. Check for cracks, loose bolts, bent or loose blades, and for contact between the blade tips and the fan shroud. Check the fan to make sure it is securely mounted. Tighten the bolts if necessary. Replace any fan that is damaged.

Check Air Intake System and Emission Control System Components



AVOID DEATH OR SERIOUS INJURY

Hot engine components can cause burns.

Avoid contact with hot engine components

- 1. Park the machine on a firm and level surface, lower the attachment to the ground, move safety lever to "LOCK" position, and stop engine.
- 2. Check the engine intake hose and hose bands for damage and tightness.
- 3. Check the exhaust pipe and several exhaust system components, and check the V-clamp tightness to prevent leaking gases.
- 4. If damaged, wrinkled, or loose, replace or retighten or contact your nearest HYUNDAI distributor.



Severe engine damage will result from running with unfiltered air.

Do not operate engine if any leaks or damage are found on air intake system.



FG021814





Figure 33

HAOA050L

Inspect Seat Belt for Proper Operation

See "Seat Belt" on page 1-36 for further information.

Inspect Rear View Camera for Proper Operation (If Equipped)



AVOID DEATH OR SERIOUS INJURY

When accessing the rear view camera, use an external ladder or platform to prevent slipping and falling. The counterweight and engine hood should not be used as a maintenance platform.

Inspect Mirrors for Damage and Adjust and Clean as Required

Inspect Structure for Cracks and Faulty Welds

1. During the daily walk-around inspection and when greasing the machine, look for any visible damage to the machine. Repair or replace any damaged parts before operating the machine.

Check Operation of All Switches and Travel Alarm (If Equipped)

1. Verify the working condition of all switches before starting the engine.

Check the Operation of Pilot Cutoff Switch

A pilot cutoff switch has a pivoting safety lever that deactivates the work group, swing and travel control functions.

When the safety lever is moved down into "LOCK" position, the work group, swing and travel control functions are deactivated.

When the safety lever is moved up into "UNLOCK" position, the work group, swing and travel control functions can be operated.



Unlock EX1300566 Figure 34

AVOID DEATH OR SERIOUS INJURY

The PILOT CUTOFF SWITCH (safety lever) must deactivate the work group, swing and travel control functions when the safety lever is moved <u>down</u> into "LOCK" position.

Contact your HYUNDAI distributor immediately if the controls do not deactivate. DO NOT MODIFY THE SYSTEM.

Inspection and Maintenance of the Pilot Cutoff Switch

- 1. Check for and keep bystanders away from the work area. Sit in operator's seat and fasten seat belt.
- 2. Start engine and move safety lever up into "UNLOCK" position.
- 3. Operate the work group (joystick) levers in all directions to check that boom, arm, work tool and swing functions operate correctly. Also, check that travel controls operate properly.

NOTE: Hydraulic system must be warmed up to operating temperatures.

- 4. Raise the boom and arm so the work tool is about 1 m (3 ft.) off the ground.
- 5. Move the safety lever down into "LOCK" position to deactivate the work group and travel functions. Move the work group (joystick) levers. There must be no movement of the boom, arm, and attachment or swing functions when the controls are moved.
- 6. With the safety lever still in the "LOCK" position, move the travel controls. There must be no movement of the machine tracks.
- 7. Move safety lever up into "UNLOCK" position. Raise the boom so the work tool is about 3 m (10 ft.) off the ground. Operate the work group (joystick) lever to lower the boom slowly. <u>While boom is lowering</u>, move the safety lever down into "LOCK" position. Boom movement must stop. Repeat these steps for arm, work tool, swing and travel functions.
- 8. Lower work group to the ground and stop engine.

NOTE: If the PILOT CUTOFF SWITCH (safety lever) does not deactivate the work group and travel functions as described above or if any parts are damaged, bent or missing, contact your HYUNDAI distributor immediately for service. DO NOT MODIFY THE SYSTEM.

Check Operation of All Exterior Lights, Horn and Control Console Indicator and Display Monitor

- 1. Turn engine starter switch to "I" (ON) position and observe all the indicator lights.
- 2. Restore operation of any light bulbs that do not turn "ON" now.
- 3. Sound the horn. Repair or replace if required.
- 4. Turn "ON" and inspect all exterior work lights. Replace any monitors, burned-out bulbs or cracked or broken housings or lenses.

Start Engine, Check Starting Ability, and Observe Exhaust Color at Start-up and at Normal Operating Temperature. Listen for Any Abnormal Sounds.

Check Operation of All Controls and Linkages



Cold weather operation requires that operator fully warm up the hydraulic oil before beginning machine operation. Follow all warm up instructions listed in the Operating Instruction section of this manual. Make sure to cycle oil through all the components, including all cylinders, both travel motors and the swing motor. Cold hydraulic oil in the lines and components needs to be warmed before beginning full operation. If this is not done, damage to the cylinders or hydraulic motors can occur.

- 1. With the engine at rated speed, operate all the controls.
- 2. Follow cold weather hydraulic system warm-up procedures.
- 3. Note any slow operations or unusual movements. Determine the cause and repair before operating.

50 HOUR / WEEKLY SERVICE

Perform All Daily Service Checks

Grease Arm and Heel Joint Pins

Grease every 10 hours for first 100 hours and every 50 hours thereafter.

- **NOTE:** If the unit has been running or working in water, the front attachment must be greased on a 10 hour/daily basis.
- Position machine on firm and level ground as shown below and lower the front attachment to the ground and stop engine.
- Press the grease fitting and inject grease with the grease gun on the marked point.
- After greasing, clean off the old grease that has been purged.



Figure 35

Reference Number	Description	
A	Boom Foot Pins (3 Points)	
В	Arm Pins (4 Points)	
С	Heel Cylinders (2 Points)	

Reference Number	Description	
D	Arm Cylinders (2 Points)	
E	Boom Cylinders (4 Points)	

- A. Boom Foot Pins (3 Points)
- B. Arm Pins (4 Points)
 - Boom To Arm (2 Points)



• Arm To Heel Rack (2 Points)

- C. Heel Cylinders (2 Points)
 - Rod (1 Point)

• Head (1 Point)



D. Arm Cylinders (2 Points)

• Rod (1 Point)

Head (1 Point)



EX1501289





Figure 41





Figure 43

- E. Boom Cylinders (4 Points)
 - Rod (2 Points)

• Head (2 Points)

Grease Swing Bearing

- 1. Park machine on firm and level ground. Lower the front attachment to the ground and stop engine.
- There are two grease fittings for the swing bearing. Do not over lubricate. Purge old grease with new. Remove all purged grease.



Drain Water and Sediment from Fuel Tank

- 1. Perform this procedure before operating the machine.
- 2. Drain water and sediment from bottom of fuel tank into an approved container.
 - **NOTE:** Dispose of drained fluids in compliance with all applicable environmental laws and regulations.
 - **NOTE:** Always completely fill fuel tank at end of each workday to prevent condensation from forming on the inside walls of the tank.



Check Engine Fan Belt for Cracks, Wear and Correct Tension (After First 50 Hours)

1. Inspect after first 50 hours of operation and every 1,000 hours thereafter.

Inspect the Track Assemblies for Proper Tension and Loose, Worn or Damaged Parts (Links, Shoes, Rollers, Idlers)

- Do a daily walk-around inspection of all components including the track assemblies. Look for missing, damaged or excessively worn parts. See "Track Tension (IF EQUIPPED TYPE 1)" on page 4-93
- 2. Jack up each track and perform the two speed travel motor test.

250 HOUR / MONTHLY SERVICE

Perform All Daily and 50 Hour Service Checks

Check Engine Fan and Alternator Belt Tension



A loose fan belt can cause engine overheating, poor charging, and/or premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing, or belt.



- 1. Inspect every 250 hours. (Inspect after first 50 hours of operation.)
- 2. With the engine shut off, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex. To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.



Fi	gι	ır	e ·	47
	J -			

	Model Belt Tension (N)		How to Measure (Alternator Belt)	
Model			Depressible Distance (5 kgf)	Α
DL06P	New	800 ±50 N (82 ±5 kgf)	2.4 mm	62 - 64 mm
	Used	600 ±50 N (61 ±5 kgf)	3.7 mm	58 - 60 mm

Replace Hydraulic Oil Return Filter (After First 250 Hours)

NOTE: Replace hydraulic oil return filter after first 250 hours of operation or rebuild, then every 1,000 hours thereafter (See page 4-58).

Change Pilot Filter (After First 250 Hours)

NOTE: Change pilot filter after first 250 hours and every 1,000 hours thereafter (See page 4-59).

Inspect Pins and Bushings of the Front End Attachments for Signs of Wear

Check Fluid Levels in Batteries

See "Inspection of Battery Electrolyte Level" on page 4-81 for further information.

Inspect for Any Loose or Missing Nuts and Bolts

Inspect Fuel System Hose Clamps

500 HOUR / 3 MONTH SERVICE

Perform All Daily, 50 and 250 Hour Service Checks

Grease Swing Gear and Pinion



AVOID DEATH OR SERIOUS INJURY

Greasing swing gear and pinion must be done by only one person.

- 1. Remove inspection cover on the main frame and inspect the condition of the grease. Inspect for water or other contaminants on the gear teeth.
 - **NOTE:** The upper structure must be rotated a little at a time so the entire face of the swing gear can be lubricated. Use extreme caution when performing this operation.



Figure 48

- 2. If water or other contaminations are found, remove lower access cover bottom of the track frame so the gear teeth can be thoroughly cleaned and lubricated.
- 3. Install access covers after lubricating gear teeth.



Figure 49



AVOID DEATH OR SERIOUS INJURY

DO NOT change oil on a hot engine. Allow the engine to cool down before attempting to change the engine oil and filter to avoid burns by touching hot engine parts.

- Position a larger container under the engine. Remove cap (1, Figure 50) and install hose (2) to drain the engine oil. Remove hose (2) and install cap (1).
 - **NOTE:** Dispose of drained fluids in compliance with all applicable environmental laws and regulations.





Dispose of filters/oils/liquids in compliance with all applicable environmental laws and regulations.

- 2. Replace engine oil filter by using filter wrench. The engine oil filter is a spin-on type. See Figure 51. Remove and discard filter.
- 3. Install new filter. Apply a small amount of oil around filter gasket. Screw filter on head until gasket contacts head, turn filter 1/2 turn more.



NOTE: See "Fluid Capacities" on page 4-20 for capacity.

- 5. Start engine. Run engine for five minutes at "LOW IDLE" and check engine oil pressure light.
- 6. Stop engine. Look for signs of leaks at filter. Recheck oil level after fifteen minutes.







Clean Air-conditioning Outer Filter

The machine is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into operator's cabin. This filter must be cleaned out.

NOTE: If the unit is being operated in a dusty environment, the cleaning and replacement must be performed more frequently. If filter is damaged, replace damaged filter with a new one.



AVOID DEATH OR SERIOUS INJURY

All service and inspection of air-conditioning system must be performed with the starter switch in the "O" (OFF) position.



AVOID DEATH OR SERIOUS INJURY

If using compressed air to clean the element, make sure that proper eye protection is worn.

- NOTE: All right and left call outs are based on the operator being seated in the operator's seat facing the front.
- Open the cover by using the starter KEY in the left side of 1. the cabin.







Figure 54 Oregon Cabin

- 2. Remove filter (Figure 55) and inspect for any damage.
- 3. Use compressed air to clean filter. If filter is still dirty, then replace filter.
- 4. Reassemble in reverse order.









Figure 56 Oregon Cabin

Check and Clean Air-conditioning Inner Filter



AVOID DEATH OR SERIOUS INJURY

All service and inspection of air-conditioning system must be performed with the starter switch in the "O" (OFF) position.



AVOID DEATH OR SERIOUS INJURY

If using compressed air to clean the element, make sure that proper eye protection is worn.

- Inspection, Maintenance and Adjustment
 - 4-50

1. Remove cover by pulling knob (Figure 57) outward on top of the left and right of the filter which is inside the left rear part of the cabin-STD cabin.

Loosen the bolts (Figure 58) and remove cover-Oregon

Cabin.

- 2. Remove inner filter by pulling knob outward while pressing the upperpart and lower part of the filter handle.
- 3. Use compressed air to clean filter. If the filter is damaged, replace with a new one.

If the filter is very dirty, use a mild soap or detergent and water to clean it.



NOTICE







DS1601478

Figure 59

Clean Radiator, Oil Cooler, Intercooler, Fuel Cooler and Air Conditioner Condenser Cores



AVOID DEATH OR SERIOUS INJURY

Using compressed air, steam or water to clean can cause serious injury. Always wear safety goggles, mask and safety shoes during the cleaning precess. Keep personnel and bystanders clear of work area.

- 1. Open the rear left door and engine cover and loosen the bolt(s) on the upper cover of oil cooler.
- 2. Loosen the wing bolt(s) and remove dust net from in front of oil cooler and radiator.





Figure 61

3. Clean the outside of the radiator and oil cooler, intercooler and fuel cooler with compressed air, steam or water. Wash from the outside of the engine compartment towards the inside. Repeat the cleaning process from the inside of the engine compartment towards the outside to remove all dirt and debris.

NOTE: Clean dust net and install it after cleaning radiator, oil cooler, intercooler and fuel cooler.

4. Clean air conditioner condenser core with compressed air, steam or water.



To prevent damage to the cores, apply compressed air from an appropriate distance. Damaged cores can cause leakage or overheating. In dusty conditions, check the cores daily.



Clean Outer Filter of Air Cleaner

- **NOTE:** Clean outer filter every 500 hours/3 months of service.
- **NOTE:** If air cleaner clogged warning symbol (Figure 63) on display monitor comes "ON", the air cleaner must be serviced.
- **NOTE:** When working in very dusty conditions, the service interval must be shortened.



AVOID DEATH OR SERIOUS INJURY

Never clean or attempt to remove air cleaner filter if the engine is running.

If using compressed air to clean the filter, make sure that proper eye protection is worn.

- 1. Locate the air cleaner assembly.
 - **NOTE:** When it reaches every 500 hours or If indicator symbol (Figure 63) on display monitor comes "ON" the air cleaner must be serviced.
 - **NOTE:** Replace outer filter after cleaning 5 times or every 2,000 hours/1 year of service.
- 2. Remove and clean rubber evacuator valve (1, Figure 64) from bottom of air cleaner housing cover (2). Inspect seal lips for wear or damage. Replace valve if necessary.
 - **NOTE:** Install evacuator valve with lips parallel to the cover.
- 3. Remove access cover (2, Figure 65) by loosening the latches (3).
- 4. Remove outer filter (4, Figure 65) from the housing. Do not remove inner filter (5).











Figure 65

- 6. Check outer filter by shinning a light through it. If small holes or thinner parts are found on the element after cleaning it, replace the filter.

Clean the outer filter (4, Figure 65) by blowing compressed air from the inside of the filter towards the outside. Do not

use more than 205 kPa (30 psi) air pressure.

- 7. Clean the inside of the air cleaner body and the inside of the air cleaner cover. Do not use compressed air.
- 8. Properly install the air filter and cover.

5.



Figure 66



FG000412

HAOC570L



- 9. Install cover (2, Figure 68) as follows.
 - A. Align cover with the element.
 - B. Hook the tip of latches (3, Figure 68) to the protruding part of the air cleaner body and lock it in position.
 - C. When locking latches (3, Figure 68) in position, attach them in turn on opposite sides (top, bottom, left, right) in the same way as when tightening bolts.
 - D. Always install cover (2, Figure 68) so evacuator (1) is facing the ground (A).

NOTE: Make sure that lips of evacuator are parallel to cover.

- E. When cover (2, Figure 68) is installed, check that cover (2) is properly seated in air cleaner body. If it is seated, install again.
- **NOTE:** If after cleaning the outer filter, the air cleaner clogged indicator remains "ON", replace the outer and inner filters. Do not clean inner filter.



Change of Water Separator and Pre Fuel Filter (Fuel Prefilter)

- 1. Open the access door on left rear side of the machine (1, Figure 69).
- 2. Close fuel drain valve (2, Figure 69).

Remove bowl using supplied tool.

Remove cartridge.

4.

5.

- 3. Position a small container under prefilter. Drain fuel by opening drain valve on bottom of filter.
 - NOTE: Dispose of drained fluids in compliance with all applicable environmental laws and regulations.







Figure 70

- Coat surface of packing (2, Figure 71) with fuel on new 6. cartridge (1).
- Tighten cartridge by hand until packing comes into contact 7. with surface of filter housing head.
- When packing contacts surface, tighten the cartridge about 8. 3/4 of a turn more.
- 9. Coat surface of seal (3, Figure 71) with fuel, and tighten the bowl with tool.







AVOID DEATH OR SERIOUS INJURY

Change filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke.

- 1. Locate fuel filter inside engine compartment.
- 2. Position a small container under fuel filter.
- 3. Unscrew fuel filter from head assembly. Discard fuel filter.

NOTE: Dispose of drained fluids in compliance with all applicable environmental regulations.

- 4. After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench.
 - **NOTE:** Coat fuel filter gasket with fuel.
 - **NOTE:** Fill fuel filter with clean fuel. This will help reduce fuel system priming.





FG000478



Fuel System Priming

If air remains in the fuel inlet line to the engine, it can cause the engine to run in an abnormal condition. Air may impact the starting capability of the engine, and may also result in surging engine speeds.

If the machine happens to have run out of fuel, or if the fuel filter has been replaced, bleed the air out using the following procedure:

- 1. Stop engine.
- 2. Check that fuel valve is open.
- 3. Open fuel drain valve.
- 4. Loosen plug (1, Figure 74) on the fuel prefilter head.
- 5. Pump the hand-operated primer pump (2, Figure 74) on the fuel prefilter. Pump primer until fuel is present at plug hole in fuel prefilter head.
- 6. Tighten plug (1, Figure 74) in fuel prefilter head.

NOTE: Plug tightening torque: 6.5 N.m (0.66 kg.m, 4.8 ft lb)

- 7. Continue to pump primer pump until a strong resistance is felt.
- 8. Start engine and look for signs of leaks.
- 9. Repeat procedure if necessary.



Figure 74

EX1401866

Check Oil Level in Travel Reduction Gear (One on Each Side of Unit)



AVOID DEATH OR SERIOUS INJURY

The gear oil is very hot after the machine has been operating. Shut all systems down and allow them to cool.

Before removing the motor case, loosen the plug slightly to allow pressurized air to escape. Residual pressure in the travel reduction gear can cause the plug to be dislodged and oil to squirt out suddenly.

Reference Number	Description	
1	Oil Level Plug	
2	Drain Plug	
3	Fill Plug	

- 1. Make sure that the machine is on firm and level ground.
- 2. Rotate the track until ports (1 thru 3, Figure 75) are in their proper positions as shown.
- 3. Loosen fill plug (3, Figure 75) slightly to allow pressurized air to escape.
- 4. Remove oil level plug (1, Figure 75).
- 5. Check oil level. The oil must be near the bottom of the level plug opening.
- 6. Add oil through the fill plug (3, Figure 75) opening, if necessary.
- 7. Clean and install oil level and fill plugs (1 and 3, Figure 75).
- 8. Repeat this procedure on the other travel reduction gear.

Change Oil in Travel Reduction Gear (One on Each Side of Unit) (After First 500 Hours)

NOTE: Drain and refill oil after first 500 hours of operation or rebuild, and every 1,000 hours thereafter (See page 4-60).

Change Oil in Swing Reduction Gear (Drain and Refill After First 500 Hours)

NOTE: Change swing reduction gear oil after first 500 hours on a new machine and every 1,000 hours thereafter (See page 4-61).





1,000 HOUR / 6 MONTH SERVICE

Perform All Daily, 50, 250 and 500 Hour Service Checks

Grease Swing Reduction Gear

- 1. Park machine on firm and level ground. Lower the front attachment to the ground and stop engine.
- 2. Remove air vent plug (1, Figure 76) from swing reduction gear.



Figure 76

- 3. Press grease fitting and inject grease with the grease gun on the marked point (2, Figure 77).
- 4. Install air vent plug (1, Figure 76) in swing reduction gear.



Figure 77

Change Hydraulic Oil Tank Breather Filter

- 1. Park machine on firm and level ground. Lower the front attachment to the ground and stop engine.
- 2. Tip breather cap up (2. Figure 78) slightly to release the internal pressure.
- 3. Unscrew the bolt (1, Figure 78) and take off the breather cap (2).
- 4. Change a filter cartridge (3, Figure 78) and assemble the breather cap by tightening the bolt.
 - **NOTE:** The used filter should always be disposed of according to local regulations.
 - **NOTE:** When the machine is operated under dusty work sites, the air breather filter needs to be cleaned or replaced regularly even before the expected replacement date.



Replace Hydraulic Oil Return Filter

- NOTE: Change hydraulic oil return filter after first 250 hours of operation or rebuild, and every 1,000 hours thereafter.
- NOTE: If return filter clogged warning symbol (Figure 79) on display monitor comes "ON" the return filter must be serviced.



Figure 79



AVOID DEATH OR SERIOUS INJURY

The hydraulic oil will be hot after machine operation. Allow the system to cool before attempting to service any of the hydraulic components.

The hydraulic tank is pressurized. Tip the hydraulic breather cap up slightly to allow the pressurized air to vent. After the pressure has been released, remove service covers or drain water from tank.



Figure 80



Make sure to clean any dirt or water from the top of the hydraulic tank, especially around the fill port and filter ports.

- 1. Park machine on firm and level ground. Lower the front attachment to the ground and stop engine.
- 2. Tip breather cap up (1, Figure 80) slightly to release the internal pressure.
- 3. Remove bolts (2, Figure 80) and service cover (3). Remove O-ring (4), spring (5), valve (6) and bypass strainer (7), and then filter (8).
- 4. Remove filter and discard.

NOTE: Used filter should always be disposed of according to local laws and regulations.

- Install new filter and a new O-ring. Install bypass strainer, 5. valve and spring. Install service cover plate.
- Run engine for ten minutes at "LOW IDLE" to purge air 6. from circuit.
- Check level in hydraulic oil tank (See page 4-27). Add oil if 7. necessary.





Change Pilot Filter

NOTE: Change pilot filter after first 250 hours of operation or rebuild, and every 1,000 hours thereafter.





A WARNING

AVOID DEATH OR SERIOUS INJURY

The hydraulic oil will be hot after machine operation.

Allow the system to cool down before changing pilot filter.

- 1. Park machine on firm and level ground. Lower the front attachment to the ground and stop engine.
- 2. Tip breather cap up (1, Figure 80) slightly to release the internal pressure.
- 3. Locate pilot system filter assembly.
- 4. Unscrew canister (2, Figure 83) and remove O-ring (3) and filter cartridge (4).

NOTE: The canister will be filled with oil. Use caution when removing this assembly.

- 5. Insert a new filter cartridge and O-ring. Apply a small amount of oil around the entire O-ring and install the canister assembly onto the filter head (1, Figure 83).
 - **NOTE:** Used filter should always be disposed of according to local laws and regulations.
- 6. After changing pilot filter, vent air from pump and check level of hydraulic oil tank.

1 0 3 0 4 0 2 DS1703795

Figure 83

Change Oil in Travel Reduction Gear (One on Each Side of Unit)



AVOID DEATH OR SERIOUS INJURY

The gear oil is very hot after the machine has been operating. Shut all systems down and allow them to cool.

Before removing the motor case, loosen the plug slightly to allow pressurized air to escape. Residual pressure in the travel reduction gear can cause the plug to be dislodged and oil to squirt out suddenly.

Reference Number	Description	
1	Oil Level Plug	
2	Drain Plug	
3	Fill Plug	

NOTE: Change oil after first 500 hours of operation or rebuild, and every 1,000 hours thereafter.

- 1. Make sure that the machine is on firm and level ground.
- 2. Rotate the track until ports (1 thru 3, Figure 84) are in their proper positions as shown.
- 3. Place a container under drain plug (2, Figure 84) and remove plugs (1 thru 3) to drain the travel reduction gear oil.

4. Install drain plug (2, Figure 84). Refill the travel reduction gear case with fluid through fill port (3) until fluid level is at port (1). Install level plug (1) and fill plug (3).

NOTE: See "Fluid Capacities" on page 4-20 for capacity.

5. Repeat this procedure on the other travel reduction gear.



NOTE: Dispose of drained fluids in compliance with all applicable environmental laws and regulations.

Change Oil in Swing Reduction Gear

NOTE: Change swing reduction gear oil after first 500 hours of operation or rebuild, and every 1,000 hours thereafter.



AVOID DEATH OR SERIOUS INJURY

The gear oil is very hot after the machine has been operating. Shut all systems down and allow them to cool.

- 1. Park machine on firm and level ground. Lower attachment to the ground and stop engine.
- 2. Release the drain plug (3, Figure 86) and drain the swing reduction gear oil into a container.

NOTE: Dispose of drained fluids in compliance with all applicable environmental regulations.

3. After draining oil, tighten the drain plug.







2









Change Air-conditioning Outer Filter

The unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into operator's cabin. This filter must be cleaned.

NOTE: In the unit is being operated in a dusty environment, the cleaning and replacement must be performed more frequently. If filter is damaged, replace damaged filter with a new one.



AVOID DEATH OR SERIOUS INJURY

All service and inspection of air-conditioning system must be performed with the starter switch in the "O" (OFF) position.

- **NOTE:** All right and left call outs are based on the operator being seated in the operator's seat facing the front.
- 1. Open the cover by using the starter KEY in the left side of the cabin.



EX1300825







- 2. Remove filter (Figure 90) and replace with new one.
- 3. Reassemble in reverse order.











Inspection, Maintenance and Adjustment 4-63



AVOID DEATH OR SERIOUS INJURY

All service and inspection of air-conditioning system must be performed with the starter switch in the "O" (OFF) position.

1. Remove cover by pulling knob (Figure 92) outward on top of the left and right of the filter which is inside the left rear part of the cabin-STD Cabin.

Loosen the bolts (Figure 93) and remove cover-Oregon



Figure 92 STD Cabin

Figure 93 Oregon Cabin

DS1601478

- 2. Remove inner filter by pulling knob outward while pressing the upperpart and lower part of the filter handle.
- 3. Replace with new one.

Cabin.

4. Reassemble filter in reverse order.



Check Air Conditioner Refrigerant



AVOID DEATH OR SERIOUS INJURY

Do not smoke while servicing or recharging airconditioning system.

Contact with refrigerant can result in frost bite. Wear Protective glasses and gloves when refrigerant lines are opened.

See a HYUNDAI distributor for servicing or recharging the air conditioner refrigerant.

- 1. Run engine at about 1,800 rpm. Operate for a minimum of ten minutes to stabilize the system.
- 2. Press the "HI" fan speed switch to set maximum airflow.
- 3. Put the temperature control switch in maximum cooling position.
- 4. Press the "Internal Air Circulation" switch.
- 5. Compare the flow of bubbles in the sight glass of receiver dryer with the drawings in the following table.



Overfilling refrigerant can cause dangerous high-pressure and poor cooling action. Low refrigerant level can cause compressor damage.

Always maintain refrigerant at normal level.

Amount of Refrigerant	Appearance of the Sight Glass	Solutions	
Normal	$ \begin{array}{c} \overbrace{\begin{smallmatrix} 1 & 0 \\ 1 & 0 \\ 1 & 0 \\ 1 & 0 \end{array} } \\ \begin{array}{c} \text{Almost clear.} \\ \text{All bubbles disappear.} \end{array} $		
High	No bubbles are seen.	Charge or withdraw the system with the correct amount of HFC-134a refrigerant.	
Low	$ (\bigcirc \circ \circ \circ \circ \circ \circ) \\ \circ \circ$		



Figure 95

Change Fuel Cap Filter

Remove screws and filter assembly from fuel cap (Figure 97).

2. After disassembly, carefully lay it as shown in Figure 98.

3. After disassembly (Figure 98), remove rubber piece as shown on (Figure 99).





Figure 97



FG015685

FG015686

Figure 98







External shock or damage to fuel cap can cause permanent damage to filter.



4. After disassembly as shown in (Figure 99), replace filter (Figure 100) with a new one.



Figure 100

5. After installing new filter, assemble fill cap in reverse order.



FG015687

Figure 101

Check and Adjust Engine**

Contact your HYUNDAI distributor for checking and adjusting the following items:

- Engine Compression Pressure.
- Injection Pressure.
- Injection Timing.

**These checks need to be completed by an authorized HYUNDAI distributor.

2,000 HOUR / YEARLY SERVICE

Perform All Daily, 50, 250, 500 and 1,000 **Hour Service Checks**

Replace Outer and Inner Air Cleaner Filters



AVOID DEATH OR SERIOUS INJURY

Never clean or attempt to remove air cleaner filter if the engine is running.

- NOTE: Replace outer element after cleaning 5 times or every 2,000 hours of service.
- NOTE: Replace inner element whenever a new outer element is installed.
- 1. Open the side door of the machine, remove 6 latches (3, Figure 103), then remove cover.
- 2. Remove evacuator valve (1, Figure 103) from the air cleaner cover (2).
 - NOTE: Inspect evacuator valve seal lips for wear or damage. Replace valve if necessary. Install evacuator valve with lips parallel to the cover.
- 3. Hold the outer element (4, Figure 104), rock it lightly up and downward, and swing the element to pull it out. Remove inner element (5) after doing this.
- 4. Wipe off the dirt stuck to the air cleaner cover and the inside of the air cleaner housing.
 - NOTE: When replacing the outer element, replace the inner element simultaneously. Do not reuse the inner element.
 - If the inner element is not installed properly and NOTE: the outer element and cover are installed, the outer element will be damaged.







- 5. Remove inner element (5, Figure 104), then install a new inner element. Insert the inner element properly so it does not move.
- 6. Push the new outer element (5, Figure 104) in straight to the air cleaner body.



Be sure to install the air cleaner filters facing in the correct direction. If the direction of installation is incorrect, this will damage the air cleaner filters or the engine.

- 7. Replace O-ring (6) of cover (2) with a new part.
 - **NOTE:** When inserting the element, if the rubber at the end is wedged or the outer element is not pushed in straight, and cover is assembled by force of hook afterward, the hook and air cleaner body can be damaged.



Figure 104



Figure 105

- 8. Install cover (2, Figure 107) as described bellow.
 - A. Align cover with the element.
 - B. Hook the tip of latches (3, Figure 107) to the protruding part of the air cleaner body and lock it in position.
 - C. When locking latches (3, Figure 107) in position, apply the hooks in turn on opposite sides (top, bottom, left, right) in the same way as when tightening bolts.
 - D. Always install cover (2, Figure 107) so evacuator (1) is facing the ground (A).
 - E. When cover (2, Figure 107) is installed, check that clearance between the air cleaner body and cover (2) is not too large. If it is too large, remove cover and install again.







Change Radiator Coolant

NOTE: Do not mix ethylene glycol and propylene glycol antifreeze together. Refer to "Engine Cooling System" and "Types of Antifreeze" page for further details.



AVOID DEATH OR SERIOUS INJURY

Allow the engine to cool before releasing the radiator cap. Make sure to loosen the cap slowly to release any remaining pressure.

Radiator cleaning is performed while the engine is running. Take extreme caution when working on or near a running engine. Make sure to lock out and tag the controls notifying personnel that service work is being performed.

Do not remove radiator cap unless it is required. Check the coolant level in the coolant recovery tank.



Do not mix up the antifreeze from different makers. Mixing the two compounds can cause generation of foreign material which can damage the system. Therefore, it is recommended to use authorized HYUNDAI genuine antifreeze solution.

To achieve the best cooling performance, keep the mixing ratio of the antifreeze and water by 50 : 50. Using water only can corrode the coolant circuit.

In bitterly cold working conditions, the customer should frequently check the performance of the coolant for appropriateness for the weather and then determine change cycle of the coolant.

- 1. Slowly open the radiator cap and the surge tank cap (Figure 108) to allow any pressure to escape.
 - **NOTE:** See "Fluid Capacities" on page 4-20 for capacity.
 - **NOTE:** Some models may have no surge tank or radiator cap. This instruction is only applicable to those with the cap.


2. Place a container under the radiator and open the drain plug (Figure 109).

NOTE: Dispose of drained fluids according to local applicable environmental laws and regulations.

3. Fill cooling system with a flushing solution.

NOTE: The speed of filling must be within 5 LPM to prevent overflow.

- 4. Run engine at low idle until coolant temperature gauge reaches the "WHITE ZONE". Run engine for another ten minutes.
- 5. Allow engine to cool.
- 6. Drain flushing fluid and fill system with water.
- 7. Run engine again to allow water to completely circulate.
- 8. After allowing engine to cool, drain water and fill system with proper antifreeze mixture for ambient temperature. Refer to coolant concentration table. See "Antifreeze Concentration Tables" on page 4-87
- 9. Run engine without radiator cap and surge tank cap installed, so all air will be purged from system. Fill radiator to fill neck.
- 10. Drain and fill radiator coolant recovery tank.

Hydraulic Oil Exchange and Suction Strainer Cleaning



AVOID DEATH OR SERIOUS INJURY

The hydraulic oil will be hot after machine operation. Allow the system to cool before attempting to service any of the hydraulic components.

The hydraulic tank is pressurized. Tip breather cap up to allow the pressurized air to vent. After the pressure has been released, remove service covers.



Make sure to clean any dirt or water from the top of the hydraulic tank, especially around the fill port and filter ports.

Hydraulic oil change interval is 2,000 hours only when HYUNDAI Genuine Oil is used. If another brand of oil is used, a change interval of 1,000 hours is necessary.







Figure 110

ARO1760L

- NOTE: Based on the type of forestry machine being completed, the working conditions (extremely hot or dusty) and the extra front end attachments being used, the hydraulic fluid will need to be changed more frequently.
- 1. Park machine on firm and level ground. Swing upper structure parallel to tracks. Lower boom and position work tool on ground as shown in Figure 111.
- 2. Move safety lever to "LOCK" position.
- 3. Stop engine.
- 4. Release pressurized air from hydraulic tank by tip breather cap up (1, Figure 114).



Figure 111



5. Drain hydraulic oil from tank into a container capable of holding 195 L (51.5 U.S. gal.). After draining tank, install drain plug.



AVOID DEATH OR SERIOUS INJURY

Be careful of squirting oil when removing drain plug.

- NOTE: Used filter and used oil should always be disposed of according to local laws and regulations.
- 6. Carefully remove bolts and cover (2, Figure 114) from top of hydraulic oil tank. There is a spring (3, Figure 114) under the cover that will force the cover up.
- Remove spring (3, Figure 114) and suction filter (5, Figure 7. 114), by pulling on rod (4, Figure 114).
- 8. Clean inside and outside of suction filter. Replace suction filter if it is broken.
- Position suction filter (5, Figure 114) on boss portion of 9. suction pipe (6, Figure 114).

NOTE: Measurement "A" is 650 mm (25.6 in).





EX1505182

Figure 112

Figure 113





EX1401894



- 10. Fill the hydraulic oil tank. Check level using sight gauge on side of tank.
- 11. Place spring (3, Figure 114) on rod (4, Figure 114) and assemble cover (2, Figure 114).
- 12. After replacing and cleaning the hydraulic oil, filter, and strainer, vent the system. See "Venting and Priming Hydraulic System" on page 4-97
- 13. Check level of hydraulic oil tank. (See page 4-27)



Figure 114

Check Alternator and Starter**

Check All Rubber Antivibration Shock Mounts

Perform and Record Results of Cycle Time Tests

Inspect Machine to Check for Cracked or Broken Welds or other Structural Damage

Check, Adjust Valve Clearance**

Check Head Bolt Torques

**These checks need to be completed by an authorized HYUNDAI distributor.

4,000 HOUR / BIENNIAL SERVICE

Major Parts - Periodic Replacement

For proper operation and work, perform periodic inspections. These parts are those most often subjected to abrasion, heat and fatigue. Replace these parts with new ones at the designated time intervals, even if the old parts look satisfactory.

Replace all related parts such as gaskets and O-rings with original equipment manufacturer's parts.

Major Component		Parts Name to be Replaced Periodically	Time to Replace
Engine		Fuel hose (Tank to fuel prefilter)	
		Fuel hose (Fuel prefilter to fuel cooler)	
		Fuel hose (Fuel cooler to ECU)	
		Fuel hose (Tank to CP pump)	
		Heater hose (Heater to engine)	
		Heater hose (Heater to radiator)	
		Air Conditioner hose	
Hydraulic	Body	Pump Suction Hose	2 years or 4,000 hours
System		Pump Discharge Hoses	
		Pump Side Branch Hoses	
		Swing Motor Hoses	
		Travel Motor Hoses	
	Work	Boom Cylinder Line Hoses	
	Device	Arm Cylinder Line Hoses	
		Heel Cylinder Line Hoses	

4,500 HOUR / BIENNIAL SERVICE

Change DEF (AdBlue) Filter



The replacement interval of the DEF (urea solution) filter is different by the amount of foreign materials in DEF.

Make sure to use only the specified DEF and container and keep the surrounding area of the tank clean to prevent possible foreign materials.

1. Remove filter cover.

2.







Figure 116



Figure 117

Inspection, Maintenance and Adjustment 4-75

Remove equalizing element.

3. Check the color (gray/green) in the filter.

4. Set the color of the mark on the end of the filter removing tool in the same direction with the filter color section.

5. Insert the end of the filter removing tool until a clicking sound is heard or engagement with the filter is felt.

6. Pull the filter removing tool to remove filter.

7. The surface must be kept clean. It can be cleaned with water only.





Figure 118



EX1401881



Figure 120



EX1401873

8. Apply oil to the O-ring and install a new filter.



AVOID INJURY Use Mobil Velocite No. 6 oil from Bosch.



EX1401882



9. Install a new equalizing element.





10. Tighten the filter cover to 20 N.m + 5 N.m.



AVOID INJURY

Check that filter surface is clean. It can be cleaned with water only.



EX1401884

Figure 124

12,000 HOUR / 6 YEAR SERVICE

Hose In-service Lifetime Limit (European Standard ISO 8331 and EN982 (CEN))

European regulations state that in-service life of any hydraulic hose may not exceed six years. HYUNDAI recommends the following:

- Hoses at the customer premises cannot be stored more than 2 years before being discarded or installed on a machine.
- In-service lifetime of hoses fitted on a machine can never exceed 6 years, but replace hoses described in "Major Parts - Periodic Replacement" on page 4-74, every 2 years. Always replace hoses having exceeded the allowed in-service lifetime irrespective of the external appearance/ wear.
- Always store hoses in a dark place at a maximum of 65% relative humidity, between 0°C (32°F) and 35°C (95°F) but as close as possible to 15°C (59°F) and away from copper, manganese or tube generating Ozone.

AIR-CONDITIONING SYSTEM

NOTE: See "Clean Air-conditioning Outer Filter" on page 4-48

Check Control Panel

When a function switch is pushed, the last setting has to be displayed on the LCD display.

When the light switch is turned to "I" position, the LED for illumination in the control panel has to turn "ON".

Check Air Conditioner Hoses

Check the hose for cracking and damage. Replace if necessary.

Check Condenser

Inspect the condenser for dust and debris. Clean if necessary.

NOTE: See "Clean Radiator, Oil Cooler, Intercooler, Fuel Cooler and Air Conditioner Condenser Cores" on page 4-51

Check Magnetic Clutch

Check the magnetic clutch for dirt and interference.

Push the "A/C" switch to energize and check magnetic clutch.

Check Belt Tension

NOTE: See "Check Engine Fan and Alternator Belt Tension" on page 4-44

ELECTRICAL SYSTEM

NOTE: Never disassemble electrical or electronic parts. Consult a HYUNDAI distributor before servicing.

Battery



AVOID DEATH OR SERIOUS INJURY

Battery electrolyte contains sulfuric acid and can quickly burn the skin and eat holes in clothing. If you spill acid on yourself, immediately flush the area with water.

Battery acid could cause blindness if splashed into the eyes. If acid gets into the eyes, flush them immediately with large quantities of water and seek professional medical attention immediately.

If you accidentally ingest acid, call a doctor or poison prevention center immediately.

When working with batteries, always wear safety goggles.

Battery generates hydrogen gas, so there is a danger of an explosion. Do not smoke near batteries, or do anything that will cause sparks.

Before working with batteries, stop engine and turn the starter switch to "O" (OFF) position.

Avoid short-circuiting the battery terminals through accidental contact with metallic objects, such as tools.

When removing or installing, check which is the positive (+) terminal and negative (-) terminal.

When removing the battery, first disconnect the negative (-) terminal. When installing the battery, first connect the positive (+) terminal.

If the terminals are loose, there is a danger that defective contact may generate sparks that will cause an explosion. When installing the terminals, install them tightly.

Batteries in Cold Weather

Battery performance decreases as the temperature gets lower.

In extremely cold weather, remove batteries at night and move them to a warm location. This will help to keep them at a higher energy level.

Inspection of Battery Electrolyte Level

This machine has two maintenance free batteries. They never require the addition to water.

When the charge indicator becomes transparent, this indicates a low electrolyte state because of a leakage or charging system error. Determine the cause of problem and replace the batteries immediately.





Check Charging State

Check charging state through the charging indicator.

- GREEN: Sufficiently charged.
- BLACK: Insufficient charged.
- TRANSPARENT: Replace battery.

Check Battery Terminals

Be certain that battery is held securely in its compartment. Clean the battery terminals and the battery cable connectors. A solution of baking soda and water will neutralize acid on the battery surface, terminals, and cable connectors. Petroleum jelly or grease can be applied to the connectors to help prevent corrosion.



Figure 126

Battery Replacement

When the charging indicator shows a transparent condition, replace the battery. The batteries should always be replaced in pairs.

Using an old battery with a new one will shorten the life span of the new battery.

Fuses

- 1. The fuses in the fuse box are used to protect the various electrical circuits and their components from being damaged. See Figure 127. The fuses used are standard automotive type fuses.
- 2. The section on "Fuse Identification" on page 4-83 lists the circuits and the fuse amperage required for each circuit. If a fuse blows, determine the cause and repair any electrical faults or failures.
- 3. Do not insert a higher amperage fuse into a lower amperage slot. Serious damage to the electrical components or fire can result.



Before replacing a fuse, be sure to turn starter switch to "O" (OFF) position.

Fuse Boxes

There are two fuse boxes (Figure 128) on the left side of the heater box. The fuses prevent electrical devices from overloading or shorting.

A decal attached inside the fuse box's cover indicates the function and amperage of each fuse.

Spare fuses are mounted on the inside of fuse box's cover. (One each of a 10A, 15A, 20A and 30A.)

Change a fuse if the element separates. If the element of a new fuse separates, check the circuit and repair the circuit.



AVOID DEATH OR SERIOUS INJURY

Always replace fuses with the same type and capacity fuse that was removed. Otherwise, electrical damage or fire could result.





HAOC670L



Figure 128

Figure 127



Fuse Box (2)



FG000542

Figure 129

STD Cabin

No	Fuse Box One			
NO.	Name	Capacity		
1	Cigarette Lighter	10A		
2	Spare	10A		
3	EGR	20A		
4	Window Washer	10A		
5	12V Power (Optional)	10A		
6	Stereo, 12V Power	15A		
7	Diesel Heater (Optional)	10A		
8	Starter Switch, Hour Meter	30A		
9	Air Conditioner, Heater	30A		
10	Micro Phone (Optional)	20A		
11	DEF Tank, NOx Sensor	30A		
12	Seat Warmer, Air Suspension	15A		
13	EPOS, TMS	15A		
14	ECU	30A		

No	Fuse Box Two			
NO.	Name	Capacity		
1	Alarm Buzzer (Optional)	10A		
2	Horn	10A		
3	DEF, Heater	30A		
4	Pedal Safety (Optional)	10A		
5	Pilot Cut Off, Headlight, Rear Working Light	15A		
6	Auxiliary Mode, Diesel Heater Timer (Optional)	10A		
7	Memory Back up	10A		
8	Room Light	10A		
9	Cabin Light (Optional)	15A		
10	Working Light	15A		
11	Fuel Heater	30A		
12	Spare	20A		
13	Gauge Panel, Pilot Buzzer	10A		
14	Fuel Pump (Optional)	15A		

Oregon Cabin

No	Fuse Box One			
NO.	Name	Capacity		
1	Cigarette Lighter	10A		
2	FAN	10A		
3	EGR	20A		
4	Window Washer	20A		
5	12V Power (Optional)	10A		
6	Stereo, 12V Power	15A		
7	Diesel Heater (Optional)	10A		
8	Starter Switch, Hour Meter	30A		
9	Air Conditioner, Heater	30A		
10	Micro Phone (Optional)	20A		
11	DEF Tank, NOx Sensor	30A		
12	Seat Warmer, Air Suspension	15A		
13	EPOS, TMS	15A		
14	ECU	30A		

No	Fuse Box Two			
NO.	Name	Capacity		
1	Alarm Buzzer (Optional)	10A		
2	Horn	10A		
3	DEF, Heater	30A		
4	Pedal Safety (Optional)	10A		
5	Pilot Cut Off, Headlight, Rear Working Light	15A		
6	Auxiliary Mode, Diesel Heater Timer (Optional)	10A		
7	Memory Back up	10A		
8	Room Light	15A		
9	Cabin Light (Optional)	15A		
10	Working Light	15A		
11	Fuel Heater	30A		
12	Spare	20A		
13	Gauge Panel, Pilot Buzzer	10A		
14	Fuel Pump (Optional)	15A		

ENGINE COOLING SYSTEM

General

Keeping an engine's cooling system in peak operating condition can have many benefits in keeping a machine in good operating condition. A properly functioning cooling system will improve fuel efficiency, reduce engine wear, and extend component life.

Always use distilled water in the radiator. Contaminants in tap water neutralize the corrosion inhibitor components. If tap water must be used, Refer to "Table of Standards for Allowed Tap Water" on page 4-87. Water that has been treated with a water softener also contains salt that will cause corrosion of components. Water from creeks and stagnant pools usually contain dirt, minerals and/or organic material that are deposited in the cooling system and impair cooling efficiency. As such, the use of distilled water is recommended.

Engine coolant shall be mixed with antifreeze solution and water in ratio of 50 : 50.

Coolant shall be checked every 500 hours of operation for ensuring adequate concentration of antifreeze solution and additives.

Engine overheating is often caused by bent or clogged radiator fins. The spaces between the fins can be cleaned by use of air or water under pressure. When straightening bent fins, use care not to damage the tubes or break the bonding joint between the fins and the tubes.



AVOID DEATH OR SERIOUS INJURY

Pressure at air nozzle must not exceed 2 kg/cm² (28 psi). Always wear goggles when using compressed air.

Do not pour cold water into radiator when engine is hot and water level is below the top of the tubes. Such action could result in damage to engine cylinder heads.

Heavy-duty diesel engines require a balanced mixture of water and antifreeze. Drain and replace the mixture 1 year or 2,000 hours of operation, whichever comes first. This will eliminate buildup of harmful chemicals.

Antifreeze is essential in any climate. It broadens the operating temperature range by lowering the coolant's freezing point and by raising its boiling point. Do not use more than 50% antifreeze

in the mixture unless additional antifreeze protection is required. Never use more than 60% antifreeze under any condition.

Types of Antifreeze

Ethylene Glycol - HYUNDAI Genuine Antifreeze Solution (for all seasons)

Ethylene glycol is a very hazardous material to human beings, animals and environment. Drain of coolant must be disposed of by an authorized waste material treatment service provider.

The color does not provide a standard. Unauthorized coolant may have the same color. Please check the label on the container. Use genuine product.



Do not mix solutions from different manufacturers. Otherwise, the performance may be deteriorated. It is recommended to use the standard product from HYUNDAI.

In extreme temperatures, the performance of the coolant must be checked frequently and the coolant change cycle adjusted as necessary.

When refilling and changing coolant, use < m bXUJfg genuine coolant is the top priority. If < m bXUJfg genuine coolant is not available, the coolant and additives specifications must meet the following table.

Description	Coolant		
Description	Refill	Change	
Coolant Standard	ASTM D6210	ASTM D6210	
Coolant Base	Ethylene Glycol Base (Do not use Propylene Glycol)	Ethylene Glycol Base or Propylene Glycol (Both available)	
Additive	Only Phosphate type available	Only Phosphate type available (Do not use Silicates type additive)	
	Below should not be contained for Scania Engine		
Remark	• 2-EHA (mono carboxylate acid)		
	Benzoat (aromatic carboxylate acid)		

Antifreeze Concentration Tables

Ethylene Glycol - HYUNDAI Genuine Antifreeze Solution (for all seasons)(2,000 Hour/1 Year)			
Ambient Temperature	Cooling Water	Antifreeze	
-20°C (-4°F)	67%	33%	
-25°C (-13°F)	60%	40%	
-30°C (-22°F)	56%	44%	
-40°C (-40°F)	50%	50%	

NOTE: The concentration shall be kept at 50% and in worst case at 30% minimum for the least corrosion resistance.

Table of Standards for Allowed Tap Water

Requirement					
Item	Inorganic chloride	Sulfates	Total Hardness	Total Solids	Acidity
Value	< 40 ppm	< 50 ppm	< 9.5° d.H	< 340 ppm	5.5 - 9.0

PPM (Parts Per Million) - Unit of concentration of minor materials.

• 1 ppm = 1 mg/1 kg, 1 mL/1 L

° d.H - Unit of concentration of minor materials.

• 1° d.H = 17 ppm



AVOID INJURY

The standard of tap water is for reference only, and may not be regarded as a standard.

If quality of the water is not trustable, stop using tap water whenever possible and use distilled water.

NOTE: Replacement cycle of the HYUNDAI Genuine Product is 2,000 hours or one year.

Electric Viscous Fan Clutch

The electrically controlled viscous fan clutch provides optimum cooling fan speeds. This also results in lower fan noise and better fuel efficiency. Coolant, hydraulic oil, and cooled charged air temperatures, with engine speeds, are monitored for optimum fan speeds.

When the electrical wire is broken, the fan speed works at its maximum speed to protect entire cooling system from overheating in any operating condition. The maximum and minimum fan speeds are shown below:



Figure 130

	Minimum Speed	Maximum Speed	
Fan Speed (rpm)	600 ±50	1,800 ±50	

Removal and Installation of the Cooling Fan Assembly

The following instruction must be followed when handling the cooling fan assembly.

- 1. The weight of the cooling fan assembly is approximately 9 kg (20 lb), which is heavier than a cooling fan assembly without electric fan clutch. Remove and handle assembly carefully not to damage cooling fan and radiator.
- 2. If not correctly secured with a tie strap, the electrical harness can be damaged by the cooling fan during operation. Properly secure the electrical harness to fan guard when assembling.
- 3. The cooling fan assembly must be assembled with 12 bolts using torque values shown below.
 - A. Before installation, cooling fan subassembly needs to be assembled by using 6 x M8 bolts. (Tightening torque 22 N.m (2.2 kg.m, 16 ft lb))
 - B. Use 6 x M10 bolts (tightening torque 43 N.m (4.4 kg.m, 32 ft lb)) when installing the cooling fan assembly to the engine.

Reference Number	Description	Torque
1	Cooling Fan (to Clutch) M8 Bolt	22 N.m (2.2 kg.m, 16 ft lb)
2	Clutch (to Engine Pulley) M10 Bolt	43 N.m (4.4 kg.m, 32 ft lb)

NOTE: If electrical wire is not properly connected, the cooling fan will run at maximum fan speed. Check fan speed after assembly.



Figure 131



FUEL TRANSFER PUMP (OPTIONAL)

Please open fuel cap before operate fuel transfer pump to avoid any safety issue/damages due to the pressure building up.

Dry operating fuel pump for more than fifteen seconds can cause wear and/or damage to pump.

 Cooling and lubrication of pump is achieved by fuel passing through pump. If pump is dry operated, heat generated by moving parts will cause damage to pump rotors, vanes and seals.

Do not operate pump for more than fifteen minutes at a time.

• Continuous usage of pump over recommended time interval will cause overheating of motor and will result in motor damage.

Do not use fueling pump for other types of fuel or fluids. (Use only for diesel fuel)

- Do not use fueling pump for other types of fuel which have a low flash point.
- Do not use fueling pump for fuel contaminated with water or high humidity. Moisture in pump mechanism can cause rust and can create pump failure.

Always operate pump using strainer installed on inlet hose. This will prevent any foreign materials from being introduced into pump. Always maintain pump and all of its components in a clean condition.

- If dirt or other foreign materials enter pump, they can become lodged between the rotor and/or vanes and generate heat which can cause pump damage.
- Do not remove strainer or use a strainer with larger mesh to increase flow of fuel.

Be careful not to overfill or spill fuel.

Make sure direction of check valve is in line with flow direction of fuel.

Any pump parts or components that become lost, damaged or inoperable must be immediately replaced.



AVOID DEATH OR SERIOUS INJURY

If there is any sign of leakage while operating transfer pump, inspect the following components to prevent fire or hazardous fuel spill:

- Check all hoses leading to and from the transfer pump.
- Check all hose clamps.
- Check transfer pump inlet port.

The transfer pump is used to transfer fuel from a refueling source to the fuel tank. A check valve is installed in the inlet hose to prevent fuel from flowing back from fuel tank to source. A strainer is installed in inlet hose to prevent any foreign material from being introduced into transfer pump or fuel tank.

A thermal limiter, built into the motor, will automatically shut off power if motor is overheating to protect it from being damaged.



Figure 133

Reference Number	Description
1	Body
2	Check Valve
3	Strainer

Reference Number	Description	
4	Strainer Cap	
5	Inlet Hose	

FG000161

- 1. Open the fuel cap on the fuel tank.
- 2. Remove strainer cap (4, Figure 133) from strainer (3, Figure 133) on end of inlet hose (5, Figure 133).
 - **NOTE:** Keep strainer cap (4, Figure 133) in a safe location to reseal strainer (3, Figure 133) after refueling is complete.
- 3. Insert inlet hose (5, Figure 133) into refueling tank.





- 4. Push fuel pump "START" switch (Figure 135) inside of battery box on front side.
- 5. Once fuel transfer is completed, the pump will automatically turn "OFF".
- 6. Lift inlet hose (5, Figure 133) from fueling source and push "START" switch and push "STOP" switch after two three seconds to drain remaining fuel from hose to fuel tank.
- 7. Install strainer cap (4, Figure 133) on inlet strainer (3, Figure 133) and return hose (5, Figure 133) to storage position.



Figure 135

HANDLING OF ACCUMULATOR



AVOID DEATH OR SERIOUS INJURY

Even though the engine is stopped, the hydraulic accumulators for the pilot system are still charged. Do not disconnect any pilot system hoses until accumulator pressure has been released from the circuit. To release pressure, turn the starter switch to "I" (ON) position and operate all hydraulic control levers and forward/reverse travel levers. Even though the engine is stopped, hydraulic actuated components may move while releasing pilot pressure. Keep all personnel and bystanders away from machine while performing this operation.

- Move safety lever to "LOCK" position after stopping engine.
- DO NOT mishandle accumulator(s), because they contain high-pressure nitrogen gas.
- DO NOT puncture or apply heat or fire to an accumulator.
- DO NOT weld on accumulator, or try attaching anything to it.
- When replacing an accumulator, contact a HYUNDAI distributor or sales agency so the gas can be properly released.
- Wear safety goggles and protective gloves when working on an accumulator. Hydraulic oil under pressure can penetrate the skin and cause death or serious injury.

Release pilot accumulator pressure using the following procedure:

- 1. Park machine on firm and level ground. Lower the front attachment to the ground and stop engine.
- 2. Move safety lever to "UNLOCK" position.
- 3. Turn starter switch to "I" (ON) position.
- 4. Fully stroke work and travel levers in all directions.
- 5. Move safety lever to "LOCK" position.
- 6. Turn key to "O" (OFF) position and remove from starter switch.
- 7. Remove accumulator by unscrewing it slowly.



Figure 136

TRACK TENSION (IF EQUIPPED TYPE 1)



AVOID DEATH OR SERIOUS INJURY

Measuring track tension requires two people. One person must be in the operator's seat, operating the controls while the other person makes dimensional checks. Block frame to make sure the machine won't move or shift position during service. Warm up the engine to prevent stalls, park the excavator in an area that provides level, uniform ground support and/or use support blocks when necessary.

NOTE: The track tension must be adjusted in accordance with the operating conditions. If a lot of dust stick to the track assembly in the working place, keep the track as loose as possible.

Track shoe link pins and bushings wear with normal usage, reducing track tension. Periodic adjustment is necessary to compensate for wear and it may also be required by working conditions.

 Track tension is checked by jacking up one side of the forestry machine. See Figure 137. Place blocking under frame while taking measurement. Turn the track backward 1 ~ 2 turns.



EX1300535



- 2. Measuring the distance (A, Figure 138) between the bottom of the side frame and the top of the lowest crawler shoe. Recommended tension for operation over most types of terrain is as below table.
 - **NOTE:** Clean off the tracks before checking clearance for accurate measurements.
- Too little sag in the crawler track (less than clearance distance "A" on below table) can cause excessive component wear. The recommended adjustment can also be too tight causing accelerated stress and wear if ground conditions are wet, marshy or muddy.



4. A track that is properly adjusted may have a different sag according to the track options. Contact your dealer for information.

Terrain Type	Distance "A"
Normal	330 ~ 360 mm (13.0 ~ 14.2 in)



AVOID DEATH OR SERIOUS INJURY

The track adjusting mechanism is under very high-pressure. NEVER release grease pressure too fast. The track tension grease valve <u>should never be</u> loosened more than one (1) complete turn from the fully tightened down position. Bleed off grease pressure slowly. Keep your body away from the valve always. Always wear eye and face protection when adjusting track tension.

- 5. Track tension adjustments are made through the grease fitting (1, Figure 139) in the middle of each side frame. Adding grease increases the length of an adjustment cylinder (2). Extending the adjustment cylinder, increases the pressure on the tension spring pushing the track idler wheel outward.
- 6. If there is not enough slack or clearance in the tracks and the adjustment is too tight, the idler wheel and adjusting cylinder can be retracted by bleeding off grease through hole in adjustment cylinder (2, Figure 139).



Figure 139

TRACK TENSION (IF EQUIPPED TYPE 2)



AVOID DEATH OR SERIOUS INJURY

Measuring track tension requires two people. One person must be in the operator's seat, operating the controls while the other person makes dimensional checks. Block frame to make sure the machine won't move or shift position during service. Warm up the engine to prevent stalls, park the excavator in an area that provides level, uniform ground support and/or use support blocks when necessary.

NOTE: The track tension must be adjusted in accordance with the operating conditions. If a lot of dust stick to the track assembly in the working place, keep the track as loose as possible.

Track shoe link pins and bushings wear with normal usage, reducing track tension. Periodic adjustment is necessary to compensate for wear and it may also be required by working conditions.

 Track tension is checked by jacking up one side of the forestry machine. See Figure 140. Place blocking under frame while taking measurement. Turn the track backward 1 ~ 2 turns.



EX1300535

Figure 140

- 2. Measuring the distance (A, Figure 141) between the bottom of the side frame and the top of the lowest crawler shoe. Recommended tension for operation over most types of terrain is as below table.
 - **NOTE:** Clean off the tracks before checking clearance for accurate measurements.
- Too little sag in the crawler track (less than clearance distance "A" on below table) can cause excessive component wear. The recommended adjustment can also be too tight causing accelerated stress and wear if ground conditions are wet, marshy or muddy.



4. A track that is properly adjusted may have a different sag according to the track options. Contact your dealer for information.

Terrain Type	Distance "A"
Normal	330 ~ 360 mm (13.0 ~ 14.2 in)



AVOID DEATH OR SERIOUS INJURY

The track adjusting mechanism is under very high-pressure. NEVER release grease pressure too fast. The track tension grease valve <u>should never be</u> loosened more than one (1) complete turn from the fully tightened down position. Bleed off grease pressure slowly. Keep your body away from the valve always. Always wear eye and face protection when adjusting track tension.

- 5. The track tension can be adjusted with the grease fitting valve (1,Figure 142) and handle screws (2, Figure 142) in the center of each side frame. Filling the grease fittings with grease increases the length of the adjustable cylinders. The longer the adjustable cylinders become, the more pressure builds in the tension springs which expand beyond the track idlers.
- 6. If the tracks and adjustment devices expand to the point that there is a lack of deflection or space between parts, turn the handle screw clockwise once or twice to drain some of the grease. Once the track tension is suitable, tighten the handle screw in the counterclockwise direction.
 - Grease fitting valve tightening torque: 68.6 ±9.8 N.m (7 kg ±1 kg.m, 5.2 ±0.7 ft lb)
 - Check the tension again after rotating the track 3 ~ 4 times.
 - **NOTE:** After draining, failure to turn the handle screw counterclockwise will allow the grease to keep draining.

Also, turning it too far counterclockwise may cause damage to the stopper of the screw. Turn the handle screw by no more than one or two turns.





DS1901245

VENTING AND PRIMING HYDRAULIC SYSTEM

Main System Pump

- **NOTE:** If pump is run without sufficient oil in the main hydraulic pump, damage can occur. Always vent pump of air after draining hydraulic system.
- 1. With the engine stopped, remove vent plug (Figure 143) to see if any oil is present.
- 2. If oil is not present, fill oil tank with oil.
- 3. Install vent plug (Figure 143) first.
- 4. Slowly loosen vent plug (Figure 143) several turns, until hydraulic oil flows out of plug. This shows that air has been released.
- 5. Tighten the plug (Figure 143).

Hydraulic Cylinders



Figure 143

DS1602721

If cylinders are operated in "HIGH IDLE" after the hydraulic system has been drained or the cylinder has been rebuilt, damage to piston packing and seals can occur. Always vent air from cylinders at "LOW IDLE" and at a slow speed.

- 1. Run engine at "LOW IDLE". Extend and retract each cylinder to within 100 mm (4 in) of fully stroking it 4 \sim 5 times.
- 2. Operate fully extend and retract each cylinder 3 ~ 4 times.
- 3. Repeat procedure until cylinders extend and retract smoothly.



If the air is not vented from the system, it will cause damage to the swing motor and bearings.

NOTE: Perform this only when oil has been drained from swing motor.

- 1. Stop engine.
- 2. Disconnect drain hose and fill swing motor case with hydraulic oil.
- З. Connect the drain hose.
- 4. Start engine and set throttle at "LOW IDLE" and swing 20° upper structure slowly 2 times to the left and right.

Travel Motor

- NOTE: Perform this only when oil is drained from travel motor.
- 1. Stop engine.
- 2. Disconnect drain hose (Figure 145) and fill motor case with hydraulic oil.
- 3. Connect drain hose.
- 4. Start engine and set engine speed control dial to "LOW IDLE". Run the engine for one minute and slowly drive forestry machine forwards and backwards within 2 m (6'7"). (2 times)

General Venting

- After venting air from all components, stop engine and 1. check the hydraulic oil level. Fill hydraulic oil tank to "H" mark on sight gauge.
- 2. Start engine and operate all controls again, and run engine for five minutes to ensure all systems have been vented and purged of air. Move engine speed to "LOW IDLE" and check hydraulic oil level again. Add oil as necessary.
- 3. Check for oil leaks and clean all fill and venting locations.









MAINTENANCE IN SPECIAL CONDITIONS

NOTE: See "Operation Under Abnormal Conditions" on page 3-47 for other recommendations.

Conditions	Maintenance Required
Operating in mud, water or rain.	Perform a walk around inspection to check for any loose fittings, obvious damage to the machine or any fluid leakage.
	After completing operations, clean mud, rocks or debris from the machine. Inspect for damage, cracked welds or loosened parts.
	Perform all daily lubrication and service.
	If the operations were in salt water or other corrosive materials, make sure to flush the affected equipment with fresh water and check that all control systems operate properly.
Operating in an extremely dusty or hot environment.	Clean the air intake filters on a more frequent basis.
	Clean the radiator and oil cooler fins to remove embedded dirt and dust.
	Clean the fuel system intake strainer and fuel filter more frequently.
	Inspect and clean as required the starter and alternator.
Operating in rocky terrain.	Check the undercarriage and track assemblies for damage or excessive wear.
	Inspect for loose or damaged fittings or bolts.
	Relax track tension.
	On a more frequent basis, inspect the front end attachments for damage or excessive wear.
	Install a top guard and front guard as required for protection against falling rock.
Operating in extreme cold.	Use the proper fuel for the temperature conditions.
	Using a hydrometer, check the antifreeze to make sure that it is providing the proper cold weather freeze protection.
	Verify the condition of the batteries. In extreme cold weather, remove batteries at night and store them in a warmer area.
	Remove mud buildup as soon as possible to prevent it from freezing to the undercarriage and causing damage.

Transportation

Check federal, state and local laws and regulations regarding weight, width, and length of a load before making preparations for transporting on public roads or highways.

The hauling vehicle, trailer, and load must comply with all applicable laws and regulations.

Check the intended route for road width, overhead clearances, weight restrictions, and traffic control regulations. Special approval or permits may be required.

If the actual height exceed the limitation on the trailer, the operator must submit special permission to the government. Consult to the national or regional Road authorities.

Or, to avoid height limit, one may disassemble front linkage or guardrail during transportation.



AVOID DEATH OR SERIOUS INJURY

Whenever removal or reassemble guardrail, always use external ladder to access. And NEVER climbing up machine without guardrail and external ladder.

Consult to the HYUNDAI dealer.



Figure 1



Do not reuse counterweight torque bolt. Once fastened and used under the harsh condition such as counterweight, the bolt may exceeded its yield point.

Use new bolt to counterweight reassemble every time.

DS1601523

LOADING AND UNLOADING

Warning for Counterweight and Front Attachment Removal



AVOID DEATH OR SERIOUS INJURY

DO NOT remove machine counterweight, front attachment or any other part. This could cause tipping or roll-over resulting in death or serious injury.

Never remove counterweight or front attachment unless the upper structure is in-line with the lower structure.

Never rotate the upper structure once the counterweight or front attachment has been removed.





DS1602722



Counterweight



AVOID DEATH OR SERIOUS INJURY

Death or serious injury can occur from a counterweight falling during removal or installation. Do not allow personnel under or around the counterweight during removal or installation.

Use certified cables and shackles of adequate load rating. Improper lifting can allow the load to shift and cause death or serious injury.



Figure 3

Removal

- 1. Park on firm and level ground.
- 2. Lower front attachment or work tool to ground.
- 3. Stop engine.
- 4. Move safety lever to "UNLOCK" position.
- 5. Turn starter switch to "I" (ON) position.



AVOID DEATH OR SERIOUS INJURY

If engine must be running while performing maintenance, use extreme care. Always have one person in the cabin at all times Never leave the cabin with the engine running.

- 6. Fully stroke work levers (joysticks) in all directions to relieve any pressure from accumulators.
- 7. Move safety lever to "LOCK" position.
- 8. Turn key to "O" (OFF) position and remove from starter switch.
- 9. Attach maintenance warning tag on controls.
- 10. Turn battery disconnect switch to "OFF" position.
- 11. Make sure all electrical lines and other items are disconnected.
- Using a suitable lifting device capable of handling a heavy load, partially support counterweight from lifting holes (5, Figure 4), counterweight (1) before loosening four bolts (2). Stop lifting with assist crane as soon as lifting slings are taut.
- 13. Remove four bolts (2, Figure 4) and washers (3) from counterweight (1, Figure 4).
 - Tool: 46 mm (2)
 - Weight: 4,400 kg (9,700 lb)

NOTE: Heat bolts, if necessary, to free them.

14. When bolts (2, Figure 4) and washers (3) have been removed, lift counterweight (1) a very short distance above support frame (4) and stop. Check slings and make sure counterweight is being supported evenly.





Installation

- Using suitable lifting device capable of handling the weight of the counterweight, support counterweight from lifting holes (5, Figure 5). Raise counterweight (1) into position just above support frame (4) leaving counterweight suspended. Verify that counterweight is level and even.
 - **NOTE:** Leave counterweight (1, Figure 5) suspended 3 mm (0.125") above support frame (4) until all four mounting bolts (2) are started in counterweight mounting holes.
- 2. Slide washers (3, Figure 5) onto bolts (2). Apply Loctite #242 to mounting bolt threads.
- 3. Install four bolts (2, Figure 5) with washers (3) into counterweight until washers contact support frame. Fully lower counterweight onto support frame and finish tightening bolts.
 - Tool: 46 mm (2003)
 - Torque: 1,471 N.m (150 kg.m, 1,085 ft lb)
- 4. Remove lifting device from counterweight lifting holes. (5, Figure 5)
- 5. Make sure all electrical lines and other items are connected.
- 6. Turn battery disconnect switch to "ON" position.



AVOID DEATH OR SERIOUS INJURY

When transporting the machine, know the width, height, length, and weight.

When loading or unloading the machine, make sure to run the engine at the lowest speed setting and travel at the slowest speed possible.

Make sure that ramp being used can handle the weight of the machine. If required, add blocking under the ramp for additional support.

Make sure that ramp surface is free of grease, debris, or mud that could cause the machine to slip or slide.

Make sure that trailer is parked on firm and level ground before attempting to load/unload the forestry machine.

If it is necessary to turn the machine while it is on the trailer, make sure to do this at the slowest engine and travel speeds possible.

Make sure to secure the machine onto the trailer as required by local transportation laws and regulations.





- 1. Make sure that trailer is parked on firm and level ground. See Figure 6.
- 2. Make sure that ramps that are being used are designed to handle the weight of the machine. If required, add blocking under the ramp to provide additional support.
- 3. The ramp angle must be less than a 15° angle. Ramps steeper than this can cause traction or stability problems when loading or unloading.



Figure 6

4. Set the travel speed selector switch to "O" (OFF) position. See Figure 7.



FG016016



- 5. Turn "OFF" auto idle selector button (1, Figure 8). The indicator symbol will disappear.
- 6. Move engine speed to "LOW IDLE".











8. The unit does not require disassembly for normal over-the-road transportation. If the boom and arm need to be removed, the counterweight will place more weight on the rear of the machine. Make sure to back the forestry machine onto the trailer so the counterweight end (heavy end) of the forestry machine is positioned on the ramp first. See Figure 10.



EX1500903



9. Extend heel and arm cylinders to maximum length and then lower the boom slowly.



Figure 11

Unlock 🕊

EX1300672





12. Remove key from starter switch.



Figure 13
- 13. Turn battery disconnect switch to "OFF" position (Figure 14).
- 14. Lock all doors and covers.
- 15. Adjust direction of rotating beacon and TMS antenna.



EX1500481



- 16. Make sure to secure the forestry machine onto the trailer before transporting. Place blocking (1, Figure 15) in front of and behind each track. Tie front and rear (2, Figure 16) and tie down point (3, Figure 16) on the lower frame with wire cable as required by local transportation regulations.
- 17. Refer to "Specification" section of this manual for overall machine height and width dimensions. Make sure to position the forestry machine as shown. If not transported in this position, the height measurements may be different.





LIFTING MACHINE



AVOID DEATH OR SERIOUS INJURY

Never lift the machine with a person in the cabin or on the machine.

Never enter the area under or around a raised machine.

Improper lifting can allow load to shift and cause death or serious injury or property damage.

When lifting, move the safety lever to "LOCK" position to prevent the machine from moving unexpectedly.

Use only properly rated cables and slings.

Never go in the area under or around the machine when it is raised.

Always use the posture given in the procedure below and use the proper lifting equipment to lift the machine.





Figure 17

- 1. Refer to "Specification" section of this manual for weight and dimensional information.
- 2. Lower the work equipment to the ground as shown in the diagram on the right.
- 3. Lower the dozer blade to the ground. (if equipped)
- 4. Move safety lever to "LOCK" position. Stop engine.
- 5. Ensure there is nothing around the operator's compartment, close the cabin door and front glass securely.
- 6. Bind wire ropes between the 1st and 2nd track rollers from the front and between the 1st and 2nd track rollers from the rear.
- Use spreader bars between the wire rope and the machine to prevent damage to the rope or machine. Set the lifting angle (1, Figure 17) of the wire rope to 30 - 40°.
- 8. After the machine comes off the ground, check the hook condition and the lifting posture, and then lift slowly.

Specification

STANDARD SPECIFICATION

	Component		Specification					
	Component		Metric	English				
		STD Cabin	31.2 metric tons	34.4 tons				
Operating Wei	ght	Oregon Cabin	32.0 metric tons	35.3 tons				
		Road Builder	28.9 metric tons	31.8 tons				
	Model	•	DLO	06P				
Engine	Туре		Water Cooled, 4-cy	cle, Direct Injection				
	Rated Output		124 kW @1,800 rpm	167 HP (169 PS) @1,800 rpm				
	Maximum Torc	lne	77 kg.m @ 1,400 rpm	557 ft lb@ 1,400 rpm				
	Fuel Tank Cap	acity	1,000 L	264 U.S. gal.				
Hydraulic Pump	Туре		Swash Plate	, Axial Piston				
	Discharging Pr	ressure	*350 kg/cm ² / 330 kg/cm ²	*343 bar (4,978 psi) / 323 bar (4,694 psi)				
	Maximum Disc	harge Quantity	2 x 216 L/min	2 x 57 U.S. gpm				
	Hydraulic Oil	Tank Level	131 L	35 U.S. gal.				
		Full	195 L	52 U.S. gal.				
	Oupdony	System	280 L	74 U.S. gal.				
	Swing Speed		11.7 rpm					
	Travel Speed	High-speed	4.2 km/h	2.61 MPH				
	Traver Speed	Low Speed	2.4 km/h	1.49 MPH				
	Traction	High-speed	12.9 metric tons	14.2 tons				
Performance	Force	Low Speed	24.7 metric tons	27.2 tons				
	Gradeability		35° (70% slope)					
		STD Cabin	0.56 kg/cm ²	8.0 psi				
	Ground	Oregon Cabin	0.57 kg/cm ²	8.1 psi				
	1 Teobure	Road Builder	0.52 kg/cm ²	7.4 psi				
Ground Clearance		•	725 mm	28.5 in				
Track Shoe Width			700 mm 27.6 in					
Upper Roller C	ty.		2 per side					
Bottom Roller	Qty.		9 per side					

* Power Boost

OVERALL DIMENSIONS

Forestry Machine



Figure 1

	Item	Dimension					
А	Shipping Height	3,453 mm (11' 4")					
В	Overall Height	4,620 mm (15' 2")/**4,770 mm (15' 8")					
С	Shipping Length	13,850 mm (45' 5")					
D	Shipping Length (W/O Attachment)	5,436 mm (17' 10")					
E	Upper Structure Width	3,325 mm (10' 11")					
F	Track Length	4,635 mm (15' 2")					
G	Shipping Width	3,600 mm (11' 10")					
Н	Undercarriage Width	700 mm (2' 4")					
I	Car Body Clearance	725 mm (2' 5")					
J	Tumbler Distance	3,680 mm (12' 1")					
М	Tail Swing Radius	3,155 mm (10' 4")					
Ν	Cab Guard Width	1,105 mm (3' 8") / **1,140 mm (3' 9")					
0	Track Height	1,204 mm (3' 11")					

**: Oregon Cabin

Road Builder



Figure 1

	Dimension	5.7 m (18' 8") Boom					
	Dimension	2.9 m (9' 6") Arm					
A	Shipping Length	9,770 mm (32' 1")					
В	Tail Swing Radius	3,155 mm (10' 4")					
С	Tumbler Distance	3,680 mm (12' 1")					
D	Track Length	4,635 mm (15' 2")					
E	Counterweight Clearance	1,310 mm (4' 4")					
F (Boom)	Shipping Height	2,920 mm (9' 7")					
F (Hose)	Shipping Height	3,020 mm (9' 11")					
G	Shipping Width (STD)	3,600 mm (11' 10")					
Н	House Width	3,325 mm (10' 11")					
I	Cabin Width	1,010 mm (3' 4")					
J	Shoe Width	700 mm (2' 4")					
К	Undercarriage Width	3,600 mm (11' 10")					
L	Height Over Cabin	3,340 mm (10' 11")					
М	Cabin Height Above House	2,250 mm (7' 5")					
N	Track Height	1,204 mm (3' 11")					
0	Car Body Clearance	725 mm (2' 5")					

DISASSEMBLED PARTS, DIMENSION AND WEIGHT

Components

Boom



Figure 2

 Description
 Dimension

 Length (A)
 6,354 (20' 10")

 Length (B)
 mm (ft in)
 876 (2' 10")

 Width (C)
 828 (2' 9")

 Weight
 kg
 2,218

 Ib
 4,890



Descrip	otion	Dimension					
Length (A)		3,860 (12' 8")					
Length (B)	mm (ft in)	779 (2' 7")					
Width (C)		504 (1' 8")					
Woight	kg	1,013					
vveigin	lb	2,233					



Descriptio	on	Dimension				
Length (A)		2,711 (8' 11")				
Length (B)	mm (ft in)	576 (1' 11")				
Length (C)	()	1,047 (3' 5")				
Woight	kg	4,400				
vveigitt	lb	9,700				

GROUND PRESSURE

Description	Shoe Width mm	Boom Length mm (ft in)	Arm Length mm (ft in)	Counter- weight kg (lb)	Operating Weight kg (lb)	Ground Pressure kg/cm² (psi)	
Double Grouser	700	6,354 (20' 10")	3,860 (12' 8")	4,400 (9,700)	30,900 (68,122)	0.59 (8.39)	

WORKING RANGE

Forestry Machine

DIMENSIONS SHOWN IN FEET



Figure 5

EX1500904

Max. Reach @ Ground Level 11,700 mm (38' - 5")

Max. Arm Height 13,000 mm (42' - 6")

Road Builder



Figure 6

	Boom Type (One Piece)	5.7 m (18' 8")
DIM.	Arm Type	2.9 m (9' 6")
	Bucket Type (SAE)	0.92 m³ (1.2 yd³)
А	Max. Digging Reach	9,880 mm (32' 5")
В	Max. Digging Reach (Ground)	9,660 mm (31' 8")
С	Max. Digging Depth	6,375 mm (20' 11")
D	Max. Loading Height	7,045 mm (23' 1")
E	Min. Loading Height	2,705 mm (8' 10")
F	Max. Digging Height	9,760 mm (32')
G	Max. Bucket Pin Height	8,500 mm (27' 11")
н	Max. Vertical Wall Depth	5,410 mm (17' 9")
I	Max. Radius Vertical	6,380 mm (20' 11")
J	Max. Depth to 2,500 mm Line	6,185 mm (20' 4")
К	Min. Radius 2,500 mm Line	2,820 mm (9' 3")
L	Min. Digging Reach	295 mm (1')
М	Min. Swing Radius	3,560 mm (11' 8")
d	Bucket Angle	177°

FORESTRY MACHINE RATED LIFT CAPACITY TABLES

Always keep operators manual in operator station:

Whenever you handling and lifting objects, ensure operator manual available on the station and refer the lifting chart.



AVOID DEATH OR SERIOUS INJURY

Keep bystanders away from the boom cylinder. While operating, boom, arm, work tool hydraulic hoses could burst causing high-pressure oil to spray or sudden lowering of the load or front structure. This could cause death or serious injury.

When changing the hydraulic hoses, record the part numbers of the hoses to factory log book.



AVOID DEATH OR SERIOUS INJURY

All rated lift capacities are based on the machine and the load both remaining level at all times. DO NOT EXCEED THE RATED LIFT CAPACITY. Lifting loads greater than those shown in the rated capacity tables can cause tipping, equipment failure and/or structural failure of the machine.

Operate the forestry machine on firm and level ground and surfaces that can support the weight of the forestry machine and the loads that will be lifted. Avoid operating the forestry machine, if these conditions exist:

- Soft or uneven ground.
- Unlevel terrain.
- Side loads.
- Modifications or poor maintenance of the forestry machine.
- Failure to lift squarely over the end or over the side of the machine.

When a load is in the air, the operator must:

• Avoid use of uneven slings that can cause side loads when traveling with a load or swinging the load.



Figure 7

- Avoid lifting loads that can become unbalanced if the hook line is twisted and starts to rotate. If the surface area of the load is large enough, wind gusts can create side loads.
- Keep the arm end point directly over the load. Use tag lines on opposite sides of the load to help stabilize the load and prevent side loads caused by wind gusts.

The following rated loads are in compliance with ISO 10567 and applicable ISO standards for hydraulic forestry machines performing lifting operations on firm supporting surfaces. An asterisk (*) next to the load rating indicates rated load does not exceed 87% of hydraulic capacity. All other ratings do not exceed 75% of tipping capacity.

Do not attempt to lift or hold any load that exceeds rated load capacity at the specified distances (from the machine's rotation centerline and height - see "Lifting Radius" and "Lifting Point Height" in the reference drawing, Figure 8).



Ground Line (Machine Supporting Surface)

Figure 8

The weight of slings and any auxiliary lifting device (and/or the weight difference of any attachment heavier than standard configuration) must be deducted from the rated lift capacity to determine net lifting load. The lift point must be on the end of the arm, as shown in Figure 8.



Select the Digging Mode switch on the Instrument Panel before using the forestry machine for lifting work. Engine and hydraulic oil should both be fully warmed up to operating temperature before operating.



Machine Type	: Forestry Machine	
Track Width	: 3.6 m (11' 10")	
Boom	: 6.15 m (20' 2")	
Arm	: 3.66 m (12' 0")	
Heel Weight	: 478 kg (1,054 lb)	
Counterweight	: 4,400kg (9,700 lb)	
Shoe	: 700 mm (28")	
Cabin	: Standard	
ů	: Rating Over Front	
⇔	: Rating Over Side or 360 degree	
Unit	: 1,000 kg (1,000 lb)	DS1604548

METRIC

1,000 kg 4.5 7.5 9 10.5 MAX. REACH A (m) 3 6 ľ ľ ľ ľ ľ Ů Н A (m) **__ __ __** ____ **__ _** B (m) 12 14.49 14.49 1.96 10.5 9.61 * 9.61 8.48 * 8.48 6.85 6.85 6.03 * 7.90 * 7.90 * 7.20 6.86 * 5.44 5.44 8.08 9 7.5 * 7.85 * 7.85 * 7.06 6.92 6.28 5.07 * 4.86 4.71 9.35 5.08 * 4.60 6 * 8.19 * 8.19 * 7.19 6.86 6.30 4.10 10.16 * 7.49 6.23 5.02 4.5 10.87 10.87 * 8.84 * 8.84 6.70 4.83 3.87 * 4.50 3.78 10.64 * 7.82 4.91 4.81 3.85 4.55 3 12.56 12.56 * 9.60 9.12 6.49 6.12 3.65 10.83 1.5 13.77 13.48 * 10.14 8.70 7.87 6.27 6.00 4.79 4.77 3.81 * 4.34 3.66 10.77 3.78 0 13.77 12.88 10.14 8.38 7.68 6.09 5.90 4.70 4.37 3.78 3.81 10.52 -1.5 * 6.28 * 6.28 12.45 12.45 * 9.38 8.20 * 7.23 5.99 * 5.44 4.66 * 4.07 * 4.07 9.94 -3 * 9.93 * 9.93 * 5.83 * 5.27 * 7.73 * 7.73 5.83 * 5.27 7.95

FEET

1,000 lb

A (ft)	10		A (ft) 10		10 15 20		0	25		30		35		MAX. REACH		
B (ft)		⇔	ľ	;	ľ			÷.		÷.		;]=-	ľ	÷.	A (ft)	
40													* 31.95	* 31.95	6.44	
35			* 21.19	* 21.19	* 18.69	* 18.69							* 15.10	* 15.10	19.79	
25					* 17.41	* 17.41	* 15.88	15.12					* 11.99	* 11.99	26.50	
25					* 17.30	* 17.30	* 15.55	15.27	13.85	11.17			* 10.72	10.38	30.66	
20					* 18.06	* 18.06	* 15.85	15.12	13.88	11.21			* 10.13	9.04	33.33	
15			* 23.97	* 23.97	* 19.49	* 19.49	* 16.50	14.77	13.73	11.06	10.66	8.54	* 9.93	8.33	34.90	
10			* 27.68	* 27.68	* 21.16	20.10	* 17.24	14.30	13.48	10.82	10.60	8.48	* 10.03	8.04	35.54	
5			* 30.37	29.71	* 22.36	19.18	17.34	13.82	13.22	10.57	10.51	8.39	* 9.57	8.06	35.34	
0			* 30.37	28.40	* 22.36	18.48	16.93	13.43	13.01	10.37	* 9.63	8.34	* 8.41	8.34	34.51	
-5	* 13.86	* 13.86	* 27.45	* 27.45	* 20.68	18.09	* 15.93	13.20	* 11.99	10.27			* 8.98	* 8.98	32.63	
-10			* 21.90	* 21.90	* 17.03	* 17.03	* 12.85	* 12.85					* 11.62	* 11.62	26.09	

1. Load point is the end of the heel to grapple pin.

2. Capacities marked with an asterisk (*) are limited by hydraulic capacities.

3. Lift capacities shown do not exceed 75% of minimum tipping loads or 87% of hydraulic capacities.

4. The least stable position is over the side.

5. Lift capacities apply only to the machine as originally manufactured and normally equipped by the manufacturer.

6. Lift capacities are in compliance with ISO 10567.



Machine Type	: Forestry Machine	
Track Width	: 3.6 m (11' 10")	
Boom	: 6.15 m (20' 2")	
Arm	: 3.66 m (12' 0")	
Heel Weight	: 478 kg (1,054 lb)	
Counterweight	: 4,400kg (9,700 lb)	
Shoe	: 700 mm (28")	
Cabin	: Oregon	
Ů	: Rating Over Front	
Ģ ≕	: Rating Over Side or 360 degree	
Unit	: 1,000 kg (1,000 lb)	DS1604549

METRIC	
--------	--

METRIC														1	,000 kg
🔨 A (m)	3	3	4	.5	6	5	7.	.5	ç)	10	.5	MA	X. REA	СН
B (m)		÷						÷				÷		¢.	A (m)
12													* 14.49	* 14.49	1.96
10.5			* 9.61	* 9.61	* 8.48	* 8.48							* 6.85	* 6.85	6.03
9					* 7.90	* 7.90	* 7.20	7.00					* 5.44	* 5.44	8.08
7.5					* 7.85	* 7.85	* 7.06	* 7.06	* 6.41	5.18			* 4.86	4.81	9.35
6					* 8.19	* 8.19	* 7.19	7.00	* 6.38	5.20			* 4.60	4.20	10.16
4.5			* 10.87	* 10.87	* 8.84	* 8.84	* 7.49	6.84	6.37	5.13	4.95	3.96	* 4.50	3.87	10.64
3			* 12.56	* 12.56	* 9.60	9.30	* 7.82	6.63	6.26	5.02	4.93	3.94	* 4.55	3.74	10.83
1.5			* 13.77	13.76	* 10.14	8.89	* 8.01	6.41	6.14	4.91	4.88	3.90	* 4.34	3.75	10.77
0			* 13.77	13.17	* 10.14	8.57	7.86	6.23	6.04	4.81	* 4.37	3.88	* 3.81	* 3.81	10.52
-1.5	* 6.28	* 6.28	* 12.45	* 12.45	* 9.38	8.39	* 7.23	6.13	* 5.44	4.77			* 4.07	* 4.07	9.94
-3			* 9.93	* 9.93	* 7.73	* 7.73	* 5.83	* 5.83					* 5.27	* 5.27	7.95

FEET

1,000 lb

A (ft)	10		15		20		25		30		35		MAX. REACH		
B (ft)		¢:]==	Ľ	;]=0	ľ	;;==		¢ ; ⊫=		ц.		;	Ľ	÷.	A (ft)
40													* 31.95	* 31.95	6.44
35			* 21.19	* 21.19	* 18.69	* 18.69							* 15.10	* 15.10	19.79
25					* 17.41	* 17.41	* 15.88	15.43					* 11.99	* 11.99	26.50
25					* 17.30	* 17.30	* 15.55	* 15.55	* 14.13	11.42			* 10.72	10.61	30.66
20					* 18.06	* 18.06	* 15.85	15.42	* 14.07	11.45			* 10.13	9.25	33.33
15			* 23.97	* 23.97	* 19.49	* 19.49	* 16.50	15.08	14.04	11.30	10.92	8.74	* 9.93	8.53	34.90
10			* 27.68	* 27.68	* 21.16	20.51	* 17.24	14.61	13.79	11.07	10.86	8.69	* 10.03	8.23	35.54
5			* 30.37	30.33	* 22.36	19.59	* 17.67	14.13	13.53	10.82	10.77	8.60	* 9.57	8.26	35.34
0			* 30.37	29.02	* 22.36	18.89	17.33	13.74	13.32	10.61	* 9.63	8.55	* 8.41	* 8.41	34.51
-5	* 13.86	* 13.86	* 27.45	* 27.45	* 20.68	18.50	* 15.93	13.51	* 11.99	10.51			* 8.98	* 8.98	32.63
-10			* 21.90	* 21.90	* 17.03	* 17.03	* 12.85	* 12.85					* 11.62	* 11.62	26.09

1. Load point is the end of the heel to grapple pin.

2. Capacities marked with an asterisk (*) are limited by hydraulic capacities.

З. Lift capacities shown do not exceed 75% of minimum tipping loads or 87% of hydraulic capacities.

4. The least stable position is over the side.

5. Lift capacities apply only to the machine as originally manufactured and normally equipped by the manufacturer.

6. Lift capacities are in compliance with ISO 10567.



Machine Type	: Road Builder
Track Width	: 3.6 m (11' 10")
Boom	: 5.7 m (19' 4")
Arm	: 2.9 m (9' 6")
Bucket	: Without Bucket
Counterweight	: 4,400kg (9,700 lb)
Shoe	: 700 mm (28")
Ů	: Rating Over Front
ф=	: Rating Over Side or 360 degree
Unit	: 1,000 kg (1,000 lb)

DS1604550

Figure 11

METRIC													1,000 kg
📃 🖊 (m)	1.5		3		4.5		6		7.5		MAX. REACH		
B (m)	ľ		Ľ		Ľ						Ľ		A (m)
7.5							* 5.34	* 5.34			* 4.21	* 4.21	6.41
6							* 5.46	* 5.46			* 3.96	* 3.96	7.45
4.5					* 7.13	* 7.13	* 6.05	* 6.05	* 5.52	* 5.52	* 3.94	* 3.94	8.07
3					* 8.98	* 8.98	* 6.89	* 6.89	* 5.88	* 5.88	* 4.06	* 4.06	8.38
1.5					* 10.49	* 10.49	* 7.69	* 7.69	* 6.26	* 6.26	* 4.36	* 4.36	8.41
0			* 6.72	* 6.72	* 11.12	* 11.12	* 8.14	* 8.14	* 6.45	6.33	* 4.90	* 4.90	8.16
-1.5	* 7.37	* 7.37	* 11.36	* 11.36	* 10.89	* 10.89	* 8.09	* 8.09	* 6.18	* 6.18	* 5.88	* 5.88	7.62
-3	* 12.19	* 12.19	* 13.57	* 13.57	* 9.79	* 9.79	* 7.24	* 7.24			* 6.12	* 6.12	6.70
-4			* 9.90	* 9.90	* 7.18	* 7.18					* 5.85	* 5.85	5.20

FEET

1,000 lb A (ft) 5 10 15 20 25 MAX. REACH ľ ľ ľ ľ ľ ľ A (ft) **__ _ __ __ __** B (ft) * 9.28 * 11.77 * 9.28 21.03 25 * 11.77 * 8.74 20 12.03 12.03 * 8.74 24.43 15.72 * 15.72 * 13.33 * 13.33 12.18 12.18 * 8.68 26.47 15 * 8.68 10 19.79 19.79 15.20 12.97 12.97 * 8.96 * 8.96 * 15.20 27.48 5 23.14 * 23.14 * 16.94 * 16.94 13.80 * 13.80 * 9.61 * 9.61 27.58 10.79 14.81 * 14.81 24.52 24.52 17.96 17.96 14.22 13.96 10.79 26.79 0 -5 * 16.25 * 16.25 * 25.05 25.05 24.02 * 24.02 * 17.83 * 17.83 13.63 13.63 12.96 12.96 24.99 -10 * 26.87 * 26.87 * 29.91 29.91 21.58 21.58 * 15.95 13.49 13.49 21.97 * 15.95 -15 * 15.83 12.89 * 21.83 * 21.83 15.83 12.89 17.06

1. Load point is the end of the arm.

2. Capacities marked with an asterisk (*) are limited by hydraulic capacities.

Lift capacities shown do not exceed 75% of minimum tipping loads or 87% of hydraulic capacities. 3.

4. The least stable position is over the side.

5. Lift capacities apply only to the machine as originally manufactured and normally equipped by the manufacturer.

6. Lift capacities are in compliance with ISO 10567.

APPROXIMATE WEIGHT OF WORKLOAD MATERIALS

Weights are approximations of estimated average volume and mass. Exposure to rain, snow or groundwater; settling or compaction because of overhead weight and chemical or industrial processing or changes because of thermal or chemical transformations could all increase value of weights listed in table.

Material	Density 1,200 kg/m ³ (2,000 lb/yd ³), or less	Density 1,500 kg/m ³ (2,500 lb/yd ³), or less	Density 1,800 kg/m ³ (3,000 lb/yd ³), or less	Density 2,100 kg/m ³ (3,500 lb/yd ³), or less	
Charcoal	401 kg/m ³ (695 lb/yd ³)	-	-	-	
Coke, blast furnace size	433 kg/m ³ (729 lb/yd ³)	-	-	-	
Coke, foundry size	449 kg/m ³ (756 lb/yd ³)	-	-	-	
Coal, bituminous slack, piled	801 kg/m ³ (1,350 lb/yd ³)	-	-	-	
Coal, bituminous r. of m., piled	881 kg/m³ (1,485 lb/yd³)	-	-	-	
Coal, anthracite	897 kg/m ³ (1,512 lb/yd ³)	-	-	-	
Clay, DRY, in broken lumps	1,009 kg/m ³ (1,701 lb/yd ³)	-	-	-	
Clay, DAMP, natural bed	-	-	1,746 kg/m ³ (2,943 lb/yd ³)	-	
Cement, portland, DRY granular	-	-	1,506 kg/m ³ (2,583 lb/yd ³)	-	
Cement, portland, DRY clinkers	-	1,362 kg/m ³ (2,295 lb/yd ³)	-	-	
Dolomite, crushed	-	-	1,522 kg/m ³ (2,565 lb/yd ³)	-	
Earth, loamy, DRY, loose	-	1,202 kg/m ³ (2,025 lb/yd ³)	-	-	
Earth, DRY, packed	-	-	1,522 kg/m ³ (2,565 lb/yd ³)	-	
Earth, WET, muddy	-	-	1,762 kg/m ³ (2,970 lb/yd ³)	-	
Gypsum, calcined, (heated, powder)	961 kg/m ³ (1,620 lb/yd ³)	-	-	-	

Material	Density 1,200 kg/m ³ (2,000 lb/yd ³), or less	Density 1,500 kg/m ³ (2,500 lb/yd ³), or less	Density 1,800 kg/m ³ (3,000 lb/yd ³), or less	Density 2,100 kg/m ³ (3,500 lb/yd ³), or less	
Gypsum, crushed to 3 inch size	-	-	1,522 kg/m ³ (2,565 lb/yd ³)	-	
Gravel, DRY, packed fragments	-	-	-	1,810 kg/m³ (3,051 lb/yd³)	
Gravel, WET, packed fragments	-	-	-	1,922 kg/m ³ (3,240 lb/yd ³)	
Limestone, graded above 2	-	1,282 kg/m ³ (2,160 lb/yd ³)	-	-	
Limestone, graded 1-1/2 or 2	-	1,362 kg/m ³ (2,295 lb/yd ³)	-	-	
Limestone, crushed	-	-	1,522 kg/m ³ (2,565 lb/yd ³)	-	
Limestone, fine	-	-	1,602 kg/m ³ (2,705 lb/yd ³)	-	
Phosphate, rock	-	1,282 kg/m ³ (2,160 lb/yd ³)	-	-	
Salt	929 kg/m ³ (1,566 lb/yd ³)	-	-	-	
Snow, light density	529 kg/m ³ (891 lb/yd ³)	-	-	-	
Sand, DRY, loose	-	-	1,522 kg/m ³ (2,565 lb/yd ³)	-	
Sand, WET, packed	-	-	-	1,922 kg/m ³ (3,240 lb/yd ³)	
Shale, broken	-	1,362 kg/m ³ (2,295 lb/yd ³)	-	-	
Sulfur, broken	529 kg/m ³ (891 lb/yd ³)	-	-	-	

INDEX

Numerics

1,000 Hour / 6 Month Service 4-57 10 Hour / Daily Service 4-26 12,000 Hour / 6 Year Service 4-78 2,000 Hour / Yearly Service 4-68 250 Hour / Monthly Service 4-68 4,000 Hour / Biennial Service 4-74, 4-75 50 Hour / Weekly Service 4-39 500 Hour / 3 Month Service 4-46

Α

Access Method 2-52 Accumulator 1-60 Active DeSOx 3-29 Adjust Valve Clearance 4-73 AEM Safety Manual (North America Only) 0-6 After Storage 3-56 Air Conditioner Filter 4-48 Air Intake System 4-35 Outer Filter of Air Cleaner 4-52 Replace Outer Air Cleaner Filter 4-68 Air-conditioning Inner Filter 4-64 Air-conditioning Outer Filter 4-62 Alternator and Starter 4-73 Antifreeze Concentration Tables 4-87 Antivibration Shock Mounts 4-73 Arm and Heel Joint Pins 4-39 Asbestos Information 1-74 Attachment 1-45 Auto Idle Mode 3-32 Auto Idle Selection 2-86 Auto Idle Selector Button 2-45 Avoid Mixing Lubricants 4-2

В

Batteries 4-45 Battery 1-63, 4-80 Electrolyte Level 4-81 Terminals 4-81 Battery Disconnection 1-9 Battery Explosion 1-9 Battery Hazard Prevention 1-63 Before Engine Starting 1-33 Before Storage 3-55 BHL Control Pattern (US Only) 1-12 Boost Mode 3-33 Boost Starting or Charging Engine Batteries 1-38 Booster Cable 3-12 Burn Prevention 1-54

С

Cabin Light 2-93 Cabin Storage Compartments 2-105 California Proposition 65 1-17 Camera Mode Selector/Escape (ESC) Button 2-23 Ceiling Cover (STD Cabin Only) 2-100 Ceiling Window Visor 2-106 Change DEF (AdBlue) Filter 4-75 Change Hydraulic Oil Tank Breather Filter 4-57 Change of Water Separator and Pre Fuel Filter (Fuel Prefilter) 4-54 Change Wiper Blade and Front Cabin Light 4-4 Check Air Conditioner Hoses 4-79 Check and Clean Air-conditioning Inner Filter 4-49 Check Belt Tension 4-79 Check Charging State 4-81 Check Condenser 4-79 Check Control Panel 4-79 Check Drained Oil and Used Filter 4-1 Check Water Separator and Pre Fuel Filter (Fuel Prefilter) and Drain Water As Required 4-31 Checks After Inspection and Maintenance Works 4-3 Checks and Maintenance After Stopping 3-17 Checks Before Starting Engine 3-4 Circuit Breaker (30 A) 2-94 Circuit Breaker (80 A) 2-93 Cleaning 1-35, 1-52 Clock 2-32 Closing Ceiling Cover 2-100 Cold Weather Hydraulic System Warm-up 3-14 Communication Indicator 2-30 Component Locations 2-2 Compressed Air 1-60 Coolant and Water for Dilution 4-12 Cooling System Clean Radiator, Oil Cooler and Air Conditioner Condenser Coil 4-51 Engine 4-85

Engine Coolant Temperature Warning 2-34 Oil Cooler Dust Net 4-33 Radiator Coolant 4-70 Refill Cooling System 4-34 Correction of Machine Problems 1-21 Counterweight 5-2 Cracks and Faulty Welds 4-36 Crush Hazard 1-10 Crushing and Cutting 1-21 Cup Holder 2-107 Cycle Time Tests 4-73

D

Decrease Volume 2-16 DEF (AdBlue) 4-10 DEF (AdBlue) Tank 4-30 Delete Warning Pop-up 2-50 Digital Clock 2-32 **Disassembling Precautions 1-52** Display Monitor 2-20, 2-27 Display Selector Button 2-43 Display Warning Symbols 2-32 Disposal of Hazardous Materials 1-75 Do not Drop Things Inside Machine 4-2 Document Delivery Hole (Oregon Cabin Only) 2-108 Door Side Latch (STD Cabin Only) 2-103 HYUNDAI Genuine Lubricants 4-1 HYUNDAI Genuine Replacement Parts 4-1 Down Arrow Button 2-42 Drop-off or Edge 1-65 During Storage 3-56 Dusty Work Site 4-2

Ε

ECO Gauge 2-31 Economy Mode Selection 2-86 Electric Welding Attention 1-15 Electrical System 4-80 Electrical System and Electrical Shock 1-27 Electrical System Maintenance 4-14 Emergency Exit 1-11 Emergency Exit from Operator's Station 1-29 Emergency Exit Glass Breaking Tool (STD Cabin Only) 2-99 Emission Control System 3-25 Enable 2-85 Engine 3-17 Adjust Valve Clearance 4-73 Check and Adjust Engine 4-67 Check Warning 2-34 Coolant Temperature Gauge 2-29 Coolant Temperature Warning 2-34 Cover 2-110

DEF Level Gauge 2-28 Fan and Alternator Belt Tension 4-44 Head Bolt Torques 4-73 Oil and Filter 4-47 Oil Level 4-26 Oil Pressure Warning 2-33 Speed 2-30 Speed Control Dial 2-14 Start 3-6 Start and Stop 3-2 Stopping 3-16 Engine Coolant Heater (Optional) 3-9 Engine Oil 4-11 Engine Stop 1-46 Entanglement in Rotating Parts 1-8 Enter Checking Mode 2-49 Entering/Leaving/Climbing the Machine 4-7 Entertainment 2-65 Environment and Circumstances 1-65 Equipment Lowering with Engine Stopped 1-45, 3-52 Escape Method 2-52 Escaping from Mud 3-40 Exhaust Ventilation 1-73

F

Fall Hazard 1-11 Falling Object 1-13 Fan Belt 4-43 Fan Switch 2-26 Filters 4-13 Fire and Explosion Prevention 1-23, 1-53 Fire Extinguisher and First-aid Kit (Emergency Medical Kit) 1-26 Fluid Capacities 4-20 Flying Debris or Objects 1-10 Flying or Falling Objects 1-20 Forestry Machine Rated Lift Capacity Tables 6-11 Fresh and Clean Lubricants 4-1 Front Bottom Window 2-102 End Attachments 4-45 Front Control 1-17 Front Window Visor 2-106 Fuel 4-8 Change Fuel Cap Filter 4-66 Gauge 2-28 Level 4-29 Main Fuel Filter 4-55 System 4-55 Transfer Pump (Optional) 4-89 Tank Drain Valve 4-43 Transfer Pump (Optional) 4-89 Fuel Strainer 4-1

Function Buttons 2-42 Functional Check 2-27 Fuse Boxes 2-94, 4-82 Fuses 4-82 Identification 4-83

G

Gauge Panel Configuration 2-72 Gauges DEF (AdBlue) Level Gauge 2-28 Fuel Gauge 2-28 Hydraulic Oil Temperature 2-29 Multifunction Gauge 2-30 General 1-18 General Hazard 1-7 General Venting 4-98 Go to Warning Display 2-49 Grease 4-11 Grease Boom, Arm and Front Attachment Pins (for first 100 hours) 4-26

Н

Handling of Accumulator 4-92 Handling Oil, Fuel, DEF (AdBlue), Coolant 4-8 Head Bolt Torques 4-73 Heater and Air Conditioner 2-87 Additional Operating Instruction 2-91 Control Panel 2-12, 2-88 Location of Controls and Vents 2-87 Memory Function of Used Mode 2-91 Refrigerant 4-65 System 4-79 Heating Operator's Seat 2-98 High-pressure Lines, Tubes and Hoses 1-62 High-voltage Cables 1-66 Hose Clamps 4-45 Hose In-service Lifetime Limit (European Standard ISO 8331 and EN982 (CEN)) 4-78 Hot Coolant and Oils- Burn Prevention 1-22 Hot Pressurized Fluid 1-8 Hot Surface 1-11 Hydraulic Breaker 1-15 Hydraulic Hose Installation 4-3 Hydraulic Oil Check (Optional) 1-14 Hydraulic System General Venting 4-98 Hydraulic Cylinders 4-97 Hydraulic Oil Exchange 4-71 Hydraulic Oil Return Filter 4-45, 4-58 Hydraulic Oil Tank 4-27 Hydraulic Oil Temperature Gauge 2-29 Leaks in the Hydraulic System 4-26 Main System Pump 4-97

Oil Exchange 4-71 Swing Motor 4-98 Travel Motor 4-98 Warm-up 3-13 Hydraulic System - Air Bleeding 4-3

I

Increase Volume 2-16 Indicator Communication Indicator 2-30 Indicator Lights Charge Warning 2-33 Coolant Temperature Warning 2-34 Engine Check Warning 2-34 Engine Oil Pressure Warning 2-33 Information and Location for Safety Decals 1-4 Inspection, Maintenance and Adjustment 4-1 Installation 5-4 ISO Control Pattern 1-12

J

Jack Assembly 2-24

Κ

Keep Bystanders Away 1-8 Know Your Machine 1-18

L

Launch Menu 2-46 Leaks in the Fuel System 4-28 Leaks in the Hydraulic System 4-26 Levers Adjusting Reclining 2-96 Adjusting the Seat Forward / Backward 2-95 Safety Lever 2-21 Lift/Tie down 1-15 Lifting and Logging 1-42 Lifting Machine 5-8 Lights Cabin 2-93 Loading and Unloading 1-31 Lock Inspection Covers 1-59 Locking Inspection Covers 4-2 Locking the Pedal 3-23 Long Term Storage 3-55 Loose or Soft Ground 1-66 Lubrication 4-15

Μ

Machine Condition 1-33 Machine Configuration 2-58 Machine Setup Position for Maintenance 4-5 Machine With a Boom Lock Valve 3-54 Machine Without a Boom Lock Valve 3-52 Magnetic Clutch 4-79 Maintenance Handling Access 4-7 Maintenance in Special Conditions 4-99 Maintenance Information 4-1 Maintenance Intervals 4-24 Manual (Forced) DeSOx 3-30 Mirror (Oregon Cabin Only) 2-108 Miscellaneous Access Doors 2-109 Miscellaneous Electrical Devices 2-93 Mode Selection 3-31 Mode Selector Buttons 2-44 Mounting/Dismounting 1-34 Multifunction Gauge 2-30 Multimedia Button 2-23

Ν

Nuts and Bolts 4-45

0

Obey State and Local Over-the-Road Regulations 1-31 Oil 4-8 Oil Cooler Dust Net 4-33 Oil Level of Travel Reducer 4-56 Opening Ceiling Cover 2-100 Operate a New Forestry Machine 3-1 Operating 3-23 Controls 2-1 Instructions 3-25 Precautions 3-37 Operation 3-1 Operation at High Altitudes 1-72, 3-51 Operation During Electrical Storms 1-73, 3-51 Operation In Dusty and Sandy Areas 1-71, 3-50 Operation In Extreme Cold 1-69, 3-47 Operation in Extreme Conditions 1-69 Operation in Extreme Heat 1-70, 3-48 Operation in Rainy or Humid Conditions 1-72. 3-50 Operation in Saltwater Areas 1-72, 3-51 **Operation Indication Examples 2-85** Operation of All Controls and Linkages 4-38 Operation of All Exterior Lights 4-38 Operation of All Switches 4-36 Operation on Slopes 1-43 **Operation Under Abnormal Conditions 3-47 Operational Controls and Panels 2-9** Operational Hour Meter Reading 4-1 **Operator Station 1-35** Operator's Area 2-6 Outer Filter of Air Cleaner 4-52 Overall Dimensions 6-2

Ρ

Panels Air Conditioner Control Panel 2-12 Audio Control 2-15 Heater and Air Conditioner 2-87 Wiper Control 2-17 Parking Forestry Machine 3-41 Parking Machine 1-46 Password Activated 2-28 Personal Protective Equipment (PPE) 1-21 Photo Sensor 2-20 Pilot Cutoff Switch 2-93 Pilot Filter 4-45, 4-59 Pins and Bushings 4-45 Plug Heater (Optional) 3-11 Poor Visibility 1-65 Power Boost Selection 2-86 Power Button 2-16 Power Mode 3-31 Power Mode Selection 2-85 Power Mode Selector Button 2-22, 2-44 Power Plus Mode Selection 2-85 Preservation/Storing Machine 1-47 Pressurized Fluids 1-19 Pressurized Gas and Fluid 1-10 Proper Tools and Clothing 1-52 Proper Work Tools and Attachments 1-19 Protecting Cabin from Flying or Falling Objects (Optional) 1-28

R

Reaction at Low Reductant Level 3-25 Reaction to Failure in SCR System 2-37, 3-26 Read Warning Message 2-50 Rear View Camera for Proper Operation (If Equipped) 4-36 Recommend Fuel, Coolant, and Lubricant 4-15 Refill Cooling System 4-34 Regulation 8.35(2) of the Mines Safety and Inspection Regulations (1995) 1-30 Removal 5-3 Roll Over Protective Structure (ROPS), Falling Object protective Structure (FOPS) 1-67 ROPS Warning (Optional) 1-13 **ROPS/FOPS** Certification 1-68 Rotating Fan 1-9 Rotating Operation 3-46 Rubber and Plastics 1-56 Rubber That Contains Fluorides 1-55

S

Safe Operation is Operator's Responsibility 1-18 Safety 1-1 Safety Decals 1-2 Safety Decals With Text 1-2 Safety Decals Without Text (No-Text) 1-3 Safety Lever 3-17 Safety Precautions 4-4 Scan Button 2-16 Seat 2-95 Seat Adjustment Adjusting height of Seat and Depth of Cushion 2-95Adjusting Height/Angle of Armrest 2-98 Adjusting Reclining 2-96 Adjusting the Seat Forward / Backward 2-95 Adjustment of Lumbar Support 2-96 Headrest 2-96 Left and Right Control Stand Height Adjustment 2-97 Left and Right Control Stand Location 2-97 Seat Belt 1-36, 2-96, 4-36 Selector Button 2-43 Shear Operation (Optional) 3-43 Shutdown Engine Stop 3-16 Parking Forestry Machine 3-41 Side Door 2-109 Silica Dust Information 1-74 Smart Power Control Switch (Road Builder Only) 2-13 Specification 6-1 Standard Mode Selection 2-85 Standard Specification 6-1 Start Engine, Check Starting Ability, and Observe Exhaust Color at Start-up and at Normal Operating Temperature. Listen for Any Abnormal Sounds. 4-38 Starting Engine 1-39 Start-up Cold Weather Hydraulic System Warm-up 3-14 Engine Start 3-6 Hydraulic System Warm-up 3-13 Inspection Before Starting Engine 3-2 Operational Checks Before Starting Engine 3-5 Starting Engine Using a Booster Cable 3-12 Stereo 2-92 Straight Travel Pedal (Optional) 3-23 Structural Damage 4-73 Suction Strainer 4-71 Sun Visor 2-106 Sunglasses Case (STD Cabin Only) 2-105 Supports and Blocking for Work Equipment 1-61 Swing Bearing 4-43 Gear and Pinion 4-46 Motor 4-98 Reduction Gear 4-32, 4-56, 4-57, 4-61

Swinging or Traveling 1-40 Switch Operation Indication 2-85 Switches 2-Pump Flow Control Switch 2-15 Automatic Travel Speed Control 3-18 Auxiliary Mode Switch 2-21 Booster Button 2-19 Cabin Work Light Switch (Optional) 2-15 Cigarette Lighter 2-13 Constant Speed Button 2-17 Down Arrow Button 2-42 Engine Speed Control 3-25 Engine Speed Control Dial 2-14 Horn Button 2-19 Hour Meter 2-21 Intermittent Speed Button 2-17 Light Switch 2-14 Micro Phone 2-24 One Touch Deceleration Button 2-22 Pilot Cutoff Switch 2-93 Power Socket 2-13 Power Socket for 12 Volt 2-18 Quick Coupler Switch (Road Builder Only) 2-18 Rotating Switch 2-19 Selector Switch Control Panel 2-22 Shear Switch 2-20 Starter Switch 2-12 Travel Speed Selector Switch 2-14 Travel/Swing Alarm (Optional) 2-18 Washer Button 2-17 Symbol Description 2-55 Symbols Air Cleaner Clogged Warning 2-35 DEF (AdBlue) Low Level Warning symbol - EPA 2-36 Fuel Shortage Warning 2-35 Hydraulic Oil Overheat Warning 2-34 Quick Coupler Release System Activated Warning (Road Builder Only) 2-36 Return Filter Clogged Warning 2-35 SCR System Warning Light 2-37 Water In Fuel Warning 2-35 Symbols for "Lubrication and service chart" 4-16

Т

Table of Recommended Lubricants 4-21 Tie down 1-15 Toggle Switch 2-22 Towing 1-44 Towing Procedure 3-42 Track Assemblies 4-43 Track on One Side Stuck 3-40 Track Tension 4-93, 4-95 Track Tension Adjustments 1-61 Tracks on Both Sides Stuck 3-40 Transportation 5-1 Transporting Machine 1-32 Travel 3-18 Control Lever Operation 3-19 Instructions 3-20 Reduction Gear 4-56, 4-60 Speed Selector Switch 2-14 Trip Meter 2-31 Two-way Valve Operation (Optional) 3-45

U

Ultra Low Sulfur Diesel Fuell (Optional) 1-12 Unloading and Loading 5-2 Up Arrow Button 2-42 Use of Lighting 1-52 User Menu 2-52 User Menu - Access and Escape Methods 2-52

V

Ventilation for Enclosed Area 1-73 Venting and Priming Hydraulic System 4-97 General Venting 4-98 Hydraulic Cylinders 4-97 Main System Pump 4-97 Swing Motor 4-98 Visibility Information 1-37

W

Walk around Checks 3-2 Warning for Counterweight and Front Attachment Removal 1-58, 5-2 Warning Light 2-41 Warning Pop-up Window 2-49 Warning Pop-up Windows List 2-51 Warning Tag 1-51 Warning Tag - "Do Not Operate" 1-8 Washer Switch 2-26 Weight of Workload Materials 6-16 Welding Instructions 4-2 Welding Repairs 1-57 Window Washer Liquid 4-34 Windows Front 2-101 Front Bottom 2-102 Front Upper 2-101 Sun Visor 2-106 Windshield Washer Fluid 4-1 Wiper Switch 2-26 Work Levers (Joysticks) (BHL Pattern) 3-36 Work Levers (Joysticks) (ISO Pattern) 3-34 Work Mode 3-32 Work Mode Selector Button 2-23, 2-44 Work Site 1-33 Work Site Areas Requiring Extra Caution 1-65 Work Site Rules 1-38 Working in Contaminated Environment 1-68 Working in Water 1-68, 3-40 Working on Machine 1-59 Working Range 6-8

Y

Your Machine Serial Numbers 0-4