1. CANOPY / CAB DEVICES

1) The ergonomically designed console box and suspension type seat provide the operator with comfort.

2) ELECTRONIC MONITOR SYSTEM

- (1) The centralized electronic monitor system allows the status and conditions of the machine to be monitored at a glance.
- (2) It is equipped with a safety warning system for early detection of machine malfunction.

CAB TYPE



CANOPY TYPE



2. CLUSTER

1) STRUCTURE

The cluster consists of LCD and switches as shown below. The LCD is to warn the operator in case of abnormal machine operation or conditions for the appropriate operation and inspection. The LCD is to display for monitoring, manage and display set with the switches.

- * The cluster installed on this machine does not entirely guarantee the condition of the machine. Daily inspection should be performed according to chapter 6, Maintenance.
- * When the cluster provides a warning, immediately check the problem and perform the required action.



2) GAUGES AND DISPLAYS

(1) Hour meter



- ① This meter shows the total operation hours of the machine.
- ② Always ensure the operating condition of the meter during the machine operation.

Inspect and service the machine based on hours as indicated in chapter 6, maintenance.

(2) Fuel gauge



- $\ensuremath{\textcircled{}}$ This gauge indicates the amount of fuel in the fuel tank.
- 2 Fill the fuel when in the red range or warning lamp \mathbf{R} ON.
- If the gauge illuminates the red range or warning lamp ON even though the machine is in the normal condition range, check the electric device as this can be caused by poor connection of sensor.

(3) Engine coolant temperature gauge



- $\ensuremath{\textcircled{}}$ This indicates the temperature of coolant.
 - · Red range : Above 105°C (221°F)
- ⁽²⁾ When the red range pointed or warning lamp \bigoplus ON, engine do not abruptly stop but run it at medium speed to allow it to cool gradually, then stop it.
 - Check the radiator and engine.
- If the engine is stopped without cooled down running, the temperature of engine parts will rise suddenly, this could cause severe engine trouble.
- If the gauge indicates the red range or warning lamp ON in red even though the machine is in the normal condition range, check the electric device as this can be caused by poor connection of sensor.

(4) Engine rpm gauge



17AZ3CD15

1 This gauge indicates the engine speed.

3) WARNING LAMPS



25AZ3CD20

(1) Fuel low level warning lamp



- 1 This lamp lights up and buzzer sounds when the level of fuel is below 9 ℓ (2.4 U.S. gal).
- 2 Fill the fuel immediately when the lamp ON.

(2) Engine coolant temperature warning lamp



 This lamp lights up and buzzer sounds when the temperature of coolant is over the normal temperature 105°C (221°F).
 Check the cooling system when the lamp ON.

(3) Engine oil pressure low warning lamp



- ① This lamp lights up and buzzer sounds after starting the engine because of the low oil pressure.
- ② If the lamp ON during engine operation, shut OFF engine immediately. Check oil level.

(4) Battery low warning lamp



- ① This lamp lights up and buzzer sounds when the starting switch is ON, it is turned OFF after starting the engine.
- ② Check the battery charging circuit when this lamp does not turn off, or turns on or blinks during engine operation.

(5) Emergency warning lamp



- $(\ensuremath{\mathbb D}$ This lamp pops up and the buzzer sounds when each of the below warnings occurs.
- Engine coolant temperature high warning lamp ON
- * The pop-up warning lamp moves to the original position and lights up when the buzzer stop switch is pushed or pop-up is touched. The buzzer will stop.
 - This is same as following warning lamps.
- ② When this warning lamp lights up, machine must be checked and serviced immediately.

(6) Overload warning lamp



- ① When the machine is overloaded, this lamp blinks and buzzer sounds.
- 2 Reduce the machine load.

4) PILOT LAMP



25AZ3CD30

(1) Travel mode pilot lamp

No	Mode	Pilot lamp	Selected mode
1	Travel mode	*	Low speed traveling High speed traveling

(2) Preheat pilot lamp



(3) Maintenance pilot lamp



- ① Turning the start key switch to the ON position starts preheating in cold weather.
- ② Start the engine after this lamp goes OFF.
- * Refer to page 4-4 for details.
- ① This lamp lights up when consumable parts are in need of replacement. It means that the change or replacement interval of parts is 30 hours from the required change interval.
- ② Check the message in maintenance information of main menu. Also, this lamp lights up for 3 minutes when the start switch is switched to the ON position.

(4) Manual safety lock pilot lamp



- ① This lamp lights up when the safety lever is set to the LOCK position.
- * Refer to page 3-29 for the safety lever.

5) SWITCHES

Sound short beep when each button is pressed.

(1) Menu button



- ① Go into the menu screen.
- % Please refer to page 3-11.

(2) Left/up/(+)



- 1 Move left in sub menu.
- 2 Move up in menu list
- ③ Increase input value in menu

(3) Right/down/(-) button



- 1 Move right in sub menu.
- $\ensuremath{\textcircled{}}$ Move down in menu list
- 3 Decrease input value in menu

(4) Enter and buzzer stop button



- ① Select menu (enter).
- 2 Stop buzzer sound when press this button immediately.

(5) ESC



1 Escape in the menu.

6) MAIN MENU



* Please refer to the switches, page 3-10 for selection and change of menus and input values.

 $\ensuremath{\,\times\,}$ In the operation screen, press the menu button to access the sub-menu screen.

(1) Structure

No	Main menu	Sub menu	Description
1	Monitoring Monitoring 17AZ3CD103	Active fault Logged fault Delete logged fault Analog input Switch status Output status	Active fault Logged fault Delete logged fault Coolant temp., Battery volt, Engine speed, Overload pressure Safety lever, Quick coupler 1, Quick coupler 2, Travel speed Quick coupler solenoid, Start limit relay, Buzzer
2	Management Manage 35AZ3CD104	Operating hours Maintenance ESL mode Change password Warning setting Machine information A/S phone number	A day's operating hours Elapse, Interval, Replacement etc. Disabled, Enable (Always), Enable (Interval) Change password Overload on/off Machine, Engine, Cluster A/S phone number, A/S phone number change
3	Display set	Clock adjust Brightness Unit Language	12 hours, 24 hours Manual, Auto Temperature Korean, English, Turkish, etc (total 12 languages)

(2) Monitoring

1 Active fault



- The active fault of the machine and engine can be checked by this menu.



2 Logged fault





- The logged fault of the machine and engine can be checked by this menu.
- This menu can be used only HCE service man.



Logged Fault

17AZ3CD116

>

③ Delete logged fault



I 0.4 h	11:02 AM
C Monitori	ng
Active Fault	>
Logged Fault	>
Delete Logged Fau	lt >
Analog Input	>
Switch Status	>
Output Status	>
	17473CD117

- The logged fault of the machine and engine can be deleted by this menu.

(It is possible under the engine stop conditions)



1 368,1 h

Enter

10:21

Service Password





(4) Analog input



- The machine status such as the engine speed, coolant temperature, battery voltage can be checked by this menu.

$\ensuremath{\textcircled{}}$ 5 Switch status



- The switch input status can be checked by this menu.



- The output status can be confirmed by this menu.

(3) Manage

① Operating hours



- You can check the operating hours by this menu.
- 2 Maintenance

0.4 h	11:02 AM		2 1.7 b		10:07 AM		X 366.9 h		05:24	PM
			\$	Management			Ð	Maintenance		
C	2		Operatin	ng Hours	>		Engine	01	0/250	>
Monit	oring		Maintena	ance	>		Engine (Oil Filter		>
Ę	}	→	ESL Mod	le	>	-	Fuel Filt	ter Element	366/400	>
Manag	ement		Change	Password	>		Air Clea	ner Element	366/500	>
Disp	blay		Warning	Setting	>		Radiato	r Coolant	366/6000	>
				• •			Travel F	Reduction Gear Oil	366/1000	>
	17AZ3CD107			17AZ	3CD132A			17	AZ3CD	133

- Elapse : Maintenance elapsed time.
- Interval : The change intervals can be changed in hour increments of 50.
- History-Hourmeter : Display elapsed time.
- Replacement : The elapsed time will be reset to zero (0).
- * Refer to section, Maintenance chart for further information of maintenance interval.





Y

17AZ3CD136

No

History - Hourmeter

3 ESL mode



ESL mode setting

- ESL mode is designed to be a theft deterrent or will prevent the unauthorized operation of the machine.
- When you Enable the ESL mode, the password will be required when the starting switch is turned to the on position.
- Machine security
 - Disable : ESL function is disabled and password is not required to start engine.
 - Enable (Always) : The password is required whenever the operator starts engine.
 - Enable (Interval) : The password is required when the operator starts engine first. But the operator can restart the engine within the interval time without inputting the password. The interval time can be set to a maximum 2 days.

* ESL : Engine Starting Limit



(4) Change password



- The password is 5~10 digits.
- Before first use, please set user password and owner password in advance for machine security.



17AZ3CD145



5 Warning setting

0.4 h	11:02 AM	2.5h	09:57 AM	2.5h
		ැලි: Management		🗂 Warnir
\bigcirc		Operating Hours	>	Overload C
Monitoring	:	Maintenance	>	
තු	→	ESL Mode	> -	►
Managemer	nt	Change Password	>	
 Display		Warning Setting	>	
		• •		ок
1	7AZ3CD107	25/	Z3CD100	

- You can set the warning items by this menu (optional menu).



6 Machine information

- This can confirm the identification of the machine, engine and cluster.



⑦ A/S phone number

- The A/S phone number can be checked and changed.

3-19

(4) Display set

1 Clock adjust

X 0.4n	11:02 AM	🗷 0.4h		11:03 AM	367.0)	0	5:28 PM
	Feddina 72781724		Display		÷	Clock Adjust	
Q		Clock	Adjust	>		2hours 🗌 24	nours
Monito	ring	Bright	ness	>		17:28	
63	3			>	→		
Manage	ment	Langua	ige	>			
<u>[</u>							
Displ	lay						
						OK Cano	a
	17AZ3CD108		17	AZ3CD160		17AZ	3CD161

- Set the time (12 hours or 24 hours)

2 Brightness



- Manual : Manual setting for LCD brightness.
- Automatic : Automatic control of LCD brightness as set level of Day/Night.
- Setting day time : Set the time for daylight.

(in figure, black area represents night time while orange shows day time)

3 Unit

I 0.4n	11:02 AM	X 0,4h	11:03 AM	Ξ 367,0 h	05:29 PM
		_ Display		Ð	Unit
0		Clock Adjust	>	Temperatu	re
Monito	ring	Brightness	>	№ °C	□ °F
63	} ->	Unit	> ->	-	
Manage	ment	Language	>		
Displ) ay				
				OK	Cancel
	17AZ3CD108	17	7AZ3CD169		17AZ3CD170

- Temperature : $^{\circ}C \leftrightarrow ^{\circ}F$

4 Language



- User can select preferable language and all displays are changed to the selected language (한국 어, English, Turkish, etc ; total 12 languages).

3. SWITCHES

ON

OFF 35AZ3CD40



- · ⊘ (START) : Use when starting the engine. Release key immediately after starting.
- ※ Key must be in the ON position with engine running to maintain electrical and hydraulic function and prevent serious machine damage.

2) WORK LIGHT SWITCH



- (1) This switch use to operates the switch illumination lamp and work light by two step.
 - · First step : Light switch illumination lamp comes ON.
 - · Second step : Work light comes ON.

3) TRAVEL SPEED CONTROL SWITCH



- (1) This switch is to control the travel speed which is changed to high speed by pressing the switch and low speed by pressing it again.
- (2) The travel speed pilot lamp lights ON on the cluster.

4) TRAVEL ALARM SWITCH (option)



- (1) This switch is the signal to alarm surroundings when the machine travels to forward and backward.
- (2) On pressing this switch, the alarm operates only when the machine is traveling.

5) QUICK COUPLER SWITCH (option)



- (1) This switch is used to engage or disengage the moving hook on quick coupler.
- * Refer to the page 8-10 for details.

6) EMERGENCY STOP SWITCH



- (1) This switch is used to emergency stop the engine.
- (2) When the users control the emergency switch, the switch should not be maintained on "EMERGENCY STOP" position more than 10 seconds in order to avoid its failure.
- (3) The users remind that it should be turned back to original "RELEASE" position within 10 seconds.
- * Be sure to keep the emergency switch on the release position when restart the engine.

7) BEACON SWITCH (option)



- (1) This switch turns ON the rotary light on the cab.
- (2) The below indicator lamp is turned ON when operation this switch.

8) HEATER SWITCH



- (1) This switch use to operates the heater by two step.
 - · First step : Low fan speed
 - · Second step : High fan speed

9) WIPER AND WASHER SWITCH



- (1) The switch use to operates the wiper and washer by two step.
 - · First step : The wiper operates.
 - Second step : The washer liquid is sprayed and the wiper is operated only while pressing. If release the switch, return to the first step position.

10) MASTER SWITCH



- (1) This switch is used to shut off the entire electrical system.
 - I : The battery remains connected to the electrical system.
 - O : The battery is disconnected to the electrical system.
- * Never turn the master switch to O (OFF) with the engine running. It could result in engine and electrical system damage.

11) LH RCV LEVER SWITCH

(1) Without proportional type



- (1) The switches on the LH RCV lever are function as below.
 - ① : None
 - 2) : None

(2) With proportional type (option)



(1) The switches on the LH RCV lever are function as below. : CW rotating switch

When this switch is pressed, the clockwise rotating will operate.

2 : CCW rotating switch

When this switch is pressed, the ounterclockwise rotating will operate.

- ③ : None
- ④ : None
- 5 : None

12) RH RCV LEVER SWITCH

(1) Without proportional type



- (1) The switches on the RH RCV lever are function as below.
 - 1 Horn switch

When this switch is pressed, the horn will sound.

- ② Quick coupler switch This switch is used to engage or disengage the moving hook on quick coupler.
- * Refer to the page 8-10.

(2) With proportional type (option)



- (1) The switches on the RH RCV lever are function as below.
 - ① 2-way clamp switch

When this switch is pressed, the clamping of the shear or thumb will operate.

2 2-way release switch

When this switch is pressed, the releasing of the shear or thumb will operate.

③ Quick coupler switch

This switch is used to engage or disengage the moving hook on quick coupler.

- * Refer to the page 8-10.
- (4) Horn switch

When this switch is pressed, the horn will sound.

(5) Breaker switch

When this switch is pressed, the breaker will only operate when the breaker selection switch on the switch panel is selected.

4. LEVERS AND PEDALS



25AZ3CD05

1) LH CONTROL LEVER



- (1) This joystick is used to control the swing and the arm.
- (2) Refer to operation of working device in chapter 4 for details.
- (3) The rotating switch are installed on the control lever (option).
- * Refer to page 3-26 for details of the switch function.

2) RH CONTROL LEVER



- (1) This joystick is used to control the boom and the bucket.
- (2) Refer to operation of working device in chapter 4 for details.
- (3) The breaker switch, horn switch, quick coupler switch and 2-way switch are installed on the control lever. (option)
- * Refer to page 3-27 for details of the switch function.

3) SAFETY LEVER



4) TRAVEL LEVER



5) TRAVEL PEDAL



- (1) All control levers are disabled from operation by locating the lever to lock position as shown.
- * Be sure to raise the lever to LOCK position when leaving from operator's seat.
- (2) By pushing lever to UNLOCK position, machine is operational.
- (1) This lever is used to move the machine forward or backward.
- (2) If left side lever is pushed or pulled, left track will move. If right side lever is pushed or pulled, right track will move.
- (3) Refer to traveling of machine in chapter 4 for details.

- (1) This pedal is used to move the machine forward or backward.
- (2) If left side pedal is pressed, left track will move. If right side pedal is pressed, right track will move.
- (3) Refer to traveling of machine in chapter 4 for details.

6) ENGINE SPEED CONTROL LEVER



- (1) This lever is used to increase or decrease the rotation speed of engine.
- (2) Move the lever backward to increase engine RPM. Move the lever forward to decrease engine RPM.
- (3) When stopping the engine, move the engine speed control lever forward completely and turn key OFF.

7) DOZER CONTROL LEVER



- (1) This lever is used to operate the dozer blade or crawler.
- (2) The lever is pushed forward, the dozer blade will be going down.
- (3) The lever is pulled back, the dozer blade will be going up.

8) BOOM SWING PEDAL



- (1) This pedal is used to swing the boom to the right or left direction.
- (2) Move the lock cover to unlock position by foot.
- (3) The pedal is pressed to left side, boom will swing to the left direction. The pedal is pressed to right side, boom will swing to the right direction.

9) DOUBLE ACTING SWITCH AND PEDAL (option)



- (1) This switch or pedal is used to operate the breaker or shear if equipped.
- * This switch applies to single or double action hydraulic attachment circuit.
- * This pedal applies to single or double action hydraulic attachment circuit.
- * Refer to page 4-27.

5. HEATER

Heater is equipped for pleasant operation against outside temperature.



25AZ3CD06

1) OUTLET CONTROL LOUVER



(1) The direction of air can be controlled. It can be closed or opened.

6. OTHERS



Radio and USB player (option)

25AZ3CD07

1) 12V SOCKET (option)



(1) Utilize the power of 12V as your need and do not exceed power of 12V, 120W.

2) SEAT

The seat is adjustable to fit the contours of the operator's body. It will reduce operator fatigue due to long work hours and enhance work efficiency.





B27793CD16

(1) For/aft adjustment (A)

The seat can be positioned over a range 52 mm, giving you plenty of room to maneuver in every height and work situation.

(2) Seatback angle adjustment (B)

The seatback adjusts over a range of -5° to +25° with 18 locking positions, to give your back full support for every job and make sure you feel best.

(3) Weight adjustment (C)

Just sit down, press the smooth-action lever, click, and you're primed for action, with optimum suspension for all operator weights between 45 and 136 kg (99 and 300 lb). Design comfort with driver appealit only takes one simple action to adjust the suspension to the ideal sitting position that's best for you and your back.

(4) Seatbelt system

The seatbelt provides freedom of movement, yet ensure that you're safety restrained in your seat, even if your vehicle should crash or tip over.

- Always check the condition of the seat belt and mounting hardware before operating the machine.
- ▲ Replace the seat belt at least once every three years, regardless of appearance.

3) UPPER WINDSHIELD



- (1) Perform the following procedure in order to open the upper windshield.
- 1 Hold both grips that are located both side of the windshield frame.
- ② Move grips to inside in order to release the lock latches. Hold both grips and push the windshield upward.
- 3 Hold both grips and back into the storage position.

Release both grips carefully until lock latches are into the locking position.

- 4 Hold both grips and back into the storage position.
- (5) Release both grips carefully until lock latches are into the locking position.
- ▲ When working, without having locked the windshield by the auto lock (by pushing the windshield to the rear untill it's completely fixed), please be careful as it can cause personal injury if the windshield is not fixed or falls off.
- (2) Perform the following procedure in order to close the upper windshield. Reverse step ① through step ⑤ in order to close the upper windshield.

4) FUSE BOX



- (1) The fuses protect the electrical parts and wiring from burning out.
- (2) The fuse box cover indicates the capacity of each fuse and circuit it protects.
- * Replace a fuse with another of the same capacity.
- A Before replacing a fuse, be sure to turn OFF the starting switch.

5) RADIO, USB PLAYER, BLUETOOTH AUDIO

FRONT VIEW



- 1 USB port with cover : Open the cover and connect the USB storage device.
- 2 AUX port with cover : Open the cover and plugging the external audio device.
- 3 Internal Microphone
- 4 Power ON/OFF, Mute and Pause knob.
- 5 Searching for next station, manual step up and next track.
 - *. Short Press :

Radio mode) Search for the next station automatically USB/BT Audio) Next Track

*. Long Press :

Radio mode) Step up manually USB/BT Audio) Fast Forward

- 6 Searching for previous station, manual step down and previous song.
 - Short Press :

Radio mode) Search for the previous station automatically USB/BT Audio) Previous song

• Long Press :

Radio mode) Step down manually USB/BT Audio) Fast rewind

- 7 Radio Button: enters Radio mode, changes the radio band ,and activates Automatic station storage
 - Short Press : Select the Radio band
 - Long Press : AST mode

8 Call button :

• When a call comes in : accepts a call(press) ; switches a call mode (Talking / Private mode)

- 9 Call end button :
 - During a call connection : ends a call (press);
- 10 Media selection or Setup button
 - Short Press : Move back to previous media
 - Long Press : Move to the setting mode
- 11~16 Preset buttons :

- Radio : Recall each stored station(press); store each station (press and hold).

- USB/BT AUDIO :

Preset1 : Display folder name / ID3 Information

Preset2 : Scan each track for 10 seconds

Preset3 : Repeat the file and folder

Preset4 : Play folders at random or play all Preset5 :

• Short Press: Move to previous folder

• Long Press : Play first 10 tracks of current folder Preset6 :

- Short Press : Move to next folder
- Long Press : Play first 10 tracks of current folder
- 17 Display window for play / reception /menu state and information.

DISPLAY WINDOW (LCD)



19A3RD03

- 1 Function display area for showing the function mode.
- 2 Bluetooth indicator for the Bluetooth connection.
- 3 Search indicator for USB play list.
- 4 USB/AUX indicators for the USB or External device connection.
- 5 MP3/WMA indicators for USB's Audio Stream detections.
- 6 ST (Stereo) indicators for FM stereo reception.

- 7 Playback mode indicators for USB playback mode.
 - C: Folder mode.
 - C: Repeat playback.
 - : Random playback.
- 8 LOUD/EQ indicators for sound effect.LOUD : Loudness mode.EQ : EQ mode.
- 9 Multi-function display area for showing the play, reception or menu information.

GENERAL

(1) Turning the unit on/off



1 Turn the starting switch to ON position.



- O Press the POWER button to turn the power on.
 - · If the source is ready, playback also starts.
 - · To turn on the power directly.



③ When power is on, press and hold the POWER button to turn power off.

(2) Adjusting volume directly



① Turn the VOLUME dial to control volume. \cdot Available volume range: 00 (mute) ~ 30.

(3) Muting the sound quickly



1 Press the MUTE button to turn mute on.

- \cdot "Mute" will be displayed on the LCD and mute the sound.
- · Press the MUTE button again or turn VOLUME dial to restore sound.

(4) Setting the sound



① Press and hold MEDIA/SET button for 2 seconds, then rotate the volume to access the [AUDIO SET] menu

Press the volume knob to access the Audio Settings menu.

Then press the volume knob and the Audio Settings option appears as below.

- · BASS : sets the bass sound level (-7 ~ +7).
- · TREBLE : sets the treble sound level (-7 ~ +7).
- BALANCE : sets the sound balance between the right and left speakers (LEFT 7 ~ RIGHT 7).
- EQUALIZER : selects the one of the 5 EQ styles (EQ OFF, CLASSIC, POP, ROCK, JAZZ).
- · LOUD : Selects the one of the 2 options (ON, OFF)
- % If there is no operation after 5 seconds, automatically exit the [Audio Settings] menu.
- * The BASS and TREBLE can be adjusted only if the EQ OFF is selected in the sub-menu.
- * Press and hold [MEDIA/SET] to enter the settings, and press [VOL] again to return to the Previous Settings item when you press [VOL] to enter the previous one.

(5) Setting the system functions



① Press and hold [MEDIA/SET] for 2 seconds, then rotate the volume knob to access the [SYSTEM SET] menu.

Press the volume knob to access the system settings menu. Then press the volume knob and the system settings option appears.

Each item can be adjusted by rotating the volume knob.

- ② S-VOL Settings.
 - The S-VOL value ranges from 5 to 25. You can set the default volume here.
 - When the player is turned on, if the volume of the last shutdown is greater than the default volume, it will be restored to the default volume after being turned on.
 - If the volume before power off is between VOL5 and the default volume, turn it on and return to the volume before power off.
 - If the volume is less than VOL5 before power off, power on will return to VOL5.

(6) Setting the regions

- ASIA / MIDDLE EAST
 FM : 87.5 ~ 108.0 MHz (100 kHz step)
 AM : 531 ~ 1,602 kHz (9 kHz step)
- AMERICA
 FM : 87.5 ~ 107.9 MHz (200 kHz step)
 AM : 530 ~ 1,710 kHz (10 kHz step)
- · LATIN
 - FM : 87.5 ~ 108.0 MHz (100 kHz step) AM : 530 ~ 1,710 kHz (10 kHz step)

· EUROPE

FM : 87.5 ~ 108.0 MHz (50 kHz step) AM : 522 ~ 1,620 kHz (9 kHz step)

- JAPAN
 FM : 76 ~ 90 MHz (100 kHz step)
 AM : 522 ~ 1,629 kHz (9 kHz step)
- Russia (OIRT)
 FM : 65.0 ~ 74.0 MHz (30 kHz step)
 AM : 522 ~ 1,602 kHz (9 kHz step)

BLUETOOTH

(1) Pairing/Connecting your device



- Press button for 2 seconds. The Bluetooth icon on the screen starts blinking for 120 seconds.
 - [The Bluetooth device is visible at this point]
- 2 Turn on your phone's Bluetooth
- 3 Go to your phone's Bluetooth Settings page
- 4 Look for a new Bluetooth device
- (5) Select [HYUNDAI] from the list of Bluetooth names.
- ⁽⁶⁾ When pairing is completed, the fixed Bluetooth icon will be displayed on the screen.

(2) Answering a call

- * When a call comes in, the audio source is muted, and display the call information with ring tone.
- * If the phonebook is not downloaded, only incoming phone number is displayed without the caller information.



- ① To answer a call, press the <u>button</u> button or to reject a call press and hold the <u>button</u>.
 - $\cdot\,$ When a call comes in, the audio source is muted.
 - When a call is ended, this unit returns to the previous state media playback.

(3) Private calls



During the call, you can do this by pressing button to switch the sound output between the phone and the car speakers.

RADIO

(1) Tuning in a radio station



 Press the RADIO/AST button repeatedly to enter the radio band in order of FM1, FM2, FMA, AM1, AMA.

You can select the FM1, FM2, FMA or AM1, AMA radio band. While the Auto Store stations (AST) are stored, you can select the AMA or FMA band by additional. The previously chosen broadcasting station will be received.



② Press the TUNE/TRACK UP & DOWN button to select the station. During the FM reception, the Stereo [ST] indicator is on.

- (2) Saving radio stations manually (Long Press : More than 2 seconds)
 - ※ You can save up to 6 preset channels each for FM1, FM2, AM1 band. If change the stations while driving, use preset button to prevent accidents.
 - ① Press RADIO/AST button repeatedly to select the band.
 - ② After selecting the frequency, press and hold the PRESET [1 DSP]
 ~ [6 D+] button.
 - ③ The frequency is saved to the selected preset button.
 - A total of 18 frequencies with 6 preset frequencies each for FM1/ FM2/AM1 modes can be saved.

(3) Saving radio stations automatically (Short Press)

* You can save up to 6 preset channels automatically each for FMA and AMA band.



① Press the RADIO/AST button repeatedly to enter the radio band.
 · The previously chosen broadcasting station will be received.



- ② Press and hold the RADIO/AST button to automatically save receivable frequencies to preset button.
 - Up to 6 stations can be stored in each of the FMA and AMA band.

(4) Listening to a preset station



- ${\textcircled{\sc l}}$ Press the RADIO/AST button repeatedly to enter the radio band.
 - You can select the FM1, FM2, FMA or AM1, AMA radio band.
 While the Auto Store stations (AST) are stored, you can select the AMA or FMA band by additional.
 - The previously chosen broadcasting station will be received.
- 2 Press the PRESET [1 DSP] ~ [6 D+] button.
 - From the 6 presets, select the frequency you want to listen to.

USB PLAYER

(1) Playing an USB device



① Open the cover, plug the USB device (included MP3/WMA media file) to the USB port.

Once a USB is connected, USB will automatically start playing from the first file within the USB.

If a previously played USB is reconnected, then the file after the most recently played file is played.

If a different USB is connected or the file information within the USB was changed, then the USB will start playing from the first song within the USB.

② When an USB device to be played is already connected, press the MEDIA/SET button to play USB device.

The previously selected file is played.



MEDIA/SET

19A3RD51

③ While playing, press the Volume Knob to pause the file.

(2) Changing the song information



- ① Press the [1 DSP] button repeatedly to display information about the file being played.
- ② The information displayed includes the file name, playing time, ID3 Tag or folder name information saved with the song.

(3) Controlling the playback



① While playing, Press the Track up and Track down button to move to the previous or next track.



- ② Press the [5 D-] or [6 D+] button to moves to the previous or next folder.
 - [5 D-] press : move to previous folder.
 - [6 D+] press : move to next folder.



③ While playing, press the [1 DSP] button to pause the track. Press the button again to play the current track.

(4) Change the playback mode



- ① Press the [3 RPT] button to select the Repeat playback mode.
- ② CO On : The current file plays repeatedly.
- ③ CO On : The current folder plays repeatedly.
- ④ Off : Cancels repeat playback.



- 1 Press the [4 RDM] button to select the Random playback mode.
- ② Con: All files of current folder play in random order.
- 4 Off : Cancels random playback.

(5) Handling precautions for USB device

- ① The amount of time required to recognize the external USB device may differ depending on the type, size, or file formats stored on the USB. Such differences in the required time are not indications of malfunction. Please wait the period of time required to recognize the device.
- ② The device may not recognize the USB device if separately purchased USB hubs and extension cables are being used.
- ③ The device may not support normal operation when using formats such as HDD Type, CF, or SD Memory.

AUX PLAYER

※ By connecting an optional portable audio device to the AUX input jack (stereo 3.5mm) on the unit and then simply selecting the source, you can listen on your car speakers.



- 1 Turn the VOLUME dial left to decrease the volume level.
 - The AUX volume can also be controlled separately through the connected device.



- ② Turn the external audio equipment off. Open the cover, connect the audio output of the external audio equipment to AUX input terminal on the unit.
- ③ Turn the external audio equipment on. Start playback of the external audio equipment at a moderate volume.



- 4 Press the MEDIA/SET button repeatedly to select the AUX function.
- ⑤ Set your usual listening volume by turn the VOLUME dial left/right on the unit.
 - · Once the connector is disconnected, the previous mode will be restored.
 - AUX mode can be used only when an external audio player has been connected.