CONTENTS

Foreword 0-1	8. Operation in the special work sites	4-20
Emission-related components warranty (USA and CANADA only) 0-1-1	9. Normal operation of excavator	4-22
	10. Attachment lowering	4-23
Before servicing this machine 0-2	11. Storage ·····	4-24
EC regulation approved	12. RCV lever operating pattern	4-26
Table to enter S/No and distribution 0-4	13. Regeneration system ·····	4-28
Safety labels		
Machine data plate 0-20	TRANSPORTATION	
Guide (direction, S/No, symbol) 0-21	1. Preparation for transportation	
CAFETY DUE EQ	2. Dimension and weight ·····	
SAFETY RULES	3. Loading the machine	
1. California proposition 65 ······ 1-1	4. Fixing the machine	5-7
2. Safety rules ····· 1-2	5. Loading and unloading by crane	5-8
SPECIFICATIONS	MAINTENANCE	
1. Major components ····· 2-1	1. Instruction ······	6-1
2. Specifications 2-2	2. Tightening torque ······	6-6
3. Working range 2-5	Fuel, coolant and lubricants ······	
4. Weight 2-7	4. Maintenance check list ·····	
5. Lifting capacities 2-9	5. Maintenance chart ·····	
6. Bucket selection guide 2-15	6. Service instruction	
7. Undercarriage 2-17	7. Electrical system ·····	
8. Specification for major components 2-19	8. Air conditioner and heater ·····	
9. Recommended oils 2-23		
CONTROL DEVICES	TROUBLESHOOTING GUIDE	
1. Cab devices 3-1	1. Engine ·····	
2. Cluster 3-2	2. Electrical system ·····	
3. Switches 3-35	3. Others ·····	7-3
4. Levers and pedals 3-40	LIVED ALII IO DDEALED AND OLIIOK OL	4 1 45
5. Others 3-42	HYDRAULIC BREAKER AND QUICK CL	
J. Othors	Selecting hydraulic breaker	
OPERATION	2. Circuit configuration	
1. Suggestion for new machine ······ 4-1	3. Maintenance	
2. Check before starting the engine 4-2	4. Precaution while operating the breaker ·····	
3. Starting and stop the engine 4-3	5. Quick clamp ·····	8-6
4. Mode selection system ······ 4-7	INDEX	0.1
5. Operation of the working device 4-12		Ð-1
6. Traveling of the machine 4-13		
7. Efficient working method 4-16		
-		

FOREWORD

This manual contains a number of instructions and safety recommendations regarding driving, handling, lubrication, maintenance, inspection and adjustment of the excavator.

The manual is to promote safety maintenance and enhance machine performance.

Keep this manual handy and have all personnel read it periodically.

If you sell the machine, be sure to give this manual to the new owners.

This machine complies with EC directive "2006/42/EC".

1. **Read** and **understand** this manual before operating the machine.

This operator's manual may contain attachments and optional equipment that are not available in your area. Please consult your local HD Hyundai Construction Equipment distributor for those items you require.

Improper operation and maintenance of this machine can be hazardous and could result in serious injury or death.

Some actions involved in operation and maintenance of the machine can cause a serious accident, if they are not done in a manner described in this manual.

The procedures and precautions given in this manual apply only to intended uses of the machine. If you use your machine for any unintended uses that are not specifically prohibited, you must be sure that it is safe for you and others. In no event should you or others engage in prohibited uses of actions as described in this manual.

Some illustrations in this manual show details or attachments that can be different from your machine. Covers and guards might have been removed for illustrative purposes.

- Inspect the jobsite and follow the safety recommendations in the safety hints section before operating the machine.
- 3. Use genuine HD Hyundai Construction Equipment spare parts for the replacement of parts. We expressly point out that HD Hyundai Construction Equipment will not accept any responsibility for defects resulting from non-genuine parts or non workmanlike repair. In such cases HD Hyundai Construction Equipment cannot assume liability for any damage.

Continuing improvements in the design of this machine can lead to changes in detail which may not be reflected in this manual. Consult HD Hyundai Construction Equipment or your HD Hyundai Construction Equipment distributor for the latest available information for your machine or for questions regarding information in this manual.

EMISSION-RELATED COMPONENTS WARRANTY (USA AND CANADA ONLY)

HD Hyundai Construction Equipment shall have obligation under the EPA (Environmental Protection Agency) regulation of warranty about Emission-related components. This warranty shall exist for 3,000 hours or five years, whichever occurs first.

Naturally, this warranty does not cover to damage arising from accident, misuse or negligence, use of non-HD Hyundai Construction Equipment parts, or from alterations not authorized by HD Hyundai Construction Equipment.

* Emission-related components according to the EPA regulation.

- 1. Air-induction system.
- 2. Fuel system.
- 3. Ignition system.
- 4. Exhaust gas recirculation systems.
- 5. After treatment devices.
- 6. Crankcase ventilation valves.
- 7. Sensors.
- 8. Electronic control units.

BEFORE SERVICING THIS MACHINE

It is the responsibility of the owner and all service and maintenance personnel to avoid accidents and serious injury by keeping this machine properly maintained.

It also is the responsibility of the owner and all service and maintenance personnel to avoid accidents and serious injury while servicing the machine.

No one should service or attempt to repair this machine without proper training and supervision.

All service and maintenance personnel should be thoroughly familiar with the procedures and precautions contained in this manual.

All personnel also must be aware of any federal, state, provincial or local laws or regulations covering the use and service of construction equipment.

The procedures in this manual do not supersede any requirements imposed by federal, state, provincial or local laws.

HD Hyundai Construction Equipment can not anticipate every possible circumstance or environment in which this machine may be used and serviced.

All personnel must remain alert to potential hazards.

Work within your level of training and skill.

Ask your supervisor if you are uncertain about a particular task. Do not try to do too much too fast. Use your common sense.

How to set the language of cluster

User can select preferable language and all displays are changed the selected language.



* Please refer to the page 3-27 for the cluster.

EC REGULATION APPROVED

· Noise level (EN474-1: 2006 and 2000/14/EC) are as followings.

LWA: 104dB (EU only)

LPA : 73dB

• The value of vibrations transmitted by the operator's seat are lower than standard value of (EN474-1 : 2006 and 2002/44/EC)



EC Declaration of Conformity (Original instruction)

This declaration of conformity is issued under the sole responsibility of manufacturer:

HD HYUNDAI CONSTRUCTION EQUIPMENT CO., LTD.

477 Bundangsuseo-ro, Bundang-gu,

Seongnam-si, Gyeonggi-do 13553, Korea

HD Hyundai Construction Equipment Europe N.V located at Hyundailaan 4, 3980 Tessenderlo, Belgium, as authorized representative in the European Community is authorized to compile the technical construction file and declares that the product:

Type: ********
Model: ******

Serial number (PIN):

is in conformity with the relevant provisions of the Community harmonization legislation:

2006/42/EC - Machinery directive

2014/30/EU - Electromagnetic compatibility directive

2000/14/EC - Noise emission outdoor equipment directive

2002/44/EU - Exposure of workers to vibration risks directive

their amendments, and other applicable directives.

EMC (2014/30/EU)

Certificate number:

Noise levels (2000/14/EC)

Conformity assessment proc.: Annex VIII Full Quality Assurance

Notified body:

Measured sound power level: nnn.n dB(A)
Guaranteed sound power level: nnn.n dB(A)

Engine information

Manufacturer: ********
Engine model name: *******
Type-approval number: *********

Stage (Regulation) : STAGE ** (**/**/**)

Gross Power (SAE J1995): ***kW / ****rpm

Net Power (SAE J1349): ***kW / ****rpm

Harmonized standards, other technical standards and specifications applied:

EN 474-1:2006+A*:**** (EMM - Safety - Part 1); EN 474-3:2006+A*:**** (EMM - Safety - Part 3); EN ISO 3471:2008 (EMM - ROPS: Lateral/Vertical/Longitudinal loads); EN ISO 3449:2008 (EMM - FOPS: Level II cabin); ISO 2631-1:1997 & ISO 2631-1:1997/Amd1 :2010 (Whole-body vibration); EN ISO 5349-1:2001 & EN ISO 5349-2:2001/A1:2015 (Hand-arm vibration)

Managing Director

Place, date of issue: Tessenderlo Belgium, DD MM YYYY

TABLE TO ENTER SERIAL NO. AND DISTRIBUTOR

Machine Serial No.	
Engine Serial No.	
Manufacturing year	
Manufacturer Address	HD Hyundai Construction Equipment Co., Ltd. 477 Bundangsuseo-ro, Bundang-gu, Seongnam-si, Gyeonggi-do 13553, Korea
Distributor for U.S.A Address	HD Hyundai Construction Equipment Americas, Inc. 6100 Atlantic Boulevard Norcross GA 30071 U.S.A
Distributor for Europe Address	HD Hyundai Construction Equipment Europe N. V. Hyundailaan 4 3980 Tessenderlo Belgium
Dealer Address	

SAFETY LABELS

1. LOCATION

20

21

Ref operator's manual


Hammer

41

42

Reflecting

Always keep these labels clean. If they are lost or damage, attach them again or replace them with a new label.



1	Air cleaner filter	22	Safety front window	43	Accumulator
2	Turbocharger cover	23	Safety rear window	44	M/control pattern change valve
3	Radiator cap	24	Air conditioner filter	45	M/control pattern change-w/o valve
4	Fueling	25	ROPS plate	46	M/control pattern change-w/valve
5	Battery accident	26	Safety knob	47	Swing bearing grease
6	High pressure hose	27	Model name	48	Battery position
7	Hydraulic oil level	29	Trade mark (boom)	49	Lubrication oil
8	Hydraulic oil lub	30	Trade mark (CWT)	50	Fuel shut off
9	Keep clear-rear	31	Reduction gear grease	51	MCU/ECM connector
10	Lifting eye	32	Clamp locking	52	Ultra low sulfur diesel
11	Name plate	33	Noise level LWA	54	Surge tank
12	Slinging ideogram	34	Service instruction	55	Key off caution
13	Keep clear-side	35	Lifting chart	56	RCV lever
14	Stay fix	36	Tie	57	Diesel exhaust fluid
15	Engine hood shearing	37	Keep clear-boom/arm	58	Control RCV
16	No step	38	Electric welding	59	DEF/AdBlue® fill-up
17	Transporting	39	Falling	60	Refrigerant
19	M/control pattern	40	FOPS FOG plate	61	Use handrail

Caution (water separator, turbocharger)

2. DESCRIPTION


There are several specific warning labels on this machine please become familiarized with all warning labels.

Replace any safety label that is damaged, or missing. If a safety label is attached to a part that is replaced, install a safety label on the replacement part.

1) AIR CLEANER FILTER (item 1)

This warning label is positioned on the left side of the rear support.

** Periodic and proper inspection, cleaning and change of elements prolong engine life time and maintain the good performance of engine.



21070FW01

2) TURBOCHARGER COVER (item 2)

This warning label is positioned on the turbocharger cover.

♠ Do not touch turbocharger or it may cause severe burn. When the engine is running or immediately after engine shut down.



21070FW02

3) RADIATOR CAP (item 3)

This warning label is positioned on the radiator.

▲ Never open the filler cap while engine running or at high coolant temperature. Hot coolant can cause serious burns, injury or death.




14070FW03

4) FUELING (item 4)

This warning label is positioned on the right side of fuel filler neck.

▲ Stop the engine when refueling. All lights or flames shall be kept at a safe distance while refueling.



290F0FW02

5) BATTERY ACCIDENT (item 5)


This warning label is positioned on the battery cover.

- ▲ Electrolyte containing sulfuric acid cause severe burns. Avoid being in contact with skin, eyes or clothes. In the event of accident flush with sufficient water, call a physician immediately.
- Maintain the electrolyte at the recommended level. Add distilled water to the battery only when starting up, never when shutting down.
 - With electrolyte at proper level, less space may cause the gases to be accumulated in the battery.
- ▲ Extinguish all smoking materials and open flames before checking the battery.
- ♠ Do not use matches, lighters or torches as a light source near the battery for the probable presence of explosive gas.
- ♠ Do not allow unauthorized personnel to change the battery or to use booster cables.
- ▲ For safety from electric shock, do not battery terminal with a wet hand.



This warning label is positioned on the right side of the hydraulic tank.

- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- ♠ Avoid the hazard by relieving pressure before disconnecting hydraulic lines or other lines.
- ※ See the maintenance section for details.



36070FW05




14070FW29

7) HYDRAULIC OIL LEVEL (item 7)

This warning label is positioned on the screen plate.

- ♠ Place the bucket on the ground whenever servicing the hydraulic system.
- * Check oil level on the level gauge.
- ※ Refill the recommended hydraulic oil up to specified level if necessary.



21070FW07

8) HYDRAULIC OIL LUBRICATION (item 8)

This warning label is positioned on the top of the hydraulic tank.

- ※ Do not mix with different brand oils.
- A Never open the filler cap while high temperature.
- ▲ Loosen the cap slowly and release internal pressure completely.




14070FW08

9) KEEP CLEAR-REAR (item 9)

This warning label is positioned on the rear of counterweight.

- ▲ To prevent serious personal injury or death keep clear or machine swing radius.
- ▲ Do not deface of remove this label from the machine.




21090FW09

10) LIFTING EYE (item 10)

This warning label is positioned on the counterweight.

- ♠ Do not lift the machine by using lifting eyes on the counterweight or the lifting eyes may be subject to overload causing its breaking and possible personal injury.
- See page 5-8 for proper lifting method of the machine.



21070FW10

11) KEEP CLEAR-SIDE (item 13)

This warning label is positioned on the side of LH rear side cover.

- ▲ To prevent serious personal injury or death keep clear of machine swing radius.
- ♠ Do not deface or remove this label from the machine.




21070FW13

12) STAY FIX (item 14)

This warning label is positioned on the side cover.

- ▲ Be sure to support the stay when the door needs to be opened.
- A Be careful that the opened door may be closed by the external or natural force like strong wind.




21070FW14

13) ENGINE HOOD SHEARING (item 15)

This warning label is positioned on the engine hood.

- ♠ Don't open the engine hood during the engine's running. Stay clear of rotating parts.
- ▲ Don't touch exhaust pipe or it may cause severe burn.



21070FW15

14) NO STEP (item 16)

This warning label is positioned on the engine hood and counterweight.

○ Don't step on the engine hood and counterweight.




21070FW16

15) TRANSPORTING (item 17)

This warning label is positioned right side of upper frame.

▲ Study the operator's manual before transporting the machine, if provided and tie down arm and track to the carrier with lashing wire.


See page 5-7 for details.



14070FW17

- **16) MACHINE CONTROL PATTERN** (item 19) This warning label is positioned in right window of the cab.
- ♠ Check the machine control pattern for conformance to pattern on this label. If not, change label to match pattern before operating machine.
- ♠ Failure to do so could result in injury or death.

See page 4-12 for details.



36070FW19

17) REF OPERATOR'S MANUAL (item 20)

This warning label is positioned on the right side window of the cab.

- (1) Ref operator manual
- ▲ Study the operator's manual before starting and operating machine.
- ♠ Do not operate this machine unless you have read and understand the instructions and warnings in this manual. Failure to follow the instructions or warnings could result in injury or death.

(2) Max height

♠ Serious injury or death can result from contact with electric lines.
An electric shock being received by merely coming into the vicinity of an electric lines, the minimum distance should be kept considering the supply voltage as page 1-7.


(3) Interference

♠ Be careful to operate machine equipped with quick clamp or extensions. Bucket may hit cab or boom, boom cylinders when it reached vicinity of them.


18) SAFETY FRONT WINDOW (item 22)

This warning label is positioned on the both side window of the cab.

- ▲ Be careful that the front window may be promptly closed.
- * See page 3-70 for details.



2609A0SL05



21070FW24

19) SAFETY REAR WINDOW (item 23)

This warning label is positioned on the inside of rear window.

- The rear window serves as an alternate exit.
- To remove rear window, pull the ring and push out the glass.




2609A0SL02

20) AIR CONDITIONER FILTER (item 24)

This warning label is positioned on the air conditioner cover.

Periodic and proper inspection, cleaning and change of filter prolong air conditioner life time and maintain good performance.




21070FW26

21) SAFETY KNOB (item 26)

This warning label is positioned on the cover of the safety knob.


▲ Before you get off the machine be sure to place the safety knob LOCKED position.



22) REDUCTION GEAR GREASE (item 31)

This warning label is positioned in the front of upper frame.

♠ Grease is under high pressure. Grease coming out of the grease plug under pressure can penetrate the body causing injury or death.




21070FW35

23) CLAMP LOCKING (item 32)

This warning label is positioned on the right side window of cab.

- ▲ Serious injury or death can result from dropping bucket.
- ♠ Operating the machine with quick clamp switch unlocked or without safety pin of moving hook can cause the bucket to drop off.



14070FW60

24) TIE (item 36)

This warning label is positioned on the lower frame.

- A Never tow the machine using tie hole, because this may break.
- ▲ See page 4-15 for detail.



4507A0FW02

25) KEEP CLEAR-BOOM/ARM (item 37)

This warning label is positioned on both side of the arm.

- ▲ Serious injury or death can result from falling of the attachment.
- ▲ To prevent serious injury or death, keep clear the underneath of attachment.



14070FW31

26) ELECTRIC WELDING (item 38)

This warning label is positioned on the battery cover.

- ♠ Before carrying out any electric welding on this machine, follow the below procedure.
- Pull the connector out of all electric control units.
- Connector the ground lead of the welding equipment as close to the welding point as possible.
- See page 6-47 for detail.

A WARNING

- Before carrying out any electric welding on this machine
- Pull the connectors out of all electronic control units.
- Connect the ground lead of the welding equipment as close to the welding point as possible.
- Read the instructions in operator's manual for

7807AFW20

27) FALLING (item 39)

This warning label is positioned on the top of the hydraulic tank.

- ▲ Falling is one of the major cause of personal injury.
- ▲ Be careful of slippery conditions on the platforms, steps and handrails when standing on the machine.



14070FW30

28) CAUTION (W/SEPARATOR, TURBOCHARGER) (item 41)

This warning label is positioned on the right window of the cab.

- ♠ In order to protect high pressure fuel system, please drain water in water separator before starting the engine.
- ▲ In order to prevent turbocharger failure, please allow more than 5 minutes' cool down period (no load low idle operation) before shutting the engine off.

A CAUTION

 In order to protect high pressure fuel system, please drain water in water separator before starting the engine.

 In order to prevent turbocharger failure, please allow more than 5 minutes cool down period(no load low idle operation) before shutting the engine off.

120090SL02

29) REFLECTING (item 42)

This warning label is positioned on the rear of counterweight.

- ▲ To prevent serious personal injury or death keep clear of machine swing radius.
- ♠ Do not deface or remove this label from the machine.



290F0FW01

30) ACCUMULATOR (item 43)

This warning label is positioned on the accumulator of the solenoid valve.

- The accumulator is filled with high-pressure nitrogen gas, and it is extremely dangerous if it is handled in the wrong way. Always observe the following precautions.
- A Never make any hole in the accumulator expose it to flame or fire.
- **A** Do not weld anything to the accumulator.
- When carrying out disassembly or maintenance of the accumulator, or when disposing of the accumulator, it is necessary to release the gas from the accumulator. A special air bleed valve is necessary for this operation, so please contact your HD Hyundai Construction Equipment distributor.




1107A0FW46

31) MACHINE CONTROL PATTERN CHANGE VALVE (item 44)

This warning label is positioned on the right side window of the cab.

- ♠ The machine control pattern can easily be changed to the "ISO type" or to the "A type" by changing the position of the lever of the pattern change valve.
- ▲ Before starting this machine, check the lever pattern valve.
- * See page 4-27 for detail.



2609A0SL11

32) MACHINE CONTROL PATTERN CHANGE-W/O VALVE(item 45)

This warning label is positioned on the LH support of cowl.

- ▲ Check the machine control pattern before starting this machine.
- ※ See page 4-26 for detail.




14W90FW47

33) MACHINE CONTROL PATTERN CHANGE-W/VALVE (item 46)

This warning label is positioned on the LH support of cowl.

- ♠ Check the machine control pattern for conformance to pattern on this label. If not, change label to match pattern before operating machine.
- ▲ Failure to do so could result in injury or death.
- See page 4-27 for details.




38090FW01A

34) SWING BEARING GREASE (item 47)

This warning label is positioned in the front of swing ring gear.


See page 6-38 for details.



38090FW02

35) BATTERY POSITION (item 48)

This warning label is positioned left inside of side cover.



38090FW03

36) LUBRICATION OIL (item 49)

This warning label is positioned on the right side of the hydraulic tank.

- * Recommended lubrication oil ACEA-E9 is equivalent to API CJ-4.
- * See page 6-9 for details.




RECOMMENDED LUBE OIL ACEA-E9 IS EQUIVALENT TO CJ-4 PLEASE REFER TO THE DRIVER'S MANUAL

290F0SL03

37) FUEL SHUT OFF (item 50)

This warning label is positioned on the left side of the hydraulic tank.

- * Fill only the hydraulic oil.
- ※ Do not fill the diesel fuel.
- ♠ Relieve tank pressure with the engine off by removing the cap slowly to prevent burns from hot oil.



140WH90FW51

38) MCU/ECM CONNECTOR (item 51)

This warning label is positioned on the low cover of the air conditioner in the cab.

- MCU communicates the machine data with Laptop computer through RS232 service socket.
- ※ ECM communicates the engine data with cummins INSITE tool adapter through J1939 service socket.
- * See page 3-69 for details.

MCU/ECM Service Tool MCU/ECM 서비스툴

235Z90FW52

39) ULTRA LOW SULFUR DIESEL (item 52)

This warning label is positioned on the light side of fuel filler neck.

- W Use ultra low sulfur fuel only.
- William Willi



ULTRA LOW SULFUR FUEL ONLY PLEASE REFER TO THE DRIVER'S MANUAL.


2609A0SL03

40) SURGE TANK (item 54)

This warning label is positioned on the top of the surge tank.

This system must be filled slowly to prevent air locks.

 \Re Fill rate ≤ 11 lpm




3009A0FW54

41) KEY OFF CAUTION (item 55)

This warning label is positioned on the right side window of the cab.

** Park on a flat place and stop the engine for inspecting and repairing. Properly TAG machine is not operational. (remove start key)

Extreme care shall be taken during maintenance work.



290F0FW05

42) RCV LEVER (item 56)

This warning label is positioned on the right side window of the cab.

When you work by moving the seat to the front of cab, it is possible to take place interference between cluster and RCV lever at specific position.

To prevent this interference, handle below works.

- (1) Rotate cluster.
- (2) Adjust seat position for up-and-downward using seat height adjuster knob in suspension.
- (3) Lower the console box height using knob between RH console box and seat cushion.
- (4) Push back console and seat position using seat and console box adjust knob between LH console box and seat cushion.




290F0FW04

43) DIESEL EXHAUST FLUID (item 57)

This warning label is positioned on the front of DEF/AdBlue® tank.

Fill only the DEF/AdBlue® (Diesel Exhaust Fluid, standardised as ISO 22241). Aqueous urea solution made with 32.5% high-purity urea and 67.5% deionized water.






290F0SL04

44) CONTROL RCV (item 58)

This warning label is positioned on the right side window of the cab.



330F0SL05

45) DEF/AdBlue® FILL-UP (item 59)

This warning label is positioned on the front of DEF/AdBlue® tank.

- Warning lamp turns on when the tank is completely filled with DEF/AdBlue®. After turning light on, do not pour DEF/ AdBlue® any more. Otherwise DEF/ AdBlue® tank may freeze and burst in winter season.
- Fill the tank with DEF/AdBlue® after key on and then turn off the start key.

WARNING

BE CAREFUL NOT TO ENTERING DUST, SAND OR OTHER CONTAMINATION SUBSTANCES WHEN YOU REFILL THE DEF/AdBlue® INTO THE TANK. OTHERWISE, FATAL PROBLEM SUCH AS ENGINE IDLE LOCKING, DERATING OR ENGINE STOPPING CAN BE HAPPEN

WARNING LAMP OF DEF/AdBlue® FILL-UP

WARNING LAMP TURNS ON WHEN THE TANK IS COMPLETELY FILLED WITH DEF/AdBlue® . AFTER TURNING LIGHT ON, DO NOT POUR DEF/AdBlue® ANY MORE. OTHERWISE DEF/AdBlue® TANK MAY FREEZE AND BURST IN WINTER SEASON.


*REMEMBER!! FILL THE TANK WITH DEF/AdBlue® AFTER KEY ON AND THEN TURN OFF THE START KEY.

480F0SL06

46) REFRIGERANT (item 60)

This warning label is positioned on the right side of engine hood.

- ▲ Inhaling air conditioner refrigerant gas through a lit cigarette or other smoking method or inhaling fumes released from a flame contacting air conditioner refrigerant gas, can cause bodily harm or death.
- * Refer to the page 6-50.



9650FW30

MACHINE DATA PLATE




- 1 Machine type / model 2 Product identification number 3 Engine power
- 4 Operating mass 5 Manufacturing year 6 Maximum certified weight
- * The machine serial number assigned to this particular machine and should be used when requesting information or ordering service parts for this machine from your authorized HD Hyundai Construction Equipment dealer. The machine serial number is also stamped on the frame.

GUIDE

1. DIRECTION

The direction of this manual indicate forward, backward, right and left on the standard of operator when the travel motor is in the rear and machine is on the traveling direction.



2. SERIAL NUMBER


Inform following when you order parts or the machine is out of order.


1) MACHINE SERIAL NUMBER

The numbers are located below the right window of the operator's cab.

2) ENGINE SERIAL NUMBER

The numbers are located on the engine name plate.





3. INTENDED USE

This machine is designed to be used mainly for the following work.

- Digging work
- Loading work
- Smoothing work
- Ditching work
- * Please refer to the section 4 (efficient working method) further details.

4. SYMBOLS

- ▲ Important safety hint.
- \triangle It indicates matters which can cause the great loss on the machine or the surroundings.
- * It indicates the useful information for operator.

1. CALIFORNIA PROPOSITION 65

MARNING

CALIFORNIA PROPOSITION 65

Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- \cdot Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- · Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

2. SAFETY INSTRUCTIONS

Safety Message

Intended Use

Machines should be operated in accordance with the procedures described in the operator manual.

The products described in the operator manual are designed and manufactured mainly for the following purposes:

- · Excavation work
- · Loading work
- · Leveling work
- · Drainage work
- · Lifting work
- · Demolition work

Do not operate the machine for any purpose other than those stated above or in areas where potential hazards have been identified. Make sure that you comply strictly with all safety instructions at all times. Please contact HD Hyundai Construction Equipment Co., Ltd. or your local dealer for more information.

HD Hyundai Construction Equipment strictly prohibits the use or operation of the machine in any of the following circumstances:

- Operation by an unskilled worker
- · Lifting a worker up
- · Transporting flammable or dangerous materials
- · Driving down or extracting piles with the bucket
- · Towing damaged vehicles

Safety guidelines

Most safety accidents related to the operation, maintenance/inspection, and repair of the machine result from a failure to comply with the safety instructions or to take adequate preventive measures. Safety accidents can be prevented by eliminating potentially hazardous situations. The operator should attend all mandatory training courses on the operation of the machine, and fully understand how to use the tools.

Improper operation, refueling, inspection or repair of this machine may cause serious injury or death.

Do not attempt to operate, refuel, inspect or repair this machine before reading and understanding the product information on such tasks.

This manual describes preventive measures and warnings about the product.

Failure to comply with the warnings about potential risks may result in serious injury or death.

General Safety Information

Unauthorized modification

Any attempt to modify the machine, including the use of unauthorized accessories or spare parts, may have adverse effects on the conditions of the machine and its ability to function as it was designed.

Do not attempt to modify the machine in any way without advanced written consent of the company.

Unauthorized modification will void the manufacturer's warranty.

Never modify the operator's cabin by welding, grinding, drilling holes or adding attachments unless instructed by HD Hyundai Construction Equipment in writing. Changes to the cabin can cause loss of operator protection from roll-over and falling objects, and result in serious injury or death.

The user is responsible for all damages and liabilities resulting from unauthorized modifications.

The attachment, the accessory, or the spare part has been made or distributed by HD Hyundai Construction Equipment and has been installed according to approved methods described in a publication available from HD Hyundai Construction Equipment.

Any modification must be approved by the company in writing.

ROPS/FOPS

The cabin is designed to provide sufficient space to minimize impacts pursuant to ISO 12117-2 of Rollover Protective Structures (ROPS). If any additional devices are installed that exceed the Max. certified weight indicated on ROPS name plate, the ROPS certification may be nullified. The protective structure of the cabin should be replaced immediately if it is permanently deformed or damaged.

Machines operated in areas where there is a risk of objects falling onto the cabin are fitted with a Falling Object Protective Structure (FOPS) pursuant to ISO 10262.

Fire and Explosion

Preventing fires

The following actions should be taken to minimize the risk of fire:

- · Do a visual inspection before operating the machine to check for any risk of fire.
- · Do not operate the machine if there is a risk of fire.
- Be sure to identify the primary exit and alternative exit of the machine, and fully understand how to use the exits in the event of a fire.
- Do not perform any welding or drilling work on the engine cover
- · Keep the engine compartment free from the buildup of flammable materials such as dead leaves, small branches, paper, and other types of trash.
- Keep the covers of the major parts of the machine closed.
 Make sure that the covers operate normally in order to be able to use firefighting equipment in the event of a fire.
- · Be careful when handling fuel. Fuel is a highly flammable.
- · Always stop the engine when refueling the machine.
- · Refuel outdoors.
- Remove any build-up of flammable materials from the machine.
- Do not operate the machine near a flame.
- All fuels and most lubricant and coolant mixtures are flammable materials, so special care should be exercised when handling such materials to prevent fire and explosion.
- Keep all fuels and lubricant in adequate containers.
- Never smoke in the area where refueling is taking place or in the space for handling battery electrolytes and other flammable materials.
- Oil leaked to a hot surface or electronic component may cause a fire.
- Do not operate the machine if there is an oil leak.
 Repair the source of the oil leak, and wipe clean any leaked oil before operating the machine.
- Always clean all electrical lines, connectors, and clamps, and check whether they are securely connected on a regular basis.
- If any electrical wire or connector is loose or damaged, repair it immediately.
- Do not weld, cut or use a cutting torch through any tubes or lines in which flammable flows. Check all tubes and lines for signs of abrasion or deterioration and replace if damaged.
- Dust or particles generated when repairing the nonmetallic hood or fender are flammable or explosive.
 Repair such parts in a well ventilated area well away from flames or sparks, and be sure to wear suitable PPE (Personal Protective Equipment).











Preventing explosions

The following actions should be taken to minimize the risk of explosion:

- Never use starting aid fluid in a low-temperature environment as it can have an adverse effect on the engine performance and may cause an explosion.
- Do not attempt to charge a frozen battery. Forcibly charging a frozen battery may result in an explosion.
- Use caution when handling the batteries. Never let a tool make contact with the positive battery post and the frame of the machine simultaneously.
 - Sparks may be generated, resulting in an explosion.
- Only charge the battery with a charger of equal voltage. Incorrect voltage may cause overheating and explosion.
- Do not use or charge the battery if the level of electrolytes in the battery is low.
 - Regularly check the electrolyte level, and refill with distilled water to the maximum level.
- Do not attempt to start the engine using an unsuitable booster cable as it may result in an explosion and serious injury or death.
- Only use the booster cable to start the engine in a well ventilated open space. Starting the engine with a booster cable may generate flammable gas.
- When hydraulic equipment and piping are overheated, flammable gas or airborne particles may explode. Protect and insulate such parts to prevent overheating.







Corrective Actions Before and After a Fire

In the event of a fire in the machine, the top priority should be the safety of the operator and workers in the work area. In the event of a fire at a level that does not endanger the operator or workers, the following actions should be taken:

- Move the machine well away from any flammable materials (e.g., fuel, engine oil, clothes, and bits of wood) and adjacent buildings.
- If the engine is running, it may cause a persistent fire. Immediately stop the engine.
- In the event of an electric short, disconnect the batteries to eliminate the main ignition source.
 - In the event of an electricity leak resulting from damage to the power wiring caused by fire, disconnect the batteries to eliminate the secondary ignition source.

If a fire becomes too large to control, assess the following risks:

The tank, accumulator, hose and fitting may burst into flames, splashing fuel and scattering particles throughout the surrounding area.

If you have to handle a machine that has been damaged by fire or one that is exposed to excessively high heat after extinguishing a fire, take the following precautions:

- · Wear thick protective gloves and protective goggles.
- Never touch any materials left after combustion with your bare hands.
- Avoid contact with melted polymer materials (e.g., plastics).





Information on fire extinguisher

Fire extinguishers (if equipped) should be kept in a fully operable condition, and be inspected by a qualified person on a regular basis. Workers should complete a training course on the use of fire extinguishers in advance.

Use fire extinguishers in accordance with the following procedures, if required:

- ① Pull the safety pin of the fire extinguisher first.
- ② Extend the nozzle, and stand toward the fire.
- ③ Aim the nozzle at the flames, and firmly press the top and bottom handles.
- 4 Stand in a downwind position, and evenly spray the foam over the flames.

If the weight of the fire extinguisher exceeds 4.5 kg, mount the extinguisher in a location near the bottom of the cabin. Do not mount the fire extinguisher at a level higher than one third of the height of the cabin.

Do not weld or drill ROPS to mount a fire extinguisher. Contact your dealer or distributor for more information about the correct mounting of fire extinguishers.



Health and Safety

Personal protective equipment

The wearing of personal protective gear is mandatory for protecting the human body from hazardous chemicals and hazardous environments.

The wearing of personal protective gear is a means of preventing injury, and should not interfere with the performance of jobs. It is designed to protect the human body from hazardous environments and hazardous materials, and should be kept in an easily accessible place.

List of personal protection gear

Name	Symbol	Remarks
Safety helmet		Protects the head from falling objects, and reduces risks when falling down.
Dust mask		Air-purifying dust mask should not be worn in workplaces with an oxygen concentration of less than 18%.
Gas mask		Prevents the inhalation of mist, airborne particles, or protects against the spray of hazardous chemicals.
Welding helmet		Blocks airborne dust and slag, and shields the face from bright light during welding.
Protective clothing	n	Blocks dust, mist and hazardous chemicals, and protects against burns.
Protective gloves		Electric insulation gloves: Should be worn when working in areas with a high risk of electric shock. Chemical protective gloves: Should be worn when working in areas where there is a risk of contact with hazardous chemicals including materials leaked from batteries.
Protective goggles		Protects the eyes from dust, particles and airborne materials in work areas.
Earplugs and earmuffs		Wear earplug and earmuffs separately or in combination depending on the level and duration of noise.
Safety shoes		Protects the feet from falling objects, impacts, and sharp objects.

Health and safety instructions in hazardous environments

Comply with the following instructions during operation and maintenance of the machine.

When handling oil


Failure to wear personal protection may result in burns caused by contact with a high-temperature liquid. Make sure you wear protective goggles, protective gloves and protective clothing when handling oils such as hydraulic oils and engine oil.

If the eyes come into contact with oil, wash them with a sufficient quantity of water for 15 minutes or longer. If the skin comes into contact with oil, take off contaminated clothes and shoes, and wash the skin with soap and water for 15 minutes or longer.



When handling the battery

If battery electrolyte leaks while handling the battery, the sulfuric acid contained in the electrolyte may cause burns. The lead components in battery electrolyte are toxic, so be sure to wear protective gloves and protective clothing. Always wash your hands after handling the battery. If a part of your body not protected by personal protective equipment comes into direct contact with battery electrolyte, immediately wash the affected part with flowing water for 20 minutes or more, and then see a doctor without delay. If you accidentally swallow battery electrolyte, drink water, do not forcibly induce vomiting, and immediately seek medical help.



When handling refrigerant

Always wear protective goggles, protective gloves and other personal protective equipment when handling refrigerant to prevent direct contact of the skin with the refrigerant.

Wear protective gloves made of materials that are resistant to chemicals (such as neoprene and butyl rubber).

Never smoke when handing refrigerant.

If refrigerant comes into direct contact with the skin, wash the skin with warm water immediately.



When handling coolants

Do not remove the radiator cap after operation of the machine until the engine has cooled and the pressure has dropped to a safe level. Failure to comply may result in serious burns.

Coolant contains toxic and combustible ethylene glycol, and should be handled in a cool, well-ventilated place only when wearing protective goggles, protective gloves, protective clothing, and a gas mask.

Avoid inhaling airborne particles or spray from coolant. If the substances make contact with skin or eyes, immediately wash the skin and eye with flowing water for 20 minutes or longer.





When working in a place subject to airborne particles and falling objects,

Always wear a safety helmet, protective goggles and safety shoes to prevent injury from airborne particles and thrown or falling objects. Earplugs or earmuffs may be necessary when working in a noisy place.



When working in places with a high level of noise

When the operator is exposed to the noise exceeding 90 dB (A) for 8 hours or longer, wear earplugs or earmuffs.




Personal protection gear for various situations

Situation	Symbol
Oil handling	
Battery handling	
Refrigerant handling	
Coolant handling	
Repair by welding	
Working in areas subject to airborne particles and falling objects	
Working in places with a high level of noise	
Handling machines damaged by fire or exposed to excessively high temperature	

WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

- Do not wear loose clothing and accessories.
 Secure long hair. These items can snag on controls or on other parts of equipment.
- · Do not wear oily clothes. They are highly flammable.
- · Wear a hard hat, safety shoes, safety goggles, mask, leather gloves, earplugs and other protective equipment, as required.
- · While working on machine, never use inadequate tools. They could break or slip, or they may not adequately perform intended.



Noise and Vibration

Information on vibration

This part describes the vibration data of the machine, and methods of calculating the vibration level.

The vibration level of the machine varies according to any of the following conditions:

- · Driving habits of the operator
- · Quality of seat and suspension
- · Type of machine, attachments, and conditions of machine
- · Conditions of work site, working environment, ground surface conditions, and weather

Vibration also varies according to the duration of operation.

Physical Agents Directive 2002/44/EC defines the exposure action value as 0.5m/s², and the exposure limit value as 1.15 m/s². If the predicted value is near the exposure action value or exposure limit value, the predicted value should be assumed to exceed the two latter values, and necessary action should be taken.

In regards to the actions taken according to the vibrations, refer to the following table:

Daily vibration exposure (A(8))	Vibration exposure range	Actions to be taken
$A(8) \le 0.5 \text{ m/s}^2$	Exposure action value or lower	When approaching the exposure activity value, reasonable measures should be taken to minimize exposure to vibration. The relevant information and opportunities for training on vibration reduction should be provided to the operator.
$0.5 \text{ m/s}^2 < A(8) \le 1.15 \text{ m/s}^2$	Exceeding the exposure action value, but not exceeding the exposure limit value	It is required to execute certain measures for reducing exposure to and risks of vibration to the minimum. The health of an operator who has been exposed to excessive vibration should be examined.
1.15 m/s ² <a(8)< td=""><td>Exceeding the exposure limit value:</td><td>Immediate action is required to reduce the vibration exposure level to below the exposure limit value.</td></a(8)<>	Exceeding the exposure limit value:	Immediate action is required to reduce the vibration exposure level to below the exposure limit value.

For futher information, please contact your local HD Hyundai Construction Equipment dealer.

The vibration level can be predicted based on the information in the following table which is used to calculate the daily level of vibration exposure.

Predict the vibration level in the three vibration directions of axes X, Y, and Z. The mean vibration level should be used under normal operation conditions. Scenario factors from mean vibration level based on operation by skilled operator and on smooth terrain are excluded. Scenario factors are included to obtain the mean vibration level based on aggressive operation and severe terrain to assess the expected vibration level.

* All vibration values are indicated in m/s2.

ISO Reference table - Vibration level equivalent to whole body vibration emission of the excavator (Unit: m/s²)

Machine		Typical operating	Vib	ration Le	vels	Scenario Factors			
family	Machine kind	condition	X axis	Y axis	Z axis	X axis	Y axis	Z axis	
	Compact	Excavating	0.33	0.21	0.19	0.19	0.12	0.10	
	crawler excavator	Hydraulic breaker app.	0.49	0.28	0.36	0.20	0.13	0.17	
	excavator	Transfer movement	0.45	0.39	0.62	0.17	0.18	0.28	
		Excavating	0.44	0.27	0.30	0.24	0.16	0.17	
Excavator	Crawler	Hydraulic breaker app.	0.53	0.31	0.55	0.30	0.18	0.28	
	excavator	Mining application	0.65	0.42	0.61	0.21	0.15	0.32	
		Transfer movement	0.48	0.32	0.79	0.19	0.20	0.23	
	Wheeled	Excavating	0.52	0.35	0.29	0.26	0.22	0.13	
	excavator	Transfer movement	0.41	0.53	0.61	0.12	0.20	0.19	

Instructions on mitigating vibration

Machines should be correctly adjusted and maintained to ensure smooth operation. The terrain conditions should be observed. The following instructions will help reduce the whole body vibration level:

- ① Use the correct size attachments for your machine.
- ② Maintain the machines pursuant to the manufacturer's recommendations.
- ③ Maintain and provide good terrain conditions.
 - · Remove any large rocks or obstacles.
 - · Fill gutters or holes.
 - Adjust speed and driving path as needed for the conditions.
- 4 Use a driver's seat that satisfies ISO 7096.
 - · Adjust the driver's seat and suspension for the weight and the size of the operator.
 - Inspect the suspension and adjusting devices of the driver's seat.
- ⑤ Perform the following maneuvers without using excessive force :
 - Steering
 - Braking
 - · Accelerating
 - · Gear shifting
- 6 Move the attachments smoothly.
- Tkeep the level of vibration minimal when working for a long time or driving for a long distance.
 - · Use a machine mounted with suspension system.
 - · Transport the machine when moving between worksites; do not drive the machine to get to another worksite.
- Take the following actions for optimal operator comfort and convenience:
 - Adjust the driver's seat adjustment device to allow a convenient posture.
 - Adjust the angles of the mirrors to minimize awkward, compromised posture
 - Avoid working for an excessively long time, and take regular breaks.
 - Do not jump on or off the cabin.
 - Minimize repeated handling of loads and lifting of loads.
 - The vibration information and calculation procedures are based on <ISO/TR 25398> has been defined according to the emission of vibrations measured under the actual working conditions of the machines.

Information on noise

Noise level (EN 474-1:2018 and 2000/14/EC) are as follows:

Sound pressure level (LpA): See pages 0-3.Sound power level (LwA): See pages 0-3.


Emergency situations

In the event of an emergency situation, use the emergency hammer installed inside the cabin to break the windshield of the cabin, and carefully escape from the cabin. The emergency hammer should always be kept inside the cabin for emergencies, and should not be removed or used for other purposes. If the emergency hammer is lost, replace it immediately.

Keep a first-aid kit inside the cabin or in another place at the worksite for safety accidents.

Keep contact information (e.g., phone number) to request help with an emergency situation or injury.





Safety Information on the Machines and Operation

Before Operating the Machine

Carefully examine the following conditions and take any necessary actions to prevent risk factors before operating the machine:

Checking the worksite

- Always be aware of weather conditions at your worksite.
 Fog or heavy rain may decrease visibility or render the machine inoperable. In the event of lightning, immediately put the bucket to the ground and evacuate to a safe place.
- Check the worksite for obstacles, and avoid collisions with such obstacles during operation. Check the surroundings of the machine for any obstacles that may hinder operation.
- Check the worksite for buried waterlines, telecommunication cables, power cables and oil pipelines in advance, and avoid damaging them.
- If the terrain of the worksite is too rough for normal operation of the machine, flatten the terrain before operating the machine. Make sure that the ground of the worksite is not soft as it may cause hazards during operation.
- If the worksite is a marshy place (e.g., shallow river, large or small lake, swamp, etc), check the conditions and the depth of marshy areas and the flow rate before driving or operating the machine. Do not operate the machine underwater.
- When operating the machine in water or when crossing shallow, check the bed soil condition and depth and flow speed of water, then proceed taking care that water is not above upper rollers.
- Do not operate the machine on cliffs or at the end of a road on soft ground as the machine may overturn. If operation of the machine on such terrain is unavoidable, keep the track perpendicular to the end, place the driving motor at the rear to facilitate escape from the machine in the event of an emergency situation.
- When operating the machine in areas with pedestrian or vehicle traffic, or in a zone in the vicinity of such an area, appoint workers exclusively responsible for controlling the traffic, or install fences or blocking wall to separate the worksite from the traffic area. Prevent unauthorized workers or machines from accessing the worksite.





Instructions before operating the machine

- The machine shall be operated by authorized and skilled operators only.
- The operator should wear clothes and personal protection gear that are appropriate for the work environment.
- Do not operate the machine while under the influence of alcohol or drugs or while experiencing extreme fatigue or other conditions that may affect your awareness of your surroundings or your reaction time.
- The operator should read and fully understand the operator's manual before operating the machine.
- The operator should fully understand the details and procedures of the work to be performed.
- Do not perform work when a hazard is anticipated or encountered. Remove the hazard before beginning work.
 Failure to comply may result in serious injury or death.

Inspect the machine before operating the machine

- Check the machine for abnormal noise, vibration or heat, and for the leakage of engine oil, hydraulic oil, fuel or refrigerant.
- · Remove any foreign substances from the engine and the battery. The buildup of such substances may cause a fire.
- Do not operate a machine until any necessary repairs are completed.
- Do not operate the machine until all regular inspection and service recommended in the operator's manual have been executed.
- Adjust the operator's seat to suit the physical condition of the operator. Check the seatbelt for damage, and replace it if damaged. Do not store unnecessary objects or tools in the cabin.
- Keep clean all parts related to visibility, such as the windshield and rearview mirror. Adjust the rearview mirror to ensure that the operator's field of vision is clear.
- Check the acoustic alarms (e.g., the horn and warning signal when driving backward or moving) for normal operation.





During Operation of the Machine Getting on and off

- · Do not jump on or off the machine.
- · Do not try to get on or off the machine while it is moving.
- Get on or off the machine using the handrail and step (or stepladder, if any). Always keep the handrail and step clean and free from mud or oil.
- · Wear anti-slip shoes.
- Comply with the principle of three-point contact* by contacting the machine with either both hands and one foot or vice versa when getting on or off the machine.
- Do not sit on any part of the machine not intended for sitting.
- ** Three-point contact means making contact with the machine with both hands and one foot, or with one hand and both feet.





During operation

- The operator should start the engine only after sitting on the operator's seat. Make sure that all levers are shifted to the neutral position before starting the engine.
- Pay close to any obstacles when operating the machine, particularly when turning or moving backward, to prevent collision. Failure to comply may result in serious injury or death.
- Do not exceed the recommended size and weight of an object when lifting a load. Do not lift a heavy object with slings by suspending the slings on the tooth of the bucket.
- · Do not allow anyone to stand under the bucket.





Operation on a slope


When operating the machine on a slope, failure to comply with these instructions could result in the machine tipping over, which may lead to serious injury or death.

- · Do not work on slopes of 10° or more.
- · Do not exceed the maximum climbing angle of 30°.
- If operation of the machine on a slope is unavoidable, perform the work after flattening the ground.
- When operating the machine laterally on a slope, there is a high risk of machine overturning or slipping. Do not operate the machine in such conditions.
- Do not operate the machine on a slope covered with wet grass or a thick layer of dead leaves, as the machine may slip.
- Do not park or stop the machine on a slope.

 If parking or stopping the machine on a slope is unavoidable, bring the bucket down to the ground, and support the wheels with wheel chocks.
- When traveling up a slope, operate the machine at a slow speed with the attachment extended forward to keep the machine balanced, and with the bucket raised at least 20 ~30 cm (1 ft) from the ground.
- When traveling down a slope, reduce the engine speed with the travel lever kept in the vicinity of the neutral position.
 Keep the bucket 20~30 cm (1 ft) above the ground, and use the bucket as a brake in an emergency situation.
- · If the engine suddenly stalls, immediately bring the bucket to the ground.
- If the fuel gauge reaches the red zone while operating the machine, immediately refill with fuel. (If the machine operates on a slope under these conditions, air may be introduced into the engine, causing it to stall suddenly.)







Operations to be avoided or prohibited

 Pay attention when operating the machine in an enclosed space as this may result in the risk of a buildup of hazardous gases.




- · If the machine is operated in the vicinity of a high-voltage line, there is a risk of death or serious injury.
- · Be aware of the height and working radius of the machine, and maintain the minimum safety distance.

Voltage	Minimum safety distance
6.6 kV	3 m (10 ft)
33.0 kV	4 m (13 ft)
66.0 kV	5 m (16 ft)
154.0 kV	8 m (26 ft)
275.0 kV	10 m (33 ft)



- In the event of contact with a high-voltage line, keep sitting on the operator's seat until the electric current has been shut down.
- · Warn any workers on the ground in the vicinity of the machine not to make contact with the machine.
- · If leaving the machine is unavoidable, jump down to a place free from any contact with the machine.
- Avoid operating the machine on soft ground, a slope or cliff as there is a risk that it may overturn. Pay special attention when it is raining as the rainfall may soften the ground.
- When operating or driving the machine in water, check the floor conditions, depth of water and flow rate, and make sure that the top roller and axle housing are not immersed in water.
- Do not operate the machine under adverse weather conditions caused by overcast skies, snow and rainfall.
- Do not turn or travel with the machine when the bucket is stuck in the ground.





Cautions when operating in specific areas

Operating in extremely cold environments


- Do not attempt to start, stop or turn the machine suddenly as this may cause it to slip. There is potential for the machine to slip.
- · Snow-covered or frozen ground may be slippery and dangerous.
- · Idle operation of the machine may be required to elevate the engine temperature during startup.
- An impact resulting from a sudden movement of the boom or the attachments at an extremely low temperature may cause serious damage to the machine.
- The working cycle or loading weight might be reduced to lower than those under normal conditions.
- · Follow these instructions when operation in cold environments:
 - Warm up the engine for 3~4 seconds when starting up the engine.
 - Always fully charge the battery. A discharged battery will freeze earlier than a fully charged battery.
 - Use engine oil and fuel that are appropriate for the temperature.
 - Keep the fuel tank full.
- Remove any moisture from the fuel tank, and change the fuel filter regularly.
- If the fuel filter is frozen, the flow of fuel may be blocked.
- Pour the proper volume of antifreeze into the coolant.
- Wait until the various parts of the machine reach the operating temperature after starting the engine.
- Make sure that every controller and function of the machine operates normally.
- Remove any dirt, snow and ice from the machine after completing the operation.

Operating in extremely hot environments

Continuous operation of the machine for a long period of time may cause the machine to overheat. Pay special attention to prevent overheating of parts such as the engine and the hydraulic system. Stop the machine and take a break if necessary.

Check the following conditions frequently:

- Check the level of the coolant in the radiator.
- Check the radiator grill for clogging by any debris, and remove them, if any.
- Check the level of the battery electrolyte.
- If the battery will not be used for a long period of time, store it in a cool place.
- Check the hydraulic system for oil leakage.
- Check the lubrication oil on the respective parts, and lubricate as needed.
- If the paint coating of any parts has been effaced or damaged, coat the parts with paints or treat them with an anti-rust additive.
- Do not park the machine under direct light for a long period of time.
- When parking or storing the machine outdoors, use the proper cover to protect the machine from sunlight and dust.



Operating in dusty or sandy environments

- Check the radiator grill for clogging by any debris, and remove any debris.
- Check the fuel system, and protect it from dust or sand when refueling.
- · Inspect the air cleaner regularly, and replace it if necessary.
- If the gauge lamp on the dashboard lights up and the buzzer sounds at the same time, clean or replace the air cleaner.
- Frequently check consumables such as hydraulic oil and lubrication oil, and change them if necessary. Protect against the introduction of dust or sand when changing the consumables.
- Check the air-conditioner and the heater filters regularly, and clean or replace them if necessary.
- · When parking or storing the machine outdoors, use the proper cover to protect the machine from dust and sand.

Operating in rainy or humid environments

- Do not operate the machine in areas where there is heavy rainfall or thick fog.
- If operating the machine in such areas is unavoidable, perform operation after ensuring sufficient field of vision.
 - Use lighting devices such as the head lamp and working light.
 - Warn any workers within the radius of operation of the machine.
- . Pay attention when operating the machine on smooth ground as there is a risk of it overturning.
- If the paint coating on any parts has been effaced or damaged, coat the parts with paint or treat them with an anti-rust additive.

Operating the machine in coastal areas

- Special care should be taken when operating the machine in coastal areas as exposed parts may be corroded easily.
- If the paint coating on any parts has been effaced or damaged, coat the parts with paint or treat them with an anti-rust additive.
- · Perform inspection and maintenance of the parts promptly.


Cautions during maintenance

Tools

- · Use the correct tools for each type of work.
- · Using improper tools may damage the machine and its parts.
- Using deteriorated or damaged tools may result in bodily injury.

Inspection and servicing

- · Prevent access to the machine by all unauthorized workers.
- · Prior to inspection, park the machine in a flat area and attach a 'Under Inspection' sign.
- · Clean the machine before inspection or maintenance.
 - When performing inspection or maintenance on a dirty machine, it may be difficult to diagnosis or detect the cause of a problem with the machine.
 - Dust or dirt accumulated on the machine may cause a worker to slip or fall.
 - Wear protective goggles and protective clothes when cleaning the machine using a compressed water.
 - Do not spray water directly on sensors or electric connectors (sensors or electrical connection units, etc.). If water gets into the electrical system, it can cause operational problems.
- Use proper lighting devices when operating the machine in a dark area.
- Use lighting devices that are explosion-proof when handling flammable materials such as fuel and hydraulic oil.
- · Never attempt to use a direct flame such as a cigarette lighter in lieu of the lighting device.
- · Check the level of the cooling water after stopping and sufficiently cooling down the engine.
- Sufficiently relieve the inside pressure before opening the cooling water cap.
- The cooling system contains basic components. Use caution to prevent the skin or eyes from coming into contact with the basic materials.
- · Exercise special care to protect the body from contact with hot fluid or parts.
- · Replace the filters only after shutting off and sufficiently cooling down the engine.
- · Slowly remove the operating oil filter plug to relieve the inside pressure.
- · Relieve the pressure from the hydraulic system before disconnecting any lines and fittings.







Collision or cutting

- · Never perform a maintenance while the engine is running.
- Never open or remove the engine hood while the machine is in operation.
- · If an inspection is required while the engine is running, two or more workers must perform the inspection.
- · Keep areas in the vicinity of rotating or moving parts clean.
- · Keep articles in the vicinity of the fan clean.
 - Wear safety gloves when handling the wire cables.
 - Wear protective goggles and protective clothes





Preventing fire and explosion

- · Use caution when handling fuels, lubrication oils, and coolant mixtures to prevent fire and explosion. Failure to comply may result in serious injury or death.
- · Oil that leaks on to a hot surface or electronic components may cause a fire.
- · Keep all fuels and lubrication oils in adequate containers.
- Do not smoke while refueling or while adding any fluids to the machine. Do not smoke near the fuel tank at anytime.
- Do not smoke in a space where battery electrolyte and other flammable materials are handled.
- Always keep all electrical lines, connectors, and clamps clean, and check whether they are securely connected on a regular basis.
- · If any electrical wire or connector is loose or damaged, repair it immediately.
- Do not weld or cut with gas cutter pipes or tubes that contains flammable fluids.

Cautions on decoupling the attachments

- · Do not allow unauthorized workers to access the machine.
- · Place the machine in a safe position.
- · Install safety fences around the machine.







Repair by welding

- · Only weld in an area where adequate facilities for welding are available.
- Welding work may be subject to risks of gas leak, flame and electric shock.
 - Welding should be performed only by a qualified welder.
- Take the following precautions when welding to avoid serious injury or death:
 - Separate and remove the battery to prevent battery explosion.
 - Perform direct heating in a place free from the risk of explosion.
 - Cover parts such as rubber hoses subject to damage by welding with flame-resistant materials.
 - Wear a welding helmet, protective clothes, protective gloves, and safety shoes.
 - Perform welding work in a well-ventilated place.
 - Remove all inflammable materials from areas in the vicinity of welding work.
 - Provide fire extinguishers.

Precautions to take when working on the machine

- · There is a risk of falling when working on the machine.
- · Keep the area around the workers' feet clean and tidy.
- · Do not spill oil or grease.
- · Do not leave tools lying on the floor.
- · Be careful on the floor when moving.
- · Never jump from the machine.
- When getting off the machine, use the step or handrail and get off the machine while keeping to the principle of threepoint contact.
- · Wear protective clothes if necessary.
- · Do not perform maintenance work in an area where no anti-slipping pads have been installed.
- · Replace anti-slipping pads and step treads with new ones if they have deteriorated or no longer function.







Cautions when working with the high-pressure line or hose

- · Make sure that the internal pressure is released before replacing or checking the high-pressure line or hose.
- · If the internal pressure is not released, serious injury may result.
- Take the following precautions to avoid serious injury or death:
 - Always check to make sure a working fire extinguisher is nearby
 - Leaked oil may penetrate the skin or cause serious injury.
 - Never check for oil leaks with your bare hands.
 - Check an oil leak using a wooden plate or cardboard.
 - Never bend or hit the high-pressure line hard.
 - Do not install a bent or damaged line or hose.
 - Make sure that all of the clamps and protective devices are properly installed.
- · Check the pipes and hoses regularly and replace any damaged parts if necessary.

Cautions on inspecting the counterweight

- · Failure to comply with these instructions may lead to serious injury or death.
- Never stand beneath the counterweight when installing or removing it.
- Make sure the condition of the lifting device is rated for the weight being lifted.
- · Make sure lifting device is in good working order and free of damage or defects.



Battery

- · The battery contains flammable materials.
- · Never smoke in the vicinity of the battery.
- The battery electrolyte is strong acid. Pay attention to prevent the skin and eyes from coming into contact with the electrolyte.
- If the battery electrolyte accidentally comes into contact with the body or clothes, immediately wash off the electrolyte with water.
- · If the battery electrolyte is frozen, do not use other devices to start the engine up.
- Always wear protective goggles and protective gloves when working on the battery.
- · Always keep the switch in the 'OFF' position when working on the battery.
- · Securely fasten the battery cap.
- Always disconnect the battery from the machine before charging the battery.
- · Disconnect the cathode (-) first when removing the battery.
- · Connect the anode (+) first when connecting the battery.
- Follow the safety procedures when jump starting or charging the battery. Improper connection of the cable may result in an explosion and serious injury.
- · Use a voltmeter when inspecting the charging system.
- Regularly inspect the battery cable, and replace it if damaged.
- A battery cable with exposed wires may cause a short if it comes into contact with the grounding surface.
- · A short circuit of the battery cable may cause heat from the battery current and result in a fire.
- If the wires of the ground cable are exposed between the battery and the master switch, the exposed wires make contact with the grounding surface and the current may bypass to the master switch. This may destabilize the machine operation.

Repair or replace the part before operating the machine.

Battery disconnection switch

- Do not turn off the battery disconnect switch while engine is running. There is a risk of damaging electrical system.
- The battery disconnect switch can be found under the left-hand door of the machine.
- Make sure to turn off the battery disconnect switch when welding or servicing electrical systems, and before clocking out.

Switchboard

- The relay and fuse can be found on the switchboard at the rear of the cab.
- Do not use the fuse that has a higher amperage than indicated on the decal. There is a risk of damaging electric circuits or catching fire.










Parking and Storage

Cautions on parking

- · Park the machine on flat ground.
- · If parking the machine on a slope is unavoidable, use wheel chocks to prevent the machine from moving.
- · Bring the bucket down and make firm contact with ground.
- Make sure that all of the switches are turned to the 'OFF' position.
- Do not turn off battery disconnect until led lamp at the disconnect goes off.
- Make sure that all of the controllers are turned to the neutral position.
- · Stop the engine, and withdraw the ignition key.
- · Close and lock the windshield, door and all covers.
- Install fences around the machine when parking it on a public road, and put up a warning sign.

Cautions on storage for a long period of time

- Park the machine in accordance to any state and local laws.
- When storing the machine for a month or longer, follow these instructions to prevent deterioration of the machine performance:
- Thoroughly clean the machine before storing.
- Inject sufficient lubrication oil and grease into the injection ports.
- If any of the machines fluids are low top them off. If any fluids are close to or in need of changing, do so before storing.
- Oils and coolant may deteriorate during storage based on the length of storage. Please take this into consideration before using the machine.
- The density of the oil may drop during storage.
- Apply an anti-rust additive to the exposed area of the piston rod of the cylinder in areas where it is likely to rust quickly.
- Keep the master switch mounted in the power box (or the toolbox on the left of the rear frame of the machine) turned 'OFF'.
- Keep the machine in a dry indoor environment.
 If storing the machine outdoors is unavoidable, store it on a wooden pallet.
- Keep all cylinders collapse so that the cylinder rods are not exposed.
- Bring the attachments right down to the ground, and keep the tracks immobile by placing wheel chocks.



Regular lubrication (during storage)

- · Breaking the lubrication film on parts may cause abnormal abrasion during the next operation.
- · Check the level of the engine oil and coolant when starting the engine up, and top them up if necessary.
- Thoroughly wipe off any oil from cylinder rod before operating machine as it will attract dust and debris.
- Start up the engine once a month, perform all functions.
 Operate machine utilizing all functions for a minimum of 15 minutes. Apply lubrication oil to every part.
- · Fully charge and store the battery.
- · If storing the excavator for longer than 6 months, disconnect the battery negative (-) terminal.



Visibility

Before you start the machine, perform a walk-around inspection in order to ensure that there are no hazards around the machine.

While the machine is in operation, constantly survey the area around the machine in order to identify potential hazards as hazards become visible around the machine.

Your machine may be equipped with visual aids. Some examples of visual aids are Closed Circuit Television(CCTV), AAVM(Advanced Around View Monitoring) and mirrors. Before operating the machine, ensure that the visual aids are in proper working condition and that the visual aids are clean.

If may not be possible to provide direct visibility on large machines to all areas around the machine, appropriate job site organization is required in order to minimize hazards that are caused by restricted visibility. Job site organization is a collection of rules and procedures that coordinates machines and people that work together in the same area.

Examples of job site organization include the following:


- · Safety instructions
- · Controlled patterns of machine movement and vehicle movement
- · Workers that direct traffic to move when it is safe
- · Restricted areas
- Operator training
- Warning symbols or warning signs on machines or on vehicles
- · A system of communication
- · Communication between workers and operators prior to approaching the machine

Modifications of the machine configuration by the user could result in a restriction of the machine visibility. In this case, a new risk assessment shall be performed according to ISO 5006:2017.

Restricted Visibility

The size and the configuration of this machine may result in areas that can not be seen when the operator is seated. The following illustration of visual map provides an approximate visual indication of areas of significant restricted visibility. This illustration indicates restricted visibility areas at ground level inside a radius of 12.00m (40 ft) from the operator on a machine only with the use of right side mirror and left side mirror installed. (without the use of optional visual aids.) This illustration provide areas of restricted visibility for distances outside a radius of 12.00m (40 ft).


This machine may be equipped with optional visual aids (CCTV or AAVM) that may provide visibility to some of the restricted visibility areas. For areas that are not covered by the optional visual aids, the job site organization must be utilized to minimize hazards of this restricted visibility.



< Top view of the machine at ground level visibility without use of optional visual aids >

★ The shaded areas indicate the approximate location of areas with significant restricted visibility. (Radius = 12 m / 34 ft)

There is restricted visibility to the area directly behind the machine with no optional visual aids. Failure to make sure the area is clear could result in serious injury or death. Make sure that the area is clear with the other person on the ground before you start the reverse movement.





< Top view of the machine at ground level visibility with use of optional visual aids >

★ The shaded areas indicate the approximate location of areas with significant restricted visibility. (Radius = 12 m / 34 ft)

SPECIFICATIONS

1. MAJOR COMPONENT






330F2SP01

2. SPECIFICATIONS

1) HX330 L


 \cdot 6.45 m (21' 2") BOOM and 3.20 m (10' 6") ARM



Description		Unit	Specification			
Operating weight		kg (lb)	33500 (73850)			
Bucket capacity (SAE heaped), standard		m³ (yd³)	1.44 (1.88)			
Overall length	Α		11220 (36' 10")			
Overall width, with 600 mm shoe	В		3280 (10' 9")			
Overall height of boom	С		3380 (11' 1")			
Superstructure width	D		2980 (9' 9")			
Overall height of cab	Е		3160 (10' 4")			
Ground clearance of counterweight	F		1200 (3' 11")			
Overall height of engine hood	G		2610 (8' 7")			
Overall height of handrail	G'		3350 (11' 0")			
Minimum ground clearance	Н	mm (ft-in)	500 (1' 8")			
Rear-end distance	I		3505 (11' 6")			
Rear-end swing radius	ľ		3570 (11' 9")			
Distance between tumblers	J		4030 (13' 3")			
Undercarriage length	K		4940 (16' 2")			
Undercarriage width	L		3280 (10' 9")			
Track gauge	М		2680 (8' 10")			
Track shoe width, standard	N		600 (24")			
Travel speed (low/high)		km/hr (mph)	3.4/5.9 (2.1/3.7)			
Swing speed		rpm	9.1			
Gradeability		Degree (%)	35 (70)			
Ground pressure (600 mm shoe)		kgf/cm²(psi)	0.65 (9.24)			
Max traction force		kg (lb)	27000 (59520)			

2) HX330 NL


\cdot 6.45 m (21' 2") BOOM and 3.20 m (10' 6") ARM



Description		Unit	Specification		
Operating weight		kg (lb)	33300 (73410)		
Bucket capacity (SAE heaped), standard		m³ (yd³)	1.44 (1.88)		
Overall length	Α		11220 (36' 10")		
Overall width, with 600 mm shoe	В		2990 (9' 10")		
Overall height of boom	С		3380 (11' 1")		
Superstructure width	D		2980 (9' 9")		
Overall height of cab	Е		3160 (10' 4")		
Ground clearance of counterweight	F		1200 (3' 11")		
Overall height of engine hood	G		2610 (8' 7")		
Overall height of handrail	G'	mm (ft-in)	3350 (11' 0")		
Minimum ground clearance	Н	111111 (11-111)	500 (1' 8")		
Rear-end distance	I		3505 (11' 6")		
Rear-end swing radius	ľ		3570 (11' 9")		
Distance between tumblers	J		4030 (13' 3")		
Undercarriage length	K		4940 (16' 2")		
Undercarriage width	L		2990 (9' 10")		
Track gauge	М		2390 (7' 10")		
Track shoe width, standard	N		600 (24")		
Travel speed (low/high)		km/hr (mph)	3.4/5.9 (2.1/3.7)		
Swing speed		rpm	9.1		
Gradeability		Degree (%)	35 (70)		
Ground pressure (600 mm shoe)		kgf/cm²(psi)	0.64 (9.10)		
Max traction force		kg (lb)	27000 (59520)		

3) HX330 L HIGH WALKER


\cdot 6.45 m (21' 2") BOOM and 3.20 m (10' 6") ARM



Description		Unit	Specification			
Operating weight		kg (lb)	36000 (79370)			
Bucket capacity (SAE heaped), standard		m³ (yd³)	1.44 (1.88)			
Overall length	Α		11150 (36' 7")			
Overall width, with 600 mm shoe	В		3470 (11' 5")			
Overall height of boom	С		3360 (11' 0")			
Superstructure width	D		2980 (9' 9")			
Overall height of cab	Е		3460 (11' 4")			
Ground clearance of counterweight	F		1500 (4' 11")			
Overall height of engine hood	G		2910 (9' 7")			
Overall height of handrail	G'		3650 (12' 0")			
Minimum ground clearance	Н	mm (ft-in)	765 (2' 6")			
Rear-end distance	I		3505 (11' 6")			
Rear-end swing radius	ľ		3570 (11' 9")			
Distance between tumblers	J		4030 (13' 3")			
Undercarriage length	K		4940 (16' 2")			
Undercarriage width	L		3470 (11' 5")			
Track gauge	М		2870 (9' 5")			
Track shoe width, standard	N		600 (24")			
Travel speed (low/high)		km/hr (mph)	3.4/5.9 (2.1/3.7)			
Swing speed		rpm	9.1			
Gradeability		Degree (%)	35 (70)			
Ground pressure (600 mm shoe)		kgf/cm²(psi)	0.69 (9.81)			
Max traction force		kg (lb)	27000 (59520)			

3. WORKING RANGE

1) HX330 L/NL




330F2SP05

Description			6.15 m (20' 2") Boom			
Description		2.2 m (7' 3") Arm	2.5 m (8' 2") Arm	3.2 m (10' 6") Arm	4.05 m (13' 3") Arm	2.2 m (7' 3") Arm
Max digging reach	Α	10330 mm (33'11")	10550 mm (34' 7")	11140 mm (36' 7")	11950 mm (39' 2")	10020 mm (32'10")
Max digging reach on ground	Α'	10110 mm (33' 2")	10330 mm (33'11")	10940 mm (35'11")	11760 mm (38' 7")	9800 mm (32' 2")
Max digging depth	В	6370 mm (20'11")	6670 mm (21'11")	7370 mm (24' 2")	8220 mm (26'12")	6160 mm (20' 3")
Max digging depth (8ft level)	B'	6160 mm (20' 3")	6470 mm (21' 3")	7210 mm (23' 8")	8080 mm (26' 6")	5950 mm (19' 6")
Max vertical wall digging depth	С	5980 mm (19' 7")	5920 mm (19' 5")	6360 mm (20'10")	7260 mm (23'10")	5710 mm (18' 9")
Max digging height	D	10220 mm (33' 6")	10170 mm (33' 4")	10310 mm (33'10")	10710 mm (35' 2")	9940 mm (32' 7")
Max dumping height	Е	7050 mm (23' 2")	7050 mm (23' 2")	7240 mm (23' 9")	7630 mm (25' 0")	6780 mm (22' 3")
Min swing radius	F	4700 mm (15' 5")	4550 mm (14'11")	4460 mm (14' 8")	4470 mm (14' 8")	4520 mm (14'10")
		189.3 [205.5] kN	189.3 [205.5] kN	189.3 [205.5] kN	189.3 [205.5] kN	189.3 [205.5] kN
	SAE	19300 [20950] kgf	19300 [20950] kgf	19300 [20950] kgf	19300 [20950] kgf	19300 [20950] kgf
Punkat diaging force		42550 [46200] lbf	42550 [46200] lbf	42550 [46200] lbf	42550 [46200] lbf	42550 [46200] lbf
Bucket digging force		211.8 [230.0] kN	211.8 [230.0] kN	211.8 [230.0] kN	211.8 [230.0] kN	211.8 [230.0] kN
	ISO	21600 [23450] kgf	21600 [23450] kgf	21600 [23450] kgf	21600 [23450] kgf	21600 [23450] kgf
		47620 [51700] lbf	47620 [51700] lbf	47620 [51700] lbf	47620 [51700] lbf	47620 [51700] lbf
		196.6 [213.4] kN	178.9 [194.2] kN	143.2 [155.5] kN	119.6 [129.9] kN	196.6 [213.4] kN
	SAE	20000 [21760] kgf	18200 [19810] kgf	14600 [15850] kgf	12200 [13240] kgf	20000 [21760] kgf
Arm around force		44190 [47980] lbf	40220 [43670] lbf	32190 [34950] lbf	26890 [29190] lbf	44190 [47980] lbf
Arm crowd force		202.8 [220.2] kN	185.1 [201.0] kN	147.1 [159.7] kN	122.7 [133.3] kN	202.8 [220.2] kN
	ISO	20700 [22450] kgf	18900 [20500] kgf	15000 [16290] kgf	12515 [13590] kgf	20700 [22450] kgf
		45600 [49510] lbf	41620 [45190] lbf	33070 [35900] lbf	27590 [29950] lbf	45600 [49510] lbf

[]: Power boost

2) HX330 L HIGH WALKER



330F2SP06

Description		6.45 m (21' 2") Boom							
Description		2.2 m (7' 3") Arm	2.5 m (8' 2") Arm	3.2 m (10' 6") Arm	4.05 m (13' 3") Arm	2.2 m (7' 3") Arm			
Max digging reach	Α	10330 mm (33'11")	10550 mm (34' 7")	11140 mm (36' 7")	11950 mm (39' 2")	10020 mm (32'10")			
Max digging reach on ground	A'	10040 mm (32'11")	10270 mm (33' 8")	10880 mm (35' 8")	11710 mm (38' 5")	9730 mm (31'11")			
Max digging depth	В	6100 mm (20' 0")	6400 mm (20'12")	7100 mm (23' 4")	7950 mm (26' 1")	5880 mm (19' 3")			
Max digging depth (8ft level)	B'	5890 mm (19' 4")	6200 mm (20' 4")	6940 mm (22' 9")	7800 mm (25' 7")	5680 mm (18' 8")			
Max vertical wall digging depth	С	5700 mm (18' 8")	5650 mm (18' 6")	6080 mm (19'11")	6980 mm (22'11")	5440 mm (17'10")			
Max digging height	D	10500 mm (34' 5")	10450 mm (34' 3")	10590 mm (34' 9")	10990 mm (36' 1")	10220 mm (33' 6")			
Max dumping height	Е	7330 mm (24' 1")	7330 mm (24' 1")	7520 mm (24' 8")	7910 mm (25'11")	7060 mm (23' 2")			
Min swing radius	F	4700 mm (15' 5")	4550 mm (14'11")	4460 mm (14' 8")	4470 mm (14' 8")	4520 mm (14'10")			
		189.3 [205.5] kN	189.3 [205.5] kN	189.3 [205.5] kN	189.3 [205.5] kN	189.3 [205.5] kN			
	SAE	19300 [20950] kgf	19300 [20950] kgf	19300 [20950] kgf	19300 [20950] kgf	19300 [20950] kgf			
Dualist dissing force		42550 [46200] lbf	42550 [46200] lbf	42550 [46200] lbf	42550 [46200] lbf	42550 [46200] lbf			
Bucket digging force		211.8 [230.0] kN	211.8 [230.0] kN	211.8 [230.0] kN	211.8 [230.0] kN	211.8 [230.0] kN			
	ISO	21600 [23450] kgf	21600 [23450] kgf	21600 [23450] kgf	21600 [23450] kgf	21600 [23450] kgf			
		47620 [51700] lbf	47620 [51700] lbf	47620 [51700] lbf	47620 [51700] lbf	47620 [51700] lbf			
		196.6 [213.4] kN	178.9 [194.2] kN	143.2 [155.5] kN	119.6 [129.9] kN	196.6 [213.4] kN			
	SAE	20000 [21760] kgf	18200 [19810] kgf	14600 [15850] kgf	12200 [13240] kgf	20000 [21760] kgf			
Arm around force		44190 [47980] lbf	40220 [43670] lbf	32190 [34950] lbf	26890 [29190] lbf	44190 [47980] lbf			
Arm crowd force		202.8 [220.2] kN	185.1 [201.0] kN	147.1 [159.7] kN	122.7 [133.3] kN	202.8 [220.2] kN			
	ISO	20700 [22450] kgf	18900 [20500] kgf	15000 [16290] kgf	12515 [13590] kgf	20700 [22450] kgf			
		45600 [49510] lbf	41620 [45190] lbf	33070 [35900] lbf	27590 [29950] lbf	45600 [49510] lbf			

[]: Power boost

4. WEIGHT

1) HX330 L, HX330 NL

lkene	HX3	330 L	HX330 NL		
ltem	kg	lb	kg	lb	
Upperstructure assembly					
· Main frame weld assembly	3910	8620	←	←	
· Engine assembly	710	1560	←	←	
· Main pump assembly	200	440	←	←	
· Main control valve assembly	220	490	←	←	
· Swing motor assembly	370	820	←	←	
· Hydraulic oil tank assembly	250	550	←	←	
· Fuel tank assembly	260	570	←	←	
· Counterweight	6000	13230	←	←	
· Cab assembly	500	1102	←	←	
· Radiator assy	230	510	←	←	
· Oil cooler assy	80	180	←	←	
Lower chassis assembly		•			
· Track frame weld assembly	3970	8750	3835	8450	
· Swing bearing	470	1040	←	←	
· Travel motor assembly	440	970	←	←	
· Turning joint	50	110	←	←	
· Tension cylinder	225	470	←	←	
· Idler	250	550	←	←	
· Sprocket	80	180	←	←	
· Carrier roller	40	90	←	←	
· Track roller	60	130	←	←	
Track-chain assembly (600 mm standard triple grouser shoe)	1880	4145	←	←	
Front attachment assembly					
· 6.45 m boom assembly	2560	5640	←	←	
· 3.2 m arm assembly	1170	2580	←	←	
· 1.44 m³ SAE heaped bucket	1230	2710	←	←	
· Boom cylinder assembly	305	670	←	←	
· Arm cylinder assembly	380	840	←	←	
D. I. I. P. I.	005	500			
· Bucket cylinder assembly	265	580	←	←	

^{*} This information is different with operating and transportation weight because it is not including harness, pipe, oil, fuel so on.

^{*} Refer to Transportation for actual weight information and Specifications for operating weight.

2) HX330 L HIGH WALKER

Item	kg	lb
Upperstructure assembly		
· Main frame weld assembly	3910	8620
· Engine assembly	710	1560
· Main pump assembly	200	440
· Main control valve assembly	220	490
· Swing motor assembly	370	820
· Hydraulic oil tank assembly	250	550
· Fuel tank assembly	260	570
· Counterweight	6000	13230
· Cab assembly	500	1100
· Radiator assy	230	510
· Oil cooler assy	80	180
Lower chassis assembly		
· Track frame weld assembly	6180	13620
· Swing bearing	470	1040
· Travel motor assembly	440	970
· Turning joint	50	110
· Tension cylinder	225	470
· Idler	250	550
· Sprocket	80	180
· Carrier roller	60	130
· Track roller	60	130
Track-chain assembly (600 mm standard triple grouser shoe)	1880	4145
Front attachment assembly		
· 6.45 m boom assembly	2560	5640
· 3.2 m arm assembly	1170	2580
· 1.44 m³ SAE heaped bucket	1230	2710
· Boom cylinder assembly	305	670
· Arm cylinder assembly	380	840
· Bucket cylinder assembly	265	580
· Bucket control linkage assembly	370	820

^{*} This information is different with operating and transportation weight because it is not including harness, pipe, oil, fuel so on.

^{*} Refer to Transportation for actual weight information and Specifications for operating weight.

5. LIFTING CAPACITIES

1) HX330 L

(1) 6.15 m (20' 2") boom, 2.2 m (7' 3") arm equipped with 1.44 m³ (SAE heaped) bucket and 600 mm (24") triple grouser shoe.

: Rating over-front : Rating over-side or 360 degree

			Load radius								At max. reach			
Load point height		3.0 m	3.0 m (9.8 ft) 4.5 m (14.7 ft) 6.0 m (19.6 ft) 7.5				7.5 m (24.5 ft)	Capacity		Reach			
		Ũ		ľ		Ū		H				m (ft)		
7.5 m (25.0 ft)	kg lb									*7380 *16270	6080 13400	7.69 (25.2)		
6.0 m (20.0 ft)	kg lb					*8280 *18250	*8280 *18250	*7970 *17570	6200 13670	*7440 *16400	4850 10690	8.61 (28.2)		
4.5 m	kg			*11980	*11980	*9530	8850	*8390	6060	6600	4230	9.16		
(15.0 ft)	lb .			*26410	*26410	*21010	19510	*18500	13360	14550	9330	(30.1)		
3.0 m	kg			*15470	13010	*11120	8350	9080	5830	6220	3950	9.39		
(10.0 ft) 1.5 m	lb kg			*34110 *17910	28680 12210	*24520 *12530	18410 7920	20020 8840	12850 5600	13710 6190	8710 3910	(30.8)		
(5.0 ft)	lb			*39480	26920	*27620	17460	19490	12350	13650	8620	(30.7)		
Ground	kg			*18640	11930	12410	7660	8670	5450	6530	4120	9.02		
Line	lb			*41090	26300	27360	16890	19110	12020	14400	9080	(29.6)		
-1.5 m	kg	*16990	*16990	*18160	11930	12320	7580	8630	5420	7400	4690	8.37		
(-5.0 ft)	lb	*37460	*37460	*40040	26300	27160	16710	19030	11950	16310	10340	(27.5)		
-3.0 m	kg	*22830	*22830	*16550	12120	*12300	7690			*8260	5970	7.29		
(-10.0 ft)	lb	*50330	*50330	*36490	26720	*27120	16950			*18210	13160	(23.9)		
-4.5 m	kg	*17800	*17800	*13080	12560									
(-15.0 ft)	lb	*39240	*39240	*28840	27690									

Note

- 1. Lifting capacity are based on SAE J1097 and ISO 10567.
- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The load point is a hook located on the back of the bucket.
- 4. *indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult your HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

▲ Failure to comply to the rated load can cause possible personal injury or property damage. Make adjustments to the rated load as necessory for non-standard configurations.

(2) 6.45 m (21' 2") boom, 2.2 m (7' 3") arm equipped with 1.44 m³ (SAE heaped) bucket and 600 mm (24") triple grouser shoe.

· Rating over-front · Rating over-side or 360 degree

			Load radius								max. rea	ch
Load point height		3.0 m	(9.8 ft)	4.5 m (14.7 ft)	6.0 m (19.6 ft)	7.5 m (24.5 ft)	Capa	acity	Reach
				J		Ū		J		P		m (ft)
7.5 m	kg									*7020	5490	8.07
(25.0 ft)	lb						12122	.=		*15480	12100	(26.5)
6.0 m	kg					*8120	*8120	*7600	6140	6900	4430	8.95
(20.0 ft)	lb					*17900	*17900	*16760	13540	15210	9770	(29.4)
4.5 m	kg			*12260	*12260	*9450	8660	*8150	5950	6140	3890	9.47
(15.0 ft)	lb			*27030	*27030	*20830	19090	*17970	13120	13540	8580	(31.1)
3.0 m	kg					*11050	8120	8930	5690	5790	3630	9.70
(10.0 ft)	lb					*24360	17900	19690	12540	12760	8000	(31.8)
1.5 m	kg					*12410	7680	8670	5450	5770	3600	9.66
(5.0 ft)	lb					*27360	16930	19110	12020	12720	7940	(31.7)
Ground	kg			*18350	11600	12150	7430	8500	5290	6060	3780	9.34
Line	lb			*40450	25570	26790	16380	18740	11660	13360	8330	(30.6)
-1.5 m	kg	*14500	*14500	*17770	11640	12080	7370	8460	5250	6810	4280	8.72
(-5.0 ft)	lb	*31970	*31970	*39180	25660	26630	16250	18650	11570	15010	9440	(28.6)
-3.0 m	kg	*22000	*22000	*16270	11850	12210	7480	,,,,,		*7830	5360	7.70
(-10.0 ft)	lb	*48500	*48500	*35870	26120	26920	16490			*17260	11820	(25.3)
-4.5 m	kg	*17710	*17710	*13290	12270					50	0	(=5.5)
(-15.0 ft)	lb	*39040	*39040	*29300	27050							

(3) 6.45 m (21' 2") boom, 2.5 m (8' 2") arm equipped with 1.44 m _3 (SAE heaped) bucket and 600 mm (24") triple grouser shoe.

· 🖟 : Rating over-front · 🚓 : Rating over-side or 360 degree

		Load radius									At ı	max. rea	ach	
Load po	oint	3.0 m	(9.8 ft)	4.5 m (14.7 ft)	6.0 m (19.6 ft)	7.5 m (24.5 ft)	9.0 m (29.4 ft)	Capa	acity	Reach
heigh	ıt	ľ		ŀ		ľ		ľ		ľ		Ů		m (ft)
7.5 m	kg											*6610	5190	8.34
(24.5 ft)	lb											*14570	11440	(27.4)
6.0 m	kg							*7220	6170			6590	4220	9.19
(19.6 ft)	lb							*15920	13600			14530	9300	(30.2)
4.5 m	kg			*11490	*11490	*9010	8710	*7820	5960			5880	3710	9.70
(14.7 ft)	lb			*25330	*25330	*19860	19200	*17240	13140			12960	8180	(31.8)
3.0 m	kg			*15000	12650	*10650	8130	*8660	5670			5560	3460	9.92
(9.8 ft)	lb			*33070	27890	*23480	17920	*19090	12500			12260	7630	(32.5)
1.5 m	kg			*17450	11780	*12090	7650	8640	5410	6410	3990	5520	3420	9.88
(4.9 ft)	lb			*38470	25970	*26650	16870	19050	11930	14130	8800	12170	7540	(32.4)
Ground	kg			*18220	11490	12090	7360	8440	5230			5780	3580	9.57
Line	lb			*40170	25330	26650	16230	18610	11530			12740	7890	(31.4)
-1.5 m	kg	*15100	*15100	*17870	11480	11980	7270	8370	5170			6450	4020	8.97
(-4.9 ft)	lb	*33290	*33290	*39400	25310	26410	16030	18450	11400			14220	8860	(29.4)
-3.0 m	kg	*22890	*22890	*16580	11660	12070	7350					*7820	4960	7.98
(-9.8 ft)	lb	*50460	*50460	*36550	25710	26610	16200					*17240	10930	(26.2)
-4.5 m	kg	*18960	*18960	*13950	12050	*10230	7640					*7180	*7180	6.42
(-14.7 ft)	lb	*41800	*41800	*30750	26570	*22550	16840					*15830	*15830	(21.1)

(4) 6.45 m (21' 2") boom, 3.2 m (10' 6") arm equipped with 1.44 m³ (SAE heaped) bucket and 600 mm (24") triple grouser shoe.

· Pating over-front · □ : Rating over-side or 360 degree

						Load	radius						At r	nax. re	ach
Load point	1.5 m	(5.0 ft)	3.0 m (10.0 ft)	4.5 m (15.0 ft)	6.0 m (20.0 ft)	7.5 m (25.0 ft)	9.0 m (30.0 ft)	Cap	acity	Reach
height															m (ft)
7.5 m kg (25.0 ft) lb									*5160 *11380	*5160 *11380			*5870 *12940	4510 9940	9.06 (29.7)
6.0 m kg (20.0 ft) lb									*6410 *14130	6300 13890			5880 12960	3740 8250	9.84 (32.3)
4.5 m kg	_						*8000	*8000	*7090	6040	*5360	4290	5300	3310	10.31
(15.0 ft) lb							*17640	*17640	*15630	13320	*11820	9460	11680	7300	(33.8)
3.0 m kg					*13300	13080	*9720	8270	*8020	5730	6570	4140	5020	3090	10.52
(10.0 ft) lb					*29320	28840	*21430	18230	*17680	12630	14480	9130	11070	6810	(34.5)
1.5 m kg					*16290	11990	*11360	7720	8650	5420	6390	3970	4970	3040	10.48
(5.0 ft) lb					*35910	26430	*25040	17020	19070	11950	14090	8750	10960	6700	(34.4)
Ground kg			*10320	*10320	*17800	11460	12070	7340	8400	5190	6260	3850	5160	3150	10.19
Line Ib			*22750	*22750	*39240	25260	26610	16180	18520	11440	13800	8490	11380	6940	(33.4)
-1.5 m kg	*11460	*11460	*14560	*14560	*18040	11320	11870	7160	8260	5060			5660	3470	9.63
(-5.0 ft) lb	*25260	*25260	*32100	*32100	*39770	24960	26170	15790	18210	11160			12480	7650	(31.6)
-3.0 m kg	*15430	*15430	*19550	*19550	*17260	11400	11870	7160	8270	5070			6690	4160	8.74
(-10.0 ft) lb		*34020	*43100	*43100	*38050	25130	26170	15790	18230	11180			14750	9170	(28.7)
-4.5 m kg			*21700	*21700	*15310	11680	*11330	7350					*7380	5670	7.37
(-15.0 ft) lb			*47840	*47840	*33750	25750	*24980	16200					*16270	12500	(24.2)
-6.0 m kg					*11240	*11240									
(-20.0 ft) lb					*24780	*24780									

(5) 6.45 m (21' 2") boom, 4.05 m (13' 3") arm equipped with 1.44 m $^{\circ}$ (SAE heaped) bucket and 600 mm (24") triple grouser shoe.

· 🖟 : Rating over-front · 🚓 : Rating over-side or 360 degree

						Load	radius						At r	nax. re	ach
Load point	1.5 m	(5.0 ft)	3.0 m ((10.0 ft)	4.5 m ((15.0 ft)	6.0 m ((20.0 ft)	7.5 m ((25.0 ft)	9.0 m ((30.0 ft)	Cap	acity	Reach
height			l l				U				U				m (ft)
7.5 m kg (25.0 ft) lb	- I												*5090 *11220	3700 8160	10.00 (32.8)
6.0 m kg	-										*4410 *9720	*4410 *9720	5020 11070	3120 6880	10.71 (35.1)
4.5 m kg	g								*6100	*6100	*5630	4330	4570	2780	11.13
(15.0 ft) lb			*17980	*17980	*11050	*11050	*8430	*8430	*13450 *7110	*13450 5780	*12410 *6360	9550 4130	10080 4340	6130 2600	(36.5)
(10.0 ft) lb			*39640	*39640	*24360	*24360	*18580	*18580	*15670	12740	*14020	9110	9570	5730	(37.1)
1.5 m kg (5.0 ft) lb	9		*10550 *23260	*10550 *23260	*14520 *32010	12330 27180	*10270 *22640	7820 17240	*8170 *18010	5420 11950	6360 14020	3930 8660	4290 9460	2540 5600	11.29 (37.0)
Ground k	-		*10920	*10920	*16810	11520	*11740	7330	8350	5130	6170	3750	4420	2620	11.03
-1.5 m kg		*9970	*24070 *13500	*24070 *13500	*37060	25400 11160	*25880 11760	16160 7050	18410 8140	11310 4940	13600 6050	8270 3650	9740 4780	5780 2850	(36.2)
(-5.0 ft) lb	9	1	*29760	*29760	*39180	24600	25930	15540	17950	10890	13340	8050	10540	6280	(34.5)
-3.0 m kg			*17090	*17090	*17640	11100	11650	6950	8060	4870	6040	3640	5480	3320	9.72
(-10.0 ft) lb	*28970		*37680	*37680	*38890	24470	25680	15320	17770	10740	13320	8020	12080	7320	(31.9)
-4.5 m kg			*21910	*21910	*16430	11260	11730	7030	8150	4950			*6870	4260	8.53
(-15.0 ft) lb		*36990	*48300	*48300	*36220	24820	25860	15500	17970	10910			*15150	9390	(28.0)
-6.0 m kg			*19740 *43520	*19740 *43520	*13170 *30230	11670 25730	*9910 *21850	7320 16140					*6610 *14570	6600 14550	6.71 (22.0)

2) HX330 NL

(1) 6.45 m (21' 2") boom, 2.2 m (7' 3") arm equipped with 1.44 m³ (SAE heaped) bucket and 600 mm (24") triple grouser shoe.

· Rating over-front · Rating over-side or 360 degree

						At	max. rea	ch				
Load po	oint	3.0 m	(9.8 ft)	4.5 m (14.7 ft)		6.0 m (19.6 ft)	7.5 m (24.5 ft)	Capa	acity	Reach
heigh	nt	Ū		Ū				H		m (ft)		
7.5 m (25.0 ft)	kg lb									*7020 *15480	4640 10230	8.07 (26.5)
6.0 m (20.0 ft)	kg lb					*8120 *17900	7760 17110	*7600 *16760	5180 11420	6850 15100	3700 8160	8.95 (29.4)
4.5 m (15.0 ft)	kg lb			*12260 *27030	11550 25460	*9450 *20830	7310 16120	*8150 *17970	5000 11020	6090 13430	3210 7080	9.47 (31.1)
3.0 m (10.0 ft)	kg lb					*11050 *24360	6790 14970	8880 19580	4750 10470	5750 12680	2980 6570	9.70 (31.8)
1.5 m (5.0 ft)	kg lb					12360 27250	6360 14020	8620 19000	4520 9960	5730 12630	2940 6480	9.66 (31.7)
Ground Line	kg lb			*18350 *40450	9450 20830	12070 26610	6130 13510	8440 18610	4370 9630	6020 13270	3100 6830	9.34 (30.6)
-1.5 m (-5.0 ft)	kg lb	*14500 *31970	*14500 *31970	*17770 *39180	9500 20940	12010 26480	6070 13380	8400 18520	4330 9550	6770 14930	3530 7780	8.72 (28.6)
-3.0 m (-10.0 ft)	kg lb	*22000 *48500	19730 43500	*16270 *35870	9690 21360	12130 26740	6170 13600			*7830 *17260	4460 9830	7.70 (25.3)
-4.5 m (-15.0 ft)	kg lb	*17710 *39040	*17710 *39040	*13290 *29300	10090 22240							

Note

- 1. Lifting capacity are based on SAE J1097 and ISO 10567.
- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The load point is a hook located on the back of the bucket.
- 4. *indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult your HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

▲ Failure to comply to the rated load can cause possible personal injury or property damage. Make adjustments to the rated load as necessory for non-standard configurations.

(2) 6.45 m (21' 2") boom, 2.5 m (8' 2") arm equipped with 1.44 m³ (SAE heaped) bucket and 600 mm (24") triple grouser shoe.

: Rating over-front : Rating over-side or 360 degree

			Load radius										max. rea	ach
Load po	oint	3.0 m	(9.8 ft)	4.5 m (14.7 ft)	6.0 m (19.6 ft)	7.5 m (24.5 ft)	9.0 m (29.4 ft)	Capa	acity	Reach
heigh	ıt	Ū		ŀ		ľ		ľ		J		Ů		m (ft)
7.5 m (24.5 ft)	kg lb											*6610 *14570	4380 9660	8.34 (27.4)
6.0 m (19.6 ft)	kg lb							*7220 *15920	5210 11490			6550 14440	3510 7740	9.19 (30.2)
4.5 m (14.7 ft)	kg lb			*11490 *25330	*11490 *25330	*9010 *19860	7350 16200	*7820 *17240	5010 11050			5840 12870	3050 6720	9.70 (31.8)
3.0 m	kg			*15000	10440	*10650	6800	*8660	4730			5520	2830	9.92
(9.8 ft) 1.5 m	lb kg			*33070 *17450	23020 9620	*23480 *12090	14990 6340	*19090 8580	10430 4480	6360	3270	12170 5480	6240 2780	(32.5) 9.88
(4.9 ft) Ground	lb kg			*38470 *18220	21210 9340	*26650 12010	13980	18920 8380	9880 4300	14020	7210	12080 5740	6130 2920	(32.4) 9.57
Line	lb			*40170	20590	26480	13360	18470	9480			12650	6440	(31.4)
-1.5 m (-4.9 ft)	kg lb	*15100 *33290	*15100 *33290	*17870 *39400	9340 20590	11900 26230	5970 13160	8310 18320	4240 9350			6400 14110	3290 7250	8.97 (29.4)
-3.0 m	kg	*22890	19360	*16580	9510	11990	6040					*7820	4110	7.98
(-9.8 ft) -4.5 m	lb kg	*50460 *18960	*18960	*36550 *13950	20970 9870	26430 *10230	13320 6330					*17240 *7180	9060 6120	(26.2) 6.42
(-14.7 ft)	lb	*41800	*41800	*30750	21760	*22550	13960					*15830	13490	(21.1)

(3) 6.45 m (21' 2") boom, 3.2 m (10' 6") arm equipped with 1.44 m 3 (SAE heaped) bucket and 600 mm (24") triple grouser shoe.

· Rating over-front · Rating over-side or 360 degree

		Load radius												At r	nax. re	ach
Load point		1.5 m	(5.0 ft)	3.0 m (10.0 ft)	4.5 m (15.0 ft)	6.0 m (20.0 ft)	7.5 m ((25.0 ft)	9.0 m (30.0 ft)	Capa	acity	Reach
height				Ů		Ū		ŀ		Ů		ľ		U		m (ft)
	kg lb									*5160 *11380	*5160 *11380			*5870 *12940	3780 8330	9.06 (29.7)
6.0 m	kg lb									*6410 *14130	5340 11770			5840 12870	3090 6810	9.84 (32.3)
4.5 m	kg lb							*8000 *17640	7520 16580	*7090 *15630	5090 11220	*5360 *11820	3570 7870	5260 11600	2700 5950	10.31 (33.8)
3.0 m	kg lb					*13300 *29320	10840 23900	*9720 *21430	6930 15280	*8020 *17680	4780 10540	6530 14400	3410 7520	4980 10980	2500 5510	10.52 (34.5)
1.5 m	kg lb					*16290 *35910	9820 21650	*11360 *25040	6400 14110	8600 18960	4480 9880	6350 14000	3250 7170	4930 10870	2450 5400	10.48 (34.4)
Ground				*10320 *22750	*10320 *22750	*17800 *39240	9320 20550	11990 26430	6030 13290	8340 18390	4260 9390	6220 13710	3130 6900	5120 11290	2540 5600	10.19 (33.4)
-1.5 m	kg lb	*11460 *25260	*11460 *25260	*14560 *32100	*14560 *32100	*18040 *39770	9180 20240	11790 25990	5860 12920	8210 18100	4140 9130	107.10		5620 12390	2820 6220	9.63 (31.6)
-3.0 m	kg lb	*15430 *34020	*15430 *34020	*19550 *43100	18810 41470	*17260 *38050	9260 20410	11790 25990	5860 12920	8220 18120	4150 9150			6640 14640	3410 7520	8.74 (28.7)
-4.5 m	kg lb	, <u>-</u>	,	*21700 *47840	19340 42640	*15310 *33750	9520 20990	*11330 *24980	6040 13320					*7380 *16270	4710 10380	7.37 (24.2)
-6.0 m	kg lb					*11240 *24780	10070 22200									, ,

3) HX330 L HIGH WALKER

(1) 6.45 m (21' 2") boom, 2.5 m (8' 2") arm equipped with 1.44 m³ (SAE heaped) bucket and 600 mm (24") triple grouser shoe.

· P : Rating over-front · ₽ : Rating over-side or 360 degree

			Load radius										max. rea	ach
Load po	oint	3.0 m	(9.8 ft)	4.5 m (14.7 ft)	6.0 m (19.6 ft)	7.5 m (24.5 ft)	9.0 m (29.4 ft)	Capa	acity	Reach
heigh	ıt	Ū		ľ		ľ		ľ		ľ		Ū		m (ft)
7.5 m (24.5 ft)	kg lb											*6620 *14590	5780 12740	8.53 (28.0)
6.0 m	kg							*7300	7120			*6720	4830	9.31
(19.6 ft)	lb							*16090	15700			*14820	10650	(30.5)
4.5 m	kg			*12140	*12140	*9300	*9300	*7960	6880			6410	4330	9.76
(14.7 ft)	lb			*26760	*26760	*20500	*20500	*17550	15170			14130	9550	(32.0)
3.0 m	kg			*15590	14610	*10950	9380	*8820	6590			6130	4100	9.93
(9.8 ft)	lb			*34370	32210	*24140	20680	*19440	14530			13510	9040	(32.6)
1.5 m	kg			*17710	13840	*12300	8920	9460	6340	7200	4840	6150	4100	9.84
(4.9 ft)	lb			*39040	30510	*27120	19670	20860	13980	15870	10670	13560	9040	(32.3)
Ground	kg			*18220	13610	*13030	8670	9290	6180			6510	4340	9.48
Line	lb			*40170	30000	*28730	19110	20480	13620			14350	9570	(31.1)
-1.5 m	kg	*16440	*16440	*17710	13640	*13030	8600	9240	6130			7340	4920	8.82
(-4.9 ft)	lb	*36240	*36240	*39040	30070	*28730	18960	20370	13510			16180	10850	(28.9)
-3.0 m	kg	*22420	*22420	*16220	13860	*12130	8720	•		•		*7780	6170	7.75
(-9.8 ft)	lb	*49430	*49430	*35760	30560	*26740	19220					*17150	13600	(25.4)
-4.5 m	kg	*17900	*17900	*13210	*13210									
(-14.7 ft)	lb	*39460	*39460	*29120	*29120									

Note

- 1. Lifting capacity are based on SAE J1097 and ISO 10567.
- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The load point is a hook located on the back of the bucket.
- 4. *indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.


The difference between the weight of a work tool attachment must be subtracted.

Consult your HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

▲ Failure to comply to the rated load can cause possible personal injury or property damage. Make adjustments to the rated load as necessory for non-standard configurations.

6. BUCKET SELECTION GUIDE

1) GENERAL BUCKET



					Recommendation								
Сар	acity	Wi	dth	Weight			6.15 m (20' 2") boom						
SAE heaped	CECE heaped	Without side cutter	With side cutter	_	2.2 m arm (7' 3")	2.5 m arm (8' 2")	3.2 m arm (10' 6")	4.05 m arm (13' 3")	2.2 m arm (7' 3")				
1.44 m³ (1.88 yd³)	1.25 m ³ (1.63 yd ³)	1410 mm (55.5")	1505 mm (59.3")	1230 kg (2710 lb)	0	0	0	•	0				
1.74 m ³ (2.28 yd ³)	1.50 m ³ (1.96 yd ³)	1640 mm (64.6")	1735 mm (68.3")	1370 kg (3020 lb)	0	0	•	•	0				
2.10 m ³ (2.75 yd ³)	1.83 m ³ (2.39 yd ³)	1780 mm (70.1")	1875 mm (73.8")	1500 kg (3310 lb)	•	•	•		•				

Applicable for materials with density of 2000 kgf/m³ (3370 lbf/yd³) or less

Applicable for materials with density of 1600 kgf/m³ (2700 lbf/yd³) or less

Applicable for materials with density of 1100 kgf/m³ (1850 lbf/yd³) or less


* These recommendations are for general conditions and average use.

Work tools and ground conditions have effects on machine performance.

Select an optimum combination according to the working conditions and the type of work that is being done.

Consult your HD Hyundai Construction Equipment dealer for information on selecting the correct boom-arm-bucket combination.

2) HEAVY DUTY AND ROCK-HEAVY DUTY BUCKET



	_					Red	commenda	tion	
Сар	acity	Wi	dth	Weight					6.15 m (20' 2") boom
SAE heaped	CECE heaped	Without side cutter	With side cutter		2.2 m arm (7' 3")	2.5 m arm (8' 2")	3.2 m arm (10' 6")	4.05 m arm (13' 3")	2.2 m arm (7' 3")
◆1.44 m³ (1.88 yd³)	1.25 m ³ (1.63 yd ³)	1480 mm (58.3")	-	1520 kg (3350 lb)	0	0	•	•	0
◆1.44 m³ (1.88 yd³)	1.25 m ³ (1.63 yd ³)	1470 mm (57.9")	-	1610 kg (3550 lb)	0	0	•	•	
◆1.63 m³ (2.09 yd³)	1.39 m ³ (1.82 yd ³)	1590 mm (62.6")	-	1690 kg (3730 lb)	•	•	•	•	0
◆1.73 m³ (2.26 yd³)	1.5 m ³ (1.96 yd ³)	1700 mm (66.9")	-	1760 kg (3880 lb)	•	•	•		
◆1.83 m³ (2.39 yd³)	1.59 m ³ (2.08 yd ³)	1770 mm (69.7")	-	1860 kg (4100 lb)	•	•	•		•

♦ : Heavy duty bucket

◆ : Rock-Heavy duty bucket

Applicable for materials with density of 2000 kg/m³ (3370 lb/yd³) or less

Applicable for materials with density of 1600 kg/m³ (2700 lb/yd³) or less

Applicable for materials with density of 1100 kg/m³ (1850 lb/yd³) or less

7. UNDERCARRIAGE

1) TRACKS

X-leg type center frame is integrally welded with reinforced box-section track frames. The design includes dry tracks, lubricated rollers, idlers, sprockets, hydraulic track adjusters with shock absorbing springs and assembled track-type tractor shoes with triple grousers.

2) TYPES OF SHOES

	Shapes		Triple grouser			
Model						
	Shoe width	mm (in)	600 (24)	700 (28)	800 (32)	900 (36)
HX330 L	Operating weight	kg (lb)	33500 (73850)	34070 (75110)	34450 (75950)	34830 (76790)
ПХ330 L	Ground pressure	kgf/cm² (psi)	0.65 (9.24)	0.56 (7.96)	0.50 (7.11)	0.45 (6' 40")
	Overall width	mm (ft-in)	3280 (10' 9")	3380 (11' 1")	3480 (11' 5")	3580 (11' 9")
	Shoe width	mm (in)	600 (24)	-	-	-
HV000 NII	Operating weight	kg (lb)	33300 (73410)	-	-	-
HX330 NL	Ground pressure	kgf/cm² (psi)	0.64 (9.10)	-	-	-
	Overall width	mm (ft-in)	2990 (9' 10")	-	-	-
	Shoe width	mm (in)	600 (24)	700 (28)	800 (32)	Double Grouser 710 (28)
HX330 L HIGH WALKER	Operating weight	kg (lb)	36000 (79370)	36570 (80620)	36950 (81460)	37480 (82630)
	Ground pressure	kgf/cm² (psi)	0.69 (9.81)	0.60 (8.53)	0.53 (7.54)	0.61 (8.67)
	Overall width	mm (ft-in)	3470 (11' 5")	3570 (11' 9")	3670 (12' 0")	3580 (11' 9")

3) NUMBER OF ROLLERS AND SHOES ON EACH SIDE

Item	Quantity
Carrier rollers	2EA
Track rollers	9EA
Track shoes	48EA

4) SELECTION OF TRACK SHOE

Suitable track shoes should be selected according to operating conditions.

Method of selecting shoes

Confirm the category from the list of applications in **table 2**, then use **table 1** to select the shoe. Wide shoes (categories B and C) have limitations on applications. Before using wide shoes, check the precautions, then investigate and study the operating conditions to confirm if these shoes are suitable.

Select the narrowest shoe possible to meet the required flotation and ground pressure. Application of wider shoes than recommendations will cause unexpected problem such as bending of shoes, crack of link, breakage of pin, loosening of shoe bolts and the other various problems.

* Table 1

Track shoe	Specification	Category
600 mm triple grouser	Standard	А
700 mm triple grouser	Option	В
710 mm double grouser	Option	В
800 mm triple grouser	Option	С
900 mm triple grouser	Option	С

* Table 2

Category	Applications	Applications
А	Rocky ground, river beds, normal soil	Travel at low speed on rough ground with large obstacles such as boulders or fallen trees
В	Normal soil, soft ground	 These shoes cannot be used on rough ground with large obstacles such as boulders or fallen trees Travel at high speed only on flat ground Travel slowly at low speed if it is impossible to avoid going over obstacles
С	Extremely soft gound (swampy ground)	 Use the shoes only in the conditions that the machine sinks and it is impossible to use the shoes of category A or B These shoes cannot be used on rough ground with large obstacles such as boulders or fallen trees Travel at high speed only on flat ground Travel slowly at low speed if it is impossible to avoid going over obstacles

8. SPECIFICATIONS FOR MAJOR COMPONENTS

1) ENGINE

Item	Specification
Model	Cummins QSL9
Туре	4-cycle turbocharged charger air cooled diesel engine
Cooling method	Water cooling
Number of cylinders and arrangement	6 cylinders, in-line
Firing order	1-5-3-6-2-4
Combustion chamber type	Direct injection type
Cylinder bore × stroke	114×145 mm (4.49"×5.69")
Piston displacement	8900 cc (543 cu in)
Compression ratio	17.8:1
Rated net horse power (SAE J1349)	287 Hp at 1800 rpm (214 kW at 2200 rpm)
Rated gross horse power (SAE J1995)	300 Hp at 1800 rpm (224 kW at 2200 rpm)
Maximum torque	145.3 kgf · m (1050 lbf · ft) at 1500 rpm
Engine oil quantity	30 ℓ (7.9 U.S. gal)
Wet weight	708 kg (1560 lb)
High idling speed	1800+50 rpm
Low idling speed	800 ± 50 rpm
Rated fuel consumption	164.8 g/Hp · hr at 1800 rpm
Starting motor	Denso 24V-7.8 kW
Alternator	Denso 24V-95A
Battery	2 × 12V × 160Ah

2) MAIN PUMP

Item	Specification	
Туре	Variable displacement tandem axis piston pumps	
Capacity	2 × 154 cc/rev	
Rated oil flow	$2 \times 277 \ \ell$ /min (73.2 U.S. gpm / 61.0 U.K. gpm)	
Rated speed	1800 rpm	

3) GEAR PUMP

Item	Specification	
Туре	Fixed displacement gear pump single stage	
Capacity	15cc/rev	
Maximum pressure	40 kgf/cm² (570 psi)	
Rated oil flow	26.3 ℓ /min (6.9 U.S. gpm/5.8 U.K. gpm)	

4) MAIN CONTROL VALVE

Item	Specification	
Туре	9 spools	
Operating method	Hydraulic pilot system	
Main relief valve pressure	350 kgf/cm² (4980 psi) [380 kgf/cm² (5400 psi)]	
Overload relief valve pressure	400 kgf/cm² (5690 psi)	

[]: Power boost

5) SWING MOTOR

Item	Specification	
Туре	Axial piston motor	
Capacity	156.9 cc/rev	
Relief pressure	300 kgf/cm² (4270 psi)	
Braking system	Automatic, spring applied hydraulic released	
Braking torque	84.4 kgf · m (610 lbf · ft)	
Brake release pressure	36.5 kgf/cm² (519 psi)	
Reduction gear type	2 - stage planetary	

6) TRAVEL MOTOR

Item	Specification	
Туре	Variable displacement axial piston motor	
Relief pressure	350 kgf/cm² (4980 psi)	
Capacity (max / min)	282.6/156.9 cc/rev	
Reduction gear type	2-stage planetary	
Braking system	Automatic, spring applied hydraulic released	
Brake release pressure	17 kgf/cm² (242 psi)	
Braking torque	134 kgf · m (969 lbf · ft)	

7) REMOTE CONTROL VALVE

Item		Specification
Туре		Pressure reducing type
Operating proceure	Minimum	6.5 kg/cm² (92 psi)
Operating pressure	Maximum	26 kg/cm² (370 psi)
Cinale execution atvalva	Lever	61 mm (2.4 in)
Single operation stroke	Pedal	123 mm (4.84 in)

8) CYLINDER

Item		Specification
Doom gulinday	Bore dia \times Rod dia \times Stroke	Ø150ר105×1480 mm
Boom cylinder	Cushion	Extend only
Arm adiador	Bore dia \times Rod dia \times Stroke	Ø160ר110×1685 mm
Arm cylinder	Cushion	Extend and retract
Dualizat audinder	Bore dia \times Rod dia \times Stroke	Ø140ר100×1285 mm
Bucket cylinder	Cushion	Extend only

^{*} Discoloration of cylinder rod can occur when the friction reduction additive of lubrication oil spreads on the rod surface.

9) SHOE

Item		Width	Ground pressure	Link quantity	Overall width
	Standard	☆600 mm (24")	0.65 kgf/cm² (9.24 psi)	48	3280 mm (10' 9")
HX330 L	Option	☆700 mm (28")	0.56 kgf/cm² (7.96 psi)	48	3380 mm (11' 1")
11X330 L		☆800 mm (32")	0.50 kgf/cm² (7.11 psi)	48	3480 mm (11' 5")
		☆900 mm (36")	0.45 kgf/cm² (6.40 psi)	48	3580 mm (11' 9")
HX330 NL	Standard	☆600 mm (24")	0.64 kgf/cm² (9.10 psi)	48	2990 mm (9' 10")
HX330 L H/WALKER	Standard	☆600 mm (24")	0.69 kgf/cm² (9.81 psi)	48	3470 mm (11' 5")
	Option	☆700 mm (28")	0.60 kgf/cm² (8.53 psi)	48	3570 mm (11' 9")
		☆800 mm (32")	0.53 kgf/cm² (7.54 psi)	48	3670 mm (12' 0")
		★710 mm (28")	0.61 kgf/cm² (8.67 psi)	48	3580 mm (11' 9")

☆ : Triple grouser★ : Double grouser

^{*} Discoloration does not cause any harmful effect on the cylinder performance.

10) BUCKET

Itam	Сара	acity	Tooth	Width	
Item	SAE heaped	CECE heaped	quantity	Without side cutter	With side cutter
	1.44 m³ (1.88 yd³)	1.25 m³ (1.63 yd³)	5	1410 mm (55.5")	1505 mm (59.3")
	1.74 m³ (2.28 yd³)	1.50 m³ (1.96 yd³)	6	1640 mm (64.5")	1735 mm (68.3")
	2.10 m³ (2.75 yd³)	1.82 m³ (2.39 yd³)	6	1780 mm (70.1")	1875 mm (73.8")
HX330 L HX330 NL	€1.44 m³ (1.88 yd³)	1.25 m³ (1.63 yd³)	5	1480 mm (58.3")	-
H/WALKER	◆1.44 m³ (1.88 yd³)	1.25 m³ (1.63 yd³)	5	1470 mm (57.9")	-
	◆1.63 m³ (2.09 yd³)	1.39 m³ (1.82 yd³)	5	1590 mm (62.6")	-
	◆1.73 m³ (2.26 yd³)	1.50 m³ (1.96 yd³)	5	1700 mm (66.9")	-
	◆1.83 m³ (2.39 yd³)	1.59 m³ (2.08 yd³)	6	1770 mm (69.7")	-

: Heavy duty bucket: Rock-Heavy duty bucket

9. RECOMMENDED OILS

HD Hyundai Construction Equipment genuine lubricating oils have been developed to offer the best performance and service life for your equipment. These oils have been tested according to the specifications of HD Hyundai Construction Equipment and, therefore, will meet the highest safety and quality requirements. We recommend that you use only HD Hyundai Construction Equipment genuine lubricating oils and grease officially approved by HD Hyundai Construction Equipment.

20 30 (68) (86) AE 30	
(68) (86)	
AE 30	
AE 30	
(00 = 0=	
er (32.5:67.5))
6 ★3	
68	
NO.2	
(=2 = 2 = 2	
pe (50 : 50)	
-	68

SAE : Society of Automotive Engineers

API : American Petroleum Institute

ISO : International Organization for Standardization

NLGI: National Lubricating Grease Institute

ASTM: American Society of Testing and Material

DEF: Diesel Exhaust Fluid, DEF compatible with AdBlue®

★ : Cold region (Russia, CIS, Mongolia)

★1: Ultra low sulfur diesel

- sulfur content ≤ 15 ppm

★2: Soft water

City water or distilled water

*3 : HD Hyundai Construction Equipment Bio Hydraulic Oil

- * Using any lubricating oils other than HD Hyundai Construction Equipment genuine products may lead to a deterioration of performance and cause damage to major components.
- * Do not mix HD Hyundai Construction Equipment genuine oil with any other lubricating oil as it may result in damage to the systems of major components.
- * Do not use any engine oil other than that specified above, as it may clog the diesel particulate filter(DPF).
- For HD Hyundai Construction Equipment genuine lubricating oils and grease for use in regions with extremely low temperatures, please contact HD Hyundai Construction Equipment dealers.


CONTROL DEVICES

1. CAB DEVICES

 The ergonomically designed console box and suspension type seat provide the operator with comfort.

2) ELECTRONIC MONITOR SYSTEM

- (1) The centralized electronic monitor system allows the status and conditions of the machine to be monitored at a glance.
- (2) It is equipped with a safety warning system for early detection of machine malfunction.



290F3CD01

2. CLUSTER

1) STRUCTURE

The cluster consists of LCD and switches as shown below. The LCD is to warn the operator in case of abnormal machine operation or conditions for the appropriate operation and inspection. Also, The LCD is to set and display for modes, monitoring and utilities with the switches.

The switches or touch screen are to set the machine operation modes.

- * The cluster installed on this machine does not entirely guarantee the condition of the machine. Daily inspection should be performed according to chapter 6, Maintenance.
- * When the cluster provides a warning immediately check the problem, and perform the required action.



380F3CD01A


* The warning lamp pops up and/or blinks and the buzzer sounds when the machine has a problem.

The warning lamp blinks until the problem is cleared. Refer to page 3-6 for details.

* This cluster is adjustable.

· Vertical (forward/backward) : each 15°

· Horizontal (left only): 8°



2) GAUGE

(1) Operation screen

When you first turn starting switch ON, the operation screen will appear.





290F3CD51A

- 1 RPM / Speed gauge
- 2 Engine coolant temperature gauge
- 3 Hydraulic oil temperature gauge
- 4 Fuel level gauge

- 5 DEF/AdBlue® level gauge
- 6 Tripmeter display
- 7 Eco guage
- 8 Accel dial gauge
- * Operation screen type can be set by the screen type menu of the display.
 Refer to page 3-27 for details.

(2) RPM / Speed gauge



① This display the engine speed.

(3) Engine coolant temperature gauge



290F3CD53

- ① This gauge indicates the temperature of coolant.
 - · White range: 40-107°C (104-225°F)
 - · Red range : Above 107°C (225°F)
- ② If the indicator is in the red range or lamp pops up and the buzzer sounds turn OFF the engine and check the engine cooling system.
- * If the gauge indicates the red range or lamp blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(4) Hydraulic oil temperature gauge



290F3CD54

- ① This gauge indicates the temperature of hydraulic oil.
 - · White range: 40-105°C(104-221°F)
 - · Red range : Above 105°C(221°F)
- ② If the indicator is in the red range or limit lamp pops up and the buzzer sounds reduce the load on the system. If the gauge stays in the red range, stop the machine and check the cause of the problem.
- * If the gauge indicates the red range or lamp blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(5) Fuel level gauge



- ① This gauge indicates the amount of fuel in the fuel tank.
- ② Fill the fuel when the red range, or | lamp pops up and the buzzer sounds.
- * If the gauge indicates the red range or lamp blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(6) DEF/AdBlue® Level gauge



- ① This gauge indicates the amount of liquid in the DEF/AdBlue® tank
- ② Fill the DEF/AdBlue® when the red range, or 👙 lamp pops up and the buzzer sounds.
- ③ Do not pour DEF/AdBlue® any more when the DEF/AdBlue® fill up warning lamp lights ON.
- Refer to page 3-11.
- * If the gauge indicates the red range or lamp blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(7) Tripmeter display



- ① This displays the engine the tripmeter.
- Refer to page 3-29 for details.

(8) Eco gauge



290F3CD58


- ① This gauge indicates the fuel consumption rate and machine load status. So that operators can be careful with fuel economy.
- ② The fuel consumption rate or machine load is higher, the number of segment is increased.
- ③ The color of Eco gauge indicates operation status.
 - · White: Idle operation
 - · Green : Economy operation
 - · Yellow : Non-economy operation at a medium level.
 - $\cdot \ \mathsf{Red} \quad : \mathsf{Non\text{-}economy} \ \mathsf{operation} \ \mathsf{at} \ \mathsf{a} \ \mathsf{high} \ \mathsf{level}.$

(9) Accel dial gauge



① This gauge indicates the level of accel dial.

3) WARNING LAMPS



Warning lamps and buzzer

Warnings	When error happened	Lamps and buzzer
All warning lamps	Warning lamp pops up on	· The pop-up warning lamp moves to the original position and
except below	the center of the LCD and	blinks, and the buzzer stops when ;
	the buzzer sounds	- the buzzer stop switch
		- the knob of the haptic controller is pushed
		- the lamp of the LCD is touched
<u>-•</u> 25	Warning lamp pops up on	\cdot The pop-up warning lamp moves to the original position and
	the center of the LCD and	light ON or blinks, and the buzzer stops when;
	the buzzer sounds	- the buzzer stop switch
		- the knob of the haptic controller is pushed
		- the lamp of the LCD is touched
		* Refer to page 3-11 for details.
	Warning lamp pops up on	\cdot The pop-up warning lamp moves to the original position and
	the center of the LCD and	lights ON, and the buzzer stops when 2 seconds elapsed.
	the buzzer sounds	
	Warning lamp pops up on	· The pop-up warning lamp moves to the original position and
	the center of the LCD and	blinks, and the buzzer stops when 2 seconds elapsed.
	the buzzer sounds	
	Warning lamp pops up on	* Refer to page 3-7 for details.
	the center of the LCD and	
	the buzzer sounds	

* Refer to page 3-16 for the buzzer stop switch and page 3-57 for the haptic controller.

(1) Engine coolant temperature warning lamp



290F3CD61

- ① Engine coolant temperature warning is indicated two steps.
 - 103°C over : The 🔄 lamp pops up and the buzzer sounds.
 - 107°C over: The \(\) lamp pops up and the buzzer sounds.
- 2 The pop-up , 1 lamps move to the original position and blinks when the buzzer stop switch when the buzzer is pushed. And the buzzer stops and [], (1) lamps keep blink.
- 3 Check the cooling system when the lamps keep blink.


(2) Hydraulic oil temperature warning lamp



290F3CD62

- ① Hydraulic oil temperature warning is indicated two steps.
 - 100°C over : The | ₪ lamp pops up and the buzzer sounds.
 - 105°C over: The /i lamp pops up and the buzzer sounds.
- ② The pop-up |b|, \triangle lamps move to the original position and blinks when the buzzer stop switch is pushed. And the buzzer stops and | | , / | lamps keep blink.
- 3 Check the hydraulic oil level and hydraulic oil cooling system.

(3) Fuel level warning lamp



290F3CD63

- ① This warning lamp pops up and the buzzer sounds when the level of fuel is below 69 ℓ (18.2 U.S. gal).
- ② Fill the fuel immediately when the lamp blinks.

(4) Emergency warning lamp



290F3CD64

- ① This warning lamp pops up and the buzzer sounds when each of the below warnings is happened.
 - Engine coolant overheating (over 107°C)
 - Hydraulic oil overheating (over 105°C)
 - MCU input voltage abnormal
 - Cluster communication data error
 - Engine ECM communication data error
- The pop-up warning lamp moves to the original position and blinks when the buzzer stop switch witch is pushed. And the buzzer stops.
- 2 When this warning lamp blinks, machine must be checked and serviced immediately.

(5) Engine oil pressure warning lamp



290F3CD65

- ① This warning lamp pops up and the buzzer sounds when the engine oil pressure is low.
- ② If the lamp blinks, shut OFF the engine immediately. Check oil level.

(6) Check engine warning lamp




290F3CD66

- ① This warning lamp pops up and the buzzer sounds when the communication between MCU and engine ECM on the engine is abnormal, or if the cluster received specific fault code from engine ECM.
- ② Check the communication line between them.

 If the communication line is OK, then check the fault codes on the cluster.

(7) Battery charging warning lamp



290F3CD67

- ① This warning lamp pops up and the buzzer sounds when the battery charging voltage is low.
- ② Check the battery charging circuit when this lamp blinks.

(8) Air cleaner warning lamp



290F3CD68

- ① This warning lamp pops up and the buzzer sounds when the filter of air cleaner is clogged.
- ② Check the filter and clean or replace it.

(9) Overload warning lamp (opt)



290F3CD69


- ① When the machine is overload, the overload warning lamp pops up and the buzzer sounds during the overload switch is ON. (if equipped)
- 2 Reduce the machine load.

(10) Engine stop warning lamp



- ① This warning lamp pops up and the buzzer sounds when 30 minutes elapsed with empty condition of the DEF/AdBlue® tank, stop the engine immediately and check the DEF/AdBlue® tank.
- ② Fill the DEF/AdBlue® immediately in the DEF/AdBlue® tank.
- * Refer to page 3-11.
- ③ This lamp pops up and the buzzer sounds when the stationary SCR system cleaning is not performed.
- * Refer to page 3-9.
- * Please contact your HD Hyundai Construction Equipment service center or local dealer.

(11) SCR (selective catalytic reduction) system cleaning warning lamp



290F3CD70

① This warning lamp lights ON or blinks when the SCR system cleaning is needed as table below.

	Warning lamp		
SCR	Check engine	Stop engine	
= <u>=</u> 3	<u>(I)</u>	STOP	Description
Off	Off	Off	Automatic SCR system cleaning
Blink	Off	Off	The status of a manual (stationary) SCR system cleaning when the SCR system cleaning switch has been activated. **Refer to page 3-10.**
On	On	Off	 The aftertreatment SCR system needs to be cleaned immediately. Engine power will be reduced automatically if action is not taken. ** The SCR system cleaning can be accomplished by: Changing to more challenging duty cycle. Performing a manual SCR system cleaning.
On	On	On	 These lamps will be ON when a stationary (manual) SCR system cleaning is not performed. Stop the engine immediately. Please contact your HD Hyundai Construction Equipment service center or local dealer.


(12) SCR system cleaning inhibit warning lamp



- ① This warning lamp indicates, when illuminated, the SCR system cleaning switch is pushed inhibit position, therefore automatic and manual SCR system cleaning can not occur.
- * Refer to the page 3-36 for the SCR system cleaning switch.

2609A3CD20

Manual SCR system cleaning



- Manual SCR system cleaning applies if the machine is in a fireproof area.
- ** To stop a manual SCR system cleaning before it has completed, set to the SCR system cleaning switch to the inhibit position or turn OFF the engine.
- ① Stop and park the machine.

- ② Pull the safety button and push the switch to position ② to initiate the manual SCR system cleaning.
- ** Refer to the page 3-36 for the SCR system cleaning switch operation.
- The engine speed may increase to 950~1050 rpm and SCR system cleaning begins and it will take approximately 20~60 minutes.
- The SCR system cleaning warning lamp will blink and HEST warning lamp will light ON during the SCR system cleaning is operating.
- ① The SCR system cleaning and/or HEST warning lamp will light OFF when the SCR system cleaning is completed.

(13) HEST (High exhaust system temperature) warning lamp



2609A3CD21

- ① This warning lamp indicates, when illuminated, that exhaust temperatures are high due to SCR system cleaning.
- ② The lamp will also illuminate during a manual SCR system cleaning.
- When this lamp is illuminated, be sure the exhaust pipe outlet is not directed at any surface or material that can melt, burn, or explode.
- ⚠ When this lamp is illuminated, the exhaust gas temperature could reach 800°C [1500°F], which is hot enough to ignite or melt common materials, and to burn people.
- ** The lamp does not signify the need for any kind of equipment or engine service; It merely alerts the equipment operator to high exhaust temperatures. It will be common for the lamp to illuminate on and off during normal equipment operation as the engine completes SCR system cleaning.

(14) DEF/AdBlue® level warning lamp




- ① This warning lamp indicates when ON or blinking, that the DEF/AdBlue® level is low as table below.
- It is recommended that the DEF/AdBlue® tank be filled completely full of the DEF/AdBlue® in order to correct any fault conditions.

290F3CD257

Warning lamp			
DEF/AdBlue® level	Check engine	Stop engine	December 2
- <u>*</u> -3;	<u>(I)</u>	STOP	Description
On	Off	Off	The DEF/AdBlue® level has fallen below the initial warning level (10%).
Blink	Off	Off	The DEF/AdBlue® level has fallen below the critical warning level (5%).
Blink	On	Off	 The DEF/AdBlue® level has fallen below the initial derate level (2.5%). The engine power will be limited automatically.
Blink	On	On	 This is happened when 30 minutes elapsed with empty conditions (0%) of the DEF/AdBlue® tank. The engine will enter the final derate level which may include low idle lock or engine shutdown with restart limitations. In order to remove the final derate, the DEF/AdBlue® tank must be filled to above 10 persent gauge reading.

(15) DEF/AdBlue® fill up warning lamp



290F3CD272

- ① This lamp lights ON when the DEF/AdBlue® tank is completely filled with DEF/AdBlue®.
- * Fill the tank with the DEF/AdBlue® after start switch ON and then turn OFF the start switch.
- Do not pour DEF/AdBlue® any more when this lamp lights
 ON. Otherwise DEF/AdBlue® tank may freeze and burst in
 winter season.

(16) Water in fuel warning lamp



- ① This warning lamp pops up and the buzzer sounds when the water separator is full of water or malfunctioning.
- When this lamp blinks, stop the machine and spill water out of the separator.

(17) Fail in SCR system warning lamp



300A3CD15

- ① This warning lamp indicates there are faults related to SCR system.
- ② The lamp lights ON when each of the below warnings is happened.
 - a. Low DEF/AdBlue® level
 - b. Poor quality of DEF/AdBlue®
 - c. Tempering or malfunction in the aftertreatment system
- ③ Once the lamp lights ON, the engine will derate shortly.
- ※ Please contact your HD Hyundai Construction Equipment service center or local dealer.

Warning lamp			
= :3>	Time	Torque reduction	
On	Fault detected	-	
On	After 2 h 30 min	· Torque is reduced to 50% of the highest torque.	
Blink	After 3 h 45 min	· Torque is reduced to 40% of the highest torque.	
Blink rapidly	After 4 hours	· Torque is reduced to 0% (low idling) of the hightest torque within 2~10 min.	

- * If a new fault occurs within 40 hours of operation since the first fault, the warning lamp will come ON. After 3 hours of operation, the warning lamp will blink rapidly and torque will be reduced to 0% (low idling) within 2~10 min.
- * Once the fault has been remedied and the engine control unit has received an indication that it is working, torque returns to the normal level.

(18) Eninge oil filter warning lamp



300A3CD306

- ① This warning lamp pops up and the buzzer sounds when the filter of eninge oil is clogged.
- ② Check the filter and clean or replace it.

4) PILOT LAMPS



290F3CD74A

(1) Mode pilot lamps

iviouc	node pilot lamps					
No	Mode	Pilot lamp	Selected mode			
		Р	Heavy duty power work mode			
1	Power mode	S	Standard power mode			
		Е	Economy power mode			
2	User mode	U	User preferable power mode			
		B	General operation - IPC speed mode			
			General operation - IPC balance mode			
3	Work mode		General operation - IPC efficiency mode			
	Work mode		Breaker operation mode			
		Ŕ	Crusher operation mode			
		丝	Lifting mode			
4	Travel mode		Low speed traveling			
·		*	High speed traveling			
5	Auto idle mode		Auto idle			

(2) Power max pilot lamp



- ① The lamp will be ON when pushing power max switch on the LH RCV lever.
- ② The power max function is operated maximum 8 seconds.
- Refer to the page 3-38 for power max function.

290F3CD78

(3) Preheat pilot lamp



290F3CD79

- ① Turning the start key switch ON position starts preheating in cold weather.
- ② Start the engine after this lamp is OFF.

(4) Warming up pilot lamp



290F3CD80

- ① This lamp is turned ON when the coolant temperature is below 30°C(86°F).
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C, or when 10 minutes have passed since starting the engine.

(5) Decel pilot lamp



290F3CD81

- ① Operating one touch decel switch on the RCV lever makes the lamp ON.
- ② Also, the lamp will be ON and engine speed will be lowered automatically to save fuel consumption when all levers and pedals are at neutral position, and the auto idle function is selected.
- One touch decel is not available when the auto idle pilot lamp is turned ON.
- ※ Refer to the page 3-38.

(6) Fuel warmer pilot lamp



290F3CD82

- ① This lamp is turned ON when the coolant temperature is below 10°C (50°F) or the hydraulic oil temperature 20°C (68°F).
- ② The automatic fuel warming is cancelled when the engine coolant temperature is above 60°C, and the hydraulic oil temperature is above 45°C since the start switch was ON position.

(7) Maintenance pilot lamp



290F3CD83

- ① This lamp will be ON when the consuming parts are needed to change or replace. It means that the change or replacement interval of the consuming parts remains below 30 hours.
- ② Check the message in maintenance information of main menu. Also, this lamp lights ON for 3 minutes when the start switch is ON position.
- ※ Refer to the page 3-23.

(8) Smart key pilot lamp (opt)



- 2 This lamp is red when the a authentication fails, green when succeeds.

 $\ensuremath{\mbox{\Large 1}}$ This lamp is ON when the engine is started by the start button.

* Refer to the page 3-24.

(9) Auto engine shutdown pilot lamp (opt)



220A3CD202A

- ① This lamp is turned ON when the auto engine shutdown is activated
- * Refer to the page 3-21-1.


5) SWITCHES



290F3CD86A


When some of the switches are selected, the pilot lamps are displayed on the LCD. Refer to the page 3-12 for details.

(1) Power mode switch




- ① This switch is to select the machine power mode and selected power mode pilot lamp is displayed on the pilot lamp position.
 - · P : Heavy duty power work.
 - · S : Standard power work.
 - · E : Economy power work.
- ② The pilot lamp changes $E \rightarrow S \rightarrow P \rightarrow E$ in order.

(2) Work mode switch



- ① This switch is to select the machine work mode, which shifts from general operation mode to optional attachment operation mode or lifting mode.
 - · 🖒 : General operation mode
 - · 🔊 : Breaker operation mode (if equipped)
 - · 🐞 : Crusher operation mode (if equipped)
 - · 🏡 : Lifting mode
 - Not installed : Breaker or crusher is not installed and lifting mode is not activated.
- Refer to the page 4-7 for details.

(3) User mode switch



- ① This switch is used to memorize the current machine operating status in the MCU and activate the memorized user mode.
 - · Memory : Automatically saved after key OFF.
 - · Action : Push this switch.
 - · Cancel : Push this switch once more.
- ② Refer to the page 3-20 for another set of user mode.

(4) Travel speed switch



- ① This switch is used to select the travel speed alternatively.
 - · Low speed : High speed
- Do not change the setting of the travel speed switch. Machine stability may be adversely affected.
- ▲ Personal injury can result from sudden changes in machine stability.

(5) Auto idle/ buzzer stop switch



- ① This switch is used to activate or cancel the auto idle function.
 - · Pilot lamp ON : Auto idle function is activated.
 - · Pilot lamp OFF: Auto idle function is cancelled.
- ② The buzzer sounds when the machine has a problem. In this case, push this switch and buzzer stops, but the warning lamp blinks until the problem is cleared.

(6) Escape/Camera switch



- ① This switch is used to return to the previous menu or parent menu.
- ② In the operation screen, pushing this switch will display the view of the camera on the machine (if equipped).

 Please refer to page 3-29 for the camera.
- ③ If the camera is not installed, this switch is used only ESC function.

(7) Work light switch



- ① This switch is used to operate the work light.
- ② The pilot lamp is turned ON when operating the switch.

(8) Head light switch



- ① This switch is used to operate the head light.
- ② The pilot lamp is turned ON when operating the switch.

(9) Intermittent wiper switch




- ① This switch is used to wipe operates intermittently.
- ② The pilot lamp is turned ON when operating the switch.

(10) Wiper switch



- $\ensuremath{\textcircled{1}}$ This switch is used to operate the window wiper.
- 2 Note that the wiper will self-park when switched off.
- ③ The pilot lamp is turned ON when operating the switch.
- If the wiper does not operate with the switch in ON position, turn the switch OFF immediately. Check the cause.
 If the switch remains ON, motor failure can result.

(11) Washer switch



- ① The washer liquid is sprayed and the wiper is operated only while pressing this switch.
- ② The pilot lamp is turned ON when operating the switch.

(12) Cab light switch



- ① This switch turns ON the cab light on the cab.
- ② The pilot lamp is turned ON when operating the switch.

(13) Beacon switch (opt)



- ① This switch turns ON the rotary light on the cab.
- ② The pilot lamp is turned ON when operating the switch.

(14) Overload switch (opt)



- ① When this switch turned ON, buzzer makes sound and overload warning lamp comes ON in case that the machine is overload.
- ② When it turned OFF, buzzer stops and warning lamp goes out.
- ♠ Overloading the machine could impact the machines stability which could result in tipover hazard. A tipover hazard could result in serious injury or death. Always activate the overload warning device before you handle or lift objects.

(15) Travel alarm switch



- ① This switch is to activate travel alarm function surrounding when the machine travels.
 - · ON : The travel alarm function is activated.
 - · OFF : The travel alarm function is not activated.

(16) Air conditioner quick touch switch



- ① This switch used to select air conditioner control mode.
- * Refer to the page 3-31.


(17) Main menu quick touch switch



- ① This switch is to activate the main menu in the cluster.
- ※ Refer to the page 3-19.

6) MAIN MENU

- You can select or set the menu by the haptic controller or touch screen.
 On the operation screen, tap MENU to access the main menu screen.
 On the sub menu screen, you can tap the menu bar to access functions or applications.
- · Operation screen



290F3CD102A


* Please refer to the haptic controller, page 3-57 for selection and change of menu and input value.

(1) Structure

No	Main menu	Sub menu	Description
1	Mode 290F3CD103	Work mode Work tool U mode power Boom/Arm speed Auto power boost IPC mode Auto engine shutdown (option) Initial mode Emergency mode	Breaker, Crusher, Lifting Mode, Not installed Breaker, Crusher, Not installed User mode only Boom speed, Arm speed Enable, Disable Speed mode, Balance mode, Efficiency mode One time, Always, Disable Key on initial mode, Accel initial mode / step Switch function
2	Monitoring 290F3CD104	Active fault Logged fault Delete logged fault Monitoring	MCU, Engine ECM, Air conditioner, AAVM (option) MCU, Engine ECM, Air conditioner, AAVM (option) All logged fault delete, Initialization canceled Machine information, Switch status, Output status
3	Management 290F3CD105	Fuel rate information Maintenance information Machine security Machine information Contact Service menu Clinometer Update	General record, Hourly, Daily, Mode record Replacement, Change interval oils and filters ESL mode setting, Password change Model, MCU, Monitor, Haptic / switch controller, RMCU, Relay drive unit, FATC, AAVM (option) A/S phone number, A/S phone number change Power shift, Operating hour, Breaker mode pump acting, EPPR current level, Overload pressure Clinometer setting Cluster, ETC device
4	Display 290F3CD106	Display item Clock Brightness Unit setup Language selection Screen type	Engine speed, Tripmeter A, Tripmeter B, Tripmeter C Clock Manual, Auto Temperature, Pressure, Flow, Distance, Date format Korean, English, Chinese, ETC A type, B type
5	Utilities 290F3CD107	Tripmeter Camera	3 kinds (A, B, C) Camera on/off, AAVM (option)

(2) Mode setup

① Work tool



- · Select on installed optional attachment
 - A: It can set the user's attachment.
 It is available in setting #1~#10.
 - B : Max flow Set the maximum flow for the attachment. Relief pressure Set the relief pressure.

2 U mode power



290F3CD112A

- Engine high idle rpm, auto idle rpm and pump torque (power shift) can be modulated and memorized separately in U-mode.
- · U-mode can be activated by user mode switch.

Step (■)	Engine speed (rpm)	Idle speed (rpm)	Power shift (bar)
1	1300	800	0
2	1400	850	3
3	1450	900	6
4	1500	950	9
5	1550	1000 (auto decel)	12
6	1600	1050	16
7	1650	1100	20
8	1700	1150	26
9	1750	1200	32
10	1800	1250	38

*One touch decel & low idle: 900 rpm

3 Boom/Arm speed



· Boom speed

Boom priority function can be activated or cancelled
 Enable - Boom up speed is automatically adjusted as working conditions by the MCU.
 Disable - Normal operation

· Arm speed

Arm regeneration function can be activated or cancelled.
 Enable - Arm in speed is up.

Disable - Normal operation.

4 Auto power boost



290F3CD117A

- · The power boost function can be activated or cancelled.
 - Enable The digging power is automatically increased as working conditions by the MCU. It is operated max 8 seconds.

Disable - Not operated.

⑤ IPC mode



- · The IPC mode can be selected by this menu.
 - Speed mode
 - Balance mode (default)
 - Efficiency mode
- · This mode is applied only general operation mode of the work tool mode.
- * Please update the cluster programs if this mode is not displayed in the mode setup menu. Refer to the page 3-25-1.

6 Automatic engine shutdown (option)



- · The automatic engine shutdown function can be set by this menu.
 - One time
 - Always
 - Disable
 - Wait time setting: Max 40 minutes, min 2 minutes

7 Initial mode



- · Key on initial mode
 - Selected the power mode is activated when the engine is started.
- · Accel initial mode
 - Last setting value
 - User setting value
- · Accel initial step
 - 0~9 step

8 Emergency mode



- · This mode can be use when the switches are abnormal on the cluster.
- · The cluster switches will be selected by touched each icon.

(3) Monitoring

① Active fault



· The active faults of the MCU, engine ECM, air conditioner or AAVM (option) can be checked by this menu.

2 Logged fault



• The logged faults of the MCU, engine ECM, air conditioner or AAVM (option) can be checked by this menu.

3 Delete logged fault



• The logged faults of the MCU, engine ECM, air conditioner or AAVM (option) can be deleted by this menu.

4 Monitoring



- The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu (Analog input).
- The switch status or output status can be confirmed by this menu (Digital input & Digital output).
- . The activated switch or output pilot lamps
 are light ON.

(4) Management

① Fuel rate information





General record (A)

- Average fuel rate (left) (from "Reset" to now)
 Fuel consumption devided by engine run time (service meter time).
- A days fuel used (right)
 Fuel consumption from 24:00 (or "Reset" time) to now (MCU real time).

· Hourly record (B)

- Hourly fuel rates for past 12 hours (service meter time).
- No record during key-off time.
- One step shift to the right for every one hour.
- Automatic deletion for 12 hours earlier data.
- All hourly records deletion by "Reset".

· Daily record (C)

- Daily fuel consumption for past seven days (MCU real time).
- No record during key-off time.
- One step shift to the right at 24:00 for every day.
- Automatic deletion for 7 days earlier data.
- All daily records deletion by "Reset".

· Mode record (D)

- Average fuel rate for each power mode/accel dial (at least 7) from "Reset" to now.
- No record during idle.
- All mode records deletion by "Reset".









210WF3CD16

2 Maintenance information



- · Alarm lamp () is ON when oil or filter needs to be changed or replaced.
- · Replacement : The elapsed time will be reset to zero (0).
- · Change interval: The change or replace interval can be changed in the unit of 50 hours.
- * Refer to the maintenance chart for further information of maintenance interval.

3 Machine security



· ESL mode setting

- ESL: Engine Starting Limit
- ESL mode is desingned to be a theft deterrent or will prevent the unauthorized operation of the machine.
- When you Enable the ESL mode, the password will be required when the starting switch is turned to the on position.
- Machine security

Disable: ESL function is disabled and password is not required to start engine.

Enable (always): The password is required whenever the operator starts engine.

- Interval: The password is required when the operator starts engine first. But the operator can restart the engine within the interval time without inputting the password. The interval time can be set to a maximum 4 hours.


※ Default password : 00000 +
✓

※ Password length: (5~10 digits) +

✓ - Smart key (option) : Refer to next page.

Password change


- The password is 5~10 digits.



* Before first use, please set user password and owner password in advance for machine security.

290F3CD138A

- Smart key



- · Smart key is registered when equipped with optional smart key. If smart key is not inside of the cabin, authentication process fails and the password is needed.
- · Tag management menu is activated when the Smart key menu is Enabled.

You can register and delete the tags.

- Tag management

· When registering a tag : Only the tag you want to register must be in the cabin.

Delete Tag

✓ oĸ


290F3CD006

 \cdot When deleting a tag : All registered tags are deleted.



Deleting

ESL Mode



290F3CD005

4 Machine Information



· This can confirm the identification of the model information (ECU), MCU, monitor, haptic controller, switch controller, RMCU, relay driver unit, FATC (air conditioner controller), AAVM (opt).

⑤ Contact (A/S phone number)



Enter the new A/S phone number

6 Service menu




- Power shift (standard/option): Power shift pressure can be set by option menu.
- · Operating hours: Operating hours since the machine line out can be checked by this menu.
- · Breaker mode pump acting (1 pump/2 pump)
- · EPPR current level (attach flow EPPR 1 & 2, boom priority EPPR, attach relief pressure EPPR 1& 2)
- Overload pressure: 100 ~ 350 bar

7 Clinometer



- · When the machine is on the flatland, if tap the "initialization", the values of X, Y reset "0".
- · You can confirm tilt of machine in cluster's operating screen.

8 Update (cluster & ETC devices)



- · ETC devices and cluster can be updated through CAN 2 network.
- · Insert USB memory stick which includes program files, start download.

(5) Display

① Display item




- · The center display type of the LCD can be selected by this menu.
- The engine speed or each of the tripmeter (A,B,C) is displayed on the center display.

2 Clock



- The first line's three spots "**/**/***" represent Month/Day/Year each.
- The second line shows the current time. (0:00~23:59)

3 Brightness



· If "Auto" is chosen, brightness for day and night can be differently set up. Also by using the bar in lower side, users can define which time interval belongs to day and night. (in bar figure, white area represents night time while orange shows day time)

4 Unit



· Temperature : $^{\circ}C \leftrightarrow ^{\circ}F$

· Pressure : bar \leftrightarrow MPa \leftrightarrow kgf/cm²

 $\begin{array}{ll} \cdot \ \, \text{Volume} & : \ell \longleftrightarrow \text{gal} \\ \cdot \ \, \text{Flow} & : \text{lpm} \longleftrightarrow \text{gpm} \\ \cdot \ \, \text{Distance} & : \text{km} \longleftrightarrow \text{mile} \end{array}$


· Date format : $yy/mm/dd \leftrightarrow mm/dd/yy \leftrightarrow dd-mm-yy$

5 Language



· User can select preferable language and all displays are changed the selected language.

6 Screen type



(6) Utilities

① Tripmeter



- · Maximum 3 kinds of tripmeters can be used at the same time.
- · Each tripmeter can be turned on by choosing "Start" while it also can be turned off by choosing "Stop".
- · If the tripmeter icon is activated in the operation screen, it can be controlled directly there.

② Camera setting

- · If the rear camera is not installed on the machine, set disable.
- · If the rear camera installed on the machine, set enable.



· In the operation screen, rear camera screen show up when ESC/CAM button is pushed.



- 4 AAVM (All Around View Monitoring, option)
- The AAVM buttons of the cluster consist of ESC/CAM and AUTO IDLE/Buzzer stop.



- Escape button
- · It will enter into the AAVM mode from the beginning screen if the AAVM is installed.
- · While in the AAVM mode, select the ESC button to return to the beginning screen.



- Buzzer stop button
- In AAVM mode, it detects surrounding pedestrians or objects and the warning buzzer sounds.
- · User can turn OFF the warning sound by pressing buzzer stop button.



- · When the worker or pedestrian go to the green line (radius 5 m), an external danger area of equipping on the cluster screen, the warning buzzer sounds and it displays the blue rectangular box for the recognition of the worker and pedestrian.
 - At this time, the operator should stop work immediately, and stop the buzzer by pressing the buzzer stop button. And then, please work after you check whether the danger factors are solved.




- When the worker or pedestrian go inside of red line (radius 3 m), an internal danger area of equipping on the cluster screen, the warning buzzer sounds and it displays the red rectangular box for the recognition of the worker and pedestrian.
 - At this time, the operator should stop work immediately, and stop the buzzer by pressing the buzzer stop button. And then, please work after you check whether the danger factors are solved.
- In AAVM mode, a touch screen of the LCD is available only. The multimodal dial of the haptic controller is not available.

7) AIR CONDITIONER AND HEATER

Full auto air conditioner and heater system automatically keeps the optimum condition in accordance with operator's temperature configuration sensing ambient and cabin inside temperature.

· Location of air flow ducts




Cluster LCD









* Haptic controller : Refer to page 3-57.

290F3CD201A

(1) Power switch



- ① This switch makes the system ON/OFF.

 Just before the power OFF, set values are stored.
- ② Default setting values

Function	Air conditioner	In/outlet	LCD	Temperature	Mode
Value	OFF	Inlet	OFF	Previous sw OFF	Previous sw OFF

(2) Air conditioner switch



- ① This switch turns the compressor ON/OFF.
- ** Air conditioner operates to remove vapor and drains water through a drain hose. Water can be sprayed into the cab in case that the drain cock at the ending point of drain hose has a problem.

In this case, exchange the drain cock.

(3) Auto switch




① Auto air conditiner and heater system automatically keeps the optimum condition in accordance with operator's temperature configuration sensing ambient and cabin inside temperature.

(4) Setting temperature



① Display the temperature setting out.

(5) Temperature switch



- ① Setting temperature indication
 - · Lo (17°C), 17.5~31.5°C, Hi (32°C)
- ② Max cool and max warm beeps 5 times.
- The max cool or the max warm position operates as following table.

Temperature	Compressor	Fan speed	In/outlet	Mode
Max cool	ON	Hi (8 step)	Recirculation	Face
Max warm	OFF	Hi (7 step)	Fresh	Def/Foot


- ④ Temperature unit can be changed between celsius (°C) and fahrenheit (°F)
 - a. Default status (°C)
 - b. Push Up/Down temperature switch simultaneously more than
 5 second displayed temperature unit change (°C → °F)

(6) Fan speed switch



- ① Fan speed is controlled automatically by setted temperature.
- 2 This switch controls fan speed manually.
 - · There are 8 up/down steps to control fan speed.
 - · The maximum step or the minimum step beeps 5 times.

(7) Fan speed



① Steps 1 through 8 to display the amount of wind.

(8) Fresh air/air recirculation switch



- ① It is possible to change the air-inlet method.
- a. Fresh air (ᠫ)
 Inhaling air from the outside.
- b. Air recirculation (国)
 It recycles the heated or cooled air to increase the energy efficiency.
- * Change air occasionally when using recirculation for a long time.
- * Check out the fresh air filter and the recirculation filter periodically to keep a good efficiency.

(9) Air mode switch



① Operating this switch, it beeps and displays symbol of each mode in order. (Face → Face/Rear → Face/Rear/Foot → Foot → Def/Foot)

		Face	Face/Rear	Face/Rear/Foot	Foot	Def/Foot
Mod swit		کیْ	ري	ری	ے گے۔	PĴ.
	Α	•	•	•		
O. 4164	В		•	•		
Outlet	С			•	•	•
	D					•


When defroster mode operating, FRESH AIR/AIR RECIRCU-LATION switch turns to FRESH AIR mode and air conditioner switch turns ON.

8) SELF DIAGNOSIS FUNCTION

- $\hbox{(1) Diagnostic methods: Diagnostic information window, select}\\$
- (2) Diagnostic indication (Displays fault)

Fault code	Description	Fail safe function	
F01 Ambient temperature sensor open F02 Ambient temperature sensor short		20°C alternate value control	
F04	Cab inside temperature sensor short	25°C alternate value control	
F05	Evaporate temperature sensor open	0°C alternate value control	
F06	Evaporate temperature sensor short	0°C alternate value control	
F07	Null	-	
F08	Null	-	
F09	Mode 1 actuator open/short	The alternate value is face	
F10	Mode 1 actuator drive circuit malfunction	If not, the alternate value is Def/Foot	
F11	Intake actuator open/short	The alternate value is air recirculation	
F12	Intake actuator drive circuit malfunction	The alternate fresh air	
F13	Temperature actuator open/short	If opening amount is 0 %, the alternate value is 0 %	
F14	Temperature actuator drive circuit malfunction	If not, the alternate value is 100 %	
F15	Null	-	
F16	Null	-	

3. SWITCHES



1) STARTING SWITCH & STARTING BUTTON (OPT)






Starting button with smart key tag (opt)

- (1) There are three positions, OFF, ON and START.
 - $\cdot \bigcirc$ (OFF) \quad : None of electrical circuits activate.
 - · | (ON) : All the systems of machine operate.
 - · (START) : Use when starting the engine.

Release key immediately after starting.

- If you turn ON the starting switch in cold weather, the fuel warmer is automatically operated to heat the fuel by sensing the coolant temperature. Start the engine in 1~2 minutes after turning ON the starting switch. More time may take according to ambient temperature.
- ※ Key must be in the ON position with engine running to maintain electrical and hydraulic function and prevent serious machine damage.

2) MASTER SWITCH



- (1) This switch is used to shut off the entire electrical system.
- (2) I: The battery remains connected to the electrical system.
 - O: The battery is disconnected to the electrical system.
- Never turn the master switch to O (OFF) with the engine running. Engine and electrical system damage could result.
- M. Off the master switch after purging lamp OFF.

3) QUICK CLAMP SWITCH (option)



- (1) This switch is used to engage or disengage the moving hook on quick clamp.
- Refer to the page 8-6 for details.

4) SCR (selective catalytic reduction) SYSTEM CLEANING SWITCH



- (1) This switch is used to select the SCR system cleaning.
- (2) Inhibit position (1)
- ① The inhibit position disallows any automatic or manual SCR system cleaning.
- ② This may be used by operator to prevent SCR system cleaning when the machine is operating in a hazardous environment is concerned about high temperature.
- ③ It is strongly recommended that this position is only activated when high temperatures may cause a hazardous condition.
- (3) Auto position (3)

This position will initiate a automatic SCR system cleaning.

(4) Manual position (2)

- ① This position will only initiate a manual SCR system cleaning when the machine is in non-mission condition, engine must run at low idle speed and SCR system levels are high enough to allow cleaning.
- ② HEST lamp will be illuminated during the entire SCR system cleaning.
- ※ Refer to the page 3-10 for ditails.
- * This switch can be move to the manual position (2) only when the safety button is pulled to backward.
- Also, this switch return to the auto position when released the manual position (2).

5) AIR COMPRESSOR SWITCH (option)



- (1) This switch is used to activate the air compressor.
- (2) The indicator lamp is turned on when operating the switch.

6) LOWER WIPER AND WASHER SWITCH (option)



- (1) The washer liquid is sprayed and the wiper is operated only while pressing this switch.
- (2) The pilot lamp is turned ON when operating the switch.

7) BOOM FLOATING SWITCH (option)




- (1) This mode is used to smooth boom operation.
- (2) Rod and head of boom cylinder are connected to the tank at the same time. So boom can be moved by the ground shape though only arm operation.

8) TRAVEL STRAIGHT SWITCH (option)




(1) When the travel straight switch is in the ON position, the machine will travel straight by use of only the left pedal or the left lever.

9) HORN SWITCH




(1) This switch is at the top of right side control lever. On pressing, the horn sounds.

10) BREAKER OPERATION SWITCH



(1) On pressing this switch, the breaker operates only when the breaker operation mode is selected.

11) ONE TOUCH DECEL SWITCH



- (1) This switch is used to actuate the deceleration function quickly.
- (2) The engine speed is increased to previous setting value by pressing the switch again.
- (3) One touch decel function is available only when the auto idle pilot lamp is turned OFF.

12) POWER MAX SWITCH



- (1) This switch activate power max function. When this switch is kept pressed, hydraulic power of work equipment will be increased to approx 110 percent during 8 seconds.
- (2) After 8 seconds, function is cancelled automatically even the switch keeps pressed.
- » Do not use for craning purposes.

13) EMERGENCY ENGINE STOP SWITCH



- (1) This switch is used to emergency stop the engine.
- * Be sure to keep the emergency switch on the release position when restart the engine.

14) SWING LOCK SWITCH (option, #0055-)



(1) When the switch is pressed ON position, the swing parking brake is locked and swing control is not available by shut off the swing pilot pressure to the swing spool.


15) FINE SWING SWITCH (option, #0055-)



- (1) When the switch is pressed ON position, fine swing valve is operated and swing parking brake is released with below condition.
 - Swing lever operated
 Enhanced soft swing is implement to allow smooth start and stop.
 - ② Boom up lever operated

 Further control is possible by allowing free spins in lifting operation for offset loads.
 - ③ Travel lever operated Reduces the shaking of an object that is lifted.
- ⚠ If the machine is operating on a slope with the switch in this position, swing motion may become uncontrollable which could result in property damage, personal injury or death. Do not use this position when the machine is operating on a slope.

4. LEVERS AND PEDALS




290F3CD16

1) LH CONTROL LEVER



- (1) This joystick is used to control the swing and the arm.
- (2) Refer to operation of working device in chapter 4 for details.

2) RH CONTROL LEVER



- (1) This joystick is used to control the boom and the bucket.
- (2) Refer to operation of working device in chapter 4 for details.

3) SAFETY KNOB



- (1) All control levers and pedals are disabled from operation by locating the safety knob to the LOCK position as shown.
- Be sure to turn the safety knob to the LOCK position when entering or leaving the operators seat/cabin.
- (2) The machine is operational by turning the safety knob to the UNLOCK position.
- Do not use the safety bar for handle when getting on or off the machine.

4) TRAVEL LEVER



- (1) This lever is mounted on travel pedal and used for traveling by hand. The operation principle is same as the travel pedal.
- (2) Refer to traveling of the machine in chapter 4 for details.

5) TRAVEL PEDAL



- (1) This pedal is used to move the machine forward or backward.
- (2) If left side pedal is pressed, left track will move. If right side pedal is pressed, right track will move.
- (3) Refer to traveling of machine in chapter 4 for details.

6) SEAT AND CONSOLE BOX ADJUST KNOB (forward/backward)




- (1) This knob is used to move the seat and console box to fit the contours of the operator's body.
- (2) Pull the knob to adjust forward or backward over 150 mm (5.9").

7) CONSOLE BOX (CONTROL LEVER) HEIGHT ADJUST KNOB



- (1) This knob is used to move the LH and RH control levers to fit the contours of the operator's body.
- (2) The control levers can be moved upward and downward over 80 mm (2.4").

5. OTHERS



290F3CD24


1) CIGAR LIGHTER



- (1) This can be used when the engine starting switch is ON.
- (2) The lighter can be used when it springs out in a short while after being pressed down.
- Service socket
 Use cigar lighter socket when you need emergency power.
 Do not use the lighter exceeding 24 V, 100 W.

2) RADIO AND USB PLAYER: MACHINE SERIAL NO.: -#0146

■ BASIC FUNCTIONS



75793CD62-2

■ FRONT PANEL PRESENTATION


- 1 ······ Audio selection button Audio selection knob Power and volume button 2 Mode button 3 (select RADIO / USB / AUX) 4 ······ UP / DOWN tuning button ······ Preset memory button 1 DISPID3 v2 display ······ Preset memory button 2
- SCN File scan Preset memory button 3 RPT Repeat play selector 8 4 Preset memory button 4 RDM Random play selector ····· Preset memory button 5

D- Directory down

10 6 Preset memory button 6 D+ ····· Directory up 11 ----- Aux function ······ Preset scan (PS) 12 Best station memory (BSM) MUTE 13 Audio mute button AM/FM AM / FM button (radio) 14 15 ······ Send 16 ······ End 17 ······ MIC (microphone) 18 AUX Aux connector

■ GENERAL

(1) Power and volume button




① Power ON/OFF button

Press power button to turn the unit ON or OFF shortly. When the power is ON, the previous mode (last memory) will appear.

② Volume up / down control


Turn volume up / down button right to increase the volume level. The level will be shown in VOLUME xx on the LCD display. Turn it left to decrease the volume level. After 5 seconds of volume indication, display will return to the previous mode.

(2) Sound function selection button/knob (audio selection)



① This button is to adjust the sound. Each time you press SEL button shortly, LCD displays each mode as follows:

$$BASS \rightarrow TREBLE \rightarrow BAL \rightarrow LOUD \rightarrow EQ \rightarrow BASS$$



When this button is pressed, LCD display shows selected function for 5 seconds and then returns back to the previous mode. On selected function, level can be controlled by turning this button. The display will automatically return to normal indication in 5 seconds after the last adjustment is made or when another function is activated.

② Bass control

To adjust the bass level, first select the bass mode by pressing the SEL button until BASS indication appears on the LCD display. Within 5 seconds of choosing the bass mode, turn selection knob right / left to adjust the bass level as desired.

The bass level will be shown on the LCD display from a minimum of BASS –10 to a maximum of BASS +10.

The display will automatically return to the normal indication in 5 seconds after the last adjustment or when another function is activated.

③ Treble control

To adjust the treble level, first select the treble mode by pressing the SEL button until TREBLE indication appears on the LCD display. Within 5 seconds of choosing the treble mode, turn selection knob right / left to adjust the treble level as desired.

The treble level will be shown on the LCD display from a minimum of TREBLE -10 to a maximum of TREBLE +10.

The display will automatically return to the normal indication in 5 seconds after the last adjustment or when another function is activated.

④ Balance control

To adjust the left-right speaker balance, first select the balance mode by pressing the SEL button until the BAL indication appears on the LCD display.

Within 5 seconds of choosing the balance mode, turn selection knob right / left to adjust the balance as desired.

The balance position will be shown on the LCD display from BAL 10L (full left) to BAL 10R (full right).

When the volume level between the left and right speakers is equal, BAL L=R will be shown on the LCD display panel.

The display will automatically return to the normal indication in 5 seconds after the last adjustment or when another function is activated.

⑤ Loud control

When listening to music at low volume levels, this feature will boost the bass and treble response.

This action will compensate for the reduction in bass and treble performance experienced at low volume.


To select the loudness feature, press SEL button until LOUD ON or LOUD OFF is displayed, then turn selection knob left or right to activate or deactivate loudness.

6 Equalizer (EQ)

You can select an equalizer curve designed for 4 music types (POP, ROCK, CLASSIC, JAZZ).

To select the desired curve, first select the EQ mode by pressing SEL button until the "EQ OFF" indication appears on the display panel. Within 5 seconds of choosing the EQ mode, turn selection knob to select an equalizer curve as desired.

(3) Mode button



① Press mode button to select RADIO / USB / AUX / BT audio.

(4) Audio mute button




① Press mute button momentarily to mute volume and MUTE mark will blink on the LCD display.

Press the button again to return to the mode in use before the mute mode was activated.

■ RADIO

(1) AM / FM / LW band selector




① Each time this button is pressed, the radio button is changed. Each time this button is pressed, LCD displays each band as follows:

$$FM1 \rightarrow FM2 \rightarrow FM3 \rightarrow AM \rightarrow LW \rightarrow FM1$$

* LW band is only available for Europe.

(2) Up / down tuning




290F3CD43

① To automatically select a radio station, momentarily press the up tune seek button ∞ or down tune seek button w for less than 3 seconds to search for the closest radio station.

To manually select a radio station, press the up tuning & down tuning button for longer than 3 seconds.

The radio frequency will move up or down step by step each time you press button.

(3) Station pre-set button




① Pressing these buttons shortly will recall your favorite pre-set radio stations.

To store your favorite stations into any of the 6 pre-set memories in each band (AM/FM/LW), use the following procedure:

- a. Turn the radio ON and select the desired band.
- b. Select the first station to be pre-set using the manual up/ down or automatic seek tuning control button.
- c. Press the chosen pre-set button to store your selected station into and continue to hold it in. The beep sound will be momentarily heard and the pre-set number will apear on the LCD display indicating that the station is now set into that pre-set memory position and can be recalled at any time, by pressing that pre-set button.

(4) Pre-set scan (PS) / Best station memory (BSM) button



① Pre-set scan (PS)

Press BSM button shortly to scan the 6 pre-set station stored the memories on each band (AM/FM/LW).

The unit will stop at each pre-set station (the pre-set number on the LCD display will flash during pre-set scan operation) and remain on the selected frequency. Press the button momentarily again to remain on the station currently being heard.

2 Best station memory (BSM)

Pressing BSM button for longer than 2 seconds will activate the BSM tuning feature which will automatically scan and enter each station into memory.

If you have already set the pre-set memories to your favorite stations, activating the BSM tuning feature will erase those stations and enter the new ones.

This BSM feature is most useful when traveling in a new area where you are not familiar with the local stations.

■ USB PLAYER



75793CD81-1

(1) USB function


- ① Connect a USB device if you want to listen to MP3 file in a USB device.
- ② It will automatically play MP3 file in the USB device and the LCD display will show "READING USB".
- * If there are no files on USB device, playback will revert back to the previous mode after displaying "NO FILE".

(2) AUX function

- ① If you want to listen to music of a external audio device, connect a external audio device through AUX cable.
- ② Change AUX mode by pressing MODE button.

 If audio file of Audio device is playing, you can listen to music through speaker.

(3) File selection & cue / review button



① File selection function

This button is used to select file up / down.

Each time the forward file select *∞* is pressed, file number is increased.

Each time the backward file select *≫* is pressed, file number is decreased.

② Cue / review functions

High-speed audible search of file on a USB can be made by this button (the cue and review functions).

Press and hold the cue button \sim to advance rapidly in the forward direction or the review button \sim to advance rapidly in the backward direction.

(4) MP3 directory / file searching

① The D-, D+ button is used to select a particular directory and file.

Press and hold for more than 3 seconds while playing MP3 file.

Turn right / left the selection knob to search the directory. Press the button when you find the wanted directory.


For example, the directory search generally changes in two methods depending on the order of writing as follows.

- · Method 1 : ROOT→ Dir01→ Dir02→ Dir03→ Dir04→ Dir05→ Dir06→ Dir07→ ROOT
- · Method 2 : ROOT→ Dir01→ Dir02→ Dir05→ Dir03→ Dir06→ Dir04→ Dir07→ ROOT


If you want to search the file in the located directory, turn right / left the selection knob consecutively. Press the button when you find the wanted file. The unit will then play the selected file.

For instance, the file search changes in Dir01 as follows.


* MP3 directory / file configuration



(5) ID3 v2 display



- Disp button is used to change the display information.
 While playing an MP3 file, you can change the file information shown on the LCD display.
 - Each time you press DISP (display), the display changes to show the following.
- * If the MP3 disc does not have any ID3 information, the display will show NO ID3 on LCD display.



(6) File scan (SCN)



① During USB play, press SCN button to play the first 10 seconds of each file on the whole file on the USB (SCN mark will appear on the LCD display).

When a desired file is reached, press the SCN button again to cancel the function.

The unit will then play the selected file.

** In case of playing MP3 file, when the SCN (scan) button is pressed and held for longer than 2 seconds, the SCN mark will blink on the LCD display and all files in the selected directory will be introduced until the file scan mode is cancelled by pressing the SCN button again or by activating the random or repeat functions.

(7) Repeat play selector (RPT)



- ① During USB play, press RPT button to play the selected file repeatedly (RPT will appear on the LCD display).
 - Play of the file will continue to repeat until this button is pressed again and the RPT disappears from the LCD display.
- ** In case of playing MP3 file, when the RPT button is pressed and held longer than 2 seconds, the RPT mark will blink on the LCD display and play all files in the selected directory and will be repeated until the directory repeat mode is cancelled by pressing the repeat button again or by activating the scan or random functions (RPT mark will disappear from LCD display).

(8) Random play selector (RDM)




① During USB play, press RDM button to play the files on the USB in a random shuffled order (RDM will appear on the LCD display). The file select function will also select file in the random order instead of the normal process.

The random play mode can be cancelled by this button again.


** In case of MP3 file, when the random button is pressed and held longer than 2 seconds, the RDM mark will blink on the LCD display and play all files in directory randomly until the directory random mode is cancelled by pressing the random button again or by activating the scan or repeat functions (RDM mark will disappear from LCD display).

(9) Directory down



① Press D- button briefly while playing MP3. The previous directory is located each time you press this button.

(10) Directory up



- ① Press D+ button briefly while playing MP3 . The next directory is located each time you press this button.
- * If the MP3 file does not have a directory, the unit play MP3 at 10-file intervals.
- * If any MP3 file does not exist in USB, this button can not operate.

■BLUETOOTH

(1) Introduce

The bluetooth radio supports bluetooth wireless technology. Bluetooth technology provides a wireless link between a bluetooth mobile phone or bluetooth music player and the HD Hyundai Construction Equipment bluetooth radio.

The bluetooth radio features a hands-free system so that you may talk on the telephone without taking your eyes off the road or your hands off the wheel. A microphone built into the front of the radio receives your voice and the calling party can be heard through the speakers.

Additionally, a bluetooth music player can be wirelessly connected to be the bluetooth radio and play-back music tracks in high quality sound through the speakers. Many bluetooth mobile phones include a music player and can provide both hands-free calling and music playback.


Check your mobile phone owner's manual for details.

- When the starting switch is in the ON position, the bluetooth radio is on standby to connect with your mobile phone even if the radio is switched off. The machine battery may therefore become drained if the ignition switch remains in the ON position for an extended period of time.
- Bluetooth technology uses low power radio transmission to connect to your bluetooth mobile phone
 or bluetooth music player. As radio signal strength reduces over distance, the quality of sound performance during phone calls and music playback may become poor if the distance between the radio
 and device widens. It is recommended that the mobile phone or music player is kept inside the cab
 for best results.
- * As a bluetooth wireless connection can extend to 10 meters, your bluetooth device may automatically connect to the bluetooth radio even if the device is not in the machine.
- * The bluetooth radio uses the latest digital noise & echo suppression system to provide the best sound clarity with little or no distortion, but in some conditions there may be some echo and noise experienced. It is recommended to keep the car windows closed during hands-free calls for best results.




1 Bluetooth indicator

The bluetooth logo is displayed when a bluetooth device is connected, and not displayed, when no bluetooth device is connected. If the bluetooth mobile phone is connected but the connection is not of satisfactory quality, the bluetooth logo is not displayed.



② Battery strength indicator

This is an indication of your mobile phone battery condition. If your mobile phone is unable to transmit battery condition level, the indicator is not displayed.



3 Single level indicator

This is an indication of the mobile phone network signal strength in your current location. If your mobile phone is not able to transmit signal level, the indicator is not displayed.

(2) Bluetooth function

1) Pairing a bluetooth mobile phone or music player

A bluetooth connection must first be established between your bluetooth mobile phone or bluetooth music player and the bluetooth radio. The first step to connecting the bluetooth radio and bluetooth device is to introduce or "Pair" the bluetooth radio and bluetooth device together.

It is recommended that you have the instruction manual for your bluetooth mobile phone or music player with you during the pairing process described below to understand how to set your device to pair with the bluetooth radio.

* It is recommended that all other bluetooth devices other than mobile phones are switched off during the registration or pairing process.

a. Connection method

- a) Press SEND button for 2 seconds in any mode, **PAIRING** appears on the bluetooth radio display.
- b) Browse your mobile phone or music player menu to find the **SETTINGS** or **CONNECTIVITY** section to find the bluetooth connection section.
- c) Find the command that may be called search for bluetooth device or discovery mode so that your bluetooth device can locate all the bluetooth devices within range that may be connected.
- d) After the search is complete, **HHI AUDIO** should appear on your mobile phone or music player screen.
- e) Select CONNECT or SELECT on your mobile phone or music player.
- f) The mobile phone or music player should now prompt you top enter a PIN code. Enter 0000 into your bluetooth device and select OK.
- g) The mobile phone or music player should confirm that it has established a new paired connection with the bluetooth radio.
- h) The connecting process is now complete.
- If the connecting process is successful, the bluetooth logo appears on the radio display and paired phone name (e.g. Samsung or LG) and CONNECTED appear on the display for 2 seconds.
- j) Your bluetooth device is now ready for use with the bluetooth radio.
- k) If the pairing failed, **FAIL** appears on the bluetooth radio display.
- * (a) The bluetooth radio allows a maximum of 6 bluetooth devices to be paired.
 - (b) Bluetooth technology only allows one phone to be connected to your bluetooth radio at one time.
 - (c) If a bluetooth music player is to be connected together with a mobile phone, refer to the page 3-55, PLAYING MUSIC USING BLUETOOTH AUDIO.
 - (d) Bluetooth connection with a mobile phone is normally established using the Hands-Free Profile (HFP). However, in some cases, the connection may use Head Set Profile (HSP) and some functions may not be available.
 - (e) As each mobile phone or music player brand and model has a different menu structure and control names, you may need to refer to the user manual of your bluetooth device for the correct procedure to connect to another bluetooth device.
 - (f) Once the bluetooth pairing is complete, automatic connection between mobile phone and the bluetooth radio is possible whenever the starting switch is switched ON.
 - The mobile phone must be set to automatically connect to the bluetooth radio to allow this automatic connection.

- (9) The bluetooth radio will give connection priority to the last connected mobile phone.
- (h) It is recommended that all other bluetooth devices other than mobile phones are switched off during the registration or pairing process.

② Disconnecting a bluetooth device

If you need to disconnect your bluetooth mobile phone or music player with the bluetooth radio, follow the steps below.

- a. Press END button for 2 seconds in any mode.
- b. When the bluetooth connection is lost, bluetooth logo disappears and the previously connected device name (e.g. Samsung or LG) and **DISCONNECTED** appear on the display.

3 Select a bluetooth device

The bluetooth radio can pair up to 6 bluetooth devices. A previously paired mobile phone or music player can be selected for connection using the method described below. Refer to the table 2-1 for examples.

Preset No.	Bluetooth device name (for example)
1	Samsung
2	LG
3	Apple
4	Motorola
5	EMPTY
6	EMPTY

Table 2-1

- a. Press SEND button, to select **BLUETOOTH** mode.
- b. Press SEL button. **SELECT PHONE** will appear on the display.
- c. Turn selection knob, until **SELECT PHONE** is displayed.
- d. When **SELECT PHONE** appears on the display, press SEL button.
- e. Press the preset button to display the name of the bluetooth device name of the mobile phones or music players previously paired. You may also turn selection knob to display the paired devices.
 - · Each time you turn or selection knob, the LCD displays as follows:

- f. If the bluetooth mobile phone name is Samsung as in the example of table 2-1, then **Samsung** appears on the display. When preset button is pressed or selection knob is turned 1 click to the right.
- g. Once the name of the bluetooth device you wish to connect is displayed, in this example **Samsung**, press SEL button to have the Samsung device connected.
- h. If the connection is successful, the bluetooth logo appears on the display and paired phone name **Samsung** and **CONNECTED** appears on the display for 2 seconds.

4 Deleting a previously paired bluetooth device

If you no longer need to use a paired bluetooth device with the bluetooth radio, it can be deleted. It is from the registration assignment for another mobile phone.

Refer to the example of paired devices shown table 2-1.

- a. Press SEND button, to select **BLUETOOTH** mode.
- b. Press SEL button and **SELECT PHONE** appears on the display.
- c. Turn selection knob, until DELETE PHONE is displayed.
- d. When **DELETE PHONE** appears on the display, press SEL button.
- e. Press the preset button to display the name of the bluetooth device name of the mobile phones or music players previously paired. You may also turn selection knob to display the paired devices.
- f. Once the name of the bluetooth device you wish to delete is displayed, in this example **Samsung**, press SEL button to have the Samsung device deleted.
- g. The display will then show **DELETE NO** or if selection knob is turned, **DELETE OK** on the display.
- h. To confirm your wish to delete the selected device, when **DELETE OK** appears on the display press SEL button.
- i. If the bluetooth device being deleted (in this example) was connected, the display will show previous paired phone name "Samsung" and DISCONNECTED.
- j. In the example above, the number of paired devices is now reduced to 3, leaving 3 vacant memory locations for additional devices. Table 2-2 shows the example.

Preset No.	Bluetooth device name (for example)
1	LG
2	Apple
3	Motorola
4	EMPTY
5	EMPTY
6	EMPTY

Table 2-2

5 Basic telephone operation

a. Using the bluetooth radio for hands-free calls

- a) When an INCOMING call arrives at the bluetooth radio via your connected bluetooth mobile phone, INCOMING CALL appears on the display for 3 seconds then the calling telephone number is shown.
- b) Press SEND button to answer the INCOMING call. HANDSFREE appears on the display.
- c) To end the call, press END button and the call will end and END CALL is displayed.
- d) If you wish to reject an INCOMING call, press END button.
- **e)** To make an OUTGOING call use the keypad of the connected bluetooth mobile phone to enter a number and press the **OFF-HOOK** (SEND) button on your mobile phone.
- f) OUTGOING CALL is displayed on the bluetooth radio and the call continues in hands-free mode.
- g) The call can be ended by pressing END button the **ON-HOOK** (END) button of the connected mobile phone.
- * Some mobile phones may not reject an INCOMING call using the action of d) above. In this case, press the **ON-HOOK** button on the connected mobile phone to reject.

b. Last call number redials

Select **BLUETOOTH** mode by pressing SEND button. To making a call to the last dialed number, press SEND button again. **OUTGOING CALL** appears on the radio display for 1 second.

* Some mobile phones may require an additional press of SEND button to start the last number redial call.

c. Switching to private (headset) mode during a call

During an INCOMING or OUTGOING call started in hands-free mode, it is possible to switch to the private call mode using the mobile phone handset to speak and to hear the calling party in private.

- a) Press SEND button during the conversation; **PRIVATE** appears on the display.
- b) To switch back to hands-free mode using the bluetooth radio, press SEND button again during the private conversation; HANDSFREE is shown on the display and hands-free call operation continues.
- * The above switching function may cause disconnection of the bluetooth link between the bluetooth radio and some mobile phones.
 - If SEND button is pressed during the private conversation, the bluetooth connection will return automatically.

(3) Function of bluetooth audio player

1) Playing music using bluetooth audio

The bluetooth radio supports the bluetooth profile Audio Advanced Distribution Profile (A2DP). If your mobile phone or music player supports this profile then it is possible to listen to music tracks located on your bluetooth device through the bluetooth radio and speakers.

Additionally, the bluetooth radio supports the Audio Video Remote Control Profile (AVRCP).

If your bluetooth mobile phone or music player supports this profile then it is possible to advance to the next track or replay previous tracks on using the buttons on the front of the bluetooth radio your machine.

- a. Press MODE button until BT AUDIO is displayed.
- b. When **BT AUDIO** appears on the display, select the music player feature on your bluetooth device. And then bluetooth device play automatically to begin playback.
- c. To pauses the bluetooth audio playback, press SEL button for 2 seconds. Press the knob again for 2 seconds to resume playback.
- d. Press buttons (∞, ∞) advance to the next or previous music track.
- * (a) Check your bluetooth device owner's manual for details of how to play music tracks via an external bluetooth audio system such as the bluetooth radio.
 - (b) Some bluetooth mobile phones cannot play music at all or may play music tracks in low-quality audio through the bluetooth radio.
 - (c) Some mobile phones require additional pairing to allow bluetooth audio playback.
 - (d) Information about songs (ID3) (e.g. the elapsed playing time, song titles, song index, etc.) playing using bluetooth audio profile cannot be displayed on this bluetooth radio.

2 Connecting a bluetooth music player and mobile phone simultaneously

It is possible to connect a bluetooth mobile phone and a separate bluetooth music player to the bluetooth radio at the same time. Phone calls can be sent and received using the hands-free feature while music is playing using the bluetooth audio feature.

(4) Bluetooth setting

1) Setting the automatic call answer feature

If this function is selected, the bluetooth radio automatically answers all INCOMING calls.

This feature enhances safety as the driver does not need to take their hands from the steering wheel to accept an INCOMING call.

Note that this feature cannot be set at different settings for each of the paired mobile phones.

- a. Press SEND button to select BLUETOOTH mode.
- b. Turn selection knob until **SETTINGS** is displayed.
- c. Press SEL button until AUTO ANSWERING is displayed.
- d. Press SEL button and turn selection knob. The LCD then displays as follows:

ANSWER OFF → ANSWER 5 SEC → ANSWER 10 SEC → RETURN → ANSWER OFF

- · ANSWER OFF = Automatic answer function is not active.
- · ANSWER 5 SEC = Automatic answers all INCOMING calls after a 5 second delay.
- · ANSWER 10 SEC = Automatic answers all INCOMING calls after a 10 second delay.
- · RETURN = Return to previous menu.
- e. After making your selection, press SEL button to store the selection.
- f. **SETTINGS** is then displayed for adjustment if required.
- g. If you do not wish to adjust any further bluetooth settings, press END button to return to the last selected mode.

② Setting calling voice volume

This function is to set the level of the mobile phone's calling voice volume to be heard through the bluetooth radio and speakers.

- a. Follow steps a. to c. of above setting below 1.
- b. When **VOICE VOLUME** appears on the display, press SEL button to display the current level of the calling voice. Turn selection knob right or left to adjust the calling voice volume as desired. This is the level the calling voice volume will be set to each time the bluetooth radio is used after the stating switch is turned off and then on again.
- c. After making your selection, press SEL button to store the selection.
- d. **SETTINGS** is then displayed for adjustment if required.
- e. If you do not wish to adjust any further bluetooth settings, press END button to return to the last selected mode.

3 Setting the ring volume

This function is to set the level of the mobile phones ring tone volume to be heard through the bluetooth radio and speakers.

- a. After making your selection, press SEL button to store the selection.
- b. When **RING VOLUME** appears on the display, press the SEL button to display the current level of the ring tone. Turn selection knob right or left to adjust the ring tone volume as desired. This is the level the ringer volume will be set to each time the bluetooth radio is used after the starting switch is turned off and then on again.
- c. After making your selection, press SEL button to store the selection.
- d. The press END button to return to the last selected mode.

RADIO AND USB PLAYER (WITH BLUETOOTH): MACHINE SERIAL NO.: #0147-



9403CD100

■ FRONT PANEL PRESENTATION

	FRON	I PANEL PRESENTATION
1		······ Power ON/OFF, Volume UP/DOWN button
2	O	Manual UP/DOWN Tuning, File search, SEL button
3	MODE MUTE	Mode button, Audio mute button
4	C	······ Call & Pair button
5	0	······ Call end button
6	1 DIS	······ Station preset 1
	DIS	······ Display button
7	2	······ Station preset 2
8	3 RPT	······ Station preset 3
	RPT	Repeat play button
9	4 RDM	······ Station preset 4

RDM Random play button

10	Station preset 5 DIR Directory down button
11	OIR+ Station preset 6
12	Scan play button (SCAN) Best station memory (BSM) button
13	······ Auto tune up, Seek up button
14	Auto tune down, Track down button
15	······ USB connector
16	AUX IN Jack
17	······ MIC hole

RADIO AND USB PLAYER (WITHOUT BLUETOOTH): MACHINE SERIAL NO.: #0147-



9403CD101

■ FRONT PANEL PRESENTATION

-	= I HONI I ANLL I HESLINIATION				
1		······ Power ON/OFF, Volume UP/DOWN button			
2	O_{i}	Manual UP/DOWN Tuning, File search, SEL button			
3	MODE MUTE	Mode button, Audio mute button			
4	SEEK	······ Radio seek up button			
5	SEEK	······ Radio seek down button			
6	DIS ···	······ Station preset 1 ······ Display button			
7	2	······ Station preset 2			
8	3 RPT	······ Station preset 3 ······ Repeat play button			
9	4 RDM	······ Station preset 4			

RDM Random play button

10		Station preset 5 Directory down button	
11	6 DIR+ ··	Station preset 6 Directory up button	
12	SCAN ISM	Scan play button (SCAN) Best station memory (BSM) b	utton
13	TRÂCK	······ Track up button	
14	TRACK	······ Track down button	
15	AUX	······ USB connector	
16	4	······ AUX IN Jack	

■ GENERAL

(1) Power and volume button



① Power ON / OFF button

Press power button (1) to turn the unit on or off.

② Volume UP/DOWN control knob

Turn VOL knob (1) right to increase the volume level.

Turn VOL knob (1) left to decrease the volume.

After 5 seconds the display will return to the previous display mode.

3 Initial volume level set up

I-VOL is the volume level the unit will play at when next turned on. To adjust the I-VOL level, press and hold VOL button (1) for longer than 2 seconds. The current volume level displays on the display panel.

Then turn button (1) right or left to set the volume level as the I-VOL level.

4 Clock ON/OFF control

The CLOCK was default at off status. To turn CLOCK ON, press and hold VOL button (1) for longer than 2 seconds to display I-VOL, then short press VOL again, turn VOL knob while CLOCK OFF display, then the CLOCK ON will be displayed.

* Due to time tolerance, the clock display on the Audio unit might have little difference.

(5) Clock adjustment

With CLOCK ON selected, press VOL knob again after CLOCK ON display, the hour will blink, turn VOL knob right or left to adjust hour. Simply press VOL again, the minute will blink, turn VOL knob to adjust minute. Then press VOL again to confirm the clock once finished.

(2) Menu Selection



① This button can adjust the sound effect and other things. Each time you press this button (2), LCD displays as follows:

BAS
$$\rightarrow$$
 TREB \rightarrow BAL L=R \rightarrow FAD F=R \rightarrow EQ \rightarrow LOUD ON \rightarrow BEEP 2ND

On each setting, the level can be controlled by turning TUNE knob (2). When the last adjustment is made, after 5 seconds, the display will automatically return to the previous display mode.

② Bass control

To adjust the bass tone level, first select the bass mode by pressing SEL button (2) repeatedly until BASS appears on the display panel. Then turn knob (2) right or left within 5 seconds to adjust the bass level as desired. The bass level will be shown on the display panel from a minimum of BASS-7 to a maximum of BASS+7.

③ Treble control

To adjust the treble tone level, first select the treble mode by pressing SEL button (2) repeatedly until TREB appears on the display panel. Then turn knob (2) right or left within 5 seconds to adjust the treble level as desired. The treble level will be shown on the display panel from a minimum of TREB -7 to a maximum of TREB +7.

4 Balance control

To adjust the left-right speaker balance, first select the balance mode by pressing SEL button (2) repeatedly until BAL indication appears on the display panel. Then turn knob (2) right or left within 5 seconds to adjust the balance as desired. The balance position will be shown by the bars on the display panel from BAL 10R (full right) to BAL 10L (full left).

⑤ Fader control

To adjust the front-rear speaker balance, first select the fader mode by pressing SEL button (2) repeatedly until FADER indication appears on the display panel. Then turn knob (2) right or left within 5 seconds to adjust the front-rear speaker level as desired. The fader position will be shown by the bars on the display panel from FAD 10F (full front) to FAD 10R (full rear).

© EQ control

You can select an equalizer curve for 4 music types (CLASSIC, POP, ROCK, JAZZ). Press button (2) until EQ is displayed, then turn knob (2) right or left to select the desired equalizer curve. Each time you turn the knob, LCD displays as follows:

When the EQ mode is activated, the BASS and TREBLE modes are not displayed.

⑦ Loud control

When listening to music at low volume levels, this feature will boost the bass and treble response. This action will compensate for the reduction in bass and treble performance experienced at low volume.

To select the loudness feature, press button (2) until LOUD is displayed, then turn knob (2) right or left to activate or deactivate loudness.

8 Beep control

To adjust the BEEP mode, first select the BEEP mode by pressing button (2) repeatedly until BEEP indication appears on the display panel. Then turn knob (2) left or right within 5 seconds to select BEEP 2ND, BEEP OFF or BEEP ON.

- BEEP 2ND : You will only hear the beep sound when the buttons are held down for more than 2 seconds.
- · BEEP OFF: You can not hear the sound beep when you press the buttons.
- · BEEP ON : You can hear the beep sound each time you press the buttons.

(3) Mute control

① Press and hold MUTE button (3) for over 2 seconds to mute sound output and MUTE ON will blink on the LCD. Press the button again to cancel MUTE function and resume to normal playing mode.

(4) Mode selection

- ① Repeat press MODE button (3) to switch between FM1, FM2, AM, USB, AUX, BT MUSIC.
- * If there is no USB, AUX, Bluetooth Phone connected, it would not display USB, AUX, BT when you press button (3).

■ RADIO

(1) Mode button



① Repeat press MODE button to select FM1, FM2 or AM.

(2) Manual tuning button



① To manually tune to a radio station, simply turn encoder TUNE (2) left or right to increase or decrease the radio frequency.

(3) Auto tuning button



① To automatically select a radio station, simply press Seek up or Track down button.



(4) Station preset button



- ① In radio mode, pressing buttons (6) to (11) will recall the radio stations that are memorized. To store desired stations into any of the 6 preset memories, in either the AM or FM bands, use the following procedure:
 - a. Select the desired station.
 - b. Press and hold one of the preset buttons for more than 2 seconds to store the current station into preset memory. Six stations can be memorized on each of FM1, FM2, and AM.

(5) Preset scan (PS) / Best station memory (BSM) button



- ① Press BSM button (12) momentarily to scan the 6 preset stations stored in the selected band. When you hear your desired station, press it again to listen to it.
 - Press BSM button (12) for longer than 2 seconds to activate the Best Station Memory feature which will automatically scan and enter each station into memory.
- ** If you have already set the preset memories to your favorite stations, activating the BSM tuning feature will erase those stations and enter into the new ones. This BSM feature is most useful when travelling in a new area where you are not familiar with the local stations.

■ USB PLAYER

(1) USB playback



- ① The unit was equipped with a front USB jack and also a rear USB Jack.
 - With a USB device plugged in the front USB jack, it will be detected as front USB mode. And with a USB device plugged in the rear USB jack, it will be detected as rear USB. To get to a USB mode, press MODE (3) button momentarily or insert the USB device in front or rear USB jack.
- * If no mp3 or wma files in USB device, it will convert to the previous mode after display NO FILE.

(2) Track Up / Down button



① Press SEEK up (13) or TRACK down (14) to select the next or previous track. Press and hold the buttons to advance the track rapidly in the forward or backward direction.



(3) MP3 directory / File searching



① Button (2) is used to select a particular directory and file in the device. Turn button (2) right or left to display the available directories. Press button (2) momentarily when the desired directory is displayed, then turn button (2) right or left again to display the tracks in that directory. Press button (2) to begin playback when the desired file is displayed.

(4) Directory Up / Down button



- ① During MP3/WMA playback, simply press DIR- button (10) to select the previous directory (if available in the device); simply press DIR+ button (11) to select the next directory (if available in the device).
- ** If the USB device does not contain directories, it would play MP3/WMA tracks at 10- file when you press DIR- button (10), and play MP3/WMA tracks at 10+ file when you press DIR+ (11) button.

(5) Track Scan Play (SCAN) button



- SCAN playback : Simply press SCAN (12) button to play the first 10 seconds of each track.
- SCAN folder: Press and hold SCAN button for longer than 2 seconds to scan play the tracks in current folder.
- SCAN off: Simply press it again to cancel SCAN feature.

(6) Track Repeat Play (RPT) button



- REPEAT playback : Simply press RPT (8) button to play current track repeatedly.
- REPEAT folder: Press and hold RPT for longer than 2 seconds to repeat play the tracks in current folder.
- REPEAT off: Simply press it again to cancel REPEAT feature.

(7) Track Random Play (RDM) button



- RANDOM playback : Simply press RDM (9) button to play the tracks in the device in a random sequence.
- RANDOM folder: Press and hold RDM button for longer than 2 seconds to random play the tracks in current folder.
- RANDOM off : Simply press it again to cancel RANDOM feature.

(8) ID3 v2 (DISP)



- ① While a MP3 file is playing, press DISP button (6) to display ID3 information. Repeat push DISP button (6) to show directory name / file name and album name / performer / title.
- If the MP3 disc does not have any ID3 information, it will show NO ID3.
- * USB Information and Notice
 - a. Playback FILE SYSTEM and condition allowance.
 - FAT, FAT12, FAT16 and FAT32 in the file system.
 - V1.1, V2.2 and V2.3 in the TAG (ID3) version.
 - b. Display up to 32 characters in the LCD display.
 - c. No support any of MULTI-CAED Reader.
 - d. No high speed playback but only playing with normal full speed.
 - * DRM files in the USB may cause malfunction to playback in the radio unit.
 - * The temperature below -10 Celsius, the audio unit with USB hook up would be affected to play well.

■ AUX OPERATION

It is possible to connect your portable media player to the audio system for playback of the audio tracks via the cab speakers.

To get the best results when connecting the portable media to the audio system, follow these steps:

- Use a 3.5 mm stereo plug cable to connect the media player headphone socket at each end as follows.
- Adjust the portable media player to approximately 3/4 volume and start playback.
- Press the MODE button (3) on the audio unit to change into AUX mode.
- The volume and tone can now be adjusted on the audio unit to the desired level.
- * The audio quality of your media player and the audio tracks on it may not be of the same sound quality as the audio system is CD Player.
- * If the sound of the media player is too low compared with the radio or CD, increase the volume of the player.
- * If the sound of the media player is too loud and/or distorted, decrease the volume of the player.
- * When in AUX mode, only the Volume, Bass, Treble, EQ and Mode functions of the audio unit can be used.

■ BLUETOOTH (if equipped)


1) Using a bluetooth wireless connection

- (1) Your audio unit supports bluetooth wireless technology. You can set up a wireless link with bluetooth cellular phone.
- (2) Keep PAIRING the cellular phone with audio unit in a few minutes as the phone are being switched on well enough.
- * Since this audio unit is on standby to connect with your cellular phone via bluetooth wireless technology, using this audio unit without running the engine can result battery drainage.
- * This audio unit phone call reception is on standby when ignition switch is set to ACC OFF or ON.
- * The line-of-sight distance between this audio unit and your cellular phone must be 10 meters or less for sending and receiving voice and data via bluetooth wireless technology. However the transmission distance may become shorter than the estimated distance depending on the environment in use.
- * Digital Noise & Echo suppression system provides the best sound clarity with little or no distortion (Echo & side tone will happen depending on cellular phone or service network).
- * To ensure the quality of calling, you should select a proper bluetooth VR level. This audio unit has already set with the best bluetooth VR level.




1 Bluetooth icon

It will blink while establishing the bluetooth pairing. It will light after a bluetooth device connected.



2 Battery icon

It indicates the battery status of the connected bluetooth device.



3 Single strength icon

It indicates the signal strength of the connected bluetooth device.

2) Pairing in hands free modes



- (1) Press and hold CALL button (4) for 2 seconds until you hear beep sound, then appears PAIR STR on the display.
- (2) For the next procedure, go to cellular phone pairing mode.
- (3) If it is in pairing status with audio unit and cellular phone, PAIRING will show on the display.
- (4) If you want to exit pairing mode, press CALL END button (5) briefly while pairing, then it will show PAIR CLR on the display.
- (5) Bluetooth Icon and PAIR OK appear on the display when pairing is successful.

3) Cellular phone pairing mode

- (1) Browse your cellular phone menu and find the connectivity or bluetooth connection section.
- (2) Select search for a new handsfree device function and allow the phone to find the mobile.
- (3) HYUNDAI should appear on your cellular phone screen.
- (4) Press connect menu among the handsfree option on your cellular phone.
- (5) The cellular phone should prompt for a pin code. Insert the pin code 1234.
- (6) The cellular phone should confirm that it has established a new paired connection.
- (7) Close the menu. The pairing is now completed. It appears PAIR FAIL on the display for 3 seconds.
- * Each cellular phone type has distinct phone menu so you may need to refer to your manufactures instruction for the correct procedure on how to connect a new bluetooth device.
- * Please retry to the pairing instruction if HYUNDAI does not appear on the cellular phone screen.
- * Please select authorized, if there is authorized menu in the menu of bluetooth connection in your cellular phone.
- * Once the bluetooth pairing is completed between your cellular pone and this audio unit, the both units will be automatically recognized on its paring and when you turn on the key in your car even though this audio unit is turned off.
- * This audio unit can store up to 6 phones pairings. If the memory is full, the first stored paired phone will be deleted.
- * The connecting priority will be given to the last connected cellular phone.
- If you want to change the connecting priority, try to connect this audio unit from the cellular phone.

4) Bluetooth connection and disconnection

(1) When established bluetooth connection between this audio unit and the cellular phone, bluetooth icon on the display appears and then the display shows HF/AV CONN when handsfree & AV profile connected.



(2) To disconnect bluetooth link

Press and hold CALL END button (4) for 2 seconds, it shows DIS CON and disappears bluetooth Icon on the display.



(3) To disconnect bluetooth link

Press CALL button (3) briefly, it blinks bluetooth Icon on the display while bluetooth is being connected. If the connection is completed, it appears bluetooth Icon on the display.

- * When your cellular phone battery is at low charge, the bluetooth connection may occasionally be lost. To maintain good connectivity ensure that your phone battery is adequately charged.
- * In case of failure of bluetooth pairing:
 - Delete item in paired list on your phone.
 - Reset both phone by power off/on and the audio unit by ACC off/
- * Connecting priority of handsfree profile is higher than headset profile.
- * The headset mode does not support caller ID, reject call and call Transfer.

5) Using the audio unit as a handsfree device



(2) To accept call

Press CALL button (4), it appears ANSWER CALL and follows TALKING on the display.

(3) To end call

To end call, press CALL END button (5), it appears REJECT on the display.

* If reject call is activated in your phone, then your cellular phone does not support reject call function.

6) Audio transfer between the audio unit and phone

The audio transfer function is for switching the call from the audio unit to the cellular phone for private conversation.



- Press CALL button (4) briefly during conversation, it appears CALL TRANS on the display. To switch back to the audio unit, press button (4) briefly during private conversation, then it appears CALL TRANS on the display again.
- * This function will be a cause of disconnection of bluetooth link in some nokia phones, but you do not worry just press button (4) during private conversation, then switch back to the audio unit automatically.
- * The quality of calling between cellular phone and audio unit is better than calling between one audio unit and another one.

7) Last call number dialing



- (1) Press CALL button (4) briefly, it appears CALL TO, then simply press CALL button once again, it would make the last call with phone number display on LCD.
 - If Reject call is activated in your phone, then your cellular phone does not support Reject Call function.
- * If you are using SAMSUNG phone, then you may need to press once more send button. First press button shows phone contact list in your phone, then second press make the last call.

8) To make a call by cellular phone

The audio transfer function is for switching the call from the audio unit to the cellular phone for private conversation.

- (1) The audio unit activated automatically when you make a call by cellular phone.
- (2) When you make a call processing by cellular phone, it shows CALLING on the display.
- (3) When you receive a call, the phone number ******* appears on the display.

9) Using the audio unit as bluetooth music

The audio unit supports A2DP (Audio Advanced Distribution Profile) and AVRCP (Audio Video Remote Control Profile), and both profiles are available to listen music at the audio unit via cellular phone which is supporting the two profiles above.

- (1) To play music, search the menu on your cellular phone as below:
 - i.e : Menu \rightarrow File manager \rightarrow Music \rightarrow Option \rightarrow Play via bluetooth. It appears BT MP3 on the display.
- (2) During BT MP3 playing, you could select the previous or next track by pressing SEEK up or TRACK down button on audio unit or operate via your cellular phone.
- (3) To stop music, press button (5) briefly and it will automatically switch into the previous mode.
- (4) To resume music playing, press the play button on your cellular phone.
- * This function maybe different depends on cellular phone. Please follow the cellular phone menu. Some kinds of phone need to pair once more for bluetooth MP3 connection.
- * This function will be caused to disconnect A2DP, AVRCP depends on cellular phone.
- * Information about songs (e.g.: the elapsed playing time, song title, song index, etc.) cannot be displayed on this audio unit.

■ RESET AND PRECAUTIONS

1) Reset function

Interfere noise or abnormal compressed files in the MP3 disc or USB instrument may cause extraordinary operation (or unit frozen/locking up). It's strongly recommended to use appropriate USB storage not cause any malfunction to the audio unit. In the unlikely event that the player fails to operate correctly, try out to reset unit by any of following two methods.

- (1) press and hold simultaneously for about 5 seconds. (without Bluetooth)

 Press and hold simultaneously for about 5 seconds. (with Bluetooth)
- (2) Take out the fuse for the audio system in the vehicle once and then plug again.
- * It will be necessary to re-enter the radio preset memories as these will have been erased when the microprocessor was reset.

After resetting the player, ensure all functions are operation correctly.

2) Precautions

When the inside of the car is very cold and the player is used soon after switching on the heater, moisture may form on the disc or the optical parts of the player and proper playback may not be possible.

If moisture forms on the optical parts of the player, do not use the player for about one hour. The condensation will disappear naturally allowing normal operation.

- (1) Operation voltage: 9~32 volts DC, negative
- (2) Output power: 40 watts maximum (20 watts x 2 channels)
- (3) Tuning range

Area	Band	Frequency range	Step
USA	FM	87.5~107.9 MHZ	200K
	AM	530~1710 KHZ	10K
EUROPE	FM	87.5~108.0 MHZ	50K
	AM	522~1620 KHZ	9K
ASIA	FM	87.5~108.0 MHZ	100K
	AM	531~1602 KHZ	9K
LATIN	FM	87.5~107.9 MHZ	100K
	AM	530~1710 KHZ	10K

AREA Selection :

- To select an area, press and hold related buttons at FM1 band for about 3 seconds.
- USA Area: Press and hold mode + 1DIS buttons for 3 seconds
- EUROPE Area: Press and hold mode + 2 buttons for 3 seconds
- ASIA Area: Press and hold mode + 3RPT buttons for 3 seconds
- LATIN Area: Press and hold mode + 4RDM buttons for 3 seconds.
- (4) USB version : USB 1.1(5) Bluetooth version : V2.1(6) Bluetooth supported profile :
 - A2DP : Advanced Audio Distribution Profile
 AVRCP : Audio/Video Remote Control Profile
 - HFP: Hands-Free Profile

3) HAPTIC CONTROLLER

The haptic controller consists of buttons, multimodal dial and USB port.



290F3CD173

(1) Cluster button



- ① When you push this button, haptic controller execute cluster interlocked mode.
- ② In cluster interlocked mode, if you push the cluster button, the haptic controller return to previous mode.
- ③ Cluster interlocked mode ON: Blue lamp is turn ON Cluster interlocked mode OFF: Blue lamp is turn OFF

(2) Air conditioner button



290F3CD175

- ① When you push this button, air conditioner system is operated.
- ② Determines whether to perform a cooling function of air conditioner.
 - Blue lamp ON : Air conditioner operation
 - Amber lamp ON: Fan only

(3) Set button



- ① When you push this button, the haptic controller executes air conditioner mode and displays air conditioner control mode in cluster.
- 2 Air conditioner control mode will be disappear when you push SET button again within 10 seconds or when you do not touch anything more than 10 seconds.

(4) OFF button



- ② This button is only for air conditioner system off.


(5) Auto button



- ① This button controls air conditioner ON/OFF.
- * Refer to the page 3-32 for the auto switch of the air conditioner.

① Only while air conditioner system is operating you can use this but-

(6) USB port




- ① This port updates firmware using a dedicated cable.
- 2 Haptic controller has built-in charging circuit supply max 500 mA current.

(7) Multimodal dial

- Cluster interlocked mode OFF


① Acceleration mode



- There are 10 dial setting.
- Setting 1 is low idle and setting 10 is high idle.
 - By rotating the dial to right : Engine speed increases
 - · By rotating the dial to left : Engine speed decreases
- Dial operating pattern is sine wave torque.


- Cluster interlocked mode ON

① Cluster main menu



290F3CD240A

- You can select the quick menu by rotating the dial as below.



CW rotation : move to right directionCCW rotation : move to left direction

2 Cluster menu move



290F3CD180A

- You can move up and down of the cluster sub menu.
- Dial operating pattern is continuous rotation trapezoid torque.

3 Air conditioner menu



290F3CD181A

 You can move the menu of the air conditioner control mode.



- Dial operating pattern is mixed type trapezoid torque.


4 Slide choice menu



290F3CD182A

- You can increase or decrease the slide choice bar.
- Dial operating pattern is repeat dot interval torque.


5 Level choice menu



290F3CD183A

- You can increase or decrease the level choice bar.
- Dial operating pattern is integrate rectangular torque.

® Push button



 Push: Select the current menu or the pop-up warning lamp move to the original position when warning lamp is happened.


Left : ESCRight : CAM

- Front : Cluster main menu


- Rear : Return to acceleration mode

4) SEAT (SUSPENSION, STD)

The seat is adjustable to fit the contours of the operator's body. It will reduce operator fatigue due to long work hours and enhance work efficiency.




(1) Weight and height adjustment



With socket wrench (A):


- ① The seat has to be adjusted for the operator's weight and height by tilting the handle (+) up or down (-) with the operator not sitting on the seat.
- ② The rotational direction is reversed by toggling the ratchet with the switch (C).
- ③ The operator weight and the seat height are adjusted correctly when the green marking is completely visible in the indicator window (B) for weight and height.
- The height can be adjusted individually as long as the green marking is visible.

(2) Fore/after adjustment




- ① The fore/after adjustment is released by lifting the locking lever.
- **A** Do not operate the locking lever while operating.
- ** After the adjustment, the locking lever must latch into the desired position with an audible click. It should not be possible to move the operator's seat into another position when it is locked.
- * Do not lift the locking lever with your leg or calf.

(3) Seat depth adjustment




- ① The depth of the seat pan can be individually adjusted.
- ② To adjust the depth of the seat cushion, pull the right handle upwards. By moving the seat pan backwards or forwards the desired seating position can be reached.

(4) Seat pan angle adjustment



- ① The angle of the seat pan can be individually adjusted.
- ② To adjust the angle of the seat pan, pull the left handle upwards. By exerting pressure on or off the front or rear part of the seat pan it can be moved to the desired angle position.


(5) Armrests



- ① The armrests can be folded up if required and the height can be individually adjusted.
- ② To adjust the armrest for height, separate the round cap (see arrow) from the cover and loosen the hexagon nut (size 13 mm) behind it adjust the armrests to the desired position (5 steps) and tighten the nut again (25 Nm).


Replace the cap onto the nut.

(6) Armrest adjustment




- ① The inclination of the armrest can be modified by turning the adjustment knob.
- ② When turning the knob to the outside (+), the front part of the armrest will be lifted; when turning the knob to the inside (-), it will be lowered.

(7) Headrest




- ① The headrest can be individually adjusted for height by pulling it upward over the various increments up the end stop.
- ② By pushing forwards or rearwards the angle of the headrest can be adjusted individually.
- ③ To remove the headrest, pull it over the end stop.

(8) Document box




- ① The document box is placed on the rear side of the backrest.
- ② To open the document box, first twist the turn lock closures 90° to the left or the right and then fold the cover of the document box upwards.

(9) Seat heater switch




① The seat heater can be turned on/off by pressing the switch.

(10) Lumbar support



- ① By turning the adjustment knob to the left (2) or right (1), both the height and curvature of the backrest cushion can be individually adjusted.
- ② This increases both the seating comfort and the performance of the operator.

(11) Backrest adjustment



- ① Pull up the locking lever to release the backrest catch. When releasing the backrest, do not load the backrest by pressing against it.
- ② By exerting pressure on or off the front or rear part of the seat pan it can be moved to the desired position. Release the locking lever to lock the backrest.
- * It should not be possible to move the backrest into another position after it has been locked.

(12) Maintenance



Dirt can impair the function of the seat, so make sure you keep your seat clean.

Upholstery does not need to be removed from the seat frame for cleaning.

▲ Take care with the backrest - it may jerk forward and cause injury.

When cleaning the backrest cushion, the backrest must be held in place when operating the backrest lever.


* Do not clean the seat with a pressure washer.

During cleaning, the upholstery must not be soaked through.

Use standard commercially available upholstery or plastics cleaning agent. Test first for compatibility on a small, concealed area.


5) SEAT (AIR SUSPENSION, OPTION)

The seat is adjustable to fit the contours of the operator's body. It will reduce operator fatigue due to long work hours and enhance work efficiency.




290F3CD28

(1) Weight adjustment




- ① The seat should be adjusted for the operator's weight by briefly pulling the actuator lever of the automatic weight and height adjuster (arrow) with the machine at a standstill and the operator's sitting on the seat.
 - The operator must sit absolutely still during adjustment.
- * Before adjusting the weight, adjust shock absorbers to the position "soft".
- * To prevent damage to the health, the setting for the operator's weight must be checked and adjusted before the machine is operated.

(2) Height adjustment




- ① The seat height can be set pneumatically and is continuously adjustable.
- ② The seat height can be altered by pulling or pressing the actuator lever fully out or in (arrow). If the adjustment reaches the top or bottom endstop, the height is adjusted automatically in order to guarantee a minimum spring travel.
- ** Before adjusting the weight, adjust shock absorbers to the position "soft".
- * In order to avoid damage, do not operate compressor for more than 1 minute.

(3) Seat pan angle adjustment




- ① The angle of the seat pan can be individually adjusted.
- ② To adjust the angle of the seat pan, lift the LH handle (see arrow). By exerting pressure on or off the seat pan it can be moved to the desired angle position.

(4) Seat depth adjustment



- ① The depth of the seat pan can be individually adjusted.
- ② To adjust the depth of the seat cushion, lift the RH handle (see arrow). By moving the seat cushion backwards or forwards the desired seating position can be reached.

(5) Absorber




- ① The absorber setting of the seat can be varied to suit the on and off-road working conditions.
 - The cushioning effect can be individually adjusted for this purpose.

Turn the lever to the desired position and release.


- 1 Soft
- 2 Hard

(6) Armrest adjustment




① The inclination of the armrests can be modified by turning the adjustment knob (arrow).

(7) Armrests




- ① The armrests can be folded up if required and the height individually adjusted.
- ② To adjust the armrests for height, separate the round cap (see arrow) from the cover, loosen the hexagon nut (size 13 mm), adjust the armrest to the desired position and tighten the nut again. Press the previously separated cap cover back onto the nut.

(8) Headrest




- ① The headrest can be individually adjusted for height by pulling it upward over the various increments up the end stop.
- ② By pushing forward or rearward the angle of the headrest can be adjusted individually.
- ③ To remove the headrest, pull it over the end stop.

(9) Seat heater switch



① The seat heater is turned on by pressing the switch.

(10) Lumbar support




- ① By turning the adjustment knob to the left or right, both the height and curvature of the backrest cushion can be individually adjusted.
- ② This increases both the seating comfort and the performance of the operator.

(11) Backrest adjustment




- ① The backrest is adjusted using the locking lever (arrow).
- * The locking lever must latch into the desired position. It should not be possible to move the backrest into another position when it is locked.

(12) Fore & after adjustment




- ① The fore/after adjustment is released by lifting the locking lever.
- ** The locking lever must latch into the desired position. It should not be possible to move the operator seat into another position when it is locked.

(13) Seat belt



▲ Fail to wear a seat belt during machine operation may result in serious injury or death in the event of an accident or machine overturn.


6) FUSE & RELAY BOX



290F3CD25

- (1) The fuses protect the electrical parts and wiring from burning out.
- (2) The fuse box cover indicates the capacity of each fuse and circuit it protects.
- * Replace a fuse with another of the same capacity.
- ▲ Before replacing a fuse, be sure to turn OFF the starting switch.

7) MCU




- (1) To match the pump absorption torque with the engine torque, MCU varies EPPR valve output pressure, which control pump discharge amount whenever feedbacked engine speed drops under the reference rpm of each mode set.
- (2) Three LED lamps on the MCU display as below.

LED lamp	Trouble	Service
G is turned ON	Normal	-
G and R are turned ON	Trouble on MCU	· Change the MCU
G and Y are turned ON	Trouble on serial communication line	Check if serial communication lines between controller and cluster are disconnected
Three LED are turned OFF	Trouble on MCU power	Check if the input power wire (24 V, GND) of controller is disconnected
		Check the fuse


G: green, R: red, Y: yellow

8) EMERGENCY ENGINE SPEED CONTROL CONNECTOR




- (1) When the CAN communication between the ECM and the MCU is abnormal due to malfunction, change the CN-16 connection from CN-16A to CN-16B and then control the engine speed by rotating the multimodal module of the haptic controller.
- Never connect connector CN-16 with CN-16B when MCU is in normal operation.
- Make repair as soon as possible.

9) SERVICE METER



- (1) This meter shows the total operation hours of the machine.
- (2) Always ensure the operating condition of the meter during the machine operation. Inspect and service the machine based on hours as indicated in chapter 6, maintenance.

10) MCU/ECM CONNECTOR




- (1) MCU communicates the machine data with Laptop computer through the connector.
- (2) ECM communicates the engine data with cummins INSITE adapter through the connector.
- ① ECM fault code check
- 2 ECM program change
- 3 Engine data monitoring & test

11) SERVICE SOCKET (12V)



(1) Utilize the power of 12 V as your need and do not exceed power of 12 V, 30 W.

12) UPPER WINDSHIELD



- (1) Perform the following procedure in order to open the upper windshield.
- ① Pull both levers with hold both grips that are located at the top of the windshield frame and push the windshield upward.
- ② Hold both grips and back into the lock position until auto lock latch is engaged, then release the grips.
- ♠ When working, without having locked the windshield by the auto lock (by pushing the windshield to the rear untill it's completely fixed), please be careful as it can cause personal injury if the windshield is not fixed or falls off.



- (2) Perform the following procedure in order to close the upper windshield.
- ① Pull the lever of the auto lock latch in order to release the auto lock latch.
- ② Reverse above step ① and ② in order to close the upper windshield.


1. SUGGESTION FOR NEW MACHINE

- 1) It takes about 100 operation hours to enhance its designed performance.
- 2) Operate according to below three steps and avoid excessive operation for the initial 100 hours.

Service meter	Load
Until 10 hours	About 60 %
Until 100 hours	About 80 %
After 100 hours	100 %


- ※ Excessive operation may deteriorate the potential performance of machine and shorten lifetime of the machine.
- 3) Be careful during the initial 100 hours operation
- (1) Check daily for the level and leakage of coolant, engine oil, hydraulic oil and fuel.
- (2) Check regularly the lubrication and fill grease daily all lubrication points.
- (3) Tighten bolts.
- (4) Warm up the machine fully before operation.
- (5) Check the gauges occasionally during the operation.
- (6) Check if the machine is operating normally during operation.
- 4) Replace followings after initial 250 hours of operation

Checking items	Hours
Engine oil	
Engine oil filter element	
Fuel filter	
Prefilter	
Hydraulic oil return filter element	250
Hydraulic oil tank drain filter cartridge	
Line filter element	
Swing reduction gear oil	
Travel reduction gear oil	



2. CHECK BEFORE STARTING THE ENGINE


- Look around the machine and under the machine to check for loosen nut or bolts, collection of dirt, leakage of oil, fuel or coolant and check the condition of the work equipment and hydraulic system. Check also loosen wiring and collection of dust at places which reach high temperature.
- Refer to the daily check on the chapter 6, maintenance.
- 2) Adjust seat to fit the contours of the operator's body for the pleasant operation.
- 3) Adjust the rear view mirror.



3. STARTING AND STOP THE ENGINE


1) CHECK INDICATOR LIGHTS

- (1) Check if all the operating levers are in the neutral position.
- (2) Turn the starting switch to the ON position. Buzzer sounding for 4 seconds with HYUN-DAI logo on cluster.
- If the ESL mode is set to the enable, enter the password to start engine.
- If the password has failed 5 times, please wait 30 minutes before re-attempting to enter the password.
- Refer to page 3-24 for ESL mode.
- (3) After initialization of cluster, the operating screen is displayed on LCD (1).
 Also, self-diagnostic function is carried out.




2) STARTING ENGINE IN NORMAL TEMPERATURE

- Sound the horn to warn the surroundings after checking if personnel or obstacles are in the area.
- (1) Turn the multimodal dial to low idle position.
- (2) Turn the starting switch to START position to start the engine.
- Do not hold the starting switch in the START position for longer than 20 seconds.
 - The start system may be seriously damaged.
- If the engine does not start, allow the stater to cool for about 2 minutes before re-attempting to start the engine again.
- (3) Release the starting switch instantly after the engine starts to avoid possible damage to the starting motor.



3) STARTING ENGINE IN COLD WEATHER

- Sound horn to warn surroundings after checking if there are obstacles in the area.
- Replace the engine oil and fuel referring to recommended oils at page 2-30.
- Fill the anti-freeze solution to the coolant as required.
- If you turn ON the starting switch, the fuel warmer is automatically operated to heat the fuel by sensing the coolant temperature.
- (1) Check if all the levers are in the neutral position.
- (2) Turn the multimodal dial to low idle position.
- (3) Turn the starting switch to the ON position, and wait 1~2 minutes. More time may take according to ambient temperature.
- (4) Wait for five minutes to warm up the engine after the preheating pilot lamp off, and than turn the starting switch to the START position to start the engine.
- If the engine does not start, allow the starter to cool for about 2 minutes before attempting to start the engine again.
- (5) Release the starting switch immediately after starting engine.
- (6) If the temperature of the coolant is lower than 30°C the warming up automatically starts.
- Do not operate the working devices, or convert the operation mode into other mode during the warming up.



4) INSPECTION AFTER ENGINE START


Inspect and confirm the following after engine starts.

- (1) Is the level gauge of hydraulic oil tank in the normal level?
- (2) Are there leakages of oil or water?
- (3) Are all the warning lamps turned OFF (1-13)? The seat belt reminder warning lamp (16) pops up and the buzzer sounds until fasten the seat belt.
- (4) Are the indicator of water temperature gauge (14) and hydraulic temperature gauge (15) in the operating range?
- (5) Are the engine sound and the color of exhaust gas normal?
- (6) Are the sound and vibration normal?
- Do not increase engine speed quickly after starting, it can damage engine or turbocharger.
- If there are problems in the cluster, stop the engine immediately and correct problems as required.

5) WARMING-UP OPERATION


- ** The most suitable temperature for the hydraulic oil is about 50°C (122°F).
 It can cause serious trouble in the hydraulic system by sudden operation when the hydraulic oil temperature is below 25°C (77°F).
 Then temperature must be raised to at least 25°C (77°F) before starting work.
- (1) Run the engine at low idle speed for 5 minutes.
- (2) Speed up the engine by multimodal dial and run the engine at mid-range speed.
- (3) Operate bucket lever for 5 minutes.
- Do not operate anything except bucket lever.
- (4) Run the engine at the high speed and operate the bucket lever and arm lever for 5-10 minutes.
- Operate only the bucket lever and arm lever.
- (5) This warming-up operation will be completed by operation of all cylinders several times, and operation of swing and traveling.





6) TO STOP THE ENGINE

- If the engine is abruptly stopped before it has cooled down, engine life may be greatly shortened. Consequently, do not abruptly stop the engine apart from an emergency.
- In particular, if the engine has overheated, do not abruptly stop it but run it at medium speed to allow it to cool gradually, then stop it.
- (1) Down the bucket on the ground then put all the levers in the neutral position.
- (2) Run the engine at low idle speed for about 5 minutes.
- (3) Return the key of starting switch to the OFF position.
- (4) Remove the key to prevent other people using the machine and the safety knob.
- (5) Lock the cab door.



4. MODE SELECTION SYSTEM

1) STRUCTURE OF MECHATRONICS SYSTEM

CAPO, Computer Aided Power Optimization system, is the name of mode selection system developed by HD Hyundai Construction Equipment.

Please refer to chapter 3, cluster for below modes setting.

(1) Power mode

Power mode designed for various work loads supports high performance and reduces fuel consumption.

P mode : Heavy duty powerS mode : Standard powerE mode : Economy power

(2) Work mode

One of the two work modes can be selected for the optimal work condition of the machine operation.

① General work mode (bucket)

When key switch is turned ON, this mode is selected automatically.

② Work tool mode (breaker, crusher)

It controls the pump flow and system pressure for the optimal operation of breaker or crusher.

3 Lifting mode

Through RPM reduction, power boost activation and pump flow control, it improves fine operability and lift capability.

(3) User mode

① User mode is useful for setting the user preperable power quickly.

(engine speed, power shift and idle speed)

② There are two methods for use of user mode.

a. In operation screen

User mode switch is used to memorize the current machine operating status and activate the memorized user mode.

Refer to page 3-16.

b. In menu

Engine high idle rpm, auto idle rpm and pump torque (power shift) can be modulated and memorized separately in menu status.

 Each memory mode has a initial set which are mid-range of max engine speed, power shift and auto idle speed.





- High idle rpm, auto idle rpm and EPPR pressure can be adjusted and memorized in the U-mode.
- ** Refer to the page 3-20 for setting the user mode (available on U mode only).
 - · LCD segment vs parameter setting

Step (■)	Engine speed (rpm)	Idle speed (rpm)	Power shift (bar)
1	1300	800	0
2	1400	850	3
3	1450	900	6
4	1500	950	9
5	1550	1000 (auto decel)	12
6	1600	1050	16
7	1650	1100	20
8	1700	1150	26
9	1750	1200	32
10	1800	1250	38

*One touch decel & low idle: 900 rpm



(4) Travel mode

: Low speed traveling.: High speed traveling.

(5) Auto idle mode

Pilot lamp ON: Auto idle function is activated. Pilot lamp OFF: Auto idle function is canceled.

(6) Monitoring system

Information of machine performance as monitored by the MCU can be displayed on the LCD. Refer to the page 3-22.

(7) Self diagnostic system

① MCU (Machine Control Unit)

The MCU diagnoses machine status and problems and displays fault code in the cluster (fault code detected by MCU is composed of HCESPN and FMI).

② Engine ECM (Electronic Control Module) If the engine or relevant system has problem, engine ECM detects and displays on the LCD

as fault codes (this code is composed of SPN and FMI).

* Refer to the page 3-22 for LCD display.

(8) Anti-restart system

The system protects the starter from inadvertent restarting after the engine is already operational.

2) HOW TO OPERATE MODE SELECTION SYSTEM


(1) When start key switch is turned ON


- ① When start key switch is turned on, the cluster turns on and buzzer sounds for 4 seconds. And then main information as gauges and engine speed are displayed on LCD.
- ② Initial default mode settings are displayed in the cluster.

Mode		Status
Power mode	Е	ON
Work mode	₽	ON
Travel mode	Low (ON
Auto idle	Ø	ON

* These setting can be changed at U mode.


3 Self-diagnostic function can be carried out from this point.





(2) After engine start

- ① When the engine is started, rpm display indicates low idle, 900 rpm.
- ② If coolant temperature is below 30°C, the warming up pilot lamp lights ON and after 4 seconds the engine speed increases to 1000 rpm automatically to warm up the machine.
 - · After 2-3 minutes, you can select any mode depending on job requirement.



3) SELECTION OF POWER MODE

(1) E mode

The multimodal dial is set 10 and the auto idle mode is canceled.

Engine rpm	Effect
1550	Variable power control in proportion to lever stroke (improvement in fuel efficiency) ** Same power as S mode in full lever operation.


When the multimodal dial is located below 9 the engine speed decreases about 50~100 rpm per dial set.


(2) S mode

The multimodal dial is set 10 and the auto idle mode is canceled.

Engine rpm	Effect
1600	Standard power

When the multimodal dial is located below 9 the engine speed decreases about 50~100 rpm per dial set.






(3) P mode

The multimodal dial is set 10 and the auto idle mode is canceled.

Engine rpm	Effect
1700	Approximately 120 % of power and speed available than S mode.

When the multimodal dial is located below 9 the engine speed decreases about 50~100 rpm per dial set.




5. OPERATION OF THE WORKING DEVICE

- Confirm the operation of control lever and working device.
- 1) Left control lever controls arm and swing.
- 2) Right control lever controls boom and bucket.
- 3) When you release the control lever, control lever returns to neutral position automatically.
- When operating swing, consider the swing distance by inertia.




** Left control lever

- 1 Arm roll-out
- 2 Arm roll-in
- 3 Swing right
- 4 Swing left



※ Right control lever

- 5 Boom lower
- 6 Boom raise
- 7 Bucket roll-out
- 8 Bucket roll-in



6. TRAVELING OF THE MACHINE

1) BASIC OPERATION

(1) Traveling position


It is the position which the traveling motor is in the rear and the working device is forward.

♠ Be careful as the traveling direction will be reversed when the whole machine is swinged 180 degree.

(2) Traveling operation


It is possible to travel by either travel lever or pedal.

- Do not travel continuously for a long time.
- Reduce the engine speed and travel at a low speed when traveling on uneven ground.




When the left and right travel lever or pedal are pushed at the same time, the machine will travel forward or backward.

The speed can be controlled by the operation stroke of lever or pedal and change of direction will be controlled by difference of the left and right stroke.




(4) Pivot turning


Operating only one side of lever or pedal make the change of direction possible by moving only one track.



(5) Counter rotation

It is to change the direction at the original place by moving the right and left track. Both side of lever or pedal are operated to the other way at the same time.







2) TRAVELING ON A SLOPE

- (1) Make sure that the travel lever is properly maneuvered by confirming the travel motor is in the right location.
- (2) Lower the bucket 20 to 30 cm (1 ft) to the ground so that it can be used as a brake in an emergency.
- (3) If the machine starts to slide or loses stability, lower the bucket immediately and brake the machine.
- (4) When parking on a slope, use the bucket as a brake and place blocks behind the tracks to prevent sliding.
- Machine cannot travel effectively on a slope when the oil temperature is low. Do the warming-up operation when it is going to travel on a slope.
- ▲ Be careful when working on slopes. It may cause the machine to lose its balance and turn over.
- ♠ Be sure to keep the travel speed switch on the LOW (turtle mark) while traveling on a slope.
- A Be sure to keep the swing lock/fine switch on the LOCK while traveling on a slope (if equipped).

3) TRAVELING ON SOFT GROUND

- If possible, avoid to operate on soft ground.
- (1) Move forward as far as machine can move.
- (2) Take care not to go beyond the depth where towing is impossible on soft ground.
- (3) When driving becomes impossible, lower bucket and use boom and arm to pull the machine. Operate boom, arm, and travel lever at the same time to avoid the machine sinking.






4) TOWING THE MACHINE


Tow the machine as follows when it can not move on it's own.

- (1) Tow the machine by other machine after hook the wire rope to the frame as shown in picture at right.
- (2) Hook the wire rope to the frame and put a support under each part of wire rope to prevent damage.
- Never tow the machine using only the tie hole, because this may break.
- ▲ Make sure no personnel are standing close to the tow rope.




7. EFFICIENT WORKING METHOD


 Do the digging work by arm.
 Use the pulling force of arm for digging and use together with the digging force of the bucket if necessary.




2) When lowering and raising the boom operate softly for the beginning and the end.In particularly, sudden stops while lowering the boom may cause damage to the machine.




 The digging resistance and wearing of tooth can be reduced by putting the end of bucket tooth to the digging direction.




 Set the tracks parallel to the line of the ditch to be excavated when digging ditch. Do not swing while digging.




5) Dig slowly with keeping the angle of boom and arm, 90-110 degree when maximum digging force is required.




6) Operate leaving a small safety margin of cylinder stroke to prevent damage of cylinder when working with the machine.




- Keep the bucket to the dumping position and the arm horizontal when dumping the soil from the bucket.
 - Operate bucket lever 2 or 3 times when hard to dump.
- Do not use the impact of bucket tooth when dumping.



8) Operate stop of swing considering the swing slip distance is created by inertia after neutralizing the swing lever.




 If the excavation is in an underground location or in a building, make sure that there is adequate overhead clearance and that there is adequate ventilation.




10) Do not use the dropping force of the work equipment for digging.

The machine can be damaged by the impact.



11) Do not use the bucket to crack hard objects like concrete or rocks.

This may break a tooth or pin, or bend boom.



12) NEVER CARRY OUT EXCESSIVE OPERATIONS


Operation exceeding machine performance may result in accident or failure.

Carry out lifting operation within specified load limit

Never carry out operations which may damage the machine such as overload or over-impactload.

Never travel while carrying a load.

In case you need installing over load warning device for object handling procedure, please contact HD Hyundai Construction Equipment distributor.



12) BUCKET WITH HOOK

When carrying out lifting work, the special lifting hook is necessary.

The following operations are prohibited.

- · Lifting loads with a wire rope fitted around the bucket teeth.
- · Lifting loads with the wire rope wrapped directly around the boom or arm.

When performing lifting operation, securely hook the wire rope onto the special lifting hook.

When performing lifting operation, never raise or lower a person.


Due to the possible danger of the load falling or of collision with the load, no persons shall be allowed in the working area.

Before performing lifting operation, designate an operation supervisor.

Always execute operation according to his instructions.

- · Execute operating methods and procedures under his direction.
- Select a person responsible for signaling.
 Operate only on signals given by such person.


Never leave the operator's seat while lifting a load. Note the use of the fine swing function on the slope. The spin may occur that is not intended by the operator.



8. OPERATION IN THE SPECIAL WORK SITES

1) OPERATION THE MACHINE IN A COLD WEATHER

- (1) Use proper engine oil and fuel for the weather.
- (2) Fill the required amount of antifreeze in the coolant.
- (3) Refer to the starting engine in cold weather. Start the engine and extend the warming up operation.
- (4) Be sure to open the heater cock when using the heater.
- (5) Always keep the battery completely charged.
- Discharged batteries will freeze more easily than fully charged.
- (6) Clean the machine and park on the wood plates.



2) OPERATION IN SANDY OR DUSTY WORK SITES

- (1) Inspect air cleaner element frequently. Clean or replace element more frequently, if warning lamp comes ON and buzzer sounds simultaneously, regardless of inspection period.
- * Replace the inner and outer element after 4 times of cleaning.
- (2) Inspect radiator, oil cooler and condenser frequently, and keep cooling fins clean.
- (3) Prevent sand or dust from getting into fuel tank and hydraulic tank during refilling.
- (4) Prevent sand or dust from penetrating into hydraulic circuit by tightly closing breather cap of hydraulic oil tank. Replace hydraulic oil filter and air breather element frequently. Also, replace the fuel filter frequently.
- (5) Keep all lubricated part, such as pins and bushings, clean at all times.
- (6) If the air conditioner and heater filters clogged, the heating or cooling capacity will drop. Clean or replace the filter element more frequently.
- (7) Clean electrical components, especially the starting motor and alternator to avoid accumulation of dust.

3) SEA SHORE OPERATION

- (1) Prevent ingress of salt by securely tightening plugs, cocks and bolts of each part.
- (2) Wash machine after operation to remove salt residue.
 - Pay special attention to electrical parts, and hydraulic cylinders and track tension cylinder to prevent corrosion.
- (3) Inspection and lubrication must be carried out more frequently.
 - Supply sufficient grease to replace all old grease in bearings which have been submerged in water for a long time.

4) OPERATION IN MUD, WATER OR RAIN WORK SITES

- Perform a walk around inspection to check for any loose fittings, obvious damage to the machine or any fluid leakage.
- (2) After completing operations, clean mud, rocks or debris from the machine. Inspect for damage, cracked welds or loosened parts.
- (3) Perform all daily lubrication and service.
- (4) If the operations were in salt water or other corrosive materials, make sure to flush the affected equipment with fresh water.


5) OPERATION IN ROCKY WORK SITES

- Check for damage to the undercarriage and for looseness, flaws, wear and damage in bolts and nut.
- (2) Loosen the track tension a little when working in such areas.
- (3) Do not turn the undercarriage directly over the sharp edge rock.

9. NORMAL OPERATION OF EXCAVATOR

Followings may occur during operation due to the nature of a hydraulic excavator.


- When rolling in the arm, the roll-in movement stop momentary at point X in the picture shown, then recovers speed again after passing point X.
 The reason for this phenomenon is that movement by the arm weight is faster than the speed of oil flow into the cylinder.
- 2) When lowering the boom, one may hear continuous sound.This is caused by oil flow in the valve.
- Overloaded movement will produce sound caused by the relief valves, which are for the protection of the hydraulic systems.
- 4) When the machine is started swing or stopped, a noise near the swing motor may be heard. The noise is generated when the brake valve relieves.



10. ATTACHMENT LOWERING (when engine is stopped)

- 1) On machines equipped with an accumulator, for a short time (within 1 minute) after the engine is stopped, the attachment will lower under its own weight when the attachment control lever is shifted to LOWER. This happens only when the starting switch is ON and the safety knob is the in the UNLOCK position. After the engine is stopped, set the safety knob to the LOCK position.
- ♠ Be sure no one is under or near the attachment before lowering the boom.
- 2) The accumulator is filled with high-pressure nitrogen gas, and it is extremely dangerous if it is handled in the wrong way. Always observe the following precautions.
- A Never make any hole in the accumulator expose it to flame or fire.
- A Do not weld anything to the accumulator.
- When carrying out disassembly or maintenance of the accumulator, or when disposing of the accumulator, it is necessary to release the gas from the accumulator.

A special air bleed valve is necessary for this operation, so please contact your HD Hyundai Construction Equipment distributor.



11. STORAGE

Maintain the machine taking care of following to prevent the deterioration of machine when storing the machine for a long time, over 1 month.

1) BEFORE STORAGE

(1) Cleaning the machine


Clean the machine. Check and adjust tracks. Grease each lubrication part.

(2) Lubrication position of each part Change all oil.

Be particularly careful when you reuse the machine.

As oil can be diluted during storage.

Apply an anticorrosive lubricant on the exposed part of piston rod of cylinder and in places where the machine rusts easily.




- 1 Lubricating manifold (5EA)
- 2 Boom cylinder pin (2EA)
- 3 Lubricating manifold (3EA)
- 4 Arm and bucket (7EA)
- 5 Boom rear bearing center (1EA)

290F4OP20

(3) Master switch

Turn OFF the master switch mounted electric box and store the machine.


- ▲ Off the master switch after lamp off.
- ▲ It may cause severe failure of aftertreatment device.
- (4) Be sure to mix anticorrosive antifreezing solution in the radiator.



(5) Prevention of dust and moisture

Keep machine dry. Store the machine setting wood on the ground.


- Cover exposed part of piston rod of cylinder.
- X Lower the bucket to the ground and set a support under track.



2) DURING STORAGE

Start engine and move the machine and work equipment once a month and apply lubrication to each part.

- * Check the level of engine oil and coolant and fill if required when starting engine.
- Clean the anticorrosive on the piston rod of cylinder.
- * Operate the machine such as traveling, swing and work equipment operation to make sure enough lubrication of all functional components.



*** BATTERY**

- ① Once a month, start the engine for 15 minutes (or use a charger) to charge the battery.
- 2 Every 2 months, check the battery voltage and keep battery voltage over 25.08V.
- ③ If the machine stock period is over 6 months, disconnect the battery negative (-) terminal.

3) AFTER STORAGE

Carry out the following procedure when taking out of a long time storage.

- (1) Wipe off the anticorrosive lubricant on the hydraulic piston rod.
- (2) Completely fill fuel tank, lubricate and add oil.

(3) When storage period is 6 months over


If the machine stock period is over 6 months, carry out the following procedure.

This procedure is to drain condensation water for the **swing reduction gear** durability.

- * Remove the drain port plug and drain the water until the gear oil comes out and then tighten the drain plug.
- * Refer to the service instruction, section 6 for the drain plug location.
- * If the machine is stored without carrying out the monthly lubricating operation, consult your HD Hyundai Construction Equipment dealer for service.

12. RCV LEVER OPERATING PATTERN

1) PATTERN CHANGE VALVE NOT INSTALL (standard)



- Whenever a change is made to the machine control pattern also exchange the pattern label in the cab to match the new pattern.
- ** The hose modification works must be carried out between RCV lever and terminal block (Not between terminal block and MCV).

330F4OP01

	Oper	ation			Hose connection (port)					
Pattern	Left RCV lever Right RCV lever		Control function		RCV	Change of To	erminal block			
	Lett 1 to v level	Tilgitt to vilovoi			lever	From	То			
ISO Type	4	E	1Arm out	2	D	-				
.55 .765	 	عراد		2Arm in	4	Е	-			
		。 ≪	Left	3Swing right	3	В	-			
	$\stackrel{4}{\bigcirc} \leftarrow \stackrel{\uparrow}{:} \rightarrow \stackrel{3}{\bigcirc}$	8 1 7 7 7 7 7 1 9 1 9 1		4Swing left	1	Α	-			
		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		5Boom lower	4	J	-			
HD Hyundai	, C	Δ	Diabt	6Boom raise	2	Н	1			
Construction	→ ~	<i>σ</i> , ε,	Right	7Bucket out	1	G	-			
Equipment	۷	0		8Bucket in	3	F	-			
A Type	1	F		1Boom lower	2	D	J			
7,	<i>ع</i> لا	5 •	Left	2Boom raise	4	E	Н			
			Leit	3Swing right	3	В	-			
	$\frac{4}{2}$ \uparrow $\frac{3}{2}$	$\begin{bmatrix} 8 \\ 1 \end{bmatrix}$		4Swing left	1	Α	-			
		8		5Arm out	4	J	D			
	$\dot{\Delta}$	<u>,</u>	Diabt	6Arm in	2	Н	E			
	77°	6	Right 7Bucket o	7Bucket out	1	G	-			
	2			8Bucket in	3	F	-			
В Туре	1	$ \begin{array}{c} 5\\ 8\\ \uparrow \\ \uparrow \\ \uparrow \\ \downarrow \\ \downarrow \end{array} $			1Boom lower	2	D	J		
- ') -	عراد			Loft	2Boom raise	4	E	Н		
	\downarrow \swarrow \downarrow \downarrow			8 A 7		Left	3Bucket in	3	В	F
	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\						4Bucket out	1	Α	G
	(5Arm out	4	J	D		
			Right	6Arm in	2	Н	Е			
	6	7Swing right	1	G	В					
				8Swing left	3	F	Α			
C Type	C Type 1 5			① Loosen the R		-	-			
, ,	$\dot{\bigcirc}$	بخرا	Left	lever assy 90° counterclockwise; then install.						
	4 4 3 8 4 7	Leit	2 To put lever in			mble nut (22)				
	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$			and rotates or	nly lever 90°	clockwise.				
	ρ , \uparrow , ρ	3 1 1 C								
	\bigcirc		Right		Same as I	SO type				
	2	9	i iigiit		Juine as h	CO type				
	_									

2) PATTERN CHANGE VALVE INSTALL (option)


- * If the machine is equipped with the pattern change valve, the machine operation pattern can be easily changed.
- * Whenever a change is made to the machine control pattern also exchange the pattern label in the cab to match the new pattern.

Operation	ISO type	A type
Left RCV lever	$ \begin{array}{c} 1 \\ \downarrow \\ 4 \\ \uparrow \\ \downarrow \\ 2 \end{array} $	$ \begin{array}{c} 1 \\ 4 \\ 4 \\ 0 \\ 0 \\ 0 \end{array} $
Right RCV lever	$ \begin{array}{c} 5 \\ 7 \\ 6 \end{array} $	5 8 7 7 7 6

- (1) The machine control pattern can be easily changed from the "ISO type" to "A type" by changing the position of the lever position.
- ♠ Before starting the machine, check the lever position of pattern change valve and actual operating of attachment.

(2) Change of operating pattern

- ① Loosen bolt.
- ② Move lever to the "ISO" or "A" position.
- 3 After the lever is set, tighten the bolt in order to secure the lever.
 - · Position ① for "ISO" pattern.
 - · Position ② for "A" pattern.




13. SCR SYSTEM CLEANING

SCR system

- * The SCR system is used to decrease the mono-nitrogen oxides (NOx) emissions from the machine tailpipe.
- It is unlawful to tamper with, modify, or remove any component of the SCR system.
 It is also unlawful to use DEF/AdBlue® that does not meet the specifications provided or to operate the machine with no DEF/AdBlue®.
- * The type of SCR system cleaning composes of automatic SCR system cleaning and manual SCR system cleaning.
- ▲ SCR system cleaning generates hot exhaust and causes hot exhaust system components.
- A Exhaust system components get very hot and can cause severe burns. Risk for fire.
- ▲ Do not perform SCR system cleaning in a flammable environment.

(1) SCR system cleaning warning lamp



This warning lamp will light ON or blink when the SCR system cleaning is needed or activated.

- Refer to page 3-9 for details.
- The machine must be in a fireproof area during the entire SCR system cleaning process.

This warning lamp will light ON when the SCR system clean-

(2) SCR system cleaning inhibit warning lamp



※ Refer to page 3-9 for details.

ing switch is pushed inhibit position.

2609A3CD20


(3) HEST (high exhaust system temperature) warning lamp



This warning lamp will light ON when the exhaust temperatures are high due to SCR system cleaning.

* Refer to page 3-10 for details.

(4) SCR system cleaning switch




This switch is used to select the SCR system cleaning.

- * Refer to page 3-36 for details.
- Manual SCR system cleaning: refer to page 3-10 for details.


TRANSPORTATION


1. PREPARATION FOR TRANSPORTATION

- 1) When transporting the machine, observe the various road rules, road transportation vehicle laws and vehicle limit ordinances, etc.
- 2) Select proper trailer after confirming the weight and dimension from the chapter 2, specification.
- 3) Check the whole route such as the road width, the height of bridge and limit of weight and etc., which will be passed.
- 4) Get the permission from the related authority if necessary.
- 5) Prepare suitable capacity of trailer to support the machine.



A	В
1.0	3.65 ~ 3.85
1.1	4.00 ~ 4.25
1.2	4.35 ~ 4.60
1.3	4.75 ~ 5.00
1.4	5.10 ~ 5.40
1.5	5.50 ~ 5.75






2. DIMENSION AND WEIGHT

1) HX330 L

(1) Base machine

Mark	Description	Unit	Specification
L	Length	mm (ft-in)	5970 (19' 7")
Н	Height	mm (ft-in)	3160 (10' 4")
W	Width	mm (ft-in)	3280 (10' 9")
Wt	Weight	kg (lb)	26920 (59350)


 $^{\,\,^{*}}$ With 600 mm (24") triple grouser shoes.



(2) Boom assembly

Mark	Description	Unit	Specification
L	Length	mm (ft-in)	6670 (21' 11")
Н	Height	mm (ft-in)	1720 (5' 8")
W	Width	mm (ft-in)	785 (2' 7")
Wt	Weight	kg (lb)	3060 (6750)


^{** 6.45} m (21' 2") boom with arm cylinder (included piping and pins).



(3) Arm assembly

Mark	Description	Unit	Specification
L	Length	mm (ft-in)	4340 (14' 3")
Н	Height	mm (ft-in)	955 (3' 2")
W	Width	mm (ft-in)	435 (1' 5")
Wt	Weight	kg (lb)	1810 (3990)


^{3.2} m (10' 6") arm with bucket cylinder (included linkage and pins).



(4) Bucket assembly

Mark	Description	Unit	Specification
L	Length	mm (ft-in)	1850 (6' 1")
Н	Height	mm (ft-in)	1210 (4' 0")
W	Width	mm (ft-in)	1505 (4' 11")
Wt	Weight	kg (lb)	1230 (2710)


^{* 1.44} m³ (1.88 yd³) SAE heaped bucket (included tooth and side cutters).



(5) Boom cylinder

Mark	Description	Unit	Specification
L	Length	mm (ft-in)	2305 (7' 7")
Н	Height	mm (ft-in)	275 (0' 11")
W	Width	mm (ft-in)	420 (1' 5")
Wt	Weight	kg (lb)	560 (1235)


^{*} Included piping.



(6) Cab assembly


Mark	Description	Unit	Specification
L	Length	mm (ft-in)	1950 (6' 5") [2070 (6' 10")]
Н	Height	mm (ft-in)	1780 (5' 10") [1822 (6')]
W	Width	mm (ft-in)	1104 (3' 7") [1126 (3' 8")]
Wt	Weight	kg (lb)	495.3 (1092) [650.2 (1433)]

[]: with FOG GUARD



(7) Counterweight

Mark	Description	Unit	Specification
L	Length	mm (ft-in)	2980 (9' 9")
Н	Height	mm (ft-in)	1240 (4' 1")
W	Width	mm (ft-in)	590 (1' 11")
Wt	Weight	kg (lb)	6000 (13230)




2) HX330 NL

(1) Base machine

Mark	Description	Unit	Specification
L	Length	mm (ft-in)	5970 (19' 7")
Н	Height	mm (ft-in)	3160 (10' 4")
W	Width	mm (ft-in)	2990 (9' 10")
Wt	Weight	kg (lb)	26720 (58910)

^{*} With 600 mm (24") triple grouser shoes.




3) HX330 L HIGH WALKER

(1) Base machine


Mark	Description	Unit	Specification
L	Length	mm (ft-in)	5970 (19' 7")
Н	Height	mm (ft-in)	3460 (11' 4")
W	Width	mm (ft-in)	3470 (11' 5")
Wt	Weight	kg (lb)	29420 (64860)


^{*} With 600 mm (24") triple grouser shoes.





3. LOADING THE MACHINE

- 1) Load and unload the machine on a flat ground.
- 2) Use the gangplank with sufficient length, width, thickness and gradient.
- 3) Place the swing lock/fine switch to the LOCK position (if equipped) before fixing the machine at the bed of trailer and confirm if the machine parallels the bed of trailer.
 - Keep the travel motor in the rear when loading and in the front when unloading.











(2) Place the swing lock/fine switch to the LOCK position (if equipped) after the swing the machine 180 degree.




- (3) Lower the working equipment gently after the location is determined.
- Place rectangular timber under the bucket cylinder to prevent the damage of it during transportation.
- ▲ Be sure to keep the travel speed switch on the LOW (turtle mark) while loading and unloading the machine.
- ♠ Avoid using the working equipment for loading and unloading since it will be very dangerous.
- ♠ Do not operate any other device when loading.
- A Be careful on the boundary place of loading plate or trailer as the balance of machine will abruptly be changed on the point.




4. FIXING THE MACHINE


- 1) Lower down the working device on the loading plate of trailer.
- 2) Keep the safety knob on the LOCK position.
- 3) Turn OFF all the switches and remove the key.



4) Secure all locks.




5) Place timber underneath of the track and fix firmly with wire rope to prevent the machine from moving forward, backward, right or left.



5. LOADING AND UNLOADING BY CRANE


- ♠ The wrong hoisting method or installation of lifting device can cause serious injury, death, or damage to the machine.
- Check the weight, length, width and height of the machine referring to chapter 7, Specification when you are going to hoist the machine.
- Use approved lifting device and ensure distance between lifting device and machine to avoid con tact between the two.
- Remove any parts (footboard, etc) that may be damaged by contact with the lifting device before lifting.
- 3) Place rubber plates at lifting points to avoid any damage to the machine.
- 4) Place crane in the proper place.
- 5) Install approve lifting device as shown in the illustration.
- 6) Use stay between the wire rope and the machine to prevent damage to the rope or machine. Set the lifting angle of the wire rope to 30°~ 40°.
- After the machine comes off the ground, check the hook condition and the lifting posture, and then lift slowly.
- ♠ Ensure that lifting device is free form any damage and is approved for the weight being lifted and supported.
- ♠ Place the safety knob to LOCK position to prevent the machine from moving when hoisting the machine.
- ♠ Do not load abruptly.
- A Keep area clear of any and all personnel.



1. INSTRUCTION

1) INTERVAL OF MAINTENANCE

- (1) You may inspect and service the machine by the period as described at page 6-11 based on hour meter at control panel.
- (2) Shorten the interval of inspect and service depending on site condition. (such as dusty area, quarry, sea shore and etc.)
- (3) Practice the entire related details at the same time when the service interval is doubled. For example, in case of 100hours, carry out all the maintenance 「Each 100hours, each 50 hours and daily service」 at the same time.



2) PRECAUTION

- (1) Start to maintenance after you have the full knowledge of machine.
- (2) The monitor installed on this machine does not entirely guarantee the condition of the machine. Daily inspection should be performed according to clause 4, maintenance check list.
- (3) Engine and hydraulic components have been preset in the factory. Do not allow unauthorized personnel to reset them.
- (4) Drain the used oil and coolant in a container and handle according to the method of handling for industrial waste to meet with regulations of each province or country.
- ♠ Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact skin.
- △ Accumulated grease and oil on the machine is a fire hazard. Remove this debris with steam cleaning or high pressure water, at least every 1000 hours.
- Inspect the engine compartment for any trash build up. Remove any trash build up from the engine compartment.
- (5) Ask to your local dealer or HD Hyundai Construction Equipment for the maintenance advice if unknown.

3) PROPER MAINTENANCE

(1) Replace and repair of parts


It is required to replace the wearable and consumable parts such as bucket tooth, side cutter, filter and etc., regularly.

Replace damaged or worn parts at proper time to keep the performance of machine.


- (2) Use genuine parts.
- (3) Use the recommended oil.
- (4) Remove the dust or water around the inlet of oil tank before supplying oil.
- (5) Drain oil when the temperature of oil is warm.
- (6) Do not repair anything while operating the engine.
 - Stop the engine when you fill the oil.
- (7) Relieve hydraulic system of the pressure before repairing the hydraulic system.
- (8) Confirm if the cluster is in the normal condition after completion of service.
- (9) For more detail information of maintenance, please contact local HD Hyundai Construction Equipment dealer.
- Be sure to start the maintenance after fully understand the chapter 1, safety hints.

4) RELIEVING THE PRESSURE IN THE HYDRAULIC SYSTEM


- Spouting of oil can cause the accident when loosening the cap or hose right after the operating of machine as the machine or oil is on the high pressure on the condition.
 Be sure to relieve the pressure in the system before repairing hydraulic system.
- (1) Place machine in parking position, and stop the engine.



- (2) Set the safety knob completely in the UNLOCK position, operate the control levers and pedals fully to the front, rear, left and right, to release the pressure in the hydraulic circuit.
- * This does not completely release the pressure, so when serving hydraulic component, loosen the connections slowly and do not stand in the direction where the oil spurt out.



(3) Relieve the pressure in the tank by pushing the top of the air breather.



5) PRECAUTION WHEN INSTALLING HYDRAULIC HOSES OR PIPES

- Be particularly careful that the joint of hose, pipe and functioning item are not damaged.
 Avoid contamination.
- (2) Assemble after cleaning the hose, pipe and joint of functioning item.
- (3) Use genuine parts.
- (4) Do not assemble the hose in the condition of twisted or sharp radius.
- (5) Keep the specified tighten torque.

6) PERIODICAL REPLACEMENT OF SAFETY PARTS

- It is desirable to do periodic maintenance the machine for using the machine safely for a long time.
 - However, recommend to replace regularly the parts related safety not only safety but maintain satisfied performance.
- (2) These parts can cause the disaster of life and material as the quality changes by passing time and it is worn, diluted, and gets fatigued by using repeatedly.
 - These are the parts which the operator can not judge the remained lifetime of them by visual inspection.
- (3) Repair or replace if an abnormality of these parts is found even before the recommended replacement interval.

Perio	Interval			
Engine		Fuel hose (tank-engine)	Every 2 years	
		Heater hose (heater-engine)		
		Pump suction hose	Every 2 years	
	Main circuit	Pump delivery hose		
Hydraulic		Swing hose	L youro	
system		Boom cylinder line hose		
	Working device	Arm cylinder line hose	Every 2 years	
		Bucket cylinder line hose	2 yours	

- * 1. Replace O-ring and gasket at the same time when replacing the hose.
 - Replace clamp at the same time if the hose clamp is cracked when checking and replacing the hose.

2. TIGHTENING TORQUE

Use following table for unspecified torque.

1) BOLT AND NUT

(1) Coarse thread

Bolt size	8.8	8T	10	10.9T		.9T
DOIL SIZE	kgf · m	lbf · ft	kgf · m	lbf ⋅ ft	kgf · m	lbf ⋅ ft
M 6×1.0	0.8 ~ 1.2	5.8 ~ 8.6	1.2 ~ 1.8	8.7 ~ 13.0	1.5 ~ 2.1	10.9 ~ 15.1
M 8×1.25	2.0 ~ 3.0	14.5 ~ 21.6	2.8 ~ 4.2	20.3 ~ 30.4	3.4 ~ 5.0	24.6 ~ 36.1
M10×1.5	4.0 ~ 6.0	29.0 ~ 43.3	5.6 ~ 8.4	40.5 ~ 60.8	6.8 ~ 10.0	49.2 ~ 72.3
M12×1.75	6.8 ~ 10.2	50.0 ~ 73.7	9.6 ~ 14.4	69.5 ~ 104	12.3 ~ 16.5	89.0 ~ 119
M14×2.0	10.9 ~ 16.3	78.9 ~ 117	16.3 ~ 21.9	118 ~ 158	19.5 ~ 26.3	141 ~ 190
M16×2.0	17.9 ~ 24.1	130 ~ 174	25.1 ~ 33.9	182 ~ 245	30.2 ~ 40.8	141 ~ 295
M18×2.5	24.8 ~ 33.4	180 ~ 241	34.8 ~ 47.0	252 ~ 340	41.8 ~ 56.4	302 ~ 407
M20×2.5	34.9 ~ 47.1	253 ~ 340	49.1 ~ 66.3	355 ~ 479	58.9 ~ 79.5	426 ~ 575
M22×2.5	46.8 ~ 63.2	339 ~ 457	65.8 ~ 88.8	476 ~ 642	78.9 ~ 106	570 ~ 766
M24×3.0	60.2 ~ 81.4	436 ~ 588	84.6 ~ 114	612 ~ 824	102 ~ 137	738 ~ 991
M30×3.5	120 ~161	868 ~ 1164	168 ~ 227	1216 ~ 1641	202 ~ 272	1461 ~ 1967

(2) Fine thread

Polt size	8.	.8T	10.9T 12		.9T	
Bolt size	kgf · m	lbf ⋅ ft	kgf · m	lbf ⋅ ft	kgf · m	lbf ⋅ ft
M 8×1.0	2.1 ~ 3.1	15.2 ~ 22.4	3.0 ~ 4.4	21.7 ~ 31.8	3.6 ~ 5.4	26.1 ~ 39.0
M10×1.25	4.2 ~ 6.2	30.4 ~ 44.9	5.9 ~ 8.7	42.7 ~ 62.9	7.0 ~ 10.4	50.1 ~ 75.2
M12×1.25	7.3 ~ 10.9	52.8 ~ 78.8	10.3 ~ 15.3	74.5 ~ 110	13.1 ~ 17.7	94.8 ~ 128
M14×1.5	12.4 ~ 16.6	89.7 ~ 120	17.4 ~ 23.4	126 ~ 169	20.8 ~ 28.0	151 ~ 202
M16×1.5	18.7 ~ 25.3	136 ~ 182	26.3 ~ 35.5	191 ~ 256	31.6 ~ 42.6	229 ~ 308
M18×1.5	27.1 ~ 36.5	196 ~ 264	38.0 ~ 51.4	275 ~ 371	45.7 ~ 61.7	331 ~ 446
M20×1.5	37.7 ~ 50.9	273 ~ 368	53.1 ~ 71.7	384 ~ 518	63.6 ~ 86.0	460 ~ 622
M22×1.5	51.2 ~ 69.2	370 ~ 500	72.0 ~ 97.2	521 ~ 703	86.4 ~ 116	625 ~ 839
M24×2.0	64.1 ~ 86.5	464 ~ 625	90.1 ~ 121	652 ~ 875	108 ~ 146	782 ~ 1056
M30×2.0	129 ~ 174	933 ~ 1258	181 ~ 245	1310 ~ 1772	217 ~ 294	1570 ~ 2126

2) PIPE AND HOSE (FLARE type)

Thread size (PF)	Width across flat (mm)	kgf · m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

3) PIPE AND HOSE (ORFS type)

Thread size (UNF)	Width across flat (mm)	kgf · m	lbf ⋅ ft
9/16-18	19	4	28.9
11/16-16	22	5	36.2
13/16-16	27	9.5	68.7
1-3/16-12	36	18	130
1-7/16-12	41	21	152
1-11/16-12	50	35	253

4) FITTING

Thread size	Width across flat (mm)	kgf · m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

5) TIGHTENING TORQUE OF MAJOR COMPONENT

NI-	lo Descriptions		Dalt ains	Tor	que
No.		Descriptions	Bolt size	kgf · m	lbf ⋅ ft
1		Engine mounting bolt (engine-bracket)	M12 × 1.75	10 ± 1.0	72.3 ± 7.2
3		Engine mounting bolt (bracket-frame)	M24 × 3.0	90 ± 9.0	651 ± 65
4	Engine	Radiator, oil cooler mounting bolt	M16 × 2.0	29.7 ± 4.5	215 ± 32.5
5		Coupling mounting socket bolt	M20 × 2.5	46.5 ±2.5	336 ±18.1
6		Fuel tank mounting bolt	M20 × 2.5	46 ± 5.1	333 ± 36.9
7		Main pump housing mounting bolt	M10 × 1.5	4.8 ± 0.3	34.7 ± 2.2
8		Main pump mounting socket bolt	M20 × 2.5	46.5 \pm 2.5	336 ± 18.1
9	Hydraulic system	Main control valve mounting nut	M12 × 1.75	12.2 ± 1.3	88.2 ± 9.4
10	- Cycloni	Hydraulic oil tank mounting bolt	M20 × 2.5	57.9 ± 5.8	419 ± 42
11		Turning joint mounting bolt, nut	M12 × 1.75	12.3 \pm 1.3	89.0 ± 9.4
12		Swing motor mounting bolt	M20 × 2.5	57.9 ± 5.8	419 ± 42
13	Power	Swing bearing upper part mounting bolt	M24 × 3.0	100 \pm 10	723 ± 72.3
14	train	Swing bearing lower part mounting bolt	M24 × 3.0	100 ± 10	723 ± 72.3
15	system	Travel motor mounting bolt	M24 × 3.0	84 \pm 8.0	608 ± 57.8
16		Sprocket mounting bolt	M20 × 2.5	57.9 ± 6.0	419 ± 43.4
17		Carrier roller mounting bolt, nut	M16 × 2.0	29.7 ± 3.0	215 ± 21.7
18		Track roller mounting bolt	M20 × 2.5	57.9 ± 6.0	419 ± 43.4
19	Under carriage	Track tension cylinder mounting bolt	M16 × 2.0	29.7 ± 4.5	215 ± 32.5
20	camage	Track shoe mounting bolt, nut	M22 × 1.5	123 \pm 6.0	890 ± 43.4
21		Track guard mounting bolt	M20 × 2.5	57.9 ± 8.7	419 ± 62.9
22		Counterweight mounting bolt	M36 × 3.0	337 ± 30	2440 ± 217
23	Others	Cab mounting bolt	M12 × 1.75	12.8 \pm 3.0	92.6 ± 21.7
24		Operator's seat mounting bolt	M 8 × 1.25	4.05 ± 0.8	29.3 ± 5.8

^{**} For tightening torque of engine and hydraulic components, see engine maintenance guide and service manual.

3. FUEL, COOLANT AND LUBRICANTS

1) NEW MACHINE

New machine used and filled with following lubricants.

Description	Specification
Engine oil (API CJ-4, ACEA-E9)	SAE 10W-30, *SAE 5W-40
DEF/AdBlue®	ISO 22241 (32.5% high-purity urea and 67.5% deionized water)
	HD Hyundai Construction Equipment genuine long life (ISO VG 32, VG 46, VG 68)
Hydraulic oil	Conventional hydraulic oil (ISO VG 15*)
	HD Hyundai Construction Equipment Bio Hydraulic Oil (HBHO, ISO VG 46)
Swing and travel reduction gear	SAE 80W-90 (GL-4/GL-5)
Grease	Lithium base grease NLGI No. 2
Fuel	ASTM D975-No. 2, Ultra low sulfur diesel
	ASTM D6210
Coolant (DCA4)	Mixture of 50% ethylene glycol base antifreeze and 50% water.
	Mixture of 60% ethylene glycol base antifreeze and 40% water.★

SAE : Society of Automotive Engineers

API : American Petroleum Institute

ISO: International Organization for Standardization

NLGI: National Lubricating Grease Institute

ASTM: American Society of Testing and Material

DEF: Diesel Exhaust Fluid

DEF compatible with AdBlue®

DCA4: Brand name of Chemical Additive

manufactured by the Cummins Fleetguard Co

Ultra low sulfur diesel

- sulfur content \leq 15 ppm

★Cold region

Russia, CIS, Mongolia

2) RECOMMENDED OILS

HD Hyundai Construction Equipment genuine lubricating oils have been developed to offer the best performance and service life for your equipment. These oils have been tested according to the specifications of HD Hyundai Construction Equipment and, therefore, will meet the highest safety and quality requirements. We recommend that you use only HD Hyundai Construction Equipment genuine lubricating oils and grease officially approved by HD Hyundai Construction Equipment.

		i ib i iyanaar oo	Ambient temperature °C(°F)	
Service	ce Kind of fluid	Service Kind of fluid	Capacity	-50 -30 -20 -10 0 10 20 30 40
point	ℓ (U.S. gal)	(-58) (-22) (-4) (14) (32) (50) (68) (86) (104		
			★SAE 5W-40	
-	Engine Engine oil		SAE 30	
oil pan		30 (7.9)	SAE 10W	
on pair			SAE 10W-30	
			SAE 15W-40	
			OAL IVIV-40	
DEF/ AdBlue®	Mixture of urea and deionized	42.5 (11.2)	ISO 22241, High-purity urea + deionized water (32.5:67.5)	
tank	water	42.5 (11.2)	130 22241, High-pully diea + delonized water (32.3.07.3)	
Swing		11 (0.01)		
drive		11 (2.91)	★SAE 75W-90	
1		7.8×2	SAE 80W-90	
drive		(2.1×2)		
		Tank : 210	★ISO VG 15	
Lludroulio		(55.5)	ISO VG 32	
Hydraulic tank	Hydraulic oil	rdraulic oil	ISO VG 46, HBHO VG 46*3	
		System : 414 (106.7)		
		(100.7)	ISO VG 68	
			★ASTM D975 NO.1	
Fuel tank	Diesel fuel*1	550 (145.3)		
			ASTM D975 NO.2	
Fitting			★NLGI NO.1	
(grease	Grease	As required		
nipple)		•	NLGI NO.2	
5	Mixture of			
Radiator (reservoir	antifreeze	55 (14 5)	Ethylene glycol base permanent type (50 : 50)	
tank)	and com	and soft 55 (14.5)	33 (14.3)	★Ethylene glycol base permanent type (60 : 40)

SAE: Society of Automotive Engineers

API : American Petroleum Institute

ISO: International Organization for Standardization

NLGI: National Lubricating Grease Institute

ASTM: American Society of Testing and Material

DEF: Diesel Exhaust Fluid DEF compatible with AdBlue®

* : Cold region (Russia, CIS, Mongolia)

★1 : Ultra low sulfur diesel

- sulfur content ≤ 15 ppm

★2 : Soft water

City water or distilled water

*3 : HD Hyundai Construction Equipment Bio Hydraulic Oil

- We Using any lubricating oils other than HD Hyundai Construction Equipment genuine products may lead to a
 deterioration of performance and cause damage to major components.

 We will be a second of the control of
- * Do not mix HD Hyundai Construction Equipment genuine oil with any other lubricating oil as it may result in damage to the systems of major components.
- * Do not use any engine oil other than that specified above, as it may clog the diesel particulate filter(DPF).
- * For HD Hyundai Construction Equipment genuine lubricating oils and grease for use in regions with extremely low temperatures, please contact HD Hyundai Construction Equipment dealers.

4. MAINTENANCE CHECK LIST

1) DAILY SERVICE BEFORE STARTING

Check items	Service	Page
Visual check		
Fuel tank	Check, Refill	6-29
Hydraulic oil level	Check, Add	6-35
Engine oil level	Check, Add	6-18
Coolant level	Check, Add	6-21
Control panel & pilot lamp	Check, Clean	6-45
Prefilter	Check, Clean	6-29
Fan belt tension and damage	Check, Adjust	6-26, 27
DEF/AdBlue® tank	Check, Add	6-33
★ Attachment pin and bushing	Lubricate	6-44
· Boom cylinder tube end		
· Boom foot		
· Boom cylinder rod end		
· Arm cylinder tube end		
· Arm cylinder rod end		
· Boom + Arm connecting		
· Bucket cylinder tube end		

[★] Lubricate every 10 hours or daily for initial 100 hours.

2) EVERY 50 HOURS SERVICE

Check items	Service	Page
Fuel tank (water, sediment)	Drain	6-29
Track tension	Check, Adjust	6-40
Swing reduction gear oil	Check, Add	6-38
Attachment pin and bushing	Lubricate	6-44
· Bucket cylinder rod end		
· Bucket + Arm connecting		
· Bucket control link + Arm		
· Bucket control rod		

3) INITIAL 50 HOURS SERVICE

Check items	Service	Page
Bolts & Nuts	Check, Tight	6-8
· Sprocket mounting bolts		
· Travel motor mounting bolts		
· Swing motor mounting bolts		
· Swing bearing mounting bolts		
· Engine mounting bolts		
· Counterweight mounting bolts		
· Turning joint locating bolts		
· Track shoe mounting bolts and nuts		
· Hydraulic pump mounting bolts		

4) EVERY 200 HOURS SERVICE

Check items	Service	Page
★ Return filter	Replace	6-37
★ Pilot line filter	Replace	6-38
★ Drain filter cartridge	Replace	6-37

[★] Replace 3 filters for continuous hydraulic breaker operation only.

5) INITIAL 250 HOURS SERVICE

Check items	Service	Page
Engine oil	Change	6-18, 19
Engine oil filter	Replace	6-18, 19
Prefilter (water, element)	Replace	6-29
Fuel filter element	Replace	6-30
Pilot line filter element	Replace	6-38
Hydraulic oil return filter	Replace	6-37
Drain filter cartridge	Replace	6-37
Swing reduction gear oil	Change	6-38
Travel reduction gear case	Change	6-39

6) EVERY 250 HOURS SERVICE

Check items	Service	Page
Battery (voltage)	Check, Clean	6-45
Swing bearing grease	Lubricate	6-38
Aircon & heater fresh air filter	Check, Clean	6-48
Bolts & Nuts	Check, Tight	6-8
· Sprocket mounting bolts		
· Travel motor mounting bolts		
· Swing motor mounting bolts		
· Swing bearing mounting bolts		
· Engine mounting bolts		
· Counterweight mounting bolts		
· Turning joint locating bolts		
· Track shoe mounting bolts and nuts		
· Hydraulic pump mounting bolts		
Attachment pin and bushing	Lubricate	6-44
· Boom cylinder tube end		
· Boom foot		
· Boom cylinder rod end		
· Arm cylinder tube end		
· Arm cylinder rod end		
· Boom + Arm connecting		
· Bucket cylinder tube end		

7) INITIAL 500 HOURS SERVICE

Check items	Service	Page
Aircon & heater filter (inner)	Replace	6-48

^{*} Service the above items only for the new machine, and thereafter keep the normal service interval.

8) EVERY 500 HOURS SERVICE

Check items	Service	Page
★Engine oil	Change	6-18, 19
★Engine oil filter	Replace	6-18, 19
Corrosion resister	Replace	6-20
Coolant test (DCA4 concentration)	Test, Add	6-21-1, 2
Radiator, cooler fin and charge air cooler	Check, Clean	6-25
Prefilter	Change	6-29
Fuel filter element	Replace	6-30

[★] If you use high sulfur containing fuel above than 0.5% or use low grade of engine oil reduce change interval.

9) EVERY 1000 HOURS SERVICE

Check items	Service	Page
Travel motor reduction gear oil	Change	6-39
Swing reduction gear oil	Change	6-38
Grease in swing gear and pinion	Change	6-39
Hydraulic oil return filter	Replace	6-37
Drain filter cartridge	Replace	6-37
Pilot line filter	Replace	6-38
Air breather element	Replace	6-37
Air cleaner element (primary)*1	Check, Clean	6-28

^{*1} When working in dusty environments, more frequent cleaning is highly recommended.

10) EVERY 2000 HOURS SERVICE

Check items	Service	Page
Coolant	Change	6-21, 22, 23, 24
Hydraulic oil*2	Change	6-36
HBHO*3	Change	6-36
Hydraulic tank suction strainer	Check, Clean	6-36
Crankcase breather filter	Replace	6-31
RCV lever	Check, Lubricate	6-40
Hoses, fittings, clamps (fuel, coolant, hydraulic)	Check, Retighten, Replace	-

^{*2} Conventional hydraulic oil

11) EVERY 4000 HOURS SERVICE

Check items	Service	Page
Air cleaner element (primary, safety)*4	Replace	6-28
DEF/AdBlue® Tank filter	Replace	6-33-1

^{*4}When working in dusty environments, more frequent replacing is highly recommended.

12) EVERY 4500 HOURS SERVICE

Check items	Service	Page
DEF/AdBlue® supply module filter	Replace	6-34

13) EVERY 5000 HOURS SERVICE

Check items	Service	Page
Hydraulic oil*5	Change	6-36

^{*5} HD Hyundai Construction Equipment genuine long life

^{*3} If do not want to change HBHO (HD Hyundai Construction Equipment Bio Hydraulic Oil, ISO VG 46) every 2000 hours, contact HD Hyundai Construction Equipment dealer and ask about SAMPLING.

^{*}Change oil every 600 hours of continuous hydraulic breaker operation.


^{*}Change oil every 1000 hours of continuous hydraulic breaker operation.


14) WHEN REQUIRED

Whenever you have trouble in the machine, you must perform the service of related items, system by system.

Check items	Service	Page
Fuel system		
· Fuel tank	Drain or Clean	6-29
· Prefilter	Clean or Replace	6-29
· Fuel filter element	Replace	6-30
Engine lubrication system		
· Engine oil	Change	6-18, 19
· Engine oil filter	Replace	6-18, 19
Engine cooling system		
· Coolant	Add or Change	6-21, 22, 23, 24
· Radiator	Clean or Flush	6-21, 22, 23, 24
· Charge air cooler	Check	6-24
Engine air system		
· Air cleaner element (primary)	Clean or Replace	6-28
· Air cleaner element (safety)	Replace	6-28
Hydraulic system		
· Hydraulic oil	Add or Change	6-35
· Return filter	Replace	6-37
· Drain line filter	Replace	6-37
· Pilot line filter	Replace	6-38
· Element of breather	Replace	6-37
· Suction strainer	Clean	6-36
· RCV lever	Lubricate	6-40
Undercarriage		
· Track tension	Check, Adjust	6-40
Bucket		
· Bucket assy	Replace	6-41
· Tooth	Replace	6-42
· Side cutter	Replace	6-42
· Linkage	Adjust	6-43
Air conditioner and heater		
· Fresh air filter	Clean, Replace	6-48
· Recirculation filter	Clean	6-48
Other		
· DEF/AdBlue® tank	Check, Add	6-33
· DEF/AdBlue® supply module filter	Replace	6-34

5. MAINTENANCE CHART





330F6MA08

Caution

- 1. Service intervals are based on the hour meter reading.
- 2. The number of each item shows the lubrication point on the machine.
- 3. Stop engine while filling oil, and use no open flames.

Service interval	No.	Description	Service action	Oil symbol	Capacity ℓ (U.S.gal)	Service points No.
	1 Hydraulic oil level		Check, Add	НО	210 (55.5)	1
	2	Engine oil level	Check, Add	EO	30 (7.9)	1
40.11	4	Radiator coolant	Check, Add	С	55 (14.5)	1
i organy ——— `	Prefilter (water, element)	Check, Clean	-	-	1	
	Fan belt tension and damage	Check, Adjust	-	-	1	
	9 Fuel tank		Check, Refill	DF	550 (145.3)	1
	28	DEF/AdBlue® tank	Check, Add	DEF	42.5 (11.2)	1
	8 Bucket linkage pins		Check, Add	PGL	-	6
50 Hours 9		Fuel tank (water, sediment)	Check, Clean	-	-	1
or weekly	11	Swing reduction gear oil	Check, Add	GO	11.0 (2.91)	1
	13	Track tension	Check, Adjust	PGL	-	2

Service interval	No.	Description	Service action	Oil symbol	Capacity ℓ (U.S.gal)	Service points No.
	7	Attachment pins & bushing	Check, Add	PGL	-	11
250	10	Swing bearing grease	Check, Add	PGL	-	2
Hours	14	Battery (voltage)	Check	-	-	1
20		Aircon and heater fresh air filter	Check, Clean	-	-	1
	2	Engine oil	Change	EO	30 (7.9)	1
	3	Engine oil filter	Replace	-	-	1
	5	Prefilter	Replace	-	-	1
Initial 250	11	Swing reduction gear oil	Change	GO	11.0 (2.91)	1
	15	Hydraulic oil return filter	Replace	-	-	2
Hours	16	Drain filter cartridge	Replace	-	-	1
	19	Pilot line filter element	Replace	-	-	1
	22	Fuel filter element	Replace	-	-	1
	24	Travel reduction gear case	Change	GO	7.8 (2.06)	2
	2	Engine oil	Change	EO	30 (7.9)	1
	3	Engine oil filter	Replace	-	-	1
500	5	Prefilter	Replace	-	-	1
500 Hours	22	Fuel filter element	Replace	-	-	1
riodio	23	Radiator, oil cooler, charge air cooler	Check, Clean	-	-	3
	25	Corrosion resister	Replace	-	-	1
	25	Coolant test (DCA4 concentration)	Test, Add	DCA4	-	1
Initial 500 Hours	20	Aircon & heater recirculation filter	Replace	-	-	1
	11	Swing reduction gear oil	Change	GO	11.0 (2.91)	1
	12	Swing gear and pinion grease	Change	PGL	11.4 kg (25.1 lb)	1
	15	Hydraulic oil return filter	Replace	-	-	2
1000	16	Drain filter cartridge	Replace	-	-	1
Hours	17	Air breather element	Replace	-	-	1
	19	Pilot line filter element	Replace	-	-	1
	21	Air cleaner element (primary)	Check, Clean	-	-	1
24 Travel reduction gear case		Travel reduction gear case	Change	GO	7.8 (2.06)	2
	1 Hydraulic oil*1		Change	НО	210 (55.5)	1
	1	Hydraulic oil (HBHO*2)	Change	-	210 (55.5)	1
	4	Radiator coolant	Change	С	55 (14.5)	1
2000	18	Hydraulic oil suction strainer	Check, Clean	-	-	1
Hours	26	Crankcase breather filter	Replace	-	-	1
	29	RCV lever	Check, Lubricate	PGL	-	2
	-	Hoses, fittings, clamps (fuel, coolant, hydraulic)	Check, Retighten, Replace	-	-	-
4000 Hours	22	Air cleaner element (primary, safety)	Replace	-	-	2
4000 110015	28	DEF/AdBlue® tank filter	Replace	-	-	1
4500 Hours	27	DEF/AdBlue® supply module filter	Replace	-	-	1
5000 Hours	1	Hydraulic oil*3	Change	НО	210 (55.5)	1
	20	Aircon & heater fresh filter	Replace	-	-	1
٨٥	20	Aircon & heater recirculation filter	Clean, Replace	-	-	1
As required	21	Air cleaner element (primary)	Replace	-	-	1
4	21	Air cleaner element (safety)	Replace	-	-	1
	28	DEF/AdBlue® tank	Check, Add	DEF	42.5 (11.2)	1

^{*1} Conventional hydraulic oil

※ Oil symbol

Please refer to the recommended lubricants for specification.

DF: Diesel fuel GO: Gear oil HO: Hydraulic oil DEF: DEF/AdBlue®

C : Coolant PGL : Grease EO : Engine oil

^{*2} HD Hyundai Construction Equipment Bio Hydraulic Oil


^{*3} HD Hyundai Construction Equipment genuine long life

6. SERVICE INSTRUCTION

1) CHECK ENGINE OIL LEVEL


Check the oil level with the machine on a flat ground before starting engine.


- (1) Pull out the dipstick and wipe with a clean cloth.
- (2) Check the oil level by inserting the dipstick completely into the hole and pulling out again.
- (3) If oil level is LOW, add oil and then check again.
- If the oil is contaminated or diluted, change the oil regardless of the regular change interval.
- Check oil level after engine has been stopped for 15 minutes.
- ♠ Do not operate unless the oil level is in the normal range.




2) REPLACEMENT OF ENGINE OIL AND OIL FILTER

- (1) Operate the engine until the coolant temperature reaches 60°C (140°F). Shut off the engine.
- (2) Remove the oil drain plug. Drain the oil immediately to be sure all the oil and suspended contaminants are removed from the engine.
- A drain pan with a capacity of 35 liters (9.2 U.S. gallons) will be adequate.
- (3) Clean the area around the lubricating oil filter head.
- (4) Use oil filter wrench to remove the oil filter.
- (5) Clean the gasket surface of oil filter head.
- * The O-ring can stick on the filter head. Be sure it is removed before installing the new filter.







- (6) Apply a light film of lubricating oil to the gasket sealing surface before installing the filters.
- * Fill the filters with clean lubricating oil.




- (7) Install the filter to the filter head.
 - Tighten the filter until the gasket contacts the filter head surface.
 - Tighten 3/4 to 1 turn after the gasket makes contact with the filter head.
- Mechanical over-tightening may distort the threads or damage the filter element seal.



- (8) Clean and check the lubricating oil drain plug threads and sealing surface. Install the lubricating oil pan drain plug.
- (9) Fill the engine with clean oil to the proper level.
 - Quantity: 30 l (7.9 U.S.gallons)




(10) Operate the engine at low idle and inspect for leaks at the filters and the drain plug. Shut the engine off and check the oil level with the dipstick. Allow 15 minutes for oil to drain down before checking.




3) CORROSION RESISTOR (COOLANT FILTER)

- ▲ Do not remove the rad radiator cap from a hot engine. Wait until the coolant temperature is below 50°C (120°C) before removing the radiator cap. Heated coolant spray or steam can cause personal injury
- (1) Remove the radiator cap.



- (2) Turn the valve to the OFF position.
- (3) Remove and discard the filter.


 Clean the coolant filter head gasket's surface.
- A small amount of coolant can leak when servicing the filter with the shutoff valve in the OFF position. To avoid personal injury, avoid contact with hot coolant.




- (4) Apply a thin film of clean engine oil to the gasket sealing surface before installing the new filter.
- If the filter canister is damaged in any way, do not use it. Dents or scrapes can lead to a rupture or premature failure of the filter.



- (5) Install a new filter on the filter head. Tighten the filter until the gasket contacts the filter head surface.
- (6) Tighten the filter an additional 1/2 to 3/4 of a turn.
- Mechanical over tightening can distort the filter threads or damage the filter head.





- (7) Turn the valve to the ON position, and install the radiator cap.
- (8) Operate the engine and check for leaks.
- * The valve must be in the ON position to prevent engine damage.



4) CHECK COOLANT

- (1) Check if the level of coolant in reservoir tank is between FULL and LOW.
- (2) Add the mixture of antifreeze and water after removing the cap of the reservoir tank if coolant is not sufficient.
- (3) Be sure to use the reservoir empty, add the coolant by opening the cap of surge tank.
- (4) Replace gasket of radiator cap when it is damaged.
- A Hot coolant can spray out if surge tank cap is removed while engine is hot. Remove the cap after the engine has cooled down.





4-1) COOLANT TEST STRIPS INSTRUCTIONS

(1) Pre-test instruction

Recommended testing frequency - at every coolant filter change interval.

- ① Collect coolant sample from the radiator drain valve.
 - Do not collect from the coolant recovery or overflow system

 - Room temperature is best.
- ② For accurate results, test must be completed within 75 seconds.
 - Follow recommended test times. Use a stopwatch.
- 3 Record and track results.



380L6CT01

(2) Test instruction

- ① Remove one strip from bottle and replace cap immediately.
 - Do not touch the pads on the end of the strip. Discard kit if nitrite test pads of unused strips have turned brown.
- ② Dip strip for 1 second in coolant sample, remove, and shake strip briskly to remove excess liquid.
- End pad A

 Middle pad B


 Top pad C

 Test strip, prior to testing

3 45 seconds after dipping strip, compare results to color chart and record in the following order:



- 4 All three readings must be completed no later than 75 seconds after dipping strip.
- (5) If uncertain about the color match, pick the low numbered block.
 - ex.) If nitrite color is not F, use column E.
- ⑥ Determine where the molybdate level intersect the nitrite level on the chart. The amount of SCA units per gallon in the cooling system is given where the molybdate row intersect the nitrite column.



380L6CT03

(3) Maintenance actions based on results

① Above normal

- ABOVE NORMAL Do not replace the coolant filter or add DCA4 liquid until additive concentration falls below 3 units per gallon.
 - Test at every subsequent coolant filter change interval.

2 Normal

NORMAL

- Continue to replace the coolant filter at your normal interval.

3 Below normal

- Replace the coolant filter and add 1 pint of additive per each 4 gallons of coolant.
 - Replace the coolant filter and add 40 cc of additive per each 1 liter of coolant.
- * If you need part number of Test kit or DCA4, please see Parts Manual.

0.0	1.7	2.8	3.1			4 9 ORM/	
0.0	1.7	2.3	2.7				
0.0	1.4	10	ORM.	<u>о</u> л	2.8	3.6	4.4
0.0	1.2	1.5	1.7	2.1	2.5	3.3	4.1
0.0	1.0	1.2	1.4	1.8	2.2	3.0	3.8
150 PRO 151 E	O &	NORN		1.5	1.9	2.7	3.5
20.0 0.0				1.2	1.6	2.4	3.2

380L6CT04

5) FLUSHING AND REFILLING OF RADIATOR

(1) Change coolant

A void prolonged and repeated skin contact with used antifreeze. Such prolonged repeated contact can cause skin disorders or other bodily injury.

Avoid excessive contact-wash thoroughly after contact.

Keep out of reach of children.

Protect the environment : Handling and disposal of used antifreeze can be subject to federal, state, and local law regulation.

Use authorized waste disposal facilities, including civic amenity sites and garages providing authorized facilities for the receipt of used antifreeze.

If in doubt, contact your local authorities for guidance as to proper handling of used antifreeze.

▲ Wait until the temperature is below 50 °C (122 °F) before removing the coolant system pressure cap.


Failure to do so can cause personal injury from heated coolant spray.


Drain the cooling system by opening the drain valve on the radiator and opening the drain valve on the bottom of the engine oil cooler housing.


A drain pan with a capacity of 70 liters (18.5 U.S. gallons) will be adequate.

(2) Flushing of cooling system

- ① Fill the system with a mixture of sodium carbonate and water (or a commercially available equivalent).
- W Use 0.5kg (1.0 pound) of sodium carbonate for every 23 liters (6.0 U.S. gallons) of water.
- Do not install the surge tank cap. The engine is to be operated without the cap for this process.









During filling, air must be vented from the engine coolant passages.


The system must be filled slowly to prevent air locks or serious engine damage can result. Wait 2 to 3 minutes to allow air to be vented, then add mixture to bring the level to the top.




② Operate the engine for 5 minutes with the coolant temperature above 80°C (176°F).
Shut the engine off, and drain the cooling system.



- ③ Fill the cooling system with clean water.
- Be sure to vent the engine and aftercooler for complete filling.
- Do not install the surge tank cap or the new coolant filter.




- ④ Operate the engine for 5 minutes with the coolant temperature above 80°C (176°F).
 Shut the engine off, and drain the cooling system.
- If the water being drained is still dirty, the system must be flushed again until the water is clean.




(3) Cooling system filling

- ① Use a mixture of 50 percent soft water and 50 percent ethylene glycol antifreeze to fill the cooling system. Refer to the page 6-10.
- Do not use hard water such as river water or well water.




- ② The system has a maximum fill rate of 19 liters (5.0 U.S. gallons) per minute.
 Do not exceed this fill rate.
- * The system must be filled slowly to prevent air locks.
 - During filling, air must be vented from the engine coolant passage.



③ Install the pressure cap. Operate the engine until it reaches a temperature 80°C (176°F), and check for coolant leaks.
Check the coolant level again to make sure the

Check the coolant level again to make sure the system is full of coolant.




6) CLEAN RADIATOR AND OIL COOLER


Check, and if necessary, clean and dry outside of radiator and oil cooler. After working in a dusty place, clean radiator more frequently.

- (1) Visually inspect the radiator for clogged radiator fins.
- (2) Use 550 kPa (80 psi) air pressure to blow the dirt and debris from the fins.
- (3) Visually inspect the radiator for bent or broken fins.

If the radiator must be replaced due to bent or broken fins which can cause the engine to overheat, refer to the manufacturer's replacement procedures.


(4) Visually inspect the radiator for core leaks.






7) CHECK CHARGE AIR COOLER

Inspect the charge air cooler for dirt and debris blocking the fins. Check for cracks, holes, or other damage. If damage is found, please contact HD Hyundai Construction Equipment distributor.




8) FAN BELT


(1) An deflection method can be used to check belt tension by applying 11.3 kgf (25 lbf) force between the pulleys on V-belts. If the deflection is more than one belt thickness per foot of pulley center distance, the belt tension must be adjusted.



- (2) Inspect the fan belt for damage.
- ① Transverse (across the belt) cracks are acceptable.
- ② Longitudinal (direction of belt ribs) cracks that intersect with transverse cracks are not acceptable.



- ③ Inspect the belt
 - Embedded debris
 - Uneven/excessive rib wear
 - Exposed belt cords
 - Glazing (high heat)
- If any of the above conditions are present, the belt is unacceptable for reuse and must be replaced.




9) INSPECTION OF COOLING FAN

- A Personal injury can result from a fan blade failure. Never pull or pry on the fan. This can damage the fan blade and cause fan failure.
- * Rotate the crankshaft by using the engine bearing gear.
- A visual inspection of the cooling fan is required daily.


Check for cracks, loose rivets, and bent or loose blades.

Check the fan to make sure it is securely mounted. Tighten the capscrews if necessary. Replace any fan that is damaged.




10) FAN BELT TENSIONER

(1) With the engine stopped, check the tensioner arm, pulley, and stops for cracks. If any cracks are found, the tensioner must be replaced.




(2) With the belt installed, verify that neither tensioner arm stop is in contact with the spring case stop.


After replacing the belt, if the tensioner arm stops are still in contact with the spring case stop, replace the tensioner.



- (3) With the belt removed, verify that the tensioner arm stop is in contact with the spring case stop. If these two are not touching, the tensioner must be replaced.
- After replacing the belt, if the tensioner arm stop is still in contact with the spring case stop, the tensioner must be replace.



(4) Check the location of the drive belt on the belt tensioner pulley. The belt should be centered on, or close to the middle of, the pulley. Misaligned belts, either too far forward or backward, can cause belt wear, belt roll-offs, or increase uneven tensioner bushing wear.



11) CLEANING OF AIR CLEANER


(1) Primary element

- ① Open the cover and remove the element.
- Wipe all contaminant and debris from inside the housing body.
- ③ Do not clean the filter element by striking or hitting the filter against any object to shake the debris from the filter element.
- ④ Clean the filter element with compressed air.
 - Remove dust from filter element by directing the compressed air into the opening of the air filter element.
 - b. Use 3 kgf/cm² (40 psi) maximum air pressure and hold the compressed air nozzle at least 2.5 cm (1") away from the pleats while cleaning. Make sure to keep the clean side of air filter free of debris.
- ⑤ Visually inspect for damage to the filter elements and components. Use a light source to help identify any defects in the media. If any defects are observed discard the filter element and replace with a new primary filter element.
 - a. Before any type of cleaning, a visual inspection of the filter is needed. If there is any damage to the filter body, gaskets or endplates, do not clean or reuse; the filter should be discarded. Always clean filters in a clean environment, observe strict inspection procedures and repackage filters immediately after the cleaning process with appropriate materials.
 - Use observe proper safety precautions and dispose of waste materials in an environmentally compliant manner.
- 6 Re-install filter element into the air housing.
- Replace the primary element at the fourth cleaning.

(2) Safety element


The safety filter element should never be cleaned since the safety filter is the last barrier to contaminant before it reaches engine.

The useful life of the safety filter is equivalent to that of the primary air filter only if the primary filter element is being regularly cleaned. If the primary filter element is not cleaned, the safety filter should be changed at every third primary air filter change or after one year of continuous service, whichever occurs first.



12) FUEL TANK

- (1) Fill fuel fully when system the operation to minimize water condensation, and check it with fuel gauge before starting the machine.
- (2) Drain the water and sediment in the fuel tank by opening the drain cock.
- * Be sure to LOCK the cap of fuel tank.
- Remove the strainer of the fuel tank and clean it if contaminated.
- ▲ Stop the engine when refueling.
 All lights and flames shall be kept at a safe distance while refueling.



13) PREFILTER


Inspect or drain the collection bowl of water daily and replace the element every 500hours.

(1) Drain water

- ① Open bowl drain valve to evacuate water.
- 2 Close drain valve.
- » Don't tighten up a drain valve so strong.
- Please inspect and drain water frequently for remain water volume to be less than 1/3 volume of a collection bowl.

(2) Replace element

- ① Loosen the air vent plug and drain the unit of fuel. Follow "Drain water" instructions above.
- ② Remove element and bowl from filter head.
- * The bowl is reusable, do not damage or discard.
- ③ Separate element from bowl. Clean bowl and seal gland.




Element

-Bowl Open


330F6MA29

Bowl

- 4 Lubricate new bowl seal with clean fuel or motor oil and place in bowl gland.
- (5) Attach bowl to new element firmly by hand.
- ⑥ Lubricate new element seal and place in element top gland.
- (7) Attach the element and bowl to the head.




- ® Do hand-priming the lift pump repeatedly until air bubbles comes out from air vent hole completely.
- 9 Tighten the air vent plug to its origin position.
- ⚠ The fuel pump, high-pressure fuel lines, and fuel rail contain very high-pressure fuel. Do not loosen any fittings while the engine is running. Personal injury and property damage can result. Wait at least 10 minutes after shutting down the engine before loosening any fittings in the high-pressure fuel system to allow pressure to do decrease to a lower level.




14) REPLACEMENT OF FUEL FILTER

- (1) Use 1" wrench, loosen and remove the filter and clean the gasket surface.
- Make sure O-ring does not stick to filter head.
 Remove O-ring with screwdriver if necessary.
- (2) Lubricate the fuel filter O-ring with clean lubricating oil.
- (3) Install the filter on the filter head. Tighten the filter until the gasket contacts the filter head surface. Tighten the fuel filter an additional 3/4 turn after contact.
- Mechanical overtightening can distort the threads or damage the filter element seal.
- (4) Relieve the air after mounting.
- Do not pre-fill an on-engine fuel filter with fuel. The system must be primed after the fuel filter is installed. Pre filling the fuel filter can result in debris entering the fuel system and damaging fuel system components.
- ** Check for fuel leakage after the engine starts. If air is in the fuel system, the engine will not start. Start engine after bleeding the air according to the method of bleeding air.



15) CRANKCASE BREATHER FILTER


- Do not use pneumatic tools to remove the breather cover capscrews. Damage to the rocker cover can result.
- (1) Remove the oil fill cap.
- (2) Remove the crankcase breather filter cover capscrews.
- (3) Remove the filter cover.





- Do not disturb the crankcase breather filter gasket located on the rocker lever cover.
- Exposure to oil can cause the gasket to swell, which can make it difficult to install the gasket back into groove. If the gasket comes out of the groove, do not attemp to install the gasket. Replace it with a new gasket.
- (5) If the gasket is damaged, remove the gasket by grasping the tab on the gasket and pulling up.
- (6) Clean the crankcase breather filter mounting surface and O-ring sealing surfaces on the rocker lever cover.
- (7) Clean the crankcase breather filter cover with warm soapy water.

Inspect the cover for cracks.

Replace the cover if damage is found.









(8) If the gasket was removed, install the gasket into the rocker lever cover groove starting with the tab end first. Then install the corners opposite the gasket tab end. Finish by pushing in the sides (see illustration).

Gently push the gasket down into the groove. Do not used a finger to trace the gasket around into the groove during installation, as this will stretch the gasket, making it difficult to fully seat into the groove.

- Do not cut the gasket to make it fit into the groove, as this will result in an oil leak. The gasket must be fully seated around the entire perimeter of the rocker lever cover groove.
- (9) Apply clean engine oil to the O-rings on the crankcase breather filter.

Install the filter onto the rocker lever cover.






(10) Install the crankcase breather filter cover. Install the filter cover capscrews.


Tighten the capscrews, starting with the innermost capscrews and working outward in a circular manner.

 \cdot 0.71 kgf \cdot m (5.16 lbf \cdot ft) Install the oil fill cap.




16) LEAKAGE OF FUEL


▲ Be careful and clean the fuel hose, injection pump, fuel filter and other connections as the leakage from these part can cause fire.



17) DEF/AdBlue® TANK


- (1) The DEF/AdBlue® tank level must be checked daily with DEF/AdBlue® level gauge.
- (2) If the DEF/AdBlue® level is found to below, DEF/AdBlue® must be added.
- ⚠ It is unlawful to tamper with or remove any component of the aftertreatment system. It is also unlawful to use a catalyst solution that does not meet the specifications provided or the operate the machine with no catalytic solution.
- (3) DEF/AdBlue® fill up warning lamp turns on when tank is completely filled with DEF/ AdBlue®. After turning light on, do not pour DEF/AdBlue® any more.
- Fill the tank with DEF/AdBlue® after key on the start key.
- Be careful to entering dust, sand or other contamination substance when you refill the DEF/AdBlue® into the tank. Otherwise, fatal problem such as engine idle locking, derating or engine stopping can be happen.






17-1) DEF/AdBlue® TANK FILTER


- (1) Remove coolant, DEF/AdBlue® and air vent hoses.
- Move hoses back and forth 3~4 times to easily remove the hoses.




- (2) Plugging the coolant return line with the plug (P/no: HDB030-0002).
- When the coolant return line is removed, the coolant come out from the return line (TCO). Nearly comes out the coolant or DEF from other lines.




(3) Rotate the DEF/AdBlue® level sender counter-clockwise about 20 degree with the Jig (P/no: HDB030-0001).



(4) Remove the DEF/AdBlue® level sender without removal of the plunger ring.




- (5) Removed DEF/AdBlue® level sender.
- * Make sure O-ring is on the right position.
- (6) Replace the DEF/AdBlue® filter and fit with a new filter.
- * Replace the filter every 4000 hours.
- * Carry out installation in the reverse order to removal.



18) DEF/AdBlue® SUPPLY MODULE FILTER

- (1) Inspect the area around the seal and vent of DEF/AdBlue® supply module filter cap for signs of leakage.
- * Turn OFF the master switch mounted electric box.





- (2) Unscrew the DEF/AdBlue® supply module filter cap.
 - A 30 mm wrench can be used on the cap to aid in removal.
- (3) Remove the filter equalizing element.
- (4) Remove the old filter element.

A disposable service tool is included with the filter to aid in filter removal. Use the appropriate end of the tool, depending on the color of the plastic on the filter.


When inserting the tool a "click" sound can be heard which indicates proper engagement with the filter.

- If the filter element and equalizing element are removed from the aftertreatment DEF/ AdBlue® tank, they must be discarded and replaced; regardless of condition.
- (5) Clean and inspect the filter cap
- ① Clean the aftertreatment DEF/AdBlue® tank cap and threads on the DEF/AdBlue® tank with warm water and a clean cloth.
- ② Check the condition of the threads on the filter cap, if the threads are damaged, replace the filter cap.





- (6) Slide the filter equalizing element in to the new filter element.
- (7) Insert the assembly into the aftertreatment DEF/AdBlue® supply module.
- (8) Install and tighten the filter cap.
 - · Tightening torque : 2.0 kgf · m (14.5 lbf · ft)





19) HYDRAULIC OIL CHECK

- (1) Position the machine as shown in the illustration on the right. Then stop engine.
- (2) Check the oil level at the level gauge of hydraulic oil tank.
- (3) The oil level is normal if the oil is between the red lines. The oil level depends on the temperature of the hydraulic oil. Refer to the height (A) in the below table to check the level gauge.

Temperature		Height A		
$^{\circ}$ C	°F	mm	inch	
0	32	15	0.6	
10	50	25	1.0	
20	68	30	1.2	
30	86	35	1.4	
40	104	40	1.6	


- Refer to page 3-22 for checking the temperature of the hydraulic oil.
- * Add the hydraulic oil, if necessary.





20) FILLING HYDRAULIC OIL

- (1) Stop the engine to the position of level check.
- (2) Relieve the pressure in the tank by pushing the top of the air breather.
- (3) Remove the breather on the top of oil tank and fill the oil to the specified level.
- (4) Start engine after filling and operate the work equipment several times.
- (5) Check the oil level at the level check position after engine stops.




21) CHANGE HYDRAULIC OIL


- (1) Lower the bucket on the ground pulling the arm and bucket cylinder to the maximum.
- (2) Relieve the pressure in the tank by pushing the top of the air breather.
- (3) Remove the cover.
 - Tightening torque : 6.9 ± 1.4 kgf · m (50 ±10 lbf · ft)
- (4) Prepare a suitable container.
- (5) To drain the oil open the drain valve at the bottom of the oil tank.
- (6) Fill proper amount of recommended oil.
- (7) Put the breather in the right position.
- (8) Bleed air hydraulic pump loosen the air breather at top of hydraulic pump assembly.
- (9) Start engine and run continually. Release the air by full stroke of each control lever.
- Incase of injecting HBHO (HD Hyundai Construction Equipment Bio Hydraulic Oil) to machines that have formerly used different hydraulic oil, the proportion of residual oil must not exceed 2 %
- * Do not mix any other Bio oil, use only HBHO as bio oil. If changing to Bio oil, contact HD Hyundai Construction Equipment dealer.

22) CLEAN SUCTION STRAINER

Clean suction strainer as follows paying attention to the cause to be kept during oil filling.

- (1) Remove the cover.
 - . Tightening torque : 6.9 ± 1.4 kgf \cdot m (50 ±10 lbf \cdot ft)
- (2) Pull out the strainer in the tank.
- (3) Wash the foreign material on the suction strainer with gasoline or cleaning oil.
- (4) Replace the suction strainer if it is damaged.
- (5) Assemble with reverse order of disassembly. Be sure to install a new O-ring and reinsert in the oil tank.
- Loosen the bolt slowly at the cover can be spring out by the spring when removing it.






23) REPLACEMENT OF RETURN FILTER


Replace as follows paying attention to the cause to be kept during the replacement.

- (1) Remove the cover.
 - Tightening torque : $6.9\pm1.4 \text{ kgf} \cdot \text{m}$ (50 $\pm10 \text{ lbf} \cdot \text{ft}$)
- (2) Remove the spring, by-pass valve and return filter in the tank.
- (3) Replace the element with new one.



24) REPLACEMENT OF ELEMENT IN HYDRAULIC TANK BREATHER


- (1) Relieve the pressure in the tank by pushing the top of the air breather.
- (2) Loosen the bolt and remove the cover.
- (3) Pull out the filter element.
- (4) Replace the filter element new one.
- (5) Reassemble by reverse order of disassembly.
 - · Tightening torque : 0.8~1.0 kgf · m (5.9~7.4 lbf · ft)



25) REPLACE OF DRAIN FILTER CARTRIDGE


Clean the dust around filter and replace with new one after removing the cartridge.

- * Tighten about 2/3 turn more after the gasket of cartridge contacts seal side of filter body for mounting.
- * Change cartridge after initial 250 hours of operation. Thereafter, change cartridge every 1000 hours.




26) REPLACE OF PILOT LINE FILTER

- (1) Loosen the nut positioned on the filter body.
- (2) Pull out the filter element and clean filter housing.
- (3) Install the new element and tighten using specified torque.
- * Change cartridge after initial 250 hours of operation. Thereafter, change cartridge every 1000 hours.



27) CHECK THE SWING REDUCTION GEAR OIL

- (1) Pull out the dipstick and clean it.
- (2) Insert it again.
- (3) Pull out one more time to check the oil level and fill the oil if the level is not sufficient.




28) CHANGE SWING REDUCTION GEAR OIL

- (1) Raise the temperature of oil by swinging the machine before replace the oil and park the machine on the flat ground.
- (2) Prepare a proper container.
- (3) Open the cap and loosen the drain valve.
- (4) Clean around the valve and close the drain valve and cap.


Fill proper amount of recommended oil.

· Amount of oil : 11 / (2.91 U.S.gal)



29) LUBRICATE SWING BEARING


- (1) Grease at 2 fitting.
- * Lubricate every 250 hours.



30) SWING GEAR AND PINION


(1) Drain old grease

- ① Remove under cover of lower frame.
- 2 Remove drain cover of lower frame.
- 3 Remove filler cover of upper frame.
- ④ Operate full turn (360°) of swing several times.




(2) Refill new grease

- ① Install drain cover.
- ② Fill with new grease.
- ③ Install filler cover.
 - · Capacity: 11.4 kg (25.1 lb)




31) CHECK THE TRAVEL REDUCTION GEAR OIL

- Operate the machine to the position of drain plug down to the flat ground.
- (2) Loosen the level plug and check the oil level. If the level is at the hole of the plug, it is normal. Fill the oil if it is not sufficient.
 - Amount of oil : 7.8 \(\(\) (2.1 U.S.gal)




32) CHANGE OF THE TRAVEL REDUCTION GEAR OIL

- (1) Raise the temperature of the oil by traveling machine first.
- (2) Stop when the position of the drain plug is down.
- (3) Loosen the level plug and then the drain plug.
- (4) Drain the oil to adequate container.
- (5) Tighten the drain plug and fill specified amount of oil at filling port.
- (6) Tighten the level plug and travel slowly to check if there is any leakage of oil.



33) LUBRICATE RCV LEVER

Remove the bellows and with a grease gun grease the joint part (A) and sliding parts (B).




34) ADJUSTMENT OF TRACK TENSION

- It is important to adjust the tension of track properly to extend the lifetime of track and traveling device.
- The wear of pins and bushings on the undercarriage will vary with the working conditions and soil properties.
 - It is thus necessary to continually inspect the track tension so as to maintain the standard tension on it.
- (1) Raise the chassis with the boom and arm.
- (2) Measure the distance between bottom of track frame on track center and track of shoe.
- Remove mud with rotating the track before measuring.
- (3) If the tension is tight, drain the grease in the grease nipple and if the tension is loose, charge the grease.
- A Personal injury or death can result from grease under pressure.
- ▲ Unscrew the grease nipple after release the tension by pushing the poppet only when necessarily required.
 - Grease leaking hole is not existing. So, while unscrew the grease nipple, grease is not leaking until the grease nipple is completely coming out. If the tension is not released in advance, the grease nipple can be suddenly popped out by pressurized grease.
- When the grease is drained, move the track to the forward and backward slightly.
 If the track tension is loose even after the grease is charged to the maximum, change

the pins and bushings as there are worn seri-


ously.





Working condition	Length (L)		
General	360~390 mm	14.2~15.4"	
Swamp	390~430 mm	15.4~16.9"	
Sand, Mud, Pebbles	About 430 mm	About 16.9"	


35) REPLACEMENT OF BUCKET

- When the bucket is removed, place it in a stable condition.
- When performing joint work, make sure signals to each other and work carefully for safety's sake.
- (1) Lower the bucket on the ground as the picture shown in the right.
- (2) Lock the safety knob to the LOCK position and stop the engine.
- (3) Remove the stopper bolts(1) and nuts(2), then remove pins(3, 4) and remove the bucket.
- When removing the pins, place the bucket so that it is in light contact with the ground.
- If the bucket is lowered strongly to the ground, the resistance will be increased and it will be difficult to remove the pins.
- After remove the pins, make sure that they do not become contaminated with sand or mud and that the seals of bushing on both sides do not become damaged.
- (4) Align the arm with holes (A) and the link with holes (B), then coat with grease and install pins (3, 4)
- When installing the bucket, the O-rings are easily damaged, so fit the O-rings on the boss of the bucket as shown in the picture. After knocking the pin, move the O-ring down to the regular groove.
- (5) Install the stopper bolt (1) and nuts (2) for each pin, then grease the pin.










36) REPLACEMENT OF BUCKET TOOTH


(1) Timing of replacement

- ① Check wearing condition as shown in the illustration and replace tooth tip before adapter starts to wear.
- ② If excessive use, tooth adapter has worn out, replacement may become impossible.



(2) Instructions for replacement

- ① Pull out pin by striking pin with punch or hammer, avoiding damage to locking washer.
- ② Remove dust and mud from surface of tooth adapter by using knife.
- 3 Place locking washer in its proper place, and fit tooth tip to adapter.
- ④ Insert pin until locking washer is positioned at tooth pin groove.
- A Personal injury can result from bucket falling.
- A Block the bucket before changing tooth tips or side cutters.



37) ADJUSTMENT OF BUCKET CLEARANCE

- (1) Lower the bucket on the ground as the picture shown in the right.
- (2) Swing to the right and keep the arm boss to be contact to the bucket left.
- (3) Lock the safety knob to the LOCK position and stop the engine.
- (4) Measure the clearance (A) between bucket and arm boss. This is the total clearance.


(5) Adjusting

- ① Loosen bolt (2), and remove washer (3), plate (1) and shim (4).
- ② Remove the shim equivalent value with measuring value.
- 3 Assemble the parts in the reverse order of removal.

 \cdot Tightening torque : 29.6 \pm 3.2 kgf \cdot m (214.0 \pm 23.1 lbf \cdot ft)

· Normal clearance : $0.5 \sim 1.0 \text{ mm}$ ($0.02 \sim 0.04 \text{ in}$)

If the bucket is not adjusted correctly, noise and vibration created during operation, and damaged O-ring, pin and bushing quickly.




38) LUBRICATE PIN AND BUSHING


(1) Lubricate to each pin of working device

Lubricate the grease to the grease nipple according to the lubricating interval.


No.	Description	Qty
1	Lubrication manifold at boom	5
2	Boom cylinder pin	2
3	Lubricating manifold	3
4	Bucket cylinder pin (head, rod)	2
	Bucket link (control rod)	2
	Arm and bucket connection pin	1
	Arm and control rod connection pin	1
	Arm and control link connection pin	1
5	Boom rear bearing center	1

- Shorten lubricating interval when working in the water or dusty place.
- (2) Dust seals are mounted on the rotating part of working device to extend the lubricating interval.
- Mount the lip to be faced outside when replace the dust seal.






- If it is assembled in wrong direction, it will cause fast wear of pin and bushing, and create noise and vibration during operation.
- Assemble the seal same direction with picture and use with plastic hammer when replace.



7. ELECTRICAL SYSTEM

1) WIRING, GAUGES

Check regularly and repair loose or malfunctioning gauges when found.



2) BATTERY

(1) Clean

- Wash the terminal with hot water if it is contaminated, and apply grease to the terminals after washing.
- ▲ Battery gas can explode. Keep sparks and flames away from batteries.
- ▲ Always wear protective glasses when working with batteries.
- ♠ Do not stain clothes or skin with electrolyte as it is acid.

Be careful not to get the electrolyte in eyes. Wash with clean water and go to the doctor if it enters the eyes.



36070FW05

(2) Recycle


Never discard a battery.

Always return used batteries to one of the following locations.

- · A battery supplier
- · An authorized battery collection facility
- · Recycling facility

(3) Method of removing the battery cable

Remove the cable from the ground connection first (\ominus terminal side) and reconnect it last when reassembling.




3) STARTING THE ENGINE WITH A BOOSTER CABLE

Keep following order when you are going to start engine using booster cable.

(1) Connection of booster cable

W Use the same capacity of battery for starting.

- ① Make sure that the starting switches of the normal machine and trouble machine are both at the OFF position.
- ② Connect the red terminal of booster cable to the battery (+) terminal between exhausted and new battery.
- ③ Connect the black terminal of the booster cable between new battery (-) terminal and chassis of trouble machine.
- ※ Keep firmly all connection, the spark will be caused when connecting finally.





(2) Starting the engine

- ① Starting the engine of the normal machine and keep it to run at high idle.
- ② Start engine of the trouble machine with starting switch.
- ③ If you can not start it by one time, restart the engine after 2 minutes.

(3) Taking off the booster cable

- ① Take off the booster cable (black).
- ② Take off the booster cable (red) connected to the (+) terminal.
- ③ Run engine with high idle until charging the exhausted battery by alternator, fully.
- ♠ Explosive gas is generated while using the battery or charging it. Keep away flame and be careful not to cause the spark.
- Charge the battery in the well ventilated place.
- Place the machine on the earth or concrete. Avoid charging the machine on the steel plate.
- ** Do not connect (+) terminal and (-) terminal when connecting booster cable because it will be shorted.






(4) Welding repair

Before start to welding, follow the below procedure.

- ① Shut off the engine and remove the starting switch.
- ② Disconnect ground cable from battery by master switch.
- ③ Before carrying out any electric welding on the machine, the battery cables should be disconnected and the connectors pulled out of the electronic control units (MCU, ECM, cluster etc).
- ④ Connect the earth (ground) lead of the welding equipment as close to the welding point as possible.
- Do not weld or flame cut on pipes or tubes that contain flammable fluids. Clean them thoroughly with nonflammable solvent before welding or flame cutting on them.
- ♠ Do not attempt to welding work before carry out the above.


If not, it will caused serious damage at electric system.




8. AIR CONDITIONER AND HEATER

1) CLEAN AND REPLACE OF FRESH AIR FILTER

- * Always stop the engine before servicing.
- (1) Open the fresh air filter room.




- (2) Remove the fresh air filter.
- When installing a filter, be careful not to change the filter direction.
- (3) If filter is damaged or badly contaminated, use a new filter.




2) CLEAN AND REPLACE OF RECIRCULATION FILTER


- Always stop the engine before servicing.
- (1) Move seat and console box to arrow direction using the adjust knob.




(2) Remove recirculation filter.



- (3) Check the recirculation filter type.
- (4) Non-woven fabric type
 - If filter is damaged or badly contaminated, use a new filter.



- (5) Clean the recirculation filter using a pressurized air (below 2 kgf/cm², 28 psi) or washing with water.
- * Dry off after washing with water.
- (6) Inspect the filter after cleaning. If it is damaged or badly contaminated, use a new filter.



3) PRECAUTIONS FOR USING AIR CONDITIONER

- (1) When using the air conditioner for a long time, open the window once every one hour.
- (2) Be careful not to overcool the cab.
- (3) The cab is properly cooled if the operator feels cool when entering there from outside (about 5°C lower than the outside temperature).
- (4) When cooling, change air occasionally.

4) CHECK DURING SEASON

Ask the service center for replenishment of refrigerant or other maintenance service so that the cooling performance is not damaged.

5) CHECK DURING OFF-SEASON

Operate the air conditioner 2 or 3 times a month (each for a few minutes) to avoid loss of oil film in the compressor.

6) REFRIGERANT

(1) Equipment contains fluorinated greenhouse gas.

Model	Туре	Quantity	GWP
HX330 L	HFC-134a	0.75 kg (1.65 lb)	1073 CO ₂ eq.

% GWP

Global warming potential (GWP) is a measure of how much heat a gas traps in the atmosphere relative to that of carbon dioxide (CO2). GWP is calculated in terms of the 100-year warming potential of 1 kg of a greenhouse gas relative to 1 kg of CO2.

(2) Environmental precautions

The air conditioning system of the machine is filled with HFC-134a refrigerant at the factory. HFC-134a refrigerant is a flourinated greenhouse gas and contributes to global warming. Do not release refrigerant into the environment.

(3) Safety precautions

Work on the air conditioning system must only be performed by a qualified service technician. Do not attempt to preform work on the air conditioning system.

Wear safety goggles, chemical resistant gloves and appropriate personal protective equipment to protect bare skin when there is a risk of contact with refrigerant.

(4) Action in case of exposure

① Eye contact / Limited skin contact
Rinse with warm water and apply a light bandage. Seek medical attention immediately.

② Extensive skin contact
Rinse with warm water and carefully heat the area with warm water or warm clothing.
Seek medical attention immediately.

③ Inhalation

Leave the area and find fresh air. Seek medical attention immediately.

TROUBLESHOOTING GUIDE

1. ENGINE

* This guide is not intended to cover every conditions, however many of the more common possibilities are listed.

Trouble	Service	Remark
The engine oil pressure lamp lights ON when engine speed is raised after completion of warm up.	 Add the oil to the specified level. Replace the oil filter cartridge. Check oil leakage from the pipe or the joint. Replace the monitor. 	
Steam is emitted from the top part of the radiator (the pressure valve). Coolant level warning lamp lights ON.	 Supply the coolant and check leakage. Adjust fan belt tension. Wash out inside of cooling system. Clean or repair the radiator fin. Check the thermostat. Tighten the radiator cap firmly or replace the packing of it. Replace the monitor. 	
The engine does not start when the starting motor is turned over.	 Add fuel. Repair where air is leaking into fuel system. Check the injection pump or the nozzle. Check the valve clearance. Check engine compression pressure. In cold weather, check if fuel warmer system is working normal. 	Refer to the pages 3-35 and 4-4.
Exhaust gas is white or blue.	Adjust to specified oil quantity.Replace with specified fuel.	
Exhaust gas occasionally turns black.	 Clean or replace the air cleaner element. Check the nozzle. Check engine compression pressure. Clean or replace the turbocharger. 	
Combustion noise occasionally changes to breathing sound.	· Check the nozzle.	
Unusual combustion noise or mechanical noise.	 Check with specified fuel. Check over-heating Replace the muffler. Adjust valve clearance. 	

2. ELECTRICAL SYSTEM

Trouble	Service	Remark
Lamp does not glow brightly even when engine runs at high speed. Lamp flickers while engine runs.	Check for loose terminals and open-circuit wiring. Adjust belt tension.	
Battery charging lamp does not go out even when engine runs at high speed.	Check the alternator. Check and repair wiring.	
Unusual noise is emitted from the alternator.	· Check the alternator.	
Starting motor does not turn when starting switch is turned ON.	 Check and repair the wiring. Charge the battery. Check the starting motor. Check the safety relay. 	
The pinion of the starting motor keeps going in and out.	Charge the battery. Check the safety relay.	
Starting motor turns the engine sluggishly.	Charge the battery. Check the starting motor.	
The starting motor disengages before the engine starts up.	Check and repair the wiring. Charge the battery.	
The engine warming up lamp does not go ON.	Check and repair wiring. Check the monitor.	
The engine oil pressure lamp does not light up when engine is stationary (when the starting switch is in ON position.)	Check the monitor.Check the caution lamp switch.	
Battery charging lamp does not light up when the engine is stationary. (when the starting switch is in ON position.)	Check the monitor. Check and repair the wiring.	

3. OTHERS

Trouble	Service	Remark
Track slip out of place. Excessive wear of the sprocket.	Adjust tension of track.	
Bucket either rises slowly or not at all.	· Add oil to specified level.	
Slow speed of travel, swing, boom, arm and bucket.	Add oil to specified level.	
Unusual noise emitted from pump.	· Clean the hydraulic tank strainer.	
Excessive oil temperature rise of hydraulic oil.	Clean the oil cooler.Adjust fan belt tension.Add oil to specified level.	

HYDRAULIC BREAKER AND QUICK CLAMP

1. SELECTING HYDRAULIC BREAKER

- ** Read safety hints in this manual and breaker & quick coupler manuals in website (Dealer Portal) before using breaker and quick coupler.
- 1) Become familiar with the manual and select breakers suitable to machine specifications.
- Make careful selection in consideration of oil quantity, pressure and striking force, to enable satisfied performance.
- 3) When apply a breaker to the machine, consult your local dealer of HD Hyundai Construction Equipment for further explanation.

2. CIRCUIT CONFIGURATION

- As for breaker oil pressure line, use extra spool of main control valve.
- 2) Set proper breaker pressure on load relief valve.
- The initial setting pressure of load relief valve for breaker is 200 bar.
- The pressure of the HX330 system is 350 kgf/cm² (4980 psi).

4) Adjusting oil quantity

- Use the breaker mode from work tool of cluster.
 Use select switch to control the oil flow quantity.
 - · Setting oil quantity (220 lpm)

Flow set

- Max flow : Set the maximum flow for the attachment.
- (2) If the quantity of hydraulic oil is not controlled properly, it causes short lifecycle of the breaker and the machine by increased breaking force and count.

Oil quantity setting



290F3CD230A

- 5) The accumulator should be used to the breaker charging and return line.

 If the accumulator is not used, it will be damage as the input wave is delivered.
- * Keep the pressure pulsation of pump below 60 kgf/cm² (853 psi) by installing the accumulator.
- 6) Do not connect the breaker return line to the main control, but connect to the return line front of the cooler.
- 7) Do not connect the breaker return line to drain lines, such as of swing motor, travel motor or pump, otherwise they should be damaged.
- 8) One of spool of the main control valve should be connected to the tank.
- 9) Select the size of pipe laying considering the back pressure.
- 10) Shimless tube should be used for the piping. The hose and seal should be used HD Hyundai Construction Equipment genuine parts.
- 11) Weld the bracket for pipe clamp to prevent damage caused by vibration.

3. MAINTENANCE

1) MAINTENANCE OF HYDRAULIC OIL AND FILTER

- (1) As machine with an hydraulic breaker provides the hydraulic oil becomes severely contaminated.
- (2) So, unless frequently maintained, the machine may easily go out of order.
- (3) Inspect and maintain hydraulic oil and 3 kinds of filter elements in particular, in order to prolong machine life.

2) RELEASE THE PRESSURE IN BREAKER CIRCUIT

When breaker operating is finished, stop engine and push pedal or switch for breaker to release pressure in breaker circuit.

If pressure still remains, the lifetime of the diaphragm in the accumulator will be shortened.

- 3) Be careful to prevent contamination by dust, sand and etc.
 - If such pollution become mixed into the oil, the pump moving parts will wear abnormally, shorten lifetime and become damaged.
- 4) When operating breaker, bolts and nuts of main equipment may be loosened by vibration. So, it must be inspected periodically.

Service interval

			ariic i rioaro
Attachment	Operating rate	Hydraulic oil	Filter element
Breaker	er 100 %	600*1	200
Dieakei		1000*2	200

unit: hours

- *1: Conventional hydraulic oil
- *2: HD Hyundai Construction Equipment genuine long life hydraulic oil


• Replace following filter same time

· Hydraulic return filter : 1 EA

· Pilot line filter: 1 EA

· Drain filter cartridge: 1 EA

Hyd oil change guide for hydraulic breaker




- *1: Conventional hydraulic oil
- *2: HD Hyundai Construction Equipment genuine long life hydraulic oil

4. PRECAUTIONS WHILE OPERATING THE BREAKER

DO NOT BREAK ROCK WHILE LOWERING


As the breaker is heavy in comparison with bucket, it must be operated slowly.

If breaker is rapidly pushed down, working device may be damaged.



DIRECTION OF THRUST


Apply a thrust in a straight line with the tool. Place the tool on a rock with the hammering side as vertically as possible. If the hammering side is oblique, the tool may slip during hammering, causing the chisel and piston to break, or seized. When breaking, select the point of a rock on which hammering can perform stably and fully stabilize the chisel to the hammer.



PROPER THRUST


To break effectively, a proper thrust force must be applied to the breaker. If thrust is too low, impact energy of the piston may not be sufficient to break rocks.

Breaking force is transferred to the breaker body, arm and boom resulting in damage of those parts.




Move the impact point from the edge to the interior. Never try to break off a too large block, if the object has not broken within 30 seconds. The object should be broken up piece by piece in small blocks. Large distance steps will not improve working results.

Operating the breaker longer than 30 seconds may cause damage to the breaker.



BLANKS THRUST


Blank blows, which are impact on the chisel without contact with the object, are very harmful for the breaker. Always press the chisel down onto the material before starting the breaker. And stop operation immediately as soon as the object has been broken. If operation is continued, blank blows could result in excessive wear to major components.



DO NOT MOVE MACHINE OR BREAKER WHILE STRIKING


Do not move hammer while striking.

This will cause damage to the working device and the swing system.




OPERATE BREAKER WITH A GAP IN EXCESS OF 100 mm (4 inches) FROM THE END OF THE STROKE TIP

If breaker is operated with the end tip, the cylinder may be damaged.




STOP THE OPERATION IMMEDIATELY IF HOSES VIBRATE EXCESSIVELY

Violent pulsations of the high / low pressure breaker hoses could indicate an accumulator fault. Check for oil leaks at the hose fitting points retightening as necessary. Should symptoms persist, contact the service shop appointed by the Hyundal dealer in your territory for repair. An excessive gap between tool and workpiece between strikes may indicate seizure of the tool in the front head. Disassemble the front head, inspect the components and repair or replace defective parts.




DO NOT WORK WHILE IN A SWING STATE


Do not work while swinging the upper structure. It cause oil leakage of the bend in the track shoe and rollers.



Conversely, if thrust is excessive or breaking is performed with boom of the lower chassis raised as shown, the machine may suddenly tip toward the movement. The breaker body may strike the broken rocks violently resulting in damage.




Do not extend the bucket cylinder fully and thrusting to raise the machine off the ground.



Excessive force as above may also result in vibrations being transmitted to the tracks causing damage.

Care is required to ensure adequate but not excessive force is applied to the breaker in operation.




NEVER DRIVE THE CHISEL INTO THE GRO-UND

If the advance is too large and the chisel is not rocked to release the dust, the chisel will be driven into the material without breaking the material. This causes the chisel tip to glow red-hot and lose its hardness.

As a result, the chisel wears out more quickly. Operating in this way is not permitted.

Dust dampens impact power, when the chisel is inserted into the ground, and reduces the efficiency of the breaker. Tilt the breaker slightly backward and forward, not more than 5°, while operating so that the dust can escape.

Do not rock the breaker at angles greater than 5° or the chisel will be broken.



NEVER USE AS A LEVER


Do not use the chisel as a lever; e.g. crowbar, as this will cause the chisel to break.


Under any circumstances, operating in this way is not permitted.

Most of bending failure of the chisel may be caused by lever action in stone that is inside hard or frozen ground. Be careful and stop operating if you feel sudden resistance under the chisel.

TAKE CARE OF CHISEL AND BOOM INTERFA-CE

Be aware of clearance between breaker tip and the underside of boom as shown.






NEVER USE FOR LIFT OR TRANSPORT PUR-POSES


The hydraulic breaker is not designed to lift or transport loads. Never use the chisel as a lifting point.

This is dangerous and could damage the breaker or the chisel.




NEVER USE THE HYDRAULIC BREAKER UNDER WATER

The hydraulic breaker, as a standard assembly, never be used in or under water without prior conversion. If you use under water, water fills the impact chamber between the piston and the chisel, a strong hydraulic pressure wave is generated and will damage the seals in the breaker. And, in addition, corrosion, lack of lubrication or penetration of water could result in further damage to components of the breaker and the lower chassis. To operate the breaker under water, compressed air must be supplied into the breaker, into the impact chamber of the front-head, prior to use. Consult your HD Hyundai Construction Equipment dealer for the underwater kit.



DO NOT USE BREAKER TO CARRY BROKEN STONE OR ROCK BY SWING OPERATING

This may damage the operation device and swing system.




NEVER USE THE CHISEL OR HYDRAULIC BREAKER TO MOVE ROCKS OR OTHER OBJUCTS

The hydraulic breaker is not designed for this usage.

Do not use the breaker or chisel to roll, push the object or reposition the lower chassis.


This may cause damage to the breaker and the lower chassis.




5. QUICK CLAMP

1) FIXING BUCKET WITH QUICK CLAMP

- (1) Before fixing bucket, remove safety pin of the moving hook.
- (2) Pulling safety button, press the quick clamp switch to unlock position. Then, the moving hook is placed on release position.



(3) Aligning the arm and bucket, insert static hook of quick clamp to the bucket pin.




(4) Operate RCV lever to bucket-in position.


Then, the moving hook is coupled with the bucket link pin.

Make ourse that the moving hook is come.


Make sure that the moving hook is completely contacted with bucket link pin.



- (5) Push safety button to lock position.Operate RCV lever to bucket-in position.
- Be sure to check connection status between bucket pins and hooks of quick clamp.



(6) After checking the connection status between bucket pins and hooks of quick clamp, insert safety pin of moving hook to lock position.



2) REMOVE BUCKET FROM QUICK CLAMP

Removing procedure is reverse of fixing.


3) PRECAUTION OF USING QUICK CLAMP


♠ When operating the machine with quick clamp, confirm that the quick clamp switch is lock position and safety pin of moving hook is inserted.

Operating the machine with quick clamp switch unlocked and without safety pin of moving hook can cause the bucket to drop off and bring about the accident.

- ▲ Serious injury or death can result from this accident.
- ♠ Be careful to operate the machine equipped with quick clamp. The bucket may hit cab, boom and boom cylinders when it reaches vicinity of them.

HD Hyundai Construction Equipment will not be responsible for any injury or damage in case that safety pin is not installed properly.





INDEX

Α		Fuel filter ·····	6-30
AAVM	3-30	Fuel leakage ·····	6-33
After engine start ·····	4-5	Fuel system bleeding ·····	6-30
Air breather element ·····	6-37	Fuel tank ·····	6-29
Air cleaner filter ·····	6-28	Fuse & relay box	3-68
Air conditioner & heater ·····	3-31	G	
Air conditioner filter ·····	6-48	Gauge	3-3
Alternate exit	0-12	Gauge	ა-ა
Attachment lowering	4-23	Н	
В		Haptic controller ·····	3-57
	0.45	HEST	3-10
Battery		Hydraulic breaker ·····	8-1
Before starting engine		Hydraulic oil changing	6-36
		Hydraulic oil filling	6-35
Boom lowering		Hydraulic oil level ·····	6-35
Bucket clearance adjustment		L	
Bucket selection guide		LCD	3-2
Bucket tooth replacement		Levers & pedals ······	3-40
Bucket tootif replacement	0-42	Lifting capacities ······	2-9
C		Lubricant specification	2-23
Cab air filter	6-48	Lubricani specification	2-23
Cab device ·····	3-1	M	
Changing machine control pattern	4-26	Maintenance check list ·····	6-11
Cigar lighter	3-42	Major component ·····	2-1
Cluster	3-2	MCU (Machine Control Unit)	3-68
Coolant ·····	6-21	Mode selection system ·····	4-7
Cooling fan ·····	6-26	Monitor panel ·····	3-2
Crankcase breather filter	6-31	Mounting and dismounting	1-12
D		Multimodal dial ·····	3-58
DEF/AdBlue® supply module filter ·····	6-34	N	
DEF/AdBlue® tank ······		New machine operation ·····	4-1
Dimension and weight ·····			
Drain filter ·····		0	
_		Oil cooler ·····	6-25
E		Operating pattern	4-26
Emergency engine speed connector ······		P	
Engine oil filter		Pedals ·····	3-41
Engine oil level		Periodical replacement parts ······	6-5
Engine starting & stop		Pilot line filter	6-38
Engine starting by booster		Pin & bushing lubrication ······	6-44
Engine stop ·····	4-6	Prefilter	6-29
F		Pilot lamps ·····	3-12
Fan belt ·····	6-26		- ·-

Q		U	
Quick clamp ·····	8-6	Undercarriage ····································	2-17 3-58
R		·	
Radiator flushing	6-22	W	
Radio & USB player ·····	3-43	Warming up operation	4-5
RCV lever lubricate ·····	6-40	Warning lamps ······	3-6
Recommended oils 2-23	. 6-10	Weight ·····	2-7
Relieving pressure ·····	6-3	Welding repair ······	6-47
Return filter	6-37	Windshield	3-70
RCV lever operating pattern	4-26	Working device operation	4-12
		Working method	4-16
S		Working range ······	2-5
SCR system cleaning	4-28	3 3	
Safety hints ·····	1-1		
Safety labels	0-5		
Safety parts ·····	6-5		
Seat ·····	3-60		
Seat belt ·····	3-67		
Service meter ·····	3-69		
Service socket ·····	3-69		
Smart key tag ·····	3-35		
Specification for major component	2-19		
Specification	2-2		
Start switch ·····	3-35		
Storage ····	4-24		
Suction strainer	6-36		
Surge tank	6-21		
Swing bearing grease ·····	6-38		
Swing gear & pinion grease ·····	6-39		
Swing reduction gear oil ·····	6-38		
Switch panel	3-35		
Switches3-15	5, 3-35		
Т			
Torques-major component ·····	6-8		
Torques-fastener ·····	6-6		
Towing machine	4-15		
Track adjustment ·····	6-40		
Track shoe selection ·····	2-18		
Transportation	5-1		
Travel reduction gear oil ·····	6-39		
Traveling machine	4-13		
Troubleshooting guide	7-1		