

CONTENTS

Foreword	0-1
Emission-related components warranty (USA and CANADA only)	0-2
Before servicing this machine	0-3
EC regulation approved	0-4
EC Declaration of conformity	0-5
Table to enter S/No and distribution	0-6
Safety labels	0-7
Machine data plate	0-18
Guide (direction, S/No, symbol)	0-19

SAFETY HINTS

1. California proposition 65	1-1
2. Safety instructions	1-2

SPECIFICATIONS

1. Major components	2-1
2. Specifications	2-2
3. Working range	2-3
4. Weight	2-4
5. Lifting capacities	2-5
6. Bucket selection guide	2-9
7. Undercarriage	2-10
8. Specification for major components	2-11
9. Recommended oils	2-14

CONTROL DEVICES

1. Cab devices	3-1
2. Cluster	3-2
3. Switches	3-37
4. Levers and pedals	3-44
5. Full auto air conditioner and heater	3-47
6. Others	3-51

OPERATION

1. Suggestion for new machine	4-1
2. Check before starting the engine	4-2
3. Starting and stop the engine	4-3

4. Operation of the working device	4-7
5. Traveling of the machine	4-8
6. Efficient working method	4-11
7. Operation in the special work sites	4-15
8. Normal operation of excavator	4-17
9. Attachment lowering pattern	4-18
10. Storage	4-19
11. Handling the rubber tracks	4-21

TRANSPORTATION

1. Preparation for transportation	5-1
2. Dimension and weight	5-2
3. Loading the machine	5-4
4. Fixing the machine	5-6
5. Loading and unloading by crane	5-7

MAINTENANCE

1. Instruction	6-1
2. Tightening torque	6-6
3. Fuel, coolant and lubricants	6-9
4. Maintenance check list	6-11
5. Maintenance chart	6-16
6. Service instruction	6-18
7. Electrical system	6-36
8. Air conditioner and heater	6-39

TROUBLESHOOTING GUIDE

1. Engine	7-1
2. Electrical system	7-2
3. Others	7-3

HYDRAULIC BREAKER AND QUICK COUPLER

1. Selecting hydraulic breaker	8-1
2. Circuit configuration	8-2
3. Maintenance	8-3
4. Precaution while operating the breaker	8-4
5. Quick coupler	8-6

INDEX	9-1
-------------	-----