

A

After engine start	4-5
Air cleaner filter	6-23
Air conditioner & heater	3-13
Air conditioner filter	6-37
Attachment lowering	4-18

B

Battery	6-34
Before starting engine	4-2
Boom lowering	4-18
Bucket replacement	6-31
Bucket selection guide	2-7
Bucket tooth replacement	6-32

C

Cab device	3-1
Cassette & radio	3-17
Changing machine control pattern	4-21
Cigar lighter	3-15
Coolant	6-19
Cooling fan	6-23

D

Dozer control	4-7
---------------------	-----

E

Emergency exit	0-7
Engine oil filter	6-17
Engine oil level	6-17
Engine starting & stop	4-3
Engine starting by booster	6-35
Engine stop	4-6

F

Fan belt	6-22
Fuel filter	6-25
Fuel leakage	6-25
Fuel system bleeding	6-26
Fuel tank	6-24
Fuse box	3-17

H

Hydraulic breaker	8-1
Hydraulic oil changing	6-26
Hydraulic oil filling	6-26
Hydraulic oil level	6-26

L

Levers & pedals	3-10
Lifting capacities	2-5
Lubricant specification	2-12, 6-9

M

Maintenance check list	6-10
Major component	2-1
Monitor panel	3-3
Mounting and dismounting	1-12

N

New machine operation	4-1
-----------------------------	-----

O

Oil cooler	6-22
Operating pattern	4-21

P

Pedals	3-10
Periodical replacement parts	6-4
Pilot line filter	6-28

R

Radiator flushing	6-19
Radio	3-17
RCV lever lubricate	6-29
Recommended oils	2-12, 6-9
Relieving pressure	6-3
Return filter	6-27

S

Safety hints	1-1
Safety labels	0-5
Safety parts	6-4
Seat	3-16
Seat belt	3-16

Service meter	3-4
Specification for major component	2-9
Specification	2-2
Start switch	3-7
Storage	4-19
Suction strainer	6-27
Swing bearing grease	6-28
Switch panel	3-7
Switches	3-7

T

Torques-major component	6-7
Torques-fastener	6-5
Towing machine	4-10
Track adjustment	6-30
Track shoe	2-8
Transportation	5-1
Travel reduction gear oil	6-29
Travelling machine	4-8
Troubleshooting guide	7-1

U

Undercarriage	2-8
---------------------	-----

W

Warming up operation	4-5
Warning lamps	3-5
Water separator	6-24
Weight	2-4
Working device operation	4-7
Working method	4-11
Working range	2-3