


5. MAINTENANCE CHART



R35Z76MA30

Caution

1. Service intervals are based on the hour meter reading.
2. The number of each item shows the lubrication point on the machine.
3. Stop engine while filling oil, and use no open flames.
4. For other details, refer to the service manual.

Service interval	No.	Description	Service action	Oil symbol	Capacity l (U.S.gal)	Service points No.
10 Hours or daily	1	Hydraulic oil level	Check, Add	HO	37(9.8)	1
	2	Radiator coolant	Check, Add	C	5(1.3)	1
	3	Water separator	Check, Drain	-	-	1
	4	Fan belt tension and damage	Check, Adjust	-	-	1
	15	Engine oil level	Check, Add	EO	6.7(1.8)	1
50 Hours or weekly	5	Attachment pins	Check, Add	PGL	-	20
	6	Dozer blade	Check, Add	PGL	-	5
	7	Boom swing cylinder	Lubricate	PGL	-	1
	8	Swing bearing	Lubricate	PGL	-	1
	9	Swing gear and pinion	Check, Add	PGL	-	1
	10	Swing drive gear case(Grease)	Check, Add	PGL	-	1
	11	Track tension	Check, Adjust	PGL	-	2
	12	Fuel tank strainer and drain	Check, Clean	-	-	1
250 Hours	13	Heater filter	Clean	-	-	1
	14	Battery(Electrolyte)	Check, Add	-	-	1
500 Hours	15	Engine oil	Change	EO	6.7(1.8)	1
	16	Engine oil filter	Replace	-	-	1
	20	Fuel filter element	Replace	-	-	1
	21	Radiator and cooler fin	Check, Clean	-	-	2
	22	Air cleaner element(Outside)	Clean	-	-	1
1000 Hours	17	Line filter element	Change	-	-	1
	18	Hydraulic oil return filter	Change	-	-	1
	23	Travel reduction gear case	Change	GO	0.5(0.32)	2
2000 Hours	1	Hydraulic oil level	Change	HO	37(9.8)	1
	2	Radiator coolant	Change	C	5(1.3)	1
	24	Hydraulic oil suction strainer	Check, Clean	-	-	1
As required	13	Heater filter	Check, Clean	-	-	1
	22	Air cleaner element(Inside/Outside)	Check, Clean	-	-	2

※ **Oil symbol**

Please refer to the recommended lubricants for specification.

DF : Diesel fuel

GO : Gear oil

HO : Hydraulic oil

C : Coolant

PGL : Grease

EO : Engine oil