

A

Accel dial switch	3-26
After engine start	4-5
Air breather	6-28
Air cleaner filter	6-24
Air conditioner & heater	3-36
Air conditioner filter	6-43
Attachment lowering	4-22
Axle gear oil	6-34

B

Battery	6-40
Before starting engine	4-2
Boom lowering	4-22
Bucket clearance adjustment	6-37
Bucket replacement	6-37
Bucket selection guide	2-6
Bucket tooth replacement	6-38

C

Cab air filter	6-43
Cab device	3-1
Changing machine control pattern	4-25
Cigar lighter	3-40
Cluster	3-2
Coolant	6-20
Cooling fan	6-24

D

Drive shaft lubricate	6-31
Dozer control	4-7

E

Engine oil filter	6-18
Engine oil level	6-18
Engine starting & stop	4-3
Engine starting by booster	6-41
Engine stop	4-6

F

Fan belt	6-23
Fuel filter	6-26
Fuel leakage	6-27
Fuel tank	6-25
Fuse box	3-48

G

Gauge	3-3
Gear box oil	6-36

H

Handsfree	3-42
Hydraulic breaker	8-1
Hydraulic oil changing	6-28
Hydraulic oil filling	6-27
Hydraulic oil level	6-27

L

Levers & pedals	3-33
Lifting capacities	2-5
Lubricant specification	2-10, 6-10

M

Machine fault code	3-11
Maintenance check list	6-11
Major components	2-1
Monitor panel	3-2
Mounting and dismounting	1-12

N

New machine operation	4-1
-----------------------------	-----

O

Oil cooler	6-23
Operating pattern	4-25

P

Pedals	3-34
Periodical replacement parts	6-5
Pilot line filter	6-28
Pin & bushing lubrication	6-39
Prefilter	6-25

Q

Quick coupler	8-6
---------------------	-----

R

Radiator flushing	6-20
Radio and USB player	3-49
RCV lever lubricate	6-31
RCV operating pattern	4-25
Recommended oils	2-10, 6-10
Relieving pressure	6-3

Remote controller	3-45
Return filter	6-29
Road traveling	5-1

S

Safety hints	1-1
Safety labels	0-5
Safety parts	6-5
Seat	3-41
Service meter	6-1
Speciation for major component	2-7
Specifications	2-2
Start switch	3-25
Storage	4-23
Suction strainer	6-28
Swing bearing grease	6-31
Swing gear	6-30
Swing reduction gear oil	6-30
Switch panel	3-13
Switches	3-13

T

Tires air pressure	6-33
Torques-major component	6-8
Torques-fastener	6-6
Towing machine	4-11
Transportation	5-2
Travelling machine	4-8
Troubleshooting guide	7-1
Turning pilot lamp	3-31

W

Warming up operation	4-5
Warning lamps	3-5,6,7
Weight	2-4
Wind shield	3-48
Working device operation	4-7
Working method	4-14
Working range	2-3