

A

Accel dial switch	3-13
After engine start	4-4
Air breather element	6-28
Air cleaner filter	6-23
Air conditioner & heater	3-22
Air conditioner filter	6-41
Attachment lowering	4-22
Axle gear oil	6-33

B

Battery	6-38
Before starting engine	4-2
Boom lowering	4-22
Bucket clearance adjustment	6-35
Bucket replacement	6-35
Bucket selection guide	2-6
Bucket tooth replacement	6-36

C

Cab air filter	6-41
Cab device	3-1
Changing machine control pattern	4-28
Cigar lighter	3-26
Cluster	3-2
Coolant	6-19
Cooling fan	6-23

D

Drive shaft lubricate	6-30
Dozer control	4-7

E

Engine oil filter	6-18
Engine oil level	6-17
Engine starting & stop	4-3
Engine starting by booster	6-39
Engine stop	4-6

F

Fan belt	6-22
Fuel filter	6-25
Fuel leakage	6-25
Fuel tank	6-24
Fuse box	3-32

G

Gauge	3-3
Gear box oil	6-34

H

Handsfree	3-28
Hydraulic breaker	8-1
Hydraulic oil changing	6-26
Hydraulic oil filling	6-26
Hydraulic oil level	6-26

L

Levers & pedals	3-19
Lifting capacities	2-5
Lubricant specification	2-10, 6-10

M

Machine fault code	3-11
Maintenance check list	6-11
Major component	2-1
Monitor panel	3-2
Mounting and dismounting	1-12

N

New machine operation	4-1
-----------------------------	-----

O

Oil cooler	6-22
Operating pattern	4-25

P

Pedals	3-20
Periodical replacement parts	6-5
Pilot line filter	6-28
Pin & bushing lubrication	6-37
Prefilter	6-24

Q

Quick clamp	8-6
-------------------	-----

R

Radiator flushing	6-20
Radio and USB player	3-33
RCV lever lubricate	6-30
RCV lever operating pattern	4-25
Recommended oils	2-10, 6-10

Relieving pressure	6-3
Remote controller	3-30
Return filter	6-27
Road travelling	5-1

S

Safety hints	1-1
Safety labels	0-5
Safety parts	6-5
Seat	3-27
Service meter	3-3
Speciation for major component	2-7
Specification	2-2
Start switch	3-12
Storage	4-23
Suction strainer	6-27
Swing bearing grease	6-29
Swing gear	6-29
Swing reduction gear oil	6-28
Switch panel	3-12
Switches	3-12

T

Tires air pressure	6-31
Torques-major component	6-8
Torques-fastener	6-6
Towing machine	4-11
Transportation	5-2
Travelling machine	4-8
Troubleshooting guide	7-1
Turning pilot lamp	3-18

W

Warming up operation	4-5
Warning lamps	3-4,5,6
Weight	2-4
Wind shield	3-32
Working device operation	4-7
Working method	4-11
Working range	2-3