


SECTION 2 REMOVAL AND INSTALLATION OF UNIT

Group 1 Major components	2-1
Group 2 Removal and installation of unit	2-2

SECTION 2 REMOVAL & INSTALLATION OF UNIT

GROUP 1 MAJOR COMPONENTS



10BTR9RE01


- | | | | | | |
|---|----------------|----|--------------------|----|---------------------|
| 1 | Lift cylinder | 9 | Front axle | 17 | Counterweight |
| 2 | Mast | 10 | Drive motor | 18 | Traction controller |
| 3 | Steering unit | 11 | Pump motor | 19 | Pump controller |
| 4 | Backrest | 12 | Hydraulic pump | 20 | Seat |
| 5 | Tilt cylinder | 13 | Main control valve | 21 | Overhead guard |
| 6 | Priority valve | 14 | Battery | 22 | Steering wheel |
| 7 | Forks | 15 | Rear wheel | | |
| 8 | Front wheel | 16 | Drive unit | | |

GROUP 2 REMOVAL AND INSTALLATION OF UNIT

Remove and install following units as explained in the flow chart.


1. MAST

1) REMOVAL




(1) Forks

- ① Lower the fork carriage until the forks are approximately 25mm(1in) from the floor.
 - ② Turn knob up and slide one fork at a time toward the center of the carriage where a notch has been cut in the bottom plate for easy removal.
 - ③ Remove only one fork at a time.
- ※ On larger forks it may be necessary to use a block of wood.




(2) Backrest(If necessary)

- ① Remove bolts securing backrest to fork carriage. Disassemble the backrest from the carriage.




(3) Carriage


- ① With the mast vertical, raise the carriage high enough to place blocks under the load forks. This is done to create slack in the load chains when the carriage is lowered. Lower the carriage all the way down to the floor. Make sure the carriage is level, this will prevent any binding when the mast is raised.



- ② While supporting lift chains, remove the split pins and slide out chain anchor pins from the chain anchors of stationary upright.




- ③ Pull the chains out of the sheaves and drape them over the front of the carriage.



- ④ Slowly raise inner mast upright until mast clears top of fork carriage. Move carriage to work area and lower the mast.


▲ Make sure that carriage remains on floor and does not bind while mast is being raised.

- ⑤ Inspect all parts for wear or damage. Replace all worn or damaged parts.



(4) Piping

- ① Loosen the bolts (2EA) of the weld-connector (2) from low crossmember of the outer mast.
- ② Disconnect the connectors from the lift cylinders.
- ③ Disassemble the velocity fuse valve (1), hoses, and weld-connector (2).




(5) Lift cylinder

- ① Loosen hexagonal bolts and remove washers securing the lift cylinders to outer mast.
- ② Bind the lift cylinder with overhead hoist rope and pull up so that the rope has no slack or binding.

▲ Make sure that the lift cylinder be tightened firmly for safety.


- ③ Loosen and remove hexagon bolts and clamp securing the lift cylinder to outer mast.
- ④ Using an overhead hoist, slowly raise the inner mast high enough to clear lift cylinder.
- ⑤ Using an overhead hoist, draw out lift cylinder carefully and put down on the work floor.



(6) Inner mast


- ① Using an overhead hoist raise the inner mast straight and carefully draw out of outer mast section.

⚠ Be careful the mast not to swing or fall.



(7) Tilt cylinder pin

- ① Attach a crane to the stay at the top of the outer mast, and raise enough to sustain jacked up machine.
- ※ This operation is carried out from under the machine, so use a pit, or if there is no pit, jack up the machine and loosen with on impact wrench.
- ② Remove the hex bolts from the pins of the tilt cylinders and the hex bolts of the mast fixing caps to the front axles, and take out the pins, the mast fixing caps, and then slowly raise up the outer mast.



2) INSTALLATION

After assembling mast components totally without piping connections, install mast assembly to the equipment.

※ Installation procedure for each of mast component is the reverse of the removal procedure.

(1) Bronze bushings


- ① Check the inside of the bronze bushings for wear which are the contact area with the mast mounting pins.
- ② Jack up the machine so that the front is raised and then using an overhead hoist, assemble the outer mast to the front axles.

(2) Tilt cylinder pin

Hold the mast with a crane, operate the tilt control lever and align the holes, then knock the pin.


(3) Lift cylinder installation and adjustment

- ① Assemble the lift cylinder inside the outer mast, then tighten the stopper bolt. If the cylinder assembly has been replaced, adjust as follows so that the left and right cylinders are synchronized at the maximum lifting height.
 - ② Assemble the cylinder rod to the inner mast, and check the left-to-right play of the mast at the maximum lifting height.
- ※ If play is to LEFT, install adjustment shim to LEFT cylinder.
- ※ If play is to RIGHT, install adjustment shim to RIGHT cylinder.
- Shim thickness : 1.0mm(0.04in)



2. POWER TRAIN ASSEMBLY

1) REMOVAL




B153RE00

(1) Mast and counterweight


Refer to section on mast(Page 2-5)

- ※ After removing mast, remove the counterweight to prevent the truck from turning over.




(2) Brake piping

Disconnect the brake piping from the front axles.



(3) Parking brake cable


Disconnect parking brake cable from the front axle assys.




(4) Front axle assy

※ Drain the oil before disassembling the front axles.

- ① Unscrew five wheel nuts and remove the wheel.



- ② Loosen seven mounting bolts on the truck frame and carefully take out the front axles.




2) INSTALLATION

Installation is the reverse order of removal, but be careful of the following tightening torque.

• Tightening torque


Item	kgf · m	lbf · ft
Front axle (1)	12.5 ~ 15	90.4 ~ 109
Wheel nut (2)	12.5 ~ 15.5	90.4 ~ 112



3. ELECTRICAL COMPONENTS

Before removing each component, disconnect cables and earth lines attached to the component.

1) REMOVAL




B15T5RE001

(1) Battery


▲ Before pulling out the battery plug, tilt the mast forward a little, and lower the fork to the lowest position.

The batteries weigh from around 450kg to 690kg so the extreme care must be taken when handling them.

- ① Disconnect the battery connector.
Release the battery cover latch and open the battery cover.




- ② Using a battery hanger, carefully raise the battery assembly.
- ※ Be careful not to damage overhead guard or control system.




(2) Pump motor


- ① Lower the fork to floor.



- ② Remove floor mat and front floor plate.
Disconnect the wiring of pump motor.




- ③ Remove elbow and connector and then disconnect the hydraulic hose from the gear pump.
Remove the gear pump from pump motor.
Remove the tightening nuts of the motor mounting bracket.
Remove the pump motor from mounting bracket.



4. STEERING AXLE


1) 10/13/15BTR-9

(1) Removal



B15T5RE91

※ Before removing counterweight apply the parking brake.



10BTR9RE24

① Counterweight

Install a lifting tool in the counterweight, and raise with a crane.
Remove the mounting bolts, raise slightly and move to the rear.


· Weight of counterweight(standard)

10BTR-9	525kg (1160lb)
13BTR-9	590kg (1300lb)
15BTR-9	695kg (1530lb)

· Tightening torque : 184~214 kgf · m (1330~1550lb · ft)

② Battery connector


Disconnect the battery connector.




B15T5RE18

③ **Hose**


Disconnect the hoses from steering hydraulic motor.




④ Loosen socket bolts and remove steering hydraulic motor assy from drive unit assy.



⑤ Jacking up the chassis of truck.
Loosen the hub nut and take off the steering wheel tire assembly.



⑥ Remove the hub cap.
Pull out the bearings and washers.



- ⑦ Loosen bolts and remove drive unit assy from chassis.

