

SECTION 1 GENERAL

Group 1 Safety hints	1-1
Group 2 Specifications	1-5
Group 3 Operational checkout record sheet	1-13

SECTION 2 REMOVAL & INSTALLATION

Group 1 Structure	2-1
Group 2 Removal and installation of unit	2-2

SECTION 3 POWER TRAIN SYSTEM

Group 1 Structure and operation	3-1
Group 2 Operation and maintenance	3-46
Group 3 Disassembly and assembly	3-57
Group 4 Adjustment	3-185

SECTION 4 BRAKE SYSTEM

Group 1 Structure and function	4-1
Group 2 Operational checks and troubleshooting	4-32
Group 3 Tests and adjustments	4-40
Group 4 Disassembly and assembly	4-43

SECTION 5 STEERING SYSTEM

Group 1 Structure and function	5-1
Group 2 Operational checks and troubleshooting	5-9
Group 3 Tests and adjustments	5-17
Group 3 Disassembly and assembly	5-21

SECTION 6 HYDRAULIC SYSTEM

Group 1 Structure and function	6-1
Group 2 Operational checks and troubleshooting	6-29
Group 3 Disassembly and assembly	6-34

SECTION 7 ELECTRICAL SYSTEM

Group 1 Component location (-#0030)	7-1
Component location (#0031-)	7-1-1
Group 2 Electrical circuit (-#0030)	7-3
Electrical circuit (#0031-)	7-3-1

Group 3	Cluster (-#0030)	7-12
	Cluster (#0031-)	7-12-1
Group 4	Transmission message indication (-#0030)	7-21
	Transmission message indication (#0031-)	7-21-1
Group 5	Switches (-#0030)	7-25
	Switches (#0031-)	7-25-1
Group 6	Electrical component specification (-#0030)	7-31
	Electrical component specification (#0031-)	7-31-1
Group 7	Connectors (-#0030)	7-41
	Connectors (#0031-)	7-41-1
Group 8	Troubleshooting	7-59

SECTION 8 MAST

Group 1	Structure	8-1
Group 2	Operational checks and troubleshooting	8-4
Group 3	Adjustment	8-7
Group 4	Removal and Installation	8-9