

SECTION 6 HYDRAULIC SYSTEM


Group 1	Structure and function	6-1
Group 2	Operational checks and troubleshooting	6-18
Group 3	Disassembly and assembly	6-22

SECTION 6 HYDRAULIC SYSTEM

GROUP 1 STRUCTURE AND FUNCTION

1. HYDRAULIC CIRCUIT

· NON-BOOSTER TYPE BRAKE




22D9HS01

- | | | | |
|---|---------------------|----|------------------------------|
| 1 | Hydraulic gear pump | 9 | Down safety valve |
| 2 | Main control valve | 10 | Hydraulic tank |
| 3 | Steering unit | 11 | Priority valve |
| 4 | Steering cylinder | 13 | Side shift cylinder (option) |
| 5 | Lift cylinder | 14 | Free lift cylinder |
| 6 | Tilt cylinder | 15 | Load sensor |
| 7 | Suction strainer | 16 | Flow regulator |
| 8 | Return filter | | |

※ The circuit diagram may differ from the equipment, so please check before a repair.

• FINGER TIP TYPE (OPTION)




33HN-00110

- | | | | | | |
|---|---------------------|----|-------------------|----|-----------------|
| 1 | Hydraulic gear pump | 6 | Tilt cylinder | 11 | Priority v/v |
| 2 | Main control valve | 7 | Suction strainer | 12 | Fork positioner |
| 3 | Steering unit | 8 | Return filter | 13 | Flow regulator |
| 4 | Steering cylinder | 9 | Velocity fuse v/v | 14 | Load sensor |
| 5 | Lift cylinder | 10 | Hydraulic tank | 15 | Main relief v/v |

※ The circuit diagram may differ from the equipment, so please check before a repair.

1) WHEN THE LIFT CONTROL LEVER IS IN THE LIFT POSITION



22D9HS03

When the lift control lever is pulled back, the spool on the first block moves to lift position.


The oil from hydraulic gear pump (1) flows into main control valve (2) and then goes to the large chamber of lift cylinder (5) by pushing the load check valve of the spool.

The oil from the small chamber of lift cylinder (5) returns to hydraulic oil tank (10) at the same time.

When this happens, the fork goes up.

※ The circuit diagram may differ from the equipment, so please check before a repair.

2) WHEN THE LIFT CONTROL LEVER IS IN THE LOWER POSITION




22D9HS04

When the lift control lever is pushed forward, the spool on the first block moves to lower position. The work port (1A) and the small and the large chamber of lift cylinder are connected to the return passage, so the fork will be lowered due to its own weight.

※ The circuit diagram may differ from the equipment, so please check before a repair.

3) WHEN THE TILT CONTROL LEVER IS IN THE FORWARD POSITION



22D9HS05

When the tilt control lever is pushed forward, the spool on the second block is moved to tilt forward position.


The oil from hydraulic gear pump (1) flows into main control valve (2) and then goes to the large chamber of tilt cylinder (6) by pushing the load check valve of the spool.

The oil at the small chamber of tilt cylinder (6) returns to hydraulic tank (10) at the same time.

When this happens, the mast tilt forward.

※ The circuit diagram may differ from the equipment, so please check before a repair.

4) WHEN THE TILT CONTROL LEVER IS IN THE BACKWARD POSITION



22D9HS06

When the tilt control lever is pulled back, the spool on the second block is moved to tilt backward position.

The oil from hydraulic gear pump (1) flows into main control valve (2) and then goes to the small chamber of tilt cylinder (6) by pushing the load check valve of the spool.

The oil at the large chamber of tilt cylinder (6) returns to hydraulic tank (10) at the same time.


When this happens, the mast tilts backward.

※ The circuit diagram may differ from the equipment, so please check before a repair.

2. HYDRAULIC GEAR PUMP

1) NON-BOOSTER TYPE

(1) Structure



20L7HS07


1	Housing	11	Back up ring	21	Spring
2	Body	12	Side plate	22	Plug
3	Body (priority valve)	13	Oil seal	23	O-ring
4	Bushing	14	Snap ring	24	Adjust screw
5	O-ring	15	Bolt	25	O-ring
6	Pin	16	Washer	26	Plug bolt
7	Drive gear	17	Plug	27	Poppet
8	Idle gear	18	O-ring	28	Relief spring
9	Side plate	19	Plug orifice	29	Plug
10	O-ring	20	Spool	30	O-ring

(2) Operation

This pump comprises of a main body, a priority valve body and a housing bolted together and equipped with a priority valve. The gear journals are supported by bushings (4) to give high volumetric and mechanical efficiencies.

3. MAIN CONTROL VALVE

1) STRUCTURE (4- Spool)




Port name	Size
Inlet port	1-1/16-12UN
Outlet port	1-1/16-12UN

20DEHS07

- | | | |
|-------------------|------------------|--------------------------|
| 1 Lift block assy | 12 Relief piston | 22 O-ring |
| 2 Tilt block assy | 13 Nut | 23 O-ring, retainer |
| 3 Aux1 block assy | 14 Relief plug | 24 Plug |
| 4 Work block assy | 15 O-ring | 25 Steel ball |
| 5 PT block | 16 Relief spring | 26 Load sensor spring |
| 6 Gauge plug assy | 17 Pilot poppet | 27 Load sensor spring |
| 7 Long bolt | 18 Plug | 28 O-ring |
| 8 Plug | 19 O-ring | 29 System relief seat |
| 9 O-ring | 20 O-ring | 30 Secondary relief seat |
| 10 Spring | 21 O-ring | 32 Solenoid valve assy |
| 11 Spool | | |

2) INLET SECTION OPERATION


(1) Structure and description



20D7HS08

- | | | | |
|----|---------------|----|-----------------------|
| 8 | Plug | 14 | Relief plug |
| 9 | O-ring | 16 | Relief spring |
| 10 | Spring | 17 | Pilot poppet |
| 11 | Spool | 28 | O-ring |
| 12 | Relief piston | 29 | System relief seat |
| 13 | Nut | 30 | Secondary relief seat |

(2) Operation




20D7HS15

Oil flows from P (pump) port to reservoir (T) by pushing hydrostat spool (1). Before the center bypass line closed, hydrostat spool is keep opening, so pump port (P) and tank port (T) are always connected in operation to minimize heat generation.

3) LIFT SECTION OPERATION

(1) Lift position



20DEHS09


When the lift control lever is pulled back, the spool moves to the right and the neutral passage is closed.

The oil supplied from the pump pushes up the load check valve and flow into lift cylinder port (1A).

The pump pressure reaches proportionally the load of cylinder and fine control finished by shut off of the neutral passage.

The return oil from cylinder flows into the tank.

(2) Lower position



20DEHS10


When the lift control lever is pushed forward, the spool moves to the left and the neutral passage is closed.

The spool moves to the lift lower position, opening up the neutral passage to tank and (1A) → T.

In lift lower position the fork drops due to its own weight.

4) TILT SECTION OPERATION

(1) Tilt forward position




20D7HS11

When the tilt control lever is pushed forward, the spool moves to the left and the neutral passage is closed.

The oil supplied from the pump pushes up the load check valve and flow into tilt cylinder port (2B). The pump pressure reaches proportionally the load of cylinders and fine control finished by closing the neutral passage.

The return oil from cylinder port (2A) flows into the tank through the hole of the tilt lock spool.

(2) Tilt backward position



20D7HS12

When the tilt control lever is pulled back, the spool moves to the right and the neutral passage is closed.

The oil supplied from the pump pushes up the load check valve and flows into tilt cylinder port (2A). The pump pressure reaches proportionally the load of cylinder and fine control finished by shut off of the neutral passage.

The return oil from cylinder port (2B) flows into the tank via the low pressure passage.


5) MAIN RELIEF VALVE

(1) Pressure setting

A good pressure gauge must be installed in the line which is in communication with the work port relief. A load must be applied in a manner to reach the set pressure of the relief unit.


① Procedure

- ① Loosen lock nut.
- ② Set adjusting bar to desired pressure setting.
- ③ Tighten lock nut.
- ④ Retest in similar manner as above.




(2) Operation

Pressurized oil over the relief pressure pushes pilot poppet and flows to tank passage, therefore the system pressure keeps under the adjusted relief pressure.




4. LIFT CYLINDER



D255HS18

- | | | |
|-----------------|------------------|---------------|
| 1 Tube assembly | 6 Wear ring | 11 O-ring |
| 2 Rod | 7 Retaining ring | 12 Guide |
| 3 Piston | 8 Gland | 13 DU bushing |
| 4 Piston seal | 9 Dust wiper | 14 Spacer |
| 5 Back up ring | 10 Rod seal | 15 O-ring |


5. TILT CYLINDER



22D9HS19

- | | | |
|-----------------|----------------|----------------------|
| 1 Tube assembly | 10 U-packing | 19 Spherical bearing |
| 2 Rod | 11 Backup ring | 20 Hex bolt |
| 3 Piston | 12 Dust wiper | 21 Spring washer |
| 4 Piston seal | 13 Stop ring | 22 Lock nut |
| 5 Wear ring | 14 O-ring | 23 Grease nipple |
| 6 O-ring | 15 Backup ring | 24 Dust cap |
| 7 Nylon nut | 16 O-ring | 25 O-ring |
| 8 Rod cover | 17 Washer | 26 O-ring |
| 9 Rod bushing | 18 Eye | |

6. FREE LIFT CYLINDER



22D9HS20

- | | | | | | |
|---|---------------|----|----------------|----|----------------|
| 1 | Tube assembly | 6 | Check valve | 11 | Dust wiper |
| 2 | Rod | 7 | Retaining ring | 12 | Retaining ring |
| 3 | Piston | 8 | Set screw | 13 | O-ring |
| 4 | Piston seal | 9 | Rod cover | 14 | Back up ring |
| 5 | Wear ring | 10 | U-packing | | |

GROUP 2 OPERATIONAL CHECKS AND TROUBLESHOOTING

1. OPERATIONAL CHECKS

1) CHECK ITEM

- (1) Check visually for deformation, cracks or damage of rod.
- (2) Set mast vertical and raise 1m from ground. Wait for 10 minutes and measure hydraulic drift (amount forks move down and amount mast tilts forward).

•Check condition

- Hydraulic oil : Normal operating temp
- Mast substantially vertical.
- Rated capacity load.



•Hydraulic drift

- Down (Downward movement of forks)
: Within 100 mm (3.9 in)
- Forward (Extension of tilt cylinder)
: Within 5°

- (3) If the hydraulic drift is more than the specified value, replace the control valve or cylinder packing.

Check that clearance between tilt cylinder bushing and mounting pin is within standard range.

	mm (in)
Standard	Under 0.6 (0.02)




2) HYDRAULIC OIL

- (1) Using dipstick, measure oil level, and oil if necessary.
- (2) When changing hydraulic oil, clean suction strainer (screwed into outlet port pipe) and line filter (screwed into inlet pipe).

3) CONTROL VALVE

- (1) Raise forks to maximum height and measure oil pressure.

Check that oil pressure is 200 kgf/cm².
(2845 psi)



2. TROUBLESHOOTING

1) SYSTEM

Problem	Cause	Remedy
Large fork lowering speed.	<ul style="list-style-type: none"> · Seal inside control valve defective. · Oil leaks from joint or hose. · Seal inside cylinder defective. 	<ul style="list-style-type: none"> · Replace spool or valve body. · Replace. · Replace packing.
Large spontaneous tilt of mast.	<ul style="list-style-type: none"> · Tilting backward : Check valve defective. · Tilting forward : tilt lock valve defective. · Oil leaks from joint or hose. · Seal inside cylinder defective. 	<ul style="list-style-type: none"> · Clean or replace. · Clean or replace. · Replace. · Replace seal.
Slow fork lifting or slow mast tilting.	<ul style="list-style-type: none"> · Lack of hydraulic oil. · Hydraulic oil mixed with air. · Oil leaks from joint or hose. · Excessive restriction of oil flow on pump suction side. · Relief valve fails to keep specified pressure. · Poor sealing inside cylinder. · High hydraulic oil viscosity. · Mast fails to move smoothly. · Oil leaks from lift control valve spool. · Oil leaks from tilt control valve spool. 	<ul style="list-style-type: none"> · Add oil. · Bleed air. · Replace. · Clean filter. · Adjust relief valve. · Replace packing. · Change to SAE10W, class CJ engine oil. · Adjust roll to rail clearance. · Replace spool or valve body. · Replace spool or valve body.
Hydraulic system makes abnormal sounds.	<ul style="list-style-type: none"> · Excessive restriction of oil flow pump suction side. · Gear or bearing in hydraulic pump defective. 	<ul style="list-style-type: none"> · Clean filter. · Replace gear or bearing.
Control valve lever is locked	<ul style="list-style-type: none"> · Foreign matter jammed between spool and valve body. · Valve body defective. 	<ul style="list-style-type: none"> · Clean. · Tighten body mounting bolts uniformly.
High oil temperature.	<ul style="list-style-type: none"> · Lack of hydraulic oil. · High oil viscosity. · Oil filter clogged. 	<ul style="list-style-type: none"> · Add oil. · Change to SAE10W, class CJ engine oil. · Clean filter.

2) HYDRAULIC GEAR PUMP

Problem	Cause	Remedy
Pump does not develop full pressure.	<ul style="list-style-type: none"> ·System relief valve set too low or leaking. ·Oil viscosity too low. ·Pump is worn out. 	<ul style="list-style-type: none"> ·Check system relief valve for proper setting. ·Change to proper viscosity oil. ·Repair or replace pump.
Pump will not pump oil.	<ul style="list-style-type: none"> ·Reservoir low or empty. ·Suction strainer clogged. 	<ul style="list-style-type: none"> ·Fill reservoir to proper level. ·Clean suction strainer.
Noisy pump caused by cavitation.	<ul style="list-style-type: none"> ·Oil too thick. ·Oil filter plugged. ·Suction line plugged or too small. 	<ul style="list-style-type: none"> ·Change to proper viscosity. ·Clean filters. ·Clean line and check for proper size.
Oil heating.	<ul style="list-style-type: none"> ·Oil supply low. ·Contaminated oil. ·Setting of relief valve too high or too low. ·Oil viscosity too low. 	<ul style="list-style-type: none"> ·Fill reservoir to proper level. ·Drain reservoir and refill with clean oil. ·Set to correct pressure. ·Drain reservoir and fill with proper viscosity.
Foaming oil.	<ul style="list-style-type: none"> ·Low oil level. ·Air leaking into suction line. ·Wrong kind of oil. 	<ul style="list-style-type: none"> ·Fill reservoir to proper level. ·Tighten fittings, check condition of line. ·Drain reservoir, fill with non-foaming oil.
Shaft seal leakage.	<ul style="list-style-type: none"> ·Worn shaft seal. ·Worn shaft in seal area. 	<ul style="list-style-type: none"> ·Replace shaft seal. ·Replace drive shaft and seal.

3) MAIN RELIEF VALVE

Problem	Cause	Remedy
Can't get pressure	<ul style="list-style-type: none"> ·Poppet stuck open or contamination under seat. 	<ul style="list-style-type: none"> ·Check for foreign matter between poppets and their mating parts. Parts must slide freely.
Erratic pressure	<ul style="list-style-type: none"> ·Pilot poppet seat damaged. 	<ul style="list-style-type: none"> ·Replace the relief valve. ·Clean and remove surface marks for free movement.
Pressure setting not correct	<ul style="list-style-type: none"> ·Normal wear. Lock nut & adjust screw loose. 	<ul style="list-style-type: none"> ·See page 6-16 for How to set pressure on work main relief.
Leaks	<ul style="list-style-type: none"> ·Damaged seats. ·Worn O-rings. ·Parts sticking due to contamination. 	<ul style="list-style-type: none"> ·Replace the relief valve. ·Install seal and spring kit. ·Disassemble and clean.


4) LIFT CYLINDER

Problem	Cause	Remedy
Oil leaks out from gland through rod.	<ul style="list-style-type: none"> · Foreign matters on packing. · Unallowable score on rod. · Unusual distortion of dust seal. · Chrome plating is striped. 	<ul style="list-style-type: none"> · Replace packing. · Smooth rod surface with an oil stone. · Replace dust seal. · Replace rod.
Oil leaks out from cylinder gland thread.	<ul style="list-style-type: none"> · O-ring damaged. 	<ul style="list-style-type: none"> · Replace O-ring.
Rod spontaneously retract.	<ul style="list-style-type: none"> · Scores on inner surface of tube. · Unallowable score on the inner surface of tube. · Foreign matters in piston seal. 	<ul style="list-style-type: none"> · Smooth rod surface with an oil stone. · Replace cylinder tube. · Replace piston seal.
Wear (clearance between cylinder tube and wear ring)	<ul style="list-style-type: none"> · Excessive clearance between cylinder tube and wear ring. 	<ul style="list-style-type: none"> · Replace wear ring.
Abnormal noise is produced during tilting operation.	<ul style="list-style-type: none"> · Insufficient lubrication of anchor pin or worn bushing and pin. · Bent tilt cylinder rod. 	<ul style="list-style-type: none"> · Lubricate or replace. · Replace.

GROUP 3 DISASSEMBLY AND ASSEMBLY

1. HYDRAULIC GEAR PUMP (NON-BOOSTER TYPE)

1) STRUCTURE



15L7MHS06A

1	Housing	11	Back up ring	21	Spring
2	Body	12	Side plate	22	Plug
3	Body (priority valve)	13	Oil seal	23	O-ring
4	Bushing	14	Snap ring	24	Adjust screw
5	O-ring	15	Bolt	25	O-ring
6	Pin	16	Washer	26	Plug bolt
7	Drive gear	17	Plug	27	Poppet
8	Idle gear	18	O-ring	28	Relief spring
9	Side plate	19	Plug orifice	29	Plug
10	O-ring	20	Spool	30	O-ring

2) DISASSEMBLY

(1) Clamping pump

- ① Clamping pump in a vice with pump shaft facing up.
(Do not chuck the aluminum parts such as body and housing.)
- ② Mark V by permanent marker pen.
This will assure proper reassembly.



PUMP101

(2) Housing

- ① Loosen 8 bolts and remove housing.
- ② Pry off snap ring for hole and remove oil seal from housing.
- ③ Remove O-ring from housing.



PUMP102

(3) Gear

- ① Mark at the end of the idle gear by permanent marker pen before removing gear set. This will assure proper reassembly.
- ② Disassemble gear set and side plate from body.
- ③ Disassemble E-type ring and backup ring from side plate.




PUMP103



PUMP104

(4) Body and rear cover

- ① Loosen the vice and remove body and bronze side plate from rear cover.
- ② Remove O-ring from rear cover.
- ③ Disassemble pin from body.



PUMP105

(5) Priority valve

- ① Loosen the plug at the side of drive gear, be careful not to bounce out spring.
- ② Take out spring.
- ③ Loosen plug opposite side and draw out spool carefully.



PUMP106

(6) Relief valve

- ※ Do not disassemble relief valve when pressure setting and caulking is not possible.
- ① Loosen adjust screw, be careful not to bounce out spring.
 - ② Take out spring and draw out poppet.
 - ③ Loosen plug for port of gage mounting.
 - ④ Remove O-ring from plug and adjust screw.

3) ASSEMBLY

(1) Preparation

- ① Clean all parts and dry them with compressed air thoroughly.
- ② Check the permanent mark.
- ③ Apply grease O-ring, oil seal, E-type ring and side plate lightly.


(2) Priority valve

- **Relief valve : if disassembled**

- ① Fit O-ring on plug and adjust screw.
- ② Tighten plug for port of gage mounting. (Tightening torque : 35 Nm)
- ③ Assemble poppet, spring and adjust screw into body in that order.
- ④ Install relief valve to the machine after final assembling and set the relief pressure and caulk 3 places (equivalent), not to loosen.



- **Priority valve**

- ① Insert spool into spring groove from idle gear side of body carefully and tighten plug. (Tightening torque : 80 Nm)
- ② Put spring the other side and tighten plug. (Tightening torque : 100 Nm)





(3) Rear cover and body

- ① Assemble pin into body.
- ② Assemble O-ring on the groove of rear cover.
- ③ Place the bronze face of side plate contact with gear on rear cover.
Insert side plate into body and adjust pin by pressing after adjusting pin hole of rear cover and pin of body.
- ④ Confirm the direction of rear cover, bronze side plate and body same as drawing.



(4) Gear

- ① Place body up.
- ② Place peck center of idle gear up and assemble drive gear and idle gear to body.
- ③ Fit E-type ring and backup ring and combine side plate with gear set.
- ④ Confirm the direction of side plate same as drawing.
- ⑤ Confirm the face of backup ring side contact with housing.



(5) Housing


- ① Press fit oil seal with same direction as drawing carefully and fit snap ring.
- ② Fit O-ring into groove of housing.
- ③ Insert drive gear into housing and combine housing with body pressing lightly after confirmed pin position.
- ④ Tighten bolt with washer zigzag lightly, be careful not to leave O-ring its place.
- ⑤ Clamp rear cover in a vice.
- ⑥ Tighten bolt zigzag with tightening torque 35~38 Nm.

(6) Inspection

- ① Clamp drive gear shaft in a vice.
- ② Rotate the gear pump.
- ③ Confirm rotation smoothly.


2. MAIN CONTROL VALVE

- 1) Remove bolt (1) to separate the valve section.
· Bolt torque (1) : $4.0^{+0.6}_0$ kgf·m




20D7MCV01

- 2) Divide the valve body.



20D7MCV02

- 3) Remove dust cap (3) and bolt (2) from the valve body.
· Bolt torque (2) : 1.2 kgf·m




20D7MCV03

- 4) Remove attachment spool (4) from the valve body.



20D7MCV04

5) Remove O-ring seals (5) from the valve body.



20D7MCV05

6) Remove tilt spool (6) from the valve body.



20D7MCV06

7) Remove lift spool (7) from the valve body.

8) Remove lock poppet (8) from the valve body.

9) Remove normal close solenoid valve (9, Opt) from the valve body.



20D7MCV07


10) Remove plug (12) and spring (11).

11) Remove hydrostat (10).




20D7MCV08

- 12) Remove relief plugs (15), springs (14) and poppets (13).
·Relief plugs torque (15) : 2.5 kgf·m



20D7MCV09

- 13) Remove normal open solenoid valve (16, Opt) from the valve body.




20D7MCV10

- 14) Assembly procedure of the main control valve is the reverse order of the removal procedure.

2-1. MAIN CONTROL VALVE (FINGERTIP, OPT)

1) STRUCTURE




※ Tightening torque

- Item (3-1-1, 4-2, 5-2, 10) : 0.97 kgf·m (7.0 lbf.ft)
- Item (9) : 2.35 kgf·m (16.9 lbf.ft)

25L7AFT01

1	Main block	4-1	Block	7	Plain washer
1A	Solenoid valve (lift)	4-2	Socket head screw	8	Plain washer
3	Tilt block	5	Aux block (auxiliary 2)	9	Tension rod
3-1	Adapter	5-1	Block	10	Tension rod
3-1-1	Socket head screw	5-2	Socket head screw	100	Section seal kit
4	Aux block (auxiliary 1)	6	End plate	200	Section seal kit

2) MAIN SECTION




25L7AFT02

※ Flow rate : 100 lpm

※ Maximum pressure : 250 bar

(1) Lifting and lowering valve

① Main section




25L7AFT03

② EMP solenoid valve



25L7AFT04


※ Tightening torque
6.12 kgf·m (44.2 lbf·ft)




25L7AFT05

※ When it can't control lifting & lowering, need to check EMP valve. Because of contamination material EMP valve often can't operate properly that means valve poppet and seat opened.

(2) 3-way controller



25L7AFT06




25L7AFT07

※ During unloading, supplied oil by the pump return to tank keeping 9 bar of system pressure.

(3) Pressure Reducing valve & G damping screw

① Pressure reducing valve



- ※ Pressure reducing valve controls valve actuation by supplying internal control oil.
- ※ Use flat screw driver.
- ※ Tightening torque
0.71 kgf·m (5.2 lbf·ft)



25L7AFT08

② G damping screw




- ※ G damping increased throttling effect of load sensing line.
- ※ Tightening torque
1.02 kgf·m (7.4 lbf·ft)




25L7AFT09A

(4) Pressure relief valve




25L7AFT10



25L7AFT11

※ Use with a 12 mm spanner.

※ Tightening torque (2)
1.43 kgf·m (10.3 lbf·ft)



25L7AFT12

※ Use with a 3 mm wrench.

※ Tightening torque (1)
1.43 kgf·m (10.3 lbf·ft)


⤵ = Pressure increases
⤴ = Pressure decreases

※ Rotating clockwise to increase setting pressure with a wrench.

※ 80 bar increase and decrease per 1 turn.

(5) Emergency lowering valve and shuttle valve


① Emergency lowering valve



25B9UFT14

※ When need to force lowering, rotate counter clockwise increasingly with emergency lowering valve.


② Shuttle valve



25L7AFT15



※ Transfer bigger load pressure through shuttle valve.
 ※ Use a flat screw driver.

3) TILT SECTION



- ※ Flow rate : 40 lpm
- ※ Load holding pressure : 210 bar

(1) Proportional directional valve



① Valve section block



② Counter balance valve block

(2) Disassembly valve section



① Disassemble spool



※ All block type, 40lpm

② Disassemble coil



※ AMP 4 pin coil



25L7AFT18

③ Disassembling process

a. Release spring cap.



25L7AFT19

b. Release spring cap completely.



25L7AFT20

c. Release lever block.



25L7AFT21



d. Pull out spool.



25L7AFT22

(3) 2 way controller and shuttle valve



① 2 way controller (6 bar)



25L7AFT24

※ 2 way controller make it keep 6 bar regardless of load change between in and out of spool.

② Shuttle valve




25L7AFT25

※ Transfer bigger load pressure through shuttle valve.
※ Fix 4 mm bolt and pull out.


(4) Counter balance valve

※ Counter balance valve needs during tilting out operation.



25L7AFT28A

4) AUXILIARY SECTION




25L7AFT29

※ Flow rate : 40 lpm

※ Pressure limit aux section : 140 bar

(1) Proportional directional valve



① Valve section block





② Ancillary block

25L7AFT30

(2) 2 way controller and shuttle valve



① 2 way controller (6 bar)



25L7AFT24

※ 2 way controller make it keep 6 bar regardless of load change between in and out of spool.

② Shuttle valve



25L7AFT25

- ※ Transfer bigger load pressure through shuttle valve.
- ※ Fix 4 mm bolt and pull out.

(3) Second relief valve

- ※ Controlling individual section pressure, rotating clockwise to increase setting pressure with wrench.
- ※ 80 bar increase and decrease per 1 turn.



25L7AFT26




- ※ Use with a 12 mm spanner.
- ※ Tightening torque (1)
1.43 kgf·m (10.3 lbf·ft)





25L7AFT27

- ※ Use with a 3 mm wrench.
- ※ Tightening torque (2)
1.43 kgf·m (10.3 lbf·ft)



5) ADD SECTION PART


(1) Disassembly



※ When it needs to disassemble HMPL valve, it's possible to release tension rod sets.

3. LIFT CYLINDER

1) STRUCTURE




20D7HS19

- | | | | | | |
|---|--------------|----|----------------|----|------------|
| 1 | Tube assy | 6 | Wear ring | 11 | O-ring |
| 2 | Rod assy | 7 | Retaining ring | 12 | Guide |
| 3 | Piston | 8 | Gland | 13 | Du bushing |
| 4 | Piston seal | 9 | Dust wiper | 14 | Spacer |
| 5 | Back up ring | 10 | Rod seal | 15 | O-ring |

2) DISASSEMBLY

- (1) Hold the cylinder tube in a vice, loosen the cylinder head and remove it.
Remove the spacer from the cylinder tube and knock out the bushing. Hook a wrench in the hole in the retainer at the piston end and turn. Lever up the edge of the guide, then turn the guide in again and the guide can be removed.




3) CHECK AND INSPECTION

mm (in)

Check item	Standard size	Repair limit	Remedy
Clearance between cylinder rod & bushing	0.072~0.288 (0.003~0.011)	0.5 (0.020)	Replace bushing
Clearance between piston ring & tube	0.05~0.030 (0.002~0.012)	0.5 (0.020)	Replace piston ring


4) ASSEMBLY

- (1) Soak the piston ring in hydraulic oil at a temperature of 40 to 50°C, expand the inside diameter and assemble on the piston. Install a piston seal.
Bend the edge of the guide and rotate it to install the guide completely.



4. TILT CYLINDER

1) STRUCTURE




22D9HS27

- | | | | | | |
|---|---------------|----|-------------|----|-------------------|
| 1 | Tube assembly | 10 | U-packing | 19 | Spherical bearing |
| 2 | Rod | 11 | Backup ring | 20 | Hex bolt |
| 3 | Piston | 12 | Dust wiper | 21 | Spring washer |
| 4 | Piston seal | 13 | Stop ring | 22 | Lock nut |
| 5 | Wear ring | 14 | O-ring | 23 | Grease nipple |
| 6 | O-ring | 15 | Backup ring | 24 | Dust cap |
| 7 | Nylon nut | 16 | O-ring | 25 | O-ring |
| 8 | Rod cover | 17 | Washer | 26 | O-ring |
| 9 | Rod bushing | 18 | Eye | | |

2) DISASSEMBLY

- (1) Hold the parallel parts of the cylinder tube bottom in a vice and mark the rod head end to show how much it is screwed in, then remove the rod head. Next, hook a wrench into the notch at the cylinder head and remove the cylinder head from cylinder tube.

When doing this, wind tape round the threaded part of the rod and be careful not to damage the dust seal and rod seal inside cylinder head.



3) CHECK AND INSPECTION

mm (in)

Check item	Standard size	Repair limit	Remedy
Clearance between cylinder rod & bushing	0.072~0.288 (0.003~0.011)	0.5 (0.020)	Replace bushing
Clearance between rod head bushing & pin	0.10~0.35 (0.004~0.014)	0.6 (0.024)	Replace bushing