


SECTION 3 POWER TRAIN SYSTEM

Group 1	Structure and operation	3-1
Group 2	Operation and maintenance	3-46
Group 3	Disassembly and assembly	3-57
Group 4	Adjustment	3-185

SECTION 3 POWER TRAIN SYSTEM

GROUP 1 STRUCTURE AND OPERATION

1. POWER TRAIN COMPONENT OVERVIEW



250D9PT01

The power train consists of the following components :

- Torque converter
- Transmission
- Propeller shaft
- Drive axle


Engine power is transmitted to the transmission through the torque converter.

The transmission is a hydraulically engaged three speed forward, three speed reverse power shift type transmission.

The transmission outputs through universal joints to drive axle assembly.

The power transmitted to front axle drives front wheels.

· Hydraulic circuit



D507PT31

Speed	Forward			Reverse			Neutral	Positions on the valve block	No. of measuring points
	F1	F2	F3	R1	R2	R3			
Y1							-	F	60
Y2				•	•	•	-	E	55
Y3	•			•			-	D	56
Y4			•			•	-	C	58
Y5	•	•	•				-	B	53
Y6		•			•		-	A	57
Clutch engaged	KV, K1	KV, K2	KV, K3	KR, K1	KR, K2	KR, K3	-	-	-

NFS Follow-on slide

D Vibration damper

B Orifice

P1 Not used

P2 Proportional valve KR

P3 Proportional valve K1


P4 Proportional valve K3

P5 Proportional valve KV

P6 Proportional valve K2

Y1~Y6 Pressure regulators

2. TORQUE CONVERTER



D503TM01

- | | | | | | |
|---|---------|---|-------------------|---|-------------|
| 1 | Turbine | 3 | Pump | 5 | Input shaft |
| 2 | Stator | 4 | Transmission pump | | |

The converter is working according to the Trilok-system, i.e. it assumes at high turbine speed the characteristics, and with it the favorable efficiency of a fluid clutch.

The converter will be defined according to the engine power so that the most favorable operating conditions for each installation case are given.

The Torque converter is composed of 3 main components :
Pump wheel - turbine wheel - stator (Reaction member)

These 3 impeller wheels are arranged in such a ring-shape system that the fluid is streaming through the circuit components in the indicated order.

Pressure oil is constantly streaming out of the transmission pump through the converter. In this way, the converter can fulfill its task to multiply the torque of the engine, and at the same time, the heat created in the converter is dissipated through the escaping oil.

The oil, escaping out of the pump wheel, enters the turbine wheel and is there inversed in the direction of flow.

According to the rate of inversion, the turbine wheel and with it also the output shaft, receive a more or less high reaction moment. The stator (Reaction member), following the turbine, has the task to inverse again the oil which is escaping out of the turbine and to delivery it under the suitable discharge direction to the pump wheel.

Due to the inversion, the stator receives a reaction moment.

The relation turbine moment/pump moment is called torque conversion. This is the higher the greater the speed difference of pump wheel and turbine wheel will be.

Therefore, the maximum conversion is created at standing turbine wheel.

With increasing output speed, the torque conversion is decreasing. The adoption of the output speed to a certain required output moment is infinitely variable and automatically achieved by the torque converter.


If the turbine speed is reaching about 80% of the pump speed, the conversion becomes 1.0 i.e. the turbine moment becomes equal to that of the pump moment.

From this point on, the converter is working similar to a fluid clutch.

A stator freewheel serves to improve the efficiency in the upper driving range, it is backing up in the conversion range the moment upon the housing, and is released in the coupling range.

In this way, the stator can rotate freely.

Function of a hydrodynamic torque converter (Schematic view)





D503TM02

3. TRANSMISSION

1) LAYOUT

Gearbox diagram





180D7ETM03

- 1 Clutch shaft (lay shaft, K4)
- 2 Clutch shaft (KV)
- 3 Input shaft / Power take-off (AN/PTO)
- 4 Clutch shaft (KR)

- 5 Clutch shaft (KZ)
- 6 Clutch shaft / Output (K3/AB)
- 7 Clutch shaft (K1)
- 8 Electro-hydraulic control

2) INSTALLATION VIEW



180D7EPT26

- 1 Electro - hydraulic control
- 2 Converter bell
- 3 Lifting lugs
- 4 Gearbox housing front and rear section
- 5 Oil level tube with oil dipstick (rear side)
- 6 Transmission suspension holes M20
- 7 Plate
- 8 Converter with diaphragm - direct mounting
- 9 Power take - off; coaxial, engine - dependent
- 10 Gearbox housing front and rear section

- 11 Lifting lugs
- 12 Converter bell
- 13 Converter with diaphragm - direct mounting
- 14 Converter with diaphragm
- 15 Exchange filter with filter head
- 16 Transmission suspension holes M20
- 17 Oil drain plug M38 × 1.5
- 18 Type plate
- 19 Output flange
- 20 Oil level tube with oil dipstick (rear side)

3) OPERATION OF TRANSMISSION

(1) Gearbox diagram

The multi-speed reversing transmission in counter shaft design is power shiftable by hydraulically actuated multi-disk clutches.


All gears are constantly meshing and carried on anti-friction bearings.

The gear wheels, bearings and clutches are cooled and lubricated with oil.


The 3-speed reversing transmission is equipped with 5 multi-disk clutches.

At the shifting, the actual plate pack is compressed by a piston, movable in axial direction, which is pressurized by pressure oil.

A compression spring takes over the pushing task of the piston, thus the release of the plate pack. As to the layout of the transmission as well as the specifications of the closed clutches in the single speeds.



Gearbox diagram



Legend

KV	= Clutch forward
KR	= Clutch reverse
K1	= Clutch 1st speed
K2	= Clutch 2nd speed
K3/AB	= Clutch 3rd speed / output
K4	= Clutch 4th speed(layshaft)
AN/PTO	= INPUT / Power take-off

Diagram Clutches


Driving direction	Speed	Clutch
Forward	1	KV/K1
	2	KV/K2
	3	KV/K3
Reverse	1	KR/K1
	2	KR/K2
	3	KR/K3

(2) Forward


In forward, forward clutch and 1st, 2nd, 3rd clutch are engaged.

Forward clutch and 1st, 2nd, 3rd clutch are actuated by the hydraulic pressure applied to the clutch piston.

Transmission diagram




1st speed-reverse




Legend

- KV = Clutch forward
- KR = Clutch reverse
- K1 = Clutch 1st speed
- K2 = Clutch 2nd speed
- K3/AB = Clutch 3rd speed / output
- K4 = Clutch 4th speed (layshaft)
- AN/PTO = INPUT / Power take-off

2nd speed-reverse



3rd speed-reverse




180D7EPT33

(3) Reverse


In reserve, reserve clutch and 1st, 2nd, 3rd clutch are engaged.

Reverse clutch and 1st, 2nd, 3rd are actuated by the hydraulic pressure applied to the clutch piston.

Transmission diagram




1st speed-reverse




Legend

- KV = Clutch forward
- KR = Clutch reverse
- K1 = Clutch 1st speed
- K2 = Clutch 2nd speed
- K3/AB = Clutch 3rd speed / output
- K4 = Clutch 4th speed (layshaft)
- AN/PTO = INPUT / Power take-off

2nd speed-reverse




3rd speed-reverse



180D7EPT34

4) ELECTRO-HYDRAULIC SHIFT CONTROL WITH PROPORTIONAL VALVE



D507PT03

- | | | | |
|---|---------------------------------|----|--------------------|
| 1 | Pressure reducing valve (9bar) | 7 | Intermediate plate |
| 2 | Main pressure valve (16 + 2bar) | 8 | Duct plate |
| 3 | Housing | 9 | Vibration damper |
| 4 | Plug (cable harness) | 10 | Follow - on slide |
| 5 | Cover | 11 | Pressure regulator |
| 6 | Valve block | | |

Transmission control, see schedule of measuring points, Oil circuit diagram and Electro-hydraulic control unit see page 3-2, 3-10.

The transmission pump, necessary for the oil supply of the converter, and for the transmission control, is sitting in the transmission on the engine-dependent input shaft.

The feed rate of the pump is

$$Q = 105 \text{ l/min, at } n_{\text{Engine}} = 2000 \text{ min}^{-1}$$

This pump is sucking the oil via the coarse filter out of the oil sump and delivers it via the fine filter - the filter can also be fitted externally from the transmission - to the main pressure valve.

If because of contamination, respective damage, the through-flow through the fine filter is not ensured, the oil will be directly conducted via a filter differential pressure valve (bypass valve $\Delta p = 5.5+3 \text{ bar}$) to the lubrication.

In this case, an error indication is shown on the display.

The five clutches of the transmission are selected via the 5 proportional valves P2 to P6.

The proportional valve (pressure regulator unit) is composed of pressure regulator (e.g. Y6), follow-on slide and vibration damper.

The control pressure of $9+0.5 \text{ bar}$ for the actuation of the follow-on slides is created by pressure reducing valve. The pressure oil ($16+2 \text{ bar}$) is directed via the follow-on slide to the respective clutch.

Due to the direct proportional selection with separated pressure modulation for each clutch, the pressure to the clutches, which are engaged in the gear change, will be controlled. In this way, a hydraulic intersection of the clutches to be engaged and disengaged becomes possible.

This is creating spontaneous shiftings without traction force interruption.

At the shifting, the following criteria will be considered :

- Speed of engine, turbine, central gear train and output.
- Transmission temperature.
- Shifting mode(up-,down-, reverse shifting and speed engagement out of Neutral).
- Load condition(full and part load, traction, overrun inclusive consideration of load cycles during the shifting).

The main pressure valve is limiting the max. control pressure to $16+2.5 \text{ bar}$ and releases the main stream to the converter and lubrication circuit.

In the inlet to the converter, a converter safety valve is installed which protects the converter from high internal pressures (opening pressure $11+2 \text{ bar}$).

Within the converter, the oil serves to transmit the power according to the well-known hydrodynamic principle (see Chapter torque converter page 3-3).

To avoid cavitation, the converter must be always completely filled with oil.

This is achieved by converter pressure back-up valve, rear-mounted to the converter, with an opening pressure of at least $4.3+3 \text{ bar}$.

The oil, escaping out of the converter, is directed to the oil cooler.

From the oil cooler, the oil is directed to the transmission and there to the lubricating oil circuit, so that all lubricating points are supplied with cooled oil.

In the electrohydraulic control unit are 5 pressure regulators installed.


5) GEAR SELECTOR (DW-3)

The gear selector is designed for the mounting on the steering column left side. By a rotative motion, the positions (speeds) 1 to 3 are selected by tilting the lever, the driving direction (Forward (F) - Neutral (N) - Reverse (R)).

For the protection from unintended start off, a neutral interlock is installed :


Position «N» - Controller lever blocked in this position

Position «D» - Driving



D507PT12

Gear selector (DW-3)




F = FORWARD
 N = NEUTRAL
 R = REVERSE
 D = MECHANICAL NEUTRAL INTERLOCK
 1 = 1st SPEED
 2 = 2nd SPEED
 3 = 3rd SPEED


CODING GEAR SELECTOR

SPEED		OUTPUT								
		FORWARD			REVERSE			NEUTRAL		
		1	2	3	1	2	3	1	2	3
AD1	B1	●			●			●		
AD2	B2									
AD3	B3	●	●		●	●		●	●	
AD4	V	●	●	●						
AD5	R				●	●	●			
AD6	N							●	●	●

CIRCUIT DIAGRAM SELECTOR



CONNECTION DIAGRAM SELECTOR



K1 = RELAY STARTER INTERLOCK
 K2 = RELAY REVERSE LIGHTS
 A1 = TCU(Transmission Control Unit)
 A2 = CONTROLLER

6) TRANSMISSION ERROR DISPLAY

(1) Function

The display can be used with the gear selector. It indicates speed and driving direction as well as the activated inching.

When driving in the automatic mode, a bar indicator gives additionally also information about the selected driving range; The automatic range is symbolized by arrows above and below the bar indicator. In case of possible errors in the system, a wrench appears on the display, combined with indication of the error number. Also sporadically occurring errors can be indicated.



180D93ACD33

※ If it happens error codes, consult with Hyundai service center to repair the fault.

2) DISPLAY DURING AEB-MODE

Symbol	Meaning	Remarks
K1.....K3 KV, KR	Calibrating clutch K1...K3, KV or KR resp.	
_and Kx	Wait for start, initialization of clutch Kx, x : 1, 2, 3, V, R	
≡ and Kx	Fast fill time determination of clutch Kx	
=and Kx	Compensating pressure determination of clutch Kx	
OK	Calibration for all clutches finished	Transmission stays in neutral, you have to restart the TCU (ignition off/on) after removing AEB-Starter
STOP	AEB canceled(activation stopped)	Transmission stays in neutral, you have to restart the TCU (ignition off/on)
STOP and Kx	AEB stopped, clutch Kx can't be calibrated	Transmission stays in neutral, you have to restart the TCU (ignition off/on)
Spanner and Kx	Kx couldn't be calibrated, AEB finished	Transmission stays in neutral, you have to restart the TCU (ignition off/on)
△E	Engine speed too low → raise enging speed	
▽E	Engine speed too high → lower enging speed	
△T	Transmission oil temperature too low → heat up transmission	
▽T	Transmission oil temperature too high → cool down transmission	
FT	Transmission temperature not in defined range during calibration	Transmission stays in neutral, you have to restart the TCU (ignition off/on)
FB	Operating mode not NORMAL or transmission temperature sensor defective or storing of Calibrated values to EEPROM-has failed.	Transmission stays in neutral, you have to restart the TCU (ignition off/on)
FO	Output speed_not_zero	Transmission stays in neutral, you have to restart the TCU (ignition off/on)
FN	Shift lever not in Neutral position	Transmission stays in neutral, you have to restart the TCU (ignition off/on)
FP	Park brake_not_applied	Transmission stays in neutral, you have to restart the TCU (ignition off/on)
STOP	AEB-Starter was used incorrect or is defective. Wrong device or wrong cable used.	Transmission stays in neutral, you have to restart the TCU (ignition off/on)

3) INITIALIZING THE INCHING SENSOR

- (1) Start engine after parking the machine on flat floor and blocking wheels.
- (2) Release parking brake and keep neutral gear shift.
- (3) Adjust the inching sensor linkage so that the regular voltage is supplied to inching sensor when operating the pedal.
 - ※ Regular voltage ; Before pedal operation ($1 \pm 0.1V$), After pedal operation ($3.5 \pm 0.1V$).
- (4) Stop the engine and then just KEY ON. (Release parking brake, keep neutral gear)
- (5) Connect the AEB STARTER to the T/M controller.
- (6) Push AEB STARTER over 3 seconds.
- (7) If display shows "▼IP", Step on the pedal fully.
- (8) If display shows "▲IP", release "OK"
- (9) After the successful completion, it displays "OK".
- (10) In case of abnormal running, it may display "STOP" with the appropriate error code.
- (11) After troubleshooting, start the machine again to repeat above.
 - ※ Above works are to be done with the parking brake released, so machine's wheels must be blocked for safety.

4) DISPLAY DURING INCHPEDAL CALIBRATION

Symbol	Meaning	Remarks
▼IP	Push down the pedal slowly until endposition is reached and hold this position	
▲IP	Release the pedal slowly until endposition is reached	
IP blinkt	A problem occurred, release the pedal slowly until endposition is reached	If the expected endposition could not be reached, release the pedal and try again
OK	Finished inchpedal calibration successful	
FN and Stop	Shift lever not in Neutral position	Calibrations is aborted
FS and Stop	Sensor supply voltage AU1 is out of the specified range	Calibrations is aborted
FO and Stop	Outputspeed_not_zero	Calibrations is aborted
SL and Stop	Sensor voltage below specified range	Calibrations is aborted
SU and Stop	Sensor voltage below specified range	Calibrations is aborted
IL and Stop	Sensor position for released pedal out of specified range	Calibrations is aborted
IU and Stop	Sensor position for released pedal out of specified range	Calibrations is aborted
TO and Stop	Time-out calibration, pedal not moved after calibration start	Calibrations is aborted
DL and Stop	Angle between pedal positions released and pressed to small	Calibrations is aborted
DU and Stop	Angle between pedal positions released and pressed to small	Calibrations is aborted
FI and Stop	Sensor signal 1 and 2 don't match together	Calibrations is aborted

(4) Transmission error codes

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
11	Logical error at gear range signal TCU detected a wrong signal combination for the gear range <ul style="list-style-type: none"> · Cable from shift lever to TCU is broken · Cable is defective and is contacted to battery voltage or vehicle ground · Shift lever is defective 	TCU shifts transmission to neutral OP-mode : Transmission shutdown	<ul style="list-style-type: none"> · Check the cables from TCU to shift lever · Check signal combinations of shift lever positions for gear range ※ Failure cannot be detected in systems with DW2/DW3 shift lever. Fault is taken back if TCU detects a valid signal for the position
12	Logical error at direction select signal TCU detected a wrong signal combination for the direction <ul style="list-style-type: none"> · Cable from shift lever to TCU is broken · Cable is defective and is contacted to battery voltage or vehicle ground · Shift lever is defective 	TCU shifts transmission to neutral OP-Mode : Transmission shutdown	<ul style="list-style-type: none"> · Check the cables from TCU to shift lever · Check signal combinations of shift lever positions F-N-R ※ Fault is taken back if TCU detects a valid signal for the direction at the shift lever
13	Logical error at engine derating device TCU detected no reaction of engine while derating device active	After selecting neutral, TCU change to OP mode limp home	<ul style="list-style-type: none"> · Check engine derating device ※ This fault is reset after power up of TCU
15	Logical error at direction select signal 2 shift lever TCU detected a wrong signal combination for the direction <ul style="list-style-type: none"> · Cable from shift lever 2 to TCU is broken · Cable is defective and is contacted to battery voltage or vehicle ground · Shift lever is defective 	TCU shifts transmission to neutral if selector active OP mode : Transmission shutdown if elector active	<ul style="list-style-type: none"> · Check the cables from TCU to shift lever 2 · Check signal combinations of shift lever positions F-N-R ※ Fault is taken back if TCU detects a valid neutral signal for the direction at the shift lever
16	Logical error at axle connection Feedback axle connection measured by TCU and output signal axle connection don't fit <ul style="list-style-type: none"> · Axle can't be connected or disconnected due to mechanical problem · One of the cables from feedback axle connection switch to TCU is broken 	OP mode : Normal	<ul style="list-style-type: none"> · Check the cables from TCU to feedback axle connection switch · Check signals of the feedback axle connection switch
21	S.C. to battery voltage at clutch cut off input The measured voltage is too high: <ul style="list-style-type: none"> · Cable is defective and is contacted to battery voltage · Clutch cut off sensor has an internal defect · Connector pin is contacted to battery voltage 	Clutch cut off function is disabled OP mode : Normal	<ul style="list-style-type: none"> · Check the cable from TCU to the sensor · Check the connectors · Check the clutch cut off sensor
22	S.C. to ground or O.C. at clutch cut off input The measured voltage is too low: <ul style="list-style-type: none"> · Cable is defective and is contacted to vehicle ground · Cable has no connection to TCU · Clutch cut off sensor has an internal defect · Connector pin is contacted to vehicle ground or is broken 	Clutch cut off function is disabled OP mode : Normal	<ul style="list-style-type: none"> · Check the cable from TCU to the sensor · Check the connectors · Check the clutch cut off sensor

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
23	S.C. to battery voltage at load sensor input The measured voltage is too high: <ul style="list-style-type: none"> • Cable is defective and is contacted to battery voltage • Load sensor has an internal defect • Connector pin is contacted to battery voltage 	Retarder function is affected TCU uses default load OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the load sensor • Check the assembly tolerances of load sensor ※ Availability of retarder depends on default load
24	S.C. to ground or O.C. at load sensor input The measured voltage is too low: <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Cable has no connection to TCU • Load sensor has as internal defect • Connector pin is contacted to vehicle ground or is broken 	Retarder function is affected TCU use default load OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the load sensor • Check the assembly tolerances of load sensor ※ Availability of retarder depends on default load
25	S.C. to battery voltage or O.C. at transmission sump temperature sensor input The measured voltage is too high: <ul style="list-style-type: none"> • Cable is defective and is contacted to battery voltage • Cable has no connection to TCU • Temperature sensor has an internal defect • Connector pin is contacted to battery voltage or is broken 	No reaction, TCU use default temperature OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the temperature sensor
26	S.C. to battery voltage or O.C. at transmission sump temperature sensor input The measured voltage is too low: <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Temperature sensor has an internal defect • Connector pin is contacted to vehicle ground 	No reaction, TCU uses default temperature OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the temperature sensor
27	S.C. to battery voltage or O.C. at retarder temperature sensor input The measured voltage is too high: <ul style="list-style-type: none"> • Cable is defective and is contacted to battery voltage • Cable has no connection to TCU • Temperature sensor has an internal defect • Connector pin is contacted to battery voltage or is broken 	No reaction, TCU uses default temperature OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the temperature sensor

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
28	S.C. to ground at retarder temperature sensor input The measured voltage is too low: <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Temperature sensor has an internal defect • Connector pin is contacted to vehicle ground 	No reaction, TCU uses default temperature OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the temperature sensor
29	S.C. to battery voltage or O.C. at converter output temperature sensor input The measured voltage is too high: <ul style="list-style-type: none"> • Cable is defective and is contacted to battery voltage • Cable has no connection to TCU • Temperature sensor has an internal defect • Connector pin is contacted to battery voltage or is broken 	No reaction, TCU uses default temperature OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the temperature sensor
30	S.C. to ground at converter output temperature sensor input The measured voltage is too low: <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Temperature sensor has an internal defect • Connector pin is contacted to vehicle ground 	No reaction, TCU uses default temperature OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the temperature sensor
31	S.C. to battery voltage or O.C. at engine speed input TCU measures a voltage higher than 7.00V at speed input pin <ul style="list-style-type: none"> • Cable is defective and is contacted to battery voltage • Cable has no connection to TCU • Speed sensor has an internal defect • Connector pin is contacted to battery voltage or has no contact 	OP mode : Substitute clutch control	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor
32	S.C. to ground at engine speed input TCU measures a voltage less than 0.45V at speed input pin <ul style="list-style-type: none"> • Cable/connector is defective and is contacted to vehicle ground • Speed sensor has an internal defect 	OP mode : Substitute clutch control	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
33	Logical error at engine speed input TCU measures a engine speed over a threshold and the next moment the measured speed is zero <ul style="list-style-type: none"> • Cable/connector is defective and has bad contact • Speed sensor has an internal defect • Sensor gap has the wrong size 	OP mode : Substitute clutch control	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor • Check the sensor gap ※ This fault is reset after power up of TCU
34	S.C. to battery voltage or O.C. at turbine speed input TCU measures a voltage higher than 7.00V at speed input pin <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle battery voltage • Cable has no connection to TCU • Speed sensor has an internal defect • Connector pin is contacted to battery voltage or has no contact 	OP mode : Substitute clutch control If a failure is existing at output speed, TCU shifts to neutral OP mode : Limp home	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor
35	S.C. to ground at turbine speed input TCU measures a voltage less than 0.45V at speed input pin <ul style="list-style-type: none"> • Cable/connector is defective and is contacted to vehicle ground • Speed sensor has an internal defect 	OP mode : Substitute clutch control If a failure is existing at output speed, TCU shifts to neutral OP mode : Limp home	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor ※ This fault is reset after power up of TCU
36	Logical error at turbine speed input TCU measures a turbine speed over a threshold and at the next moment the measured speed is zero <ul style="list-style-type: none"> • Cable/connector is defective and has bad contact • Speed sensor has an internal defect • Sensor gap has the wrong size 	OP mode : Substitute clutch control If a failure is existing at output speed, TCU shifts to neutral OP mode : Limp home	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor • Check the sensor gap
37	S.C. to battery voltage or O.C. at internal speed input TCU measures a voltage higher than 7.00V at speed input pin <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle battery voltage • Cable has no connection to TCU • Speed sensor has an internal defect • Connector pin is contacted to battery voltage or has no contact 	OP mode : Substitute clutch control	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor
38	S.C. to ground at turbine speed input TCU measures a voltage less than 0.45V at speed input pin <ul style="list-style-type: none"> • Cable/connector is defective and is contacted to vehicle ground • Speed sensor has an internal defect 	OP mode : Substitute clutch control	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
39	Logical error at internal speed input TCU measures a internal speed over a threshold and at the next moment the measured speed is zero <ul style="list-style-type: none"> • Cable/connector is defective and has bad contact • Speed sensor has an internal defect • Sensor gap has the wrong size 	OP mode : Substitute clutch control	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor • Check the sensor gap ※ This fault is reset after power up of TCU
3A	S.C. to battery voltage or O.C. at output speed input TCU measures a voltage higher than 12.5V at speed input pin <ul style="list-style-type: none"> • Cable is defective and is contacted to battery voltage • Cable has no connection to TCU • Speed sensor has an internal defect • Connector pin is contacted to battery voltage or has no contact 	Special mode for gear selection OP mode : Substitute clutch control If a failure is existing at turbine speed, TCU shifts to neutral OP mode : lamp home	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor
3B	S.C. to ground at output speed input TCU measures a voltage less than 1.00V at speed input pin <ul style="list-style-type: none"> • Cable/connector is defective and is contacted to vehicle ground • Speed sensor has an internal defect 	Special mode for gear selection OP mode : Substitute clutch control If a failure is existing at turbine speed, TCU shifts to neutral OP mode : lamp home	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor
3C	Logical error at output speed input TCU measures a turbine speed over a threshold and at the next moment the measured speed is zero <ul style="list-style-type: none"> • Cable/connector is defective and has bad contact • Speed sensor has an internal defect • Sensor gap has the wrong size 	Special mode for gear selection OP mode : Substitute clutch control If a failure is existing at turbine speed, TCU shifts to neutral OP mode : lamp home	<ul style="list-style-type: none"> • Check the cable from TCU to the sensor • Check the connectors • Check the speed sensor • Check the sensor gap ※ This fault is reset after power up of TCU
3D	Turbine speed zero doesn't fit to other speed signals	-	※ Not used
3E	Output speed zero doesn't fit to other speed signals If transmission is not neutral and the shifting has finished, TCU measures output speed zero and turbine speed or internal speed not equal to zero. <ul style="list-style-type: none"> • Speed sensor has an internal defect • Sensor gap has the wrong size 	Special mode for gear selection OP mode : Substitute clutch control If a failure is existing at turbine speed, TCU shifts to neutral OP mode : lamp home	<ul style="list-style-type: none"> • Check the sensor signal of output speed sensor • Check the sensor gap of output speed sensor • Check the cable from TCU to the sensor ※ This fault is reset after power up of TCU

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
71	S.C. to battery voltage at clutch K1 The measured resistance value of the valve is out of limit, the voltage at K1 valve is too high <ul style="list-style-type: none"> • Cable/connector is defective and has contact to battery voltage • Cable/connector is defective and has contact to another regulator output of the TCU • Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check the cable from TCU to the gearbox • Check the connectors from TCU to the gearbox • Check the regulator resistance* • Check internal wire harness of the gearbox * See page 3-36
72	S.C. to ground at clutch K1 The measured resistance value of the valve is out of limit, the voltage at K1 valve is too low <ul style="list-style-type: none"> • Cable/connector is defective and has contact to vehicle ground • Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check the cable from TCU to the gearbox • Check the connectors from gearbox to TCU • Check the regulator resistance* • Check internal wire harness of the gearbox * See page 3-36
73	O.C. at clutch K1 The measured resistance value of the valve is out of limit <ul style="list-style-type: none"> • Cable/connector is defective and has no contact to TCU • Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check the cable from TCU to the gearbox • Check the connectors from gearbox to TCU • Check the regulator resistance* • Check internal wire harness of the gearbox * See page 3-36
74	S.C. to battery voltage at clutch K2 The measured resistance value of the valve is out of limit, the voltage at K2 valve is too high <ul style="list-style-type: none"> • Cable/connector is defective and has contact to battery voltage • Cable/connector is defective and has contact to another regulator output of the TCU • Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check the cable from TCU to the gearbox • Check the connectors from gearbox to TCU • Check the regulator resistance* • Check internal wire harness of the gearbox * See page 3-36
75	S.C. to ground at clutch K2 The measured resistance value of the valve is out of limit, the voltage at K2 valve is too low <ul style="list-style-type: none"> • Cable/connector is defective and has contact to vehicle ground • Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check the cable from TCU to the gearbox • Check the connectors from gearbox to TCU • Check the regulator resistance* • Check internal wire harness of the gearbox * See page 3-36
76	O.C. at clutch K2 The measured resistance value of the valve is out of limit <ul style="list-style-type: none"> • Cable/connector is defective and has no contact to TCU • Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check the cable from TCU to the gearbox • Check the connectors from gearbox to TCU • Check the regulator resistance* • Check internal wire harness of the gearbox * See page 3-36

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
77	S.C. to battery voltage at clutch K3 The measured resistance value of the valve is out of limit, the voltage at K3 valve is too high <ul style="list-style-type: none"> • Cable/connector is defective and has contact to battery voltage • Cable/connector is defective and has contact to another regulator output of the TCU • Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check the cable from TCU to the gearbox • Check the connectors from gearbox to TCU • Check the regulator resistance* • Check internal wire harness of the gearbox * See page 3-36
78	S.C. to ground at clutch K3 The measured resistance value of the valve is out of limit, the voltage at K3 valve is too low <ul style="list-style-type: none"> • Cable/connector is defective and has contact to vehicle ground • Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check the cable from TCU to the gearbox • Check the connectors from gearbox to TCU • Check the regulator resistance* • Check internal wire harness of the gearbox * See page 3-36
79	O.C. at clutch K2 The measured resistance value of the valve is out of limit <input type="checkbox"/> Cable/connector is defective and has no contact to TCU <input type="checkbox"/> Regulator has an internal defect	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check the cable from TCU to the gearbox • Check the connectors from gearbox to TCU • Check the regulator resistance* • Check internal wire harness of the gearbox * See page 3-36
7A	S.C. to battery voltage at converter clutch	-	-
7B	S.C. to ground at converter clutch	-	-
7C	O.C. at converter clutch	-	※ Not used
7D	S.C. ground at engine derating device <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Engine derating device has an internal defect • Connector pin is contacted to vehicle ground 	Engine derating will be on until TCU power down even if fault vanishes(Loose connection) OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the engine derating device • Check the connectors from engine derating device to TCU • Check the resistance* of engine derating device ※ Not used * See page 3-36
7E	S.C. battery voltage at engine derating device <ul style="list-style-type: none"> • Cable/connector is defective and is contacted to battery voltage • Engine derating device has an internal defect 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the engine derating device • Check the connectors from backup alarm device to TCU • Check the resistance* of backup alarm device * See page 3-36

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
7F	O.C. at engine derating device TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> · Cable is defective and has no connection to TCU · Engine derating device has an internal defect · Connector has no connection to TCU 	No reaction OP mode : Normal	<ul style="list-style-type: none"> · Check the cable from TCU to the engine derating device · Check the connectors from engine derating device to TCU · Check the resistance* of engine derating device * See page 3-36
85	S.C. to ground at clutch KV The measured resistance value of the valve is out of limit, the voltage at K4 valve is too low <ul style="list-style-type: none"> · Cable/connector is defective and has contact to vehicle ground · Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> · Check the cable from TCU to the gearbox · Check the connectors from gearbox to TCU · Check the regulator resistance* · Check internal wire harness of the gearbox * See page 3-36
86	O.C. at clutch KV The measured resistance value of the valve is out of limit <ul style="list-style-type: none"> · Cable/connector is defective and has contact to TCU · Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> · Check the cable from TCU to the gearbox · Check the connectors from gearbox to TCU · Check the regulator resistance* · Check internal wire harness of the gearbox * See page 3-36
87	S.C. to battery voltage at clutch KR The measured resistance value of the valve is out of limit, the voltage at KR valve is too high <ul style="list-style-type: none"> · Cable/connector is defective and has contact to battery voltage · Cable/connector is defective and has contact to another regulator output of the TCU · Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> · Check the cable from TCU to the gearbox · Check the connectors from gearbox to TCU · Check the regulator resistance* · Check internal wire harness of the gearbox * See page 3-36

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
88	S.C. to ground at clutch KR The measured resistance value of the valve is out of limit, the voltage at KR valve is too low <ul style="list-style-type: none"> · Cable/connector is defective and has contact to vehicle ground · Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> · Check the cable from TCU to the gearbox · Check the connectors from gearbox to TCU · Check the regulator resistance* · Check internal wire harness of the gearbox * See page 3-36
89	O.C. at clutch KR The measured resistance value of the valve is out of limit <ul style="list-style-type: none"> · Cable/connector is defective and has no contact to TCU · Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> · Check the cable from TCU to the gearbox · Check the connectors from gearbox to TCU · Check the regulator resistance* · Check internal wire harness of the gearbox * See page 3-36
91	S.C. to ground at relay reverse warning alarm TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground <ul style="list-style-type: none"> · Cable is defective and is contact to vehicle ground · Backup alarm device has an internal defect · Connector pin is contacted to vehicle ground 	Backup alarm will be on until TCU power down even if fault vanishes(Loose connection) OP mode : Normal	<ul style="list-style-type: none"> · Check the cable from TCU to the backup alarm device · Check the connectors from backup alarm device to TCU · Check the resistance* of backup alarm device * See page 3-36
92	S.C. to battery voltage at relay reverse warning alarm TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage <ul style="list-style-type: none"> · Cable is defective and is contacted to battery voltage · Backup alarm device has an internal defect · Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	<ul style="list-style-type: none"> · Check the cable from TCU to the backup alarm device · Check the connectors from backup alarm device to TCU · Check the resistance* of backup alarm device * See page 3-36

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
93	O.C. at relay reverse warning alarm TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU • Backup alarm device has an internal defect • Connector has no connection to TCU 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the backup alarm device • Check the connectors from backup alarm device to TCU • Check the resistance* of backup alarm device * See page 3-36
94	S.C. to ground at relay starter interlock TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground <ul style="list-style-type: none"> • Cable is defective and is connection to vehicle ground • Starter interlock relay has an internal defect • Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the starter interlock relay • Check the connectors from starter interlock relay to TCU • Check the resistance* of starter interlock relay * See page 3-36
95	S.C. to battery voltage at relay starter interlock TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage <ul style="list-style-type: none"> • Cable is defective and has no connection to battery voltage • Starter interlock relay has an internal defect • Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the starter interlock relay • Check the connectors from starter interlock relay to TCU • Check the resistance* of starter interlock relay * See page 3-36
96	O.C. at relay starter interlock TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU • Starter interlock relay has an internal defect • Connector has no connection to TCU 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the starter interlock relay • Check the connectors from starter interlock relay to TCU • Check the resistance* of starter interlock relay * See page 3-36

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
97	S.C. to ground at park brake solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground <ul style="list-style-type: none"> • Cable is defective and is connection to vehicle ground • Park brake solenoid has an internal defect • Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the park brake solenoid • Check the connectors from park brake solenoid to TCU • Check the resistance* of park brake solenoid * See page 3-36
98	S.C. to battery voltage at park brake solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage <ul style="list-style-type: none"> • Cable is defective and is connection to battery voltage • Park brake solenoid has an internal defect • Connector pin is contacted to battery voltage 	No reaction Optional : (Some customers) TCU shifts to neutral caused by park brake feed back OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the park brake solenoid • Check the connectors from park brake solenoid to TCU • Check the resistance* of park brake solenoid * See page 3-36
99	O.C. at park brake solenoid TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU • Park brake solenoid has an internal defect • Connector has no connection to TCU 	No reaction Optional : Some customers TCU shifts to neutral caused by park brake feed back OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the park brake solenoid • Check the connectors from park brake solenoid to TCU • Check the resistance* of park brake solenoid * See page 3-36
9A	S.C. to ground at converter lock up clutch solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Converter clutch solenoid has an internal defect • Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the converter clutch solenoid • Check the connectors from converter clutch solenoid to TCU • Check the resistance* of park brake solenoid * See page 3-36
9B	O.C. at converter lock up clutch solenoid TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU • Converter clutch solenoid has an internal defect • Connector has no connection to TCU 	Converter clutch always open, retarder not available OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the converter clutch solenoid • Check the connectors from converter clutch solenoid to TCU • Check the resistance* of park brake solenoid * See page 3-36

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
9C	S.C. to battery voltage at converter lock up clutch solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage <ul style="list-style-type: none"> · Cable is defective and has no contacted to battery voltage · Converter clutch solenoid has an internal defect · Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	<ul style="list-style-type: none"> · Check the cable from TCU to the converter clutch solenoid · Check the connectors from converter clutch solenoid to TCU · Check the resistance* of converter clutch solenoid * See page 3-36
9D	S.C. to ground at retarder solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground <ul style="list-style-type: none"> · Cable is defective and is contacted to vehicle ground · Retarder solenoid has an internal defect · Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	<ul style="list-style-type: none"> · Check the cable from TCU to the retarder solenoid · Check the connectors from retarder solenoid to TCU · Check the resistance* of retarder solenoid * See page 3-36
9E	O.C. at retarder solenoid TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> · Cable is defective and has no connection to TCU · Retarder solenoid has an internal defect · Connector has no connection to TCU 	No reaction OP mode : Normal	<ul style="list-style-type: none"> · Check the cable from TCU to the retarder solenoid · Check the connectors from retarder solenoid to TCU · Check the resistance* of retarder solenoid * See page 3-36
9F	S.C. to battery voltage at retarder solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage <ul style="list-style-type: none"> · Cable is defective and has no connection to battery voltage · Retarder solenoid has an internal defect · Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	<ul style="list-style-type: none"> · Check the cable from TCU to the retarder solenoid · Check the connectors from retarder solenoid to TCU · Check the resistance* of retarder solenoid * See page 3-36

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
A1	S.C. to ground at difflock or axle connection solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Difflock solenoid has an internal defect • Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the difflock solenoid • Check the connectors from difflock solenoid to TCU • Check the resistance* of difflock solenoid * See page 3-36
A2	S.C. to battery voltage at difflock or axle connection solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage <ul style="list-style-type: none"> • Cable is defective and has no connection to battery voltage • Difflock solenoid has an internal defect • Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the difflock solenoid • Check the connectors from difflock solenoid to TCU • Check the resistance* of difflock solenoid * See page 3-36
A3	O.C. at difflock or axle connection solenoid TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU • Difflock solenoid has an internal defect • Connector has no connection to TCU 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the difflock solenoid • Check the connectors from difflock solenoid to TCU • Check the resistance* of difflock solenoid * See page 3-36
A4	S.C. to ground at warning signal output TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Warning device has an internal defect • Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the warning device • Check the connectors from warning device to TCU • Check the resistance* of warning device * See page 3-36
A5	O.C. voltage at warning signal output TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU • Warning device has an internal defect • Connector has no connection to TCU 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the warning device • Check the connectors from warning device to TCU • Check the resistance* of warning device * See page 3-36
A6	S.C. to battery voltage at warning signal output TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage <ul style="list-style-type: none"> • Cable is defective and has is contacted to battery voltage • Warning device has an internal defect • Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the warning device • Check the connectors from warning device to TCU • Check the resistance* of warning device * See page 3-36

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
B1	Slippage at clutch K1 TCU calculates a differential speed at closed clutch K1. If this calculated value is out of range, TCU interprets this as slipping clutch <ul style="list-style-type: none"> • Low pressure at clutch K1 • Low main pressure • Wrong signal at internal speed sensor • Wrong signal at output speed sensor • Wrong size of the sensor gap • Clutch is defective 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check pressure at clutch K1 • Check main pressure in the system • Check sensor gap at internal speed sensor • Check sensor gap at output speed sensor • Check signal at internal speed sensor • Check signal at output speed sensor • Replace clutch
B2	Slippage at clutch K2 TCU calculates a differential speed at closed clutch K2. If this calculated value is out of range, TCU interprets this as slipping clutch <ul style="list-style-type: none"> • Low pressure at clutch K2 • Low main pressure • Wrong signal at internal speed sensor • Wrong signal at output speed sensor • Wrong size of the sensor gap • Clutch is defective 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check pressure at clutch K2 • Check main pressure in the system • Check sensor gap at internal speed sensor • Check sensor gap at output speed sensor • Check signal at internal speed sensor • Check signal at output speed sensor • Replace clutch
B3	Slippage at clutch K3 TCU calculates a differential speed at closed clutch K3. If this calculated value is out of range, TCU interprets this as slipping clutch <ul style="list-style-type: none"> • Low pressure at clutch K3 • Low main pressure • Wrong signal at internal speed sensor • Wrong signal at output speed sensor • Wrong size of the sensor gap • Clutch is defective 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check pressure at clutch K3 • Check main pressure in the system • Check sensor gap at internal speed sensor • Check sensor gap at output speed sensor • Check signal at internal speed sensor • Check signal at output speed sensor • Replace clutch

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
B5	Slippage at clutch KV TCU calculates a differential speed at closed clutch KV. If this calculated value is out of range, TCU interprets this as slipping clutch <ul style="list-style-type: none"> Low pressure at clutch KV Low main pressure Wrong signal at internal speed sensor Wrong signal at turbine speed sensor Wrong size of the sensor gap Clutch is defective 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> Check pressure at clutch KV Check main pressure in the system Check sensor gap at internal speed sensor Check sensor gap at turbine speed sensor Check signal at internal speed sensor Check signal at turbine speed sensor Replace clutch
B6	Slippage at clutch KR TCU calculates a differential speed at closed clutch KR. If this calculated value is out of range, TCU interprets this as slipping clutch <ul style="list-style-type: none"> Low pressure at clutch KR Low main pressure Wrong signal at internal speed sensor Wrong signal at turbine speed sensor Wrong size of the sensor gap Clutch is defective 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> Check pressure at clutch KR Check main pressure in the system Check sensor gap at internal speed sensor Check sensor gap at turbine speed sensor Check signal at internal speed sensor Check signal at turbine speed sensor Replace clutch
B7	Overtemp sump TCU measured a temperature in the oil sump that is over the allowed threshold.	No reaction OP mode : Normal	<ul style="list-style-type: none"> Cool down machine Check oil level Check temperature sensor
B8	Overtemp retarder TCU measured a temperature in the retarder oil that is over the allowed threshold	TCU disables retarder OP mode : Normal	<ul style="list-style-type: none"> Cool down machine Check oil level Check temperature sensor
B9	Overspend engine	Retarder applies OP mode : Normal	-
BA	Differential pressure oil filter TCU measured a voltage at differential pressure switch out of the allowed range <ul style="list-style-type: none"> Oil filter is polluted Cable/connector is broken or cable/connector is contacted to battery voltage or vehicle ground Differential pressure switch is defective 	No reaction OP mode : Normal	<ul style="list-style-type: none"> Check oil filter Check wiring from TCU to differential pressure switch Check differential pressure switch(Measure resistance)

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
BB	Slippage at converter lockup clutch TCU calculates a differential speed at closed converter lockup clutch. If this calculated value is out of range, TCU interprets this as slipping clutch <ul style="list-style-type: none"> • Low pressure at converter lockup clutch • Low main pressure • Wrong signal at engine speed sensor • Wrong signal at turbine speed sensor • Wrong size of the sensor gap • Clutch is defective 	-	<ul style="list-style-type: none"> • Check pressure at converter lockup clutch • Check main pressure in the system • Check sensor gap at engine speed sensor • Check sensor gap at turbine speed sensor • Check signal at engine speed sensor • Check signal at turbine speed sensor • Replace clutch
BD	S.C. to ground at engine brake solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Engine brake solenoid has an internal defect • Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to engine brake solenoid • Check the connectors from engine brake solenoid to TCU • Check the resistance* of engine brake solenoid * See page 3-36
BE	S.C. to battery voltage at engine brake TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage <ul style="list-style-type: none"> • Cable is defective and is contacted to battery voltage • Engine brake solenoid has an internal defect • Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the engine brake solenoid • Check the connectors from engine brake solenoid to TCU • Check the resistance* of engine brake solenoid * See page 3-36
BF	O.C. at engine brake TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU • Engine brake solenoid has an internal defect • Connector has no connection to TCU 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the engine brake solenoid • Check the connectors from engine brake solenoid to TCU • Check the resistance* of engine brake solenoid * See page 3-36

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
C3	Overtmp converter output TCU measured a oil temperature at the converter output that is the allowed threshold	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Cool down machine • Check oil level • Check temperature sensor
C4	S.C. to ground at joystick status indicator TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground <ul style="list-style-type: none"> • Cable is defective and is contacted to vehicle ground • Joystick status indicator has an internal defect • Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to joystick status indicator • Check the connectors from joystick status indicator to TCU • Check the resistance* of joystick status indicator * See page 3-36
C5	S.C. to battery voltage at joystick status indicator TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage <ul style="list-style-type: none"> • Cable is defective and is contacted to battery voltage • Joystick status indicator has an internal defect • Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to joystick status indicator • Check the connectors from joystick status indicator to TCU • Check the resistance* of joystick status indicator * See page 3-36
C6	O.C. at joystick status indicator TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU • Joystick status indicator has an internal defect • Connector pin has no connection to TCU 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to joystick status indicator • Check the connectors from joystick status indicator to TCU • Check the resistance* of joystick status indicator * See page 3-36


Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
D1	S.C. to battery voltage at power supply for sensors TCU measures more than 6V at the pin AU1 (5V sensor supply)	See fault codes No.21 to 2C	<ul style="list-style-type: none"> • Check cables and connectors to sensors, which are supplied from AU1 • Check the power supply at the pin AU1 (Should be appx. 5V) ※ Fault codes No.21 to No.2C may be reaction of this fault
D2	S.C. to ground at power supply for sensors TCU measures less than 4V at the pin AU1 (5V sensor supply)	See fault codes No.21 to 2C	<ul style="list-style-type: none"> • Check cables and connectors to sensors, which are supplied from AU1 • Check the power supply at the pin AU1 (Should be appx. 5V) ※ Fault codes No.21 to No.2C may be reaction of this fault
D3	Low voltage at battery Measured voltage at power supply is lower than 18V(24V device)	Shift to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check power supply battery • Check cables from batteries to TCU • Check connectors from batteries to TCU
D4	High voltage at battery Measured voltage at power supply is higher than 32.5V(24V device)	Shift to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check power supply battery • Check cables from batteries to TCU • Check connectors from batteries to TCU
D5	Error at valve power supply VPS1 TCU switched on VPS1 and measured VPS1 is off or TCU switched off VPS1 and measured VPS1 is still on <ul style="list-style-type: none"> • Cable or connectors are defect and are contacted to battery voltage • Cable or connectors are defect and are contacted to vehicle ground • Permanent power supply KL30 missing • TCU has an internal defect 	Shift to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check fuse • Check cables from gearbox to TCU • Check connectors from gearbox to TCU • Replace TCU
D6	Error at valve power supply VPS2 TCU switched on VPS2 and measured VPS2 is off or TCU switched off VPS2 and measured VPS2 is still on <ul style="list-style-type: none"> • Cable or connectors are defect and are contacted to battery voltage • Cable or connectors are defect and are contacted to vehicle ground • Permanent power supply KL30 missing • TCU has an internal defect 	Shift to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check fuse • Check cables from gearbox to TCU • Check connectors from gearbox to TCU • Replace TCU

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
E1	S.C. battery voltage at speedometer output	-	※ Not used
E2	S.C. to ground or O.C at speedometer output	-	※ Not used
E3	S.C. to battery voltage at display output TCU sends data to the display and measures always a high voltage level on the connector <ul style="list-style-type: none"> • Cable or connectors are defective and are contacted to battery voltage • Display has an internal defect 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the display • Check the connectors at the display • Change display
E4	S.C. to ground at display output TCU sends data to the display and measures always a high voltage level on the connector <ul style="list-style-type: none"> • Cable or connectors are defective and are contacted to battery voltage • Display has an internal defect 	No reaction OP mode : Normal	<ul style="list-style-type: none"> • Check the cable from TCU to the display • Check the connectors at the display • Change display
E5	Communication failure on DeviceNet	Shift to neutral OP mode : TCU shutdown	<ul style="list-style-type: none"> • Check Omron master • Check wire of DeviceNet-Bus • Check cable to Omron master
E5	DISPID1 timeout Timeout of CAN-massage DISPID1 from display controller <ul style="list-style-type: none"> • Interference on CAN-Bus • CAN wire/connector is defective • Can wire/connector is defective and has contact to vehicle ground or battery voltage 	TCU select parameter set with ID0 OP mode : Limp home	<ul style="list-style-type: none"> • Check display controller • Check wire of CAN-Bus • Check cable display controller

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
F1	General EEPROM fault TCU can't read non volatile memory · TCU is defective	No reaction OP mode : Normal	· Replace TCU ※ Often shown together with fault code F2
F2	Configuration lost TCU has lost the correct configuration and can't control the transmission · Interference during saving data on non volatile memory · TCU is brand new or from another vehicle	Transmission stay neutral OP mode : TCU shutdown	· Reprogram the correct configuration for the vehicle (e.g. with cluster controller,...)
F3	Application error Something of this application is wrong	Transmission stay neutral OP mode : TCU shutdown	· Replace TCU ※ This fault occurs only if an test engineer did something wrong in the application of the vehicle
F5	Clutch failure AEB was not able to adjust clutch filling parameters · One of the AEB-Values is out of limit	Transmission stay neutral OP mode : TCU shutdown	· Check clutch ※ TCU shows also the affected clutch on the display
F6	Clutch adjustment data lost TCU was not able to read correct clutch adjustment parameters · Interference during saving data on non volatile memory · TCU is brand new	No reaction, Default values : 0 for AEB Offsets used OP mode : Normal	· Execute AEB

(5) Measuring of resistance at actuator/sensor and cable


① Actuator



76043PT19

Open circuit $R_{12} = R_{1G} = R_{2G} = \infty$
 Short cut to ground $R_{12} = R$; $R_{1G} = 0$, $R_{2G} = R$ or $R_{1G} = R$, $R_{2G} = 0$
 (For S.C. to ground, G is connected to vehicle ground)
 Short cut to battery $R_{12} = R$; $R_{1G} = 0$, $R_{2G} = R$ or $R_{1G} = R$, $R_{2G} = 0$
 (For S.C. to battery, G is connected to battery voltage)

② Cable



76043PT20

Open circuit $R_{12} = R_{1P} = R_{1C} = R_{2P} = R_{2C} = \infty$
 Short cut to ground $R_{12} = 0$; $R_{1C} = R_{2C} = 0$, $R_{1P} = R_{2P} = \infty$
 Short cut to battery $R_{12} = 0$; $R_{1C} = R_{2C} = 0$, $R_{1P} = R_{2P} = 0$

7) ELECTRONIC CONTROL FOR POWER TRANSMISSION

(1) Description of the basic functions

The powershift transmission is equipped with TCU.

- The system is processing the desire of the driver according to the following criteria :
- Gear determination depending on gear selector position, driving speed and load condition.
- Protection from operating error as far as necessary, is possible via electronic protection (programming).
- Protection from over-speeds (on the base of engine and turbine speed).
- Electronic inching.

(2) Automatic calibration of the shifting elements (AEB)

The AEB serves to compensate tolerances (plate clearance and pressure level), which are influencing the filling procedure of the clutches. For each clutch, the correct filling parameters for

- * Period of the rapid - filling time
- * Level of the filling equalizing pressure are defined in a test cycle.

The filling parameters are stored, together with the ABE-program and the driving program in the transmission electronics. Because the electronics will be separately supplied, the AEB-cycle must be started only after the installation of both components in the vehicle, thus ensuring the correct mating (transmission and electronics).

- ※ At any rate, the AEB - cycle must be carried out at the vehicle manufacturer prior to the commissioning of the vehicles.

It is imperative, to respect the following test conditions :

- Shifting position neutral
- Engine in idling speed
- Parking brake applied
- Transmission in operating temperature

- ※ After a replacement of the transmission the electrohydraulic control or the TCU in the vehicle the AEB-cycle must be as well carried out again.

The AEB-cycle continues for about 3 to 4 minutes. The determined filling parameters are stored in the EEPROM of the electronics. In this way, the error message F6 shown on the display will be cancelled also at non - performed AEB.

- ※ For the start of the AEB-cycle there are principally two possibilities :


- ① Start of the AEB by separate tools which are connected on the diagnostic port of the wiring.

Following tools for the AEB start will be offered by the ZF service ;

- Testmann (see Diagnostic systems)
- AEB Starter

Order - No. : ZGAQ-03870

The Special tool developed by the ZF can be used only for the starting of the AEB.



- ② Start AEB by operating elements on the vehicle.

For it a CAN-communication between transmission and vehicle electronics is necessary.

- ※ Due to the operation of the transmission the paper friction linings installed in the ergopower transmissions are settling, i.e. the plate clearance becomes greater. Because these settling appearances can interfere the shifting quality, ZF recommends to repeat the AEB-cycle at the Maintenance intervals.
- ※ The ZF recommends likewise at a reduced shifting quality as first measure to repeat the AEB-cycle.

(3) Inching device


This function is especially suitable for lift trucks. It allows to reduce the driving speed infinitely variable without modification of the engine speed in such a way that driving with a very low speed will be possible. In this way, the driver can move the vehicle very exactly to a determined position. At the same time an important part of the engine power for the output of the hydraulic system is at disposal by the high engine speed.

Operation is carried out by a separate inching pedal, where an angle of rotation sensor is mounted.

By means of the proportional valve technology the TCU regulates the pressure in the driving direction clutch in such a way that the driving speed is adjusted in accordance with the inch rotating angle sensor position. Clutch overloading is avoided thanks to the electronic protection.

4. TRANSMISSION MEASURING POINTS AND CONNECTIONS

The measurement have to be carried out with hot transmission (about 80~95°C)



180D7ETM04

		· Pressure regulator under voltage					Engaged clutch	
Driving direction	Speed	Y2	Y3	Y4	Y5	Y6		
Forward	1		●		●		K1	KV
	2				●	●	KV	K2
	3			●	●		K3	KV
	1	●	●				KR	K1
Reverse	2	●				●	KR	K2
	3	●		●			KR	K3
Neutral								
Engaged clutch		KR	K1	K3	KV	K2		
Position on valve block		E	D	C	B	A		
Consec. No. Of measuring points		55	56	58	53	57		

1) OIL PRESSURE AND TEMPERATURE

Port	Description	Size
51	In front of converter - Opening pressure 11+2 bar	M10 × 1
53	Clutch Forward 16 + 2 bar KV	M10 × 1
55	Clutch reverse 16 + 2 bar KR	M10 × 1
56	Clutch 16 + 2 bar K1	M10 × 1
57	Clutch 16 + 2 bar K2	M10 × 1
58	Clutch 16 + 2 bar K3	M10 × 1
63	Temperature sensor behind the converter	M14 × 1.5
65	System pressure 16 + 2.5 bar	M10 × 1

2) MEASURING POINTS FOR DELIVERY RATES

Port	Description	Size
15	Connection to the oil cooler	M33 × 2
16	Connection from the oil cooler	M33 × 2

3) INDUCTIVE TRANSMITTER - IMPULSE - SPEED SENSOR AND SWITCH


Port	Description	Size
21	Inductive transmitter n Turbine	M18 × 1.5
34	Speed sensor n Output an speedometer	-
47	Inductive transmitter n Central gear train	M18 × 1.5
48	Inductive transmitter n Engine	M18 × 1.5
54	Filter contamination switch	M14 × 1.5

4) CONNECTIONS

Port	Description	Size
10	Breather	-
49	Plug connection on electro-hydraulic control unit	-

5. DRIVE AXLE


1) STRUCTURE 1



250D7EDR02

400	Differential & carrier	413	Hexagon socket screw	428	Sealing ring
401	Drive pinion	414	Hexagon screw	432	Tapered roller bearing
402	Ring gear	415	Tapered roller bearing	433	Thrust washer
403	Differential housing	417	Differential carrier housing	436	Tapered roller bearing
404	Differential housing	418	Hexagon screw	439	Cover
405	Differential spider	419	Setting ring	440	Radial seal ring
406	Differential side gear	420	Setting ring	442	Hexagon socket screw
408	Differential pinion	421	Lock plate	444	Drive flange
409	Disk	422	Hexagon screw	445	Adjusting nut
411	Thrust washer	423	Hexagon screw	572	O-ring
412	Bearing bushing	427	Screw plug	579	Lock pin


2) STRUCTURE 2



250D7EDR03

250	Inner disk	261	Brake housing	274	Screw plug
251	Outer disk	262	O-ring	275	Sealing ring
252	Piston	264	O-ring	278	Bleeding socket
253	Bushing	265	O-ring	279	Sealing ring
254	Hex socket screw	266	Hex socket screw	280	Bleeder valve
255	Disk carrier	267	Hex socket screw	281	Pipe
256	Hex socket screw	269	Hex screw	282	Hexagon screw with flange
258	Gasket	271	Face seal	283	Compression spring
259	Gasket	272	Screw plug		
260	Brake carrier	273	Sealing ring		

3) STRUCTURE 3



250D7EDR04

300 Planetary housing	314 Sun gear	331 Planetary pin
304 O-ring	318 Sleeve	333 Locking pin
305 Screw plug	319 Hexagon socket screw	335 Ring gear
306 Sealing ring	320 Thrust ring	336 Ring gear carrier
307 Screw plug	322 Planetary gear	337 Retainer
308 Sealing ring	324 Thrust washer	338 Hexagon screw
309 Thrust washer	329 Needle bearing	340 O-ring
312 Hexagon socket screw		


4) OPERATION

Both sides of the housing are supported by the frame and the center is mounted on the transmission case through propeller shaft.

The mast is installed on the front of the frame. The final deceleration and differential device built in the housing guarantee accurate rotation and smooth operation.

The power from the transmission is transferred through the pinion, ring gear, differential case, the pinion of the differential device and the side gear to the drive axle shaft by the side gear spline and to the hub and wheel mounted on the shaft by high tension bolts.

6. TIRE AND WHEEL



250D7EAX68

- | | | | | | |
|---|-----------|---|-----------------|---|---------------|
| 1 | Wheel rim | 4 | Side ring | 7 | Harden washer |
| 2 | Tire | 5 | Extension valve | | |
| 3 | Lock ring | 6 | Hub nut | | |

- 1) The tire acts to absorb the shock from the ground surface to the machine, and at the same time they must rotate in contact with the ground to gain the power which drives the machine.
- 2) Various types of tires are available to suit the purpose. Therefore it is very important to select the correct tires for the type of work.

GROUP 2 OPERATION AND MAINTENANCE

1. OPERATION

1) Driving preparation and maintenance

Prior to the commissioning of the transmission, take care that the prescribed oil grade will be filled in with the correct quantity. At the initial filling of the transmission has to be considered that the oil cooler, the pressure filters as well as the pipes must get filled with oil.

According to these cavities, the quantity of oil to be filled in, is greater than at the later oil fillings in the course of the usual maintenance service.

- ※ Because the converter and the oil cooler, installed in the vehicle, as well as the pipes can empty at standstill into the transmission, the **oil level check must be carried out at engine idling speed and operation temperature of the transmission.**

▲ At the oil level check, the vehicle has to be secured against rolling by blocks, articulated vehicles additionally against unintended turning-in.

2) DRIVING AND SHIFTING

(1) Neutral position

Neutral position will be selected via the gear selector.

After the ignition is switched on, the electronics remains in the waiting state. By the position NEUTRAL of the gear selector, the TCU becomes ready for operation.

A gear can be engaged.

(2) Starting

The starting of the engine has always to be carried out in the NEUTRAL POSITION of the gear selector.

For safety reasons it is to recommend to brake the vehicle securely in position with the parking brake prior to start the engine.

After the starting of the engine and the preselection of the driving direction and the gear, the vehicle can be set in motion by acceleration.

At the start off, the converter takes over the function of a master clutch.

On a level road it is possible to start off also in higher gears.

- Upshifting under load.

Upshifting under load will be then realized if the vehicle can continue to accelerate by it.

- Downshifting under load.

Downshifting under load will be then realized if more traction force is needed.

- Upshifting in overrunning condition.

In the overrunning mode, the upshifting will be suppressed by accelerator pedal idling position, if the speed of the vehicle on a downgrade should not be further increased.

- Downshifting in overrunning condition.

Downshifting in overrunning mode will be then carried out if the vehicle should be related.

If the vehicle will be stopped and is standing with running engine and engaged transmission, the engine cannot be stalled. On a level and horizontal roadway it is possible that the vehicle begins to crawl, because the engine is creating at idling speed a slight drag torque via the converter.

It is convenient to brake the vehicle at very stop securely in position with the parking brake. At longer stops, the controller has to be shifted to the NEUTRAL POSITION.

At the start off, the parking brake has to be released. We know from experience that at a converter transmission it might not immediately be noted to have forgotten this quite normal operating step because a converter, due to its high ratio, can easily overcome the braking torque of the parking brake.

Temperature increases in the converter oil as well as overheated brakes will be the consequences to be find out later.

Neutral position of the selector switch at higher vehicle speed (above stepping speed) is not admissible.

Either a suitable gear is to be shifted immediately, or vehicle must be stopped at once.

3) COLD START

At an oil temperature in the shifting circuit $< -12^{\circ}\text{C}$, the transmission must be warmed-up for some minutes.

This must be carried out in neutral with an increased engine speed (about 1500 min^{-1}).

Until this oil temperature is reached, the electronics remains in neutral, and the symbol of the cold start phase will be indicated on the display.

Indication on the display:

After the indication on the display is extinguished, the full driving program can be utilized out of „NEUTRAL“.

4) OIL TEMPERATURE

The oil temperature in the transmission sump is in the electrohydraulic control unit.

The service temperature in the sump of $60^{\circ}\sim 90^{\circ}\text{C}$ must not be exceeded.

By overstepping results by 105°C notice "WS" on the display.

At a trouble-free unit and an adequate driving mode, a higher temperature will not occur.

The notice "WS" results at the display, the vehicle has to be stopped and controlled for external oil loss and the engine must run with a speed of $1200\text{--}1500\text{ min}^{-1}$ at NEUTRAL POSITION of the transmission.

Now, the temperature must drop quickly (in about 2-3 minutes) to normal values. If this is not the case, there is a trouble pending, which must be eliminated prior to continue working.

The monitoring of the oil temperature (behind the converter) is additionally on the temperature gauge which is located on the dashboard.

Operating temperature behind the converter at least 65°C and 100°C in continuous operation, a short-time increase up to max. 120°C is permitted.

The temperature is measured on the measuring point "63" (see schedule of measuring points-3-40)

2. MAINTENANCE

1) TRANSMISSION

(1) Oil level check

▲ At the oil level check, the vehicle has to be secured against rolling with blocks.

The oil level check must be carried out as follows :

- Oil level check (weekly)
- At horizontally standing vehicle
- Transmission in neutral position «N»
- In the cold start phase, the engine must be running about 2~3 minutes at idling speed, and the marking on the oil dipstick must then be lying above the cold start mark «COLD»
- At operating temperature of the transmission (about 80°~90°C)
- At engine idling speed
- Loosen oil dipstick by counter-clock rotation, remove and clean it
- Insert oil dipstick slowly into the oil level tube until contact is obtained, and pull it out again.
- On the oil dipstick, the oil level must be lying in the zone «HOT»
- Insert the oil dipstick again, and tighten it by clockwise rotation

If the oil level has dropped in operating temperature condition below the «HOT» zone, it is absolutely necessary to replenish oil.

An oil level above the «HOT» marking, is leading to a too high oil temperature.

(2) Oil change and filter replacement intervals

※ First oil change after 100 operating hours in service.

Every further oil change after 1000 operating hours in service, however at least once a year.

At every oil change, the fine filter has to be replaced.

① Oil change and oil filling capacity

The oil change has to be carried out as follows. At operating temperature of the transmission, horizontally standing vehicle open the oil drain plug and drain the used oil.

- Clean oil drain plug with magnetic insert and surface on the housing and install again along with O-ring.

- Fill in oil (about 20 liters).

(Sump capacity, external oil capacities e. g. in the heat exchanger, in the lines etc. are depended on the vehicle).

The indicated value is a guide value.

※ It is imperative to pay attention to absolute cleanliness of oil and filter.

Binding is in any case the making on the oil dipstick.

- Start the engine-idling speed

- Transmission in neutral position „N“

- Top up oil up to the marking „COLD“

- Brake the vehicle securely in position and warm up the transmission

- Shift all controller positions through

- Check the oil level once more and top up oil once more if necessary

- On the oil dipstick, the oil level must be lying in the zone „HOT“

- Insert the oil dipstick again and tighten it by clockwise rotation

※ At the initial filling of the transmission has to be considered that the heat exchanger, the pressure filter as well as the pipes must get filled with oil.

According to these cavities, the oil capacity to be filled in is greater than at the later oil fillings in the course of the usual maintenance service.

② Filter replacement

At the replacement of the filter in the main oil stream, pay attention that no dirt or oil sludge can penetrate into the circuit.

At the mounting of the filter, any exertion of force has to be avoided.


※ Treat the filter carefully at the installation, the transport and the storage.

Damaged filters must no more be installed.

The mounting of the filter must be carried out as follows:

- Cover the gasket with a small amount of oil.

- Screw the filter in until contact with the sealing surface is obtained and tighten it now by hand about 1/3 to 1/2 turn.



180D7EPT19


Legend:

1 = Oil filter tube with oil dipstick

2 = Oil drain plug M38 × 1.5

3 = Fine filter

Oil dipstick



180D7EPT20

2) DRIVE AXLE

(1) Important remarks

- ① For safety reasons, the operator should verify and service at regular intervals all of the bolted assemblies and all of the important safety locks such as :
 - Wheel nuts
 - Nuts of axle mounting bolts
 - Bolts on the steering components and the brake system parts : if the screws are tightable, the loctite contact breaks loose and remounting is necessary.
 - Corrosion on the carrier elements (such as the axle spindle) is not acceptable for operational safety reasons.
 - Verify seals, oil levels and lubrication at regular intervals.

② Brakes

- Inspect brake disk regularly as well as wear of brake system parts.
- In case of signs of excessive heating, consult a brake specialist or the manufacturer.

(2) General lubrication instructions

① Lubrication points

See page 3-53 installation drawing.

② Fill levels

Checked at the level control plugs.

③ Oil change

Place the vehicle in a horizontal position. Draining of the oil is to be accomplished only in warm condition. Clean all lubrication points before opening them. On the hub assemblies, the drain plug should be turned downward.

Replacement of the oil draining plugs.

Oil draining

Remove the oil filler plug as well as the oil level control plug on the carrier assembly, and on the planetary assembly. Drain the oil.

Oil filling

Supply oil into oil filler hole until it overflows.

Check the oil level at the oil level plug hole (Overflow control). Wait a few minutes. If the oil level falls, add oil until the level remains constant.

Clean the grease nipples before lubrication.


(3) Lubrication points

※ Legend

1 : Oil fill plug

2 : Oil level control plug

3 : Oil drain plug



3. TROUBLESHOOTING

1) BRAKE LEAKS ACTUATION FLUID

Condition	Possible cause	Correction
Internal leak : Fluid bypasses seals into axle and fills axle with fluid and blows out breather or empties brake fluid reservoir.	<ol style="list-style-type: none">1. Worn or damaged piston seal.2. Melted or extruded piston seals.3. Corrosion, pitting, wear or other damage, marks, scratches to piston and/or brake housing bore in area of seal/sealing lips.	<ol style="list-style-type: none">1. Replace piston seals.2. Correct cause of overheating and replace seals.3. Clean, smooth, rework or replace affected parts.
External leak	<ol style="list-style-type: none">1. Loose bleeder screw.2. Loose inlet fitting or plugs.3. Damaged inlet fitting or plugs or damaged seats.	<ol style="list-style-type: none">1. Tighten bleeder screw to 2.0~2.7 kgf · m (15~20 lb-ft)2. Tighten inlet fitting to 3.4~4.8 kgf · m (25~35 lb-ft)3. Replace inlet fitting or plug and O-ring if used.

2) BRAKE NOISE AND VIBRATION

Condition	Possible cause	Correction
Brakes product noise, chatter, vibration.	Incorrect axle fluid and/or friction material used.	<ol style="list-style-type: none">1. Use only meritor specified or approved materials.2. Drain and flush fluid from axle. Replace with approved fluid.3. Replace all friction discs. Thoroughly clean or replace stationary discs.

3) BRAKE OVERHEATS

Condition	Possible cause	Correction
Overheating due to excessive duty cycle.	Inadequate coolant flow or heat exchange.	1. Install brake cooling system if not already installed on vehicle. 2. Re-analyze and re-size brake cooling system if necessary.
Inadequate coolant flow	Low pump output, blocked filter or coolant lines.	Check pump output at different operating modes. Replace filter and check lines.
Low or no coolant.	1. Improper fill or leaks. 2. Leaking face seal. 3. Loose or damaged plugs. 4. Deteriorated or inadequate sealant used at joint.	1. Check for proper fill level. 2. Replace or reinstall face seal assembly. 3. Tighten drain, fill or forced cooling plug. Replace if damaged. 4. Disassemble, clean, re-seal and re-assemble brake housing joint.
Brake drags.	1. More than 1.4bar(20psi) pressure applies when brakes released. 2. Damaged piston return spring assembly. 3. Piston not returning. 4. Wrong cooling and/or actuation fluid used. 5. Tight or damaged splines (eg. friction disc-to-hub driver).	1. Repair hydraulic system so pressure is less than 1.4bar(20psi) when brakes released and while machine is operating in any mode. 2. Repair or replace piston return spring assembly. 3. Check piston seals and seal separator. 4. Check piston seals and seal separator for swelling or damaged. Replace as necessary. Purge system and use correct fluid. 5. Repair or replace parts.

4) BRAKE DOES NOT APPLY

Condition	Possible cause	Correction
Low or no pressure to brake	1. Empty fluid reservoir. 2. Damaged hydraulic system. 3. Leaked of brake actuation fluid. 4. Parking brake not adjusted properly.	1. Fill reservoir to correct level with specified fluid. 2. Repair hydraulic system. 3. Refer to "Brake leaks actuation fluid" in this section. 4. Adjust parking brake lever as described in assembly of this manual.

5) BRAKE DOES NOT RELEASE

Condition	Possible cause	Correction
Vehicle does not move	Damaged hydraulic system.	Repair hydraulic system.
Brakes dragging	<ol style="list-style-type: none"> 1. More than 1.4bar(20psi) pressure applied when brakes released. 2. Damaged piston return spring assembly. 3. Piston not returning. 4. Wrong cooling and/or actuation fluid used. 5. Parking brake not adjusted properly. 	<ol style="list-style-type: none"> 1. Repair hydraulic system so pressure is less than 1.4bar(20psi) when brakes released and while machine is operating in any mode. 2. Repair or replace piston return spring assembly. 3. Check piston seals for swelling or damage. Replace as necessary. 4. Check piston seals for swelling or damage. Purge system and use specified fluid. 5. Adjust parking brake lever as described in assembly of this manual.

6) BRAKING PERFORMANCE

Condition	Possible cause	Correction
Noticeable change or decrease in stopping performance.	<ol style="list-style-type: none"> 1. Inadequate actuation fluid supply to brakes. 2. Inadequate pressure to apply brakes. 3. Worn or damaged discs. 4. Overheated seals and/or discs. 5. Dirty or contaminated cooling fluid. 	<ol style="list-style-type: none"> 1. Replenish fluid in brake system. Check for leakage and correct cause. 2. Check brakes apply system. Check for leakage in brake system or brakes, and correct cause. 3. Inspect and replace discs if necessary. ※ As disc wear occurs, make sure brake system can supply adequate fluid to fully apply brakes. 4. Inspect and replace discs and seals if necessary. 5. Drain and flush cooling fluid from brakes and entire brake system. Replace with approved fluid. In some cases, it may necessary to replace discs. Clean or replace filter.
Brake does not fully apply.	<ol style="list-style-type: none"> 1. Empty fluid reservoir. 2. Damaged hydraulic system. 3. Leakage of brake actuation fluid. 	<ol style="list-style-type: none"> 1. Fill reservoir to correct level with specified fluid. 2. Repair hydraulic system. 3. Refer to "Brake leaks actuation fluid" in this section.
Brakes fell spongy/soft.	Brakes or brake system not properly bled.	Bleed brakes and brake system.

GROUP 3 DISASSEMBLY AND ASSEMBLY

1. TRANSMISSION DISASSEMBLY


1) ELECTRO-HYDRAULIC CONTROL UNIT AND FINE FILTER

① Fix transmission on assembly truck.

(S) Assembly truck 5870 350 000

(S) Holding fixtures (1) 5870 350 063

(S) Clamping Angle (2) 5870 350 124




180DTM011

(1) Remove oil drain plug and oil filler tube


Drain oil before starting disassembly

① Loosen screw plug (1) and remove seal ring (2).



180DTM012

② Loosen hex screw (1) from tab and hex screws (2) from oil level tube and remove oil level tube (3) with sealing (4).




180DTM013

(2) Dismounting of filter

- ① Separate fine filter (1) from filter head by belt wrench.


(S) Belt wrench 5870 105 005



180DTM014

- ② Loosen torx screws (1), separate filter head (2) from transmission housing and remove O-rings (3).

(S) Socket wrench TX 40 5873 042 004



180DTM015


(3) Dismounting of electric control unit

- ① Dismantle control unit (1).

Loosen torx screws (2).

(S) Socket wrench TX-27 5873 042 002


(S) Adjusting screws M6 5870 204 063



180DTM016

- ② Remove cpl control unit (1) and sealing plate (2).


(S) Adjusting screws M6 5870 204 063



180DTM017


- ③ Remove differential pressure switch for fine filter from the duct plate.

1 = Switch with O-ring
2 = Piston
3 = Compression spring



180DTM018


- ④ Loosen torx screws and separate duct plate (1) and seals (2 and 3) from housing front part.



180DTM019


- ⑤ Pull converter safety valve out of housing hole.

1 = Piston
2 = Compression spring



180DTM020


- ⑥ Mark installation position of wiring harness (1) towards valve block (2).



180DTM021


⑦ Loosen torx screws (1).

(S) Socket wrench TX-27 5873 042 002




180DTM022

⑧ Separate duct plate (1) and sealing plate plate (2) from valve block (3).



180DTM023


⑨ Remove retaining clamp (1).



180DTM024

⑩ Loosen torx screws (1) and remove lid (2).
Remove opposite cover (3) in the same way.


(S) Socket wrench TX-27 5873 042 002



180DTM025


- ⑪ Remove wiring harness (1).

Loosen cyl screws (3), remove fixing plates and dismount pressure controllers (2).



180DTM026


- ⑫ Loosen cyl screws on opposite side, remove fixing plates and dismount pressure controllers (1).



180DTM027

- ⑬ Loosen two torx screws (1) and temporarily fix housing by means of adjusting screws (S).
Then loosen remaining torx screws (Housing is spring-loaded).


(S) Adjusting screws 5870 204 036



180DTM028

- ⑭ Separate housing from valve housing by evenly loosening the adjusting screws.

(S) Adjusting screws 5870 204 036




180DTM029

⑮ Remove single components :

1 = Pressure reducing valve

2 = Vibration damper

3 = Follow-on slide




180DTM030

⑯ Remove single components of the opposite side analogously :

1 = Main pressure valve

2 = Vibration damper

3 = Follow-on slide



180DTM031


2) INDUCTIVE SENSOR, HALL SENSOR, BREATHER AND TEMPERATURE SENSOR

① Dismantle positioned parts.

1 = Breather

2 = Inductive sensor-n central gear chain

3 = Inductive sensor-n turbine



180DTM032

② Dismantle inductive sensor - n engine (1) and temperature sensor (3)


Loosen cyl screw and remove speed sensor (2).

Remove O-ring.

1 = Inductive sensor - n engine (1)

2 = Speed sensor - n output (Hall sensor)

3 = Temperature sensor measuring point "63" after converter



180DTM033

3) ENGINE CONNECTION AND OIL PRESSURE PUMP


(1) Engine connection

Loosen two hex screws (2), fit eye bolts (1) and pull off converter by means of lifting device.

- ① Separate flexplate (3) from converter.


(S) Eye bolts assortment 5870 204 002

(S) Lifting chain 5870 281 047



180DTM034


- ② Loosen threaded connection converter bell-housing/transmission housing and remove converter bell-housing (1).



180DTM035

- ③ Remove O-ring (1).

Loosen threaded connection plate/transmission housing and oil pressure pump/transmission housing, then remove plate (2).




180DTM036

(2) Oil pressure pump

- ① Pull off stator hollow shaft/oil pressure pump by means of puller and lifting device.

(S) Puller


5870 000 107



180DTM037

- ② Remove O-ring (1).

Loosen cylindrical screws (2).



180DTM038

※ Check oil gear pump :


In case of wear marks in the pump housing, cover or on the inner and outer rotor, the complete oil pressure pump is to be replaced.

1 = Cover

2 = Inner rotor


3 = Outer rotor

4 = Pump housing



180DTM039


- ④ Remove shaft seal (1) from the pump housing (2).



180DTM040


4) DISASSEMBLY PTO

- ① Loosen hex screws (1) and remove lid (2).




180DTM041

- ② Take O-ring (1) out of lid, unsnap and remove retaining ring (2).
Pull pump shaft (3) out of housing hole.
Unsnap rectangular ring (4).



180DTM042


- ③ Snap out retaining ring (1) and press ball bearing (2) off the pump shaft.



180DTM043

5) REMOVAL OF INPUT SHAFT AND CLUTCHES

- ① Loosen hex Screws (1), remove disc and O-ring.




180DTM044

- ② Pull-off output flange (1) and remove shaft seal (2).

Force out both cylindrical pins (3).

Loosen threaded connection (4) housing front and rear part.




180DTM045

- ③ Separate housing rear part by means of lifting device.

(S) Lifting chain 5870 281 047

(S) Eye-bolt assortment 5870 204 002



180DTM046

- ④ Dismantle pipes (system pressure from the electro-hydraulic control unit to the corresponding clutch).

Keep the following order to dismantle the pipes :


1 = Pipe K1

2 = Pipe KV

3 = Pipe K3

4 = Pipe K2

5 = Pipe KR




180DTM047

- ⑤ Dismantle bearing outer rings from housing front part.

※ Legend: see figure TM050.

※ If, contrary to the ZF recommendation, the tapered roller bearings of clutches and input are not replaced, it is imperative to ensure the previous pairing (bearing outer ring/bearing inner ring).

※ Bearing outer ring and bearing inner ring must be marked.




180DTM048

- ⑥ Loosen cylinder screws (1), remove upper screen sheet (2) and sleeves.

Remove all rectangular rings (3) from clutches KV, KR, K1, K2, K3, K4 and input shaft.

Remove tubes (4) with O-rings.



180DTM049

- ⑦ Lift clutches out of the housing following the numeric order, as described in the legend.

1 = Clutch K3 / Output

2 = Clutch K2


3 = Clutch K1

4 = Clutch K4 (Intermediate shaft)

5 = Clutch KR


6 = Clutch KV

7 = Input shaft



180DTM050

- ⑧ Loosen and remove cyl screws of suction tube (1) in the housing front part.




180DTM051

⑨ Dismantle bearing outer rings from housing rear part.

※ Legend : see figure TM050.

※ If, contrary to the recommendation, the tapered roller bearings of clutches and input are not replaced, it is imperative to ensure the previous pairing (bearing outer ring/bearing inner ring).


Bearing outer ring and bearing inner ring must be marked.



180DTM052

6) CLUTCHES KV/KR/K1/K2/K3/K4 INPUT SHAFT


- 1 = Clutch K3 / Output
- 2 = Clutch K2
- 3 = Clutch K1
- 4 = Clutch K4 (Intermediate shaft)
- 5 = Clutch KR
- 6 = Clutch KV
- 7 = Input shaft



180DTM050

(1) Clutch KV


- ① Unsnap piston ring (1).



180DTM053

- ② Pull tapered roller bearing (internal ring) off the shaft.


- (S) Forcing device 5870 026 100
- (S) Grab sleeve 5873 001 057
- or
- (S) Rapid grip 5873 011 011



180DTM054

- ③ Unsnap retaining ring (1).


- (S) Set of external pliers 5870 900 015



180DTM055


④ Pull clutch (1) off the shaft.

(S) Two-armed puller 5870 970 004




180DTM056

⑤ Remove snap ring (1).



180DTM057


⑥ Remove end plate (1) and disc package (2) from disc carrier (3).



180DTM058


⑦ Preload compression spring and remove L-ring (1).

(S) Assembly aid 5870 345 088




180DTM059

- ⑧ Remove guide ring (1), compression spring (2) and disc (3).




180DTM060

- ⑨ Lift piston (1) off the disc package by compressed air out of hole, and remove it.



180DTM061


- ⑩ Remove both O-rings (1 and 2).



180DTM062

- ⑪ Pull spur gear off the shaft.


(S) Cut-off device 5870 300 024
(S) Puller 5870 300 033



180DTM063


- ⑫ Unsnap retaining ring (2) out of idler gear (1) and remove ball bearing (3).

(S) Set of internal pliers 5870 900 013



180DTM064

- ⑬ Pull needle cage (1) off the shaft (2).



180DTM065


- ⑭ Pull tapered roller bearing (internal ring) off the shaft.

(S) Forcing device 5870 026 100

(S) Grab sleeve 5873 001 057


or

(S) Rapid grip 5873 011 011



180DTM066


- ⑮ Unsnap piston ring (1).



180DTM067

(2) Clutch KR


- ① Unsnap piston ring (1).



180DTM068

- ② Pull tapered roller bearing (internal ring) off the shaft.


(S) Forcing device 5870 026 100
(S) Grab sleeve 5873 001 059



180DTM069

- ③ Unsnap retaining ring (1).


(S) Set of external pliers 5870 900 015



180DTM070

- ④ Pull clutch (1) together with spur gear off the shaft.


(S) Two-armed puller 5870 970 004



180DTM071


⑤ Pull clutch (1) off the spur gear (2).

※ No further disassembly of spur gear (2) is possible.




180DTM072

⑥ Remove snap ring (1).



180DTM057

⑦ Remove end plate (1) and disc package (2) from disc carrier.




180DTM058

⑧ Preload compression spring and remove L-ring (1).


(S) Assembly aid

5870 345 088




180DTM059

- ⑨ Remove guide ring (1), compression spring (2) and disc (3).




180DTM060

- ⑩ Lift piston (1) off the disc carrier by compressed air out of hole, and remove it.




180DTM061

- ⑪ Remove both O-rings (1 and 2).



180DTM062


- ⑫ Pull off needle cage (1) off the shaft (2).



180DTM073

- ⑬ Unsnap retaining ring (2) from idler gear (1) and dismount ball bearing (3).

(S) Set of internal pliers 5870 900 013



180DTM074


- ⑭ Pull tapered roller bearing (internal ring) off the shaft.

(S) Forcing device 5870 026 100

(S) Grab sleeve 5873 001 057


or

(S) Rapid grip 5873 011 011



180DTM066


- ⑮ Unsnap piston ring (1).



180DTM067

(3) Clutch K1


- ① Unsnap piston ring (1).



180DTM075

- ② Pull tapered roller bearing (internal ring) off the shaft.


(S) Forcing device 5870 026 100
(S) Grab sleeve 5873 001 059



180DTM076


- ③ Unsnap retaining ring (1).

(S) Set of external pliers 5870 900 015




180DTM077

- ④ Remove cpl axial bearing (1) and idler gear (2).



180DTM078


- ⑤ Remove needle cage (1) and cpl axial bearing (2).



180DTM079


- ⑥ Pull clutch (1) off the shaft.

(S) Two-armed puller 5870 970 004




180DTM080

- ⑦ Remove snap ring (1).



180DTM057

- ⑧ Remove end plate (1) and disc package (2) from disc carrier.




180DTM081

- ⑨ Preload cup springs and remove L-ring (1).


(S) Assembly aid

5870 345 088




180DTM059

- ⑩ Remove guide ring (1) and cup spring package (2).




180DTM082

- ⑪ Lift piston (1) off the disc carrier by compressed air out of hole, and remove it.




180DTM061



180DTM062


⑫ Unsnap piston ring (1).



180DTM083

⑬ Pull tapered roller bearing (internal ring) off the shaft.


(S) Basic tool 5873 002 001
(S) Grab sleeve 5873 002 038



180DTM084

(4) Clutch K2


- ① Unsnap piston ring (1).



180DTM085

- ② Pull tapered roller bearing (internal ring) off the shaft.


(S) Forcing device 5870 026 100
(S) Grab sleeve 5873 001 059



180DTM086


- ③ Unsnap retaining ring (1).

(S) Set of external pliers 5870 900 015




180DTM087

- ④ Remove cpl axial bearing (1) and idler gear (2).




180DTM088


- ⑤ Remove needle cage (1) and cpl axial bearing (2).




- ⑥ Pull clutch (1) off the shaft.
(S) Two-armed puller 5870 970 004



- ⑦ Remove snap ring (1).




- ⑧ Remove end plate (1) and disc package (2) from disc carrier.



- ⑨ Preload cup springs and remove L-ring (1).


(S) Assembly aid

5870 345 088




180DTM059

- ⑩ Remove guide ring (1) and cup spring package (2).




180DTM082

- ⑪ Lift piston (1) off the disc carrier by compressed air out of hole, and remove it.




180DTM061

- ⑫ Remove both O-rings (1 and 2).




180DTM062

⑬ Unsnap piston ring (1).




⑭ Pull tapered roller bearing (internal ring) off the shaft.

(S) Forcing device 5870 026 100
(S) Grab sleeve 5873 001 059



(5) Clutch K3


- ① Unsnap piston ring (1).



180DTM094


- ② Pull tapered roller bearing (internal ring) off the shaft.

(S) Forcing device 5870 026 100
(S) Grab sleeve 5873 001 059




180DTM095

- ③ Remove cpl axial bearing (1) and idler gear (2).



180DTM096


- ④ Remove needle cage (1) and cpl axial bearing (2).




180DTM097

⑤ Pull clutch (1) off the shaft.


(S) Two-armed puller 5870 970 004



⑥ Remove snap ring (1).




⑦ Remove end plate (1) and disc package (2) from disc carrier.




⑧ Preload cup springs and remove L-ring (1).

(S) Assembly aid 5870 345 088




- ⑨ Remove guide ring (1) and cup spring package (2).




180DTM082

- ⑩ Lift piston (1) off the disc carrier by compressed air out of hole, and remove it.




180DTM061

- ⑪ Remove both O-rings (1 and 2).



180DTM062

- ⑫ Unsnap piston rings (1).




180DTM098

- ⑬ Pull tapered roller bearing (internal ring) off the shaft.

(S) Basic tool 5873 002 001


(S) Grab sleeve 5873 002 038



180DTM099

(6) Clutch K4 (Intermediate shaft)

① Unsnap piston ring (1).



180DTM100


② Pull tapered roller bearing (internal ring) off the shaft.

(S) Forcing device 5870 026 100

(S) Grab sleeve 5873 001 057


or

(S) Rapid grip 5873 011 011




180DTM101

※ The gear (3) cannot be removed (shrink fit).



180DTM102

③ Unsnap piston rings (1).




180DTM103

- ④ Pull tapered roller bearing (internal ring)
off the shaft.

(S) Forcing device 5870 026 100

(S) Grab sleeve 5873 001 059




180DTM104

(7) Input shaft

- ① Unsnap piston rings (1).

Turbine wheel shaft (2) and drive gear (3) are fixed by means of a snap ring.

※ When separated, the components will be destroyed.



180DTM105


- ② Pull tapered roller bearing (internal ring) off the drive gear.

(S) Basic tool 5873 001 000

(S) Rapid grip 5873 011 014

or

(S) Grab sleeve 5873 001 058




180DTM106

- ③ Pull tapered roller bearing (internal ring) off the drive gear.

(S) Forcing device 5870 026 100

(S) Rapid grip 5873 011 014




180DTM107

7) REASSEMBLY OF CLUTCHES

(1) Clutch KV

- ① Shaft - clutch shaft KV- (1).




180DTM108

- ② Heat up bearing inner ring (app. 120°C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501




180DTM109

- ③ Mount bearing inner ring (1) until contact.

Mount piston ring (2).


▲ Wear protective gloves.

※ Readjust bearing inner ring after cooling down.



180DTM110

- ④ Mount needle cage 60×68×20 (1) on shaft and oil it.




180DTM111

- ⑤ Mount stud bolt (1).

Tightening torque (M10/8.8 × 16)


$$M_A = 1.7 \text{ Nm}$$



180DTM112

- ⑥ Insert ball bearing 55 × 90 × 18 (2) into idler gear (1) until contact is obtained and fix it by means of retaining ring (3) 90 × 3.

(S) Set of internal pliers 5870 900 013




180DTM113

- ⑦ Heat up ball bearing (app. 120°C).

(S) Hot air blower 230 V 5870 221 500


(S) Hot air blower 115 V 5870 221 501



180DTM114

- ⑧ Mount pre-assembled idler gear (1) until contact.

▲ Wear protective gloves.




180DTM115

- ⑨ Insert both O-rings (1 and 2) into piston grooves and oil them.

1 = 75 × 3

2 = 142 × 3


- ※ Check function of the drain valve (see arrow) - there must be no jamming of the ball.



180DTM116

- ⑩ Insert piston (1) into disc carrier.

- ※ Observe installation position, see figure.




180DTM117

- ⑪ Use a hand-operated press to place piston into the disc carrier by means of the assembly aid.

(S) Assembly aid

5870 345 088




180DTM118

- ⑫ Mount inner installer (S) onto the disk carrier.

Install disk (1), compression spring (2), support shim (3) and L-ring (4).

- ※ Installation position support shim and L-ring see figure TM121.

(S) Inner installer → see figure TM120.



180DTM119


- ⑬ Preload compression spring by means of assembly aid (S1) and pressure piece (S2), until L-ring has engaged into the annular groove.

(S) Assembly aid 5870 345 088

(S) Assembly fixture 5870 345 124

(Inner installer and pressure piece)

- ※ It is always necessary to mount a new L-ring.



180DTM120

- ⑭ Disk carrier with piston retraction :

Legend :

1 = Washer

2 = Compression spring


3 = Support shim

4 = L-ring

5 = Disk carrier

6 = Drain valve (piston)

7 = Piston with O-rings



180DTM121

- ⑮ Install outer and inner disks alternately into the disk carrier (4) as personated in figure TM122.

Legend :

1 = Friction disk-coated on one side


(1 pcs)

2 = Outer disks (10 pcs)

3 = Inner disks (10 pcs)


- ※ Take care that the uncoated (blank) side of the friction disk (1) is showing towards the piston.

Number of friction surfaces : 20.




180DTM122

- ⑯ Mount end plate (1) and fix disk package by means of snap ring (2) (e.g. thickness = 2.65 mm / recommended value).



180DTM123

- ⑰ Press on end plate with F (approx. 100 N = 10 kg) and set dial indicator to "zero".




180DTM124

- ⑱ Then press end plate against the snap ring (upwards) and read disk clearance.


※ Disk clearance : 2.65 ~ 2.95 mm

※ In case of deviations, the disk clearance must be corrected with an appropriate snap ring (optional thicknesses = 2.1~4.2 mm).



180DTM125

- ⑲ Heat up clutch inner diameter (approx. 120°C).




180DTM126

- ⑳ Install clutch until contact is obtained.


Mount inner disks onto the inner disk carrier by means of short left/right rotations.

▲ Wear protective gloves.




180DTM127

- ② Fix clutch (1) by means of retaining ring 55×2 (2).



180DTM128

- ② Heat up bearing inner ring (approx. 120°C)



180DTM129


- ② Mount bearing inner ring (1) until contact is obtained.

⚠ Wear protective gloves.

- ※ Adjust bearing inner ring after cooling-down.

Check closing and opening of the clutch by means of compressed air at the hole (see arrow).


Closing and opening of the clutch must be clearly audible.



180DTM130

(2) Clutch KR

- ① Shaft - clutch shaft KR- (1).




180DTM108

- ② Heat up bearing inner ring (app. 120°C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501




180DTM109

- ③ Mount bearing inner ring (1) until contact.

Mount piston ring (2).


▲ Wear protective gloves.

※ Readjust bearing inner ring after cooling down.



180DTM110

- ④ Mount needle cage 60×68×20 (1) on shaft and oil it.




180DTM111

⑤ Mount stud bolt (1).

Tightening torque (M10/8.8×16)

$$M_A = 17 \text{ Nm}$$



180DTM112

⑥ Insert ball bearing 55×90×18 (2) into idler gear (1) until contact is obtained and fix it by means of retaining ring (3) 90×3.

(S) Set of internal pliers 5870 900 013


※ The idler gear (1) is only available as a complete assy in spare parts service.

Consisting of :

1A = Idler gear

1B = Spur gear

1C = Retaining ring 110x4




180DTM131

⑦ Heat up ball bearing (app. 120°C).

(S) Hot air blower 230 V 5870 221 500


(S) Hot air blower 115 V 5870 221 501



180DTM132

⑧ Mount pre-assembled idler gear (1) until contact.

▲ Wear protective gloves.




180DTM133

- ⑨ Insert both O-rings (1 and 2) into piston grooves and oil them.

1 = 75×3

2 = 142×3


- ※ Check function of the drain valve (see arrow) - there must be no jamming of the ball.



180DTM116

- ⑩ Insert piston (1) into disc carrier.

- ※ Observe installation position, see figure.




180DTM117

- ⑪ Use a hand-operated press to place piston into the disc carrier by means of the assembly aid.

(S) Assembly aid

5870 345 088




180DTM118

- ⑫ Mount inner installer (S) onto the disk carrier.

Install disk (1), compression spring (2), support shim (3) and L-ring (4).

- ※ Installation position support shim and L-ring see figure TM121.

(S) Inner installer → see figure TM120.




180DTM119

- ⑬ Preload compression spring by means of assembly aid (S1) and pressure piece (S2), until L-ring has engaged into the annular groove.

(S) Assembly aid 5870 345 088
 (S) Assembly fixture 5870 345 124
 (Inner installer and pressure piece)

※ It is always necessary to mount a new L-ring.




180DTM120

- ⑭ Disk carrier with piston retraction :

Legend :

1 = Washer
 2 = Compression spring
 3 = Support shim
 4 = L-ring
 5 = Disk carrier
 6 = Drain valve (piston)
 7 = Piston with O-rings



180DTM121


- ⑮ Install outer and inner disks alternately into the disk carrier (4) as personated in figure TM122.

Legend :

1 = Friction disk-coated on one side (1 pcs)
 2 = Outer disks (10 pcs)
 3 = Inner disks (10 pcs)


Take care that the uncoated (blank) side of the friction disk (1) is showing towards the piston.

Number of friction surfaces : 20.




180DTM122

- ⑯ Mount end plate (1) and fix disk package by means of snap ring (2) (e.g. thickness = 2.65 mm / recommended value).



180DTM123

- ⑰ Press on end plate with F (approx. 100 N = 10 kg) and set dial indicator to "zero".




180DTM124

- ⑱ Then press end plate against the snap ring (upwards) and read disk clearance.


※ Disk clearance : 2.65 ~ 2.95 mm

※ In case of deviations, the disk clearance must be corrected with an appropriate snap ring (optional thicknesses = 2.1~4.2 mm).



180DTM125

- ⑲ Heat up clutch inner diameter (approx. 120°C).




180DTM126

- ⑳ Install clutch until contact is obtained.


Mount inner disks onto the inner disk carrier by means of short left/right rotations.

▲ Wear protective gloves.




180DTM127

- ② Fix clutch (1) by means of retaining ring 55×2 (2).



180DTM134

- ② Heat up bearing inner ring (approx. 120°C).



180DTM135


- ② Mount bearing inner ring (1) until contact is obtained.

⚠ Wear protective gloves.

※ Adjust bearing inner ring after cooling-down.

Check closing and opening of the clutch by means of compressed air at the hole (see arrow).


Closing and opening of the clutch must be clearly audible.



180DTM136

(3) Clutch K1

- ① Shaft - clutch shaft K1- (1).




180DTM137

- ② Heat up bearing inner ring (app. 120°C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501




180DTM109

- ③ Mount bearing inner ring (1) until contact.

Mount piston ring (2).

▲ Wear protective gloves.

- ※ Readjust bearing inner ring after cooling down.




180DTM110

- ④ Insert both O-rings (1 and 2) into piston grooves and oil them.

1 = 75 × 3

2 = 158 × 3


- ※ Check function of the drain valve (see arrow) - there must be no jamming of the ball.



180DTM116

⑤ Insert piston (1) into disc carrier.


※ Observe installation position, see figure.



180DTM117

⑥ Use a hand-operated press to place piston into the disc carrier by means of the assembly aid.

(S) Assembly aid 5870 345 088




180DTM118

⑦ Mount inner installer (S) onto the disk carrier.

Install cup spring package (1) and L-ring (2).

※ Installation position cup spring package and L-ring see figure TM139.

(S) Inner installer → see figure TM120.



180DTM138


⑧ Preload cup spring package by means of assembly aid (S1) and pressure piece (S2), until L-ring has engaged into the annular groove.

(S) Assembly aid 5870 345 088

(S) Assembly fixture 5870 345 124

(Inner installer and pressure piece)

It is always necessary to mount a new L-ring.



180DTM120

⑨ Disk carrier with piston retraction :


Legend :

1 = Cup spring package

2 = L-ring

3 = Disk carrier

4 = Piston with O-rings



180DTM139


⑩ Install outer and inner clutch discs alternately into disc carrier (4) as described in figure.

Legend :

1 = Friction disc - coated on one side (1pc)

2 = Outer discs (9 pcs)

3 = Inner discs (9 pcs)




180DTM140

※ When mounting the friction disc (1) ensure that its uncoated (bare) side shows towards the piston.

Number of friction surfaces : 18.

⑪ Mount end plate (1) and fix disc package by means of snap ring (2) (e.g. $s = 2.65 \text{ mm}$ / experience value).




180DTM123

⑫ Press on end plate with F (app. 100 N = 10 kg) and set dial indicator to "zero".

(S) Magnetic stand 5870 200 055

(S) Dial indicator 5870 200 057




180DTM124

- ⑬ Then press end plate against snap ring (upwards) and read disc clearance.

※ Disc clearance : 2.35 ~ 2.65 mm

※ Any deviation demands a correction of the disc clearance by a suitable snap ring (optional s = 2.1~4.2 mm).




180DTM125

- ⑭ Heat up internal diameter of clutch (app. 120°C).

(S) Hot air blower 230 V 5870 221 500


(S) Hot air blower 115 V 5870 221 501



180DTM126

- ⑮ Mount clutch (1) until contact is obtained.


▲ Wear protective gloves.



180DTM141


- ⑯ Mount and oil running disc 55×78×5 (1), axial cage (2) and axial washer 55×78×1 (3).

※ Install running disc (1) with chamfer (see arrow) showing towards the axial cage.



180DTM142


- ⑰ Mount needle cage $55 \times 63 \times 64$ (1) on shaft and oil it.



180DTM143

- ⑱ Install idler gear.


Install inner discs on inner disc carrier (idler gear) by shortly rotating them cw/ccw.



180DTM144

- ⑲ Mount and oil axial washer $55 \times 78 \times 1$ (1), axial cage (2) and running disc $55 \times 78 \times 5$ (3).


※ Install running disc (3) with chamfer (see arrow) showing towards the axial cage.



180DTM145

- ⑳ Fix clutch (1) with retaining ring (2) 50×3 .

(S) Set of external pliers 5870 900 015




180DTM146

② Heat up bearing inner ring (app. 120 °C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501



180DTM135

② Mount bearing inner ring (1) until contact.


Mount stud bolt (1).

Tightening torque (M10/8.8 × 16)

$M_A = 17 \text{ Nm}$

▲ Wear protective gloves.


※ Readjust bearing inner ring after cooling down.



180DTM147

※ Check closing and opening of the clutch by means of compressed air at the hole (see arrow).

Closing and opening of the clutch must be clearly audible.




180DTM148

(4) Clutch K2

① Heat up bearing inner ring (app. 120° C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501




180DTM135

② Mount bearing inner ring (1) until contact.

Mount piston ring (2).

▲ Wear protective gloves.

※ Readjust bearing inner ring after cooling down.




180DTM149

③ Insert both O-rings (1 and 2) into piston grooves and oil them.

1 = 75 × 3

2 = 142 × 3


※ Check function of the drain valve (see arrow) - there must be no jamming of the ball.



180DTM116

④ Insert piston (1) into disc carrier.


※ Observe installation position, see figure.



180DTM117

- ⑤ Use a hand-operated press to place piston into the disc carrier by means of the assembly aid.

(S) Assembly aid 5870 345 088




180DTM118

- ⑥ Mount inner installer (S) onto the disk carrier.

Install cup spring package (1) and L-ring (2).

※ Installation position cup spring package and L-ring see figure TM139.

(S) Inner installer → see figure TM120.



180DTM138


- ⑦ Preload cup spring package by means of assembly aid (S1) and pressure piece (S2), until L-ring has engaged into the annular groove.

(S) Assembly aid 5870 345 088

(S) Assembly fixture 5870 345 124

(Inner installer and pressure piece)

※ It is always necessary to mount a new L-ring.



180DTM120

- ⑧ Disk carrier with piston retraction :


Legend :

1 = Cup spring package

2 = L-ring

3 = Disk carrier

4 = Piston with O-rings



180DTM139


- ⑨ Install outer and inner clutch discs alternately into disc carrier (4) as described in figure TM150.

Legend :

- 1 = Friction disc- coated on one side (1 pc)
 2 = Outer discs (7 pcs)
 3 = Inner discs (7 pcs)


- ※ When mounting the friction disc (1) ensure that its uncoated (bare) side shows towards the piston.

Number of friction surfaces : 14



180DTM150


- ⑩ Mount end plate (1) and fix disc package by means of snap ring (2) (e.g. $s = 2.65 \text{ mm}$ / experience value).



180DTM123

- ⑪ Press on end plate with F (app. $100 \text{ N} = 10 \text{ kg}$) and set dial indicator to "zero".


- (S) Magnetic stand 5870 200 055
 (S) Dial indicator 5870 200 057



180DTM124

- ⑫ Then press end plate against snap ring (upwards) and read disc clearance.

- ※ Disc clearance : $1.75 \sim 2.05 \text{ mm}$
 ※ Any deviation demands a correction of the disc clearance by a suitable snap ring (optional $s = 2.1 \sim 4.2 \text{ mm}$).




180DTM125

- ⑬ Heat up internal diameter of clutch (app. 120 °C).

(S) Hot air blower 230 V 5870 221 500


(S) Hot air blower 115 V 5870 221 501



180DTM126

- ⑭ Mount clutch until contact is obtained.


▲ Wear protective gloves.



180DTM151


- ⑮ Mount and oil running disc 55×78×5 (1), axial cage (2) and axial washer 55×78×1 (3).

※ Install running disc (see arrow) with chamfer (see arrow) showing towards the axial cage.



180DTM152


- ⑯ Mount needle cage 55×63×50 (1) on shaft and oil it.



180DTM153

⑰ Install idler gear.


Install inner discs on inner disc carrier (idler gear) by shortly rotating them cw/ccw.



180DTM154

⑱ Mount axial washer 55×78×1 (1), axial cage (2) and running disc 55×78×5 (3) and oil them.


Install running disc (arrow) with chamfer (see arrow) showing towards the axial cage.



180DTM155

⑲ Fix clutch (1) with retaining ring (2) 50×3.

※ (S) Set of external pliers 5870 900 015




180DTM156

⑳ Heat up bearing inner ring (app. 120°C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501



180DTM135

② Mount bearing inner ring (1) until contact.


Mount stud bolt (1).

Tightening torque (M10/8.8 × 16)

$$M_A = 17 \text{ Nm}$$

▲ Wear protective gloves.


※ Readjust bearing inner ring after cooling down.



180DTM157

※ Check closing and opening of the clutch by means of compressed air at the hole (see arrow).

Closing and opening of the clutch must be clearly audible.




180DTM158

(5) Clutch K3

- ① Close machining aperture of the oil supply hole by means of plug (1).

(S) Lever riveting pliers 5870 320 016




180DTM159

- ② Heat up bearing inner ring (app. 120° C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501




180DTM135

- ③ Mount bearing inner ring (1) until contact.

Install rectangular rings 65 × 2 (2).

▲ Wear protective gloves.

※ Readjust bearing inner ring after cooling down.




180DTM160

- ④ Insert both O-rings (1 and 2) into piston grooves and oil them.

1 = 75 × 3

2 = 142 × 3


※ Check function of the drain valve (see arrow) - there must be no jamming of the ball.



180DTM161

⑤ Insert piston (1) into disc carrier.


※ Observe installation position, see figure.



180DTM117

⑥ Use a hand-operated press to place piston into the disc carrier by means of the assembly aid.

(S) Assembly aid 5870 345 088




180DTM118

⑦ Mount inner installer (S) onto the disk carrier.

Install cup spring package (1) and L-ring (2).

Installation position cup spring package and L-ring see figure TM139.

※ (S) Inner installer → see figure TM120.



180DTM138


⑧ Preload cup spring package by means of assembly aid (S1) and pressure piece (S2), until L-ring has engaged into the annular groove.

(S) Assembly aid 5870 345 088

(S) Assembly fixture 5870 345 124

(Inner installer and pressure piece)

※ It is always necessary to mount a new L-ring.



180DTM120

⑨ Disk carrier with piston retraction :


Legend :

1 = Cup spring package

2 = L-ring

3 = Disk carrier

4 = Piston with O-rings



180DTM139

⑩ Install outer and inner clutch discs alternately into disc carrier (4) as described in figure TM150.


Legend :

1 = Friction disc-coated on one side

(1 pc)

2 = Outer discs (7 pcs)

3 = Inner discs (7 pcs)




180DTM150

※ When mounting the friction disc (1) ensure that its uncoated (bare) side shows towards the piston.

Number of friction surfaces : 14.

⑪ Mount end plate (1) and fix disc package by means of snap ring (2) (e.g. $s = 2.65 \text{ mm}$ / experience value).




180DTM123

⑫ Press on end plate with F (app. $100 \text{ N} = 10 \text{ kg}$) and set dial indicator to "zero".

(S) Magnetic stand 5870 200 055

(S) Dial indicator 5870 200 057




180DTM124

- ⑬ Then press end plate against snap ring (upwards) and read disc clearance.

Disc clearance : 1.75 ~ 2.05 mm

Any deviation demands a correction of the disc clearance by a suitable snap ring (optional $s = 2.1 \sim 4.2$ mm).




180DTM125

- ⑭ Heat up internal diameter of clutch (app. 120° C).

(S) Hot air blower 230 V 5870 221 500


(S) Hot air blower 115 V 5870 221 501



180DTM126

- ⑮ Mount clutch (1) until contact is obtained.


▲ Wear protective gloves.



180DTM162


- ⑯ Mount and oil running disc 55×78×5 (1), axial cage (2) and axial washer 55×78×1 (3).

※ Install running disc (1) with chamfer (see arrow) showing towards the axial cage.



180DTM163


- ⑰ Mount needle cage $55 \times 63 \times 50$ (1) on shaft and oil it.



180DTM164

- ⑱ Install idler gear.


Install inner discs on inner disc carrier (idler gear) by shortly rotating them cw/ccw.



180DTM165


- ⑲ Mount and oil axial washer $55 \times 78 \times 1$ (1), axial cage (2) and running disc $55 \times 78 \times 5$ (3).

※ Install running disc (3) with chamfer (see arrow) showing towards the axial cage.



180DTM166

※ Pay attention that the running disc (see arrow) is flush with the shaft collar to ensure that all inner discs are mounted on the idler gear teeth.




180DTM167

① Heat up bearing inner ring (app. 120 °C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501




180DTM135

② Mount bearing inner ring (1) until contact.

⚠ Wear protective gloves.


※ Readjust bearing inner ring after cooling down.



180DTM168

※ Check closing and opening of the clutch by means of compressed air at the hole (see arrow).

Closing and opening of the clutch must be clearly audible.




180DTM169

(6) Clutch K4

① Heat up bearing inner ring (app. 120°C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501




180DTM135

② Mount bearing inner ring (1) until contact.

Mount piston ring (2).

▲ Wear protective gloves.


※ Readjust bearing inner ring after cooling down.



180DTM170

③ Undercool shaft (1) (app. -80°C), heat up gear (2) (app. +120°C) and mount until contact is obtained.


▲ Wear protective gloves.



180DTM171

④ Secure gear by means of retaining ring 80×2.5 (1).


※ (S) Set of external pliers 5870 900 015



180DTM172

(7) Input shaft


- ① Install snap ring SB-38 (1) into annular groove of turbine shaft (2).



180DTM173

- ② Press turbine shaft (1) into the input shaft (2) under a handoperated press until snap ring engages into the groove.

※ Axial fixture of turbine shaft.




180DTM174

- ③ Heat up both bearing inner rings (app. 120°C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501




180DTM135

- ④ Mount bearing inner rings (1) until contact.

Install rectangular ring (2) 60×3.

▲ Wear protective gloves.

※ Readjust bearing inner ring after cooling down.




180DTM175

⑤ Heat up bearing inner ring (app. 120°C).

(S) Hot air blower 230 V 5870 221 500

(S) Hot air blower 115 V 5870 221 501



180DTM135

⑥ Mount bearing inner ring (1) until contact is obtained.

Fit rectangular ring 40 × 2.5 (2).


▲ Wear protective gloves.

※ Adjust bearing inner ring after cooling-down.

Mount stud bolt (3).

Tightening torque (M10/8.8 × 16)

$$M_A = 17 \text{ Nm}$$



180DTM176

8) INSTALLATION OF INPUT SHAFT AND CLUTCHES

(1) Preassembly of front and rear transmission housing


- ① Stop for converter outlet pressure valve.

Fit threaded pin M10 × 16 (1) with pin.

Tightening torque $M_A = 10 \text{ Nm}$

Fit threaded pin M10 × 12 (2).

Tightening torque $M_A = 23 \text{ Nm}$



180DTM177


- ② Fix screen sheet (1) by means of cyl screws (2) in the transmission housing.

Oil cylinder screws before the assembly.

Tightening torque M8/8.8 × 12

$M_A = 23 \text{ Nm}$

※ It is always necessary to use new cylinder screws.



180DTM178

- ③ Insert all bearing outer rings into bearing holes of both housing parts.

Housing front part :

1 = "K3" Clutch - 3rd gear

2 = "K2" Clutch - 2nd gear


3 = "K1" Clutch - 1st gear

4 = "K4" Clutch - Intermediate shaft

5 = "KR" Clutch - reverse

6 = "KV" Clutch - forward

7 = "An" Input




180DTM179

※ K4/K2/K3 and "An" have got the same outer diameter, but merely K4/K2/K3 are fitted with the same bearings. Risk of confusing.

Housing rear part :

Legend see figure TM179.

- ※ Insert bearing outer rings into bearing holes with assembly grease.
- ※ If, contrary to the recommendation, the tapered roller bearings of clutches and the input are not replaced, it is imperative to ensure the previous pairing (bearing inner ring/bearing outer ring) - see chapter 5) figure TM048 and TM052.
- ※ K1/K2/KR and "An" have got the same outer diameter, but merely K1/K2/KR are fitted with the same bearings. Risk of confusing.




180DTM180

- ④ Install pipes (system pressure from electro-hydraulic control unit to the corresponding clutch).

Keep the following order to install the pipes with hollow screws and seal rings A14×18:

- | | |
|----------|---------------------------|
| 1 = Pipe | KR |
| 2 = Pipe | K2 |
| 3 = Pipe | K3 |
| 4 = Pipe | K4 - Intermediate shaft - |
| 5 = Pipe | K1 |

Tightening torque $M_A = 40 \text{ Nm}$



180DTM181


- ⑤ Install various screw plugs and place closing covers until contact is obtained.

- | | |
|---|-------|
| 1 = Screw plug M16×1.5 with O-ring 13×2 | (1×) |
| 2 = Screw plug M10×1 with O-ring 8×1.5 | (14×) |
| 3 = Closing cover 12 | (3×) |

Tightening torque (item. 1) $M_A = 40 \text{ Nm}$

Tightening torque (Item. 2) $M_A = 25 \text{ Nm}$

- ※ Wet contact face of closing covers (3) with Loctite (type no. 262).



180DTM182


- ⑥ Place closing covers (1) until contact and fasten fixing plate (2) with cyl screws on the transmission housing rear part.

1 = Closing cover

2 = Fixing plate with cyl screw

Tightening torque (item. 2) M10/8.8 × 20
 $M_A = 46 \text{ Nm}$

- ※ Wet contact face of closing covers (1) with Loctite (type no. 262).




180DTM183

(2) Installation of converter outlet pressure valve

- ① Insert valve (1) into transmission housing front part by means of drift (S) until contact is obtained.

(S) Drift 5870 705 012



180DTM184

- ② Place indented ring (1) into transmission housing front part by means of press-fit mandrel (S) .


(S) Press-fit mandrel 5870 705 015

Fasten fixing plate (2) on transmission housing front part by means of cyl screws.

Tightening torque M10/8.8 × 20
 $M_A = 46 \text{ Nm}$

Install screw plug M22 × 1.5 (3) with O-ring 19 × 2

Tightening torque M10/8.8 × 20
 $M_A = 60 \text{ Nm}$




180DTM185

(3) Insert clutches into transmission housing front part

- ① Install piston rings in clutches KV and KR, as well as rectangular ring 60×3 into input shaft, align and grease them.


Insert clutch KR (2), clutch KV (3) and input shaft (1) jointly into bearing outer rings.



180DTM186

- ② Install piston ring into clutch K4 -Intermediate shaft-, align and grease it.


Bring clutch K4 - Intermediate shaft - (1) into proper position.



180DTM187

- ③ Install piston ring in clutch K1 (1), align and grease it.

Bring clutch K1 (1) into proper position.



180DTM188


- ④ Mount O-ring 35×3 on suction tube (1), grease it and then fix it in the transmission housing front part with cyl screws M8×12.

Oil cylinder screws before the assembly.

Tightening torque M8/8.8×12

$$M_A = 23 \text{ Nm}$$


※ It is always necessary to use new cylinder screws.



180DTM189

- ⑤ Mount piston ring into clutch K2, align and grease it.


Bring clutch K2 (1) into proper position.



180DTM190

- ⑥ Mount piston ring into clutch K3, align and grease it.

Place screen sheet (1) and bring clutch K3 (2) into proper position.



180DTM191

- ⑦ Place screen sheet (1) and fix it with cyl screws (2) with sleeves and with cyl screws (3).

Oil cylinder screws before the assembly.

Tightening torque M6/8.8 × 10

$$M_A = 9.5 \text{ Nm}$$


Tightening torque M8/8.8 × 65

$$M_A = 23 \text{ Nm}$$

Insert tubes . guide tubes - (4 and 5) into connecting holes of transmission housing front part with O-rings.

O-ring 24 × 3 (2 ×)

O-ring 12 × 2.5 (7 ×)




180DTM192

※ It is always necessary to use new cylinder screws.

※ Wet tubes (4 and 5) on outer diameter with Loctite (type no. 262) and insert into hole.

- ⑧ Install piston rings on clutches KV, KR, K1, K2, K4, and rectangular ring 65×3 on clutch K3 and rectangular ring 60×3 on input shaft, align and grease them.


1 = Clutch K2
 2 = Clutch K1
 3 = Clutch K3
 4 = Clutch K4 - Intermediate shaft -
 5 = Input shaft
 6 = Clutch KR
 7 = Clutch KV



180DTM193

- ⑨ Carefully bring transmission housing rear part into contact position by means of lifting device.

※ Ensure an exact alignment of the tubes.
 ※ Wet mounting face with Loctite (type no. 574).



180DTM194


- ⑩ Fix transmission housings with 2 cyl screws (1) crosswise by hand.

Fit both cylindrical pins (2) 10×26 centrically to the mounting face.

Fix transmission housing front and rear part by means of cylinder screws (1).

Tightening torque $M10/8.8 \times 65$

$M_A = 46 \text{ Nm}$



180DTM195

(4) Install output flange


- ① Mount shaft seal 90×120×13 (1) by means of driver tool, with the sealing lip showing to the oil sump.

(S) Driver tool 5870 048 237

- ※ Use the specified driver tool (S) , to obtain the exact installation position.

- ※ Fill space between sealing lip and dust lip with grease.


Wet outer diameter (rubber-coated) with spirit.



180DTM196


- ② Install hex screws (1) M12×1.5×45 into holes of output flange (2) and press screen sheet (3) into flush position.

(S) Pressure sleeve 5870 506 142



180DTM197

- ③ Mount pre-assembled output flange (1) on output shaft.



180DTM198

- ④ Insert O-ring 48×4 into the space between output flange and shaft.


Fix output flange with washer (1) and hex screws (2).

Oil hexagon screws before the assembly.

Tightening torque M10/8.8×30


$$M_A = 46 \text{ Nm}$$

It is always necessary to use new hexagon screws.



180DTM199

- ⑤ Check clearance of gear drive train and output gears by rotating the output flange (1) and turbine shaft (2).



180DTM200


9) REASSEMBLY ENGINE CONNECTION AND OIL PRESSURE PUMP

(1) Oil pressure pump :

※ In case of wear marks in the pump housing or on the control disk, the pump assy must be replaced.

① Install outer rotor.


※ Chamfer (see arrow) to show downwards.



180DTM201

② Install inner rotor.

※ Teeth (see arrow) to show upwards.




180DTM202

③ Place control disk and fix it radially by means of two cylindrical screws M6×12 (1).

※ Do not tighten the cylindrical screws-just turn them in until contact is obtained and then turn them back by approx 1/2 rotation.

Pay attention to the installation position of the control disk, see figure.

Place O-ring 182×3 (2) into the annular groove and oil it.




180DTM203

④ With the sealing lip showing downwards, carefully insert the shaft seal 75×905×10 (1) into the pump housing (2) until contact is obtained.

※ Wet outer diameter of shaft seal with spirit.

(S) Driver 5870 055 070
(S) Handle 5870 260 002




180DTM204

- ⑤ Install two adjusting screws and mount stator shaft (1).

※ Pay attention to hole pattern.

(S) Adjusting screws (M10)

5870 204 007




180DTM205

※ Oil sliding bearing (see arrow) before the assembly.

- ⑥ Mount pre-assembled pump (1).

※ Pay attention to hole pattern.



180DTM206

- ⑦ Provide cylinder screws with O-rings 9.5×1.6 .


※ Grease O-rings.

Fix transmission pump (2) by means of cyl screws (1).

Tightening torque (M10/8.8 \times 75)

$$M_A = 46 \text{ Nm}$$

※ Wet mounting faces - duct ribs - (3) with Loctite (type no. 574).



180DTM207


- ⑧ Mount two adjusting screws and place plate (1), and fix with cylinder screws (2).

(S) Adjusting screws (M10)

5870 204 007

Tightening torque (M10/8.8 \times 20)

$$M_A = 46 \text{ Nm}$$



180DTM208

(2) Converter connection :

- ① Install two adjusting screws and place converter bell-housing (1), and bring into contact position evenly with 3 cylinder screws (3 × 180 offset).

※ Make sure that O-ring will not be damaged (sheared off).


Fix converter bell-housing with cylinder screws (2).

Tightening torque (M10/8.8 × 30)

$$M_A = 46 \text{ Nm}$$

Mount, align and grease rectangular ring 36 × 2.5 (3) .

※ Wet mounting face with Loctite (type no 574).



180DTM209


- ② Always position 1 disk 4 × (1) onto the flexplate mounting web (4 ×).

Install flexplate set (2)

Flexplate set consisting of :

3 = flexplates (3 pieces)

4 = clamps (4 pieces)



180DTM210


- ③ Mount disk (1) onto the hexagon screw M10x16 (2) and fix flexplates.

Mount eyebolts

Tightening torque (M12/10.9 × 18)

$$M_A = 115 \text{ Nm}$$


※ Wet the thread with Loctite (Type no. 262).



180DTM211

- ④ Insert the converter by using the lifting device until contact is obtained.

Remove the eyebolts and fix the flexplates with hexagon screws (see figure TM211).




180DTM212

10) REASSEMBLY PTO

- (1) Press ball bearing (1) on pump shaft (2) until contact is obtained.

Mount, align and grease rectangular ring (4) 60×3 .




180DTM213

- (2) Mount pump shaft (1) into turbine wheel of converter until contact is obtained and fix with retaining ring (2) 85×3 .

Grease O-ring (3) 180×3 and insert it into hole.

- ⚠ When mounting the pump shaft make sure that the converter will not be forced out of the converter bell-housing. Fix converter axially. Risk of injury.**




180DTM214

- (3) Fix cover plate (1) with hex screws (2).

Tightening torque (M12/10.9 \times 18)

$$M_A = 115 \text{ Nm}$$



180DTM215

11) REASSEMBLY INDUCTIVE SENSOR, HALL SENSOR, BREATHER AND TEMPERATURE SENSOR

(1) Mount positioned parts.

1 = Breather


Tightening torque $M_A = 12 \text{ Nm}$

2 = Inductive sensor with O-ring 15.5×2.6
(n central gear chain)

Tightening torque $M_A = 30 \text{ Nm}$

3 = Inductive sensor with O-ring 15.5×2.6
(n turbine)

Tightening torque $M_A = 30 \text{ Nm}$



180DTM216

(2) Mount inductive sensor (1), temperature sensor (2) and speed sensor (3).

1 = Inductive sensor with O-ring 15.5×2.6
(n engine)

Tightening torque $M_A = 30 \text{ Nm}$

2 = temperature sensor with O-ring 11×3
(Measuring point "63" after converter)


Tightening torque $M_A = 25 \text{ Nm}$

3 = Speed sensor with O-ring 15.5×2.6
(n output Hall sensor)

Fix with cyl screws

Tightening torque (M8/8.8 \times 16)

$M_A = 23 \text{ Nm}$






180DTM217

12) REASSEMBLY

Electro-hydraulic control with proportional valves :

※ Different versions regarding the wiring harness position are possible.

The following sketches show the sectional views of the electro-hydraulic control.



(1) Fitting of electric control


- ※ All single parts are to be checked for damage and replaced, if required.
Ensure free travel of the moving parts in the valve block prior to installation.
Pistons can be exchanged individually.
Prior to the installation, oil single parts.

① With the concave side showing upwards, insert orifice (1 and 2) until contact is obtained.


- ※ See arrows for installation position.
Orifice - cover plate - (2) without through-hole.

The opposite figure shows the following single parts :

- 1 = pressure reducing valve
(1 × , piston and compr spring)
- 2 = vibration damper
(3 × , piston and compr spring)
- 3 = follow-on slide
(3 × , piston and compr spring)




180DTM221



180DTM222

② Install the single parts acc to figure TM222.

- ※ Preload compression springs of the follow-on slides and preliminarily fix pistons by means of cylindrical pins $\varnothing 5.0$ mm (assembly aid), see arrows (S).




180DTM223

③ Fit two adjusting screws.


Mount seal (1) and housing (2).
Then position housing equally by means of adjusting screws until contact is obtained.

(S) Adjusting screws 5870 204 036



180DTM224

- ④ Bring housing (1) into contact position by means of the Torx screws. This will preload the pistons, and you can remove the cylindrical pins (assembly aid).



180DTM225


- ⑤ Fix housing by means of Torx screws (1).

Tightening torque (M5/10.9×30)

$$M_A = 5.5 \text{ Nm}$$

(S) Reducing adapter 5870 656 056

(S) Socket wrench TX-27 5873 042 002



180DTM226


⑥ Preassemble the opposite side

The figure on the right shows the following single parts :

1 = Main pressure valve
(1×, Piston a. compr spring)

2 = Vibration damper
(3×, Piston a. compr spring)

3 = Follow-on slide
(3×, Piston a. compr spring)



180DTM227


- ⑦ Install the single parts acc. to figure TM228.

- ※ Preload the compression springs of the follow-on slides and fasten the pistons preliminarily by means of cylindrical pins (S) $\varnothing 5.0 \text{ mm}$ (assembly aid), see arrows (S).

Install two adjusting screws.

(S) Adjusting screws M5 5870 204 036

Assemble flat gasket (1) and housing cover. Then place the housing cover by means of adjusting screws equally until contact.



180DTM228

- ⑧ Preload the pistons with Torx screws and remove the cyl pins (assembly aid) again.

Then fasten the housing cover by means of cap screws (1).


Tightening torque (M5/10.9 × 30)

$$M_A = 5.5 \text{ Nm}$$

(S) Adjusting screws 5870 204 036

(S) Reducer 5870 656 056

(S) Socket spanner TX-27 5873 042 002



180DTM229

- ⑨ Mount pressure controllers with O-ring 13.5 × 2 (1) and fasten them by means of fixing plates (2) and Torx screws (3).

※ Install fixing plate, with the claw showing downwards.


Pay attention to the radial installation position of pressure controllers, see figure.

Tightening torque (M5/8.8 × 12)

$$M_A = 5.5 \text{ Nm}$$

(S) Reducing adapter 5870 656 056

(S) Socket wrench TX-27 5873 042 002



180DTM230

- ⑩ Mount the pressure regulators (1) and fasten them by means of fixing plates and Torx screws.

※ Install the fixing plate with the neck showing downwards.


Observe radial installation position of the pressure regulators, see figure.

Tightening torque (M5/8.8 × 12)

$$M_A = 5.5 \text{ Nm}$$

(S) Reducing adapter 5870 656 056

(S) Socket wrench TX-27 5873 042 002




180DTM231

- ⑪ Assemble the wiring harness (1) and connect the pressure regulators (5×).

※ See figure TM218, page 3-142 for installation position of pressure regulators.

※ Pay attention to the installation position of the wiring harness, also see markings (Chapter 1) figure TM019).



180DTM232

- ⑫ Put on the flat gasket (1).


Assemble the plug socket with the slot showing to the lug of the cover until contact.

Fasten the cover by means of Torx screws.

Tightening torque (M5/10.9×30)

$$M_A = 5.5 \text{ Nm}$$


(S) Socket spanner TX-27 5873 042 002



180DTM233

- ⑬ Fix the wiring harness by means of retaining clamp (1).


※ Install the opposite cover.



180DTM234

- ⑭ Install two adjusting screws.


(S) Adjusting screws 5870 204 063



180DTM235

- ⑮ Flush-mount screens (1) into the holes of the sealing plate, see arrows.

※ Pay attention to the installation position -screens to show upwards (towards the duct plate).




180DTM236

- ⑯ Put on sealing plate (1) and duct plate (2).

※ Screens (3) to show upwards.

※ It is not permitted to re-assemble the seal plate after opening the threaded joint shift unit/duct plate.

In case of repair it is always necessary to mount a new seal plate.




180DTM237

- ⑰ Place duct plate (1) and fix it equally by means of Torx screws (2).

Tightening torque (M6/10.9 × 23)

$$M_A = 10.5 \text{ Nm}$$

(S) Socket wrench TX-27 5873 042 002




180DTM238

- ⑱ Provide the screw plugs M10x1 with O-rings 8 × 1.5 (1) and install them.


Tightening torque

$$M_A = 6 \text{ Nm}$$



180DTM239

- ⑲ Insert converter outlet pressure valve (1) into housing hole.




180DTM240

- ⑳ Fit 4 adjusting screws.

Mount sealing (1 and 2) and duct plate (3).

(S) Adjusting screws 5870 204 063



180DTM241


- ㉑ Fix duct plate with torx screws (1).

Tightening torque (M6/10.9 × 25)

$M_A = 9.5 \text{ Nm}$

Tightening torque (M6/10.9 × 60)

$M_A = 9.5 \text{ Nm}$



180DTM242

- ㉒ Mount filter differential pressure valve (1).


Filter differential pressure valve consists of :

2 = Switch with O-ring 13 × 2

3 = Piston

4 = Compression spring

Tightening torque $M_A = 30 \text{ Nm}$




180DTM243

②③ Fit two adjusting screws.

(S) Adjusting screws 5870 204 063

Mount sealing plate (1) and electro-hydraulic control unit (2).

※ It is not permitted to re-assemble the seal plate after opening the threaded joint shift unit/gearbox housing.
In case of repair it is always necessary to mount a new seal plate.



180DTM244

②④ Evenly fix electro-hydraulic control unit (1) by means of torx screws.

Tightening torque (M6/10.9 × 80)

$M_A = 9.5 \text{ Nm}$


Tightening torque (M6/10.9 × 100)

$M_A = 9.5 \text{ Nm}$

(S) Torque wrench 5870 203 031

(S) Reducing adapter 5870 656 056

(S) Socket wrench TX-27 5873 042 002



180DTM245

13) REASSEMBLY FINE FILTER (PRESSURE FILTER), OIL FILLER TUBE AND OIL DRAIN PLUG

(1) Installation of fine filter (pressure filter)


- ① Fix filter head (1) with O-rings 34.2x3 (2) by means of torx screws (3) on housing rear part.

Tightening torque (M8/10.9 × 35)

$$M_A = 23 \text{ Nm}$$

(S) Torque wrench 5870 203 034


(S) Socket wrench TX-40 5870 042 004



180DTM246

- ※ Stick to the following instructions for the installation of the filter (1) :

- Slightly oil sealing
- Turn in the filter until contact with the sealing surface is obtained, and then tighten it by hand with approx. 1/3 to 1/2 rotation.



180DTM247

- ② Bring oil level tube (1) with seal (2) into contact position with the housing rear part and fix it by means of hexagon screws (3).

Tightening torque (M8/10.9 × 50)


$$M_A = 34 \text{ Nm}$$

Fix tab of oil level tube with hexagon screw (4) on housing rear part.

Tightening torque (M10/8.8 × 65)

$$M_A = 46 \text{ Nm}$$

Turn oil dipstick (5) into oil level tube.



180DTM248


- ③ Install oil drain plug (1) with O-ring (2)
35×2

Tightening torque (M38×1.5)

$$M_A = 80 \text{ Nm}$$

Fix identification plate (3) to the housing
front part.

※ Use Loctite (type no. 5069).




180DTM249

- ④ Fit screw plug M16×1.5 (1) with O-ring
13×2.

Tightening torque

$$M_A = 23 \text{ Nm}$$

※ Before putting the transmission into
operation, fill it with oil according to the
operator's manual.



180DTM250

3. DRIVE AXLE DISASSEMBLY

1) GENERAL INSTRUCTIONS FOR CORRECT ASSEMBLY AND DISASSEMBLY

- (1) Disassembly and assembly are to be accomplished only by trained personnel.
- (2) The assembly can be made reverse to the respective disassembly instruction.
- (3) Drain oil before removing, check for presence of metal particles.
- (4) Mark the parts to each other before dismantle.
- (5) Never use a hard object to separate tightly fitted assemblies. To remove bearings, drive flanges and similar parts, use the proper pullers.
- (6) It is recommended that the special tools according page 3-155 used for disassembly.
- (7) Do not place parts on a dirty surface.
- (8) Systematically replace used seals, O-rings and, if necessary, bearings on disassembly.
- (9) Clean parts before reassembly.
- (10) Replace or clean corroded parts.
- (11) The cages of bearings rotating in oil are to be coated with oil at reassembly.
- (12) Seal ring treads on flanges, shafts etc. must be preserved with SAE80W-90/API GL-5 before mounting.
- (13) Oil seal rings and particularly the anti-dust lip seals must be filled with grease.
- (14) The universal joint shafts and the axle shafts must not be force mounted (They must slide).
- (15) At mounting of radial seal rings pay attention that there is suffice overlap to the housing bores.
Pay attention for a plain alignment of the radial seal ring. The seal lips always must not be contacted with Loctite.
- (16) The bolted or keyed assemblies safeties are to be checked according to instructions ; in case of doubt, consult Hyundai dealer.
- (17) Refill the oil after assembly.
- (18) Repair weldment is only allowed after consultation with Hyundai.

2) USING OF LOCTITE AND OPERATING SUPPLIES


Kind	Type	Color	Application
Loctite	243	Blue	Lightly locked screws
	262	Red	Middle locked screws
	270	Green	Highly locked screws
	270	Green	Increased coefficient of friction in contact surfaces
	510	Orange	Surface gasket
	572	White	Special gasket
	638	Light-green	Glueing with big width of slit
Epple	33	Grey	Surface gasket
Dirko	-	Grey	Elastic gasket

3) REMARKS FOR WORKING UP LOCTITE AND OPERATING SUPPLIES

- (1) Threads and surfaces have to be cleaned and free from color, oil and grease before applying loctite.
- (2) Loctite will harden under following conditions :
 - ① Exclusion of air
 - ② Metal contact
 - ③ Increased temperature
- (3) Pre-assembly and control tightening has to be made in a short time(5 to 10min).
- (4) The time between glueing and mounting of the parts should be shorter than 1hour.
Exception : Parts made from nonferrous metal have to be glued within one minute.
- (5) Assembled parts must remain unloaded for at least 24 hours.

(6) Loctite quantity :

- At screws :



100D7XL80

- At contact surfaces : Pay attention for a sufficient loctite application.

4) UTILIZATION OF LOCTITE AND OPERATING SUPPLIES

(1) Hub assembly

Safety blocked parts	Joint	Loctite	Operating supplies
Spacer ring	Contact surface	572	-
Axle spindle	Screws	562	-
Axle spindle	Contact surface	270	-
Grommet	In planetary housing	270	-
Disk	In axle spindle	270	-
Adjusting screw with nut	In planetary housing	270	-
Support	Screw	262	-
Ring gear retainer	Screws	270	-
Pol wheel	Contact surface	638	-
Steering lever	Screws	262	-
Track rod lever			-
Steering lever	Contact surface	270	-
Track rod lever			-
Wheel hub cover	Thread	572	-
Radial seal rings	Contact surface	572	-
Rubber casing			-
Radial seal rings	Contact surface	270	-
Steel casing			-
Wheel safety nut → See page 3-167 → Adjustment of wheel bearings			

(2) Drive assembly

Safety blocked parts	Joint	Loctite	Operating supplies
Drive flange	Nut surface	-	Epple 33
Diff-housing	Screws	262	-
Shifter cylinder (Diff-lock)	Contact surface	572	-
Diff. carrier (Through drive)	Contact surface	510	-
Drop gear housing	Contact surface	510	-
Diff. carrier	Contact surface	-	Epple 33
Through drive cover	Contact surface	510	-
Differential stap	Screws	262	-
Adjustment nut screw	Screw	270	-
Ring gear	Screw	262	-
Ring gear	Contact surface	270	-
Ring gear support	Cap	270	-
Ring gear support	Thread	-	Epple 33

5) TIGHTENING TORQUES

Unit : N · m

Metric standard thread						
Thread	Screw	Nut	Screw	Nut	Screw	Nut
	8.8	8	10.9	10	12.9	12
M4	3.0		4.4		5.1	
M5	5.9		8.7		10	
M6	10		15		18	
M8	25		36		43	
M10	49		72		84	
M12	85		125		145	
M14	135		200		235	
M16	210		310		365	
M8	300		430		500	
M20	425		610		710	
M22	580		830		970	
M24	730		1050		1220	
M27	1100		1550		1800	
M30	1450		2100		2450	


Unit : N · m

Metric fine thread						
Thread	Screw	Nut	Screw	Nut	Screw	Nut
	8.8	8	10.9	10	12.9	12
M 8×1	27		39		46	
M10×1	55		81		95	
M10×1.25	52		76		90	
M12×1.25	93		135		160	
M12×1.5	89		130		155	
M14×1.5	145		215		255	
M16×1.5	225		330		390	
M18×1.5	340		485		570	
M20×1.5	475		680		790	
M22×1.5	650		920		1050	
Brake caliper dowel screws(Greased)						
M20×1.5	400 + 100					
M27×2	900 + 100					

Wheel nut (M22 × 1.5) : 650 Nm

(1) Tightening torque of the adjusting nut respective slotted nut at flanges respective gear wheels ect.



Thread d1 (mm)	Torque (Nm)
M45 × 1.5	850




6) SERVICE TOOLS

When ordering service tools please provide order number (Installation drawing no), respective fabrication number→see identification plate. (The illustrations are not binding for the design)


(1) Spanner for wheel safety nut




(2) Spanner for splined nut (hub assembly)




(3) Seal ring sleeve driver.




(4) Spanner for thread rings.
(Differential bearing)




(5) Spanner for counter nut.
(Planetary gear drive)




(6) Assembly cone for O-ring.
(Differential lock)



(7) Centering tool for discs.



(8) Installation tool for face seal.




7) ASSEMBLY DRIVE ASSEMBLY

(1) Adjustment of gear meshing of gleason gears

① Perfect marking

To become a perfect gear meshing is only possible, if the fabrication number of the drive pinion (marked on the end face) and the ring gear (marked on the circumference) are corresponding.




※ Improper gear meshing marks

The following figures are showing improper gear meshing marks of the ring gear. The text alongside gives the corrections to obtain correct gear meshing. The dark colored arrows in the sketch of the drive pinion and ring gear are indicating the direction towards which the drive pinion has to be moved. The clear arrows are indicating the direction towards which the ring gear has to be moved, to get further more a correct backlash.


② Gear meshing to deep

Increase the drive pinion distance by correction of the adjustment disk thickness. Regulate the backlash by inwards moving of the ring gear.




③ Gear meshing to high

Decrease the drive pinion distance by correction of the adjustment disk thickness. Regulate the backlash by outwards moving of the ring gear.




(2) Securing of the striking nut

The brim of the striking nut has to be sheared only along the slot flank and the corner has to be bent on the slot ground.



100D7XL26



100D7XL25

① Using of Loctite and other operating supplies

a. Striking nut at drive flange

- In thread : Assembly paste with MoS_2 (exception through drive pinion see point Z).
- Front side contact surface : Sealing compound (Epple 33 or equivalent).

b. Striking nut at through drive pinion

- In thread : Loctite 262.


Striking nut at gear wheels, bearings etc.

- In thread : Assembly paste with MoS_2 .

② Removing of the striking nut

Bend away the nose and screw off the nut.

③ Drive assembly D 51




250DEXL27

(3) Adjustment drive pinion distance

To obtain the proper tooth flank contact, adjust the axial position of the drive pinion with the thickness of the adjustment disk. The necessary thickness of the adjustment disk for first time assembly can be obtained by measurement (see calculation example).

The final thickness of the adjustment disk can be fixed during the checking of gear meshing at the assembled drive assembly (see page 3-189 "Adjustment of gear meshing of gleason gears")



- A = Set value for correct pinion support. This dimension is written on the end face of the pinion in millimeter. It indicates the deviation from the theoretic distance (setpoint dimension).
- B = Measured width of the taper roller bearing. (B theorem = 40 mm)

※ Calculation example to ascertain the thickness S from the adjustment disk :

$$A = +0.10 ; B = 39.95$$

$$S = 3.20 \text{ mm (theorem)}$$

$$+ 0.05 \text{ mm} \rightarrow B = 0.05 \text{ mm smaller than B theorem.}$$

$$= 3.25 \text{ mm}$$

$$- 0.10 \text{ mm} \rightarrow \text{Drive pinion value A}$$


$$= \mathbf{3.15 \text{ mm}} \rightarrow \text{Necessary thickness of the adjustment disk}$$

Fit corresponding disk and outer rings of the taper roller bearings.


- ※ If value A is positive (e.g +0.1) the adjustment disk has to be 0.1 mm thinner than theorem.
S. If value A is negative (e.g -0.1) the adjustment disk has to be 0.1 mm thicker than theorem S.
- ※ If measure B is positive (e.g 40.05) the adjustment disk has to be 0.05 mm thinner than theorem S.
If measure B is negative (e.g 39.95) the adjustment disk has to be 0.05 mm thicker than theorem S.

(4) Assembly of drive pinion bearing

- ① Insert the two outer rings of the taper roller bearings into the differential carrier.
- ② Calculate the thickness C of the spacer ring.
 - a. Place the two inner rings of the taper roller bearings in their outer rings. Measure A.
 - b. Measure the dimension B of the drive pinion.
 - c. Thickness of the spacer ring $C = A - B$.
- ③ Heat the drive pinion side taper roller bearing to about 100 °C and install it on the drive pinion shaft. (Drive on completely after it cools)



- ④ Install the spacer ring on the pinion shaft.
- ⑤ Install the drive pinion into the differential carrier. Heat the taper roller bearing inner ring at undersize to about 100 °C and install it with a tube onto the drive pinion shaft.
- ⑥ Install the drive flange onto the drive pinion shaft. Tighten the safety nut according page 3-167. For tightening fix the differential carrier and block the drive flange.




- ⑦ Measure the resistance of the bearings by using a torque wrench. If the measured value is not the prescribed 0.8 to 1.2Nm, adjust the resistance by modification of the thickness of the spacer ring. After arriving at the adjustment of the bearing, back-off the safety nut and draw off the drive flange.
- ⑧ Install the radial seal ring with Loctite 572 applied. Fill the radial seal ring with bearing grease. Fit the carrier of the parking brake (if present) on the differential carrier and tighten the screws. Slip on the drive flange, screw on the safety nut with sealing compound between the contact surfaces. Tighten the safety nut according page 3-157. Lock the nut by striking the nut brim into the slot of the pinion.


8) ASSEMBLY OF THE DIFFERENTIAL

Before assembly all of the bevel gears and the thrust rings should be well oiled.


- (1) Place one differential side gear with the side gear thrust washer in the differential case.
- (2) Install the spider with differential gears and differential pinion thrust washers in the differential case.



- (3) Install the other differential side gear and side gear thrust washer. (At variants with nospin differential install the nospin diff. instead of the differential gears)
- (4) Install the other half of the differential case over the assembly and observe the alignment marks, tighten the differential case bolts. Secure with Loctite 262.




- (5) Check that all differential pinions can rotate easily.
- (6) Coat the contact surface of the ring gear with Loctite 270 and install the ring gear on the differential case by tapping lightly on the circumference. Tighten the ring gear bolts. Secure with Loctite 262.
- (7) Heat the two taper roller bearings to about 100°C and install them by using a sleeve.




9) ASSEMBLY OF DRIVE ASSEMBLY


- (1) Place the differential with the outer rings of the taper roller bearings on the differential carrier which is in a vertical position, with mounted drive pinion.
- (2) Mount the differential straps and align them with the thread rings.
- (3) During this operation be careful of the alignment marks on the differential straps with respect to the differential carrier. (Do not interchange the differential straps)



- (4) Hand tighten the differential strap bolts. By a counter rotation of the two thread rings, move the differential until the backlash is correct. (The smallest admissible value at the closest place is marked on the ring gear)
- (5) Therefore hold the drive pinion at the drive flange. Check the backlash by careful forwards and rearwards rotating the ring gear. Use a dial indicator.
- (6) Measure the backlash during a few times turns of the ring gear and if need correct the backlash, because of the smallest admissible value at the closest place must not be fall short of.



- (7) Adjust gear meshing according to page 3-189 "Adjustment of gear meshing of gleason gears".
- (8) Tighten screws of the differential straps and lock them with Loctite 262.
- (9) Adjust the bearing roll resistance through tightening of the thread rings. Set value : 2.0 to 3.0 Nm. Check the value with a torque wrench. If measuring at the drive pinion/drive flange, take the ratio of the bevel wheel set into account.
- (10) Screw the lock plates for the thread rings and secure with Loctite 270, if need bend the lock plates.




10) ASSEMBLY OF HUB ASSEMBLY

(1) Assembly of the spacer ring

Coat the seat of the spacer ring on the steering knuckle respective axle spindle with Loctite 572.


Heat the spacer ring to about 100°C and push it by gently striking onto the steering knuckle respective axle spindle. (The steering knuckle respective axle spindle must be free of corrosion)

Oil the seal ring tread onto the spacer ring.




100D7XL37

(2) Hub assembly drive axle




250DEXL38

11) ASSEMBLY OF THE DRIVE ASSEMBLY ONTO THE AXLE HOUSING



100D7XL39



100D7XL40

- (1) Coat the contact surface of the axle housing with Epple 33 and mount the complete drive assembly. The axle housing being placed in a horizontal position, secure the screws with Loctite 262.
- (2) Engage the axle shaft into the axle housing.
- (3) The axle shaft should be able to be moved easily (by hand) in the toothing of the differential side gear.

(5) Assembly hub assembly

- ① Assembly of the spacer ring (if present) see page 3-165.
- ② Install the brake onto the axle spindle, be careful of the brake control position and bolt it.
At version with disk brake install the brake carrier then mount the wheel hub with the brake disk, and after this operation install the brake.
- ③ Prepare and mount the wheel hub see page 3-167.
Attention : Hold the wheel hub with a hoist till the outer bearing with ring gear carrier is mounted.
- ④ Assembly of the planetary gear drive see page 3-173.


(6) Prepare wheel hub

- ① Install the wheel studs (1), attach the shim (2), screw on the nuts (3) with 800 Nm.
- ② Press in outer rings of taper roller bearings (4+5), do not hammer them.
- ③ Install inner ring of taper roller bearing (5).
- ④ Install the distance ring (6).
- ⑤ Press the radial seal rings (7) with Loctite 572 (rubber cage) respective Loctite 270 (steel cage) applied into the wheel hub (9). Fill the radial seal rings with bearing grease.
- ⑥ Install the face seal (8) into the wheel hub (9) (see page 3-168).

(7) Mount wheel hub

① Push the pre-assembled wheel hub (9) parallel onto the axle spindle respective steering knuckle.

※ Be carefully do not damage the seal rings.



250DE7XL41

(8) Adjustment of wheel bearings

① Tightening torque of the wheel safety nut.

Series	Nm
91	500

② Adjustment of wheel bearings

The temperature of the axle parts should be between 0 and +20°C at the bearing adjustment.

Screw on the wheel safety nut (Loctite-respective Molykote-using see below) and adjust and secure as following described :


Screw on the wheel safety nut and tighten it with a 1.5 to 2 times higher tightening torque than the finish tightening torque. During the tightening, turn the wheel hub a few times and knock it with a plastic hammer. Untighten the wheel safety nut (about 180° back rotation), then tighten the wheel safety nut to the tightening torque according to the table. At this tightening turn the wheel hub also a few times, if there is no possibility for securing, the wheel safety nut has to be turned back to next securing possibility.

③ Wheel safety nut




Designation	Version	Security / Remarks
Shaft nut with cheese head screw		Cheese head screw & Loctite 270

(9) Assembly of the face seal

- 1 Seal ring
- 2 Rubber toric ring
- 3 Housing retaining lip
- 4 Housing ramp
- 5 Seal ring housing




- ① Seal rings, torics, and housings must be clean and free of any oil film, dust, or other foreign matter. Use a solvent that evaporates quickly, leaves no residue, and is compatible with the rubber toric rings. The recommended solvent is Isopropanol. Ring and housings should be wiped with a solvent-soaked lint free cloth or paper towel.
- ② After all components have been wiped clean, the torics should be installed on the metal seal rings so that they rest in the radius on the tail of the metal ring. Insure that the torics are not twisted by inspecting the mold flash line on the outside diameter of the toric for true circumferential tracking around the seal. Twisted torics will cause nonuniform face load that can result in leakage of lubricant and pumping of debris past the toric. If a twist is apparent, it can be eliminated by gently pulling a section of the toric radially away from the metal seal ring and letting it "snap" back. Repeating this in several places around the ring will eliminate any twist in the toric ring.




- ③ Put the toric ring (2) on seal ring (1), at the bottom of the seal ring ramp (7) and against the retaining lip (8).
- ④ The toric ring (2) can twist if it is not wet all around during installation or if there are burrs or fins on the retaining lip (3) of the housing (5).
- ⑤ Eliminate toric twist by gently pulling a section of the toric (2) rapidly away from the seal ring (1) and letting it "snap" back.
- ⑥ Place the installation tool around the seal ring and dip the seal ring into a pan of Isopropanol solvent to lubricate the toric ring. It is essential to lubricate the toric with Isopropanol so that the toric will slip past the housing retaining lip and seal uniformly in the housing nose radius. Insufficient lubrication can cause poor seal performance due to nonuniform loading (twisted torics or cocked seals). Use of solvents other than Isopropanol can leave a residue on the toric or ramps and allow the toric to slide rather than roll in seat. This can also result in poor seal performance due to nonuniform loading.


- ⑦ Put the installation tool (9) onto the seal ring (1) with toric ring (2).
Lower the rings into a container with Isopropanol until all surfaces of the toric (2) are wet.




- ⑧ Toric sliding on retainer ramp.



- ⑨ Toric caught on housing retainer lip.




- ⑩ Toric sliding on seal ramp.




- ⑪ After dipping the seal assembly in the solvent, shake the excess solvent from the seal assembly and immediately "pop" the seal into the housing with a firm push of the installation tool. Remove the installation tool and check the seal standoff height at several places around the circumference of the ring to verify an accurate installation. If the seal does not meet the height specification, inspect the toric for twists or obvious bulges.

- ⑫ With all surfaces of the toric ring (2) wet with Isopropanol, use the installation tool (9) to position the seal ring (1) and the toric ring (2) squarely against the housing (5) as shown. Use sudden and even pressure to pop (push) the toric ring (2) under the retaining lip (3) of the housing (5).




- ⑬ The seal can be adjusted by gently pushing the toric into position by hand or by using a fabricated adjustment hook.


- ⑭ If small adjustments are necessary, do not push directly on the seal ring (1); use the installation tool (9) to push down or the adjustment tool (11) to pull up.



- ⑮ A thin film of light oil should be applied to the seal faces prior to assembly. Use an applicator, a disposable tissue or a clean finger to distribute the oil evenly. Be careful not to get any oil on the rubber toric rings.



- ⑩ Be sure there is no visible debris on either of the seal faces even a small piece of lint can hold the seal faces apart and cause leakage.




- ⑪ After successful installation, wait one minute for the Isopropanol to dry before assembling the two seal halves in the final loaded position. This delay is to allow any excess solvent to dry so that the torics roll, rather than slide, in the housing as the faceload is increased. If the torics slide, this can produce a nonuniform load that can result in poor seal performance.

- ※ Results of incorrect assembly :
Point "A" and point "B" remain stationary.
Points "X" and "Y" rotate 180°.
This causes high pressure at "A" and "Y" and possible galling.
When rotated, points "B" and "X" have low pressure and possible leakage.

Original assembled position



Rotated 180°




- ⑱ After the unit to be sealed is assembled, a post-assembly leakage test can be performed to insure the seal is properly installed. A vacuum check is recommended rather than a pressure check as vacuum checks are more sensitive. Many users find this an easy check to combine with a vacuum fill technique for the lubricant. It is recommended the compartment be filled to the correct level with lubricant and then rotated slowly several revolutions to seat the seals. A vacuum test will catch big seal damage such as broken seal rings or cut torics that may be caused in the last phases of assembly. The Duo-Cone seal is not designed to seal air, so some leakage can be expect using such a procedure.
- ⑲ Following these guidelines and recommendations should insure optimum performance from the Duo-Cone-Seals.

10) ASSEMBLY OF PLANETARY GEAR DRIVE

(1) Prepare the ring gear and the ring gear carrier

Heat the taper roller bearing inner ring with cage (1) to about 100°C and install it onto the ring gear carrier (2). Place the ring gear (3) onto the ring gear carrier. Bolt the retainer (5) with the screws (4), secure the screws with Loctite 270.



(2) Assembly of the ring gear carrier


Install the ring gear carrier (2) with ring gear (3) into the wheel hub respective onto the steering knuckle respective axle spindle.

The oil compensating hole in the ring gear carrier must be on the bottom.

Subsequent adjust wheel bearings (see page 3-167).

(3) Assembly of the thrust ring


Press the thrust ring (6) into the steering knuckle respective axle spindle. Secure with Loctite 270.



(4) Assembly of the sun gear

Push the sleeve (34) onto the universal joint respective axle shaft. Introduce the sun gear (8) into the sleeve and bolt it with the screw (35) onto the universal joint respective axle shaft, secure the screw with Loctite 262.

Push the universal joint respective axle shaft towards the inside until the sun gear contacts to the sleeve and the sleeve contacts to the thrust ring.



The binding lubrication points have to be taken from the according installation drawing of the axle.


Single drive assembly

* The position is dependent from the respective axle version.


I=Oil fill plug

II=Oil level control plug


III=Oil drain plug



Hub assembly with planetary gear drive




Hub assembly with wet disc brake




(5) Assembly of planetary gear

① Prepare planetary gear :


Install the needle bearing (10) into the planetary gear (12).



② Insert the preassembled planetary gears (12) with needle bearings (10) and thrust disks (14, 15) into the planetary housing (22) (planetary housing in horizontal position).




③ Place O-ring (19) into the slot of the planetary housing (22). Because of the difference of diameter of 0.1mm press the planetary pin (17) in direction of arrow. Be sure, that the bore hole of the locking pin in the planetary pin and planetary housing are aligned. After inserting, secure the planetary pin with the locking pin (20).




(6) Disassembly of planetary gear

- ① Knock the locking pin (20, 21) completely to the inner side of the planetary pin.




- ② Press the planetary pin in direction of arrow out of the planetary housing.

※ Because of the difference of diameter of 0.1 mm do not press the planetary pin against the direction of arrow out of the planetary housing, to prevent damaging the bore.



- ③ Remove the planetary gears with the thrust disks and needle bearings.



11) Adjustment of the axial clearance

The axial clearance between sun gear and thrust disc (27) in the planetary housing must be 0.3~0.7 mm.

Measure distances :

Dimension A =


Dimension B =

Calculate required thickness, take the axial clearance (0.3~0.7 mm) into consideration.

Mount the correctly dimensioned thrust disc (if necessary, make final correction on a lathe) into the planetary housing. Secure with Loctite 270.


12) Assembly of the planetary housing

Place o-ring (30) into the slot of the planetary housing. Install the preassembled planetary housing and bolt it, secure with Loctite 262.



250DEXL71

14) Assembly of service brake



100D7XL83


1	Brake carrier	9	Seal ring	17	Seal ring
2	Brake housing	10	Seal ring	18	Screw plug
3	Piston	11	Connection piece	19	O-ring
4	Inner disk	12	Breather	20	Face seal
5	Outer disk	13	Sealing ring	21	Screw
6	O-ring	14	Sealing ring	22	Tube
7	Screw	15	Spring	23	Bushing
8	Screw plug	16	Screw	24	Screw

(2) Assembly of the piston seals

Place piston with the larger diameter downwards. Note succession of the sealing parts at fitting. Install O-rings free of torsion and loops.

(3) Assembly of O-ring and supporting ring

Install the supporting rings to the averting side of pressure.



100D7XL73/84

1 Large supporting ring

2 Large O-ring



3 Small O-ring

4 Small supporting ring

(4) Assembly of the Omegat seal kit

Install the PTFE-profile rings with small diameter to pressure side.

For assembly there can be used mounting tapes from Merkel company.



100D7XL74/85


1 Large O-ring

2 Small O-ring

3 Large supporting ring

4 Small supporting ring

(5) Assembly of the piston




100D7XL86

Lubricate cylinder bore, apply the thread holes at wet disk brakes with Loctite 243. Place the piston onto the brake carrier(do not cant it).

Press the piston equal by hand into the brake carrier.

① Prepare housing and check the air gap



100D7XL87

Lay discs into the housing.

② Check the air gap

Air gap = measure A-measure B (measured without pressure)

Rated size about 0.5 mm smaller than the air gap pressurized (see table).

Install O-ring (brake housing / brake carrier) free of torsion and loops.

③ Air gap and wear dimension

Brake type	Air gap sL new (Pressurized) (mm)	Wear dimension (mm)
4460	2.5 [+0.7 / -0.1]	1.6

(6) Finish assembly

Place the brake carrier onto the brake housing and bolt it. Mount breather with connection piece and seal ring, screw plugs with seal rings.

Check brake hydraulic system for leaks (see tightness checking instruction).

Install O-ring (Brake carrier / axle spindle respective steering knuckle) free of torsion and loops.

① Check the air gap (pressurized)

Measure through the check hole the distance from brake carrier to the piston end face, while non actuated brake, actuate the brake and repeat the measure operation-the difference of the measured distances gives the air gap sL (pressurized), rated size sL see table.

Measure through the check hole the distance from brake carrier to the piston end face, while actuating the brake and knock the measured value with marking punches into the brake carrier.

Install the complete brake on the axle (coat the contact surface with Loctite 270).

Mount face seal see page 3-168.

② Alignment of the discs

The alignment of the discs has to be made at mounting of the wheel hub by itself.

(7) Tightness checking instruction for brake hydraulic system and cooling oil room

① Check brake hydraulic system for leaks

Before conducting the test, bleed the brake hydraulic system.

The pressure drop after applying 120 bar for a period of 15 minutes must not exceed 2% (leaving 117.5 bar).


Test medium : Motor oil SAE 10W corresponding to MIL-L2104.

② Check cooling oil room for leaks

After assembly of the wheel hub with the face seal and adjusting of the wheel bearings check the tightness of the cooling oil room. Install a air pressure gauge with shutoff valve.

Beload the hub assembly with 1.5 bar pressure air. Turn the hub assembly several times.

The pressure drop after a period of 10 minutes must not exceed 0.1 bar.



100D7XL75

(8) Permissible oil for brake with external cooling

① Actuation fluid

Do not use brake fluid any time.


Use a mineral oil base hydraulic oil.

② Cooling fluid

- Hydraulic oil with an additive (LZ 9990A).


③ Check measure

It is measured through the check hole, while actuating the brake. The check measure, new, is marked in the housing below the hole. Is the measured dimension bigger than the marked dimension and max. wear dimension, unconditional consult Hyundai dealer.



After working at the brake, bleed the brake hydraulic system and check for tightness.

(9) Brake disk



100D7XL78

A	Network - like formation of cracks	admissible
B	Radially shaped crack	not admissible
C	Uneven brake surface characteristics below 1.0 mm	admissible
D	Continuous cracks	not admissible

(10) Spring - loaded sliding caliper brakes


Safety notes :

· Warning

Before commencing work on the parking brake, ensure that no unintended machine movement can happen when the braking effect is removed.

· Danger

The parking brake is under spring tension. Parts could become loose and fly out suddenly if improper brake opening. Therefore release the lock nut (2) and turn the adjusting screw (3) counter - clockwise until the spring set is released before disassembly of the circlip (1).



100D7XL79

GROUP 4 ADJUSTMENT


1. CHECKING THE RING GEAR BACKFACE RUNOUT

Runout specification : 0.20 mm (0.008-inch)
maximum

- 1) Attach a dial indicator on the mounting flange of the carrier.
- 2) Adjust the dial indicator so that the plunger or pointer is against the back surface of the ring gear.
- 3) Set the dial indicator to zero (0).
- 4) Rotate the ring gear and read the dial indicator. The runout must not exceed 0.20 mm (0.008 inch).

If runout exceeds specification, remove the differential and ring gear assembly from the carrier. Refer to "Assembly of the differential".

- 5) Check the differential parts, including the carrier, for problems that may cause the ring gear runout to exceed specifications. Repair or replace parts.
- 6) Re-install the differential and ring gear into the carrier. Refer to "Assembling the differential case".
- 7) Repeat the preload adjustment of the differential bearings.



2. ADJUSTING THE GEARSET BACKLASH

Backlash specification : 0.13~0.18 mm

(0.005-0.007 inch)

If the old gearset is installed, adjust the backlash to the setting that was measured before the carrier was disassembled.

If a new gearset is installed, adjust the backlash to the correct specification for new gearsets.

- 1) Attach a dial indicator on the mounting flange of the carrier.
- 2) Adjust the dial indicator so that the plunger or pointer is against the tooth surface, near the heel end of the gear tooth. Set the indicator dial to zero (0).
- 3) Hold the drive pinion in position.
- 4) Read the dial indicator, while rotating the ring gear a small amount in both directions, against the drive pinion teeth.




※ When you adjust backlash, move the ring gear ONLY. DO NOT move the drive pinion.

If the backlash reading is within specification, continue checking tooth contact patterns.

Otherwise, adjust backlash. Refer to step 6), and check, following steps 1)-4).

Backlash is increased by moving the ring gear away from the drive pinion. Backlash is decreased by moving the ring gear toward the drive pinion.



Loosen one bearing adjusting ring one notch, then tighten the opposite ring the same amount.



3. ADJUSTING TOOTH CONTACT PATTERN OF THE GEARSET

Always check tooth contact pattern on the drive side of the gear teeth.

- 1) Apply marking compound to approximately 12 teeth of the ring gear.



- 2) Rotate ring gear forward and backward so that the 12 marked teeth go past the drive pinion six times to get a good contact pattern.



- 3) Compare the contact patterns.



In new gearsets, a good contact pattern is toward the toe of the tooth, and centered between the top and bottom of the tooth.

In used gearsets, a good contact pattern fills approximately the full length of the tooth. The top of the pattern is near the top of the tooth. The location should match the wear pattern on the tooth.

If the contact patterns require adjustment along the width of tooth (top/bottom), follow steps 4)-5).


If the contact patterns requires adjustment along the length of tooth (toe/heel), follow step 6)-7).






4) High pattern : A high contact pattern indicates that the pinion was installed too shallow into the carrier.

To correct, move the pinion toward the ring gear by decreasing the shim pack between pinion spigot and inner bearing cone. Refer to "Assembling the pinion bearing cage".



5) Low pattern : A low contact pattern indicates that the pinion was installed too deep into the carrier.

To correct, move the pinion away from the ring gear by increasing the shim pack between pinion spigot and inner bearing cone. Refer to "Assembling the pinion bearing cage".




4. ADJUSTMENT OF GEAR MESHING OF GLEASON GEARS

To become a perfect gear meshing is only possible, if the fabrication number of the drive pinion (marked on the end face) and the ring gear (marked on the circumference) are corresponding.

Perfect marking


The following figures are showing improper gear meshing marks of the ring gear.

The text alongside gives the corrections to obtain correct gear meshing. The dark colored arrows in the sketch of the drive pinion and ring gear are indicating the direction towards which the drive pinion has to be moved. The clear arrows are indicating the direction towards which the ring gear has to be moved, to get further more a correct backlash.




Gear meshing to deep

Increase the drive pinion distance by correction of the adjustment disk thickness. Regulate the backlash by inwards moving of the ring gear.




Gear meshing to high

Decrease the drive pinion distance by correction of the adjustment disk thickness. Regulate the backlash by outwards moving of the ring gear.




5. SECURING OF THE STRIKING NUT

The brim of the striking nut has to be sheared only along the slot flank and the corner has to be bent on the slot ground.



100D7XL25



100D7XL26

Using of Loctite and other operating supplies

1) Striking nut at drive flange

- In thread : Assembly paste with MoS₂ (Exception through drive pinion see point Z)
- Front side contact surface : Sealing compound (Epple 33 or equivalent).

2) Striking nut at through drive pinion

- In thread : Loctite 262.

3) Striking nut at gear wheels, bearings etc.

- In thread : assembly paste with MoS₂.

Removing of the striking nut

Bend away the nose and screw off the nut.