


SECTION 2 REMOVAL & INSTALLATION OF UNIT

Group 1 Major components	2-1
Group 2 Removal and installation of unit	2-2
Group 3 Maintenance for hose	2-13

SECTION 2 REMOVAL & INSTALLATION OF UNIT

GROUP 1 MAJOR COMPONENTS



25BX2RE02


- | | | | | | |
|---|--------------------|----|---------------------|----|------------------|
| 1 | Lift cylinder | 9 | Drive axle | 17 | Counterweight |
| 2 | Mast | 10 | Drive motor | 18 | Traction control |
| 3 | Steering unit | 11 | Hydraulic gear pump | 19 | Pump control |
| 4 | Backrest | 12 | Pump motor | 20 | Seat |
| 5 | Tilt cylinder | 13 | Battery | 21 | Overhead guard |
| 6 | Main control valve | 14 | Rear battery | 22 | Steering wheel |
| 7 | Fork | 15 | Steering axle | | |
| 8 | Front wheel | 16 | Steering cylinder | | |

GROUP 2 REMOVAL AND INSTALLATION OF UNIT

Remove and install following units as explained in the flow chart.

1. MAST


1) REMOVAL



L15C3RE001

(1) Forks


- ① Lower the fork carriage until the forks are approximately 25 mm from the floor.
 - ② Turn knob up and slide one fork at a time toward the center of the carriage where a notch has been cut in the bottom plate for easy removal.
 - ③ Remove only one fork at a time.
- ※ On larger forks it may be necessary to use a block of wood.



25B9URE04

(2) Backrest (If necessary)


- ① Remove bolts securing backrest to fork carriage. Lift backrest straight up and remove it from carriage.



22BH9RE03


(3) Carriage

- ① With the mast vertical, raise the carriage high enough to place blocks under the carriage. This is done to create slack in the load chains when the carriage is lowered. Lower the carriage all the way down to the floor. Make sure the carriage is level, this will prevent any binding when the mast is raised.




25B9URE01

- ② While supporting lift chains, remove the split pin and nuts from the chain anchor.




- ③ Pull the chains out of the sheaves and drape them over the front of the carriage.



- ④ Slowly raise inner mast upright until mast clears top of fork carriage. Move carriage to work area and lower the mast.


▲ Make sure that carriage remains on floor and does not bind while mast is being raised.

※ Inspect all parts for wear or damage. Replace all worn or damaged parts.



(4) Piping

- ① Remove the return hoses and clamps attached to the lift cylinder
 - ② Remove hose assembly, valve and connector from the lift cylinder
- ※ Put blind plugs in the piping immediately after removing hoses to prevent the hydraulic oil from flowing out and also prevents dust and dirt from getting in.




(5) Lift cylinder

- ① Loosen and remove stud bolts and washers and secure lift cylinders to outer mast.
- ② Bind the lift cylinder with overhead hoist rope and pull up so that the rope has no slack or binding.

▲ **Make sure that the lift cylinder be tightened firmly for safety.**


- ③ Loosen and remove hexagon bolts and nuts securing the cylinder.
- ④ Using an overhead hoist, slowly raise the inner mast high enough to clear lift cylinder.
- ⑤ Using an overhead hoist, draw out lift cylinder carefully and put down on the work floor.



(6) Inner mast

- ① Using an overhead hoist raise the inner mast straight and carefully draw out of outer mast section

▲ Be careful the mast not to swing or fall.




(7) Tilt cylinder pin

Loosen the bolt and remove the tilt cylinder pin.

(8) Mast mounting pin

- ① Attach a crane to the stay at the top of the outer mast, and raise enough to sustain jacked up truck.
- ※ This operation is carried out under the truck, so use a pit, or if there is no pit, jack up the truck and loosen with an impact wrench.
- ② Loosen the mounting socket bolts and remove the mast mounting pins. Then slowly raise the outer mast.



2) INSTALLATION

After assembling mast components totally without piping connections, install mast assembly to the equipment.

※ Installation procedure for each of mast component is the reverse of the removal procedure.

(1) Mast support cap


- ① Check mast mounting bolts and bushings for wear.
- ② Jack up the truck so that the front is raised and then using an overhead hoist assemble outer mast to drive axle unit.
- ③ Tighten mast support cap and mounting bolts to mast. Lubricate with GTP 600 or 1000 PASTE.
 - Tightening torque : $24.5 \pm 2.5 \text{ kgf} \cdot \text{m}$

(2) Tilt cylinder pin

Hold the mast with a crane, operate the tilt control lever and align the holes, then knock the pin


(3) Lift cylinder installation and adjustment

- ① Assemble the lift cylinder inside the outer mast, then tighten the stopper bolt. If the cylinder assembly has been replaced, adjust as follows so that the left and right cylinders are synchronized at the maximum lifting height.
 - ② Assemble the cylinder rod to the inner mast, and check the left-to-right play of the mast at the maximum lifting height.
- ※ If play is to LEFT, install adjustment shim to LEFT cylinder.
- ※ If play is to RIGHT, install adjustment shim to RIGHT cylinder.
- Shim thickness : 1.0 mm



2. POWER TRAIN ASSEMBLY

1) REMOVAL




25B9U3RE00

(1) Mast

Refer to section on mast (Page 2-2) to remove mast.


(2) Service brake piping

Disconnect the service brake piping from the brake housing of drive axle.



(3) Parking brake cable


Remove the Parking cable from the drive axle.




(4) Drive axle and drive motor

※ Before removing the drive axle unit, drain all of the oil from the axle.


- ① Unscrew 12 wheel nuts and remove the wheel.



- ② Prepare to remove drive axle by using eye bolt tab of the drive axle.
- ③ Remove 12 mounting bolts fixing the axle to the frame and carefully remove the drive motor and axle from the vehicle.




- ④ Remove 5 mounting bolts fixing the motor to the axle and carefully remove the drive motor from the drive axle.



2) INSTALLATION


Installation is the reverse order of removal. Refer to Tightening torque for major components in 1-8.



3. ELECTRICAL COMPONENTS

Before removing each component, disconnect cables and earth lines attached to the component.

1) REMOVAL




25BX2RE36

(1) Battery

Battery can be replaced using Forklift, Pallet truck or exclusive jig. Make sure max capacity of the Forklift or Pallet truck is above the battery weight.

- ⚠ Using improper method may result in battery tip over accident so be cautious.
- ⚠ Change battery on flat ground.
- ⚠ Battery might fall off if equipment tip over while battery locking device is loose. Always operate equipment with battery locked.

- ① Park the truck horizontally and with 140mm or more road clearance, turn the engine off and open the right battery door. Then disconnect the connector and unlock battery locking device (a)




25BXP10

- ※ Make sure road clearance is over 140 mm by placing plate (10~20 t) under front and rear wheels.
- ※ If manual unlocking procedure is impossible due to battery being too close to the locking device, push the battery in slightly with fork then unlock the locking device.


- ② Place fork in a way that battery sits balanced, carefully remove battery from the frame.

- ※ When carrying the battery, slow maneuver is required.




(2) Pump motor


- ① Lower the fork to floor



- ② Remove floor mat and rear floor plate.



- ③ Remove pump motor, gear pump, wiring for priority valve, rubber hose and hydraulic hose.
- ④ Loosen mounting nut and remove pump motor, gear pump, priority valve from the frame.
- ⑤ Loosen mounting bolt and remove priority valve and pump motor.




2) INSTALLATION

Installation is the reverse order of removal.
Refer to Tightening torque for major components in 1-8.

4. STEERING AXLE

1) REMOVAL




25BX2RE37

(1) Rear wheel

Refer to 5-17


(2) Hose

Disconnect the hoses from the steering cylinder.



(3) Mounting bolt


Put a block between the steering axle and support of a truck, and raise the frame with a crane. Remove the mounting bolts installing to the frame, and pull out to the rear. There are shims and spacers between the trunnion block and steering axle to prevent play.



2) INSTALLATION

Installation is the reverse order of removal. Please refer to following :


- (1) When changing bushing of the trunnion block, make sure install the bushing with hole on the surface face down.



(2) When installing trunnion block, make sure the space at the back is under 0.5 mm when it was pushed completely.

Be aware of tightening torque for the mounting bolt of the trunnion block. Apply loctite #277.

· Tightening torque : 59~65 kgf · m



Apply molybden disulphide to hub bolt when installing rear wheel, and tighten nut at 22~24 kgf · m torque.

Balance with center of the frame when installing counterweight. Apply molybden disulphide to mounting bolt before tightening.

GROUP 3 MAINTENANCE FOR HOSE

1) MAINTENANCE


The function and service life of hydraulic components depend to a great extent on how they are maintained regularly. Therefore, it is very important to prevent dirt from entering the hydraulic system. Some simple advice to keep the hydraulic system clean:

- Always clean the area around parts before starting work. If possible, it is better to wash the truck.
- Plug hose connections immediately after disconnecting. If possible, use correct plugs for the connection type. If plugs do not match, use clean plastic bags and cable ties or tape to seal the connection.
- Never reuse oil that has been drained from the truck.
- If possible, filter the oil before pouring it into the truck, oil barrels often contain impurities.

2) HOSE LENGTH

Connected hoses have HG part number, but if they have no information the hoses are measured as follows:

- The hose length is measured on a laid-out hose between the sealing surfaces
- On angled connections, measure from the sealing surface's center line according to the figure.



3) CAUTION FOR REPLACEMENT

When replacing hoses for maximum service life and functionality, the following must be observed:

- To avoid stress when connecting, a straight hose length must be secured after connection.
- Do not kink the hose. 7% twist reduces the service life by 90%.
- Do not use hoses that are too short. It may cause leakage or damage
- Use the correct coupling to minimize the number of bends.
- Avoid sharp bending.
- When storing, keep the inside of the hose clean. When installing, keep the plug in place for as long as possible.