

## SECTION 1 GENERAL

Group 1	Safety hints .....	1-1
Group 2	Specifications .....	1-5
Group 3	Periodic replacement .....	1-13


## GROUP 1 SAFETY HINTS

Careless performing of the easy work may cause injuries.


Take care to always perform work safely, at least observing the following.

- Oil is a dangerous substance. Never handle oil, grease or oily clothes in places where there is any fire of flame.


As preparation in case of fire, always know the location and directions for use of fire extinguishers and other fire fighting equipment.




- Wear well-fitting helmet, safety shoes and working clothes. When drilling, grinding or hammering, always wear protective goggles. Always do up safety clothes properly so that they do not catch on protruding parts of truck. Do not wear oily clothes. When checking, always release battery plug.



- Flames should never be used instead of lamps. Never use a naked flame to check leaks or the level of oil or electrolyte.




- Exhaust gas is dangerous. Provide adequate ventilation when working a closed space.



⚠ Be particularly careful when removing the radiator cap and the hydraulic oil tank filler cap, if this is done immediately after using the truck, there is a danger that boiled oil may spurt out.

- The procedure for releasing the hydraulic pressure is as follows : lower the fork to the ground, and stop the engine, move the control levers to each position two or three times.




- When working on top of the truck, be careful not to lose your balance and fall.



- Hand a caution sign in the operator's compartment (For example **Do not start** or **Maintenance in progress**).

This will prevent anyone from starting or moving the truck by mistake.


⚠ It is extremely dangerous to try to check the fan belt tension while the engine is running.




When inspecting the engine is running parts, or near such parts, always stop the engine first.

Before checking or servicing accumulator or piping, depress brake pedal repeatedly to release pressure.

- Park the truck on firm, flat ground.  
Lower the fork to the ground and stop the engine.  
Return each lever to **NEUTRAL** and apply the brake lock.



- Immediately remove any oil or grease on the floor of the operator's compartment, or on the handrail. It is very dangerous if someone slips while on the truck.




D50ASF09

- When working with others, choose a group leader and work according to his instructions. Do not perform any maintenance beyond the agreed work.



D50ASF10

- Always remember that the hydraulic oil circuit is under pressure. When feeding or draining the oil or carrying out inspection and maintenance, release the pressure first.



D50ASF11


- Unless you have special instructions to the contrary, maintenance should always be carried out with the engine stopped. If maintenance is carried out with the engine running, there must be two men present : one sitting in the operator's seat and the other one performing the maintenance. In such a case, never touch any moving part.

- Thoroughly clean the truck. In particular, be careful to clean the filler caps, grease fittings and the area around the dipsticks. Be careful not to let any dirt or dust into the system.
- Always use HYUNDAI Forklift genuine parts for replacement.
- Always use the grades of grease and oil recommended by HYUNDAI Forklift.  
Choose the viscosity specified for the ambient temperature.
- Always use pure oil or grease, and be sure to use clean containers.
- When checking or changing the oil, do it in a place free of dust, and prevent any dirt from getting into the oil.
- Before draining the oil, warm it up to a temperature of 30 to 40 °C.
- After replacing oil, filter element or strainer, bleed the air from circuit.
- When the strainer is located in the oil filler, the strainer must not be removed while adding oil.
- When changing the oil filter, check the drained oil and filter for any signs of excessive metal particles or other foreign materials.
- When removing parts containing O-ring, gaskets or seals, clean the mounting surface and replace with new sealing parts.
- After injecting grease, always wipe off the oil grease that was forced out.
- Do not handle electrical equipment while wearing wet places, as this can cause electric shock.
- During maintenance do not allow any unauthorized person to stand near the truck.
- Be sure you fully understand the contents of the operation. It is important to prepare necessary tools and parts and to keep the operating area clean.
- When checking an open gear case there is a risk of dropping things in. Before removing the covers to inspect such cases, empty everything from your pockets. Be particularly careful to remove wrenches and nuts.
- Way to use dipstick  
Push the dipstick fully into the guide, and then pull out.

Carrying out other difficult maintenance work carelessly can cause unexpected accidents. If you consider the maintenance is too difficult, always request the HYUNDAI Forklift distributor to carry out it.

## GROUP 2 SPECIFICATIONS


### 1. MAJOR COMPONENTS



35D9FOM54

1 Mast	9 Turn signal lamp	17 Precleaner
2 Lift chain	10 Head lamp	18 Silencer
3 Lift cylinder	11 Operator's seat	19 Air conditioner (opt)
4 Backrest	12 Bonnet	20 Beacon lamp (opt)
5 Tilt cylinder	13 Counterweight	21 Camera (opt)
6 Lift bracket	14 Rear wheel	22 Rear work lamp (opt)
7 Forks	15 Front wheel	23 Rear handle with horn (opt)
8 Overhead guard	16 Rear combination lamp	24 Blue spot (opt)

## 2. SPECIFICATIONS



35D9FSP01

Model			Unit	35D-9F	40D-9F	45D-9F	50DA-9F
Capacity			kg (lb)	3500 (8000)	4000 (9000)	4500 (10000)	5000 (11000)
Load center		R	mm (in)	600 (24")	←	←	←
Weight (Unloaded)			kg (lb)	5893 (12992)	6438 (14193)	6894 (15199)	7298 (16089)
Fork	Lifting height	A	mm (ft. in)	3020 (9' 11")	←	←	2930 (9' 7")
	Free lift	B	mm (in)	120 (4.7")	←	←	←
	Lifting speed (Unload/Load)		mm/sec	540/500	540/490	540/480	460/410
	Lowering speed (Unload/Load)		mm/sec	500/500	←	←	←
	L × W × T	L,W,T	mm (in)	1070 × 122 × 50 (42 × 4.8 × 2)	1070 × 150 × 50 (42 × 5.9 × 2)	1220 × 150 × 50 (48 × 5.9 × 2)	1200 × 150 × 60 (47 × 5.9 × 2.4)
Mast	Tilt angle (forward/backward)	C/C'	degree	8/10	←	←	←
	Max height	D	mm (ft. in)	4234 (13' 11")	←	←	4147 (13' 7")
	Min height	E	mm (ft. in)	2235 (7' 4")	2220 (7' 3")	←	←
Body	Travel speed (Unload)		km/h (mph)	26.6 (16.5)	25.7 (16.0)	25.6 (15.9)	←
	Gradeability (Load)		%	38.5	34.5	31.3	28.9
	Min turning radius (Outside)	F	mm (ft. in)	2867 (9' 5")	2916 (9' 7")	2964 (9' 9")	3009 (9' 10")
ETC	Operating pressure		kgf/cm² (psi)	210 (2990)	←	←	←
	Hydraulic oil tank		ℓ (U.S. gal)	70 (18.5)	←	←	←
	Fuel tank		ℓ (U.S. gal)	95 (25.1)	←	←	←
Overall length		G	mm (ft. in)	3225 (10' 7")	←	3264 (10' 9")	3300 (10' 10")
Overall width		H	mm (ft. in)	1373 (4' 6")	1746 (5' 9")	←	←
Overhead guard height		I	mm (ft. in)	*12220 (7' 3") *22350 (7' 7")	*12210 (7' 3") *22340 (7' 7")	←	←
Ground clearance		J	mm (in)	170 (6.7")	155 (6.1")	←	←
Wheel base		K	mm (ft. in)	2000 (6' 7")	←	←	←
Wheel tread front/rear		M/M'	mm (ft. in)	1132/1140 (3' 9"/3' 9")	1282/1140 (4' 2"/3' 9")	←	←
Max drawbar pull (load)			kg (lb)	3768 (8307)	3797 (8371)	3801 (8380)	3807 (8393)

\*1: Low

\*2: High

### 3. SPECIFICATION FOR MAJOR COMPONENTS

#### 1) ENGINE

Item	Unit	Specification
Model	-	Kubota V3800-TIE4
Type	-	Vertical, 4 cycle DI, Tier 4 final diesel engine
Cooling Method	-	Water cooling
Number of cylinders and arrangement	-	4 cylinders, In-line
Firing order	-	1-3-4-2
Combustion chamber type	-	Direct injection
Cylinder bore X stroke	mm (in)	100 × 120 (3.94 × 4.72)
Piston displacement	cc (cu in)	3769 (230)
Compression ratio	-	17.0 :1
Rated gross horse power	hp/rpm	74.3/2200
Maximum torque at rpm	kgf · m/rpm	31.6/1500
Engine oil quantity	l (U.S.gal)	13.2 (3.49)
Dry weight	kg (lb)	316 (697)
High idling speed	rpm	2400
Low idling speed	rpm	850
Rated fuel consumption	g/kw.hr	222
Starting motor	V-kW	12-3.0
Alternator	V-A	12-80
Battery	V-AH	12-100
Fan belt deflection	mm (in)	10~12 (0.40~0.47)

#### 2) MAIN PUMP

Item	Unit	Specification
Type	-	Fixed displacement gear pump
Capacity	cc/rev	46.1
Maximum operating pressure	kgf/cm <sup>2</sup> (psi)	235 (3340)
Rated speed (Max/Min)	rpm	3000/600

#### 3) MAIN CONTROL VALVE

Item	Unit	Specification
Type	-	Sectional
Operating method	-	Mechanical
Relief valve pressure (Main/Aux)	kgf/cm <sup>2</sup> (psi)	210/150 (2990/2130)
Flow capacity	lpm	125



#### 4) STEERING UNIT

Item	Unit	Specification
Type	-	Load sensing/Non load reaction/Dynamic signal
Capacity	cc/rev	160
Rated flow	lpm	22.7
Relief pressure	kgf/cm <sup>2</sup>	135

#### 5) POWER TRAIN DEVICES

Item			Specification	
Torque converter	Model		DE 280 (KAPEC)	
	Type		3 Element, 1 stage, 2 phase	
	Stall ratio		2.25 : 1	
Transmission	Type		Power shift	
	Gear shift(FWD/REV)		2/2	
	Control		Electrical single lever type	
	Overhaul ratio	FWD	1st : 2.550	2nd : 1.218
		REV	1st : 2.550	2nd : 1.218
Axle	Type		Front-wheel drive type, fixed location	
	Gear ratio		11.692	
Wheels	Q'ty(FR/RR)		Single : 2/2, Double : 4/2	
	Front(drive)	Single	3.5 ton : 8.25-15-14 PR	4.0~5.0 ton : 300-15-18 PR
		Double	7.50-16-12 PR	
	Rear(steer)		3.5 ton : 7.00-12-12 PR	4.0~5.0 ton : 7.00-12-14 PR
Brakes	Travel		Front wheel, wet disk brake	
	Parking		Ratchet, drum brake (DIC axle) Wet disk brake, negative (TNA axle)	
Steering	Type		Full hydraulic, power steering	
	Steering angle		74.8° to both right and left angle, respectively	
	Relief valve pressure		135 kgf/cm <sup>2</sup> (1920 psi)	

#### 4. TIGHTENING TORQUE FOR MAJOR COMPONENTS

NO	Item		Size	kgf · m	lbf · ft
1	Engine	Engine mounting bolt	M12 × 1.25	6.9 ± 1.4	49.9 ± 10.1
2		Engine bracket mounting nut	M10 × 1.5	6.9 ± 1.4	49.9 ± 10.1
3		Radiator mounting bolt, nut	M10 × 1.5	6.9 ± 1.4	49.9 ± 10.1
4	Hydraulic system	MCV mounting bolt, nut	M12 × 1.75	12.8 ± 3.0	92.6 ± 21.7
5		Steering unit mounting bolt	M10 × 1.5	4.0 ± 0.5	28.9 ± 3.6
6		Hydraulic pump mounting bolt	M14 × 1.5	21.0 ± 3.1	152 ± 22.4
7	Power train system	Transmission mounting bolt, nut	M16 × 2.0	7.5 ± 1.5	54.2 ± 10.8
8		Torque converter mounting bolt	M10 × 1.5	6.9 ± 1.4	50 ± 10
9		Drive axle mounting bolt, nut	M24 × 2.0	62.5 ± 9.5	452 ± 68.7
10		Drive shaft mounting bolt	3/8-24 UNF	7.0 ± 0.7	50.6 ± 5.1
11		Steering axle mounting bolt, nut	M14 × 2.0	19.6 ± 2.9	142 ± 21
12		Front wheel mounting nut	M22 × 1.5	62.0 ± 9.3	448 ± 67.3
13		Rear wheel mounting nut	M22 × 1.5	61.2 ± 9.3	442 ± 67.3
14	Others	Counterweight mounting bolt	M30 × 3.5	199 ± 29.9	1439 ± 216
15		Operator's seat mounting nut	M 8 × 1.25	2.5 ± 0.5	18.1 ± 3.6
16		Head guard mounting bolt	M12 × 1.75	12.8 ± 3.0	92.6 ± 21.7
17		Cabin mounting bolt	M12 × 1.75	12.8 ± 3.0	92.6 ± 21.7
18		Mast mounting bolt	M18 × 2.5	41.3 ± 6.2	229 ± 44.8

## 5. TORQUE CHART

Use following table for unspecified torque.

### 1) BOLT AND NUT

#### (1) Coarse thread

Bolt size	8T		10T	
	kgf · m	lbf · ft	kgf · m	lbf · ft
M 6 × 1.0	0.85 ~ 1.25	6.15 ~ 9.04	1.14 ~ 1.74	8.2 ~ 12.6
M 8 × 1.25	2.0 ~ 3.0	14.5 ~ 21.7	2.73 ~ 4.12	19.7 ~ 29.8
M10 × 1.5	4.0 ~ 6.0	28.9 ~ 43.4	5.5 ~ 8.3	39.8 ~ 60
M12 × 1.75	7.4 ~ 11.2	53.5 ~ 79.5	9.8 ~ 15.8	71 ~ 114
M14 × 2.0	12.2 ~ 16.6	88.2 ~ 120	16.7 ~ 22.5	121 ~ 167
M16 × 2.0	18.6 ~ 25.2	135 ~ 182	25.2 ~ 34.2	182 ~ 247
M18 × 2.5	25.8 ~ 35.0	187 ~ 253	35.1 ~ 47.5	254 ~ 343
M20 × 2.5	36.2 ~ 49.0	262 ~ 354	49.2 ~ 66.6	356 ~ 482
M22 × 2.5	48.3 ~ 63.3	350 ~ 457	65.8 ~ 98.0	476 ~ 709
M24 × 3.0	62.5 ~ 84.5	452 ~ 611	85.0 ~ 115	615 ~ 832
M30 × 3.5	124 ~ 168	898 ~ 1214	169 ~ 229	1223 ~ 1655
M36 × 4.0	174 ~ 236	1261 ~ 1703	250 ~ 310	1808 ~ 2242

#### (2) Fine thread

Bolt size	8T		10T	
	kgf · m	lbf · ft	kgf · m	lbf · ft
M 8 × 1.0	2.17 ~ 3.37	15.7 ~ 24.3	3.04 ~ 4.44	22.0 ~ 32.0
M10 × 1.25	4.46 ~ 6.66	32.3 ~ 48.2	5.93 ~ 8.93	42.9 ~ 64.6
M12 × 1.25	7.78 ~ 11.58	76.3 ~ 83.7	10.6 ~ 16.0	76.6 ~ 115
M14 × 1.5	13.3 ~ 18.1	96.2 ~ 130	17.9 ~ 24.1	130 ~ 174
M16 × 1.5	19.9 ~ 26.9	144 ~ 194	26.6 ~ 36.0	193 ~ 260
M18 × 1.5	28.6 ~ 43.6	207 ~ 315	38.4 ~ 52.0	278 ~ 376
M20 × 1.5	40.0 ~ 54.0	289 ~ 390	53.4 ~ 72.2	386 ~ 522
M22 × 1.5	52.7 ~ 71.3	381 ~ 515	70.7 ~ 95.7	512 ~ 692
M24 × 2.0	67.9 ~ 91.9	491 ~ 664	90.9 ~ 123	658 ~ 890
M30 × 2.0	137 ~ 185	990 ~ 1338	182 ~ 248	1314 ~ 1795
M36 × 3.0	192 ~ 260	1389 ~ 1879	262 ~ 354	1893 ~ 2561

## 2) PIPE AND HOSE(FLARE TYPE)

Thread size	Width across flat (mm)	kgf · m	lbf · ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

## 3) PIPE AND HOSE(ORFS TYPE)

Thread size	Width across flat (mm)	kgf · m	lbf · ft
9/16-18	19	4	28.9
11/16-16	22	5	36.2
13/16-16	27	9.5	68.7
1-3/16-12	36	18	130
1-7/16-12	41	21	152
1-11/16-12	50	35	253

## 4) FITTING

Thread size	Width across flat (mm)	kgf · m	lbf · ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

## 6. RECOMMENDED LUBRICANTS

Use only oils listed below or equivalent.

Do not mix different brand oil.

Service point	Kind of fluid	Capacity l (U.S. gal)	Ambient temperature °C ( °F)								
			-50 (-58)	-30 (-22)	-20 (-4)	-10 (14)	0 (32)	10 (50)	20 (68)	30 (86)	40 (104)
Engine oil pan	Engine oil	13.2 (3.5)	★SAE 5W-40								
								SAE 30			
				SAE 10W							
				SAE 10W-30							
				SAE 15W-40							
Torque converter transmission	Transmission oil	12 (3.2)	ATF DEXRON III								
Axle	Gear oil	10.5 (2.8)	SHELL DONAX TD								
Hydraulic tank	Hydraulic oil	70 (18.5)	★ISO VG 15								
					ISO VG 46						
					ISO VG 68						
Fuel tank	Diesel fuel★ <sup>1</sup>	95 (25.1)	★ASTM D975 NO.1								
						ASTM D975 NO.2					
Fitting (Grease nipple)	Grease	-	★NLGI NO.1								
						NLGI NO.2					
Brake reservoir tank	Brake oil	0.5 (0.13)	★AZOLLA ZS10 (Hydraulic oil, ISO VG10)								
				AZOLLA ZS32 (Hydraulic oil, ISO VG32)							
Radiator	Antifreeze : Water	22.3 (5.9)	Ethylene glycol base permanent type ( 50:50)								
			★Ethylene glycol base permanent type (60 : 40)								

### NOTES :

- Engine oil should be API classification CJ-4.
- Change the type of engine oil according to the ambient temperature.
- When using oil of different brands from the previous one, be sure to drain all the previous oil before adding the new engine oil.

★<sup>1</sup> : Ultra low sulfur diesel  
- sulfur content ≤ 15 ppm

★ : Cold region  
Russia, CIS, Mongolia

### GROUP 3 PERIODIC REPLACEMENT

For operation safety, never fail to perform periodic maintenance or make periodic replacement of the consumable parts listed in the following.

These parts may deteriorate in time and are susceptible to wear. It is difficult to estimate the degree of wear at time of periodic maintenance; therefore, even if no apparent wear is found, always replace with new parts within the prescribed period of replacement (Or earlier if trouble is found).

Note that periodic replacement has nothing to do with guarantee service.

No.	Periodical replacement of safety parts	Interval
1	Fuel hose	Every 2 to 4 years
2	Hydraulic pump hose	Every 2 years
3	Power steering hose	Every 2 years
4	Packing, seal, and O-ring of steering cylinder	Every 2 to 4 years
5	Lift chain	Every 2 to 4 years
6	Lift cylinder hose	Every 1 to 2 years
7	Tilt cylinder hose	Every 1 to 2 years
8	Side shift cylinder hose	Every 1 to 2 years
9	Master cylinder and wheel cylinder caps dust seals	Every 1 years
10	Brake hose or tube	Every 1 to 2 years
11	Brake reservoir tank tube	Every 2 to 4 years
12	Intake air line	Every 2 years
13	Coolant hose and clamps	Every 2 years

- ※ **Replace the O-ring and gasket at the same time when replacing the hose.**
- ※ **Replace clamp at the same time if the hose clamp is cracked when checking and replacing hose.**