

SECTION 4 BRAKE SYSTEM

| | | |
|---------|--|-----|
| Group 1 | Structure and function | 4-1 |
| Group 2 | Operational checks and troubleshooting | 4-5 |
| Group 3 | Tests and adjustments | 4-7 |

SECTION 4 BRAKE SYSTEM

GROUP 1 STRUCTURE AND FUNCTION

1. OUTLINE

There are two brake systems, the foot brake system and the parking brake system.

The foot brake adopts the brake system of oil type at drive axle.

Oil pressure is generated in maximum 60 kgf/cm² through oil input path of the left and right drive axle housing, this pressure allows the piston brake to advance and compresses a friction plate and a plate.

So when the transportation travels, it is possible to brake.

The parking brake works by the switch installed on steering column.

2. SPECIFICATION

1) SERVICE BRAKE


| Item | | Specification |
|------------------|--------------|------------------------|
| Type | | Wet disk brake |
| Pedal adjustment | Pedal height | 135±4 mm (5.3±0.16 in) |
| | Play | 0 |

2) PARKING BRAKE

| Item | | Specification |
|-----------------|--|---|
| Type | | SAHR (Spring Actuate Hydraulic Release) |
| Switch location | | Steering column |
| Disc location | | Drive axle carrier sub assy |

3. BRAKE PIPING

1) STRUCTURE




35D9VB4BS01

- | | | |
|----------------|-----------------------|-----------------------|
| 1 Pipe assy | 7 Sensor-pressure | 13 Hose assy-Orfs&Thd |
| 2 Pipe assy-LH | 8 Elbow-90 | 14 Connector |
| 3 Pipe assy-RH | 9 Elbow-90 | 15 Connector |
| 4 Block-3way | 10 Elbow-90 | 16 Hose assy-Orfs&Thd |
| 5 Bolt-hex | 11 Elbow-45 | |
| 6 Fitting | 12 Hose assy-Orfs&Thd | |

4. INCHING PEDAL AND LINKAGE


The brake pedal serves to actuate the hydraulic brakes on the front axle. At the beginning of the pedal stroke, the inching spool of the transmission control valve is actuated to shift the hydraulic clutch to neutral and turn off the driving force. By treading the pedal further, the brake is applied.



35D9VB4BS02

5. WET DISK BRAKE

1) STRUCTURE




35D9VB3PS10

- | | | |
|-----------------------|-------------------|-------|
| 1 Pinion shaft | 4 Axle shaft | 7 Hub |
| 2 Ring gear | 5 Traveling brake | |
| 3 Differential device | 6 Hub reduction | |

2) OPERATION

The drive axle is connected with the transmission output gear by drive shaft assembly. The power transferred by the drive shaft assembly is connected to the pinion shaft of drive axle, the pinion shaft delivers the power to the differential device through the ring gear. The differential device deliver the power to hub reduction through axle shaft.



35D9VB3PS12

- | | | |
|-----------------------|-----------------|------------------------|
| 1 Pinion shaft | 4 Axle shaft | 7 Parking brake device |
| 2 Ring gear | 5 Service brake | |
| 3 Differential device | 6 Hub reduction | |

GROUP 2 OPERATIONAL CHECKS AND TROUBLESHOOTING


1. OPERATIONAL CHECKS

1) BRAKE PIPING

- (1) Check pipes, hoses and joints for damage, oil leakage or interference.
- (2) Operate brake pedal and check operating force when pedal is depressed. Check also change in operating force, and change in position of pedal when pedal is kept depressed.

2) PARKING BRAKE

- (1) Position 1
Parking brake is applied and front wheel is locked.
 - (2) Position 2
Parking brake is released.
- ※ **Before moving the truck be sure the parking brake is released.**



2. TROUBLESHOOTING

The truck use transmission hydraulic system as a hydraulic system mentioned below

| Problem | Cause | Remedy |
|---|---|---|
| Insufficient braking force | <ul style="list-style-type: none"> Hydraulic system leaks oil. Hydraulic system leaks air. Disk worn. Brake valve malfunctioning. Hydraulic system clogged. | <ul style="list-style-type: none"> Repair and add T/M oil. Bleed air. Replace. Repair or replace. Clean. |
| Brake acting unevenly. (truck is turned to one side during braking.) | <ul style="list-style-type: none"> Tires unequally inflated. Brake out of adjustment. Disk surface roughened. Wheel bearing out of adjustment. Hydraulic system clogged. | <ul style="list-style-type: none"> Adjust tire pressure. Adjust. Repair by polishing or replace. Adjust or replace. Clean. |
| Brake trailing. | <ul style="list-style-type: none"> Pedal has no play. Piston cup faulty. Brake valve return port clogged. Hydraulic system clogged. Wheel bearing out of adjustment. | <ul style="list-style-type: none"> Adjust. Replace. Clean. Clean. Adjust or replace. |
| Brake chirps | <ul style="list-style-type: none"> Brake trailing. Piston fails to return. Disk worn. Disk surface roughened. | <ul style="list-style-type: none"> See above. Brake trailing. Replace. Replace. Repair by polishing or replace. |
| Brake squeaks | <ul style="list-style-type: none"> Disk surface roughened. Disk worn. Excessively large friction between disk plate. | <ul style="list-style-type: none"> Repair by polishing or replace. Replace. Clean and apply brake grease. |
| Large pedal stroke | <ul style="list-style-type: none"> Brake out of adjustment. Hydraulic line sucking air. Oil leaks from hydraulic line, or lack of oil. Disk worn. | <ul style="list-style-type: none"> Adjust. Bleed air. Check and repair or add T/M oil. Replace. |
| Pedal dragging. | <ul style="list-style-type: none"> Twisted push rod caused by improperly fitted brake valve. Brake valve seal faulty. | <ul style="list-style-type: none"> Adjust. Replace. |

GROUP 3 TESTS AND ADJUSTMENTS


1. AIR BLEEDING OF BRAKE SYSTEM

※ Check transmission oil level and fill if insufficient.

- 1) Air bleeding should be performed by two persons :

One rides on truck for depressing and releasing brake pedal : the other person is on the ground and removes cap from air vent plug on wheel cylinder.

- 2) Block the front wheel securely and apply parking brake.
- 3) Start the engine.
- 4) Attach a vinyl tube to air vent plug and immerse other end of tube into a vessel filled with hydraulic oil.
- 5) Loosen air vent plug by turning it 3/4 with a wrench. Depress brake pedal to drain oil mixed with air bubbles from plug hole.
- 6) Depress brake pedal until no air bubbles come out of air vent plug hole.
- 7) After completion of air bleeding, securely tighten air vent plug. Install cap on plug.




2. ADJUSTMENT OF PEDAL

- 1) BRAKE PEDAL

Pedal height from floor plate

Adjust with stopper bolt.

- Pedal height : 135 ± 4 mm (5.3 ± 0.16 in)



2) INCHING PEDAL

- (1) Pedal height from floor plate
Adjust with stopper bolt.
 - Pedal height : 135 ± 4 mm (5.3 ± 0.16 in)
- (2) Inching interlocking distance
Adjust with interlocking bolt
 - Distance : 0

