# MODEL D4B SHOP MANUAL (FOR INDUSTRIAL USE)



# FORWORD

We would like to express our sincere gratitude to the patrons who have given us unwavering encouragement. This manual covers shop manual and parts catalog in one volume for an easy reference of parts list, as well as contains the accurate and efficient service procedures for HYUNDAI D4B industrial engine.

This manual includes specifications, troubleshooting, removal, installation, disassembly and assembly in each group and presents component illustrations and descriptions for an easy reference.

Accordingly, thoroughly read this manual, rapidly purchase the required parts and service the engine in proper methods to extend its life and benefit.

Improper service methods and procedures may shorten the engine life resulting from its low performance. Hyundai genuine parts are designed and built to provide the best performance in your engine. If your claim is caused by using non-Hyundai genuine parts or servicing at places not recommended, your warranty is not available.

Hyundai Motor Co., Inc. makes efforts to enhance quality and build better parts and service data for you. We want to assist you in every way possible with this manual and your purchase of HYUNDAI engine is highly appreciated.

#### March 2004

Hyundai Motor Co., Inc. Industrial Engine Development Team (TEL 82-52-280-8221~8223) O.E.M Parts Export Team (TEL 82-2-746-0291~0299)

NOTE: Contents and specifications are subject to change according to design changes without notice.

# **IMPORTANT SAFETY NOTICE**

Appropriate service methods and proper repair procedures are essential for the safe, reliable operation of all engines as well as the personal safety during work. This manual provides general directions for the efficient service methods and procedures.

There are numerous variations in procedure, techniques, tools and parts for servicing engines, as well as in the skill of the individual technician.

This manual cannot possibly anticipate all such variations and provide advice or cautions as to each.

Accordingly, anyone who departs from the instructions provided in this manual must establish that he comprises neither his personal safety nor the vehicle integrity by his choice of methods, tools or parts.

#### NOTE, CAUTION, WARNING

**III** NOTE : Information needed in reference to a repair service.

**CAUTION:** Information about an activity that could cause damage to the vehicle.

WARNING : Information about an activity that could cause injury or damage to the driver, occupants or repairman.

#### [SAFETY INFORMATION]

The following list contains some general warnings that you should follow when you work on an engine.

- Always wear safety glasses for eye protection.
- Be sure that the ignition switch is always in the OFF position, unless otherwise required by the procedure.
- Operate the engine only in a well-ventilated area to avoid the danger carbon monoxide poisoning.
- Keep yourself and your clothing away from moving parts when the engine is running, especially the drive belt.
- To prevent serious burns, avoid contact with hot metal parts such as the radiator, exhaust manifold, tail pipe, catalytic converter and muffler.
- Do not smoke while working on an engine.
- To avoid injury, always remove rings, watches, loose hanging jewelry and loose clothing before beginning to work on an engine.
- Keep hands and other objects clear of the radiator fan. The fan can be operated with the ignition key in the OFF position. Therefore necessarily disconnect the radiator fan motor connector.

# CONTENTS

1.	GENERAL	1-1	
2.	ENGINE MECHANICAL SYSTEM	2-1	
3.	LUBRICATION SYSTEM	3-1	
4.	COOLING SYSTEM	4-1	
5.	INTAKE AND EXHAUST SYSTEM	5-1	
6.	ENGINE ELECTRICAL SYSTEM	6-1	
7.	FUEL SYSTEM	7-1	

# CHAPTER 1 GENERAL INFORMATION

1.	GENERAL 1-1
2.	ENGINE IDENTIFICATION NUMBER 1-6
3.	TIGHTENING TORQUE OF STANDARD PARTS 1-7
4.	RECOMMENDED LUBRICANTS AND CAPACITIES 1-8
5.	SPECIFICATIONS 1-9
6.	TORQUE SPECIFICATIONS 1-13
7.	SPECIAL TOOLS 1- 15
8.	TROUBLESHOOTING 1-18
9.	CHECKING POINT

# 1. OVERALL

# 1) ENGINE


Cylinder head is made of aluminum alloy and combustion chamber is a swirl type.

Valve is a SOHC type and the camshaft is operated by the Cog type timing belt.

Cylinder block is made of special cast iron and dry cylinder liner is press-fitted in the cylinder. Water jacket is a Siamese type and piston is made of aluminum alloy and connected with connecting rod by full floating piston pin.


Oil ring no.1 of the piston ring is made of steel, no.2 of special cast iron, piston ring no.1 of barrel face, no.2 of taper face and oil ring of bevel cutter and coil expander is attached.

## **ENGINE ASSEMBLY**




Crankshaft is made of forged steel and supported with main bearing. Pulley attached with torsional damper is installed in the front of crankshaft and flywheel in the rear of it. Silent shaft is installed to both ends of the cylinder block, operated with cog belt and rotated at a double speed of crankshaft.

## Timming belt train




# 2) LUBRICATION SYSTEM

It is a forced lubrication system and the forced oil by the oil pump is sent to the engine compartment through the oil cooler and oil filter as shown in the illustration and directly operated by the crank shaft. Maximum oil pressure is controlled by the reducing valve.




Oil filter is a combined type and full flow filter and bypass filter are built in it. The bypass filter in the full flow filter uses a thick multi-fiber media to filter dirt (soot).

If oil enters the oil filter, filtered oil from the full flow filter passes through the main passage and the filtered oil from the bypass filter returns to the oil pan.



# 3) COOLING SYSTEM


Engine is cooled with the circulated coolant forced by the water pump. This illustration shows the flow of coolant.




# 2. ENGINE INDENTIFICATION NUMBER

# 1) ENGINE IDENTIFICATION NUMBER LOCATION

The engine identification number is stamped on the right front side of the top edge of the cylinder block.



# 2) DESCRIPTION OF ENGINE IDENTIFICATION NUMBER



1 Engine fuel

- D : diesel

- ② Engine range
  - 4 : In line 4 cycle 4 cylinder
- ③ Engine development order
  - B:4D56
- ④ Engine capacity
  - F: 2476 cc TC
  - H : 2476 cc TCI
  - B : 2607 cc NA
- 5 Production year
  - 1:2001
  - 2:2002
  - 3:2003
  - 4:2004
- 6 Engine production sequence number
  - 000000 ~ 999999

# 3. TIGHTENING TORQUE TABLE OF STANDARD PARTS

Bolt nominal		Torque (kg · m)		
diameter (mm)	Pitch (mm)	Head Mark 4	Head Mark 7	
EADA010R	EADA010S	EADA010T	EADA010U	
M5	0.8	0.3 ~ 0.4	0.5 ~ 0.6	
M6	1.0	0.5 ~ 0.6	0.9 ~ 1.1	
M8	1.25	1.2 ~ 1.5	2.0 ~ 2.5	
M10	1.25	2.5 ~ 3.0	4.0 ~ 5.0	
M12	1.25	3.5 ~ 4.5	6 ~ 8	
M14	1.5	7.5 ~ 8.5	12 ~ 14	

### **NOTE**

- 1. The torques shown in the table are standard values under the following conditions.
  - . Nuts and bolts are made of steel bar, and galvanized.
  - . Galvanized plain steel washers are inserted.
  - . All nuts, bolts and plain washers are dry.
- 2. The torques shown in the table are not applicable.
  - . When spring washers, toothed washers and the like are inserted.
  - . If plastic parts are fastened.
  - . If self-tapping screws or self-locking nuts are used.
- 3. If you reduce the torques in the table to the percentage indicated below, under the following conditions, it will be the standard value.
  - . If spring washers are used : 85%
  - . If threads and bearing surfaces are stained with oil : 85%

# 4. LUBRICANTS CAPACITES

Description		Capacities	Specified oil
	Oil pan	0.7 <i>l</i>	
	Oil filter	0.5 <i>l</i>	Above API CD or SG
Engine oil	Oil cooler	9.5 <i>l</i>	(10W/30 or 1500W/40)
	Total	0.7 <i>l</i>	
Coolant		Antifreeze for aluminum	

## 

For the best performance and maximum protection of all types of operation, select only those lubricants which :

- 1. Satisfy the requirements of the API classification.
- 2. Have the proper SAE grade number for expected ambient temperature range.Lubricants which do not have both an SAE grade number and an API service clasification on the container should not be used.

# **5. SPECIFICATIONS**

Description			Specification		Limit
	Туре		Diesel engine		
	Number of cyli	nders	4		
	Valve syste	em	0	HC	
			D4BB	D4BF, D4BH	
	Total displace	ment	2607cc	2476cc	
	Cylinder bo	ore	91.1 mm	91.1 mm	
General	Cylinder stro	oke	100 mm	95 mm	
	Compression	ratio	22	21	
		Intake valve - OPEN - CLOSE		BTDC ATDC	
	Valve timing	Exhaust valve - OPEN - CLOSE		BTDC ATDC	
	Firing order		1 - 3 - 4 - 2		
	Flatness of gasket surface		0.05 mm		0.2 mm
	Flatness of manifold mounting surface		0.15	5 mm	0.3 mm
	Overall height		94.0 ~	94.1 mm	
	Oversize of valve guide hole				
Cylinder head	Rework dimensions (both intake and exhaust)	0.05 0.25 0.50	13.250 ~	13.068 mm 13.268 mm 13.518 mm	
	Oversize rework dimen- sions of intake valve seat hole	0.30 0.60		43.325 mm 43.625 mm	
	Oversize rework dimensions of exhaust valve seat hole	0.30 0.60		37.325 mm 37.625 mm	
	Cam height	Intake Exhaust		)5 mm )5 mm	36.55 mm 36.55 mm
Camshaft	Journal O.D.		29.935 ~	29.950 mm	
	Oil clearance		0.05 ~	0.08 mm	
	End play	,	0.1 ~ 0.2 mm		
Rocker arm	I.D		18.910 ~ 18.928 mm		
	Rocker arm - to -guid	le clearance	0.012 ~	0.050 mm	

# **SPECIFICATIONS**

	Description			Specification	Limit
Deelverahaft	O.D.			18.878 ~ 18.898 mm	
Rocker shaft	Length			451.5 mm	
			Intake	136.5 mm	
	Over length	ו	Exhaust	136.5 mm	
			Intake	7.960 ~ 7.975 mm	
	Stem diame	ter	Exhaust	7.930 ~ 7.950 mm	
Valve	Fa	ge angle		45° ~ 45° 3 0 "	
	Thickness of valv	/e head	Intake	2 mm	1.0 mm
	(Margin)		Exhaust	2 mm	1.0 mm
	Stem-to-guide of	clear-	Intake	0.03 ~ 0.06 mm	
	ance		Exhaust	0.05 ~ 0.09 mm	
	Free height			49.1 mm	
Valve spring			· kg/mm	276/40.4	
			of squareness	Max 2°	
	Over length		Intake	71 mm	
			Exhaust	74 mm	
	I.D.			8.000 ~ 8.018 mm	
Valve guide		O.D.		13.06 ~ 13.07 mm	
	Press temperature			Ordinary temperature	
	Seat angle		)	45°	
Valve seat	Valve contack widht		widht	0.9 ~ 1.3 mm	
	Sinkage				0.2
			Right		
			- Front	18.300 ~ 18.467 mm	
	lournal diama	tor	- Rear	42.975 ~ 42.991 mm	
Silient shaft	Journal diameter		Left		
			- Front	18.959 ~ 18.980 mm	
			- Rear	49.975 ~ 42.991 mm	
			Front	0.02 ~ 0.06 mm	
	Oil clearance		Rear	0.05 ~ 0.09 mm	

# **SPECIFICATIONS**

Description			Specification		Limit
	O.D.		79.0 ~ 79.2 mm		
			TC	NA	
	Piston-to cylir	ider clearance	0.04 ~ 0.06	0.03 ~ 0.05	
Piston		No. 1 ring	2.601 ~ 2.603	2.02 ~ 2.04	
	Ring groove width	No. 2 ring	2.100 ~ 2.102	2.07 ~ 2.09	
		Oil ring	4.010 ~ 4.035	3.01 ~ 3.035	
		No. 1 ring	0.35 ~ 0.50	0.25 ~ 0.40	0.8 mm
	End gap	No. 2 ring	0.41 ~ 0.54	0.45 ~ 0.60	0.8 mm
Piston ring		Oil ring	0.25 ~ 0.45	0.20 ~ 0.40	0.8 mm
FISION	Ring-to-ring	No. 1 ring	0.056 ~ 0.076	0.03 ~ 0.07	0.15 mm
	groove	No. 2 ring	0.046 ~ 0.066	0.08 ~ 0.12	0.15 mm
	clearance	Oil ring	0.02 ~ 0.065	0.02 ~ 0.065	0.1 mm
Piston pin	0	. D.	28.994 ~ 29.000 mm		
	Big end center-to small end center length bend		157.95 ~ 158.05 mm		
Connecting rod	Bend		0.	.05	
Connecting fou	Twist		C	).1	
	Bing end side clearance		0.1 ~ 0	).25 mm	
	End play		0.05 ~	0.18 mm	0.2 mm
	Journal O.D.		66	mm	0.3 mm
	Pin O.D.		53 mm		
	Out of roundness of journal and pin		0.05 mm less than		
	Out-of taper of journal and pin		0.015 mm less than		
	Oil clelarance of journal		0.02 ~ 0.05 mm		0.1 mm
Crank shaft	Oil cleara	nce of pin	0.02 ~ 0.05 mm		
		0.25 U.S.	65.735 ~	65.750 mm	
	Journal	0.50 U.S.	65.485 ~ 65.500 mm		
		0.75 U.S.	65.235 ~	65.250 mm	
		0.25 U.S.	52.735 ~	52.750 mm	
	Pin	0.50 U.S.	52.485 ~ 52.500 mm		
		0.75 U.S.		52.250 mm	

# **SPECIFICATIONS**

	Description		Specification	Limit
	O. D.		91.10 ~ 91.13 mm	
Cylinder block	Flatness of gasket surface		0.05 mm	0.1 mm
	Over	all height	318.45 ~ 318.55 mm	
Flywheel	Flywheel Run out		0.13 mm	0.13 mm
		Inner gear	0.22 ~ 0.35 mm	0.5 mm
	Tip clearnace	Outer gear	0.12 ~ 0.22 mm	0.4 mm
Oil pump	Body clearnace	Side clearance	0.04 ~ 0.10 mm	0.15 mm
		Inner gear	0.03 ~ 0.09 mm	0.15 mm
	Side clearance	Outer gear	0.12 ~ 0.22 mm	0.30 mm
	Cooling system		Water-cooled forced circulation system	
	Drive Belt		V Belt	
	Water pump type		Centrifugal impeller	
	Fan clutch type		Bimetal thermostat type	
	Thermo type		Wax type	
	Coolant temperature gauge unit		Thermister type	
	Thermo switch(113°C, A/con)		Thermister type	
Cooling system	Drive belt		10 ~ 13 mm	
	Thermostat	Valve opening temperature	76.5±2°C / 82±2°C	
	Fulley opening temperature		95°C	
	Repea	at amount	8 or not less than	
	Coolant tempera-	Coolant temperature	90.5 ~ 117.5Ω /70°C	
	ture gauge unit	gauge element	21.3 ~ 26.3Ω /115°C	
	Resistance	Glow control	22.3 ~ 27.3kΩ /-20°C	
	element		2.92 ~ 3.58kΩ /20°C	
Intake &	Air	cleaner	Paper filter type	
Exhaust	N	luffler	Expansion resonance type	

# 6. TORQUE SPECIFICATIONS

Deseriptio	n	Standard (kg · m)	
Crankshaft pulley bolt		17 ~ 19	
Crankshaft sprocket bolt		6.5 ~ 7.5	
Timing belt tensioner bolt		2.2 ~ 3.0	
Injection pump sprocket nut		8 ~ 9	
Silent shaft sprocket nut		3.4 ~ 4.0	
Timing belt tensioner "B" nut		2.2 ~ 3.0	
Rocer cover bolt		0.5 ~ 0.7	
Rocker arm shft bolt		1.9 ~ 2.1	
Outlinday based balt	Cold engine	10.5 ~ 11.5	
Cylinder head bolt	Hot engine	11.5 ~ 12.5	
Oil pan bolt		0.6 ~ 0.8	
Oil pan drain plug		6 ~ 8	
Front case bolt (upper, lower)		1.2 ~ 1.5	
Silent shaft driven gear bolt		3.4 ~ 4.0	
Silent shaft plug gap		2.0 ~ 2.7	
Silent shaft gear cover bolt		1.5 ~ 1.8	
Connecting rod cap nut		4.5 ~ 4.8	
Flywheel bolt		13 ~ 14	
Crankshaft bearing cap bolt		7.5 ~ 8.5	
Silent shaft chamber cover bolt		0.5 ~ 0.7	
Oil relief valve plug		3.0 ~ 4.5	
Oil pump cover bolt		0.9 ~ 1.4	
Oil pressure switch		0.8 ~ 1.2	
Oil filter bracket		1.2 ~ 1.5	
Oil cooler by-pass valve		5.0 ~ 6.0	
Oil jet check valve		3.0 ~ 3.5	
Water pump bolt		1.2 ~ 1.5	
Water pump pulley bolt		1.0 ~ 1.2	

# TORQUE SPECIFICATIONS

Deseripti	วท	Standard (kg · m)	
Water outlet fitting attaching bol	[	1.0 ~ 1.3	
Coolant tempeature gauge unit		3.0 ~ 4.0	
Thermo switch (113°)		0.9	
Alternator brace bolt		1.2 ~ 1.5	
Adjust rocker arm		1.2 ~ 1.5	
Alternator support bolt nut		2.0 ~ 2.5	
Intake fitting bolt		1.0 ~ 1.3	
Intake manifold bolt		1.5 ~ 2.0	
Liest protector helt	M6	0.8`1.0	
Heat protector bolt	M8	1.2 ~ 1.5	
Oil return pipe bolt		0.8 ~ 1.0	
Exhaust fitting nut		5.0 ~ 7.0	
Turbo charger nut		5.0 ~ 7.0	
Exhaust manifold nut		1.5 ~ 2.0	

# SEALANTS

Description	Sealants	Amount
Half circle packing	3M ATR P/No. 8660 or equivalent	As required
Oil pan gasket	3M ATR P/No. 8660 or equivalent	As required
Coolant gauge unit	3M nut rocking P/No. 4171 or equivalent	As required
Thermo switch (113°, A/con)	Threebond No.2440 or equivalent	As required

# 7. SPECIAL TOOLS

Tool (Number and name)	Illustration	Use
Silent shaft bearing puller (09212-43100)		Removal of silent shaft rear bearing
	B1243100	
Silent shaft bearing installer (09212-43200)	5)	Installation of silent shaft rear bearing
	D) B1243200	
Bearing installer stopper (09212-43300)		Removal of Right silent shaft rear bear- ing
Crank shaft front oil seal installer (09214-32000)	B1243300	Installation of crankshaft front oil seal
Crankshaft front oil seal guide (09214 - 32100)	B1432000 B1621100	Guide for installation of crank shaft front oil seal
Connecting - rod small - end busing replacement tool (09214-43000)	B1443000	Replacement of connecting - rod small - end bushing
Camshaft oil seal installer (09221-21000)	ECLA002I	Installation of camshaft oil seal

# SPECIAL TOOLS

Tool (Number and name)	Illustration	Use
Cylinder head bolt wrench (09221-32000)		Loosening and tightening of cylinder head bolt
	ECLA002A	
Valve seat cutter pilot (09221-43200)		Correction of valve seat
	ECLA002B	
Valve seat cutter 45° (09221-43300)		Correction of valve seat
Valve seat cutter 65° (09221-43400)	ECLA002C	Correction of valve seat
Valve seat cutter 30° (09221 - 43500)	ECLA002D ECLA002D	Correction of valve seat
Valve spring compressor (09222-21000)	B2221000	Compression of valve spring
Valve stem seal installer (09222-32100)		Installation of valve stem seal
	B2232100	

1-16

# SPECIAL TOOLS

Tool (Number and name)	Illustration	Use
Valve guide installer (09222-32200)	ECLA002F	Removal and Installation of valve guide
Silent shaft drive gear oil seal guide (09222-43200)	B2243200	Installation of silent shaft drive oil seal
Crankshaft rear oil seal installer (09232-32000)	B3132000	Installation of crankshaft rear oil seal
Oil pressure switch wrench (09260-32000)	B6032000	Removal and Installation of oil pres- sure switch
Injection pump sprocket puller (09314-43000)	C1443000	Removal of injection of pump sprocket

# 8. Troubleshooting

Symptom	Probable cause	Remedy
Low compression	Blown cylinder head gasket	Install new head gasket
	Worn or broken piston rings	Hone cylinder bores and install new rings
	Warped or pitted valves	Install new valve
	Excessive run-out of valve seats on valve faces	Reconditioning valve seats and valves
Noisy valves	Incorrect of valve cleanrance	Adjust as standard and valve
	Worn valve guides	Install new valves and/or new valve guides with O.S.
Connecting rod	Excessive camshaft end play	Reconditioning valve seats and valve
noise	Insufficient oil supply	Correct end play
	Low oil pressure	Check engine oil level
		Check engine oil level
	Thin or diluted oil	Inspect oil relief valve and spring
	Excessive bearing clearance	Change oil to correct viscosity
	Connecting rod journals out-of-roundness	Measure bearings for correct clearance
	Misaligned connecting rods	Replace crankshaft or regrind journals
		Replace bent connecting rods
Crankshaft	Insufficient oil supply	Check engine oil level
Bearing noise	Low oil pressure	Check engine oil level
		Inspect oil relief valve and spring.
	Thin or diluted oil	Change oil to correct viscosilty
	Excessive end play	Measure bearings for correct clearances
	Crankshaft journal out-of-roundness worn	Replace crankshft or regrind journals
	Loosen flywheel	Tighten to correct torque
Piston noise	Excessive clearance due to cylinder wear	Correct cylinder wear
	Piston or piston pin worn	Replace piston
	Burnt piston	Install new piston
	Piston ring damaged	Install new rings

# TROUBLESHOOTING

Symptom	Probable cause	Remedy
Oil leak	Oil pan drain plug loose	Tighten to torque
	Oil pan mounting bolt loose	Tighten to torque
	Oil pan gasket broken	Install new oil seal
	Crankshaft front oil seal defective	Install new oil seal
	Crankshaft front oil seal defective	Install new oil seal
	Rocker cover gasket broken	Install new oil seal
	Oil filter loose	Tighten to torque
	Oil filter gasket broken	Install new oil seal
Oil consumption	Worn, scuffed, or broken rings	Hone cylinder bores and install new rings
	Carbon in oil ring slot	Install new rings
	Ring fitted too tight in grooves	Remove the rings. Check grooves. If groove
		width is not , proper width, replace pistion.
	Faulty valve stem seals	Install new valve stem selas
Overheat	Low oil level	Check engine oil level
	Slow idle speed	Set idle speed to specification
	Faulty oil pressure switch	Install new switch
	Colgged oil filter	Install new oil filter
	Worn parts in oil pump	Replace worn parts or pump
	Thin or diluted oil	Change oil to correct viscosity
	Excessive bearing clearance	Measure bearings for correct clearance
	Oil relief valve stuck	Remove valve and inspect, clean and reinstall
	Oil pump cover bent or cracked	Install new oil pump
	Oil screen loose or clogged	Clean or replace screen
Insufficent coolant	Radiator leakage	Correct or replace
	Loose or damage radiator hose, heater hose	Retighten or replace
	Themostat water pump leakage	Retighten or replace
Radiator clogged	Coolant dirty	Replenish
	Damaged radiator cap	Replace
High coolant tem-	Damaged themostat	Replace
perature	Loose or broken belt	Correct or replace

# 9. CHECK POINT

# **CHECKING COOLANT RESERVIOR**

- 1. Use an adapter to attach the cap to the tester.
- 2. Increase the pressure until the gauge stops moving. Check that the pressure level is maintained at or above the limit.

Main valve opening pressure	0.75 ~ 1.05 kgf/cm <sup>2</sup>
Main valve closing pressure	0.65 kgf/cm <sup>2</sup>

3. Replace the radiator cap if the reading does not remain at or above the limit.

**NOTE** 

Be sure that the cap is clean before testing, since rust or other foreign material on the cap seal will cause an incorrect reading.

# **CHECKING COOLANT**

- 1. Check that the coolant level of the reservoir tank is between FULL and LOW marks.
- 2. Check that the coolant is not mixed with oil.
- 3. The standard coolant concentration range is as below.

Standard	30 ~ 60% (normal range)
----------	-------------------------

### **CAUTION**

If the concentration of coolant falls below 30% or above 60%, vapor corrosion is not inhibited, cooling is not efficient or the engine part could become damaged or not work properly.

#### 3. Antifreeze ratio

Delivery	Freezing	Coolant quantity (9.51)	
condition	temperature(°C)	Mixture ratio(%)	Antifreeze quantity( <i>l</i> )
	-15	30	10
40%	-20	35	2.45
	-25	40	2.80

## **REPLACE COOLANT**

- 1. Loosen and remove the drain plug.
- 2. Remove the reservoir tank and drain coolant.
- 3. After draining the coolant, pour water into the coolant reservoir cap and clean the coolant passage.
- 4. Securely tighten the radiator drain plug.
- 5. Install the reservoir tank.
- 6. Fill the reservoir tank up to FULL line with coolant.

Coolant	3.9 <i>l</i>	Engine capacity
quantity	9.5 <i>l</i>	Overall capacity including the reservoir tank and radiator

- 7. Securely install the coolant reservoir cap.
- 8. Check the coolant quantity after warming up the engine and add coolant.
  - **CAUTION**

Do not open the coolant reservoir cap when it is hot. Steam and scalding liquids released from a hot cooling system can burn you badly.

## **CHECKING ENGINE OIL LEVEL**

- 1. Pull out the engine oil indicator(dipstick) and wipe it clean with clothing.
- 2. Insert the indicator into the oil level gauge guide.
- 3. Remove the indicator carefully and check that the oil level is between LOW and HIGH marks as shown in the illustration.


#### 

- Make sure the vehicle is on a level ground.
- If the engine is running, turn the engine off and wait a few minutes before checking.
- 4. If the oil level is below the LOW mark, add enough recommended oil.

Engine oil	Diesel	Above API CD SAE 10W30
------------	--------	------------------------

Oil levels above the HIGH mark may cause engine damage.

5. After starting the engine, let it idle for a few minutes, stop the engine and recheck the engine oil level is within the normal range.




## **REPLACING ENGINE OIL**

### **CAUTION**

When replacing engine oil and oil filter, do not drop engine oil in the alternator. Engine oil placed in the alternator may harm the alternator.

- 1. After warming up the engine, remove the oil filler cap.
- 2. Remove the drain plug and drain oil.
  - CAUTION Protect yourself from the hot oil.
- 3. Tighten the drain plug.
- 4. Add new oil to the oil filler.




# CHECKING AND ADJUSTING DRIVE BELT TENSION

1. Inspect tension by pressing in the middle of belt with 10 kg<sup>.</sup> f as shown in the illustration.

#### Standard

Alternator


10 ~ 13 mm



# CHECKING AND ADJUSTING DRIVE BELT TENSION

**CAUTION** 


Inspect tension after rotating the engine to one turn counterclockwise.



# **BELT ADJUSTMENT**

- 1. Loosen the alternator support nut.
- 2. Loosen the alternator brace bolt.
- 3. Move the alternator to increase the belt tension to the standard value.


Standard	10 ~ 13 mm
----------	------------



4. When using a tension gauge, move the alternator to the standard tension value.

#### Standard

	50 ~ 70 kg
Standard	40 kg




# VALVE CLEARANCE ADJUSTMENT

1. Warm up the engine until the coolant temperature reaches  $80 \sim 90^{\circ}$ C.

2. Measure the valve clearance at arrow positions shown in the illustration.

Description	Hot engine
Exhaust valve	0.25 mm
Intake valve	0.25 mm





- 3. If the measured value exceeds the standard, loosen the locker arm nut and adjust clearance with the adjust screw turning using a thickness gauge.
- 4. Tighten the lock nut to the specified torque with the adjusting nut fixed not to rotate using a screwdriver.
- 5. Rotate the crankshaft to 360° place the cylinder no.4 to the dead point.
- 6. Measure valve clearance at arrow positions shown in the illustration.


	(): Cold engine
Item	Hot engine
Exhaust valve	0.25 (0.15) mm
Intake valve	0.25 (0.15) mm


- 7. If the measured value exceeds the standard, adjust it as the procedures (6)~(7).
- 8. Inspect clearance of the intake and exhaust valves and adjust it if required.

Standard	0.25 mm
----------	---------









# VALVE CLEARANCE ADJUSTMENT

- 1. Check the engine oil, starter and battery for normal operation.
- Warm up the engine until the coolant temperature reaches 80~90°C.
- 3. Engage the gauge adapter and install the preheat plug to the pressure gauge.

## 1-24

4. Crank the engine and measure the pressure.


Limit (250rpm)	19.2 kg/cm <sup>2</sup>
----------------	-------------------------


5. Check that the measured value of each cylinder is within the limit.


Limit	3.0 kg/cm <sup>2</sup>
	_

# **CHECKING COMPRESSED PRESSURE**

- 1. Disassemble the timing belt upper cover.
- 2. Rotate the crankshaft clockwise to place the cylinder no.1 to the dead point. Check that the timing mark on the sprocket is aligned.








- 4. Rotate the crankshaft clockwise to the second gear of the camshaft sprocket.
- 5. Fix the tensioner groove bolt and tighten the spiral bolt to the specified torque.

Tightening torque	2.2 ~ 3.0 kg · m
-------------------	------------------




- 6. Rotate the crankshaft counterclockwise to align it to the timing mark.
- 7. Check the belt tension by pressing the middle of cam sprocket and injection pump sprocket with hand.


Standard	4 ~ 5 mm


8. Assemble the timing belt upper cover.


# ADJUSTING TIMING BELT "B" TENSION

- 1. Disassemble the timing belt upper cover.
- 2. Rotate the crankshaft clockwise to place the cylinder no.1 to the dead point.










- 4. Loosen the spiral bolt to a turn and the groove nut to 1-2 turns.
- 5. First tighten the tensioner groove bolt and then the spiral bolt to the specified torque.

#### Tightening torque

Bolt	2.0 ~ 2.7 kg · m
Nut	2.2 ~ 3.0 kg · m

- 6. Assemble the access cover.
- 7. Install the timing belt upper cover.




### 1-26

# **CHECKING INJECTION TIMING**

1. Stop the cold starting advance angle function. Insert a screwdriver into the lever lower groove and turn it as shown in the illustration.

## **CAUTION**

Do not turn the lever too much.




- 2. Insert the spacer (thickness: 10mm) between the rod and adjusting screw.
- 3. Remove the screwdriver.
  - **CAUTION**

When checking and adjusting to replace the injection pump, stop the advance angle function not to result in lack of power.

# WAX TYPE COLD STARTING EQUIPMENT

This unit is adopted at low temperature to properly correct the fuel injection timing according to the engine coolant temperature.





# STRUCTURE


1. Wax is sealed in the cold starting equipment, so the piston rod is operated according to the engine coolant temperature.

 The lever is rotated by the piston and the roller puller is operated by pin(B) to control the injection timing in retard or advance. The torsion spring pushes the piston to the injection timing advance angle direction.

3. According to the engine coolant temperature except for the injection timing, the rod connected in the accelerator lever adjusts the engine idle speed.







## **ADJUSTING INJECTION TIMING**


## **CAUTION**


Adjust the injection timing with the engine stopped.


- 1. Rotate the crankshaft to place the cylinder no.1 to the compression dead point.
- 2. Loosen the four union nuts in the injection pump side injection pipe and temporarily tighten them. Fix the distribution holder using a spanner not to be turned during loosening the union nut.


3. Loosen the injection pump mounting nut and temporarily tighten it.

4. Remove the timing check plug from the injection pump.












5. Before installing the special tool, check that the push rod is jutted out about 10mm. Protrusion of the push rod is adjusted by the inner nut.



6. Install the dial gauge by installing the special tool to the injection pump.



- 7. Align the crank pulley to  $30^{\circ}$  front of the cylinder no.1 compression dead point.
- 8. Set the dial gauge to read '0'.
- Slightly move the crank pulley notch left and right and check that the pointer moves away from 0 position.
   If the pointer is unstable, realign the notch position to 30° front of the dead point




10. Rotate the crankshaft to the right to place the pulley notch to  $5^{\circ}$ .

Normal injection timing	ATDC 5°
-------------------------	---------


Recheck the dial gauge is within the standard.

Standard

 $1\pm$  0.03 mm



- 11. If the pointer of dial gauge is out of the standard values, move the injection pump body left or right to correct and tighten the injection pump mounting nut and bolt to the specified torque.
- 12. After adjusting, repeat the procedures (7) and (10) to check that the adjustment is correct.



- 13.Detach the dial gauge and special tool and install the gasket and plug.
- 14. Install the injection pipe nut.Fix the spanner not to turn the distribution holder together.
- 15. Install a new gasket and tighten the plug to the specified torque.


Tightening torque	2.3 ~ 3.7 kg · m


# CHECKING AND ADJUSTING ENGINE IDLE SPEED

- CAUTION
   Only use the idle speed adjusting screw.
- 1. Before checking and adjusting
  - Engine coolant temperature: 80~90°C
- 2. Check the injection timing and valve clearance and adjust them if required.
- 3. Install the idle speedometer.
- 4. Measure the engine idle rpm.

Standard	$750\pm100$ mm
----------	----------------

- 5. If the measure the value is out of the standard, loosen the lock nut and adjust it within the standard values by turning the adjusting screw.
- 6. After adjusting, tighten the lock nut.






## CHAPTER 2. ENGINE MECHANICAL SYSTEM

1.	CYLINDER HEAD ASSEMBLY	2-1
2.	TIMING SYSTEM	2- 14
3.	FRONT CASE	2- 25
4.	MAIN MOVING SYSTEM	2- 31
5.	CYLINDER BLOCK	2- 41

## **1. CYLINDER HEAD ASSEMBLY**

## 1) LOCKER ARM & CAM SHAFT


#### COMPONENTS



#### INSPECTION


#### CAMSHAFT

 Visually inspect the camshaft journals and replace them if they are damaged and burned.
 If the camshaft journals have burned, check the cylinder head bearing for damage and the cylinder head oil passage for clogging.



2. Measure the camshaft diameter and bearing inner diameter and if the oil clearance exceeds the limit value, replace the camshaft, cylinder head or both.

Standard	0.05 ~ 0.08 mm
Limit	0.13 mm



3. Check the cam surface for abnormal wear or damage and replace it if required.

Measure the cam height (bigger diameter) and replace it if it exceeds the limit.

Standard	37.05 mm
Limit	36.55 mm

#### **ROCKER ARM**

- 1. Check the contact surface with the cam and replace the rocker arm if it damaged and burned.
- 2. Visually check the inside for damage or burn and replace it if required.
- 3. Measure the inner and outer diameters and if the oil clearance exceeds the limit, replace the rocker arm, shaft or both.

Standard	0.01 - 0.04 mm
Limit	0.08 mm

#### **ROCKER SHAFT**

- 1. Check the oil passage for clogging and clean it if required.
- 2. Check the rocker arm assembly for damage or burn and replace it if required.

#### ASSEMBLY


#### **CAM SHAFT**


1. Measure A and B, calculate the end play, and if the value exceeds the limit, replace parts.

#### B - A = End play

Standard	0.01 - 0.04 mm
Limit	0.08 mm

2. Install the camshaft with the dowel pin upward to the cylinder head.






#### CAM SHAFT BEARING CAP

Assemble the camshaft bearing cap in sequence of the identification number engraving on the upper surface of bearing cap.

#### CAM SHAFT OIL SEAL

- 1. Using the special tool, press-fit a new camshaft oil seal to the front bearing cap portion.
- 2. Apply oil to the oil seal lip portion.




#### **ROCKER ARM (EXHAUST, INTAKE)**

Take care not to make mistakes of the identification numbers.

#### **ROCKER ARM SHAFT**

- 1. Assemble the oil passage side shown in the illustration, facing it downward.
- 2. The shaft having one oil passage should be assembled in the front.




#### PACKING

Apply sealant to the marked portion in the illustration.


Specified sealant

3M P/No. 8660 or equivalent




#### ADJUSTING VALVE CLEARANCE

1. Rotate the crankshaft clockwise to align the camshaft sprocket with the timing mark.



2. Adjust the valve clearance at the arrow position shown in the illustration.




- 3. Loosen the adjusting screw mounting nut.
- 4. Adjust the valve clearance by turning the adjusting screw.

#### Standard (Cold engine)

Intake	0.15 mm
Exhaust	0.15 mm

5. Fix the adjusting screw not to turn using a screwdriver and install the adjusting nut




- 6. Rotate the crankshaft to one turn clockwise to place the cylinder no.4 to the compression dead point.
- 7. Follow the procedures (2), (3) and (4) to adjust the valve clearance.

#### Standard (Hot-engine)


Intake	0.25 mm
Exhaust	0.25 mm

8. After installing the engine assembly to the vehicle, inspect the valve clearance with hot engine and adjust it if required.



## 2) CYLINDER HEAD & VALVE

#### COMPONENTS





KCMB750A

#### DISASSEMBLY

#### **CYLINDER HEAD BOLT**


Using the special tool, Cylinder Head bolt Wrench (09221-32000), loosen 18 Cylinder head bolts and remove them. Loosen the bolts in the sequence shown and in two to three steps.





#### VALVE SPRING RETAINER LOCK

- 1. Using a valve spring compressor (09222 21000), compress the spring and fit the retainer lock in position.
- 2. The valve spring, if compressed excessively, causes the bottom end of retainer to be in contact with, and damages, the stem seal.



#### **INSPECTION**

#### **CYLINDER HEAD**

- 1. Before cleaning the cylinder head, check for water and oil leaks, damage, or cracks.
- 2. Remove oil, scale, sealant, and carbon deposits completely. After cleaning the oil passages, apply compressed air to ensure that the passages are not clogged.


3. If there is gas leak from the cylinder head gasket surface, measure the surface flatness. If distortion exceeds the limit, replace the cylinder head.

Standard value	0.05 mm less than
Limit L	0.2 mm

4. Visually check the camshaft bearing internal surfaces for damage or seizure. If defects are evident, replace the bearing.


#### INTAKE VALVE, EXHAUST VALVE

1. If the valve stem develops wear (taper wear) or damaged, replace. If there is a dent in the stem end face (the surface in contact with the rocker arm adjust screw), replace.



- 2. Check the valve face for contact. If the contact is not proper, correct with a valve refacer. The contact pattern with the valve seat must be even at the center of valve face.
- 3. Replace if the margin (valve head thickness) exceeds the limit.

Standard value	2.0 mm
Limit	1.0 mm




#### **VALVE SPRING**

1. Measure the free height of spring and replace if the limit is exceeded.

Standard value	49.1 mm
Limit	48.1 mm

2. Measure the squareness of the spring and, if the limit is exceeded, replace.


Standard value	2° less than
Limit	4°



#### VALVE GUIDE

Measure the valve guide to stem clearance and, if the measurement exceeds the limit, replace the valve guide or valve, or both.

		1
Ctondovel velve	Exhaust	0.05 ~ 0.09 mm
Standard value	Intake	0.03 ~ 0.06 mm
Limit	Intake	0.10 mm
	Exhaust	0.15 mm




#### **RECONDITIONING VALVE SEAT**

- 1. When reconditioning the valve seat, inspect clearance between the valve guide and valve and replace the valve guide if required.
- 2. Using the special tool or valve grinder, correct the seat width and angle to the specified value.

#### VALVE SEAT CUTTER

Cutter angle	Parts number
45°	09221-43300
65°	09221-43400
30°	09221-43500


3. Apply compound to the valve and seat.



#### VALVE SEAT REPLACEMENT PROCEDURE


- 1. Cut the valve seat to be replaced from the inside to thin the wall thickness. Then, replace the valve seat.
- 2. Rebore the valve seat hole in cylinder head to the oversize valve seat diameter.

Intake valve seat ring hole	0.30 O.S.	43.300 ~ 43.325mm
diameter	0.60 O.S.	43.600 ~ 43.625mm
Exhaust valve seat ring hole	0.30 O.S.	37.300 ~ 37.325mm
diameter	0.60 O.S.	37.600 ~ 37.625mm



#### 2-10

- Before fitting the valve seat, either heat the cylinder head up to approximately 250°C (482°F) or cool the valve seat in liquid nitrogen to prevent the cylinder head bore from abrasion.
- 4. After installation, recondition the valve seat.



#### VALVE GUIDE REPLACEMEMT PROCEDURE

- 1. Using the push rod of Valve Guide installer (09222 32200) and apress, remove the valve guide forward cylinder block.
- 2. Rebore valve guide hole to the new oversize valve guide outside diameter.

0.05 O.S.	13.050 ~ 13.068 mm
0.25 O.S.	13.250 ~ 13.268 mm
0.50 O.S.	13.500 ~ 13.518 mm


#### **CAUTION**


Do not reassemble the same size of valve guide.

3. Using Valve Guide Installer (09222-32200), press-fit the valve guide, working from the cylinder head top surface.


#### **▲** CAUTION

Take care not to change the exhaust and intake valve guides because both lengths are not equal.





- 4. After installing valve guides, insert new valves in them to check for sliding condition.
- 5. When replacing the valve guides, inspect valve contact and correct the valve seat if required.




#### INSTALLATION

#### VALVE STEM SEAL

1. Using Valve Stem Seal Installer (09222 - 32100), install the valve stem seal into the valve guide.


#### **CAUTION**

- The valve stem seal must be not reused.
- The special tool must be used for the installation of the valve stem seal. Improper installation could result in oil consumption through valve guide.



#### **VALVE SPRING**

Direct the valve spring end with identification color to the therocker arm.




#### 2-12

#### VALVE SPRING RETAINER LOCK

Using a valve spring compressor (09222 - 21000), compress the spring and fit the retainer lock in position.

#### 

The valve spring, if compressed excessively, causes the bottom end of retainer to be in contact with, and damages, the stem seal.



#### **CYLINDER HEDA GASKET**


- 1. Clean contact surfaces between the cylinder head and cylinder block gasket.
- 2. Assemble the gasket facing upward the marking portion in the illustration.

#### **CYLINDER HEAD BOLT**

- 1. Scrape off gasket adhered to cylinder head assembly.
- 2. Tighten in the numerical order indicated in the diagram in two or three groups with special tool.

#### **Specified torque**


Limit	11.5 ~ 12.5 kg⋅m
Cold engine	10.5 ~ 11.5 kg⋅m



## 2. TIMING SYSTEM

## 1) TIMING BELT

#### COMPONENTS



KCMB850A

#### REMOVAL


#### TIMING BELT


- 1. Remove the cooling fan, water pump, crankshaft pulley and timing belt cover.
- 2. Turn the crankshaft to bring the piston in No. 1 cylinder to the top dead center on the compression stroke.
- 3. Mark an arrow on the back of the timing belt and timing belt B with a chalk to indicate the direction of rotation. This ensures that the belt is installed in the same direction for reuse.
  - A CAUTION


Stained belts with water or oils may be highly short enedtheir life. So, the removed timing belt, sprocket and tensioner should not be washed off, as well as not be stained with oils. If the belts are seriously stained, replace them.

4. The piston in No. 1 cylinder is at the top dead center on the compression stroke when all timing marks at the three places are aligned as shown.

5. Slightly loosen the two bolts securing the tensioner. Then, slide the tensioner toward the water pump and tighten the bolts temporarily to secure the tensioner in place.








#### **CAMSHAFT SPROCKET**

- 1. Loosen the bolt securing the camshaft sprocket and remove the camshaft sprocket.
- 2. Remove the sprocket nut.
  - CAUTION

Use care not to give shock to the fuel injection pump shaft, as it could result in defective fuel injection pump. Using Injection Pump Sprocket Puller (09314 -43000) or suitable tool, remove the sprocket from injection pump.

3. Remove the tensioner and tensioner spring.




#### INSPECTION


#### TIMING BELT

Carefully inspect the belt and replace it with a new one if there are damages presented as below.


 Hardened back surface of rubber Back surface is glossy, Non-elastic and so hard that, when your fingernail is pressed into it, no mark is produced.



- 2. Cracked back surface of rubber
- 3. Cracked or separating canvas
- 4. Badly worn out teeth (initial stage)
- 5. Badly worn out teeth (last stage)




 Side of belt cracked Normal belt should have precisely cut side as if produced by a sharp knife.



7. Cracked tooth bottom


Initial state: Canvas worn (swollen canvas fiber, low quality of rubber, discolored with white, and bad clearness) Latter state: Canvas worn and rubber exposed (tooth width narrowed)

8. Missing tooth



#### TIMING BELT TENSIONER

- 1. Check it for smooth rotation and abnormal noise and replace it if required.
- 2. Check it for clicking sound and rolling and replace it if required.




#### **TIMING BELT COVER**

- 1. Check it for deformation and crack and replace it if required.
- 2. Check the seal for wear and damage and replace the timing belt if required.

#### INSTALLATION

#### **CRANKSHAFT SPROCKET**


- 1. Mount the crankshaft sprocket to the crankshaft noting the direction of the sprocket as well as the flange.
- 2. Mount the camshaft sprocket and tighten the flange bolts to specified torque.
- 3. Be careful of the flange installation direction.



#### TIMING BELT TENSIONER

- 1. Install the tensioner, tensioner spring and tensioner spacer.
- 2. The tensioner moved all the way to the water pump, temporarily tighten bolt.

CAUTION When installing, face the short end of tensioner spring toward the water pump.




#### TIMING BELT


- 1. Correctly line up timing marks on three sprockets.
- 2. While ensuring that the tension side of timing belt is not slack, install belt onto the crankshaft sprocket, injection pump sprocket, tensioner and camshaft sprocket, in that order.

#### CAUTION

- When installing the belt onto the injection pump sprocket, keep the sprocket in position, as it tends to turn by itself at the timing mark alignment position.
- If the belt is to be reused, make sure that the arrow mark made during disassembly faces to the correct direction at reassembly.



3. Check if all timing marks are aligned correctly.



- 4. Back off tensioner bolt A, that have previously been secured to the water pump side, one to two turns to give tension to the belt using tensioner spring tension.
- 5. Confirm that the timing belt is correctly engaged with three sprockets.

#### **CAUTION**


Turn crankshaft clockwise by the two teeth of the camshaft sprocket and keep the position. Camshaft sprocket

- 6. Tighten bolt A.
- 7. Tighten bolt B.
  - **CAUTION**

If the bolt B is tightened first, the tensioner should be turned together, causing an undue tension to be applied to the timing belt.


- 8. Turn the crankshaft in the direction of backward rotation to line up timing marks.
- 9. In this condition, ensure that the deflection when the center of belt is pushed by the index finger.

Standard 4 ~ 5 mm




#### FLANGE INSTALLATION

Note that bolt holes in the flange and those in the injection pump sprocket are offset positioned at one place. When assembling, position the jlange and sprocket as shown.



## 2) TIMING "B"


### COMPONENTS



#### REMOVAL

#### TIMING BELT "B"

- 1. Remove the timing belt.
- 2. Using chalk or the like, put an arrow on the back of the timing belt "B" to indicate the direction of drive.




- 3. Slightly loosen the bolts and nuts securing the tensioner. Then, slide the tensioner toward the water pump and tighten the nuts to secure the tensioner in place temporarily.
- 4. Remove the timing belt "B".
- 5. Remove the crankshaft sprocket "B".
- 6. Remove the two silent shaft sprockets.

#### SILENT SHAFT SPROKCET(LEFT, RIGHT)

When loosening the nut and bolt for two silent shaft sprockets, be sure to lock the silent shaft as shown.

#### 


Water, oil, or grease on the belt shortens its life drastically. Use special care to ensure that the removed timing belt, sprockets, and tensioner are free from oil and grease.




#### 2-22

#### INSTALLATION

1. Mount the crankshaft sprocket "B"to the crankshaft, noting the direction of the sprocket "B".




2. The spacer must be installed with its chamfered end facing toward the silent shaft. If the spacer is installed in the wrong direction, damage to oil seal will result.



## TIMING BELT "B" TENSIONER

- 1. Install the tensioner spring and spacer, with the tensioner moved all the way to the water pump.
- 2. Tigh ten the nut. Tighten the bolt not fully put finger tight.




#### TIMING BELT "B"


- 1. Line up timing marks on the crankshaft sprocket B, and right and left silent shaft sprockets.
- 2. With the timing belt B installed, ensure that its tension side is not slack.

#### CAUTION

If the belt is to be reused, make sure that the arrow mark made during disassembly faces to the correct direction at reinstallation.

3. With the tension side of timing belt B kept tight by pushing the slack side (indicated by A in illustration) with a finger, make sure that the timing marks are properly aligned with each other.







- 4. Back off tensioner B nut, that have previously been secured to the water pump side, one to two turns to give tension to the belt using tensioner spring tension.
- 5. First tighten the timing belt "B" tensioner mounting nut and then the bolt.
  - CAUTION

If the bolt is tightened first, the tension B should be turned together, resulting in reduced timing belt B tension.

6. Ensure that the deflection is 4 to 5 mm (0.0394 to 0.1969 in.) when the belt is pushed by the index finger at the position indicated by and arrow.

Belt deflection 4 ~ 5 mm






2-24

## **3. FRONT CASE**

## 1) FRONT CASE, SLIENT SHAFT, OIL PAN

#### **COMPONENTS**



KCMB150A


#### REMOVAL

#### **OIL PAN**

Remove the oil pan by tapping the oil pan bottom edge or drain plug with a soft hammer.


**CAUTION** 

Do not insert a chisel or screwdriver between the oil pan flange and cylinder block to remove the oil pan. It may deform the oil pan flange surface.




#### FLANGE BOLT REMOVAL

1. Remove the plug on the right side of the cylinder block.



- 2. Insert a screwdriver (cross slotted) into the plug hole not to turn the silent shaft.
- 3. Remove the flange bolt.



#### INSPECTION

#### SILENT SHAFT

- 1. The oil holes must be free from clogging.
- 2. Check journal for seizure, damage, and contact with the bearing. If defects are evident, replace the silent shaft, bearing, or front case assembly.
- 3. Check the silent shaft for oil clearance. If wear is excessive, replace the silent shaft bearing, silent shaft, or front case assembly.

#### STANDARD VALUE

Front left	0.02 ~ 0.6 mm
Front right	0.02 ~ 0.05 mm
Rear	0.05 ~ 0.09 mm

#### FRONT UPPER CASE, FRONT LOWER CASE

Check them for damage and crack. Replace them if required.


#### **OIL PAN**


Check the gasket surface for deformation and replace it if required.

#### REPLACEMENT

#### SILENT SHAFT

1. Use Bearing Installer Stopper (special tool) only for removal and reinstallation of the right bearing.





 Using Bearing Installer Stopper and Silent Shaft Bearing Puller (09212 - 43300, 09212 - 43100), remove two rear bearings from the cylinder block.


3. Using Bearing Installer Stopper and Silent Shaft Bearing Puller (09212 - 43300, 09212 - 43100), remove two rear bearings from the cylinder block.

4. When press-fitting the right bearing, align the bearing oil hole with the cylinder block oil hole.

#### INSTALLATION

#### OIL SEAL

Install special tools in drive gear and apply to engine oil to drive gear shaft.




Silent shaft bearing

Plug

Cylinder block


09212 - 43200

Bearing




Oil hole

KCMB180D




#### SILENT SHAFT GEAR

- 1. Apply engine oil to the gear.
- 2. Align the mating marks on the silent shaft drive gear and driven gear and assemble them to the front lower case




#### FRONT LOWER CASE

When tightening the bolts, be sure to secure the silent shaft in position.




#### FRONT OIL SEAL


- 1. Install the special tool guide to the crankshaft and apply engine oil to the outer surrounding.
- 2. Using the special tool, assemble the front oil seal to the case.



#### **FLANGE BOLT**

- 1. Insert a screwdriver (cross slotted) into the plug hole not to turn the silent shaft(right).
- 2. Assemble the flange bolt and tighten it to the specified torque.





#### **OIL PAN**


- 1. Remove the sealant attached in the cylinder block and oil pan gasket surface.
- 2. Apply sealant to the oil pan flange to the thickness of 4mm.
- 3. After applying sealant, assemble the oil pan and tighten the bolt to the specified torque in 15 minutes.

Tightening torque	0.6 ~ 0.8 kg⋅m
-------------------	----------------

## 4. MAIN MOVING SYSTEM

## 1) CRANK SHAFT & FLY WHEEL

#### COMPONENT




#### INSPECTION


#### CRANKSHAFT

- 1. Visually inspect the journals and pins for damage and replace them if required.
- 2. Measure the journal O.D. and main bearing I.D. and if the clear ance exceeds the limit, replace the main bearing (and crank shaft if required).


Or, grind the crankshaft to undersize and replace it with the undersize main bearing.

Standard	0.02 ~ 0.05 mm
Limit	0.01 mm






 When grinding the crankshaft to undersize, ensure correct fillet radius dimensions in journals and pins.




## CRANKSHAFT OIL CLEARANCE (PLASTIGAGE METHOD)

- 1. Wipe crankshaft O.D. and bearing I.D. clean of oil.
- 2. Install the crankshaft.
- 3. Put a strip of Plastigage lengthwise in the center of the journal.



- 4. Replace the main bearing cap carefully and tighten bolts to specification.
- 5. Remove bolts and carefully remove the main bearing cap.
- 6. Using the scale printed on the bag of plastigage, measure the amount the Plastigage has been flattened (the widest point).




#### **CRANKSHAFT FRONT AND REAR OIL SEALS**

- 1. Wear and damage in oil seal lips.
- 2. Deteriorated or hardened rubber.
- 3. Cracks or damage on oil seal case.

#### **RING GEAR**

- 1. If the ring gear teeth are worn, damaged, or broken, replace the ring gear.
- 2. If the teeth are damaged or broken, check the starting motor pinion.
- To remove the ring gear for replacement, tap its outer rim one place after another. Heating the gear makes it impossible to remove. To install the ring gear onto the flywheel, heat it up to 260-280°C (500-536°C) : it is a shrink fit in the flywheel.



#### FLYWHEEL

- 1. Visually inspect the flywheel clutch disc surface for wear and damage and replace it if required
- 2. If the clutch disc surface rolling exceeds the limit, replace it.


Limit	0.13 mm

#### DRIVE PLATE (AUTOMATIC TRANSAXLE)

Check the drive plate for deformation, damage and crack and replace it if required.


#### INSTALLATION

- 1. Install the upper crankshaft bearing to the cylinder block. There is oil hole in the upper crankshaft bearing.
- 2. Install the lower crankshaft bearings to each bearing cap and apply engine oil to the bearing surface.




#### **BEARING GAP**

1. Install the main bearing to the cylinder block. Ensure the correct cap number and arrow mark direction.




2. Check to ensure that the crankshaft turns smoothly and there is an adequate end play.

Standard	0.05 ~ 0.18 mm
Limit	0.25 mm




#### OIL SEAL CASE

Using special tool, press-fit a new crankshaft rear oil seal into the oil seal case.




#### **OIL SEPARATOR**

Push oil separator into the oil seal case. Make sure that the oil hole in the separator comes at the bottom (indicated by an arrow in illustration.)



## 2) PISTON



#### INSPECTION

#### **PISTON**

- 1. Check each piston for scuffing, scoring, wear and other defects. Replace any piston that is defective.
- 2. Check that the piston pin fits in the piston pin hole.


#### CAUTION Replace the piston and piston pin as an assembly.

- 3. Replace any piston and pin assembly that is defective.
- 4. The piston pin must be smoothly pressed by hand into the pin hole (at room temperature).


#### **PISTON RING**

- 1. Check each piston ring for breakage, damage and abnormal wear. Replace the defective rings.
- 2. When the piston requires replacement, its ring should also be replaced.

Item		TC	NA
Standard	No.1 No.2 OIL	0.056 ~ 0.076 0.046 ~ 0.066 0.02 ~ 0.065	0.03 ~ 0.07 0.08 ~ 0.12 0.02 ~ 0.065
imit	No.1 No.2 OIL	0.1 0.1 0.	5




3. Measure the clearance between piston ring and ring home.




4. Place a piston ring in the cylinder bore and set it square by pushing it down with piston.

l!	tem	тс	NA
Standard	No.1 No.2 OIL	0.30 ~ 0.50 0.41 ~ 0.54 0.25 ~ 0.45	0.25 ~ 0.40 0.45 ~ 0.60 0.20 ~ 0.40
Limit		0.	8




#### **CONNECTING ROD BEARING**

 Check the bearing surfaces for uneven contact pattern, streaks, scratches, and seizure. If defects are evident, replace. If the surfaces are seriously nicked and seized, check also the crankshaft. If the crankshaft is also damaged, replace the crankshaft or grind to undersize for reuse.




 Measure the connecting rod bearing I.D. and crankshaft pin O.D. If the clearance (oil clearance) exceeds the limit, replace the bearing and, if necessary, the crankshaft. Or, grind the crankshaft to an undersize and, at the same time, replace the bearing with an undersize.

Standard	0.02 ~ 0.05 mm
Limit	0.1 mm




#### **CONNECTING ROD BUSHING**

1. Pull out the bushing using the special tool.




Press-fit the bushing using the special tool.
 At this time, align the busing with connecting rod small end oil hole.




3. Adjust the busing inner diameter within the standard values.

Standard	29.015 ~ 29.025 mm
----------	--------------------




## **CAUTION**

1. Insert the piston pin, following the front mark.




2. Install the snap ring in the following direction.



### INSTALLATION


#### **PISTON RING INSTALLATION**

- 1. Install the oil ring expander and oil ring to the piston.
- 2. Then, install No.2 piston ring and No.1 piston ring, in that order. Make sure that the ring side, on which manufacturer and size marks are stamped, faces to the piston crown.




#### **PISTON & CONNECTING ROD ASSEMBLY**

- 1. Apply engine oil to the piston surface, piston ring and oil ring.
- 2. Adjust gap between the piston ring and oil ring as shown in the illustration.



- 3. Insert the piston and connecting rod assembly from above the top of cylinder. Ensure that the front mark on piston crown and that (ID mark) on the connecting rod face toward the front of engine (to the crank pulley side).
- Clamp firm the piston rings with the ring band and install the piston assembly into cylinder. Do not strike it hard into the piston, as broken piston ring or damaged crank pin could result.




5. When assembling, align the bearing cap with the connecting rod.

If parts are new ones, align notches in the same direction.


6. Make sure the clearance of connecting rod big end side.

Standard	0.10 ~ 0.25 mm
Limit	0.4 mm



## **5. CYLINDER BLOCK**

## 1) CYLINDER BLOCK



#### INSPECTION

- - Before inspection and repair, clean parts to remove dirt, oil, carbon, deposits, and scale.
  - Before cleaning the cylinder block, be sure to check for evidences of water leaks and damage.
  - Romove contaminants from oil holes with compressed air and, at the same time, make sure that they are not blocked.

## **CYLINDER BLOCK**


- 1. Check for scratches, rust, and corrosion. Use also a flaw detecting agent for the check. If defects are evident, correct or replace.
- 2. Using a straightedge and thickness gauge, check the cylinder block top surface for flatness. Lay the straightedge longways and crossways as indicated by A, B,... in illustration. If flatness is not within the limit, replace the cylinder block. At measurement, ensure that the cylinder block top surface is free from any traces of gasket material.


Standard	0.05 mm
Limit	0.1 mm

3. Check cylinder wall for scratches and seizure. If defects are evident, correct (to oversize) or replace.

4. Using cylinder gauge, measure the cylinder bore. If it wears out excessively, bore the cylinder to oversize and replace the piston and piston rings. Measurement points are as shown.

Standard 9	1.10 ~ 91.13 mm
------------	-----------------





#### **BORING OF CYLINDER**

1. Using the maximum cylinder bore as a basis, determine the oversize piston to be used.

#### There are four oversize pistons available :

Size	Identification mark
0.25 mm(0.01 in.) O.S.	0.25
0.50 mm(0.02 in.) O.S.	0.50
0.75 mm(0.03 in.) O.S.	0.75
1.00 mm(0.04 in.) O.S.	1.00

### 

Sizes are marked on the pistons.

2. Based on the piston O.D. measured, calculate the boring dimension.

#### • Boring dimension

Piston O.D. + 0.04 to 0.06 mm (piston to cylinder clearance) - 0.02 mm (0.0008 in.) (honing margin).

4. Bore cylinders to obtain the calculated boring dimension.

#### CAUTION


To prevent thermal distortion due to temperature rise during boring operation, bore cylinders in the sequence of No. 2, 4, 1 and 3.

- 5. The cylinders must be honed to finish dimension.
- 6. Check clearance between piston and cylinder.

Olasmanas	TC	NA
Clearance	0.02 ~ 0.08 mm	0.03 ~ 0.05 mm

#### **CAUTION**


- 1. When boring cylinders, finish all of four cylin ders to the same oversize.
- 2. Don't bore only one cylinder to oversize.




## 2) REPLACING CYLINER SLEEVE

### REMOVAL

- Fix the cylinder block with a boring machine before centering. Centering should be done in the lower part of the cylinder sleeve where has little abnormal wear.
- 2. Bore the sleeve until the thickness is 0.5mm.
- 3. Insert the processed screwdriver as shown in the illustration between the cylinder sleeve and cylinder block and remove the cylinder sleeve by tapping on the screwdriver slightly. Be careful not to damage the cylinder block wall.






## INSPECTION

- 1. After removing the cylinder sleeve, inspect the cylinder block sleeve hole surface.
- 2. If there are damages, scuffing, abnormal wear and other defects, bore the cylinder block sleeve hole to oversize.

 Measure the cylinder sleeve O.D. and cylinder block sleeve hole I.D. with a gauge placed as shown in the illustration. Measure D1, D2 and D3 in the directions of X and Y and if the average value is below 0.12mm, bore the sleeve hole to 0. 5mm oversize and press-fit the oversized sleeve into the sleeve hole.




Be sure when boring the cylinder, all sleeves should be removed from all cylinders not to make mistakes during rounding.


#### PRESS-FIT

- 1. Without boring cylinder block sleeve hole
  - 1) Apply press oil to the cylinder block sleeve hole surface and sleeve outer surface.
  - 2) Put a flat rounded plate on the sleeve top end and pressfit it with a hydraulic press.

	Press-fit load	2200kg or more
--	----------------	----------------


 Press-fit the sleeve until the sleeve top end surface is flush with the block top surface.
 Press-fit it toward the chamfer as shown in the illustration.






 To prevent the cylinder sleeve and cylinder block top surfaces from roughness and bump, cut the cylinder block top surface.

Difference between them should be '0' as possible. (The limit: 0.2mm)



5) Chamfer the cylinder sleeve top end as shown in the illustration.



 Cylinder sleeve I.D. is processed with 90.08~90.10mm, after press-fitting the sleeve, hone the bore to be within the standard value.


Cylinder bore	91.10~91.13mm
Honing surface formation	2~4
Honing rendering angle (Cross-hatch)	15~25°
Cylinder bore perpendicularity	0.05mm

- 2. Boring cylinder sleeve hole
  - 1. Prepare a 0.5mm oversized cylinder sleeve.
  - 2. Hone the cylinder block sleeve hole to 94.025~94.050mm.
  - Press-fit the cylinder sleeve and render the bore.
     For press-fit and process procedures, refer to "Without boring block sleeve hole".

#### **INSPECTION AFTER ASSEMBLY**

- After assembling the crankshaft and piston, inspect protrusion of the piston.
   If the protrusion is out of the limit, replace the piston inserted into thin one to be the protrusion within the limit.
- 2. After procedure 1, if the protrusion is not within the limit, replace the cylinder block.


Limit	1.1 mm
-------	--------



# **CHAPTER 3. LUBRICATION**

1.	OIL FILTER	3- 1
2.	OIL PAN	3- 5
3.	OIL PUMP	3-7

## **1. OIL FILTER**




## REMOVAL

#### **OIL PRESSURE SWITCH**

To remove the oil pressure switch, use Oil Pressure Switch Wrench (09260 - 32000).

#### **CAUTION**

During removal, use care to prevent damage to the sealant applied to threads.



#### INSPECTION


#### **OIL FILTER BRACKET**


- 1. The oil filter mounting surface must be free from damage.
- 2. Check for cracks and oil leaks.

### OIL PRESSURE SWITCH

1. Connect a tester ( $\Omega$  range) between the terminal and the body of the switch to check for continuity. The switch is normal if there is continuity. If there is no continuity, replace the switch.

2. Insert a thin rod in the oil hole of the switch and push it in lightly. The switch is normal if no continuity is detected (infinite resistance on the tester). If there is continuity, replace the switch.






Apply a 0.5 kg/cm<sup>2</sup> pressure to the oil hole. The switch is normal if there is no continuity. Also check for air leaks. If any air leaks are detected, the cause may be a broken diaphragm. Replace the switch if it leaks.

#### **OIL JET, CHECK VALVE**

- 1. Check the oil jet and check valve for clogging.
- 2. Check the oil jet for damage and deformation.




#### **OIL COOLER BYPASS VALVE**

1. Ensure that the dimension L measures the standard value under normal temperature and humidity.

Dimension L	34.5mm
-------------	--------

2. The dimension must be the standard value when measured after the valve has been dipped in 100°C.


Dimension L	40mm
-------------	------



## INSTALLATION

#### OIL JET

There are two types of oil jets installed: one for No. 1 and 3, and the other for No. 2 and 4. Make sure that the correct one is installed with correct direction as shown.




#### **OIL JET SWITCH**

1. Before installation, apply sealant to the switch threads.

#### **CAUTION**

- The sealant must not get into the thread top surface.
- Use care not to torque excessively.


## 2. OIL PAN



## REMOVAL

#### **OIL FAN**


When the oil pan is stuck with the gasket, remove it by tapping the drain plug downward with a plastic hammer or equivalent.



## INSTALLATION


#### **OIL FAN**

1. Remove the gaskets attached in the oil pan and cylinder block using a scrapper, wire brush, etc.




2. Cut the nozzle attached to the liquefied gasket as shown in the illustration. The liquefied gasket comes out with 4mm diameter.


Semi-dry sealant MZ 100080 THREEBOND TB1212
--



3. Squeeze the liquefied gasket from the tube and apply it to the oil pan as shown in the illustration.




## 3. OIL PUMP



#### DISASSEMBLY

Before removing the oil pump outer and inner gears, mark the outer gear to make sure that it goes back to the position with correct direction.



#### INSPECTION

#### **OIL PUMP ROTOR**

- 1. Install the outer and inner gear into the front case and make sure that they turn smoothly with no excessive play between them.
- 2. Check the side clearance (the front case and oil pump cover surface).

Standard	0.04 ~ 0.10 mm
Limit	0.15 mm

3. Measure the body clearance and if the measure value ex ceeds the limit, replace the gear or case.

Item	Standard	Limit
Inner rotor	0.22 ~ 0.35 mm	0.5 mm
Outer rotor	0.12 ~ 0.22 mm	0.4 mm


4. Check the oil pump cover rotor contact surface for wear and if there is bump, replace the cover. (If the individual part is not available, replace it as an oil pump case assembly).

#### INSTALLATION

#### OIL PUMP INNER ROTOR/OIL PUMP OUTER ROTOR

1. Apply engine oil to all rotor surfaces.

2. Install the gear in the same direction as markings represented during disassembly.



 When air pressure of 0.5kg/cm<sup>2</sup> is applied to the oil hole, if there is no continuity, it is normal.
 If air leakage is detected, replace the switch because the dia phragm may be damaged.

#### OIL JET, CHECK BELT


- 1. Check the oil jet and check valve for clogging.
- 2. Check the oil jet nozzles for damage or deformation.

## OIL COOLER BYPASS VALVE

1. Standard value of 'L' at room temperature.

Standard	34.5mm

2. Limit value of 'L' after coming out from oil of 100°C.




# **CHAPTER 4. COOLING SYSTEM**

1.	WATER PUMP & WATER PIPE	<b>4</b> - '	1
2.	RADIATOR FAN MOTOR	4- 4	4
3.	THERMOSTAT	4- 8	8
4.	RADIATOR	<b>4</b> - <sup>-</sup>	10

## **1. WATER PUMP AND WATER PIPE**

#### **COMPONENTS**



KCMB300A

### INSTALLATION

#### **DRIVER BELT**

Inspect the following items and replace them if required.

- 1. Loose belt
- 2. Damage, crack, and wear


#### WATER PUMP & HOSE

- 1. Water pipe for crack, damage and clogging
- 2. Water hose for crack, damage and clogging

#### WATER PUMP

Check each part for cracks, damage or wear, and replace the water pump assembly if necessary.

- 1. Coolant leaks
- 2. Coolant leaks from A
- 3. Water pump body for damage and crack
- 4. Impeller for damage and crack
- 5. Bearing for damage




## ASSEMBLY

#### WATER PUMP

- 1. Clean the gasket contact surfaces inserting between the water pump and cylinder block.
- 2. Bolt sizes are as below.

No	Hardness category	dx1	Torque
1	4T	4T	1.2~1.5 kg⋅m
2	4T	4T	1.2~1.5 kg⋅m
3	7T	7T	2.0~2.7 kg⋅m




#### WATER PIPE & O-RING


1. Fit water pipe O-ring in the groove provided at water pipe end, wet the periphery of water pipe O-ring and insert water pipe.

CAUTION

Do not apply oil and grease to water pipe O-ring.



## 2. RADIATOR PAN MOTOR




### INSPECTION

#### **COOLING FAN**


- 1. Check the blades for damage and cracks.
- 2. If any portion of fan is damaged or cracked, replacecooling fan.

#### **FAN CLUTCH**

- 1. Check the case joint and seal for oil leakage from the pan clutch.
- 2. Oil leakage may cause overheating the engine resulting from the pan speed decrease.
- 3. Check the bimetal strip for damage




## **RADIATOR PAN MOTOR**



### INSPECTION

## WATER TEMPERATURE GAUGE UNIT


1. Put the sensor in water and increase the water temperature measure the resistance.



- 2. If the measurement radically deviates from specification, replace.
- 3. Measure the resistance across terminal (A) and body for water temperature gauge element and across terminal (B) and body for glow control element.

#### Standard

Terminal (A)	0.4Ω / 70°C
(For coolant temp)	23.8Ω / 115°C
Terminal (B)	24.8Ω / -20°C
(For preheat plug)	3.25Ω / 20°C



#### THERMO SWITCH (FOR A/CON)


- 1. After inserting the coolant temperature switch into oil, heat the oil.
- 2. Check that the coolant temperature switch is turned OFF when the oil temperature reaches the standard.

#### Standard

Coolant temperature at A	$113 \pm 3^{\circ}\mathrm{C}$
Coolant temperature at B	106°C


#### A CAUTION

Only engine oil is available and stir the oil during heating. Do not overheat.



## 3. THERMOSTAT

## COMPONENTS



KCUB040C


**4-8** 

### INSPECTION

- 1. Check that valve closes tightly at room temperature.
- 2. Check for defects or damage.


3. Immerse thermostat in container of water.

Opening valve temperature	$82\pm2^\circ C$
	$76.5\pm2^\circ\mathrm{C}$




## ASSEMBLY

Assemble the thermostat in the direction shown in the illustration.



## 4. RADIATOR



### **INSPECTION**


- 1. Check between the radiator pins for foreign material.
- 2. Check the radiator pins for bending or damage.
- 3. Check the radiator for contamination, damage or rust.
- 4. Check the radiator hose for crack, damage or deformation.
- 5. Check the reservoir tank for damage.
- 6. Check the radiator cap spring for damage.
- 7. Check the radiator cap packing for damage or crack.

# CHAPTER 5. INTAKE AND EXHAUST SYSTEM

1.	INTAKE AND EXHAUST MANIFOLD	5- 1
2.	TURBO CHARGER (TC)	5- 3
3.	AIR CLEANER	5- 8

# **1. INTAKE AND EXHAUST MANIFOLD**

### COMPONENTS



- 1. Exhaust fitting
- 2. Gasket
- 3. Oil return pipe
- 4. Oil return pipe gasket
- 5. Exhaust manifold
- 6. Turbo charger gasket
- 7. Turbo charger assembly


KCMB600A

## ASSEMBLY

#### **TURBO CHARGER ASSEMBLY**


Remove the heat protector.

Be careful of foreign material not to come in the oil passage during cleaning.




## EYE BOLT

Before installing the oil pipe eyebolt (turbocharger upper part), fill the turbocharger with clean engine oil. After full filling, check that the turbine and compressor wheel are rotating smoothly.



# 2. TURBO CHARGER (TC)

## **COMPONENTS** [D4BF]



## **TURBO CHARGER [TC]**


## DISASSEMBLY

#### **TURBINE HOUSING**

Before removal, make the mating mark on compressor cover bearing housing and turbine housing.


**CAUTION** 

Be sure not to damage the compressor and turbine wheel blade.



#### **SNAP RING**

Remove the snap ring using snap ring filler.



### CARTRIDGE ASSEMBLY


Remover by tapping the compressor cover of cartridge assembly with plastic hammer.

## 🔟 ΝΟΤΕ

O-ring installed around the cartridge assembly may cause tight installation sometimes.

### 


- Use a heavy duty carbon solvent to loosen the carbon from the parts.
- Do not use caustic solutions, wire brushes, or wire wheels to remove carbon deposits from any turbo charger part.



#### INSPECTION

#### **TURBINE HOUSING**

1. Check the inner housing contacting turbine wheel for crack, pitching and other damages caused by overheat.




2. Make sure that the waste gate valve lever operates freely by hands.

#### **COMPRESSOR COVER**

Make sure there are no damages on the inner housing surface contacting compressor wheel.

#### **CARTRIDGE ASSEMBLY**

- Turbine wheel and shaft assemblies with cracks in the blades or broken blades can not be used again. If the blades are slightly bent, it can be used again but severely bent blades can not be reused.
- 2. Check if there are foreign materials disturbing the oil flow in the oil passage of cartridge assembly.



#### OIL PIPE AND OIL RETURN PIPE

Check the oil pipe and oil return pipe for clogging and deformation. Repair or replace them if required.

## TURBO CHARGER [TC]


#### WASTE GATE INSPECTION

Check the waste gate rod operation under the pressure below.

#### Pressure

TCI engine

Approx. 0.80kg/cm<sup>2</sup>




### ASSEMBLY

#### **O-RING ASSEMBLY**

Apply engine oil to the new O-ring thinly and assemble the cartridge assembly.

#### **CAUTION**

Take care not to damage the O-ring.




#### COMPRESSOR COVER/CARTRIGE ASSEMBLY


- 1. Install the cartridge assembly to the compressor cover with them mating as marked when disassembling.
- 2. When replacing it with a new one, install it as shown in the left illustration.
  - CAUTION When installing the cartridge assembly to the compressor cover, take care not to damage the compressor wheel blade.

#### **SNAP RING**

Install the snap ring with the compressor cover downward.

CAUTION Install the snap ring with the chamfer upward.





#### 5-6

#### **TURBINE HOUSING**


Install the cartridge assembly to the compressor cover with them mating as marked when disassembling.

## A CAUTION

Take care not to damage the compressor wheel blade.

# 3. AIR CLEANER

## COMPONENTS




# **CHAPTER 6. ENGINE ELECTRICAL**

1.	GENERAL	<b>6-</b> ′	1
2.	SPECIFICATIONS	6- 2	2
3.	SERVICE SPECIFICATIONS	6- 3	3
4.	TIGHTENING TORQUE	6- 3	3
5.	TROUBLESHOOTING	6- 4	4
6.	ALTERNATOR	<b>6-</b> ′	11
7.	STARTER MOTOR	<b>6-</b> ′	17
8.	GLOW PLUG	6- 2	26

# 1. GENERAL


## **STARTER MOTOR**

Starter motor is a reduction drive type.




## ALTERNATOR

Alternator is electronic voltage regulator built-in type.



## **GLOW PLUG**

Glow plug uses AGS.



# 2. SPECIFICATIONS

## ALTERNATOR

Item	Specification	Remark
Туре	Battery voltage sensing	
Rated output	12V / 50A	
Motor speed	1,000 ~ 10,000 rpm	
Voltage regulator type	Electronic voltage regulator, with vacuum pump	
Regulator setting voltage	14.4 ± 0.3V	
Temperature compensated	-10 ± 3 mV/°C	

### **STARTER MOTOR**

Item		Specification	Remark
Output		12V / 2.2KW (Generator, Excavator, Loader)	
		24V / 5KW (Bus aircon)	
Number of	pinion teeth	13	
No-load	Terminal voltage	11V	
characteristics	Amperage	30A	

## **GLOW PLUG**

Item	Auto glow
Identification mark	Y-115T
Туре	Sheathed type

# **3. SERVICE SPECIFICATIONS**

## ALTERNATOR

Item	Standard	Limit
Brush length		Wear limit
Slip ring O.D.	33mm	32.2mm
Rotor coil resistance (at 20°C)	2.75 ± 0.2Ω	

## **STARTER MOTOR**

No-load characteristics voltage (Bus aircon)	11V (23V)	
Amperage (Bus aircon)	130A (95A)	
Revolution number (Bus aircon)	4500rpm (3300rpm)	
Pinion gap	0.5~2.0mm	
Commutator O.D.	29.4mm	28.4mm
Undercut	0.5mm	0.2 mm
Outer round	0.05mm	0.1mm
Brush length		Wear limit

## **GLOW PLUG**

Resistance AGS	$0.5\Omega$ (Generator, Excavator, Loader)	
	10 $\Omega$ (Bus aircon)	

# **4. TIGHTENING TORQUE**

Item	Torque (kg.m)	Remark
Lock bolt	1.2 ~ 1.5	
Generator support bolt nut	2.0 ~ 2.5	
Eye bolt	1.4 ~ 1.9	
Starter motor attaching bolt	2.7 ~ 3.4	
Glow plug	1.5 ~ 2.0	
Glow plug plate attaching nut	0.1 ~ 0.15	

# 5. TROUBLESHOOTING

## STARTING SYSTEM

Trouble symptom	Probable cause	Remedy
Starter spins but engine will not crank	Starter motor faulty	After removing the starter motor, check the drive for crack and wear
	Flywheel ring gear teeth broken	Replace flywheel ring gear or torque con- verter
Engine will not crank	Battery cables loose, corroded or worn out	Repair or replace cables
	Battery charge low	Charge or replace battery
	Cables loose or cables wear	Tighten or replace cables
	Starter motor faulty	Repair or replace starter motor
Engine cranks slowly	Battery cables loose, corroded or worn out	Repair or replace cables
	Battery charge low	Charge or replace battery
	Starter motor faulty	Repair or replace starter motor

## **CHARGING SYSTEM**


Trouble symptom	Probable cause	Remedy
Low battery	Wiring connection loose	Tighten loose connections
	Overload	Check and remove the accessories if re- quired
	Worn battery	Replace battery
	Generator faulty	Repair or replace
	Electronic voltage regulator faulty	Replace voltage regulato
	Battery faulty	Check the battery or replace, if necessary

## **GLOW CONTROL SYSTEM**

Trouble symptom	Probable cause	Remedy
Engine will not start below	Wiring connection loose or bad wiring	Repair or replace wiring
50°C	ECT sensor malfunction	Replace ECT sensor
	Glow plug malfunction	Repair or replace glow plug
	Glow plug control unit failed	Replace glow control unit
After first combustion, en-	Wiring connection loose or bad wiring	Repair or replace wiring
gine stall or rough idle be- low 50°C	Glow plug malfunction	Check the resistance of glow plug and replace, if necessary
	Glow plug relay malfunction	Check the relay and replace, if necessary
	Glow plug control unit failed	Check the control unit and replace, if nec- essary
Yellow glow lamp will not	Open lamp	Replace lamp
turn-ON	Wiring connection loose or bad wiring	Repair or replace wiring
	Shorted wiring	Repair or replace wiring
	Glow plug control unit failed	Replace control unit, if necessary

## **VEHICLE INSPECTION**

## **SPECIFICATIONS**



#### **NOTE**

#### Register with diode

 According to battery voltage detective type alternator adoption, when the charge warning lamp is short, to get the charging function, the continuity circuit of the L terminal (field coil) is installed parallel with the circuit of the charge warning lamp.

### INSPECTION

Check the following items before inspecting voltage regulator adjusting voltage alternator output current.

- 1. Alternator installation
- 2. Alternator drive belt tension
- 3. Battery specific gravity and voltage
- 4. Fusible link
- 5. Abnormal noise from alternator durng operation
  - **NOTE**


Use fully charged battery to obtain the standard value.

## PREPARATION

- 1. Turn ignition switch to "OFF."
- 2. Disconnect the battery ground cable.
- Connect a digital voltmeter between the "S(L)" terminal of the alternator and ground. Connect the (+) lead of the voltmeter to the "S(L)" terminal of the alternator. Connect the (-) lead to good ground or the battery (-) terminal.
- 4. Disconnect the alternator output wire from the generator "B" terminal.
- 5. Connect a DC ammeter (0 to 100A) in series between the "B" terminal and the disconnected output wire. Connect the (-) lead wire of the ammeter to the disconnected output wire.
- 6. Attach the engine tachometer and connect the battery ground cable.

## **REGULATED VOLTAGE TEST**

1. Set the special tool wiring connector, voltmeter and ammeter as following.




2. Check as the following procedures.

No.	Check item	Operation	Determination			
			Normal	Abnormal	Cause	Remedy
1	Voltage between L terminal and earth	Ignition switch: OFF	٥V	Voltage arises	Abnormal wiring or alternator	Correct wiring or repair alternator
		Ignition switch:	2~5V	0V		
		ON		Battery voltage	Faulty ALTR	Repair ALTR
2	Voltage be- tween S terminal and earth	Ignition switch: OFF	Battery voltage	ΟV	Short wiring or fusable link	Correct wiring or replace fusable link
		Ignition switch: ON				
3	Voltage between S terminal and earth (regulator adjust voltage)	Run the engine and keep the engine at 2000~3000rpm.	14.4 ±0.5V (At 20°C)	Highly exceed the standard value	Abnormal IC regulator	Repair ALTR
				Below the standard value	If the output current is 5A or more	fully charge the battery.
					If the output current is 5A or less, the alterna- tor is abnormal.	Repair ALTR

#### **NOTE**

- Adjust voltage becomes slightly low in proportion to the output current, so it is inspected with low output current (approx. 5A or less) of IC regulator.
- Adjust voltage varies according to the IC regulator surrounding temperature, so refer to the characteristics as shown in the left figure.
- If the battery may be discharged or the head lamp is overloaded, the current reads 5A or more. Recheck the battery lamp this time.



## **CURRENT OUTPUT TEST**

- 1. Remove battery ground cable.
- 2. Remove alternator outlet line from alternator "B" terminal. Connect 0-100A test ammeter DC between "B" terminal and remove outlet line in series.
- 3. Connect a voltmeter (0 to 20V) between the "B" terminal and ground.
- 4. Attach an engine tachometer.
- Check that the values on voltmeter and battery are the same.
   OV is caused by a disconnected wire between the alternator "B" terminal and battery (+), or a blown fusible link, or defective ground.
- 6. With headlamp switch ON, start engine. Set headlamps at high beam and heater blower switch to HIGH. Increase engine speed to 2500 rpm and read the maximum output current on the ammeter.

Limit

70% of nominal output current

#### 🔟 NOTE

Read the maximum value quickly as charged current drops repidly. Nominal output current value is indicated on a plate on the alternator.


7. The value on the ammeter should be over the limit value. When the value is under the limit and the alternator outlet wiring [between alternator "B" terminal and battery (+) terminal] is normal, remove the alternator for inspection.

#### **NOTE**

Having headlamps on when checking alternator output current increases the load. Standard current is generated at low speed of alternator. However, output current is stabilized at about 4000rpm alternator speed.

Therefore, the output current at 2500 rpm engine speed exceeds the standard value, and the alternator can be considered as near normal.

8. Alternator output current changes due to load. Therefore, the standard output current may not be obtained due th small electric load despite the charging system being normal. In this case, increase the load and recheck.




## RESULT

- 1. After output current test, bring engine speed to idle. Turn ignition switch OFF.
- 2. Remove battery ground cable.
- 3. Remove ammeter, voltmeter and engine tachometer.
- 4. Connect alternator output line to alternator "B" terminal.
- 5. Connect battery ground cable.

## 6. ALTERNATOR

## COMPONENTS




#### INSTALLATION

#### ALTERNATOR ASSEMBLY

1. For belt tension, refer to Chapter 5 Engine-Service adjustment procedures.

## **COMPONENTS**




#### DISASSEMBLY

#### **FRONT BRACKET**

- 1. With a screwdriver blade inserted between the front bracket and stator core, pry it to separate the stator and the front bracket.
- 2. If they are hard to separate, lightly strike the bracket with a plastic hammer while prying with the screwdriver.

**CAUTION** 

Do not insert the screwdriver too deep as the stator core could be damaged.




# STATOR ASSEMBLY, RECULATOR AND BRUSH HOLDER

- 1. When removing the stator, unsolder the three stator leads from the main diodes.
- 2. When removing the rectifier from the brush holder, unsolder two soldered points.

#### **▲** CAUTION

- When soldering or unsoldering, use care not to expose the diode to soldering iron heat for extended time. Complete soldering or unsoldering in as short a time as possible.
- Do not overstress the diode leads.




## INSPECTION


#### ROTOR

 Check the rotor coil continuity. Make sure that there is continuity between slip rings. Measure the rotor resistance. If it is excessively small, it indicates a shorted rotor, If without continuity or shorted, replace the rotor assembly.

Standard value	3 - 5 ohms


2. Check the rotor coil grounding. Make sure that there is no continuity between the slip ring and core. Replace the rotor assembly if there is continuity.






### STATOR

1. Check the stator continuity. Make sure that there is continuity between coil leads. Replace the stator assembly if there is no continuity.




2. Check the coil grounding. Make sure that there is no continuity between the coil and core. Replace the stator assembly if there is continuity.



#### RECTIFIER


1. Inspection of (+) Heat Sink Assembly

Using a circuit tester, check continuity between the (+) heat sink and the stator coil lead connection terminals. If there is continuity in both directions, the diode is shorted. Then, replace the rectifier assembly.




#### 2. Inspection of (-) Heat Sink Assembly

Check continuity between the (-) heat sink and the stator coil lead connection terminals. If there is continuity in both directions the diode is shorted. Then, replace the rectifier assembly.




#### 3. Inspection of Diode

Trio With a circuit tester connected to both ends of each diode, check continuity of the three diodes. If there is continuity or no continuity in both directions, the diode is damaged. Then, replace the rectifier assembly.




### BRUSH


1. The brush must be replaced if worn to the wear limit line.



2. Unsolder the brush lead wires, and the brush and spring will come out.

3. When installing a new brush, push the brush into the holder as illustrated and solder the leads.






### REASSEMBLY


#### **ROTOR ASSEMLY**

1. Before installing the rotor on the rear bracket, thread a steel wire through the small hole provided in the rear bracket to lift up the brush. After rotor installation, remove the steel wire.



## 7. STRATER MOTOR

## COMPONENTS



## REMOVAL

Remove the starter at the engine room lower portion.

### INSPECTION

#### **PINION GAP ADJUSTMENT**


- 1. Disconnect the field coil wire from the terminal M of the magnetic switch.
- 2. Connect at 12V battery the terminal S and the terminal M.


#### **CAUTION**

This test must be performed quickly within 10 seconds to prevent the switch coil from burning.

- 3. When the battery is connected, the pinion moves out. Now, push back the pinion with a finger and measure the pinion stroke (the travel along which the pinion is pushed back). This is the pinion gap.
- 4. If the pinion gap is not up to specification, adjust by adding or removing fiber washers between the magnetic switch and front bracket. Using more washers makes the gap smaller.

Pinion gap	0.2 ~ 2.0 mm
------------	--------------





#### PULL-IN TEST OF MAGNETIC SWITCH

The pull-in coil is in good condition if the plunger is pulled in to cause the pinion to move out when a battery is connected between the terminals S and M of the magnetic switch. If the pinion does not move out, replace the magnetic switch.

### **CAUTION**


- The connector must be disconnected from terminal M for this test.
- The test must be finished within 10 seconds.


#### HOLD-IN TEST OF MAGNETIC SWITCH

With a battery connected between the terminal S and body of magnetic, manually pull the pinion up to the pinion stopper. The hold-in coil is in good condition if the pinion remains out when releasing it.

#### **CAUTION**

This test must be completed with 10 seconds.






# RETURN TEST OF MAGNETIC SWITCH

With a battery connected between the terminal M and body of the magnetic switch, manually pull the pinion out to the pinion stopper. Body coils are fully operational if the pinion returns immediately when releasing it.


### **CAUTION**

This test must be completed with 10 seconds.



### **NO-LOAD TEST**


- 1. Set up a circuit as shown which connects a starter motor, battery, ammeter, voltmeter, and variable resistance.
- 2. The starting motor should be in good condition if it turns smoothly and steadily when the switch is turned ON with a maximum variable resistance value. Adjust the variable resistor so that the voltmeter reads 11.5V. If the current and rpm are out of specification after this adjustment, troubleshoot according to the table below and take remedial action as required.



## ENGINE ELECTRICAL SYSTEM

Symptom	Possible cause
Large current with low rpm (torque also being small)	<ul> <li>Contaminated bearing</li> <li>Armature coil rubbing pole piece</li> <li>Armature coil shorting</li> </ul>
Large current with no rotation	<ul> <li>Solenoid switch grounding</li> <li>Armature and field coil grounding</li> <li>Seized bearing</li> </ul>
No current flowing with no rotation	<ul> <li>Broken armature and field coils</li> <li>Broken brush and pigtail</li> <li>Improper contact between brush and commutator</li> </ul>
Small current with low rpm (torque also being small)	<ul> <li>Improper field coil connection (Note, however, that open or improperly connected shunt coil only will result in high rpm.)</li> </ul>
Large current with high rpm (torque being small)	Shorted field coil

## COMPONENTS




KD4B6030

## DISASSEMBLY


#### **MAGNETIC SWITCH**

Remove the field coil wire from the terminal M of magnetic.




#### **SNAP RING**

Measure the pinion shaft end play using the feeler gauge for the purpose of reassembly.




#### **SNAP RING AND STOP RING**

1. Using an adequate socket, push the stop ring over the snap ring.



2. Remove the snap ring with a screwdriver, then, remove the stop ring.



#### **CLEANING THE STARTER MOTOR PARTS**


- 1. Do not immerse parts in cleaning solvent. Immersing the yoke and field coil assembly and/or armature will damage the insulation. Wipe these parts with a cloth only.
- 2. Do not immerse the drive unit in cleaning solvent. The overrun clutch is pre-lubricated at the factory and solvent will wash lubrication from the clutch.
- 3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

## INSPECTION

#### CHECKING THE COMMUTATOR


1. Place the armature on a pair of V-blocks, and check the run - out by using a dial gauge.

Standard value	0 ~ 0.03mm
Limit	0.1mm




2. Check the outer diameter of the commutator.

Standard value	32 ±0.1mm
Limit	31.4mm




3. Check the depth of the undercut between segments.

Standard value	0.5mm
Limit	0.2mm




#### FIELD COIL OPEN-CIRCUIT TEST

Check for condinuity between field brushes. There must be continuity.




### FIELD COIL GROUND TEST

Check for continuity between the field coil brush and yoke. There must be no continuity.




#### **BRUSH HOLDER**

Check for continuity between brush holder plate and brush holder. There must be no continuity.



#### **OVERRUNNING CLUTCH**

- 1. Ensure that the pinion locks when turned counterclockwise and turns freely when turned clockwise.
- 2. Check the pinion for wear and damage.





#### BURSHES

1. Check the brush surface in contact with the commutator for surface roughness. Check also the brush length.

Limit Wear limit line
-----------------------

- 2. If the surface has been refaced or brush has been replaced, wrap sand paper around the commutator to correct its surface.
- 3. When removing a worn brush by breaking with pliers, use care to prevent damage to the pigtail.
- 4. Polish the pigtail end for battery soldering with sand paper.
- 5. Insert the pigtail into the hole in a new brush and solder. Make sure that the brush surface is free from excess solder.





#### **ARMATURE COIL SHORT TEST**


- 1. Place the armature on a growler.
- 2. Slowly turn the armature while a thin metal is held above it. The armature coil is not shorted if the metal does not vibrate.


#### CAUTION

Before this test, ensure that the armature surface if free from foreign substances.

### **ARMATURE COIL GROUND TEST**

Check for insulation between the commutator segment and armature coil core. There must be no continuity.






#### 6-24

#### ARMATURE COIL OPEN-CIRCUIT TEST


Check for continuity between segments. There must be continuity.



#### INSTALLATION


#### STOP RING AND SNAP RING

Using a puller of adequate type, pull the stop ring over the snap ring.



## 8. GLOW PLUG

#### COMPONENTS



#### REMOVAL

#### **GLOW PLUG**

Especially ceramic part of glow plug is so fragile that the screw should be removed with the hand after unscrewing it several turns with a tool.


#### INSPECTION

- 1. Check for rust on glow plug plate.
- 2. Check glow plug for damage.

#### **NOTE**


Do not use the plug dropped at the height of 10cm or higher.

3. Check the continuity between the terminal and body as illustrated. Replace if discontinuity or with large resistance.



**NOTE** 

Remove oil from plug before measuring as glow plug resistance is very small.



#### **INSTALLATION**

#### **GLOW PLUG**

Especially ceramic part of glow plug is so fragile that the screw should be removed with the hand after unscrewing it several turns with a tool.


# **CHAPTER 7. FUEL SYSTEM**

1.	GENERAL	7- 1
2.	INJECTION NOZZLE	7- 8
3.	INJECTION NOZZLE HOLDER	7- 10
4.	INJECTION PUMP	7- 12
5.	TROUBLESHOOTING	7- 15

## **1. GENERAL IMFORMATION**

### OVERALL

A distribution-type fuel injection pump is installed in the front upper case and is driven by the timing belt. The fuel is drawn from the fuel tank by a pump inside the fuel injection pump and sent to the injection pump through a filter which contains a water separator. The fuel under pressure enters the pump chamber, where the fuel pressure is regulated by a regulating valve. From the pump chamber, the fuel is sent through the distributor head passage and then the inlet port in the barrel to the high pressure chamber above the plunger. The plunger pumps the fuel and the highly pressurized fuel is injected from the nozzle in accordance with the injection sequence. The excess fuel in the pump housing chamber is returned through the overflow valve and the overflow pipe to the fuel tank. The injection pump is cooled and lubricated by means of fuel circulation. The excess fuel at the nozzle holder is also returned through the overflow pipe with unions on the injection pump to the fuel tank. Since the injection pump is lubricated by fuel, water in the fuel will shorten the pump life to a great degree. Therefore, special care must be taken to prevent the entry of water, dust, etc. into the system.



#### SPECIFICATIONS

	Item	Specification	Remark
Fuel filter type		Cartridge paper filter element type	
Fuel injiction	Туре	Distribution type	
pump	Turning direction	Clockwise as viewed from drive side	
	Injection sequence	1 - 3 - 4 - 2	
	Governor type	Half All Speed	
	Feed pump type	Vane type	
Injection	Nozzle type	Throttle type	
nozzle	Holder type	Screw-on type	

#### SERVICE SPECIFICATIONS

Item		Standard	Limit	
Injiction pump         Injection timing           Cam lift         Cam lift		ATDC 5°		
		2.2mm		
	Plunger diameter		10mm	
	Delivery valve opening pressure		21.5kg/cm <sup>2</sup>	
Fuel cut solenoid		12V/8Ω		
Injiction	Injection orifice (Number-diameter)		1 ~ 1.02mm	
	Pressure	Opening pressure	120kg/cm <sup>2</sup>	110kg/cm <sup>2</sup>
		Adjust pressure	125 ~ 135kg/cm <sup>2</sup>	
	Idle speed		820 ~ 880rpm	

#### **TOQUE SPECIFICATIONS**

Item	Torque (kg·m)
Injection pipe clamp bolts	0.4 ~ 0.6
Injection pipe union nuts	2.3 ~ 3.7
Pump bracket-to-cylinder block bolts	1.8 ~ 2.5
Injection pump-to-pump bracket bolts	2.0 ~ 2.7
Injection pump mounting nuts	1.5 ~ 2.2
Fuel return pipe nuts	3.0 ~ 4.0
Injection nozzle	5.0 ~ 6.0
ning nut-to-nozzle body	3.0 ~ 5.0
Pump sprocket nut	8.0 ~ 9.0

#### SPECIAL TOOLS

Tool (Number and name)	Illustration	Use
09310-43000 Prestroke measuring adapter	D1043000	Injection timing adjustment
09314-43100 Nozzle holder socket wrench	D1443100	Removal of nozzle holder
09314-43000 Injection pump sprocket puller	C1443000	Removal of injection pump sprocket


#### **INSPECTION AND ADJUSTMENT**

#### **ACCELERATOR CABLE**

- 1. Warm engine until stabilized at idle.
- 2. Confirm idle rpm is at prescribed rpm.
- 3. Stop engine.
- 4. Confirm there are no sharp bends in accelerator cable.
- 5. Check inner cable for correct slack.
- 6. If there is too much slack, adjust slack by the following procedures.
  - 1) Loosen adjusting nut. Fully close throttle lever.
  - Tighten adjusting nut until throttle lever just starts moving. Return 1 turn and lock with lock nut. This adjusts accelerator cable play to standard value.

Standard value

approx. 1 mm (0.04 in.)



- 3) Adjust so that accelerator pedal stopper touches pedal arm when throttle lever is fully opened.
- 4) After adjusting, confirm that throttle level fully opens and closes by operating pedal.


#### **EVACUATION OF AIR FROM FUEL LINE**

- 1. When fuel is drained and re-filled for service.
- 2. When fuel filter is replaced.
- 3. When main fuel line is removed.
  - 1) Loosen fuel filter air plug.
  - Place rags around air plug hole. Operate hand pump repeatedly until no bubbles come from plug hole. Tighten air plug.
  - 3) Repeat until hand pump operation becomes stiff.

#### **EVACUATION OF WATER FROM FUEL FILTER**

Water is in the filter when fuel filter indicator lights. Evacuate water by the following procedures.

- 1. Loosen drain plug.
- 2. Drain water with hand pump. Finger-tighten drain plug.



#### **INJECTION NOZZLE**

#### INJECTION START PRESSURE


- 1. Set injection nozzle in nozzle tester and check the following.
- 2. Move nozzle tester handle at about one stroke per second.
- 3. The pressure gauge pointer rises slowly and swings when injection is made. Read the position at which the pointer started to swing. Check the injection start pressure is the standard value.

Standard	Opening pressure	120kg/cm <sup>2</sup>
value	Adjust preesure	125~135kg/cm <sup>2</sup>
	Limit	112kg/cm <sup>2</sup> or more


 If the nozzle is faulty, disassemble and adjust injection start pressure to the standard value by changing the shim thickness. Injection pressure increases by approx. 1,000 kPa (10 kg/ cm<sup>2</sup>,142 psi) as shim thickness is increased by 0.1 mm (0. 0039 in.).

#### 1 CAUTION

When disassembling nozzle holder, be careful not to allow entry of dirt or water.




5. If the injection start pressure can not be adjusted by changing the shim thickness, replace nozzle assembly.



#### **INJECTION STATUS**

Move nozzle tester handle at about 1 stroke per second.




#### **NEEDLE VALVE VIBRATION**

Inject on is normal if the characteristic intermittent sound is heard as the handle is operated, and vibration of the needle valve is felt at the handle.


#### SPRAY

- 1. Check that the spray is good, as illustrated in the figure, in the test, the spray may be bolt shaped with a course mist and fuel may remain. This is phenomenon common in this type of inspection, and the nozzle function is normal.
- 2. Move nozzle tester handle at 4 to 6 strokes per second.
- Confirm the spray is cone shaped with an angle of about 15°. This indicates a good condition.
- 4. If the injection is not good, disassemble nozzle and replace nozzle tip or entire assembly.
- 5. Confirm fuel does not drip after injection.
- 6. If dripping, disassemble injection nozzle and replace nozzle tip or entire assembly.



#### NOZZLE OIL-SEAL


 Maintain internal nozzle pressure (pressure gauge indication value) with the nozzle tester at 10,000-11,000 kPa (100-110 kg/cm<sup>2</sup>, 1,422-1,565 psi). Check for fuel leaking from nozzle tip in this condition.



2. If there is leakage, disassemble injection nozzle and replace nozzle tip or entire assembly.

## 2. INJECTION NOZZLE

#### **COMPONENTS**




#### REMOVAL

1. Injection pipe

When loosening the union nuts, hold delivery valve holder on fuel injection pump head or hexagon nut of fuel return pipe with a wrench to prevent it from rotating along with the union nut.

#### 

Because VE type injection pipe is different from DPC type injection pipe, be careful when you install. (VE type injection pipe is coated yellow)




#### 2. Fuel return pipe

When removing the fuel return pipe nut, hold the fuel return pipe by the hexagon nut with a wrench.

#### **CAUTION**

If you remove the hexagon nut without holding the fuel return pipe nut, the pipe might be damaged. So you must remove the hexagon nut with holding return pipe.




#### 3. Return holder

Using a deep socket wrench, loosen the injection nozzle and remove.

#### **CAUTION**

Write the number of the cylinder on the injection nozzle that has been removed. Cover the opening with an appropriate cap to prevent entry of dust, water and foreign material into the fuel passage land combustion chamber.




#### INSTALLATION

#### **NOZZLE HOLDER**

1. Clean nozzle holder installation area of the cylinder head.

### 


Gasket groove may cause lack of idle RPM.



2. Fit a new nozzle gasket and holder gasket into the nozzle holder hole in the cylinder head.

## **3. INJECTION NOZZLE HOLDER**


#### **COMPONENTS**



#### DISASSEMBLY


#### **RETAINING NUT**

- 1. Retaining nut Lightly clamp the retaining nut with a cushion bracket .
- 2. Hold the retaining nut with a box wrench, and loosen the nozzle holder body using a deep socket wrench.




#### NOZZLE TIP

- Check the nozzle tip for carbon deposits: Scrape off carbon deposits with a piece of wood land clean each part with patrol. After cleaning, keep parts submerged in diesel fuel. Take particular care to protect the nozzle tip needle valve from damage.
- 2. While the nozzle tip is submerged in diesel fuel, check that the needle valve slides smoothly. If the needle valve does not slide smoothly, replace the nozzle tip. When replacing the nozzle tip, completely wash off the anticorrosive oil from the new nozzle tip with clean diesel fuel before using it.
- Check plunger tip "A" for deformation and breakage. If "A" is damaged or broken replace it. Check the surface in contact with the nozzle holder body by using minimum. Check spring for weakness and breakage.




#### **RETAINING NUT**

- 1. Finger-tighten the nozzle holder body.
- 2. clamp the retaining nut in a vise with cushion plates.
- 3. While holding the retaining nut with a box wrench, tighten the nozzle holder body to the specified torque with a deep socket wrench.



## **4. INJECTION PUMP**

#### COMPONENTS




TORQUE : kg·m

#### REMOVAL

#### **FUEL INJECTION PIPE**

To remove the fuel injection pipe, refer to Injection nozzle




#### FUEL INJECTION PUMP SPROCKET

- 1. Rotate the crankshaft to place it to the first cylinder piston compression dead point.
- 2. Place the belt tensioner to the full loose position of timing belt..
- 3. After removing the sprocket mounting nut, remove the sprocket from the pump drive shaft using the special tool or equivalent puller.



Do not tap on the pump drive shaft with a hammer.



4. Leave the sprocket in the timing belt lower cover with the timing belt engaged.

#### **CAUTION**


- Do not burden the timing belt with twist, bend, etc.
- After removing, do not rotate the crank shaft.
- When holding the injection pump, do not pull down the accelerator lever or fast idle lever.
   Do not these levers. It may cause malfunction of the injection pump.

#### INSTALLATION OF FUEL INJECTION PUMP SPROCKET

When installing the sprocket to the injection pump, be sure the timing mark is aligned and tighten the nut to the specified torque.

#### **CAUTION**

After installing the sprocket, adjust the belt tension. (Refer to Timing belt of EM group)



## **5. TROUBLESHOOTING**

### FUEL TANK AND FUEL LINE

Symptom	Probable cause	Remedy
Engine fault caused by	Bend and twist of fuel pipes and hoses	Correct or replace
low fuel supply	Fuel pipes and hoses clogged	Clean or replace
	Fuel filter clogged	Replace
	Water in fuel filter	Drain water from the fuel filter
	Air in fuel filter	Bleed the fuel filter
	Fuel tank inside damaged and rusted	Clean or replace
	Fuel pump fault	Replace

#### FUEL INJECTION SYSTEM

Symptom	Probable cause	Remedy
Engine does not start	No voltage at fuel cut-off solenoid on injec- tion pump	Check for voltage with test light. If necessary, replace fuse or faulty wires.
	Fuel cut-off solenoid on injection pump loose or faulty	Tighten solenoid. Check that solenoid clicks when key is turned OFF and ON. Replace faulty solenoid.
	No voltage at glow plug bus	If test light shows no voltage at bus with key at "O" position, test relay and wiring.
	Glow plug faulty	Test and, if necessary, replace glow plug.
	Air in fuel system	Bleed fuel system.
	Injection pump not delivering fue	If no fuel emerges from a looseness injec- tion pipe during cranking, check timing belt and fuel supply from filter.
	Injection pipes misconnected	Connect pipes in correct location
	Injection timing incorrect	Adjust injection timing.
	Faulty injection nozzles	Check and, if necessary, repair or replace nozzles.
	Faulty injection pump	Try to start engine with new pump installed. If necessary, replace pump permanently.
Idle speed incorrect or idle rough irregular	speed incorrectly adjusted	Check and, if necessary, adjust the idle speed.
	Accelerator control binding	Check that lever on pump is not loose, then adjust accelerator cable.
	Loose fuel hose between filter and injection pump	Replace hose or secure with clamps, bleed air from system.
	Inadequate fuel supply owing to clogged fuel filter, or fuel return line and injection pipes leaking, dirty, kinked, or squeezed at con- nections	Inspect and, if necessary, replace lines and hoses or replace fuel filter.
	Air in fuel system	Bleed fuel system.
	Faulty injection nozzles	Check and, if necessary, repair or replace injection nozzles.
	Injection timing incorrect	Adjust injection timing.
	Faulty injection pump	Try engine at idle with new pump installed. If necessary, replace pump permanently.

### TROUBLESHOOTING

Symptom	Probable cause	Remedy
Smoky exhaust (black, blue or white)	Maximum rpm incorrect	Check and if necessary, replace injection pump.
	Faulty injection nozzles	Check and, if necessary, repair or replace injection nozzles.
	Injection timing incorrect	Adjust injection timing.
	Faulty injection pump	Observe exhaust with new pump installed if necessary, replace pump permanently.
Poor power output, slow acceleration (speedometer accurate,	Injection pump accelerator lever loose or not reaching maximum rpm adjusting screw	Tighten lever, check that accelerator pedal travel is not restricted, then adjust accelerator cable.
clutch not slipping)	Maximum rpm incorrect	Check and, if necessary, replace injection pump.
	Inadequate fuel supply owing to clogged fuel filter, or fuel return line and injection pipes leaking, dirty, kinked, or squeezed at con- nections	Inspect and, if necessary, replace lines and hoses, replaced fuel filter.
	Air in fuel system	Bleed fuel system.
	Ice or solidified wax in fuel lines. (winter time only)	Move car to a warm garage until ice or wax has become liquid, then bleed fuel system.
	Faulty injection nozzles	Check and, if necessary, repair or replace injection nozzles.
	Injection timing incorrect	Adjust injection timing.
	Faulty injection pump	Check acceleration and speed with new pump installed. If necessary, replace pump permanently.
Excessive fuel consumption	Fuel leaks	Check and, if necessary, replace or tighten all pipes, hoses and connections.
	Return pipe and hose blocked	Check return line for kinks and dents. Re- place faulty lines. If line is clogged, blow it out with compressed air, then bleed fuel system.
	Idle speed too fast or maximum rpm too high	Check and, if necessary, adjust idle speed or replace injection pump.
	Injection timing incorrect	Check and, if necessary, repair or replace injection nozzles.
	Faulty injection pump	Check fuel consumption with new pump installed, if unnecessary, replace pump permanently.