1. SAFETY HINTS

1. DAILY INSPECTION

At the beginning of each shift, inspect your truck and fill out a check, maintenance and lubrication table.

Check for damage and maintenance problems.

Have repairs made before you operate the truck.

Do not make repairs yourself. Lift truck mechanics are trained professionals. They know how to make repairs safely.



2. DO'S AND DON'TS



Do watch for pedestrians.



Do wear safety equipment when required.



Don't mix drugs or alcohol with your job.



Don't block safety or emergency equipment.



Don't smoke in NO SMOKING areas or when refueling.



Don't operate the truck outdoors in rainy day.

 \ast Exclude the truck equipped cabin.




Exhaust gas is dangerous. Do not operate the truck at the inhouse, if possible. Provide adequate ventilation when working in a closed space.

3. SEAT BELTS

Always buckle up for the machine equipped with safety belt.




▲ Seat belts can reduce injuries.



4. NO RIDERS

1) The operator is the only one who should be on a truck.



2) Never transport personnel on the forks of a lift truck.




5. PEDESTRIANS

- Watch where you are going. Look in the direction of travel. Pedestrians may use the same roadway you do. Sound your horn at all intersections or blind spots.
- 15D9SOM13
- Watch for people in your work area even if your truck has warning lights or alarms. People may not watch for you.



3) Watch for people standing back, even when you are parked.




6. OPERATOR PROTECTION

- 1) Keep under the overhead guard.
- 2) Always keep your body within the confines of the truck.
- ▲ Do not operate truck without overhead guard, unless condition prevent use of a guard.




7. FORK SAFETY


Never allow anyone to walk under raised forks.



There is special equipment to raise people for overhead work. DO NOT USE LIFT TRUCKS.




Always lower the load slowly. Raise and lower with mast vertical or tilted slightly back (Never forward).




8. PINCH POINTS

A Keep hands, feet and legs out of the mast.



 \mathbf{A} Don't use the mast as a ladder.




A Never try to repair the mast, carriage, chain, or attachment by yourself. Always get a trained mechanic.




9. TRAVEL

- 1) Travel with the load near the floor/ground, with mast tilted back to cradle the load whenever possible.
- A Never lift or lower the load when the truck is in motion.
- 15D9SOM23
- When handling bulky loads that restrict your vision operate your truck in reverse to improve visibility. Be sure to pivot in the seat to give maximum visibility.




3) Unstable loads are a hazard to you and to your fellow workers. Always make certain that the load is well stacked and evenly positioned across both forks. Never attempt to lift a load with only one fork.




10. GRADES, RAMPS, SLOPES AND INCLINES

A Never turn on a grade, either loaded or unloaded.

1) Unloaded-Forks downgrade



2) Loaded - Forks upgrade



11. TIP OVER

1) LATERAL TIP OVER

- Lateral tip over can occur with a combination of speed and sharpness of turn. This combination will exceed the stability of the truck. This condition is even more likely with an unloaded truck.
- (2) With the load or mast raised, lateral tip over can occur while turning and/or braking when traveling in reverse or accelerating and turning while traveling forward.
- (3) Lateral tip over can occur loaded or unloaded by turning on an incline or ramp.


2) LONGITUDINAL TIP OVER


- (1) Longitudinal tip over can occur with combination of overloading and load elevated also with capacity load and elevated. This combination will exceed the stability of the truck. This condition is even more likely with excessive forward tilt, braking in forward travel or accelerating rearward.
- (2) Longitudinal tip over can occur by driving with the load down slope on a steep grade.

Lateral and longitudinal tip over can occur if the truck is driven over objects on the floor or ground, off the edge of improved surfaces, or into potholes in the road surface, or by running into overhead objects or collisions.

An off dock type of tip over can occur if the truck is steered too close to the dock edge, driven off the edge of the dock or ramp, or if the highway truck or trailer rolls away from the dock or is driven away during loading.

- ▲ The conditions listed above can be further aggravated by overloading, excessive tilt, or off center loads.
- ▲ Lift truck tip over can cause serious injury or death if the operator is trapped between the truck and the ground.






- 3) WHAT TO DO IN CASE OF A TIP OVER
- A If your truck starts to tip over, do not jump.
- A Brace yourself as illustrated right.
 - 1. Make sure your seat belt is fastened securely, if the truck is equipped with seat belt.
 - 2. Stay in your seat.
 - 3. Grip the wheel.
 - 4. Brace your feet.
- ▲ Your chances for survival in a tip-over are better if you stay with the truck, in your seat.



12. SURFACE AND CAPACITY


Avoid these conditions. They can cause a truck to tip over or lose traction for braking or driving.

A Know the weight of your truck and load. Especially when using elevators, know the capacity of the elevator you intend to use. Do not overload.




TIP OVER

▲ Seat belts can reduce injuries. ALWAYS BUCKLE UP.




13. PARKING


1) Never park on a grade.




2) Always come to a complete stop before leaving truck. Be sure travel control is in NEUTRAL.



3) Lower forks fully to floor and tilt forward.




- 4) Set parking brake. Position 1 : Lock Position 2 : Release
- 5) Turn key to OFF position.




14. REFUELING


1) Before adding oil, check around machine for oil leakage.



2) Keep away from fire when adding oil or during operation.




3) After adding oil, wipe off any oil spilled on machine.




15. STEP

1) When getting on or off the machine, use the step provided.




2) Do not jump up or down from the machine.




16. OPERATOR'S SAFETY RULES

- 1) All operational functions require that the operator be seated in the operator's seat.
- Always buckle up if a seat belt is provided.



- 2) Parking brake must be locked in the PARK POSITION before exiting from the vehicle.
- ▲ Parking brake must remain locked in the park position (2) except when an operator is in the normal operating position.



3) ANSI/ASME REGULATIONS


▲ This forklift truck is equipped with an Operator Existence Sensing System per ANSI/ASME B56.1 ~ 7.21.10 and 7.21.11 (travel OPSS) or ISO 3961 (travel and mast OPSS).

(1) Traction safety warning

- 1 This function works when the key switch is ON or START position.
- ② The transmission shifts automatically to neutral in 2 seconds from the driver's off the seat.
- 3 At the same time, the alarm will sound intermittently.
- ④ To release the function, the forward-reverse lever must be cycled through neutral with the operator in the normal operating position to regain powered directional control.


17. SIDE SHIFT

A Do not put side loads on forks.




A Restrict the sideshift movement with raised load.

Abrupt sideshifting under such condition will dramatically reduce the stability of machine and may cause over-turning.



Avoid overloading or uneven loading.

Load on forks according to load capacity mentioned on machine name plate when sideshift is applied. Uneven loading will deteriorate the stability of machine when load is raised.



▲ Top of load should not extend above backrest.

