SECTION 1 GENERAL

Group	1	Safety Hints	1-1
Group	2	Specifications	1-10
Group	3	Operational Checkout Record Sheet	1-22

SECTION 2 ENGINE

Group	1	Structure and Function	2-1
Group	2	Engine speed and Stall rpm	2-8

SECTION 3 POWER TRAIN SYSTEM

Group	1 Structure and Function	3-1
Group	2 Operational Checks and Troubleshooting	3-81
Group	3 Test and Adjustments	3-93
Group	4 Disassembly and Assembly	3-95

SECTION 4 BRAKE SYSTEM

Group	1 Structure and Function	4-1
Group	2 Operational Checks and Troubleshooting	4-29
Group	3 Tests and Adjustments	4-36
Group	4 Disassembly and assembly	4-38

SECTION 5 STEERING SYSTEM

Group	1	Structure and Function	5-1
Group	2	Operational Checks and Troubleshooting	5-18
Group	3	Tests and Adjustments	5-26
Group	4	Disassembly and Assembly	5-34

SECTION 6 WORK EQUIPMENT

Group	1	Structure and Function	6-1
Group	2	Operational Checks and Troubleshooting	6-39
Group	3	Tests and Adjustments	6-50
Group	4	Disassembly and Assembly	6-64

SECTION 7 ELECTRICAL SYSTEM

Group	1 Component Location	7-1
Group	2 Electrical Circuit	7-3
Group	3 Monitoring System	7-22
Group	4 Electrical Component Specification	7-72
Group	5 Troubleshooting	7-79

1. STRUCTURE

This service manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This service manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into the following sections.

Structure and function

This group explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

Operational checks and troubleshooting

This group explains the system operational checks and troubleshooting charts correlating problem to remedy.

Tests and adjustments

This group explains checks to be amide before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Disassembly and assembly

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your HD Hyundai Construction Equipment distributor for the latest information.

2. HOW TO READ THE SERVICE MANUAL

Distribution and updating

Any additions, amendments or other changes will be sent to HD Hyundai Construction Equipment distributors.

Get the most up-to-date information before you start any work.

Filing method

1. See the page number on the bottom of the page.

File the pages in correct order.

2. Following examples shows how to read the page number.

Example 1

- 3-3
- Section number (3. Power train system)

Consecutive page number for each section.

3. Additional pages : Additional pages are indicated by a hyphen(-) and number after the page number. File as in the example.

10 - 5

Revised edition mark (123...)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

Revisions

Revised pages are shown at the list of revised pages on the between the contents page and section 1 page.

Symbols

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol Item		Remarks				
	Safaty	Special safety precautions are necessary when performing the work.				
	Safety	Extra special safety precautions are necessary when performing the work because it is under internal pressure.				
*	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.				

3. CONVERSION TABLE

Method of using the Conversion Table

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

Example

- 1. Method of using the Conversion Table to convert from millimeters to inches Convert 55 mm into inches.
 - (1) Locate the number 50 in the vertical column at the left side, take this as (a), then draw a horizontal line from (a).
 - (2) Locate the number 5in the row across the top, take this as b, then draw a perpendicular line down from b.
 - (3) Take the point where the two lines cross as \bigcirc . This point \bigcirc gives the value when converting from millimeters to inches. Therefore, 55 mm = 2.165 inches.
- 2. Convert 550 mm into inches.
 - (1) The number 550 does not appear in the table, so divide by 10 (move the decimal point one place to the left) to convert it to 55 mm.
 - (2) Carry out the same procedure as above to convert 55 mm to 2.165 inches.
 - (3) The original value (550 mm) was divided by 10, so multiply 2.165 inches by 10 (move the decimal point one place to the right) to return to the original value. This gives 550 mm = 21.65 inches.

 (\mathbf{h})

_			50			1mm =	0.03937 in				
		0	1	2	3	4	5	6	7	8	9
	0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
	10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
	20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
	30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
	40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
							C				
a)	50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
	60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
	70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
	80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
	90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Millimeters to inches

Millimeters to inches

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Kilogram to Pound

1kg = 2.2046lb

	0	1	2	3	4	5	6	7	8	9
0		2.20	4.41	6.61	8.82	11.02	13.23	15.43	17.64	19.84
10	22.05	24.25	26.46	28.66	30.86	33.07	35.27	37.48	39.68	41.89
20	44.09	46.30	48.50	50.71	51.91	55.12	57.32	59.5.	61.73	63.93
30	66.14	68.34	70.55	72.75	74.96	77.16	79.37	81.57	83.78	85.98
40	88.18	90.39	92.59	94.80	97.00	99.21	101.41	103.62	105.82	108.03
50	110.23	112.44	114.64	116.85	119.05	121.25	123.46	125.66	127.87	130.07
60	132.28	134.48	136.69	138.89	141.10	143.30	145.51	147.71	149.91	152.12
70	154.32	156.53	158.73	160.94	163.14	165.35	167.55	169.76	171.96	174.17
80	176.37	178.57	180.78	182.98	185.19	187.39	189.60	191.80	194.01	196.21
90	198.42	200.62	202.83	205.03	207.24	209.44	211.64	213.85	216.05	218.26

Liter to U.S. Gallon

1 ℓ = 0.2642 U.S.Gal

	0	1	2	3	4	5	6	7	8	9
0		0.264	0.528	0.793	1.057	1.321	1.585	1.849	2.113	2.378
10	2.642	2.906	3.170	3.434	3.698	3.963	4.227	4.491	4.755	5.019
20	5.283	5.548	5.812	6.6076	6.340	6.604	6.869	7.133	7.397	7.661
30	7.925	8.189	8.454	8.718	8.982	9.246	9.510	9.774	10.039	10.303
40	10.567	10.831	11.095	11.359	11.624	11.888	12.152	12.416	12.680	12.944
50	13.209	13.473	13.737	14.001	14.265	14.529	14.795	15.058	15.322	15.586
60	15.850	16.115	16.379	16.643	16.907	17.171	17.435	17.700	17.964	18.228
70	18.492	18.756	19.020	19.285	19.549	19.813	20.077	20.341	20.605	20.870
80	21.134	21.398	21.662	21.926	22.190	22.455	22.719	22.983	23.247	23.511
90	23.775	24.040	24.304	24.568	24.832	25.096	25.631	25.625	25.889	26.153

Liter to U.K. Gallon

1 ℓ = 0.21997 U.K.Gal

	0	1	2	3	4	5	6	7	8	9
0		0.220	0.440	0.660	0.880	1.100	1.320	1.540	1.760	1.980
10	2.200	2.420	2.640	2.860	3.080	3.300	3.520	3.740	3.950	4.179
20	4.399	4.619	4.839	5.059	5.279	5.499	5.719	5.939	6.159	6.379
30	6.599	6.819	7.039	7.259	7.479	7.969	7.919	8.139	8.359	8.579
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.778
50	10.998	11.281	11.438	11.658	11.878	12.098	12.318	12.528	12.758	12.978
60	13.198	13.418	13.638	13.858	14.078	14.298	14.518	14.738	14.958	15.178
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378
80	17.598	17.818	18.037	18.257	18.477	18.697	18.917	19.137	19.357	19.577
90	19.797	20.017	20.237	20.457	20.677	20.897	21.117	21.337	21.557	21.777

kgf∙	m	to	lbf	•	ft
------	---	----	-----	---	----

 $1 \text{kgf} \cdot \text{m} = 7.233 \text{lbf} \cdot \text{ft}$

	0	1	2	3	4	5	6	7	8	9
		7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	396.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	10005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4

kgf/cm² to lbf/in²

 $1 \text{kgf} / \text{cm}^2 = 14.2233 \text{lbf} / \text{in}^2$

	0	1	2	3	4	5	6	7	8	9
		14.2	28.4	42.7	56.9	71.1	85.3	99.6	113.8	128.0
10	142.2	156.5	170.7	184.9	199.1	213.4	227.6	241.8	256.0	270.2
20	284.5	298.7	312.9	327.1	341.4	355.6	369.8	384.0	398.3	412.5
30	426.7	440.9	455.1	469.4	483.6	497.8	512.0	526.3	540.5	554.7
40	568.9	583.2	597.4	611.6	625.8	640.1	654.3	668.5	682.7	696.9
50	711.2	725.4	739.6	753.8	768.1	782.3	796.5	810.7	825.0	839.2
60	853.4	867.6	881.8	896.1	910.3	924.5	938.7	953.0	967.2	981.4
70	995.6	1010	1024	1038	1053	1067	1081	1095	1109	1124
80	1138	1152	1166	1181	1195	1209	1223	1237	1252	1266
90	1280	1294	1309	1323	1337	1351	1365	1380	1394	1408
100	1422	1437	1451	1465	1479	1493	1508	1522	1536	1550
110	1565	1579	1593	1607	1621	1636	1650	1664	1678	1693
120	1707	1721	1735	1749	1764	1778	1792	1806	1821	1835
130	1849	2863	1877	1892	1906	1920	1934	1949	1963	1977
140	1991	2005	2020	2034	2048	2062	2077	2091	2105	2119
150	2134	2148	2162	2176	2190	2205	2219	2233	2247	2262
160	2276	2290	2304	2318	2333	2347	2361	2375	2389	2404
170	2418	2432	2446	2460	2475	2489	2503	2518	2532	2546
180	2560	2574	2589	5603	2617	2631	2646	2660	2674	2688
200	2845	2859	2873	2887	2901	2916	2930	2944	2958	2973
210	2987	3001	3015	3030	3044	3058	3072	3086	3101	3115
220	3129	3143	3158	3172	3186	3200	3214	3229	3243	3257
230	3271	3286	3300	3314	3328	3343	3357	3371	3385	3399
240	3414	3428	3442	3456	3470	3485	3499	3513	3527	3542

TEMPERATURE

Fahrenheit-Centigrade Conversion.

A simple way to convert a fahrenheit temperature reading into a centigrade temperature reading or vice verse is to enter the accompanying table in the center or boldface column of figures.

These figures refer to the temperature in either Fahrenheit or Centigrade degrees.

If it is desired to convert from Fahrenheit to Centigrade degrees, consider the center column as a table of Fahrenheit temperatures and read the corresponding Centigrade temperature in the column at the left.

If it is desired to convert from Centigrade to Fahrenheit degrees, consider the center column as a table of Centigrade values, and read the corresponding Fahrenheit temperature on the right.

°C		°F	°C		°F	°C		°F	°C		°F
-40.4	-40	-40.0	-11.7	11	51.8	7.8	46	114.8	27.2	81	117.8
-37.2	-35	-31.0	-11.1	12	53.6	8.3	47	116.6	27.8	82	179.6
-34.4	-30	-22.0	-10.6	13	55.4	8.9	48	118.4	28.3	83	181.4
-31.7	-25	-13.0	-10.0	14	57.2	9.4	49	120.2	28.9	84	183.2
-28.9	-20	-4.0	-9.4	15	59.0	10.0	50	122.0	29.4	85	185.0
-28.3	-19	-2.2	-8.9	16	60.8	10.6	51	123.8	30.0	86	186.8
-27.8	-18	-0.4	-8.3	17	62.6	11.1	52	125.6	30.6	87	188.6
-27.2	-17	1.4	-7.8	18	64.4	11.7	53	127.4	31.1	88	190.4
-26.7	-16	3.2	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-26.1	-15	5.0	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-25.6	-14	6.8	-6.1	21	69.8	13.3	56	132.8	32.8	91	195.8
-25.0	-13	8.6	-5.6	22	71.6	13.9	57	134.6	33.3	92	197.6
-24.4	-12	10.4	-5.0	23	73.4	14.4	58	136.4	33.9	93	199.4
-23.9	-11	12.2	-4.4	24	75.2	15.0	59	138.2	34.4	94	201.2
-23.3	-10	14.0	-3.9	25	77.0	15.6	60	140.0	35.0	95	203.0
-22.8	-9	15.8	-3.3	26	78.8	16.1	61	141.8	35.6	96	204.8
-22.2	-8	17.6	-2.8	27	80.6	16.7	62	143.6	36.1	97	206.6
-21.7	-7	19.4	-2.2	28	82.4	17.2	63	145.4	36.7	98	208.4
-21.1	-6	21.2	-1.7	29	84.2	17.8	64	147.2	37.2	99	210.2
-20.6	-5	23.0	-1.1	35	95.0	21.1	70	158.0	51.7	125	257.0
-20.0	-4	24.8	-0.6	31	87.8	18.9	66	150.8	40.6	105	221.0
-19.4	-3	26.6	0	32	89.6	19.4	67	152.6	43.3	110	230.0
-18.9	-2	28.4	0.6	33	91.4	20.0	68	154.4	46.1	115	239.0
-18.3	-1	30.2	1.1	34	93.2	20.6	69	156.2	48.9	120	248.0
-17.8	0	32.0	1.7	35	95.0	21.1	70	158.0	51.7	125	257.0
-17.2	1	33.8	2.2	36	96.8	21.7	71	159.8	54.4	130	266.0
-16.7	2	35.6	2.8	37	98.6	22.2	72	161.6	57.2	135	275.0
-16.1	3	37.4	3.3	38	100.4	22.8	73	163.4	60.0	140	284.0
-15.6	4	39.2	3.9	39	102.2	23.3	74	165.2	62.7	145	293.0
-15.0	5	41.0	4.4	40	104.0	23.9	75	167.0	65.6	150	302.0
-14.4	6	42.8	5.0	41	105.8	24.4	76	168.8	68.3	155	311.0
-13.9	7	44.6	5.6	42	107.6	25.0	77	170.6	71.1	160	320.0
-13.3	8	46.4	6.1	43	109.4	25.6	78	172.4	73.9	165	329.0
-12.8	9	48.2	6.7	44	111.2	26.1	79	174.2	76.7	170	338.0
-12.2	10	50.0	7.2	45	113.0	26.7	80	176.0	79.4	172	347.0

Group	1	Safety Hints	1-1
Group	2	Specifications	1-10
Group	3	Operational Checkout Record Sheet	1-22

GROUP 1 SAFETY HINTS

FOLLOW SAFE PROCEDURE

Unsafe work practices are dangerous. Understand service procedure before doing work; Do not attempt shortcuts.

WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

- Do not wear loose clothing and accessories. Secure long hair. These items can snag on controls or on other parts of equipment.
- Do not wear oily clothes. They are highly flammable.
- Wear a hard hat, safety shoes, safety goggles, mask, leather gloves, earplugs and other protective equipment, as required.
- While working on machine, never use inadequate tools. They could break or slip, or they may not adequately perform intended.

WARN OTHERS OF SERVICE WORK

Unexpected machine movement can cause serious injury.

Before performing any work on the wheel loader, attach a **FDo Not Operate** tag on the right side controller lever.





USE HANDHOLDS AND STEPS

Falling is one of the major causes of personal injury.

When you get on and off the machine, always maintain a three point contact with the steps and handrails and face the machine. Do not use any controls as handholds.

Never jump on or off the machine. Never mount or dismount a moving machine.

Be careful of slippery conditions on platforms, steps, and handrails when leaving the machine.



PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



WORK IN CLEAN AREA

Before starting a job :

- · Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- · Have the right parts on hand.
- Read all instructions thoroughly; Do not attempt shortcuts.

PROTECT AGAINST FLYING DEBRIS

Guard against injury from flying pieces of metal or debris; Wear goggles or safety glasses.





PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



PARK MACHINE SAFELY

Before working on the machine:

- · Park machine on a level surface.
- · Lower bucket to the ground.
- Turn key switch to OFF to stop engine. Remove key from switch.
- Move pilot control shutoff lever to locked position.
- · Allow engine to cool.

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load.

Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands.







HANDLE FLUIDS SAFELY-AVOID FIRES

Handle fuel with care; It is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks. Always stop engine before refueling machine. Fill fuel tank outdoors.



Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags ; They can ignite and burn spontaneously.



Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.

If you must operate in a building, be positive there is adequate ventilation. Either use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring enough outside air into the area.

REMOVE PAINT BEFORE WELDING OR HEATING

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.





ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.



SERVICE MACHINE SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.

STAY CLEAR OF MOVING PARTS

Entanglements in moving parts can cause serious injury.

To prevent accidents, use care when working around rotating parts.





AVOID HIGH PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.





AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials.

Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area. Install fire resisting guards to protect hoses or other materials.

T3031GE16

PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; It may explode. Warm battery to $16^{\circ}C(60^{\circ}F)$.



PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

- 1. Avoid the hazard by:
- 2. Filling batteries in a well-ventilated area.
- Wearing eye protection and rubber gloves. Avoiding breathing fumes when electrolyte is added.
- 4. Avoiding spilling of dripping electrolyte.
- 5. Use proper jump start procedure.
- 1. If you spill acid on yourself:
- Flush your skin with water. Apply baking soda or lime to help neutralize the acid.
- 3. Flush your eyes with water for 10-15 minutes. Get medical attention immediately.
- 1. If acid is swallowed:
- Drink large amounts of water or milk.
 Then drink milk of magnesia, beaten eggs, or vegetable oil.
- 3. Get medical attention immediately.

USE TOOLS PROPERLY

Use tools appropriate to the work. Makeshift tools, parts, and procedures can create safety hazards.

Use power tools only to loosen threaded tools and fasteners.

For loosening and tightening hardware, use the correct size tools. Avoid bodily injury caused by slipping wrenches.

Use only recommended replacement parts. (See Parts catalogue.)





SERVICE TIRES SAFELY

Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion.

Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and not in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.

USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.





DISPOSE OF FLUIDS PROPERLY

Improperly disposing of fluids can harm the environment and ecology. Before draining any fluids, find out the proper way to dispose of waste from your local environmental agency.

Use proper containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

DO NOT pour oil into the ground, down a drain, or into a stream, pond, or lake. Observe relevant environmental protection regulations when disposing of oil, fuel, coolant, brake fluid, filters, batteries, and other harmful waste.



REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.

KEEP ROPS INSTALLED PROPERLY

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.



GROUP 2 SPECIFICATIONS

1. MAJOR COMPONENT



980A2SE01

2. SPECIFICATIONS

1) WITH BOLT-ON CUTTING EDGE TYPE BUCKET (HL980A)





980A2SE03

Description			Unit	Specification
Operating weig	ht		kg (lb)	30800 (67905)
		Struck		4.8 (6.3)
Bucket capacity	/	Heaped	m³ (yd³)	5.6 (7.3)
Overall length		Α		9610 (31' 6")
Overall width		В	-	3450 (11' 4")
Overall height		С		3865 (12' 8")
Ground clearar	nce	D		495 (1' 7")
Wheelbase		E	mm (ft-in)	3700 (12' 2")
Tread		F		2440 (8' 0")
Dump clearanc	e at 45°	G		3300 (10' 10")
Dump reach (fu	ıll lift)	Н		1490 (4' 11")
Width over tires	3	I		3190 (10' 6")
Dump angle		J	dogroo (°)	50
Roll back angle (carry position)		К	degree ()	47
		Lift (with load)		6.6
Cycle time	Dump (with load		sec	1.5
		Lower (empty)		4.8
Maximum trave	l speed		km/hr (mph)	36.5 (22.7)
Braking distand	e		m (ft in)	13.3 (43' 8")
Minimum turnir	ng radius (cente	r of outside tire)	III (II-III)	6.42 (21' 1")
Gradeability			degree (°)	30
Breakeout force	Э		kg (lb)	24670 (54390)
		First gear		6.2 (3.9)
Ferruard		Second gear		11.6 (7.2)
	Forwaru	Third gear		18.2 (11.3)
Travel speed		Fourth gear	km/hr (mph)	36.5 (22.7)
		First gear		6.2 (3.9)
	Reverse	Second gear		11.6 (7.2)
		Third gear		25.3 (15.7)

WITH BOLT-ON CUTTING EDGE TYPE BUCKET (HL980A XT)





980A2SE03-1

Description			Unit	Specification	
Operating weig	ht		kg (l b)	31500 (69450)	
Ducket conceits	_	Struck	a (_ la)	4.8 (6.3)	
Bucket capacity	1	Heaped	m³ (yd³)	5.6 (7.3)	
Overall length		A		9930 (32' 7")	
Overall width		В		3450 (11' 4")	
Overall height		С		3865 (12' 8")	
Ground clearan	ce	D		495 (1' 7")	
Wheelbase		E	mm (ft-in)	3700 (12' 2")	
Tread		F		2440 (8' 0")	
Dump clearance	e at 45°	G		3620 (11' 11")	
Dump reach (fu	ll lift)	Н		1525 (5' 0")	
Width over tires		I		3190 (10' 6")	
Dump angle		J	dograa (°)	50	
Roll back angle (carry position)	К	degree ()	47	
		Lift (with load)		6.6	
Cycle time	e Dump (with loa		sec	1.5	
		Lower (empty)		4.8	
Maximum trave	speed		km/hr (mph)	36.5 (22.7)	
Braking distanc	е		m (ft in)	13.3 (43' 8")	
Minimum turnin	g radius (center	of outside tire)	· · · (· · · ·)	6.42 (21' 1")	
Gradeability			degree (°)	30	
Breakeout force)		kg (l b)	24400 (53795)	
		First gear		6.2 (3.9)	
	Forward	Second gear		11.6 (7.2)	
	Forward	Third gear		18.2 (11.3)	
Travel speed		Fourth gear	km/hr (mph)	36.5 (22.7)	
		First gear		6.2 (3.9)	
	Reverse	Second gear		11.6 (7.2)	
		Third gear		25.3 (15.7)	

3. WEIGHT

lte	em	kg	lb
Front frame assembly		2993	6598
Rear frame assembly		3309	7259
Front fender (LH/RH)		53/53	116/116
Counterweight (HL980A)		1229	2709
Counterweight (HL980A XT	Г)	1758	3875
Cab assembly		976	2151
Engine assembly		860	1895
Transmission assembly (4-	speed/5-speed)	889/951	1959/2096
Drive shaft (front)		50	110
Drive shaft (center)		47	103
Drive shaft (rear/upper)		29/16	63/35
Front axle (include different	ial)	1876	4135
Rear axle (include differenti	ial)	1873	4129
Tire (29.5 R25, ★★, L3)		598	1318
Hydraulic tank assembly		433	954
Fuel tank assembly		472	1040
Main pump assembly/Stee	ring pump assembly	49/50	108/110
Fan & brake pump assemb	ly	12	26
Main control valve (2 spool/	/3 spool)	106/125	233/275
Flow amplifier		29	64
Room assembly	HL980A	2130	4695
Boom assembly	HL980A XT	2240	4938
Bell crank assembly		645	1420
Bucket link		103	227
5.6 m ³ bucket, with bolt on a	cutting edge	2835	6250
Boom cylinder assembly		276	608
Bucket cylinder assembly		303	668
Steering cylinder assembly		61	134
Seat		103	227
Battery		58	127

4. SPECIFICATION FOR MAJOR COMPONENTS

1) ENGINE

Item	Specification
Model	Cummins X12
Туре	4-cycle turbocharged, charge air cooled electronic controlled diesel engine
Cooling method	Water cooled
Number of cylinders and arrangement	6 cylinders, in-line
Firing order	1-5-3-6-2-4
Combustion chamber type	Direct injection type
Cylinder bore $ imes$ stroke	132×144 mm (5.2"×5.7")
Piston displacement	11800 cc (720 cu in)
Compression ratio	17.0 : 1
Gross power	355 hp (265 kW) at 2000 rpm
Net power	351 hp (262 kW) at 2000 rpm
Maximum power	380 hp (283 kW) at 1700 rpm
Peak torque	190 kgf · m (1373 lbf · ft) at 1400 rpm
Engine oil quantity	34 ℓ (9.0 U.S. gal)
Wet weight	860 kg (1896 lb)
Starting motor	24 V-7.5 kW
Battery	2×12 V×220 Ah

2) STEERING PUMP / MAIN PUMP

ltom	Specification			
	Steering pump	Main pump		
Туре	Variable double piston pump			
Capacity	110 cc/rev	100 cc/rev		
Maximum operating pressure	250 kgf/cm ² (3560 psi)	280 kgf/cm ² (3980 psi)		
Rated oil quantity (at 2200 rpm)	242 ℓ /min (63.9 U.S.gpm)	220 ℓ /min (58.1 U.S.gpm)		
Engine high rpm	2100 rpm			

3) FAN + BRAKE PUMP

ltom	Specification			
item	Fan pump Brake pump			
Туре	Piston pump			
Capacity	45 cc/rev			
Maximum operating pressure	250 kgf/cm ² (3980 psi)	150 kgf/cm ² (2130 psi)		
Rated oil quantity (at 2200 rpm)	99.0 ℓ /min (26.1 U.S.gpm)			
Engine high rpm	2100 rpm			

4) MAIN CONTROL VALVE

Item	Specification		
Туре	2 spool / 3 spool		
Operating method	Hydraulic pilot assist		
Main relief valve pressure	280 kgf/cm ² (3980 psi)		
Overload relief valve pressure	340 kgf/cm ² (4840 psi) / * 300 kgf/cm ² (4267 psi)		

 \star Bucket dump

5) ELECTRO-HYDRAULIC BLOCK

Item	Specification	
Туре	Proportional pressure reducing valve	
Control current	0~950 mA	
Resistance	10.5 Ω	
Normal flow	12 ℓ /min (3.17 U.S.gpm)	

6) REMOTE CONTROL VALVE (EH TYPE)

Item	Specification	
Туре	Fingertip	
Axle	Single axle for boom, bucket, auxiliary	
Operating voltage	4.5~5.5 V	
Output signal	0.5~4.5 V (neutral 2.5 V)	

7) REMOTE CONTROL VALVE (FNR TYPE)

Item	Specification		
Туре	Joystick		
Axle	Two axle for boom, bucket, roller for auxiliary		
Operating type	CAN J1939		
Baud rate	500 kbps		

8) CYLINDER

Item		Specification
Boom cylinder	Bore dia $ imes$ Rod dia $ imes$ Stroke	\emptyset 180 \times \emptyset 105 \times 885 mm
Bucket cylinder (HL980A)	Bore dia $ imes$ Rod dia $ imes$ Stroke	\emptyset 200 \times \emptyset 110 \times 550 mm
Bucket cylinder (HL980A XT)	Bore dia $ imes$ Rod dia $ imes$ Stroke	\emptyset 200 \times \emptyset 110 \times 545 mm
Steering cylinder	Bore dia $ imes$ Rod dia $ imes$ Stroke	\emptyset 105 \times \emptyset 55 \times 460 mm

9) DYNAMIC POWER TRANSMISSION DEVICES

Item			Specification	
	Model		ZF 4WG 310	
	Time	Converter	Single-stage, single-phase	
	туре	Transmission	Full-automatic power shift	
	Converter	stall ratio	2.51 : 1	
4-speed transmission (std)	Gear shift		Forward fourth gear, reverse third gear	
	Control		Electrical single lever type, kick-down system Automatic kick down from 2nd to 1st gear FNR switch on joystick lever (option)	
	Pump rate	ed flow	135 ℓ /min (35.7 U.S.gpm) at 2000 rpm	
	Travel spe	ed	See the page 2-2.	
	Model		ZF 5WG 310	
	Time	Converter	Single-stage, double-phase (with lock up clutch)	
	iype	Transmission	Full-automatic power shift	
	Converter stall ratio		2.51 : 1	
	Gear shift		Forward fifth gear, reverse third gear	
5-speed transmission (opt)	Control		Electrical single lever type, kick-down system Automatic kick down from 2nd to 1st gear FNR switch on joystick lever (option)	
	Pump rate	d flow	135 ℓ /min (35.7 U.S.gpm) at 2000 rpm	
	Travel	Forward 1/2/3/4/5	6.2/11.9/18.5/27.1/40.0 km/hr	
	speed	Reverse 1/2/3	6.2/11.6/25.3 km/hr	
	Drive devi	ces	4-wheel drive	
Axle	Front		Front fixed location	
	Rear		Oscillation \pm 11° of center pin-loaded	
Wheels	Tires		29.5 R25, **, L3	
Brokoo	Travel		Four-wheel, wet-disc type, full hydraulic	
Diakes	Parking		Spring applied, hydraulic released brake on T/M	
Stooring	Туре		Full hydraulic, articulated	
Sieering	Steering angle		40° to both right and left angle, respectively	

5. TIGHTENING TORQUE

Use following table for unspecified torque.

1) BOLT AND NUT

(1) Coarse thread

Poltoizo	8.8T		10.9T		12.9T	
DUILSIZE	kgf ∙ m	lbf ⋅ ft	kgf ∙ m	lbf ⋅ ft	kgf ∙ m	lbf ⋅ ft
M 6×1.0	0.8 ~ 1.2	5.8 ~ 8.6	1.2 ~ 1.8	8.7 ~ 13.0	1.5 ~ 2.1	10.9 ~ 15.1
M 8×1.25	2.0 ~ 3.0	14.5 ~ 21.6	2.8 ~ 4.2	20.3 ~ 30.4	3.4 ~ 5.0	24.6 ~ 36.1
M10×1.5	4.0 ~ 6.0	29.0 ~ 43.3	5.6 ~ 8.4	40.5 ~ 60.8	6.8 ~ 10.0	49.2 ~ 72.3
M12×1.75	6.8 ~ 10.2	50.0 ~ 73.7	9.6 ~ 14.4	69.5 ~ 104	12.3 ~ 16.5	89.0 ~ 119
M14×2.0	10.9 ~ 16.3	78.9 ~ 117	16.3 ~ 21.9	118 ~ 158	19.5 ~ 26.3	141 ~ 190
M16×2.0	17.9 ~ 24.1	130 ~ 174	25.1 ~ 33.9	182 ~ 245	30.2 ~ 40.8	141 ~ 295
M18×2.5	24.8 ~ 33.4	180 ~ 241	34.8 ~ 47.0	252 ~ 340	41.8 ~ 56.4	302 ~ 407
M20×2.5	34.9 ~ 47.1	253 ~ 340	49.1 ~ 66.3	355 ~ 479	58.9 ~ 79.5	426 ~ 575
M22×2.5	46.8 ~ 63.2	339 ~ 457	65.8 ~ 88.8	476 ~ 642	78.9 ~ 106	570 ~ 766
M24×3.0	60.2 ~ 81.4	436 ~ 588	84.6 ~ 114	612 ~ 824	102 ~ 137	738 ~ 991
M30×3.5	120 ~161	868 ~ 1164	168 ~ 227	1216 ~ 1641	202 ~ 272	1461 ~ 1967

(2) Fine thread

Delt size	8.8T		10.9T		12.9T	
Boil Size	kgf · m	lbf ⋅ ft	kgf ∙ m	lbf ⋅ ft	kgf ∙ m	lbf ⋅ ft
M 8×1.0	2.1 ~ 3.1	15.2 ~ 22.4	3.0 ~ 4.4	21.7 ~ 31.8	3.6 ~ 5.4	26.1 ~ 39.0
M10×1.25	4.2 ~ 6.2	30.4 ~ 44.9	5.9 ~ 8.7	42.7 ~ 62.9	7.0 ~ 10.4	50.1 ~ 75.2
M12×1.25	7.3 ~ 10.9	52.8 ~ 78.8	10.3 ~ 15.3	74.5 ~ 110	13.1 ~ 17.7	94.8 ~ 128
M14×1.5	12.4 ~ 16.6	89.7 ~ 120	17.4 ~ 23.4	126 ~ 169	20.8 ~ 28.0	151 ~ 202
M16×1.5	18.7 ~ 25.3	136 ~ 182	26.3 ~ 35.5	191 ~ 256	31.6 ~ 42.6	229 ~ 308
M18×1.5	27.1 ~ 36.5	196 ~ 264	38.0 ~ 51.4	275 ~ 371	45.7 ~ 61.7	331 ~ 446
M20×1.5	37.7 ~ 50.9	273 ~ 368	53.1 ~ 71.7	384 ~ 518	63.6 ~ 86.0	460 ~ 622
M22×1.5	51.2 ~ 69.2	370 ~ 500	72.0 ~ 97.2	521 ~ 703	86.4 ~ 116	625 ~ 839
M24×2.0	64.1 ~ 86.5	464 ~ 625	90.1 ~ 121	652 ~ 875	108 ~ 146	782 ~ 1056
M30×2.0	129 ~ 174	933 ~ 1258	181 ~ 245	1310 ~ 1772	217 ~ 294	1570 ~ 2126

2) PIPE AND HOSE (FLARE type)

Thread size	Width across flat (mm)	kgf ∙ m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

3) PIPE AND HOSE (ORFS type)

Thread size	Width across flat (mm)	kgf ∙ m	lbf ⋅ ft
9/16-18	19	4	28.9
11/16-16	22	5	36.2
13/16-16	27	9.5	68.7
1-3/16-12	36	18	130
1-7/16-12	41	21	152
1-11/16-12	50	35	253

4) FITTING

Thread size	Width across flat (mm)	kgf ∙ m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

	No. Descriptions		Polt oizo	Torque	
			Boit size	kgf · m	lbf ⋅ ft
1		Engine mounting bolt, nut (rubber, 2EA)	M20×2.5	$\textbf{57.9} \pm \textbf{8.7}$	$\textbf{419} \pm \textbf{63}$
2		Engine mounting bolt (bracket, 8EA)	M12×1.75	11.7 \pm 1.8	$\textbf{84.6} \pm \textbf{13.0}$
3		Engine mounting bolt (T/C housing, 3EA)	M10×1.5	4.6 ± 0.9	$\textbf{33.3} \pm \textbf{6.5}$
4	Engine	Engine mounting bolt (flywheel, 8EA)	M10×1.5	4.5 ± 0.6	$\textbf{32.5} \pm \textbf{4.3}$
5		Fan motor mounting bolt	M12×1.75	12.8 \pm 3.0	$\textbf{92.6} \pm \textbf{21.7}$
6		Radiator mounting bolt	M16×2.0	$\textbf{29.7} \pm \textbf{5.9}$	$\textbf{215} \pm \textbf{42.7}$
7		Fuel tank mounting bolt, nut	M16×2.0	$\textbf{29.7} \pm \textbf{4.5}$	$\textbf{215} \pm \textbf{32.5}$
8		Main pump housing mounting bolt	M16×2.0	$\textbf{29.7} \pm \textbf{4.5}$	215 ± 32.5
9		Fan&brake pump housing mounting bolt	M10×1.5	6.9 ± 1.4	50 ± 10.1
10		Main control valve mounting bolt	M12×1.75	12.8 \pm 3.0	$\textbf{92.6} \pm \textbf{21.7}$
11		Steering unit mounting bolt	M10×1.5	6.9 ± 1.4	50 \pm 10.1
12	Hydraulic	Steering valve (EHPS) mounting bolt	M8×1.25	2.5 ± 0.5	$\textbf{18.1} \pm \textbf{3.6}$
13	system	Brake valve mounting bolt	M8×1.25	2.5 \pm 0.5	18.1 ± 3.6
14		Cut-off valve mounting bolt	M8×1.25	2.5 ± 0.5	18.1 ± 3.6
15		EH control block mounting bolt	M8×1.25	2.5 ± 0.5	18.1 ± 3.6
16		Safety valve	M10×1.5	6.9 ± 1.4	50 ± 10.1
17		Hydraulic oil tank mounting bolt	M16×2.0	$\textbf{29.7} \pm \textbf{4.5}$	$\textbf{215} \pm \textbf{32.5}$
18		Transmission mounting bolt, nut (rubber, 2EA)	M24×3.0	100 ± 15	$\textbf{723} \pm \textbf{108}$
19		Transmission mounting bolt (bracket, 6EA)	M20×2.5	$\textbf{46.3} \pm \textbf{7.0}$	$\textbf{335} \pm \textbf{50.6}$
20	Power	Front axle mounting bolt, nut	M33×2.0	$\textbf{225} \pm \textbf{20}$	1627 \pm 145
21	system	Rear axle support mounting bolt, nut	M36×3.0	$\textbf{308} \pm \textbf{46.2}$	$\textbf{2227} \pm \textbf{334}$
22		Tire mounting nut	M22×1.5	79 \pm 2.5	571 \pm 18.1
23		Drive shaft joint mounting bolt	1/2-20UNF	15 \pm 2.0	108 \pm 14.5
24		Counterweight mounting bolt	M30×3.5	199 \pm 30	1439 ± 216
25	Othere	Operator's seat mounting bolt	M8×1.25	3.4 ± 0.8	24.6 ± 5
	Others	ROPS Cab mounting bolt (4EA)	M30×3.5	199 \pm 29.9	1440 ± 216
20		ROPS Cab mounting nut (4EA)	M16×2.0	20.5 ± 4.7	148± 34

5) TIGHTENING TORQUE OF MAJOR COMPONENT

6) NEW MACHINE

New machine used and filled with following lubricants.

Description	Specification
Engine oil (API CJ-4)	SAE 15W-40, * ² SAE 5W-40
DEF/AdBlue®	ISO 22241 (32.5% high-purity urea and 67.5 deionized water)
Hydraulic oil	HD Hyundai Construction Equipment genuine long life (ISO VG 46, VG 68 only) Conventional (ISO VG15 ^{*2}) HD Hyundai Construction Equipment Bio Hydraulic Oil (HBHO, ISO VG 46)
Transmission oil	SAE 15W-40 (Oils of the API CI-4+, CJ-4, CK-4, SM, or ACEA specification, Category E9 are not permitted to use for the transmission)
Axle oil	*Refer to below list
Grease	Lithium base grease NLGI No. 2
Fuel	ASTM D975-No. 2, *1Ultra low sulfur diesel
	ASTM D6210
Coolant	Mixture of 50% ethylene glycol base antifreeze and 50% water Mixture of 60% ethylene glycol base antifreeze and 40% water \star^2
	Mixture of 00 % etityiene giyoof base antineeze and 40 % water

SAE	:	Society of Automotive Engineers	* Recommended oil list
API	:	American Petroleum Institute	- Gear oil with limited-slip additive
ISO	:	International Organization for Standardization	- Viscosity grades: SAE 75W-90/75W-110/
NLGI	:	National Lubricating Grease Institute	75W-140 /80W-90/85W-90
ASTM	:	American Society of Testing and Material	- Universal axle and transmission oil
DEF	:	Diesel Exhaust Fluid	- Premium universal axle and transmission oil
		DEF compatible with AdBlue®	*1 Ultra low sulfur diesel
			- sulfur content \leq 15 ppm
			* ² Cold region
			Russia, CIS, Mongolia

2) RECOMMENDED OILS

HD Hyundai Construction Equipment genuine lubricating oils have been developed to offer the best performance and service life for your equipment. These oils have been tested according to the specifications of HD Hyundai Construction Equipment and, therefore, will meet the highest safety and quality requirements. We recommend that you use only HD Hyundai Construction Equipment genuine lubricating oils and grease officially approved by HD Hyundai Construction Equipment.

- * Using any lubricating oils other than HD Hyundai Construction Equipment genuine products may lead to a deterioration of performance and cause damage to major components.
- * Do not mix HD Hyundai Construction Equipment genuine oil with any other lubricating oil as it may result in damage to the systems of major components.
- * Do not use any engine oil other than that specified above, as it may clog the diesel particulate filter(DPF).
- * For HD Hyundai Construction Equipment genuine lubricating oils and grease for use in regions with extremely low temperatures, please contact HD Hyundai Construction Equipment dealers.

		Capacity				Ambi	ent temp	erature °(C(°F)		
Service point	Kind of fluid	ℓ (U.S. gal)	-50	-30	-2	20 -1	0 () 1	0 2	20 3	30 40
			(-58) (-22)	(4) (1	4) (3	62) (5	50) (6	8) (8	6) (104)
								<u> </u>	15\1/40		
Engine								5AL	1300-40		
oil pan	Engine oil	34 (9.0)					★2	SAE 5W-	-40		
				9	SAE 0	W-40					
	Mistrume of										
DEF/	IVIIXTURE OF										
AdBlue®	deionized	44.5 (11.8)	18	SO 22	2241,	High-pur	rity urea -	- deionize	ed water	(32.5 : 6	7.5)
tank	water										
Transmission	Engine oil	53 (14)					S	4E 10VV-3	30	[1
110110111001011		55 (14)						SAE 1	5W-40		
				_							
		FB · 64 (16.9)									
Axle *4	0110	RR: 64 (16.9)		1		7	Refer to	below lis	st		1
		. ,		_							
		Tank: 184 (48.6)	* ² ISO VG 15								
Hydraulic	Hydraulic									*5	
tank	ık oil System:	System:			-		150 VG	40, HBH	IO VG 46		
		340 (89.8)							SO VG 6	8	1
Fuel tank	Diesel	430 (114)		*2 AS	STM E	0975 NC	0.1				
TUETLATIK	fuel*1	430 (114)						AST	M D975 I	NO.2	1
				_							
Fitting						★ ² NLC	GI NO.1				
(grease	Grease	As required						N		2	
пірріе)											
Radiator	Mixture of				F	thylene	alvcol ba	se perma	anent type	e (50 · 50))
(reservoir	anuireeze	ert 45.5 (12.0)	10-1-1								
tank)	water*3		* ² Ethyle	ene glyc	ol base p	permanent t	ype (60 : 40)				

- SAE : Society of Automotive Engineers
- API : American Petroleum Institute
- ISO : International Organization for Standardization
- NLGI : National Lubricating Grease Institute
- **ASTM** : American Society of Testing and Material
- UTTO : Universal Tractor Transmission Oil
- DEF : Diesel Exhaust Fluid
 - DEF compatible with AdBlue®
- *1 Ultra low sulfur diesel
 - sulfur content $\leq 15 \text{ ppm}$

- * Recommended oil list
 - Gear oil with limited-slip additive
 - Viscosity grades: SAE 75W-90/75W-110/ 75W-140 /80W-90/85W-90
 - Universal axle and transmission oil
 - Premium universal axle and transmission oil
- *² Cold region : Russia, CIS, Mongolia
- *3 Soft water : City water or distilled water
- *4 If the machine is equipped with axle oil cooler, refer to page 6-44 in operator's manual.
- *5 HD Hyundai Construction Equipment Bio Hydraulic Oil

GROUP 3 OPERATIONAL CHECKOUT RECORD SHEET

· Owner

:

:

:

- · Date
- · Hours
- · Serial No. :
- \cdot Technician :
- Use this sheet to record operational checkout results.
 Perform the operational check before installing any test equipment.



9801GE02

	Item	OK	NOT OK	Comments
--	------	----	-----------	----------

1. Monitor indicator and gauge checks (engine OFF)

 Hourmeter and gauge check Battery check Monitor indicator circuit check Cluster turn signals and warning indicator check 			
2. Transmission, axle and engine, neutral start switch and reverse warning alarm switch checks			
	_	_	
 Transmission control lever and neutral 			
 Neutral start and reverse warning 			
· Alarm circuit checks			
3. Monitor indicator and gauge checks (engine running)			
· Monitor display and alternator output checks			
 Monitor bypass circuit and seat belt indicator check 			
 Monitor primary and secondary level check 			
Transmission oil warm up procedure			
· Transmission temperature gauge check			
nalioniloolon tompolataro gaago onook			

4. Brake system and clutch cut off checks

 Park brake capacity check Park brake transmission lockout check Service brake pump flow check Service brake capacity check Brake accumulator precharge check Brake system leakage check Service brake pedal check Service and park brake system drag check Clutch cut off check 		
5. Driving checks		
 Transmission oil warm up procedure Transmission noise check Speedometer check Transmission kick down system check 1st, 2nd, 3rd and 4th speed clutch pack drag check Transmission pressure, pump flow and leakage check Transmission shift modulation check Torque converter check Engine power check 6. Hydraulic system checks		
 Hydraulic system warm up procedure Hydraulic pump performance check Pilot control valve boom float check Boom down solenoid valve check Control valve lift check Bucket rollback circuit relief valve check Bucket dump circuit relief Low pressure check High pressure check Boom and bucket cylinder drift check Boom down solenoid valve leakage check Pilot controller check 		
 Return to dig check Boom height kickout check-if equipped 		

7. Steering system checks

Steering system leakage check Steering valve (EHPS) Low check pressure High check pressure B. Accessory checks 8. Accessory checks Operating lights check Work light check Brake light check Cab light check Windshield washer and wiper check Windshield washer and wiper check Windshield washer and wiper check Heater functional check Air conditioner functional check Start aid system check 9. Cab components and vandal protection checks Cab door latch check Cab door lock check Cab window latch check Cab window latch check Cab window check </th <th>· Steering unit check</th> <th></th> <th></th>	· Steering unit check		
Steering valve (EHPS) Low check pressure High check pressure B. Accessory checks Operating lights check Operating lights check Operating lights check Operating lights check Operating light check O	· Steering system leakage check		
Low check pressure High check pressure B. Accessory checks Operating lights check Work light check Brake light check B	· Steering valve (EHPS)		
High check pressure	Low check pressure		
8. Accessory checks • Operating lights check • Work light check • Brake light check • Brake light check • Cab light check • Cab light check • Horn circuit check • Windshield washer and wiper check • Windshield washer and wiper check • Defroster blower check • Heater functional check • Heater functional check • Air conditioner functional check • Start aid system check • Cab door latch check • Cab door latch check • Cab door latch check • Cab door lock check • Cab door lock check • Cab door lock check • Cab window latch check • Cab window latch check • Steering column adjustment check • Steering column adjustment check • Air intake filter door check • Air intake filter door check • Radiator cap access door check • Frame locking bar check • Sonni lock check	High check pressure		
8. Accessory checks • Operating lights check • Work light check • Brake light check • Cab light check • Horn circuit check • Horn circuit check • Windshield washer and wiper check • Windshield washer and wiper check • Defroster blower check • Defroster blower check • Heater/Air conditioner blower check • Heater functional check • Air conditioner functional check • Start aid system check • Cab door latch check • Cab window latch check • Cab window latch check • Cab door vindow check • Sterring column adjustment check • Frame			
Operating lights check Work light check Brake light check Cab light check Cab light check Windshield washer and wiper check Windshield washer and wiper check Windshield washer and wiper check Defroster blower check Defroster blower check Defroster blower check Defroster blower check Heater/Air conditioner blower check Heater functional check Heater functional check Air conditioner functional check Start aid system check Cab door latch check Cab door release button checks Cab door release button check Cab door release button check Cab door latch check Cab door window check Cab door window check Stering column adjustment check Seat and seat belt check Air intake filter door check Frame locking bar check Som lock check Gab door lack check Cab door lack check Som lock check Gab check Cab door lack check Gab check Som lock check Gab check Gab check Cab check Gab check	8. Accessory checks		
Operating lights check Work light check Brake light check Cab light check Cab light check Windshield washer and wiper check Defroster blower check Defroster blower check Defroster blower check Heater/Air conditioner blower check Heater functional check Heater functional check Air conditioner functional check Start aid system check Cab door latch check Cab door latch check Cab door latch check Cab door release button check Cab door latch check Cab door lock			
Work light check	· Operating lights check		
Brake light check Cab light check Horn circuit check Windshield washer and wiper check Defroster blower check Defroster blower check Heater/Air conditioner blower check Heater functional check Heater functional check Air conditioner functional check Cab door latch check C	· Work light check		
Cab light check Horn circuit check Windshield washer and wiper check Defroster blower check Heater/Air conditioner blower check Heater functional check Heater functional check Air conditioner functional check Cab door latch check Cab door lock check Cab door lock check Cab door lock check Cab door lock check Seat and seat belt check Air intake filter door check Frame locking bar check Frame locking bar check Sonvice deral	· Brake light check		
Horn circuit check Windshield washer and wiper check Defroster blower check Heater/Air conditioner blower check Heater functional check Heater functional check Air conditioner functional check Start aid system check Gab components and vandal protection checks Cab door latch check Cab door latch check Cab door release button check Cab door lock check Steering column adjustment check Air intake filter door check Frame locking bar check Sevice deral check Sevice deral check	· Cab light check		
Windshield washer and wiper check Defroster blower check Heater/Air conditioner blower check Heater functional check Heater functional check Air conditioner functional check Start aid system check Cab components and vandal protection checks Cab door latch check Cab door release button check Cab door release button check Cab door lock check Cab door lock check Cab door window check Cab door lock check Steering column adjustment check Air intake filter door check Frame locking bar check Boom lock check	· Horn circuit check		
Defroster blower check Heater/Air conditioner blower check Heater functional check Heater functional check Air conditioner functional check Start aid system check Cab door latch check Cab door latch check Cab door hold open latch check Cab door release button check Cab door lock check Cab door lock check Cab door window check Cab door window check Cab door window check Cab door window check Cab door lock check Cab door window check Cab door lock check Cab	 Windshield washer and wiper check 		
Heater/Air conditioner blower check Heater functional check Air conditioner functional check Start aid system check Cab components and vandal protection checks Cab door latch check Cab door nelease button check Cab door release button check Cab door lock check Cab door lock check Cab door window check Cab door window check Cab window latch check Seat and seat belt check Air intake filter door check Frame locking bar check Service deral check	· Defroster blower check		
Heater functional check Air conditioner functional check Start aid system check 9. Cab components and vandal protection checks Cab door latch check Cab door hold open latch check Cab door release button checks Cab door lock check Cab door lock check Cab door window check Cab window latch check Steering column adjustment check Seat and seat belt check Engine side panels check Frame locking bar check	· Heater/Air conditioner blower check		
Air conditioner functional check Start aid system check Start aid system check Cab components and vandal protection checks Cab door latch check Cab door hold open latch check Cab door release button check Cab door lock check Cab door lock check Cab door lock check Cab door window check Cab door window check Cab window latch check Steering column adjustment check Seat and seat belt check Air intake filter door check Frame locking bar check Service decal check Service decal check Service decal check Cab door lock check Service decal check Service dec	· Heater functional check		
Start aid system check Gab components and vandal protection checks Cab door latch check Cab door hold open latch check Cab door release button check Cab door release button check Cab door vindow check Cab door window check Cab door window check Cab window latch check Cab window latch check Seering column adjustment check Seat and seat belt check Air intake filter door check Radiator cap access door check Frame locking bar check Senvice decal check Cab door lock check Senvice decal check Cab door check Cab door window check Cab window latch check Cab door window check Ca	· Air conditioner functional check		
9. Cab components and vandal protection checks • Cab door latch check	· Start aid system check		
9. Cab components and vandal protection checks • Cab door latch check			
Cab door latch check Cab door hold open latch check Cab door release button check Cab door lock check Cab door lock check Cab door window check Cab door window check Cab window latch check Cab window latch check Steering column adjustment check Seat and seat belt check Air intake filter door check Cab adjustment check Radiator cap access door check Frame locking bar check Sepvice decal check	9. Cab components and vandal protection checks		
Cab door hold open latch check Cab door release button check Cab door lock check Cab door lock check Cab door window check Cab window latch check Cab window latch check Steering column adjustment check Seat and seat belt check Seat and seat belt check Air intake filter door check Engine side panels check Radiator cap access door check Frame locking bar check Service decal check	· Cab door latch check		
Cab door release button check Cab door lock check Cab door window check Cab door window check Cab window latch check Cab window latch check Steering column adjustment check Seat and seat belt check Seat and seat belt check Air intake filter door check Engine side panels check Radiator cap access door check Frame locking bar check Service decal check	· Cab door hold open latch check		
Cab door lock check Cab door window check Cab window latch check Cab window latch check Steering column adjustment check Seat and seat belt check Seat and seat belt check Air intake filter door check Engine side panels check Radiator cap access door check Frame locking bar check Boom lock check Service decal check	Cab door release button check		
 Cab door window check Cab window latch check Steering column adjustment check Seat and seat belt check Air intake filter door check Engine side panels check Radiator cap access door check Frame locking bar check Boom lock check Service decal check 	· Cab door lock check		
Cab window latch check Steering column adjustment check Seat and seat belt check Seat and seat belt check Air intake filter door check Engine side panels check Radiator cap access door check Frame locking bar check Boom lock check Service decal check	· Cab door window check		
Steering column adjustment check Seat and seat belt check Seat and seat belt check Air intake filter door check Engine side panels check Radiator cap access door check Frame locking bar check Boom lock check Service decal check	· Cab window latch check		
Seat and seat belt check Air intake filter door check Engine side panels check Radiator cap access door check Frame locking bar check Boom lock check Service decal check	· Steering column adjustment check		
 Air intake filter door check Engine side panels check Radiator cap access door check Frame locking bar check Boom lock check Service decal check 	Seat and seat belt check		
Engine side panels check In a check Radiator cap access door check In a check Service decal check In a check In	· Air intake filter door check		
Radiator cap access door check Frame locking bar check Boom lock check Service decal check	· Engine side panels check		
Frame locking bar check Boom lock check Service decal check	· Radiator cap access door check		
Boom lock check Service decal check	· Frame locking bar check		
	· Boom lock check		
	· Service decal check		

Group	1	Structure and Function	2-1
Group	2	Engine speed and Stall rpm	2-8
SECTION 2 ENGINE

GROUP 1 STRUCTURE AND FUNCTION

1. FUEL SYSTEM



9752EG03

- 1 Fuel supply from suction side filter
- 2 Fuel pump gear pump inlet
- 3 Fuel pump gear pump outlet
- 4 Pressure side fuel filter inlet
- 5 Pressure side fuel filter
- 6 Pressure side fuel filter outlet
- 7 High pressure fuel pump inlet
- 8 Fuel pump actuator
- 9 High pressure fuel pump outlet
- 10 Fuel rail supply line

- 11 Fuel rail
- 12 Fuel rail pressure sensor
- 13 Injector supply lines
- 14 Injectors
- 15 Fuel drain from injectors
- 16 Fuel pressure relief valve
- 17 Fuel pressure relief valve drain
- 18 Fuel drain line
- 19 Fuel return to tank.

2. LUBRICATING OIL SYSTEM



- 1 Flow from oil pan through suction tube
- 2 Flow from suction tube to lubricating oil pump
- 3 Lubricating oil pump
- 4 Lubricating oil pressure regulator valve
- 5 Lubricating oil high-pressure relief valve
- 6 Lubricating oil return to oil pan
- 7 Lubricating oil flow from lubricating oil pump to lubricating oil cooler module
- 8 Lubricating oil thermostat
- 9 Flow with lubricating oil thermostat open
- 10 Lubricating oil flow from lubricating oil cooler module main oil rifle to lubricating oil filter head
- 11 Lubricating oil filter head
- 12 Flow with lubricating oil thermostat closed
- 13 Lubricating oil flow to oil cooler
- 14 Lubricating oil flow through oil cooler elements
- 15 Lubricating oil flow from lubricating oil cooler to lubricating oil cooler main oil rifle
- 16 Lubricating oil filter bypass valve
- 17 Lubricating oil filter
- 18 Flow with lubricating oil filter bypass valve closed
- 19 Lubricating oil flow from filter head to filter
- 20 Filtered lubricating oil flow to engine block main oil rifle
- 21 Filtered lubricating oil flow to turbocharger
- 22 Flow with lubricating oil filter bypass valve open
- 23 Unfiltered lubricating oil flow to engine block main oil rifle
- 24 Unfiltered lubricating oil flow to turbocharger
- 25 Lubricating oil drain from turbocharger
- 26 Block oil riffle pressure sensing channel
- 27 Flow with pressure regulator valve closed
- 28 Flow with pressure regulator valve open



9752EG4-1

- 1 Lubricating oil flow from lubricating oil filter head to engine block main oil rifle
- 2 Main oil rifle
- 3 Flow to main bearings
- 4 Flow to cylinder head
- 5 Flow to piston cooling nozzle
- 6 Flow to air compressor
- 7 Flow to fuel pump
- 8 Flow to camshaft idler gear
- 9 Flow to crankshaft idler gear
- 10 Flow to REPTO idler gear (if applicable)
- 11 Block oil rifle pressure sensing channel
- 12 Oil drain to lubricating oil pan.



9752EG4-2

- 1 Flow from cylinder block to cylinder head
- 2 Flow to camshaft bushings
- 3 Flow to rocker lever shafts
- 4 Rocker lever shaft
- 5 Flow from rocker lever shaft to intake rocker levers
- 6 Flow from rocker lever shaft to exhaust rocker levers.



9752EG4-3

- 1 Main bearing flow from oil rifle
- 2 Flow to crankshaft connecting rod bearing
- 3 Piston pin
- 4 Flow from oil rifle to piston cooling nozzle
- 5 Piston cooling nozzle

3. COOLING SYSTEM



- 1 Coolant from radiator
- 2 Coolant flow to water pump
- 3 Water pump
- 4 Coolant flow from water pump to oil cooler module
- 5 Oil cooler element
- 6 Coolant flow around oil cooler element
- 7 Coolant flow from oil cooler module to coolant manifold
- 8 Coolant manifold

- 9 Coolant flow from coolant manifold to cylinder block
- 10 Coolant flow around cylinders
- 11 Coolant flow from cylinder block to lower cylinder head
- 12 Coolant flow to upper cylinder head
- 13 Coolant flow to rocker lever housing
- 14 Coolant flow from air compressor return line to cylinder head





9752EG5-1

- 1 Coolant flow from rocker lever housing
- 2 Thermostat closed
- 3 Coolant flow through bypass tube to coolant inlet connection
- 4 Coolant inlet connection
- 5 Thermostat open
- 6 Coolant flow to radiator

4. AIR INTAKE SYSTEM



- 1 Intake air inlet to turbocharger
- 2 Turbocharger air to charge-air cooler
- 3 Charge-air cooler
- 4 From charge-air cooler to intake air connection
- 5 Cold starting aid
- 6 Intake port
- 7 Intake valve

5. EXHAUST SYSTEM



- 1 Exhaust flow from cylinder
- 2 Exhaust manifold (pulse type)
- 3 Dual-entry turbocharger

- 4 Exhaust pressure regulator
- 5 Flow from exhaust pressure regulator



9752EG06-1

- 1 Exhaust gas inlet to turbocharger turbine housing
- 2 Exhaust gas outlet from exhaust pressure regulator
- 3 Intake air inlet to turbocharger compressor housing
- 4 Intake air outlet from compressor housing

GROUP 2 ENGINE SPEED & STALL RPM

1. TEST CONDITION

- 1) Normal temperature of the whole system
 - Coolant : Approx 80°C (176°F)

- Hydraulic oil : $45 \pm 5^{\circ}$ C (113 \pm 10°F)

- Transmission oil : 75 \pm 5°C (167 \pm 10°F)

2) Normal operating pressure : See page 6-57.

2. SPECIFICATION

	Engine speed, rpm (P mode)					
Low idle	High idle	Pump stall	Converter stall	Full stall	Fan motor	Remark
800±25	2130±50	2130±70	2030±70 (4-speed) 2020±70 (5-speed)	1980±70 (4-speed) 1970±70 (5-speed)	850±50	

3. ENGINE RPM CHECK

Remark : If the checked data is not normal, it indicates that the related system is not working properly. Therefore, it is required to check the related system pressure : See page 6-57.

1) Pump stall rpm

- Start the engine and raise the bucket approx 45 cm (1.5 ft) as the figure.
- Press the accelerator pedal fully and operate the bucket control lever to the retract position fully.
- Check the engine rpm at the above condition.

2) Convertor stall rpm

- Start the engine and lower the bucket on the ground as the figure.
- Set the clutch cut off mode at the OFF position.
- Press the brake pedal and accelerator pedal fully.
- Shift the transmission lever to the 4th forward position.
- Check the engine rpm at the above condition.

3) Full stall rpm

- Start the engine and raise the bucket approx 45 cm (1.5 ft) as the figure.
- Set the clutch cut off mode at the OFF position.
- Press the brake pedal and accelerator pedal fully.
- Shift the transmission lever to the 4th forward position and operate the bucket lever to the retract position fully.
- Check the engine rpm at the above condition.







Group	1	Structure and Function	3-1
Group	2	Operational Checks and Troubleshooting	3-81
Group	3	Tests and Adjustments	3-93
Group	4	Disassembly and Assembly	3-95

GROUP 1 STRUCTURE AND FUNCTION

1. POWER TRAIN COMPONENT OVERVIEW



980A3PT01

The power train consists of the following components:

- · Transmission
- · Front, center, rear and upper drive shafts
- · Front and rear axles

Engine power is transmitted to the transmission through the torque converter.

The transmission is a hydraulically engaged four speed forward, three speed reverse countershaft type power shift transmission. A calliper-disc type parking brake is located on the transmission.

The transmission outputs through universal joints to foue drive shaft assemblies. The front drive shaft is a telescoping shaft which drives the front axle. The front axle is mounted directly to the loader frame. The front axle is equipped with hydraulic lock differential as standard.

The rear axle is equipped with conventional differential as standard.

The rear axle is mounted on an oscillating pivot.

The power transmitted to front axle and rear axle is reduced by the pinion gear and ring gear of differential. It then passes from the differential to the sun gear shaft (axle shaft) of final drive.

The power of the sun gear is reduced by a planetary mechanism and is transmitted through the planetary hub to the wheel.

HYDRAULIC CIRCUIT (4-speed transmission)



7707APT09

- NFS Follow-on slide
 - D Oscillation damper
 - B Orifice
- P1 Proportional valve clutch KR
- P2 Proportional valve clutch K4

- P3 Proportional valve clutch K1
- P4 Proportional valve clutch K3
- P5 Proportional valve clutch KV
- P6 Proportional valve clutch K2
- Y1~Y6 Pressure regulator valve with filter

Speed		Forv	ward			Reverse		Neutral	Engaged	Positions on the	Current No. of the
	1	2	3	4	1	2	3		CIUTCH	valve block	points
Y1					Х	Х	Х		KR	F	55
Y2			Х	Х					K4	E	60
Y3	Х				Х				K1	D	56
Y4				Х			Х		K3	С	58
Y5	Х	Х							KV	В	53
Y6		Х	Х			Х			K2	A	57
Engaged clutch	K1,KV	KV,K2	K4,K2	K4,K3	KR,K1	KR,K2	KR, K3		-	-	-

X : Pressure regulator under voltage

HYDRAULIC CIRCUIT (5-speed transmission)



- NFS Follow-on slide
- D Oscillation damper
- B Orifice
- P1 Proportional valve clutch KR
- P2 Proportional valve clutch K4

- P3 Proportional valve clutch K1
- P4 Proportional valve clutch K3
- P5 Proportional valve clutch KV
- P6 Proportional valve clutch K2
- Y1~Y6 Pressure regulator with filter

Speed			Forward	1			Reverse)	Neutral	Engaged	Positions on the	Current No. of the	
	1	2	3	4	5	1	2	3		clutch	valve block	measuring points	
Y1						Х	Х	Х		KR	F	55	
Y2			Х		Х					K4	Е	60	
Y3	Х					Х				K1	D	56	
Y4				Х	Х			Х		K3	С	58	
Y5	Х	Х		Х						KV	В	53	
Y6		Х	Х				Х			K2	А	57	
Engaged clutch	K1,KV	KV,K2	K4,K2	K3,KV	K4,K3	KR,K1	KR,K2	KR,K3		-	-	-	

X : Pressure regulator under voltage

2. TORQUE CONVERTER

1) FUNCTION



1	Turbine	3	Pump	5
2	Stator	4	Transmission pump	

The converter is working according to the Trilok-system, i.e. it assumes at high turbine speed the characteristics, and with it the favorable efficiency of a fluid clutch.

7704PT03

Input shaft

The converter will be defined according to the engine power so that the most favorable operating conditions for each installation case are given.

The Torque converter is composed of 3 main components : Pump wheel - turbine wheel - stator (reaction member)

These 3 impeller wheels are arranged in such a ring-shape system that the fluid is streaming through the circuit components in the indicated order.

Pressure oil is constantly streaming out of the transmission pump through the converter. In this way, the converter can fulfill its task to multiply the torque of the engine, and at the same time, the heat created in the converter is dissipated through the escaping oil.

The oil, escaping out of the pump wheel, enters the turbine wheel and is there inversed in the direction of flow.

According to the rate of inversion, the turbine wheel and with it also the output shaft, receive a more or less high reaction moment. The stator (reaction member), following the turbine, has the task to inverse again the oil which is escaping out of the turbine and to delivery it under the suitable discharge direction to the pump wheel.

Due to the inversion, the stator receives a reaction moment.

The relation turbine moment/pump moment is called torque conversion. This is the higher the greater the speed difference of pump wheel and turbine wheel will be.

Therefore, the maximum conversion is created at standing turbine wheel.

With increasing output speed, the torque conversion is decreasing. The adoption of the output speed to a certain required output moment is infinitely variable and automatically achieved by the torque converter.

If the turbine speed is reaching about 80% of the pump speed, the conversion becomes 1.0 i.e. the turbine moment becomes equal to that of the pump moment. From this point on, the converter is working similar to a fluid clutch.

A stator freewheel serves to improve the efficiency in the upper driving range, it is backing up in the

conversion range the moment upon the housing, and is released in the coupling range. In this way, the stator can rotate freely.

Function of a hydrodynamic torque converter (schematic view)



3-4(770-3)

2) CONVERTER LOCK-UP CLUTCH (5-speed transmission)



9 System pressure from lock-up clutch valve to lock-up clutch



7609A3PT23

With closed converter lock-up clutch the slip between pump and turbine wheel and consequently the hydraulic loss in the converter is equal to "zero" (see figure A).

According to the turbine speed the converter lock-up clutch is shifted automatically.

Via a proportional valve the pilot pressure is applied to the actuating piston, which compresses the disc set (see figure B, lock-up clutch valve).

3. TRANSMISSION

1) LAYOUT



- 1 Torque converter
- 2 Breather
- 3 Electro-hydraulic shift control
- 4 2nd power take off
- 5 Transmission pump
- 6 1st power take off
- 7 Clutch axle-KV/K1

- 8 Clutch axle-KR/K2
- 9 Clutch axle-K4/K3
- 10 Parking brake
- 11 Output shaft
- 12 Output flange (converter side)
- 13 Countershaft

2) INSTALLATION VIEW



- 1 Breather
- 2 Transmission suspension M16
- 2' Transmission suspension M20
- 3 Attachment possibility for an oil filler tube with oil dipstick.
- 4 Output flange
- 5 Oil drain plug
- 6 Coarse filter
- 7 Input flange
- 8 Converter bell
- 9 Lifting lug
- 10 Electrohydraulic shift controller
- 11 Gearbox housing
- 12 Cover

- 13 Output flange
- 14 Pressure oil line clutch K2
- 15 Pressure oil line clutch KR
- 16 Pressure oil line clutch KV
- 17 1st power take off
- 18 2nd power take off
- 19 Pressure oil line clutch K3
- 20 Pressure oil line clutch K1
- 21 Lubricating oil line S2 clutch K4/K3
- 22 Lubricating oil line S1 clutch KR/K2
- 23 Parking brake
- 24 Pressure oil line clutch K4
- 25 Solenoid valve for converter lock-up clutch (5-speed transmission only)

3) OPERATION OF TRANSMISSION (4-speed transmission)

(1) Forward

1 Forward 1st

In 1st forward, forward clutch and 1st clutch are engaged. Forward clutch and 1st clutch are actuated by the hydraulic pressure applied to the clutch piston.



2 Forward 2nd

In 2nd forward, forward clutch and 2nd clutch are engaged. forward clutch and 2nd clutch are actuated by the hydraulic pressure applied to the clutch piston.



③ Forward 3rd

In 3th forward, 4th clutch and 2nd clutch are engaged. 4th clutch and 2nd clutch are actuated by the hydraulic pressure applied to the clutch piston.



78093PT09-1

④ Forward 4th

In 4th forward, 4th clutch and 3rd clutch are engaged. 4th clutch and 3rd clutch are actuated by the hydraulic pressure applied to the clutch piston.



(2) Reverse

① Reverse 1st

In 1st reverse, reverse clutch and 1st clutch are engaged.

reverse clutch and 1st clutch are actuated by the hydraulic pressure applied to the clutch piston.



2 Reverse 2nd

In 2nd reverse, reverse clutch and 2nd clutch are engaged. reverse clutch and 2nd clutch are actuated by the hydraulic pressure applied to the clutch piston.



③ Reverse 3rd

In 3rd reverse, reverse clutch and 3rd clutch are engaged. reverse clutch and 3rd clutch are actuated by the hydraulic pressure applied to the clutch piston.



4) ELECTRO-HYDRAULIC SHIFT CONTROL WITH PROPORTIONAL VALVE

(1) 4-speed transmission





73033CV01

- 1 Pressure reducing valve (9+0.5 bar)
- 2 System pressure valve (16+2 bar)
- 3 Housing
- 4 Cable harness
- 5 Cover
- 6 Valve block

- 7 Intermediate sheet
- 8 Duct plate
- 9 Oscillation damper
- 10 Follow-on slide
- 11 Pressure regulator

(2) 5-speed transmission



7609AW3PT30

- 1 Cable harness
- 2 Proportional valve
- 3 Intermediate plate/duct plate
- 4 System pressure valve (16+2 bar)
- 5 Pressure reducing valve (9+0.5 bar)
- 6 Vibration damper
- 7 Follow-on slide
- Y1~Y6 Proportional valve

Transmission control, see schedule of hydraulic circuit, electro-hydraulic control unit and measuring points at page 3-2, 3-16, 3-17 and 3-98.

The six clutches of the transmission are selected via the 6 proportional valves P1 to P6. The proportional valve (pressure regulator unit) is composed of pressure regulator (e.g. Y1), follow-on slide and vibration damper.

The control pressure of 9 bar for the actuation of the follow-on slides is created by the pressure reducing valve. The pressure oil (16+2 bar) is directed via the follow-on slide to the respective clutch.

Due to the direct proportional selection with separated pressure modulation for each clutch, the pressures to the clutches, which are engaged in the gear change, will be controlled. In this way, a hydraulic intersection of the clutches to be engaged and disengaged becomes possible.

This is creating spontaneous shiftings without traction force interruption.

At the shifting, the following criteria are considered:

- Speed of engine, turbine, central gear train and output.
- Transmission temperature.

- Shifting mode (Up-, down-, reverse shifting and speed engagement out of neutral).

- Load condition (full and part load, traction, overrun inclusive consideration of load cycles during the shifting).

The main pressure value is limiting the maximum control pressure to 16+2 bar and releases the main stream to the converter and lubricating circuit.

In the inlet to the converter, a converter safety valve is installed which protects the converter from high internal pressures (opening pressure 11+2 bar).

Within the converter, the oil serves to transmit the power according to the well-known hydrodynamic principle (see torque converter, page 3-3).

To avoid cavitation, the converter must be always completely filled with oil.

This is achieved by a converter back pressure back-up valve, rear-mounted to the converter, with an opening pressure of at least 4.3bar.

The oil, escaping out of the converter, is directed to a oil cooler.

The oil is directed from the oil cooler to the transmission and from there to the lubricating oil circuit, so that all lubricating points are supplied with cooled oil.

In the electro-hydraulic control unit are 6 pressure regulators installed.

5) GEAR SELECTOR (DW-3)

The gear selector is designed for the mounting on the left side of the steering column. The positions (speeds) 1 to 4 are selected by a rotary motion, the driving direction Forward (F)-Neutral (N)-Reverse (R) by tilting the gear selector lever.

The gear selector is also available with integrated kickdown push button.

For the protection from unintended start off, a neutral interlock is installed.

Position N - Gear selector lever blocked in this position.

Position D - Driving.



6) ELECTRIC CONTROL UNIT

(1) Complete system



9803PT23

- 1 Gear selector (DW-3)
- 2 Monitor
- 3 Clutch cut off mode switch
- 4 Transmission shift mode switch
- 5 Control unit (EST-37)
- 6 Filter
- 7 Power supply connection
- 8 Kickdown switch
- 9 Wiring
- 10 Cable to speed sensor output and speedometer
- 11 Cable to temperature measuring point behind the converter
- 12 Cable to plug connection on the electrohydraulic control unit
- 13 Cable to inductive transmitter speed engine
- 14 Cable to inductive transmitter speed turbine
- 15 Cable to inductive transmitter speed central gear train
- 16 Transmission
- 17 Brake pressure sensor / Load sensor
- 18 Cable to lock-up clutch valve (5-speed transmission)

(2) Description of the basic functions

The powershift transmission will be equipped with the electronic transmission control unit (EST-37), developed for it.

The system is processing the desire of the driver according to the following criteria.

 \cdot Protection from operating errors as far as necessary, is possible via electronic protection (programming).

- · Protection from over-speeds (On the basis of engine and turbine speed).
- · Automatic reversing (Driving speed-dependent).
- · Pressure cut-off possible (Disconnecting of the drive train for maximum power on the power take-off).
- · Change-over possibility for Auto-/Manual mode.
- · Kick down functions possible.

(3) Driving and shifting

- Neutral position :

Neutral position will be selected via the controller.

After the ignition is switched on, the electronics remains in the waiting state. By the position NEUTRAL of the controller, resp. by pressing the pushbutton NEUTRAL, the EST-37A becomes ready for operation.

Now, a gear can be engaged.

- Starting :

The starting of the engine has always to be carried out in the NEUTRAL POSITION of the controller.

For safety reasons it is to recommend to brake the machine securely in position with the parking brake prior to start the engine.

After the starting of the engine and the preselection of the driving direction and the gear, the machine can be set in motion by acceleration.

At the start off, the converter takes over the function of a master clutch.

On a level road it is possible to start off also in higher gears.

- Upshifting under load

Upshifting under load will be then realized if the machine can still accelerate by it.

- Downshifting under load

Downshifting under load will be realized if more traction force is needed.

- Upshifting in overrunning condition

In the overrunning mode, the upshifting will be suppressed by accelerator pedal idling position, if the speed of the machine on a downgrade should not be further increased.

Downshifting in overrunning condition

Downshiftings in overrunning mode will be then carried out if the machine should be retarded.

If the machine will be stopped and is standing with running engine and engaged transmission, the engine cannot be stalled. On a level and horizontal roadway it is possible that the machine begins to crawl, because the engine is creating at idling speed a slight drag torque via the converter.

It is convenient to brake the machine at every stop securely in position with the parking brake. At longer stops, the controller has to be shifted to the NEUTRAL POSITION.

At the start off, the parking brake has to be released. We know from experience that at a converter transmission it might not immediately be noted to have forgotten this quite normal operating step because a converter, due to its high ratio, can easily overcome the braking torque of the parking brake.

Temperature increases in the converter oil as well as overheated brakes will be the consequences to be find out later.

Neutral position of the selector switch at higher machine speeds (above stepping speed) is not admissible.

Either a suitable gear is to be shifted immediately, or the machine must be stopped at once.

(4) Independent calibration of the shifting elements (AEB)

The AEB has the task to compensate tolerances (plate clearance and pressure level) which are influencing the filling procedure of the clutches. For each clutch, the correct filling parameters are determined in one test cycle for :

- · Period of the quick-filling time
- · Level of the filling compensating pressure

The filling parameters are stored, together with the AEB-program and the driving program in the transmission electronics. Because the electronics will be separately supplied, the AEB-cycle must be started only after the installation of both components in the machine, thus ensuring the correct mating (Transmission and electronics).

* It is imperative, to respect the following test conditions :

- Shifting position neutral
- Engine in idling speed
- Parking brake actuated
- Transmission in operating temperature
- * After a replacement of the transmission, the electrohydraulic control or the TCU in the machine, the AEB-cycle must be as well carried out again.

The AEB-cylcle continues for about 3 to 4 minutes. The determined filling parameters are stored in the EEProm of the electronics. In this way, the error message F6 shown on the display will be cancelled also at non-performed AEB.

(5) Pressure cut-off

In order to provide the full engine power for the hydraulic system, the control can be enlarged for the function of a pressure cut-off in the 1st and 2nd speed. In this way, the pressure in the powershift clutches will be cut-off, and the torque transmission in the drive train will be eliminated by it. This function will be released at the actuation of a switch, arranged on the brake pedal. For a soft restart, the pressure will be build-up via a freely programmable characteristic line.

4. FAULT CODE

1-1) MACHINE FAULT CODE

DTC		Diagnostia Criteria		Application					
HCESPN	FMI		G	С	S				
	3	10 seconds continuous, Hydraulic Oil Temp. Measurement Voltage > 3.95 V							
	4	10 seconds continuous, Hydraulic Oil Temp. Measurement Voltage < 0.3 V							
	(Resu	llts / Symptoms)							
	1. Mo	nitor – Hydraulic Oil temperature display failure							
101	2. Cor	ntrol Function – No warming up operation, No fuel warmer function operation,							
		High hydraulic oil temperature warning failure							
	(Chec	king list)							
	1. CN	-58B (#23) – CD-01 (#2) Checking Open/Short							
	2. CN	-58B (#25) – CD-01 (#1) Checking Open/Short		1	1				
	0	10 seconds continuous, Steering main pump pressure Measurement Voltage > 5.3 V							
	4	10 seconds continuous, Steering main pump pressure Measurement							
		Voltage < 0.3 V							
	(Results / Symptoms)								
202	1. Mo	nitor – Steering main pump press. Display failure							
202	2. Cor	ntrol Function – No automatic Emergency steering operation, ECO gauge displa	ay failı	ure					
	3. RMS – Working hours accumulation failure								
	(Chec	(Checking list)							
	1. CN	-58B (#35) – CD-39 (B) Checking Open/Short							
	2. CN	-58A (#11) – CD-39 (A) Checking Open/Short							
	3. CN	-58B (#25) – CD-39 (C) Checking Open/Short			1				
	0	10 seconds continuous,							
		Boom cylinder head pressure Measurement Voltage > 5.3 V							
	4	Poem evlinder 'bood' proceure Measurement Veltage < 0.2 V							
	(Roci	lite / Symptome)							
		nitor – Boom cylinder 'bead' press, display failure							
204	2 Cor	1. World – Booth Cylinder Head press, display idiule 2. Control Eurotion – No Boom prossure calibration function operation, workload measurement ave							
	2. Control r unction – no boom pressure calibration function operation, workload measurement sys.								
	1. CN	-58B (#29) – CD-80 (B) Checking Open/Short							
	2. CN	-58A (#11) – CD-80 (A) Checking Open/Short							
	3. CN	-58B (#25) – CD-80 (C) Checking Open/Short							
G : Genera	al C	: Cummins Engine application equipment S: Scania Engine applicat	ion e	quipn	nent				

DTC		Diagnostia Criteria		Application						
HCESPN	FMI	Diagnostic Criteria	G	С	S					
	0	10 seconds continuous,								
	0	Boom cylinder 'rod' pressure Measurement Voltage > 5.3V								
	4	10 seconds continuous,								
	-	Boom cylinder 'rod' pressure Measurement Voltage < 0.3V								
	(Resu	Ilts / Symptoms)								
205	1. Mo	nitor – Boom cylinder 'rod' press. display failure								
200	2. Cor	ntrol Function – No Boom pressure calibration function operation, workload mea	asurer	nent s	sys.					
		operation failure								
	(Chec	king list)								
	1. CN	-58B(#36) – CD-81(B) Checking Open/Short								
	2. CN	-58A(#11) – CD-81(A) Checking Open/Short								
	3. CN	-58B(#25) – CD-81(C) Checking Open/Short								
	3	10 seconds continuous, Fuel level Measurement Voltage > 3.8V								
	4	10 seconds continuous, Fuel level Measurement Voltage < 0.3V								
	(Resu	ilts / Symptoms)								
301	1. Mo	nitor – Fuel level display failure								
	2. Control Function – Fuel level low warning operation failure									
	(Chec	(Checking list)								
	1. CN-58B (#22) – CD-02 (#2) Checking Open/Short									
	2. CN	-58B (#25) – CD-02 (#1) Checking Open/Short								
		(In the startup conditions) 30 seconds continuous, Fan speed < 10 rpm in								
	8	the Remote cooling fan EPPR current reference value is in X Ma(differ by								
		model)								
318	(Resu	lts / Symptoms)								
	1. Mo	nitor – Cooling Fan revolutions display failure								
	(Checking list)									
	1. CN	-58A (#15) – CD-73 (#1) Checking Open/Short								
	2. CN	-58A (#18) – CD-73 (#2) Checking Open/Short								
	3	10 seconds continuous,								
		Accel pedal position 1 voltage Measurement Voltage > 5.0 V								
	4	Accel pedal position 1 voltage Measurement Voltage < 0.2 V								
	(Roci	Accel pedal position i voltage measurement voltage < 0.2 v								
220		nitor – Accel pedal position 1 voltage display failure								
339	2 Cor	atrol Function – Engine rom control failure								
	(Chec	king list)								
	1. CN	-58B(#39) — CN-162(#2) Checking Open/Short								
	2. CN	-58A(#6) – CN-162(#3) Checking Open/Short								
	3. CN	-58A(#8) – CN-162(#1) Checking Open/Short								

DTC		Diagnostia Critaria			on						
HCESPN	FMI	Diagnostic Criteria	G	С	S						
	3	10 seconds continuous,									
		Accel pedal position 2 voltage Measurement Voltage > 5.0 V									
	4	10 seconds continuous,									
	(5	Accel pedal position 2 voltage Measurement Voltage < 0.2 V			L						
0.40	(Resu	lits / Symptoms)									
343		nitor – Accel pedal position 2 voltage display failure									
	2.00	king list)									
	1. CN	-58B (#40) – CN-162 (#5) Checking Open/Short									
	2. CN	-58A (#7) – CN-162 (#6) Checking Open/Short									
	3. CN	-58A (#9) – CN-162 (#4) Checking Open/Short									
	0	10 seconds continuous, Brake oil pressure Measurement Voltage > 5.3V									
	4	10 seconds continuous, Brake oil pressure Measurement Voltage < 0.3V									
	(Resu	lits / Symptoms)									
	1. Mo	nitor – Brake oil press. display failure									
503	2. Cor	ntrol Function – Brake oil pressure low warning display failure									
	(Chec	Checking list)									
	1. CN	CN-58B (#27) – CD-03 (B) Checking Open/Short									
	2. CN	. CN-58A (#11) – CD-03 (A) Checking Open/Short									
	3. CN	-58B (#25) – CD-03 (C) Checking Open/Short									
	0	10 seconds continuous, Parking oil pressure Measurement Voltage > 5.3V									
	4	10 seconds continuous, Parking oil pressure Measurement Voltage < 0.3V									
	(Resu	Ilts / Symptoms)									
	1. Mo	nitor – Parking oil Press. display failure									
507	2. Cor	ntrol Function – No judgment Parking status									
	(Chec	king list)									
	1. CN	. CN-58B (#34) – CD-26 (B) Checking Open/Short									
	2. CN	-58A (#11) – CD-26 (A) Checking Open/Short									
	5. UN	10 seconds continuous									
	0	Brake oil charoing priority pressure Measurement Voltage > 5.3V									
		10 seconds continuous.									
	4	Brake oil charging priority pressure Measurement Voltage < 0.3V									
	(Resu	llts / Symptoms)									
557	1. Mo	nitor – Brake oil charging priority press. display failure									
	2. Cor	ntrol Function – Cooling fan revolutions control failure, Brake oil(Accumulator) ch	nargin	g failu	re						
	(Cheo	king list)									
	1. CN	-58B (#38) – CD-31 (B) Checking Open/Short			ļ						
	2. CN-58A (#11) – CD-31 (A) Checking Open/Short										
	3. CN	-58B (#25) – CD-31 (C) Checking Open/Short									

DTC		Dis mostis Criteria			on					
HCESPN	FMI	Diagnostic Criteria	G	С	S					
	0	10 seconds continuous, Battery input Voltage > 35V								
	1	10 seconds continuous, Battery input Voltage < 18V								
	(Resu	lts / Symptoms)								
705	1. Cor	ntrol Function – Disabled startup								
700	(Chec	king list)								
	1. Che	ecking battery voltage								
	2. CN-58A (#1) – CN-36 (07 fuse) Checking Open/Short									
	3. CN	-58A (#2) – CN-36 (07 fuse) Checking Open/Short								
	1	(In the 500rpm or more) 10 seconds continuous,								
	-	Alternator Node I Measurement Voltage < 18V								
	(Resu	Its / Symptoms)								
707	1. Cor	ntrol Function – Battery charging circuit failure								
	(Chec	king list)								
	1. CN	-58B (#33) – CN-04 (#18) Checking Open/Short								
	2. CN	-04 (#18) – CN-74 (#2) Checking Open/Short								
	3	10 seconds continuous,								
		Boom position sensor signal voltage Measurement Voltage > 5.0V								
	4	10 seconds continuous,								
		Boom position sensor signal voltage Measurement Voltage < 0.3V								
	(Results / Symptoms)									
	1. Moi	1. Monitor – Boom position sensor signal voltage display failure								
728	2. Co	2. Control Function - No calibration angle sensor, No calibration boom pressure , Boom Detent								
	operation failure,									
	Soft end stop(Boom) operation failure, Lock-up clutch operation failure									
	2. CN	-56A (#5) - CN-100 (C) Checking Open/Short								
	0.011	10 seconds continuous								
	3	Bucket position sensor signal voltage Measurement Voltage > 5.0V								
		10 seconds continuous.								
	4	Bucket position sensor signal voltage Measurement Voltage < 0.3V								
	(Resu	Its /Symptoms)								
	1. Мо	nitor – Bucket position sensor signal voltage display failure								
729	2. Co	ntrol Function – No calibration angle sensor, Bucket Detent operation fa	ailure	, Soft	end					
	stop(E	Bucket) operation failure								
	(Chec	king list)								
	1. CN	-58B(#30) – CN-101(B) Checking Open/Short								
	2. CN	-58A(#5) – CN-101(C) Checking Open/Short								
	3. CN	-58B(#25) – CN-101(A) Checking Open/Short								

DTC		Diagnostia Critaria		Application							
HCESPN	FMI	Diagnostic Criteria	G	С	S						
	0	(When mounting the A/C Controller) 10 seconds continuous,									
001	2	A/C controller Communication Data Error									
831	(Results / Symptoms)										
	1. Cor	ntrol Function – A/C Controller malfunction									
	2	10 seconds continuous, ECM Communication Data Error									
841	(Resu	lts /Symptoms)									
	1. Cor	ntrol Function – ECM operation failure									
	2	10 seconds continuous, TCU Communication Data Error									
842	(Resu	(Results / Symptoms)									
	1. Control Function – TCU operation failure										
	2	10 seconds continuous, Monitor Communication Data Error									
844	(Results / Symptoms)										
	1. Cor	ntrol Function – Monitor operation failure									
	0	(When mounting the RMCU)									
050	2	90 seconds continuous, RMCU Communication Data Error									
850	(Resu	lts / Symptoms)									
	1. Cor	ntrol Function – RMCU operation failure									
	0	(When mounting the EHCU)									
961	2	10 seconds continuous, EHCU Communication Data Error									
001	(Resu	lts / Symptoms)									
	1. Cor	ntrol Function – EHCU operation failure									
	2	(When mounting the BKCU)									
860	~	10 seconds continuous, BKCU Communication Data Error									
009	(Resu	lts / Symptoms)									
	1. Cor	ntrol Function – BKCU operation failure									

1-2) EHCU FAULT CODE

HCESPN	FMI	Description	
2333	9	Communication timeout between EHCU and TCU	
2331	9	Communication timeout between EHCU and MCU	
2332	9	Communication timeout between EHCU and working joystick	
2317	9	Communication timeout between EHCU and steering joystick	
2319	2	Steering joystick position signal error	
2320	2	Steering joystick - FNR enable switch error	
2321	2	Steering joystick - foward switch error	
2322	2	Steering joystick - neutral switch error	
2323	2	Steering joystick - reverse switch error	
2324	2	Steering joystick - kick down switch error	
2325	2	Steering joystick - steering on switch error	
2326	5	PVE coil power current below normal or open circuit	
2326	6	PVE coil power current above normal or grounded circuit	
2327	0	PVE coil PWM duty cycle input value above normal operation range	
2327	1	PVE coil PWM duty cycle input value below normal operation range	
2327	5	PVE coil PWM duty cycle current below normal or open circuit	
2327	6	PVE coil PWM duty cycle current above normal or grounded circuit	
2327	14	PVE coil PWM duty cycle control block parameter invalid	
2311	2	Boom joystick position signal error	
2311	0	Boom joystick position input value above normal operation range	
2311	1	Boom joystick position input value below normal operation range	
2311	3	Boom joystick position input voltage above normal or shorted to high source	
2311	4	Boom joystick position input voltage below normal or shorted to low source	
2311	13	Boom joystick position control block out of calibration	
2311	14	Boom joystick position control block parameter invalid	
2311	31	Boom joysitck position signal redundancy lost	
2313	2	Bucket joystick position signal error	
2313	0	Bucket joystick position input value above normal operation range	
2313	1	Bucket joystick position input value below normal operation range	
2313	3	Bucket joystick position input voltage above normal or shorted to high source	
2313	4	Bucket joystick position input voltage below normal or shorted to low source	
2313	13	Bucket joystick position control block out of calibration	
2313	14	Bucket joystick position control block parameter invalid	
2313	31	Bucket joysitck position signal redundancy lost	
2315	2	Aux joystick position signal error	
2315	0	Aux joystick position input value above normal operation range	
2315	1	Aux joystick position input value below normal operation range	
HCESPN	FMI	Description	
--------	-----	--	--
2315	3	Aux joystick position input voltage above normal or shorted to high source	
2315	4	Aux joystick position input voltage below normal or shorted to low source	
2315	13	Aux joystick position control block out of calibration	
2315	14	Aux joystick position control block parameter invalid	
2315	31	Aux joysitck position signal redundancy lost	
2304	0	Boom up EPPR valve input value above normal operation range	
2304	1	Boom up EPPR valve input value below normal operation range	
2304	5	Boom up EPPR valve input current below normal or open circuit	
2304	6	Boom up EPPR valve input current above normal or grounded circuit	
2304	14	Boom up EPPR valve block parameter invalid	
2305	0	Boom down EPPR valve input value above normal operation range	
2305	1	Boom down EPPR valve input value below normal operation range	
2305	5	Boom down EPPR valve input current below normal or open circuit	
2305	6	Boom down EPPR valve input current above normal or grounded circuit	
2305	14	Boom down EPPR valve block parameter invalid	
2306	0	Bucket in EPPR valve input value above normal operation range	
2306	1	Bucket in EPPR valve input value below normal operation range	
2306	5	Bucket in EPPR valve input current below normal or open circuit	
2306	6	Bucket in EPPR valve input current above normal or grounded circuit	
2306	14	Bucket in EPPR valve block parameter invalid	
2307	0	Bucket dump EPPR valve input value above normal operation range	
2307	1	Bucket dump EPPR valve input value below normal operation range	
2307	5	Bucket dump EPPR valve input current below normal or open circuit	
2307	6	Bucket dump EPPR valve input current above normal or grounded circuit	
2307	14	Bucket dump EPPR valve block parameter invalid	
2308	0	Aux. Up EPPR valve input value above normal operation range	
2308	1	Aux. Up EPPR valve input value below normal operation range	
2308	5	Aux. Up EPPR valve input current below normal or open circuit	
2308	6	Aux. Up EPPR valve input current above normal or grounded circuit	
2308	14	Aux. Up EPPR valve block parameter invalid	
2309	0	Aux. Down EPPR valve input data above normal operation range	
2309	1	Aux. Down EPPR valve input data below normal operation range	
2309	5	Aux. Down EPPR valve input current below normal or open circuit	
2309	6	Aux. Down EPPR valve input current above normal or grounded circuit	
2309	14	Aux. Down EPPR valve block parameter invalid	
2328	0	EHCU sensor power voltage high	
2328	1	EHCU sensor power voltage low	
2328	3	EHCU sensor power voltage above normal or shorted to high source	

HCESPN	FMI	Description
2328	4	EHCU sensor power voltage below normal or shorted to low source
2329	0	EHCU power voltage high
2329	1	EHCU power voltage low
2329	11	EHCU safety cpu error
739	2	Armrest switch signal error
2334	0	Steering pilot pressure sensor data above normal range
2334	1	Steering pilot pressure sensor data below normal range
2335	2	Steering proportional valve moving position error
2335	14	Steering proportional valve start position error

1-3) AAVM FAULT CODE

Fault Code	Description
A01	AAVM Communication Error -AAVM
A02	AAVM Communication Error -Front Camera
A03	AAVM Communication Error -Rear Camera
A04	AAVM Communication Error -Left Camera
A05	AAVM Communication Error -Right Camera
A06	Manual Setting Fail
A07	No MCU CID
A08	MCU CID Format Error
A09	AAVM Hardware Error -AAVM
A10	AAVM Hardware Error -Front Camera
A11	AAVM Hardware Error -Rear Camera
A12	AAVM Hardware Error -Left Camera
A13	AAVM Hardware Error -Right Camera
A14	MCU CID Model is not registered
A15	MCU CID Model can't be applied

2) ENGINE FAULT CODE

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
111 629 12	Engine control module critical internal failure - Bad intelligent device or component. Error internal to the ECM related to memory hardware failures or internal ECM voltage supply circuits.	Possible no noticeable performance effects, engine dying, or hard starting.
115 612 2	Engine magnetic crankshaft speed/position lost both of two signals - Data erratic, intermittent, or incorrect. The ECM has detected the primary and backup speed sensor signals are connected backwards.	The engine will shut down or will not start.
122 102 3	Intake manifold 1 pressure sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the intake manifold pressure circuit.	Engine power derate.
123 102 4	Intake manifold 1 pressure sensor circuit - Voltage below normal, or shorted to low Source. Low signal voltage or open circuit detected at the intake manifold pressure circuit.	Engine power derate.
124 102 16	Intake manifold 1 pressure - Data valid but above normal operational range - Moderately severe level. Intake manifold pressure is above the maximum operating limit.	Engine power derate.
125 102 18	Intake Manifold 1 Pressure - Data valid but below normal operating range - Moderately severe level. Intake manifold pressure is below the minimum operating limit.	Engine power derate.
131 91 3	Accelerator pedal or lever position sensor 1 circuit - Voltage above normal, or shorted to high source. High voltage detected at accelerator pedal position number 1 circuit.	The engine will operate in limp home mode.
132 91 4	Accelerator pedal or lever position sensor 1 circuit - Voltage below normal, or shorted to low source. Low voltage detected at accelerator pedal position number 1 signal circuit.	The engine will operate in limp home mode.
133 974 3	Remote accelerator pedal or lever position sensor 1 circuit - Voltage above normal, or shorted to high source. High voltage detected at remote accelerator pedal position signal circuit.	Remote accelerator will not operate.
134 974 4	Remote accelerator pedal or lever position sensor 1 circuit - Voltage below normal, or shorted to low source. Low voltage detected at remote accelerator pedal position signal circuit.	Remote accelerator will not operate.
143 100 18	Engine oil rifle pressure - Data valid but below normal operational range - Moderately severe level. Engine oil pressure signal indicates engine oil pressure is below the engine protection warning limit.	Engine power derate.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
144 110 3	Engine coolant temperature 1 sensor circuit - Voltage above normal, or shorted to high source. High signal voltage or open circuit detected at engine coolant temperature circuit.	Fan will stay ON if controlled by ECM.
145 110 4	Engine coolant temperature 1 sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at engine coolant temperature circuit.	Fan will stay ON if controlled by ECM.
146 110 16	Engine coolant temperature - Data valid but above normal operational range - Moderately severe level. Engine coolant temperature is above engine protection warning limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red stop lamp starts flashing.
151 110 0	Engine coolant temperature - Data valid but above normal operational range - Most severe level. Engine coolant temperature signal indicates engine coolant temperature above engine protection critical limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red stop lamp starts flashing.
153 105 3	Intake manifold 1 temperature sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at intake manifold air temperature circuit.	Fan will stay ON if controlled by ECM.
154 105 4	Intake manifold 1 temperature sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at intake manifold air temperature circuit.	Fan will stay ON if controlled by ECM.
155 105 0	Intake manifold 1 temperature - Data valid but above normal operational range - Most severe level. Intake manifold air temperature signal indicates intake manifold air temperature above engine protection critical limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red stop lamp starts flashing.
175 3464 3	Electronic throttle control actuator driver circuit - Voltage above normal, or shorted to high source. A short circuit to battery or open circuit has been detected in the engine intake air throttle actuator signal circuit.	Possible reduced engine performance.
176 3464 4	Electronic throttle control actuator driver circuit - Voltage below normal, or shorted to low source. A short circuit to ground has been detected in the engine intake air throttle actuator signal circuit.	Possible reduced engine performance.
177 3464 7	Electronic throttle control actuator - Mechanical system not responding or out of adjustment. The engine intake air throttle actuator has failed the auto zero span check.	Possible reduced engine performance.
187 3510 4	Sensor supply 2 circuit - Voltage below normal, or shorted to low source. Low voltage detected at the sensor supply number 2 circuit.	Engine power derate.
195 111 3	Coolant level sensor 1 circuit - Voltage above normal, or shorted to high source. High signal voltage detected at engine coolant level circuit.	None on performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
196 111 4	Coolant level sensor 1 circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at engine coolant level circuit.	None on performance.
197 111 18	Coolant level - Data valid but below normal operational range - Moderately severe level. Low coolant level has been detected.	Engine power derate.
221 108 3	Barometric pressure sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at barometric pressure circuit.	Engine power derate.
222 108 4	Barometric pressure sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at barometric pressure circuit.	Engine power derate.
227 3510 3	Sensor supply 2 circuit - Voltage above normal, or shorted to high source. High voltage detected at sensor supply number 2 circuit.	Engine power derate.
234 190 0	Engine crankshaft speed/position - Data valid but above normal operational range - Most severe level. Engine speed signal indicates engine speed above engine protection limit.	Engine power derate.
238 3511 4	Sensor supply 3 circuit - Voltage below normal, or shorted to low source. Low voltage detected on the +5 volt sensor supply circuit to the engine speed sensor.	Engine may run rough, may stop running, may not start, or may be difficult to start.
239 3511 3	Sensor supply 3 circuit - Voltage above normal or shorted to high source. High voltage detected on the 5 volt sensor supply circuit to the engine speed sensor.	Engine may run rough, may stop running, may not start, or may be difficult to start.
241 84 2	Wheel-based vehicle speed - Data erratic, intermittent, or incorrect. The ECM lost the vehicle speed signal or is reading an erratic value.	Engine speed limited to ,maximum engine speed without VSS parameter value. Cruise control, gear-down protection, and road speed governor will not work.
245 647 4	Fan control circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the fan control circuit when commanded on.	The fan may stay on continuously or not run at all.
249 171 3	Ambient air temperature sensor 1 circuit - Voltage above normal or shorted to high source. High signal voltage detected at ambient air temperature circuit.	Possible reduced engine performance.
256 171 4	Ambient air temperature sensor 1 circuit - Voltage below normal or shorted to low source. Low voltage detected at ambient air temperature circuit.	Possible reduced engine performance.
271 1347 4	Fuel pump pressurizing assembly 1 circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the fuel pump actuator circuit.	Engine power derate.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
272 1347 3	Fuel pump pressurizing assembly 1 circuit - Voltage above normal, or shorted to high source. High signal voltage or open circuit detected at the fuel pump actuator circuit.	Engine may run rough, may stop running, may not start, or may be difficult to start.
285 639 9	SAE J1939 multiplexing PGN timeout error - Abnormal update rate. The ECM expected information from a multiplexed device but did not receive it soon enough or did not receive it at all.	At least one multiplexed device will not operate properly.
286 639 13	SAE J1939 multiplexing configuration error - Out of calibration. The ECM expected information from a multiplexed device but only received a portion of the necessary information.	At least one multiplexed device will not operate properly.
288 974 19	Sae J1939 multiplexing remote accelerator pedal or lever position sensor circuit - Received network data in error. The oem vehicle electronic control unit (VECM) detected a fault with the remote accelerator.	Remote accelerator will not operate.
295 108 2	Barometric pressure - Data erratic, intermittent, or incorrect. An error in the barometric pressure sensor signal was detected by the ECM.	Engine power derate.
322 651 5	Injector solenoid driver cylinder 1 circuit - Current below normal, or open circuit. Current detected at injector 1 when voltage is turned OFF.	Engine power derate.
323 655 5	Injector solenoid driver cylinder 5 circuit - Current below normal, or open circuit. Current detected at injector 5 when voltage is turned OFF.	The current to the injector is shut OFF. Engine power derate.
324 653 5	Injector solenoid driver cylinder 3 circuit - Current below normal, or open circuit. Current detected at injector 3 when voltage is turned OFF.	The current to the injector is shut OFF. Engine power derate.
325 656 5	Injector solenoid driver cylinder 6 circuit - Current below normal, or open circuit. Current detected at injector 6 when voltage is turned OFF.	The current to the injector is shut OFF. Engine power derate.
331 652 5	Injector solenoid driver cylinder 2 circuit - Current below normal, or open circuit. Current detected at injector 2 when voltage is turned OFF.	The current to the injector is shut OFF. Engine power derate.
332 654 5	Injector solenoid driver cylinder 4 circuit - Current below normal, or open circuit. Current detected at injector 4 when voltage is turned OFF.	The current to the injector is shut OFF. Engine power derate.
334 110 2	Engine coolant temperature - Data erratic, intermittent, or incorrect. The engine coolant temperature sensor is reading an erratic value at initial key ON.	None on performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
338 1267 3	Idle shutdown vehicle accessories relay driver circuit - Voltage above normal, or shorted to high source. Open circuit or short to voltage source detected at the idle shutdown vehicle accessory/ignition bus relay circuit.	Vehicle accessories or ignition bus loads controlled by the idle shutdown relay will not power up.
339 1267 4	Idle shutdown vehicle accessories relay driver circuit - Voltage below normal, or shorted to low source. Low voltage detected at the idle shutdown vehicle accessory or ignition bus relay circuit when commanded ON.	Vehicle accessories or ignition bus loads controlled by the idle shutdown relay will not power up.
343 629 12	Engine control module warning internal hardware failure - Bad intelligent device or component. ECM power supply errors have been detected.	Engine power derate.
346 630 12	Engine control module calibration memory software - Bad intelligent device or component. Invalid switch configuration adjustable parameter setting have been detected by the engine control module (ECM).	Various optional switch inputs to the ECM may not operate correctly.
351 627 12	Injector power supply - Bad intelligent device or component. The ECM measured injector boost voltage is low.	Engine power derate.
352 3509 4	Sensor supply 1 circuit - Voltage below normal, or shorted to low source. Low voltage detected at sensor supply number 1 circuit.	Engine power derate.
383 729 5	Engine intake air heater 1 circuit - Current below normal or open circuit. A malfunctioning engine intake air heater circuit has been detected.	Engine may not start or may be difficult to start.
386 3509 3	Sensor supply 1 circuit - Voltage above normal, or shorted to high source. High voltage detected at sensor supply number 1 circuit.	Engine power derate.
415 100 1	Engine oil rifle pressure - Data valid but below normal operational range - Most severe level. Oil pressure signal indicates oil pressure below the engine protection critical limit.	Progressive power and/or speed derate increasing in severity from time of alert. If engine protection shutdown feature is enabled, engine will shut down 30 seconds after red stop lamp starts flashing.
418 97 15	Water in fuel indicator - Data valid but above normal operational range - Least severe level. water has been detected in the fuel filter.	None on performance.
427 639 9	J1939 data link - Abnormal update rate. Communication between the engine control module (ECM) and another device on the SAE J1939 data link has been lost.	Engine will only idle.
428 97 3	Water in fuel indicator sensor circuit - Voltage above normal, or shorted to high source. High voltage detected at the water in fuel circuit.	None on performance. No water in fuel warning available.
435 100 2	Engine oil rifle pressure - Data erratic, intermittent, or incorrect. The engine oil pressure sensor is reading an erratic value.	None on performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
436 105 2	Intake manifold 1 temperature - Data erratic, intermittent, or incorrect. The intake manifold temperature sensor is reading an erratic value at initial key on or while the engine is running.	Possible reduced engine performance.
441 168 18	Battery 1 voltage - Data valid but below normal operational range - Moderately severe level. ECM supply voltage is below the minimum system voltage level.	Engine may run rough, may stop running, may not start, or may be difficult to start.
442 168 16	Battery 1 Voltage - Data valid but above normal operational range - Moderately severe level. ECM supply voltage is above the maximum system voltage level.	None on performance.
451 157 3	Injector metering rail 1 pressure sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the rail fuel pressure sensor circuit.	Power and/or speed derate.
452 157 4	Injector metering rail 1 pressure sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the rail fuel pressure sensor circuit.	Power and/or speed derate.
483 1349 3	Injector metering rail 2 pressure sensor circuit - Voltage above normal or shorted to high source. High signal voltage detected at the fuel rail 2 pressure sensor circuit.	Possible reduced engine performance.
484 1349 4	Injector metering rail 2 pressure sensor circuit - Voltage below normal or shorted to low source. Low signal voltage detected at the fuel rail 2 pressure sensor circuit.	Possible reduced engine performance.
515 3514 3	Sensor supply 6 circuit - Voltage above normal or shorted to high source. High voltage detected on the +5 volt sensor supply circuit to the fuel rail pressure sensor.	Engine power derate.
516 3514 4	Sensor supply 6 circuit - Voltage below normal or shorted to low source. Low voltage detected on the +5 volt sensor supply circuit to the fuel rail pressure sensor.	Engine power derate.
553 157 16	Injector metering rail 1 pressure - Data valid but above normal operational range - Moderately severe level. The ECM has detected that fuel pressure is higher than commanded pressure.	Possible reduced engine performance.
555 101 16	Crankcase pressure - Data valid but above normal operational range - Moderately severe level. The crankcase breather filter requires maintenance.	None on performance.
556 101 0	Crankcase pressure - Data valid but above normal operational range - Most severe level. The crankcase breather filter requires maintenance.	None on performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
559 157 18	Injector metering rail 1 pressure - Data valid but below normal operational range - Moderately severe level. The ecm has detected that fuel pressure is lower than commanded pressure.	Possibly hard to start or low power. Engine could possibly not start.
584 677 3	Starter relay driver circuit - Voltage above normal, or shorted to high source. Open circuit or high voltage detected at starter lockout circuit.	Either the engine will not start or the engine will not have starter lockout protection.
585 677 4	Starter relay driver circuit - Voltage below normal, or shorted to low source. Low voltage detected at starter lockout circuit.	Either the engine will not start or the engine will not have starter lockout protection.
595 103 16	Turbocharger 1 speed - Data valid but above normal operating range - Moderately severe level. High turbocharger speed has been detected by the ecm.	Engine power derate.
596 167 16	Electrical charging system voltage - Data valid but above normal operational range - Moderately severe level. High battery voltage detected by the battery voltage monitor feature.	None on performance.
597 167 18	Electrical charging system voltage - Data valid but below normal operational range - Moderately severe level. Low battery voltage detected by the battery voltage monitor feature.	None on performance.
649 1378 31	Engine oil change interval - Condition exists. Change engine oil and filter.	None on performance.
687 103 18	Turbocharger 1 speed - Data valid but below normal operational range - Moderately severe level. Low turbocharger speed detected by the ECM.	Engine power derate. The ECM uses an estimated turbocharger speed.
689 190 2	Engine crankshaft speed/position - Data erratic, intermittent, or incorrect. The ECM has detected an error in the engine speed signal.	Possible reduced engine performance.
691 1172 3	Turbocharger 1 compressor inlet temperature sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at turbocharger compressor inlet air temperature circuit.	Engine power derate.
692 1172 4	Turbocharger 1 compressor inlet temperature circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at turbocharger compressor inlet air temperature circuit.	Engine power derate.
693 1172 2	Turbocharger 1 compressor intake temperature - Data erratic, intermittent, or incorrect. A temperature too high or low for the operating conditions has been detected by the turbocharger compressor intake temperature sensor.	Possible reduced engine performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
731 723 7	Engine speed / position camshaft and crankshaft misalignment - Mechanical system not responding properly or out of adjustment. Engine position signal from the crankshaft position sensor and camshaft position sensor do not match.	Engine power derate.
755 157 7	Injector metering rail 1 pressure - Mechanical system not responding or out of adjustment. The ecm has detected a difference in the 2 fuel rail pressure signals.	Possible reduced engine performance.
778 723 2	Engine camshaft speed / position sensor - Data erratic, intermittent, or incorrect. The ECM has detected an error in the camshaft position sensor signal.	Possible reduced engine performance.
784 1590 2	Adaptive cruise control mode - Data erratic, intermittent, or incorrect. Loss of communication with adaptive cruise control.	Adaptive cruise control will not operate. Standard cruise control may not operate.
1117 627 2	Power supply lost with ignition on - Data erratic, intermittent, or incorrect. Supply voltage to the ECM fell below 6.2 volts momentarily, or the ECM was not allowed to power down correctly (retain battery voltage for 30 seconds after key OFF).	Possible no noticeable performance.
1139 651 7	Injector solenoid driver cylinder 1 - Mechanical system not responding or out of adjustment. The ECM has detected an error with the injection timing or quantity.	Possible reduced engine performance.
1141 652 7	Injector solenoid driver cylinder 2 - Mechanical system not responding or out of adjustment. The ECM has detected an error with the injection timing or quantity.	Possible reduced engine performance.
1142 653 7	Injector solenoid driver cylinder 3 - Mechanical system not responding or out of adjustment. The ECM has detected an error with the injection timing or quantity.	Possible reduced engine performance.
1143 654 7	Injector solenoid driver cylinder 4 - Mechanical system not responding or out of adjustment. The ECM has detected an error with the injection timing or quantity.	Possible reduced engine performance.
1144 655 7	Injector solenoid driver cylinder 5 - Mechanical system not responding or out of adjustment. The ECM has detected an error with the injection timing or quantity.	Possible reduced engine performance.
1145 656 7	Injector solenoid driver cylinder 6 - Mechanical system not responding or out of adjustment. The ECM has detected an error with the injection timing or quantity.	Possible reduced engine performance.
1228 27 2	Egr valve position - Data erratic, intermittent, or Incorrect. The EGR valve is unable to meet commanded position.	Possible reduced engine performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
1239 2623 3	Accelerator pedal or lever position sensor 2 circuit - Voltage above normal or shorted to high source. High voltage detected at accelerator pedal position number 2 signal circuit.	The engine will operate in limp home mode.
1241 2623 4	Accelerator pedal or lever position sensor 2 circuit - Voltage below normal or shorted to low source. Low voltage detected at accelerator pedal position number 2 signal circuit.	The engine will operate in limp home mode.
1242 91 2	Accelerator pedal or lever position sensor 1 and 2 - Data erratic, intermittent, or incorrect. Accelerator position sensor number 1 and number 2 are reading different values.	The engine will only idle.
1515 91 19	Sae J1939 multiplexed accelerator pedal or lever sensor system - Received network data in error. The J1939 multiplexing controller has indicated a malfunction of the multiplexed accelerator pedal.	The engine will only idle.
1654 1323 31	Engine misfire cylinder 1- Condition exists. Engine misfire has been detected in cylinder number 1.	Possible reduced engine performance.
1655 1324 31	Engine misfire cylinder 2 - Condition exists. Engine misfire has been detected in cylinder number 2.	Possible reduced engine performance.
1656 1325 31	Engine misfire cylinder 3 - Condition exists. Engine misfire has been detected in cylinder number 3.	Possible reduced engine performance.
1657 1326 31	Engine misfire cylinder 4 - Condition exists. Engine misfire has been detected in cylinder number 4.	Possible reduced engine performance.
1658 1327 31	Engine misfire cylinder 5 - Condition exists. Engine misfire has been detected in cylinder number 5.	Possible reduced engine performance.
1659 1328 31	Engine misfire cylinder 6 - Condition exists. Engine misfire has been detected in cylinder number 6.	Possible reduced engine performance.
1668 1761 4	Aftertreatment diesel exhaust fluid tank level sensor circuit - Voltage below normal or shorted to low source. Low signal voltage detected at the aftertreatment diesel exhaust fluid tank level sensor circuit.	Possible reduced engine performance.
1669 1761 3	Aftertreatment diesel exhaust fluid tank level sensor circuit - Voltage above normal or shorted to high source. High signal voltage detected at the catalyst tank level sensor circuit.	Possible reduced engine performance.
1673 1761 1	Aftertreatment diesel exhaust fluid tank level - Data valid but below normal operating range - Most severe level. The aftertreatment diesel exhaust fluid tank level has fallen below the critical warning level.	Possible reduced engine performance.

 $\, \mbox{\ensuremath{\mathbb X}}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
1677 3031 4	Aftertreatment diesel exhaust fluid tank temperature sensor - Voltage below normal or shorted to low source. Low signal voltage detected at the diesel exhaust fluid tank temperature sensor circuit.	Possible reduced engine performance.
1678 3031 3	Aftertreatment diesel exhaust fluid tank temperature sensor - Voltage above normal or shorted to high source. High signal voltage or open circuit detected at the diesel exhaust fluid tank temperature sensor circuit.	Possible reduced engine performance.
1679 3031 2	Aftertreatment diesel exhaust fluid tank temperature - Data erratic, intermittent, or incorrect. The diesel exhaust fluid tank temperature sensor has indicated a tank temperature too high or too low for the ambient conditions.	Possible reduced engine performance.
1682 3362 31	Aftertreatment diesel exhaust fluid dosing unit input lines - Condition exists. The aftertreatment diesel exhaust fluid dosing unit is unable to prime.	Possible reduced engine performance.
1683 3363 3	Aftertreatment diesel exhaust fluid tank heater - Voltage above normal or shorted to high source. High signal voltage detected at the aftertreatment diesel exhaust fluid tank heater circuit.	Possible reduced engine performance.
1684 3363 4	Aftertreatment diesel exhaust fluid tank heater - Voltage below normal, or shorted to low source. Low signal voltage detected at the aftertreatment diesel exhaust fluid tank heater circuit.	Possible reduced engine performance.
1691 100 18	Aftertreatment diesel oxidation catalyst conversion efficiency - Data valid but below normal operating range - Moderately severe level. The temperature increase across the aftertreatment catalyst is lower than expected.	Possible frequent need for aftertreatment regeneration.
1695 3513 3	Sensor supply 5 - Voltage above normal or shorted to high source. High voltage detected at sensor supply 5 circuit in the oem harness.	the engine will operate in limp home mode.
1696 3513 4	Sensor supply 5 - Voltage below normal or shorted to low source. Low voltage detected at sensor supply number 5 circuit in the oem harness.	the engine will operate in limp home mode.
1712 3363 18	Aftertreatment diesel exhaust fluid tank heater - Data valid but below normal operating range - Moderately severe level. The aftertreatment diesel exhaust fluid tank heater is unable to thaw the frozen diesel exhaust fluid.	Possible reduced engine performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
1713 3363 16	Aftertreatment diesel exhaust fluid tank heater - Data valid but above normal operating range - Moderately severe level. The diesel exhaust fluid tank heater is continuously in the on position.	None on performance.
1718 1322 31	Engine misfire for multiple cylinders - Condition exists. Engine misfire has been detected in multiple cylinder numbers.	Possible reduced engine performance.
1776 2634 3	Power relay driver circuit - Voltage above normal or shorted to high source. High voltage detected at power relay driver circuit.	Possible reduced engine performance.
1777 2634 4	Power relay driver circuit - Voltage below normal or shorted to low source. An open circuit or low voltage has been detected at the power relay circuit.	Possible reduced engine performance.
1843 101 3	Crankcase pressure circuit - Voltage above normal or shorted to high source. High signal voltage detected at the crankcase pressure circuit.	None on performance.
1844 101 4	Crankcase pressure circuit - Voltage below normal or shorted to low source. Low signal voltage detected at the crankcase pressure circuit.	None on performance.
1866 411 2	Exhaust gas recirculation valve delta pressure - Data erratic, intermittent, or incorrect. An error in the egr delta pressure signal was detected at initial key on or the sensor failed the autozero test.	possible reduced engine performance.
1867 412 2	Engine gas recircuilation temperature - Data erratic, intermittent, or incorrect. Engine misfire has been detected in multiple cylinder numbers.	Possible reduced engine performance.
1879 3251 3	Aftertreatment diesel particulate filter differential pressure sensor circuit - Voltage above normal or shorted to high source. High signal voltage detected at the aftertreatment differential pressure sensor circuit.	possible reduced engine performance.
1881 3251 4	Aftertreatment diesel particulate filter differential pressure sensor circuit - Voltage below normal or shorted to low source. Low signal voltage or open circuit detected at the aftertreatment differential pressure sensor circuit.	possible reduced engine performance.
1883 3251 2	Aftertreatment diesel particulate filter differential pressure sensor - Data erratic, intermittent, or incorrect. The aftertreatment diesel particulate filter differential pressure sensor is reading an erratic value at initial key on or during engine operation.	possible reduced engine performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
1885 3216 4	Aftertreatment intake NOx sensor circuit - Voltage below normal or shorted to low source. An internal circuit error has been detected by the aftertreatment intake NOx sensor.	Possible reduced engine performance.
1887 3226 4	Aftertreatment outlet NOx sensor circuit - Voltage below normal or shorted to low source. An internal circuit error has been detected by the aftertreatment outlet NOx sensor.	Possible reduced engine performance.
1896 2791 13	EGR valve controller - Out of calibration. The EGR valve has failed the automatic calibration procedure at initial key ON.	Possible reduced engine performance.
1921 3251 0	Aftertreatment diesel particulate filter differential pressure - Data valid but above normal operating range - Moderately severe level. The soot load of the aftertreatment diesel particulate filter has exceeded the recommended limits.	Possible reduced engine performance.
1922 3251 0	Aftertreatment diesel particulate filter differential pressure - Data valid but above normal operating range - Most severe level. The soot load of the aftertreatment diesel particulate filter has exceeded the recommended limits. Engine protection derate is enabled.	Possible reduced engine performance.
1938 3597 1	Ecu power output supply voltage 1 - Data valid but below normal operational range - Moderately severe level. Low battery voltage detected by the VGT actuator.	Possible reduced engine performance.
1942 101 2	Crankcase pressure - Data erratic, intermittent, or incorrect. The ECM has detected that the crankcase pressure signal is reading an erratic value at initial key ON or during engine operation.	None on performance.
1961 2791 0	EGR valve control circuit calculated over temperature - Data valid but above normal operational range - Least severe level. High EGR valve driver temperature has been detected.	Possible reduced engine performance.
1962 641 0	VGT Actuator driver over temperature (calculated) - Data valid but above normal operating range - Least severe level. High internal VGT actuator temperature has been detected.	None on performance.
1974 101 16	Crankcase pressure - Data valid but above normal operating range - Moderately severe level. The crankcase breather filter requires maintenance.	None on performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
1993 4795 31	Aftertreatment diesel particulate filter missing - Condition exists. The aftertreatment diesel particulate filter in the exhaust system is not present.	Active aftertreatment diesel particulate filter regeneration will be disabled.
2185 3512 3	Sensor supply 4 circuit - Voltage above normal, or shorted to high source. High voltage detected at 5 VDC sensor supply circuit to the accelerator pedal position sensor.	Engine will only idle.
2186 3512 4	Sensor supply 4 circuit - Voltage below normal, or shorted to low source. Low voltage detected at 5 VDC sensor supply circuit to the accelerator pedal position sensor.	Engine will only idle.
2198 641 11	VGT Actuator driver circuit - Root cause not known. Intermittent communication between the smart VGT controller and the ECM has been detected. The VGT controller is not interpreting the J1939 message from the ECM correctly.	Possible reduced engine performance.
2272 27 4	EGR Valve position circuit - Voltage below normal or shorted to low source. Low signal voltage has been detected at the EGR valve position sensor circuit	Possible reduced engine performance.
2273 411 3	Exhaust gas recirculation valve delta pressure sensor circuit - Voltage above normal or shorted to high source. High signal voltage detected at the EGR differential pressure sensor circuit.	Possible reduced engine performance.
2274 411 4	Exhaust gas recirculation valve delta pressure sensor circuit - Voltage below normal or shorted to low source. Low signal voltage detected at the EGR differential pressure sensor circuit.	Possible reduced engine performance.
2288 103 15	Turbocharger 1 speed - Data valid but above normal operating range - Least severe level. High turbocharger speed has been detected by the ECM.	Possible reduced engine performance.
2311 633 31	Electronic fuel injection control valve circuit - Condition exists. Fuel pump actuator circuit resistance too high or too low, or an intermittent connection has been detected.	Possible reduced engine performance.
2322 723 2	Engine camshaft speed / position sensor - Data erratic, intermittent, or incorrect. Camshaft engine speed sensor intermittent synchronization.	None on performance.
2349 2791 5	EGR Valve control circuit - Current below normal or open circuit. Motor terminal or motor coil open circuit has been detected by the ECM.	Possible reduced engine performance.

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
2353 2791 6	EGR Valve control circuit - Current above normal or grounded circuit. A short circuit to ground has been detected in the EGR valve motor circuit.	Possible reduced engine performance.
2372 95 16	Fuel filter differential pressure - Data valid but above normal operational range - Moderately severe level. Excessive fuel flow restriction to the high pressure fuel pump has been detected.	Possible reduced engine performance.
2373 1209 3	Exhaust gas pressure sensor circuit - Voltage above normal or shorted to high source. High signal voltage detected at the exhaust gas pressure circuit.	Possible reduced engine performance.
2374 1209 4	Exhaust gas pressure sensor circuit - Voltage below normal or shorted to low source. Low signal voltage detected at the exhaust gas pressure circuit.	Possible reduced engine performance.
2375 412 3	Exhaust gas recirculation temperature sensor circuit - Voltage above normal or shorted to high source. High signal voltage detected at EGR temperature circuit.	Possible reduced engine performance.
2376 412 4	Exhaust gas recirculation temperature sensor circuit - Voltage below normal or shorted to low source. Low signal voltage detected at EGR temperature circuit.	Possible reduced engine performance.
2377 647 3	Fan control circuit - Voltage above normal, or shorted to high source. Open circuit or high voltage detected at the fan control circuit.	The fan can stay on continuously or not run at all.
2387 641 7	VGT Actuator driver circuit (motor) - Mechanical system not responding or out of adjustment. The smart VGT controller has detected incorrect stop limits, or the VGT is unable to move to the closed position.	Possible reduced engine performance.
2398 171 2	Ambient air temperature - Data erratic, intermittent, or incorrect. The ambient air temperature sensor is reading an erratic value.	Possible reduced engine performance.
2448 111 17	Coolant level - Data valid but below normal operational range - Least severe level. Low engine coolant level detected.	none on performance.
2449 641 13	Vgt actuator controller - Out of calibration. The VGT actuator has been installed incorrectly.	Possible reduced engine performance.
2468 102 3	Engine crankshaft speed/position - Data valid but above normal operating range - Moderately severe level. The engine speed has exceeded a critical limit.	Engine will be shut down.
2554 1209 2	Exhaust gas pressure - Data erratic, intermittent or incorrect. The exhaust gas pressure sensor is reading an erratic value.	possible reduced engine performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
2555 729 3	Intake air heater 1 circuit - Voltage above normal, or shorted to high source. High voltage detected at the intake air heater signal circuit.	The intake air heaters may be ON or OFF all the time.
2556 729 4	Intake air heater 1 circuit - Voltage below normal, or shorted to low source. Low voltage detected at the intake air heater signal circuit.	The intake air heaters may be ON or OFF all the time.
2634 641 12	VGT Actuator controller - Bad intelligent device or component. An internal error has been detected by the smart VGT controller.	Possible reduced engine performance.
2636 641 9	VGT Actuator driver circuit - abnormal update rate. No communications on the J1939 data link between the engine ECM and the smart VGT controller.	Possible reduced engine performance.
2638 5298 17	Aftertreatment diesel oxidation catalyst conversion efficiency - Data valid but below normal operating range - Least severe level. The temperature increase across the aftertreatment diesel oxidation catalyst is lower than expected.	Possible frequent need for aftertreatment regeneration.
2639 3251 15	Aftertreatment diesel particulate filter differential pressure - Data valid but above normal operating range - Least severe level. The soot load of the aftertreatment diesel particulate filter has exceeded the recommended limits.	Possible reduced engine performance.
2646 110 32	Engine coolant temperature - Condition exists. The EGR valve was closed to reduce engine coolant temperature.	Possible reduced engine performance.
2718 520325 31	Brake switch and accelerator pedal position incompatible - Condition exists. The ECM has detected the brake pedal and accelerator pedal were depressed simultaneously.	The engine will operate in limp home mode.
2771 3226 9	Aftertreatment outlet NOx sensor - Abnormal update rate. No communications or an invalid data transfer rate detected on the J1939 data link between the ECM and the aftertreatment outlet NOx sensor.	Possible reduced engine performance.
2777 3703 31	Particulate trap active regeneration inhibited due to inhibit switch - Condition exists. Regeneration of the diesel particulate filter has been prevented due to the permit switch being disabled.	Possible frequent need for aftertreatment regeneration.
2961 412 15	Exhaust gas recirculation temperature - Data valid but above normal operational range - Least severe level. EGR temperature has exceeded the engine protection limit.	Possible reduced engine performance.
2962 412 16	Exhaust gas recirculation temperature - Data valid but above normal operational range - Moderately severe level. EGR temperature has exceeded the engine protection limit.	Possible reduced engine performance.

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
2963 110 15	Engine coolant temperature - Data valid but above normal operational range - Least severe level. Engine coolant temperature is above the engine protection warning limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the Engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
2964 105 15	Intake manifold 1 temperature - Data valid but above normal operational range - Least severe level. Intake manifold air temperature signal indicates intake manifold air temperature is above engine protection warning limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the Engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
2973 102 2	Intake manifold 1 pressure - Data erratic, intermittent, or incorrect. The intake manifold pressure sensor is reading an erratic value.	Possible reduced engine performance.
2976 3361 2	Aftertreatment diesel exhaust fluid dosing unit temperature - Data erratic, intermittent, or incorrect. An internal error has been detected in the aftertreatment diesel exhaust fluid dosing unit.	Possible reduced engine performance.
3133 3610 3	Aftertreatment diesel particulate filter outlet pressure sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the aftertreatment diesel particulate filter outlet pressure sensor circuit.	Possible reduced engine performance.
3134 3610 4	Aftertreatment diesel particulate filter outlet pressure sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the aftertreatment diesel particulate filter outlet pressure sensor circuit.	Possible reduced engine performance.
3135 3610 2	Aftertreatment diesel particulate filter outlet pressure - Data erratic, intermittent or incorrect. The aftertreatment diesel particulate filter outlet pressure sensor is reading an erratic value at initial key ON or during engine operation.	Possible reduced engine performance.
3146 4363 3	Aftertreatment SCR outlet temperature sensor circuit - Voltage above normal or shorted to high source. High signal voltage detected at the SCR outlet temperature sensor circuit.	Possible reduced engine performance.
3147 4363 4	Aftertreatment SCR outlet temperature sensor circuit - Voltage below normal or shorted to low source. Low signal voltage detected at the SCR outlet temperature sensor circuit.	Possible reduced engine performance.
3148 4363 2	Aftertreatment SCR outlet temperature sensor - Data erratic, intermittent, or incorrect. The SCR outlet temperature sensor is not changing with engine operating conditions.	Possible reduced engine performance.
3151 4794 31	Aftertreatment SCR catalyst system missing - Condition exists. The aftertreatment SCR catalyst in the exhaust system is not present.	Possible reduced engine performance.

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
3165 4363 0	Aftertreatment SCR outlet temperature - Data valid but above normal operational range - Most severe level. The SCR outlet temperature sensor reading has exceeded the maximum engine protection temperature limit.	Possible reduced engine performance.
3168 3936 16	Aftertreatment diesel particulate filter system - Data valid but above normal operating range - Moderately severe level. The system has detected a malfunction in the filtering capability of the aftertreatment diesel particulate filter.	None on performance.
3186 1623 9	Tachograph output shaft speed - Abnormal update rate. No communication or an invalid data transfer rate has been detected on the J1939 data link between the ECM and the tachograph output shaft speed sensor.	None on performance.
3213 1623 19	Tachograph output shaft speed - Received network data in error. The J1939 multiplexing controller has indicated a malfunction of the tachograph output shaft speed sensor.	None on performance.
3228 3216 2	Aftertreatment Intake NOx sensor - Data erratic, intermittent, or incorrect. An incorrect NOx sensor reading has been detected by the aftertreatment intake NOx sensor.	Possible reduced engine performance.
3232 3216 9	Aftertreatment Intake NOx sensor - Abnormal update rate. No communication or an invalid data transfer rate has been detected on the J1939 data link between the ECM and the aftertreatment intake NOx sensor.	Possible reduced engine performance.
3235 4363 16	Aftertreatment SCR outlet temperature - Data valid but above normal operating range - Moderately severe level. The SCR outlet temperature sensor reading has exceeded the maximum temperature limit.	Possible reduced engine performance.
3237 4340 3	Aftertreatment diesel exhaust fluid line heater 1 circuit - Voltage above normal or shorted to high source. High signal voltage detected at the diesel exhaust fluid line heater 1 circuit.	Possible reduced engine performance.
3238 4340 4	Aftertreatment diesel exhaust fluid line heater 1 circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the diesel exhaust fluid line heater 1 circuit.	Possible reduced engine performance.
3239 4342 3	Aftertreatment diesel exhaust fluid line heater 2 circuit - Voltage above normal or shorted to high source. High signal voltage detected at the diesel exhaust fluid line heater 2 circuit.	Possible reduced engine performance.
3241 4342 4	Aftertreatment diesel exhaust fluid line heater 2 circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the diesel exhaust fluid line heater 2 circuit.	Possible reduced engine performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
3242 3363 7	Aftertreatment diesel exhaust fluid tank heater - Mechanical system not responding or out of adjustment. The aftertreatment diesel exhaust fluid temperature did not increase when the aftertreatment diesel exhaust fluid tank heater was commanded ON.	Possible reduced engine performance.
3243 3060 18	Engine cooling system monitor - Data valid but below normal operating range - Moderately severe level. The engine is not warming up as expected.	None on performance.
3251 4765 16	Aftertreatment diesel oxidation catalyst intake temperature - Data valid but above normal operating range - Moderately severe level. The diesel oxidation catalyst intake temperature sensor reading has exceeded the maximum temperature limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the Engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
3253 3242 16	Aftertreatment diesel particulate filter intake temperature - Data valid but above normal operating range - Moderately severe level. The aftertreatment diesel particulate filter intake temperature sensor reading has exceeded the maximum engine protection temperature limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the Engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
3254 3242 15	Aftertreatment diesel particulate filter intake temperature - Data valid but above normal operating range - Least severe level. The aftertreatment diesel particulate filter intake temperature sensor reading has exceeded the maximum engine protection temperature limit.	Possible reduced engine performance.
3255 3246 16	Aftertreatment diesel particulate filter outlet temperature - Data valid but above normal operating range - Moderately severe level. The aftertreatment diesel particulate filter outlet temperature sensor reading has exceeded the maximum engine protection temperature limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
3256 3246 15	Aftertreatment diesel particulate filter outlet temperature - Data valid but above normal operating range - Least severe level. The aftertreatment diesel particulate filter outlet temperature sensor reading has exceeded the maximum engine protection temperature limit.	Possible reduced engine performance.
3258 4340 5	Aftertreatment diesel exhaust fluid line heater 1 circuit - Current below normal or open circuit. Open circuit detected in the diesel exhaust fluid line heater 1.	Possible reduced engine performance.
3261 4342 5	Aftertreatment diesel exhaust fluid line heater 2 circuit - Current below normal or open circuit. Open circuit detected in the diesel exhaust fluid line heater 2.	Possible reduced engine performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
3311 3242 0	Aftertreatment diesel particulate filter intake temperature - Data valid but above normal operating range - Most severe level. The aftertreatment diesel particulate filter intake temperature sensor reading has exceeded the maximum engine protection temperature limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
3312 3246 0	Aftertreatment diesel particulate filter outlet temperature - Data valid but above normal operating range - Most severe level. The aftertreatment diesel particulate filter outlet temperature sensor reading has exceeded the maximum engine protection temperature limit.	Progressive power and/or speed derate increasing in severity from time of alert. If the engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
3313 4765 4	Aftertreatment diesel oxidation catalyst intake temperature sensor circuit - Voltage below normal or shorted to low source. Low signal voltage detected at the catalyst intake sensor circuit.	Possible reduced engine performance.
3314 4765 3	Aftertreatment diesel oxidation catalyst intake temperature sensor circuit - Voltage above normal or shorted to high source. High signal voltage detected at the catalyst intake temperature sensor circuit.	Possible reduced engine performance.
3315 4765 2	Aftertreatment diesel oxidation catalyst intake temperature - Data erratic, intermittent, or incorrect. The aftertreatment diesel oxidation catalyst intake temperature sensor is not changing with engine operating conditions.	Possible reduced engine performance.
3316 3242 4	Aftertreatment diesel particulate filter intake temperature sensor circuit - Voltage below normal or shorted to low source. Low signal voltage detected at the aftertreatment diesel particulate filter intake temperature sensor circuit.	Possible reduced engine performance.
3317 3242 3	Aftertreatment diesel particulate filter intake temperature sensor circuit - Voltage above normal or shorted to high source. High signal voltage or open circuit detected at the aftertreatment diesel particulate filter intake temperature sensor circuit.	Possible reduced engine performance.
3318 3242 2	Aftertreatment diesel particulate filter intake temperature - Data erratic, intermittent, or incorrect. The aftertreatment diesel particulate filter intake temperature is not changing with engine operating conditions.	Possible reduced engine performance.
3319 3246 3	Aftertreatment diesel particulate filter outlet temperature sensor circuit - Voltage above normal or shorted to high source. High signal voltage or open circuit detected at the aftertreatment diesel particulate filter outlet temperature sensor circuit.	Possible reduced engine performance.

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
3321 3246 4	Aftertreatment diesel particulate filter outlet temperature sensor circuit - Voltage below normal or shorted to low source. Low signal voltage detected at the aftertreatment diesel particulate filter outlet temperature sensor circuit.	Possible reduced engine performance.
3322 3246 2	Aftertreatment diesel particulate filter outlet temperature - Data erratic, intermittent, or incorrect. The aftertreatment diesel particulate filter outlet temperature is not changing with engine operating conditions.	Possible reduced engine performance.
3326 91 9	SAE J1939 Multiplexed accelerator pedal or lever sensor system - Abnormal update rate. The ECM expected information from a multiplexed accelerator pedal or lever sensor but did not receive it soon enough or did not receive it at all.	Engine will only idle.
3328 191 9	Transmission output shaft speed - Abnormal update rate. No communication or an invalid data transfer rate has been detected on the J1939 data link between the ECM and the transmission output shaft speed sensor.	None on performance.
3342 4752 18	Engine exhaust gas recirculation cooler efficiency - Data valid but below normal operating range - Moderately severe level. The EGR cooler is not cooling the recirculated exhaust gas sufficiently.	None on performance.
3343 5285 18	Engine charge-air cooler efficiency - Data valid but below normal operating range - Moderately severe level. The engine charge air cooler is not cooling the intake air flow sufficiently.	None on performance.
3361 102 10	Intake manifold 1 pressure - Abnormal rate of change. The VGT position reading is stuck.	Possible reduced engine performance.
3366 111 18	Coolant level - Data valid but below normal operating range - Moderately severe level. Very low engine coolant level detected.	None on performance.
3374 1818 31	Roll over protection brake control active - Condition exists. The ECM received a message from the anti-lock braking (ABS) controller, inhibiting cruise control operation.	Cruise control could possibly not operate.
3375 5397 31	Aftertreatment diesel particulate filter regeneration too frequent - Condition exists. The system has detected the need for an active regeneration has occurred too soon following the last active regeneration.	None on performance.
3376 5319 31	Aftertreatment diesel particulate filter incomplete regeneration - Condition exists. The system has detected that the aftertreatment diesel particulate filter differential pressure is too high following an active regeneration.	Possible frequent need for aftertreatment regeneration.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
3382 3058 18	Engine exhaust gas recirculation (EGR) system - Data valid but below normal operating range - Moderately severe level. Measured egr flow is lower than commanded.	Possible reduced engine performance.
3383 3058 16	Engine exhaust gas recirculation (EGR) system - Data valid but above normal operating range - Moderately severe Level. Measured EGR flow is higher than commanded.	Possible reduced engine performance.
3394 4766 18	Aftertreatment 1 diesel oxidation catalyst outlet gas temperature - Data valid but below normal operating range - Moderately severe level. The diesel oxidation catalyst outlet Temperature is below the operating limit	Possible frequent need for aftertreatment regeneration.
3396 3750 31	Diesel particulate filter 1 conditions not met for active regeneration - Condition exists. The aftertreatment temperatures are not warm enough for aftertreatment injection.	Possible frequent need for aftertreatment regeneration.
3418 191 19	Transmission output shaft speed - Received network data in error. The J1939 multiplexing controller has indicated a malfunction of the transmission output shaft speed sensor.	None on performance.
3422 4344 3	Aftertreatment diesel exhaust fluid line heater 3 circuit - Voltage above normal or shorted to high source. High signal voltage detected at the diesel exhaust fluid line heater 3 circuit.	Possible reduced engine performance.
3423 4344 4	Aftertreatment diesel exhaust fluid line heater 3 circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the diesel exhaust fluid line heater 3 circuit.	Possible reduced engine performance.
3425 4344 5	Aftertreatment diesel exhaust fluid line heater 3 circuit - Current below normal or open circuit. Open circuit detected in the diesel exhaust fluid line heater 3.	Possible reduced engine performance.
3488 563 9	Anti-lock braking (ABS) controller - Abnormal update rate. No communication or an invalid data transfer rate has been detected on the J1939 data link between the ECM and the anti- lock braking (ABS) controller.	None on performance.
3492 251 10	Real time clock - Abnormal rate of change. The real time clock indicates a stuck engine off timer.	None on performance.
3494 1081 7	Engine wait to start lamp - Mechanical system not responding or out of adjustment. Wait to Start lamp has malfunction.	None on performance.
3497 1761 17	Aftertreatment diesel exhaust fluid tank level - Data valid but below normal operating range - Least severe level. The aftertreatment diesel exhaust fluid tank level is low.	None on performance.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
3498 1761 18	Aftertreatment diesel exhaust fluid tank level - Data valid but below normal operating range - Moderately severe level. The aftertreatment diesel exhaust fluid tank level is very low.	None on performance.	
3525 84 19	Wheel-based vehicle speed - Received network data in error. The J1939 multiplexing controller has indicated a malfunction of the wheel-based vehicle speed sensor.	Engine speed limited to maximum engine speed without VSS parameter value. Cruise control, gear-down protection, and road speed governor will not work.	
3526 84 9	Wheel-Based vehicle speed - Abnormal update rate. No communication or an invalid data transfer rate has been detected on the J1939 data link between the ECM and the wheel- based vehicle speed sensor.	Engine speed limited to maximum engine speed without VSS parameter value. Cruise control, gear-down protection, and road speed governor will not work.	
3527 558 19	Accelerator pedal or lever idle validation switch - Received network data in error. The J1939 multiplexing controller has indicated a malfunction of the accelerator pedal or lever idle validation switch.	witch The engine will only idle. ated lever	
3528 558 9Accelerator pedal or lever idle validation switch - Abnormal update rate. No communication or an invalid data transfer rate has been detected on the J1939 data link between the ECM and the accelerator pedal or lever idle validation switch.Engine will only idle		Engine will only idle.	
3531 171 9	Ambient air temperature - Abnormal update rate. No communication or an invalid data transfer rate has been detected on the J1939 data link between the ECM and the ambient air temperature sensor.	Possible reduced engine performance.	
3532 171 19	Ambient air temperature - Received network data in error. The J1939 multiplexing controller has indicated a malfunction of the ambient air temperature sensor.	Possible reduced engine performance.	
3539 51 3	Engine intake throttle actuator position sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the engine intake air throttle position sensor circuit.	Possible reduced engine performance.	
3541 51 4	Engine intake throttle actuator position sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the engine intake air throttle position sensor circuit.	Possible reduced engine performance.	
3542 51 2	Engine intake throttle actuator position sensor - Data erratic, intermittent or incorrect. The engine intake air throttle posistion feedback is erratic or incorrect.	Possible reduced engine performance.	
3545 3226 10	Aftertreatment outlet NOx sensor circuit - Abnormal rate of change. The aftertreatment outlet NOx sensor reading is not valid.	None on performance.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
3547 4096 31	Aftertreatment diesel exhaust fluid tank empty - Condition exists. The diesel exhaust fluid tank is empty.	Possible reduced engine performance.	
3555 1081 9	Engine wait to start lamp - Abnormal update rate. A loss of communication has been detected.	None on performance.	
3556 1081 19	Engine wait to start lamp - Received network data in error. The ECM received an invalid signal on the SAE J1939 datalink.	None on performance.	
3558 3361 3	Aftertreatment diesel exhaust fluid dosing unit - Voltage above normal or shorted to high source. High signal voltage detected at the aftertreatment diesel exhaust fluid dosing unit.	Possible reduced engine performance.	
3559 3361 4	Aftertreatment diesel exhaust fluid dosing unit - Voltage below normal or shorted to low source. Low signal voltage detected at the aftertreatment diesel exhaust fluid dosing unit.		
3562 5491 3	Aftertreatment diesel exhaust fluid line heater relay - Voltage above normal or shorted to high source. High signal voltage detected at the diesel exhaust fluid line heater relay.	Possible reduced engine performance.	
3563 5491 4	Aftertreatment diesel exhaust fluid line heater relay - Voltage below normal or shorted to low source. Low signal voltage detected at the diesel exhaust fluid line heater relay.	Possible reduced engine performance.	
3567 5394 5	Aftertreatment diesel exhaust fluid dosing valve - Current below normal or open circuit. A circuit error has been detected in the aftertreatment diesel exhaust fluid dosing valve circuit.	Possible reduced engine performance.	
3568 5394 7	Aftertreatment diesel exhaust fluid (DEF) Dosing valve - Mechanical system not responding or out of adjustment. A mechanical malfunction has been detected in the DEF dosing valve.	Possible reduced engine performance.	
3571 4334 3	Aftertreatment diesel exhaust fluid pressure sensor - Voltage above normal or shorted to high source. High signal voltage detected at the aftertreatment diesel exhaust fluid pressure sensor circuit.	Possible reduced engine performance.	
3572 4334 4	Aftertreatment diesel exhaust fluid pressure sensor - Voltage below normal or shorted to low source. Low signal voltage detected at the diesel exhaust fluid pressure sensor circuit.	Possible reduced engine performance.	
3574 4334 18	Aftertreatment diesel exhaust fluid pressure sensor - Data valid but below normal operating range - Moderately severe level. Low diesel exhaust fluid pressure has been detected in the dosing unit.	Possible reduced engine performance.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
3575 4334 16	Aftertreatment diesel exhaust fluid pressure sensor - Data valid but above normal operating range - Moderately severe level. The diesel exhaust fluid dosing unit has detected a blockage in the diesel exhaust fluid return flow.	Possible reduced engine performance.	
3577 4376 3	Aftertreatment diesel exhaust fluid return valve - Voltage above normal or shorted to high source. High signal voltage detected at the aftertreatment diesel exhaust fluid return valve.	Possible reduced engine performance.	
3578 4376 4	Aftertreatment diesel exhaust fluid return valve - Voltage below normal, or shorted to low source. Low signal voltage detected at the diesel exhaust fluid return valve.	Possible reduced engine performance.	
3582 4364 18	 Aftertreatment SCR catalyst conversion Aftertreatment SCR catalyst conversion efficiency - Data valid but below normal operating range - Moderately severe level. NOx conversion across the SCR catalyst is too low. 		
3583 5031 10	Aftertreatment outlet NOx sensor heater - Abnormal rate of change. The aftertreatment outlet NOx sensor heater is unable to maintain its normal operating temperature.	None on performance.	
3596 4334 2	Aftertreatment diesel exhaust fluid pressure sensor - Data erratic, intermittent, or incorrect. The diesel exhaust fluid pressure sensor has reported a reading too high or low for the operating conditions.	Possible reduced engine performance.	
3649 5024 10	Aftertreatment Intake NOx sensor heater - Abnormal rate of change. The aftertreatment intake NOx sensor heater is unable to maintain its normal operating temperature.	None on performance.	
3681 3228 2	Aftertreatment outlet NOx sensor power supply - Data erratic, intermittent, or incorrect. The aftertreatment outlet NOx sensor indicates that the power supply to the sensor is incorrect.	None on performance.	
3682 3218 2	Aftertreatment Intake NOx sensor power supply - Data erratic, entermittent or encorrect. The aftertreatment intake NOx sensor indicates that the power supply to the sensor is incorrect.	None on performance.	
3697 630 12	Engine control module calibration memory - Bad intelligent device or component. Error internal to the ECM related to engine software failures.	Engine may not start or may be difficult to start.	
3712 5246 0	Aftertreatment SCR operator inducement - Data valid but above normal operational range - Most severe level. Critical SCR related fault codes have been active for an extended period of time and require immediate attention.	Vehicle speed will be limited to 8 km [5 miles] per hour.	

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
3714 1569 31	Engine protection torque derate - Condition exists. Critical fault codes related to engine operation are active.	Possible reduced engine performance.	
3715 188 16	Engine speed at idle - Data valid but below normal operating range - Moderately severe level. The engine speed at idle has exceeded the governed idle speed.	Possible reduced engine performance.	
3716 188 18	Engine speed at idle - Data valid but below normal operational range - Moderately severe level. Engine is not maintaining the governed idle speed.	None on performance.	
3717 3226 13	Aftertreatment outlet NOx sensor - Out of calibration. A calibration mismatch between the aftertreatment outlet NOx sensor and the ECM has been detected.	None on performance.	
3718 3216 13	Aftertreatment intake NOx - Out of calibration. A calibration mismatch between the aftertreatment intake NOx sensor and the ECM has been detected.	None on performance.	
3724 168 17	Battery 1 voltage - Data valid but below normal operating range - Least severe level. Low voltage to the EGR valve device driver has been detected.	Possible reduced engine performance.	
3725 3216 10	Aftertreatment Intake NOx sensor - Abnormal rate of change. The aftertreatment intake NOx sensor reading is not valid.	None on performance.	
3727 5571 7	High pressure common rail fuel pressure relief valve - Mechanical system not responding or out of adjustment. The fuel rail high-pressure relief valve has opened at a lower than expected pressure.	Possible reduced engine performance.	
3737 1675 31	Engine starter mode overcrank protection - Condition exists. The starter motor has been temporarily disabled in order to prevent starter damage.	Starter operation is prohibited until the starter motor has adequately cooled.	
 High pressure common rail fuel pressure relief valve - Data valid but above normal operational range - Most severe level. The fuel rail pressure relief valve has opened due to high fuel rail pressure. 		Engine may run rough, may stop running, may not start, or may be difficult to start.	
3749 3226 20	Aftertreatment outlet NOx sensor - Data not rational - Drifted high. An offset in the outlet NOx sensor reading has been detected.	None on performance.	
3838 2978 9	Estimated engine parasitic losses - Percent torque - Abnormal update rate. A loss of communication has been detected.	None on performance.	
3843 5603 9	Cruise control disable command - Abnormal update rate. No communication or an invalid data transfer rate has been detected on the J1939 data link between the ECM and the cruise control.	None on performance.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
3844 5605 31	Cruise control pause command - Condition exists. The adaptive cruise control has dropped out and must be manually engaged.	Cruise control could possibly not operate.	
3845 5603 31	Cruise control disable command - Condition exists. The adaptive cruise control has dropped out and must be manually engaged.	Cruise control could possibly not operate.	
3899 5848 4	Aftertreatment 1 SCR Intermediate NH3 sensor - Voltage below normal, or shorted to low source. A circuit error has been detected in the NH3 sensor.	None on performance.	
3911 5848 9	3911 5848 9Aftertreatment SCR Intermediate NH3 sensor - Abnormal update rate. Loss of communication with the aftertreatment SCR intermediate NH3 sensor.Possible reduced engine performance		
3912 5853 10Aftertreatment SCR Intermediate NH3 sensor heater - Abnormal rate of change. A malfunction of the aftertreatment SCR intermediate NH3 sensor heater has been detected.Possible reduced engine		Possible reduced engine performance.	
 Aftertreatment SCR Intermediate NH3 gas sensor power supply - Data valid but above normal operating range - Moderately severe level. High battery voltage supply detected at the aftertreatment SCR intermediate NH3 sensor. 		Possible reduced engine performance.	
 Aftertreatment SCR Intermediate NH3 gas sensor power supply - Data valid but below normal operating range - Moderately severe level. Low battery voltage supply detected at the aftertreatment SCR intermediate NH3 sensor. 		Possible reduced engine performance.	
Aftertreatment SCR Intermediate NH3 gas sensor power supply - Data erratic, intermittent or incorrect. Intermittent battery voltage supply detected at the aftertreatment SCR intermediate NH3 sensor.		Possible reduced engine performance.	
 Aftertreatment SCR Intermediate NH3 sensor - Out of calibration. Incorrect trim resistance has been detected in the aftertreatment SCR intermediate NH3 sensor. 		Possible reduced engine performance.	
3936 5848 12	Aftertreatment SCR Intermediate NH3 sensor - Bad intelligent device or component. An internal error of the aftertreatment SCR intermediate NH3 sensor has been detected.	Possible reduced engine performance.	
3937 5848 10	Aftertreatment 1 SCR Intermediate NH3 sensor - Abnormal rate of change. The aftertreatment SCR intermediate NH3 sensor reading is NOT valid.	Possible reduced engine performance.	

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
4149 2623 8	Accelerator pedal or lever position sensor 2 circuit frequency - Abnormal frequency or pulse width or period. The accelerator pedal position sensor reading is out of range.	The engine will operate in Limp Home mode.	
4151 5742 9 Aftertreatment diesel particulate filter rate. No communications on the J1939 data link between the ECM and the aftertreatment diesel particulate filter temperature sensor module		Possible reduced engine performance.	
4152 5743 9	Aftertreatment selective catalytic reduction temperature sensor module - Abnormal update rate. No communications on the J1939 data link between the ECM and the aftertreatment SCR temperature sensor module.	Possible reduced engine performance.	
4155 5746 3	Aftertreatment 1 diesel exhaust fluid dosing unit heater relay - Voltage above normal, or shorted to high source. High signal voltage detected at the aftertreatment diesel exhaust fluid dosing unit heater relay circuit.	Possible reduced engine performance.	
 Aftertreatment 1 diesel exhaust fluid dosing unit heater relay - Voltage below normal, or shorted to low source. Low signal voltage detected at the aftertreatment diesel exhaust fluid dosing unit heater relay circuit. 		Possible reduced engine performance.	
4157 4376 7	Aftertreatment diesel exhaust fluid return valve - Mechanical system not responding or out of adjustment. A stuck aftertreatment diesel exhaust fluid return valve has been detected.	None on performance.	
4158 5742 12	Aftertreatment diesel particulate filter temperature sensor module - Bad intelligent device or component. An internal error has been detected in the aftertreatment diesel particulate filter temperature sensor module.	Possible reduced engine performance.	
 Aftertreatment selective catalytic reduction temperature sensor module - Bad intelligent device or component. An internal error has been detected in the aftertreatment SCR temperature sensor module. 		Possible reduced engine performance.	
4161 5742 3	Aftertreatment diesel particulate filter temperature sensor module - Voltage above normal, or shorted to high source. High battery supply voltage detected at the aftertreatment diesel particulate filter temperature sensor module.	Possible reduced engine performance.	
4162 5742 4	Aftertreatment diesel particulate filter temperature sensor module - Voltage below normal, or shorted to low source. Low battery supply voltage detected at the aftertreatment diesel particulate filter temperature sensor module.	Possible reduced engine performance.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
4163 5742 16	Aftertreatment diesel particulate filter temperature sensor module- Data valid but above normal operating range - Moderately severe level. High internal temperature detected in the aftertreatment diesel particulate filter temperature sensor module.	Possible reduced engine performance.	
4164 5743 3	Aftertreatment selective catalytic reduction temperature sensor module - Voltage above normal, or shorted to high source. High battery supply voltage detected at the aftertreatment SCR temperature sensor module.	Possible reduced engine performance.	
4165 5743 4	Aftertreatment selective catalytic reduction temperature sensor module - Voltage below normal, or shorted to low source. Low battery supply voltage detected at the aftertreatment SCR temperature sensor module.	Possible reduced engine performance.	
4166 5743 16 Aftertreatment selective catalytic reduction temperature sensor module - Data valid but above normal operating range - Moderately severe level. High internal temperature detected in the aftertreatment SCR temperature sensor module.		Possible reduced engine performance.	
4168 5745 3	Aftertreatment diesel exhaust fluid dosing unit heater - Voltage above normal, or shorted to high source. The aftertreatment diesel exhasut fluid dosing unit heater is detected to be stuck on.	None on performance.	
4169 5745 5	Aftertreatment diesel exhaust fluid dosing unit heater - Voltage below normal, or shorted to low source. The aftertreatment diesel exhasut fluid dosing unit heater is detected to be stuck off.	Possible reduced engine performance.	
 Aftertreatment diesel exhaust fluid dosing unit heater - Data valid but below normal operating range - Moderately severe level. The aftertreatment diesel exhaust fluid dosing unit failed to thaw. 		Possible reduced engine performance.	
4213 3695 2	Aftertreatment diesel particulate filter regeneration inhibit switch - Data erratic, intermittent or incorrect. The diesel particulate filter regeneration permit switch is stuck in the OFF or INHIBIT position.	Possible frequent need for aftertreatment regeneration.	
4215 563 31	Anti-lock braking (ABS) Active - Condition exists. Cruise control was paused due to an anti-wheel slip message from teh ABS controller.	Adaptive cruise control will not operate. Standard cruise control may not operate.	
4244 4337 2	Aftertreatment diesel exhaust fluid dosing temperature - Data erratic, intermittent or incorrect. The aftertreatment diesel exhaust fluid dosing temperature is irrational.	None on performance.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
4245 5798 2	Aftertreatment diesel exhaust fluid dosing unit heater temperature - Data erratic, intermittent or incorrect. The aftertreatment diesel exhaust fluid dosing unit heater temperature is irrational.	None on performance.	
4249 4337 10	Aftertreatment diesel exhaust fluid dosing temperature - Abnormal rate of change. The aftertreatment diesel exhaust fluid dosing unit temperature is stuck.	None on performance.	
4251 5798 10	Aftertreatment 1 diesel exhaust fluid dosing unit heater temperature - Abnormal rate of change. The aftertreatment diesel exhaust fluid dosing unit heater temperature sensor reading is stuck.	None on performance.	
4252 1081 31	Engine wait to start lamp - Condition exists. The received signal does not match the commanded signal.	None on performance.	
4259 Aftertreatment diesel particulate filter 5742 known. Intermittent battery voltage supply 11 detected at the aftertreatment diesel particulate filter temperature sensor module.		Possible reduced engine performance.	
4261 5743 11	Aftertreatment selective catalytic reduction temperature sensor module - Root cause not known. Intermittent battery voltage supply detected at the aftertreatment SCR temperature sensor module.	Possible reduced engine performance.	
4279 5848 21	Aftertreatment 1 SCR Intermediate NH3 - Data not rational - Drifted low. An in range low failure has been detected.	Possible reduced engine performance.	
4281 5848 2	Aftertreatment SCR Intermediate NH3 - Data erratic, intermittent or incorrect. The aftertreatment SCR intermediate NH3 sensor reading is stuck.	None on performance.	
4284 5793 9	Desired engine fueling state - Abnormal update rate. A valid message from the transmission ECU has NOT been received.	Engine may not start or may be difficult to start.	
4289 91 8	Accelerator pedal or lever position sensor 1 circuit frequency - Abnormal frequency or pulse width or period. The accelerator pedal position sensor reading is out of range.	The engine will operate in limp home mode.	
4452 520668 31	Aftertreatment outlet NOx sensor closed loop operation - Condition exists. The maximum dosing adjustment has been reached.	Possible reduced engine performance.	
4453 520669 31	Aftertreatment intermediate NH3 sensor closed loop operation - Condition exists. The maximum dosing adjustment has been reached.	None on performance.	
4517 237 13	Vehicle Identification number - Out of calibration. The vehicle identification number has not been programmed into the ECM.	None on performance.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
4518 5862 3	Aftertreatment SCR Intermediate gas temperature sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the aftreatment SCR intermediate temperature sensor circuit.	Possible reduced engine performance.	
4519 5862 4	Aftertreatment SCR Intermediate gas temperature sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the aftertreatment SCR intermediate temperature sensor circuit.	Possible reduced engine performance.	
4521 5862 2	Aftertreatment SCR Intermediate gas temperature sensor - Data erratic, intermittent or incorrect. The aftertreatment SCR intermediate temperature sensor reading is irrational.	Possible reduced engine performance.	
4524 5862 0 Aftertreatment SCR intermediate gas temperature - Data valid but above normal operational range - Most severe level. The aftertreatment SCR intermediate temperature sensor reading is above the engine protection limit.		Progressive power and/or speed derate increasing in severity from time of alert. If the engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.	
4525 5862 16	Aftertreatment 1 SCR intermediate gas temperature - Data valid but above normal operating range - Moderately severe level. High SCR Intermediate temperature detected.	Progressive power and/or speed derate increasing in severity from time of alert. If the engine protection shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.	
4526 521 2	Brake pedal position - Data erratic, intermittent or incorrect. The values of the 2 brake switch signals do not match.	None on performance.	
4572 3031 9	Aftertreatment diesel exhaust fluid tank temperature - Abnormal update rate. The ECM lost communication with the aftertreatment diesel exhaust fluid tank temperature sensor.	Possible reduced engine performance.	
4584 3936 14 Aftertreatment diesel particulate filter system - Special instructions. The incorrect aftertreatment diesel particulate filter system has been installed with the engine.		Engine will be shut down.	
4585 4792 14	Aftertreatment 1 SCR catalyst system - Special instructions. The incorrect SCR system has been Installed.	Engine will be shut down.	
4612 520701 31	Engine intake manifold pressure system monitor - Condition exists. The engine is unable to meet the air handling system commands.	Possible reduced engine performance.	
4658 4331 18	Aftertreatment SCR actual dosing reagent quantity - Data valid but below normal operating range - Moderately severe level. Low aftertreatment diesel exhaust fluid flow detected.	Possible reduced engine performance.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
4691 5585 18	Engine injector metering rail 1 cranking pressure - Data valid but below normal operating range - Moderately severe level. The fuel rail pressure during cranking is too low for the engine to start.	Engine may not start or may be difficult to start.	
4713 5357 31	Engine fuel injection quantity error for multiple cylinders - Condition exists. A malfunction of all fuel injectors has been detected.	Engine may run rough, may stop running, may not start, or may be difficult to start.	
4726 1239 16	Engine fuel leakage - Data valid but above normal operating range - Moderately severe level. Fuel rail pressure decay has been detected.	Engine may run rough, may stop running, may not start, or may be difficult to start.	
4727 157 15	Injector metering rail 1 pressure - Data valid but above normal operating range - Least severe level. A self pumping condition has been detected in the fuel system.	Possible reduced engine performance.	
4731 3031 13	Aftertreatment diesel exhaust fluid tank temperature sensor - Out of calibration. The received datalink message was not valid.	Possible reduced engine performance.	
4732 1761 13	Aftertreatment diesel exhaust fluid tank level sensor - Out of calibration. The received datalink message was not valid.	None on performance.	
4739 1761 11	Aftertreatment 1 diesel exhaust fluid tank level sensor - Root cause not known. An unknown error has been detected with the aftertreatment diesel exhaust fluid tank level sensor.	Possible reduced engine performance.	
4769 1761 10	Aftertreatment 1 diesel exhaust fluid tank level sensor - Abnormal rate of change. A valid diesel exhaust fluid tank level reading has NOT been received.	Possible reduced engine performance.	
4865 6303 3	Engine coolant level 2 sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the engine coolant level 2 circuit.	None on performance.	
4866 6303 4	Engine coolant level 2 sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the engine coolant level 2 circuit.	None on performance.	
4956 520750 13	Engine variable geometry turbo (VGT) software - Out of calibration. VGT software does not match application.	Possible reduced engine performance.	
4957 520750 31	Engine variable geometry turbo (VGT) software - Condition exists. The VGT actuator and ECM software is not compatible.	Possible reduced engine performance.	

3) DEFINITION OF OPERATING MODES

(1) Normal

There's no failure detected in the transmission system or the failure has no or slight effects on transmission control. TCU will work without or in special cases with little limitations. (See following table)

(2) Substitute clutch control

TCU can't change the gears or the direction under the control of the normal clutch modulation.

TCU uses the substitute strategy for clutch control. All modulations are only time controlled. (Comparable with EST 25)

(3) Limp-home

The detected failure in the system has strong limitations to transmission control. TCU can engage only one gear in each direction. In some cases only one direction will be possible.

TCU will shift the transmission into neutral at the first occurrence of the failure. First, the operator must shift the gear selector into neutral position.

If output speed is less than a threshold for neutral to gear and the operator shifts the gear selector into forward or reverse, the TCU will select the limp-home gear.

If output speed is less than a threshold for reversal speed and TCU has changed into the limphome gear and the operator selects a shuttle shift, TCU will shift immediately into the limp-home gear of the selected direction.

If output speed is greater than the threshold, TCU will shift the transmission into neutral.

The operator has to slow down the vehicle and must shift the gear selector into neutral position.

(4) Transmission-shutdown

TCU has detected a severe failure that disables control of the transmission.

TCU will shut off the solenoid valves for the clutches and also the common power supply (VPS1). Transmission shifts to neutral.

The park brake will operate normally, also the other functions which use ADM1 to ADM8.

The operator has to slow down the vehicle. The transmission will stay in neutral.

(5) TCU-shutdown

TCU has detected a severe failure that disables control of system.

TCU will shut off all solenoid valves and also both common power supplies (VPS1, VPS2).

The park brake will engage, also functions are disabled which use ADM 1 to ADM 8.

The transmission will stay in neutral.

※ Abbreviations

- OC : Open circuit
- SC : Short circuit

OP mode : Operating mode

- TCU : Transmission control unit
- EEC : Electronic engine controller
- PTO : Power take off

4) TRANSMISSION FAULT CODES

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
10	Logical error at direction select signal 3rd shift lever TCU detected a wrong signal combination for the direction · Cable from shift lever 3 to TCU is broken · Cable is defective and is contacted to battery voltage or vehicle ground · Shift lever is defective	TCU shifts transmission to neutral if selector active OP mode : Transmission shutdown if selector active	 Check the cables from TCU to shift lever 3 Check signal combinations of shift lever positions F-N-R If shift lever is a CAN shift lever check CAN cable/shifter/device Fault is cleared if TCU detects a valid neutral signal for the direction at the shift lever
11	Logical error at gear range signal TCU detected a wrong signal combination for the gear range · Cable from shift lever to TCU is broken · Cable is defective and is contacted to battery voltage or vehicle ground · Shift lever is defective	TCU shifts transmission to neutral OP mode : Transmission shutdown	 Check the cables from TCU to shift lever Check signal combinations of shift lever positions for gear range Failure cannot be detected in systems with DW2/DW3 shift lever. Fault is taken back if TCU detects a valid signal for the position
12	Logical error at direction select signal TCU detected a wrong signal combination for the direction · Cable from shift lever to TCU is broken · Cable is defective and is contacted to battery voltage or vehicle ground · Shift lever is defective	TCU shifts transmission to neutral OP mode : Transmission shutdown	 Check the cables from TCU to shift lever Check signal combinations of shift lever positions F-N-R Fault is taken back if TCU detects a valid signal for the direction at the shift lever
13	Logical error at engine derating device TCU detected no reaction of engine while derating device active	After selecting neutral, TCU change to OP mode limp home	 Check engine derating device This fault is reset after power up of TCU
15	Logical error at direction select signal 2 shift lever TCU detected a wrong signal combination for the direction · Cable from shift lever 2 to TCU is broken · Cable is defective and is contacted to battery voltage or vehicle ground · Shift lever is defective	TCU shifts transmission to neutral if selector active OP mode : Transmission shutdown if elector active	 Check the cables from TCU to shift lever 2 Check signal combinations of shift lever positions F-N-R Fault is taken back if TCU detects a valid neutral signal for the direction at the shift lever
17	 S.C. to ground at customer specific function No. 1 (ride control) TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground Cable is defective and is contacted to vehicle ground Customer specific function No. 1 device has an internal defect Connector pin is contacted to vehicle ground 	Customer specific	 Check the cable from TCU to customer specific function No. 1 device Check the connectors from customer specific function No. 1 to TCU Check the resistance of customer specific function No. 1 device

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
18	 S.C. to battery voltage at customer specific function No. 1 (ride control) TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage Cable is defective and is contacted to battery voltage Customer specific function No. 1 device has an internal defect Connector pin is contacted to battery voltage 	Customer specific	 Check the cable from TCU to customer specific function No. 1 device Check the connectors from customer specific function No. 1 to TCU Check the resistance of customer specific function No. 1 device
19	 O.C. at customer specific function No. 1 (ride control) TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin Cable is defective and has no connection to TCU Customer specific function No. 1 device has an internal defect Connector has no connection to TCU 	Customer specific	 Check the cable from TCU to customer specific function No. 1 device Check the connectors from customer specific function No. 1 device to TCU Check the resistance of customer specific function No. 1 device
21	 S.C. to battery voltage at clutch cut off input The measured voltage is too high: Cable is defective and is contacted to battery voltage Clutch cut off sensor has an internal defect Connector pin is contacted to battery voltage 	Clutch cut off function is disabled OP mode : Normal	 Check the cable from TCU to the sensor Check the connectors Check the clutch cut off sensor
22	 S.C. to ground or O.C. at clutch cut off input The measured voltage is too low: Cable is defective and is contacted to vehicle ground Cable has no connection to TCU Clutch cut off sensor has an internal defect Connector pin is contacted to vehicle ground or is broken 	Clutch cut off function is disabled OP mode : Normal	 Check the cable from TCU to the sensor Check the connectors Check the clutch cut off sensor
25	 S.C. to battery voltage or O.C. at transmission sump temperature sensor input The measured voltage is too high: Cable is defective and is contacted to battery voltage Cable has no connection to TCU Temperature sensor has an internal defect Connector pin is contacted to battery voltage or is broken 	No reaction, TCU use default temperature OP mode : Normal	 Check the cable from TCU to the sensor Check the connectors Check the temperature sensor
Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
---------------------	--	--	---
26	 S.C. to battery voltage or O.C. at transmission sump temperature sensor input The measured voltage is too low: Cable is defective and is contacted to vehicle ground Temperature sensor has an internal defect Connector pin is contacted to vehicle ground 	No reaction, TCU uses default temperature OP mode : Normal	 Check the cable from TCU to the sensor Check the connectors Check the temperature sensor
27	 S.C. to battery voltage or O.C. at retarder temperature sensor input The measured voltage is too high: Cable is defective and is contacted to battery voltage Cable has no connection to TCU Temperature sensor has an internal defect Connector pin is contacted to battery voltage or is broken 	No reaction, TCU uses default temperature OP mode : Normal	 Check the cable from TCU to the sensor Check the connectors Check the temperature sensor
28	 S.C. to ground at retarder temperature sensor input The measured voltage is too low: Cable is defective and is contacted to vehicle ground Temperature sensor has an internal defect Connector pin is contacted to vehicle ground 	No reaction, TCU uses default temperature OP mode : Normal	 Check the cable from TCU to the sensor Check the connectors Check the temperature sensor
31	S.C. to battery voltage or O.C. at engine speed input TCU measures a voltage higher than 7.00V at speed input pin · Cable is defective and is contacted to battery voltage · Cable has no connection to TCU · Speed sensor has an internal defect · Connector pin is contacted to battery voltage or has no contact	OP mode : Substitute clutch control	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor
32	S.C. to ground at engine speed input TCU measures a voltage less than 0.45V at speed input pin · Cable/connector is defective and is contacted to vehicle ground · Speed sensor has an internal defect	OP mode : Substitute clutch control	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor
33	Logical error at engine speed input TCU measures a engine speed over a threshold and the next moment the measured speed is zero · Cable/connector is defective and has bad contact · Speed sensor has an internal defect · Sensor gap has the wrong size	OP mode : Substitute clutch control	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor Check the sensor gap This fault is reset after power up of TCU

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
34	 S.C. to battery voltage or O.C. at turbine speed input TCU measures a voltage higher than 7.00V at speed input pin Cable is defective and is contacted to vehicle battery voltage Cable has no connection to TCU Speed sensor has an internal defect Connector pin is contacted to battery voltage or has no contact 	OP mode : Substitute clutch control If a failure is existing at output speed, TCU shifts to neutral OP mode : Limp home	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor
35	S.C. to ground at turbine speed input TCU measures a voltage less than 0.45V at speed input pin · Cable/connector is defective and is contacted to vehicle ground · Speed sensor has an internal defect	OP mode : Substitute clutch control If a failure is existing at output speed, TCU shifts to neutral OP mode : Limp home	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor This fault is reset after power up of TCU
36	Logical error at turbine speed input TCU measures a turbine speed over a threshold and at the next moment the measured speed is zero · Cable/connector is defective and has bad contact · Speed sensor has an internal defect · Sensor gap has the wrong size	OP mode : Substitute clutch control If a failure is existing at output speed, TCU shifts to neutral OP mode : Limp home	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor Check the sensor gap
37	 S.C. to battery voltage or O.C. at internal speed input TCU measures a voltage higher than 7.00V at speed input pin Cable is defective and is contacted to vehicle battery voltage Cable has no connection to TCU Speed sensor has an internal defect Connector pin is contacted to battery voltage or has no contact 	OP mode : Substitute clutch control	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor
38	 S.C. to ground at turbine speed input TCU measures a voltage less than 0.45V at speed input pin Cable/connector is defective and is contacted to vehicle ground Speed sensor has an internal defect 	OP mode : Substitute clutch control	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor
39	Logical error at internal speed input TCU measures a internal speed over a threshold and at the next moment the measured speed is zero · Cable/connector is defective and has bad contact · Speed sensor has an internal defect · Sensor gap has the wrong size	OP mode : Substitute clutch control	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor Check the sensor gap This fault is reset after power up of TCU
3A	 S.C. to battery voltage or O.C. at output speed input TCU measures a voltage higher than 12.5V at speed input pin Cable is defective and is contacted to battery voltage Cable has no connection to TCU Speed sensor has an internal defect Connector pin is contacted to battery voltage or has no contact 	Special mode for gear selection OP mode : S u b s t i t u t e clutch control If a failure is existing at turbine speed, TCU shifts to neutral OP mode : Limp home	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
3B	 S.C. to ground at output speed input TCU measures a voltage less than 1.00V at speed input pin Cable/connector is defective and is contacted to vehicle ground Speed sensor has an internal defect 	Special mode for gear selection OP mode : Substitute clutch control If a failure is existing at turbine speed, TCU shifts to neutral OP mode : Limp home	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor
3C	Logical error at output speed input TCU measures a turbine speed over a threshold and at the next moment the measured speed is zero · Cable/connector is defective and has bad contact · Speed sensor has an internal defect · Sensor gap has the wrong size	Special mode for gear selection OP mode : Substitute clutch control If a failure is existing at turbine speed, TCU shifts to neutral OP mode : Limp home	 Check the cable from TCU to the sensor Check the connectors Check the speed sensor Check the sensor gap This fault is reset after power up of TCU
3D	Turbine speed zero doesn't fit to other speed signals	-	· Not used
3E 54	Output speed zero doesn't fit to other speed signals If transmission is not neutral and the shifting has finished, TCU measures output speed zero and turbine speed or internal speed not equal to zero. • Speed sensor has an internal defect • Sensor gap has the wrong size DCT1 timeout Timeout of CAN-message DCT1 from	Special mode for gear selection OP mode : Substitute clutch control If a failure is existing at turbine speed, TCU shifts to neutral OP mode : Limp home OP mode : Normal	 Check the sensor signal of output speed sensor Check the sensor gap of output speed sensor Check the cable from TCU to the sensor This fault is reset after power up of TCU Check display computer Check wire of CAN-Bus
	 display computer Interference on CAN-Bus CAN wire/connector is broken CAN wire/connector is defective and has contact to vehicle ground or battery voltage 		Check cable to display computer
55	JSS timeout Timeout of CAN-message JSS from joystick steering controller • Interference on CAN-Bus • CAN wire/connector is broken • CAN wire/connector is defective and has contact to vehicle ground or battery voltage	TCU shifts to neutral while joystick steering is active OP mode : Normal	 Check joystick steering controller Check wire of CAN-Bus Check cable to joystick steering controller
56	Engine CONF timeout Timeout of CAN-message engine CONF from engine controller • Interference on CAN-Bus • CAN wire/connector is broken • CAN wire/connector is defective and has contact to vehicle ground or battery voltage	OP mode : Substitute clutch control	 Check engine controller Check wire of CAN-Bus Check cable to engine controller

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
57	EEC1 timeout Timeout of CAN-message EEC1 from EEC controller • Interference on CAN-Bus • CAN wire/connector is broken • CAN wire/connector is defective and has contact to vehicle ground or battery voltage	OP mode : Substitute clutch control	 Check EEC controller Check wire of CAN-Bus Check cable to EEC controller
58	EEC3 timeout Timeout of CAN-message EEC3 from EEC controller • Interference on CAN-Bus • CAN wire/connector is broken • CAN wire/connector is defective an has contact to vehicle ground or battery voltage	OP mode : Substitute clutch control	 Check EEC controller Check wire of CAN-Bus Check cable to EEC controller
5C	Auto downshift signal CAN signal for automatic downshift is defective · Cluster controller is defective · Interference on CAN-Bus	No reaction	 Check cluster controller Check wire of CAN-Bus Check cable to cluster controller
5D	Manual downshift signal CAN signal for manual downshift is defective · Cluster controller is defective · Interference on CAN-Bus	No reaction	 Check cluster controller Check wire of CAN-Bus Check cable to controller
5E	CCO request signal CAN signal for CCO request is defective · Cluster controller is defective · Interference on CAN-Bus	No reaction	 Check cluster controller Check wire of CAN-Bus Check cable to controller
61	AEB request signal CAN signal for AEB request is defective · I/O controller is defective · Interference on CAN-Bus	No reaction OP mode : Normal	 Check I/O controller, Omron master Check wire of CAN-Bus Check cable to I/O controller, Omron master
64	Sarting gear signal CAN signal for starting gear is defective · I/O controller is defective (illegal starting gear) · Interference on CAN-Bus	No reaction. TCU uses default starting gear OP mode : Normal	 Check I/O controller Check wire of CAN-Bus Check cable to I/O controller
65	Engine torque signal CAN signal for engine torque is defective · Engine controller is defective · Interference on CAN-Bus	OP mode : Substitute clutch control	 Check engine controller Check wire of CAN-Bus Check cable to engine controller
69	Reference engine torque signal CAN signal for reference of engine torque is defective · Engine controller is defective · Interference on CAN-Bus	OP mode : Substitute clutch control	 Check engine controller Check wire of CAN-Bus Check cable to engine controller
6A	Actual engine torque signal CAN signal for actual engine torque is defective · Engine controller is defective · Interference on CAN-Bus	OP mode : Substitute clutch control	 Check engine controller Check wire of CAN-Bus Check cable to engine controller

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
6E	EEC2 timeout Timeout of CAN-message EEC2 from EEC controller • Interference on CAN-Bus • CAN wire/connector is broken • CAN wire/connector is defective and has contact to vehicle ground or battery voltage	No reaction, TCU uses default signal accelerator pedal in idle position OP mode : Normal	 Check EEC controller Check wire of CAN-Bus Check cable to EEC controller
71	 S.C. to battery voltage at clutch K1 The measured resistance value of the valve is out of limit, the voltage at K1 valve is too high Cable/connector is defective and has contact to battery voltage Cable/connector is defective and has contact to another regulator output of the TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from TCU to the gearbox Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
72	 S.C. to ground at clutch K1 The measured resistance value of the valve is out of limit, the voltage at K1 valve is too low Cable/connector is defective and has contact to vehicle ground Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
73	 O.C. at clutch K1 The measured resistance value of the valve is out of limit Cable/connector is defective and has no contact to TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
74	 S.C. to battery voltage at clutch K2 The measured resistance value of the valve is out of limit, the voltage at K2 valve is too high Cable/connector is defective and has contact to battery voltage Cable/connector is defective and has contact to another regulator output of the TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
75	 S.C. to ground at clutch K2 The measured resistance value of the valve is out of limit, the voltage at K2 valve is too low Cable/connector is defective and has contact to vehicle ground Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
76	 O.C. at clutch K2 The measured resistance value of the valve is out of limit Cable/connector is defective and has no contact to TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
77	 S.C. to battery voltage at clutch K3 The measured resistance value of the valve is out of limit, the voltage at K3 valve is too high Cable/connector is defective and has contact to battery voltage Cable/connector is defective and has contact to another regulator output of the TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
78	 S.C. to ground at clutch K3 The measured resistance value of the valve is out of limit, the voltage at K3 valve is too low Cable/connector is defective and has contact to vehicle ground Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
79	 O.C. at clutch K3 The measured resistance value of the valve is out of limit Cable/connector is defective and has no contact to TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
7D	 S.C. ground at engine derating device Cable is defective and is contacted to vehicle ground Engine derating device has an internal defect Connector pin is contacted to vehicle ground 	Engine derating will be on until TCU power down even if fault vanishes (Loose connection) OP mode : Normal	 Check the cable from TCU to the engine derating device Check the connectors from engine derating device to TCU Check the resistance* of engine derating device * Not used * See page 3-77
7E	 S.C. battery voltage at engine derating device Cable/connector is defective and is contacted to battery voltage Engine derating device has an internal defect 	No reaction OP mode : Normal	 Check the cable from TCU to the engine derating device Check the connectors from backup alarm device to TCU Check the resistance* of backup alarm device * See page 3-77

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
7F	 O.C. at engine derating device TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin Cable is defective and has no connection to TCU Engine derating device has an internal defect Connector has no connection to TCU 	No reaction OP mode : Normal	 Check the cable from TCU to the engine derating device Check the connectors from engine derating device to TCU Check the resistance* of engine derating device * See page 3-77
81	 S.C. to battery voltage at clutch K4 The measured resistance value of the valve is out of limit, the voltage at K4 valve is too high Cable/connector is defective and has contact to battery voltage Cable/connector is defective and has contact to another regulator output of the TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
82	 S.C. to ground at clutch K4 The measured resistance value of the valve is out of limit, the voltage at K4 valve is too low Cable/connector is defective and has contact to vehicle ground Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the engine derating device Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
83	 O.C. at clutch K4 The measured resistance value of the valve is out of limit Cable/connector is defective and has contact to TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
84	 S.C. to battery voltage at clutch KV The measured resistance value of the valve is out of limit, the voltage at KV valve is too high Cable/connector is defective and has contact to battery voltage Cable/connector is defective and has contact to another regulator output of the TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
85	S.C. to ground at clutch KV The measured resistance value of the valve is out of limit, the voltage at KV valve is too low • Cable/connector is defective and has contact to vehicle ground • Regulator has an internal defect	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
86	 O.C. at clutch KV The measured resistance value of the valve is out of limit Cable/connector is defective and has contact to TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
87	 S.C. to battery voltage at clutch KR The measured resistance value of the valve is out of limit, the voltage at KR valve is too high Cable/connector is defective and has contact to battery voltage Cable/connector is defective and has contact to another regulator output of the TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
88	 S.C. to ground at clutch KR The measured resistance value of the valve is out of limit, the voltage at KR valve is too low Cable/connector is defective and has contact to vehicle ground Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
89	 O.C. at clutch KR The measured resistance value of the valve is out of limit Cable/connector is defective and has no contact to TCU Regulator has an internal defect 	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check the cable from TCU to the gearbox Check the connectors from gearbox to TCU Check the regulator resistance* Check internal wire harness of the gearbox * See page 3-77
91	 S.C. to ground at relay reverse warning alarm TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground Cable is defective and is contact to vehicle ground Backup alarm device has an internal defect Connector pin is contacted to vehicle ground 	Backup alarm will be on until TCU power down even if fault vanishes(Loose connection) OP mode : Normal	 Check the cable from TCU to the backup alarm device Check the connectors from backup alarm device to TCU Check the resistance* of backup alarm device * See page 3-77
92	 S.C. to battery voltage at relay reverse warning alarm TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage Cable is defective and is contacted to battery voltage Backup alarm device has an internal defect Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	 Check the cable from TCU to the backup alarm device Check the connectors from backup alarm device to TCU Check the resistance* of backup alarm device * See page 3-77

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
93	 O.C. at relay reverse warning alarm TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin Cable is defective and has no connection to TCU Backup alarm device has an internal defect Connector has no connection to TCU 	No reaction OP mode : Normal	 Check the cable from TCU to the backup alarm device Check the connectors from backup alarm device to TCU Check the resistance* of backup alarm device * See page 3-77
94	 S.C. to ground at relay starter interlock TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground Cable is defective and is connection to vehicle ground Starter interlock relay has an internal defect Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	 Check the cable from TCU to the stater interlock relay Check the connectors from starter interlock relay to TCU Check the resistance* of starter interlock relay * See page 3-77
95	 S.C. to battery voltage at relay starter interlock TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage Cable is defective and has no connection to battery voltage Starter interlock relay has an internal defect Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	 Check the cable from TCU to the starter interlock relay Check the connectors from starter interlock relay to TCU Check the resistance* of starter interlock relay * See page 3-77
96	 O.C. at relay starter interlock TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin Cable is defective and has no connection to TCU Starter interlock relay has an internal defect Connector has no connection to TCU 	No reaction OP mode : Normal	 Check the cable from TCU to the starter interlock relay Check the connectors from starter interlock relay to TCU Check the resistance* of starter interlock relay * See page 3-77
9A	 S.C. to ground at converter lock up clutch solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground Cable is defective and is contacted to vehicle ground Converter clutch solenoid has an internal defect Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	 Check the cable from TCU to the converter clutch solenoid Check the connectors from converter clutch solenoid to TCU Check the resistance* of converter clutch solenoid * See page 3-77

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
9B	 O.C. at converter lock up clutch solenoid TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin Cable is defective and has no connection to TCU Converter clutch solenoid has an internal defect Connector has no connection to TCU 	Converter clutch always open, retarder not available OP mode:Normal	 Check the cable from TCU to the converter clutch solenoid Check the connectors from converter clutch solenoid to TCU Check the resistance* of converter clutch solenoid * See page 3-77
9C	 S.C. to battery voltage at converter lock up clutch solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage Cable is defective and has no contacted to battery voltage Converter clutch solenoid has an internal defect Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	 Check the cable from TCU to the converter clutch solenoid Check the connectors from converter clutch solenoid to TCU Check the resistance* of converter clutch solenoid * See page 3-77
A1	 S.C. to ground at difflock or axle connection solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground Cable is defective and is contacted to vehicle ground Difflock solenoid has an internal defect Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	 Check the cable from TCU to the difflock solenoid Check the connectors from difflock solenoid to TCU Check the resistance* of difflock solenoid * See page 3-77
A2	 S.C. to battery voltage at difflock or axle connection solenoid TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage Cable is defective and has no connection to battery voltage Difflock solenoid has an internal defect Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	 Check the cable from TCU to the difflock solenoid Check the connectors from difflock solenoid to TCU Check the resistance* of difflock solenoid * See page 3-77
A3	 O.C. at difflock or axle connection solenoid TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin Cable is defective and has no connection to TCU Difflock solenoid has an internal defect Connector has no connection to TCU 	No reaction OP mode : Normal	 Check the cable from TCU to the difflock solenoid Check the connectors from difflock solenoid to TCU Check the resistance* of difflock solenoid * See page 3-77

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
A4	 S.C. to ground at warning signal output TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground Cable is defective and is contacted to vehicle ground Warning device has an internal defect Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	 Check the cable from TCU to the warning device Check the connectors from warning device to TCU Check the resistance* of warning device * See page 3-77
A5	 O.C. voltage at warning signal output TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin Cable is defective and has no connection to TCU Warning device has an internal defect Connector has no connection to TCU 	No reaction OP mode : Normal	 Check the cable from TCU to the warning device Check the connectors from warning device to TCU Check the resistance* of warning device * See page 3-77
A6	 S.C. to battery voltage at warning signal output TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage Cable is defective and has is contacted to battery voltage Warning device has an internal defect Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	 Check the cable from TCU to the warning device Check the connectors from warning device to TCU Check the resistance* of warning device * See page 3-77
B1	Slippage at clutch K1 TCU calculates a differential speed at closed clutch K1. If this calculated value is out of range, TCU interprets this as slipping clutch · Low pressure at clutch K1 · Low main pressure · Wrong signal at internal speed sensor · Wrong signal at output speed sensor · Wrong size of the sensor gap · Clutch is defective	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check pressure at clutch K1 Check main pressure in the system Check sensor gap at internal speed sensor Check sensor gap at output speed sensor Check signal at internal speed sensor Check signal at output speed sensor Check signal at output speed sensor Check signal at output speed sensor Replace clutch
B2	Slippage at clutch K2 TCU calculates a differential speed at closed clutch K2. If this calculated value is out of range, TCU interprets this as slipping clutch · Low pressure at clutch K2 · Low main pressure · Wrong signal at internal speed sensor · Wrong signal at output speed sensor · Wrong size of the sensor gap · Clutch is defective	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check pressure at clutch K2 Check main pressure in the system Check sensor gap at internal speed sensor Check sensor gap at output speed sensor Check signal at internal speed sensor Check signal at output speed sensor Replace clutch

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
B3	Slippage at clutch K3 TCU calculates a differential speed at closed clutch K3. If this calculated value is out of range, TCU interprets this as slipping clutch · Low pressure at clutch K3 · Low main pressure · Wrong signal at internal speed sensor · Wrong signal at output speed sensor · Wrong size of the sensor gap · Clutch is defective	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check pressure at clutch K3 Check main pressure in the system Check sensor gap at internal speed sensor Check sensor gap at output speed sensor Check signal at internal speed sensor Check signal at output speed sensor Check signal at output speed sensor Replace clutch
B4	Slippage at clutch K4 TCU calculates a differential speed at closed clutch K4. If this calculated value is out of range, TCU interprets this as slipping clutch · Low pressure at clutch K4 · Low main pressure · Wrong signal at internal speed sensor · Wrong signal at turbine speed sensor · Wrong size of the sensor gap · Clutch is defective	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check pressure at clutch K4 Check main pressure in the system Check sensor gap at internal speed sensor Check sensor gap at turbine speed sensor Check signal at internal speed sensor Check signal at turbine speed sensor Replace clutch
B5	Slippage at clutch KV TCU calculates a differential speed at closed clutch KV. If this calculated value is out of range, TCU interprets this as slipping clutch · Low pressure at clutch KV · Low main pressure · Wrong signal at internal speed sensor · Wrong signal at turbine speed sensor · Wrong size of the sensor gap · Clutch is defective	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check pressure at clutch KV Check main pressure in the system Check sensor gap at internal speed sensor Check sensor gap at turbine speed sensor Check signal at internal speed sensor Check signal at turbine speed sensor Check signal at turbine speed sensor Replace clutch
B6	Slippage at clutch KR TCU calculates a differential speed at closed clutch KR. If this calculated value is out of range, TCU interprets this as slipping clutch · Low pressure at clutch KR · Low main pressure · Wrong signal at internal speed sensor · Wrong signal at turbine speed sensor · Wrong size of the sensor gap · Clutch is defective	TCU shifts to neutral OP mode : Limp home If failure at another clutch is pending TCU shifts to neutral OP mode : TCU shutdown	 Check pressure at clutch KR Check main pressure in the system Check sensor gap at internal speed sensor Check sensor gap at turbine speed sensor Check signal at internal speed sensor Check signal at turbine speed sensor Replace clutch
B7	Overtemp sump TCU measured a temperature in the oil sump that is over the allowed threshold.	No reaction OP mode : Normal	 Cool down machine Check oil level Check temperature sensor
B9	Overspend engine	Retarder applies OP mode : Normal	-
BA	Differential pressure oil filter TCU measured a voltage at differential pressure switch out of the allowed range · Oil filter is polluted · Cable/connector is broken or cable/ connector is contacted to battery voltage or vehicle ground · Differential pressure switch is defective	No reaction OP mode : Normal	 Check oil filter Check wiring from TCU to differential pressure switch Check differential pressure switch(Measure resistance)

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
BB	Slippage at converter lockup clutch TCU calculates a differential speed at closed converter lockup clutch. If this calculated value is out of range, TCU interprets this as slipping clutch · Low pressure at converter lockup clutch · Low main pressure · Wrong signal at engine speed sensor · Wrong signal at turbine speed sensor · Wrong size of the sensor gap · Clutch is defective	No reaction OP mode : Normal	 Check pressure at converter lockup clutch Check main pressure in the system Check sensor gap at engine speed sensor Check sensor gap at turbine speed sensor Check signal at engine speed sensor Check signal at turbine speed sensor Check signal at turbine speed sensor Replace clutch
CO	Engine torque or engine power overload TCU calculates an engine torque or engine power above the defined thresholds	OP mode : Normal	
C1	Transmission output torque overload TCU calculates an transmission output torque above the defined threshold	OP mode : Normal	
C2	Transmission input torque overload TCU calculates an transmission input torque above the defined threshold	programmable : No reaction or shift to neutral OP mode : Normal	
C3	Overtemp converter output TCU measured a oil temperature at the converter output that is the allowed threshold	No reaction OP mode : Normal	 Cool down machine Check oil level Check temperature sensor
C4	 S.C. to ground at joystick status indicator TCU detected a wrong voltage at the output pin, that looks like a S.C. to vehicle ground Cable is defective and is contacted to vehicle ground Joystick status indicator has an internal defect Connector pin is contacted to vehicle ground 	No reaction OP mode : Normal	 Check the cable from TCU to joystick status indicator Check the connectors from joystick status indicator to TCU Check the resistance* of joystick status indicator * See page 3-77
C5	 S.C. to battery voltage at joystick status indicator TCU detected a wrong voltage at the output pin, that looks like a S.C. to battery voltage Cable is defective and is contacted to battery voltage Joystick status indicator has an internal defect Connector pin is contacted to battery voltage 	No reaction OP mode : Normal	 Check the cable from TCU to joystick status indicator Check the connectors from joystick status indicator to TCU Check the resistance* of joystick status indicator * See page 3-77

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
C6	 O.C. at joystick status indicator TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin Cable is defective and has no connection to TCU Joystick status indicator has an internal defect Connector pin has no connection to TCU 	No reaction OP mode : Normal	 Check the cable from TCU to joystick status indicator Check the connectors from joystick status indicator to TCU Check the resistance* of joystick status indicator * See page 3-82
D1	S.C. to battery voltage at power supply for sensors TCU measures more than 6V at the pin AU1 (5V sensor supply)	See fault codes No.21 to 2C	 Check cables and connectors to sensors, which are supplied from AU1 Check the power supply at the pin AU1(Should be appx. 5V) Fault codes No.21 to No.2C may be reaction of this fault
D2	S.C. to ground at power supply for sensors TCU measures less than 4V at the pin AU1 (5V sensor supply)	See fault codes No.21 to 2C	 Check cables and connectors to sensors, which are supplied from AU1 Check the power supply at the pin AU1(Should be appx. 5V) Fault codes No.21 to No.2C may be reaction of this fault
D3	Low voltage at battery Measured voltage at power supply is lower than 18V(24V device)	Shift to neutral OP mode : TCU shutdown	 Check power supply battery Check cables from batteries to TCU Check connectors from batteries to TCU
D4	High voltage at battery Measured voltage at power supply is higher than 32.5V(24V device)	Shift to neutral OP mode : TCU shutdown	 Check power supply battery Check cables from batteries to TCU Check connectors from batteries to TCU
D5	 Error at valve power supply VPS1 TCU switched on VPS1 and measured VPS1 is off or TCU switched off VPS1 and measured VPS1 is still on Cable or connectors are defect and are contacted to battery voltage Cable or connectors are defect and are contacted to vehicle ground Permanent power supply KL30 missing TCU has an internal defect 	Shift to neutral OP mode : TCU shutdown	 Check fuse Check cables from gearbox to TCU Check connectors from gearbox to TCU Replace TCU
D6	Error at valve power supply VPS2 TCU switched on VPS2 and measured VPS2 is off or TCU switched off VPS2 and measured VPS2 is still on • Cable or connectors are defect and are contacted to battery voltage • Cable or connectors are defect and are contacted to vehicle ground • Permanent power supply KL30 missing • TCU has an internal defect	Shift to neutral OP mode : TCU shutdown	 Check fuse Check cables from gearbox to TCU Check connectors from gearbox to TCU Replace TCU

 $\ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

Fault code (Hex)	Meaning of the fault code possible reason for fault detection	Reaction of the TCU	Possible steps to repair
E3	 S.C. to battery voltage at display output TCU sends data to the display and measures always a high voltage level on the connector Cable or connectors are defective and are contacted to battery voltage Display has an internal defect 	No reaction OP mode : Normal	 Check the cable from TCU to the display Check the connectors at the display Change display
E4	 S.C. to ground at display output TCU sends data to the display and measures always a high voltage level on the connector Cable or connectors are defective and are contacted to battery voltage Display has an internal defect 	No reaction OP mode : Normal	 Check the cable from TCU to the display Check the connectors at the display Change display
E5	Communication failure on DeviceNet	Shift to neutral OP mode : TCU shutdown	 Check Omron master Check wire of DeviceNet-Bus Check cable to Omron master
F1	General EEPROM fault TCU can't read non volatile memory · TCU is defective	No reaction OP mode : Normal	 Replace TCU Øften shown together with fault code F2
F2	Configuration lost TCU has lost the correct configuration and can't control the transmission · Interference during saving data on non volatile memory · TCU is brand new or from another vehicle	Transmission stay neutral OP mode : TCU shutdown	 Reprogram the correct configurat- ion for the vehicle (e.g. with cluster controller,)
F3	Application error Something of this application is wrong	Transmission stay neutral OP mode : TCU shutdown	 Replace TCU This fault occurs only if an test engineer did something wrong in the application of the vehicle
F5	Clutch failure AEB was not able to adjust clutch filling parameters · One of the AEB-Values is out of limit	Transmission stay neutral OP mode : TCU shutdown	 Check clutch TCU shows also the affected clutch on the display
F6	Clutch adjustment data lost TCU was not able to read correct clutch adjustment parameters · Interference during saving data on non volatile memory · TCU is brand new	No reaction, Default values : 0 for AEB Offsets used OP mode : Normal	 Execute AEB and brake sensor calibration
F7	Substitute clutch control · Transmission input torque wrong · Engine retarder torque wrong · Speed signal (s) defective	OP mode : Substitute clutch control	 Check engine retarder torque Check speed sensors

5) MEASURING OF RESISTANCE AT ACTUATOR/SENSOR AND CABLE

(1) Actuator



76043PT19

76043PT20

(2) Cable



Short cut to ground $R_{12} = 0$; $R_{1C} = R_{2C} = 0$, $R_{1P} = R_{2P} = \infty$ Short cut to battery $R_{12} = 0$; $R_{1C} = R_{2C} = 0$, $R_{1P} = R_{2P} = 0$

5. AXLE

1) OPERATION

- The power from the engine passes through torque converter, transmission and drive shafts, and is then sent to the front and rear axles.
- Inside the axles, the power passes from the bevel pinion to the bevel gear and is sent at right angles. At the same time, the speed is reduced and passes through the both differentials to the axle shafts. The power of the axle shafts is further reduced by planetary-gear-type final drives and is sent to the wheels.

(1) Front axle





(2) Rear axle



78093PT15

Brake

3

78093PT14

1 Input

2 Output

4 Axle housing

2) DIFFERENTIAL

(1) Description

When the machine makes a turn, the outside wheel must rotate faster than the inside wheel. A differential is a device which continuously transmits power to the right and left wheels while allowing them to turn a different speeds, during a turn.

The power from the drive shaft passes through bevel pinion (1) and is transmitted to the bevel gear (2). The bevel gear changes the direction of the motive force by 90 degree, and at the same time reduces the speed.

It then transmits the motive force through the differential (3) to the axle gear shaft (4).

(2) When driving straight forward

When the machine is being driven straight forward and the right and left wheels are rotating at the same speed, so the pinion gear inside the differential assembly do not rotate. The motive force of the carrier is send through the pinion gear and the side gear, therefore the power is equally transmitted to the left and right axle gear shaft.





(3) When turning

When turning, the rotating speed of the left and right wheels is different, so the pinion gear and side gear inside the differential assembly rotate in accordance with the difference between the rotating speed of the left and right wheels.

The power of the carrier is then transmitted to the axle gear shafts.



6. TIRE AND WHEEL



- 1) The tire acts to absorb the shock from the ground surface to the machine, and at the same time they must rotate in contact with the ground to gain the power which drives the machine.
- 2) Various types of tires are available to suit the purpose. Therefore it is very important to select the correct tires for the type of work and bucket capacity.

GROUP 2 OPERATIONAL CHECKS AND TROUBLESHOOTING

1. POWER TRAIN OPERATIONAL CHECKS

This procedure is designed so that the mechanic can make a quick check of the system using a minimum amount of diagnostic equipment. If you need additional information, read Structure and function, Group 1.

A location will be required which is level and has adequate space to complete the checks.

The engine and all other major components must be at operating temperature for some checks.

Locate system check in the left column and read completely, following the sequence from left to right. Read each check completely before performing.

At the end of each check, if no problem is found(OK), that check is complete or an additional check is needed. If problem is indicated(NOT OK), you will be given repair required and group location. If verification is needed, you will be given next best source of information :

Chapter 2 : Troubleshooting Group 3 : Tests and adjustments

* '	Transmission	oil must b	e at o	perating	temperature	for these checks.
-----	--------------	------------	--------	----------	-------------	-------------------

Item		Description	Service action
Transmission oil warm-up procedure		Start engine. Apply service brakes and release parking brake.	OK Check completed.
		Select T/M shift mode to MANUAL mode.	
		Move gear selector lever to 3rd speed.	
		Move gear selector lever to forward "F" position.	
		Increase engine speed to high idle for 30 seconds.	
		Move gear selector lever to neutral "N" position and run for 15 seconds.	
		Repeat procedure until transmission temperature gauge arrow points to bar above dial.	
Gear selector lever and neutral lock latch checks		Move gear selector lever to each position.	OK Check completed.
Engine OFF.		NOTE : Gear selector lever position changes slightly as steering column is tilted.	NOT OK Repair lock or replace
	<i>0</i> 2	FEEL : Lever must move freely through all positions.	
		Engage neutral lock.	
		Apply slight effort to move lever into forward (F) and reverse (R).	
		LOOK : Neutral lock must stay engaged.	
Automatic shifting check		Start engine.	OK
		Move gear selector lever to 4th speed.	NOT OK
	AL mode	Select T/M shift mode to AL (auto light) mode.	Go to transmission fault code group at page 3-57~
		LOOK : Automatic sign on cluster.	3-73. Repair or replace the
	Automatic mode	Move gear selector lever to forward or reverse position.	monitor or harness.
		Increase engine rpm.	
	DEF LEVEL : 0%	LOOK : Speed on cluster must vary with machine speed.	

Item		Description	Service action	
Transmission noise check Engine running.		Run engine at approximately 1600 rpm.	OK Check completed.	
		forward and reverse speed.	Go to transmission makes excessive noise, chapter 2	
		LISTEN : Transmission must not make excessive noise in any range.	in this group.	
		Engine rpm must not "lug down" as unit is shifted between gears.		
Transmission "quick shift" check	Release	Release parking brake and select T/M shift mode to MANUAL mode.	OK Check completed.	
Engine running.		Shift to 2nd forward.	NOT OK	
	MANUAL mode	Drive machine at approximately 5km/h and press gear selector lever kick down switch or RCV levers switch once.	of control valve.	
		 Description Run engine at approximately 160 rpm. Drive unit with transmission in each forward and reverse speed. LISTEN : Transmission must n make excessive noise in any rang Engine rpm must not "lug down" a unit is shifted between gears. Release parking brake and sele T/M shift mode to MANUAL mode Shift to 2nd forward. Drive machine at approximate 5km/h and press gear selector lever kick down switch or RCV lever switch once. LOOK/FEEL : Transmission must num shift to and remain in 1st gear. Press gear selector lever kick down switch once. LOOK/FEEL : Transmission must num shift back to 2nd gear. Shift to (3rd or 4th) gear and prest gear selector lever kick down switch once. LOOK/FEEL : Transmission must not shift down. Select T/M shift mode to AL (aur light) mode. Drive machine at approximate 90% speed of max speed in each gear (2nd or 3rd or 4th). Shift to (2nd or 3rd or 4th) gear each forward and reverse speed and press gear selector kick down switch once. LOOK/FEEL : If shift down quickly from curre gear to one step lower speed at recover to original speed quick when push the switch one motime. (mode 1) 	controller circuit in group 1.	
		shift to and remain in 1st gear. Press gear selector lever kick down switch once.		
		LOOK/FEEL : Transmission must shift back to 2nd gear.		
		switch once. LOOK/FEEL : Transmission must shift back to 2nd gear. Shift to (3rd or 4th) gear and press gear selector lever kick down switch once. LOOK/FEEL : Transmission must not shift down.		
		LOOK/FEEL : Transmission must not shift down.		
		Select T/M shift mode to AL (auto light) mode.		
	0= 0=	Drive machine at approximately 90% speed of max speed in each gear (2nd or 3rd or 4th).		
		Shift to (2nd or 3rd or 4th) gear in each forward and reverse speed and press gear selector kick down lever switch or RCV lever switch once.		
		LOOK/FEEL : If shift down quickly from current gear to one step lower speed and recover to original speed quickly when push the switch one more time. (mode 1)		
		If shifts down from current gear to one step lower speed when push the switch everytime and recover when push the switch in 1st gear. (mode 2)		

ltem	Description		Service action
Forward, reverse and 4th speed clutch pack drag check * Transmission must be warmed up for this check. Engine running.		Park unit on level surface. Apply service brakes. Move gear selector lever to neutral. Move gear selector lever to 1st. Release parking brake and service brakes. Run engine at low idle. LOOK : Unit must not move in either direction.	OK Check completed. NOT OK If unit moves, repair transmission.
		NOTE : If unit moves forward, either the forward pack or the 4th speed pack is dragging.	
Transmission shift modulation check Engine running.		Run engine at approximately 1300 rpm. Put transmission in 1st forward, shift several times from forward to reverse and reverse to forward. Repeat check in 2nd gear. LOOK : Unit must slow down and change direction smoothly.	OK Check completed. NOT OK Go to unit shifts too fast, chapter 2 in this group.
Torque converter check		Start engine. Apply service brakes and release parking brake. Move gear selector lever to 3rd speed. Move gear selector control lever to forward "F" position. Increase engine speed to high idle. LOOK : Torque converter stall rpm must be within the following range. Stall rpm : 2030±70 rpm (4-speed) 2020±70 rpm (5-speed) Move gear selector control lever to neutral "N" position and run for 15 seconds.	OK Check completed. NOT OK If stall rpm are too low or too high, problem may be engine power or torque converter. IF OK Replace transmission torque converter.

2. TROUBLESHOOTING

- 1) TRANSMISSION
- * Diagnose malfunction charts are arranged from most probable and simplest to verify, to least likely, more difficult to verify. Remember the following steps when troubleshooting a problem :

Step 1. Operational check out procedure (See group 3 in section 1.)

Step 2. Operational checks (In this group.)

Step 3. Troubleshooting

Step 4. Tests and/or adjustments (See group 3.)

Problem	Cause	Remedy
Transmission slippage Low oil level.		Add oil.
	Wrong oil grade.	Change oil.
	Restricted transmission pump suction screen.	Remove and clean screen.
	Leak in transmission control valve or gasket.	Remove valve and inspect gaskets.
	Low transmission pump flow due to worn pump.	Do transmission pump flow test.
	Weak or broken pressure regulat- ing valve spring.	Do transmission system pressure test.
Error code on display	Something wrong in transmission.	Go to transmission fault code group at page 3-57~3-73.

Problem	Cause	Remedy
Machine will not move	Low oil level.	Add oil.
	Applied park brake.	Check parking brake fuse. Check continuity to parking brake switch.
	No power to transmission contro- ller.	Check transmission controller fuse.
	Malfunctioning parking brake solenoid valve.	Remove and inspect parking brake solenoid valve. Check for power to solenoid valve.
	Restricted orifice of PPC valve.	Remove orifice and check for contamination and/or plugging. (Do not remove valve housing for this purpose.)
	Excessive leakage in transmission element.	Do transmission element leakage test using system pressure.
	Worn clutch disks.	Repair transmission.
	Low or no transmission pressure.	See transmission pressure is low in this group.
	Service brake will not release.	Do brake pedal operational check. Do service and park system drag checks.
	Failed torque converter.	Do torque converter stall test. If engine pulldown in normal, torque converter is good.
	Broken shafts or gears.	Drain transmission to determine if large pieces of metal contamination are present.
	Broken drive shafts.	Inspect drive shafts and universal joints for external damage. Repair.
	Broken ring or pinion gear.	If drive shaft rotate with transmission in gear but machine does not move, a differential failure is indicated. Repair.
Machine does not engage in low gear	Malfunctioning transmission control solenoid valve.	Check solenoid valve.
	Stuck spool in transmission control valve.	Remove and inspect transmission control valve spools.
	Stuck PPC valve.	Remove end cover to inspect PPC valve. Replace if necessary.
	Malfunctioning transmission speed sensor.	Check speed sensor.

Problem	Cause	Remedy
Transmission pressure is low (all gears)	Low oil level.	Check transmission oil level and refill if necessary.
	Failed transmission pressure switch.	Verify transmission system pressure. Do transmission system pressure test.
	Plugged suction strainer.	Transmission pump may be noisy if transmission suction screen is clogged. Drain transmission. Remove and clean suction screen. Also, check condition of transmission filter.
	Stuck transmission pressure regulating valve or broken spring.	Remove transmission pressure regulating valve. Inspect for damage (See transmission control valve).
	Failed control valve gasket.	Inspect transmission control valve for external leakage. Remove control valve. Inspect or replace gasket.
	Stuck PPC valve.	Remove end cover to inspect modulation spool and check torque on cap screws retaining control valve to transmission.
Transmission system	Failed transmission pump.	Do pump flow test.
pressure is low (one or two gears)	Failed transmission control valve gasket.	Inspect transmission control valve for external leakage. Remove control valve. Inspect or replace gasket.
	Leakage in clutch piston or seal ring.	Disassemble and repair.
Transmission shifts too	Low oil level (aeration of oil).	Add oil.
low	Low transmission pressure.	Do transmission system pressure test.
	Restricted transmission pump suction screen.	Remove and clean screen.
	Low transmission pump flow.	Do transmission pump flow test.
	Excessive transmission element leakage.	Do transmission element leakage test using system pressure.
	Stuck PPC valve.	Remove end cover to inspect modulation spool. Replace if necessary.
	Restricted PPC valve orifice.	Remove orifice and inspect for contamination and /or plugging.
	Restricted oil passages between control valve and transmission elements.	Remove control valve and inspect oil passage.
	Incorrect transmission oil.	Change oil (SAE 10W-30/15W-40)

Problem	Cause	Remedy
Transmission shifts too fast	Wrong transmission controller.	Check if transmission controller has been changed
	System pressure too high.	Do transmission system pressure test.
	Stuck PPC valve.	Remove and inspect PPC valve. Replace if necessary. Also remove end cover to inspect PPC valve and control valve housing. Replace if necessary.
	Stuck or missing check valves.	Inspect transmission control valve.
	Missing O-ring from end of modulation orifice.	Remove orifice and inspect port for O-ring.
	Broken piston return spring.	Disassemble and inspect clutch.
	Incorrect transmission oil.	Change oil (SAE 10W-30/15W-40).
Machine "creeps" in neutral	Warped disks and plates in transmission.	Check transmission.
Transmission hydraulic system overheats	High oil level.	Transmission overfilled or hydraulic pump seal leaking.
	Low oil level.	Add oil.
	Wrong oil grade.	Change oil.
	Park brake dragging.	Check for heat in park brake area.
	Pinched, restricted or leaking lube lines.	Check cooler lines.
	Machine operated in too high gear range.	Operate machine in correct gear range.
	Malfunction in temperature gauge or sensor.	Install temperature sensor the verify temperature. Do tachometer/temperature reader installation procedure.
	Restricted air flow through oil cooler or radiator.	Do radiator air flow test.
	Failed oil cooler bypass valve (In thermal bypass valve).	Disassemble and inspect.
	Failed thermal bypass valve.	Remove thermal bypass valve and check to see if machine still overheats. Do transmission oil cooler thermal bypass valve test.
	Internally restricted oil cooler.	Do oil cooler restriction test.
	Leakage in transmission hydraulic system.	Do transmission system pressure, element leakage test.
	Malfunction in converter relief valve.	Do converter out pressure test.
	Low transmission pump output.	Do transmission pump flow test.

Problem	Cause	Remedy
Excessive transmission	Too low engine low idle.	Check engine low idle speed.
noise (Under load or no load)	Worn parts or damaged in transmission.	Remove transmission suction screen. Inspect for metal particles. Repair as necessary.
	Warped drive line between engine and torque converter.	Inspect drive line.
	Low or no lube.	Do converter-out and lube pressure test. Do transmission pump flow test.
Foaming oil	Incorrect type of oil.	Change oil.
	High oil level.	Transmission overfilled or hydraulic pump seal leaking.
	Low oil level.	Add oil.
	Air leak on suction side of pump.	Check oil pickup tube on side of transmission.
Oil ejected from dipstick	Plugged breather.	Inspect breather on top of transmission. Replace.
Machine vibrates	Aerated oil.	Add oil.
	Low engine speed.	Check engine speed.
	Failed universal joints on transmission drive shaft or differential drive shafts.	Check universal joints.
Machine lacks power and acceleration	Engine high idle speed set too low.	Check high idle adjustment.
	Incorrect transmission oil.	Change oil.
	Aerated oil.	Add oil.
	Low transmission pressure.	Do transmission system pressure test.
	Warped transmission clutch.	Do transmission clutch drag checks.
	Torn transmission control valve gasket.	Inspect gasket.
	Brake drag.	Do brake drag check.
	Failed torque converter.	Do torque converter stall speed test.
	Low engine power.	Do engine power test.
Torque converter stall RPM too high	Aerated oil.	Put clear hose on thermal bypass outlet port. Run machine to check for bubbles in oil.
	Stuck open converter relief valve.	Do converter-out pressure test.
	Leakage in torque converter seal.	Do converter-out pressure test.
	Torque converter not transferring power (Bent fins, broken starter).	Replace torque converter.

Problem	Cause	Remedy
Torque converter stall	Low engine power.	Do engine power test.
RPM too low	Mechanical malfunction.	Remove and inspect torque converter.
Transmission pressure	Low oil level.	Add oil.
light comes ON when shifting from forward to	Cold oil.	Warm oil to specification.
reverse (all other gears OK)	Leak in reverse pack.	Do transmission pressure, pump flow, and leakage check.
Transmission pressure light comes ON for each shift	Cold oil.	Warm oil to specification.
	No time delay in monitor.	Do monitor check.
	Restriction in modulation orifice.	Remove orifice and inspect for restriction and/or plugging.
	Stuck PPC valve.	Remove and inspect.
	Low transmission pressure circuit.	Do transmission system pressure test.
	Leak in transmission pressure circuit.	Do converter out pressure test.
	Failed transmission pump.	Do transmission pump flow test.
	Clogged filter.	Inspect filter. Replace.

2) DIFFERENTIAL / AXLE

Problem	Cause	Remedy
Differential low on oil	External leakage.	Inspect axle and differential for leaks.
Excessive differential and/or axle noise	Low oil level in differential.	Check oil. Remove drain plug and inspect for metal particles in differential case. Disassemble and determine cause.
	Incorrect type of oil.	Change oil
	Dragging brakes.	Do brake check.
	Failed pinion bearing.	Remove and inspect pinion. Check to ensure pinion housing was indexed.
	Incorrect gear mesh pattern between ring and pinion gear.	Remove pinion gear housing and inspect ring and pinion gear.
	Failed differential pinion gears and/or cross shafts.	Remove differential housing drain plug and inspect for metal particles. Disassemble and inspect.
	Failed axle bearing.	Do axle bearing adjustment check.
	Mechanical failure in axle planetary.	Remove differential. Inspect, repair.
Oil seeping from outer	Excessive end play in axle.	Do axle bearing adjustment check.
axle seal	Worn outer bearing and/or cup.	Disassemble and inspect outer axle bearing, cup, spacer, and seal. Replace, if necessary.
	Overfilled differential.	Check differential oil return system for excessive internal restriction.
Axle overheats	Low differential oil.	Add oil.
	Overfilled differential.	See differential overfills with oil in this group.
	Brake drag.	See brakes drag in this group.

3) DRIVE LINE

Problem	Cause	Remedy	
Excessive drive line	Yokes not in line on drive shafts.	Inspect. Align drive shaft yokes.	
vibration or noise	Worn front drive line support bearing.	Inspect, repair.	
	Bent drive shaft.	Inspect all drive shafts. Replace.	
	Loose yoke retaining nuts (drive shafts wobble at high speed).	Inspect. Replace.	
	Rear axle oscillating support.	Inspect, repair.	
	Lack of lubrication.	Lubricate with proper grade of grease.	

GROUP 3 TESTS AND ADJUSTMENTS

1. TRANSMISSION MEASURING POINTS AND CONNECTIONS

The measurements have to be carried out at hot transmission (about 80~95°C).



1) OIL PRESSURE AND TEMPERATURE

Port	Description			Size
51	In front of the converter-opening pressure (11bar)		Н	M10×1.0
52	Behind the converter-opening pressure (5bar)			M14×1.5
53	Forward clutch (16+2bar)	KV	В	M10×1.0
55	Reverse clutch (16+2bar)	KR	F	M10×1.0
56	1st clutch (16+2bar)	K1	D	M10×1.0
57	2nd clutch (16+2bar)	K2	А	M10×1.0
58	3rd clutch (16+2bar)	K3	С	M10×1.0
60	4th clutch (16+2bar)	K4	Е	M10×1.0
63	Behind the converter temperature 100°C, short-time 120°C			M14×1.5
65	System pressure (16+2bar)		K	M10×1.0
*67	Lock-up clutch pressure (12+2bar)			M10×1.0

7809A3PT17

*: 5-speed transmission

2) DELIVERY RATES

Port	Description	Size
10	Breather	M10×1.0
15	Connection to the oil cooler	-
16	Connection from the oil cooler	-
27	Connection to the filter	M42×2.0
28	Connection from the filter	M42×2.0
29	Connection from the filter bypass	M42×2.0
33	Connection oil filler plug	M42×2.0
49	Plug connection on the electro-hydraulic control unit	-

3) INDUCTIVE TRANSMITTER AND SPEED SENSOR

Port		Description	Size
21	Inductive transmitter	n Turbine	M18×1.5
34	Speed sensor	n Output and speedometer	-
47	Inductive transmitter	n Central gear train	M18×1.5
48	Inductive transmitter	n Engine	M18×1.5

4) SOLENOID VALVE (5-speed transmission)

Item	Description	Size
70	Converter lock-up clutch	AMP 282080-1

GROUP 4 DISASSEMBLY AND ASSEMBLY

1. CONTROL VALVE

1) DISASSEMBLY

(1) Attach transmission to assembly truck.

Assembly truck	5870 350 000
Holding fixture	5870 350 071

- * Drain oil prior to starting disassembly.
- Disposal of oil according to legal requirements.



Removal of electric gear-shift control

(2) Remove all oil pipes.Remove gear-shift control (1).Loosen torx screws (2).

Socket wrench TX-27	5873 042 002
Adjusting screws M6	5870 204 063



(3) Remove gear-shift control assy (1) and gasket (2).



7709ACV03

(4) Loosen torx screws and separate duct plate (1) and gasket (2) from gearbox housing.



7709ACV04

(5) Mark installation position of wiring harness (1) towards valve block (2).



(6) Loosen torx screws (1).Socket wrench TX-27 5873 042 002



(7) Separate duct plate (1) and sealing plate (2) from valve block (3).



(8) Remove retaining clamp (1).



7709ACV08

(9) Loosen torx screws (2) and remove cover (2). Remove opposite cover (3) in the same way.

Socket wrench TX-27 5873 042 002



7709ACV09

(10) Remove wiring harness (1). Loosen cylindrical screws (3), remove fixing plates and remove pressure controllers (2).



7709ACV10

(11) Lock-up clutch solenoid valve (5-speed transmission)

Mark installation position of connecting housing (4) towards valve block (5).

Loosen cylindrical screws (1) and remove lock-up clutch valve.

Loosen screws neck (2) and remove O-rings.

Loosen torx screws (3) and remove connecting housing.


(12) Loosen cylindrical screws, remove fixing plates and remove pressure controllers (1) on opposite side.



7709ACV12

(13) Loosen torx screws (1) and preliminarily fix housing by means adjusting screws(S). (Housing is spring-loaded.) Then loosen remaining torx screws.

Adjusting screws 5870 204 036



(14) Separate housing from valve housing by loosening the adjusting screws equally.

Adjusting screws 5870 204 036



(15) Remove individual parts :

- 1 Pressure reducing valve
- 2 Vibration dampers
- 3 Follow-on silde



- (16) Remove individual parts of opposite side analogously :
 - 1 Main pressure valve
 - 2 Vibration dampers
 - 3 Follow-on silde



7709ACV16

2) REASSEMBLY

Electro-hydraulic control with proportional valves :

* The following sketches show the sectional views of the electro-hydraulic control.



(1) Fitting of electric control

- All single parts are to be checked for damage and replaced, if required.
 Ensure free travel of the moving parts in the valve block prior to installation. Pistons can be exchanged individually.
 Prior to the installation, oil single part.
- ① With the concave side showing upwards, insert orifice (1) until contact is obtained.
- * See arrows for installation position.
- ② The opposite figure shows the following single parts :
 - 1 Pressure reducing valve (1EA, piston and compression spring)
 - 2 Vibration damper (3EA, piston and compression spring)
 - 3 Follow-on slide (3EA, piston and compression spring)
- ③ Install the single parts according to figure CV21.
- Preload compression springs of the follow-on slides and preliminarily fix pistons by means of cylindrical pins Ø 5.0 mm (assembly aid), see arrows (S).



7709ACV20





④ Fit two adjusting screws.

Mount seal (1) and housing (2). Then position housing equally by means of adjusting screws until contact is obtained.

Adjusting screws (S) 5870 204 036



⑤ Bring housing (1) into contact position by means of the torx screws. This will preload the pistons, and you can remove the cylindrical pins (assembly aid).



7709ACV24

⑥ Fix housing by means of the torx screws (1).

•	Tightening torque (M5/10.9 $ imes$ 30) :	
	0.56 kgf \cdot m (4.06 lbf \cdot	ft)

Reducing adapter	5870 656 056
Socket wrench TX-27	5873 042 002



- ⑦ Monut pressure controllers with O-ring 13.5×2 (1) and fasten them by means of fixing plates (2) and torx screws (3).
- Install the fixing plate, with the claw showing downwards.

Pay attention to the radial installation position of pressure controllers, see figure.

 \cdot Tightening torque (M5/8.8imes12) :

0.56 kgf \cdot m (4.06 lbf \cdot ft)

Reducing adapter	5870 656 056
Socket wrench TX-27	5873 042 002

Preassemble the opposite side

- (8) The figure on the right shows the following single parts :
 - 1 Main pressure valve (1EA, piston and compression spring)
 - 2 Vibration damper (3EA, piston and compression spring)
 - 3 Follow-on slide (3EA, piston and compression spring)





- Install the single parts according to figure CV27.
- Preload the compression springs of the follow-on slides and fasten the pistons preliminarily by means of cylindrical pins (S) Ø 5.0 mm (assembly aid), see arrows (S).

Install two adjusting screws.

Adjusting screws M5 5870 204 036

Assemble flat gasket (1) and housing cover. Then place the housing cover by means of adjusting screws equally until contact.

 Preload the position with torx screws and remove the cylindrical pins (assembly aid) again.

Then fasten the housing cover by means of torx screws (1).

 \cdot Tightening torque (M5/10.9 \times 30) : 0.56 kgf \cdot m (4.06 lbf \cdot ft)

Adjusting screws	5870 204 036
Reducer	5870 656 056
Socket spanner TX-27	5873 042 002

- II) Monut the pressure regulators with O-ring 13.5×2 (1) and fasten them by means of fixing plates and cap screws.
- Install the fixing plate with the neck showing downwards.

Observe radial installation position of the pressure regulators, see figure.

 \cdot Tightening torque (M5/8.8 \times 12) : 0.56 kgf \cdot m (4.06 lbf \cdot ft)

- Assemble the wiring harness (1) and connect the pressure regulators (6EA).
- See figure CV01 for installation position of pressure regulators.
- Pay attention to the installation position of the wiring harness, also see markings (figure CV05).









13 Put on the flat gasket (1).

Assemble the plug socket with the slot showing to the lug of the cover until contact.

Fasten the cover by means of cap screws.

 \cdot Tightening torque (M5/10.9imes30) :

0.56 kgf · m (4.06 lbf · ft)

Reducer	5870 656 056
Socket spanner TX-27	5873 042 002

If it is the wiring harness by means of retaining clamp (1).



7709ACV32



7709ACV33

- (5) Lock-up clutch solenoid valve (5-speed transmission)
- a. Place gasket (1).
 Fix connecting housing (2) by means of torx screws (3).
 - \cdot Tightening torque (M5/10.9 \times 30) : 0.56 kgf \cdot m (4.06 lbf \cdot ft)

Torque wrench	5870 203 031
Socket wrench TX-27	5873 042 002
Reducing adapter	5870 656 056

* Pay attention to installation position of connection housing, see the markings applied during disassembly.



b. Fix pressure controller (1) by means of cylindrical screws (2).

 \cdot Tightening torque (M6/8.8 \times 12) : 1.02 kgf \cdot m (7.38 lbf \cdot ft)

Fit screw necks with O-ring 11.3×2.4 (3).

 \cdot Tightening torque : 2.55 kgf \cdot m (18.4 lbf \cdot ft)

Fit screw plug with O-ring 8×1.5 (4).

- \cdot Tightening torque (M10 \times 1) : 1.02 kgf \cdot m (7.38 lbf \cdot ft)
- (6) Install two adjusting screws (S).

Adjusting screws 5870 204 063





7709ACV36

- ⑦ Flush-mount screens (1) into the holes of the sealing plate, see arrows.
- Pay attention to the installation position
 screens to show upwards (towards the duct plate).



- 18 Put on sealing plate (1) and duct plate (2).
 - * Screens (3) to show upwards.
 - It is not permitted to reassemble the seal plate after opening the threaded joint shift unit/duct plate.

In case of repair it is always necessary to mount a new seal plate.



(1) Place duct plate (1) and fix it equally by means of torx screws (2).

· Tightening torque (M6/10.9 \times 23) : 1.07 kgf \cdot m (7.74 lbf \cdot ft) Socket wrench TX-27 5873 042 002



7709ACV39

- ② Provide the screw plugs M10×1 with O-rings 8×1.5 (1) and install them.
 - · Tightening torque :

0.61 kgf · m (4.43 lbf · ft)



7709ACV40

2 Fit two adjusting screws.

Adjusting screws

5870 204 011

Place gasket (1) and duct plate (2) at the gearbox housing part until contact is obtained.



② Fix duct plate (1) by means of torx screws (2).

· Tightening torque (M8/10.9 \times 35) : 2.35 kgf \cdot m (17.0 lbf \cdot ft)

Mount screw plug with O-ring 8×1.5 (3).

· Tightening torque (M10 \times 1) :

0.61 kgf · m (4.43 lbf · ft)

Socket wrench TX-40 5873 042 004



3 Fit two adjusting screws.

Adjusting screws

5870 204 063

Mount sealing plate (1) and electrohydraulic control unit (2).

It is not permitted to reassemble the seal plate after opening the threaded joint shift unit/gearbox housing.

In case of repair it is always necessary to mount a new seal plate.

- ② Fix electro-hydraulic control unit (1) equally by means of torx screws (2 and 3)
 - · Tightening torque (M6/10.9 \times 76) :
 - 0.97 kgf · m (7.01 lbf · ft)

 Tightening torque (M6/10.9×100) : 0.97 kgf · m (7.01 lbf · ft)

Socket wrench TX-27	5873 042 002
Reducing adapter	5870 656 056

Pipe - System pressure to lock-up clutch valve (5-speed transmission)

② Fix pipes (1) with hollow screws (3) and O-rings and screw nut (2).

Fit O-ring 13×2 on hollow screw (3), insert into eye of pipes, mount O-ring 18×2.5 .

 \cdot Tightening torque :

4.59 kgf · m (33.2 lbf · ft)

Fixing of screw nut (2).

- · Tightening torque :
 - 3.57 kgf · m (25.8 lbf · ft)



7709ACV43





7709ACV45

Pipes - System pressure from lock-up clutch valve to lock-up clutch (5-speed transmission)

²⁶ Fix pipe union (1).

• Tightening torque :

4.08 kgf · m (29.5 lbf · ft)

Fix connection socket (2).

· Tightening torque :

3.57 kgf · m (25.8 lbf · ft)

Fix pipes (3) with screw nut (4 and 5).

· Tightening torque :

3.57 kgf · m (25.8 lbf · ft)



7709ACV46



* Before putting the transmission into operation, fill it with oil according to operation manual.



2. TRANSMISSION

1) DISASSEMBLY

- (1) Fasten the complete transmission to the assembly truck.
- * Special tool
- Assembly truck Holding fixture

5870 350 000
5870 350 071

- Figure 1
- (2) Remove the plug (arrow) and drain the oil. Then remove the oil cylinder.



Figure 2

(3) Remove all oil pipes, the complete gear shift system and the duct plate.



Figure 3

Converter drive

(1) By means of the lifting tackle separate the torque converter from the transmission.

*	Special tool	
	Eybolts assortment	5870 204 002
	Lifting chain	5870 281 047



- (2) Loosen the bolt connection and by means of the forcing screws (3EA) separate the cover from the converter bell.
- Special toolForcing screws 5870 204 005



Figure

- (3) By means of the extractor pull the oil supply flange out of the converter bell.
- Special toolExtractor5870 000 089



Figure 6

- (4) Remove the converter safety valve (arrow 1), if required.
- Converter safety valve is fixed by means of slotted pin (arrow 2).



Figure 7

- (5) Loosen the bolt connection (M8 and M12) and by means of lifting tackle and pry bar set separate the coverter bell from the transmission housing.
- Special tool
 Eyebolts assortment
 Pry bar set
 Lifting chain

5870 204 002 5870 345 036 5870 281 047



(6) Remove the rectangular ring (arrow).



(7) Press the input shaft out of the spur gear bearing. Remove the released bearing inner ring and the spur gear.



Figure10

(8) Press off the bearing inner ring from the spur gear.



Figure11

(9) Remove the converter pressure back-up valve.



 $(10)\, Remove the inductive transmitter.$

9 = n - Engine



Figure 13

Input shaft-pump/power take-off (the 1st power take-off)

(1) Loosen the cap screw.





Figure 21



Figure 22

- (3) Press the input shaft out of the bearing.
- * Pay attention to released input shaft as well as shims.
- Special tool
 Extractor

5870 000 065



(4) Snap out the rectangular ring (arrow 1) and remove both shims (arrow 2).



Figure 24

Transmission pump

- Loosen the cap and hexagon screws (depending on the version) respectively and separate the pump flange from the housing.

Figure 25

- (2) Loosen the cap screws (4EA / M8).
 Position the extractor on the transmission pump and fasten it by means of screws (M8×65) to the transmission pump. Then pull out the pump from the housing bore.
- Extracting is supported by slightly tapping onto the transmission housing.
- Special toolExtractor5870 000 089

Remove the bearing outer ring (2nd/3rd and 4th power take-off)

- (3) Pull out the bearing outer ring from the bore.
- Special tool
 Internal extractor
 Counter-support
 5870 300 017
 5870 300 009



Figure 26



Remove the ball bearing and the driver

(1st power take-off, figure 28~29)

(4) Snap out the retaining ring.



Figure 28

(5) Press out the driver with ball bearing from the bearing bore.Then separate the ball bearing from the

Then separate the ball bearing from the driver.



Figure 29

- (6) Loosen the cap screws, take off the pump cover and remove the rotor set.
- ▲ If marks due to running-in are found on the pump housing or housing cover, the complete pump is to be replaced.

Then assemble the rotor set with the chamfer on the tooth tip showing downwards and install the housing cover again.

· Torque limit (M8/8.8) :

2.35 kgf · m (17.0 lbf · ft)

· Torque limit (M6/8.8) :

0.97 kgf \cdot m (7.01 lbf \cdot ft)



Figure 30

3rd/and 4th power take-off

thread M8 to be cut.

cap from the housing bore.

(7) Remove the screw-in sleeve (arrow).



Figure 31



Figure 32

(9) By means of the striker expel the pin from the housing bore (figure 33) and remove the complete spur gear (figure 34).

(8) Sealing cap is to be drilled centrically and

By means of the striker expel the sealing

* Pay attention to released shim (2).Striker 5870 650 001





(10) Loosen the hexagon screws and remove the cover.



Figure 35

(11) Remove the pump flange on the rear side and snap out the retaining ring.

Clamping pliers 5870 900 021



Figure 36

(12) Expel the driver from the bearing bore and remove the released single components.

Plastic hammer

5870 280 004



Layshaft

(1) Remove the sealing cover and loosen the hexagon screw.



Figure 38

(2) Expel the idler shaft by means of the striker from the housing bore and layshaft bearing respectively.

Striker

5870 650 014



Figure 39

Removal of inductive and speed transmitter (figure 40~41)

14 = n - Turbine

- 5 = n Internal speed input
- 13 = n Output (speed transmitter)



Figure 40



Output

Converter side :

Remove the lock plate. Loosen hexagon screws and take off the output flange. Rotate the housing by 180° and remove the output flange on the housing rearside.



Figure 42

Transmission rearside

- ▲ For working on the brake system observe the instructions and specifications of the brake manufacturer.
- (1) Unscrew the screw cap.

(2) Loosen the counternut and unscrew the adjusting screw in counterclockwise direction until the brake disc is released.



Figure 43



Figure 44

(3) Loosen the cap screws and separate the complete brake from the transmission housing.

Remove the lock plate. Loosen the hexagon screws and separate the output flange/brake disc from the output shaft.

* (S) Socket spanner 5870 656 047



Removal of the clutches and layshaft

- (1) Loosen the hexagon screws and expel the bearing cover KV/K1 by means of the striker from the housing bore.
 Remove the bearing cover KR/K2 (arrow) analogously.
- Mark the installation location of the bearing cover.
- Special tool
 Threaded insert
 Striker
 5870 204 069
 5870 650 014
- (2) Pull out the bearing cover K4/K3 by means of the forcing screws from the housing bore.
- Special toolForcing screws 5870 204 005







Figure 47

- (3) Separate the bearing inner ring from bearing cover K4/K3.
- Special toolThree-armed puller5870 971 003



- (4) Loosen the bolt connection. Separate the housing cover from the housing by equally tightening both forcing screws (arrow 1 and 2) as well as the threaded spindle (arrow 3).
- Special tool

Internal hex spanner, size 8	5870 290 003
Forcing screws	5870 204 005
Lifting tackle	5870 281 061



(5) Expel the output shaft from the output gear.



Figure 50

(6) Loosen the hexagon screws and remove the oil baffle.

Lift the output gear out of the transmission housing (figure).

Special tool
 Stop washer
 Eyebolts assortment
 5870 100 054
 5870 204 002



Figure 51

- (7) Remove the bearing inner ring from the output gear.
- Special toolThree-armed puller5870 971 003



Figure 52

(8) Take the roller bearing out of the housing bore and remove the oil baffle (arrow).



Remove the multi-disc clutches

- ※ For removal of the single clutches observe the following sequence :
 K4/K3 → KR/K2 → KV/K1.
 For removal of clutch K4/K3, lift the clutch KR/K2 slightly and move it in direction of the arrow, see figure.
- Special toolEyebolts assortment5870 204 002
- (9) Opposite figure shows the clutches when removed.

(10) Remove the layshaft gear.



Figure 54



Figure 55



Figure 56

Dismantling of the Multi-Disc Clutch K3/K4

- (1) By means of clamping ring (S) fasten the clutch to the assembly truck.
- Special toolClamping ring5870 654 033



Figure 62

- (2) Pull off the roller bearing from the disc carrier.
- Special toolThree-armed puller5870 971 002



Figure 63

(3) Separate spur gear K3 from the disc carrier.



Figure 64

- (4) Pull off the bearing inner ring from the disc carrier.
- Special tool
 Rapid grip
 Basic tool

5873 012 012 5873 002 001



(5) Squeeze out the snap ring. Remove the end shim and disc set K3.



Figure 66

(6) Rotate disc carrier by 90°.Loosen the slotted nut.

*	Special tool	
	Slotted nut wrench	5870 401 118
	Slotted nut wrench	5870 401 115



Figure 67

(7) Rotate disc carrier by 90°.Pull off the taper roller bearing.

*	Special tool	
	Gripping insert	5873 011 012
	Basic tool	5873 001 000



Figure 68

- (8) Pull off the spur gear K4 from the disc carrier.
- Special toolThree-armed puller5870 971 003



(9) Remove the ring.



Figure 70

(10) Pull off the taper roller bearing.

*	Special tool	
	Three-armed puller	5870 971 002



Figure 71

(11) Squeeze out the snap ring.Remove the end shim and the disc set K4.



Figure 72

(12) Preload the compression spring by means of fixture.

Squeeze out the snap ring and the released single components. Remove the opposite single components

(K3 side) analogously.% Special tool

Pressure piece

5870 345 072



(13) Separate both pistons by means of compressed air from the disc carrier.



Figure 74

Dismantling of the multi-disc clutch KR/K2

- (1) Fasten the clutch by means of clamping ring (arrow) on the assembly truck.
- Special tool
 Clamping ring

5870 654 033



Figure 75

- (2) Rotate disc carrier by 90°. Loosen the slotted nut.
- Special toolSlotted nut wrench 5870 401 099



- (3) Pull off the taper roller bearing from the disc carrier.
- Special tool
 Gripping insert
 Basic tool
 5873 012 018
 5873 002 001



- (4) Press off the spur gear K2 from the disc carrier.
- $\ensuremath{\mathbf{A}}$ Pay attention to released disc carrier.



Figure 78

- (5) Fasten the disc carrier by means of clamping ring. Pull off the taper roller bearing from the disc carrier.
- Special tool Clarr

Clamping ring	5870 654 033
Gripping insert	5873 012 019
Basic tool	5873 002 001



Figure 79

(6) Squeeze out the snap ring. Remove the end shim and disc set K2.



Figure 80

- (7) Rotate disc carrier by 90°. Loosen the slotted nut.
- * Special tool Slotted nut wrench

5870 401 099



- (8) Pull off the taper roller bearing from the disc carrier.
- * Special tool Gripping insert Basic tool

5873 002 044 5873 002 001



Figure 82

- (9) Fasten spur gear KR by means of clamping ring (arrow) and pull it from the disc carrier.
- * Collar of the clamping ring must show upwards (to the spur gear).
- Special tool Three-armed puller 5870 971 003 Clamping ring 5870 654 045



Figure 83

(10) Remove the ring.



Figure 84

(11) Squeeze out the snap ring. Remove end shim and disc set KR.



- (12) Pull off the taper roller bearing from the disc carrier.
- Special tool
 Gripping insert
 Basic tool
 5873 012 013
 5873 002 001

Remove both piston (like described in figure 73 and 74)



Figure 86

Dismantling of the multi-disc clutch KV/K1

- (1) Fasten clutch by means of clamping ring to the assembly truck.Loosen the slotted nut (figure 87).
- Special tool

Clamping ring	5870 654 033
Slotted nut wrench	5870 401 118
Slotted nut wrench	5870 401 099

Figure 87

- (2) Pull off the taper roller bearing from the disc carrier.
- Special tool
 Gripping insert
 Basic tool
 5873 001 023
 5873 001 000



Figure 88





(4) Pull off spur gear K1 from the disc carrier.

*	Special tool		
	Three-armed pull	ler	5870 971 003



Figure 90

- (5) Opposite figure shows the spur gear bearing K1.Bearing (1) can only be obtained as complete part.
- ▲ If it is necessary to remove the clutchpack-sided ball bearing (arrow or Figure 93 and 94), the complete bearing (1) has to be removed.

Figure 91

(6) Take off the bush.



Figure 92

- (7) Pull off the ball bearing from the disc carrier (figure 93 and 94).
- * Pay attention to released balls.





Figure 94

(8) Squeeze out the snap ring. Remove end shim and disc set K1.



Figure 95

(9) Rotate disc carrier by 90°.Loosen the slotted nut.

*	Special tool	
	Slotted nut wrench	5870 401 118
	Slotted nut wrench	5870 401 115



Figure 96

- (10) Pull off the taper roller bearing from the disc carrier.
- Special tool
 Gripping insert
 Basic tool
 5873 001 034
 5873 001 000



(11) Pull off spur gear KV from the disc carrier.

*	Special tool	
	Three-armed puller	5870 971 003



Figure 98

(12) Remove the ring.



Figure 99

- (13) Pull off the taper roller bearing from the disc carrier (figure 100).Squeeze out the snap ring.Remove end shim and disc set KV.Remove both pistons (like described in Figure 73 and 74).
- Special tool
 Gripping insert
 Basic tool
 5873 001 034
 5873 001 000



2) ASSEMBLY

3rd/4th power take-off

- 1 = Ball bearing
- 2 = Spur gear
- 3 = Driver
- 4 = Ball bearing
- 5 = Pump flange
- 6 = Cover
- 7 = Intermediate gear
- 8 = Shim
- 9 = Pin
- 10 = Sealing cover
- 11 = Orifice



(1) Insert the ball bearing (1) into the housing bore until contact.



Figure 110

- (2) Position spur gear (2).
- * Pay attention to the installation position, see sketch (figure 109).



Figure 111

(3) Heat the ball bearing (inner ring) and bore of the gear respectively.

*	(S) Hot-air blower 230V	5870 221 500
	Hot-air blower 115V	5870 221 501



Figure 112

- (4) Align the spur gear centrally and insert the driver (3) until con-tact.
- ※ Pay attention to the installation position, also see sketch (figure 109).



Figure 113

- (5) Install the ball bearing (4) by means of fixture until contact.
- * Pay attention to perfect contact of the ball bearing.

Fixture 5870 000 083



Figure 114

Adjust the axial play of power take-off bearing = 0.2~0.3 mm (figure 115~116)

(6) Fasten ball bearing by means of shim s = 1.80 mm (empirical value) and retaining ring.

Clamping pliers 5870 900 021


- (7) Check the axial play by means of feeler gauge.
- * If different from the required axial play = 0.2~0.3 mm this is tobe corrected with the corresponding shim.

Feeler gauge 5870 200 112

(8) Place the O-ring (arrow) in the annular groove of the pumpflange (5) and grease it.



Figure 116



Figure 117

(9) Fasten the pump flange (5) by means of hexagon screws.

Tightening torque (M14/8.8) : 12.7 kgf · m (92.2 lbf · ft)



Figure 118

Converter side

(10) Place the O-ring (arrow) with assembly grease in the recess of the housing bore.



(11) Fasten the cover (6) with hexagon screws.

Tightening torque (M14/8.8) : 12.7 kgf \cdot m (92.2 lbf \cdot ft)

Provide the orifice (arrow) with a new sealing ring (CU) and install it.



Figure 120

- (12) Preassemble the intermediate gear (7) according to figure 121.
- Exact locating of the single components
 to be ensured bypressing

(13) Put in the bearing inner rings and position the intermediate gear (7), see arrow.



Figure 121



Figure 122

(14) Adjust the axial play-intermediate gear bearing max. 0.1 mm (figure 123~124)

Determine the gap size by means of feeler gauge (arrow).

Dim I e.g.	1.25 mm
------------	---------

Example

resulting shim e.g.	s	=	1.20) mm
Axial play (0~0.1 mm) e.g.			0.05	mm
Dim I (gap size)			1.25	mm

Feeler gauge 5870 200 112



Figure 123

- (15) Install the corresponding shim (8) e.g. s = 1.20 mm (arrow).
- * Install shim on the converter side



Figure 124

(16) Align the single components centrically.Undercool the pin (9) and install it until contact.



Figure 125

- (17) Flush-mount the sealing cover (10) with the concave side showing upwards (arrow 1).
- Wet contact face of the sealing cover with loctite (type No.262).
- * Provide orifice (11) with a new O-ring and install it (arrow 2).



Assembly of the multi-disc clutch K4/K3

The following sketch shows the clutch sectioning



Figure 127

- 1 Disc carrier(assy)
- 2 Spur gear K4
- 3 Spur gear K3
- K4 Multi-disc clutch K4
- K3 Multi-disc clutch K3
- 4 Piston

- 5 Compression spring
- 6 Plug 2EA
- 7 Plug 1EA

* Observe the installation position of the single components for the following assembly.

- (1) Lift the disc carrier with the K4-side showing downwards into the clamping ring and fasten it.
 Rotate disc carrier by 180°.
- Special toolClamping ring5870 654 033
- A To install new disc carriers the finished bores have to be sealed with plugs. Installation position, see arrow, figure128 and 129.
- Special tool
 Hand inserting tool
 5870 320 014
 Ratchet spanner
 5870 320 018





Figure 129

- (2) Flush-mount the drain valve (arrow) with the chamfer showing downwards.
- Special tool
 Inserting tool

5870 320 019



Figure 130

(3) Put both O-rings **scroll-free** into the annular grooves of the piston, see arrows.



- (4) Oil the O-rings and the piston contact surface.Install K3 piston equally until contact.
- * Observe the installation position of the piston, see figure.
- (5) Install spacer and compression spring.

- (6) Place guide ring, with the chamfer (arrow)
- 6) Place guide ring, with the chamfer (arrow) showing upwards, over the compression spring and install the snap ring.



Figure 133



Figure 134

 (7) Lift the disc carrier out of the clamping ring. Preload the compression spring by means of fixture and engage the snap ring into the annular groove of the disc carrier (arrow), see figure 135.

*	Special tool	
	Fixture	5870 345 072
	Clamping fixture	5870 654 036

Install the drain valve, piston and compression spring on the opposite side (clutch K4) analogously (figure 130~135).

Then lift the disc carrier with the K4-side showing downwards into the clamping ring and fasten it. Rotate disc carrier by 180°.



Figure 135

Disc Components K4

* Below sketch or table shows the standard version as to the installation position of the single components. Obligatory is the respective spare parts list.



Position	Description	Quantity	s (mm)	Remarks
1	Disc carrier	1		
2	Piston	1		
3	Outer clutch disc	2	1.85	Coated on one side
4	Outer clutch disc	5	2.5	Coated on both sides
5	Inner clutch disc	3	3.5	
6	Inner clutch disc	1	4.0	
7	Inner clutch disc	2	2.5~4.0	Optional
8	Snap ring	1	2.10~3.10	Optional
9	End shim	1		
Number of friction surfaces : 12				
Disc clearance : 2.2 ~ 2.4 mm				

- * Install the outer clutch discs position 3 with uncoated side showing to the piston and end shim respectively. The respective clutch side can be seen on the length of the disc carrier, see sketch.
 - K4 Dimension X (short disc carrier side)
 - K3 Dimension Y (long disc carrier side)

Check disc clearance K4=2.2~2.4 mm (figure 137~139)

- * In order to ensure a perfect measuring result, the disc set is first of all to be installed without oil.
- (1) Install disc set according to sketch or table (figure 136).
- (2) Install the end shim and fasten it by means of the snap ring.



Figure137



Figure138

(3) Press on end shim with approximately 100N (10 kg) and set dial indicator to "Zero".

Then press end shim against snap ring (upwards) and read disc clearance on the dial indicator.

If the required disc clearance differs, it has to be corrected with the adequate inner clutch disc or/and snap ring, see table/ position 7 and position 8.

Upon setting of disc clearance, remove the disc set, oil the clutch discs and reinstall them.

* Special tool

Magnetic stand	5870 200 055
Dial indicator	5870 200 057



Preassemble and install spur gear K4 (figure 140~144) :

- (1) Opposite figure shows the single components of spur gear K4.
 - 1 Bearing inner ring
 - 2 Bearing outer ring
 - 3 Ring
 - 4 Spur gear

Locate both bearing outer rings (2) until contact.

(2) Heat the bearing inner ring and install it until contact.







Figure141



Figure142

(4) Assemble the spur gear until all inner clutch discs are located.



- (5) Heat the bearing inner ring (spur gear bearing) and locate it until contact.
- ▲ Use safety gloves.



- (6) Heat the bearing inner ring (clutch bearing) and install it until contact.
- ▲ Use safety gloves.



Clutch Components K3

* Below sketch or table shows the standard version as to the installation position of the single components. Obligatory is the respective spare parts list.



Position	Description	Quantity	s(mm)	Remarks
1	Disc carrier	1		
2	Piston	1		
3	Outer clutch disc	2	1.85	Coated on one side
4	Outer clutch disc	8	2.5	Coated on both sides
5	Inner clutch disc	7	3.0	
6	Inner clutch disc	2	2.5~4.0	Optional
7	Snap ring	1	2.10~3.10	Optional
8	End shim	1		
Number of friction surfaces : 18				
Disc clearance : 2.6 ~ 2.8 mm				

^{*} Install the outer clutch discs position 3 with uncoated side showing to the piston and end shim respectively. The respective clutch side can be seen on the length of the disc carrier, see sketch.

- K3 Dimension Y (long disc carrier side)
- K4 Dimension X (short disc carrier side)

Check disc clearance K3=2.6~2.8 mm (figure 147~149)

- In order to ensure a perfect measuring result, the disc set is first of all to be installed without oil.
- (1) Install disc set according to sketch or table (figure 146).
- (2) Install the end shim and fasten it by means of the snap ring.



Figure 147



Figure 148

(3) Press on end shim with approximately 100N (10 kg) and set dial indicator to "Zero".

Then press end shim against snap ring (upwards) and read disc clearance on the dial indicator.

If the required disc clearance differs, it has to be corrected with the adequate inner clutch disc or/and snap ring, see table/ position 6 and position 7.

Upon setting of disc clearance, remove the disc set, oil the clutch discs and reinstall them.

* Special tool

*	Magnetic stand	5870 200 055
	Dial indicator	5870 200 057



Figure 149

- (4) Heat the bearing inner ring and install it until contace.
- A Use safety gloves.



(5) Lift the disc carrier out of the clamping ring (S).

To ensure the exact locating of the single components, preload the bearing with 100KN (10 t) (figure 151)

▲ Support on the lower as well as upper bearing inner ring.

Use pressure pieces.

- Special toolPressure piece 5870 506 096
- (6) Lift the disc carrier with the K4-side showing downwards into the clamping ring (S) and fasten it.
 Rotate disc carrier by 90°.
 Install the slotted nut.
- * Observe installation position of the slotted nut. Collar (Ø 60 mm) must show to the bearing inner ring, also see sketch (Figure 127). Oil the thread.

· Tightening torque : 56.1 kgf · m (406 lbf · ft)

* Special tool

Clamping ring	5870 654 033
Slotted nut wrench	5870 401 118
Slotted nut wrench	5870 401 115



Figure 151



Figure 152

(7) Install the bearing outer ring into spur gear K3 until contact.



Figure 153

(8) Assemble the spur gear until all inner clutch discs are located.



Figure 154

- (9) Heat the roller bearing and locate it until contact.
- ▲ Use safety gloves.





Figure 155



- (11) Check function of the clutches K3 and K4 by means of compressed air.
- Closing or opening of the clutches is clearly audible when the single parts have been installed adequately.



(12) Snap-in and lock the rectangular rings (3EA, see arrows).



Assembly of the multi-disc clutch KR/K2

The following sketch shows the clutch sectioning.



* Observe the installation position of the single components for the following assembly.

- Lift the disc carrier with the KR-side showing downwards into the clamping ring and fasten it. Then rotate disc carrier by 180°.
- ▲ To install new disc carriers the finished bores have to be sealed with plugs. Installation position, see arrow, figure 160~161.
- * Special tool

Clamping ring	5870 654 033
Hand mounting tool	5870 320 014
Ratchet	5870 320 018





Figure 161

- (2) Flush-mount the drain valve (arrow) with the chamfer showing downwards.
- Special toolInserting tool5870 320 019



Figure 162

(3) Put both O-rings **scroll-free** into the annular grooves of the piston, see arrows.



- (4) Oil the O-rings and the piston contact surface.Install K2 piston equally until contact.
- * Observe the installation position of the piston, see figure.
- (5) Install spacer and compression spring.

(6) Place guide ring, with the chamfer (arrow) showing upwards, over the compression spring and install the snap ring.

(7) Lift the disc carrier out of the clamping ring. Preload the compression spring by means of fixture and engage the snap ring into the annular groove of the disc carrier (arrow), see figure 167.

Install the drain valve, piston and compression spring on the opposite side(clutch KR) analogously (like figure 162~167).

Then lift the disc carrier with the KR-side showing downwards into the clamping ring and fasten it. Rotate disc carrier by 180°.

Special tool

Pressure piece
Clamping fixture

5870 345 072 5870 654 036















Disc Components KR

* Below sketch or table shows the standard version as to the installation position of the single components. Obligatory is the respective spare parts list.



Position	Description	Quantity	s (mm)	Remarks
1	Disc carrier	1		
2	Piston	1		
3	Outer clutch disc	2	1.85	Coated on one side
4	Outer clutch disc	11	3.35	Coated on both sides
5	Inner clutch disc	5	2.5	
6	Inner clutch disc	5	3.0	
7	Inner clutch disc	2	2.5~4.0	Optional
8	Snap ring	1	2.10~3.10	Optional
9	End shim	1		
Number of friction surfaces : 24				
Disc clearance : 2.8 ~ 3.0 mm				

- * Install the outer clutch discs position 3 with uncoated side showing to the piston and end shim respectively. The respective clutch side can be seen on the length of the disc carrier, see sketch.
 - KR Dimension X (long disc carrier side)
 - K2 Dimension Y (short disc carrier side)

Check disc clearance KR=2.8~3.0 mm (figure 169~171)

- In order to ensure a perfect measuring result, the disc set is first of all to be installed without oil.
- (1) Install disc set according to sketch or table.
- (2) Install the end shim and fasten it by means of the snap ring.



Figure 169



Figure 170

(3) Press on end shim with approximately 100N (10 kg) and set dial indicator to "Zero".

Then press end shim against snap ring (upwards) and read disc clearance on the dial indicator.

If the required disc clearance differs, it has to be corrected with the adequate inner clutch disc or/and snap ring, see table/ position 7 and Position 8.

Upon setting of disc clearance, remove the disc set, oil the clutch discs and reinstall them.

* Special tool

Magnetic stand	5870 200 055
Dial indicator	5870 200 057



Figure 171

Preassemble and install spur gear KR (figure 172~176) :

- (1) Opposite figure shows the single components of spur gear KR.
 - 1 Bearing inner ring (75 \times 37 mm)
 - 2 Ring
 - 3 Spur gear
 - 4 Bearing inner ring (75×41 mm)
- (2) Heat the bearing inner ring (75 \times 37 mm) and install it until contact.
- ▲ Use safety gloves.





Figure 172



Figure 173



Figure 174





- (5) Heat the bearing inner ring (75 \times 41 mm) and locate it until contact.
- ▲ Use safety gloves.



- (6) Heat the bearing inner ring (clutch bearing) and locate it until contact.
- ▲ Use safety gloves.



Disc Components K2

* Below sketch or table shows the standard version as to the installation position of the single components. Obligatory is the respective spare parts list.



Figure 178

Position	Description	Quantity	s (mm)	Remarks
1	Disc carrier	1		
2	Piston	1		
3	Outer clutch disc	2	1.85	Coated on one side
4	Outer clutch disc	8	2.5	Coated on both sides
5	Inner clutch disc	7	3.0	
6	Inner clutch disc	2	2.5~4.0	Optional
7	Snap ring	1	2.10~3.10	Optional
8	End shim	1		
Number of friction surfaces : 18				
Disc clearance : 2.6 ~ 2.8 mm				

* Install the outer clutch discs position 3 with uncoated side showing to the piston and end shim respectively. The respective clutch side can be seen on the length of the disc carrier, see sketch.

K2 Dimension X (short disc carrier side)

KR Dimension Y (long disc carrier side)

Check disc clearance K2=2.6~2.8 mm (figure 179~181)

- In order to ensure a perfect measuring result, the disc set is first of all to be installed without oil.
- (1) Install disc set according to sketch or table (figure 178).
- (2) Install the end shim and fasten it by means of the snap ring.



Figure 179



Figure 180

(3) Press on end shim with approximately 100N (10 kg) and set dial indicator to "Zero".

Then press end shim against snap ring (upwards) and read disc clearance on the dial indicator.

If the required disc clearance differs, it has to be corrected with the adequate inner clutch disc or/and snap ring, see table/ position 6 and position 7.

Upon setting of disc clearance, remove the disc set, oil the clutch discs and reinstall them.

* Special tool

Magnetic stand	5870 200 055
Dial indicator	5870 200 057



Preassemble and install spur gear K2 (figure182~186) :

(1) Undercool gear 1 (approx -80°C) and heat gear 2 (approx 120°C).

Engage the snap ring(arrow), preload it and join both components by means of hydraulic press until the snap ring engages into the annular groove of gear 2.

- (2) Opposite figure shows the single components of the spur gear bearing.
 - 1 Bearing inner ring
 - 2 Spur gear assy
 - 3 Bearing inner ring



Figure 182



Figure 183

- (3) Heat the bearing inner ring and install it until contact.
- ▲ Use safety gloves.



Figure 184

(4) Assemble the spur gear until all inner clutch discs are located.



- (5) Heat the bearing inner ring (spur gear bearing) and install it until contact.
- ▲ Use safety gloves.



Figure 186

- (6) Heat the bearing inner ring (clutch bearing) and locate it until contact.
- ▲ Use safety gloves.



Figure 187

(7) Lift the disc carrier out of the clamping ring.

To ensure the exact locating of the single components, preload the bearing with 100 KN (10t) (figure 188)

 Support on the lower as well as upper bearing inner ring. Use pressure pieces.

Special toolPressure piece 5870 5

5870 506 096



- (8) Lift the disc carrier into the clamping ring and fasten it.
 Rotate disc carrier by 90°.
 K2-side : Install the slotted nut.
- Observe installation position of the slotted nut. Chamfer must show to the bearing inner ring, also see sketch (figure 159).
 Oil the thread.
 - · Torque limit : 81.6 kgf · m (590 lbf · ft)
- Special tool
 Clamping ring
 Slotted nut wrench
 5870 654 033
 5870 401 099

KR-side :

Install the slotted nut.

* Observe installation position of the slotted nut. Collar (Ø76 mm) must show to the bearing inner ring, also see sketch (figure 159). Oil the thread.

 \cdot Torque limit : 81.6 kgf \cdot m (590 lbf \cdot ft)

- Special toolSlotted nut wrench5870 401 099
- (9) Check function of the clutches K3 and K4 by means of compressed air (figure 191).
- Closing or opening of the clutches is clearly audible when the single parts have been installed adequately.

Snap-in and lock the rectangular rings (3EA, see arrows).



Figure 189



Figure 190



Assembly of the multi-disc clutch KV/K1

The following sketch shows the clutch sectioning



* Observe the installation position of the single components for the following assembly.

- (1) Lift the disc carrier with the KV-side showing downwards into the clamping ring(S) and fasten it. Then rotate disc carrier by 180°.
- A To install new disc carriers the finished bores have to be sealed with plugs. Installation position, see arrow, figure193~194.
- * Special tool Hand mounting tool

Ratchet spanner

5870 320 014 5870 320 018



Figure 193



Figure 194

- (2) Flush-mount the drain valve (arrow) with the chamfer showing downwards.
- * Special tool 5870 320 019 Inserting tool



Figure 195

(3) Put both O-rings scroll-free into the annular grooves of the piston, see arrows.



- (4) Oil the O-rings and the piston contact surface.Install K1 piston equally until contact.
- * Observe the installation position of the piston, see figure.
- (5) Install spacer and compression spring.

(6) Place guide ring, with the chamfer (arrow) showing upwards, over the compression spring and install the snap ring.

(7) Lift the disc carrier out of the clamping ring. Preload the compression spring by means of fixture and engage the snap ring into the annular groove of the disc carrier (arrow), see figure 200.

Install the drain valve, piston and compression spring on the opposite side (clutch KV) analogously.

Then lift the disc carrier with the KV-side showing downwards into the clamping ring and fasten it.

Rotate disc carrier by 180°.

Special tool

1	
Pressure piece	5870 345 072
Clamping fixture	5870 654 036







Figure 198









Disc Components KV

* Below sketch or table shows the standard version as to the installation position of the single components. Obligatory is the respective spare parts list.



Position	Description	Quantity	s (mm)	Remarks
1	Disc carrier	1		
2	Piston	1		
3	Outer clutch disc	2	1.85	Coated on one side
4	Outer clutch disc	11	2.5	Coated on both sides
5	Inner clutch disc	9	3.5	
6	Inner clutch disc	1	4.0	
7	Inner clutch disc	2	2.5~4.0	Optional
8	Snap ring	1	2.10~3.10	Optional
9	End shim	1		
Number of friction surfaces : 24				
Disc clearance : 2.8 ~ 3.0 mm				

- * Install the outer clutch discs position 3 with uncoated side showing to the piston and end shim respectively. The respective clutch side can be seen on the length and \emptyset of the disc carrier respectively, see sketch.
 - KV Dimension Y (long disc carrier side and large Ø respectively)
 - K1 Dimension X (short disc carrier side and small Ø respectively)

Check disc clearance KV=2.8~3.0 mm (figure 202~204)

- In order to ensure a perfect measuring result, the disc set is first of all to be installed without oil.
- (1) Install disc set according to sketch or table (figure 201).
- (2) Install the end shim and fasten it by means of the snap ring.



Figure 202



Figure 203

(3) Press on end shim with approximately 100N (10 kg) and set dial indicator to "Zero".

Then press end shim against snap ring (upwards) and read disc clearance on the dial indicator.

If the required disc clearance differs, it has to be corrected with the adequate inner clutch disc or/and snap ring, see table/ position 7 and position 8.

Upon setting of disc clearance, remove the disc set, oil the clutch discs and reinstall them.

* Special tool

Magnetic stand	5870 200 055
Dial indicator	5870 200 057



Figure 204

Preassemble and install spur gear KV (figure 205~209) :

- (1) Opposite figure shows the single components of spur gear KV.
 - 1 Bearing inner ring
 - 2 Bearing outer ring
 - 3 Ring
 - 4 Spur gear

Install both bearing outer rings (2) until contact.

- (2) Heat the bearing inner ring and install it until contact.
- ▲ Use safety gloves.

(3) Install the ring.



Figure 207

Figure 208





Figure 206

clutch discs are located.

(4) Assemble the spur gear until all inner

- (5) Heat the bearing inner ring (spur gear bearing) and locate it until contact.
- ▲ Use safety gloves.



- (6) Heat the bearing inner ring (clutch bearing) and locate it until contact.
- ▲ Use safety gloves.

Rotate disc carrier by 180°.



Disc Components K1

* Below sketch or table shows the standard version as to the installation position of the single components. Obligatory is the respective spare parts list.



Position	Description	Quantity	s (mm)	Remarks
1	Disc carrier	1		
2	Piston	1		
3	Outer clutch disc	2	1.85	Coated on one side
4	Outer clutch disc	8	2.5	Coated on both sides
5	Inner clutch disc	7	2.5	
6	Inner clutch disc	2	2.5~4.0	Optional
7	Snap ring	1	2.1~2.5	Optional
8	End shim	1		
Number of friction surfaces : 18				
Disc clearance : 2.6 ~ 2.8 mm				

- * Install the outer clutch discs position 3 with uncoated side showing to the piston and end shim respectively. The respective clutch side can be seen on the length and Ø of the disc carrier respectively, see sketch.
 - K1 Dimension X (short disc carrier side and small Ø respectively)
 - KV Dimension Y (long disc carrier side and large Ø respectively)

Check disc clearance KV=2.6~2.8 mm (figure 212~214)

- In order to ensure a perfect measuring result, the disc set is first of all to be installed without oil.
- (1) Install disc set according to sketch or table (figure 211).
- (2) Install the end shim and fasten it by means of the snap ring.



Figure 212



Figure 213

(3) Press on end shim with approximately 100N (10 kg) and set dial indicator to "Zero".

Then press end shim against snap ring (upwards) and read disc clearance on the dial indicator.

If the required disc clearance differs, it has to be corrected with the adequate inner clutch disc or/and snap ring, see table/ position 7 and position 8.

Upon setting of disc clearance, remove the disc set, oil the clutch discs and reinstall them.

* Special tool

Magnetic stand	5870 200 055
Dial indicator	5870 200 057



Figure 214
Preassemble and install spur gear K1 (figure 215~222) :

- (1) Opposite figure shows the single components of spur gear K1.
 - 1 Ball bearing (assy)
 - 2 Snap ring
 - 3 Spur gear

(2) Install the ring.

Prior to installation of the single components, align the disc set by means of the spur gear radially and center it, see figure 216.



Figure 215



Figure 216



Figure 217

(3) Install the bush with collar (arrow) on face end showing to the snap ring.



- (4) Press in the ball bearing until contact.
- Install the ball bearing with the lubricating groove (arrow) showing downwards.
 Put the press-in tool only to te bearing outer ring.



Figure 219

Figure 220

- (5) Heat the second ball bearing and install it until contact.
- * Lubricating groove (arrow), must show upwards.
- ▲ Use safety gloves.

(6) Assemble the bush.



Figure 22

- (7) Heat the spur gear to approximately 120°C and assemble it until all inner clutch discs are located.
- ▲ Use safety gloves.



(8) Install shim s = 1.20 mm



Figure 223

- (9) Heat the bearing inner ring and install it until contact.
- A Use safety gloves.



Figure 224

- (10) Lift the disc carrier out of the clamping ring. To ensure the exact locating of the single components, preload the bearing with 100KN (10 t) (figure 225).
- Support on the lower as well as upper bearing inner ring. Use pressure pieces.
- Special toolPressure pieces 5870 506 096

- (11) Lift the disc carrier into the clamping ring.Rotate disc carrier by 90°.Install the slotted nut.
- Observe installation position of the slotted nut. Collar (Ø60 mm) must show to the taper roller bearing also see sketch (figure 192). Oil the thread.
 - \cdot Torque limit : 56.1 kgf \cdot m (406 lbf \cdot ft)
- Special tool
 Slotted nut wrench
 Slotted nut wrench
 5870 401 118
 5870 401 099

Install the opposite slotted nut (KV-side) analogously.

- Special tool
 Slotted nut wrench
 Slotted nut wrench
 5870 401 118
 5870 401 115
- (12) Check function of the clutches KV and K1 by means of compressed air.
- Closing or opening of the clutches is clearly audible when the single parts have been installed adequately.

(13) Snap-in and lock the rectangular rings (3EA, see arrows).



Figure 226







Installation of layshaft gear, multi-disc clutches and output gear

- (1) Opposite figure shows the single components of the layshaft gear bearing.
 - 1 Bearing inner ring (2EA)
 - 2 Ring
 - 3 Layshaft gear
- (2) Position layshaft gear (assy) in the housing.
- Only when the clutches are installed, the idler shaft can be mounted.

(3) Insert the bearing outer rings KV/K1, KR/ K2 and K3/K4 into the housing bores until contact, see arrows.



Figure 229



Figure 230



- (4) Position clutch KV/K1 by means of lifting tackle.
- Special toolEyebolts assortment5870 204 002



Figure 232

- (5) Position clutch KR/K2.
- Special toolEyebolts assortment5870 204 002



Figure 233

(6) Check the installation position of the layshaft gear (arrow) once again and correct it, if required.



Figure 234

- (7) Fasten the spur gear K3 by means of fixture and eyebolt (arrow) axially.
- Spur gear fixing prevents the clutch discs from dislocating when the clutch is lifted in.
- Special tool
 Assembly fixture
 Eyebolt
 5870 345 033
 5870 204 066
- (8) Lift the clutch KR/K2 slightly, move it in direction of the arrow and position clutch K3/K4.

Then remove the fixture (figure 235) again.



Figure 235



(9) Insert the bearing outer ring into the housing bore until contact.



Figure 237

(10) Heat the bearing inner ring and install it until contact.

A Use safety gloves.

- * Observe installation position-collar (arrow) shows to the spur gear. Install the bearing inner ring after cooling down subsequently (press).

Figure 238

(11) Position the oil baffle.



Figure 239

- (12) Install the output gear by means of lifting tackle.
- Special tool
 Stop washer
 Eyebolts assortment
 5870 100 054
 5870 204 002



Figure 240

- (13) Position upper oil baffle and fasten both plates by means of hexagon screws (4EA).
- * Install washers.

Secure hexagon screws with loctite (type No.243).

 \cdot Torque limit : 2.35 kgf \cdot m (16.7 lbf \cdot ft)

Preassembly and mounting of the housing cover

Note to figure 242 and 243 :

Depending on the transmission version, differences as regards the single components and their installation position are possible.

Obligatory is the respective parts list.

- (1) Install the sealing cover (arrow).
- Wet the sealing surface with loctite (type No.262).
- (2) Insert the O-ring into the annular groove of the cover and fasten the cover by means of hexagon screws.
- Wet the thread of the hexagon screws with loctite (type No.574). Observe the installation position of the cover, see figure.
 - Torque limit : 2.35 kgf · m (16.7 lbf · ft)



Special tool
 Lifting tackle

5870 281 055



igure 241



Figure 242



Figure 243



Figure 244

(4) Install both cylindrical pins (arrow 1 and 2) and the slotted pin (arrow 3).Then fasten the housing cover by means

of hexagon and cap screws.

- · Torque limit M10/8.8 :
 - 4.69 kgf · m (33.9 lbf · ft)



For installation of a new bearing cover, both finished bores have to be sealed by means of a plug.

Finished bores are located opposite (180°) to each other, also see arrow/figure 246 and 247.

- 1 Bearing cover-K4/K3
- 2 Plug (konig)
- (S) Special tool
- * Special tool

Hand mounting tool	5870 320 014
Ratchet spanner	5870 320 018





Figure 246



Housing dimension :

- (1) Press on equally the bearing inner ring and detemine Dimension I, from the mounting face to the bearing inner ring.
 Dimension I e.g. 43.65 mm
- * Take several measuring points and determine the mean value.

Then remove the bearing inner ring again.

*	Special tool	
	Measuring shaft	5870 200 022
	Digital depth gauge	5870 200 072

Cover dimension :

*	Special tool	
	Straightedge	5870 200 022
	Gauge blocks	5870 200 067
	Digital depth gauge	5870 200 072



Figure 248



Figure 249

Example :

Dimension II	Dimension I	43.65 mm
	Dimension II	- 42.12 mm
Difference = 1.53 mm	Difference	= 1.53 mm
Bearing preload e.g. + 0.02 mm	Bearing preload e.g.	+ 0.02 mm
Resulting shim(s) s = 1.55 mm	Resulting shim(s) s	=1.55 mm

(3) Put on the shim.



Figure 250

(4) Heat the bearing inner ring and place it until contact.

A Use safety gloves.

Install the bearing inner ring after cooling down subsequently (press).



(5) Grease the rectangular rings (3EA, arrows) and centrally align them.



- (6) Install the O-ring (arrow) and grease it. Heat the inner diameter of the bearing cover (bearing seat).
- Special tool Hot-air blower 230

Hot-air blower 230V	5870 221 500
Hot-air blower 115V	5870 221 501



Figure 253

(7) Install two adjusting screws.

Assemble the bearing cover and tighten it equally until contact by means of hexagon screws.

· Torque limit (M10/8.8) :

4.69 kgf · m (33.9 lbf · ft)

- * Observe the radial installation position.
- Special tool 5870 204 007 Adjusting screws
- (8) Check the function of **both** clutches by means of compressed air.
- * In case of a decisive pressure loss, the possible cause might be the breakage of one or several rectangular rings (see arrow, figure 252).

Replace the rectangular rings, if required.







Figure 255

Adjust the bearing preload of clutch KR/K2

- = 0.0~0.05 mm (figure 258~262)
- For installation of a new bearing cover, both finished bores have to be sealed by means of a plug.

Finished bores are located opposite (18°) to each other, also see arrow/Figure 256 and 257.

- 1 Bearing cover-KR/K2
- 2 Plug
- (S) Special tool
- * Special tool

Hand mounting tool	5870 320 014
Ratchet spanner	5870 320 018



Figure 256



Figure 257

- (1) Install both studs (arrows).
- * Wet the thread with loctite (type No. 243).
 - \cdot Torque limit (M10) :
 - 1.33 kgf · m (9.59 lbf · ft)



- (2) Install the bearing outer ring until contact.
- * Pay attention to exact contact.



Housing dimension :



Figure 260

Cover dimension :

- (4) Determine Dimension II, from the contact/ bearing outer ring to the mounting face.Dimension II e.g 17.75 mm
- Special toolDigital depth gauge 5870 200 072



Figure 261

Example :

Dimension II	17.75 mm
Dimension I	- 16.13 mm
Difference	= 1.62 mm
Bearing preload e.g.	+ 0.03 mm
Resulting shim (s)s	=1.65 mm

- (5) Fix the shim with assembly grease into the cover. Install the O-ring (arrow).
- (6) Grease the rectangular rings (arrows) and centrally align them.



Figure 262



Figure 263

(7) Pull the bearing cover equally until contact.

· Torque limit (M10/8.8) :

4.69 kgf · m (33.9 lbf · ft)



Figure 264

- (8) Check the function of both clutches by means of compressed air.
- In case of a decisive pressure loss, the possible cause might be the breakage of one or several rectangular rings (see figure 263).

Replace the rectangular rings, if required.



Figure 265

Adjust the bearing preload of clutch KV/K1

- = 0.0~0.05 mm (figure 267~270)
- For installation of a new bearing cover, both finished bores have to be sealed by means of a plug.

Installation position, see arrows/figure 266.

- 1 Bearing cover-KV/K1
- 2 Plug
- (S) Special tool
- Special tool
 Hand mounting tool
 5870 320 014
 Ratchet spanner
 5870 320 018
- (1) Put the bearing outer ring over the bearing inner ring.

Housing dimension :

Press on equally the bearing outer ring and determine Dimension I, from the mounting face to the bearing outer ring.

Dimension I e.g 52.67 mm

- * Take several measuring points and determine the mean value.
- (2) Put the ring with the chamfer showing downwards into the bearing cover.



Figure 266



Figure 267



Figure 268

Cover dimension :

- Special tool
 Digital depth gauge
 Gauge blocks
 5870 200 072
 5870 200 067



Figure 269

Example :

Dimension I	52.67 mm
Dimension II	- 50.75 mm
Difference e.g	. 1.92 mm
Bearing preload	+ 0.03 mm
Resulting shim (s)s	=1.95 mm

- (4) Put in the shim.
- (5) Install the bearing outer ring until contact. Assemble the O-ring (arrow).



Figure 270



Figure 271

(6) Grease the rectangular rings (arrows) and centrally align them.



Figure 272

(7) Heat the bearing bore.

*	Special tool	
	Hot-air blower 230V	5870 221 500
	Hot-air blower 115V	5870 221 501



Figure 273

- (8) Install two adjusting screws.Place the bearing cover until contact and fasten it by means of hexagon screws.
- * Observe the radial installation position, see figure.
- Special toolAdjusting screws 5870 204 007



Figure 274

- (9) Check the function of both clutches by means of compressed air.
- In case of a decisive pressure loss, the possible cause might be the breakage of one or several rectangular rings (see arrow, figure 272).

Replace the rectangular ring (s), if required.



Figure 275

Output

Installation of the output shaft

(1) Heat the inner diameter of the output gear.

*	Special tool	
	Hot-air blower 230V	5870 221 500
	Hot-air blower 115V	5870 221 501

(2) Assemble the output shaft with the long gearing showing downwards until contact.



Figure 276



Figure 277

(3) Rotate the transmission housing into the vertical position (90°).

By means of the mounting tool the output shaft has preliminarily to be fixed axially (figure 278 and 279) at the convert-er side.

Special tool
 Mounting tool

5870 048 265

Then rotate the transmission housing back again (90°).





Adjust the axial play of the output bearing = 0.3~0.5 mm (figure 280~282)

(4) Determine Dimension I, from plane face/ housing to end face/output shaft.

- Special toolDigital depth gauge 5870 200 072
- (5) Measure Dimension II, from plane face/ housing to contact face/ball bearing.

Dimension II e.g	·· 64.20 mm
Example :	
Dimension I	·· 66.90 mm
Dimension II	- 64.20 mm
Difference	= 2.70mm
Required axial play e.g	g. <u>-0.40 mm</u>
	(0.3~0.5 mm)
Resulting shims	=2.30 mm

(6) Install the shim.



Figure 280



Figure 281



Figure 282

(7) Install the ball bearing (figure 283) and pull it until contact by means of the output flange (figure 284).

Then remove the output flange again.





Figure 284

- (8) Fasten the ball bearing by means of retaining ring.
- * Clamping pliers 5870 900 021



Figure 285

(9) Remove the converter-side mounting tool again.

Install the shaft seal, (arrow) with the sealing lip showing to the oil sump.

- Using of the specified mounting tool (S), results in the exact installation position (without retaining ring = 20 mm).
 Grease the sealing lip.
- Special toolMounting tool5870 048 265
- * Depending on the version different shaft seals can be used :

Outer diameter rubber-coated-wet it with spirit. Outer diameter metallic-wet it with sealing compound (loctite, type No. 574).



Figure 286

Adjust gap size $X = 0.3 \sim 0.8$ mm (figure 289~292) :

- X Gap size
- 1 Shim
- 2 O-ring.



Figure 289

(1) Install the output flange until contact.

Measure Dimension I, from the plane face of the output flange to the end face of the output shaft.

Special toolDigital depth gauge 5870 200 072



Figure 290

(2) Measure Dimension II, from the plane face to the collar of the output flange.

Dimension II e.g.	36.00 mm
Example :	
Dimension I	37.00 mm
Dimension II	- 36.00 mm
Difference	= 1.00 mm
Gap size X e.g.	- 0.50 mm
(0.3~0.8 mm)	
Resulting shim s	=0.50 mm



(3) Place the O-ring (arrow) into the space between output flange and shaft (see also figure 289) and put on the shim.



Figure 292

- (4) Put on the washer and fasten the output flange by means of hexagon screws.
 - · Torque limit (M10/8.8) :

4.69 kgf · m (33.9 lbf · ft)



Figure 293

- (5) Fasten the hexagon screws by means of the lock plate.
- Specail tool
 Mounting tool
 Handle

5870 057 009 5870 260 002



Output flange - parking brake

- (1) Press on the screen sheet (arrow) until contact.
- * The installation position of the screen sheet is identical with the output flange.

Pressing bush 5870 506 138

(2) Install the output flange-brake disk until contact.



Figure 295



Figure 296

Mount the brake (figure 297~301)

- ▲ For working on the brake system, the instructions and specifications of the brake manufacturer are mandatory.
- (3) Remove the screw cap and loosen the locking nut (wrench size 30).
 Unscrew the adjusting screw in counterclockwise direction until a demension > 13.0 mm (brake disc shim) results (figure 297).
- Figure 297
- (4) Position the brake and fasten it with cap screws.

Tightening torque M14/8.8) : 12.7 kgf \cdot m (92.2 lbf \cdot ft)

Socket spanner 5870 656 047



Figure 298

Adjust the nominal clearance = 2.0 mm (figure 299~301)

(5) Make the pressure connection and apply the required release pressure = 150 bar to the brake (cup spring set preloaded). Fasten the adjusting screw in clockwise direction until both brake lining carriers contact the brake disc (turning of the adjusting screw is then not possible or admissible any more without a higher application of force).

Then turn back the adjusting screw by 4/5 turns in counterclockwise direction. 4/5 turns is equal to a nominal clearance of 2.0 mm.



Figure 299

(6) Keep the adjusting screw positioned and fix it by means of a lock nut.

HP-Pump	5870 287 007
Mini-measuring hub	5870 950 102



Figure 300

(7) Put new O-Ring into the screw cap and grease it.Install the screw cap.



Figure 301

Output Flange (converter side)

- (1) Install the shaft seal (arrow) with the sealing lip showing to the oil sump.
- Using of the specified mounting tool, results in the exact installation position (with retaining ring = 7.0 mm).
 Grease the sealing lip.
- Special toolMounting tool5870 048 265
- * Depending on the version different shaft seals can be used :

Outer diameter rubber-coated-wet it with spirit. Outer diameter metallic-wet it with sealing compound (loctite, type No. 574).

- (1) Press the screen sheet (arrow) over the collar of the output flange until contact.
- % Observe the installation position, see figure 304.
- Special toolPressing bush 5870 506 138





Figure 303

- 1 Screen sheet
- 2 Output flange



- (2) Install the output flange until contact.
- * Setting of the gap size as well as fixing of the output flange is identical with the installation of the output flange at the transmission rearside, see figure 289~294.



Figure 305

Installation of the idler shaft

- (1) Align the layshaft gear and the single components centrically. Heat the layshaft gearing (figure 306).
- * Special tool Hot-air blower 230V 5870 221 500 Hot-air blower 115V 5870 221 501



Figure 306

- (2) Install the adjusting screw.
- Special tool Adjusting screws 5870 204 007



Figure 307





- (4) Remove the adjusting screw and fasten the axle by means of hexagon screw.
- * Wet the thread of the hexagon screw with Loctite (type No. 243).
 - · Torque limit (M10/8.8) : 4.69 kgf · m (33.9 lbf · ft)
- (5) Insert the sealing covers (arrow), with the concave side showing downwards, flush to the housing surface.
- * Wet contact face with loctite (type No. 262).



Figure 309



Figure 310

Transmission pump

(with 2nd/3rd or 4th power take-off)

(1) Press the needle sleeve (arrow), with the reinforced coating towards the press-in tool until contact.

Mounting tool	5870 058 041
Handle	5870 260 002





Figure 311



Figure 312

(3) Install the O-Ring (arrow) and grease it.



Figure 313

(4) Heat the housing bore.

Preheating bush	5870 801 006
Hot-air blower 230 V	5870 221 500
Hot-air blower 115 V	5870 221 501



Figure 314

- (5) Install two adjusting screws and assemble the pump until contact.
- * Observe the radial installation position.

5870 204 021 Adjusting screws



Figure 315

- (6) Put the O-Ring (arrow) into the annular groove of the pump flange.
- * Depending on the transmission version, differences as regards the version and fastening of the pump flange are possible. Obligatory is the respective parts list.



Figure 316

- (7) Fasten the pump flange and pump respectively by means of cap screws.
- * Wet thread of both cap screws (position, see arrows) with loctite, type No. 574 (through holes).
- * Tightening torque (M12/8.8) : 8.06 kgf · m (58.3 lbf · ft)
- (8) Rotate the transmission housing by 180° .

Snap the V-rings (3X) into the recess of the driver (internal gearing). Install the key (arrow).







Figure 318

(9) Install shim s = 2.0 mm and locate the bearing inner ring until contact.



Figure 319





- (11) Install the driver by means of clamping plate until contact and fasten it by means of cap screw.
- Tightening torque M10/8.8, DIN 6912) : 3.26 kgf · m (23.6 lbf · ft)
- Wet thread of the cap screw with loctite (Type No. 243).
- (12) Press the bearing inner ring until contact.



Figure 321



Figure 322

(13) Snap in the retaining ring (arrow) and install the input gear.

Set of external pliers 5870 900 015



Figure 323

(14) Snap-in and lock the rectangular ring (arrow).



- (15) Install the preassembled input shaft until contact.
- * Pay attention to align the key to the keyway.



Figure 325

Adjust the axial play of the input shaft bearing = 0.0~0.05 mm (figure 326~328) :

(16) Put on the gasket.

Put on the bearing outer ring, press it on equally and determine Dim. I, from the mounting face (gasket) to the bearing outer ring.

Dim I e.g. 128.50 mm

- * Take several measuring points and determine the mean value.
- (17) Measure Dim II, from the mounting face/ converter bell to the mounting face/ bearing outer ring.

Dim II e.g	127.46 mm
Straightedge	5870 200 022
Gauge blocks	5870 200 080
Digital depth gauge	5870 200 072



Figure 326



Figure 327

Example :

resulting shim(s) s	=	=	1.00 mm
Axial play			0.04 mm
Difference	. :	=	1.04 mm
Dim II		12	27.46 mm
Dim I		12	8.50 mm

Put in the shim and locate the bearing inner ring until contact.



Figure 328

Transmission pump

(with 1st power take-off)

- Press the needle sleeve (arrow), with the reinforced coating towards the press-in tool until contact.
- Special tool
 Mounting tool
 Handle

5870 058 041 5870 260 002

(2) Snap the V-Rings (3EA) into the recess of the driver (internal gearing). Install the key (arrow).



Figure 329



Figure 330

(3) Press the ball bearing over the collar of the driver until contact.



Figure 331

- (4) Install the ball bearing and driver respectively and press it until contact.
- * Pay attention to align the key to the keyway.



- (5) Fasten the ball bearing by means of retaining ring.
- Special toolSet of internal pliers 5870 900 013



Figure 333

(6) Install the O-ring (arrow) and grease it.



Figure 334

(7) Heat the housing bore.

*	Special	tool
---	---------	------

Preheating bush	5870 801 006
Hot-air blower 230V	5870 221 500
Hot-air blower 115V	5870 221 501



- (8) Install two adjusting screws and assemble the pump until contact.
- * Observe the radial installation position.
- Special toolAdjusting screws 5870 204 021



Figure 336

- (9) Put the O-ring (arrow) into the annular groove of the pump flange.
- Depending on the transmission version, differences as regards the version and fastening of the pump flange are possible.
 Obligatory is the respective parts list.



Figure 337

- (10) Fasten the pump flange and the pump respectively by means of hexagon screws.
- Wet thread of both hexagon screws (position, see arrows) with Loctite, Type No. 574 (through holes).
 - · Torque limit (M12/8.8) :

8.06 kgf · m (58.3 lbf · ft)

Then rotate the transmission housing by 90°.

(11) Snap-in and lock the rectangular ring (arrow).



Figure 338



- (12) Install both shims (each 2.0 mm thick)
- * Use assembly grease.



(13) Heat the bevel bearing inner ring.

*	Special tool	
	Hot-air blower 230V	5870 221 500
	Hot-air blower 115V	5870 221 501



Figure 341

(14) Install the input shaft until contact.



Figure 342

(15) Fasten the input shaft by means of clamping plate and cap screw (arrow).

· Torque limit (M10/8.8) :

3.26 kgf · m (23.6 lbf · ft)

Wet thread of the cap screw with loctite (type No. 243).

Input-Converter Bell

- * To install a new converter bell the finished bores (3EA) have to be sealed with plugs. Installation position, see arrow, figure 344.
- Special tool 5870 320 016 Lever riveting tongs
- (1) Locate the bearing outer ring into the housing bore until contact and install the bearing inner ring, see arrow.

(2) Install the spur gear (arrow) with the long collar showing upwards and position it.

Figure 344



Figure 345



Figure 346

- (3) Heat the spur gear bore (arrow).
- Special tool Hot-air blower 230V

Hot-air blower 115V

5870 221 500 5870 221 501


(4) Install the input shaft until contact.



Figure 348

- (5) Heat the bearing inner ring and install it until contact.
- ▲ Use safety gloves.



(6) Install the bearing outer ring until contact.



(7) Snap in the rectangular ring (arrow) into the annular groove of the input shaft and lock it.

Then grease the rectangular ring and centrally align it.



Figure 351

- (8) Install the converter safety valve (arrow 1) and fasten it by means of slotted pin (arrow 2).
- * Flush-mount slotted pin to recess.

Put the O-ring (arrow 3) into the annular groove.



Figure 352

- (9) Press the needle bearing (arrow), with the reinforced coating towards the press-in tool into the bore of the bearing cover until contact.
- Special tool Mounting tool 5870 058 051 Handle 5870 260 002



Figure 353

- (10) Flush-mount the shaft seal (arrow) with the sealing lip showing (downwards) to the oil sump.
- ※ Wet the outer diameter with spirit. Grease the sealing lip.
- * Special tool Mounting tool 5870 048 030



Figure 354

- Make the following steps (figure 355~358) in direct time sequence to secure the precise contact of the oil supply flange.
- (11) Heat the housing bore.

*	Special tool	
	Preheating bush	5870 801 006
	Hot-air blower	5870 221 500
	Hot-air blower	5870 221 501



- (12) Install two adjusting screws and put in the oil supply flange until contact.
- * Observe the radial installation position.
- Special tool Adjusting screws 5870 204 007

(13) Place the O-ring (arrow) with assembly grease into the annular groove of the

bearing cover.



Figure 356

Figure 357

- (14) Put on the bearing cover and fasten it by means of hexagon screws.
 - · Torque limit (M10/8.8) :

4.69 kgf \cdot m (33.9 lbf \cdot ft)



Figure 358

- (15) Install the single components according to the opposite figure.
 - 1 Screw plug : 15.3 kgf \cdot m (110 lbf \cdot ft)
 - 2 Screw plug : 2.55 kgf \cdot m (18.4 lbf \cdot ft)
 - 3 Temperature sensor :

2.55 kgf · m (18.4 lbf · ft) and screw plug respectively(depending on the version) : 3.57 kgf · m (25.8 lbf · ft)

* Always install new O-ring.



Converter pressure back-up valve

(figure 360~361)

(1) Install the slotted pin (6×50 mm) until contact.



Figure 360

- (2) Assemble piston and compression spring. Provide screw plug with a new O-ring and install it.
 - · Torque limit (M36 \times 1.5) : 13.3 kgf \cdot m (95.9 lbf \cdot ft)



Figure 361

- (3) Fasten the gasket and cover plate by means of hexagon screws (install the washers).
 - · Torque limit (M6/8.8) : 0.97 kgf \cdot m (7.0 lbf \cdot ft)



Figure 362

- (4) Install two adjusting screws and put on the gasket (arrow 1). Put the O-ring (arrow 2) into the annular groove.
- * Special tool Adjusting screws 5870 204 021



- (5) Install the converter bell by means of lifting tackle until contact.
- Slight rotary motions of the input shaft facilitate the installation (protect teeth from damage). Observe the radial installation position.
- Special tool
 Lifting tackle
 Eyebolts assortment
 5870 281 047
 5870 204 002
- (6) Fasten the converter bell by means of hexagon screws.
 - · Torque limit (M8/10.9) :

3.47 kgf · m (25.1 lbf · ft)

- · Torque limit (M12/10.9) :
 - 11.7 kgf \cdot m (84.8 lbf \cdot ft)



Figure 364



Figure 365

- (7) Fasten flexible plate (3EA) by means of hexagon screws (install the washers).
- Wet thread of the hexagon screws with Loctite (type No. 243).
 - · Torque limit (M10/8.8) :

4.69 kgf · m (33.9 lbf · ft)



Figure 366

(8) Install the rectangular ring (arrow) into the annular groove and lock it. Then grease the rectangular ring and

centrally align it.

Figure 367

3-210

- (9) Assemble converter by means of lifting tackle until contact (figure 368).
- * At a control dimension < 43 mm, the exact installation position of the converter is ensured, see Figure 369.
- Special tool

Eyebolts assortment Lifting chain 5870 204 002 5870 281 047



Figure 368



Figure 369

▲ Until installation of the transmission, fix the converter axially, see figure 370.



Figure 370

Coarse Filter

- (1) Install filter (assy) into the housing bore.
- * Oil the sealing (arrow).



Figure 371

- (2) Fasten the cover by means of hexagon screws (install the washers).
- * Install the new O-ring (arrow).
 - · Torque limit (M8/8.8) :

2.35 kgf · m (17.0 lbf · ft)



Figure 372

Inductive and speed transmitters

- Following sketches show the installation position of the single inductive and speed transmitters.
 - 14 Inductive transmitter n-Turbine
 - 9 Inductive transmitter n-Engine
 - 5 Inductive transmitter n-Intenal
 - 13 Speed transmitter n-Output



* The following figures describe the installation and setting respectively of the inductive transmitter n-Engine (9). Installation of the inductive transmitter n-Turbine (14) and n-internal speed input (5) is to be made analogously.

Observe the different setting dimensions "X" :

▲ Inductive transmitter n-Engine (9) $X = 0.5^{+0.3} \text{ mm}$ Inductive transmitter n-Turbine (14) $X = 0.5^{+0.3} \text{ mm}$ Induct. transmitter n-int. speed input (5) $X = 0.3 \pm 0.1 \text{ mm}$

Adjust Dimension "X" by means of shim ring (s) (figure 376~381)

- (1) Measure Dimension I on the inductive transmitter, from contact face to screw-in face.
- Dimension I e.g 30.00 mm





(2) Turn in the counting disc radially until one tooth tip is centrally to the inductive transmitter bore.

Turn the plug gauge until contact. Locate anvil at the tooth tip and lock it by means of threaded pin (figure 377 and 378).

Special tool Plug gauge 5870 200 104

Special tool Plug gauge 5870 200 104







(3) Turn out the plug gauge and determine Dimension II (also see figure 378).

Dimension II e.g 30.10 mm



Figure 379

Example "A1" :		
Dimension II	30.10 mm	
Dimension X (0.5 ^{+0.3} mm)	- 0.60 mm	
Results in installation dimension A		
	= 29.50 mm	
Example "A2" :		
Dimension I	30.00 mm	
Installation dimension A	- 29.50 mm	
Results in shim ring (s)	s = 0.50 mm	

(4) Install the adequate shim ring (s) and wet the thread (arrow) with Loctite (type No. 574).



Figure 380

(5) Install the inductive transmitter n-Engine (9), see arrow.

· Torque limit : 3.06 kgf · m (22.1 lbf · ft)

Set and install the inductive transmitter n-Turbine (14) and n-internal speed input (5) analogously.

* Observe the different setting dimensions. Installation position of the single inductive transmitters, also see figure 373.



Install speed transmitter n-Output/Speedo (13) (figure 382~387)

- 1 Housing
- 2 Spur gear K3
- 3 Disc carrier
- 13 Speed transmitter (hall sensor)
- X Setting dimension "X" =1.0+0.5 mm
- (1) Opposite figure shows the speed transmitter (hall sensor).



Figure 382



Figure 383

- (2) Determine Dimension I, from the housing face to spur gear K3.Dimension I e.g. 39.70 mm
- Special toolDigital depth gauge 5870 200 072



Figure 384

(3) Measure Dimension II, from the contact face to the mounting face.

Dimension II e.g 40.00 mm

Special toolDigital depth gauge 5870 200 072



Figure 385

Example "B1" :

Dimension I Dimension X(1.0+0.5mm)	<u>39.70 mm</u>	
	1.2011	
Results in installation dimension		
	= 38.50 mm	
Example "B ₂ " :		
Dimension II	40.00 mm	
Installation dimension A	- 38.50 mm	



(5) Fasten the speed transmitter by means of cap screw.

· Torque limit (M8/8.8) :

* Installation position of the speed transmitter, also see figure 382.



Figure 386



Figure 387

3. AXLE

1) DISASSEMBLY

- (1) Disassembly output and brake
- $(\ensuremath{\underline{1}})$ Fix axle to assembly truck.

Assembly truck	5870 350 000
Fixtures	5870 350 077
Clamping brackets	5870 350 075
Support	5870 350 125

% Before clamping the axle fully turn in the support.

Position axle first onto the two fixtures, secure with clamping brackets and then unbolt the support until contact with the axle is obtained.

② Loosen screw plugs (3EA, see figure AX02 and AX03) and drain oil from the axle.





7809AX02



- ③ Remove the breather valve (see arrow).
- * To avoid any damage, the breather valve must be removed when separating the output.



7809AX04

④ Secure the output with the lifting device and loosen hexagon screws.

Then separate the output assy from the axle housing.

Load carrying device AA00 685 875

% Fix the load carrying device with wheel nuts.

7809AX05

- (5) Pull stub shaft and sun gear shaft.
- % Pay attention to potentially releasing shim(s).



7809AX06

6 Fix output to assembly truck.

Assembly truck	5870 350 000
Fixtures (2EA)	5870 350 113



⑦ Use a lever to remove the cover from the output shaft.



7809AX08

8 Loosen locking screws and remove the releasing cover.



7809AX09

④ Lift the planetary carrier out of the brake housing by means of the lifting device.

•	Rear axle (planetary	carrier with 3
	planetary gears)	
	Internal extractor	5870 300 019
	Eye bolt	5870 204 073

- Front axle (planetary carrier with 4 planetary gears)
 Internal extractor
 Eye nut
 5870 300 008
 AA00 680 376
- Description Pull the tapered roller bearing from the planetary carrier.

Rapid grip	AA00 693 459
Basic tool	5873 004 001
Clamping cylinder	5873 003 016
Pump	5870 287 010





1) Disengage retaining ring.



7809AX71

12 Pull off planetary gear.

Extractor	AA00 696 012
Clamping cylinder	5873 003 016
Pump	5870 287 010



7809AX72

3 Lift the end plate out of the brake housing.



7809AX73

(14) Lift the disk package out of the brake housing.



(5) Loosen hexagon screws, remove releasing disk and cup spring.

(6) Mount breather valve and press piston out of the brake housing by means of

compressed air.



7809AX13

7809AX14

- If necessary, remove guide ring, back-up rings and grooved rings out of the annular grooves of the brake housing (see arrows).
- For the installation position of the single parts please also refer to the following sketch.

κ κ

3-221

Legend to sketch :

- 1 = Brake housing
- 2 = Guide ring
- 3 = Back-up ring
- 4 = Grooved ring
- 5 = Grooved ring
- 6 = Back-up ring
- 7 = Slide ring seal
- 8 = Output shaft



① Lift the brake housing from the output shaft by means of the lifting device.



7809AX17

① Use a lever to remove the slide ring seal from the brake housing.

If necessary, force out both bearing outer rings.

Resetting device 5870 400 001



② Use a lever to remove the slide ring seal from the output shaft.

Resetting device 5870 400 001



7809AX74

② Pull the tapered roller bearing from the output shaft.



7809AX75

(2) Disassembly axle housing

① Secure axle housing with the lifting device and loosen the hexagon screws. Then separate the axle housing from the axle drive housing.

2 Loosen the threaded connections and remove the releasing brake tube.







7809AX20



(3) Disassembly axle drive housing

③ Loosen both screw necks.

① Secure axle drive housing with the lifting device and loosen the hexagon screws. Then separate the axle drive housing from the axle housing.

Eyebolt (M20)	5870 204 086
Thread insert	AA00 677 715



② Fix axle drive housing to the assembly truck.

Assembly truck	5870 350 000
Fixtures (2EA)	5870 350 113



7809AX76

③ Loosen cylindrical screws and lift the releasing bearing housing with the lifting device.

Inner extractor	
Eye bolt	

5870 300 008 AA00 680 376



7809AX77

④ Pull the bearing outer ring (see arrow) out of the bearing hole and remove the shim behind.



7809AX78

⑤ Press the piston out of the bearing housing by means of compressed air.



6 Lift differential out of the axle drive housing with the lifting device.

Inner extractor	5870 300 008
Eye nut	AA00 680 376

- Disassembly of the various differentials is described as of page 3-229.
- ⑦ Pull the bearing outer ring (see arrow) out of the bearing hole and remove the shim behind.







7809AX81

- ⑧ Heat slotted nut by means of hot-air blower.
- * Slotted nut is secured with Loctite # 262.



7809AX82

(9) Loosen the slotted nut and remove the shim behind.

Wrench	5870 401 093
Fixing device	AA00 695 905
Clamping device	5870 240 002



① Pull input flange from the input pinion and use a lever to lift the shaft seal ring behind out of the axle drive housing.



7809AX84

 Use a two-armed puller to press the input pinion out of the axle drive housing and remove the releasing tapered roller bearing.



7809AX85

2 Remove the spacer and pull the tapered roller bearing from the input pinion.

Gripping device	AA00 253 881
Basic tool	5873 003 000
Clamping cylinder	5873 003 016
Pump	5870 287 010



Is Loosen the threaded connection and remove the releasing oil tube.



If necessary pull the internal bearing outer ring out of the axle drive housing and remove the shim behind.

Assembly device	
Counter support	

AA00 696 770 5870 300 020



7809AX88

(5) If necessary pull the external bearing ring out of the axle drive housing.

Assembly device	AA00 696 770
Counter support	5870 300 020



7809AX89

(4) Disassembly differentials

Disassembly multi-disk differential lock

1 Remove axial roller cage (arrow).



7809AX90

② Pull both tapered roller bearings from the differential.

Crown wheel side	
Rapid grip	AA00 303 274
Basic tool	5873 004 001
Pressure piece	AA00 694 360
Opposite side	
Grab sleeve	5873 004 026
Basic tool	5873 004 001
Clamping cylinder	5873 003 016
Pump	5870 287 010

③ Preload the differential by means of the press and loosen the locking screws.

Pressure piece

AA00 694 360



7809AX91



7809AX92

④ Lift the differential cover from the differential housing by means of the lifting device.

Inner extractor
Eye nut

5870 300 008 AA00 680 376



⑤ Preload the compression spring by means of the press and disengage the retaining ring.

Then pull the sliding sleeve out of the differential cover and remove the releasing compression springs.



7809AX94

- 6 Remove single parts.
 - 1 = Disk
 - 2 = Pressure piece
 - 3 = Cage
 - 4 = Lever (15EA)
 - 5 = Disk carrier
 - 6 = Disk package

7809AX95

⑦ Loosen hexagon screws and remove the releasing disk.



7809AX96

⑧ Remove thrust washer and axle bevel gear from the differential housing.



(9) Force out slotted pins (4EA).



......

Pull spider shafts (4EA) and remove the releasing spider gears with the thrust washers from the differential housing.



7809AX99

① Remove the axle bevel gears and the shims behind.



7809AX100

② Support the crown wheel and force out the differential housing.



2) ASSEHBY

(1) Assembly differentials

Assembly multi-disk differential lock

 Mount two adjusting screws and press the heated crown wheel onto the differential housing until contact is obtained.

Adjusting screws 5871 204 040

② Insert disk and thrust washer into the differential housing



7809AX102



7809AX103

③ Insert axle bevel gear.



809AX104

- ④ Insert spider gears with thrust washers into the differential housing and fix them with the spider shaft.
- * Thrust washers must be positioned with the tabs (see arrow 1) in the recesses of the differential housing.

Pay attention to radial installation position of the spider shafts (fixing holes, arrow 2).



- (5) Fix spider shafts with slotted pins (2 pieces / hole).
- * Press the slotted pins with 180° offset openings into flush position.



7809AX106

6 Mount second axle bevel gear and thrust washer.



7809AX107

- ⑦ Mount disk and fix it with hexagon screws.
 - Tightening torque (M10/10.9) : 5.1 kgf • m (36.9 lbf • ft)



Setting of disk package

- (8) Premount single parts according to the adjacent sketch.
 - 1 = Differential cover
 - 2 = Pressure piece
 - 3 = Disk
 - 4 = Cage
 - 5 = Lever(15EA)
 - 6 = End plate
 - 7 = Outer disks (optional)
 - 8 = Inner disks
- 9 Preload disk package with an axial force of F = 7 ton.

Then check the setting dimension $A = 15.5_{-0.2}$ mm from the mounting face of the differential cover to the plane face of the outer disk (see also below sketch).

* Any deviation from the specified setting dimension must be corrected with a corresponding outer disk.

Legend to sketch:

A = Setting dimension = 15.5 _{-0.2} mm







7809AX111

7809AX112

① Engage the snap ring (see arrow) into the annular groove of the disk carrier. Insert the premounted disk carrier onto the axle bevel gear.



7809AX113

- 12 Mount outer and inner disks.
- * For the number of disks and disk arrangement please refer to the parts manual.
- * Pay attention to the radial installation position of the disk package, as shown on the adjacent figure.

7809AX114





7809AX115

14 Mount cage and lever (15EA).



Insert pressure piece (see arrow) and install disk.



7809AX117

(6) Insert compression springs (6EA) into the differential cover.



7809AX118

1 Insert sliding sleeve.



7809AX119

Preload the compression springs by means of the press and engage the retaining ring into the annular groove of the sliding sleeve.



(9) Mount two adjusting screws and insert the differential cover by means of the lifting device.

Adjusting screws	5870 204 040
Inner extractor	5870 300 008
Eye nut	AA00 680 376



7809AX121

- ② Preload the differential by means of the press and bolt with **new** locking screws.
 - · Tightening torque (M16/12.9) : 40.7 kgf · m (295 lbf · ft)

Pressure piece AA00 694 360



7809AX122

- ② Heat both tapered roller bearings and insert until contact is obtained.
- * Adjust tapered roller bearing after cooling down.



7809AX123





(2) Assembly axle drive housing

% If crown wheel or input pinion are damaged, both parts must be jointly replaced.

In case of a new installation of a complete bevel gear set pay attention to an identical mating number of input pinion and crown wheel.

Determination of shim thickness to obtain a correct contact pattern

* The following measuring procedures must be carried out with utmost accuracy.

Inaccurate measurements lead to an incorrect contact pattern requiring an additional disassembly and reassembly of input pinion and differential.





③ Determine dimension III (bearing width).

Dimension III e.g. 63.60 mm

Calculation example A :

Dimension I	. 331.25 mm
Dimension II	- 265.00 mm
Dimension III	- 63.60 mm
Difference = shim	s = 2.60 mm



7809AX127

Reassembly of input pinion

 Undercool the external bearing outer ring and insert it into the axle drive housing until contact is obtained.

Driver tool	5870 050 007
Handle	5870 260 004



7809AX128

 \bigcirc Insert the determined shim e.g. s = 2.60 mm into the housing hole.



③ Undercool the internal bearing outer ring and bring it into contact position in the housing hole by using the assembly fixture.

Assembly fixture

AA00 623 955



④ Heat the tapered roller bearing and insert it into the input pinion until contact is obtained.



Setting of rolling torque of input pinion bearing 0.1~0.5 kgf·m (without shaft seal ring)

- (5) Insert spacer (e.g. s = 7.13 mm).
- * According to our experience the necessary rolling torque is obtained when reusing the spacer which has been removed during disassembly (e.g. s = 7.13 mm).

A later check of the rolling torque, however, is absolutely necessary.

⑥ Insert the preassembled input pinion into the axle drive housing and insert the heated tapered roller bearing until contact is obtained.







7809AX133

- ⑦ Press the protection plate onto the input flange (see arrow) until contact is obtained.
- * Do not fit the shaft seal ring until the contact pattern has been checked.



- 8 Insert input flange and fix it by means of disk and slotted nut.
 - Tightening torque :

122 kgf \cdot m (885 lbf \cdot ft)

Wrench	5870 401 093
Fixing device	AA00 695 905
Clamping device	870 240 002

- * Preliminarily mount slotted nut without Loctite.
- * While tightening rotate the input pinion several times in both directions.
- ④ Check rolling torque (0.15~0.51 kgf·m without shaft seal ring).
- * When installing new bearings try to achieve the upper value of the rolling torque.
- * In case of deviations from the necessary rolling torque correct with a corresponding spacer (figure AX132, page 3-240) as specified below.

Insufficient rolling torque - install thinner spacer ring.

Excessive rolling torque - install thicker spacer ring.

10 Mount threaded connection.

Tightening torque :

10.2 kgf \cdot m (73.8 lbf \cdot ft)





7809AX136


(1) Mount oil tube.

Tightening torque :

10.2 kgf · m (73.8 lbf · ft)



7809AX138

12 Grease O-rings (see arrows) and insert them into the annular grooves of the piston.



7809AX139

(13) Insert piston (see arrow) into the bearing housing until contact is obtained.



7809AX140

Determination of shims for setting of bearing rolling torque (differential housing) and backlash (bevel gear set)

- Determine the required shims on the basis of the read value (deviation/test dimension) and the corresponding specifications of the table below: (KRS – SET – RIGHT) (KRS = bevel gear set):
 - 1 Deviation see crown wheel rear side.

The test dimension 108 is stamped into the crown wheel rear side. If no + or deviation is indicated, this value corresponds to the actual value 0 in the table below. According to this value, the required shims are allocated in the table below.

* Any + or - deviation of the test dimension caused by production is also marked on the crown wheel rear side (e.g.- 20 or - 10 or 10 or 20).

In accordance with this deviation, the required shims are allocated in the table below.

Legend to sketch:

- 1 = Bearing housing
- 2 = Shim (crown wheel side)
- 3 = Shim (differential carrier side)
- 4 = Axle drive housing



7809AX141



7809AX142

Shims for differential						
Crow wheel marking	- 30	- 20	- 10	0	10	20
Deviation	- 0.3	- 0.2	- 0.1	0	0.1	0.2
Shim diff cage side shim thickness	1.1	1.2	1.3	1.4	1.5	1.6
Shim P/No.	ZGAQ-03681	ZGAQ-03676	ZGAQ-03677	ZGAQ-03678	ZGAQ-03679	ZGAQ-03680
Shim crown wheel side shim thickness	1.7	1.6	1.5	1.4	1.3	1.2
Shim P/No.	ZGAQ-03687	ZGAQ-03686	ZGAQ-03685	ZGAQ-03684	ZGAQ-03683	ZGAQ-03682

(2) Insert the determined shim (e.g. s = 1.4) mm) into the hole of the axle drive housing and reset until contact with the bearing outer ring is obtained.



7809AX143

3 Cover some drive and coast flanks of the crown wheel with marking ink. Then insert the premounted differential into the axle drive housing.

Inner extractor	5870 300 008
Eye nut	AA00 680 376



7809AX144

(4) Insert the determined shim (e.g. s = 1.4) mm) into the bearing housing and reset the bearing outer ring until contact is obtained.



7809AX145

(5) Place the premounted bearing housing onto the axle drive housing by means of the lifting device.

Inner extractor	5870 300 008
Eye nut	AA00 680 376

* Preliminarily mount the bearing housing without O-ring.



- ⁽⁶⁾ Fix the bearing housing by means of cylindrical screws (3EA).
 - Tightening torque (M12/10.9) :

5.1 kgf \cdot m (36.9 lbf \cdot ft)



7809AX147

Leakage test of lock

- ⑦ Pressurize the lock (p = 1 bar), close shut-off valve and remove air line.
- % No noticeable pressure loss is allowed to occur within 10 sec.



7809AX148

(8) By rotating the input flange, roll crown wheel over the input pinion in both directions several times.

Then remove the bearing housing again and lift the differential out of the axle drive housing.

Compare the obtained contact pattern with contact pattern.

- In case of any contact pattern deviation, a measuring error was made when determining the shim (Figure AX129, page 3-239), which must be corrected by all means.
- ④ After the contact pattern check insert the differential again into the axle drive housing.





Reassembly of shaft seal ring (figure AX151~153)

10 Loosen slotted nut and pull the input flange from the input pinion.

Wrench	5870 401 093
Fixing device	AA00 695 905
Clamping device	5870 240 002



7809AX151

1 Mount the shaft seal ring with the seal lip showing to the oil chamber.

Driver tool AA00 623 986

- * The exact installation position of the shaft seal ring is obtained when using the specified driver tool.
- * Wet the outer diameter of the shaft seal ring with spirit directly before installation and fill the space between seal and dust lip with grease.



7809AX152

12 Insert input flange and finally tighten by means of disk and slotted nut.

· Tightening torque :

122 kgf \cdot m (12.5 lbf \cdot ft)

Wrench	5870 401 093
Fixing device	AA00 695 905
Clamping device	5870 240 002

- * Cover the thread of the slotted nut with loctite #262.
- 13 Grease O-ring (see arrow) and insert it into the annular groove of the bearing housing.







- Insert the bearing housing by means of the lifting device and finally tighten it with cylindrical screws.
 - · Tightening torque (M12/10.9) :
 - 5.1 kgf · m (36.9 lbf · ft)



7809AX155

(5) Grease O-rings (see arrows) and insert them on both sides of the axle drive housing.



7809AX156

(6) Mount two adjusting screws and bring axle drive housing in contact position with the axle housing by using the lifting device.

Then fix the axle drive housing with hexagon screws.

· Tightening torque (M20/10.9) :

* After mounting the axle drive housing unbolt the support until contact is obtained.



(3) Assembly axle housing

① Mount both fittings. \cdot Tightening torque : 3.67 kgf \cdot m (26.6 lbf \cdot ft)



7809AX158

2 Mount brake tube.

 \cdot Tightening torque : 10.2 kgf \cdot m (73.8 lbf \cdot ft)



7809AX159

③ Mount two adjusting screws and bring the axle housing into contact position with the axle drive housing by using the lifting device.

Then fix the axle housing by means of hexagon screws.

 \cdot Tightening torque (M20/10.9) :

57.1 kgf \cdot m (413 lbf \cdot ft)

Adjusting screws (M20) 5870 204 024

* After assembling the axle housing secure the axle with clamping brackets.



7809AX160

(4) Aeassembly output and brake

① Pull in wheel stud into the output shaft until contact is obtained.

Wheel stud puller - basic tool

Insert (M22x1.5)

obtained.

5870 610 001 5870 610 002

Special tool may only be used for repair solution when exchanging individual wheel studs with mounted output shaft. When using a new output shaft, mount the wheel studs with the press.

② Heat tapered roller bearing and insert it into the output shaft until contact is



7809AX28

7809AX29

② Wet O-ring of the slide ring seal and locating hole with spirit.

Snap **new** slide ring seal (1) into the output shaft.

Then mount **new** slide ring seal (part 2) accordingly into the brake housing.

- For the installation position of the seal please also refer to sketch AX34, page 3-251.
- * The surface of the slide ring seal may not have any grooves, scratches or other types of damage. Take care that the sealing surface is parallel to the housing face.

The O-rings must be mounted evenly into the locating hole and must not bulge out of the hole. Risk of injury - Metal rings have extremely sharp edges. Wear protective gloves.



7809AX30



- ③ Insert the premounted brake housing by means of the lifting device over the output shaft until contact is obtained.
- Before clamping the seal rings to installation dimension, clean the sliding surfaces and apply an oil film. We recommend to use a leather cloth soaked with oil.
- ④ Insert back-up rings and grooved rings into the annular grooves of the brake housing (see arrows).
- ※ Pay attention to the installation position; please also refer to sketch AX34, page 3-251.



7809AX31



7809AX32

 Clean the annular groove of the brake housing with spirit.
 Then insert the guide ring into the annular groove (see also the following sketch) and fix it with loctite #415 at its

extremities (see arrows).

- * The full circumference of the guide ring must be in an exact contact position.
- We upon installation the orifice of the guide ring must show upwards (12 o'clock).



Legend to sketch:

- 1 = Brake housing
- 2 = Guide ring
- 3 = Back-up ring
- 4 = Grooved ring
- 5 = Grooved ring
- 6 = Back-up ring
- 7 = Slide ring seal
- 8 = Output shaft



⑥ Insert the piston into the brake housing and carefully install with the fixing device until contact is obtained.

Fixing device

AA00 680 530

- Sufficiently oil seal surface of piston/ back-up rings, grooved rings and guide ring (W-10 oils to be used).
- ⑦ Insert cup spring into the piston with the convex side showing upwards.





7809AX36

- ⑧ Insert disk and fix it by means of hexagon screws.
 - · Tightening torque (M8/10.9) :
 - 3.47 kgf · m (25.1 lbf · ft)



7809AX37

- (9) Mount outer and inner disks.
- * For the number of disks and the disk arrangement please refer to the relating spare parts list.

10 Insert end plate.



7809AX38



7809AX39

Setting of installation dimension 57.25~ 57.79 mm

 Measure installation dimension from the mounting face of the brake housing to the front face of the end plate.

Installation dimension e.g 57.50 mm

Any deviation from the necessary installation dimension must be corrected with an appropriate outer disk (see spare parts manual).



7809AX40

Press stop bolt into the cover until contact is obtained.

Then insert the premounted cover into the planetary carrier until contact is obtained.

Legend to sketch:

- 1 = Stop bolt
- 2 = Cover
- 3 = Planetary carrier
- Insert the cylindrical roller bearing into the planetary gear – for this purpose press the cylindrical roller bearing through the packaging sleeve until the snap ring engages into the annular groove of the planetary gear.
- * Use packaging sleeve to facilitate assembly.
 - 1 = Cylindrical roller bearing
 - 2 = Packaging sleeve
 - 3 = Snap ring
 - 4 = Planetary gear
- Heat bearing inner rings and insert the premounted planetary gears with large radius facing the planetary carrier (downwards) until contact is obtained.
- * Adjust bearing inner rings after cooling down.

Then fix planetary gears by means of retaining rings.

(5) Heat tapered roller bearing and install it to the planetary carrier until contact is obtained.







7809AX163



7809AX164

(6) Wet front face (contact face bearing inner ring, arrow 1) and profile (teeth, arrow 1) in the output shaft with anticorrosive agent.



7809AX41

- ① Align disk package centrally and radially. Then insert the planetary carrier by means of the lifting device into the teeth of the output shaft until contact is obtained.
 - Rear axle (planetary carrier with 3 planetary gears)
 Inner extractor
 5870 300 019
 Eve bolt
 5870 204 073

	Lyo solt	00/0 20/0/0
•	Front axle (planetary	carrier with 4
	planetary gears)	
	line ou audua atau	

Inner extractor	5870 300 008
Eye nut	AA00 680 376



7809AX42

() Pivot output 90°.

Insert disk and fix planetary carrier with **new** locking screws.

Tighten locking screws successively with a tightening torque of 20.4 kgf · m (147.5 lbf · ft).

Then retighten the locking screws successively with a tightening torque of 51 kgf \cdot m (369 lbf \cdot ft).



(19 Install O-ring (see arrow) to the cover.



7809AX44

② Insert the cover into the output shaft until contact is obtained.



7809AX45

Set the axial play of the sun gear shaft $0.5 \sim 2.0 \text{ mm}$

② Determine dimension I, from the mounting face of the brake housing to the front face of the stop bolt.

Dimension I e.g	58.60 mm
Gauge blocks	5870 200 066
Straightedge	5870 200 022

- ② Insert stub shaft into the teeth of the axle bevel gear until contact is obtained.
- ※ Pay attention to the installation position; mount the stub shaft with the long teeth showing to the differential.





7809AX47

2 Insert the sun gear shaft until contact is obtained.



7809AX48

23 Measure dimension II, from the front face of the sun gear shaft to the mounting surface of the axle housing.

Difference = shim e.g.	s = 1.00 mm
Required axial play e.g	1.00 mm
Difference	2.00 mm
Dimension II	<u>- 56.60 mm</u>
Dimension I	58.60 mm
Calculation example :	
Straightedge	5870 200 022
Dimension II e.g.	56.60 mm

24 Insert sun gear shaft into the planetary carrier.



7809AX49



25 Fix determined shim e.g. s = 1.00 mm with grease into the sun gear shaft.



② Fix O-ring (see arrow) with grease into the countersink of the brake housing.



⑦ Grease O-ring (see arrow) and install it to the axle housing.



7809AX53

- Mount two adjusting screws and use the lifting device to bring the output into contact position with the axle housing. Then fix the output by means of hexagon screws.
 - \cdot Tightening torque (M20/10.9) ; 57.1 kgf \cdot m (413 lbf \cdot ft)

Adjusting screws (M20)	5870 204 024
Load-carrying device	AA00 685 875

- * Fix load carrying device with wheel stud.
- 29 Mount breather (see arrow).





- ③ Check brake hydraulics for leakages.
- Before starting the test, completely breathe the brake hydraulics. Then pressurize the brake temporarily

(5EA) with p = 100 bar max.

High-pressure test :

Build up test pressure $p = 100_{-10}$ bar max. and close connection to HP pump via shut-off valve.

A pressure drop of max. 2 % (2 bar) is permissible during a 5 minute testing time.

Low-pressure test :

Reduce test pressure p = 5 bar and close shut-off valve.

No pressure drop is allowed during a 5 minute testing time.

Test media :

Engine oils SAE 10-W

HP pump	5870 287 007
Clutch	0501 207 939
Reduction (M18x1.5)	5870 950 161
Oil collector bottle	5870 286 072

③ Check operability of differential hydraulic lock

Build up pressure p = 20 bar max. and close connection to HP pump via shut-off valve.

Lock on:

When rotating the input flange, both outputs must have the same direction of rotation.

Lock off:

When rotating the input flange one side holds or has the opposite direction of rotation.

Prior to putting the axle into operation, fill it with oil according to the related lubrication and maintenance instructions.



7809AX56



7809AX165

Group	1	Structure and Function	4-1
Group	2	Operational Checks and Troubleshooting	4-29
Group	3	Tests and Adjustments	4-36
Group	4	Disassembly and Assembly	4-38

SECTION 4 BRAKE AND FAN SYSTEM

GROUP 1 STRUCTURE AND FUNCTION

1. OUTLINE

The variable displacement piston pump supplies the hydraulic oil that is required in order to operate the brake and the hydraulic fan system. Oil flows from pump to the cut-off valve.

The cut-off valve controls the flow of oil from the pump to the brake accumulators and also controls the flow of oil to the hydraulic fan motor.

The cut-off valve contains a priority valve. The brake system has priority. The oil flows to the brake accumulators while the accumulators are charged. After the accumulators are fully charged, the oil then flows to the hydraulic fan system.

The accumulator has pre-charged gas and an inlet check valve to maintain a pressurized volume of oil for reserving brake system.

The oil through the accumulator flows to the brake valves. The brake valve is a closed center design, dual circuit operated by a pedal.

The front and rear brakes will operate simultaneously with only one brake pedal depressed.

The hydraulic fan system is used to meet the cooling requirements. The hydraulic fan system controls the fan speed through the pump output pressure. The desired pressure level can be set by varying the solenoid current.

The hydraulic fan system contains directional valve that reverses the direction of fan.

The brake and hydraulic fan system contains the following components :

- · Fan & brake pump
- \cdot Cut-off valve
- · Brake valve
- · Accumulators
- · Pressure sensors and switch
- · Fan motor
- · Directional valve

FULL POWER HYDRAULIC BRAKE SYSTEM

ADVANTAGES - The full power hydraulic brake system has several advantages over traditional brake actuation systems. These systems are capable of supplying fluid to a range of very small and large volume service brakes with actuation that is faster than air brake systems. Figure represents a time comparison between a typical air/ hydraulic and full power hydraulic brake actuation system.

Full power systems can supply significantly higher brake pressures with relatively low reactive pedal forces. The reactive pedal force felt by the operator will be proportional to the brake line pressure being generated.

This is referred to as brake pressure modulation.

Another key design feature of full power systems is the ability to control maximum brake line pressure. In addition, because these systems operate with hydraulic oil, filtration can be utilized to provide long component life and low maintenance operation.

Because these systems are closed center, by using a properly sized accumulator, emergency power-off braking that is identical to power-on braking can be achieved. These systems can be either dedicated, where the brake system pump supplies only the demands of the brake system or non-dedicated, where the pump supplies the demands of the brake system as well as some secondary down stream hydraulic device.

Another important note is that all seals within these system must be compatible with the fluid medium being used.

Response time Full power brake actuation VS Air/Hydraulic brake actuation



2. HYDRAULIC CIRCUIT



980A4BS01

- 3 Fan & brake pump
- 9 Fan motor
- 10 Directional valve
- 11 Oil cooler

- 28 Cut-off valve
- 29 Accumulator
- 30 Pressure sensor
- 31 Brake valve
- 32 Pressure switch
- 33 Hydraulic tank
- 47 Filter assy

1) SERVICE BRAKE RELEASED



980A4BS02

When the pedal of brake valve (31) is released, the operating force is eliminated by the force of the spring, and the spool is returned.

When the spool removes up, the drain port is opened and the hydraulic oil in the piston of axles return to the tank (33).

Therefore, the service brake is kept released.

2) SERVICE BRAKE OPERATED



980A4BS03

When the pedal of brake valve (31) is depressed, the operating force overcomes the force of the spring, and is transmitted to the spool. When the spool moves down, the inlet port is opened, and at the same time the hydraulic oil controlled the pressure level by the cut-off valve (28) enters the piston in the front and rear axles. Therefore, the service brake is applied.

3) PARKING BRAKE RELEASED



980A4BS04

When the parking brake switch is pressed A position, the solenoid value is energized and the hydraulic oil controlled the pressure level by the cut-off value enters the parking brake. It overcomes the force of the spring and pushes the piston rod. This releases the brake.

Therefore, the hydraulic oil pressure is applied to the parking brake piston through the solenoid valve and the parking brake is kept released.

4) PARKING BRAKE OPERATED



980A4BS05

When the parking brake switch is pressed B position, the solenoid valve is deenergized and the valve open the drain port.

At the same time, the hydraulic oil in the parking brake return to the tank through the solenoid valve. When the piston rod is returned by the force of the spring, the parking brake is applied.

5) FAN MOTOR OPERATED



980A4BS06

When the brake accumulators are fully charged, the priority valve switches position and the oil is directed to hydraulic fan motor through directional valve (10). The flow of the oil causes fan motor (9) to rotate the fan blade. The rotation of the fan forces cool air to flow through the cooler.

6) DIRECTIONAL VALVE OPERATED



980A4BS07

When the cooling fan reverse mode is selected manual or automatic mode, the solenoid valve in the directional valve (10) is energized and the flow of the oil is changed. The rotation of the fan is reversed to clear the radiators.

3. FAN AND BRAKE PUMP

1) STRUCTURE







Port	Port name	Port size
В	Delivery port	SAE 3/4"
S	Suction port	SAE 1 1/4"
L	Drain port	3/4-16UNF-2B

7809A4BS30

2) OPERATION



7609A4BS31

The pump is a variable displacement piston pump. This pump has a maximum delivery pressure of 250 kgf/cm². The axial piston type pump is used to supply oil flow to the cut off valve. The oil is pressurized by the movement of rotary group in the pump.

When the engine is in operation, the drive shaft (1) is driven by the gears in the engine with rotary group. There are nine piston assemblies (2) in rotary group.

Each piston inside cylinder (5) is held against swashplate (3) by piston shoe (4). Swashplate can be any angle between the maximum angle and the neutral angle. The angle of swashplate determines the amount of oil that is pushed out of each cylinder.

The neutral angle is perpendicular with drive shaft (1). When swashplate(3) is at the neutral angle, pistons (2) do not move in and out of rotating cylinder. Therefore, no oil is drawn into the pump and no oil is pushed out of the pump. The pump has zero displacement and zero flow.

When swashplate (3) is at the maximum angle, pistons (2) move in and out of cylinder. The movement of the pistons allows the maximum amount of oil to be drawn into the cylinder. The pump will produce the maximum displacement.

The swashplate (3) angle is controlled by command current signal to control valve solenoid (6). The pump output pressure level can be set by the solenoid current. When the solenoid current signal drops toward a zero value, the pump output pressure level is the maximum.

*** FAN SYSTEM OPERATION**

When the brake system pressure is below minimum pressure (125 ± 5 bar), it has the high priority than the fan system. Pump flow to the fan motor is blocked while brake system is charged.

However, The fan system has controlled pump when the brake system pressure is charged.

The fan speed solenoid valve (6) controls the pressure (fan speed) of pump when the brake system is fully charged.

The fan speed solenoid valve (6) is a proportional solenoid. As current to the fan speed solenoid increases, pump output pressure decreased, therefore, the fan motor rotates slower.

When the current of the fan speed solenoid valve (6) is reduced, the output pressure is increased. The pump will be stroked and the pump will send maximum flow to the fan motor, thus, the fan motor is turning faster.

4. BRAKE VALVE

1) STRUCTURE



 \cdot Brake pressure specification : 80 \pm 5 bar (1160 \pm 70 psi)

2) OPERATION

(1) Purpose

The purpose of the brake valve is to sensitively increase and decrease the braking pressure when the brake pedal is actuated.

(2) Ready position

When the braking system is ready for operation, its accumulator pressure acts directly on ports (P1, P2) of the brake valve. A connection is established between ports (BR1, BR2) and ports (T1, T2) so that the wheel brakes ports (BR1, BR2) are pressureless via the returns ports (T1, T2).

(3) Partial braking

When the brake valve is actuated, an amount of hydraulic pressure is output as a ratio of the foot force applied.

The spring assembly beneath base is designed in such a way that the braking pressure changes depending on the angle. In the lower braking pressure range, the machine can be slowed sensitively.

When the braking process is commenced, the upper spool is mechanically actuated via spring assembly, and the lower spool is actuated hydraulically by spool. As spools move downward, they will first close returns (T1, T2) via the control edges, thus establishing a connection between accumulator ports (P1, P2) and ports (BR1, BR2) for the wheel brake cylinders. The foot force applied now determines the output braking pressure. The control spools are held in the control position by the force applied (Spring assembly above the spools and the hydraulic pressure below the spool (Balance of forces).

After output of the braking pressure, spools are in a partial braking position, causing ports (P1, P2) and ports (T1, T2) to close and holding the pressure in ports (BR1, BR2).

(4) Full braking position

When pedal is fully actuated, end position of the brakes is reached and a connection established between accumulator ports (P1, P2) and brake cylinder ports (BR1, BR2). Returns (T1, T2) are closed at this point.

When the braking process is ended, a connection is once again established between brake cylinder ports (BR1, BR2) and return ports (T1, T2), closing accumulator ports (P1, P2).

The arrangement of spools in the valve ensures that even if one braking circuit fails the other remains fully operational. This is achieved by means of the mechanical actuation of both spools and requires slightly more pedal travel.

(5) Failure of a circuit

In the event of the lower circuit failing, the upper circuit will remain operational. Spring assembly will mechanically actuate spool.

In the event of the upper circuit failing, the lower circuit will remain operational since the lower spool is mechanically actuated by spring assembly and spool.

(6) Installation requirements

Return lines (T1, T2) must be connected directly to the tank.

The connecting lines must be installed is such a way as to permit proper bleeding.

(7) Maintenance of the brake valve

No special maintenance beyond the legal requirements is necessary.

When using high-pressure cleaners on the machine, please make sure that the water jet is not aimed directly at the brake valve (to prevent damaging the bellows).

 \triangle For safety reasons the whole of the brake valve must be replaced if parts other than those listed above are damaged.

(8) Repair work

 \triangle When working on the braking system, always make sure that there is absolutely no pressure in the system. Even when the engine is switched off there will be some residual pressure in the system.

When doing repair work, make sure your environment is very clean.
 Immediately close all open ports on the components and on pipes using plugs.

(9) Replacing the complete actuating mechanism

Carefully clamp the unit vertically in a fixture. The actuating mechanism can be removed by taking out the three bolts. Make sure that spring assembly does not fall out. When installing the new actuating mechanism, make sure that spring assembly is fitted in the right order. Tighten the three bolts.





970A4BS32

- 1 Priority valve
- 2 Orifice
- 3 Orifice
- 4 Pressure control valve
- 5 Check valve
- 6 Coil, Solenoid valve
- 7 Directional valve

2) OPERATION

The pressure control valve (4) controls the minimum and maximum pressure of the braking system. When the service brake pressure is below the maximum pressure (125 ± 5 bar), the pressure control valve (4) is blocked and PS pilot pressure (brake priority pressure) increases.

As soon as PS pilot pressure raises up above 15 bar, pump controller current is reduced by MCU (pressure sensor detects brake priority pressure, and pump supply flow and pressure in order to meet the brake system).

The pressure sensor at PS port detect whether brake system needs to be charged.

Priority valve spring and pilot pressure (brake priority pressure) pushed priority spool to the upward.

Therefore, full pump flow directly goes to the brake system in order to satisfy the demand of the brake system.

Pump flow goes through the following components : orifice (2), check valve (5), directional valve (7). Brake failure pressure sensor at G1 port detects pressure in the brake accumulators.

When the pressure is lower than 100 bar, the sensor activates warning lamp on the cluster in order to check brake system.

When brake system pressure reaches the maximum brake system pressure (150 bar \pm 5 bar), pressure control valve (4) opens, pilot pressure (brake priority pressure) of priority valve is low by draining the spring side of priority valve (1) to hydraulic tank through valve (4).

6. BRAKE ACCUMULATOR

1) STRUCTURE



	3111-40020	
Item	(itom20)	
	(1129)	
Diameter	167 mm	
Mounting height	219 mm	
Norminal volume	2.0 ℓ	
Priming pressure	50 kgf/cm ²	
Operating medium	Oil	
Operating pressure	Max 210 kgf/cm ²	
Thread	M22×1.5	
Priming gas	Nitrogen	
A Fluid portion	C Diaphragm	
B Gas portion	D Valve disk	

75794BS09

2) OPERATION

(1) Purpose

Fluids are practically incompressible and are thus incapable of accumulating pressure energy. In hydropneumatic accumulators, the compressibility of a gas is utilized to accumulate fluid. The compressible medium used in the accumulators is nitrogen.

In braking systems, the purpose of the accumulators is to store the energy supplied by the hydraulic pump. They are also used as an energy reserve when the pump is not working, as a compensator for any losses through leakage, and as oscillation dampers.

(2) Operation

The accumulator consists of a fluid portion (A) and a gas portion (B) with a diaphragm (C) as a gas-tight dividing element. The fluid portion (A) is connected to the hydraulic circuit, causing the diaphragm accumulator to be filled and the gas volume to be compressed as the pressure rises.

When the pressure falls, the compressed gas volume will expand, thus displacing the accumulated pressure fluid into the circuit.

The diaphragm bottom contains a valve disk (D) which, if the diaphragm accumulator is completely empty, closes the hydraulic outlet, thus preventing damage to the diaphragm.

(3) Installation requirements

The accumulators can be fitted in the hydraulic circuit, directly on a component or in blocks on suitable consoles.

They should be fitted in as cool a location as possible. Installation can be in any position.

(4) Maintenance of the accumulator

No special maintenance beyond the legal requirements is necessary.

The accumulator should be checked annually. It should be replaced if the initial gas pressure has fallen by more than 30% (please refer to Performance testing and checking of the accumulator).

(5) Disposal of the accumulator

Before the accumulator is scrapped, its gas filling pressure must be reduced. For this purpose, drill a hole through gas chamber (B) using a drill approx. 3mm in diameter. The gas chamber is located on the side opposite the threaded port above the welding seam around the center of the accumulator.

* Wear safety goggles when doing this job.

(6) Performance testing and checking of the accumulator

The accumulator is gradually pressurized via the test pump; until the initial gas pressure is reached, the hydraulic pressure in the accumulator will rise abruptly. This is apparent from gauge **M**. If the initial gas pressure is more than 30% below the prescribed value, the accumulator needs to be replaced. If the measuring process needs to be repeated, wait for intervals of 3 minutes between the individual tests. Any accumulator whose initial gas pressure is insufficient must be scrapped following the instructions under **Disposal of the accumulator**.

The amount of initial gas pressure can also be checked from the vehicle. Start the vehicle's engine. The pump will now supply oil to the accumulators. Until the initial gas pressure is reached, the hydraulic pressure in the accumulator will rise abruptly. This is apparent from the gauge in the cab. If the initial gas pressure is more than 30% below the prescribed value, that initial pressure lies outside the permissible range for **at least one** of the accumulators fitted in the vehicle. This accumulator can be traced only by using the method described above, i.e. all accumulators have to be individually tested. The accumulator whose initial gas pressure is insufficient must be replaced and scrapped following the instruction under **Disposal of the accumulator**.



75794BS10

(7) Repair work

- \triangle When working on the braking system, always make sure that there is absolutely no pressure in the system. Even when the engine in switched off there will be some residual pressure in the system.
- When doing repair work, make sure your environment is very clean. Immediately close all open ports on the components and on pipes using plugs.
- \triangle For safety reasons the accumulators need to be replaced as a whole if damaged.
7. PRESSURE SENSOR AND SWITCH

1) STRUCTURE



- Normally open

7609A4BS12

2) TECHNICAL DATA

ltem	Туре	Medium	G	H1 mm	H2 mm	Adjusting range kgf/cm ²	Actuating pressure kgf/cm ²	Voltage V
Parking pressure sensor	-	Oil	PF 1/4"	45	12.5	0 ~ 200	100 ± 5	Max 30
Charging pressure sensor	-	Oil	PF 1/4"	45	12.5	0 ~ 200	100 ± 5	Max 30
Brake priority pressure sensor	-	Oil	PF 1/4"	45	12.5	0 ~ 200	100 ± 5	Max 30
Brake stop pressure switch	NO	Oil	PF 1/4"	45	12.5	1 ~ 10	5 ± 1	Max 32

NO : Normally open

3) Tightening torque : 3.5 kgf \cdot m (25.3 lbf \cdot ft)

2) OPERATION

(1) Purpose

The pressure switches are used to visually or audibly warn the driver of the pressure within the system.

(2) Make contact / circuit closer

The pressure switch can be fitted in the braking system or directly on one of its components. The system pressure acts on an absorption area within the switch, making an electrical contact as the pressure on that area is increased. The resulting current is used to activate a warning facility, for instance.

(3) Break contact / circuit breaker

The pressure switch can be fitted in the braking system or directly on one of its components. The system pressure acts on a absorption area within the switch, breaking an electrical contact as the pressure on that area is increased. The current is now broken, e.g. to deactivate a warning facility.

(4) Installation requirements

No special measures need to be taken.

(5) Maintenance of the pressure switch

No special maintenance beyond the legal requirements is necessary. When using high-pressure cleaners on the vehicle, please make sure that the water jet is not directed at the pressure switch (corrosion of contacts).

(6) Repair work

- △ When working on the braking system, always make sure that there is absolutely no pressure in the system. Even when the engine is switched off there will be some residual pressure in the system.
- When doing repair work, make sure your environment is very clean. Immediately close all open ports on the components and on pipes using plugs.
- * For safety reasons the pressure switch needs to be replaced as a whole if damaged.

8. PARKING BRAKE SYSTEM

1) STRUCTURE



78094BS21

1 Housing

Pressure ring

Thrust bolt

2

3

- 4 Adjust screw
- 5 Bank of cup springs

6

- Piston
- 8 Lining pad

7

Lining pad

9 Gliding bolt

2) OPERATION

The two identical brake pads and slide freely on the guide bolt, which is fastened in the housing. The guide bolts are guided in an additional brake anchor plate which in turn is screwed onto the vehicle, i.e. its axle.

On actuation, the brake generates a clamping force at the brake lining pads, which cause a tangential force/braking moment to be generated at the brake disk, the extent of which depends on the coefficients of friction generated by the linings.

The clamping force is generated by the bank of cup springs, during which the piston is moved together with the adjusting screw, the thrust bolt and the brake pad towards the brake disk.

When the brake pad comes into contact with the brake disk, the reaction force shifts the housing onto the guide bolts until the brake pad is also pressed against the brake disk.

The brake is released by complete pre-tensioning of the bank of cup springs. During this process, through application of the necessary release pressure after overcoming the cup spring force, the piston must move back until it comes to rest against the pressure ring.

The clamping force diminishes with wear of the brake lining and brake disk. The brake must be adjusted at the latest at the times indicated by the adjusting specification followings.

3) MOUNTING AND BASIC SETTING REGULATIONS

Basic brake setting is required after mounting new brake lining plates or brake disks, as well as during all repair stages and in the event of insufficient braking performance.



100D7BS112

1 Thrust bolt

3

- Screw cap 4 5 Lock nut
- 2 Bank of cup springs Adjusting screw
- 6 Piston

- Even surface Ρ
- S Socket wrench

* All mounting and basic setting work must be carried out on the brake when cold.

(1) Mounting the brake

- ① Stand the vehicle on an even surface and secure against rolling away.
- ⁽²⁾ Release the screw cap.
- ③ Release the lock nut (size 24 or 30) and turn the adjusting screw anticlockwise using a size 8 or 10 socket wrench until the pressure bolt comes to rest against the even surface of the piston. In this status, the brake can be mounted onto the brake disk and fastened.

4 Mount the pressure connection again.

Apply the necessary release pressure to the brake until the bank of cup springs is completely pre-tensioned. Following carry out the following page basic setting regulation.

(2) Basic setting regulation

- ① Turn the adjusting screw manually clockwise until both brake pads make contact with the brake disk. Then it is not longer possible to turn the adjusting screw without exerting a major amount of force.
- ² Turn the adjusting screw anticlockwise in order to set the following rated clearances.

Adjusting screw	Clearance (mm)	Turns	
	Min.	1.0	2/5
M20 (SW 10)	Clearance	2.0	4/5
	Max.	3.0	1 1/5

- ③ Hold the adjusting screw in position with a hexagonal socket wrench and lock with lock nut.
- ④ Mount the screw cap and tighten as far as possible manually.
- $^{(5)}$ Mount the pressure connection in accordance with the instructions of the axle.
- * For bleeding the piston chamber use the socket spanner size 13 for the bleeding valve.

(3) Adjusting regulations

During this adjusting process, the parking brake must be released, i.e. the bank of cup springs must be completely pre-tensioned.

- ① Stand the vehicle on an even surface and secure against rolling away.
- ② Release the parking brake by using the required release pressure.
- ③ Release the screw cap and unscrew.
- ④ Release the lock nut (size 24 or 30) and turn the adjusting screw with socket wrench size 8 or 10 manually clockwise until the two brake pads make contact with the brake disk.
- (5) Turn the adjusting screw anti-clockwise and set the clearance specified in the above table.
- 6 Hold the adjusting screw in position with the hexagonal socket wrench and lock with the lock nut.
- ⑦ Mount the screw cap and tighten as far as possible manually.
- * Actuate the brake valve several times and check the braking efficiency of the parking brake on a slope.

4) EMERGENCY RELEASE OF THE PARKING BRAKE

After the failure of the pressure release the parking brake by using following manual procedure.



100D7BS117

1 Thrust bolt

3

- Screw cap
- Even surface Ρ
- S Socket wrench

- 2 Bank of cup springs Adjusting screw
- 5 Lock nut 6 Piston

4

- (1) The vehicle has to be secured against rolling away.
- (2) Release the screw cap and unscrew
- (3) Release the lock nut (size 24 or 30) and turn the adjusting screw with socket wrench size 8 or 10 manually counter-clockwise until the brake disc is free.
- A For the emergency release is an actuation torque of 40Nm respectively 70Nm required.
- (4) Mount the lock nut and the screw cap and tighten both as far as possible manually. (protection against dirt)
- A Now, the vehicle do not have any brake function. The vehicle must be secured against moving away with proper means. Before putting the vehicle into operation again, the brake has to be adjusted again. Refer to previous page. "Assembly and basic setting regulations".

5) MAINTENANCE AND REPAIR WORK

(1) Maintenance and exchange of brake pads

The brake pads themselves are maintenance free. All that is required here is a check for damaged parts, as well as inspection to ensure that the brake disk remains easy running.

The thickness of the brake lining must be subjected to a visual inspection at regular intervals, which depend on vehicle usage, but every six months at the latest. In the event of a minimal residual lining thickness, these intervals must be reduced accordingly in order to avoid major damage to the brake or disk.

Min. residual thickness 2.0 mm per lining pad (8 mm carrier plate thickness).



100D7BS113

- 1 Piston
- 2 Adjusting screw
- 3 Lock nut
- 4 Thrust bolt

- S Socket wrench
- S1 Screwdriver
- P Inside of the piston
- * Only original spare lining plates may be used. If any other spare parts are used, no warranty claims will be accepted either for the brakes or their functional characteristics.
- ${\rm (I)}$ Stand the vehicle on an even surface and secure against rolling away.
- 2 Release the parking brake by applying the required release pressure.
- \bigcirc Release the screw cap and unscrew.
- ④ Release the lock nut (size 24 or 30) and turn the adjusting screw with socket wrench size 8 or 10 manually clockwise until it lies flush with the inside of the piston.
- ^⑤ Press back the thrust bolt using a suitable screwdriver until it has contact with the piston.



100D7BS114

- 1 Guide bolt
- 2 Lining pad
- 3 Lining pad
- 4 Permanent magnet

- 5 Castellated nut
- 6a Safety splint
- 6b Safety clip
- 6 Depending on the free space available, release one of the two guide bolts, removing the safety splint, unscrewing the castellated nut and pulling the guide bolt out of the brake anchor plate. Now, the brake lining pads can be removed tangentially to the brake disk.
- In the event of minimal clearance, i.e. it is not possible for space reasons to exchange the brake lining plate in accordance with these instructions, the brake must be removed completely. To do this, pull both guide bolts out of the brake anchor plate.
- A Check the pressure hose. If the pressure hose is to short, it must be unscrewed to remove the brake. Before the pressure hose can be released the brake must be emergency released.
- \bigcirc Exchange the brake pads and insert the guide bolts into the brake anchor plate. If you have removed the complete brake you have to amount the brake on both guide bolt again, now.
- ⁽⁸⁾ Check both permanent magnets if they still have sufficient magnetic force to hold the brake lining plates. Should this not be the case, the permanent magnets must also be changed by using a suitable screw driver.
- ⁽⁹⁾ Secure the guide bolt with the castellated nut and the safety splint respective safety clip.
- After mounting new brake lining plates or their repair, the brake must be correctly set in accordance with the instructions "Adjusting regulations".

(2) Changing the seal



* Faulty seals must be exchanged in accordance with the instructions below.

- ${\ensuremath{\textcircled{}}}$ Stand the vehicle on an even surface and secure against rolling away.
- 2 Release the parking brake by applying the necessary release pressure.
- $\ensuremath{\textcircled{}}$ Belease the screw cap and unscrew.
- ④ Release the lock nut (size 24 or 30) and turn the adjusting screw with socket wrench size 8 or 10 manually counter clockwise until the adjuster screw is flush with the inner side of the piston.
- ⁽⁵⁾ Push back the thrust bolt until it has contact with the piston. Following actuate the hand brake valve (no pressure must be in the piston chamber). The bank of cup springs is now completely depressurized.
- 6 Unscrew the pressure hose and remove the brake.
- $\ensuremath{\mathbb{7}}$ Release the circlip and remove the pressure ring of the housing.
- \circledast Release the bank of cup spings and the piston.
- A Pay attention to the mounting direction of the seal rings, otherwise leaks can occur.
- **A** Use for mounting the new seal rings a suitable mounting needle with rounded edge. Be careful.

(9) Change all seals and mount the parts of the brake in other way round order. By mounting the piston, the sliding and sealing surfaces must be greased lightly using lubricating grease to DIN 51825. The dust protection cap is fitted with a vulcanized-in steel ring which is used to press it through the locating hole. For exchanging, "lever out" the ring using a suitable tool. The new dust protection cap must be pressed in with the aid of a suitable mounting ring and screw clamps or a lever press.

(2) General

Any discovered defects or damage to parts not listed here must naturally be repaired or replaced using original parts.

For any other information not contained in these instructions or for more detailed instructions, please contact HD Hyundai Construction Equipment dealer.

GROUP 2 OPERATIONAL CHECKS AND TROUBLESHOOTING

1. OPERATIONAL CHECKS

This procedure is designed so the mechanic can make a quick check of the system using a minimum amount of diagnostic equipment. If you need additional information, read **structure and function**, Group 1.

A location will be required which is level and has adequate space to complete the checks.

The engine and all other major components must be at operating temperature for some checks.

Locate system check in the left column and read completely, following the sequence from left to right. Read each check completely before performing.

At the end of each check, if no problem is found (OK), that check is complete or an additional check is needed. If problem is indicated (NOT OK), you will be given repair required and group location. If verification is needed, you will be given next best source of information:

Chapter 2 : Troubleshooting Group 3 : Tests and adjustments * Hydraulic oil must be at operating temperature for these checks (refer to page 6-54).

Item		Description	Service action
Parking brake capacity		Start engine.	OK Check completed.
check Seat belt must be worn	11 10 mph 40	Fasten seat belt.	
while doing this check to prevent possible injury		Release parking brake and put transmission in 2nd gear forward.	NOT OK Inspect parking brake. Go to group 3.
when machine stops suddenly.		Drive machine at 8 km/hr and switch parking brake ON.	
	Release	LOOK/FEEL : Machine must come to a stop within 2 meters (6 feet) when parking brake is engaged at 8 km/hr.	
		Transmission must shift to neutral.	
Parking brake	Release	Turn parking brake to ON.	OK
transmission lockout check		Place transmission in 1st forward.	Check completed.
Engine running.		Slowly increase engine speed to high idle.	NOT OK Go to transmission control circuit in section 3.
	~	LOOK : Machine must not move.	
	en la		

Item	Description		Service action
Service brake pump flow check * Hydraulic oil must be at operating temperature for the check. Engine OFF.		Stop engine. Operate brake pedal approximately 20 times. Start engine and run at low idle. Record number of seconds required for low brake pressure indicator lamp to go out. LOOK : Indicator lamp must go out in less than 4 seconds from time engine starts.	OK Check completed. NOT OK Check for brake circuit leakage. Go to next page. IF OK Install a cap on line connected to inlet of brake valve and repeat pump flow check.
		NOTE : Indicator will not come on approximately 1 second after starting engine.	If time does not decrease, check for worn brake pump.
Service brake capacity check Engine running.	OFF	Select clutch cut-off mode to OFF. Apply service brakes, release park brake and put transmission in 2nd forward. Increase engine speed to high idle. LOOK : Machine may not move or move at a very slow speed. Repeat check three times to ensure accurate results.	OK Check completed. NOT OK Check brake pressure. IF OK Inspect brake disk.

Item	Description		Service action
Brake accumulator precharge check		Start and run engine for 30 seconds.	OK Check completed.
* The axles and hydraulic oil must be at operating temperature for this		Stop engine and turn start switch to ON and wait 5 seconds.	NOT OK Make sure brake pedal is not binding and keeping brakes partially engaged.
check.		NOTE : Engine oil pressure lamp will be on due to no engine oil pressure.	
			Bleed brakes in group 3.
		Count the number of times the brake pedal can be fully depressed	Check brake system pressure.
		before the low brake pressure warning lamp comes ON.	NOT OK If light comes ON with
		LOOK : Warning lamp should not come ON in 1~5 applications.	engine running, accumulator has lost it's
		Start engine and operate at low idle.	charge. Inspect and recharge accumulator.
		Observe cluster while applying brake pedal with maximum force.	
		LOOK/LISTEN : Brake pressure indicator must not come ON.	
Brake system leakage		Start engine and wait 30 seconds.	OK
check		Stop engine.	Check completed.
		Wait 2 minutes.	NOT OK If brake leakage is
		Turn start switch to ON and wait 5 seconds.	indicated with brakes released, check leakage at
		LOOK : Brake oil pressure warning lamp must not come ON within 2 minutes after stopping engine.	accumulator inlet check valve and brake valve. If brake leakage is indicated with brakes applied, check for leakage at brake valve and brake pistons.
			Check individual component leakage.

Item	Description		Service action
Service brake pedal check		Slowly depress brake pedal. Listen for a hissing noise that indicates oil is flowing to brake pistons.	OK Check completed. NOT OK Inspect for debris under
		LISTEN/FEEL : A hissing noise must be heard when pedal is depressed.	ргаке редаі.
Service and parking brake system drag checks Engine running	Release	Position machine on gradual slope. Lower bucket approximately 50 mm (2 in) from ground. Release parking and service brakes. LOOK : Machine must move or coast. NOTE : If machine does not move, check brake pedals to be sure they fully release when feet are removed from pedals. Drive machine at high speed for about 5 minutes. Brake drag is indicated if brake areas in differential case are hot. NOTE : Observe parking brake. If disk is hot, parking brake drag is	OK Check completed. NOT OK Adjust park brake. NOT OK Check floor mat interfer- ence to pedal or debris build-up. IF OK Check for brake pressure when brake is released. Go to brake pressure test.
Clutch cut-off check	L mode	Select clutch cut-off mode to L mode. Release parking brake. Run engine at half speed in 1st forward. Firmly depress brake pedal. FEEL : Transmission must disengage when brake pedal is depressed at 30% of pedal stroke. NOTE : Clutch cut-off mode can be selected to operator preference to match your loading needs.	OK Check completed. NOT OK Adjust clutch cut-off mode.

2. TROUBLESHOOTING

1) SERVICE BRAKE

Diagnose malfunction charts are arranged from most probable and simplest to verify, to least likely, more difficult to verify. Remember the following steps when troubleshooting a problem :

Step 1. Operational check out procedure (see section 1)

Step 2. Operational checks (in this group)

Step 3. Troubleshooting

Step 4. Tests and adjustments (see group 3)

Problem	Cause	Remedy	
Poor or no brakes	Brake accumulator charge low.	Do brake accumulator check.	
	Brake pump standby pressure low.	Do brake pump standby pressure test.	
	Brake pressure low.	Do brake valve pressure test.	
	Air in system.	Bleed brakes.	
	Worn brake surface material.	Inspect brake surface material.	
	Leakage in brake valve.	Do brake valve leakage test.	
	Leakage in brake piston seal.	Check for an over filled differential. Apply brakes and check for leakage from check plug.	
Aggressive brakes	Internal restriction in circuit.	Remove lines and components.	
	Brake valve malfunction.	Disassemble and inspect.	
	Low oil level.	Check oil level.	
Brakes drag	Brake pedal not returning properly.	Inspect floor mat and pedal.	
	Debris holding valve partially open in brake valve.	Do brake valve pressure test.	
	Warped brake disk.	Inspect brake disk.	
	Stuck brake piston.	Repair.	
Brakes lock up	Brake valve malfunction.	Clean or replace brake valve.	

Problem	Cause	Remedy
Brakes chatter	Air in brake system.	Do brake bleed procedure.
	Worn brake surface material.	Inspect brake surface material.
	Wrong oil in differential.	Drain. Refill.
Hissing noise when brake pedal is held with engine stopped	Leakage in brake valve, or brake piston.	Do brake system leakage test.
Brake pressure warning light will not go out or	Malfunction in brake low pressure warning switch.	Replace switch.
stays on excessively long after start-up	Brake accumulator pressure too low.	Recharge accumulator.
	Low brake pump standby pressure setting.	Do brake pump standby pressure test.
	Leakage in pressure reducing manifold block.	Do pressure reducing valve manifold leakage test.
	Leakage in brake system.	Do brake system components leakage tests.
	Worn brake pump.	Do brake pump flow test.
	Leakage in parking brake solenoid.	Do parking brake pressure test.

2) PARKING BRAKE MALFUNCTIONS

Problem	Cause	Remedy
Brake will not hold	Pads not adjusted correctly.	Adjust parking brake.
	Malfunctioning parking brake solenoid.	Inspect and replace.
	Worn brake disk and / or brake pads.	Disassemble, inspect, repair.
	Brake piston hangs up in bore.	Remove and inspect. Repair.
Brake disk overheats	Pads out of adjustment.	Adjust parking brake.
	Brake not released.	Release parking brake. Disassemble, inspect brake. Repair if necessary. Inspect for loosen or broken lines between brake pressure switch and indicator on dash.
Parking brake indicator in monitor does not come on when brake applied	Faulty wiring or switch.	Inspect for loose or broken lines between brake pressure switch and indicator on dash. Inspect for a faulty indicator on dash. Replace if necessary.
Brake will not apply	Pads out of adjustment.	Adjust parking brake.
	Malfunctioning wiring, switch, or solenoid.	Check electric circuit.
	Restriction between brake valve and brake.	Remove hose and inspect. Replace.

GROUP 3 TESTS AND ADJUSTMENTS

1. PARKING BRAKE PERFORMANCE

1) MEASUREMENT CONDITION

- (1) Tire inflation pressure : Specified pressure
- (2) Road surface : Flat, dry, paved surface with 1/5 (11°20') gradient.
- (3) Machine : In operating condition

Item	Standard valve
Parking brake performance	Keep machine on 20% (11°20') gradient

2) MEASURING PROCEDURE

- Start the engine and drive the machine straight up a 1/5 gradient with the bucket unloaded.
- (2) Depress the service brake, place the gear selector lever in neutral, then stop the engine.
- (3) Turn the parking brake switch ON, then slowly release the service brake pedal and the machine must be kept stopped.
- * The measurement must be made with the machine facing either up or down the slope.

2. ADJUSTMENT OF PARKING BRAKE

- (1) External brake inspection · Inspect for wear of brake pad
- (2) Refer to the PARKING BRAKE SYSTEM on the page 4-21.







3. HYDRAULIC BRAKE BLEEDING PROCEDURE

▲ Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.

Doctors unfamiliar with this type of injury should reference a knowledgeable medical source.

Two people are required to bleed brake system oil, one to operate brake valve and other to open and close bleed screws.

- 1) Install frame locking bar. Engage parking brake.
- Put a clear plastic tube on bleed screw to route low to hydraulic oil tank filler tube or container (A).
- 3) Start engine and run at low idle.
- 4) Push and hold brake pedal down until brake bleeding procedure is complete.
- If bubbles continue for more than 2 minutes, stop bleeding procedure. Check for and correct problem, then continue.
- Open on bleed screw on differential and axle assembly until hydraulic oil starts to flow. Close bleed screw when oil is free of air. Release brake pedal.
- 6) Repeat steps 1)~5) for each bleed screw.
- 7) Push either brake pedal and hold down.
- 8) Check hydraulic oil level.



GROUP 4 DISASSEMBLY AND ASSEMBLY

1. FAN AND BRAKE PUMP

1) STRUCTURE



- 1-101 Piston
- 1-102 Cylinder
- 1-104 Retaining plate
- 1-106 Retaining ball
- 1-107 Spring
- 1-109 Pressure pin
- 1-110 V-ring
- 1-111 Back-up plate
- 1-2 Control plate
- 2 Pressure spring
- 3 Stop

- 6 Port plate
- 7 Swash plate
- 8 Drive shaft
- 10 Spring
- 12 Adjustment shim
- 14 Stop ring
- 15 Tapered roller bearing
- 16 Tapered roller bearing
- 17 Liner bearing
- Liner bearing 18
- 19 Flat screw

7609A4BS11

- 21 O-ring
- 24 Kantseal ring
- 25 Retaining ring
- 27 Socket screw
 - 31 Plug
- 33 Cylinder pin
- 41 Control valve
- 42 Gasket
- 43 Socket screw
- Control piston 51
- 52 Locking screw

2) GENERAL REPAIR GUIDELINES

- ※ Observe the following guidelines when carrying out repairs on hydraulic pumps.
- (1) Close off all openings of the hydraulic unit.
- (2) Replace all of the seals.Use only original spare parts.
- (3) Check all sealing and sliding surfaces for wear.
- Re-work of the sliding surfaces by using, for example abrasive paper, can damage the surface.
- (4) Fill the hydraulic pump with hydraulic oil before commissioning.

3) SEALING THE DRIVE SHAFT

- 1 Retaining ring 2 Shaft seal
- 3 Bearing 4 Stop ring



(1) Protect the drive shaft.Wrap the drive shaft with tape.Remove the retaining ring.Remove shaft seal to front.



- Change the shaft seal and check its sliding surface (drive shaft) and housing, grease the sealing ring.
 Visual check shaft seal and housing.
- 73096WE62
- (2) Assembling of the sealing ring carefully down to the stop ring.



- (3) Assemble the retaining ring (circlip).
- X Visual check to ensure that the circlip is correctly located in the groove.



4) SEALING THE CONTROL VALVE

(1) Remove the control valve.



(2) Measure dimension A and note down.Check sealing surface (1).Replace gasket (2).



(3) Assemble control valve.

Tighten the bolts.

(4) Check dimension A.

- Tightening torque : 1.58 kgf · m (11.4 lbf · ft)
- T609A6WE101



- **5) INSPECT HINTS**
- (1) Renew all bearings.

(2) Check :

- 1 Wear on splines, rust
- 2 Drive shaft seal wear grooves
- 3 Bearing seat
- 4 Splines for cylinder drive
- 5 Bearing seat



(3) Check : Sliding surface free of grooves.



(4) Check :

Bearing surfaces.



(5) Check :

That the retaining plate is free of grooves and that there is no wear in the slipper pad area.



(6) Check :

Check to see that there are no scratches or metal deposits on the sliding surface (1) and that there is no axial play (2) (Pistons must only be replaced as a set).



(7) Check :

- 1 Cylinder bores
- 2 Splines







(9) Check :

Cylinder sliding surface free of grooves, no wear, no embedded foreign particles. That there are no scratches on the control plate. (Only replace them as a set).



2. FAN MOTOR

1) STRUCTURE



- 1-1 Rotary group
- 1-101 Piston
- 1-102 Cylinder
- 1-104 Retaining plate
- 1-106 Retaining ball
- 1-107 Spring
- 1-109 Pressure pin
- 1-110 V-ring
- 1-111 Back-up plate

- 1-2 Control plate
- 5 Motor housing
- 6 Port plate
- 7 Cam plate (swash plate)
- 8 Drive shaft
- 9 Shaft key
- 12 Adjustment shim
- 15 Tapered roller bearing
- 16 Tapered roller bearing

- 18 Bearing bushing
- 20 Shaft seal
- 22 O-ring
- 25 Retaining ring (circlip)
- 27 Socket bolt
- 33 Cylinder pin
- 35 Cylinder pin
- 40 Screw
- 41 Screw

2) SEALING THE DRIVE SHAFT

- (1) 1 Circlip
 - 2 Shaft seal



(2) Remove key.Protect the drive shaft.Remove the circlip.

(3) Change the shaft seal and check its sliding surface (drive shaft) and housing, grease the sealing ring.



7609A4BS32

(4) Use installation tool or plastic strip for assembling seal.



(5) Use a suitable pipe to mount the shaft seal, but don't push it too deep. If the shaft ring touches the bearing ring you will damage the seal ring.

(6) Assemble the circlip.

(7) Assemble the circlip in the correct position.

* This discription showes how th change the drive shaft seal but it isn't the way of serial assembly.

The seal is assembled together with the taper roller bearing from inside the motor housing normally to get a secure sealing condition. If you decide to repair the motor in the shown way be very careful while handling so that the drive shaft wouldn't be damaged during disassembly of the shaft seal.







3) DISASSEMBLE THE MOTOR

Disassembly position.
Mark the location of the port plate on the housing.



(2) Remove the port plate fixing bolts crosswise.



- (3) Remove the port plate.
- * Control plate can drop down-hold tight.



(4) Remove control plate.



(5) Remove bearing outer ring with withdrawal tool.Do not damage the sealing surface.



(6) Disassemble the taper roller bearing (near by port plate).Remove the adjustment shim.



(7) Remove the rotary group in a horizontal position.



(8) Remove the drive shaft to rear side.



(9) Remove swash plate with special tool (see the next figure).



(10) Loosen the swash plate with a slide hammer (a small hook - diameter 6 mm catches the end of the swash plate at the bottom).



(11) Press down bearing.



(12) The external front bearing ring is pulled out of the pump housing.



(13) Disassemble circlip and shaft seal.



(14) Remove shaft seal and shim.



(15) Pre-tension the spring using a suitable device.



(16) Remove circlip. Remove spring and pressure pins.



4) INSPECTION HINTS

(1) Check to see that there are no scratches or metal deposits on the sliding surface (1), and that there is no axial play (2), (pistons must only be replaced as a set).



(2) Check cylinder bores (1) and splines (2).



(3) Free of grooves, no signs of wear.



(4) Cylinder sliding surface free of grooves, no wear, no embedded foreign particles. That there are no scratches on the control plate. (Only replace them as a set).



(5) Mounting surface - control plate undamaged.



5) MOTOR ASSEMBLY

(1) Fit the circlip into the housing.



(2) Assemble shaft seal and shim against circlip.



(3) Assembly of the shaft seal (1) against the safety ring (2) back up the shim (3) down to the seal ring.



- (4) Press outer bearing ring into housing.Shaft seal with pre-assembled bearing into housing.
- * Protect splines of the shaft with plastic strip against damage of the seal lip.



(5) Assemble swash plate.



(6) Fit pressure pins using an assembly aid.


(7) Pre-tension the spring using a suitable device.





- (8) Assemble piston with retaining plate.
- * Oil piston and slipper pad.



- (9) Fit rotary group.
- Assembly aid : Hold the pistons by using an O-ring.



- (10) Fit bearing (1) in port plate.Fit cyilindrical pin (2).Fit O-ring (3).Fit control plate (4).
- * Assembly : Hold the components in place with grease.



(11) Fit control plate. Assembly aid : Grease



(12) Fit the port plate and fix it with the bolts crosswise.



SECTION 5 STEERING SYSTEM

Group	1	Structure and Function	5-1
Group	2	Operational Checks and Troubleshooting	5-18
Group	3	Tests and Adjustments	5-26
Group	4	Disassembly and Assembly	5-34

GROUP 1 STRUCTURE AND FUNCTION

1. OUTLINE

The steering system of this machine consists of a variable displacement piston pump supplying a load sensing steering system and a closed center loader system.

This system offers faster response from the priority valve of flow amplifier and the pump. Also if offers advantages in connection with cold start up and improvements in system stability.

The components of the steering system are :

- · Steering pump
- · Flow amplifier
- · Steering unit
- \cdot Accumulators
- · Steering cylinders

The flow amplifier contain a directional valve, an amplification stage, a priority valve, a pilot pressure relief valve and shock and suction valve.

The steering pump draws hydraulic oil from the hydraulic tank.

Outlet flow from the pump flows to the priority valve of flow amplifier. The priority valve of flow amplifier preferentially supplies flow, on demand, to the steering unit. When the machine is steered, the steering unit routes flow to the steering cylinders to articulate the machine.

When the machine is not being steered, or if pump flow is greater than steering flow, the priority valve supplies flow to the loader system.

That is, output flow from the steering pump enters into the main control valve for the operation of the attachment.

2. HYDRAULIC CIRCUIT



980A5SE01

- 1 Steering pump
- 2 Loader pump
- 13 Shuttle valve
- 16 Steering cylinder
- 18 Steering unit
- 19 Flow amplifie

- 20 Accumulator
- 22 Check valve
- 24 Proportional valve (option)
- 25 LS compensating valve (option)
- 26 Shuttle valve
- 27 Pressure sensor
- 33 Hydraulic tank
- 38 Motor pump (option)
- 39 Check valve (option)

1) NEUTRAL



980A5SE02

- The steering wheel is not being operated so control spool (G) does not move.
- The oil from the steering pump enters port HP of the priority valve of flow amplifier and the inlet pressure oil moves the spool (D) to the right.
- Almost all of pump flow goes to the loader system (main control valve) through the EF port and partly flows into the hydraulic tank (33) through the control spool (G).

This small flow is useful to prevent the thermal shock problem of the steering unit (18).

2) LEFT TURN



- When the steering wheel is turned to the left, the spool (G) within steering unit (18) connected with steering column shaft is pushed to the right direction.
- The oil discharged from the pump flows into HP port of flow amplifier (19).
- The delivered oil passes through the main orifice of steering unit (8), through the priority valve spool
 (D) of flow amplifier (19). The position of priority spool (D) is determined when the pressure difference between front and rear of main orifice is balanced with control spring (K) force.
- The oil supplied through the directional spool (J) from the steering unit is combined with the direct oil from the priority valve spool (D) in the amplifier spool (M). The amplified oil flows into the small chamber of the left steering cylinder and large chamber of the right steering cylinder respectively.
- · Oil returned from left and right cylinder returns to hydraulic tank through directional spool (J) of flow amplifier (19).
- $\cdot\,$ When the above operation is completed, the machine turns to the left.

3) RIGHT TURN



- When the steering wheel is turned to the right, the spool (G) within steering unit (18) connected with steering column shaft is pushed to the right direction.
- The oil discharged from the pump flows into HP port of flow amplifier (19).
- The delivered oil passes through the main orifice of steering unit (8), through the priority valve spool
 (D) of flow amplifier (19). The position of priority spool (D) is determined when the pressure difference between front and rear of main orifice is balanced with control spring (K) force.
- The oil supplied through the directional spool (J) from the steering unit is combined with the direct oil from the priority valve spool (D) in the amplifier spool (M). The amplified oil flows into the small chamber of the right steering cylinder and large chamber of the left steering cylinder respectively.
- · Oil returned from left and right cylinder returns to hydraulic tank through directional spool (J) of flow amplifier (19).
- $\cdot\,$ When the above operation is completed, the machine turns to the right.

3. STEERING PUMP

1) STRUCTURE (1/2)

This steering pump is variable displacement piston pump.



78096WE88-1

Port	Port name	Port size
B1	Pressure port	SAE 1 1/4"
S1	Suction port	SAE 2 1/2"
L1, L2	Case drain port	1 5/16-12UN
X1	Pilot pressure port	7/16-20UNF

Function, disassembly and assembly : Refer to page 6-11~18 and 6-64~76.

STRUCTURE (2/2)



- 1 Rotary group
- 1-1 High speed rotary group
- 1-2 Control plate
- 2 Adjusting piece
- 5 Pump housing
- 6 Port plate
- 7 Swash plate

- 8 Drive shaft
- 12 Adjustment shim
- 15 Taper roller bearing
- 16 Taper roller bearing
- 17 Bearing liner
- 20 Shaft seal ring
- 22 O-ring

- 23 O-ring
- 25 V-ring
- 27 Socket screw
- 30 Locking screw
- 31 Double break-off pin
- 33 Cylinder pin
- 51 Control valve

4. FLOW AMPLIFIER

1) STRUCTURE



- 1 O-ring
- 2 O-ring
- 4 O-ring
- 5 Washer
- 6 Washer
- 7 O-ring
- 8 O-ring
- 9A Amplifier valve
- 9B Priority valve
- 9C Directional valve
- 10 Check valve
- 11 Screw

- 12 Spring washer
- 13 Screw
- 14 Spring washer
- 15 End cover
- 16 End cover
- 19 Relief valve
- 20 Plug
- 21 Shock, suction valve
- 22 Spring seat
- 23 Spring seat
- 24 Spring guide
- 27 Orifice

- 28 Spring
- 29 Spring
- 30 Spring
- 31 Throttle check valve
- 34 Orifice
- 35 Orifice
- 36 Orifice
- 37 Plug
- 38 Plug
- 40 Spring
- 41 Spring
- 42 Orifice

2) OPERATION

(1) Introduction

The flow amplifier contain a directional valve, an amplification stage, a priority valve, a pilot pressure relief valve and shock and suction valves.

The flow amplifier amplifies the oil flow from the steering unit cylinder ports L or R by an amplification factor of 8. The amplified oil flow is directed from the flow amplifier ports CL or CR to the steering cylinder. The amplified flow is proportional to the rate of the steering wheel rotation. If the oil flow from the pump fails, the flow amplifier cuts off the amplification.

(2) Priority valve

The priority valve is used in load sensing systems where the same pump supplies oil to both steering system and working hydraulics.

The steering system always has first priority.

The pressure on the LS connection is almost zero during measuring (steering unit in neutral position).

(3) Shock valves

The shock valves protect the flow amplifier against shock from external forces on the steering cylinders. The shock valves in flow amplifier limit the maximum pressure drop from CL to HT and from CR to HT.

(4) HP-HT ports characteristic

The pilot pressure relief valve protects the steering unit against excess pressure. The pilot pressure relief valve together with the priority valve limit the maximum steering pressure HP-HT.

(5) Neutral



980A5SE100

In neutral position, the oil passes from the pump across the integrated priority valve (9B) in the flow amplifier for discharge through the EF port. With the steering unit in neutral, flow through it is blocked and all flow through the priority valve (9B) in flow amplifier is directed out the EF port to the loader control valve.

With the engine off, the priority valve spool (9B) is pushed to the left by the spring (30). The passage to the EF port is blocked while the passage to the P port is open.

When the machine is first started, all pump flow is routed to the steering unit which blocks the flow. With the flow blocked, the pressure increases.

Steering inlet pressure is supplied through the dynamic orifice (42) in the spool. This causes the priority valve spool (9B) to shift to the right against the spring (30) and open the EF port.

As long as the steering unit is in neutral, just enough pressure is maintained at the steering unit to keep the priority valve spool (9B) shifted to the right.

The operating pressure in the loader system has no effect on the operation of the priority valve (9B) of flow amplifier. With the loader actuated in relief, the priority valve (9B) will not shift until the machine is steered.

Flow through the priority valve spool (9B) passes from the P port through the orifice (42) and into the LS port. It flows through the steering unit LS passage which is routed to return when the steering unit is in neutral. This provides a warm-up circuit for the steering unit to prevent binding of the steering unit due to oil temperature extremes.

In neutral position, also the directional valve (9C) is in its center position.

This means that knock and impacts from the cylinder are not transmitted to the steering unit. The flow amplifier is thus of the non-reaction type.

(6) Mid-turn



980A5SE101

If the steering wheel is turned to the left, a LS signal is passed to the priority valve (9B). The priority valve (9B) is reversed so that more oil is passed across the P port to the steering unit for discharge through the L port of the flow amplifier.

The directional valve (9C) is reversed through the pressure being transmitted across the boring in the spool whereby the spool is moved the right.

The opening shall allow connection between the pilot flow and the pressure control/amplifier valve (9A).

The pilot pressure from the orifice in chamber C moves the valve to the left and passage for the pilot flow therefore is possible out of hole F.

The main flow passes from the priority valve (9B) to the circular channel M. As the amplifier spool is moved to the left, the passage will now be open across the holes N to the chamber S.

The spool goes to a position so that the pressure in chamber S equals the pressure in chamber C.

The passage is now open for the main flow through the priority valve (9B) across the holes A.

The main flow and pilot flow merge and is passed across the directional valve (9C) to the steering cylinder through CL port.

The return oil passes across the directional valve (9C) to the hydraulic tank.

(7) Full turm



980A5SE102

When the machine is steered to a full turn, the frames bottom against the steering stops. To limit steering system pressure, a relief system is built into the priority valve assembly (9B).

When the frames bottom is stopped, the pressure in the steering cylinders increases. This pressure is sensed at the LS port. When the pressure in the LS port increases enough to push priority valve spool (9B) off its seat, oil in the load sensing circuit flows to return through the T port. Load sensing pressure is limited to the pressure setting of the relief valve.

Pressure to the steering unit (pilot pressure), which is sensed at the left end of the priority valve spool (9B) in flow amplifier, continues to increase until it can move the spool to the right against the load sensing pressure plus spring (30) force. At this time, all oil flows out of the EF port to the loader control valve.

If the loader attachment is being operated while steering, the loader function will slow until the machine reaches the steering stops. At that time, the loader cycle speed will increase until the machine is steered again.

4. STEERING UNIT

1) STRUCTURE







7607SE17

1 Bearing

- 5 Gear wheel
- 2 Neutral position spring
- 3 Cross pin
- 4 Housing

- 6 Gear rim
- 7 Sleeve
- 8 Cardan shaft
- 9 Spool
- 10 Check valve
- 11 Distributor plate
- 12 End cover

2) OPERATION

The steering unit consists of a rotary valve and a rotary meter.

Via a steering column the steering unit is connected to the steering wheel of the machine.

When the steering wheel is turned, oil is directed from the steering system pump via the rotary valve (spool and sleeve) and rotary meter (gear wheel set) to the cylinder ports L or R, depending on the direction of turn. The rotary meter meters the oil flow to the steering cylinder in proportion to the angular rotation of the steering wheel.

Spool (9) is connected directly to the drive shaft of steering wheel. It is connected to sleeve (7) by cross pin (3) (not in contact with the spool when the steering wheel is at neutral) and neutral position spring (2).

Cardan shaft(8) is meshed at the top with cross pin (3) and forms one unit with sleeve (7).

At the same time, it is meshed with gear rim (5) of the gerotor set by spline.

There are four ports in valve body. They are connected to the pump circuit, tank circuit, and the head, and left and right steering cylinder. In addition, the pump port and tank port are connected inside the body by the check valve. Therefore, if there is any failure in the pump of engine, oil can be sucked in directly from the tank through the check valve.

5. STEERING CYLINDER

1) STRUCTURE



- 1 Tube assembly
- 2 Rod assy
- 3 Gland
- 4 Dust wiper
- 5 Retaining ring
- 6 Rod seal
- 7 Back-up ring
- 8 Buffer ring
- 9 Bearing
- 10 O-ring
- 11 Back-up ring

- 12 O-ring
- 13 Piston
- 14 Piston seal
- Wear ring 15
- 16 O-ring
- 17 Back-up ring
- 18 Cushion plunger
- 19 Paraller pin
- 20 Steel ball
- 21 Set screw
- 22 Check valve

- 23 Spring
- 24 Socket plug
- 25 Pipe assembly
- 26 O-ring
- 27 Hexagon bolt
- 28 U-bolt
- 29 Hexagon nut
- 30 Spring washer
- 31 Bearing
- 32 Retaining ring

2) OPERATION

This machine use to cross connected cylinder for steering operation.

The steering cylinder use a gland (3) to remove piston and sealed seals. Dust wiper (4) located on the inside of the gland protects cylinder inner parts from dust. The piston (13) is fastened to the rod (2).

The piston uses a single wear ring (15) with a piston seal (14) to seal between the piston and tube. The gland seals against the tube with two O-rings. The rod is sealed against the gland with a rod seal (6).

9805SE05

GROUP 2 OPERATIONAL CHECKS AND TROUBLESHOOTING

1. OPERATIONAL CHECKS

This procedure is designed so the service man can make a quick check of the steering system using a minimum amount of diagnostic equipment. If you need additional information, prefer to structure and function in group 1.

A location will be required which is level and has adequate space to complete the checks.

The engine and all other major components must be at operating temperature for some checks.

Locate system check in the left column and read completely, following this sequence from left to right. Read each check completely before performing.

At the end of each check, if no problem is found (OK), that check is complete or an additional check is needed. If problem is indicated (NOT OK), you will be give repair required and group location. If verification is needed, you will be give next best source of information :

- · Chapter 2 : Troubleshooting
- · Group 3 : Tests and adjustments

Item		Description	Service action	
Steering unit check	\wedge	Run engine at low idle.	ОК	
		Turn steering wheel until frames are at maximum right (A) and then left (B) positions.	Check completed. NOT OK Go to next check.	
		LOOK : Frames must move smoothly in both directions.		
		When steering wheel is stopped, frames must stop.		
		FEEL : Excessive effort must not be required to turn steering wheel.		
		NOTE : It is normal for steering to drift from stops when steering wheel is released.		
Steering system leakage check	Lott Disht	Turn steering wheel rapidly until frames are against stop.	OK Check completed.	
Heat hydraulic oil to operating temperature. Run engine at high idle.	Left Hight	Hold approximately 2 kg on steer- ing wheel.	NOT OK Do steering system leakage test in group 3 to isolate the leakage.	
		Count steering wheel revolutions for 1 minute.		
		Repeat test in opposite direction.		
		LOOK : Steering wheel should rotate less than 7 rpm.		
		NOTE : Use good judgment;		
		Excessive steering wheel rpm does not mean steering will be affected.		
Priority valve (in flow		Park machine on a hard surface.	OK	
amplifier) low pressure check		Hold brake pedal down.	Check completed.	
		Run engine at high idle.	Do flow amplifier pressure	
		Steer machine to the right and left as far as possible.	test in group 3.	
		LOOK : Machine must turn at least half way to the right and left stops.		
Priority valve (in flow amplifier) high pressure	00-	Steer to steering stop and release steering wheel.	OK Check completed.	
check Bun engine at high idle.		Roll bucket back and hold over relief and observe engine rpm.	NOT OK Priority pressure is set too	
		Turn steering wheel to steering stop and hold, observe engine rpm.	high. Do flow amplifier pre sure test in group 3.	
		LOOK : Steering stall engine rpm must be higher than hydraulic stall rpm.		

* Hydraulic oil must be at operating temperature for these checks (refer to page 6-54).

2. TROUBLESHOOTING

* Diagnose malfunction charts are arranged from most probable and simplest to verify, to least likely, more difficult to verify. Remember the following steps when troubleshooting a problem : Step 1. Operational check out procedure (see group 3 in section 1)

Step 2. Operational checks (in this group)

Step 3. Troubleshooting

Step 4. Tests and adjustments (see group 3)

Problem	Cause	Remedy
No steering	Low oil level.	Add recommended oil.
	Failed steering pump.	Remove and inspect return filter for metal pump particles.
	Failed main pump drive.	Do main pump flow test.
	Stuck priority valve spool.	Remove and inspect priority valve spool.
	Broken priority valve spring.	Remove and inspect spring.
	Relief valve in flow amplifier stuck open.	Do relief cartridge leakage test in group 3.
No hydraulic functions	Stuck open system relief valve.	Replace relief valve.
steering normal	Locked safety valve.	Unlock safety valve.
	Plugged pilot line filter.	Inspect and replace.
	Failed hydraulic pump.	Remove and inspect the pump.
	Low secondary pressure of RCV.	Check the pressure and replace if nec- essary.

Problem	Cause	Remedy
Slow or hard steering	Too much friction in the mechanical parts of the machine.	Lubricate bearings and joints of steering column or repair if necessary. Check steering column installation.
	Cold oil.	Warm the hydraulic oil.
	Low priority valve pressure setting.	Do priority valve pressure test. Clean or replace cartridge in flow amplifier.
	Worn hydraulic pump.	Do hydraulic pump performance check .
	Sticking priority valve spool.	Remove and inspect.
	Broken priority valve spring.	Remove and inspect.
Constant steering to	Air in system.	Check for foamy oil.
maintain straight travel	Leakage in steering system.	Do steering system leakage check.
	Worn steering unit.	Do steering system leakage check. Do steering unit neutral leakage test in group 3.
	Leaf spring without spring force or broken.	Replace leaf springs.
	Spring in double shock valve broken.	Replace shock valve.
	Gear wheel set worn.	Replace gear wheel set.
	Cylinder seized or piston seals worn.	Replace defects parts.
Slow steering wheel	Leakage in steering unit gerotor.	Do steering system leakage check.
any frame movement	Worn steering unit gerotor.	Do steering leakage check.
Steering wheel can be turned with frames against steering stop	Leakage in steering system.	Do steering system leakage check.
Steering wheel turns with no resistance and	Broken steering column or splined cou- pling.	Remove and inspect.
causes no trame move- ment	Lack of oil in steering unit.	Start engine and check steering operation.
	Leakage in steering system.	Do steering system leakage test in group 3.

Problem	Cause	Remedy
Erratic steering	Air in oil.	Check for foamy oil.
	Low oil level.	Add recommended oil.
	Sticking priority valve spool.	Remove and inspect spool.
	Loose cylinder piston.	Remove rod to inspect piston.
	Damaged steering unit.	Remove and inspect.
Spongy or soft steering	Air in oil.	Check for foamy oil.
	Low oil level.	Add recommended oil.
Free play at steering	Loose steering wheel nut.	Tighten.
wheel	Worn or damaged splines on steering col- umn or unit.	Inspect.
Steering unit binding or steering wheel does not	Binding in steering column or misalignment of column.	Inspect.
immediately return to neutral when released	High return pressure.	Check for a pinched or damaged return line.
	Contamination in steering unit.	Inspect hydraulic filter for contamination. Repair cause of contamination. Flush hydraulic system.
	Large particles of contamination in steering unit.	Inspect hydraulic filter for contamination. Repair cause of contamination. Flush hydraulic system.
Steering unit locks up	★ Thermal shock	Do priority valve LS port flow test in group 5. This oil flow provides a warm -up flow to steering unit when not using the steering.
	Worn or damaged steering unit.	Repair or replace steering unit.
Abrupt steering wheel oscillation	Improperly timed gerotor gear in steering unit.	Time gerotor gear.
Steering wheel turns by itself	Lines connected to wrong port.	Reconnect lines.
Vibration in steering sys- tem or hoses jump	High priority valve setting.	Do priority valve pressure test.
Neutral position of steer- ing wheel cannot be	Steering column and steering unit out of line.	Align the steering column with steering unit.
obtained, i.e. there is a tendency towards "motoring"	Too little or no play between steering col- umn and steering unit input shaft.	Adjust the play and, if necessary, shorten the splines journal.
	Pinching between inner and outer spools.	Contact the nearest service shop.

★ Thermal shock is caused by a large temperature differential(Approx. 30°C, 50°F) between the steering valve and hydraulic oil. If the steering is not operated for a long period of time and the orifice in the bottom of the priority valve spool is plugged, the steering valve may bind up when the steering is operated if the hydraulic oil is hot enough.

Problem	Cause	Remedy
"Motoring" effect. The steering wheel can	Leaf springs are stuck or broken and have therefore reduced spring force.	Replace leaf springs.
turn on its own.	Inner and outer spools pinch, possibly due to dirt.	Clean steering unit or contact the nearest service shop.
	Return pressure in connection with the reaction between differential cylinder and steering unit too high.	Reduce return pressure.
	Oil is needed in the tank.	Fill with clean oil and bleed the system.
	Steering cylinder worn.	Replace or repair cylinder.
	Gear wheel set worn.	Replace gear wheel set.
	Spacer across cardan shaft forgotten.	Install spacer.

Problem	Cause	Remedy
Backlash	Cardan shaft fork worn or broken.	Replace cardan shaft.
	Leaf springs without spring force or broken.	Replace leaf springs.
	Worn splines on the steering column.	Replace steering column.
"Shimmy" effect. The steered wheels vibrate. (Rough tread on tires	Air in the steering cylinder.	Bleed cylinder. Find and remove the reason for air collec- tion.
gives vibrations)	Mechanical connections or wheel bearings worn.	Replace worn parts.
	High priority valve setting pressure.	Set pressure as regular value.
Steering wheel can be turned slowly in one or both directions without the steered wheels turn- ing.	One or both shock valves are leaky or are missing in steering valve.	Clean or replace defective of missing valves.
Steering is too slow and heavy when trying to turn	Insufficient oil supply to steering unit, pump defective or number of revolutions too low.	Replace pump or increase number of revolutions.
quickly.	Relief valve setting too low.	Adjust valve to correct setting.
	Relief valve sticking owing to dirt.	Clean the valve.
	Spool in priority valve sticking owing to dirt.	Clean the valve, check that spool moves easily without spring.
	Too weak spring in priority valve.	Replace spring by a stronger.
"Kick back" in steering wheel from system. Kicks from wheels.	Fault in the system.	Contact authorized man or shop.

Problem	Cause	Remedy
Heavy kick-back in steer- ing wheel in both direc- tions.	Wrong setting of cardan shaft and gear- wheel set.	Correct setting as shown in this manual.
urning the steering wheel activates the steered wheels opposite.	Hydraulic hoses for the steering cylinders have been switched around.	Connect lines to correct ports.
Hard point when starting to turn the steering wheel	Spring force in priority valve too weak. Oil is too thick (cold).	Replace spring by a stronger. Let motor run until oil is warm.
Too little steering force (possibly to one side only).	Pump pressure too low. Too little steering cylinder. Piston rod area of the differential cylinder too large compared with piston diameter.	Correct pump pressure. Fit a larger cylinder. Fit cylinder with thinner piston rod or 2 dif- ferential cylinders.
Leakage at either input shaft, end cover, gear- wheel set, housing or top part.	Shaft defective. Screws loose. Washers or O-rings defective.	Replace shaft seal. Tighten screws. Replace.

GROUP 3 TESTS AND ADJUSTMENTS

1. HYDRAULIC OIL CLEAN UP PROCEDURE USING PORTABLE FILTER CADDY

- * Service equipment and tool.
 - · Portable filter caddy
 - \cdot Two 3658 mm (12 ft) \times 1" I.D. 100R1 hoses with 3/4 M NPT ends
 - · Quick disconnect fittings
 - · Discharge wand
 - · Various size fittings and hoses
- * Brake system uses oil from hydraulic oil tank. Flush all lines in the steering system.

Disassemble and clean major components for steering system.

Steering components may fail if steering system is not cleaned after hydraulic oil tank contamination.

- If hydraulic system is contaminated due to a major component failure, remove and disassemble steering cylinders to clean debris from cylinders.
- 2) Install a new return filter element. Clean filter housing before installing new element.
- * For a failure that creates a lot of debris, remove access cover from hydraulic oil tank. Drain and clean hydraulic oil tank of fill the specified oil to hydraulic oil tank through upper cover.
- To minimize oil loss, pull a vacuum in hydraulic oil tank using a vacuum pump. Connect filter caddy suction line to drain port at bottom of hydraulic oil tank using connector. Check to be sure debris has not closed drain port.
- Put filter caddy discharge line into hydraulic oil tank filter hole so end is as far away from drain port as possible to obtain a through cleaning of oil.

 Start the filter caddy. Check to be sure oil is flowing through the filters.
 Operate filter caddy approximately 10 min-

utes so oil in hydraulic oil tank is circulated through filter a minimum of four times.

% Hydraulic oil tank capacity 184 ℓ (48.6 U.S. gal).

Leave filter caddy operating for the next steps.

- 6) Start the engine and run it at high idle.
- * For the most effective results, cleaning procedure must start with the smallest capacity circuit then proceed to the next largest capacity circuit.
- Operate all functions, one at a time, through a complete cycle in the following order: clam, steering, bucket, and boom. Also include all auxiliary hydraulic functions.

Repeat procedure until the total system capacity has circulated through filter caddy seven times, approximately 30 minutes. Each function must go through a minimum of three complete cycles for a through cleaning for oil.

- Filtering time for machines with auxiliary hydraulic functions must be increased because system capacity is larger.
- 8) Stop the engine. Remove the filter caddy.
- 9) Install a new return filter element.
- 10) Check oil level in hydraulic oil tank ; Add oil if necessary.

2. TEST TOOLS

1) CLAMP-ON ELECTRONIC TACHOMET-ER INSTALLATION

Service equipment and tools Tachometer

A : Clamp on tachometer.

Remove paint using emery cloth and connect to a straight section of injection line within 100 mm (4in) of pump. Finger tighten only-do not over tighten.

- B : Black clip (-). Connect to main frame.
- C : Red clip (+). Connect to transducer.
- D : Tachometer readout. Install cable.



2) DIGITAL THERMOMETER INSTALLATION

· Service equipment and tools Digital thermometer

- A : Temperature probe. Fasten to a bare metal line using a tie band. Wrap with shop towel.
- B : Cable.
- C : Digital thermometer.



3) DISPLAY MONITOR TACHOMETER

The display monitor tachometer is accurate enough for test work.



3. STEERING SYSTEM RESTRICTION TEST

· SPECIFICATION

Oil temperature $45\pm5^{\circ}C (113\pm9^{\circ}F)$ Engine speedHigh idleMaximum pressure2.1MPa (21 bar, 300psi)at flow amplifier

- GAUGE AND TOOL Gauge 0~7 MPa (0~70 bar, 0~1000 psi) 2EA
- This test will check for restrictions in the steering system which can cause overheating of hydraulic oil.
- Install temperature reader. (see temperature reader installation procedure in this group).
- Heat hydraulic oil to specifications.
 (see hydraulic oil warm up procedure at page 6-54).
- 3) Connect fitting and install gauge.
- ▲ Do not operate steering or loader functions or test gauge may be damaged.
- 4) Run engine at specification and read pressure gauges.

If pressure is more than specification at the flow amplifier, inspect flow amplifier for a priority valve spool. Make sure orifice plugs installed in ends of priority valve spool. Check for plugged orifice in flow amplifier LS

port.



4. STEERING UNIT LEAKAGE TEST

· SPECIFICATION

- GAUGE AND TOOL
 Temperature reader
 Measuring container (approx. 20 l)
 Stop watch
- 1) Install frame locking bar to prevent machine from turning.
- Install temperature reader.
 (see temperature reader installation procedure in this group).
- Heat hydraulic oil to specifications.
 (see hydraulic oil warm up procedure at page 6-54).
- 4) Disconnect return hose from fitting. Install cap fitting.
- Run engine at specifications. Rotate steering wheel against locking bar using approximately 1.2 kgf · m of force. Measure oil flow from return hose for 1 minute.
- 6) Leakage is greater than specifications, repair or replace steering unit.



5. FLOW AMPLIFIER PRESSURE TEST

· SPECIFICATION

 Oil temperature
 45±5°C (113±9°F)

 Engine speed
 High idle

 Oil pressure
 20.1~21.1 MPa

 (205~215 bar, 2900~3100 psi)

GAUGE AND TOOL Gauge 0~35 MPa (0~350 bar, 0~5000 psi) Temperature reader

- 1) Connect gauge to test port.
- 2) Install temperature reader (see installation procedure in this group).
- 3) Install frame locking bar.
- Heat hydraulic oil to specifications.
 (see hydraulic oil warm up procedure at page 6-54)
- Run engine at specifications and turn steering wheel rapidly hold approximately 22N (5lb force) pressure on wheel with frames locked.
- % If steering wheel is turned slowly, it will continue to with the frames locked.

This will give an incorrect pressure reading.

If steering wheel continues to turn rapidly with the frames locked, steering system leakage is indicated.

- 6) Read pressure gauge. This is the flow amplifier relief pressure.
- If pressure in not to specification, turn adjusting screw in relief cartridge using a hex head wrench to adjust pressure.

If pressure cannot be adjusted to specification, disassemble and inspect flow amplifier.



6. FLOW AMPLIFIER LS PORT FLOW TEST

· SPECIFICATION

Oil temperature $45\pm5^{\circ}C (113\pm9^{\circ}F)$ Engine speedLow idleLS port flow (approx.)1 m ℓ /min

• GAUGE AND TOOL Temperature reader Measuring container Stop watch

Flow amplifier LS port flow test will check for a plugged or missing orifice in the bottom of the priority valve spool. A plugged orifice will block warm up flow to the steering unit which can cause thermal shock (see for an explanation of thermal shock page 5-22).

A missing orifice can cause the pump to be loaded to high pressure at all times causing overheating.

- 1) Install temperature reader (see temperature reader installation procedure in this group.)
- Heat hydraulic oil to specifications (see hydraulic oil warm up procedure at page 6-54).
- 3) Disconnect line from LS port and install plug (A).
- 4) Connect line (B) to flow amplifier.
- 5) Start engine and run at specification.
- 6) Measure flow from LS port for 1 minute.
- If flow is low, low steering system neutral pressure or a plugged orifice in bottom priority valve spool is indicated.

If flow is high, remove priority valve spool and inspect for a missing orifice.

Do hydraulic system restriction test in this group.


7. FLOW AMPLIFIER RELIEF CARTRIDGE LEAKAGE TEST

SPECIFICATION Oil temperature 45±5°C (113±9°F) Engine speed High idle Maximum leakage 1 m ℓ /min (16 drops per min)

- GAUGE AND TOOL Temperature reader Measuring container Stop watch
- Install temperature reader. (see temperature reader installation procedure in this group).
- Heat hydraulic oil to specifications.
 (see hydraulic oil warm up procedure at page 6-54).
- Install plug (A) in HT port.
 Disconnect line from T port on flow amplifier. Install plug (B) in line.
- 4) Connect line (C) to flow amplifier.
- 5) Start engine and run at specification.
- 6) Measure oil leakage from T port.
- 7) If leakage is more than specification, disassemble and inspect cartridge for damage or debris.



1. FLOW AMPLIFIER

1) STRUCTURE



- 5 Washer
- 6 Washer
- 7 O-ring
- 8 O-ring
- 9 Housing
- 9A Amplifier valve
- 9B Priority valve
- 9C Directional valve
- 10 Check valve
- 11 Screw

- 16 End cover
- 19 Relief valve
- 20 Plug
- 21 Shock, suction valve
- 22 Spring seat
- 23 Spring seat
- 24 Spring guide
- 26 Name plate
- 27 Orifice

- 34 Orifice
- 35 Orifice
- 36 Orifice
 - 37 Plug
- 38 Plug
- 40 Spring
- 41 Spring
- 42 Orifice

2) TOOLS

- \cdot Guide screws : M8 \times 1.0
- · Hook : Wire



6,8

o 🔘

00000

Ð

- · Hexagon keys : 4, 5, 6, 8 and 10 mm
- · Ratchet for socket spanners
- Hex socket for external : 13, 17 & 19 mm
- · Hex socket for internal : 8 & 10 mm
- · Multigrip pliers
- · Ring spanner: 13 mm
- · Screwdrivers : 3 and 10 mm
- · Steel Mandrels : 3, 5 and 8 mm
- Torque wrench : 12.2 kgf m (88 lbf ft)
- · Magnetic rod

3) DISASSEMBLY

- (1) Disassembly counter pressure valve
- ① Unscrew plug with O-ring (hexagon socket for 8 mm internal hexagon).



(770-3ATM) FA002

② Take out small spring (hook).



3 Take out ball (magnetic rod).



4 Take out piston.



5 Take out spring.



6 Counter pressure valve shown disassembled.



⑦ Counter pressure valve with orifice shown disassembled.



(2) Removing pressure relief valve

① Unscrew plug with washer (hexagon socket for 8 mm internal hexagon).



② Screw pressure relief valve out (10 mm hexagon key).



③ Take out washer (magnetic rod).



(3) Disassembly pressure relief valve

 Hold cartridge (multigrip pliers) and screw the adjustment screw out (5 mm hexagon key).



② Pressure relief valve shown disassembled.



(4) Removing end cover at PP-connection

① Unscrew screws with spring washer using hexagon socket for 13 mm external hexagon and 10 mm internal hexagon.



2 Remove end cover.



3 Remove stop and 2 springs.



4 Remove spring.



3 Remove plate and 6 O-rings.



④ Remove spring guide.



(5) Removing end cover at LS-connection

① Unscrew screws with spring washer using hexagon socket for 13 mm external hexagon and 10 mm internal hexagon.

(2) Remove end cover.

③ Remove stop and 2 springs.

4 Remove stop and spring.











(5) Remove plate and 4 O-rings.



6 Remove spring guide.



(6) Removing spools

 $(\ensuremath{\underline{1}})$ Remove directional spool.



② Remove amplifier spool.



③ Remove priority valve spool.



(7) Removing orifices and throttle check valve

① Unscrew orifice in LS-connection with 6 mm hexagon key.



② Unscrew throttle check valve in PP-connection with 6mm hexagon key.



③ Unscrew orifice in housing with 4 mm hexagon key.



(8) Removing shock valves

① Remove shock valve with screwdriver and hexagon key.



(9) Overview of disassembled parts

1 Housing and end cover with accessories.







(10) Disassembly of directional spool

② Spool with accessories.

① Unscrew orifice with 4mm hexagon key. Use a mandrel.



② Directional spool shown disassembled.



(11) Disassembly of priority valve spool

① Unscrew plug or throttle check valve with 8 mm hexagon key.



② Priority valve spool with plug for external PP shown disassembled.



③ Priority valve spool with throttle check valve for internal PP shown disassembled.



(12) Disassembly of amplifier spool

- ① Carefully remove the spring ring from the recess with 3mm screwdriver.
- * Avoid damage to the spring ring.



2 Carefully guide the spring ring back.



- ③ Carefully take the spring ring from the recess and guide it back with 3mm screwdriver.
- $\ensuremath{\,\times\,}$ Avoid damage to the spring ring.



4 Press pin out gently with finger.



5 Take out plug.



6 Take out spring.



0 Take out pin 3mm screwdriver.





⑧ Take out inner spool.

- (9) Unscrew check valve with hexagon socket for 17 mm external hexagon and mandrel in the pin hole.
- * Avoid damaging the spool surface.



① Unscrew orifice out of plug with 4 mm hexagon key. Use a mandrel.



1 Amplifier spool shown disassembled.



(13) Disassembly of check valve

① Unscrew plug with 4 mm hexagon key and hexagon socket for 17 mm external hexagon.



(2) Check valve shown disassembled.



(14) Disassembly of shock valve / suction valve

- Unscrew locknut with hexagon socket for 13 mm external hexagon. Use a mandrel.
- * When readjusting shock valve hold locknut with 13 mm ring spanner.
- (770-3ATM) FA054

2 Take out disc and spring.



③ Take off housing.



④ Unscrew pilot valve with hexagon socket for 19 mm external hexagon. Use a mandrel.



5 Take out pilot valve and spring.



6 Take out spool.



⑦ Unscrew adjustment screw and take out spring and ball.



⑧ Shock valve / suction valve shown disassembled.



* Cleaning

Clean all parts carefully with low aromatic kerosene.

* Inspection and replacement

Replace all gaskets and sealing washers. Check all other parts carefully and replace if necessary.

* Lubrication

Before assembly, lubricate all parts with hydraulic oil.

4) ASSEMBLY

- (1) Assembly of shock valve / suction valve
- 1 Guide spring with cone into housing.



② Fit adjustment screw.



④ Fit spring.











5 Fit pilot valve. Remember O-ring.



- (6) Tighten with torque wrench for 19 mm external hexagon. Use a mandrel.
 - \cdot Tightening torque : 2 \pm 0.5 kgf \cdot m (14.5 \pm 3.6 lbf \cdot ft)



0 Fit housing.







9 Fit disc.

10 Fit locknut.





(2) Assembly of check valve

- 1 Fit ball, spring and plug.
 - \cdot Tightening torque : 0.5 \pm 0.1 kgf \cdot m (3.6 \pm 0.7 lbf \cdot ft)

 \cdot Tightening torque : 1.5 \pm 0.2 kgf \cdot m

(10.8 \pm 1.4 lbf \cdot ft)



(3) Assembly of amplifier spool

- 1 Fit orifice in plug.
 - \cdot Tightening torque : 0.5 \pm 0.1 kgf \cdot m (3.6 \pm 0.7 lbf \cdot ft)



- 0 Fit check value.
 - \cdot Tightening torque : 2 \pm 0.3 kgf \cdot m (14.5 \pm 2.2lbf \cdot ft)
- * Avoid damaging spool surface. Remember O-ring.



3 Place inner spool in the correct position.



4 Guide inner spool in.





5 Fit pin.

6 Push spring ring into position. Place spring ring into the recess with ends facing away from pin holes.









 \bigcirc Fit spring.

⑧ Fit plug.

9 Fit pin.

10 Push spring ring into position. Place spring ring into the recess with ends facing away from pin holes.



(4) Assembly of priority valve spool

- Fit plug or throttle check valve.
 External PP : Plug.
 Internal PP : Throttle check valve.
 - \cdot Tightening torque : 1 \pm 0.3 kgf \cdot m (7.2 \pm 2.2 lbf \cdot ft)



(5) Assembly of directional spool

- 1 Screw in orifice.
 - \cdot Tightening torque : 0.5 \pm 0.1 kgf \cdot m (3.6 \pm 0.7 lbf \cdot ft)



(6) Installation of orifice and throttle check valve

- 1 Fit orifice in housing.
 - \cdot Tightening torque : 0.5 \pm 0.1 kgf \cdot m (3.6 \pm 0.7 lbf \cdot ft)



② Fit orifice in LS - connection.

 \cdot Tightening torque : 1 \pm 0.3 kgf \cdot m (7.2 \pm 2.2 lbf \cdot ft)



- ③ Fit throttle check valve in PP connection.
 - \cdot Tightening torque : 1 \pm 0.3 kgf \cdot m (7.2 \pm 2.2 lbf \cdot ft)



- $\,\, \mbox{\ensuremath{\mathbb K}}\,$ Comments on flow amplifiers with internal PP :
 - 1. 1/4 BSP. F in PP connection. Fit washer and plug.
 - \cdot Tightening torque : 4.1 \pm 0.3 kgf \cdot m

(29.7
$$\pm$$
2.2 lbf \cdot ft)

2. 7/16 - 20 UNF in PP - connection.

Fit O-ring and plug.

 \cdot Tightening torque : 1.5 \pm 0.5 kgf \cdot m (10.8 \pm 3.6 lbf \cdot ft)

(7) Installation of shock valves

 $(\ensuremath{\underline{1}})$ Guide shock value in and secure it by hand.

Remember O-ring.



(8) Assembly of pressure relief valve

① Guide adjustment screw, spring and cone up into the cartridge.



② Screw the adjustment screw so far in that the 10 mm hexagon key fully engages.



(9) Installation of pressure relief valve

1 Let the washer drop into the hole.



- 2 Fit pressure relief valve.
 - \cdot Tightening torque : 3.1 \pm 0.3 kgf \cdot m (22.4 \pm 2.2 lbf \cdot ft)



- 3 Fit plug with washer.
 - \cdot Tightening torque : 6±0.5 kgf \cdot m (44.1±3.6 lbf \cdot ft)



(10) Installation of back pressure valve

① First fit spring in piston with vaseline. Fit assembled piston and spring.



2 Let the ball drop down.



- ③ Fit spring in plug with vaseline.Fit assembled plug and spring.Remember O-ring.
 - \cdot Tightening torque : 2.6 \pm 0.3 kgf \cdot m (18.8 \pm 2.2 lbf \cdot ft)



(11) Installation of spools

- Fit directional spool.
 Fit priority valve spool.
- Spring control must be placed in correct position against LS connection.



- 2 Fit spring.
- * Spring must be by the LS connection.



- $\ensuremath{\textcircled{}}$ S Fit amplifier spool.
- * The orifice must be placed in correct position against LS connection.



(12)Installation of end cover at PP - connection

 Fit spring with vaseline on amplifier * spool.

The spring must be fitted at the PP - connection.



2 Fit spring guide with vaseline.



3 Fit large and small springs with vaseline.



4 Fit guide screws.





(5) Fit 4 large and 2 small O-rings.

6 Guide plate in.



 $\textcircled{\sc 0}$ Fit stop (thickness : 5 mm) in end cover with vaseline.



 \circledast Guide end cover in.



9 Fit screw with spring washer.



- 10 Fit screws with spring washer.
 - \cdot Tightening torque : 2.6 \pm 0.5 kgf \cdot m (18.8 \pm 3.6 lbf \cdot ft)
 - Tightening torque : 8.2±1 kgf · m for large screw (59.3±7.2 lbf · ft)



(13)Installation of end cover at LS - connection

Fit guide screws.
 Fit remote control with vaseline.







3 Guide in plate with 4 O-rings.



④ Fit stop for priority valve spool (thickness : 8 mm) with vaseline.



(5) Fit stop for directional spool (thickness : 5 mm) with vaseline.



6 Guide in end cover.



 \bigcirc Fit large screw with spring washer.



- 8 Fit screws with spring washers.
 - \cdot Tightening torque : 2.6 \pm 0.5 kgf \cdot m (18.8 \pm 3.6 lbf \cdot ft)
 - Tightening torque : 8.2±1 kgf · m for large screw (59.3±7.2 lbf · ft)



9 Fit plastic plugs.



This completes assembly.

2. STEERING UNIT

1) STRUCTURE



7707SE21

- 1 Dust seal ring
- 2 Housing, Spool, sleeve
- 3 Ball
- 4 Bushing
- 5 Lip seal
- 7 Bearing assy
- 8 Ring

- 9 Cross pin
- 11 Shaft
- 12 Spring set
- 13 O-ring
- 14 Distributor plate
- 15 Gearwheel set
- 16 O-ring

- 17 End cover
- 18 Washer
- 20 Pin screw
- 21 Screw
- 32 Check valve

2) TOOLS

(1) Holding tool.



(2) Assembly tool for O-ring and kin-ring.



(3) Assembly tool for lip seal.



(4) Assembly tool for cardan shaft.



(5) Assembly tool for dust seal.



(6) Torque wrench 0~7.1 kgf · m (0~54.4 lbf · ft)
13 mm socket spanner
6, 8 mm and 12 mm hexagon sockets
12 mm screwdriver
2 mm screwdriver
13 mm ring spanner
6, 8 and 12 mm hexagon socket spanners
Plastic hammer
Tweezers


3) TIGHTENING TORQUE AND HYDRAULIC CONNECTIONS

(1) Hydraulic connections



- L: Left port
- R: Right port
- T : Tank
- P: Pump

(770-3ATM) 5-71

(2) Tightening torque

Scrowod	Max. tightening torque [kgf · m (lbf · ft)]					
connection	With cutting edge	With copper washer	With aluminum washer	With O - ring		
1/4 BSP.F	4.1 (29.7)	2.0 (14.5)	3.1 (22.4)	-		
3/8 BSP.F	6.1 (44.1)	2.0 (14.5)	5.1 (36.9)	-		
1/2 BSP.F	10.2 (73.8)	3.1 (22.4)	8.2 (59.3)	-		
7/16-20 UNF	-	-	-	2.0 (14.5)		
3/4-16 UNF	-	-	-	6.1 (44.1)		
M 12×1.5	4.1 (29.7)	2.0 (14.5)	3.1 (22.4)	2.0 (14.5)		
M 18×1.5	7.1 (51.4)	2.0 (14.5)	5.1 (36.9)	5.1 (36.9)		
M 22×1.5	10.2 (73.8)	3.1 (22.4)	8.2 (59.3)	7.1 (51.4)		

4) DISASSEMBLY

(1) Disassemble steering column from steering unit and place the steering unit in the holding tool.

Screw out the screws in the end cover(6-off plus one special screw).



(2) Remove the end cover, sideways.



(3) Lift the gearwheel set (with spacer if fitted) off the unit.Take out the two O-rings.



(4) Remove cardan shaft.



(5) Remove distributor plate.

(7) Remove O-ring.



(6) Screw out the threaded bush over the check valve.

0 0 (770-3ATM) 5-73(2)



(8) Take care to keep the cross pin in the sleeve and spool horizontal. The pin can be seen through the open end of the spool. Press the spool inwards and the sleeve, ring, bearing races and needle bearing will be pushed out of the housing together.



(9) Take ring, bearing races and needle bearing from sleeve and spool. The outer (Thin) bearing race can sometimes "stick" in the housing, therefore check that it has come out.

(10) Press out the cross pin. Use the special screw from the end cover.





* A small mark has been made with a pumice stone on both spool and sleeve close to one of the slots for the neutral position springs (see drawing).

If the mark is not visible, remember to leave a mark of your own on sleeve and spool before the neutral position springs are disassembled.

- (770-3ATM) 5-74(3)
- (11) Carefully press the spool out of the sleeve.



(12) Press the neutral position springs out of their slots in the spool.



(13) Remove dust seal and O-ring.



(14) The steering unit is now completely disassembled.



% Cleaning

Clean all parts carefully in Shellsol K or the like.

※ Inspection and replacement

Replace all seals and washers. Check all parts carefully and make any replacements necessary.

*** Lubrication**

Before assembly, lubricate all parts with hydraulic oil.

5) ASSEMBLY

- (1) Assemble spool and sleeve.
- When assembling spool and sleeve only one of two possible ways of positioning the spring slots is correct. There are three slots in the spool and three holes in the sleeve in the end of the spool / sleeve opposite to the end with spring slots. Place the slots and holes opposite each other so that parts of the holes in the sleeve are visible through the slots in the spool.
- (2) Place the two flat neutral position springs in the slot.

Place the curved springs between the flat ones and press them into place (see assembly pattern).





- * Assembly pattern.
- · Weak springs (blue)
 - 2 off flat, blue : Part no. 150-0748
 - 2 off curved, blue : Part no. 150-0749
- Blue set
 Spare set : Part no. 150-4265



(3) Line up the spring set.



(4) Guide the spool into the sleeve. Make sure that spool and sleeve are placed correctly in relation to each other (see page 3-76, No.(1)).



(5) Press the springs together and push the neutral position springs into place in the sleeve.



(6) Line up the springs and center them.



- (7) Guide the ring down over the sleeve.
- * The ring should be able to rotate free of the springs.



(8) Fit the cross pin into the spool / sleeve.



(9) Fit bearing races and needle bearing as shown on below drawing.



- * Assembly pattern for standard bearings
 - 1 Outer bearing race
 - 2 Needle bearing
 - 3 Inner bearing race
 - 4 Spool
 - 5 Sleeve



Installation instruction for O-ring

(10) Turn the steering unit until the bore is horizontal. Guide the outer part of the assembly tool into the bore for the spool / sleeve.



(11) Grease O-ring with hydraulic oil and place them on the tool.





(12) Hold the outer part of the assembly tool in the bottom of the steering unit housing and guide the inner part of the tool right to the bottom.



(13) Press and turn the O-ring into position in the housing.



(14) Draw the inner and outer parts of the assembly tool out of the steering unit bore, leaving the guide from the inner part in the bore.



Installation instructions for lip seal

(15) Lubricate the lip seal with hydraulic oil and place it on the assembly tool.





(16) Guide the assembly tool right to the bottom.



(17) Press and turn the lip seal into place in the housing.



- (18) With a light turning movement, guide the spool and sleeve into the bore.
- Fit the spool set holding the cross pin horizontal.



(19) The spool set will push out the assembly tool guide. The O-ring are now in position.



(20) Turn the steering unit until the bore is vertical again. Put the check valve ball into the hole indicated by the arrow.



(21) Screw the threaded bush lightly into the check valve bore. The top of the bush must lie just below the surface of the housing.



(22) Grease the O-ring with mineral oil approx. viscosity 500 cSt at 20 $_{\circ}\,$ C .



(23) Place the distributor plate so that the channel holes match the holes in the housing.



(24) Guide the cardan shaft down into the bore so that the slot is parallel with the connection flange.



- (25) Place the cardan shaft as shown so that it is held in position by the mounting fork.
- (770-3ATM) 5-83(1) 0
- (26) Grease the two O-rings with mineral oil approx. viscosity 500 cSt at 20° C and place them in the two grooves in the gear Õ rim. Fit the gearwheel and rim on the \bigcirc



(27) Important

cardan shaft.

Fit the gearwheel (rotor) and cardan shaft so that a tooth base in the rotor is positioned in relation to the shaft slot as shown.

Turn the gear rim so that the seven through holes match the holes in the housing.



(28) Fit the spacer, if any.



(29) Place the end cover in position.



(30) Fit the special screw with washer and place it in the hole shown.



- (31) Fit the six screws with washers and insert them. Cross-tighten all the screws and the rolled pin.
 - \cdot Tightening torque : 3.1 \pm 0.6 kgf \cdot m (22.4 \pm 4.3 lbf \cdot ft)



(32) Place the dust seal ring in the housing.



(33) Fit the dust seal ring in the housing.



- (34) Press the plastic plugs into the connection ports.
- * Do not use a hammer!



3. STEERING CYLINDER

1) STRUCTURE



- 1 Tube assembly
- 2 Rod assy
- 3 Gland
- 4 Dust wiper
- 5 Retaining ring
- 6 Rod seal
- 7 Back-up ring
- 8 Buffer ring
- 9 Bushing
- 10 O-ring
- 11 Back-up ring

- 12 O-ring
- 13 Piston
- 14 Piston seal
- 15 Wear ring
- 16 O-ring
- 17 Back-up ring
- 18 Cushion plunger
- 19 Parallel pin
- 20 Steel ball
- 21 Set screw
- 22 Check valve

23 Spring

78095SE05

- 24 Plug
- 25 Pipe assy
- 26 O-ring
- 27 Hexagon nut
- 28 U-bolt
- 29 Hexagon nut
- 30 Spring washer
- 31 Spherical bearing
- 32 Retaining ring

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

Tool name	В	Remark		
L-wrench	5	B		
Spanner	70			
Wrench	For gla	and		
(-) Driver		Small and large sizes		
Torque wrench	Capable of tightening with the specified torques			

(2) Tightening torque

Dort name	ltere	<u>Cinc</u>	Torque	
Part name	liem	Size	kgf ∙ m	lbf ⋅ ft
Gland	3	M110×2	88±9	637±65
Piston	13	M 45×2	75±8	542±58
Set screw	21	M 8×1.5	2.0±0.2	14.4±1.4
Plug	24	PT 3/8	7.0±0.7	50.6±5.06

3) DISASSEMBLY

- (1) Remove cylinder head and piston rod
 - Hold the clevis section of the tube in a vise.
 - * Use mouth pieces so as not to damage the machined surface of the cylinder tube. Do not make use of the outside piping as a locking means.
 - ② Pull out piston rod (2) about 200 mm (7.8 in). Because the piston rod is rather heavy, finish extending it with air pressure after the oil draining operation.



- \bigcirc Loosen and remove the gland (3).
- * Cover the extracted piston rod (2) with rag to prevent it from being accidentally damaged during operation.



- ④ Draw out gland (3) and piston rod (2) assembly together from cylinder tube (1).
- Since the piston rod assembly is heavy in this case, lift the tip of the piston rod (2) with a crane or some means and draw it out. However, when piston rod(2) has been drawn out to approximately two thirds of its length, lift it in its center to draw it completely.



- ※ Note that the plated surface of piston rod (2) is to be lifted. For this reason, do not use a wire sling and others that may damage it, but use a strong cloth belt or a rope.
- (5) Place the removed piston rod assembly on a wooden V-block that is set level.
- * Cover a V-block with soft rag.



(2) Remove piston and gland assembly

- ① Remove the set screw (21) and steel ball (20).
- 2 Remove piston assembly (13), back up ring (17) and O-ring (16).



- ③ Remove the gland (3) assembly from piston rod (2).
- % If it is too heavy to move, move it by striking the flanged part of gland (3) with a plastic hammer.
- * Pull it straight with gland assembly lifted with a crane. Exercise care so as not to damage the lip of rod bushing (9) and packing

Lift with a crane 分 5,4 7,6 8 9 Plastic hammer 2 3 9805SE21

(4,5,6,7,8) by the threads of piston rod (2).

(3) Disassemble the piston assembly

- Remove wear ring (15) and piston seal (14).
- Exercise care in this operation not to damage the grooves.



(4) Disassemble gland assembly

- Remove back up ring (11), and O-ring (10).
- 2 Remove O-ring (12).
- ③ Remove retaining ring (5) and dust wiper (4).
- ④ Remove back up ring (7), rod seal (6) and buffer ring (8).
- Exercise care in this operation not to damage the grooves.
- ※ Do not remove seal and ring, if does not damaged.



4) ASSEMBLY

(1) Assemble gland assembly

- % Check for scratches or rough surfaces if found smooth with an oil stone.
- ① Coat the inner face of gland (3) with hydraulic oil.



② Coat dust wiper (4) with grease and fit dust wiper (4) to the bottom of the hole of dust wiper.

At this time, press a pad metal to the metal ring of dust seal.

 \bigcirc Fit retaining ring (5) to the stop face.



- ④ Fit back up ring (7) and rod seal (6), and buffer ring (8) to corresponding grooves, in that order.
- % Coat each packing with hydraulic oil before fitting it.
- Insert the backup ring until onside of it is inserted into groove.



- Rod seal (6) has its own fitting direction. Therefore, confirm it before fitting them.
- Fitting rod seal (6) up side down may damage its lip. Therefore check the correct direction that is shown in figure.



- \bigcirc Fit back up ring (10) to gland (3).
- % Put the backup ring in the warm water of 30~50°C.
- 6 Fit O-ring (10,12) to gland (3).
- 0 Fit bushing (9) to gland (3).



(2) Assemble piston assembly

- * Check for scratches or rough surfaces.
- If found smooth with an oil stone.
 Coat the outer face of piston (13) with hydraulic oil.



- 2) Fit piston seal (14) to piston
- % Put the piston seal in the warm water of 60~100°C for more than 5 minutes.
- * After assembling the piston seal, press its outer diameter to fit in.



- \bigcirc Fit wear ring (15) to piston (13).
- ④ Fit back up ring (17) and O-ring (16) to piston (13).



(3) Install piston and gland assembly

- ① Fix the piston rod assembly to the work bench.
- ② Apply hydraulic oil to the outer surface of piston rod (2), the inner surface of piston and gland.
- ③ Insert gland assembly to piston rod (2).



- 4 Fit piston assembly to piston rod.
- (5) Tighten piston (13) to piston rod (2).
 - Tightening torque : 75±8 kgf · m (542±57.9 lbf · ft)
- (6) Tighten set screw (21) to piston (13).
 - \cdot Tightening torque : 2.0 \pm 0.2 kgf \cdot m (14.5 \pm 1.45 lbf \cdot ft)



(4) Overall assemble

- Place a V-block on a rigid work bench. Mount the cylinder tube assembly on it and fix the assembly by passing a bar through the clevis pin hole to lock the assembly.
- ② Insert the piston rod assembly in to the cylinder tube assembly, while lifting and moving the piston rod assembly with a crane.
- ※ Be careful not to damage piston seal by thread of cylinder tube.
- ③ Fit gland to the tube.
 - \cdot Tightening torque : 88 \pm 9 kgf \cdot m (637 \pm 65 lbf \cdot ft)





4. CENTER PIVOT PIN

1) CONSTRUCTION

Figure shows the construction of the center pivot pin assembly. This assembly serves to connect the front frame with the rear frame; two sets of assemblies are provided, one each for the upper and lower parts. The numbers in parentheses following the parts name denote the item numbers shown in the figure in the disassembly and assembly procedures.



UPPER

78095SE13

- Bearing 1
- 2 Cover
- 3 Cover
- 4 Shim (0.1 t)
- 5 Shim (0.5 t)
- 6 Hexagon bolt
- 7 Pin
- 8 Collar
- 9 Collar
- 10 Plate
- 11 Pin

- Dust seal 12
- 13 Shim (0.1 t)
- 14 Shim (0.5 t)
- 15 Shim (2.0 t)
- 16 Bushing
- Cover 17
- 18 Cover
- 19 Hexagon bolt
- Hardened washer 20
- 21 Dust seal
- 22 Bushing

- Hexagon bolt 23
- 24 Hardened washer
- 25 Hexagon bolt
- Plate 26
- Plate 28
- 29 Hexagon bolt
- Hardened washer 30
- 31 Front frame
- Rear frame 32

2) DISASSEMBLY

After supporting the front frame and the rear frame as horizontally as possible using wood blocks and jacks, disassemble as follows: In order to facilitate the disassembly/assembly of the center pivot pins, remove the drive shaft, hydraulic line and steering cylinder first.

- Maintain the horizontal level of front frame (31) and rear frame (32), and then remove hexagon bolt (6, 23, 29), washer (20, 24) and plate (26, 28).
- (2) Take out upper pin (11) to the downside using a metal punch.

- (3) Maintain the front frame horizontal level, remove hexagon bolts (6) and then remove the plate (10) and shims (13, 14, 15).
- (4) Take out lower pin (7) to the upside using a metal punch carefully.
- (5) Jack up or lifting the front frame (31) slightly, the collar (9) protrudes over the rear frame.Remove the collar (9).
- (6) Lift the frame by passing the slinging wire rope at four positions of front frame, in order to separate it from the rear frame.
- (7) Support the front frame safely.





- (8) Remove bolt (25), washer (20) and then take out cover (2) and shims (4, 5).
- (9) Take out dust seal (21) from the cover (2).
- (10) Remove the bearing (1), and dust seal (21).



- (11) Remove bolt (19), washer (20) and then take out cover (17, 18) and shims (4, 5).
- (12) Take out the dust seal (12) from the cover (17, 18).
- (13) Remove the bearing (1) and collar (8).



3) INSPECTION

- (1) Check the bearing sliding surface for excessive wear, scorching or scratches; replace if necessary.
- (2) Replace all dust seals (12, 21) with new ones.
- (3) Grind any pins (7, 11) dented with an oilstone or replace any pins abrasive excessively.
- (4) Check inside cover (2, 3, 17, 18) and collar (8, 9) for dents or scratches; if any damage is found, correct with a grinder or replace.
- (5) The serviceable limit of pins and bushings is shown in the table below.

Unit : mm

Item No.	Name	Std dimension	Serviceable limit			Domodu
			Outer dia	Inner dia	Clearance	пенеру
7, 11	Pin	Lipport 100	99.5/104.5			
1	Tapered roller bearing	Lower : 105		100.5/105.5	0.8	Replace
8, 9	Collar			100.5/105.5		
12, 21	Dust seal	When removed		Replace		

4) ASSEMBLY



Assemble the center pivot group by reversing the order of disassembly while paying close attention to the following.

- (1) Put the dust seal (12,21) into cover (2, 3, 17, 18).
- * Apply grease to the lip of the dust seal. Insert the dust seal so that the dust seal lip faces out and punch four places on the outer circumference of the seal to lock it.
- (2) Lower the temperature of the lower bearing cup to $-75\pm5^{\circ}$ C ($-103\pm9^{\circ}$ F) and install it to front frame until it contacts the bottom of the frame.
- (3) Place the cover (3, 18).
- (4) Coat lightly with oil and install lower bearing in bore in front frame. Coat lightly with oil and install upper bearing in bore in upper front frame.
- (5) Place the cover (2, 17) and hold in place with bolt (19, 25). At this time, adjust shims (4, 5) to press the shoulder of bearing (1) against retainer.

· Adjustment method of clearance A

- Install bearing (1) and cover (2, 17) without shim (4, 5)
 Install four of bolt (19, 25) so that each bolt is separated by 90 degrees.
 - Tightening torque : 2.0~3.0 kgf · m (14.5~21.7 lbf · ft)
- 0 Adjust shims (4, 5) in order to control the clearance A.
 - · Clearance A : Below 0.1 mm
 - Shim thickness : 0.1 mm, 0.5 mm
- 3 Measure bearing preload and confirm the value.
 - Bearing preload : 1.2~2.5 kgf · m (8.7~18.1 lbf · ft)

- (5) Apply grease to lower collar (8) and insert it to the lower of roller bearing.
- (6) After setting the bearing so that its upper surface is horizontal, tighten the all the bolt (19, 25). After tightening, confirm that tapered roller bearing moves lightly ; if does not move smoothly, add shims (4, 5).
 - Tightening Torque : 35~43 kgf m (253~311 lbf ft)
 - Apply loctite #243.
- (7) Move the front frame and join it to the rear frame so that match the pin hole at the center.
- (8) Apply grease to pin (11), bushing (22) and insert it into tapered roller bearing (1).
- (9) Apply grease to lower collar (9) and insert it to the lower of roller bearing through rear frame (32).
- (10) Apply grease to pin (7) and insert it into tapered roller bearing (1).
- (11) Before tightening bolt (6), adjust shims (13, 14, 15) in order to control the clearance between the plate (21) and rear frame (32).
 - · Adjustment method of clearance B
 - Install pin (7) and plate (10) without shim (13, 14, 15).
 Install four of bolt (6) so that each bolt is separated by 90 degrees.
 - Tightening torque : $2.0 \sim 3.0 \text{ kgf} \cdot \text{m} (14.5 \sim 21.7 \text{ lbf} \cdot \text{ft})$
 - ② Adjust shims in order to control the clearance B.
 - · Clearance B : 0.1~0.2 mm
 - · Shim thickness : 0.1 mm, 0.5 mm, 2.0 mm
- (12) Tighten the all the bolts (6).
 - Tightening Torque : 35~43 kgf m (253~311 lbf ft)
 - · Apply loctite #243.

Trouble	Probable cause	Remedy
	Capscrew for fixing steering valve is loose	Retighten
Charle in falt when staaring	Faulty center pivot pin mounting bolts	Retighten
Shock is lelt when steering	Center pivot pins have worn out	Readjust or replace
	Faulty hydraulic system	See hydraulic system
	Fault fixing of connecting capscrews	Retighten
	Center pins have worn out	Readjust or replace
Shock is felt when moving	Bearings of support unit have worn out	Retighten
	Drive shaft damaged	See drive system
	Faulty transmission	See transmission system

5) TROUBLESHOOTING

Group	1	Structure and Function	6-1
Group	2	Operational Checks and Troubleshooting	6-39
Group	3	Tests and Adjustments	6-50
Group	4	Disassembly and Assembly	6-64

GROUP 1 STRUCTURE AND FUNCTION

1. HYDRAULIC SYSTEM OUTLINE

The loader hydraulic system is a pilot operated, closed center system which is supplied with flow from the variable displacement piston main hydraulic pump.

The loader system components are :

- · Loader pump
- · Main control valve
- · Bucket cylinder
- · Boom cylinders
- · Remote control valve (Pilot control valve, EH type)
- Safety valve

Flow from the steering pump not used by the steering system leaves the flow amplifier EF port. It flows to the inlet port plate of two section or three section block type main control valve.

The main control value is load pressure independent flow distribution system which routes flow to the boom, bucket or auxiliary cylinders (not shown) when the respective spools are shifted.

Flow from the loader pump is routed to the main control valve where pump outlet pressure is reduced to pilot circuit pressure. The main control valve flow to the remote control valve. The remote control valve routed flow to either end of each spool valve section in the main control valve to control spool stroke.

A accumulator mounted on safety valve supplies a secondary pressure source to operated remote control valve so the boom can be lowered if the engine is off.

The return circuit for the main hydraulic system have return filter inside the hydraulic tank. The return filter uses a filter element and a bypass valve. The bypass valve is located in the upside of filter.

2. HYDRAULIC CIRCUIT



2 Loader pump Fan & brake pump 3 Main control valve 4 5 EH controller Boom lowering valve 6 Remote control block 7 8,8' Remote control valve 9 Fan motor Directional valve 10 11 Hyd oil cooler 12 Safety valve 13 Shuttle valve Boom cylinder 14 Bucket cylinder 15 16 Steering cylinder 17 Pressure sensor 18 Steering unit 19 Flow amplifier 20 Accumulator 21 Orifice 22 Check valve 23 Joystick steering RCV (opt) Proportional valve (opt) 24 25 LS compensating valve (opt) 26 Shuttle valve (opt) Pressure sensor (opt) 27 Cut off valve 28 29 Accumulator 30 Pressure sensor 31 Brake valve 32 Pressure switch 33 Hydraulic tank 34 Air breather 35 Return filter 36 Bypass valve 37 Strainer assy 38 Motor pump (opt) Check block (opt) 39 40 Pressure sensor (opt) Check valve (opt) 41 Ride control valve (opt) 42 43,44 Accumulator Quick coupler cylinder (opt) 45 46 Solenoid valve (opt) 47 Filter assy

Steering pump

1

3. WORK EQUIPMENT HYDRAULIC CIRCUIT



980A6WE02

- 2 Loader pump
- 4 Main control valve
- 5 Control unit
- 6 Boom lowering valve
- 7 EH control block
- 8, 8' RCV (EH type, FNR type)

- 12 Safety valve
- 14 Boom cylinder
- 15 Bucket cylinder
- 22 Check valve
- 23 Joystick steering lever (opt)
- 33 Hydraulic tank

1) WHEN THE RCV LEVER IS IN THE RAISE POSITION



- When the EH RCV lever (8, boom) is pulled back, the boom spool is moved to raise position by pilot oil pressure from EH control block (7).
- The oil from loader pump flows into main control valve (4) and then goes to the large chamber of boom cylinder (14) by pushing the load check valve of the boom spool.
- The oil from the small chamber of boom cylinder (14) returns to hydraulic oil tank (33) through the boom spool at the same time.
- · When this happens, the boom goes up.

2) WHEN THE RCV LEVER IS IN THE LOWER POSITION



980A6WE04

- When the EH RCV lever (8, boom) is pushed forward, the boom spool is moved to lower position by pilot pressure from EH control block.
- The oil from loader pump flows into main control valve (4) and then goes to small chamber of boom cylinder (14) by pushing the load check valve of the boom spool.
- The oil returned from large chamber of boom cylinder (14) returns to hydraulic tank (33) through the boom spool at the same time.
- When the lowering speed of boom is faster, the return oil from the large chamber of boom cylinder combines with the oil from the pump through the regeneration check valve, and flows into the small chamber of the cylinder.

This prevents cylinder cavitation by the negative pressure when the pump flow cannot match the boom down speed.

3) WHEN THE RCV LEVER IS IN THE FLOAT POSITION



980A6WE05

- When the EH RCV lever (8, boom) is pushed further forward from the lower position, the pilot pressure reaches to 13~15bar, then the boom spool is moved to floating position.
- The work ports (A2), (B2), (A3), (B3) and the small chamber and the large chamber are connected to the return passage, so the boom will be lowered due to it's own weight.
- In this condition, when the bucket is in contact with the ground, it can be move up and down in accordance with the shape of the ground.

4) WHEN THE RCV LEVER IS IN THE DUMP POSITION



980A6WE06

- If the EH RCV lever (8, bucket) is pushed right, the bucket spool is moved to dump position by pilot oil pressure from EH control block.
- The oil from loader pump flows into main control valve (4) and then goes to the small chamber of bucket cylinder (15) by pushing the load check valve of the bucket spool.
- The oil at the large chamber of bucket cylinder (15) returns to hydraulic tank (33).
- When this happens, the bucket is dumped.
- When the dumping speed of bucket is faster, the oil returned from the large chamber of bucket cylinder combines with the oil from the pump, and flows into the small chamber of the cylinder. This prevents cylinder cavitation by the negative pressure when the pump flow cannot match the bucket dump speed.
5) WHEN THE RCV LEVER IS IN THE ROLL BACK (retract) POSITION



980A6WE07

- If the EH RCV lever (8, bucket) is pulled left, the bucket spool is moved to roll back position by pilot oil pressure from EH control block.
- The oil from loader pump flows into main control valve (4) and then goes to the large chamber of bucket cylinder by pushing the load check valve of the bucket spool.
- The oil at the chamber of bucket cylinder (15) returns to hydraulic tank (33).
- When this happens, the bucket roll back.

4. MAIN PUMP (LOADER PUMP)

1) STRUCTURE (1/2)

This loader pump is variable displacement piston pump.



980A6WE88

Port	Port name	Port size
B2	Pressure port	SAE 1 1/4"
S2	Suction port	SAE 2 1/2"
L3, L4	Case drain port	1 5/16-12UN
X2	Pilot pressure port	7/16-20UNF

· STRUCTURE (2/2)



- 1 Rotary group
- 1-1 High speed rotary group
- 1-2 Control plate
- 2 Adjusting piece
- 5 Pump housing
- 6 Port plate
- 7 Swash plate

- 8 Drive shaft
- 12 Adjustment shim
- 15 Taper roller bearing
- 16 Taper roller bearing
- 17 Bearing liner
- 20 Shaft seal ring
- 22 O-ring

- 23 O-ring
- 25 V-ring
- 27 Socket screw
- 30 Locking screw
- 31 Double break-off pin
- 33 Cylinder pin
- 51 Control valve

2) FUNCTION



- 2 Swash plate
- 3 Shoe plate

Piston

5

- 4 Counter piston
- Cylinder 10 Control piston

Piston shoe

8

9

- 12 Pressure compensator spool
- 13 Flow compensator spool

The steering pump and loader pump are variable displacement piston pump. The steering pump and loader pump are flow controlled by LS signal. When the steering and loader are not being used, the pumps are at low pressure standby.

The load sensing pressure that is sensed from steering and loader hydraulic systems flows to flow compensator spool (13). This spool keeps the pump output at a level that is necessary to fulfill the requirements for the system flow and for the pressure.

The pressure compensator spool (12) also limits maximum system pressure. The pressure compensator spool (12) prevents damage to the steering and loader hydraulic components from excessive pressure.

The swivel angle of the pumps is controlled by counter piston (4) and control piston (10). Counter spring (6) cause swash plate (2) to move at maximum displacement or causes swash plate (2) to upstroke.

Control piston (10) has a larger area (diameter) than counter piston (4). Control piston (10) causes swash plate (2) to destroke the pump.

Flow compensator spool (13) and/or pressure compensator spool (12) changes pump output by regulating the pump discharge pressure that is acting on control piston (10).

Control piston (10) diameter is larger than counter piston (4) diameter, the oil pressure that is acting against control piston (10) overcomes the force of counter spring (6). The oil pressure than causes the pump to destroke.

Pressure and flow compensator valve (7) also controls the maximum output of pump pressure. When steering and loader pressure rises above pressure compensator setting, pressure compensator spool (12) overrides flow compensator spool (13). This causes the pump to destroke.

(1) Upstroking



Upstroking of the pump occurs as flow demand from loader and steering system.

The increased flow demand causes a LS pressure in LS line (19). The LS pressure in LS line (19) combines with the force of spring (18) in cavity (20).

The force of spring (18) causes pump pressure to be higher than the LS pressure (19).

If the combination of LS pressure and of spring force is greater than the pump discharge pressure, this difference pressure causes spool (13) to move right. As spool (13) moves right, the spool (13) blocks the flow of supply oil to control piston (10). Pump swash plate (2) is controlled by pressure and flow as much as hydraulic system requests.

When the oil flow to control piston (10) is blocked, the pilot oil in passage (22) drains to passage (23). The oil then flows past pressure compensator spool (12) and through passage (16) into the housing and via the drain line (14) to tank.

Supply oil flows through passage (15) to counter piston (4). The oil acts against counter piston (4). The oil combines with the force of counter spring (6). This causes swash plate (2) to upstroke.

This also causes the pump flow to increase. As flow requirements are satisfied, the pump output pressure increase. The pressure increases until the pressure in passage (15) moves flow compensator spool (13) up to be satisfied with system requirement for pressure and flow.

 \cdot Pump discharge pressure = force of spring (18) + LS pressure (19)

(2) Destroking



The decreased flow demand causes a LS pressure in line (19). The LS pressure in line (19) combines with the force of spring (18) in cavity (20).

This combination of LS pressure and of spring force is less than the pump pressure in passage (21). This causes flow compensator spool (13) to move left.

Pump oil now flows through passage (15). The oil then flows past flow compensator spool (13), through passage (22), and then to control piston (10).

The pump pressure behind control piston (10) is now greater than the combined force of counter piston(4) and of counter spring (6). The angle of swash plate (2) decreases. This decreases the pump output and the system pressure.

When the lower flow requirements are met, flow compensator spool (13) moves right up to the balanced position. Swash plate (2) maintains an angle that is sufficient to provide the lower required pressure. If the operator does not turn the steering wheel and does not move RCV, then the pump will return to low pressure standby.

 $\ensuremath{\mathscr{K}}$ Control piston \rightarrow Changes pump displacement ; influenced by controller.

Counter piston \rightarrow Helps to change pump displacement but no possible to control this piston.

(3) Low pressure standby



Low pressure standby constitutes the following condition: a running engine and inactive steering and loader. There are no flow demands on the pump or pressure demands on the pump. Therefore, there is no LS pressure in line (19).

Before you start the engine, counter spring (6) holds swash plate (2) at the maximum angle. As the pump begins to turn, oil begins to flow and pressure increases in the system.

Because of close centered steering control valve and close centered loader hydraulic system.

As this pressure increase, the pressure pushes flow compensator spool (13) against spring (18). This causes flow compensator spool (13) to move left. This opens passage (23) in order to allow pressure oil to flow to control piston (10).

The oil acts against control piston (10) in order to overcome the force of counter spring (6). The oil causes control piston (10) to move to the left.

When control piston (10) moves to the left, the piston moves swash plate (2) toward the minimum angle. Control piston (10) continues to move to the left until cross-drilled hole (24) allows the oil to drain to the case.

Cross-drilled hole (24) limits the maximum travel of control piston (10) to the left. The pump supplies a sufficient amount of flow that compensates for system leakage. The pump also supplies a sufficient of flow that compensates for leakage to the pump case. The leakage to the pump case is a result of the cross-drilled hole. The pump maintains low pressure standby. Low pressure standby pressure should not exceed 40 bar (580 psi).

* Low pressure standby will vary in the same pump as the system leakage or the pump leakage increases. The pump will upstroke slightly in order to compensate for the increasing leakage. Control piston (10) will cover more of the cross-drilled hole.

(4) High pressure stall



When the hydraulic system stalls under load or when the cylinders reach the end of the stroke, the main system pressure increases. But LS pressure (19) is regulated by LS relief valve on steering system and loader system. The pressure difference between discharged pump and LS pressure equal to spring (18). It means no flow is necessary. Therefore, discharged pressure push flow compensator spool (13) left . Supply oil now flows past flow compensator spool (13) and through passage (23). The oil flows past flow compensator spool (13) and into passage (22). The oil then flows to control piston (10).

Pump swash plate (2) will be minimum displacement if the operator does not turn the steering wheel and RCV, then the pump will return to low pressure standby.

(5) Adjustment of flow control

Flow compensator setting must be carried out following procedures and conditions.

① Conditions

- Engine is running (at high or low idle).
- RCV is operated slowly (example : Boom up).
- Pressure gauges are installed.
- * Discharge pump flow should be less than max pump flow.

2 Procedures

- Loosening the hexagon nut (2).
- Adjusting screw (1) of flow controller by tightening or loosing the screw (1).
 - · Flow setting : $\triangle P$ = Gauge A Gauge B
 - · Specification : Steering pump (27 bar)/Loader pump (22 bar)



75796WE37

(6) Adjustment of pressure control

Pressure compensator setting must be carried out following procedures and conditions.

1 Conditions

- Engine is running.
- System is at relief condition.

2 Procedures

- Loosening the hexagon nut (2).
- Adjusting screw (1) of pressure controller by tightening or loosing the screw (1).
- · Maximum pressure setting = Gauge A
- · Specification : Steering pump (250 bar)/Loader pump (300 bar)



5. EH (electro hydraulic) CONTROL BLOCK

1) STRUCTURE





2) OPERATION

The proportional pressure reducing valve (10-1~6) is a direct-acting spool-type valve. When de-energized, port 2 is closed and port 1 (delivery) is connected to port 3 (tank). When the inlet pressure fluctuates it provides an almost constant outlet pressure-depending on the energization of the coil. When the control current increases, the coil solenoid exerts a force on the control piston which is proportional to the control current and thereby defines the regulated pressure at port 1. This setting is proportional to the control current. Pressures at tank port 3 are additive to the set pressure. If, as a result of external factors, the pressure at port 1 rises above the preset pressure, the valve opens from port 1 to tank port 3.



6. MAIN CONTROL VALVE

1) STRUCTURE (1/3)

· Type : Closed center, Load pressure - Independent - Flow - Distribution



980A6W	F10

Port	Port name	Port size	Port	Port name	Port size
Р	From main pump	SAE 1"	a2, b2	Boom pilot port	11/16-16UN
Т	To hydraulic tank	SAE 1 1/4"	a3, b3	Auxiliary pilot port	11/16-16UN
A1, B1	To bucket cylinder port	SAE 3/4"	LS	Load sensing port	9/16-18UNF
A2, B2, A3, B3	To boom cylinder port	SAE 3/4"	Pst	To RCV P port	9/16-18UNF
a1, b1	Bucket pilot port	11/16-16UN	-	-	-

Hydraulic circuit

μĽ ģ b3

b4

)(¢ ______ b2

STRUCTURE (2/3)



78096WE13

- 11 Housing
- 30 O-ring
- 31 O-ring
- 32 O-ring
- 33 O-ring
- 35 O-ring
- 36 O-ring
- 37 O-ring

- 38 O-ring
- 50 Housing
- 60 Plate
- 61 Stud
- 62 Hexagon nut
- 63 Washer
- 65 Sandwich plate
- 71 Shuttle valve

- 74 Compensator valve
- 79 Pressure valve
- 80 Plug screw
- 84 Flow regulator
- 85 Precharge valve
- 86 Pressure reducing valve
- 102 Locking screw
- 165 Pressure relief valve

STRUCTURE (3/3)



23 Threaded steel pipe fitting 50 Housing

2) FUNCTION





980A6WE15

Spring chamber

7

- 1 Housing
- 2 Spool
- 3 Pressure compensator
- 4 Counter balance valve
- 5 Regeneration check valve
- 6 Port relief valve

(1) Control block

Proportional direction valve to the LUDV principle (Load pressure - Independent - Flow - Distribution)

(2) Actuator control

At the spool (2) the direction and volume of flow is determined that flows to the actuator connections (A or B).

The spring chambers (7) are supplied with pilot pressure either via the pilot connections a and b hydraulic control.

The value of the pilot pressure within the spring chamber (7) determines the stroke of the spool (2).

The pressure compensator (3) controls the pressure differential at the spool (2) and therefore, the flow to the actuators (A, B).

(3) Loader pressure compensation (LUDV)

The control block works to the LUDV principle. In this load - sensing version the pressure compensators (3) are located between the spool (2) and the actuator connections (A, B).

The highest load pressure of all of the actuators involved is applied to all of the pressure compensators. In parallel it is also applied to the pump.

If the pump flow is insufficient for all of the functions, then all work movements are reduced in speed by the same ratio.

(4) Pressure safety, actuator connections

Large nominal size port relief valve (6) with combined anti-cavitation functions protect the actuators from overloads and cavitation.

(5) Float position

The float position is obtained by means of a 4-position spool.

(6) Regeneration

To prevent cavitation, with negative loads (e. g. dump or lowering), the tank port is pre-loaded via counter balance valve (4) and is fed with oil via the regeneration check valve (5) downstream of the pressure compensator.

3) BOOM SECTION OPERATION

(1) Spool in neutral



980A6WE51

When the boom spool is in neutral position, oil from the pump will be blocked. Then, the pumps are at low pressure stand by.

(2) Boom raise position



980A6WE52

When the pilot pressure is led to the port b2, b3 the boom spool moved to raise position. Oil from the pump flows to the cylinder port B2, B3 and oil from the cylinder flows into the tank passage through the cylinder port A2, A3.

(3) Boom lower position



980A6WE53

When the pilot pressure is led to the port a2, a3, the boom spool moved to lower position.

Oil from the pump flows to the cylinder port A2, A3 and oil from the cylinder flows into the tank passage through the cylinder port B2, B3.

When the lowering speed of boom is faster, the return oil from the large chamber of boom cylinder combines with the oil from the pump through regeneration check valve (6), and flows into the small chamber of the cylinder. This prevents cylinder cavitation by the negative pressure when the pump flow cannot match the boom down speed.

(4) Boom float position



980A6WE54

When the boom spool is located in float position, the oil from the pump will be blocked. The cylinder ports (A2, A3, B2, B3) are connected to the tank passage, so the boom will be lowered due to it's own weight.

4) BUCKET SECTION OPERATION

(1) Spool in neutral



980A6WE55

When the bucket spool is in neutral position, oil from the pump will be blocked. Then, the pumps are at low pressure standby.

(2) Bucket rollback position



980A6WE56

When the pilot pressure is led to the port b1, the bucket spool moved to rollback position. Oil from the pump flows to the cylinder port B1 and oil from the cylinder flows into the tank passage through the cylinder port A1.

(3) Bucket dump



980A6WE57

When the pilot pressure is led to the port a1, the bucket spool moved to dump position.

Oil from the pump flows to the cylinder port A1, through the load holding valve and oil from the cylinder flows into the tank passage through the cylinder port B1.

When the dumping speed of bucket is faster, the return oil from the large chamber of bucket cylinder combines with the oil from the pump through regeneration check valve (6), and flows into the small chamber of the cylinder. This prevents cylinder cavitation by the negative pressure when the pump flow cannot match the bucket dump speed.

7. SAFETY VALVE

1) STRUCTURE



Port	Port name	Port size
P1	From MCU	PF 3/8"
A1	Supply to RCV lever	PF 1/4"
Т	To hydraulic tank	PF 1/4"

75796WE16

- 1 Bowl and element assy
- 2 Check valve Cartridge

- Solenoid valve 4
- 5 Accumulator

3

2) OPERATION

This valve is used to cut off the pilot circuit.

When the pilot cut off switch in the cab is pressed to ON position, the solenoid valve is activated and then the pilot oil flow into the pilot circuit.

The accumulator satisfied short term peak power demands and is a source of emergency power in case of main circuit pressure failures.

8. BOOM AND BUCKET CYLINDER

The boom cylinders are two unit and the bucket cylinder is one unit. They use a bolt on rod guide.

The piston (14) threads on to the rod (2) and is retained by a nut (20) and set screw (21).

The piston seals against the tube (1) with piston seal (15). Two wear rings (16) are located on each side of the piston seal.

The gland (3, the rod guide) seals against the tube with an O-ring (12). The cylinder thread seals against the rod with a lip type buffer ring (8) and a rod seal (5). A dust wiper (9) cleans the rod when it is retracted.

1) BOOM CYLINDER



- 1 Tube assembly
- 2 Rod assembly
- 3 Gland
- 4 Bushing
- 5 Snap ring
- 6 Rod seal
- 7 Back up ring
- 8 Buffer ring
- 9 Dust wiper
- 10 Snap ring

- 11 O-ring
- 12 O-ring
- 13 Back up ring
- 14 Piston
- 15 Piston seal
- 16 Wear ring
- 17 Dust ring
- 18 O-ring
- 10 Dealeura
- 19 Back up ring
- 20 Lock nut

21 Set screw

78096WE17

- 22 Bolt
- 23 Bushing
- 24 Dust seal
- 25 Band
- 26 Pipe assembly
- 27 Pipe assembly
- 28 O-ring
- 29 Bolt





1 Tube assembly

- 2 Rod assembly
- 3 Gland
- 4 Dust wiper
- 5 Snap ring
- 6 Rod seal
- 7 Back up ring
- 8 Buffer ring
- 9 Bushing
- 10 Snap ring

- 11 O-ring
- 12 Back up ring
- 13 O-ring
- 14 Piston
- 15 Piston seal
- 16 Wear ring
- 17 Dust ring
- 18 O-ring
- 19 Back up ring
- 20 Steel ball

- 21 Set screw
- 22 Bolt
- 23 Band assembly

9806WE18

- 24 Pipe assembly
- 25 Pipe assembly
- 26 Bolt
- 27 O-ring
- 28 Pin bushing
- 29 Pin bushing
- 30 Dust seal

9. HYDRAULIC OIL TANK

1) STRUCTURE

- The oil from the hydraulic tank is sent from the pump through main control valve to the cylinders. In the return circuit, the oil from various parts merges.
- A part of oil is cooled in the oil cooler, passes through the hydraulic filter and returns to the hydraulic tank (1).
- If the hydraulic return oil filter becomes clogged, return filter bypass valve (16) acts to allow the oil to return directly to the hydraulic tank (1). This prevents damage to the hydraulic filter (14). The bypass valve (16) is also actuated when negative pressure is generated in the circuit.



- 1 Hydraulic tank wa
- 2 Cover
- 3 Cover
- 4 Cover
- 5 Bolt
- 6 O-ring
- 7 O-ring
- 8 Bolt
- 12 Suction pipe
- 13 Strainer
- 14 Return filter
- 15 Spring
- 16 Bypass valve
- 17 Spring
- 18 O-ring
- 19 Bolt
- 20 Strainer
- 21 Retaining ring
- 22 Air breather

2) RETURN OIL FILTER BYPASS VALVE

(1) When the filter is clogged

Bypass valve (1) is opened and the oil returns directly to the tank without passing through the filter.

· Bypass valve set pressure : 1.36 kg/cm² (19.3 psi)



3) AIR BREATHER

The air breather is equipped with the capacity to perform three functions simultaneously-as an air filter, breathing valve, and as a lubrication opening.

(1) Preventing negative pressure inside the tank

The tank is a pressurized sealed type, so negative pressure is formed inside the hydraulic tank when the oil level drops during operations. When this happens, the difference in pressure between the tank and the outside atmospheric pressure opens the poppet in the breather, and air from the outside is let into the tank or prevent negative pressure.

(2) Preventing excessive pressure inside the tank

When the hydraulic cylinder is being used, the oil level in the hydraulic system increases and as temperature rises. If the hydraulic pressure rises above the set pressure, breather is actuated to release the hydraulic pressure inside the tank.



10. ACCUMULATOR

The accumulator is installed at the safety valve. When the boom is left the raised position, and the control levers are operated with the engine stopped the pressure of the compressed nitrogen gas inside the accumulator sends pilot pressure to the control valve to actuate it and allow the boom and bucket to come down under their own weight.

Type of gas	Nitrogen gas (N2)
Volume of gas	0.75 ℓ (0.2 U.S.gal)
Charging pressure of gas	16 kg/cm ² (228 psi)
Max actuating pressure	128 kg/m² (1820 psi)



11. RIDE CONTROL SYSTEM (option)

1) ACCUMULATORS

(1) Pre-charging

Use an inert gas such as nitrogen for pre-charging accumulator.

- * Do not use oxygen or shop air.
- Nitrogen source and all components must be rated for a pressure at least as high as the nitrogen source.

Accumulator having gas valve as per figure 1.

- $(\ensuremath{\underline{1}})$ Remove gas valve guard and gas valve cap.
- ② Back gas chuck "T" handle (A) all the way out (counter clockwise) before attaching charging & gauging kit to accumulator gas valve.
- ③ Close bleed valve (B).
- ④ Making sure not to loop or twist the hose, attach swivel nut (C) to gas valve and tighten 11.5~17 kgf·cm (10~15 lbf·ft).
- ⑤ Turn gas chuck "T" handle (A) until the gauge starts showing the pressure in the accumulator. Do not turn the "T" handle all the way down, as it will damage the valve core.
- ⑥ Crack open nitrogen bottle valve (D) and slowly fill accumulator. Shut off when gauge indicates desired pre-charge.
- C Let the pre-charge set for 10 to 15 minutes.

 This will allow the gas temperature to stabilize.

 If the desired pre-charge is exceeded, close
 nitrogen bottle valve (D), then slowly open
 bleed valve (B). Do not reduce pre-charge by
 depressing valve core with a foreign object.
 High pressure may rupture rubber valve seat.
- ⑧ When finished pre-charging accumulator, turn "T" handle (A) all the way out on gas chuck, then open bleed valve (B).
- ④ Hold gas valve to keep from turning, loosen swivel nut (C), remove assembly. Check for pre -charge leak using a common leak reactant.
- Replace gas valve cap 11.5~17 kgf·cm (10~15 lbf·ft) and valve guard. (Gas valve cap serves as a secondary seal.)

(2) Pre-charge checking procedure

Using appropriate valve in the hydraulic system, discharge all oil from accumulator and allow piston to bottom against hydraulic end cap.





(3) Structure



1 Body

3

4

5

- 5A V-O-ring back-up washers
- 2 Hydraulic cap Gas cap

Piston

- 6 Piston ring (piston)
- 7 O-ring
 - 7A O-ring back-up washer
- V-O-ring
- 8 Gas valve

2) REMOVE FROM HYDRAULIC SYSTEM

A Attention

- 1) Before carrying out any maintenance work the accumulators must be unloaded (zero pressure).
- 2) For this, unscrew the plug (A) then rotate the drain screw (B), located under the plug (A), 2 turns anti-clockwise with 3 mm L-wrench.
- 3) The lifting system must firstly be secured against lowering.
- 4) After carrying out maintenance work, screw the plug (A) and drain screw (B).
 - · Tightening torque
 - A: 0.51 kgf · m (3.69 lbf · ft)
 - B: 0.36 kgf · m (2.58 lbf · ft)



8A Gas valve O-ring

- 9 Gas valve guard
- 9A Screw

GROUP 2 OPERATIONAL CHECKS AND TROUBLESHOOTING

1. OPERATIONAL CHECKS

This procedure is designed so the mechanic can make a quick check of the system using a minimum amount of diagnostic equipment. If you need additional information, read structure and function, Group 1.

A location will be required which is level and has adequate space to complete the checks.

The engine and all other major components must be at operating temperature for some checks.

Locate system check in the left column and read completely, following the sequence from left to right. Read each check completely before performing.

At the end of each check, if no problem is found (OK), that check is complete or an additional check is needed. If problem is indicated (NOT OK), you will be given repair required and group location. If verification is needed, you will be given next best source of information:

- · Chapter 2 : Troubleshooting
- · Group 3 : Tests and adjustments

Hydraulic oil must be at operating temperature for these checks (refer to page 6-54).

Item		Description	Service action
Hydraulic system warm-up procedure		Hold a hydraulic function over relief to heat oil. (don't keep relief condition over 5 seconds at a time)	OK Check completed.
nun ongino at ngri ulo.		Periodically cycle all hydraulic functions to distribute warm oil.	
		Repeat procedure until oil is at operating temperature.	
		FEEL : Hydraulic reservoir must be uncomfortable to hold your hand against. (approximately 40 ~50°C)	
Hydraulic pump performance check		With bucket flat on ground, actuate boom raise. Time how long it takes to raise boom to full height.	OK Check completed.
operating temperature. Run engine at high idle.		LOOK : Boom must raise to full height in less than 7 seconds.	Go to priority valve (in flow amplifier) high pressure check at page 5-31.
			IF OK Do steering system leakage check at page 5-30.
			IF OK Do main hydraulic pump flow test at page 6-55.
Control valve lift check Run machine at low idle.		With bucket partially dumped, lower boom to raise front of	OK Check complete.
		machine.	NOT OK
		Slowly move boom control lever (RCV lever) to boom lower position.	Repair lift checks in loader control valve.
		Slowly move bucket control lever to bucket dump position.	
		LOOK : Boom must not raise before moving down.	
		Bucket must not rollback before dumping.	

Item	Description		Service action
Bucket rollback circuit relief valve check	¢	Position bucket at a 45° angle against an immovable object.	OK Check complete.
		Engage transmission in 3rd speed forward.	NOT OK Replace boom lower
		LOOK : Bucket angle must not change.	check valve.
Bucket dump circuit relief valve low pressure check	∕₹₹ ∎ Let a	Raise front of machine which bucket at 45° angle.	OK Go to next check.
	POLO	Backdrag with bucket while observing bucket angle.	NOT OK Do loader system and
		LOOK : Bucket must not rollback	circuit relief valve test at page 6-59.
Pilot control valve float check		With the bucket partially dumped, lower boom to raise front of	OK Check complete.
Run engine at low idle.	DOTO	machine. Push control lever to the float detent position and release lever.	NOT OK Do pilot control valve pressure test in group 3.
		LOOK : Front of machine lower to the ground and valve must remain in float position when lever is released.	
Boom cylinder and bucket cylinder drift		Set the boom and bucket horizontal, then stop the engine.	OK Check complete.
check Heat hydraulic oil to		Stop the engine, wait for 5 minutes, then start measuring.	NOT OK Go to next check.
operating temperature.		Measure the amount the lift and dump cylinder rods retract during 15 minutes. (unloaded bucket)	
		A : Retraction of boom cylinder rod	
		B : Retraction of bucket cylinder rod	
		Boom cylinder must drift less than 30 mm	
		Bucket cylinder must drift less than 15 mm	

Item	Description		Service action
Boom cylinder leakage check Heat hydraulic oil to operating temperature.		Dump bucket until teeth or cutting edge is perpendicular to the ground. Raise boom until cutting edge is	OK Drift is approximately the same between first and second measurement.
		Stop engine. Measure drift from tooth or cutting edge to ground for 1 minute. Wait 10 minutes. Measure drift from tooth or cutting edge to ground for 1 minute. LOOK : Compare the drift rate between the first measurement and the second measurement	Repair loader control valve or circuit relief valve. NOT OK If drift is considerably less on second measurement, repair cylinder.
Bucket cylinder leakage check Heat hydraulic oil to operating temperature		Raise bucket about 1 m (3 ft) off ground with bucket level. Stop engine. Place a support under boom	OK Drift is approximately the same between first and second measurement.
operating temperature.		Measure drift from tooth or cutting edge to ground for 1 minute. Wait 10 minutes.	Repair loader control valve or circuit relief valve at page 6-59.
		Measure drift from tooth or cutting edge to ground for 1 minute. LOOK : Compare the drift rates	NOT OK Drift is considerably less on second measurement.
		between the first measurement and the second measurement.	Repair cylinder.
Check valve of safety valve leakage check		Put bucket level and position about 1.2 m (4 ft) above ground.	OK Check complete.
Heat hydraulic oil to operating temperature.	Surger Statement	Place a piece of tape on cylinder rod at least 51 mm (2 in) from rod guide. Run engine at low idle in safety- release position.	NOT OK Check or replace safety valve.
		LOOK : Bucket must not drift up.	
Pilot control valve	999	Stop engine. Turn key switch to OFF position.	OK Check completed.
		Move control lever to all positions and then release. LOOK : Lever must return to neutral when released from all	NOT OK Repair pilot control valve.
		positions.	
ltem	Description		Service action
--	----------------------------	---	--
Bucket leveler (positioner) check		Position bucket fully dumped just above ground level.	OK Check complete.
Run engine at low idle.		Move control lever to bucket leveler detent position and release.	NOT OK Do bucket leveler checks.
		LOOK : Bucket must rollback to the level position and control lever must return to neutral. If bucket is in a rolled back position when key is turned ON, control lever must be returned to neutral manually if placed in the bucket leveler detent position.	
		After bucket is dumped once, bucket leveler will work normally.	
Boom height kickout		Position bucket flat on ground.	ОК
check	000	Move control lever to boom raise	Check complete.
Run engine at low idle.		detent position and release.	NOT OK Do boom height kickout
		LOOK : Boom must raise to the set height and stop.	check.
		Control lever must return to neutral.	
Cycle time check	Function	Operating condition.	Maximum cycle time
Heat hydraulic oil to	Boom raise	Bucket flat on ground to full height.	6.6 sec
operating temperature. Run engine at high idle.	Boom lower	Full height to level ground.	4.8 sec
	Bucket dump	Boom at full height.	1.5 sec
	Bucket rollback	Boom at full height.	1.9 sec
	Steering [No. of turns]	Frame stop to frame stop.	4.7 turns
			OK Check complete.
			NOT OK Go to slow hydraulic functions in group 2.

*** MEASURING BOOM AND BUCKET CYCLE TIME**

1) MEASUREMENT CONDITION

- · Coolant temperature : Inside operating range
- · Steering position : Neutral
- · Hydraulic temperature : 40~50°C
- · Bucket : Unloaded
- · Engine speed : High idling

2) MEASURING TOOL

· Stop watch (1EA)

3) MEASURING PROCEDURE

(1) LIFTING TIME OF BOOM

Set the bucket near the maximum tilt back position and at the lowest position on the ground. Raise the bucket and measure the time taken for bucket to reach the maximum height of the boom.



(2) LOWERING TIME OF BOOM

Set the bucket horizontal with the boom at the maximum height, lower the bucket and measure the taken for the bucket to reach the lowest position on the ground.



(3) DUMPING TIME OF BUCKET

Raise the boom to the maximum height and measure the time taken for the bucket to move from the maximum tilt back position to the maximum dump position

(4) ROLL BACK TIME OF BUCKET

Raise the boom to the maximum height and measure the time taken for the bucket to reach the maximum tilt back position.



2. TROUBLESHOOTING

* Diagnose malfunction charts are arranged from most probable and simplest to verify, to least likely, more difficult to verify. Remember the following steps when troubleshooting a problem :

Step 1. Operational check out procedure (see section 1) Step 2. Operational checks (see group 2) Step 3. Troubleshooting

Step 4. Tests and adjustments (see group 3)

Problem	Cause	Remedy
Noisy hydraulic pump	Low oil supply or wrong viscosity.	Fill reservoir with recommended oil.
	Plugged or pinched suction line.	Clean or replace line.
	Air in oil.	Check for foamy oil. Tighten connections. Replace O-rings and or lines.
	Plugged suction strainer.	Inspect and clean strainer in reservoir.
	Loose or missing hydraulic line clamps.	Tighten or replace clamps.
	Hydraulic lines in contract with frame.	Inspect and repair.
	Worn or damaged pump.	Do hydraulic pump performance check in group 2. Do hydraulic pump flow test in group 3.
No or Slow hydraulic	Failed or worn hydraulic pump.	Do performance check.
functions	Cold oil.	Warm oil up.
	Slow engine speed.	Adjust engine speed. Check high idle speed.
	Suction line air leak.	Check for foamy oil.
	Low oil supply.	Add recommended oil.
	Wrong oil viscosity.	Use recommended oil.
	Oil leaking past cylinders or control valve.	Check cylinder drift in group 2.
	Blocked or damaged line.	Inspect lines.
	Faulty pilot control valve (RCV).	Do pilot control valve (RCV) pressure test in group 3.
	Binding loader control valve (MCV) spool.	Inspect valve.
	Faulty flow amplifier.	Check priority valve, orifice of flow amplifier specification.

Problem	Cause	Remedy
No steering or hydraulic	Low oil level.	Add recommended oil.
function	Failed hydraulic pump.	Remove and inspect return filter for metal pump particles.
No hydraulic functions steering normal	Failed hydraulic pump.	Remove and inspect return filter for metal pump particles, or replace the pump.
	Failed line filter.	Remove and inspect line filter for RCV.
	Faulty safety valve.	Safety valve leakage test or ON, OFF function test.
	Stuck open port relief valve.	Replace relief valve.
Boom float function does not work	Low pilot control pressure.	Do pressure reducing valve pressure test in group 3.
	Faulty pilot control valve (RCV).	Replace relief valve.
	Loader control valve (MCV) spool binding in bore.	Do pressure reducing valve pressure test in group 3.
One hydraulic function does not work.	Faulty pilot control valve (RCV).	Do pilot control valve pressure test. Inspect and repair valve.
	Stuck open port relief valve.	Replace relief valve.
	Oil leaking past cylinder packings.	Do boom and bucket cylinder leakage test in group 3.
	Blockage in oil lines or valve.	Inspect lines for damage. Disconnect and inspect lines for internal blockage.
	Loader control valve (MCV) spool stuck in bore.	Inspect and repair valve.
Low hydraulic power	Leakage within work circuit.	Do cylinder drift check in group 2.
	Low system relief valve (main relief valve) setting.	Do loader system and port relief valve pressure test in group 3.
	Low port relief valve setting.	Do loader system and port relief valve pressure test in group 3.
	Leaking system relief valve.	Remove and inspect valve.
	Worn hydraulic pump.	Do hydraulic pump performance check in group 2.
	Faulty pilot control valve (RCV).	Do pilot control valve pressure test in group 3.

Problem	Cause	Remedy
Function drifts down	Leaking cylinders.	Do cylinder leakage checks in group 3.
	Leaking seals in circuit relief valve (port relief valve) or valve stuck open.	Inspect seals. Replace relief valve.
	Leaking loader control valve (MCV).	Repair or replace valve section.
Boom drifts up	Leakage in boom down spool.	Remove and inspect boom down spool.
Boom down does not	Safety valve not operated.	Operate valve.
work (engine off)	Stuck pilot control valve.	Inspect.
	Faulty line filter.	Remove and inspect filter.
	Accumulation not operated.	Inspect.
	MCV spool stuck.	Inspect and repair valve.
Oil overheats	Low oil viscosity in hot weather.	Use recommended oil.
	Excessive load.	Reduce load.
	Holding hydraulic system over relief.	Reduce load.
	Leakage in work circuit.	Do boom and bucket cylinder leakage test in group 3.
	Plugged fins in oil cooler.	Inspect and clean oil cooler.
	Internally plugged oil cooler.	Do hydraulic oil cooler restriction test.
	Incorrect system or circuit relief valve setting.	Do loader system and circuit relief valve pressure test in group 3.
	Restriction in oil lines or loader control valve (MCV).	Inspect for dented or kinked lines.
	Malfunctioning steering valve.	Do hydraulic system restriction test in group 3.
	Leaking system main relief valve.	Do hydraulic system restriction test in group 3. Remove and inspect valve and seals.
	Worn hydraulic pump (internal leakage).	Do hydraulic pump performance check in group 2.
Function drops before raising when valve is activated	Stuck open lift check valve.	Do control valve lift check in group 2.

Problem	Cause	Remedy
Hydraulic oil foams	Low oil level.	Add recommended oil.
	Wrong oil.	Change to recommended oil.
	Water in oil.	Change oil.
	Loose or faulty suction lines (air leak in system).	Tighten or install new lines.
Remote control valve (RCV) leaking	Leaking plunger seals.	Remove, inspect and replace plunger seals.

- * Followings are general precautions for the hydraulic system and equipment.
- Every structure has its limit of strength and durability. The relief valve is installed to limit the pressure on the hydraulic equipment and protect various parts of the wheel loader from possible damage. Therefore, never change the preset pressure of the relief valve unless absolutely necessary.
- 2) Since the hydraulic equipment is built with precision, the presence of only the slightest amount of dust and / or other particles in the hydraulic circuit might cause wear and/or damage, resulting in unstable functions and/or damage, resulting in unstable functions and/or unexpected accidents. Therefore, always keep hydraulic oil clean. Periodically, check the filter in the return circuit and replace the element as necessary.
- 3) Extract about 200cc of hydraulic oil from the tank as a sample every 6 months. If possible, have it analyzed by a specialist to confirm that the oil can still be used. Never extract the oil for sampling until the oil temperature has become the normal operating temperature. Since the replacement period varies depending on operating conditions, refer to **Operator's Manual** and change oil.
- 4) Should the equipment get damaged due to the presence of metal particles and/or foreign matter in the circuit drain out the hydraulic oil and carry out flushing. Also, replace the filter element and clean the hydraulic tank. Change the hydraulic oil entirely.
- 5) When checking the filter, if found metal particles in the element, drain out the hydraulic oil entirely, flush the whole circuit, and then fill with new oil. The presence of metal particles may indicate internal damage to the equipment. In such a case, check carefully before flushing, and repair or replace as required.
- 6) To add and/or change the hydraulic oil, always use recommended oil. (Refer to the list of recommended oils and lubricants at page 1-20, **Recommended lubricants.**) Never mix oil of different makes of kinds.
- 7) To change the hydraulic oil, use a clean vessel and funnel for pouring it into the tank. Never use cloth because it might cause the presence of lint in the circuit.
- 8) When removing the hydraulic equipment, be sure to put plugs or caps on hoses, tube lines and ports. Also, enter mating marks for later identification.

- 9) Disassemble and/or assemble the hydraulic equipment only in a clean place free of dust. When disassembling, be careful about the interchangeability of parts, and clean the disassembled parts with pure and clean mineral cleansing oil. Clean the internal passages as well. After the parts have dried, wipe them off with a clean lint-free cloth.
- 10) When overhauling the hydraulic equipment replace all O-rings, backup rings, etc. with new ones. Assemble O-rings with grease or vaseline applied.
- 11) After installing the equipment, add more hydraulic oil to make up for that lost during disassembly.
- 12) Tighten joints correctly. Loose joints will cause the hydraulic oil to leak. If the oil leaks, the tank oil level drops and air gets sucked in, so the pump will break down. Also loose joints in suction lines will take air in and might cause abnormal noise, malfunction or damage to pumps.

GROUP 3 TESTS AND ADJUSTMENTS

1. HYDRAULIC OIL CLEAN UP PROCEDURE USING PORTABLE FILTER CADDY

- * Service equipment and tool
 - · Portable filter caddy
 - \cdot Two 4000 mm \times 1in 100R1 Hoses
 - · Quick disconnect fittings.
 - · Discharge wand
 - · Various size fittings.
- Brake system uses oil from hydraulic oil tank. Flush all lines in the brake, pilot, steering system and cut off system. Disassemble and clean major components for brake and steering system. Remove and clean pilot caps from main control valve.

Brake and steering components may fail if brake and steering system is not cleaned after hydraulic oil tank contamination.

- If hydraulic system is contaminated due to a major component failure, remove and disassemble steering cylinders to clean debris from cylinders.
- 2) Install a new return filter element. Inspect filter housing before installing new element.
- * For a failure that creates a lot of debris, remove access cover from hydraulic oil tank. Drain and clean hydraulic oil tank of fill the specified oil to hydraulic oil tank through upper cover.
- To minimize oil loss, pull a vacuum in hydraulic oil tank using a vacuum pump. Connect filter caddy suction line to drain port at bottom of hydraulic oil tank using connector. Check to be sure debris has not closed drain port.
- Put filter caddy discharge line into hydraulic oil tank filler hole so end is as far away from drain port as possible to obtain a thorough cleaning of oil.

5) Start the filter caddy. Check to be sure oil is flowing through the filters.

Operate filter caddy approximately 10 minutes so oil in hydraulic oil tank is circulated through filter a minimum of four times.

※ Hydraulic oil tank capacity : 184 ℓ (48.6 U.S. gal)

Leave filter caddy operation for the next steps.

- 6) Start the engine and run it at high idle.
- For the most effective results, cleaning procedure must start with the smallest capacity circuit then proceed to the next largest capacity circuit.
- 7) Operate all functions, one at a time, through a complete cycle in the following order: Clam, steering, bucket, and boom. Also include all auxiliary hydraulic functions. Repeat procedure until the total system capacity has circulated through filter caddy seven times, approximately 30 minutes. Each function must go through a minimum of three complete cycles for a through cleaning for oil.
- Filtering time for machines with auxiliary hydraulic functions must be increased because system capacity is larger.
- 8) Stop the engine. Remove the filter caddy.
- 9) Install a new return filter element.
- 10) Check oil level in reservoir; Add oil if necessary.

2. BOOM HEIGHT KICKOUT ADJUSTMENT

The bucket can be adjusted to a height desired by using the boom kick-out device.

- A Park the machine on level ground and block the tires to prevent sudden movement of the machine.
- A Press the parking brake switch.
- ▲ Fix the front and rear frames by using the safety lock bar.
- ▲ Do not work underneath the work equipment.

1) ADJUSTMENT OF THE BOOM KICKOUT AND BUCKET LEVELER

(1) Lift kickout position

To set the lift kickout, raise the bucket to the desired position above the midway point. Then push icon (, A) for 2~3 seconds. The boom will return to the programmed position when the raise detent is activated and the boom is below the kickout position.

(2) Lower kickout position

To set the lower kickout, lower the bucket to the desired position below the midway point. Then push icon (, A) for 2~3 seconds. The boom will return to the programmed position when the float detent is activated and the boom is at least a foot above the kickout position.

(3) Bucket leveler position

To set the bucket leveler, roll back the bucket to the desired position. Then push icon (, B) for 2~3 seconds. The bucket will return to the programmed position when the roll back detent is activated and the bucket is below the leveler position.



3. TEST TOOLS

1) CLAMP-ON ELECTRONIC TACHOMETER INSTALLATION

- · Service equipment and tools Tachometer
- A : Clamp on tachometer.

Remove paint using emery cloth and connect to a straight section of injection line within 100 mm (4 in) of pump. Finger Tighten only-do not over tighten.

- B : Black clip (-). Connect to main frame.
- C : Red clip (+). Connect to transducer.
- D: Tachometer readout. Install cable.



2) DIGITAL THERMOMETER INSTALLATION

- · Service equipment and tools Digital thermometer
- A : Temperature probe. Fasten to a bare metal line using a tie band. Wrap with shop towel.
- B : Cable.
- C : Digital thermometer.



3) DISPLAY MONITOR TACHOMETER

The display monitor tachometer is accurate enough for test work.



4. HYDRAULIC OIL WARM UP PROCEDURE

- 1) Install temperature reader (see temperature reader installation procedure in this group).
- 2) Run engine at high idle.
- 3) Hold a hydraulic function over relief to heat the oil.
- Periodically cycle all hydraulic functions to distribute warm oil.
- 5) Heat oil to test specification (approx. 45°C).

* Ride control system (option)

Attention

- 1) Before carrying out any maintenance work the accumulators must be unloaded (zero pressure).
- For this, unscrew the plug (A) then rotate the drain screw (B), located under the plug (A), 2 turns anti-clockwise with 3 mm L-wrench.
- 3) The lifting system must firstly be secured against lowering.
- 4) After carrying out maintenance work, screw the plug (A) and drain screw (B).
 - Tightening torque
 A : 0.51 kgf · m (3.69 lbf · ft)
 - B: 0.36 kgf · m (2.58 lbf · ft)



5. MAIN HYDRAULIC PUMP FLOW TEST

· SPECIFICATION

Oil temperature $45\pm5^{\circ}C (113\pm9^{\circ}F)$ Engine speed $2100\pm25 \text{ rpm}$ Test pressure $280\pm5 \text{ bar} (3980 \text{ psi})$ Maximum pump flow $441 \ell / \text{min} (117 \text{ gpm})$ (steering+loader pump)

- FLOW METER, GAUGE AND TOOL Gauge 0~35 MPa (0~350 bar, 0~5000 psi) Temperature reader
- 1) Make test connections.
- Install temperature reader.
 (see temperature reader installation procedure in this group)
- Heat hydraulic oil to specifications. (see hydraulic oil warm up procedure in this group)
- 4) Run engine at test specifications.
- 5) Close flow meter loading valve to increase pressure to test specifications.
- 6) Read flow meter.
- If flow is below specifications, check suction line and suction pressure for abnormality before removing pump.



6. LOADER SYSTEM AND PORT RELIEF VALVE PRESSURE TEST

· SPECIFICATION

Oil temperature (40~50°C)

Relief valve	Engine speed	Relief pressure
System (M)	Low	280±5 kg/cm² (3980±70 psi)
Boom raise (U)	Low	340±10 kg/cm² (4840±140 psi)
Bucket rollback (R)	Low	340±10 kg/cm² (4840±140 psi)
Bucket dump (D)	Low	300 ± 10 kg/cm ² (4267 \pm 140 psi)

- Gauge and tool
 - Gauge 0~35 MPa (0~350 bar, 0~5000 psi)
 - M : System (main) relief valve
 - R : Bucket rollback relief
 - D : Bucket dump relief
 - U : Boom raise relief
- 1) Install fitting and pressure gauge to test port in pump delivery line.
- Install temperature reader. (see temperature reader installation procedure in this group)
- Heat hydraulic oil to specifications.
 (see hydraulic oil warm up procedure in this group)
- 4) To check the system relief (M), run engine at low idle. Lower boom to bottomed position.

Slowly activate boom down function while watching pressure gauge. If pressure is not to specification, loosen lock nut on system relief valve (M) and adjust to specification.



* Do not adjust the system relief valve above 280 kg/cm² (3980 psi). Damage to the pump will result from excessive pressure settings.

7. HYDRAULIC SYSTEM RESTRICTION TEST

· SPECIFICATION

Oil temperature 45±5°C(113±9°F) Engine speed High idle Maximum pressure 4.5 MPa (45 bar, 640 psi) at flow amplifier. Maximum pressure at main control valve 1 MPa (10 bar, 145 psi)

· GAUGE AND TOOL

Gauge 0~7 MPa (0~70 bar, 0~1000 psi) 2EA This test will check for restrictions in the hydraulic system which can cause overheating of hydraulic oil.

- Install temperature reader. (see temperature reader installation procedure in this group)
- Heat hydraulic oil to specifications.
 (see hydraulic oil warm up procedure in this group)
- 3) Connect fitting and gauge to steering valve.
- 4) Connect fitting and gauge to main control valve.
- A Do not operate steering or loader functions or test gauge may be damaged.
- 5) Run engine at specification and read pressure gauges.

If pressure is more than specification at the loader control valve, check for a kinked, dented or obstructed hydraulic line. Check loader control valve for a binding spool.

If pressure is more than specification at the steering unit, inspect neutral condition of the steering unit and flow amplifier for a stuck spool. Make sure orifice plugs are installed in ends of priority valve spool.

Check for plugged orifice in priority valve and dynamic signal orifice on flow amplifier body.



8. LOADER CYLINDER DRIFT TEST

· SPECIFICATION

Oil temperature 45±5°C(113±9°F) Boom horizontal Bucket horizontal Bucket unloaded

Item	Standard value
Retraction of boom cylinder rod	30 mm
Retraction of bucket cylinder rod	15 mm

- GAUGE AND TOOL Stop watch Temperature reader
- A Put the safety lock lever in the lock position.
- A Do not go under the work equipment.
- 1) Set the boom and bucket horizontal, then stop the engine.
- 2) Stop the engine, wait for 5 minutes, then start measuring.
- 3) Measure the amount the boom and bucket cylinder rods retract during 15 minutes.



9. BOOM AND BUCKET CYLINDER LEAKAGE TEST

· SPECIFICATION

 Oil temperature
 45±5°C(113±9°F)

 Engine speed
 Low idle

 Maximum leakage
 15 m ℓ /min (1/2 oz/min)

GAUGE AND TOOL Temperature reader Stop watch Measuring container

- 1) Fasten temperature sensor to head end port of cylinder to be tested. Cover sensor with a shop towel.
- Heat hydraulic oil to specifications (see hydraulic oil warm up procedure in this group).
- A Never work under raised equipment unless it is supported with a hoist or support stands.
- Full extend the cylinder to be tested. If testing the boom cylinders, restrain boom in the fully raised position using a hoist or a stand.
- * Check cylinders for leakage in the fully extended position only. In the retracted position contacts the end of the cylinder and seals off piston seal leakage.
- 4) Remove and plug cylinder rod end hose or line.
- Run engine at slow idle. Activate control lever to extend cylinder for 1 minute over relief while measuring leakage for open port.

If leakage is within specification, excessive cylinder drift is caused by leakage in the loader control valve or circuit relief valve.



10. PILOT CONTROL VALVE (EH CONTROL BLOCK) PRESSURE TEST

· SPECIFICATION

Oil temperature45±5°C(113±9°F)Engine speedHigh idleMaximum pressure3.0 MPa (30 bar, 427 psi)

- GAUGE AND TOOL
 Gauge 0~7 MPa (0~70 bar, 0~1000 psi)
- 1) Lower boom to ground.
- 2) Connect gauge to the pilot pressure port of function to be checked.
- 3) Install temperature reader (see temperature reader installation procedure in this group).
- Heat hydraulic oil to specification (see hydraulic oil warm up procedure in this group).



11. CYCLE TIME TEST

· SPECIFICATION

Oil temperature $-45\pm5^{\circ}C(113\pm9^{\circ}F)$

Engine speed —— High idle

Function	Operating conditions	Maximum cycle time (seconds)
Boom raise	Bucket flat on ground to full height	6.6
Boom lower (float)	Full height to ground level	4.8
Bucket dump	Boom at full height	1.5
Bucket rollback	Boom at full height	1.9
Steering (number of turns)	Frame stop to stop	4.7 turns

12. HYDRAULIC OIL FILTER INSPECTION PROCEDURE

- Lower the bucket to the ground, stop the engine, move the control lever back and forth several times, and clean all over the upper surface of the hydraulic oil tank.
- 2) Remove the bolts and take out the filter case cover and O-ring.
- 3) Remove the spring and bypass valve.
- 4) Remove the filter element from the tank.
- 5) Check the element and the filter case bottom for debris. Excessive amounts of brass and steel particles can indicate a failed hydraulic pump or a pump failure in process. A rubber type of material can indicated cylinder packing or other packing failure.
- * The hydraulic oil filter in the filter case of the hydraulic oil tank should be replaced every 250 operating hours or more often. When the filter element is replaced, please keep as follows.
- (1) Clean the inside of the filter case.
- (2) Place new element in the proper positions inside the filter case.
- (3) Install the bypass valve and spring. Make sure the element stand upright, and check for complete contact of the element bottom with the filter case bottom.
- (4) Install the O-ring and filter case covers. Tighten them with bolt. Replace the O-ring with new one if damaged.



GROUP 4 DISASSEMBLY AND ASSEMBLY

1. MAIN PUMP (STEERING PUMP, LOADER PUMP)

1) STRUCTURE



- 1 Rotary group
- 1-1 High speed rotary group
- 1-2 Control plate
- 2 Adjusting piece
- 5 Pump housing
- 6 Port plate
- 7 Swash plate

- 8 Drive shaft
- 12 Adjustment shim
- 15 Taper roller bearing
- 16 Taper roller bearing
- 17 Bearing liner
- 20 Shaft seal ring
- 22 O-ring

- 23 O-ring
- 25 V-ring
- 27 Socket screw
- 30 Locking screw
- 31 Double break-off pin
- 33 Cylinder pin
- 51 Control valve

2) GENERAL REPAIR GUIDELINES

- ※ Observe the following guidelines when carrying out repairs on hydraulic pumps.
- (1) Close off all openings of the hydraulic unit.
- (2) Replace all of the seals.Use only original spare parts.
- (3) Check all sealing and sliding surfaces for wear.
- Re-work of the sliding surfaces by using, for example abrasive paper, can damage the surface.
- (4) Fill the hydraulic pump with hydraulic oil before commissioning.

3) SEALING THE DRIVE SHAFT

- Protect the drive shaft. Remove the circlip. Remove the shaft seal.
 - 1 Circlip 2 Shaft seal



(2) Change the shaft seal and check its sliding surface (drive shaft) and housing, grease the sealing ring.



(3) Assemble the sealing ring, fitting tool holds the correct position of the sealing ring in the pump housing.

Assemble the circlip in the correct position.



4) SEALING/CLEANING THE CONTROL VALVE

- (1) Disassemble the control valve.
- Measure dimension A and note down.
 Check sealing surface (1).



5) DISASSEMBLE THE PUMP

(1) Remove the control valve.



(2) Mark the location of the connection plate on the housing.



- (3) Remove the connection plate fixing bolts and the connection plate.
- Distributor plate and adjustment piston can drop down.



- (4) Remove distributor plate.Take note of the orientation.
- Remove bearing with withdrawal tool.Do not damage the sealing surface.



(5) Remove the rotary group in a horizontal position.



(6) Remove swash plate and bearing shells.



(7) Remove the circlip and the shaft seal.



(8) Remove the drive shaft through rear side.



(9) Pre-tension the spring (1) using a suitable device.Remove circlip (2).Remove spring (1) and pressure pins (3).



(10) Use bearing puller to remove outer bearing race of front bearing out of housing press seat.



(11) Remove the control plate.



(12) Use bearing puller to remove outer bearing race of rear bearing - press seat.



(13) Disassemble the guide of control piston (Mounting position: pilot valve side).



(14) Disassemble the guide of the opposite piston.



6) INSPECT HINTS

(1) Renew all bearings.



(2) Check :

- 1 Wear on splines, rust
- 2 Drive shaft seal wear grooves
- 3 Bearing seat
- 4 Splines for cylinder drive
- 5 Bearing seat



(3) Check : Sliding surface free of grooves.



(4) Check : Bearing surfaces.



(5) Check :

That the retaining plate is free of grooves and that there is no wear in the slipper pad area.



(6) Check :

Check to see that there are no scratches or metal deposits on the sliding surface (1) and that there is no axial play (2) (Pistons must only be replaced as a set).



(7) Check :

- 1 Cylinder bores
- 2 Splines



(8) Free of grooves, no signs of wear.



(9) Check :

Cylinder sliding surface free of grooves, no wear, no embedded foreign particles. That there are no scratches on the control plate. (Only replace them as a set).



(10) Check :

Mounting surface - control plate undamaged.



(11) Check :

Check running conditions of the control piston.



(12) Check :

Check running conditions of the opposite piston.



7) ADJUSTMENT OF TAPER ROLLER BEARING SET

 Cast iron housing must have initial tension of the bearings: 0~0,05 mm, grind position A if necessary.



8) PUMP ASSEMBLY

(1) Fit the seal into the housing. Fit the circlip.



- (2) Fit the drive with bearing from rear end.
- ※ Do not touch seal lip with edge of keyway or spline.



(3) Fit pressure pins using an assembly aid.



(4) Pre-tension the spring using a suitable device.



- (5) Assemble piston with retaining plate.
- * Oil piston and slipper pad.



- (6) Fit rotary group.
- Hold the piston by using an O-ring. Fit O-ring (1).



(7) Fit bearing (1) in connection plate.
Fit cyilindrical pin (2).
Fit O-rings (3) 4 pieces.
Fit adjustment spool (4) and guide piston (4a).

Fit distributor plate (5) (direction of rotation dependent)

* Assembly.

Hold the components in place with grease.



- (8) Fit distributor plate.
- * Assembly aid : Grease



(9) For clockwise rotation pumps the distributor plate is off-set by 4° to the right from the centre position.
(Clockwise and anti-clockwise rotation distributor plates are not identical).



(10) Fit connection plate and control valve.



2. MAIN CONTROL VALVE

1) STRUCTURE (1/2)



78096WE13

- 11 Housing
- 30 O-ring
- 31 O-ring
- 32 O-ring
- 33 O-ring
- 35 O-ring
- 36 O-ring
- 37 O-ring

- 38 O-ring
- 50 Housing
- 60 Plate
- 61 Stud
- 62 Hexagon nut
- 63 Washer
- 65 Sandwich plate
- 71 Shuttle valve

- 74 Compensator valve
- 79 Pressure valve
- 80 Plug screw
- 84 Flow regulator
- 85 Precharge valve
- 86 Pressure reducing valve
- 102 Locking screw
- 165 Pressure relief valve

STRUCTURE (2/2)

21

23

Throttle check valve

Threaded steel pipe fitting



6-78

44

50

Spool

Housing
2) GENERAL PRECAUTIONS

- (1) Clean room with no dust is recommended for maintenance. Because hydraulic components are precision, and have minute clearance. Tool and wash-oil must be clean, too. Handle them carefully.
- (2) At removing control valve from the machine, wash around the piping port, and neither dust nor water should go into inside with plugging. It is same at attaching the machine.
- (3) Prepare the required parts by checking structure figure before assembly. There are parts which are supplied with only sub-assembly part, so check the parts list before assembly.

3) PRECAUTIONS FOR DISASSEMBLY

- (1) Handle the components carefully not to drop them or bump them with each other as they are made with precision.
- (2) Do not force the work by hitting or twisting as burred or damaged component may not be assembled or result in oil leakage or low performance.
- (3) When disassembled, tag the components for identification so that they can be reassembled correctly.
- (4) Once disassembled, O-ring and back-up rings are usually not to be used again.(Remove them using a wire with its end made like a shoe-horn. Be careful not to damage the slot)
- (5) If the components are left disassembled or half-disassembled, they may get rust from moisture or dust. If the work has to be interrupted, take care to prevent rust and dust.

4) PRECAUTIONS FOR REASSEMBLY

- (1) Take the same precautions as for disassembly.
- (2) When assembling the components, remove any metal chips or foreign objects and check them for any burrs or dents. Remove burrs and dents with oil-stone, if any.
- (3) O-rings and back-up rings are to be replaced with new ones, as a rule.
- (4) When installing O-rings and back-up rings, be careful not to damage them. (Apply a little amount of grease for smoothness)
- (5) Tighten the bolts and caps with specified torque.

5) DISASSEMBLY AND ASSEMBLY

(1) Spool

1 Loosen the bolt (2EA). ·Tool : Wrench 5 mm ·Tightening torque : 0.85 kgf·m (6.1 lbf·ft)



76096WE40

2 Remove the cover, spring retainer, spring and spool.



76096WE41

- Spring 1
- Spring ratainer 2
- Spool 3
- Cover 4
- Bolt 5



(2) Compensator valve

·Tool : Spanner 42 mm



76096WE43

·Tightening torque : 20.4 kgf·m (148 lbf·ft)



76096WE44



76096WE45





76096WE47

(3) Port relief valve ·Tool : Spanner 30 mm

> ·Tightening torque : 10.2 kgf·m (73.8 lbf · ft)

(4) Precharge valve

·Tool : Spanner 32 mm

•Tightening torque : 6.1 kgf·m (44.3 lbf·ft)



76096WE48



76096WE49



76096WE50

(5) Shttle valve

·Tool : Spanner 22 mm

•Tightening torque : 3.6 kgf·m (25.8 lbf·ft)

SECTION 7 ELECTRICAL SYSTEM

Group	1 Component Location	7-1
Group	2 Electrical Circuit	7-3
Group	3 Monitoring System	7-22
Group	4 Electrical Component Specification	7-72
Group	5 Troubleshooting	7-79

GROUP 1 COMPONENT LOCATION

1. LOCATION 1



960A7EL20

- 1 Kick down button
- 2 Horn button
- 3 FNR switch
- 4 FNR select button
- 5 Hone button
- 6 Multi function switch
- 7 Hazard switch

- 8 Gear select lever
- 9 Radio & USB player
- 10 Aircon & heater switch
- 11 Monitor
- 12 Starting switch Starting button (opt)
- 13 Work load button

- 14 Pilot cut off switch
- 15 Parking brake switch
- 16 SCR switch
- 17 Differential lock switch (opt)
- 18 Emergency test switch
- 19 Engine control unit (ECU)
- 20 Air compressor switch (opt)
- 21 Camera monitor

2. LOCATION 2



960A7EL21

- 1 Head lamp
- 2 Horn
- 3 Angle sensor
- 4 Work lamp
- 5 Machine control unit (MCU)
- 6 Transmission control unit (TCU)
- 7 Fuse and relay box

- 8 Master switch
- 9 Start relay
- 10 Fuel sender
- 11 Battery relay
- 12 Battery
- 13 Rear combi lamp
- 14 Number plate lamp
- 15 Camera (opt)
- 16 Work lamp
- 17 Control unit (electro hydraulic & joystick steering)
- 19 Engine hood open switch

GROUP 2 ELECTRICAL CIRCUIT

• ELECTRICAL CIRCUIT (1/3, machine serial No.: ~#0213)



7-3



20WD-95140-00



• ELECTRICAL CIRCUIT (2/3, machine serial No.: ~#0213)

7-4

20WH-95032



²⁰WD-95033-00







WORK LOAD SENSING OPTION HARNE
CN-171 R 510 POWER CONN. 2 B 512
REMOTE ADD CONN ROPS PILLAR
CN-13 B 516 PTI IN-CAB CONN. 2 G 518 3 G 518 3 Y 519







20WH-95014-00

MEMORANDUM

1. ILLUMINATION CIRCUIT

1) OPERATING FLOW



2) CHECK POINT

Engine	Key switch	Check point	Voltage
		① - GND (relay input)	
OFF	ON	② - GND (relay output)	20~25V
		3 - GND (to light)	

* GND : Ground

ILLUMINATION CIRCUIT



980A7EL04

2. HEAD LIGHT CIRCUIT

1) OPERATING FLOW

Main light switch on monitor --- Switch ON, Select head lamp --- MCU [CN-58A (A14)]

- --- Driving relay [CR-211 (87)] --- Multi function switch [CS-11(8)]
- -- Multi function switch MIDDLE [CS-11(7)] -- I/conn [CN-05 (32)]

LH Head light low beam ON [CL-03 (6)] RH Head light low beam ON [CL-04 (6)]

--- Multi function switch DOWN [CS-11(6)] [--- I/conn [CN-05 (31)]



I/conn [CN-05 (31)]
 LH Head light high beam ON [CL-03 (4)]

RH Head light high beam ON [CL-03 (4)]
 RH Head light high beam ON [CL-04 (4)]

Cluster high beam pilot lamp ON [CN-56 (5)]

2) CHECK POINT

Engine	Key switch	Check point	Voltage
		① - GND (relay input)	
	F ON	② - GND (relay output)	
		③ - GND (multi function input)	
		4 - GND (multi function output)	20~25V
OFF		5 - GND (multi function output)	
		6 - GND (low beam)	
		${ar {\mathbb T}}$ - GND (high beam)	
		⑧ - GND (passing B ⁺)	

※ GND : Ground

HEAD LIGHT CIRCUIT



980A7EL05

3. WORK LIGHT SWITCH

1) OPERATING FLOW

- % Main light switch on monitor : Select position lamp.
- (1) Work lamp switch (select Front)

MCU [CN-58B (B09)] - Front work lamp relay [CR-03 (87)] - I/conn [CN-07 (06)]

- --- LH Front work lamp ON [CL-32 (1)]
- RH Front work lamp ON [CL-33 (1)]

(2) Work lamp switch (select Rear)

MCU [CN-58B (B03)] -- Rear work lamp relay [CR-55 (87)] -- I/conn [CN-01 (05)]

- → I/conn [CN-24 (12)] → LH Rear work lamp ON [CL-46 (1)]
 - → RH Rear work lamp ON [CL-45 (1)]



2) CHECK POINT

Engine	Key switch	Check point	Voltage
	ON	1 - GND (work lamp power input)	20~25V
OFF		2 - GND (work lamp power output)	
OFF		\Im - GND (front work lamp)	
		4 - GND (rear work lamp)	

* GND : Ground





980A7EL06

4. STARTING CIRCUIT

1) OPERATING FLOW

Battery(+) terminal \rightarrow Fusible link [CN-351 (40A)] \rightarrow Master switch [CS-74 (1) \rightarrow (2)] \rightarrow I/conn [CN-01 (16, 17)] \rightarrow Fuse box [CN-36] \rightarrow Start switch [CS-02 (1)] \rightarrow ECM power relay [CR-30 (30)] \rightarrow Power relay [CR-35 (30)]

* The gear selector lever is neutral position. It is necessary condition before the starting. The gear selector has an output signal which is activated whenever the shift lever is in the neutral position. This signal can be used to control a relay and prevent engine from starting whenever the shift lever is not in the neutral position.

(1) When start key switch is in ON position

Start switch ON [CS-02 (2, 3)]
$$\rightarrow$$
 I/conn [CN-01(2)] \rightarrow Master switch [CS-75 (1) \rightarrow (2)] \rightarrow Battery relay [CR-1]

- -- Battery relay operating (All power is supplied with the electric component)
- -- ECM power relay [CR-30 (30) \rightarrow (87)] -- Fuse box [CN-37 (19)]
 - —— I/conn [CN-04 (29)] —— ECM [CN-J2 (3)]
- -- Fuse box [CN-37 (13)] -- MCU [CN-58A (A03)]
- Power relay [CR-35 (30) \rightarrow (87)] Fuse box [CN-37 (15)]
 - ---- TCU [CN-157 (45)]

(2) When start key switch is in START position

Start switch START [CS-2 (6)] \longrightarrow Start safety relay [CR-05 (30) \rightarrow (87)] \longrightarrow I/conn [CN-04 (20)] \longrightarrow Starter (terminal B⁺ and M connector of start motor)

2) CHECK POINT

Engine	Key switch	Check point	Voltage
	Running ON	① - GND (battery B ⁺)	
		② - GND (fusible link)	20~25 V
		③ - GND (start key B terminal)	
Bunning		4 - GND (start key BR terminal)	
i toi i iiig		⑤ - GND (i/conn CN-01 (16))	
		⑥ - GND (start key C terminal)	
		$\ensuremath{\overline{\mathcal{T}}}$ - GND (start safety relay output)	
		(\$) - GND (start key ACC terminal)	

* GND : Ground

* ECM : Electronic control module

* MCU : Machine control unit

* TCU : Transmission control unit

STARTING CIRCUIT



* The circuit diagram may differ from the equipment, so please check before a repair.

980A7EL07A

5. CHARGING CIRCUIT

When the starter is activated and the engine is started, the operator releases the key switch to the ON position.

Charging current generated by operating alternator flows into the battery through the battery relay (CR-01).

The current also flows from alternator to each electrical component and controller through the fuse box.

1) OPERATING FLOW

(1) Warning flow

- Altermator [CN-74 (1)] -- I/conn [CN-04 (18)] -- MCU [CN-58B (B33)]
- -- Cluster charge warning lamp ON

(2) Charging flow

- Alternator --- Starter [CN-45 (B⁺)] --- Battery relay [CR-01]
- Battery (+) terminal -- Charging
- Fusible link [CN-351 (40A)] → Master switch [CS-74 (1)→(2)] → I/conn [CN-01 (16, 17)]
 Fuse box [CN-36, 39]
- └─► Fusible link [CN-352 (80A)] ─► I/conn [CN-01 (21~26)] ─► Fuse box [CN-38, 39]

2) CHECK POINT

Engine	Key switch	Check point	Voltage
	ON	① - GND (battery)	20, 281/
OFF		2 - GND (battery relay)	
		③ - GND (alternator B ⁺)	20~20 V
		④ - GND (MCU)	

% GND : Ground

* MCU : Machine control unit

CHARGING CIRCUIT



6. ELECTRIC PARKING, PILOT CUT OFF CIRCUIT

1) OPERATING FLOW

(1) Parking OFF

Fuse box [CN-39 (41)] → Parking switch OFF → [CS-17 (5)→(4)] → I/conn [CN-05 (14)]



I/conn [CN-12 (13)]
 Parking solenoid ON (activated)

--- Parking brake released (by hydraulic pressure)

- [CS-17 (2)→(1)] -- T/M control unit [CN-157 (21)]

(2) Parking ON

Fuse box [CN-39 (41)] — Parking switch ON — Parking solenoid [CN-71] OFF — Parking brake applied [By spring force]

(3) Pilot cut off ON

Fuse box [CN-39 (41)] → Pilot cut off switch ON → Pilot cut off switch [CS-4 (5)→(4)]

--- I/conn [CN-05 (11)] --- I/conn [CN-12 (12)] --- Pilot cut off solenoid ON [CN-68] (activate)

Pilot cut off released

(4) Pilot cut off OFF

Fuse box [CN-39 (41)] — Pilot cut off switch OFF — Pilot cut off solenoid [CN-68] OFF — Pilot cut off applied

2) CHECK POINT

Engine	Key switch	Check point	Voltage
		① - GND (parking switch input)	
	ON	2 - GND (parking switch output)	20, 2514
Duration		3 - GND (pilot cut off switch input)	
nunning		4 - GND (pilot cut off switch output)	20~250
		5 - GND (parking solenoid)	
		6 - GND (pilot cut off solenoid)	

* GND : Ground

ELECTRIC PARKING, PILOT CUT OFF CIRCUIT



980A7EL09

7. WIPER AND WASHER CIRCUIT

1) OPERATING FLOW

Fuse box [CN-39 (40)] → Wiper relay Hi [CR-4 (3)→(4)] → Front wiper motor [CN-21 (1)] → Wiper relay Lo [CR-26 (5), (2)] — Multi function switch [CS-12 (6)] Rear washer relay [CR-203 (2, 3)] Rear wiper relay [CS-25 (2, 5)] I/conn [CN-07 (5)] — Rear wiper motor [CN-203 (1)] (1) Front washer switch ON MCU [CN-58A (A39)→(B17)] → Front wiper relay Lo $[CR-26 (5) \rightarrow (3)] \longrightarrow$ Front wiper motor $[CN-21 (5)] \longrightarrow$ Wiper motor operating (low) (2) Front wiper switch ON ① INT position Wiper switch ON [CS-12 (6)→(1)] → MCU [CN-58A (A40)→(B17)] → Wiper relay Lo [CR-26 (5)→(3)] → Front wiper motor [CN-21(5)] → Front wiper motor intermittently operating 2 Lo position Wiper switch ON [CS-12 (6) \rightarrow (4)] \rightarrow Wiper relay Lo [CR-26 (4) \rightarrow (3)] \rightarrow Front wiper motor [CN-21 (5)] -- Front wiper motor operating (low) 3 Hi position Wiper switch ON [CS-12 (6) \rightarrow (3)] \rightarrow Wiper relay Hi [CR-4(3) \rightarrow (5)] \rightarrow Front wiper motor [CN-21(4)] - Front wiper motor operating (high) (3) Auto-parking (when switch OFF) Switch OFF → Fuse box [CN-39 (40)] → Wiper relay Hi [CR-4 (3)→(4)] → Front wiper motor [CN-21 (1) \rightarrow (2)] \rightarrow Multi function switch [CS-12 (5) \rightarrow (4)] \rightarrow Wiper relay Lo [CR-26 (4)→(3)] → Front wiper motor [CN-21 (5)] → Wiper motor stop (4) Rear wiper and washer switch Rear wiper switch on monitor → MCU [CN-58B (B16)] → Rear wiper relay [CR-25 (5)→(3)] → I/conn [CN-07 (8)] → Rear wiper motor [CN-203 (5)] --- Rear wiper motor operating MCU [CN-58B (B05)] → Rear washer relay [CR-203 (3)→(5)]

→ I/conn [CN-01 (39)] → Rear washer pump [CN-103 (1)]

--- Washer operating

2) CHECK POINT

Condition	Check point		
	① - GND (front wiper switch power input)	6 - GND (wiper relay power input)	
Engine : Stop	2 - GND (rear wiper relay power input)	0 - GND (front washer power output)	
Key switch : ON	$\ensuremath{\Im}$ - GND (wiper relay power input)	8 - GND (rear washer power output)	
Voltage : 20~25V	4 - GND (front wiper motor Lo power input)	${\small 9}$ - GND (front wiper motor power output)	
-	5 - GND (front wiper motor High power input)	0 - GND (rear wiper motor power output)	

% GND : Ground



HAZARD, TURN AND ROTARY CIRCUIT



GROUP 3 MONITORING SYSTEM

1. CLUSTER

1) STRUCTURE

The cluster consists of gauges, lamps and LCD as shown below, to warn the operator in case of abnormal machine operation or conditions for the appropriate operation and inspection.

- · Gauges : Indicate operating status of the machine.
- $\cdot\,$ Warning lamps : Indicate abnormality of the machine.
- Pilot lamps : Indicate operating status of the machine.
- · LCD : Indicates selected the driving speed and direction.
- * The cluster installed on this machine does not entirely guarantee the condition of the machine. Daily inspection should be performed according to chapter 6, MAINTENANCE.
- * When the cluster provides a warning immediately check the problem, and perform the required action.



960A7EL50

2) GAUGE

(1) Speedometer



- ① The speedometer displays the speed of machine in mph and km/h.
- * The unit (km/h or mph) can be set by the display set up menu of the monitor and selected unit is displayed. Refer to page 7-55.

(2) Fuel gauge



- ${\ensuremath{\textcircled{}}}$ This gauge indicates the amount of fuel in the fuel tank.
- ② Fill the fuel when the indicator moves red range or B lamp blinks in red, refuel as soon as possible to avoid running out of fuel.
- * If the gauge indicates red range even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(3) Engine coolant temperature gauge



- ① This gauge indicates the temperature of coolant.
 - \cdot White range : 40~105 $^{\circ}\text{C}$ (104~221 $^{\circ}\text{F})$
 - Red range : Above 105°C (221°F)
- ② If the indicator is in the red range or ♣ lamp blinks in red, turn OFF the engine and check the radiator and engine.
- * If the gauge indicates red range even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(4) Transmission oil temperature gauge



- ① This gauge indicates the temperature of transmission oil.
 - · White range : 40~107°C (104~225°F)
 - · Red range : Above 107°C (225°F)
- ② If the indicator is in the red range or I amp blinks in red, it means the transmission is overheated. Be careful that the indicator does not move into the red range.
- If the gauge indicates red range even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

3) WARNING LAMPS



960A3CD09A

(1) Emergency warning lamp



- ① This lamp blinks when each of the below warnings is happened.
 Warning lamps light ON
 - MCU input voltage abnormal
 - Monitor communication data error
 - Engine ECM and TCU communication data error
- ② When this warning lamp blinks, machine must be checked and service immediately.

(2) Engine overheat warning lamp



- ① This lamp is turned ON when the temperature of coolant is over the normal temperature (105°C, 221°F).
- ② Check the cooling system when the lamp is ON.

(3) Transmission oil temperature warning lamp



- ① This lamp is turned ON when the temperature of transmission oil is over the normal temperature (107°C, 225°F).
- ② When this lamp lights up during operation, stop the engine and check the machine.

(4) Hydraulic oil temperature warning lamp



- ① This warning lamp operates and the buzzer sounds when the temperature of hydraulic oil is over 106°C (223°F).
- ② Check the hydraulic oil level when the lamp is turned ON and the buzzer sounds.
- 3 Check for debris between oil cooler and radiator.
- * If you want to stop buzzer sound, just touch the M icon.

(5) Fuel level warning lamp



① This warning lamp lights ON when the fuel level is low. Refuel the machine as soon as possible.

(6) Transmission error warning lamp



- ① This lamp lights ON and the LCD display show the error codes when an error occurs in the transmission.
- ② Immediately pull the machine to a convenient stop. Stop the engine. Investigate the cause.
- ※ Consult a HD Hyundai Construction Equipment dealer to investigate the cause.
- * Do not operate until the cause has been corrected.

(7) Air cleaner warning lamp



- ① This lamp lights ON and the buzzer sounds when the filter of air cleaner is clogged.
- ② When the air cleaner warning lamp is ON and the buzzer sounds, check and clean the primary element.
- ※ If you want to stop buzzer sound, just touch the M icon.
- * The primary element should be replaced if the warning lamp is ON after installation of a clean primary element.
- * Replace the primary element after 4 times cleanings.

(8) Engine oil pressure warning lamp



- ① This lamp is comes ON and the buzzer sounds after starting the engine because of the low engine oil pressure.
- ② If the lamp comes ON and the buzzer sounds during engine operation, shut OFF engine immediately. Check engine oil level.

(9) Steering warning lamp



① Primary

This lamp indicates that the primary steering has failed. When the indicator comes ON and the action alarm sounds, steer the machine immediately to a convenient location and stop the machine. Stop the engine and investigate the cause.

- * If you want to stop buzzer sound, just touch the Micon.
- * Do not operate the machine until the cause has been corrected.
- ② Emergency

This lamp indicates the emergency steering system is active.

- Immediately pull the machine to a convenient stop and stop the engine.
- * The emergency steering system can be manually tested. Refer to page 3-45.

(10) Battery charging warning lamp

960A3CD51



- ① This lamp is ON and the buzzer sounds when key ON, it is turned OFF after starting the engine.
- ② Check the battery charging circuit when this lamp comes ON and the buzzer sounds, during engine operation.
- * If you want to stop buzzer sound, just touch the Micon.

(11) Brake fail warning lamp



- ① The lamp lights ON and the buzzer sounds when the oil pressure of service brake drops below the normal range.
- ② When the lamp is ON and the buzzer sounds, stop the engine and check for its cause.
- * If you want to stop buzzer sound, just touch the Micon.
- * Do not operate until any problems are corrected.

(12) Check engine warning lamp



- This lamp lights ON and the buzzer sounds when the communication between MCU and engine ECM on the engine is abnormal, or if the cluster received specific fault code from engine ECM.
- ② Check the communication line between them. If the communication line is OK, then check the fault codes on the monitor.
- * If you want to stop buzzer sound, just touch the Micon.

(13) Engine stop warning lamp



- This warning lamp pops up and the buzzer sounds when 30 minutes elapsed with empty condition of the DEF/AdBlue® tank, stop the engine immediately and check the DEF/ AdBlue® tank.
- ② Fill the DEF/AdBlue® immediately in the DEF/AdBlue® tank.
- * Refer to page 7-30.
- ③ This lamp lights ON when the stationary exhaust system cleaning is not performed.
- * Refer to page 7-28.
- * Please contact your HD Hyundai Construction Equipment service center or local dealer.
- "Engine shutdown" cluster message up when the exhaust gas temperature reaches above 800℃.

(14) Engine coolant low level warning lamp



This warning lamp lights ON when the level of coolant is low.
 Fill the coolant immediately when the lamp is ON.

(15) Water in fuel warning lamp



- ① This warning lamp lights ON when the water separator is full of water or malfunctioning.
- * When this lamp lights ON, stop the machine and spill water out of the separator.

(16) Exhaust system cleaning warning lamp



① This warning lamp lights ON or blinks when the exhaust system cleaning is needed as table below.

Warning lamp				
Exhaust	Check engine	Stop engine	Description	
= <u>:</u> :}	[]	STOP		
Off	Off	Off	· Automatic exhaust system cleaning	
Blink	Off	Off	 The status of a manual (stationary) exhaust system cleaning when the exhaust system cleaning switch has been activated. * Refer to page 7-29 	
On	On	Off	 The aftertreatment exhaust system needs to be cleaned immediately. Engine power will be reduced automatically if action is not taken. The exhaust system cleaning can be accomplished by : Changing to more challenging duty cycle. Performing a manual exhaust system cleaning. 	
On	On	On	 These lamps will be ON when a stationary (manual) exhaust system cleaning is not performed. Stop the engine immediatary. Please contact your HD Hyundai Construction Equipment ser- vice center or local dealer. 	

(17) Exhaust system cleaning inhibit warning lamp



- ① This warning lamp indicates, when illuminated, the exhaust system cleaning switch is pushed inhibit position, therefore automatic and manual exhaust system cleaning can not occur.
- * Refer to the page 7-69 for the exhaust system cleaning switch.
※ Manual exhaust system cleaning



Manual exhaust system cleaning applies if the machine is in a fireproof area.

- * To stop a manual exhaust system cleaning before it has completed, set to the exhaust system cleaning switch to the inhibit position or turn OFF the engine.
- $(\ensuremath{\underline{1}})$ Stop and park the machine.
- ② Pull the safety button and push the switch to position ② to initiate the manual exhaust system cleaning.
- ※ Refer to the page 7-69 for the exhaust system cleaning switch operation.
- * The engine speed may increase to 950~1050 rpm and exhaust system cleaning begins and it will take approximately 20~30 minutes.
- ③ The exhaust system cleaning warning lamp will blink and HEST warning lamp will light ON during the exhaust system cleaning is operating.
- ④ The exhaust system cleaning and/or HEST warning lamp will light OFF when the exhaust system cleaning is completed.

(18) HEST (High exhaust system temperature) warning lamp

9753CD129A



- ① This warning lamp indicates, when illuminated, that exhaust temperatures are high due to exhaust system cleaning.
- ② The lamp will also illuminate during a manual exhaust system cleaning.
- ③ When this lamp is illuminated, be sure the exhaust pipe outlet is not directed at any surface or material that can melt, burn, or explode.
- ▲ When this lamp is illuminated, the exhaust gas temperature could reach 800°C [1500°F], which is hot enough to ignite or melt common materials, and to burn people.
- ** The lamp does not signify the need for any kind of equipment or engine service; It merely alerts the equipment operator to high exhaust temperatures. It will be common for the lamp to illuminate on and off during normal equipment operation as the engine completes exhaust system cleaning.

(19) DEF/AdBlue® level warning lamp



- ① This warning lamp indicates when ON or blinking, that the DEF/AdBlue® level is low as table below.
- * It is recommended that the DEF/AdBlue® tank be filled completely full of the DEF/AdBlue® in order to correct any fault conditions.

	Warnin	ig lamp		
Fail in SCR system	DEF/AdBlue® level	Check engine	Stop engine	Description
=j:3>	3 ∴ ∴ ∴ ∴		Description	
On	On	Off	Off	• The DEF/AdBlue® level has fallen below the initial warning level (10%).
On	On	On	Off	 The DEF/AdBlue® level has fallen below the initial derate level (2.5%). The engine power will be limited automatically.
On	Blink	On	On	 This is happened when 30 minutes elapsed with empty conditions (0%) of the DEF/ AdBlue® tank. The engine will enter the final derate level which may include low idle lock or engine shutdown with restart limitations. In order to remove the final derate, the DEF/ AdBlue® tank must be filled to above 10 persent gauge reading.

(20) Fail in SCR system warning lamp



- ① This warning lamp indicates there are faults related to SCR system.
- ② The lamp lights ON when each of the below warnings is happened.
 - a. Low DEF/AdBlue® level
 - b. Poor quality of DEF/AdBlue®
 - c. Tempering or malfunction in the aftertreatment system
- ③ Once the lamp lights ON, the engine will derate shortly.
- * Please contact your HD Hyundai Construction Equipment service center or local dealer.

4) PILOT LAMPS



(1) High beam pilot lamp



- 1 This lamp works when the illuminating direction is upward.
- ② This lamp comes ON when the dimmer switch is operated, e.g., when passing another vehicle.

(2) Parking brake pilot lamp



- 1 When the parking brake is actuated, the lamp lights ON.
- * Check the lamp is OFF before driving.

(3) FNR select pilot lamp (option)



- ① The lamp comes ON when FNR select button on the optional FNR remote control lever is pressed.
- * Refer to page 7-70.

(4) Joystick steering pilot lamp (option)



This lamp lights ON when joystick steering is activated.
 It is then possible to steer the machine and select gears from the armrest to the left of the operator's seat.

(5) Differential lock pilot lamp (option)



- This lamp lights ON when the differential lock function is operating.
- * Refer to page 7-68.

(6) Pilot cut off pilot lamp



① This lamp lights ON when the pilot cut off switch is pressed.
※ Refer to page 7-68.

5) LCD



 The LCD can be used with the gear selector.
 It indicates speed, driving direction, DEF/AdBlue® level and transmission warning.

No	Symbol	Meaning	Remark						
	Δ , ∇ , N		Forward, reverse, neutral						
1	1, 2, 3, 4, 5	Actual gear display	Actual gear						
	Р	alopidy	Parking brake mode active						
2	^ , V	Forward, reverse	FWD 1 REV 1						
3		Gear range display	FWD 5 FWD 5						
4		DEF/AdBlue® Dispaly the amount of liquid in the DI level Blue® tank							
5	- - - 	Fill the DEF/AdBlue® when the landblinks in red. ODEF/AdBlue® Ievel warning lamp Fill the DEF/AdBlue® level 5~10% - ON : DEF/AdBlue® level 5~10% - Blink : DEF/AdBlue® level below 5 Wilf the lamp ON or blinks in red. though the machine is on the condition, check the electric device can be caused by the poor content electricity or sensor.							
	LF, LR	Limp home gear	-						
	**	Oil temperature too low, no gear available	Warm up engine/transmission						
6	WS	Warning sump temperature	Alternate between WS and actual gear / direction while driving, in neutral only displayed WS if no fault is detected * Cool down transmission						
	WT	Warning torque c o n v e r t e r temperature	Alternate between WS and actual gear / direction while driving, in neutral only displayed WS if no fault is detected ※Cool down transmission						

2. MONITOR (7 inch touch screen)

- The monitor is adjustable.
- Vertical : 30°
- Horizontal : 15°



1) MAIN DISPLAY

- * You can select or set the menu by the switches or touch screen.
- * Please refer to switch, page 7-62 for selection and change of menu and input value.

760F3CD20-1

* Display type can be changed by operator. See page 7-56 for details.



7-33

(1) Menu bar



- * In main display, you can move to right side menu by touching each icon.
- ① Clock setting

Set the time (hour, minute and AM or PM)

2 Wiper speed

Set the wiper speed (slow, normal, fast and very fast)

③ Menu

Move to main menu.

④ Buzzer stop

If you want to stop buzzer sound, just touch the icon.



2 Wiper speed







760E3CD07C-1

4 Buzzer stop



760F3CD07E-1

(2) Change display information



760F3CD08-1

* In main display, you can check the data and setup what you want by touching each window area or icon.

① Machine monitoring

To display the item in main display, select two items of them.

※ Priority in the machine monitoring display

The priority of the weighing system is the highest. If the weighing system is selected, the other items are not

available. To display the other items, the weighing system should not be selected.

※ Weighing system : see page 7-42.

① Machine monitoring



2 Fuel rate

- · Set average fuel rate or a days fuel used on main display screen.
- · Refer to page 7-49.

3 Engine mode and operation history

- \cdot Set the engine mode (A).
- · Refer to page 3-19.
- \cdot Set Hour meter / ODO meter (B).
- · Refer to page 7-48.



③ Engine mode



4 Transmission mode

- Set the clutch cut off (A), shift (B) and torque converter lock up mode (C).
- · Refer to page 7-40.

④ Transmission mode







(5) Quick menu



- Move the quick menu screen by touching .
- ⓐ User switching
 - When multiple users share a machine, it allows users to switch user settings of machine.
 - · User can apply or save the setting of monitor easily.
- **b** Active fault
 - · Display the fault code of MCU/ECU/TCU/EHCU.
 - · Refer to page 7-48.
- © Maintenance
 - · Elapsed time, change or replace cycle can be changed.
 - · Refer to page 7-52.
- **d** Help
 - · Read the monitor manual as a PDF file on the monitor.
- **% Smart terminal**
 - The menu features a smartphone and operates the miracast.
 - ▲ Operation of screen mirroring can be dangerous while driving.

Driver is responsible for accident or other damages. Operate the screen mirroring while stopping for safety.

To display the virtual keypad, drag the button (_____) to top of the screen.



760F3CD08H-1

b Active fault



© Maintenance









Virtual keypad



760F3CD68B-1

(3) Fault and maintenance warning



- ① If you touch the warning sign (red icon), move to the quick menu.
- ② You can check the fault message and move the maintenance screen by touching relevant area.

(4) Machine monitoring warning

- ① Warning sign (red icon) will be shown when the temperature of hydraulic oil, cooling water, transmission oil or battery voltage is not normal state.
- 0 Case of warning sign

Icon	Description
	Above 106°C of hydraulic oil temperature
-	Above 105°C of cooling water temperature
	Above 107°C of transmission oil temperature
	Below 24.5 voltage of battery (for 3 minutes)
ŀ\$H	Above 100°C of axle oil temperature (option)

(5) Communication error

① MCU could not communicate with monitor over 10 seconds, error message will be show on the screen.

Active Fault Machine(6) Engine(0) Transmission(0) Transmission(0) EHCU(0) Machine Axis 1899-7282 Xethine

760F3CD16-1







(6) Eco gauge

- This gauge indicates the fuel consumption rate and machine load status. So that operators can be careful with fuel economy.
- ② The fuel consumption rate or machine load is high, the segment is increased.
- ③ The color of Eco gauge indicates operation status.
 - \cdot White $\,:$ Idle operation
 - · Green : Economy operation
 - \cdot Yellow : Non-economy operation at a medium level.
 - \cdot Red \cdot : Non-economy operation at a high level.



2) MAIN AND SUB MENU

(1) Structure

No	Main menu	Sub menu	Description
1	Mode Kode 760F3CD25A	Engine setting Kick down I.C.C.O mode Shift mode T.C. lock up Work load Boom/bucket detent mode Bucket priority Auxiliary attach max flow level Soft end stop Speedometer frequency setting Cooling fan reverse mode Wiper level setting Calibration Engine auto shutdown	Engine mode, Engine speed Mode 1 (down/up), Mode 2 (down only) Clutch cut off mode ON/OFF Transmission shift mode (manual, AL, AN, AH) Torque converter lock up ON/OFF Weighing system, Weighing display, Error detection Boom pressure calibration, Weighing system compensation Boom/bucket detent ON/OFF, Save position Bucket priority ON/OFF Max oil flow level setting Boom up/down, Bucket in/dump ON/OFF Speedometer setting Off, Manual, Automatic Slow, Normal, Fast, Very fast Boom/bucket angle, Boom pressure, Brake pedal sensor, AEB Once, On/Always, Disable, ESL system setting
2	Monitoring Monitoring 760F3CD25B	Machine monitoring Operation history Fault history Fuel consumption history Machine information	Hyd, Coolant, axle and TM oil temp, Battery voltage Hour meter, ODO meter Active/Logged fault (MCU, ECU, TCU, EHCU, AAVM) General record, Hourly record, Daily record, Mode record, Operation efficiency record TCU, ECM, MCU, RMCU, EHCU, Monitor, Cluster
3	Management Management 760F3CD25C	Machine security Maintenance Service menu Change A/S phone number Software update Owner menu editing	ESL system setting, Change password Elapsed time, Cycle, Maintenance history Sensor monitoring, Speed limit setting, Weighing system compensation, EHCU I/O information Check and change of contact information Update file in USB memory Owner menu editing, Menu list, Password change
4	Preference Preference	Brightness setting Clock setting Unit setting Display style/Language Camera setting AAVM setting	Manual, Automatic Clock setting Temp (°F/°C), Distance (km, mile), Weight (ton, lb), Pressure (bar, Mpa, kgf/m², psi), Volume (I, gal) Type A, Type B, 14 multiple language Acive camera, Display order, Reverse mode AAVM camera reverse mode
5	Multimedia Multimedia	Media player Smart terminal	Play video and audio files in USB. Operation of screen mirroring

(2) Mode

1 Engine setting mode



· Engine mode

The operator can adjust the machine's performance.

- Econo : Maximum fuel efficiency for general loading.
- Power : Maximum power output for hard digging operation or hill climb.
- Smart power : Fuel efficient operation with same performance as power mode.

Engine speed

Setting engine low idle rpm.

2 Kick down mode







- Manual mode (shift mode : manual)
 It is effective 2nd speed to 1st speed only and recover to 2nd speed
 quickly when push the switch one more time.
- · Automatic mode (shift mode : AL, AN, AH)
- Mode 1 (down/up) It shifts down quickly from current gear to one step lower speed by pushing the switch and recover to current speed quickly when push the switch one more time.
- Mode 2 (down only)
 It shifts down from current gear to one step lower speed when push the switch every time.
 The kick down function is released in only 1st speed.
- * The normal autoshift function continues after the kick down switch is released.

③ I.C.C.O. (Intelligent Clutch Cut Off) mode



- · OFF : The clutch cut off function is disable.
- \cdot ON (I.C.C.O) : It will cut off the clutch when brake pedal operation.
- * The clutch cut off function is automatically adjusted depending on slope angle or machine load, And inching fuction becomes possible by using the brake pedal.

④ Shift mode

•		Mode		•	ſ	Node	
Monitoring	ENG. / TM. Engine Setting	HYD.	ETC.	Mode Monitoring	Shift N	Node	ETC.
6 Management	Kick Down		MODE 2	→ 6 Management	Manual	AL	Manual
Preference	Shift Mode		АН	Preference	AN	АН	Mode 1
Weighing System	T.C. Lock Up	7	on 60E3CD28A	Multimedia	T.C. Lock Up		0 rpm On
							7605200288

- · Four modes are available for operator's preference and job condition.
 - Manual : Machine is operated by selected gear on lever.
 - AL (Auto Light) : Automatic shifting point is fast for long-distance transportation and fuel efficiency.
 - AN (Auto Normal) : Automatic shifting point is normal without automatic kick-down to 1st gear for general digging and loading operation.
 - AH (Auto Heavy) : Automatic shifting point is normal with automatic kick-down to 1st gear for more powerful operation.

(5) Torque converter (T.C.) lock up mode (5-speed transmission)



- · If you select ON, the lock-up clutch on the torque converter will automatically activate according to load.
- · Lock-up clutch function (option)

To prevent power loss in the torque converter, the pump rotor and turbine rotor on the torque converter lock together through a direct lock-up clutch.

6 Work load

•		Mode	샵		Work Lo	ad
Mode	ENG. / TM.	HYD.	ETC.	Weighing System	🔘 Manu	al 🔘 Automatic
tonitoring	Work Load				Oaily	Project : Not s
6	Boom Bucket Det	ent Mode		 Weighing Display 	C Truck	: Truck A
	Bucket Priority			Error Detection	🔘 On	O off
erence	Auxilliary Attachm	nent Max Flow Level	15			
2	Soft End Stop			Boom Pressure Calil	oration W	Weighing System Compensation
Jojotena		76	0F3CD33A	😪 Default	😢 CANC	EL 🛛 🛇 OK
						960A3CD3

- · Weighing system : Set the workload measurements.
- · Weighing display : Set the display on main display screen.
- Error detection : Set error detection ON/OFF.
- OFF : Errors are not displayed.
- ON : (a), (b) and (c) are displayed on main display screen.
- (a) The boom lift was performed too fast.
- The bucket was not in the fully tilted back position while bucket was in the weigh range.



© The hydraulic temperature is low (below 40 °C).

A Today	Work weight (today)
A	Work weight (previous day)
(Choel A Choel G	Total weight accumulated in memory A, B, C individually redardless of date
₹	Current weight

- · Boom pressure calibration : See the page 7-45 for details.
- · Weighing system compensation
 - Calibration workload depending on work tool.
 - * Only for the service person. Do not adjust arbitrary.
- * Refer to page 7-65 for details.



9603CD750

※ Weighing system

- The weight indication in bucket is calculated by measuring boom position and boom pressure.
- (a) The weight is '0.0 ton' when the boom is placed at below -15°.
- ^(b) The weight is indicated when the boom is placed at the range (-5°→15°).
- [©] The weight is calculated when the boom is placed at above -5° and boom is lowered below -15° after dumping operation.



In order to recheck weight, go to the (b) after changing boom position (below -15°).

- Dump operation : It is checked by bucket cylinder's stroke change (below 250 mm).
- * The temperature for the hydraulic oil must be raised to at least 40 °C (104 °F) before operation.

⑦ Boom/bucket detent mode

•	N	Aode				Boom/Bucket	Detent Mode
EN EN	łG. / TM.	HYD.	ETC.		• Boom		
work	Load				Off	🔘 On	Save Position
O Boon agement	n Bucket Detent	Mode		\rightarrow			
Buck	et Priority				 Bucket 		
ference Auxil	lliary Attachment	t Max Flow Lev	el 15		Off	O On	Save Position
ing System	End Stop						Save resident
		7	60F3CD35A				🛇 ОК
							760F3C

- · OFF : Detent functions are not operated.
- · ON : Boom or bucket detent functions are operated.
- Save position

[®] Bucket priority mode (option)



· Bucket priority function is to be more convenient for operator to load materials.

Bucket-in (roll back) operation takes priority over the boom-up (raise) operation in case of using both operations at the same time and therefore boom (raise) operation is stopped and only bucket (roll back) is operated.

· Set the bucket priority function ON/OFF.

9 Auxiliary attachment max flow level mode (option)



- · If the machine is equipped with auxiliary attachment, auxiliary attachment flow can be easily adjusted and controlled.
- · Set the oil flow level from 0 to 15 level by using +/- button.

⁽¹⁾ Soft end stop mode (option)



- This function gives shock free operation by reducing the speed of attachment near the end stroke.
- · Set the soft end stop function ON/OFF.

(1) Speedometer frequency setting mode



- · Press speedometer setting bar (or \mathbf{C}) for 3 seconds.
- * Only for the service person. Do not adjust arbitrary.

% Using button

- · To change the pulse value, press \blacktriangleleft or \blacktriangleright .
- · To change the position, press \mathfrak{S} .



- · Manual : Rotate the fan with reverse direction while pressing the button "Execute".
- · Automatic : Rotate the fan with reverse direction by preset cycle.
 - Interval : 30 min ~ 5 hrs
 - Time : 30 sec ~ 5 min
- * Default : Interval (60 min), time (120 sec)

⁽³⁾ Wiper level setting (Intermittent mode)



Setting wiper speed in J position of multi fumction switch (slow, normal, fast and very fast)
 * Refer to the page 7-71.

(4) Calibration



- · You should turn OFF " Soft end stop " before start calibration.
- · Press NEXT button after following the instruction at each step.
- · If correction is right, NEXT button will be activated, then go to next stage.
- · After following each step correctly, the message "Calibration completed" will be shown. Press OK button, then process be ended.
- * Using switch
 - Using *e* instead of NEXT, complete button.

· Boom / Bucket angle calibration

- MCU get sensing signal from boom angle and bell crank angle and calculate bucket cylinder stroke and boom link position angle from ground real time basis.
- Boom angle position and bucket cylinder stroke is set by detent setting switch on monitor.
- Individual setting position is done by lever (detent, release operation).
- Angle sensor calibration is basically carried out before delivery of the machine.

When angle sensor is replaced or actual value is different compared to setting value, this function can be done.

- Bucket cylinder stroke Boom angle United to the stroke Bell crank angle Detent setting switch
- The calibration must be carried out as follows :
- ① Lower the boom at maximum low position and press NEXT button or 𝔄 (bucket must be max tilting position).
- 2 Raise boom at maximum high position and press NEXT button (or \mathbf{e}).
- ③ Position boom at -5° and press NEXT button (or \bigcirc).
- ④ Retract bucket cylinder length (to minimum position) at -5° boom position and press NEXT button (or 健).
- (5) Extend bucket cylinder length (to maximum position) at -5° boom position and press NEXT button (or ♂).
- 6 In case above steps are carried normally, "Calibration is done" message is shown. Then angle sensor calibration is finished.
- * Boom down / boom up / bucket position setting : Refer to page 4-22 in operator's manual.

Boom pressure calibration



Display A 960

- Press START button after following the instruction.
- After a few minutes, "Calibration failed" or "Calibration completed" message will be shown. Press OK button then process be ended.
- **% Using button**
 - Using *C* instead of NEXT, complete button.
- · Boom pressure calibration
- It is used when bucket weight is changed or measured weight is inaccurate.
- The calibration must be carried out as follows :
- Increase hydraulic temperature (about 40~ 60°C).
- ② Select "Boom-pressure".
- ③ Roll-in the bucket at maximum range and lower the boom at minimum height.
- ④ Press START button.
- ⑤ Raise boom to maximum position. Boom up must be finished before stepping advance in "display A".
- ⑥ If it show "Calibration success" message in a moment, press complete button (or €).
- * Raise hydraulic temperature enough when checking work load / boom pressure sensor calibration (recommendation : about 40 ~ 60°C).
- * Check if pressure sensor or angle sensor is in normal condition for accurate work load algorism or pressure sensor calibration [pressure sensors at boom cylinder head area and rod area, boom angle sensor (CD-80), bell crank angle sensor (CD-81)].
- * Sensor error message during pressure sensor calibration : sensor need to be checked.
- · Brake pedal sensor calibration





- Press OK button, then calibration will be started.
- When display " IP 🔒 " on main display, press slowly the brake pedal completely.
- Release the brake pedal when display " IP . on main display.
- For cancel, press MENU/HOME switch.
- * When the brake pedal or sensor is replaced, brake pedal sensor calibration must be performed.



· AEB



- AEB mode controls the disk clearance of the transmission, automatically.
- To start AEB setting, press AEB bar (or ↔) for 3 seconds.
- If you press & or ESC, AEB setting will be canceled. Machine need to restart.
- If "OK" in actual gear window, press ♂ to complete AEB setting.
- Display during AEB mode

Symbol	Meaning
ST	Start AEB
K1~K4, KV, KR	Calibrating clutch K1~K4, KV or KR respectively
OK*	Calibration for all clutches finished
Spanner and Kx*	Kx couldn't be calibrated, AEB finished
△E	Engine speed too low - Raise engine speed
∇E	Engine speed too high - Lower engine speed
∆T	Transmission oil temperature too low - Heat up transmission
∀T	Transmission oil temperature too high - Cool down transmission
FO*	Output speed not zero
FN*	Shift lever not in neutral position
FP*	Parking brake not applied

* : Transmission stays in neutral, you have to restart the TCU (starting switch off/on).

15 Engine auto shutdown mode



- · The engine auto shutdown function can be activated or cancelled.
- · If machine is idling for the setting time (2~40 minutes), then engine will be shutdown automatically.

(3) Monitoring

① Machine monitoring

¢	Monitoring	Machine M	onitoring
A contraction of the contraction	Machine Monitoring	• HYD Temp.	10 °⊂
Monitoring	Operation History Fault History	Battery Volt.	25.6 v
Management	Fuel Consumption History	Coolant Temp.	60 ≪
Preference	Machine Information	• TM Oil Temp.	40 ∝
Weighing System	760F3CD41A-1		🛇 ок
			760F3CD41B-

· Monitor the status of the machine.

2 Operation history



· Hour meter / ODO meter

- · Total
 - Total distance (this item cannot be initialized).
 - Total working hour can check on service meter. See page 3-59.
- · Latest
 - Working hour/distance after reset.
 - If you select Initialization, working hour/distance start zero.
- To display the item in main display, select the item in main display. See the page 3-13.



③ Fault history

- · Display the fault code of MCU/ECU/TCU/EHCU and delete logged fault.
- * Refer to service manual for HCESPN/FMI of engine and transmission.
- * EHCU : Electro Hydraulic Control Unit AAVM : All Around View Monitoring

④ Fuel consumption history



- · Dispaly the fuel consumption history.
 - General record (average fuel rate and a days fuel used)
 - Hourly record Daily record Mode record : P, P(smart), E mode
 - Operation efficiency record (Shuttle shift, Idle, Relief)

(5) Machine information



· Software versions of MCU, ECM, TCU, EHCU, RMCU, Cluster and monitor can be checked.

(4) Management

① Machine security



· ESL system setting

- ESL : Engine Starting Limit
- ESL mode is designed to be a theft deterrent or will prevent the unauthorized operation of the machine.
- If the ESL mode was selected ON, the password will be required when the start switch is turned ON.
- Engine start limit
 - . Disable : Not used ESL function
 - . Enable : The password is required whenever the operator start engine.
- Activate after specific time

The password is required when the operator start engine first. But the operator can restart the engine within the specific time without inputting the password.

The specific time can be set maximum 2 days.

- Smart key authentication function (option)
 - . Enable : Set the using or not of smart key. If you using smart key, ESL function always be activated.
 - . **Disable :** Register or delete user tag and display registered user tag. When delete user tag, all user tag will be deleted.

* Using smart key

- Verification success

Green smart key icon is displayed on the main display screen.

- Verification failure Red smart key icon and password input screen is displayed.



Verification success

Verification failure

※ Remote door control system (option)

- The machine operator can lock, unlock and open the cab door by means of the remote key tag, as long as he is within a range of 15 meters from the machine.
- Please note that the door cannot be closed using the Remote Key Tag.



- 1 Door lock
- 2 Door unlock
- 3 Door open (press and hold for 2 seconds)
 - ▲ Do not activate this function if there is person nearby the door and when machine work or travel.

· Door control deactivation time setting

- There is a limited period of a maximum of 10 days that can be set during which the 'Remote Door Functionality' can be used if the machine has been parked or at a standstill.
- If the machine is parked or at a standstill for a period that exceeds the period in days set by the operator without any activity, then to prevent the machine batteries from draining, the 'Remote Door Functionality 'will be disabled.
- When this happens, the operator will be able to only use the machine Key to open the cab door, after which the 'Remote Door functionality' can be enabled again during first start-up.
- During the first start-up after the machine was inactive for a period that exceeds the period in days set by the operator, the operator will be able to see the below pop-up on the monitor, by which the operator can then enable the 'Remote Door functionality 'again by clicking the 'Setting 'tab and confirming the settings thereafter.



Tag management

- Tag number
 - . Max 5 tags can be registered.
- Battery alarm
 - . Check tag's battery status. (normal or low)
- Communication history (check, lock, unlock, open)

Tag Management				
Tag Number		Battery Alarm		Communication History
		۲		LOCK
		NOT Registered		NOT Registered
		NOT Registered		NOT Registered
		NOT Registered		NOT Registered
		NOT Registered		NOT Registered
				🛇 ок
				960A3CD47K

· Engine Starting Condition

Case	ESL Mode	Smart Key	Condition
1	Disable	Disable	 With registered tag : Engine can be started without password input. Without registered tag : Engine can be started without password input.
2	Disable	Enable	If Smart Key is enabled, ESL Mode is automatically enabled. This Case 2 work the same as the Case 4.
3	Enable	Disable	 With registered tag : Engine can be started with password input. Without registered tag : Engine can be started with password input.
4	Enable	Enable	 With registered tag : Engine can be started without password input. Without registered tag : Engine can be started with password input.

2 Maintenance

¢	Management 🖒		Maintenance								Maintenance				
AD	Machine Security		л	141		Iti	л	-	E)		0	() Engine oil	Ø		
Monitoring	Maintenance		\odot		Feed		<u>, O</u> ,		FRE		* Elapsed Time : 500Hour	• Cycle : 50	OHour		
6 Management	Service Menu	►	It.	0	-	۲	$\underline{\bigcirc}$	юЧ	ાન્ય	→					
	Change A/S Phone Number								R		* Maintenance History :				
Preference	Software Update		8	10 III	E			\$	PS						
Weiching System	Owner Menu Editing		1	OUT			<u>Si</u>	F-m4	b4		Replacement		Change Cycle		
	960A3CD48A		A/S 1899-7282				0	ок		A/S 1899-7	282	🛇 ок			
			960A3CD48B							960A3CD48C					

 \cdot Replacement : The elapsed time will be reset to zero (0).

Change cycle : The change or replace cycle can be changed in the unit of 50 hours.

- $\cdot\,$ Show the maintenance history below 10.
- When history have more than 10, delete the old item.

· Change or replace interval

No	Item	Interval
1	Engine oil	800
2	Hydraulic oil	*12000 *25000
3	Pilot line filter element	1000
4	Hydraulic oil return filter	1000
5	Engine oil filter	800
6	Fuel filter element	1000
7	Fuel pre-filter element	1000
8	Hydraulic tank air breather	1000
9	Air cleaner element	2000
10	Radiator coolant	*12000 *26000
11	Transmission oil and filter	1000
12	Axle oil (front and rear)	1500
13	Aircon & heater outer filter	1000
14	Pressure filter element	1000
15	DEF/AdBlue® supply module filter	4500
16	DEF/AdBlue® Tank filter	2000
17	Aircon & heater inner filter	2000

 \star^1 : Conventional

*2 : HD Hyundai Construction Equipment genuine long life

③ Service menu



- · Sensor monitoring : Display information of each sensors.
- Speed limit setting : 20~40 km/h (5 km/h intervals)
- · EHCU I/O information
 - Real time monitoring (joystick stroke, EPPR current).

$\textcircled{\begin{tmatrix} \textcircled{\begin{tmatrix} \blacksquare \begin{tmatrix} \blacksquare \begin{t$



· Check and change of contact information for customer service.

Software update



· Update file in USB memory.

⑤ Owner menu editing



- **Owner menu editing** : Owner can set the status of the function. (Enable / Disable)
- Menu list : In the menu, owner can set the list of the function to lock or unlock it.
- Owner passward change (Default password : 11111)
 - Owner can manage and change the password.
 - Necessary to input the password to access the set of function.

(5) Preference

① Brightness setting



· Manual

- Manual setting for LCD brightness.

· Automatic

- Automatic control of LCD brightness as set level of day/night.

- · Setting day time
 - Set the time for daylight.
 - If you set the time for daylight, the rest time will be night.

2 Clock setting



· Set the time (hour, minute and AM or PM)

③ Unit setting



- $\cdot \text{ Volume } : \ell \leftrightarrow \text{gal}$
- · Temperature : $^{\circ}C \leftrightarrow ^{\circ}F$
- · Distance : km \leftrightarrow mile
- · Weight : ton \leftrightarrow lb
- · Pressure : bar \leftrightarrow Mpa \leftrightarrow kgf/m² \leftrightarrow psi
- **% Using button**
 - Move to other item by @.

④ Display style/ Language



- · Set the display type A or B.
- · User can select preferable language and all display are changed the selected language.
- 14 multiple language available.

(5) Camera setting

* If the camera monitor is equipped, camera will showing on camera monitor only.

¢	Preference		Camera Setting								
Mode	Brightness Setting	Manual		Active Cam	era			_	Δ	+	
Monitoring	Clock Setting			Display Or	lor						
6	Unit Setting		-	Display Or	, iei						
Management	Display Style / Language			CAM I	~	CAM 2	`	CAM 3	~	CAM 4	>
Preference	Camera Setting		-							4th	
Weighing System				Activate when the reverse gear is selected.							
	960A3	3CD39A				(C C	ANCEL		🛇 ок	
									7	60F3CD	39B-1

· Active camera

- Four cameras can be installed on the machine.
- · Display order

- Set the channel sequence of each camera.

· Active when the reverse gear is selected

- If transmission engages the reverse gear (R1~R3), the camera mode is displayed automatically in main display.
- · If the camera was not equipped, this menu is not useful.
- · If the camera monitor is equipped, camera will showing on camera monitor only. This menu is not useful.
- · In main display, if the III is touched (or IIII switch is pushed), the first ordered display camera will be viewed.
- * If AAVM is equipped, this menu will be changed to AAVM setting.

6 AAVM (Advance Around View Monitoring, option)

- * If the camera monitor is equipped, AAVM will showing on camera monitor only.
- · The AAVM switchs of the cluster consist of Camera, ESC and Buzzer stop.



- Camera switch

- · It will enter into the AAVM mode from the main display if the AAVM is installed.
- · If the camera monitor is equipped, AAVM will showing on camera monitor only. This menu is not useful.
- $\cdot\,$ While in the AAVM mode, select the ESC switch to return to the main display.





AAVM mode

- Buzzer stop switch
- $\cdot\,$ In AAVM mode, it detects surrounding pedestrians or objects and the warning buzzer sounds.
- · User can turn OFF the warning sound by pressing buzzer stop switch.



290F3CD246



290F3CD247

- When the worker or pedestrian go near the danger area line (green, radius 3 m), an external danger area of equipping on the main display, the warning buzzer sounds and it displays the green rectangular box for the recognition of the worker and pedestrian. At this time, the operator should stop work immediately, and stop the buzzer by pressing the buzzer stop switch. And then, please work after you check whether the danger factors are solved.
- When the worker or pedestrian go inside of the danger area line (red, radius 3 m), an internal danger area of equipping on the main display, the warning buzzer sounds and it displays the red rectangular box for the recognition of the worker and pedestrian. At this time, the operator should stop work immediately, and stop the buzzer by pressing the buzzer stop switch. And then, please work after you check whether the danger factors are solved.

3) PILOT LAMPS



960A3CD90

(1) Warming up pilot lamp



- This lamp lights ON when the coolant temperature is below 30°C (86°F).
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C, or when 10 minutes have passed since starting the engine.

(2) Seat belt pilot lamp



① This lamp lights ON for the first five seconds after starting the engine.

(3) Preheat pilot lamp



- This lamp lights ON when start switch is turned clockwise to the ON position. Light will turn off after approximately 5~45 seconds, depending on engine temperature, indicating that preheating is completed.
- ② When the lamp goes out the operator should start cranking the engine.

(4) Engine auto shutdown pilot lamp



① This lamp lights ON when the engine auto shutdown function is activated.

(5) Clutch cut off pilot lamp



① This lamp lights ON when clutch cut off mode is set L, M, H.

(6) Float mode pilot lamp



① This lamp lights ON when the boom float is activated.

(7) Ride control pilot lamp (option)



① Auto ride control

This lamp lights ON when the automatic ride control function is activated (**ON, Conditional speed** setting).



2 Manual ride control

This lamp lights ON when the manual ride control function is activated (**ON, Always** setting).

(8) Fan reverse pilot lamp



This lamp lights ON when the cooling fan reverse mode is activate

(9) Torque converter lock up pilot lamp (option)



① This lamp lights ON when the torque converter lock up function is operating.

(10) Fuel warmer pilot lamp



- ① This lamp is turned ON when the coolant temperature is below 10°C (50°F) or the hydraulic oil temperature 20°C (68°F).
- ② The automatic fuel warming is cancelled when the engine coolant temperature is above 60°C and the hydraulic oil temperature is above 45°C since the start switch was ON position.

3) SWITCHES



- ※ If you push left or right switch (►) on main display, show the select box on current time.
 Move to next item in order by using left / right button.
 - (1) Time \rightarrow 2) Buzzer \rightarrow 3) Wiper \rightarrow 4) Camera \rightarrow 5) Menu \rightarrow 6) Machine monitoring \rightarrow
 - ⑦ Fuel rate \rightarrow ⑧ Engine mode/Operation history \rightarrow ⑨ Transmission mode \rightarrow ⑩ Quick menu)
- * Move to selected setting screen by using enter switch (♂).
- * When keypad is not pressed for 3 seconds, convert screen to main display.
- * If you push left and right switch (\triangleleft) at the same time, move language settings.

(1) Menu / Home switch



① Main display to main menu, main menu to main display.

(2) ESC switch



- ① For other menu, this is used for cancellation (move to previous menu).
- 2 AEB cancel or finish button in AEB.

(3) Left / Right move switch



① Move in menu (left, up / right, down).

- ② Decrease / Increase input value.
- 3 Stop buzzer sound when sound is on.

(4) Enter switch



① Select menu (enter).

(5) Camera switch



(6) Main light switch



- 1 Enter camera or AAVM mode in main display.
- ② If the camera monitor is equipped, camera or AAVM will showing on camera monitor only. This switch is not useful.
- 1 This switch use to operates the clearance lamp and head light. \cdot Position lamp : Clearance lamp and cluster illumination lamp
 - come ON. The green pilot lamp is turned ON.
 - Head lamp + Position lamp : Clearance lamp, cluster illumination lamp and head light come ON. The green pilot lamp is turned ON.

(7) Work lamp switch



- This switch use to operates the front and rear work lamps.
 - Front : Front work lamp located on the cab comes ON. The green pilot lamp is turned ON.
 - Front + Rear : Front work lamp located on the cab and rear work lamp located on the cowl come ON. The green pilot lamp is turned ON.

(8) Central grease lubrication switch (option)



- ${\ensuremath{\textcircled{}}}$ This switch is used to operate the central grease lubrication system.
- ② The central grease lubrication system is operated for set period. The green pilot lamp is turned ON.
- When malfunction occur in grease lubrication system, the red pilot lamp is turned ON.

(9) Quick coupler switch (option)



① Disengage quick coupler

- The quick coupler pins move in the disengaged position and buzzer sounds.
- The red pilot lamp is turned ON.
- Always check that the attachment is properly secured to the attachment quick coupler by pressing the front part of the attachment against the ground.
- A Never use an attachment before you have checked its mounting.

2 Engage quick coupler

- The quick coupler pins move in the engaged position and buzzer sounds.
- The green pilot lamp is turned ON.
- * Check for engagement as followings.
- a. Put down pressure on the attachment.
- b. Back up the machine and make sure that there is no movement between the quick coupler and attachment.

(10) Ride control switch (option)

960A3CD86B



① Forward / Backward 1~15 km/h

- The ride control automatically turns on when the travel speed exceeds a preset speed. (forward / backward 1~15 km/h)
- The blue pilot lamp is turned ON.

2 ON, Always

- Select **ON**, **Always** in order to turn on the system for ride control regardless speed. The ride control will smooth the ride of the machine during travel.
- The green pilot lamp is turned ON.

3 ON/OFF

Select ON/OFF in order to turn on/off the system for the ride control.
(11) Work mode switch



Current weight in the bucket /

Daily total weight

1

- 2 Select button (Click gray icon) for status (Project status / Truck status)
- 3 Target weight
- 4 Loaded weight
- 5 Remaining weight to complete job / Over weight to complete job
- 6 Progress bar / Total weight

7 Select button for mode (Standby mode / Weigh mode)

960A3CD115

- 8 Project name
- 9 Truck name
- 10 Operator
- 11 Materials
- 12 Go to Work load setting menu
- 13 Save Work log to USB
- 14 Delete Work log
- 15 Go to Main menu

(12) Rear wiper and washer switch

PM 12:00	▶ □□≣	
Rear Wiper	/	
	Ooff	
		Washer
	OLow	
+t+ 🔜 🐨		
⊂ ⊉ 💮 }		
		760F3CD89-1

- ① This switch use to operates the rear wiper and washer. When pressing the switch, the mode is changed sequence base. (OFF \rightarrow intermittent \rightarrow Low \rightarrow OFF)
 - · Intermittent : The rear wiper operates intermittently.
 - · Low : The rear wiper is operated lower speed.
 - Washer : The washer liquid is sprayed while long pressing the button.
- $\ensuremath{\textcircled{}}$ The green pilot lamp is turned ON.

(13) Beacon lamp switch (option)



- $(\ensuremath{\underline{1}})$ This switch turns ON the rotary light on the cab.
- 2 The green pilot lamp is turned ON.

(14) Mirror defrost switch (option)



\bigcirc ON

- In condition of ON, it operates for 15 minutes. After 15 minutes, the defrost function stops automatically.
- The green pilot lamp is turned ON.
- \bigcirc OFF
- Stops defrost function.

(15) Detent setting switch



$\ensuremath{\textcircled{}}$ Boom and bucket

- Set the boom and bucket detent function ON/OFF.
- 2 Save position
- Set the boom kickout and bucket leveler.
- Refer to page 4-22 in operator's manual.
- * The green pilot lamps are turned ON.

(16) Fine modulation switch



① **ON**

- Remote control lever provide the operator with precise control of the work equipment (bucket and boom cylinders can be controlled precisely).
- The green pilot lamp is turned ON.

$\bigcirc \mathbf{OFF}$

- Turn off the function.

4. SWITCHES



960A3CD29A

1) STARTING SWITCH & STARTING BUTTON (OPT)





Starting button with smart key tag (opt)

- (1) There are three positions, OFF, ON and START.
 - $\cdot \bigcirc$ (OFF) : None of electrical circuits activate.
 - \cdot (ON) : All the systems of machine operate.
 - $\cdot \bigcirc$ (START) : Use when starting the engine.

Release key immediately after starting.

- If you turn ON the starting switch in cold weather, the fuel warmer is automatically operated to heat the fuel by sensing the coolant temperature. Start the engine in 1~2 minutes after turning ON the starting switch. More time may take according to ambient temperature.
- Key must be in the ON position with engine running maintain electrical and hydraulic function and prevent serious machine damage.

2) PILOT CUT OFF SWITCH



3) PARKING BRAKE SWITCH



- (1) When the switch is pressed to OFF position, the hydraulic pilot line will be cut off, so the work equipment will not operate.
- (2) Press the ON position in order to unlock the hydraulic pilot line.
- * This switch can be set to ON or OFF position only when the safety button is pulled to the unlock position.
- (1) When the switch is pressed to ON position, the parking brake will start to operate and the cluster warning lamp will comes ON.
- (2) Press the release position in order to disengage the parking brake.
- * When operating the gear selector lever, be sure to release the parking brake. If the machine is operated with the parking brake engaged, the brake will overheat and may cause the brake system to go out of order.
- * This switch can be set to ON or Release position only when the safety button is pulled to the unlock position.
- If you turn ON the starting switch with the parking brake disengaged (release position), the parking brake will be engaged.

To release the parking brake, press the parking brake switch to ON and Release position.

4) EMERGENCY TEST SWITCH (option)



- (1) The emergency steering system can be manually tested. Push the switch in order to determine if the emergency steering and the emergency steering lamp are functional.
- (2) When the switch is pressed, the emergency steering pump motor will run. The emergency steering lamp will light. If the emergency steering lamp does not light, do not operate the machine.

5) DIFFERENTIAL LOCK SWITCH (option)



(1) This switch is used to apply differential lock.

The differential lock gives equal power to both front wheels and is used in conditions when traction is poor.

(2) Manual mode

Press the **M** of the switch for the manual mode of the differential lock function. You press the switch, the differential lock will engage immediately and differential lock pilot lamp lights ON (buzzer sounds). Manual mode is temporarily engaged as long as the operator pushes the switch. When the switch is released, differential lock function is disengaged and the switch returns to OFF position.

(3) Auto mode

Press the **A** of the switch for auto mode of the differential lock function. If you press the switch, the axle differential lock will automatically engage when the differential function is used.

* While the axle differential lock function is operating, the differential lock pilot lamp lights ON.

6) EXHAUST SYSTEM CLEANING SWITCH



(1) This switch is used to select the exhaust system cleaning.

(2) Inhibit position (1)

- The inhibit position disallows any automatic or manual exhaust system cleaning.
- ② This may be used by operator to prevent exhaust system cleaning when the machine is operating in a hazardous environment is concerned about high temperature.
- ③ It is strongly recommended that this position is only activated when high temperatures may cause a hazardous condition.

(3) Auto position (3)

This position will initate a automatic exhaust system cleaning.

(4) Manual position (2)

- ① This position will only initate a manual exhaust system cleaning when the machine is in non-mission condition, engine must run at low idle speed and exhaust system levels are high enough to allow cleaning.
- ② HEST lamp will be illuminated during the entire exhaust system cleaning.
- * Refer to the page 7-29 for ditails.
- * This switch can be move to the manual position (2) only when the safety button is pulled to backward.
- * Also, this switch return to the auto position when released the manual position (2).

7) HORN BUTTON



(1) If you press the button, the horn will sound.

8) CAB LAMP SWITCH



(1) This switch turns ON the cab room lamp.

1 DOOR

The lamp comes ON when the door is opened. When the door is closed the lamp is OFF.

2 ON

This switch is used to turn the lamp ON or OFF.

9) KICK DOWN SWITCH



(1) Manual mode

It is effective 2nd speed to 1st speed only and recover to 2nd speed quickly when push the switch one more time.

(2) Automatic mode

① Mode 1 (down/up)

It shifts down quickly from current gear to one step lower speed by pushing the switch and recover to current speed quickly when push the switch one more time.

2 Mode 2 (down)

It shifts down from current gear to one step lower speed when push the switch every time.

The kick down function is released in only 1st speed.

- * Refer to page 7-40 for the kick down mode.
- * The normal autoshift function continues after the kick down switch is released.

10) FNR SELECT BUTTON AND SWITCH



- (1) These button and switch are used for froward and backward drive.
- * Gear range can be selected by gear selector lever.

(2) FNR select button

- ① If the select button is pressed, the indication lamp on the cluster will be ON and this FNR switch will start to operate.
- When the engine is running, the machine is on standstill (0 speed), parking brake is released, gear selector lever is in the neutral position, you can use this function after pressing the select button.

(3) FNR switch

- · F : Forward drive
- · N : Neutral
- · R : Reverse drive
- 1 If the upper side (F, FWD) of this switch is pushed, the machine moves forward.
- ② If the down side (R, REV) of this switch is pushed, the machine moves backward.
- ③ This function is automatically released when the engine is stopped, parking brake is ON or gear selector lever is out of neutral.
- (4) Auxiliary roller : If the machine is equipped with auxiliary hydraulics, this roller is used for the attachments.

11) WORKLOAD BUTTON



12) HAZARD SWITCH



- This button is used to calculate the weight manually.
 If the button is not pushed, the weight of the weighing system is not calculated.
- (2) This button is pushed for one second more, calculated weight will be accumulated.
- * Refer to the page 7-42, weighing system.
- (1) Use for parking or loading the machine.
- (2) Both turn signal lights will flash simultaneously.
- If the switch is left ON for a long time, the battery may be discharged.

13) MULTI FUNCTION SWITCH



(1) Front wiper and washer switch

- $(\ensuremath{\mathbbm l})$ When the switch is in J position, the wiper moves intermittently.
- * Refer to the page 7-44 (Wiper level setting).
- O When placed in $\ensuremath{\,I}$ or $\ensuremath{\,I}$ position, the wiper moves continuously.
- ③ If you push the grip of the lever, washer liquid will be sprayed and the wiper will be activated 2-3 times.
- * Check the quantity of washer liquid in the tank. If the level of the washer liquid is LOW, add the washer liquid (in cold, winter days) or water. The capacity of the tank is 1 liter.
- If the wiper does not operate with the switch in ON (J, I, II) position, turn the switch OFF (O) immediately and check the cause. If the switch remains ON, motor failure can result.





(2) Dimmer switch

- $(\ensuremath{\underline{1}})$ This switch is used to turn the head lights direction.
- ② Switch positions
 - · Up : To flash for passing
 - · Middle : Head lights low beam ON
 - · Down : Head lights high beam ON
- ③ If you release the switch when it's in up position, the switch will return to middle.

(3) Turning switch

- ① This switch is used to warn or signal the turning direction of the machine to other vehicles or equipment.
- ② Push the lever up for turning left, pull the lever down for turning right.

GROUP 4 ELECTRICAL COMPONENT SPECIFICATION

Part name	Symbol	Specifications	Check item
Battery		12V × 220Ah (2EA)	Gravity 1.280 over : over charged 1.280 ~ 1.250 : normal 1.250 below : discharged
Battery relay	CR-1	Rated load : 24V 100A (continuity) 1000A (30seconds)	Coil resistance breaked : approx 50 Ω connected : $\infty \Omega$
Fusible link	CN-351 (40A), CN-352 (80A)	24V	Resistance between ring termi- nal and each connector pin 0 \Omega : normal
Start key	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	B-BR : 24V 1A B-ACC : 24V 10A B-ST : 20V 40A	Resistance between each pin Key off : $\infty \Omega$ (for each pin) Key on : 0Ω (for pin 1-2 & 1-3) Start : 0Ω (for pin 1-5)
Pressure switch	$\begin{array}{c c} A & \begin{array}{c} Pa \\ B \\ C \end{array} \begin{array}{c} \bullet \\ C \end{array} \begin{array}{c} \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \begin{array}{c} \bullet \\ \bullet \\ \bullet \\ \bullet \end{array} \end{array}$	N.C Туре	Resistance 0Ω: normal (close)
Pressure switch	○ 1 ○ 2 Pa CD-48 CD-129	N.O Туре	Resistance $\infty \Omega$: normal (open)

Part name	Symbol	Specifications	Check item
Pilot cut off, parking brake, diff lock, attach lock, unlock solenoid	CN-68 CN-177 CN-71 CN-178 CN-79	24V 1A	Resistance normal : 15~25 Ω
Air cleaner pressure switch	CD-10	Max load : 6W N.O Type	Resistance $\infty \Omega$: normal (open)
Lock-up, Ride control valve / Fan sole- noid	○ 2 ○ 1 CN-43 CN-136 CN-154 CN-155	24V 1.2A	 ※ Check LED lamp ※ Check resistance about 24 Ω
Fuel sender	010 020 CD-2	-	Resistance at fuel levels full level : 200Ω 9/12 level : 500Ω 6/12 level : 800Ω 3/12 level : 1100Ω empty : 1300Ω
Room lamp	CL-1	24V 10W	Resistance normal : 1.2Ω
Relay (5pin)	CR-3 CR-5 CR-7 CR-30 CR-35 CR-36 CR-38 CR-40 CR-46 CR-55 CR-56 CR-63 CR-210 CR-211 CR-381	24V 20A	Resistance normal : about 160 Ω (for pin 85~86) 0 Ω (for pin 30~87) ∞ Ω (for pin 30~87)

Part name	Symbol	Specifications	Check item
Relay (5 pin)	CR-2 CR-4 CR-25 CR-26 CR-37 CR-58 CR-79 CR-115 CR-117 CR-136 CR-302 CR-303	24V 20A	Resistance normal : about 160 Ω (for pin 1~2) 0 Ω (for pin 3~4) ∞ Ω (for pin 3~5)
Hydraulic, transmission temperature	CD-1 CD-49	_	Resistance normal : $\infty \Omega$ 105. C over : 0Ω
Speaker	CN-123 (LH) CN-124 (RH)	4Ω 20W	Resistance normal : 4Ω
Switch (Locking type)	CS-4 CS-17 CS-75	24V 8A	Resistance at switch off position ∞Ωbetween pin 1-5 and 2-6 0Ωbetween pin 5-7 and 6-8
Work lamp, Number plate lamp	CL-21 CL-32 CL-33 CL-35 CL-36 CL-42 CL-43 CL-45 CL-46	Work lamp 24V 70W Number plate lamp 24V 10W	Resistance normal : 1.2Ω
Beacon lamp	CL-117	24V 70W (H1 TYPE)	Resistance normal : 1.1 Ω

Part name	Symbol	Specifications	Check item
DC/DC Converter	* 3 * 10 * 12 * 2 * 4 * 5 * 5 * 5 * 5 * 7 * 7 * 10 * 12 * 12 * 5 * 5 * 5 * 5 * 5 * 5 * 5 * 5	12V 3A	Resistance 8.8Ω (for pin A-B) 7.7Ω (for pin B-C)
Horn	CN-120 CN-121	24V 2A	Operation by external power source - conncet 24V power to (+) terminal - ground the (-) terminal
Receiver dryer	20 PA 010-0- CN-29	24V 2.5A	Resistance $0\Omega: 2.1\pm0.3$ ~27 ±2 kgf/cm ² $\infty \Omega: ~2.1\pm0.3, 27\pm2$ ~kgf/cm ²
Radio & USB player	CN-52	24V 20W+20W	Resistance Power ON : 4Ω+4Ω (for pin 1-6, 4-8)
Back up buzzer	CN-65	24V 0.5A 110dB	Resistance normal : 5.2Ω
Washer pump	CN-102 (FR) CN-103 (RR)	24V 2.5A	Resistance normal : 26.4 Ω (for pin1-2)

Part name	Symbol	Specifications	Check item
Wiper motor	E 3 Pf 2 B 1 Hi 4 Hi 4 So 60 CN-21 (FR) CN-102 (RR)	24V 1.5A 2-speed Auto parking	-
Cigar lighter	CL-2	24V 5A 1.4W	Coil resistance normal : about 1MΩ
Starter	M B+ CN-45	24V-7.5kW	Operating or not
Aircon compressor	CR-23	24V 79W	Resistance normal : 13.4Ω
Start relay	CN-28	24V 300A	Coil resistance normal : 1-2 Ω Switch connection $\infty \Omega$ at normal open position 0Ω when engaged

Part name	Symbol	Specifications	Check item
Blower motor		24V 9.5A	Resistance at each switch position normal : 0.5-2 Ω
Door switch	CS-1 CS-55	24V 2W	Resistance normal : about 5MΩ
Flasher unit	85 85 87 87 87 86 87 86 87 86 87 86 87 86 87 86 86 87 86 86 87 86 86 87 86 86 86 87 86 <	24V 85 ~ 190 C/M 50dB	-
Head lamp	$ \begin{array}{c c} \circ & 6 & \downarrow & c \\ \circ & 4 & \circ & Hi \\ \circ & 5 & \circ \\ \circ & 5 & \circ \\ \circ & 3 & \circ & c \\ \circ & 3 & \circ & c \\ \circ & 1 & \neg & \hline T \\ \hline & CL-3 \\ \end{array} $	24V 75W/70W (H4 TYPE) 24V 4W (T4W)	Resistance normal : a few Ω
Combi lamp (rear)	0 4 0 C 3 0 T 2 0 E 0 1 S CL-15 CL-16	24V 5W (R5W) 2×24V 21W (P21W)	-
Master switch	CS-74 CS-75	Continuous capaci- ty : 180Amp Push in capacity : 1000Amp	-

Part name	Symbol	Specifications	Check item
Warning buzzer	020 00 CN-26	24V 200mA 90±5dB (ℓm)	-
Preheater	CN-80	24V 200A	Resistance 0.25~0.12Ω
Resistor	$ \begin{array}{c c} O & A \\ O & B \\ O & C \\ \end{array} $ B CN-99	4W	Resistance A - B : 120 Ω

GROUP 5 TROUBLESHOOTING

1. WHEN STARTING SWITCH IS TURNED ON, CLUSTER AND MONITOR LAMP DOES NOT LIGHT UP

- Before carrying out below procedure, check all the related connectors are properly inserted and the fuse No.12, 17 are not blown out and ON/OFF of bulb.
- · After checking, connect the disconnected connectors again immediately unless otherwise specified.



No.17

960A7EL24

Check voltage

CN-56

YES	20 ~ 30 V
NO	0 V

2. **WHEN BATTERY LAMP LIGHTS UP** (engine is started)

· Before carrying out below procedure, check all the related connectors are properly inserted.

· After checking, connect the disconnected connectors again immediately unless otherwise specified.





980A7EL38

Check valtage

YES	20 ~ 30 V
NO	0 V

3. WHEN PARKING SOLENOID DOES NOT WORK

- Before carrying out below procedure, check all the related connectors are properly inserted and the fuse No.41 is not blown out.
- · After checking, connect the disconnected connectors again immediately unless otherwise specified.





960A7EL39

4. TRANSMISSION IS NOT RETURNED TO NEUTRAL WHEN PARKING BRAKE IS APPLIED

- Before carrying out below procedure, check all the related connectors are properly inserted and the fuse No.15 (transmission control unit) and No.41 are not blown out.
- · After checking, connect the disconnected connectors again immediately unless otherwise specified.







YES	ΜΑΧ 1 Ω
NO	ΜΙΝ 1Μ Ω

760F7EL40

5. MACHINE DOES NOT TRAVEL

- · Before carrying out below procedure, check all the related connectors are properly inserted and the fuse No.15 (transmission control unit) is not blown out.
- · After checking, connect the disconnected connectors again immediately unless otherwise specified.





Check resistance

YES	ΜΑΧ 1 Ω
NO	ΜΙΝ 1Μ Ω

6. WHEN STARTING SWITCH IS TURNED ON, WIPER MOTOR DOES NOT OPERATE

• Before carrying out below procedure, check all the related connectors are properly inserted and the fuse No.40 is not blown out.

· After checking, connect the disconnected connectors again immediately unless otherwise specified.





7. WHEN STARTING SWITCH "ON" DOES NOT OPERATE

· Before carrying out below procedure, check all the related connectors are properly inserted the fuse No.2 is not blown out.

· After checking, connect the disconnected connectors again immediately unless otherwise specified.





8. WHEN STARTING SWITCH IS TURNED ON, WORK LAMP DOES NOT LIGHTS UP

· Before carrying out below procedure, check all the related connectors are properly inserted, and the fuse No.26, 39 is not blown out.

· After checking, connect the disconnected connectors again immediately unless otherwise specified.





ç

	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	ATT. 200 43	- 8 10 45		(ET 104 14		1,2,3 15A 50		ADER 2104 02] ⊉[CN-39
ALITO GREASE	AIR PRE-HEAT	FAN REVERSE, ATT	RIDE CONTROL SPARE	QUICK COUPLLER	SERVICE SOCKET	DEF SENSOR	HOSE HEATING 1,2;	ECU B+	SMART KEY READE	COWL OPEN	OPEN ACTUATOR	HORN	SERVICE B+	

980A7EL43