

ELECTRIC SYSTEM

CHAPTER 5

ELECTRIC SYSTEM

TABLE OF CONTENTS

1. SPECIFICATIONS.....	5-2
2. CIRCUIT AND COMPONENT LOCATION	5-3
2.1 Electric circuit diagram.....	5-3
2.2 Location of electronic components.....	5-5
3. WIRING IDENTIFICATION	5-7
3.1 Wiring color identification.....	5-7
3.2 Cross sectional area of wiring	5-8
3.3 Symbols for electric components	5-8
3.4 Fuse	5-9
3.4.1 Inspection.....	5-9
3.4.2 Cause for blown fuse	5-9
3.5 Electric device diagnosis	5-10
4. ELECTRIC COMPONENTS.....	5-11
4.1 Engine room	5-11
4.1.1 Battery	5-11
4.1.2 Fuse box.....	5-11
4.1.3 Starter motor	5-13
4.1.4 Alternator.....	5-14
4.1.5 Glow plug	5-16
4.1.6 Coolant temperature sensor.....	5-16
4.1.7 Engine oil pressure switch.....	5-18
4.1.8 ECU	5-18
4.1.9 Sensors and relays.....	5-19
4.2 Cabin & Chassis	5-39
4.2.1 Ignition switch	5-39
4.2.2 Escort unit.....	5-40
4.2.3 Flasher.....	5-41
4.2.4 Switch panel	5-41
4.2.5 Engine accelerator dial	5-43
4.2.6 Accelerator pedal sensor.....	5-44
4.2.7 Relay box	5-46
4.2.8 Instrument panel	5-47
4.2.9 MCU (Micro Controller Unit)	5-74
4.2.10 Telematics controller	5-88
4.2.11 RCV assembly (LH) (RH)	5-90
4.2.12 Safety sensor (safety bar)	5-91
4.2.13 Seat switch	5-92
4.2.14 Oil temperature sensor.....	5-93
4.2.15 Horn.....	5-93
4.2.16 Wiper motor.....	5-94
4.3 Lamps (Bulb replacement).....	5-95
4.3.1 Led work lamp	5-95
4.3.2 Turn signal lamp	5-95
4.3.3 Brake lamp (Rear lamp) / Turn signal lamp	5-96
4.3.4 Room lamp.....	5-97
5. TROUBLESHOOTING	5-98
5.1 When the engine cannot be started.....	5-98
5.2 When the system is not charged	5-100
5.3 When the system is not preheated automatically	5-102
5.4 When work lamp cannot be operated....	5-105
5.5 Fuel gauge operation.....	5-107
5.6 Temperature gauge operation	5-108
5.7 Hour meter operation	5-109
6. WIRING DIAGRAM.....	5-111
6.1 Main	5-111
6.2 MCU update.....	5-115
7. EXPLODED VIEW.....	5-116
7.1 LF1-G311007 Engine electrical group	5-116
7.2 LF1-G327001 Light control group	5-117
7.3 LF1-G328002 Power socket group	5-118
7.4 LF1-G331001 Wire harness group.....	5-119
7.5 LF1-G332001 Cluster control group	5-120
7.6 LF1-G332501 Fuel sender group	5-121
7.7 LF1-G333501 Vehicle control group	5-122

ELECTRIC SYSTEM - SPECIFICATIONS

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM


CABIN

INDEX

1. SPECIFICATIONS


ITEM	SPECIFICATION
Battery	12V 110Ah
Alternator	13.5V 75A
Starter motor	12V 2.5kW
Slow-blow fuse	30A(Start), 40A(Engine), 60A(Lamp), 70A(Power 2), 80A(Preheat), 100A(Power 1)
Engine oil pressure switch	0.5 kgf/cm ²
Crankshaft wheel sensor	Operating voltage : 4 ~ 24 VDC
DPF differential pressure sensor	Operating voltage : 4.75 ~ 5.25 VDC
Intake air temperature sensor (T1)	Temperature range : -40°C ~ 250°C
MCU	Operating voltage : 8 ~ 16 VDC
Buzzer	Rated voltage : 6 ~ 24 VDC
Twin relay (For motor)	Operating voltage : 10 ~ 15 VDC
Oil temperature sensor	Operating temperature : -30°C ~ 130°C
Escort unit	Operating voltage : 10 ~ 16 VDC
Relay (70A)	Operating voltage : 9 ~ 16 VDC
Flash unit	Operating voltage : 9 ~ 15 VDC
Horn	12V 2.5A 105 ~ 118 dB(A)
Turn signal lamp, tail lamp	12V P21W, 5W
Brake lamp, turn signal lamp, tail lamp	12V P21W, P21/5W
Work lamp	LED
Number plate lamp	12V 3W
Room lamp	12V 10W

HS80V




2. CIRCUIT AND COMPONENT LOCATION
2.1 ELECTRIC CIRCUIT DIAGRAM (HS120V)

HS120V




2.2 LOCATION OF ELECTRONIC COMPONENTS




ENGINE (LH)




ENGINE (RH)



ENGINE ROOM



DRIVER'S SEAT



- (1) Telematics controller
- (2) MCU
- (3) Engine diagnosis connector(OBD II)
- (4) Flasher unit
- (5) Escort unit
- (6) MCU update connector

- (1) Instrument panel
- (2) Engine accelerator dial
- (3) Ignition switch
- (4) Switch panel (RH)
- (5) Switch panel (LH)
- (6) Relay box
- (7) A/C controller
- (8) Power socket


3. WIRING IDENTIFICATION

3.1 WIRING COLOR IDENTIFICATION

The color codes in the following table are marked on every wiring in the wiring diagrams. It is necessary to have full knowledge of the color codes in order to understand circuit diagrams when checking actual wirings based on circuit diagrams.

Code	Color	Code	Color
B	Black	R	Red
Lg	Light Green	Gr	Gray
W	White	G	Green
L	Blue	Y	Yellow
P	Pink	Br	Brown
Or	Orange	BR	Black/Red
BW	Black/White	BG	Black/Green
BY	Black/Yellow	RB	Red/Black
RW	Red/White	RG	Red/Green
RL	Red/Blue	RY	Red/Yellow
LgB	Light Green/Black	LgR	Light Green/Red
LgW	Light Green/White	LgY	Light Green/Yellow
GrY	Gray/Yellow	WB	White/Black
WR	White/Red	WL	White/Blue
WY	White/Yellow	GR	Green/Red
GW	Green/White	GL	Green/Blue
GOR	Green/Orange	LW	Blue/White
LY	Blue/Yellow	YB	Yellow/Black
YR	Yellow/Red	YW	Yellow/White
YG	Yellow/Green	YL	Yellow/Blue
YBr	Yellow/Brown	PB	Pink/Black
BrR	Brown/Red	BrW	Brown/White

The following figures are examples for colors according to the codes.



C56WB02A

3.2 CROSS SECTIONAL AREA OF WIRING

All wirings in circuit diagrams are marked with their colors and cross sectional area so that mechanics can understand wiring thickness with ease.


For example, "5.0 R" refers to a red wiring with 5 mm² of cross sectional area. Therefore, the diameter of the wiring with 5 mm² of the cross sectional area is 2.523 mm.

3.3 SYMBOLS FOR ELECTRIC COMPONENTS

SYMBOL	DESCRIPTION	SYMBOL	DESCRIPTION
	Fuse		Double bulb
	Fuse (15 A)		Diode
	Motor		Relay
	Switch (Normally Open Type)		Buzzer
	Switch (Normally Close Type)		
	Ground (Wire) Ground (Chassis)		Safety switch
	Resistor		Reverse buzzer
	Coil		Solenoid
	Battery		Horn
	Disconnected wire		Speaker
	Connected wire		Glow plug Fuel heater
	Lamp		Sensor

3.4 FUSE

3.4.1 INSPECTION




(1) Tester

(2) Fuse box

The blade type fuse can be checked without pulling it out from the fuse box. When connecting the lead wires from the test lamp to the test lead wire and grounding, the test lamp should light up.

3.4.2 CAUSE FOR BLOWN FUSE



- (1) Blown fuse due to excessive current
- (2) Blown fuse due to heat fatigue


OVER-CURRENT

1. When a fuse is blown due to over-current, do not simply replace the fuse.
2. Check if there is any abnormal condition or open circuit in any electric device.
3. Correct the cause for a blown fuse first, and then replace the blown fuse with a new one with the rated capacity.
4. If using a fuse with a different capacity, its wiring or related components can be damaged.

FREQUENTLY REPEATED ON/OFF STATUS CHANGE

1. This can degrade parts' durability. Avoid excessively repeated operation.
2. Replace the fuse with a new one with the rated capacity.

3.5 ELECTRIC DEVICE DIAGNOSIS



(1) Tester (2) Ground (3) Test lamp

An electric circuit consists of power, switch, relay, load, ground, etc. It can be checked by various methods, such as voltage check, open circuit check and continuity check.

VOLTAGE INSPECTION

With the ignition switch in the "ON" position, measure the voltage between the terminals to be tested with a tester. Connect the red lead of a tester to the electric load and the black lead to the chassis or ground to measure voltage.

TEST LAMP CHECK

Ground one lead of a test lamp and connect the other lead to an electric load. The test lamp should turn on and a voltage value should be detected by a tester. If a circuit is intact but an electric device is faulty, start troubleshooting from the closest connector with the voltage test and visual check.

4. ELECTRIC COMPONENTS

4.1 ENGINE ROOM

4.1.1 BATTERY




Open the rear cover, the battery is installed on the right hand side. A lead-acid battery is used, which is rechargeable by supplying electricity from outside.

- Capacity : 12V 110Ah

4.1.2 FUSE BOX

SLOW-BLOW FUSE





- (1) Lamp power fuse (60A)
- (2) Power 2 fuse (70A)
- (3) Preheat power fuse (80A)
- (4) Power 1 fuse (100A)
- (5) Engine power fuse (40A)
- (6) Ignition power fuse (30A)

Six slow-blow fuses are installed on the frame in the left side of the engine compartment and they are connected to the main wiring. If any electric system does not operate while the battery operates properly, the slow-blow fuse should be checked. If the replaced fuse is blown again, there is a short circuit between the direct B line (power from the battery) and the chassis.

FUSE	COMPONENT TO DIAGNOSE
Lamp	RCV (LH), Horn relay, Flasher unit, Room lamp, Power relay 2
Power 2	Power relay 4, Power socket, 14-pin
Preheat	Power relay 1, Glow plug
Power 1	Alternator, Ignition switch, A/C, Cabin, Fuel heater
Engine	ECU relay, ECU
Ignition	Starter relay

MAIN FUSE BOX



The main fuse box is installed on the right side of the engine room.

It protects systems from excessive electric load.



If the current through the fuse is over the specified capacity, the conductor of the fuse is blown to protect controller and circuit.

If the fuse is blown, find the cause and replace it with new one with the same capacity.

CONDITIONS	RESULT
110% of rated current is applied	The fuse is not blown.
130% of rated current is applied	The fuse is blown within 60 seconds.
150% of rated current is applied	The regular fuse is blown within 15 seconds and the fuse for over 30 A is blown within 30 seconds.

NO	CAPACITY	FUNCTION
1	10A	RMS Alternator
2	10A	14-pin
3	25A	Electric fan
4	25A	Fuel heater
5	10A	ECU_key_power
6	10A	Room lamp
7	10A	Flasher unit
8	10A	Joystick (LH)
9	10A	Horn
10	10A	ECU sensor
11	25A	ECU power
12	5A	ECU relay
13	15A	Wiper/washer
14	10A	Bluetooth Player
15	30A	Valve power
16	10A	Cabin
17	10A	Right Joystick
18	10A	Brake lamp
19	30A	Air con
20	10A	Beacon lamp
21	10A	Power socket
22	15A	MCU/Cluster
23	20A	Work lamp (Front, Rear)
24	30A	14-pin (C/D/E/F/G/H)
25	10A	Back buzzer
26	20A	Pilot lock Bucket/Travel
27	10A	Parking
28	15A	Seat
29	5A	Fan clutch
30	5A	SPARE
31	10A	SPARE
32	10A	SPARE
33	15A	SPARE
34	20A	SPARE
35	25A	SPARE
36	30A	SPARE

4.1.3 STARTER MOTOR



The start motor is divided by three sections:

- Motor - Generates torque for cranking the engine.
- Magnet switch - Engages the ring gear with the pinion gear and turns current ON and OFF.
- Overrun clutch - Transfers torque from the start motor to the engine, and blocks engine turning torque to the start motor if the engine rotates faster than the start motor, i.e. the engine is started, for protection of the start motor.

ENGINE START SYSTEM INSPECTION


ITEM	CAUSE	SOLUTION
The start motor runs but the engine does not crank	Damaged clutch pinion gear or defective start motor	Replace the start motor
	Damaged flywheel ring gear	Replace the flywheel
	Open related circuit	Repair
The start motor keeps running	Defective start motor	Repair or replace
	Defective ignition switch	Replace
The engine cannot crank	Low battery charging voltage	Charge or replace
	Loose, corroded or worn battery cable	Repair or replace
	Defective start motor or open circuit	
	Defective ignition switch or blown power fuse	Replace the ignition switch or fuse.
	Poor engine ground	Repair
The engine cranks slowly	Low battery charging voltage	Charge or replace
	Loose, corroded or worn battery cable	Repair or replace
	Defective start motor	

4.1.4 ALTERNATOR

There are some components, such as Head lamp, start motor, engine stop solenoid and glow plug, which need a lot of electricity. The alternator supplies power to such components and charges the battery which stores electricity for the tractor.


Therefore, the alternator correlates with the battery and electric loads and it is an original source of electricity for the entire tractor.

TEST



(1) 2P No. 1 connector (3) Battery power
 (2) 2P No. 2 connector

PERFORMANCE CURVE OF ALTERNATOR



T46WBA5A

As shown in the performance curve in the above figure, the alternator does not generate power until its speed reaches 1,200 rpm. This minimum revolution speed is called "Cut In Speed".

If the alternator's speed is below the cut in speed, the alternator does not generate power and the charge warning lamp does not go off.

Also, the output performance changes as the output current (A) changes according to the coil's temperature (cold and hot). Therefore, the average curve for the cold and hot conditions is presented as guaranteed performance.


In general, the alternator's pulley ratio is determined to maximize the alternator output in the rated maximum output of the engine.

Item	Tester Connection		Location	Result
	Red Lead	Black Lead		
DC Voltage	2P No. 1 connector	Chassis (GND)	Ignition switch ON	DC 12V
	2P No. 2 connector	Chassis (GND)	Ignition switch in ST	DC12 ~ 14.7 V
	2P No. 1 connector	2P No. 2 connector	Ignition switch ON	DC 12 V

CHARGING SYSTEM INSPECTION

ITEM	CAUSE	SOLUTION
The charge warning lamp does not illuminate with the ignition switch in the ON position (engine stopped)	Defective alternator regulator	Replace the alternator
	Open/Blown charge warning lamp, fuse or wiring	Replace or repair the charge warning lamp/fuse
	Defective ignition switch	Replace the ignition switch
	Poor alternator circuit ground	Repair
The charge warning lamp does not go off after the engine is started (frequent battery charging required)	Defective alternator regulator	Replace the alternator
	Corroded or worn battery cable	Repair or replace the cable
	Loose alternator drive belt	Adjust the belt tension or replace the belt
	Defective wiring	Repair or replace
The battery is discharged	Loose alternator drive belt	Adjust the belt tension or replace the belt
	Poor connection of related circuit or open circuit	Tighten the connection or repair open circuit
	Defective alternator regulator	Replace the alternator
	Expired battery	Replace the battery
	Poor ground	Repair
The battery is over-charged	Defective alternator regulator	Replace the alternator
	Defective alternator regulator	Replace the alternator
	Defective voltage detecting wiring	Repair or replace

4.1.5 GLOW PLUG




The glow plug is installed in the engine cylinder head close to the nozzle.

It is installed in each cylinder as one of the ignition system component to heat air in the combustion chamber for cold start. Max. 20 A of current flows through the glow plug in 4 seconds after voltage is generated. When its temperature rises to 800°C at this time, it is normal.

TEST

Item	Location	Tester Connection		Result
		Red Lead	Black Lead	
Resistance	Connector disconnected	Connector No. 1	Ground	0.5 Ω
DC Voltage	Ignition switch ON (below 0°C)	Connector No. 1	Ground	DC 12 V

4.1.6 COOLANT TEMPERATURE SENSOR



- (1) Temperature sensor terminal (-)
- (2) Gauge unit terminal (+)
- (3) Temperature sensor terminal (+)

The coolant temperature sensor is installed to the side of the coolant flange.

This sensor detects the engine coolant temperature and sends the automatic preheat signal to the cluster temperature gauge and display unit.

This sensor is used to show the driver the current engine temperature.


RESISTANCE OF GAUGE UNIT SENSOR

Temperature (°C) (°F)	60 140	85 185	110 230	125 257
Resistance (Ω)	125	48	24	15

RESISTANCE OF TEMPERATURE SENSOR

Temperature (°C)	Resistance (kΩ)
-40	48.14
-20	15.48 ± 1.35
0	5.790
20	2.45 ± 0.14
40	1.148
60	0.5865
80	0.3222
100	0.1884
110	0.1471 ± 0.002
120	0.1163

※ The reference value of the temperature sensor for preheat relay output is 30°C (86°F).

4.1.7 ENGINE OIL PRESSURE SWITCH


LF1W510A

The engine oil pressure switch is installed to the top of the start motor on the left rear section of the engine.

When $0.5 \pm 0.1 \text{ kg/cm}^2$ (7 psi \pm 1.4 psi) or less of pressure is built in the engine oil system, this switch's contact point is connected to send a warning signal to the instrument cluster.

TEST

Item	Tester Connection		Position	Result
	Red Lead	Black Lead		
Resistance	Oil switch contact	Chassis (GND)	Oil lamp ON on instrument cluster	Continuity (0Ω)


4.1.8 ECU

U89WB12A

LF1W511A

The ECU (Electronic Control Unit) is installed on the rear right side of the engine. The ECU receives information from various sensors installed in the engine to optimize combustion in order to enhance engine performance and fuel consumption.

4.1.9 SENSORS AND RELAYS



- | | |
|--|---------------------------------------|
| (1) Crankshaft wheel sensor | (8) Water-in-fuel sensor |
| (2) Intake air pressure sensor (T1) | (9) Exhaust gas temperature sensor |
| (3) EGR valve sensor | (10) Camshaft wheel sensor |
| (4) Fuel rail pressure sensor | (11) DPF differential pressure sensor |
| (5) Intake air temperature & pressure sensor | (12) Air control valve sensor |
| (6) Accelerator (Knock) sensor | |
| (7) High-pressure fuel pump temperature sensor | |

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX




CRANKSHAFT WHEEL SENSOR

The crankshaft wheel sensor is installed to the edge on the lower right side of the engine next to the transmission.

- Supplied power: 4 ~ 24 VDC
- Supplied current: 6 mA
- Output current: 30 mA



CAUTION

- When installing the crankshaft wheel sensor to the engine block, be careful not to miss the O-rings.

CIRCUIT DIAGRAM**CONNECTOR**

The crankshaft wheel sensor is a magnetic pickup type and it is supplied with 5 V power. It outputs sine waveform according to the change in magnetic field occurred by rotation of the crankshaft. Then, the position/speed of the crankshaft can be determined by the current value through the changed resistance value.

The crankshaft wheel sensor detects the position of each piston and sends this information to the ECU which then uses this information to set the injection timing and amount.

INTAKE AIR TEMPERATURE SENSOR (T1)


The intake air temperature sensor is installed on the intake hose which is connected the turbo charger.


It measures the amount and temperature of the intake air and sends these information to the ECU which then uses these information to set the injection amount and timing. The intake air amount information is also used as a primary condition for the EGR control.

- It measures the amount and temperature of the air drawn into the engine.
- Its measurement is used as an important information to determine the fuel injection amount for theoretical air-fuel ratio control.
- Its measurement is also used as a feedback signal for EGR valve control.
- Intake air temperature - output as digital/analogue
- Temperature detection range of the element : -40°C ~ 250°C

► RESISTANCE BY TEMPERATURE

Temp [°C]	R min [kΩ]	R cent [kΩ]	R max [kΩ]
-40	192.11	204.12	216.68
0	26.500	27.598	28.716
25	9.7000	10.000	10.300
85	1.3810	1.4510	1.5240
100	0.9165	0.9672	1.0200
150	0.2741	0.2927	0.3123
200	0.1022	0.1102	0.1187
250	0.0451	0.0490	0.0532

► INPUT/OUTPUT DIAGRAM

EGR VALVE SENSOR

U89WB21A

LF1W515A

The EGR (Exhaust Gas Recirculation) valve sends some of exhaust gas back into the cylinder through the intake port to decrease the combustion temperature during ignition in order to decrease NOx (Nitrogen Oxides) in exhaust gas. The EGR valve sensor detects the position of the valve so that the EGR valve can control the air intake amount.

FUEL RAIL PRESSURE SENSOR


U89WB23A

LF1W516A

The fuel rail pressure sensor is installed to the side of the fuel rail. The fuel rail is a device to convert the fuel pressure signal into a electric signal, amplify it and supply it to the ECU. The fuel rail pressure is determined based on the engine RPM, engine torque, barometric pressure, coolant temperature, intake air temperature, etc. Once the fuel rail pressure is determined, it is controlled by the IMV. Then, the fuel rail pressure sensor is used to detect the fuel rail pressure and set the opening amount of the IMV. The fuel rail pressure sensor can measure the fuel pressure from 0 up to 2,200 bars.


► FUEL RAIL PRESSURE SENSOR CHARACTERISTICS

SENSOR OUTPUT VOLTAGE



Sensor supply voltage	5 ± 0.1 V	
Sensor output voltage	At 2,200 bars	4.5 ± 0.125 V
	At 0 bar	0.5 ± 0.04 V
Faulty range	At 0 - 1,000 bars	$\pm 1.0\%$ or more
	At 1,000 - 1,800 bars	$\pm 1.6\%$ or more

INTAKE AIR TEMPERATURE & PRESSURE SENSOR



The intake air pressure sensor and temperature sensor are installed on the intake manifold side by side.


The intake air pressure sensor detects the pressure of air drawn in forcibly by the turbocharger precisely for use as important information to determine the optimal fuel injection amount.

Also, the intake air temperature sensor detects the temperature of the intake air by its resistor which its resistance value is changed by changes in the air temperature. This information is used to identify the exact air mass and adjust the fuel injection amount accordingly for optimum operation.

► INTAKE AIR TEMPERATURE & PRESSURE SENSOR (PRESSURE SENSING)

Guaranteed pressure range	20 ~ 300 kPa
Guaranteed temperature range	-40°C ~ 125°C
Guaranteed supplying power	4.75 ~ 5.25 V
Max. current consumption	12.5 mA

- Pressure sensor output characteristics $V_s = 5$ V




► INTAKE AIR TEMPERATURE SENSOR

Applied temperature range (continuous)	-40°C ~ 200°C
Supplied power	5 ± 4% VDC

- PROBE CHARACTERISTICS

TEMPERATURE (°C)	RESISTANCE (Ω)			TEMP. TOL. (± °C)
	MINIMUM	NORMAL	MAXIMUM	
-40	36,308	39,650	42,992	1.5
-20	12,890	13,844	14,798	1.4
0	5,179	5,489	5,799	1.3
20	2,316	2,419	2,522	1.1
25	1,925	2,000	2,075	1.0
50	805.8	833	860.2	1.0
80	326.7	336.1	345.5	1.0
100	190.7	197.3	203.8	1.3
150	60.93	63.77	66.61	2.2
180	34.45	36.26	38.08	2.8
200	24.49	25.87	27.25	3.3

ACCELERATOR (KNOCK) SENSOR


Two acceleration (knock) sensors are installed to the engine cylinder block (intake manifold side).

When engine knocking occurs, the piston or connecting rod is vibrated and, in a severe condition, hitting a metallic object is heard. The knock sensor is to detect this knocking condition due to abnormal combustion.

This sensor has a piezo-electric element fixed to the diaphragm to detect vibration of the engine occurred by abnormal combustion, and the diaphragm is fixed to the base.

Also, it is also used to control idle stability and detect injector's faulty condition to illuminate the engine warning lamp and adjust the pilot injection amount precisely.

If the acceleration (knock) sensor malfunctions, the ECU calibrates the injection timing based on the engine RPM, intake air amount and coolant temperature.

► CONNECTOR**► KNOCK SENSOR CHARACTERISTICS**

When the engine temperature is low, it outputs a high value due to a large fuel injection amount and vibration. However, after the engine is warmed up, its signal value is decreased.


The 1st knock sensor outputs signals for the 1st and 2nd cylinders while the 2nd knock sensor outputs signals for the 3rd and 4th cylinders.

Insulation resistance	Min. 1 MΩ
Resonance frequency	25 kHz
Operating temperature range	-40 ~ 150°C
	26 ± 8 mV/g (at 5 kHz)
Output voltage	22 ~ 37 mV/g (3~10kHz)
	22 ~ 57 mV/g (10~20kHz)


HIGH-PRESSURE FUEL PUMP TEMPERATURE SENSOR

The high-pressure fuel pump temperature sensor is installed right below the IMV (Inlet Metering Valve) of the high-pressure fuel pump. This temperature sensor detects the inlet temperature of the high-pressure fuel pump and sends this information to the ECU. Generally, the temperature of returning fuel rises quite a lot in the common rail diesel engine. In this case, lubrication film of fuel is destroyed so its lubricating performance is deteriorated, resulting in possible damage of the high-pressure fuel pump. Therefore, when the fuel temperature rises over the specified level, this information is sent from the temperature sensor to the ECU which then adjusts the fuel injection amount to control the engine RPM in order to prevent further fuel temperature increase.



It also measures the fuel temperature to decrease the opening amount of the IMV in case of overheating condition in order to decrease the amount of compressed fuel and prevent a further rise of the fuel temperature. The fuel temperature sensor is a NTC resistor type and is installed between the low-pressure line and high-pressure line in the high-pressure pump. It uses 5 V power to generate its output voltage.

FUEL TEMPERATURE SENSOR CHARACTERISTICS

Temperature (°C)	Resistance (Ω)	Voltage (V)
-40	75,789	4.903
-10	12,462	4.463
0	7,355	4.153
10	4,481	3.746
20	2,812	3.261
40	1,199	2.221
70	394	1.040
90	206	0.604
120	87	0.276
140	52	0.171

WATER-IN-FUEL SENSOR

The water-in-fuel sensor is installed under the fuel filter. When water enters the engine fuel system, it can damage the high-pressure fuel pump, filter and injector and cause poor engine starting performance and malfunction. Therefore, when water is collected (45cc or more) on the bottom of the fuel filter, this water-in-fuel sensor sends a signal to the instrument cluster which then turns on the water-in-fuel warning lamp. Make sure to drain water from the pre-filter in this case.

EXHAUST GAS TEMPERATURE SENSOR

The exhaust gas temperature sensors are installed to the side of the exhaust manifold (front exhaust temperature sensor) and to the CCRT (Catalyzed Continuously Regenerating Trap) (rear exhaust temperature sensor).

It is also installed to the outlet of the DOC (Diesel Oxidation Catalyst) to detect the temperature in the DOC for determination of overheating condition.

When the engine is overheated (over 900°C to 950°C), the DOC is melted, increasing soot in exhaust gas.

Therefore, when the exhaust gas temperature rises over a certain level, the exhaust gas temperature sensor sends a signal to the ECU which then controls the EGR operation to decrease the temperature in the combustion chamber in order to prevent overheating of the catalyst and decrease the exhaust gas temperature.

- FRONT EXHAUST TEMPERATURE SENSOR

The front exhaust temperature sensor is installed in the exhaust manifold. It uses the change in resistance occurred by the exhaust gas temperature change, converts it to the voltage value, and send this information to the engine ECU.

To prevent turbocharger damage in the post-injection process, it is used to limit the fuel injection amount at a high exhaust gas temperature.

- REAR EXHAUST TEMPERATURE SENSOR

The rear exhaust temperature sensor measures the temperature of exhaust gas passing through the DPF. If this temperature in the DPF regenerating section is low (below approx. 600°C), the engine ECU decreases the amount of intake air and increases the post-injection duration based on this information to increase the temperature of exhaust gas.


In other words, this sensor determines whether the CCRT is at a proper temperature for regeneration and sets the post-injection amount accordingly.


- Input data
 - Min. operating temperature of probe tip: 1000°C
 - Supplied power: 5 ± 0.1 VDC
- Output data
 - Type: passive
 - Max. current: 2.5 mA

► RESISTANCE BY MEASURED TEMPERATURE

Temp (°C)	RT(Ω) RW = 1.0 Ω	VO (V)
-40	170.20	0.727
0	201.27	0.838
25	220.07	0.902
50	239.30	0.965
100	276.78	1.084
150	313.62	1.194
200	349.90	1.296
250	385.59	1.391
300	420.75	1.481
400	488.72	1.641
500	554.88	1.784
600	618.07	1.910
700	678.91	2.022
800	739.02	2.125
850	767.46	2.171

► CONNECTOR



CAMSHAFT WHEEL SENSOR

The camshaft wheel sensor is installed to the side of the gear case in the front section of the engine.


This sensor is aligned with the operating trajectory of the camshaft wheel to detect the rotating condition of the camshaft. It supplies information about cylinder stroke or position to the ECU to control the fuel injection timing.


The camshaft rotates at a half speed of the crankshaft. When the piston moves toward TDC while controlling the intake and exhaust valves of the engine, this sensor detects the position of the camshaft to check whether a particular cylinder is at the compression stroke or exhaust stroke.

Especially, when the engine is initially started, it is hard to identify the stroke condition of a particular cylinder only with information from the crankshaft wheel sensor. Therefore, information from the camshaft wheel sensor is necessary to identify the accurate stroke condition of cylinders after the engine is initially started.

On the other hand, after the engine is started, information from the crankshaft wheel sensor is fed to the ECU which then learns conditions of every cylinder in the engine. Therefore, afterwards the engine can keep running even when the camshaft wheel sensor is malfunctioning.

- Operating temperature range: $-40^{\circ}\text{C} \sim 150^{\circ}\text{C}$
- Possible speed range: 15 ~ 4,000 rpm
- Supplied power (V_s): 6 ~ 24 VDC
- Supplied current: Max. 10 mA
- Output (V_{out}): Max. 24 VDC
Max. 20 mA

► CONNECTOR

DPF DIFFERENTIAL PRESSURE SENSOR

The DPF differential pressure sensor is installed on the top of the CCRT (Catalyzed Continuously Regenerating Trap).


The CCRT is mainly composed of the DOC (Diesel Oxidation Catalyst) and DPF (Diesel Particulate Filter). When exhaust gas passes through this trap, hydrocarbon soot called PM (Particulate Material) is accumulated in the DPF.

If excessive PM is accumulated, air passage is blocked, resulting in high pressure difference between the front and back of the DPF. The differential pressure sensor detects this pressure difference and sends this information to the ECU.


If a certain amount of PMs is detected in the CCRT, the post-injection is performed to increase the temperature of the DOC to 450 to 500°C in order to regenerate (oxidize) PMs.

The post-injection process is activated only when the amount of PMs is over the specification. In a normal condition, the PM amount is monitored.

- Supplied power: 4.75 ~ 5.25 VDC
- Supplied current: Max. 10 mA
- Operating temperature range: -40°C ~ 145°C
- Operating pressure range (difference between ports): -10 ~ 150 kPa
- Pressure range in normal mode (each port): 50 ~ 250 kPa



► CONNECTOR

E17WC07B

► DIFFERENTIAL PRESSURE SENSOR CHARACTERISTICS

E17WC08A


The differential pressure sensor detects the pressure difference between the inlet and outlet of the CCRT and sends a signal value of 0.5 to 4.5 V to the ECU. The larger the pressure difference between the inlet port and outlet port is, the closer the signal value gets to 4.5 V. The smaller the pressure difference is, the closer the signal value gets to 0.5 V.

AIR CONTROL VALVE SENSOR

The air control valve sensor is installed to the air control valve between the turbocharger intake hose and intake manifold flange.

The air control valve adjusts the amount of air entering the intake manifold. The operating angle of the blade at its inlet is changed according to the depressed amount of the accelerator pedal to control the intake air amount into the engine.


Therefore, this sensor detects the opening angle of the blade and sends this information to the ECU which then adjust the fuel injection amount accordingly.

RELAY (70A)

- | | |
|-------------------|-------------------|
| (1) Power relay 5 | (4) Power relay 4 |
| (2) Power relay 1 | (5) Power relay 3 |
| (3) Power relay 2 | |

Relays (70A) are installed side by side on the panel at the left side of the engine compartment and supply power to individual elements.

Power relay 1	Glow plug
Power relay 2	Reverse buzzer, Air suspension seat, Beacon lamp
Power relay 3	Wiper motor
Power relay 4	14-pin, Power socket, Motor fan
Power relay 5	Air conditioner

TEST

To perform the relay test, disconnect the relay from the wiring.


Check the resistance and continuity within the resistance range (Ω) of a tester.

Numbers on the auxiliary relay terminals indicate corresponding coil and contact.

- Capacity: 12 V 70 A

Item	Measuring point with tester		Result
	Red Lead	Black Lead	
Resistance (Ω)	Relay No. 85	Relay No. 86	86 Ω
	Relay No. 30	Relay No. 87	No continuity


※ When measuring resistance, red and black tester leads can be interchangeable.

TWIN RELAY

(1) 14-pin C-D relay
(2) 14-pin E-F relay

(3) 14-pin G-H relay

Twin relays are installed on the upper panel at the left side of the engine compartment and supply power to the corresponding 14-pin connectors.




► CONNECTOR

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	RELAY1 N.O.	6	RELAY1 COIL-
2	RELAY1 N.C.	7	RELAY1 COM.
3	RELAY2 N.C.	8	RELAY2 COM.
4	RELAY2 N.O.	9	RELAY2 COIL-
5	RELAY1 COIL+	10	RELAY2 COIL+

LF1W530A

5P / 4P RELAY


► CIRCUIT



- (1) Fuel heater relay (5P)
- (2) ECU relay (5P)
- (3) Start relay (4P)
- (4) Electric fan relay (4P)
- (5) Horn relay (4P)
- (6) Reverse buzzer relay (4P)
- (7) Stop relay(4P)
- (8) Pilot lock driving relay (4P)
- (9) Pilot lock bucket relay (4P)
- (10) Quick attachment lock relay (Option)(4P)
- (11) Quick attachment release relay (Option)(4P)

These relays are installed at the right side of engine compartment to supply power to the fuel heater, ECU and start motor.


5P RELAY



The 5P relay consists of 3 terminals, and terminal No. 30 and 87a, and the terminal No. 30 and 87 are decoupled in a normal condition (relay "OFF"). When supplying power (DC 12 V) to the terminal No 86 and 85, the terminal 30 and 87a will be decoupled, and the terminal 30 and 87 will be coupled, resulting in continuity.

Load Terminal	Resistance	Lamp	Inductance
N.O. type (Terminal No. 30 and 87)	40 A	30 A	30 A
N.C. type (Terminal No. 30 and 87a)	30 A	20 A	20 A

► TEST




To perform the relay test, disconnect the relay from the wiring.

Check the resistance and continuity within the resistance range (Ω) of a tester.

Numbers on the auxiliary relay terminals indicate corresponding coil and contact.

Item	Measuring point with tester		Result
	Red Lead	Black Lead	
Resistance	Relay No. 85	Relay No. 86	84 Ω
	Relay No. 30	Relay No. 87a	Continuity
	Relay No. 30	Relay No. 87	No continuity


4P RELAY




FAN CLUTCH CONTROLLER

The fan clutch controller is installed at the lower left side of the engine compartment.


This controller is connected to the engine wiring and fan clutch wiring, to control the fan clutch according to the input signals reflecting temperature changes.

**► CONNECTOR**

CONTROLLER SIDE





MATING



No	Signal	NOTE
1	BATT+	12-24V DC IN
2	FAN_PWR	DC FAN OUT
3	A/C	A/C COMPRESSOR SIGNAL IN
4	FAN_GND	FAN GND
5	DIAG_RX	DIAGNOSE PC CONNECTION RX
6	CAN_HI	CAN_HI
7	GND	GND
8	FAN_GND	FAN_GND
9	FAN SENSOR +5V	FAN SENSOR +5V OUT
10	FAN SENSOR IN	FAN SENSOR IN
11	DIAG_TX	DIAGNOSE PC CONNECTION TX
12	CAN_LOW	CAN_LOW


LF1W536A

► CIRCUIT

FUEL SENDER



The fuel sender is installed on the top of the fuel tank from the right side of the engine room.

The sensor float goes up or down along with the fuel in the fuel tank as the resistance at the ground circuit of the fuel gauge changes.

► CONNECTOR**► RESISTANCE BY FLOATER POSITION****Resistance by floater position (H)**

H (mm)	Resistance value (Ω)
<69	3.3±1.05
80	6.6 ±1.0
124	9.9 ±1.15
168	15 ±1.23
189	20.1 ±1.31
210	25.2 ±1.38
231	29.9 ±1.45
252	35 ±1.53
273	40.1 ±1.61
294	44.8 ±1.68
315	49.9 ±1.75
336	55 ±1.83
357	60.1 ±1.91
378	64.8 ±7.98
399	69.9 ±2.05
420	75 ±2.13
441	80.1 ±2.21
462	84.8 ±2.28
483	89.9 ±2.35
504	95 ±2.43
525	100.1 ±2.51
543	110.1 ±2.66

DRIVING PRESSURE SENSER



(1) Forward (RH)
(2) Forward (LH)


(3) Reverse

The forward LH/RH driving pressure sensor is installed on the hydraulic hose that is connected to the forward driving side of the RCV (LH) on the right side of the HST pump, while the reverse driving pressure sensor is installed on the block in the pilot rock valve, connected to the reverse driving side of the RCV (LH) with the hydraulic hose. These sensors detect the pressure of the discharged flow according to the operation displacement of the RCV (LH) operating lever.

(Switch point : 5 bar)


► CONNECTOR

SENSE




LF1W543A

WIRING




Driving pressure sensor forward (LH)




Driving pressure sensor reverse

LF1W544A

SAFETY COVER SWITCH (SAFETY SENSOR)


The safety cover switch is installed at the upper left side at the engine compartment entrance. This can be accessed by opening the rear cover.

This switch automatically stops the engine when the rear cover and then the cooler unit are opened.

► CONNECTOR**REVERSE BUZZER**


The reverse driving buzzer is installed on the edge inside of the rear cover and it automatically sounds the alarm when the equipment is moving backwards.

- Warning volume : $107 \pm 5 \text{ dB(A)}$

► CONNECTOR


4.2 CABIN & CHASSIS

4.2.1 IGNITION SWITCH



The ignition switch is installed on the right side panel of the driver's seat.

IGNITION SWITCH OPERATION



1. The "Preheat (3 steps)" position is on the left from the "OFF" position while the other positions are on the right from it.
2. When the key switch is released and returned from the "PREHEAT (3rd)" position to the "OFF" position or from the "START (ST)" position to the "ON" position, it is automatically returned to the corresponding position by the load of its spring.

IGNITION SWITCH TEST

Disconnect the ignition switch from the wiring connector.

Use an ohmmeter (Ω) to test the switch.

- With the ignition switch in the "3rd" position, there will be continuity between the (BR), (ACC) and (RI) terminals.
 - With the ignition switch in the "OFF" position, the continuity will not exist between any of the terminals.
 - With the ignition switch in the "1st" position, there will be continuity between the (B), (BR) and (ACC) terminals.
 - With the ignition switch in the "2nd" position, there will be continuity between the (B), (BR), (ACC) and (C) terminals.
- ※ If the test results are not as outlined above, replace the ignition switch.

CONNECTOR & CIRCUIT

1 B Battery
2 R1 Glow
3 ACC Light, radio etc
4 BR Battery relay
5 C Start relay

LF1W551A

Key	Terminal (Symbol)				
	Battery (B)	Battery relay (BR)	Light, radio etc (ACC)	Glow plug (R1)	Start relay (C)
3 Step	○	○	○	○	○
OFF	○				
1 Step	○	○	○		
2 Step	○	○			○

4.2.2 ESCORT UNIT




The escort unit (1) is installed under the top cover behind the driver's seat.


The escort unit keeps the headlamps (work lamp) ON for approx. 30 seconds and then turns them off if the engine is stopped with them ON.

- Rated voltage : DC 12V
- Operating voltage : DC 10 ~ 16V

CONNECTOR & CIRCUIT



4.2.3 FLASHER




LF1W554A

The flasher unit (1) is installed under the top cover behind the driver's seat; this flickers the lamps when the hazard warning flasher switch or turn signal lamp switch is operated.


As the flasher unit is directly connected to the battery, it can operate without the key in the ignition switch. It is designed to flash the lamp faster to inform a driver if a bulb of any turn signal lamp is blown.

CONNECTOR & CIRCUIT




LF1W555A

4.2.4 SWITCH PANEL




LF1W5A87A



LF1W5A88A

No	Switch	Function
1	Reset (Green)	Driving system release
2	Main light	Front, Rear work lamp ON, OFF
3	Turn signal lamp	Turn signal lamp operation
4	Parking (Red)	Parking brake emgagement
5	Wiper/Washer	Wiper, washerr operation
6	AUX	External implement flow rate / power supply
7	High flow (Option)	Supplying additional flow to equipment when needed
8	Hydraulic lock	Blocking operating hydraulic line
9	Self leveling (Option)	Maintaining balance when lifting or lowering the bucket
10	Hazard lamp	Emergency lamp operation
11	Quick attachment	Loader removal, installation
12	Beacon lamp	Beacon lamp operation
13	Room lamp	Room lamp ON, OFF
14	DPF regeneration	DPF regeneration and stop

SWITCH CIRCUIT DIAGRAM



LF1W558A


RESET SWITCH




PARKING BRAKE SWITCH



DPF SWITCH



AUX. HYDRAULIC SWITCH




POS 1 — POS 2 — POS 3 —
LF1W5A99A


POS 1 — POS 2 — POS 3 —
LF1W5A90A

POS 1 — POS 2 — POS 3 —
LF1W5A60A


POS 1 — POS 2 — POS 3 —
LF1W5A64A



LF1W5A99A




LF1W5A64A



LF1W5A65A

4.2.5 ENGINE ACCELERATOR DIAL






The engine accelerator dial is installed on the panel on the right side of the driver's seat. It detects the amount of movement of the accelerator dial and sends this information to the ECU which then adjusts the fuel injection amount and timing accordingly.

Two sensors are integrated into one unit. The sensor 1 detects the main displacement of the lever while the sensor 2 detects any faulty condition. If the difference between the main displacement signal and auxiliary displacement signal is over the specified level, the ECU sends a fault signal.

**REMARKS**

- If the difference between the signal 1 and signal 2 is over 15 %, it is determined as a fault and this error is displayed on the instrument cluster.**

CONNECTOR

CIRCUIT

LF1W569B

4.2.6 ACCELERATOR PEDAL SENSOR


The accelerator pedal sensor is installed on the accelerator pedal. This sensor detects the depressed amount of the accelerator pedal and sends this information to the ECU when then controls the engine accordingly. This sensor is a double potentiometer type with two sensors integrated into one unit for a complementary measure. The 1st sensor detects the depressed amount of the pedal for determination of the fuel injection amount and timing while the 2nd sensor compares its value with the value from the 1st sensor for accurate operation.

If the 1st or 2nd sensor is defective, the ECU stores the corresponding DTC and responsiveness to acceleration demand is deteriorated, resulting in difficult engine RPM rise.

REMARKS

- If the difference between the signal 1 and signal 2 is over 15 %, it is determined as a fault and this error is displayed on the instrument cluster.



CONNECTOR



PIN LOCATION	DESCRIPTION	COLOR
A	Power Input, Vcc1	Red
B	Pedal Signal Output, Vs1	Green
C	Ground 1 (Signal 1)	Black
D	Power Input, Vcc2	White
E	Pedal Signal Output, Vs2	Orange
F	Ground 2 (Signal 2)	Violet

LF1W571A

CIRCUIT




LF1W572B


4.2.7 RELAY BOX



CONNECTOR & CIRCUIT



The relay box is installed on the left lower side of the driver's seat.




- (1) Self level relay (Option)
- (2) Parking relay
- (3) Work lamp relay (Rear)
- (4) Work lamp relay (Front)
- (5) Beacon lamp relay (Option)
- (6) Power relay 3
- (7) Soft shift relay (Option)
- (8) Ride control relay (Option)
- (9) High flow relay (Option)

4.2.8 INSTRUMENT PANEL




The instrument panel is installed on the right front side of the driver's seat.

CONNECTOR & CIRCUIT



NO	FUNCTION	LEAD COLOR
1	Power IG 12V	R
2	Battery B+	R/W
3	-	-
4	Turn Signal RH	R/B
5	Turn Signal LH	Gr
6	GND	B
7	CAN_L	W/L
8	CAN_H	Y
9	-	-
10	Buzzer	W/R
11	Self Leveling Lamp	G
12	Quick Attach Unlock Lamp	Y/R
13	Quick Attach lock Lamp	Br/W
14	GND	B
15	Camera Power	R/Y
16	-	-
17	-	-
18	-	-
19	-	-
20	Alternator	R/G



ELECTRIC SYSTEM - ELECTRIC COMPONENTS

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN











INDEX

CONFIGURATION AND SYMBOL

SYMBOL	FUNCTION
	Water-In-Fuel warning lamp
	Check engine warning lamp 1
	Check engine warning lamp 2
	Emissions system warning lamp
	Glow lamp
	DPF regeneration lamp
	DPF under way lamp(재생진행)
	Oil pressure lamp
	Engine shut down
	Caution lamp
	Safety lamp

SYMBOL	FUNCTION
	Parking lamp
	Safety cover lamp
	Right turn signal lamp
	Left turn signal lamp
	Battery charge warning lamp
	Engine coolant gauge
	Engine coolant lamp
	Tachometer
	Hoermeter
	Fuel level gauge
	Fuel level lamp

ELECTRIC SYSTEM - ELECTRIC COMPONENTS

SYMBOL	FUNCTION	SYMBOL	FUNCTION
	Fluid high temp. warning lamp		Aux. hydraulic port M lamp
	Ride control lamp		Aux. hydraulic port F lamp
	Aux. lamp		2 speed lamp
	Aux. hydraulic lamp		Self leveling lamp
	Aux. electric port lamp		High flow lamp
	14-pin C lamp		Hydraulic lock system lamp
	14-pin D lamp		Quick attachment un-lock lamp
	14-pin G lamp		Quick attachment lock lamp
	14-pin H lamp		Consumables replacement
	14-pin E lamp		Communication warning light
	14-pin F lamp		

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

MAIN & SUB MENU



LF1W5A71A

- (1) Menu switch
 (2) Left menu button
 (3) Right menu button / Camera button

- (4) Enter button
 (5) ESC / Buzzer stop button

No	Item	Function	Remarks
1	MENU	When pressing this button on the home screen, the sub menu is displayed. When pressing this button on the sub-menu screen, the corresponding item is selected and its input value can be adjusted.	While controlling the function within each sub menu, pressing this button lets you move to the next sub menu.
2, 3	◀ ▶/CAMERA	The button to select functions and adjust (increase or decrease) input values within the sub-menu	When the camera button is selected, the rear camera image is on regardless of the driving direction.
4	↓	The button to enter the desired function and set input values within the sub menu	-
5	ESC/ BUZZER OFF	The button to move back to the previous menu screen or to cancel the current function	Press and hold the button to move to the home screen immediately. Press the button while the buzzer sounds to turn the buzzer off.

► STRUCTURE

Main menu	Sub menu	Description
Diagnosis function	Machine condition	Displaying coolant temperature, hour meter, RPM, etc.
	Machine information	Displaying instrument panel & MCU version, model name, etc.
	Current fault	Displaying current fault status list of the engine and machine
Maintenance function	Engine start inhibition setting	Engine start inhibition setting, password change or password display
	Consumables management	Changing oil/filters replacement intervals and checking elapsed time
	A/S contact	Displaying and changing A/S telephone number
	Administrator menu	Displaying fault history and mode change
Configuration	Brightness settings	Brightness manual/automatic (day, night) settings
	Time settings	Current time settings
	Unit settings	Temperature (°F/°C)
	Language settings	Korean, English
	Camera settings	Reverse gear-linked function ON/OFF





※ Press the menu button to activate the sub-menu.

► DIAGNOSIS FUNCTION

① MACHINE STATUS







② MACHINE INFORMATION



- The status of the machine is displayed.

- You can check the version of the instrument panel and MCU as well as the machine's model name.

③ CURRENT FAULT



- You can check the current fault of the engine.

- You can check the current fault of the machine.



REMARKS

- In case of related codes, contact a dealer nearby to get it checked.



REMARKS

- In case of related codes, contact a dealer nearby to get it checked.

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM





ELECTRIC SYSTEM

CABIN






INDEX

► MAINTENANCE FUNCTION

① ENGINE START INHIBITION SETTING







- Engine start inhibition setting




- Password change

② CONSUMABLES MANAGEMENT




- Password display





- Elapsed time
- Replacement interval
- Replacement frequency
- Replacement


③ A/S CONTACT



④ HYDRAULIC CONTROL




- You can check and change the A/S contact details.



- Hydraulic control: The amount of hydraulic flow delivered to the external hydraulic implement can be controlled.
- AUX HOLD M : The amount of flow sent to the male coupler can be set by percentage, using the \blacktriangleleft , \triangleright buttons in the instrument panel.
- AUX HOLD F: The amount of flow sent to the female coupler can be set by percentage, using the \blacktriangleleft , \triangleright buttons in the instrument panel.


► CONFIGURATIONS

① BRIGHTNESS SETTINGS




LF1O4H4U


② TIME SETTINGS




LF1O4H7U



LF1O4H5U







LF1O4L9U



LF1O4H6U

- Manual
- Automatic
- Daytime duration setting

- The time can be set. (Year, Month, Day, Hour, Minute)

③ LANGUAGE SETTINGS**④ CAMERA SETTINGS**

- The desired language can be selected. Once a language is selected, all information is displayed in that language.
- You can set the camera function on or off (optional).
- You can turn the reverse gear linked function on or off.
- Reverse gear linked function: When the vehicle is in reverse, the camera mode is automatically displayed on the main screen.

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

MACHINE DIAGNOSIS (DTC)**1) CHECKING THE MONITOR**

LF1O4C3B



LF1O4C5U

- Check if the or warning lamp is illuminated on the monitor.

- Press the Enter button () to select the 'Diagnosis' function.




LF1O4C4U

- Press the MENU button.



LF1O4C6U

- Press the Enter button () to select the "Current fault".



LF1O4C7U

5. Press the Enter button () to select the "Machine fault".



LF1O4C9U

7. Verify and check the diagnosis details.






LF1O4C8U

6. Check the DTC code and press the Enter button ().

2) DTC CODE


NO	DTC		Diagnosis	Part that might have failed	Relative wiring No.		Warning lamp
	DDSPN	FMI					
1	101	3	Oil temperature sensor and wiring voltage higher than normal range or having short circuit > 4.9 V maintained	Oil temp. sensor, Oil temp. sensor wiring	972	Z992	
		4	Oil temperature sensor and wiring voltage below normal range or having short circuit < 0.1V maintained				
	-	-	Warning lamp ON when oil temperature exceeds 90°C				
2	301	3	Fuel level sensor circuit - Voltage above normal or shorted to high source (or open circuit)	Fuel sender wiring	987	-	
		4	Fuel level sensor circuit - Voltage below normal or shorted to low source				
3	705	0	Battery voltage high	Battery wiring	B31A	B10	
		1	Battery voltage low				
4	707	1	Alternator voltage low (or open circuit)	Fuse (R-terminal power)	B13A		
				ALTERNATOR			
				WIRING HARNESS			
5	841	2	ECU communication error	ECU	247A	248A	
				MCU			
				CLUSTER			
				WIRING HARNESS			

2-1) DIAGNOSIS BY DTC CODES**2-1-1) DDSPN - 101 / FMI - 3, 4****FIGURE OF RELATED PART****► MCU WIRING CONNECTOR****► MIN WIRING + CABIN WIRING CONNECTOR****DIAGNOSIS PROCEDURES****► CHECKING VOLTAGE OF THE OIL TEMPERATURE SENSOR**

- Start key ON → Measure the voltage of the oil temperature sensor (if the measurement is over 4.9V) → Replace the oil temperature sensor
- Start key ON → Measure the voltage of the oil temperature sensor (if the measurement is below 0.1V) → Replace the oil temperature sensor


INFORMATION OF RELATED WIRING HARNESS

► MAIN WIRING (CABIN WIRING) CONNECTOR




LF1W5A94A

► CABIN WIRING (MAIN WIRING) CONNECTOR




LF1W5A95A

► OIL TEMPERATURE SENSOR CONNECTOR



LF1W5A97A

► MCU WIRING CONNECTOR




LF1W5A96A


2-1-2) DDSPN - 301 / FMI - 3, 4

FIGURE OF RELATED PART


► FUEL SENDER CONNECTOR



► MCU WIRING CONNECTOR



► MAIN WIRING + CABIN WIRING CONNECTOR



DIAGNOSIS PROCEDURES

► STEP 1 : CHECKING RESISTANCE OF THE FUEL SENDER

- Start key OFF → Disconnect the fuel sender connector → Measure the resistance ($3\Omega \sim 110\Omega$) → Replace the fuel sender if the measurement is excessive.

► STEP 2 : CHECKING THE WIRING IF THE RESISTANCE IS NORMAL (PIN-TO-PIN INSPECTION)

- Start key OFF → Check for continuity between the oil sender connector (Pin #987) and main (cabin) wiring connector (Pin #987)
- Start key OFF → Check for continuity between the cabin (main) wiring connector (Pin #987) and MCU wiring connector (Pin #987) → In case of no continuity, replace the wiring

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN

INDEX


INFORMATION OF RELATED WIRING HARNESS

► MAIN WIRING (CABIN WIRING) CONNECTOR




LF1W5A98A

► CABIN WIRING (MAIN WIRING) CONNECTOR




LF1W5A99A

► FUEL SENDER CONNECTOR



LF1W5B01A

► MCU WIRING CONNECTOR




LF1W5B02A

2-1-3) DDSPN - 705 / FMI - 0, 1

FIGURE OF RELATED PART

► BATTERY



► SLOW BLOW FUSE



DIAGNOSIS PROCEDURES

► STEP 1


- Start key OFF → Disconnect the (-) and (+) battery terminals and measure the voltage (acceptable operation voltage for engine start: 12.3 ~ 12.9V) → Replace the battery if abnormal voltage is measured

► STEP 2


- If the voltage is acceptable, check the slow-blow fuse (power: 100A) and cabin fuse (10A) → If abnormal, replace them with those with the same capacity

INFORMATION OF RELATED WIRING HARNESS

► SLOW BLOW FUSE (POWER : 100A)



► CABIN FUSE (10A)



2-1-4) DDSPN - 707 / FMI - 1

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

FIGURE OF RELATED PART




FIGURE OF RELATED PART

► STEP 1

- Start key OFF → Check the tightening state of the B+ connection (A) of the alternator and battery

► STEP 2

- Check for continuity between the body of alternator and vehicle body

► STEP 3

- Check the tension of the fan belt (press the point between the fan drive pulley and alternator with force of 98N and see whether the belt is deflected for 7 ~ 9 mm)

► STEP 4

- Check the cabin fuse (10A)

► STEP 5

- If normal, replace the alternator with a new one

► FAN BELT








FIGURE OF RELATED PART



2-1-5) DDSPN - 841 / FMI - 2

FIGURE OF RELATED PART**► ECU WIRING CONNECTOR****► MCU WIRING CONNECTOR****► MAIN WIRING + CABIN WIRING CONNECTOR****DIAGNOSIS PROCEDURES****► STEP 1 : CHECKING THE WIRING (PIN TO PIN)**

- Start key OFF → Check for continuity between the ECU wiring connector (Pin #247A) and main wiring connector (Pin #247A)
- Start key OFF → Check for continuity between the ECU wiring connector (Pin #248A) and main wiring connector (Pin #248A)
- Start key OFF → Check for continuity between the cabin wiring connector (Pin #247A) and MCU wiring connector (Pin #247A)
- Start key OFF → Check for continuity between the cabin wiring connector (Pin #248A) and MCU wiring connector (Pin #248A)

► STEP 2 : CHECKING THE ENGINE DTC CODES

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN


INDEX

INFORMATION OF RELATED WIRING HARNESS


► ECU WIRING CONNECTOR




► MAIN WIRING (CABIN WIRING) CONNECTOR



► CABIN WIRING (MAIN WIRING) CONNECTOR





► MCU WIRING CONNECTOR



UPDATE



1. Unscrew the cover mounting screws (1) at the lower back of the dashboard to remove the cover (2).



2. Insert a micro 5-pin USB cable to the USB port at the lower back of the dashboard, and then connect the cable to the PC.

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX



LF1W586A




LF1W5B07A




LF1W588A

- With the power off Press the two arrow buttons (\blacktriangleleft , \triangleright) simultaneously. Then, supply the power (Key ON) and access the USB drive.



LE1W589A

4. Copy and paste the bin file to be downloaded into the “bin” folder of the USB drive. (Delete the old file.)
At this time, the file name must be Application.bin.



5. With the power OFF, press the and buttons simultaneously for approx. 2 seconds and turn the power ON.

6. Once the update is started and completed, the system automatically restarts.

REMARKS


COPYING AND PASTING THE IMAGE CONTENTS & FONT

▶ FONT


1. Copy and paste the .bin file into the “font” folder of the USB drive. (Delete the old CLKORTABLE_XXXXX.BIN file.)
2. Restart the power.

▶ CONTENTS

1. Copy and paste the .dat file into the “contents” folder of the USB drive. (Delete the old contents_xxxxx.dat file.)
2. Restart the power.



4.2.9 MCU (MICRO CONTROLLER UNIT)



The MCU (1) is located under the top cover behind the driver's seat.

The MCU controls the operation of equipment components by receiving signals from various sensors, such as battery power, various switches and hydraulic system.


- Rated voltage: 12 VDC
- Operating voltage: 8 ~ 16 VDC
- Operating temperature: -40°C ~ 150°C

LED SPECIFICATIONS

GREEN	AMBER	RED	Description
ON	OFF	OFF	Normal Operation
OFF	OFF	ON	CPU Error
ON	ON	OFF	Communication Error
OFF	OFF	OFF	Power Off

LF1W594A

CONNECTOR & CIRCUIT



► INPUT/OUTPUT SPECIFICATIONS

Function	INPUT (Connector CN1)				REMARK
	NO.	Terminal name	Condition	Logic	
Power	26	Battery B+	12V	8 ~ 16V	
	27	Battery B+	12V	8 ~ 16V	
Key Switch	18	Power IG 12V	OFF-> ON (12V)	8 ~ 16V	LED lamp "ON" (Green)
AUX	21	Aux Switch	OFF -> ON (12V)	Icon "ON" in the LCD	
	29	Aux Electrical Mode Switch	OFF -> ON (12V)	Icon "ON" in the LCD	
	19	Aux 14C Switch	OFF -> ON (12V)	Icon "ON" in the LCD CN2-8 +12V output	
	1	Aux 14D Switch	OFF -> ON (12V)	Icon "ON" in the LCD CN2-15 +12V output	
	20	Aux 14E Switch	OFF-> ON (12V)	Icon "ON" in the LCD CN2-6 +12V output	
	5	Aux 14F Switch	OFF -> ON (12V)	Icon "ON" in the LCD CN2-13 +12V output	
	11	Aux 14G Switch	OFF -> ON (12V)	Icon "ON" in the LCD CN2-24+12V output	
	3	Aux 14H Switch	OFF -> ON (12V)	Icon "ON" in the LCD CN2-9 +12V output	
	13	Aux hold M switch	OFF-> ON (12V)	Icon "ON" in the LCD CN2-25 +12V output	
	28	Aux hold F switch	OFF -> ON (12V)	Icon "ON" in the LCD CN2-34 +12V output	
Travel	16	Travel Pressure Sensor (Forward Lh)	OFF -> ON (12V)		When "N" position, Back Buzzer : OFF Stop LAMP : ON
	17	Travel Pressure Sensor (Forward Rh)	OFF -> ON (12V)		
	25	Travel Pressure Sensor (Reverse)	OFF-> ON (12V)	CN2-14 +12V output	When "R" position, Back Buzzer : ON Stop LAMP : OFF

ELECTRIC SYSTEM - ELECTRIC COMPONENTS

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

Digital	2	Hyd Lock Switch	OFF -> ON (12V)		
	10	Ride Control	OFF-> ON (12V)	Icon "ON" in the LCD CN2-11 +12V output	
	4	Parking Switch	OFF-> ON (12V)	Icon "ON" in the LCD CN2-10 +12V output	
	24	Reset Switch	OFF -> ON (12V)	CN2-5, 12, 17 +12V output	
	30	Safety Cover switch	OFF -> ON (12V)	LAMP "ON" CN2-2 +12V output	
	31	2 Speed Switch	OFF-> ON (12V)	Icon "ON" in the LCD CN2-7 +12V output	
	32	Hlgh Flow switch	OFF -> ON (12V)	Icon "ON" in the LCD CN2-19 +12V output	
	15	Seat switch	OPEN -> LOW(0V)	LAMP "ON"	
	14	Safety Sensor LH	OFF -> ON (12V)	LAMP "ON"	
	33	Safety Sensor RH	OFF -> ON (12V)	LAMP "ON"	
	34	Start Switch	OFF -> ON (12V)	LAMP "ON" CN2-18 +12V output	
Analog	7	Hyd Temp Sensor	48KΩ ~ 160Ω	Temperature display on the LCD	
		Hyd Temp Sensor High	322Ω or less	Icon "ON" in the LCD	
	8	Fuel Sender	3Ω - 110.3Ω	Fuel level display on the LCD	
		Fuel Sender Empty	110Ω or less	Icon "ON" in the LCD	
	9	Aux Port Variation	0.5 - 4.5V Center : 2.5V	Icon "ON" in the LCD	

► RESISTANCE VALUE OF THE HYD TEMP. SENSOR (Only reference value)

Temp (°C)	-40	0	25	50	100	150	200
RESISTANCE (Ω)	170.20	201.27	220.07	5.790	276.78	313.62	349.90

ELECTRIC SYSTEM - ELECTRIC COMPONENTS

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

MCU DIAGRAM



LF1W596B

MCU SAFETY SENSOR LOGIC

INPUT			OUTPUT
Safety Sensor LH (A14)	Safety Sensor RH (A33)	SEAT SWITCH (A15)	
ON (Safety bar "DOWN", 12V)	ON (Safety bar "DOWN", 12V)	ON (When sit down, 1 sec or more, GND)	Standby "Reset" signal (A14 ON and A33 ON and A15 ON)
		OFF (When stand up, 3 sec or more, OPEN)	Parking valve output ON, Hydraulic lock valve output ON
	OFF (Safety bar "UP", GND)	ON (When sit down, 1 sec or more, GND)	Parking valve output ON, Hydraulic lock valve output ON
		OFF (When stand up, 3 sec or more, OPEN)	Parking valve output ON, Hydraulic lock valve output ON
OFF (Safety bar "UP", GND)	ON (Safety bar "DOWN", 12V)	ON (When sit down, 1 sec or more, GND)	Parking valve output ON, Hydraulic lock valve output ON
		OFF (When stand up, 3 sec or more, OPEN)	Parking valve output ON, Hydraulic lock valve output ON
	OFF (Safety bar "UP", GND)	ON (When sit down, 1 sec or more, GND)	Parking valve output ON, Hydraulic lock valve output ON
		OFF (When stand up, 3 sec or more, OPEN)	Parking valve output ON, Hydraulic lock valve output ON

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX

MCU FIRMWARE UPDATE

MCU UPDATE CONNECTOR



COMPOSITION OF CONNECTOR PIN



CONNECTING CABLE




LF1W596A

1) PREPARING THE USB DRIVER

1-1) INSTALLING RS232 TO USB DRIVER (TO INSTALLATION FILE)

이름	수정한 날짜	유형
amd64	2020-09-15 오후 1:39	파일 풀더
i386	2020-09-15 오후 1:39	파일 풀더
Static	2020-09-15 오후 1:39	파일 풀더
ftd2xx.h	2017-09-19 오후 4:46	H 파일
ftdibus.cat	2017-09-19 오후 4:46	보안 카탈로그
ftdibus.inf	2017-09-19 오후 4:46	설치 정보
ftdiport.cat	2017-09-19 오후 4:46	보안 카탈로그
ftdiport.inf	2017-09-19 오후 4:46	설치 정보


LF1W597A



LF1W598A

If a COM port is recognized, this step can be omitted.

1-2) INSTALLING RS232 TO USB DRIVER (DRIVER UPDATE)



If a COM port is recognized, this step can be omitted.

1-3) CONFIRMING INSTALLATION OF RS232 TO USB DRIVER (DEVICE MANAGER)

The USB serial port should be displayed under the port (COM & LPT) in the Device Manager of the Windows system. Otherwise, firmware update cannot proceed.

If this doesn't appear on the Device Manager, re-install the USB driver.



※ Here, the COM Port is port no.11 on the Device Manager.

2) INSTALLING THE EXECUTABLE PROGRAM AND CONNECTING TO THE PC

2-1) DOWNLOADING, INSTALLING AND RUNNING TERA TERM




The program can be downloaded at <https://tera-term.softonic.kr/>.

※ Install the program. (This free software is open to anyone for use.)

2-2) CONNECTING YOUR VEHICLE TO PC




1. Unscrew the 3 bolts on the back of the seat and connect to the circular connector (HD16-9-96S).
2. Connect the RS232 connector (DB9-FEMALE) to the RS232-USB gender.
3. Connect to the PC with the USB drive.

3) SETUP

Set the COM Port as shown in the above setup screen.


- The port number can be found at the Device Manager. (Refer to “1-3) Confirming installation of RS232 to USB driver (device manager).”)
- Set the Speed to “115200 bps.”
- Set the Data to “8 bit.”
- Set the Parity to “none.”
- Set the Stop Bit to “1 bit.”
- Set the Flow Control to “none.”
- After setup, press the “New open” button to open the port.

4) CHECKING CONNECTION BETWEEN PC AND MCU POWER

1. Once the COM Port is connected and the MCU board is supplied with 12V power, the logs are output on the screen through UART as shown in the figure. This screen confirms that the MCU board and PC are successfully connected.
2. Once this screen appears, you can move on to the next step.
3. Check the log starting with “Start...” on the screen.
4. Turn the start key to the OFF position.

5) ENTERING THE FIRMWARE UPDATE MODE


- The MCU firmware can be updated only when the program enters the download mode during booting.
- Press and hold the Ctrl+C keys on Tera Term while the MCU is turned off. This sends Ctrl+C command to the USB drive.
- Once 12V power is supplied to the MCU, it enters the download mode during booting.



LF1W5A08A




ENTERING THE FIRMWARE UPDATE SCREEN




LF1W5A09A

- An update screen will appear when power is supplied to the MCU while pressing and holding Ctrl+C keys on the keyboard.

6) DELETING THE USERS PROGRAM AND MEMORY AND ENTERING THE DOWNLOAD MODE




LF1W5A10A




LF1W5A11A

- The program can be downloaded only if the old users program is deleted.
Hence, press the 'A'/'a' key to execute the "Erase All Flash" command.
- Pressing the 'A' or 'a' key will delete the users program. (Erase ALL)
The old program must be first deleted to use the new program.
Press the 'A' key to delete the users program.
- When the following string appears, deletion is completed.
To enter the download mode, press the 'D' or 'd' key.




- Once the 'd' key is pressed, "Send User Program *.Hex" is displayed on the screen. Then, drag and drop the Hex file to be downloaded onto the Tera Term.

7) SETTING THE FILE TRANSFER



1. The default setting is shown in the figure. After confirming all the settings, press the OK button.




2. Wait until all the files are transferred.

Wait until the Send file window disappears.

Do not disconnect the cable or touch the USB cable while this task is ongoing. This may cause a download failure.

If failed, the process has to be restarted from the beginning.

8) LAUNCHING THE PROGRAM



```

COM11 - Tera Term VT
메뉴(F) 수정(E) 설정(S) 제어(O) 창(W) 도움말(H)

Monitor_ctml]#d
Send User Program *.Hex

23100 Word Download Complete!!

Erase Flash Sector H
Flash Erase complete!! codestart_branch address [7d], [cdd6]

Burn User Program End!!

Start... LF100_MCU[0.0.2.0]
Compile Time: Sep 14 2020, 12:19:53
Magic Number is OK : Load EEPROM.
[HM]Loaded H:F0DEBCA1, S:0DD8

```


LF1W5A15A

- Once the file transfer is completed, the firmware update is completed and the MCU will reboot.
- If the firmware normally starts, the log will appear on the screen: Burn User Program End!! Start... LF100_MCU[0.0.2.0].

※ Check the updated features as download is successfully completed.

REMARKS


DOWNLOAD CABLE



Wiring	RS-232 connector (Female)	HD16-9-96S plug Deutsch
RS-232 GND	5	A
RS-232 Rx	3	C
RS-232 Tx	2	B

LF1W5A69A

4.2.10 TELEMETRICS CONTROLLER



The telematics controller is located under the top cover behind the driver's seat.


This controller confirms the location of the equipment with GPS, controls remote operation and manages emergency states.

- Rated voltage: 12/24 VDC
- Operating voltage: 8 ~ 32 VDC
- Operating temperature: -40°C ~ 85°C

CONNECTOR

CONNECTOR : MOLEX 51110-1251 PIN : MOLEX 87396-8051			Deutsch DT04-12P, AWG 18		
	NO.	NAME		NO.	NAME
	1	Battery		1	Battery
	2	Key_IG		2	Key_IG
	3	RS232_TX_2		3	CAN_High
	4	RS232_RX_2		4	RS232_TX_1
	5	RS232_GND		5	RS232_GND
	6	MAIN GND		6	RS232_TX_2
	7	D/O(KEY_CONTROL)		7	RS232_RX_2
	8	D/I(DOOR S/W)		8	D/O(KEY_CONTROL)
	9	RS232_TX_1		9	RS232_RX_1
	10	RS232_RX_1		10	D/I(DOOR S/W)
	11	CAN_HIGH		11	CAN_Low
	12	CAN_LOW		12	MAIN GND

SCHEMATIC DIAGRAM



LF1W5A18A

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX

4.2.11 RCV ASSEMBLY (LH) (RH)




(1) RCV assembly (LH)


(2) RCV assembly (RH)



- (1) Horn (ON/OFF push button)
- (2) Ride control (ON/OFF push button)
- (3) Aux 1 (Electric, ON/OFF push button)
- (4) 2-speed (ON/OFF push button)
- (5) Aux 3 (Electric, on/off, FNR Rocker switch)





- (1) Aux hold switch (ON/OFF push button)
- (2) Aux hold switch (ON/OFF push button)
- (3) Aux 2(Electric, ON/OFF push button)
- (4) Aux port variable switch (Proportional roller)
- (5) Aux electrical mode change switch(ON/OFF push button)




The RCV assembly (LH) operates the functions related to steering and driving while the RCV assembly (RH) operates the boom and bucket.

4.2.12 SAFETY SENSOR (SAFETY BAR)



CONNECTOR



The safety sensors are mounted on both ends of the safety bar of the driver's seat. The output of the parking valve and hydraulic lock valve is turned ON or OFF according to the raising or lowering state of the safety bar.

When the safety bar is raised, the parking brake is applied and the hydraulic line is locked to prevent unexpected accidents from operation of the machine.

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX

4.2.13 SEAT SWITCH




The seat switch is mounted inside of the seat bottom. When the driver is seated or not seated on the seat, the switch plunger is actuated to start the engine or to stop the engine. In addition, the engine stops automatically when the driver is not seated on the seat and it exceeds 3 seconds during driving.

ENGINE OFF




ENGINE ON




TEST

Connect the tester (ohmmeter) to the two terminals of the seat switch and check the continuity by pressing the plunger. If the plunger does not conduct when it is pressed, or conduction occurs when it does not press the plunger, there is a problem with the seat switch. Replace the seat switch with a new one.

4.2.14 OIL TEMPERATURE SENSOR

The oil temperature sensor is located on the front of the oil tank on the right side from the driver's seat. It detects oil temperature in the oil tank and sends a signal to the MCU. Normally, a warning lamp on the dashboard will be illuminated if the temperature exceeds 90°C.

- Operating temperature: -40°C ~ 150°C

4.2.15 HORN

The horn is installed on the front upper frame in the cabin.

- Horn volume : 105 ~ 118 dB(A)

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

RESISTANCE BY TEMPERATURE

Temp. (°C)	Resistance value (Ω)
-40	170.20
0	201.27
25	220.07
50	239.30
100	276.78
150	313.62


4.2.16 WIPER MOTOR




The wiper motor is installed on the side of the front glass door.

- Rotation angle : $120^\circ \pm 3^\circ$

CONNECTOR



CIRCUIT




4.3 LAMPS (BULB REPLACEMENT)

4.3.1 LED WORK LAMP




1. Unscrew the lower bracket mounting nut (1) of the work lamp.
2. Disconnect the wiring connector and replace the LED work lamp assembly.

4.3.2 TURN SIGNAL LAMP



1. Unscrew lens mounting screws (1) to remove the lens.



2. Remove the turn signal lamp bulb (1) by turning it and replace it with a new bulb if necessary.
 - Bulb specification: 12V 21W

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM


CABIN

INDEX

4.3.3 BRAKE LAMP (REAR LAMP) / TURN SIGNAL LAMP






3. Remove the tail lamp bulb (2) and replace it with a new bulb if necessary.
 - Bulb specification: 12V 5W




2. Remove the brake lamp (tail lamp) bulb (1) by turning it and replace it with a new one if necessary.
 - Bulb specification: 12V P21/5W

4.3.4 ROOM LAMP



- Remove the turn signal lamp bulb (2) by pressing and turning it and replace it with a new one if necessary.
- Bulb specification: 12V P21W





- Using a flat-bladed screwdriver, pry off the edge of the interior lamp lens to remove the lens (1).







- Remove the interior lamp lens (2) and replace it with a new one if necessary.
- Bulb specification: 12V 10W





5. TROUBLESHOOTING

5.1 WHEN THE ENGINE CANNOT BE STARTED

CHECK POINT	CHECK METHOD	REMARKS
1. Check the battery voltage	<ul style="list-style-type: none"> - Measure the voltage between battery (+) and (-) terminals using a tester Result: 11.8 ~ 12.9 V. However, the voltage may be over this range if it is measured immediately after turning the engine off. 	 <p>LF1W5A47A</p>
2. Battery terminal of start motor	<ol style="list-style-type: none"> 1. Check the battery cable connection. <ul style="list-style-type: none"> - The voltage between the terminal M of start motor and chassis should be approximately same to the battery voltage. - Check for corrosion. 2. Checking when voltage is not supplied <ul style="list-style-type: none"> - Check the battery cable connection. 	 <p>T85WBD6A</p>
3. Slow-blow fuse	<ol style="list-style-type: none"> 1. Fuse engagement 2. Check the main fuse for short circuit. Rated capacity: 30 A (Start) Rated capacity: 40 A (Engine) 	 <p>LF1W5A48A</p>
4. Ignition switch	<ul style="list-style-type: none"> - Check for proper connection <ul style="list-style-type: none"> "OFF" position: No connection "ACC/ON" position: A-B-D "PREHEAT" position: A-C-D "ST" position: A-D-E 	 <p>A - Battery B - Accessory (ACC) C - Engine preheat (G) D - Ignition switch ON E - Ignition (ST)</p> <p>T85WBD8A</p>




CHECK POINT	CHECK METHOD	REMARKS
5. Starter relay	<p>1. When connecting power to terminals No. 85 and 86 : Check continuity between terminals No. 87 and 30.</p> <p>2. When do not connecting power to terminals No.85 and 86: Check continuity between terminals No.87 and 30.</p>	 <p>Terminal Diagram</p> <p>LF1W5A49A</p>
6. Main fuse box	<p>1. Check the fuse for short circuit. F12 : 5A (ECU_relay coil fuse) F11 : 25A (ECU_Power fuse) F5 : 10A (ECU_key fuse)</p> <p>2. If it has a short circuit, replace it with a new one with the rated capacity.</p>	 <p>LF1W5B28A</p>
7. Check ECU power relay	<p>1. Voltage inspection With the ignition switch ON, measure the voltage between the connector No. 87 and vehicle body. It should be 12 V.</p>	 <p>Terminal Diagram</p> <p>H89WBM5A</p>
8. Check MCU	<p>1. Voltage inspection With the ignition switch ON, measure the voltage between the connector No. 34 (CN1) and vehicle body. It should be 12 V.</p>	 <p>LF1W5A51A</p>
9. Check ECU	<ul style="list-style-type: none"> - ECU - Camshaft sensor - Crankshaft wheel sensor - IMV - Fuel rail pressure sensor - Injector 	<p>Refer to the engine troubleshooting manual. (Check for error codes.)</p>

5.2 WHEN THE SYSTEM IS NOT CHARGED





CHECK POINT	CHECK METHOD	REMARKS
1. Battery voltage	<ul style="list-style-type: none"> - Measure the voltage between the battery (+) and (-) terminals using a tester. - Result: 11.8 ~ 12.9 V. However, the voltage may be over this range if it is measured immediately after turning the engine off. 	 LF1W5A47A
2. Slow-blow fuse	<ul style="list-style-type: none"> - Check the fuse engagement status. - Check if the slow blow fuse is blown. Rated current: 100 A (Power1) 	 LF1W5A53A
3. Regulator operating power	<ul style="list-style-type: none"> - With the KEY ON, measure the voltage between the terminal No.1 (P) of the connector and alternator body (ground). Normal: 12 V - Measure the voltage between the terminal No.1 and No.2 of the connector 2P. Normal: 12 V 	 H89WBK2A
4. Ignition switch	Check proper connection with it in "ON" position: A-B-D	 T85WBD8A



NORMAL OPERATING CONDITION

- Before starting the engine (ignition switch in "ON" position): Charge warning lamp ON
- After starting the engine: Charge warning lamp OFF




Check point	Check method	Remarks
1. Charge warning lamp . (on cluster)	<p>1. Check the voltage.</p> <ul style="list-style-type: none"> - Voltage between the terminal No. 1 of the A connector (cluster) and terminal 20 of the A connector with the key "ON" <p>Voltage: It should be 12 V.</p>	 <p>LF1W5A54A</p>
2. Charge warning lamp	1. Visual check	 <p>LF1W5A55A</p>
3. Check the fuse.	1. Check the F22 fuse : 15 A for MCU/Cluster	 <p>LF1W5B29A</p>
4. Diode	<p>1. Check the diode.</p> <p>Check if current flows from the positive pole to the negative pole of the diode.</p>	 <p>T85WBF0A</p>

5.3 WHEN THE SYSTEM IS NOT PREHEATED AUTOMATICALLY





Check point	Check method	Remarks
1. Battery voltage	<p>1. Measure the voltage between the battery (+) and (-) terminals using a tester</p> <p>2. Result: 11.8 ~ 12.9 V. However, the voltage may be over this range if it is measured immediately after turning the engine off.</p>	 LF1W5A47A
2. Battery terminal of starter motor	<p>1. Check the battery cable connection.</p> <ul style="list-style-type: none"> - The voltage between the terminal M of start motor and chassis should be approximately same to the battery voltage. - Check for corrosion. <p>2. Checking when voltage is not supplied</p> <ul style="list-style-type: none"> - Check the battery cable connection. 	 T85WBD6A
3. Slow-blow fuse	<p>1. Check the fuse engagement status.</p> <p>2. Check if slow-blow fuse is blown : Rated capacity - 80 A</p>	 LF1W5A58A
4. Ignition switch	<p>1. Check the ignition switch connection.</p> <p>"ON" position: A-B-D "PREHEAT" position: A-C-D</p>	 T85WBD8A

Check point	Check method	Remarks
5. ECU	- Check for the glow plug relay driver and glow lamp LSD of the ECU	Refer to "ECU troubleshooting" manual
6. Coolant temperature sensor	1. Check the coolant temperature sensor resistance. Approx. 2.45 kΩ (at 20°C)	 T85WBF5A
7. Preheat relay	1. When connecting power to terminals No. 85 and 86(Preheating operation) - Check continuity between terminals No. 87 and 30.	 T85WB38A
8. Glow plug	1. Check resistance of the glow plug coil (0.43 Ω). - Resistance ∞ (Ω): Open coil - Resistance 0 (Ω): short circuit	 T85WBF2A
9. Check ECU	- ECU error	Refer to the engine troubleshooting manual. (Check for error codes.)

 **REMARKS**

Check point	Check method	Remarks
1. Check fuel heater relay (5P)	<p>1. Voltage inspection With the ignition switch ON, measure the voltage between the connector No. 87 and vehicle body. It should be 12 V.</p>	 <p>Terminal Diagram</p>  <p>H89WBM5A</p>
2. Check fuel heater	<p>1. Voltage inspection Measure the voltage between the terminals A and B with the ignition switch ON. It should be 12 V.</p>	 <p>H89WBM8A</p>

5.4 WHEN WORK LAMP CANNOT BE OPERATED

Check point	Check method	Remarks																																																
1. Check the battery voltage	<p>1. Measure the voltage between the battery (+) and (-) terminals using a tester.</p> <ul style="list-style-type: none"> - Result: 11.8 ~ 12.9 V However, the voltage may be over this range if it is measured immediately after turning the engine off. 	 <p>LF1W5A47A</p>																																																
2. Battery terminal of start motor	<p>1. Check the battery cable connection.</p> <ul style="list-style-type: none"> - The voltage between the terminal M of the start motor and chassis should be approximately same to the battery voltage. - Corrosion <p>2. Checking when voltage is not supplied</p> <ul style="list-style-type: none"> - Check the battery cable connection. - Continue to the next step. 	 <p>T85WBD6A</p>																																																
3. Slow-blow fuse	<p>1. Check the fuse engagement status.</p> <p>2. Check if slow-blow fuse is blown : Rated capacity - 60 A</p>	 <p>LF1W5A73A</p>																																																
4. Check the fuse	<p>1. Check the fuse engagement status.</p> <p>2. Check if the fuse is blown. Head lamp fuse 20 A (F23)</p>	 <table border="1"> <thead> <tr> <th>RMS Alternator</th> <th>14-pin (C-E/F/G/H)</th> <th>Back Buzzer</th> </tr> </thead> <tbody> <tr> <td>10A</td> <td>3</td> <td>10A</td> </tr> <tr> <td>14-pin</td> <td>Work lamp (Front/Rear) 20A</td> <td>Pilot Lock Buckle Travel 20A</td> </tr> <tr> <td>10A</td> <td></td> <td></td> </tr> <tr> <td>Electric fan 25A</td> <td>MCU/Cluster 15A</td> <td>Parking 10A</td> </tr> <tr> <td>Fuel heater 25A</td> <td>Power socket 10A</td> <td>Seat 15A</td> </tr> <tr> <td>ECU_key_power 10A</td> <td>Beacon lamp 10A</td> <td>Fan clutch 5A</td> </tr> <tr> <td>Room lamp 10A</td> <td>Air con 30A</td> <td>SPARE 5A</td> </tr> <tr> <td>Flasher unit 10A</td> <td>Brake lamp 10A</td> <td>SPARE 10A</td> </tr> <tr> <td>Joystick (LH) 10A</td> <td>Right Joystick 10A</td> <td>SPARE 10A</td> </tr> <tr> <td>Horn 10A</td> <td>Cabin 10A</td> <td>SPARE 15A</td> </tr> <tr> <td>ECU sensor 10A</td> <td>Valve power 30A</td> <td>SPARE 20A</td> </tr> <tr> <td>ECU power 25A</td> <td>Bluetooth Player 10A</td> <td>SPARE 25A</td> </tr> <tr> <td>ECU relay 5A</td> <td>Wiper/washer 15A</td> <td>SPARE 30A</td> </tr> <tr> <td colspan="2">Fuel Heater Relay</td> <td></td> </tr> <tr> <td colspan="2">ECU Relay</td> <td></td> </tr> </tbody> </table> <p>LF1W5B30A</p>	RMS Alternator	14-pin (C-E/F/G/H)	Back Buzzer	10A	3	10A	14-pin	Work lamp (Front/Rear) 20A	Pilot Lock Buckle Travel 20A	10A			Electric fan 25A	MCU/Cluster 15A	Parking 10A	Fuel heater 25A	Power socket 10A	Seat 15A	ECU_key_power 10A	Beacon lamp 10A	Fan clutch 5A	Room lamp 10A	Air con 30A	SPARE 5A	Flasher unit 10A	Brake lamp 10A	SPARE 10A	Joystick (LH) 10A	Right Joystick 10A	SPARE 10A	Horn 10A	Cabin 10A	SPARE 15A	ECU sensor 10A	Valve power 30A	SPARE 20A	ECU power 25A	Bluetooth Player 10A	SPARE 25A	ECU relay 5A	Wiper/washer 15A	SPARE 30A	Fuel Heater Relay			ECU Relay		
RMS Alternator	14-pin (C-E/F/G/H)	Back Buzzer																																																
10A	3	10A																																																
14-pin	Work lamp (Front/Rear) 20A	Pilot Lock Buckle Travel 20A																																																
10A																																																		
Electric fan 25A	MCU/Cluster 15A	Parking 10A																																																
Fuel heater 25A	Power socket 10A	Seat 15A																																																
ECU_key_power 10A	Beacon lamp 10A	Fan clutch 5A																																																
Room lamp 10A	Air con 30A	SPARE 5A																																																
Flasher unit 10A	Brake lamp 10A	SPARE 10A																																																
Joystick (LH) 10A	Right Joystick 10A	SPARE 10A																																																
Horn 10A	Cabin 10A	SPARE 15A																																																
ECU sensor 10A	Valve power 30A	SPARE 20A																																																
ECU power 25A	Bluetooth Player 10A	SPARE 25A																																																
ECU relay 5A	Wiper/washer 15A	SPARE 30A																																																
Fuel Heater Relay																																																		
ECU Relay																																																		

ELECTRIC SYSTEM - TROUBLESHOOTING

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM





ELECTRIC SYSTEM

CABIN





INDEX

Check point	Check method	Remarks
5.Ignition switch	1. Check proper connection with it in "ON" position: A-B-D	<p>A - Battery B - Accessory (ACC) C - Engine preheat (G) D - Ignition switch ON E - Ignition (ST)</p> <p>T85WBD8A</p>



5.5 FUEL GAUGE OPERATION

Check point	Check method	Remarks																																																																																																																								
1. Fuse	<p>1. Check the fuse engagement status.</p> <p>2. Check that the cluster fuse capacity is 15 A(F22).</p>	 <p>F22</p> <table border="1"> <tr><td>RMS Alternator</td><td>14-pin</td><td>3.1</td><td>/G/H)</td><td>Back Buzzer</td><td>10A</td></tr> <tr><td>10A</td><td></td><td></td><td></td><td>Pilot Lock</td><td>10A</td></tr> <tr><td>10A</td><td></td><td></td><td></td><td>Buzzer Travel</td><td>20A</td></tr> <tr><td>14-pin</td><td></td><td></td><td></td><td>Parking</td><td>10A</td></tr> <tr><td>10A</td><td></td><td></td><td></td><td>Seat</td><td>15A</td></tr> <tr><td>Worn lamp</td><td>(Front, Rear)</td><td></td><td></td><td>Fan clutch</td><td>5A</td></tr> <tr><td>MCU/Cluster</td><td>15A</td><td></td><td></td><td>SPARE</td><td>5A</td></tr> <tr><td>Electric fan</td><td>25A</td><td></td><td></td><td>SPARE</td><td>10A</td></tr> <tr><td>25A</td><td></td><td></td><td></td><td>SPARE</td><td>10A</td></tr> <tr><td>Fuel heater</td><td>25A</td><td></td><td></td><td>SPARE</td><td>15A</td></tr> <tr><td>25A</td><td></td><td></td><td></td><td>SPARE</td><td>20A</td></tr> <tr><td>ECU key power</td><td>10A</td><td></td><td></td><td>SPARE</td><td>30A</td></tr> <tr><td>ECU sensor</td><td>10A</td><td></td><td></td><td>SPARE</td><td>30A</td></tr> <tr><td>Horn</td><td>10A</td><td></td><td></td><td>SPARE</td><td>30A</td></tr> <tr><td>Joystick (LH)</td><td>10A</td><td></td><td></td><td>SPARE</td><td>30A</td></tr> <tr><td>Right Joystick</td><td></td><td></td><td></td><td>SPARE</td><td>30A</td></tr> <tr><td>Room lamp</td><td>10A</td><td></td><td></td><td>SPARE</td><td>30A</td></tr> <tr><td>Flasher unit</td><td>10A</td><td></td><td></td><td>SPARE</td><td>30A</td></tr> <tr><td>ECU relay</td><td>5A</td><td></td><td></td><td>SPARE</td><td>30A</td></tr> <tr><td>Fuel Heater Relay</td><td></td><td></td><td></td><td>ECU Relay</td><td></td></tr> </table> <p>LF1W5B29A</p>	RMS Alternator	14-pin	3.1	/G/H)	Back Buzzer	10A	10A				Pilot Lock	10A	10A				Buzzer Travel	20A	14-pin				Parking	10A	10A				Seat	15A	Worn lamp	(Front, Rear)			Fan clutch	5A	MCU/Cluster	15A			SPARE	5A	Electric fan	25A			SPARE	10A	25A				SPARE	10A	Fuel heater	25A			SPARE	15A	25A				SPARE	20A	ECU key power	10A			SPARE	30A	ECU sensor	10A			SPARE	30A	Horn	10A			SPARE	30A	Joystick (LH)	10A			SPARE	30A	Right Joystick				SPARE	30A	Room lamp	10A			SPARE	30A	Flasher unit	10A			SPARE	30A	ECU relay	5A			SPARE	30A	Fuel Heater Relay				ECU Relay	
RMS Alternator	14-pin	3.1	/G/H)	Back Buzzer	10A																																																																																																																					
10A				Pilot Lock	10A																																																																																																																					
10A				Buzzer Travel	20A																																																																																																																					
14-pin				Parking	10A																																																																																																																					
10A				Seat	15A																																																																																																																					
Worn lamp	(Front, Rear)			Fan clutch	5A																																																																																																																					
MCU/Cluster	15A			SPARE	5A																																																																																																																					
Electric fan	25A			SPARE	10A																																																																																																																					
25A				SPARE	10A																																																																																																																					
Fuel heater	25A			SPARE	15A																																																																																																																					
25A				SPARE	20A																																																																																																																					
ECU key power	10A			SPARE	30A																																																																																																																					
ECU sensor	10A			SPARE	30A																																																																																																																					
Horn	10A			SPARE	30A																																																																																																																					
Joystick (LH)	10A			SPARE	30A																																																																																																																					
Right Joystick				SPARE	30A																																																																																																																					
Room lamp	10A			SPARE	30A																																																																																																																					
Flasher unit	10A			SPARE	30A																																																																																																																					
ECU relay	5A			SPARE	30A																																																																																																																					
Fuel Heater Relay				ECU Relay																																																																																																																						
2. Ignition switch	<p>1. Check proper connection with it in "ON" position: A-B-D</p>	 <p>A - Battery B - Accessory (ACC) C - Engine preheat D - Ignition switch ON E - Ignition (ST)</p> <p>T85WBD8A</p>																																																																																																																								
3. Fuel sender	<p>1. Measure the resistance between two terminals of the fuel sender connector after disconnecting wiring and fuel sender connector.</p> <ul style="list-style-type: none"> - Empty: 110 Ω - Full: 3 Ω 	 <p>543(E)</p> <p>69(F)</p> <p>GND</p> <p>B(-)</p> <p>POWER RED(+)</p> <p>LF1W5A66A</p>																																																																																																																								
4. Fuel gauge on instrument panel	<p>1. Check the instrument cluster wiring (gauge signal wiring) and the ground wiring for proper connection</p> <ul style="list-style-type: none"> - The pointer moves slowly to the Full point if it is normal. 	 <p>LF1W5A67A</p>																																																																																																																								

5.6 TEMPERATURE GAUGE OPERATION


Check point	Check method	Remarks								
1. Fuse	<p>1. Check the fuse engagement status. 2. Check that the cluster fuse capacity is 15 A (F22).</p>	 <p>LF1W5B29A</p>								
2. Ignition switch	<p>1. Check proper connection with it in "ON" position: A-B-D</p>	 <p>A - Battery B - Accessory (ACC) C - Engine preheat (G) D - Ignition switch ON E - Ignition (ST)</p> <p>T85WBD8A</p>								
3. Temperature sensor	<p>1. Measure the resistance of the temperature sensor after disconnecting the connector.</p> <table border="1"> <tr> <td>Temp.</td> <td>85°C</td> <td>110°C</td> <td>125°C</td> </tr> <tr> <td>Resistance</td> <td>48.4Ω</td> <td>24Ω</td> <td>(15.2Ω)</td> </tr> </table> <p>* The value in the blank is reference value.</p>	Temp.	85°C	110°C	125°C	Resistance	48.4Ω	24Ω	(15.2Ω)	 <p>T85WBK5B</p>
Temp.	85°C	110°C	125°C							
Resistance	48.4Ω	24Ω	(15.2Ω)							
4. Temperature gauge on instrument cluster	<p>1. Check the instrument cluster wiring (sensor signal wiring) and the ground wiring for proper connection - The pointer slowly moves up when it is normal.</p>	 <p>LF1W5A68A</p>								

5.7 HOUR METER OPERATION


Check point	Check method	Remarks																																				
1. Fuse	<p>1. Check the fuse engagement status.</p> <p>2. Check that the cluster fuse capacity is 15 A (F22).</p>	 <p>F22</p> <table border="1"> <tr> <td>RMS Alternator 10A</td> <td>14-pin (Front, Rear) 10A</td> <td>Back Buzzer 10A</td> </tr> <tr> <td>14-pin 10A</td> <td>Wiper pump 10A</td> <td>Pilot Lock 10A</td> </tr> <tr> <td>Electric fan 25A</td> <td>MCU/Cluster 15A</td> <td>Buzzer Travel 20A</td> </tr> <tr> <td>Fuel heater 25A</td> <td>Power supply 10A</td> <td>Parking 10A</td> </tr> <tr> <td>ECU key power 10A</td> <td>Beacon lamp 10A</td> <td>Seat 15A</td> </tr> <tr> <td>Room lamp 10A</td> <td>Air con 30A</td> <td>Fan clutch 5A</td> </tr> <tr> <td>Flasher unit 10A</td> <td>Brake lamp 10A</td> <td>SPARE 5A</td> </tr> <tr> <td>Joystick (LH) 10A</td> <td>Right Joystick 10A</td> <td>SPARE 10A</td> </tr> <tr> <td>Horn 10A</td> <td>Cabin 10A</td> <td>SPARE 15A</td> </tr> <tr> <td>ECU sensor 10A</td> <td>Valve power 30A</td> <td>SPARE 20A</td> </tr> <tr> <td>ECU power 25A</td> <td>Bluetooth Player 10A</td> <td>SPARE 25A</td> </tr> <tr> <td>ECU relay 5A</td> <td>Wiper/washer 15A</td> <td>SPARE 30A</td> </tr> </table> <p>Fuel Heater Relay ECU Relay</p> <p>LF1W5B29A</p>	RMS Alternator 10A	14-pin (Front, Rear) 10A	Back Buzzer 10A	14-pin 10A	Wiper pump 10A	Pilot Lock 10A	Electric fan 25A	MCU/Cluster 15A	Buzzer Travel 20A	Fuel heater 25A	Power supply 10A	Parking 10A	ECU key power 10A	Beacon lamp 10A	Seat 15A	Room lamp 10A	Air con 30A	Fan clutch 5A	Flasher unit 10A	Brake lamp 10A	SPARE 5A	Joystick (LH) 10A	Right Joystick 10A	SPARE 10A	Horn 10A	Cabin 10A	SPARE 15A	ECU sensor 10A	Valve power 30A	SPARE 20A	ECU power 25A	Bluetooth Player 10A	SPARE 25A	ECU relay 5A	Wiper/washer 15A	SPARE 30A
RMS Alternator 10A	14-pin (Front, Rear) 10A	Back Buzzer 10A																																				
14-pin 10A	Wiper pump 10A	Pilot Lock 10A																																				
Electric fan 25A	MCU/Cluster 15A	Buzzer Travel 20A																																				
Fuel heater 25A	Power supply 10A	Parking 10A																																				
ECU key power 10A	Beacon lamp 10A	Seat 15A																																				
Room lamp 10A	Air con 30A	Fan clutch 5A																																				
Flasher unit 10A	Brake lamp 10A	SPARE 5A																																				
Joystick (LH) 10A	Right Joystick 10A	SPARE 10A																																				
Horn 10A	Cabin 10A	SPARE 15A																																				
ECU sensor 10A	Valve power 30A	SPARE 20A																																				
ECU power 25A	Bluetooth Player 10A	SPARE 25A																																				
ECU relay 5A	Wiper/washer 15A	SPARE 30A																																				
2. Ignition switch	<p>1. Check proper connection with it in "ON" position: A-B-D</p>	 <p>A - Battery B - Accessory (ACC) C - Engine preheat (G) D - Ignition switch ON E - Ignition (ST)</p> <p>T85WBD8A</p>																																				
3. Crank sensor	<p>1. The engine revolution is calculated from the point without two teeth on the crank sensor wheel.</p>	Refer to "ECU troubleshooting" manual																																				
4. ECU	<p>1. Check for engine hour meter of the ECU</p>	Refer to "ECU troubleshooting" manual																																				

6. WIRING DIAGRAM

6.1 MAIN



Wire Label	Color	Signal Name	Wire Label	Color	Signal Name	Wire Label	Color	Signal Name	Wire Label	Color	Signal Name	Wire Label	Color	Signal Name	Wire Label	Color	Signal Name
35	W	Battery_12V_38	159	R/Y	CAM_Shift_Position_Sensor	308	W	Aux_Hold_F_Switch	713A	R/G	Diode2	931	Y/R	AIRCON_PANEL	B07H	R	Power2
36	L	Battery_12V_36	160	R/B	Crank_Sensor_Signal	309	Or	14PinE	713B	R/G	Pilot_Lock_Travel_RY2	932	L/Y	AIRCON_PANEL	B10F	R/W	Battery_12V
37	L	Battery_12V_37	163	G/R	Intake_Throttle_Position_Sensor	310	Br/L	14PinF	715A	Lg	Diode2	933	Or	AIRCON_PANEL	B10H	R/W	Key_On1D
38A	R	UP_NO	164	P/B	EGR(Sensor 5V)	311	W/G	Aux_Port_Variable_Switch	715B	Lg	Pilot_Lock_Bucket_RY2	934	L/R	AIRCON_PANEL	B10I	R/W	HEATER_RELAY
51	P	Horn	166	R/G	Exhaust Gas Delta Press. 5V	313	Y/B	Travel_Pressure_SNSR_FW_LH	731	R/Y	Room_Lamp	935	B	AIRCON_PANEL	B10T	R/W	Battery_12V_3
71	P	Charge Signal	168	B	IMTS Return	314	G/B	Travel_Pressure_SNSR_FW_RH	732	R/G	Horn_Relay1	938	B/Y	AIRCON_PANEL	B10U	R/W	Alternator_Diode
76	Or	Flasher_Unit_12V	169	B	Water_In_Fuel_Sensor_Return	315	L/B	Travel_Pressure_SNSR_Reverse	813	G/R	14PIN D POW	939	B	AIRCON_PANEL	B10W	R/W	Battery_12V_
87B	R/B	Turn RH Signal1	170	B	Intake_Throttle_Position_Sensor_Gnd	322	R/G	Alternator	814	G/Y	14PIN C POW	940	Y/B	AIRCON_PANEL	B10Y	R/W	Battery_12V_2
96A	W	Lamp_Tail_Lamp1	171	B	Crank_Sensor_Return	341A	W/B	Main_Control_M_Valve	816	G	14PIN E POW	942	B/W	AIRCON_PANEL	B11	R/G	HEATER_RELAY
96K	W	Lamp 12V	172	B	Gnd	341B	W/B	Diode2	818	G/Y	14PIN F POW	955A	R	Battery_12V_26	B12	R	Key_On1D
96L	W	License_Lamp	174	B	Fuel_Injector_LSD2B	342A	Y/L	Diode2	820	G/L	14PIN G POW	955B	R	Battery_12V_26	B12A	R	Aircon B+
96W	W	Rear_Tail_Lamp_RH	175	B	Fuel_Injector_LSD1B	342B	Y/L	Main_Control_F_Valve	822	L/B	14PIN H POW	955K	R	Battery_12V_35	B13	R/B	Battery_12V
97A	R/B	Rear_Stop_Lamp_RH	177	B	Inlet_Metering_Valve_PWM	343	G/L	Stop_Lamp	851	R/G	FUEL_HEATER	955P	R	Battery_12V_25	B20	R	Power_relay4_1
97B	R/B	Stop_Relay2	183	B/Y	Intake_Throttle(H_Bridge_Neg)	344	Br/L	Back_Buzzer	855	Br/B	14PIN C COIL	960	R/Y	FAN_VCC	B21	R	Starter1
97C	R/B	Rear_Stop_Lamp_LH	184	R/L	Intake_Throttle(H_Brdige_Pos)	347	W/G	Electric_Fan_RY	856	Br/R	14PIN D COIL	961	R/G	FAN_PWR	B22	R	Starter2
100A	W/R	Oil SW signal	192	Gr	EGR(H_Bridge_Pos)	349	P	Rock_Travel_RY_Coil	857	Br/Y	14PIN E COIL	962	B/W	FAN_SPD_GND	B31A	R	Battery_B+
103	R/G	Fuel_Injector_HSDA2	193	W	EGR(H_Bridge_Neg)	350	Or	Lock_Bucket_RY_Coil	858	Br/Y	14PIN F COIL	963	L/W	FAN_SPD_5V	B31B	R	Battery +12V
105	R	Exhaust_Gas_Temperature_Sensor1	196	Gr	DPF_Regen_Inhibit_Switch	361	Y/L	Beacon_Relay1	859	Br/L	14PIN G COIL	964	P	FAN_SPD_SIG	B42A	R	Battery_12V_13
106	R	Exhaust_Gas_Temperature_Sensor2	201	R	Protected_Battery1	393A	Y	Diode2	860	Br	14PIN H COIL	965	B/Y	FAN_PWR_GND	B42C	R	Horn_Fuse
109	Y/R	Coolant_Temperature_Sensor	202	B	Gnd	393B	Y	Soft_Shift_Relay2	871	G	OPC_SW	966	G	RS232_GND	B42D	R	Room_Lamp_Fuse
110	G/R	Fuel_Temperature_Sensor	203	R	Protected_Battery2	398A	Y	Diode2	891	Y	RMS_KEY_IG	967	L	TX	B42G	R	Flasher_Unit_Fuse
112	R/G	Intake_Manifold_Pressure_Sensor	204	B	Gnd	398B	Y	Ride_Control_Relay2	891A	Y	Key_On10A	968	W	RX	B42H	R	VBB_L
113A	G	Comp	205	R	Protected_Battery3	401	R	Wiper_Washer_Fuse	899D	B	MCU_GND	971B	P	Ride_Control	B42K	R	Battery_12V_13
113B	G	A/C_Switch	206	B	Gnd	402	Gr	Back_Buzzer_Relay1	899D	B	MCU_GND	972	Y/R	OIL_TEMP	B42M	R	Light_Lamp1_Fuse
114	R/L	Forced_DPF_Regeneration_Switch	208	Y	Foot_Accel	414B	Gr	Turn_LH_Signal1	899F	B	MCU_GND	975B	Y/R	Quick_Attah_Unlock_RY_Coil	B45	R	Glow_Power_B+
115	L/Y	Intake_Throttle_Position_Feedback	209	Y	Foot_Accel	454C	Y/R	OBD2_DPF_Switch_Input2	899G	B	MCU_GND	976B	Br/R	Quick_Attah_Lock_RY_Coil	B46	R	Glow_Plug_ON_Signal
116	W	EGR(Sensor Signal)	213	G	Hand Accelerator Track 2, Signal	454G	Y/R	ECU_Sensor_Fuse2	899H	B	MCU_GND	977	B	Camera_GND	K01A	R	key_On1A
117	R	Exhaust_Gas_Delta_Press_Output	214	B	Hand Accelerator Track 2, Return	454H	Y/R	Inlet_Metering_Valve1	899J	B	MCU_GND	977A	B	Camera_GND	K01B	R	CLUSTER_FUSE
118	R/Y	Water_In_Fuel_Sensor_Signal	215	W	Air_Inlet_Temperature	454L	Y/R	Inlet_Metering_Valve2	899K	B	MCU_GND	979	R/Y	floating_mag.12v	K01C	R	Key_On1C
119	B	GND	219	R/G	Key_Switch_Input	454T	Y/R	Glow_Relay_Coil	899L	B	MCU_GND	980	R	Camera_Power	K01D	R	CLUSTER_FUSE
122	B	Exhaust_Gas_Temp_Sen_GND	220	B	Foot_Accel	467A	R/Y	Travel_Sol_CTL	899M	B	MCU_GND	981A	P	Light_Switch_Input2A	K01E	R	RIGHT_JOYSTICK_FUSE
123	B	Exhaust_Gas_Temp_Sen_GND	221	B	AMF_Frequency_Gnd	467B	R/Y	Travel_Sol_CTL	899N	B	MCU_GND	985	Lg	ACC1B	K01F	R	Key_On1M
125	B	Fuel_Injector_LSD2A	222	R/B	Foot_Accel	502A	W/R	Key_Start_2	899P	B	MCU_GND	987	Y/R	FUEL_SENDER	K01G	R	Pilot_Lock_Travel_Fuse
126	B	Fuel_Injector_LSD1A	223	R/B	Foot_Accel	502H	W/R	Key_Start_3	903	Y	Battery_12V_29	989	Gr	14PIN 12V	K01H	R	Key_On10A
127	R/B	Fuel_Injector_HSDA1	224	R/G	Hand_VREF1_PPS1_5V	592A	R	Stop_Lamp_Fuse	903A	Y	Diode2	993	Vo	AV1_GND	K01J	R	RMS_Fuse
128A	B	Accelerometer1_Screen	225	G	Hand_Pedal_Position_Sensor1	592B	R	Back_Buzzer_Fuse	905A	L/Y	Diode2	994	R/B	SEAT_POWER	K01M	R	Key_On1M
128B	B	Shield_GND	226	B	Hand_PPS1_Return	592C	R	Stop_Lamp_Fuse	905B	L/Y	Quick_Attah_Lock_RY2	995P	R	14Pin	K01N	R	Key_On1N
129A	B	Accelerometer2_Screen	229	R/G	Hand_VREF2_PPS2_5V	592D	R	Stop_Lamp_Fuse	907A	W	Diode2	996A	Gr	RIGHT_JOYSTICK_INPUT	K01R	R	Left_Joystick_Fuse
129B	B	Shield_GND	232	W/G	Parking_Relay3	592G	R	Beacon_Lamp_Fuse	907B	W	Quick_Attah_Unlock_RY2	996B	Gr	Key_On1W	K01S	R	Power_Relay5_Coil
130	Y/B	Accelerometer1_Return	234	B	Foot_Accel	595A	R/G	Horn_Relay2	909A	Gr	Hi_Flow_Relay2	996C	Gr	Key_On5K	K01T	R	FAN_KEY_ON
131	Y	Accelerometer1	237	Br/R	Stater_Motor_Inhibit_Relay	598	Gr	Back_Buzzer_Relay2	909B	Gr	Diode2	997	W	AV1	K04A	R/W	ILL+
132	Y	Accelerometer2	245	B	ECU_Main_Power_Relay	599	Br	Stop_Relay1	921	R	Battery_12V_28	A01B	Lg	ACC1B	K04B	R/W	ILL+
133	Y/B	Accelerometer2_Return	247A	W/L	MCU_CAN_L	685	Y	COMPRESSURE_PW	921	R	Battery_12V_28	A01U	Lg	HEATER_RELAY_COIL	K04C	R/W	KEY_ON
134	Y/R	Intake_Air_Temperature_Sensor	247G	W/L	FAN_CAN_L	686	Or	MCU_IG	921J	R	Quick_Attah_Lock_RY1	B02A	R	Engine_B+	K04Z	R/W	Dual_Pressure_Switch_Input
135	R/L	Rail_Pressure_Sensor_Output_Signal	248A	Y	MCU_CAN_H	686J	Or	Travel_Pres_Sen(F_LH)	921K	R	Quick_Attah_Unlock_RY1	B02B	R	Engine_B+	K05	G/R	14PIN D POW
138	R/G	Rail_Pressure_Sensor_Supply_Voltage	248G	Y	FAN_CAN_H	686K	Or	Travel_Pres_Sen(F_LH)	922	R	AIRCON_PANEL	B02R	R	Battery_B+	K05A	G/R	14PIN D POW
139	R/Y	VREF1_Crank_Sensor	256	B	Glow_Plug_Relay_Driver	686P	Or	Travel_Pres_Sen(F_LH)	923	R/W	AIRCON_PANEL	B03A	R	ECU_Relay_Coil	K05B	G/R	14PIN C POW
141	R/B	VREF_INPRES	258	R/Y	Engine_Emergency_Stop_Signal	686R	Or	OPC_SW	924	L	AIRCON_PANEL						



Wire Label	Color	Signal Name
31	Br	CD_Player3
32	B	CD_Player4
33	Br	CD_Player5
34	B	CD_Player6
35	W	Battery_12V_38
35A	W	USB_POWER
38A	R	UP_NO
61A	R	Work_Lamp_Relay_R2
61B	R	Lamp_12V
76	Or	Flasher_Unit_12V
81A	R/G	Hazard_Switch_Input2
81B	R/G	Flasher_Unit_Signal
81C	R/G	Turn_Signal_Switch_Input
87A	R/B	Turn_RH_Signal2
87B	R/B	Turn_RH_Signal1
87C	R/B	FRONT_TURN_LAMP_RH
87D	R/B	Turn_Signal_RH_Cluster
96A	W	Lamp_Tail_Lamp1
96B	W	Work_Lamp_FR
96C	W	OVERRIDE_SWITCH_LAMP
96E	W	Regen_SW_Lamp
96E	W	Regen_SW_Lamp
96F	W	Regen_SW_Lamp
96G	W	HYD_LOCK_SW_LAMP
96H	W	Light_Switch_Lamp
96I	W	SELF_LEVELING_SW_LAMP
96J	W	Wiper_Washer_SW_Lamp
96M	W	HI_FLOW_SW_LAMP
96N	W	QUICK_ATTACH_SW_LAMP
96P	W	AUX_SWITCH_LAMP
96R	W	Beacon_SW_Lamp
96S	W	Front_Tail_Lamp_RH
96T	W	Hazard_Switch_Lamp_Input
96U	W	Front_Tail_Lamp_LH
96V	W	Front_Tail_Lamp_LH
96X	W	Front_Tail_Lamp_LH
96Y	W	Work_Lamp_Relay_F2
96Z	R/B	ROOM_LAMP
114	R/L	Forced_DPF_Regeneration_Switch
196	Gr	DPF_Regen_Inhibit_Switch
213	G	Hand Accelerator Track 2, Signal
214	B	Hand Accelerator Track 2, Return
224	R/G	Hand VREF1 PPS1 5V
225	G	Hand Pedal Position Sensor1
226	B	Hand PPS1 Return
229	R/G	Hand VREF2 PPS2 5V
232	W/G	Parking_Relay3
247A	W/L	MCU_CAN_L


Wire Label	Color	Signal Name
247B	W/L	OBD_CAN_L
247C	W/L	CLUSTER_CAN_L
247D	W/L	CANL
247E	W/L	RMS_CAN_L
247F	W/L	TEL_CAN_L
248A	Y	MCU_CAN_H
248B	Y	OBC_CAN_H
248C	Y	CLUSTER_CAN_H
248D	Y	CANH
248E	Y	RMS_CAN_H
248F	Y	TEL_CAN_H
258	R/Y	Engine_Emergency_Stop_Signal
301	Y	Aux_Switch
302	G	Aux_Electrical_Mode_Change
303	R	14PinC
304	Br	14PinD
305	Lg	14PinG
306	Gr	14PinH
307	P	Aux_Hold_M_Switch
308	W	Aux_Hold_F_Switch
309	Or	14PinE
310	Br/L	14PinF
311	W/G	Aux_Port_Variable_Switch
312	L/G	Safety_Switch
313	Y/B	Travel_Pressure_SNSR_FW_LH
314	G/B	Travel_Pressure_SNSR_FW_RH
315	L/B	Travel_Pressure_SNSR_Reverse
316	G	Safety_SW_LH
317	L	Seat_SW
318	Y/W	Reset_Switch
319	G/W	Hydraulic_Lock_Switch
321	P/G	Parking_Switch
322	R/G	Alternator
323	Y/G	High_Flow_Switch
341A	W/B	Main_Control_M_Valve
342B	Y/L	Main_Control_F_Valve
343	G/L	Stop_Lamp
344	Br/L	Back_Buzzer
345	P/L	Parking_Sol_RY_Coil
347	W/G	Electric_Fan_RY
349	P	Rock_Travel_RY_Coil
350	Or	Lock_Bucket_RY_Coil
351	Y	High_Flow_RY_Coil
361	Y/L	High_Flow_RY_Coil
361	Y/L	High_Flow_RY_Coil
393B	Y	Soft_Shift_Relay2
398B	Y	Ride_Control_Relay2
401	R	Wiper_Washer_Fuse

Wire Label	Color	Signal Name
403	R/Y	Beacon_Lamp
414A	Gr	FRONT_TURN_LAMP_LH
414B	Gr	Turn_LH_Signal1
414C	Gr	Turn_LH_Signal2
414D	Gr	Turn_Signal_LH_Cluster
454A	Y/R	DPF_Switch_Signal
454B	Y/R	OBD2_DPF_Switch_Input1
454C	Y/R	OBD2_DPF_Switch_Input2
467B	R/Y	Travel_Sol_CTL
502	W/R	Key_Start_1
502A	W/R	Key_Start_2
502B	W/R	Start_Switch
586	P	Beacon_Relay_Coil
595A	R/G	Horn_Relay2
595B	R/G	Diode2
686A	Or	Safety_Switch_Input
686B	Or	Safety_Switch_Input
686C	Or	Reset_Switch_Input
686D	Or	Reset_Switch_Input
686G	Or	Safety_Switch_Input
686H	Or	Safety_Switch_Input
686L	Or	MCU_POWER
686Q	Or	BUZZER
686W	Or	MCU_IG
686X	Or	Key_On1V
686Y	Or	KEY_ON
686Z	Or	MCU_IG
704	Br/B	Parking_Relay1
707B	Y/R	Parking_Relay2
731	R/Y	Room_Lamp
752	G	Wiper_Relay1
761	Y	Wiper_Relay_Coil
761B	Y	Wash_M(F) 12V
761C	Y	Wiper_Relay2
762	R	Wiper_Relay_Coil
806	G/B	Wash_M(F) SW
855	Br/B	14PIN C COIL
856	Br/R	14PIN D COIL
857	Br/Y	14PIN E COIL
858	Br/Y	14PIN F COIL
859	Br/L	14PIN G COIL
860	Br	14PIN H COIL
871	G	OPC_SW
881	B	GND
882	Y/B	232TX
883	G/R	232RX
891	Y	RMS_KEY_IG
891B	Y	key_on

Wire Label	Color	Signal Name
891C	Y	Battery_B+
899	B	MCU_GND
899A	B	MCU_GND
899B	B	MCU_GND
899C	B	MCU_GND
899D	B	MCU_GND
899E	B	MCU_GND
903	Y	Battery_12V_29
909A	Gr	Hi_Flow_Relay2
921	R	Battery_12V_28
921A	R	Battery_12V_27
921C	R	POWER
921D	R	Hi_Flow_Fuse
921E	R	Soft_Shift_Fuse
921F	R	Self_Leveling_SW_Input2
921G	R	Quick_Attach_SW_Input2
921H	R	Quick_Attach_SW_Input5
921L	R	High_Flow_SW_Input2
922	R	AIRCON_PANEL
923	R/W	AIRCON_PANEL
924	L	AIRCON_PANEL
925	Y	AIRCON_PANEL
926	G	AIRCON_PANEL
927	B/W	AIRCON_PANEL
928	Lg	AIRCON_PANEL
929	G/W	AIRCON_PANEL
930	L/W	AIRCON_PANEL
931	Y/R	AIRCON_PANEL
932	L/Y	AIRCON_PANEL
933	Or	AIRCON_PANEL
934	L/R	AIRCON_PANEL
935	B	AIRCON_PANEL
938	B/Y	AIRCON_PANEL
939	B	AIRCON_PANEL
940	Y/B	AIRCON_PANEL
941	L/W	RIDE_CONTROL_RY
942	B/W	AIRCON_PANEL
971B	P	RIDE_CONTROL
972	Y/R	OIL_TEMP
973A	G	Self_Leveling_Lamp
973B	G	Self_Leveling_Relay_Coil
975A	Y/R	Quick_Attach_Unlock_Lamp
975B	Y/R	Quick_Attach_Unlock_RY_Coil
976A	Br/R	Quick_Attach_Lock_Lamp
976B	Br/R	Quick_Attach_Lock_RY_Coil
977	B	Camera_GND
977C	B	CAMERA_GND(SHIELD)
979	R/Y	floating_mag.12v

Wire Label	Color	Signal Name
980	R	Camera_Power
981A	P	Light_Switch_Input2A
981A	P	Light_Switch_F
981B	P	Light_Switch_Input2A
981C	P	Light_Switch_R
981C	P	FRONT_WORKING_LAMP(B+)
981D	P	Work_Lamp_Relay_R1
982	R/Y	ROOM_LAMP
983	R/Y	Work_Lamp_Relay_F_Coil
984	Br	Work_Lamp_Relay_R_Coil
985	Lg	ACC1B
987	Y/R	FUEL_SENDER
990	R/Y	FRONT_WORK_LAMP_RELAY(+)
991	Y/R	REAR_WORKING_LAMP_RELAY(+)
992	B/R	WORK_LAMP_SWITCH_LED(-)
992A	B/R	WORK_LAMP_SWITCH_LED(-)
992B	B/R	TAIL_LAMP(-)
992C	B/R	TAIL_LAMP(-)
992D	B/R	TAIL_LAMP(-)
992E	B/R	TAIL_LAMP(-)
992F	B/R	TAIL_LAMP(-)
992G	B/R	TAIL_LAMP(-)
992H	B/R	TAIL_LAMP(-)
992I	B/R	TAIL_LAMP(-)
992J	B/R	TAIL_LAMP(-)
992K	B/R	TAIL_LAMP(-)

6.2 MCU UPDATE



SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX


7. EXPLODED VIEW



REMARKS

- The manufacturing parts are subject to change without notice. Therefore, check the parts catalog or electronic manual for latest information.

7.1 LF1-G311007 ENGINE ELECTRICAL GROUP




LF1W5A78A

COMPONENTS

- (1) Exhaust Gas Temperature Sensor
- (2) Sensor, DPF Diff Press

- (3) Assy Sensor, Intake Air Temp-T1
- (4) Housing-Intake Temp Sensor

7.2 LF1-G327001 LIGHT CONTROL GROUP



LF1W5A79A

COMPONENTS

(1) Escort Unit

(2) Flaner Bolt

(3) Unit, Flasher

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

7.3 LF1-G328002 POWER SOCKET GROUP




LF1W5A80A

COMPONENTS

(1) Power Outlet Ass'y(12V)

(2) Socket-USB

7.4 LF1-G331001 WIRE HARNESS GROUP




LF1W5A81A

COMPONENTS

(1) Wire Harness, Main

(2) Wire Harness, Cabin

7.5 LF1-G332001 CLUSTER CONTROL GROUP



LF1W5A82A


COMPONENTS

(1) Cluster
(2) Screw With Washer

(3) Cord Band
(4) Assy Buzzer

(5) Screw
(6) Plate, Buzzer

7.6 LF1-G332501 FUEL SENDER GROUP




LF1W5A83A

COMPONENTS

(1) Sender, Fuel

(2) Screw with washer

7.7 MACHINE CONTROL GROUP (HS120V)




LF1W5B13A

COMPONENTS

- | | | |
|----------------------------|------------------------------|-----------------------------|
| (1) MCU | (13) Wir'g Clamp | (25) Relay 70A |
| (2) Sensor, Safety | (14) Flaner Bolt | (26) Sensor, Safety |
| (3) Screw | (15) Nut | (27) Screw |
| (4) Travel Pressure Sensor | (16) Screw | (28) Oil Thermometer Sensor |
| (5) Switch, Turn Signal | (17) Screw | (29) Twin Relay, Motor |
| (6) Switch, Light | (18) Bolt, Washer | (30) Switch, Wiper/Washer |
| (7) Reset Switch | (19) Bolt, Flange | (31) Switch, Self leveling |
| (8) Switch, High Flow | (20) Pedal, Foot Acltr-Lf100 | (32) Switch, Room lamp |
| (9) Hazard Switch | (21) Accel Dial | (33) Switch, Beacon |
| (10) Switch, DPF-Regen | (22) Taping Screw(M4x18) | (34) Switch, Quick Attach |
| (11) Switch, Parking | (23) Hydraulic Lock Switch | |
| (12) Cord Band | (24) Aux Switch | |

7.7 MACHINE CONTROL GROUP (HS80V)



SL6W505A

COMPONENTS

- | | | |
|---------------------------|-----------------------|-----------------------------|
| (1) MCU | (13) Flange bolt | (25) Sensor, Safety |
| (2) Sensor, Safety | (14) Nut | (26) Screw |
| (3) Screw | (15) Screw | (27) Oil Thermometer Sensor |
| (4) Switch, Wiper | (16) Screw | (28) Twin Relay, Motor |
| (5) Switch, Light | (17) Bolt | (29) Switch, Room lamp |
| (6) Switch, Parking | (18) Bolt, Flange | (30) Switch, Reset |
| (7) Switch, Turn Signal | (19) Foot accel pedal | |
| (8) Hydraulic Lock Switch | (20) Accel dial | |
| (9) Switch, DPF-Regen | (21) Tapping switch | |
| (10) Plug | (22) Switch, Aux | |
| (11) Code band | (23) Hazard Switch | |
| (12) Wiring clamp | (24) Relay 70A | |