CONTENTS

SECTIO	N 1 GENERAL	
Group	1 Safety Hints	1-1
•	2 Specifications ·····	
		
SECTIO	N 2 STRUCTURE AND FUNCTION	
Group	1 Pump Device ·····	2-1
Group	2 Main Control Valve ·····	2-21
Group	3 Swing Device	2-52
Group	4 Travel Device	2-63
Group	5 RCV Lever ····	2-76
Group	6 RCV Pedal ·····	2-83
SECTIO	N 3 HYDRAULIC SYSTEM	
Group	1 Hydraulic Circuit ·····	3-1
Group	2 Main Circuit ·····	3-4
Group	3 Pilot Circuit ·····	3-7
Group	4 Single Operation ·····	3-16
	5 Combined Operation ····	
SECTIO	N 4 ELECTRICAL SYSTEM	
Group	1 Component Location	4-1
	2 Electrical Circuit ·····	
Group	3 Electrical Component Specification	4-23
	4 Connectors ·····	
SECTIO	N 5 MECHATRONICS SYSTEM	
Group	1 Outline	5-1
Group	2 Mode selection System	5-3
Group	3 Automatic Deceleration System	5-6
Group	4 Power Boost System	5-7
Group	5 Travel Speed Control System	5-8
	6 Automatic Warming Up Function	
	7 Engine Overheat Prevention Function	

	Group	8	Variable Power Control System ·····	5-11
	Group	9	Attachment Flow Control System	5-12
	Group	10	Intelligent Power Control System	5-13
	Group	11	Anti-Restart System	5-15
	Group	12	Self-Diagnostic System ·····	5-16
	Group	13	Engine Control System	5-62
	Group	14	EPPR Valve	5-63
	Group	15	Monitoring System	5-68
	Group	16	Fuel Warmer System	5-105
	Group	17	1 or 2-Way Optional Piping Pressure Removal System	5-106
SE	CTION	6 -	TROUBLESHOOTING	
	Group	1	Before trobleshooting	6-1
	Group	2	Hydraulic and Mechanical System	6-4
			Electrical System	
	Group	4	Mechatronics System	6-42
	Group	5	Air conditioner and Heater System	6-71
SE	CTION	7	MAINTENANCE STANDARD	
	Group	1	Operational Performance Test	7-1
	-		Major Components	
	Group	3	Track and Work Equipment	7-29
SE	CTION	8	DISASSEMBLY AND ASSEMBLY	
	Group	1	Precaution	8-1
	Group	2	Tightening Torque ····	8-3
	Group	3	Pump Device ····	8-7
	Group	4	Main Control Valve	8-32
	Group	5	Swing Device	8-46
	Group	6	Travel Device	8-78
	Group	7	RCV Lever	8-110
	Group	8	Turning Joint	8-124
	Group	9	Boom, Arm and Bucket Cylinder	8-129
	Group	10	Undercarriage	8-148
	Group	11	Work Equipment ·····	8-160

1. STRUCTURE

This service manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This service manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into the following sections.

SECTION 1 GENERAL

This section explains the safety hints and gives the specification of the machine and major components.

SECTION 2 STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

SECTION 3 HYDRAULIC SYSTEM

This section explains the hydraulic circuit, single and combined operation.

SECTION 4 ELECTRICAL SYSTEM

This section explains the electrical circuit, monitoring system and each component. It serves not only to give an understanding electrical system, but also serves as reference material for trouble shooting.

SECTION 5 MECHATRONICS SYSTEM

This section explains the computer aided power optimization system and each component.

SECTION 6 TROUBLESHOOTING

This section explains the troubleshooting charts correlating **problems** to **causes**.

SECTION 7 MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

SECTION 8 DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your HD Hyundai Construction Equipment distributor for the latest information.

2. HOW TO READ THE SERVICE MANUAL

Distribution and updating

Any additions, amendments or other changes will be sent to HD Hyundai Construction Equipment distributors.

Get the most up-to-date information before you start any work.


Filing method

1. See the page number on the bottom of the page.

File the pages in correct order.

2. Following examples shows how to read the page number.

Example 1



Additional pages: Additional pages are indicated by a hyphen (-) and number after the page number. File as in the example.

Revised edition mark (123...)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

Revisions

Revised pages are shown at the list of revised pages on the between the contents page and section 1 page.

Symbols

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol	Item	Remarks
Λ	Cofoty	Special safety precautions are necessary when performing the work.
	Safety	Extra special safety precautions are necessary when performing the work because it is under internal pressure.
*	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.

3. CONVERSION TABLE

Method of using the Conversion Table

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

Example

1. Method of using the Conversion Table to convert from millimeters to inches

Convert 55 mm into inches.

- (1) Locate the number 50 in the vertical column at the left side, take this as ⓐ, then draw a horizontal line from ⓐ.
- (2) Locate the number 5 in the row across the top, take this as ⓑ, then draw a perpendicular line down from ⓑ.
- (3) Take the point where the two lines cross as ©. This point © gives the value when converting from millimeters to inches. Therefore, 55 mm = 2.165 inches.

2. Convert 550 mm into inches.

- (1) The number 550 does not appear in the table, so divide by 10 (Move the decimal point one place to the left) to convert it to 55 mm.
- (2) Carry out the same procedure as above to convert 55 mm to 2.165 inches.
- (3) The original value (550 mm) was divided by 10, so multiply 2.165 inches by 10 (Move the decimal point one place to the right) to return to the original value.

 This gives 550 mm = 21.65 inches.

	Millimete	rs to inche	es				1 mm = 0.03937 in				
		0	1	2	3	4	5	6	7	8	9
	0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
	10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
	20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
	30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
	40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
							c				
(a)	50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
	60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
	70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
	80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
	90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Millimeters to inches 1 mm = 0.03937 in

	1 11111 - 0.00007									
	0	1	2	3	4	5	6	7	8	9
0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Kilogram to Pound 1 kg = 2.2046 lb

	0	1	2	3	4	5	6	7	8	9
0		2.20	4.41	6.61	8.82	11.02	13.23	15.43	17.64	19.84
10	22.05	24.25	26.46	28.66	30.86	33.07	35.27	37.48	39.68	41.89
20	44.09	46.30	48.50	50.71	51.91	55.12	57.32	59.5.	61.73	63.93
30	66.14	68.34	70.55	72.75	74.96	77.16	79.37	81.57	83.78	85.98
40	88.18	90.39	92.59	94.80	97.00	99.21	101.41	103.62	105.82	108.03
50	110.23	112.44	114.64	116.85	119.05	121.25	123.46	125.66	127.87	130.07
60	132.28	134.48	136.69	138.89	141.10	143.30	145.51	147.71	149.91	152.12
70	154.32	156.53	158.73	160.94	163.14	165.35	167.55	169.76	171.96	174.17
80	176.37	178.57	180.78	182.98	185.19	187.39	189.60	191.80	194.01	196.21
90	198.42	200.62	202.83	205.03	207.24	209.44	211.64	213.85	216.05	218.26

Liter to U.S. Gallon 1 ℓ = 0.2642 U.S.Gal

	. , , , , , , , , , , , , , , , , , , ,									
	0	1	2	3	4	5	6	7	8	9
0		0.264	0.528	0.793	1.057	1.321	1.585	1.849	2.113	2.378
10	2.642	2.906	3.170	3.434	3.698	3.963	4.227	4.491	4.755	5.019
20	5.283	5.548	5.812	6.6076	6.340	6.604	6.869	7.133	7.397	7.661
30	7.925	8.189	8.454	8.718	8.982	9.246	9.510	9.774	10.039	10.303
40	10.567	10.831	11.095	11.359	11.624	11.888	12.152	12.416	12.680	12.944
50	13.209	13.473	13.737	14.001	14.265	14.529	14.795	15.058	15.322	15.586
60	15.850	16.115	16.379	16.643	16.907	17.171	17.435	17.700	17.964	18.228
70	18.492	18.756	19.020	19.285	19.549	19.813	20.077	20.341	20.605	20.870
80	21.134	21.398	21.662	21.926	22.190	22.455	22.719	22.983	23.247	23.511
90	23.775	24.040	24.304	24.568	24.832	25.096	25.631	25.625	25.889	26.153

Liter to U.K. Gallon 1 ℓ = 0.21997 U.K.Gal

	0	1	2	3	4	5	6	7	8	9	
0		0.220	0.440	0.660	0.880	1.100	1.320	1.540	1.760	1.980	ĺ
10	2.200	2.420	2.640	2.860	3.080	3.300	3.520	3.740	3.950	4.179	
20	4.399	4.619	4.839	5.059	5.279	5.499	5.719	5.939	6.159	6.379	ı
30	6.599	6.819	7.039	7.259	7.479	7.969	7.919	8.139	8.359	8.579	ı
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.778	ì
											ı
50	10.998	11.281	11.438	11.658	11.878	12.098	12.318	12.528	12.758	12.978	ı
60	13.198	13.418	13.638	13.858	14.078	14.298	14.518	14.738	14.958	15.178	ı
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378	ı
80	17.598	17.818	18.037	18.257	18.477	18.697	18.917	19.137	19.357	19.577	ı
90	19.797	20.017	20.237	20.457	20.677	20.897	21.117	21.337	21.557	21.777	ı

kgf · m to lbf · ft $1 \text{ kgf} \cdot \text{m} = 7.233 \text{ lbf} \cdot \text{ft}$

	0	1	2	3	4	5	6	7	8	9
		7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	396.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	10005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4

kgf/cm² to lbf/in²

 $1 \text{ kgf} / \text{cm}^2 = 14.2233 \text{ lbf} / \text{in}^2$

J	1 kgr/cm² = 14.2233 II						2233 101 / 1112			
	0	1	2	3	4	5	6	7	8	9
		14.2	28.4	42.7	56.9	71.1	85.3	99.6	113.8	128.0
10	142.2	156.5	170.7	184.9	199.1	213.4	227.6	241.8	256.0	270.2
20	284.5	298.7	312.9	327.1	341.4	355.6	369.8	384.0	398.3	412.5
30	426.7	440.9	455.1	469.4	483.6	497.8	512.0	526.3	540.5	554.7
40	568.9	583.2	597.4	611.6	625.8	640.1	654.3	668.5	682.7	696.9
50	711.2	725.4	739.6	753.8	768.1	782.3	796.5	810.7	825.0	839.2
60	853.4	867.6	881.8	896.1	910.3	924.5	938.7	953.0	967.2	981.4
70	995.6	1010	1024	1038	1053	1067	1081	1095	1109	1124
80	1138	1152	1166	1181	1195	1209	1223	1237	1252	1266
90	1280	1294	1309	1323	1337	1351	1365	1380	1394	1408
100	1422	1437	1451	1465	1479	1493	1508	1522	1536	1550
110	1565	1579	1593	1607	1621	1636	1650	1664	1678	1693
120	1707	1721	1735	1749	1764	1778	1792	1806	1821	1835
130	1849	2863	1877	1892	1906	1920	1934	1949	1963	1977
140	1991	2005	2020	2034	2048	2062	2077	2091	2105	2119
150	2134	2148	2162	2176	2190	2205	2219	2233	2247	2262
160	2276	2290	2304	2318	2333	2347	2361	2375	2389	2404
170	2418	2432	2446	2460	2475	2489	2503	2518	2532	2546
180	2560	2574	2589	5603	2617	2631	2646	2660	2674	2688
200	2845	2859	2873	2887	2901	2916	2930	2944	2958	2973
210	2987	3001	3015	3030	3044	3058	3072	3086	3101	3115
220	3129	3143	3158	3172	3186	3200	3214	3229	3243	3257
230	3271	3286	3300	3314	3328	3343	3357	3371	3385	3399
240	3414	3428	3442	3456	3470	3485	3499	3513	3527	3542

TEMPERATURE

Fahrenheit-Centigrade Conversion.

A simple way to convert a fahrenheit temperature reading into a centigrade temperature reading or vice verse is to enter the accompanying table in the center or boldface column of figures.

These figures refer to the temperature in either Fahrenheit or Centigrade degrees.

If it is desired to convert from Fahrenheit to Centigrade degrees, consider the center column as a table of Fahrenheit temperatures and read the corresponding Centigrade temperature in the column at the left.

If it is desired to convert from Centigrade to Fahrenheit degrees, consider the center column as a table of Centigrade values, and read the corresponding Fahrenheit temperature on the right.

°C		°F	°C		°F	°C		°F	°C		°F
-40.4	-40	-40.0	-11.7	11	51.8	7.8	46	114.8	27.2	81	117.8
-37.2	-35	-31.0	-11.1	12	53.6	8.3	47	116.6	27.8	82	179.6
-34.4	-30	-22.0	-10.6	13	55.4	8.9	48	118.4	28.3	83	181.4
-31.7	-25	-13.0	-10.0	14	57.2	9.4	49	120.2	28.9	84	183.2
-28.9	-20	-4.0	-9.4	15	59.0	10.0	50	122.0	29.4	85	185.0
-28.3	-19	-2.2	-8.9	16	60.8	10.6	51	123.8	30.0	86	186.8
-27.8	-18	-0.4	-8.3	17	62.6	11.1	52	125.6	30.6	87	188.6
-27.2	-17	1.4	-7.8	18	64.4	11.7	53	127.4	31.1	88	190.4
-26.7	-16	3.2	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-26.1	-15	5.0	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-25.6	-14	6.8	-6.1	21	69.8	13.3	56	132.8	32.8	91	195.8
-25.0	-13	8.6	-5.6	22	71.6	13.9	57	134.6	33.3	92	197.6
-24.4	-12	10.4	-5.0	23	73.4	14.4	58	136.4	33.9	93	199.4
-23.9	-11	12.2	-4.4	24	75.2	15.0	59	138.2	34.4	94	201.2
-23.3	-10	14.0	-3.9	25	77.0	15.6	60	140.0	35.0	95	203.0
-22.8	-9	15.8	-3.3	26	78.8	16.1	61	141.8	35.6	96	204.8
-22.2	-8	17.6	-2.8	27	80.6	16.7	62	143.6	36.1	97	206.6
-21.7	-7	19.4	-2.2	28	82.4	17.2	63	145.4	36.7	98	208.4
-21.1	-6	21.2	-1.7	29	84.2	17.8	64	147.2	37.2	99	210.2
-20.6	-5	23.0	-1.1	35	95.0	21.1	70	158.0	51.7	125	257.0
-20.0	-4	24.8	-0.6	31	87.8	18.9	66	150.8	40.6	105	221.0
-19.4	-3	26.6	0	32	89.6	19.4	67	152.6	43.3	110	230.0
-18.9	-2	28.4	0.6	33	91.4	20.0	68	154.4	46.1	115	239.0
-18.3	-1	30.2	1.1	34	93.2	20.6	69	156.2	48.9	120	248.0
-17.8	0	32.0	1.7	35	95.0	21.1	70	158.0	51.7	125	257.0
-17.2	1	33.8	2.2	36	96.8	21.7	71	159.8	54.4	130	266.0
-16.7	2	35.6	2.8	37	98.6	22.2	72	161.6	57.2	135	275.0
-16.1	3	37.4	3.3	38	100.4	22.8	73	163.4	60.0	140	284.0
-15.6	4	39.2	3.9	39	102.2	23.3	74	165.2	62.7	145	293.0
-15.0	5	41.0	4.4	40	104.0	23.9	75	167.0	65.6	150	302.0
-14.4	6	42.8	5.0	41	105.8	24.4	76	168.8	68.3	155	311.0
-13.9	7	44.6	5.6	42	107.6	25.0	77	170.6	71.1	160	320.0
-13.3	8	46.4	6.1	43	109.4	25.6	78	172.4	73.9	165	329.0
-12.8	9	48.2	6.7	44	111.2	26.1	79	174.2	76.7	170	338.0
-12.2	10	50.0	7.2	45	113.0	26.7	80	176.0	79.4	172	347.0

SECTION 1 GENERAL

Group	1	Safety Hints	1-1
Group	2	Specifications	1-10


GROUP 1 SAFETY

FOLLOW SAFE PROCEDURE

Unsafe work practices are dangerous. Understand service procedure before doing work; Do not attempt shortcuts.

WEAR PROTECTIVE CLOTHING


Wear close fitting clothing and safety equipment appropriate to the job.



WARN OTHERS OF SERVICE WORK

Unexpected machine movement can cause serious injury.

Before performing any work on the excavator, attach a 「Do Not Operate」 tag on the right side control lever.




USE HANDHOLDS AND STEPS

Falling is one of the major causes of personal injury.

When you get on and off the machine, always maintain a three point contact with the steps and handrails and face the machine. Do not use any controls as handholds.

Never jump on or off the machine. Never mount or dismount a moving machine.

Be careful of slippery conditions on platforms, steps, and handrails when leaving the machine.




PREPARE FOR EMERGENCIES

Be prepared if a fire starts.


Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



PROTECT AGAINST FLYING DEBRIS


Guard against injury from flying pieces of metal or debris; Wear goggles or safety glasses.



PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.


Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



AVOID POWER LINES

Serious injury or death can result from contact with electric lines.


Never move any part of the machine or load closer to electric line than 3m(10ft) plus twice the line insulator length.



KEEP RIDERS OFF EXCAVATOR

Only allow the operator on the excavator. Keep riders off.

Riders on excavator are subject to injury such as being struck by foreign objects and being thrown off the excavator. Riders also obstruct the operator's view resulting in the excavator being operated in an unsafe manner.




MOVE AND OPERATE MACHINE SAFELY

Bystanders can be run over. Know the location of bystanders before moving, swinging, or operating the machine.

Always keep the travel alarm in working condition. It warns people when the excavator starts to move.

Use a signal person when moving, swinging, or operating the machine in congested areas. Coordinate hand signals before starting the excavator.



OPERATE ONLY FORM OPERATOR'S SEAT

Avoid possible injury machine damage. Do not start engine by shorting across starter terminals.

NEVER start engine while standing on ground. Start engine only from operator's seat.



PARK MACHINE SAFELY

Before working on the machine:


- · Park machine on a level surface.
- · Lower bucket to the ground.
- · Turn auto idle switch off.
- · Run engine at low idle speed without load for 5 minutes.
- Turn key switch to OFF to stop engine. Remove key from switch.
- · Place safety lever to locked position.
- · Allow engine to cool.

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load.


Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands.



HANDLE FLUIDS SAFELY-AVOID FIRES

Handle fuel with care; It is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks. Always stop engine before refueling machine.


Fill fuel tank outdoors.



Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; They can ignite and burn spontaneously.



BEWARE OF EXHAUST FUMES

Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.

If you must operate in a building, be positive there is adequate ventilation. Either use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring enough outside air into the area.

REMOVE PAINT BEFORE WELDING OR HEATING

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:


· If you sand or grind paint, avoid breathing the dust.


Wear an approved respirator.

· If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.






SERVICE MACHINE SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.


Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



STAY CLEAR OF MOVING PARTS

Entanglements in moving parts can cause serious injury.

To prevent accidents, use care when working around rotating parts.




AVOID HIGH PRESSURE FLUIDS


Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.





AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials.

Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area. Install fire resisting guards to protect hoses or other materials.



PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and flame away from the top of battery.

Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; It may explode. Warm battery to 16° C (60° F).



PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

- 1. Filling batteries in a well-ventilated area.
- 2. Wearing eye protection and rubber gloves.
- 3. Avoiding breathing fumes when electrolyte is added.
- 4. Avoiding spilling of dripping electrolyte.
- 5. Use proper jump start procedure.

If you spill acid on yourself:

- 1. Flush your skin with water.
- 2. Apply baking soda or lime to help neutralize the acid.
- 3. Flush your eyes with water for 10-15 minutes.
 - Get medical attention immediately.

If acid is swallowed:

- 1. Drink large amounts of water or milk.
- 2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
- 3. Get medical attention immediately.

USE TOOLS PROPERLY


Use tools appropriate to the work. Makeshift tools, parts, and procedures can create safety hazards.


Use power tools only to loosen threaded tools and fasteners.

For loosening and tightening hardware, use the correct size tools.

DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only recommended replacement parts. (See Parts manual.)






DISPOSE OF FLUIDS PROPERLY

Improperly disposing of fluids can harm the environment and ecology. Before draining any fluids, find out the proper way to dispose of waste from your local environmental agency.


Use proper containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

DO NOT pour oil into the ground, down a drain, or into a stream, pond, or lake. Observe relevant environmental protection regulations when disposing of oil, fuel, coolant, brake fluid, filters, batteries, and other harmful waste.



REPLACE SAFETY LABELS

Replace missing or damaged safety labels. See the machine operator's manual for correct safety label placement.





LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.

GROUP 2 SPECIFICATIONS

1. MAJOR COMPONENT






160A2SP01


2. SPECIFICATIONS

1) HX130A LCR, MONO BOOM




		Unit		Specification	
Description		Boom		4.3 (14' 1")	
Description		m (ft-in) Arm	2.26 (7' 5")	1.96 (6' 5")	2.81 (9' 3")
		mm (in) Shoe		600 (24)	
Operating weight		kg (lb)	13445 (29640)	13415 (29570)	13510 (29780)
Overall length	Α		6850 (22' 6")	6820 (22' 5")	6805 (22' 4")
Overall width	В		2590 (8' 6")	2590 (8' 6")	2590 (8' 6")
Overall width with add footboard	В'		2590 (8' 6")	2590 (8' 6")	2590 (8' 6")
Overall height of boom	С		2760 (9' 1")	2570 (8' 5")	3080 (10' 1")
Overall width of upper structure	D		2485 (8' 2")	2485 (8' 2")	2485 (8' 2")
Overall height of cab	Е		2860 (9' 5")	2860 (9' 5")	2860 (9' 5")
Ground clearance of counterweight	F		900 (2' 11")	900 (2' 11")	900 (2' 11")
Overall height of engine hood	G		2035 (6' 8")	2035 (6' 8")	2035 (6' 8")
Overall height of handrail	G'		3080 (10' 1")	3080 (10' 1")	3080 (10' 1")
Minimum ground clearance	Н	mm (ft-in)	435 (1' 5")	435 (1' 5")	435 (1' 5")
Rear-end distance	1		1520 (5' 0")	1520 (5' 0")	1520 (5' 0")
Rear-end swing radius	ľ		1520 (5' 0")	1520 (5' 0")	1520 (5' 0")
Distance between tumblers	J		2780 (9' 1")	2780 (9' 1")	2780 (9' 1")
Undercarriage length (without grouser)	K		3457 (11' 4")	3457 (11' 4")	3457 (11' 4")
Undercarriage length (with grouser)	K		3497 (11'6")	3497 (11' 6")	3497 (11' 6")
Undercarriage width	L		2590 (8' 6")	2590 (8' 6")	2590 (8' 6")
Undercarriage width with add footboard	L		2590 (8' 6")	2590 (8' 6")	2590 (8' 6")
Track gauge	М		1990 (6' 6")	1990 (6' 6")	1990 (6' 6")
Track shoe width, standard	Ν		600 (2' 0")	600 (2' 0")	600 (2' 0")
Track shoe link quantity		EA	43	43	43
Travel speed (low/high)		km/hr (mph)	3.0 / 5.2 (1.9/3.2)	3.0 / 5.2 (1.9/3.2)	3.0 / 5.2 (1.9/3.2)
Swing speed		rpm	12.4	12.4	12.4
Gradeability		Degree (%)	35 (70)	35 (70)	35 (70)
Ground pressure		kgf/cm² (psi)	0.37 (5.28)	0.37 (5.28)	0.37 (5.31)
Max traction force		kg (lb)	11948 (26340)	11948 (26340)	11948 (26340)

2) HX130A LCR, 2-PIECE BOOM



		Uı	nit	Specif	ication		
Description		(ft :)	Boom	4.56 (1	l4' 11")		
Description		m (ft-in)	Arm	2.26 (7' 5")	1.96 (6' 5")		
		mm (in)	Shoe	600	(24)		
Operating weight		kg	(lb)	14230 (31370)	14202 (31310)		
Overall length	Α			7090 (23' 3")	7100 (23' 4")		
Overall width	В			2590 (8' 6")	2590 (8' 6")		
Overall width with add footboard	В'			2590 (8' 6")	2590 (8' 6")		
Overall height of boom	С			3000 (9' 10")	2835 (9' 4")		
Overall width of upper structure	D			2485 (8' 2")	2485 (8' 2")		
Overall height of cab	Е			2860 (9' 5")	2860 (9' 5")		
Ground clearance of counterweight	F			900 (2' 11")	900 (2' 11")		
Overall height of engine hood	G			2035 (6' 8")	2035 (6' 8")		
Overall height of handrail	G'			3080 (10' 1")	3080 (10' 1")		
Minimum ground clearance	Н	mm ((ft-in)	435 (1' 5")	435 (1' 5")		
Rear-end distance	I			1520 (5' 0")	1520 (5' 0")		
Rear-end swing radius	ľ			1520 (5' 0")	1520 (5' 0")		
Distance between tumblers	J			2780 (9' 1")	2780 (9' 1")		
Undercarriage length (without grouser)	K			3457 (11' 4")	3457 (11' 4")		
Undercarriage length (with grouser)	K'			3497 (11' 6")	3497 (11' 6")		
Undercarriage width	L			2590 (8' 6")	2590 (8' 6")		
Undercarriage width with add footboard	L'			2590 (8' 6")	2590 (8' 6")		
Track gauge	М			1990 (6' 6")	1990 (6' 6")		
Track shoe width, standard	Ν			600 (2' 0")	600 (2' 0")		
Track shoe link quantity		Е	Α	43	43		
Travel speed (low/high)		km/hr	(mph)	3.0 / 5.2 (1.9/3.2)	3.0 / 5.2 (1.9/3.2)		
Swing speed		rp	m	12.4	12.4		
Gradeability		Degre	e (%)	35 (70)	35 (70)		
Ground pressure		kgf/cm	n² (psi)	0.39 (5.59)	0.39 (5.58)		
Max traction force		kg	(lb)	11948 (26340)	11948 (26340)		


3) HX130A LCRD, MONO BOOM



130A2SP04

		Ur	nit		Specification	
Description		(# :)	Boom		4.3 (14' 1")	
Description		m (ft-in)	Arm	2.26 (7' 5")	1.96 (6' 5")	2.81 (9' 3")
		mm (in)	Shoe		600 (24)	
Operating weight		kg	(lb)	14275 (31470)	14245 (31400)	14340 (31610)
Overall length	Α			7580 (24' 10")	7550 (24' 9")	7530 (24' 8")
Overall width	В			2590 (8' 6")	2590 (8' 6")	2590 (8' 6")
Overall width with add footboard	В'			2590 (8' 6")	2590 (8' 6")	2590 (8' 6")
Overall height of boom	С			2760 (9' 1")	2570 (8' 5")	3080 (10' 1")
Overall width of upper structure	D			2485 (8' 2")	2485 (8' 2")	2485 (8' 2")
Overall height of cab	Е			2860 (9' 5")	2860 (9' 5")	2860 (9' 5")
Ground clearance of counterweight	F			900 (2' 11")	900 (2' 11")	900 (2' 11")
Overall height of engine hood	G			2035 (6' 8")	2035 (6' 8")	2035 (6' 8")
Overall height of handrail	G'			3080 (10' 1")	3080 (10' 1")	3080 (10' 1")
Minimum ground clearance	Н			260 (0' 10")	260 (0' 10")	260 (0' 10")
Rear-end distance	I	mm /	ft in	1520 (5' 0")	1520 (5' 0")	1520 (5' 0")
Rear-end swing radius	ľ	111111 (mm (ft-in)	1520 (5' 0")	1520 (5' 0")	1520 (5' 0")
Distance between tumblers	J			2780 (9' 1")	2780 (9' 1")	2780 (9' 1")
Undercarriage length (without grouser)	K			3457 (11' 4")	3457 (11' 4")	3457 (11' 4")
Undercarriage length (with grouser)	K'			3497 (11' 6")	3497 (11' 6")	3497 (11' 6")
Undercarriage width	L			2590 (8' 6")	2590 (8' 6")	2590 (8' 6")
Undercarriage width with add footboard	L'			2590 (8' 6")	2590 (8' 6")	2590 (8' 6")
Track gauge	М			1990 (6' 6")	1990 (6' 6")	1990 (6' 6")
Track shoe width, standard	Ν			600 (2' 0")	600 (2' 0")	600 (2' 0")
Height of blade	0			575 (1' 11")	575 (1' 11")	575 (1' 11")
Ground clearance of blade up	Р			550 (1' 10")	550 (1' 10")	550 (1' 10")
Depth of blade down	Q			515 (1' 8")	515 (1' 8")	515 (1' 8")
Track shoe link quantity		E	A	43	43	43
Travel speed (low/high)		km/hr	(mph)	3.0 / 5.2 (1.9/3.2)	3.0 / 5.2 (1.9/3.2)	3.0 / 5.2 (1.9/3.2)
Swing speed	rp	m	12.4	12.4	12.4	
Gradeability	Degre	e (%)	35 (70)	35 (70)	35 (70)	
Ground pressure	kgf/cm	² (psi)	0.39 (5.6)	0.39 (5.59)	0.40 (5.63)	
Max traction force		kg	(lb)	11948 (26340)	11948 (26340)	11948 (26340)


4) HX130A LCRD, 2-PIECE BOOM



		Uı	nit	Specif	ication		
Description		(ft :)	Boom	4.56 (1	4' 11")		
Description		m (ft-in)	Arm	2.26 (7' 5")	1.96 (6' 5")		
		mm (in)	Shoe	600	(24)		
Operating weight		kg	(lb)	15060 (33200)	15035 (33150)		
Overall length	Α			7820 (25' 8")	7820 (25' 8")		
Overall width	В			2590 (8' 6")	2590 (8' 6")		
Overall width with add footboard	В'			2590 (8' 6")	2590 (8' 6")		
Overall height of boom	С			3000 (9' 10")	2835 (9' 4")		
Overall width of upper structure	D			2485 (8' 2")	2485 (8' 2")		
Overall height of cab	Ε			2860 (9' 5")	2860 (9' 5")		
Ground clearance of counterweight	F			900 (2' 11")	900 (2' 11")		
Overall height of engine hood	G			2035 (6' 8")	2035 (6' 8")		
Overall height of handrail	G'			3080 (10' 1")	3080 (10' 1")		
Minimum ground clearance	Н			260 (0' 10")	260 (0' 10")		
Rear-end distance	I	mm	n (ft-in)	1520 (5' 0")	1520 (5' 0")		
Rear-end swing radius	ľ	111111 (1520 (5' 0")	1520 (5' 0")		
Distance between tumblers	J			2780 (9' 1")	2780 (9' 1")		
Undercarriage length (without grouser)	K			3457 (11' 4")	3457 (11' 4")		
Undercarriage length (with grouser)	K'			3497 (11' 6")	3497 (11' 6")		
Undercarriage width	L			2590 (8' 6")	2590 (8' 6")		
Undercarriage width with add footboard	Ľ			2590 (8' 6")	2590 (8' 6")		
Track gauge	М			1990 (6' 6")	1990 (6' 6")		
Track shoe width, standard	Ν			600 (2' 0")	600 (2' 0")		
Height of blade	0			575 (1' 11")	575 (1' 11")		
Ground clearance of blade up	Р			550 (1' 10")	550 (1' 10")		
Depth of blade down	Q			515 (1' 8")	515 (1' 8")		
Track shoe link quantity		Е	A	51	51		
Travel speed (low/high)		km/hr	(mph)	3.0 / 5.2 (1.9/3.2)	3.0 / 5.2 (1.9/3.2)		
Swing speed		rp	m	10.3	10.3		
Gradeability		Degre	e (%)	35 (70)	35 (70)		
Ground pressure		kgf/cm	² (psi)	0.42 (5.92)	0.42 (5.9)		
Max traction force		kg	(lb)	11948 (26340)	11948 (26340)		

3. WORKING RANGE AND DIGGING FORCE

1) HX130A LCR/LCRD, MONO BOOM




130A2SP06

Description	m (ft in)	Boom		4.3 (14' 1")		
Description	m (ft-in)	Arm	2.26 (7' 5")	1.96 (6' 5")	2.81 (9' 3")	
Max digging reach		Α	7745 (25' 5")	7470 (24' 6")	8270 (27' 2")	
Max digging reach on ground		A'	7600 (24' 11")	7310 (24' 0")	8140 (26' 8")	
Max digging depth		В	5090 (16' 8")	4790 (15' 9")	5640 (18' 6")	
Max digging depth (8 ft level)	mm (ft-in)	B'	4860 (15' 11")	4530 (14' 10")	5450 (17' 11")	
Max vertical wall digging depth		С	4630 (15' 2")	4330 (14' 2")	5170 (17' 0")	
Max digging height		D	8165 (26' 9")	7975 (26' 2")	8540 (28' 0")	
Max dumping height		Е	5710 (18' 9")	5530 (18' 2")	6090 (20' 0")	
Min swing radius		F	2340 (7' 8")	2275 (7' 6")	2470 (8' 1")	
	kN		83.5 [91]	83.2 [90.7]	83.5 [91]	
	kgf	SAE	8510 [9280]	8480 [9250]	8510 [9280]	
Dualest diaging force	lbf		18761 [20459]	18695 [20393]	18761 [20459]	
Bucket digging force	kN		98 [106.9]	97.6 [106.4]	98 [106.9]	
	kgf	ISO	9990 [10900]	9950 [10850]	9990 [10900]	
	lbf		22024 [24030]	21936 [23920]	22024 [24030]	
	kN		55 [60]	59.4 [64.8]	47.6 [51.9]	
	kgf	SAE	5610 [6120]	6055 [6610]	4850 [5290]	
Arm diaging force	lbf		12368 [13492]	13349 [14573]	10692 [11662]	
Arm digging force	kN		57.7 [62.9]	62.4 [68.1]	49.4 [53.9]	
	kgf	ISO	5880 [6410]	6360 [6940]	5040 [5500]	
	lbf		12963 [14132]	14021 [15300]	11111 [12125]	

[]: Power boost

2) HX130A LCR/LCRD, 2-PIECE BOOM



130A2SP07

Description	m (ft in)	Boom	4.56 (1	4' 11")
Description	m (ft-in)	Arm	2.26 (7' 5")	1.96 (6' 5")
Max digging reach		Α	8060 (26' 5")	7770 (25' 6")
Max digging reach on ground		A'	7920 (26' 0")	7630 (25' 0")
Max digging depth		В	5280 (17' 4")	4980 (16' 4")
Max digging depth (8 ft level)	mm (ft in)	B'	5160 (16' 11")	4860 (15' 11")
Max vertical wall digging depth	mm (ft-in)	С	4680 (15' 4")	4370 (14' 4")
Max digging height		D	8880 (29' 2")	8650 (28' 5")
Max dumping height		Е	6390 (21' 0")	6160 (20' 3")
Min swing radius		F	2430 (8' 0")	2220 (7' 3")
	kN		83.5 [91]	83.2 [90.7]
	kgf	SAE	8510 [9280]	8480 [9250]
Bucket digging force	lbf		18761 [20459]	18695 [20393]
Bucket digging force	kN		98 [106.9]	97.6 [106.4]
	kgf	ISO	9990 [10900]	9950 [10850]
	lbf		22024 [24030]	21936 [23920]
	kN		55 [60]	59.4 [64.8]
	kgf	SAE	5610 [6120]	6055 [6610]
Arm digging force	lbf		12368 [13492]	13349 [14573]
Arm digging force	kN		57.7 [62.9]	62.4 [68.1]
	kgf	ISO	5880 [6410]	6360 [6940]
	lbf		12963 [14132]	14021 [15300]

[]: Power boost

4. WEIGHT

ltono	Qty	HX130	A LCR	HX130/	A LCRD
ltem	EA	kg	lb	kg	lb
Upperstructure assembly					
· Main frame weld assembly	1	1152	2540	1152	2540
· Engine assembly	1	348	767	348	767
· Aftertreatment assy	1	30	66	30	66
· Main pump assembly	1	88	194	88	194
· Main control valve assembly	1	140	309	140	309
· Swing motor assembly	1	130	287	130	287
· Hydraulic oil tank WA	1	182	402	182	402
· Fuel tank WA	1	162	357	162	357
· Counterweight	1	2100	4630	2100	4630
· Cab assembly	1	450	992	450	992
Lower chassis assembly			I		
Track frame weld assembly	1	1226	2703	1365	3009
· Dozer blade assembly	1	-	-	475	1047
· Swing bearing	1	262	578	262	578
Travel motor assembly	2	278	613	278	613
· Turning joint	1	59	130	59	130
· Sprocket	2	40	87	40	87
· Track recoil spring	2	93	206	93	206
· Idler	2	108	238	108	238
· Upper roller	2	12	27	12	27
· Lower roller	12	25	54	25	54
· Track Guard	2	31	68	31	68
· Track-chain assembly (500 mm, 43 link)	2	716	1579	716	1579
· Track-chain assembly (600 mm, 43 link)	2	796	1754	796	1754
· Track-chain assembly (700 mm, 43 link)	2	875	1929	875	1929
· Track-chain assembly (600 mm, 43 link)-HW	2	960	2116	960	2116
· Track-chain assembly (700 mm, 43 link)-HW	2	1058	2332	1058	2332
· Track-chain assembly (500 mm, 43 link)-rubber pad	2	793	1749	793	1749
Front attachment assembly					-
· 4.3 m mono boom assembly	1	702	1548	702	1548
· 4.56 m 2-piece boom assembly	1	986	2173	986	2173
· 2.26 m arm assembly	1	364	803	364	803
· 1.96 m arm assembly	1	337	743	337	743
· 2.81 m arm assembly	1	427	941	427	941
· 2.26 m arm assembly (w/o reinforce)	1	356	785	356	785
· 2.81 m arm assembly (w/o reinforce)	1	419	923	419	923
· 0.58 m³ bucket assembly	1	439	967	439	967
· 0.50 m³ bucket assembly	1	422	931	425	936
· 0.61 m³ bucket assembly	1	474	1045	422	931
· 0.50 m³ bucket assembly	1	425	936	474	1045
· 0.59 m³ bucket assembly	1	473	1043	473	1043
Boom cylinder assembly	2	98	216	98	216
· Arm cylinder assembly	1	118	260	118	260
Bucket cylinder assembly	1	96	212	96	212
· 2-piece boom cylinder assembly	1	170	375	170	375
Dozer cylinder assembly	2	53	117	53	117
Bucket control linkage total	1	112	247	112	247
This information is different with an arcting and transportation		haaayaa it ia			

^{*} This information is different with operating and transportation weight because it is not including harness, pipe, oil, fuel so on.

 $[\]ensuremath{\,{\times}\,}$ Refer to Transportation for actual weight information and Specifications for operating weight.


5. LIFTING CAPACITIES

1) HX130A LCR MONO BOOM

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCR	BOOM	4300	1960	2100	600	-	-	-	-	-

· P : Rating over-front

· 🖶 : Rating over-side or 360 degree



					Lift-noint	radius (B)				Δτ	max. rea	ch
				'	Liit poirit i	adido (D)				710	max. rea	011
Lift-po		1.5 m	(4.9 ft)	3.0 m (9.8 ft)		4.5 m (14.8 ft)		6.0 m (19.7 ft)		Capa	acity	Reach
height	(A)	Ů				H	#		#	Ů		m (ft)
6.0 m	kg									*2620	*2620	4.21
(19.7 ft)	lb									*5780	*5780	(13.8)
4.5 m	kg					*3340	3060			*2310	2240	5.42
(14.8 ft)	lb					*7360	6750			*5090	4940	(17.8)
3.0 m	kg			*5290	*5290	*3920	2930	*2450	1860	*2270	1850	6.03
(9.8 ft)	lb			*11660	*11660	*8640	6460	*5400	4100	*5000	4080	(19.8)
1.5 m	kg			*7380	5000	4080	2760	2630	1810	*2390	1720	6.22
(4.9 ft)	lb			*16270	11020	8990	6080	5800	3990	*5270	3790	(20.4)
0.0 m	kg			*7210	4820	3950	2650	2590	1780	2570	1760	6.04
(0.0 ft)	lb			*15900	10630	8710	5840	5710	3920	5670	3880	(19.8)
-1.5 m	kg	*5310	*5310	7800	4820	3930	2620			2980	2030	5.44
(-4.9 ft)	lb	*11710	*11710	17200	10630	8660	5780			6570	4480	(17.9)
-3.0 m	kg			*6500	4950					*4350	2940	4.26
(-9.8 ft)	lb			*14330	10910					*9590	6480	(14.0)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.


The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outr	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCR	BOOM	4300	1960	2450	600	-	-	-	-	-

· 🖟 : Rating over-front

· 🖶 : Rating over-side or 360 degree



					Lift-point r	adius (B)				At	max. rea	ch
Lift-po		1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ		ŀ		U				Ů		m (ft)
6.0 m	kg									*2620	*2620	4.21
(19.7 ft)	lb									*5780	*5780	(13.8)
4.5 m	kg					*3340	3240			*2310	*2310	5.42
(14.8 ft)	lb					*7360	7140			*5090	*5090	(17.8)
3.0 m	kg			*5290	*5290	*3920	3110	*2450	1990	*2270	1980	6.03
(9.8 ft)	lb			*11660	*11660	*8640	6860	*5400	4390	*5000	4370	(19.8)
1.5 m	kg			*7380	5320	4300	2940	2790	1940	*2390	1840	6.22
(4.9 ft)	lb			*16270	11730	9480	6480	6150	4280	*5270	4060	(20.4)
0.0 m	kg			*7210	5140	4180	2830	2750	1900	2720	1880	6.04
(0.0 ft)	lb			*15900	11330	9220	6240	6060	4190	6000	4140	(19.8)
-1.5 m	kg	*5310	*5310	*7920	5140	4150	2800			3160	2170	5.44
(-4.9 ft)	lb	*11710	*11710	*17460	11330	9150	6170			6970	4780	(17.9)
-3.0 m	kg			*6500	5270					*4350	3130	4.26
(-9.8 ft)	lb			*14330	11620					*9590	6900	(14.0)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.


The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outr	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCR	BOOM	4300	2260	2100	600	-	-	-	-	-

· Pating over-front

· 🖶 : Rating over-side or 360 degree



					Lift-point i	radius (B)				At	max. rea	ch
Lift-po	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)											m (ft)
6.0 m	kg					*2730	*2730			*2360	*2360	4.62
(19.7 ft)	lb					*6020	*6020			*5200	*5200	(15.1)
4.5 m	kg					*3070	*3070			*2110	2050	5.74
(14.8 ft)	lb					*6770	*6770			*4650	4520	(18.8)
3.0 m	kg			*4770	*4770	*3690	2950	2700	1880	*2070	1720	6.31
(9.8 ft)	lb			*10520	*10520	*8140	6500	5950	4140	*4560	3790	(20.7)
1.5 m	kg			*7100	5060	4090	2770	2630	1810	*2180	1600	6.50
(4.9 ft)	lb			*15650	11160	9020	6110	5800	3990	*4810	3530	(21.3)
0.0 m	kg			*7500	4810	3950	2640	2580	1760	2390	1640	6.32
(0.0 ft)	lb			*16530	10600	8710	5820	5690	3880	5270	3620	(20.7)
-1.5 m	kg	*4830	*4830	7750	4780	3900	2600			2730	1860	5.76
(-4.9 ft)	lb	*10650	*10650	17090	10540	8600	5730			6020	4100	(18.9)
-3.0 m	kg	*9240	*9240	*6920	4890	3970	2670			3780	2550	4.66
(-9.8 ft)	lb	*20370	*20370	*15260	10780	8750	5890			8330	5620	(15.3)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.


The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outr	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCR	BOOM	4300	2260	2450	600	-	-	-	-	-

· 🖟 : Rating over-front

· 🖶 : Rating over-side or 360 degree



				-	Lift-point i	adius (B)				At	max. rea	ch
Lift-po	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	·		U	#	!	#	U		m (ft)
6.0 m	kg					*2730	*2730			*2360	*2360	4.62
(19.7 ft)	lb					*6020	*6020			*5200	*5200	(15.1)
4.5 m	kg					*3070	*3070			*2110	*2110	5.74
(14.8 ft)	lb					*6770	*6770			*4650	*4650	(18.8)
3.0 m	kg			*4770	*4770	*3690	3130	2860	2000	*2070	1840	6.31
(9.8 ft)	lb			*10520	*10520	*8140	6900	6310	4410	*4560	4060	(20.7)
1.5 m	kg			*7100	5380	4320	2950	2790	1940	*2180	1720	6.50
(4.9 ft)	lb			*15650	11860	9520	6500	6150	4280	*4810	3790	(21.3)
0.0 m	kg			*7500	5130	4170	2820	2730	1890	*2460	1750	6.32
(0.0 ft)	lb			*16530	11310	9190	6220	6020	4170	*5420	3860	(20.7)
-1.5 m	kg	*4830	*4830	*8060	5100	4130	2780			2890	1990	5.76
(-4.9 ft)	lb	*10650	*10650	*17770	11240	9110	6130			6370	4390	(18.9)
-3.0 m	kg	*9240	*9240	*6920	5200	4200	2850			3990	2720	4.66
(-9.8 ft)	lb	*20370	*20370	*15260	11460	9260	6280			8800	6000	(15.3)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.


The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCR	BOOM	4300	2810	2100	600	-	-	-	-	-

· 🖟 : Rating over-front

· 🖶 : Rating over-side or 360 degree



					Lift-point i	radius (B)				At	max. rea	ch
Lift-po		1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	U		U	#	U	#	ŀ	#	m (ft)
6.0 m	kg					*2480	*2480			*1770	*1770	5.34
(19.7 ft)	lb					*5470	*5470			*3900	*3900	(17.5)
4.5 m	kg					*2560	*2560	*2380	1940	*1610	*1610	6.33
(14.8 ft)	lb					*5640	*5640	*5250	4280	*3550	*3550	(20.8)
3.0 m	kg			*3790	*3790	*3210	3000	2720	1890	*1590	1500	6.86
(9.8 ft)	lb			*8360	*8360	*7080	6610	6000	4170	*3510	3310	(22.5)
1.5 m	kg			*6250	5190	4120	2800	2630	1810	*1660	1410	7.03
(4.9 ft)	lb			*13780	11440	9080	6170	5800	3990	*3660	3110	(23.1)
0.0 m	kg			7800	4820	3940	2630	2560	1740	*1840	1420	6.87
(0.0 ft)	lb			17200	10630	8690	5800	5640	3840	*4060	3130	(22.5)
-1.5 m	kg	*4140	*4140	7680	4720	3860	2560	2520	1710	*2220	1580	6.35
(-4.9 ft)	lb	*9130	*9130	16930	10410	8510	5640	5560	3770	*4890	3480	(20.8)
-3.0 m	kg	*7280	*7280	*7470	4770	3880	2580			2990	2020	5.38
(-9.8 ft)	lb	*16050	*16050	*16470	10520	8550	5690			6590	4450	(17.6)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.


The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outr	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCR	BOOM	4300	2260	2450	600	-	-	-	-	-

· Pating over-front

· 🖶 : Rating over-side or 360 degree



					Lift-point i	radius (B)				At	max. rea	ch
Lift-po		1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	·		ŀ	#	!	#	!		m (ft)
6.0 m	kg					*2480	*2480			*1770	*1770	5.34
(19.7 ft)	lb					*5470	*5470			*3900	*3900	(17.5)
4.5 m	kg					*2560	*2560	*2380	2060	*1610	*1610	6.33
(14.8 ft)	lb					*5640	*5640	*5250	4540	*3550	*3550	(20.8)
3.0 m	kg			*3790	*3790	*3210	3180	2870	2020	*1590	*1590	6.86
(9.8 ft)	lb			*8360	*8360	*7080	7010	6330	4450	*3510	*3510	(22.5)
1.5 m	kg			*6250	5510	*4150	2980	2790	1930	*1660	1510	7.03
(4.9 ft)	lb			*13780	12150	*9150	6570	6150	4250	*3660	3330	(23.1)
0.0 m	kg			*7830	5140	4170	2810	2710	1860	*1840	1530	6.87
(0.0 ft)	lb			*17260	11330	9190	6190	5970	4100	*4060	3370	(22.5)
-1.5 m	kg	*4140	*4140	8120	5030	4080	2730	2680	1830	*2220	1700	6.35
(-4.9 ft)	lb	*9130	*9130	17900	11090	8990	6020	5910	4030	*4890	3750	(20.8)
-3.0 m	kg	*7280	*7280	*7470	5090	4110	2750			*3120	2170	5.38
(-9.8 ft)	lb	*16050	*16050	*16470	11220	9060	6060			*6880	4780	(17.6)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.


Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

2) HX130A LCR 2-PIECE BOOM

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	2-PIECE	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCR	BOOM	4556	1960	2450	600	-	-	-	-	-

· Rating over-front

· 🖶 : Rating over-side or 360 degree



				Lift-point	radius (B)			At	max. rea	ch
Lift-po	int	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Cap	acity	Reach
height	(A)	Ů	#	P	#	H	#	U	#	m (ft)
6.0 m	kg			*3310	3280			*2670	*2670	4.66
(19.7 ft)	lb			*7300	7230			*5890	*5890	(15.3)
4.5 m	kg	*3650	*3650	*3290	3260			*2360	2140	5.77
(14.8 ft)	lb	*8050	*8050	*7250	7190			*5200	4720	(18.9)
3.0 m	kg	*5580	*5580	*3900	3080	2850	1970	*2300	1790	6.34
(9.8 ft)	lb	*12300	*12300	*8600	6790	6280	4340	*5070	3950	(20.8)
1.5 m	kg			4270	2870	2770	1890	*2380	1660	6.53
(4.9 ft)	lb			9410	6330	6110	4170	*5250	3660	(21.4)
0.0 m	kg	*4580	*4580	4120	2740	2700	1840	2500	1700	6.35
(0.0 ft)	lb	*10100	*10100	9080	6040	5950	4060	5510	3750	(20.8)
-1.5 m	kg	*7530	4990	4090	2710			2850	1930	5.79
(-4.9 ft)	lb	*16600	11000	9020	5970			6280	4250	(19.0)
-3.0 m	kg	*6230	5130	*4080	2800					
(-9.8 ft)	lb	*13730	11310	*8990	6170					

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outr	igger
HX130A	2-PIECE	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCR	BOOM	4556	2260	2450	600	-	-	-	-	-

· Pating over-front

· 🖶 : Rating over-side or 360 degree



				Lift-point	radius (B)			At	max. rea	ch
Lift-poi	int	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	·	#		#	P	#	H	#	m (ft)
7.5 m	kg	*3450	*3450					*3330	*3330	3.04
(24.6 ft)	lb	*7610	*7610					*7340	*7340	(10.0)
6.0 m	kg			*2960	*2960			*2400	*2400	5.05
(19.7 ft)	lb			*6530	*6530			*5290	*5290	(16.6)
4.5 m	kg			*3050	*3050	*2580	2030	*2150	1970	6.09
(14.8 ft)	lb			*6720	*6720	*5690	4480	*4740	4340	(20.0)
3.0 m	kg	*5070	*5070	*3690	3120	2860	1980	*2100	1670	6.64
(9.8 ft)	lb	*11180	*11180	*8140	6880	6310	4370	*4630	3680	(21.8)
1.5 m	kg			4290	2890	2770	1900	*2170	1560	6.81
(4.9 ft)	lb			9460	6370	6110	4190	*4780	3440	(22.4)
0.0 m	kg	*4920	*4920	4120	2730	2690	1830	2330	1580	6.65
(0.0 ft)	lb	*10850	*10850	9080	6020	5930	4030	5140	3480	(21.8)
-1.5 m	kg	*7690	4940	4060	2680	2680	1810	2620	1770	6.11
(-4.9 ft)	lb	*16950	10890	8950	5910	5910	3990	5780	3900	(20.1)
-3.0 m	kg	*6600	5060	4130	2740			3460	2340	5.09
(-9.8 ft)	lb	*14550	11160	9110	6040			7630	5160	(16.7)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.


Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

3) HX130A LCRD MONO BOOM

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	BOOM	4300	1960	2100	600	-	Down	-	-	-

· Rating over-front

· 🖶 : Rating over-side or 360 degree



				I	Lift-point I	radius (B)				At	max. rea	ch
Lift-poi		1.5 m ((4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height ((A)	U	#	U		U	#	Ů				m (ft)
6.0 m	kg									*2620	*2620	4.21
(19.7 ft)	lb									*5780	*5780	(13.8)
4.5 m	kg					*3350	*3350			*2310	*2310	5.42
(14.8 ft)	lb					*7390	*7390			*5090	*5090	(17.8)
3.0 m	kg			*5290	*5290	*3930	3370	*2460	2150	*2270	2140	6.03
(9.8 ft)	lb			*11660	*11660	*8660	7430	*5420	4740	*5000	4720	(19.8)
1.5 m	kg			*7360	5870	*4730	3200	*3780	2100	*2390	1990	6.22
(4.9 ft)	lb			*16230	12940	*10430	7050	*8330	4630	*5270	4390	(20.4)
0.0 m	kg			*7220	5680	*5280	3080	*3100	2060	*2730	2050	6.04
(0.0 ft)	lb			*15920	12520	*11640	6790	*6830	4540	*6020	4520	(19.8)
-1.5 m	kg	*5320	*5320	*7920	5690	*5260	3060			*3490	2360	5.44
(-4.9 ft)	lb	*11730	*11730	*17460	12540	*11600	6750			*7690	5200	(17.8)
-3.0 m	kg			*6500	5820					*4350	3420	4.26
(-9.8 ft)	lb			*14330	12830					*9590	7540	(14.0)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.


Lifting capacities will vary with different work tools, ground conditions and attachments.


The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	gger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	BOOM	4300	1960	2100	600	-	Up	-	-	-

· 🖶 : Rating over-side or 360 degree





Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.


Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	BOOM	4300	1960	2450	600	-	Down	-	-	-

· 🖶 : Rating over-side or 360 degree



					Lift-point	radius (B)				At	max. rea	ch
Lift-po	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	P	#	ŀ	#	P	#	U		m (ft)
6.0 m	kg									*2620	*2620	4.21
(19.7 ft)	lb									*5780	*5780	(13.8)
4.5 m	kg					*3350	*3350			*2310	*2310	5.42
(14.8 ft)	lb					*7390	*7390			*5090	*5090	(17.8)
3.0 m	kg			*5290	*5290	*3930	3560	*2460	2280	*2270	*2270	6.03
(9.8 ft)	lb			*11660	*11660	*8660	7850	*5420	5030	*5000	*5000	(19.8)
1.5 m	kg			*7360	6210	*4730	3390	*3780	2230	*2390	2120	6.22
(4.9 ft)	lb			*16230	13690	*10430	7470	*8330	4920	*5270	4670	(20.4)
0.0 m	kg			*7220	6020	*5280	3270	*3100	2190	*2730	2180	6.04
(0.0 ft)	lb			*15920	13270	*11640	7210	*6830	4830	*6020	4810	(19.8)
-1.5 m	kg	*5320	*5320	*7920	6030	*5260	3250			*3490	2510	5.44
(-4.9 ft)	lb	*11730	*11730	*17460	13290	*11600	7170			*7690	5530	(17.8)
-3.0 m	kg			*6500	6160					*4350	3620	4.26
(-9.8 ft)	lb			*14330	13580					*9590	7980	(14.0)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	gger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	BOOM	4300	1960	2450	600	-	Up	-	-	-

· 🖶 : Rating over-side or 360 degree



					Lift-point i	adius (B)				At	max. rea	ch
Lift-po	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	·	#	U	#	P	#	·		m (ft)
6.0 m	kg									*2620	*2620	4.21
(19.7 ft)	lb									*5780	*5780	(13.8)
4.5 m	kg					*3350	*3350			*2310	*2310	5.42
(14.8 ft)	lb					*7390	*7390			*5090	*5090	(17.8)
3.0 m	kg			*5290	*5290	*3930	3290	*2460	2120	*2270	2100	6.03
(9.8 ft)	lb			*11660	*11660	*8660	7250	*5420	4670	*5000	4630	(19.8)
1.5 m	kg			*7360	5640	4260	3120	2760	2070	*2390	1960	6.22
(4.9 ft)	lb			*16230	12430	9390	6880	6080	4560	*5270	4320	(20.4)
0.0 m	kg			*7220	5460	4140	3010	2720	2030	2700	2010	6.04
(0.0 ft)	lb			*15920	12040	9130	6640	6000	4480	5950	4430	(19.8)
-1.5 m	kg	*5320	*5320	*7920	5470	4110	2990			3130	2320	5.44
(-4.9 ft)	lb	*11730	*11730	*17460	12060	9060	6590			6900	5110	(17.8)
-3.0 m	kg			*6500	5600					*4350	3330	4.26
(-9.8 ft)	lb			*14330	12350					*9590	7340	(14.0)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.


The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	BOOM	4300	2260	2100	600	-	Down	-	-	-

· Pating over-front

· 🖶 : Rating over-side or 360 degree



					Lift-point	radius (B)				At	max. rea	ch
Lift-po	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	U		ŀ	#	·	#	·	#	m (ft)
6.0 m	kg					*2740	*2740			*2350	*2350	4.62
(19.7 ft)	lb					*6040	*6040			*5180	*5180	(15.2)
4.5 m	kg					*3070	*3070			*2110	*2110	5.74
(14.8 ft)	lb					*6770	*6770			*4650	*4650	(18.8)
3.0 m	kg			*4780	*4780	*3690	3390	*3300	2170	*2070	1990	6.31
(9.8 ft)	lb			*10540	*10540	*8140	7470	*7280	4780	*4560	4390	(20.7)
1.5 m	kg			*7110	5930	*4540	3210	*3650	2100	*2180	1860	6.50
(4.9 ft)	lb			*15670	13070	*10010	7080	*8050	4630	*4810	4100	(21.3)
0.0 m	kg			*7510	5670	*5180	3080	*3900	2050	*2460	1910	6.32
(0.0 ft)	lb			*16560	12500	*11420	6790	*8600	4520	*5420	4210	(20.7)
-1.5 m	kg	*4840	*4840	*8060	5640	*5300	3030			*3070	2160	5.76
(-4.9 ft)	lb	*10670	*10670	*17770	12430	*11680	6680			*6770	4760	(18.9)
-3.0 m	kg	*9260	*9260	*6910	5750	*4440	3100			*4180	2960	4.66
(-9.8 ft)	lb	*20410	*20410	*15230	12680	*9790	6830			*9220	6530	(15.3)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- Lifting capacities are based upon a standard machine conditions.


Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	gger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	BOOM	4300	2260	2100	600	-	Up	-	-	-

· 🖶 : Rating over-side or 360 degree



					Lift-point	adius (B)				At	max. rea	ch
Lift-po	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	U	#	ŀ	#	y	#	P	#	·	#	m (ft)
6.0 m	kg					*2740	*2740			*2350	*2350	4.62
(19.7 ft)	lb					*6040	*6040			*5180	*5180	(15.2)
4.5 m	kg					*3070	*3070			*2110	*2110	5.74
(14.8 ft)	lb					*6770	*6770			*4650	*4650	(18.8)
3.0 m	kg			*4780	*4780	*3690	3130	2680	2000	*2070	1840	6.31
(9.8 ft)	lb			*10540	*10540	*8140	6900	5910	4410	*4560	4060	(20.7)
1.5 m	kg			*7110	5380	4050	2950	2610	1940	*2180	1720	6.50
(4.9 ft)	lb			*15670	11860	8930	6500	5750	4280	*4810	3790	(21.3)
0.0 m	kg			*7510	5130	3910	2820	2550	1890	2370	1750	6.32
(0.0 ft)	lb			*16560	11310	8620	6220	5620	4170	5220	3860	(20.7)
-1.5 m	kg	*4840	*4840	7670	5110	3860	2780			2700	1990	5.76
(-4.9 ft)	lb	*10670	*10670	16910	11270	8510	6130			5950	4390	(18.9)
-3.0 m	kg	*9260	*9260	*6910	5210	3940	2850			3750	2720	4.66
(-9.8 ft)	lb	*20410	*20410	*15230	11490	8690	6280			8270	6000	(15.3)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	BOOM	4300	2260	2450	600	-	Down	-	-	-

· 🖶 : Rating over-side or 360 degree



					Lift-point	radius (B)				At	max. rea	ch
Lift-po	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	U		ŀ	#	·	#	y	+	m (ft)
6.0 m	kg					*2740	*2740			*2350	*2350	4.62
(19.7 ft)	lb					*6040	*6040			*5180	*5180	(15.2)
4.5 m	kg					*3070	*3070			*2110	*2110	5.74
(14.8 ft)	lb					*6770	*6770			*4650	*4650	(18.8)
3.0 m	kg			*4780	*4780	*3690	3580	*3300	2300	*2070	*2070	6.31
(9.8 ft)	lb			*10540	*10540	*8140	7890	*7280	5070	*4560	*4560	(20.7)
1.5 m	kg			*7110	6270	*4540	3400	*3650	2230	*2180	1980	6.50
(4.9 ft)	lb			*15670	13820	*10010	7500	*8050	4920	*4810	4370	(21.3)
0.0 m	kg			*7510	6010	*5180	3260	*3900	2180	*2460	2030	6.32
(0.0 ft)	lb			*16560	13250	*11420	7190	*8600	4810	*5420	4480	(20.7)
-1.5 m	kg	*4840	*4840	*8060	5980	*5300	3220			*3070	2300	5.76
(-4.9 ft)	lb	*10670	*10670	*17770	13180	*11680	7100			*6770	5070	(18.9)
-3.0 m	kg	*9260	*9260	*6910	6090	*4440	3290			*4180	3140	4.66
(-9.8 ft)	lb	*20410	*20410	*15230	13430	*9790	7250			*9220	6920	(15.3)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- Lifting capacities are based upon a standard machine conditions.


Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	gger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
	BOOM	4300	2260	2450	600	-	Up	-	-	-

· 🖶 : Rating over-side or 360 degree



					Lift-point i	radius (B)				At	max. rea	ch
Lift-po		1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	H		U	#	U	#	!		m (ft)
6.0 m	kg					*2740	*2740			*2350	*2350	4.62
(19.7 ft)	lb					*6040	*6040			*5180	*5180	(15.2)
4.5 m	kg					*3070	*3070			*2110	*2110	5.74
(14.8 ft)	lb					*6770	*6770			*4650	*4650	(18.8)
3.0 m	kg			*4780	*4780	*3690	3310	2830	2130	*2070	1960	6.31
(9.8 ft)	lb			*10540	*10540	*8140	7300	6240	4700	*4560	4320	(20.7)
1.5 m	kg			*7110	5700	4280	3130	2760	2070	*2180	1830	6.50
(4.9 ft)	lb			*15670	12570	9440	6900	6080	4560	*4810	4030	(21.3)
0.0 m	kg			*7510	5450	4130	3000	2700	2010	*2460	1870	6.32
(0.0 ft)	lb			*16560	12020	9110	6610	5950	4430	*5420	4120	(20.7)
-1.5 m	kg	*4840	*4840	*8060	5420	4090	2960			2860	2120	5.76
(-4.9 ft)	lb	*10670	*10670	*17770	11950	9020	6530			6310	4670	(18.9)
-3.0 m	kg	*9260	*9260	*6910	5530	4160	3030			3960	2900	4.66
(-9.8 ft)	lb	*20410	*20410	*15230	12190	9170	6680			8730	6390	(15.3)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
	BOOM	4300	2810	2100	600	-	Down	-	-	-

· Pating over-front

· 🖶 : Rating over-side or 360 degree



				I	_ift-point :	radius (B)				At	max. rea	ch
Lift-poi		1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height ((A)	y	#	y	#	ŀ	#	U	#	<u> </u>		m (ft)
6.0 m	kg					*2480	*2480			*1770	*1770	5.34
(19.7 ft)	lb					*5470	*5470			*3900	*3900	(17.5)
4.5 m	kg					*2560	*2560	*2380	2230	*1610	*1610	6.33
(14.8 ft)	lb					*5640	*5640	*5250	4920	*3550	*3550	(20.8)
3.0 m	kg			*3800	*3800	*3220	*3220	*2990	2180	*1590	*1590	6.86
(9.8 ft)	lb			*8380	*8380	*7100	*7100	*6590	4810	*3510	*3510	(22.5)
1.5 m	kg			*6260	6070	*4150	3230	*3390	2100	*1660	1640	7.03
(4.9 ft)	lb			*13800	13380	*9150	7120	*7470	4630	*3660	3620	(23.1)
0.0 m	kg			*7840	5680	*4940	3070	*3750	2030	*1840	1670	6.87
(0.0 ft)	lb			*17280	12520	*10890	6770	*8270	4480	*4060	3680	(22.5)
-1.5 m	kg	*4140	*4140	*8160	5580	*5280	2990	*3840	2000	*2220	1850	6.35
(-4.9 ft)	lb	*9130	*9130	*17990	12300	*11640	6590	*8470	4410	*4890	4080	(20.8)
-3.0 m	kg	*7290	*7290	*7460	5630	*4910	3010			*3130	2360	5.38
(-9.8 ft)	lb	*16070	*16070	*16450	12410	*10820	6640			*6900	5200	(17.6)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
	BOOM	4300	2810	2100	600	-	Up	-	-	-

· 🖶 : Rating over-side or 360 degree



					Lift-point	adius (B)				At	max. rea	ch
Lift-po	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	H		U	#	P	#	P		m (ft)
6.0 m	kg					*2480	*2480			*1770	*1770	5.34
(19.7 ft)	lb					*5470	*5470			*3900	*3900	(17.5)
4.5 m	kg					*2560	*2560	*2380	2060	*1610	*1610	6.33
(14.8 ft)	lb					*5640	*5640	*5250	4540	*3550	*3550	(20.8)
3.0 m	kg			*3800	*3800	*3220	3180	2690	2020	*1590	*1590	6.86
(9.8 ft)	lb			*8380	*8380	*7100	7010	5930	4450	*3510	*3510	(22.5)
1.5 m	kg			*6260	5510	4080	2980	2610	1940	*1660	1510	7.03
(4.9 ft)	lb			*13800	12150	8990	6570	5750	4280	*3660	3330	(23.1)
0.0 m	kg			7730	5140	3900	2810	2530	1860	*1840	1530	6.87
(0.0 ft)	lb			17040	11330	8600	6190	5580	4100	*4060	3370	(22.5)
-1.5 m	kg	*4140	*4140	7600	5040	3820	2740	2500	1830	*2220	1700	6.35
(-4.9 ft)	lb	*9130	*9130	16760	11110	8420	6040	5510	4030	*4890	3750	(20.8)
-3.0 m	kg	*7290	*7290	*7460	5100	3840	2760			2970	2170	5.38
(-9.8 ft)	lb	*16070	*16070	*16450	11240	8470	6080			6550	4780	(17.6)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- Lifting capacities are based upon a standard machine conditions.


Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
	BOOM	4300	2810	2450	600	-	Down	-	-	-

· 🖶 : Rating over-side or 360 degree



					Lift-point i	radius (B)				At	max. rea	ch
Lift-poi	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	ŀ	#	H		ŀ	#	U	#	U		m (ft)
6.0 m	kg					*2480	*2480			*1770	*1770	5.34
(19.7 ft)	lb					*5470	*5470			*3900	*3900	(17.5)
4.5 m	kg					*2560	*2560	*2380	2360	*1610	*1610	6.33
(14.8 ft)	lb					*5640	*5640	*5250	5200	*3550	*3550	(20.8)
3.0 m	kg			*3800	*3800	*3220	*3220	*2990	2310	*1590	*1590	6.86
(9.8 ft)	lb			*8380	*8380	*7100	*7100	*6590	5090	*3510	*3510	(22.5)
1.5 m	kg			*6260	*6260	*4150	3420	*3390	2230	*1660	*1660	7.03
(4.9 ft)	lb			*13800	*13800	*9150	7540	*7470	4920	*3660	*3660	(23.1)
0.0 m	kg			*7840	6020	*4940	3260	*3750	2160	*1840	1780	6.87
(0.0 ft)	lb			*17280	13270	*10890	7190	*8270	4760	*4060	3920	(22.5)
-1.5 m	kg	*4140	*4140	*8160	5920	*5280	3180	*3840	2130	*2220	1970	6.35
(-4.9 ft)	lb	*9130	*9130	*17990	13050	*11640	7010	*8470	4700	*4890	4340	(20.8)
-3.0 m	kg	*7290	*7290	*7460	5970	*4910	3200			*3130	2510	5.38
(-9.8 ft)	lb	*16070	*16070	*16450	13160	*10820	7050			*6900	5530	(17.6)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	MONO	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
	BOOM	4300	2810	2450	600	-	Up	-	-	-

· 🖶 : Rating over-side or 360 degree



				I	_ift-point ı	adius (B)				At	max. rea	ch
Lift-poi	int	1.5 m	(4.9 ft)	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height ((A)	y	#	ŀ	#	y	#	P	#	<u> </u>		m (ft)
6.0 m	kg					*2480	*2480			*1770	*1770	5.34
(19.7 ft)	lb					*5470	*5470			*3900	*3900	(17.5)
4.5 m	kg					*2560	*2560	*2380	2190	*1610	*1610	6.33
(14.8 ft)	lb					*5640	*5640	*5250	4830	*3550	*3550	(20.8)
3.0 m	kg			*3800	*3800	*3220	*3220	2850	2140	*1590	*1590	6.86
(9.8 ft)	lb			*8380	*8380	*7100	*7100	6280	4720	*3510	*3510	(22.5)
1.5 m	kg			*6260	5830	*4150	3160	2760	2060	*1660	1610	7.03
(4.9 ft)	lb			*13800	12850	*9150	6970	6080	4540	*3660	3550	(23.1)
0.0 m	kg			*7840	5460	4130	2990	2680	1990	*1840	1640	6.87
(0.0 ft)	lb			*17280	12040	9110	6590	5910	4390	*4060	3620	(22.5)
-1.5 m	kg	*4140	*4140	8040	5360	4040	2920	2650	1960	*2220	1820	6.35
(-4.9 ft)	lb	*9130	*9130	17730	11820	8910	6440	5840	4320	*4890	4010	(20.8)
-3.0 m	kg	*7290	*7290	*7460	5410	4070	2940			*3130	2310	5.38
(-9.8 ft)	lb	*16070	*16070	*16450	11930	8970	6480			*6900	5090	(17.6)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.


Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

4) HX130A LCRD 2-PIECE BOOM

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	2-PIECE	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	BOOM	4556	1960	2456	600	-	Down	-	-	-

· Rating over-front

· 🖶 : Rating over-side or 360 degree



				Lift-point i	radius (B)			At	max. rea	ch
Lift-poi	int	3.0 m ((9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height ((A)	Ů	#	H	#				#	m (ft)
6.0 m	kg			*3310	*3310			*2670	*2670	4.66
(19.7 ft)	lb			*7300	*7300			*5890	*5890	(15.3)
4.5 m	kg	*3650	*3650	*3290	*3290			*2360	*2360	5.77
(14.8 ft)	lb	*8050	*8050	*7250	*7250			*5200	*5200	(18.9)
3.0 m	kg	*5580	*5580	*3900	3540	*3360	2270	*2300	2070	6.34
(9.8 ft)	lb	*12300	*12300	*8600	7800	*7410	5000	*5070	4560	(20.8)
1.5 m	kg			*4670	3320	*3630	2190	*2380	1930	6.53
(4.9 ft)	lb			*10300	7320	*8000	4830	*5250	4250	(21.4)
0.0 m	kg	*4590	*4590	*5130	3190	*3810	2140	*2640	1980	6.35
(0.0 ft)	lb	*10120	*10120	*11310	7030	*8400	4720	*5820	4370	(20.8)
-1.5 m	kg	*7520	5880	*5080	3160			*3220	2250	5.79
(-4.9 ft)	lb	*16580	12960	*11200	6970			*7100	4960	(19.0)
-3.0 m	kg	*6220	6030	*4080	3260					
(-9.8 ft)	lb	*13710	13290	*8990	7190					

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Shoe Wheel Dozer		zer	Outrigge	
HX130A	2-PIECE	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD BOOM		4556	1960	2450	600	-	Up	-	-	-

· 🖶 : Rating over-side or 360 degree



				Lift-point	radius (B)			At	max. rea	ch
Lift-po		3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	U	#	·	#	P	#	U	#	m (ft)
6.0 m	kg			*3310	*3310			*2670	*2670	4.66
(19.7 ft)	lb			*7300	*7300			*5890	*5890	(15.3)
4.5 m	kg	*3650	*3650	*3290	*3290			*2360	2270	5.77
(14.8 ft)	lb	*8050	*8050	*7250	*7250			*5200	5000	(18.9)
3.0 m	kg	*5580	*5580	*3900	3270	2820	2100	*2300	1910	6.34
(9.8 ft)	lb	*12300	*12300	*8600	7210	6220	4630	*5070	4210	(20.8)
1.5 m	kg			4230	3050	2740	2020	*2380	1780	6.53
(4.9 ft)	lb			9330	6720	6040	4450	*5250	3920	(21.4)
0.0 m	kg	*4590	*4590	4080	2920	2680	1960	2470	1820	6.35
(0.0 ft)	lb	*10120	*10120	8990	6440	5910	4320	5450	4010	(20.8)
-1.5 m	kg	*7520	5310	4050	2890			2820	2070	5.79
(-4.9 ft)	lb	*16580	11710	8930	6370			6220	4560	(19.0)
-3.0 m	kg	*6220	5460	*4080	2990					
(-9.8 ft)	lb	*13710	12040	*8990	6590					

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outri	igger
HX130A	2-PIECE	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	LCRD BOOM 4556		2260	2450	600	-	Down	-	-	-

· 🖶 : Rating over-side or 360 degree



				Lift-point	radius (B)			At	max. rea	ch
Lift-po	int	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	·	#		#	P	#	H	#	m (ft)
7.5 m (24.6 ft)	kg lb	*3460 *7630	*3460 *7630					*3330 *7340	*3330 *7340	3.05 (10.0)
6.0 m	kg	7 000	7 000	*2950	*2950			*2400	*2400	5.06
(19.7 ft)	lb			*6500	*6500			*5290	*5290	(16.6)
4.5 m	kg			*3050	*3050	*2590	2330	*2150	*2150	6.09
(14.8 ft)	lb			*6720	*6720	*5710	5140	*4740	*4740	(20.0)
3.0 m	kg	*5080	*5080	*3690	3570	*3200	2280	*2100	1930	6.64
(9.8 ft)	lb	*11200	*11200	*8140	7870	*7050	5030	*4630	4250	(21.8)
1.5 m	kg			*4500	3340	*3520	2200	*2170	1810	6.81
(4.9 ft)	lb			*9920	7360	*7760	4850	*4780	3990	(22.4)
0.0 m	kg	*4930	*4930	*5050	3180	*3760	2120	*2390	1840	6.65
(0.0 ft)	lb	*10870	*10870	*11130	7010	*8290	4670	*5270	4060	(21.8)
-1.5 m	kg	*7690	5830	*5110	3130	*3640	2110	*2870	2070	6.11
(-4.9 ft)	lb	*16950	12850	*11270	6900	*8020	4650	*6330	4560	(20.1)
-3.0 m	kg	*6590	5950	*4410	3190			*3600	2720	5.09
(-9.8 ft)	lb	*14530	13120	*9720	7030			*7940	6000	(16.7)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.


Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

Model	Туре	Boom	Arm	Counterweight	Shoe	Wheel	Do	zer	Outrigger	
HX130A	2-PIECE	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
LCRD	LCRD BOOM 455		2260	2450	600	-	Up	-	-	-

· 🖶 : Rating over-side or 360 degree



				Lift-point i	radius (B)			At	max. rea	ch
Lift-po	int	3.0 m	(9.8 ft)	4.5 m (14.8 ft)	6.0 m (19.7 ft)	Capa	acity	Reach
height	(A)	U	#	ŀ	#	H	#	L	#	m (ft)
7.5 m (24.6 ft)	kg lb	*3460 *7630	*3460 *7630					*3330 *7340	*3330 *7340	3.05 (10.0)
6.0 m	kg			*2950	*2950			*2400	*2400	5.06
(19.7 ft)	lb			*6500	*6500			*5290	*5290	(16.6)
4.5 m	kg			*3050	*3050	*2590	2150	*2150	2090	6.09
(14.8 ft)	lb			*6720	*6720	*5710	4740	*4740	4610	(20.0)
3.0 m	kg	*5080	*5080	*3690	3300	2840	2110	*2100	1780	6.64
(9.8 ft)	lb	*11200	*11200	*8140	7280	6260	4650	*4630	3920	(21.8)
1.5 m	kg			4250	3070	2740	2020	*2170	1660	6.81
(4.9 ft)	lb			9370	6770	6040	4450	*4780	3660	(22.4)
0.0 m	kg	*4930	*4930	4080	2910	2670	1950	2300	1690	6.65
(0.0 ft)	lb	*10870	*10870	8990	6420	5890	4300	5070	3730	(21.8)
-1.5 m	kg	*7690	5260	4020	2860	2660	1940	2590	1900	6.11
(-4.9 ft)	lb	*16950	11600	8860	6310	5860	4280	5710	4190	(20.1)
-3.0 m	kg	*6590	5380	4090	2930			3440	2500	5.09
(-9.8 ft)	lb	*14530	11860	9020	6460			7580	5510	(16.7)

Note 1. Lifting capacity are based on ISO 10567.

- 2. Lifting capacity of the HX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. *Indicates load limited by hydraulic capacity.
- * Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.

The difference between the weight of a work tool attachment must be subtracted.

Consult with your local HD Hyundai Construction Equipment dealer regarding the lifting capacities for specific work tools and attachments.

6. BUCKET SELECTION GUIDE

1) HX130A LCR/LCRD, 2100 kg COUNTERWEIGHT



General bucket

		C	ounterweig	ht			2100 kg			
	Cap	acity	Width				MONO			
Туре	SAE Heaped	CECE heaped	Without side cutter	Weight	Tooth	4.3 m (14' 1") Boom				
	m³ (yd³)	m³ (yd³)	mm (in)	kg (lb)	EA	1.96 m (6' 5") Arm	2.26 m (7' 5") Arm	2.81 m (9' 3") Arm		
	0.50 (0.65)	0.46 (0.60)	762 (30.0")	425 (940)	4	•	•	•		
	0.61 (0.80)	0.56 (0.73)	914 (36.0")	473 (1040)	5	•		•		
General bucket	0.58 (0.76)	0.50 (0.65)	950 (37.4"	438 (970)	5	•	•	•		
	0.50 (0.65)	0.44 (0.58)	900 (35.4")	425 (940)	4	•	•	•		
	0.59 (0.77)	0.52 (0.68)	1050 (41.3")	473 (1040)	5	•	0			

	Applicable for materials with density of 2100 kg/m³ (3500	lb/yd³) or less
	Applicable for materials with density of 1800 kg/m 3 (3000	lb/yd³) or less
	Applicable for materials with density of 1500 kg/m 3 (2500	lb/yd³) or less
	Applicable for materials with density of 1200 kg/m³ (2000	lb/yd³) or less
X	Not recommended	

^{*} These recommendations are for general conditions and average use.

Work tools and ground conditions have effects on machine performance.

Select an optimum combination according to the working conditions and the type of work that is being done.

Consult with your local HD Hyundai Construction Equipment dealer for information on selecting the correct boom—arm—bucket combination.

2) HX130A LCR/LCRD, 2450 kg COUNTERWEIGHT



General bucket

		Co	ounterweig	ıht		2100 kg					
	Cap	acity	Width					MONO			
Туре	SAE Heaped	CECE heaped	Without side cutter	Weight	Tooth	4.3 :	m (14' 1") B	4.56 m (14' 11") Boom			
	m³ (yd³)	m³ (yd³)	mm (in)	kg (lb)	EA	1.96 m (6' 5") Arm	2.26 m (7' 5") Arm	2.81 m (9' 3") Arm	1.96 m (6' 5") Arm	2.26 m (7' 5") Arm	
	0.50 (0.65)	0.46 (0.60)	762 (30.0")	425 (940)	4	•	•	•	•	•	
	0.61 (0.80)	0.56 (0.73)	914 (36.0")	473 (1040)	5	•	•	Ŀ	•		
General bucket	0.58 (0.76)	0.50 (0.65)	950 (37.4"	438 (970)	5	•	•	•	0	•	
	0.50 (0.65)	0.44 (0.58)	900 (35.4")	425 (940)	4	•	•	•	•	•	
	0.59 (0.77)	0.52 (0.68)	1050 (41.3")	473 (1040)	5	•	•		0		

	Applicable for materials with density of 2100 kg/m 3 (3500	lb/yd³) or less
	Applicable for materials with density of 1800 kg/m 3 (3000	lb/yd³) or less
	Applicable for materials with density of 1500 kg/m 3 (2500	lb/yd³) or less
	Applicable for materials with density of 1200 kg/m 3 (2000	lb/yd³) or less
Χ	Not recommended	

^{*} These recommendations are for general conditions and average use.

Work tools and ground conditions have effects on machine performance.

Select an optimum combination according to the working conditions and the type of work that is being done.

Consult with your local HD Hyundai Construction Equipment dealer for information on selecting the correct boom—arm—bucket combination.

7. UNDERCARRIAGE

1) TYPES OF SHOES

Model	Description	Un	it			Triple o	grouser		
IVIOGEI	width	mm	(in)	500	(20")	600	(24")	700	(28")
	Operating weight	kg	(lb)	13265	29240	13445	29640	13605	29990
HX130A	Ground pressure	kgf/cm²	(psi)	0.44	(6.26)	0.37	(5.28)	0.32	(4.58)
LCR	Overall width	mn	n	2490	(8' 2")	2590	(8' 6")	2690	(8' 10")
	Link quantity	EA		4	3	4	3	4	3
	Operating weight	kg	(lb)	14090	31060	14275	31470	14445	31850
HX130A	Ground pressure	kgf/cm²	(psi)	0.47	(6.64)	0.39	(5.60)	0.34	(4.86)
LCRD	Overall width	mm		2490	(8' 2")	2590	(8' 6")	2690	(8' 10")
	Link quantity	EA		43		4	3	43	

Model	Description	Unit		Triple grouser-HW				Rubber pad	
IVIOGEI	width	mm	(in)	600	(24")	700	(28")	500	(20")
	Operating weight	kg	(lb)	13770	30360	13970	30800	13420	29590
HX130A	Ground pressure	kgf/cm²	(psi)	0.38	(5.40)	0.33	(4.71)	0.44	(6.22)
LCR	Overall width	mm		2590	(8' 6")	2690	(8' 10")	2490	(8' 2")
	Link quantity	EA		43		43		43	
	Operating weight	kg	(lb)	14600	32190	14810	32650	14240	31390
HX130A	Ground pressure	kgf/cm²	(psi)	0.40	(5.73)	0.35	(4.98)	0.46	(6.59)
LCRD	Overall width	mn	n	2590	(8' 6")	2690	(8' 10")	2490	(8' 2")
	Link quantity	EA		43		43		43	

2) SELECTION OF TRACK SHOE

Suitable track shoes should be selected according to operating conditions.

Method of selecting shoes

Confirm the category from the list of applications in **table 2**, then use **table 1** to select the shoe. Wide shoes (categories B and C) have limitations on applications. Before using wide shoes, check the precautions, then investigate and study the operating conditions to confirm if these shoes are suitable.

Select the narrowest shoe possible to meet the required flotation and ground pressure. Application of wider shoes than recommendations will cause unexpected problem such as bending of shoes, crack of link, breakage of pin, loosening of shoe bolts and the other various problems.

Table 1

Model	Track shoe	Specification	Category
HX130A LCR LCRD	500 mm triple grouser	Standard	Α
	600 mm triple grouser	Option	В
	700 mm triple grouser	Option	С
	600 mm triple grouser-HW	Option	В
	700 mm triple grouser-HW	Option	С
	500 mm rubber pad	Option	С

Table 2

Category	Applications	Precautions
А	Rocky ground, river beds, normal soil	Travel at low speed on rough ground with large obstacles such as boulders or fallen trees or a wide range of general civil engineering work
В	Normal soil, soft ground	 These shoes cannot be used on rough ground with large obstacles such as boulders or fallen trees Travel at high speed only on flat ground Travel slowly at low speed if it is impossible to avoid going over obstacles
С	Extremely soft ground (swampy ground)	 Use the shoes only in the conditions that the machine sinks and it is impossible to use the shoes of category A or B These shoes cannot be used on rough ground with large obstacles such as boulders or fallen trees Travel at high speed only on flat ground Travel slowly at low speed if it is impossible to avoid going over obstacles

8. SPECIFICATIONS FOR MAJOR COMPONENTS

1) ENGINE

Item	Specification
Maker / Model	Cummins / F3.8
Туре	4-cycle, turbocharged, charge air cooled, electronic controlled diesel engine
Cooling method	Water cooled
Number of cylinders and arrangement	4 cylinders, in-line
Firing order	1-3-4-2
Combustion chamber type	Direct injection type
Cylinder bore × stroke	$102 \times 115 \text{ mm } (4.02" \times 4.53")$
Displacement	3.8 ℓ (229 cu in)
Compression ratio	17.2:1
Gross power	74 Hp (55 kW) at 2200 rpm
Net power	72 Hp (54 kW) at 2200 rpm
Max. power	74 Hp (55 kW) at 2200 rpm
Peak Torque	400 N·m (295 lbf·ft) at 1300 rpm
Engine oil quantity	12 ℓ (3.2 U.S. gal)
Wet weight	348 kg (757 lb)
Starter motor	24 V-4.8 kW
Alternator	24 V-70 A

2) MAIN PUMP

Item	Specification
Туре	Variable displacement tandem axis piston pumps
Capacity	2 × 65 cc/rev
Maximum pressure	350 kgf/cm² (4980 psi)
Maximum pressure (power boost)	380 kgf/cm² (5400 psi)
Rated oil flow	$2\times$ 117 ℓ /min (30.9 U.S. gpm / 25.7 U.K. gpm)
Rated speed	1800 rpm

3) GEAR PUMP

Item	Specification
Туре	Fixed displacement gear pump single stage
Capacity	15 cc/rev
Maximum pressure	40 kgf/cm² (570 psi)
Rated oil flow	27 ℓ /min (7.1 U.S. gpm/5.9 U.K. gpm)

4) MAIN CONTROL VALVE

Item			Specification	
Туре			11 spools two block	
Operating method			Hydraulic pilot system	
Main relief valve pressure			330 kgf/cm² (4700 psi) [360 kgf/cm² (5130 psi)]	
	Boom		380 kgf/cm ² (5410 psi)	
Port relief velve preseure	Auro	LC	380 kgf/cm² (5410 psi)	
Port relief valve pressure	Arm	SC	400 kgf/cm ² (5690 psi)	
	Bucket		380 kgf/cm² (5410 psi)	

[]: Power boost

5) SWING MOTOR

Item	Specification
Туре	Fixed displacement axial piston motor
Capacity	72 cc/rev
Relief pressure	280 kgf/cm² (3990 psi)
Braking system	Automatic, spring applied hydraulic released
Braking torque	640 kgf · m (4629 lbf · ft) over
Brake release pressure	24 kgf/cm² (341 psi)
Reduction gear type	2 - stage planetary

6) TRAVEL MOTOR

Item	Specification
Туре	Variable displacement axial piston motor
Capacity	77/44.5 cc/rev
Relief pressure	350 kgf/cm² (4629 psi)
Braking system	Automatic, spring applied hydraulic released
Braking torque	1779 kgf·m (12868 lbf·ft)
Brake release pressure	12.5~15.9 kgf/cm² (202~239 psi)
Reduction gear type	2-stage planetary

7) CYLINDER

Ite	m	Specification
Boom cylinder	Bore dia × Stroke	Ø100×1015 mm
(mono, 2-piece boom 1st)	Cushion	Extend only
Aura audio da u	Bore dia \times Stroke	Ø110 × 1070 mm
Arm cylinder	Cushion	Extend and retract
Adjust sulinder (2 piece beem)	Bore dia × Stroke	Ø145×613 mm
Adjust cylinder (2-piece boom)	Cushion	-
Adjust been sulinder (2 piece been)	Bore dia × Stroke	Ø100×975 mm
Adjust boom cylinder (2-piece boom)	Cushion	Extend only
Dualist adiaday	Bore dia × Stroke	Ø110 × 855 mm
Bucket cylinder	Cushion	Extend only
De con l'ade	Bore dia × Stroke	Ø100 × 240 mm
Dozer cylinder	Cushion	-

^{*} Discoloration of cylinder rod can occur when the friction reduction additive of lubrication oil spreads on the rod surface.

^{*} Discoloration does not cause any harmful effect on the cylinder performance.

9. RECOMMENDED OILS

HD Hyundai Construction Equipment genuine lubricating oils have been developed to offer the best performance and service life for your equipment. These oils have been tested according to the specifications of HD Hyundai Construction Equipment and, therefore, will meet the highest safety and quality requirements. We recommend that you use only HD Hyundai Construction Equipment genuine lubricating oils and grease officially approved by HD Hyundai Construction Equipment.

		7 i iyandar Oons	and the contract of the contra				
Service		Capacity	Ambient temperature °C(°F)				
point	Kind of fluid		50 -30 -20 -10 0 10 20	30 40			
Politi		ℓ (U.S. gal)	(-58) (-22) (-4) (14) (32) (50) (68)	(86) (104)			
			★SAE 0W-40				
Engine oil pan	Engine oil	12.0 (3.2)	SAE 5W-40				
Oii pari			SAE 15W-40				
			OAL 1300-40				
Swing		3.2 (0.9)	★SAE 75W-90				
drive	Gear oil	3.2 (0.9)	* SAE 75W-90				
Final	Geal Oil	2.3 (0.6)x2	CAT 2014/ 00				
drive		2.3 (0.0)x2	SAE 80W-90				
		- .	★ISO VG 15				
	Hydraulic oil	Tank 96 (25.4) il System 160 (42.3)		- I			
Hydraulic			ISO VG 32				
tank			ISO VG 46, HBHO VG 46*3				
			ISO VG 68				
Fuel tank	Discal final #1	040 (60.4)	★ASTM D975 NO.1				
ruei larik	Diesel fuel ^{★1}	240 (63.4)	ASTM D975 NO.	2			
Litting							
Fitting (grease	Grease	As required	★NLGI NO.1				
nipple)	Circase	As required	NLGI NO.2				
	Mixture of						
Radiator	antifreeze		Ethylene glycol base permanent type (5	0:50)			
(reservoir	and soft		★Ethylene glycol base permanent type (60 : 40)				
tank)	water*2		21 July 201 2000 pointer on 197				

SAE : Society of Automotive Engineers

API : American Petroleum Institute

ISO: International Organization for Standardization

NLGI: National Lubricating Grease Institute

ASTM: American Society of Testing and Material

★ : Cold region (Russia, CIS, Mongolia)

★1: Ultra low sulfur diesel

- sulfur content \leq 15 ppm

★2: Soft water

City water or distilled water

*3 : HD Hyundai Construction Equipment

Bio Hydraulic Oil

- * Using any lubricating oils other than HD Hyundai Construction Equipment genuine products may lead to a deterioration of performance and cause damage to major components.
- * Do not mix HD Hyundai Construction Equipment genuine oil with any other lubricating oil as it may result in damage to the systems of major components.
- * Do not use any engine oil other than that specified above, as it may clog the diesel particulate filter(DPF).
- ** For HD Hyundai Construction Equipment genuine lubricating oils and grease for use in regions with extremely low temperatures, please contact your local HD Hyundai Construction Equipment dealer.


SECTION 2 STRUCTURE AND FUNCTION

Group	1 Pump Device ·····	2-1
Group	2 Main Control Valve	2-21
Group	3 Swing Device	2-52
Group	4 Travel Device ·····	2-63
Group	5 RCV Lever ·····	2-76
Group	6 RCV Pedal	2-83

GROUP 1 PUMP DEVICE


1. STRUCTURE

The pump device consists of main pump, regulator and gear pump.




1) MAIN PUMP (1/2)

The main pump consists of two piston pumps (A1 and A2) and valve block.




111	Drive shaft (F)	272	Pump casing (R)	711	O-ring
113	Drive shaft (R)	312	Valve block	717	O-ring
116	1st Gear	313	Valve plate (R)	723	O-ring
123	Roller bearing	314	Valve plate (L)	724	Square ring
124	Needle bearing	401	Hexagon socket bolt	728	O-ring
127	Bearing spacer	402	Hexagon socket bolt	732	O-ring
141	Cylinder block	406	Hexagon socket bolt	733	O-ring
151	Piston	415	Hexagon socket bolt	734	O-ring
152	Shoe	466	Plug	774	Oil seal
153	Set plate	467	Plug	789	Back up ring
156	Spherical bushing	468	Plug	792	Back up ring
157	Cylinder spring	497	Plug	806	Hexagon head nut
211	Shoe plate	531	Tilting pin	808	Hexagon head nut
212	Swash plate	532	Servo piston	824	Snap ring
214	Tilting bushing	533	Plug (Q min)	886	Spring pin
251	Support	534	Stopper (L)	901	Eye bolt
255	Lock pin	535	Stopper (S)	953	Set screw
261	Seal cover (F)	548	Feed back pin	954	Set screw
263	Seal cover (R)	702	O-ring	981	Name plate
271	Pump casing (F)	710	O-ring	983	Pin


MAIN PUMP (2/2)





04	Gear pump	128	Bearing spacer	711	O-ring
115	Idler shaft	262	Cover	728	O-ring
117	Gear No. 2	326	Gear case	825	Snap ring
118	Gear No. 3	414	Hexagon socket bolt	826	Snap ring
125	Ball bearing	435	Flange socket bolt	885	Spring pin
126	Roller bearing	468	Plug	886	Pin


2) REGULATOR (1/2)













Port	Port name	Port size		
А	Delivery port	SAE 6000 psi 3/4"		
В	Suction port	SAE 2500 psi 2 1/2"		
Pi	Pilot port	PF 1/4-15		
P1	EPPR valve primary port	PF 1/4-13		
P2	Companion delivery port	internal		

REGULATOR (2/2)




079	EPPR valve assembly	624	Spring seat (C)	724	Square ring
412	Hexagon socket screw	625	Outer spring	725	O-ring
413	Hexagon socket screw	626	Inner spring	728	O-ring
418	Hexagon socket screw	627	Adjust stem (C)	730	O-ring
437	Hexagon socket screw	628	Adjust screw (C)	734	O-ring
438	Hexagon socket screw	629	Cover (C)	753	O-ring
439	Hexagon socket screw	630	Lock nut	755	O-ring
466	Plug	631	Sleeve, Pf	757	O-ring
496	Plug	641	Pilot cover (C)	801	Nut
497	Plug	643	Pilot piston	802	Nut
601	Casing	644	Spring seat (Q)	814	Snap ring
611	Feed back lever	645	Adjust stem (Q)	836	Snap ring
612	Lever 1	646	Pilot spring	874	Pin
613	Lever 2	651	Sleeve	875	Pin
614	Center plug	652	Spool	887	Pin
615	Adjust plug	653	Spring seat	897	Pin
616	Plug	654	Return spring	898	Pin
621	Compensator piston	655	Set spring	924	Set screw
622	Piston case	656	Valve casing (B)		
623	Compensator rod	708	O-ring		

3) GEAR PUMP



307	Poppet	353	Drive gear	466	Plug
308	Seat	354	Driven gear	700	Square ring
309	Ring	355	Filter	710	O-ring
310	Spring	361	Front case	725	O-ring
311	Adjusting screw	433	Flange socket bolt	732	O-ring
312	Lock nut	434	Flange socket bolt	850	Snap ring
351	Gear case	435	Flange socket bolt	887	Pin

4) EPPR VALVE ASSY



311	Spool	361	O-ring	802	Seal nut
312	Sleeve	362	O-ring	861	O-ring
324	Spring	363	O-ring	901	Name plate
326	Retainer ring	801	Solenoid	902	Function name plate

2. FUNCTION

1) MAIN PUMP

The pumps may be classified roughly into the rotary group performing a rotary motion and working as the major part of the whole pump function: the swash plate group that varies the delivery rates: and the valve cover group that changes over oil suction and discharge: and the PTO group that transfers drive shaft of gear pump.

(1) Rotary group

The rotary group consists of drive shaft (F) (111), cylinder block (141), piston shoes (151,152), set plate (153), spherical bushing (156) and cylinder spring (157). The drive shaft is supported by bearing (123,124) at its both ends.

The shoe is caulked to the piston to from a spherical coupling. It has a pocket to relieve thrust force generated by loading pressure and to take hydraulic balance so that it slides lightly over the shoe plate (211). The sub group composed by a piston and a shoe is pressed against the shoe plate by the action of the cylinder spring via the set plate and a spherical bushing.


Similarly, the cylinder block is pressed against valve plate (313) by the action of the cylinder spring.

(2) Swash plate group


The swash plate group consists of swash plate (212), shoe plate (211), swash plate support (251), lock pin (255), tilting bushing (214), tilting pin (531) and servo piston (532).

The swash plate is a cylindrical part formed on the opposite side of the sliding surface of the shoe and is supported by the swash support.

If the servo piston moves to the right or left as hydraulic force controlled by the regulator connects to hydraulic chamber located on both sides of the servo piston, the swash plate slides over the swash plate support via the spherical part of the tilting pin to change the tilting angle (α)



21092MP06



140Z92MP09

(3) Valve block group

The valve block group consists of valve block (312), valve plate (313, 314) and spring pin(886).

The valve plate having two kidmey ports is fixed to the valve block and feeds and collects oil to and from the cylinder block. The oil changed over by the valve plate is connected to an external pipeline by way

(4) PTO group

of the valve block.


PTO group consist of 1st gear (116) and 2nd gear (117), 3rd gear (118).


2nd gear and 3rd gear are supported by bearings (125, 126), and it can be mounted to the valve block.

Now, if the drive shaft is driven by a prime mover (electric motor, engine, etc), it rotates the cylinder block via a spline linkage at the same time. If the swash plate is tilted as in Fig (previous page) the pistons arranged in the cylinder block make a reciprocating motion with respect to the cylinder block, while they revolve with the cylinder block.

If you pay attention to a single piston, it performs a motion away from the valve plate (oil sucking process) within 180 degrees, and makes a motion towards the valve plate (oil discharging process) in the rest of 180 degrees. When the swash plate has a tilting angle of zero, the piston makes no stroke and discharges no oil.

Concurrently, the auxiliary pump is driven by gears of PTO.






2) REGULATOR

Regulator consists of the negative flow control, total horse power control and power shift control function.


(1) Negative flow control

By changing the pilot pressure Pi, the pump tilting angle (delivery flow) is regulated arbitrarily, as shown in the figure.

This regulator is of the negative flow control in which the delivery flow Q decreases as the pilot pressure Pi rises. With this mechanism, when the pilot pressure corresponding to the flow required for the work is commanded, the pump discharges the required flow only, and so it does not consume the power uselessly.



① Flow reducing function



As the pilot pressure Pi rises, the pilot piston (643) moves to the right to a position where the force of the pilot spring (646) balances with the hydraulic force.

The groove (A) in the pilot piston is fitted with the pin (875) that is fixed to lever 2 (613). Therefore, when the pilot piston moves, lever 2 rotates around the fulcrum of point B [fixed by the fulcrum plug (614) and pin (875)]. Since the large hole section (C) of lever 2 contains a protruding pin (897) fixed to the feedback lever (611), the pin (897) moves to the right as lever 2 rotates. Since the opposing-flat section (D) of the feedback lever is fitted with the pin (548) fixed by the tilting pin (531) that swings the swash plate, the feedback lever rotates around the fulcrum of point D, as the pin (897) moves.


Since the feedback lever is connected with the spool (652) via the pin (874), the spool moves to the right.

The movement of the spool causes the delivery pressure P1 to connect to port CL through the spool and to be admitted to the large diameter section of the servo piston. The delivery pressure P1 that is constantly admitted to the small diameter section of the servo piston moves the servo piston to the right due to the area difference, resulting in decrease of the tilting angle.

When the servo piston moves to the right, point D also moves to the right. The spool is fitted with the return spring (654) and is tensioned to the left at all times, and so the pin (897) is pressed against the large hole section (C) of lever 2.

Therefore, as point D moves, the feedback lever rotates around the fulcrum of point C, and the spool is shifted to the left. This causes the opening between the sleeve (651) and spool (652) to close slowly, and the servo piston comes to a complete stop when it closes completely.

② Flow increasing function



As the pilot pressure Pi decreases, the pilot piston (643) moves to the left by the action of the pilot spring (646) and causes lever 2 (613) to rotate around the fulcrum of point B. Since the pin (897) is pressed against the large hole section (C) of lever 2 by the action of the return spring (654) via the spool (652), pin (874), and feedback lever (611), the feedback lever rotates around the fulcrum of point D as lever 2 rotates, and shifts the spool to the left. Port CL opens a way to the tank port as the spool moves. This deprives the large diameter section of the servo piston of pressure, and shifts the servo piston to the left by the discharge pressure P1 in the small diameter section, resulting in an increase in the flow rate.

As the servo piston moves, point D also moves to the left, the feedback lever rotates around the fulcrum of point C, and the spool moves to the right till the opening between the spool and sleeve is closed.

3 Adjustment of flow control characteristic


The flow control characteristic can be adjusted with the adjusting screw.


Adjust it by loosening the hexagon nut (801) and by tightening (or loosening) the hexagonal socket head screw (924).

Tightening the screw shifts the control chart to the right as shown in the figure.

* Adjusting value

_ : •			
Speed	Adjustment of flow control characteristic		
	Tightening amount of adjusting screw (924)	Flow control starting pressure change amount	Flow change amount
(min ⁻¹)	(Turn)	(kgf/cm²)	(ℓ /min)
1900	+1/4	+1.4	+7.1





(2) Total horsepower control

The regulator decreases the pump tilting angle (delivery flow) automatically to limit the input torque within a certain value with a rise in the delivery pressure P1 of the self pump and the delivery pressure P2 of the companion pump.

(The input horsepower is constant when the speed is constant.)


Since the regulator is of the simultaneous total horsepower type that operates by the sum of load pressures of the two pumps in the tandem double-pump system, the prime mover is automatically prevented from being overloaded, irrespective of the load condition of the two pumps, when horsepower control is under way.

Since this regulator is of the simultaneous total horsepower type, it controls the tilting angles (displacement volumes) of the two pumps to the same value as represented by the following equation:


Tin =
$$P1 \times q/2JI + P2 \times q/2JI$$

= $(P1+P2) \times q/2JI$

The horsepower control function is the same as the flow control function and is summarized in the following. (For detailed behaviors of respective parts, refer to the section of flow control).



① Overload preventive function




140Z92RG03

When the self pump delivery pressure P1 or the companion pump delivery pressure P2 rises, it acts on the stepped part of the compensating piston (621). It presses the compensating rod (623) to the right till the force of the outer spring (625) and inner spring (626) balances with the hydraulic force. The movement of the compensating rod is transmitted to lever 1 (612) via pin (875).

Lever 1 rotates around the pin (875) (E) fixed to the casing (601).

Since the large hole section (F) of lever 1 contains a protruding pin (897) fixed to the feedback lever (611), the feedback lever rotates around the fulcrum of point D as lever 1 rotates, and then the spool (652) is shifted to the right. As the spool moves, the delivery pressure P1 is admitted to the large diameter section of the servo piston via port CL, causes the servo piston move to the right, reduces the pump delivery, flow rate, and prevents the prime mover from being overloaded. The movement of the servo piston is transmitted to the feedback lever via point D. Then the feedback lever rotates around the fulcrum of point F and the spool is shifted to the left. The spool moves till the opening between the spool (652) and sleeve (651) is closed.

② Flow reset function



140Z92RG04

As the self pump delivery pressure P1 or the companion pump delivery pressure P2 decreases, the compensating rod (623) is pushed back by the action of the springs (625 & 626) to rotate lever 1 (612) around point E. Rotating of lever 1 causes the feedback lever (611) to rotate around the fulcrum of point D and then the spool (652) to move to the left. As a result, port CL opens a way to the tank port.

This causes the servo piston to move to the left and the pump's delivery rate to increase.

The movement of the servo piston is transmitted to the spool by the action of the feedback mechanism to move it till the opening between the spool and sleeve is closed.

3 Low tilting angle (low flow) command preferential function

As mentioned above, flow control and horsepower control tilting angle commands are transmitted to the feedback lever and spool via the large-hole sections (C & F) of levers 1 and 2. However, since sections C and F have the pins (\varnothing 4) protruding from the large hole (\varnothing 8), only the lever lessening the tilting angle contacts the pin (897); the hole (\varnothing 8) in the lever of a larger tilting angle command is freed without contacting the pin (897). Such a mechanical selection method permits preference of the lower tilting angle command of the flow control and horsepower control.

4 Adjustment of input horsepower

Since the regulator is of total cumulative horsepower type, adjust the adjusting screws of both the front and rear pumps, when changing the horsepower set values. The pressure change values by adjustment are based on two pumps pressurized at the same time, and the values will be doubled when only one pump is loaded.


a. Adjustment of outer spring

Adjust it by loosening the hexagon nut (630) and by tightening (or loosening) the adjusting screw C (628).


Tightening the screw shifts the control chart to the right and increases the input horsepower as shown in the figure. Since turning the adjusting screw C (628) by N turns changes the setting of the inner spring (626), return the adjusting stem C (627) by $N \times A$ turns at first. (A=1.73)

* Adjusting value

Speed	Adjustment of input horsepower		
	Tightening amount of adjusting screw (C) (628)	Compensating control starting pressure change amount	Input torque change amount
(min ⁻¹)	(Turn)	(kgf/cm²)	(kgf · m)
1900	+1/4	+15.9	+2.5



140792RG07




b. Adjustment of inner spring

Adjust it by loosening the hexagon nut (802) and by tightening (or loosening) the adjusting stem C (627).


Tightening the screw increases the flow and then the input horsepower as shown in the figure.

* Adjusting value


Speed	Adjustment of input horsepower		
	Tightening amount of adjusting stem (C) (627)	Flow change amount	Input torque change amount
(min ⁻¹)	(Turn)	(\ell /min)	(kgf·m)
1900	+1/4	+3.2	+3.2



140Z92RG08




(3) Power shift control



The set horsepower valve is shifted by varying the command current level of the proportional pressure reducing valve attached to the pump.

Only one proportional pressure reducing valve is provided.

However, the secondary pressure Pf (power shift pressure) is admitted to the horsepower control section of each pump regulator through the pump's internal path to shift it to the same set horsepower level.



This function permits arbitrary setting of the pump output power, thereby providing the optimum power level according to the operating condition.

The power shift pressure Pf controls the set horsepower of the pump to a desired level, as shown in the figure.

As the power shift pressure Pf rises, the compensating rod (623) moves to the right via the pin (898) and compensating piston (621).

This decreases the pump tilting angle and then the set horsepower in the same way as explained in the overload preventive function of the horsepower control. On the contrary, the set horsepower rises as the power shift pressure Pf falls.

(4) Adjustment of maximum and minimum flows

① Adjustment of maximum flow

Adjust it by loosening the hexagon nut (808) and by tightening (or loosening) the set screw (954).

The maximum flow only is adjusted without changing other control characteristics.


Speed	Adjustment of max flow		
	Tightening amount of adjusting screw (954)	Flow change amount	
(min ⁻¹)	(Turn)	(ℓ /min)	
1900	+1/4	-3.0	





Adjust it by loosening the hexagon nut (806) and by tightening (or loosening) the hexagonal socket head set screw (953). Similarly to the adjustment of the maximum flow, other characteristics are not changed.


However, remember that, if tightened too much, the required horsepower during the maximum delivery pressure (or during relieving) may increase.

Speed	Adjustment of min flow		
	Tightening amount of adjusting screw (953)	Flow change amount	
(min -1)	(Turn)	(ℓ /min)	
1900	+1/4	+3.0	











GROUP 2 MAIN CONTROL VALVE

DOZER DOWN

1. STRUCTURE






Mark	Port name	Port size	Tightening torque
Rs	Make up for swing motor	UNF 1 3/16	18 kgf·m (130 lbf·ft)
Pa1 Pb1 Pb1 Pc1 Pd1 Pa20 Pa21 Pb20 Pb21 Pc2 Pb3 Pc3 Pc4 Pc40 Pc41 Pc42 Pd40 Pc41 Pc5 Pc5 Pc5 Pc5 Pc6 (Pd0) Pd6 P0 Paitt P02 P03 P04 P04 P01 P01 P02 P03 P04 P05 P05 P05 P05 P06 P0 P0 P1 P07	Travel left pilot port (BW) Travel left pilot port (FW) Travel right pilot port (FW) Travel right pilot port (BW) Boom up pilot port Boom up confluence pilot port Boom down pilot port Lock valve pilot port (boom) Swing pilot port (RH) Swing pilot port (LH) Arm in confluence pilot port Swing priority pilot port Option A pilot port (breaker) Arm in regeneration cut port Lock valve pilot port Lock valve pilot port (arm) Arm in regen-cut signal selector port	PF 1/4	3.5~3.9 kgf⋅m (25.3~28.2 lbf⋅ft)
Pn1 Pn2	Negative control signal port (P1 port side) Negative control signal port (P2 port side)	PF 3/8	7~8 kgf·m (50.6~57.8 lbf·ft)
A1 B1 C1 D1 B2 C2 D2 B4 A5 B5 C5 D5 C6 D6 P1 P2	Travel motor left side port (BW) Travel motor left side port (FW) Travel motor right side port (FW) Travel motor right side port (BW) Boom rod side port Swing motor port (RH) Swing motor port (LH) Option A port (breaker) Bucket head side port Bucket rod side port Option B port Option B port Option C pilot port (dozer down port) Option C pilot port (dozer up port) Pump port (A2 pump side) Pump port (A1 pump side) Boom head side port	PF 3/4	15~18 kgf·m (109~130 lbf·ft)
C4 D4 DR4	Arm head side port Arm rod side port Drain port (swing logic valve)	PF 1	20~25 kgf·m (115~180 lbf·ft) 1.5~1.9 kgf·m
DR5	Drain port (flow summation)	PF 1/8 SAE 3000, 1 1/2	(10.8~13.7 lbf·ft) 8.5~11.5 kgf·m
T1	Return port	(M12×1.75)	(61.5~83.1 lbf · ft)

130A2MC01

DOZER UP


(in)

1) P2 SPOOL SECTION




- 1 Housing P1
- 31 Plug
- 62 O-ring

2) P1 SPOOL SECTION




- 2 Housing P2
- 54 Socket bolt
- 55 Socket bolt
- 57 Spring washer

3) STRAIGHT TRAVEL AND SUPPLY SECTION



- 3 Straight travel spool assy
- 16 Main relief valve
- 28 Plug
- 30 Plug
- 31 Plug
- 34 Plug
- 42 Plug
- 43 Poppet
- 46 Sleeve
- 47 Piston
- 48 Signal orifice
- 49 Coin type filter
- 50 Pilot A cap
- 51 Pilot B1 cap
- 53 Socket bolt
- 56 Washer
- 61 O-ring
- 62 O-ring
- 65 O-ring
- 69 O-ring
- 72 O-ring
- 77 Back up ring
- 79 Spring


4) TRAVEL RIGHT AND LEFT SECTION



- 4 Travel spool assy
- 17 Overload relief valve
- 28 Plug
- 29 Plug
- 33 Plug
- 36 Plug
- 42 Plug
- 43 Poppet
- 45 Poppet
- 48 Signal orifice
- 49 Coin type filter
- 50 Pilot A cap
- 53 Socket bolt
- 56 Washer
- 58 O-ring
- 63 O-ring
- 64 O-ring
- 69 O-ring
- 72 O-ring
- 73 O-ring
- 78 Back up ring
- 79 Spring
- 81 Spring

140A2MC05


5) SWING AND BOOM 1 SECTION



- 6 Swing spool assy
- 7 Boom 1 spool assy
- 17 Overload relief valve
- 21 Swing logic valve
- 24 Holding valve kit A1
- 26 Holding valve kit B
- 28 Plug
- 29 Plug
- 43 **Poppet**
- 44 **Poppet**
- 50 Pilot A cap
- 53 Socket bolt
- 56 Washer
- 63 O-ring
- 69 O-ring
- 72 O-ring
- 79 Spring
- 80 Spring


130A2MC06

6) SWING PRIORITY AND BOOM 2 AND ARM 2 SECTION



- 8 Swing priority spool assy
- 9 Boom 2 spool assy
- 10 Arm 2 spool assy
- 17 Overload relief valve
- 29 Plua
- 31 Plug
- 32 Plug
- 34 Plug
- 35 Plug
- 44 Poppet
- 50 Pilot A cap
- 51 Pilot B1 cap
- 52 Pilot B2 cap
- 53 Socket bolt
- 56 Washer
- 60 O-ring
- 61 O-ring
- 63 O-ring
- 65 O-ring
- 66 O-ring
- 69 O-ring
- 71 O-ring
- Back up ring
- Back up ring 77
- 80 Spring
- Overload relief valve


7) ARM 1 AND ARM REGEN/ BREAKER SECTION



130A2MC08


- 11 Arm 1 spool assy
- 12 Arm regen spool assy
- 25 Holding valve kit A2
- 26 Holding valve kit B
- 27 Regen block assy
- 28 Plug
- 29 Plug
- Plug 31
- 32 Plug
- 41 Plug
- 43 **Poppet**
- 44 Poppet
- 50 Pilot A cap
- 53 Socket bolt
- 56 Washer
- 58 O-ring
- 59 O-ring
- 62 O-ring
- 63 O-ring
- 67 O-ring
- 69 O-ring
- 72 O-ring
- 80 Spring
- Spring 81
- 83 Plug
- 84 Plug

8) OPTION B AND BUCKET SECTION




- Option B spool assy 13
- Bucket spool assy 14
- Overload relief valve 17
- 18 Overload relief valve
- 22 Bucket stroke limiter
- 23 Option ON/OFF valve
- 28 Plug
- 29 Plug
- 32 Plug
- 38 Plug
- 39 Plug
- 40 Plug 43
- Poppet 50 Pilot A cap
- 51 Pilot B1 cap
- 53 Socket bolt
- Washer 56
- 59 O-ring
- 61 O-ring
- 63 O-ring
- 67 O-ring
- 69 O-ring
- 72 O-ring
- 75 Back up ring
- 76 Back up ring
- 79 Spring

9) OPTION C AND NEGATIVE CONTROL SECTION



- 15 Option C1 spool assy
- 20 Negacon relief valve
- 28 Plug
- 29 Plug
- 32 Plug
- 37 Plug
- 43 Poppet
- 50 Pilot A cap
- 51 Pilot B1 cap
- 53 Socket bolt
- 56 Washer
- 63 O-ring
- 64 O-ring
- 67 O-ring
- 68 O-ring
- 69 O-ring
- 72 O-ring
- 78 Back up ring
- 79 Spring

2. HYDRAULIC CIRCUIT




3. FUNCTION

1) CONTROL IN NEUTRAL


(1) P1 SIDE

The hydraulic fluid from pump A2 flows into the main control valve through the inlet port "P1", pass the straight travel spool into the P1 bypass passage and P1parallel passage.

The hydraulic fluid from the pump A2 is directed to the tank through the bypass passage of spools: travel left, boom 1, arm 2, arm regeneration & option A and bucket, the negative relief valve of P1, tank passage, and the tank port "T1"




SECTION A-A




(2) P2 SIDE

The hydraulic fluid from pump A1 flows into the main control valve through the inlet port "P2", into the P2 bypass passage and P2 parallel passage.

The hydraulic fluid from the pump A1 is directed to the tank through the bypass passage of spools: travel right, swing, boom 2 & swing priority, arm 1, option "B" and option "C" (dozer), the negative relief valve of P2, tank passage and the tank port "T1".






14092MC12


2) TRAVEL OPERATION

(1) TRAVEL FORWARD OPERATION



14092MC18

(2) TRAVEL BACKWARD OPERATION



14092MC17

During the travel forward operation, the hydraulic fluid of the pump A2 is supplied to the travel left motor and the hydraulic fluid of the pump A1 is supplied to the other travel right motor.


The pilot pressure from the pilot control valve is supplied to the spring side of pilot port (pb1, pc1).

And it shifts travel right and left spools in the left direction against springs. Hydraulic fluid from the pump A1 flow into the travel right spool through the bypass passage and hydraulic fluid from the pump A2 flow into the travel left spool through the bypass passage.

Then they are directed to the each travel motor through port A1 and C1. As a result, the travel motors turn and hydraulic fluid returns to the tank passage through the travel spools.

In case of the reverse operation, the operation is similar.

(3) TRAVEL STRAIGHT FUNCTION



14092MC19

This function keeps straight travel in case of simultaneous operation of other actuators (boom, arm, bucket, swing) during a straight travel.

① During travel only:

The hydraulic fluid of the pump A1 is supplied to the travel right motor and the pump A2 is supplied to the travel left motor.

Thus, the machine keep travel straight.

② The other actuator operation during straight travel operation:

When the other actuator spool (s) is selected under straight travel operation, the straight travel spool is moved.

The hydraulic fluid from pump A2 is supplied actuator through P2 and P1 parallel pass and travel motors through orifice at side of straight travel spool.

The hydraulic oil fluid from pump A1 is supplied to travel motors (left/right).

Therefore, the other actuator operation with straight travel operation, hydraulic oil fluid from pump A2 is mainly supplied to actuator, and the hydraulic oil fluid form pump A1 is mainly supplied to travel motors (left/right).

Then the machine keeps straight travel.


3) BOOM OPERATION


(1) BOOM UP OPERATION

During boom up operation, the pilot secondary pressure from RCV is supplied to the port Pa20 of the spring side and shifts the boom 1 spool in the left direction. The bypass passage is shut off by the movement of the boom 1 spool and the hydraulic oil fluid from pump A2 is entered P1 parallel passage and then passes through the load check, bridge passage and boom holding valve then flows into the port A2. Following this it flows into the head side of the boom cylinder. (In this case, the boom holding valve is free flow condition)

At the same time, the pilot pressure from RCV is supplied to the port Pa21 of the spring side of boom 2 and shifts the boom 2 spool. The bypass passage is shut off by the movement of the boom 2 spool and the hydraulic oil fluid from pump A1 entered boom summation passage via the P2 parallel passage, the land of the swing priority spool, notch of the boom 2 spool, arm 2 spool and the check. The flows combine in passage and are directed to port A2 and head side of boom cylinder.

At the same time, the flow from rod side of the boom cylinder return to the boom 1 spool through the port B2. Thereafter it is directed to the hydraulic oil tank through the tank passage.





(2) BOOM DOWN OPERATION

During the boom lowing operation, the pilot pressure from RCV is supplied to the port Pb20 of the spring opposite side and shifts the boom 1 spool in the right direction.


The bypass passage is shut off by the movement of the boom 1 spool and the hydraulic fluid from the pump A2 enters the parallel passage and is directed to the port B2 through the load check. Following this, it flows into the rod side of the boom cylinder.

At the same time, the return flow from the head side of the boom cylinder returns to the port A2 and boom holding valve. And it is directed to the hydraulic oil tank through opened tank passage by movement of the boom 1 spool.

Meanwhile some of return flow is directed to P1 parallel passage through the internal passage of the boom 1 spool. (boom regeneration)

In this case, the holding valve is open condition, for details of the boom holding valve, see page following page.

During the boom lowering operation, the fluid from A1 pump is not summation.




4) HOLDING VALVE OPERATION

(1) HOLDING OPERATION

At neutral condition, the pilot piston chamber is connected to drain port through the pilot port. And the piston "B" is supported with spring "B".

Also, the pressured fluid from actuator entered to inside of the holding valve through the periphery hole of check, crevice of the check and the plug and the periphery hole of plug. Then, this pressured oil pushed the poppet to the poppet seat and the check to the seat of body. So the hydraulic fluid from actuator is not escaped and the actuator is not moved.




(2) RELEASE HOLDING OPERATION

The pilot pressure is supplied to the pilot port for release holding valve and shifts the piston "B" in the left direction against the spring "B", and shifts the poppet in the left direction through piston "B" and piston "A" against spring "B" and shifts the spool in the left side.

At same time, the return fluid from actuator returns to the drain port through the periphery hole of check, crevice of the check and the plug, the periphery hole of the plug, in side of holding valve, crevice of the poppet and the poppet seat, the periphery hole of the poppet seat, crevice of socket and spool and internal passage of spool.

When the poppet is opened, pressure of inside of holding valve is decreased and the return fluid from actuator returns to the tank passage through the notch of spool.



5) BUCKET OPERATION

(1) BUCKET IN OPERATION


During the bucket in operation, the pilot secondary pressure from RCV is supplied to port Pa5 of the spring side and shifts the bucket spool in the left direction.

The bypass passage is shut off by the movement of the bucket spool and the hydraulic fluid from pump A2 entered P1 parallel passage and is directed to the port A5 through the check 1.

At the same time, the hydraulic fluid from P1 bypass passage is directed to the port A5 through the check 2.

Following this it flows into the head side of the bucket cylinder.

The return flow from the rod side of the bucket cylinder returns to the bucket spool through the port B5. Thereafter it is directed to the hydraulic oil tank through the tank passage.



130ZF2MC34


(2) BUCKET OUT OPERATION

During the bucket out operation, the pilot secondary pressure from RCV is supplied to port Pb5 of the spring opposite side and shifts the bucket spool in the right direction.

The bypass passage is shut off by the movement of the bucket spool and the hydraulic fluid from pump A2 entered P1 parallel passage and is directed to the port B5 through the check 1.

At the same time, the hydraulic fluid from P1 bypass passage is directed to the port B5 through the check 2.

The return flow from the head side of the bucket cylinder returns to the hydraulic oil tank through the port A5 and the tank passage.




140L2MC135

(3) BUCKET IN OPERATION WITH BOOM OPERATION

When combined operation, mostly same as previous page but the fluid from P1 bypass passage is empty.

When the boom up and bucket in combined operation, the boom up pilot pressure is supplied the pilot port (P04) of bucket spool stroke limit and the piston is shifted to the right and then the bucket in spool stroke is limited and the open of the bucket in spool is reduced.

Accordingly, the oil of the bucket in spool is reduced and the boom speed up.



6) SWING OPERATION


(1) SWING LEFT & RIGHT OPERATION

During the swing left operation, the pilot secondary pressure from the RCV is supplied to the port Pd2 of the spring side and shift the swing spool in left direction. The bypass passage is shut off by the movement of the swing spool and the hydraulic fluid from pump A1 flows into swing spool through the P2 parallel passage. Then it is directed to swing motor through the port D2.

As the result, swing motor turns and flow from the swing motor returns to the hydraulic oil tank through the port C2, swing spool and the tank passage.

In case of swing right operation, the operation is similar to swing left operation but the pilot secondary pressure from the RCV is supplied to the port Pc2 of the spring opposite side.


Accordingly, the hydraulic fluid from pump A1 flows into swing motor through the port C2 and returns to the hydraulic oil tank through the port D2 and the tank passage.



(2) SWING LEFT OPERATION WITH ARM OR BOOM OPERATION

When combined operation, mostly same as previous page but the fluid from P2 bypass passage is empty.

So only the fluid from parallel passage is supplied to the swing motor. Also, parallel passage is installed the orifice of swing logic valve for supplying the fluid from pump A1 to the boom or the arm operation prior to the swing operation. In case of the swing right operation with arm or boom operation, operation is similar.




7) ARM OPERATION


(1) ARM IN OPERATION

During arm in operation, the pilot secondary pressure from the RCV is supplied to the port Pc40 of spring opposite side and shifts arm 1 spool in the right direction.

The bypass passage is shut off by the movement of the arm 1 spool and the hydraulic oil from the pump A1 flows into the arm cylinder head side through P2 parallel passage, the load check valve, bridge passage and the port C4.

At same time, the pilot secondary pressure from the RCV is supplied to the port Pb3 of spring opposite side and shifts arm 2 spool in the right direction. The bypass passage is shut off by the movement of the arm 2 spool and the hydraulic fluid from the pump A2 flows into the arm summation passage through P1 parallel passage, the check valve, the arm 2 spool and the boom 2 spool. Then it entered the arm cylinder head side with hydraulic fluid from arm 1 spool.






ARM REGENERATION

The return flow from the arm cylinder rod side is pressurized by self weight of arm and so, returns to port D4. The pressurized oil returning to port D4 enters the arm regeneration & breaker spool through the arm holding valve and the arm 1 spool. It is supplied the arm cylinder head through internal passage. This is called the arm regeneration function.

The amount of regeneration fluid is changed by movement of the arm regeneration spool. A few fluids after P2 parallel passage is push piston "C" through the notch of arm regeneration spool and selector spool. At this time, the selector spool is opened by pilot pressure from RCV.

Then, the arm regeneration spool shifts to right side and flow to tank pass increases and regeneration flow decreases. Therefore, pressure of arm cylinder head increases, then, arm regeneration flow decreases.

Furthermore, the arm regeneration cut pressure is supplied to the port Pb4 of spring opposite side and arm regeneration spool is move into the right direction fully. The flow from the arm cylinder rod is returned to the hydraulic oil tank and regeneration function is not activated. (The return fluid is maximum condition)



(2) ARM OUT OPERATION

During arm out operation, the pilot secondary pressure from RCV is supplied to the port Pd40 of spring side and shifts arm 1 spool in the left direction.


The bypass passage is shut off by the movement of the arm 1 spool and the hydraulic fluid from pump A1 flows into arm 1 spool through the P2 parallel passage. Then it enters into the arm cylinder rod side through the load check, bridge passage, arm holding valve and the port D4.


Also, the pilot secondary pressure from RCV is supplied to the port Pd41 of spring side and shifts arm 2 spool in the left direction.

The bypass passage is shut off by the movement of the arm 2 spool and some of the hydraulic fluid from pump A2 bypassed through bypass notch. The rest of hydraulic fluid from pump A2 flows into the arm summation passage through P1 parallel passage, the check valve, arm 2 spool and boom 2 spool.

Then it enters into the arm cylinder rod side with the fluid from the arm 1 spool.

The return flow from the arm cylinder head side returns to the hydraulic tank through the port C4, the arm 1 spool and tank passage.






8) SWING PRIORITY FUNCTION

During swing priority operation, the pilot secondary pressure is supplied to the port Pc3 of the spring side of the swing priority spool and shift swing priority spool in the right direction.

The hydraulic fluid from P2 parallel passage flows into the parallel passage of arm 1 side through swing priority spool and the path "A" and also flows into the boom 2 spool.


When the swing priority spool is neutral condition, the passage is same as normal condition. But due to shifting of the swing priority spool, the fluid from pump A1 flows to swing side more then the boom 2, arm 1, option B and dozer spools to make the swing operation most preferential.



14W92MC27


9) DOZER OPERATION

(1) Dozer down operation



14W92MC30

(2) Dozer up operation



14W92MC31

During the dozer down operation, the pilot pressure from the dozer control valve is supplied into the port Pc6 of the spring side and it shifts the dozer spool in the left direction.

The hydraulic fluid from the pump A1 enters the parallel passage and is direction to the head side of the dozer cylinder through port D6.

The return flow from the rod side of the dozer cylinder returns to the dozer spool through C6 port. Thereafter it is directed to the hydraulic tank through tank passage.

In case of the dozer up operation, operation is similar.

10) NEGATIVE RELIEF VALVE OPERATION


When no function is being actuated on P1 side, the hydraulic fluid from the pump A2, flows into the tank passage through the P1 bypass passage and orifice. The restriction caused by this orifice thereby pressurizes. This pressure is transferred as the negative control signal pressure Pn1 to the pump A2 regulator.

It controls the pump regulator so as to minimize the discharge of the pump A2.

The bypass passage is shut off when the shifting of one or more spools and the flow through bypass passage became zero. The pressure of negative control signal becomes zero and the discharge of the pump A2 becomes maximum.

The negative control pressure reaches to the set level, the hydraulic fluid in the passage pushes open negative control valve and escapes into the return passage.


For the pump A1 the same negative control principle.



14W92MC28


11) OPERATION OF MAIN RELIEF VALVE

(1) The pressurized oil passes through the orifice (A) of the plunger is filled up in chamber A of the inside space, and seats the plunger against the housing securely.




14W92MC36

(2) When the pressure at (P) becomes equal to the set pressure of the spring the hydraulic oil passes through the piston (A) pushes open the poppet and flows to tank passage (T) through the plunger internal passage, periphery orifice A, chamber A, periphery orifice B and the hole (E).




14W92MC37

(3) Opening the poppet causes the pressure in chamber A to fall and the plunger to open. As the result the pressurized oil at port P runs into tank passage (T).




14W92MC38

(4) The pressure at port P becomes lower than set pressure of the spring, the poppet is seated by spring force. Then the pressure at port P becomes equal to set pressure of the spring and the plunger is seated to the socket.



14W92MC39


(5) When the power boost switch is ON, the pilot pressure enters through hole A.
It pushes the piston (B) in the left direction to increase the force of the spring and change the relief set pressure to the high pressure.



12) OPERATION OF OVERLOAD RELIEF VALVE


FUNCTION AS RELIEF VALVE

(1) The pressurized oil passes through the piston A and orifice A is filled up in chamber A of the inside space and seat the plunger against the socket and the socket against the housing securely.




14W92MC41

(2) When the pressure at port P becomes equal to the set pressure of the spring, the pressurized oil pushes open the poppet and flows to tank passage (T) through the plunger internal passage, orifice A, chamber A, periphery orifice B and hole E.




(3) Opening of the poppet causes the pressure in chamber A to fall and the plunger to open. As the result the pressurized oil at port P runs into tank passage (T).




14W92MC43

(4) The pressure at port P becomes lower than set pressure of the spring, the poppet is seated by spring force. Then the pressure at port P becomes equal to set pressure of the spring and the plunger is seated to the socket.



MAKE-UP FUNCTION

(5) When negative pressure exists at port P, the oil is supplied through tank passage (T). When the pressure at tank passage (T) becomes higher than that of at port P, the socket moves in the right direction. Then, sufficient oil passes around the socket from tank passage (T) to port P and fills up the space.





GROUP 3 SWING DEVICE

1. STRUCTURE

Swing device consists swing motor, and swing reduction gear.

Swing motor include mechanical parking valve, relief valve, make up valve and port block assy.







Port	Port name	Port size
А	Main port	Ø13
В	Main port	Ø13
DB	Drain port	PF 3/8
С	Make up port	PF 3/4
PG	Brake release port	PF 1/4
PA, PB	Gauge port	PF 1/4

140A2SM01

1) SWING MOTOR






140A2SM02

4	Cooling	15	Chan	20	Carina
ı	Casing	15	Shoe	29	Spring
2	Oil seal	16	Separate plate	30	Plug assy
3	Ball bearing	17	Friction plate	31	Relief valve assy
4	Drive shaft	18	O-ring	32	Port block assy
5	Shoe plate	19	O-ring	33	Socket bolt
6	Rotary block	20	Brake piston	34	Socket bolt
7	Washer	21	Spring	35	Name plate
8	Spring	22	Valve casing	36	Screw
9	Snap ring	23	Spring pin	37	Plug
10	Roller	24	Ball bearing	38	Plug
11	Collar washer	25	Valve plate	39	Reactionless valve assy
12	Thrust ball	26	O-ring	40	Snap ring
13	Retainer plate	27	Plug assy	41	Socket bolt
14	Piston	28	Plunger		

2) REDUCTION GEAR



125LCR2SM23

1	Ring gear	11	Planetary gear No. 2	21	Carrier pin No. 1
2	Drive shaft	12	Needle bearing	22	Sun gear No. 1
3	Taper roller bearing	13	Thrust washer	23	Snap ring
4	Taper roller bearing	14	Carrier pin No. 2	24	Thrust plate
5	Ring nut	15	Spring pin	25	Sleeve
6	Lock plate	16	Sun gear No. 2	26	O-ring
7	Hexagon bolt	17	Carrier No. 1	27	Oil seal
8	Casing	18	Planetary gear No. 1	30	Socket plug
9	Socket bolt	19	Needle bearing	31	Parallel pin
10	Carrier No. 2	20	Thrust washer	32	Thrust washer

2. PRINCIPLE OF DRIVING

1) GENERATING THE TURNING FORCE

The high hydraulic supplied from a hydraulic pump flows into a rotary block (6) through valve casing (22) of motor, and valve plate (25).

The high hydraulic is built as flowing on one side of Y-Y line connected by the upper and lower sides of piston (14).


The high hydraulic can generate the force, $F1=P\times A$ (P : supplied pressure, A : water pressure area), like following pictures, working on a piston.

This force, F1, is divided as N1 thrust partial pressure and W1 radial partial pressure, in case of the plate of a tilt angle, α .

W1 generates torque, T=W1+R1, for Y-Y line connected by the upper and lower sides of the piston as following pictures.

The sum of torque (Σ W1×R1), generated from each piston (4~5 pieces) on the side of a high hydraulic, generates the turning force.

This torque transfers the turning force to a rotary (6) through a piston; because a rotary is combined with a turning axis and spline, a turning axis rotates and a turning force is sent.



210WA8SM05


2) MAKE UP VALVE

In the system using this type of motor, there is no counterbalance functioning valve and there happens the case of revolution exceeding hydraulic supply of motor. To prevent the cavitation caused by insufficient oil flow there is a make up valve to fill up the oil insufficiency.

A make up valve is provided immediately before the port leading to the hydraulic oil tank to secure feed pressure required when the hydraulic motor makes a pumping action. The boost pressure acts on the hydraulic motor's feed port via the make up valve.


Pressurized oil into the port B, the motor rotate counterclockwise.

If the swing motion is stopped, the oil in the motor is drain via left relief valve, the drain oil run into motor via right make up valve, which prevent the cavitation of motor.



140A2SM04

3) RELIEF VALVE




- 1 Sleeve
- 2 Poppet
- 3 Poppet seat
- 4 Spring
- 5 Spring seat
- 6 Shim
- 7 Piston
- 8 Stopper
- 9 Plug
- 10 O-ring
- 11 O-ring

(1) Construction of relief valve


The valve casing contains two cartridge type relief valves that stop the regular and reverse rotations of the hydraulic motor. The relief valves relieve high pressure at start or at stop of swing motion and can control the relief pressure in two steps, high and low, in order to insure smooth operation.

(2) Function of relief valve

Figure illustrates how the pressure acting on the relief valve is related to its rising process. Here is given the function, referring to the figure following page.




① Ports (P,R) at tank pressure.



145WF2SM26


$$P1 \times A1 = Fsp + Pg \times A2$$

$$P1 = \frac{Fsp + Pg \times A_2}{A_1}$$



145WF2SM27

③ The oil flows into chamber (g) via orifice (m) and (n). When the pressure of chamber (g) reaches the preset force (FSP) of spring (4), the piston (7) moves left and stop the piston (7) hits the bottom of stopper (8).




145WF2SM28

④ When piston (7) hits the bottom of stopper (8), it stops moving to the left any further. As the result, the pressure in chamber (g) equals (Ps).

$$Ps \times A1=Fsp+Ps \times A2$$

$$Ps = \frac{Fsp}{A_1 - A_2}$$




145WF2SM29

4) BRAKE SYSTEM

(1) Control valve swing brake system

This is the brake system to stop the swing motion of the excavator during operation. In this system, the hydraulic circuit is throttled by the swing control valve, and the resistance created by this throttling works as a brake force to slow down the swing motion.




(2) Mechanical swing parking brake system

This is function as a parking brake only when the swing control lever and arm in control lever are not operated.

① Brake assembly

Circumferential rotation of separate plate (16) is constrained by the groove located at casing (1). When housing is pressed down by brake spring (21) through friction plate (17), separate plate (16) and brake piston (20), friction force occurs between friction plate and separate plate.


Friction force constrains motion of rotary block (6). When hydraulic force exceeds spring force, brake is released.



Casing
 Separate plate
 Rotary block
 Brake piston
 Friction plate
 Brake spring

② Operating principle

- a. When any of the swing, arm in, travel and boom up function is operated, the swing parking solenoid valve (5) is shifted to the swing position, so pilot pump charged oil (P3) goes to the chamber G through port PG.
 - This pressure is applied to move the brake piston (20) to the upward against the force of the brake spring (21). Thus, it releases the brake force.
- b. Stop operation and a few second has been elapsed, the swing parking solenoid valve (5) is shifted to the swing parking position and swing brake works.



③ Electric control swing prarking system

- a. A safety is ensured by recognizing the swing operation and canceling the swing parking only under specific conditions by releasing parking electronically.
- b. After receiving the RCV pressure, the MCU applies the parking release signal.
- c. Depending on each RCV operation, there is a time difference between re-entry into swing parking.

Mode	Fine swing switch	RCV operation	Parking delay time	
	ON or OFF	Swing	5 sec	
Work mode	(No condition)	Arm in	1 sec	
	ONI	Boom up	2 sec	
	ON	Travel	3 sec	
	OFF	Boom up / Travel	Not applied	

4 Manual override function

When the swing parking solenoid valve or related electric system is malfunction, the swing parking brake is not released even if the swing lever is operated.

To release the swing parking brake, the manual override function is needed.

Manual override solenoid valve

a. Use hand only to turn the control knob (do not use a tool).

b. Parking brake release


Turn the control knob to counterclockwise fully (about 2.5 mm)

c. Parking brake work

Turn the control knob to clockwise fully.

Be careful not damage the control knob by using a tool or tightening forcibly.

It can cause malfunction of the solenoid valve.




160A2SM11


GROUP 4 TRAVEL DEVICE


1. CONSTRUCTION


Travel device consists travel motor and gear box.

Travel motor includes brake valve, parking brake and high/low speed changeover mechanism.











Port	Port name	Port size
VA, VB	Valve port	PF 3/4
Ps	Pilot port	PF 1/4
DR	Drain port	PF 1/2
MA, MB	Gauge port	PF 1/4

2. STRUCTURE





1	Casing
2	Plug
3	Oil seal
4	Piston
5	Piston seal
6	Shaft
7	Front ball bearing
8	Rear ball bearing
9	Steel ball
10	Pivot
11	Swash plate
12	Cylinder block
13	Spring
14	Ball guide
15	Retainer plate
16	Piston assy
17	Friction plate
18	Separated plate

19	Parking piston
20	O-ring
21	Back up ring
22	O-ring
23	Back up ring
24	Valve plate
25	Spring pin
26	Spring
27	O-ring
28	Spring pin
29	Parallel pin
30	Rear cover
31	Main spool assy
32	Cover
33	Spring
34	Restrictor
35	Spring

36 O-ring

37	Spring seat
38	Relief valve assy
39	O-ring
40	Spool
41	Plug
42	Spring seat
43	Parallel pin
44	Spring
45	Connector
46	O-ring
47	Hexagon socket head bolt
48	Hexagon socket head bolt
49	Hexagon socket head bolt
50	Check valve
51	Spring
52	Plug
53	O-ring

	Destricten
55	Restrictor
56	Restrictor
57	Name plate
58	Rivet
59	Ring gear
60	Bearing
61	Floating seal assy
62	Nut ring
63	Lock plate
64	Hexagon head bolt
65	Thrust plate
66	Planetary gear No.2
67	Needle bearing
68	Inner race No. 2
69	Thrust washer
70	Sun gear No.2
71	Carrier No.1
72	Planetary gear No.1

74 Inner race No. 1 75 Thrust plate 76 Hexagon head bolt 77 Countersunk head screw 78 Sun gear No.1 79 O-ring 80 Cover 81 Hex socket head bolt 82 Plug 83 O-ring 84 Name plate 85 Rivet 86 Rubber cap 87 Rubber cap 88 Plain washer 89 Hexagon bolt 90 Thrust plate

130ZF2TM21

49 40 43 42 41 44 38


54 Plug

3. OPERATION

1) MOTOR

High pressure oil delivered form hydraulic pump is led to inlet port that is provided in the brake valve portion and, through the rear cover (30) and valve plate (24), led to cylinder block (12).

The oil flow and direction of shaft rotation are indicated in table.



Inlet port		
VB	VA	Right (clockwise)
VA	VB	Left (counterclock wise)

125LCR2TM23

As shown in below figure, high pressure oil is supplied to the pistons which are on one side of the line Y-Y that connects upper and lower dead points and produces force F1.


 $F1 = P \times A$ (P : pressure, A : area of piston section)

The swash plate (11) with inclined angle of $^{\alpha}$ divides this force F1 into thrust force F2 and radial force F31-34.

This radial force is applied to axis Y-Y as turning force and generate drive torque of T.

$$T = r_1 \cdot F31 + r_2 \cdot F32 + r_3 \cdot F33 + r_4 \cdot F34$$

This drive torque is transmitted via cylinder block (12) to driving shaft (6).



29092TM07


2) PARKING BRAKE

Parking brake is released when high pressure oil selected by the brake valve portion that is connected directly to the rear cover (30), is applied to the parking piston (19).

Otherwise the braking torque is always applied.

This braking torque is generated by the friction between the separated plates (18), inserted into the casing (1), and friction plates (17), coupled to cylinder block (12) by the outer splines.

When no pressure is activated on the parking piston (19), it is pushed by the brake springs (26) and it pushes friction plates (17) and separated plates (18) towards casing (1) and generates the friction force which brakes the rotation of cylinder block (12) and hence the shaft (6).



3) CAPACITY CONTROL MECHANISM

Figure typically shows the capacity control mechanism.

When high speed pilot line is charged with the pressure P_A that overcome the spring (44), the spring (44) is compressed and spool (40) shifts to the right to connect the port P and port C.

Then, the highest pressure is selected by the check valve (50) from inlet and outlet pressure of the motor and high speed pilot line pressure and pushes shifter piston (4). As a result, swash plate (11) turns around the line L which connect the two pivot (10) as shown by dotted lines. The turn stops at the stopper (1-1) of casing and swash plate (11) keeps the position.


In this case, the piston stroke become shorter and motor capacity become smaller and motor rotates faster, around 1.60 times, by the same volume of oil.

When no pressure is in the high speed pilot line P_A , spool (40) is pushed back by the spring (44) and pressure that pressed the shifter piston (4) is released to the hydraulic tank through restrictor (55).

Here, nine pistons are there and they equally spaced on the swash plate (11). The force that summed up those of pistons comes to almost the center of the swash plate (11) as shown. Since the steel balls (10) are off-set by S from the center, the rotating force of product S and the force moves swash plate (11) to the former position and the speed returns to low.

When the power demand exceeds the engine power, such as in steep slope climbing or turning at high speed mode, the system step down to the low speed automatically. The mechanism is that: pump pressure is led to the port P_B and this pressure activate on pin (43). When the pressure at P_B exceeds predetermined value, spool (40) returns to the left by the counter-pressure against pin (43) and the pressure on the shifter piston (4) through port C is released to the tank and the motor comes to low speed.


When P_B goes down, the spool (40) moves to the right and the speed become high.



4) OVERLOAD RELIEF VALVE

(1) Structure

This valve is screwed in the motor rear cover (30) and consists of : plug (38-1) that is screwed and fixed in the rear cover (30), poppet (38-8) and supports the poppet seat (38-9), spring (38-2) that is operating relief valve setting pressure and supports the spring seat (38-3), that is inserted in the sleeve (38-4), piston (38-5) that reduce the shock.



38-1	Plug	38-6	O-ring	38-11 O-ring
38-2	Spring	38-7	Back-up ring	38-12 Ring
38-3	Spring seat	38-8	Poppet	38-13 O-ring
38-4	Sleeve	38-9	Poppet seat	
38-5	Piston	38-10	Back-up ring	


(2) Operation

Two pieces of overload valves are located at cross-over position in the counterbalance circuit of brake valve and have the following functions:

- ① When hydraulic motor starts, keep the driving pressure below predetermined value and while accelerating, bypasses surplus oil to return line.
- ② When stopping the motor, keep the brake pressure, that develops on the outlet side of motor, under the predetermined value to stop the inertial force.
- ③ To accelerate sharply while starting, and to mitigate the braking shock while stopping. For these purposes, the developed pressure is kept comparatively low for a short period, then keep the line pressure as normal value. While the pressure is low, meshing of reduction gears, crawler and sprocket etc. can be smoothly done and the shock are absorbed.

When starting, "A" port pressure of overload valve increases, this pressure is applied to the effective diameter of poppet (38-8) which seats on the poppet seat (38-9) and, at the same time, is delivered, via small hole, to the spring seat (38-3) located inside the sleeve (38-4) and the seat bore pressure increases up to "A" port pressure. The poppet (38-8) opposes to spring (38-2) by the force of the pressure exerted on the area difference between poppet seat's effective diameter and spring seat bore and keep the predetermined pressure.

When hydraulically braking, the piston (38-5) is at the left position by the driving pressure, and when "A" port pressure increases, the pressure is applied also to the piston (38-5) through the small hole in the poppet (38-8), sleeve (38-4) and piston (38-5) moves rightward until it touches the stopper in rear cover. In this while, the poppet (38-8) maintains "A" port pressure at comparatively low against the spring (38-2) force and exhaust oil to "B" port side. After the piston reached to the plug, the valve acts the same as at starting.



5) BRAKE VALVE

(1) Structure

The brake valve portion mainly consists of the following parts:


① Spool

By shifting the spool (31), the discharged oil from hydraulic motor is automatically shut off or restricted according to the condition and give the effect of holding, accelerating, stopping and counterbalance operations.

(See page 2-71, (2) Operation)

② Check valve (built in the spool)

This valve is located in the oil supplying passage to hydraulic motor, and at the same time functions to lock oil displacement. Therefore, this valve serves as not only a suction valve but also a holding valve for hydraulic motor.



31	Main spool	34	Restrictor	36	O-ring
33	Spring	35	Restrictor spring	37	Spring seat

(2) Operation

① Holding operation


When the control valve is at neutral position, VA and VB ports are connected to the tank, and the spring (33) located on both spool ends holds the spool (31) at central position.

Therefore, the passages from VA to MA and VB to MB are closed, which result in closing MA and MB ports connected to hydraulic motor.

Since the passage to parking brake is connected to the tank line, the brake cylinder pressure is equal to the tank pressure and the brake is applied by the springs. Thus, the rotation of the motor is mechanically prevented.

If external torque is exerted on the motor shaft, the motor would not rotate as usual by this negative parking brake.

In case the brake should be released for some reason, pressure is built on MA or MB port. But, due to oil leakage inside hydraulic motor or so, high-pressure oil escapes from the closed circuit and motor rotates a bit. So, the cavitation tends to occur in the lower pressure side of the closed circuit. Then, the check valve, built in the spool (31), operates to avoid the cavitation and opens the passage from VA to MA or from VB to MB. Then the oil equivalent to the leakage is sucked from the tank line to the closed circuit.




2 Accelerating operation

When VA and VB ports are connected respectively to pump and tank by operating the control valve, hydraulic oil from pump is forwarded through VA port to push open the check valve provided inside spool (31), and oil flows to motor via MA port to rotate the motor.

Therefore, the pressure increases and negative brake is released by the pressure supplied from pump. At the same time, the pressure of pilot chamber increases to push and move the spool (31) leftwards, overcoming the spring (33) force. Thus, the return line from MB to VB opens to rotate the motor.

In case inertia load is too big to start rotation, accelerating pressure reaches the set pressure of relief valve and high pressure oil is being relieved while the motor gains the rotational speed. As the rotational speed goes up, the relieved volume decreases, and finally the motor rotates at a fixed speed.




3 Stopping operation

Returning the control valve to neutral position while running the motor, the oil supply is cut off and VA and VB ports are connected to the tank line. Then the pressure of the pilot chamber located on both spool ends become equal, and the spool (31) returns to the neutral position by spring (33) force. Thus, the passage from MA to VA is closed.

Owing to the inertia force of the load, the hydraulic motor tends to continue the rotation. Here, the motor functions as a pump and forwards the oil to MB port but the passage is blocked and MB port pressure increases. Then the relief valve opens to relieve the pressure and rotational speed decelerates and at last the motor stops.

Negative brake release pressure is gradually lowered due to the restrictor and finally the brake works and the motor is mechanically stopped.



4 Counterbalance operation

Counterbalance operation is required to decelerate slowly the hydraulic motor while absorbing inertia force.

In case the hydraulic oil is gradually decreased from pump to VB port, the drive shaft of hydraulic motor tends to rotate faster than that matched to the volume of oil supply.


Consequently, the pilot chamber pressure on MB to VB side decreases and the spring (33) force moves the spool (31) leftwards towards neutral position.

Therefore, the area of passage from MA to VA becomes smaller and the pressure on MA side rises due to increased resistance in the passage and the motor receives hydraulic braking effect.

If the motor rotates slower than that matched to the volume of supplied oil, the pilot chamber pressure on VB port increases, and spool (31) moves rightwards to enlarge the area of passage from MA to VA. Therefore the braking effect becomes smaller and the rotational speed of motor is controlled to correspond to the volume of supplied oil.

In order to give stable counterbalance operation, the restrictors (34) are set in the pilot chamber to damp the spool (31) movement.

The parking brake is released during pressure adjusting action of the spool (31).



6) REDUCTION GEAR

Reduction unit slows down the rotating speed of motor and converts motor torque to strong rotating force.


This reduction unit utilizes two stages, planetary reduction system.

Planetary reduction system consists of sun gear, planetary gears, (planetary) carriers, and ring gear.

When the sun gear (s) is driven through input shaft, planetary pinions (b), rotating on their center, also move, meshing with fixed ring gear (a), around sun gear (s).


This movement is transferred to carrier (k) and deliver the torque.

This mechanism is called planetary gear mechanism.



When the sun gear S1 is driven by input shaft, planetary action occurs among gears S1, a and b and revolution of gear b transfers the rotation of carrier K1 to second sun gear S2, and also evokes planetary action between gear S2, a and d.

This time, because carrier **K2** is fixed to frame, gear **d** drives ring gear **a** and then ring gear **a** rotates to drive sprocket.



29072TM12


GROUP 5 RCV LEVER


1. STRUCTURE

The casing has the oil inlet port P (primary pressure) and the oil outlet port T (tank). In addition the secondary pressure is taken out through ports 1, 2, 3 and 4 provided at the bottom face.


* Refer to the parts manual for the types of the RCV lever.

1) TYPE M1, M10






TYPE M1




1	TYPE M10
Switches	


Туре	No.	LH	RH
	5	Null	Null
M1 6 7 8	6	Null	Null
	7	One touch decel	Horn
	8	Power boost	Breaker
	5	CW rotation	2-way open
	6	CCW rotation	2-way close
M10	7	One touch decel	Null
	8	Null	Horn
	9	Power boost	Breaker




Pilot ports








2) TYPE M11, M12







TYPE M12


TYPE M11




Туре	No.	LH	RH
	5	Null	Null
M12	6	Null	Null
IVITZ	7	One touch decel	Horn
	8	Power boost	Breaker
	5	CW rotation	2-way open
	6	CCW rotation	2-way close
M11 7		One touch decel	Null
	8	Null	Horn
	9	Power boost	Breaker










VIEW A-A

Pilot ports

Port	LH	RH	Port size
Р	Pilot oil inlet port	Pilot oil inlet port	
Т	Pilot oil return port	Pilot oil return port	
1	Left swing port	Bucket out port	PF 3/8
2	Arm out port	Boom up port	FF 3/0
3	Right swing port	Bucket in port	
4	Arm in port	Boom down port	

160A2RL05

3) CROSS SECTION



Item numbers are based on the type M1.

The construction of the pilot valve is shown in the attached cross section drawing. The casing has vertical holes in which reducing valves are assembled.

The pressure reducing section is composed of the spool (3), spring (5) for setting secondary pressure, return spring (7), spring seat (6) and shim (4). The spring for setting the secondary pressure has been generally so preset that the secondary pressure is 5 to 20.5 kgf/cm² (depending on the type). The spool is pushed against the push rod (9) by the return spring.

When the push rod is pushed down by tilting the handle, the spring seat comes down simultaneously and changes setting of the secondary pressure spring.

2. FUNCTIONS

1) FUNDAMENTAL FUNCTIONS

The pilot valve is a valve that controls the spool stroke, direction, etc of a main control valve. This function is carried out by providing the spring at one end of the main control valve spool and applying the output pressure (secondary pressure) of the pilot valve to the other end.

For this function to be carried out satisfactorily, the pilot valve is composed of the following elements.

- (1) Inlet port (P) where oil is supplied from hydraulic pump.
- (2) Output ports (1, 2, 3 & 4) to apply pressure supplied from inlet port to ends of control valve spools.
- (3) Tank port (T) necessary to control the above output pressure.
- (4) Spool to connect output port to inlet port or tank port.
- (5) Mechanical means to control output pressure, including springs that work on the above spools.

2) FUNCTIONS OF MAJOR SECTIONS

Item numbers are based on the type M1.

The functions of the spool (3) are to receive the supply oil pressure from the hydraulic pump at its port P, and to change over oil paths to determine whether the pressure oil of port P is led to output ports 1, 2, 3 & 4 or the output port pressure oil to tank port T.

The spring (5) works on this spool to determine the output pressure.

The change the deflection of this spring, the push rod (9) is inserted and can slide in the plug (8).

For the purpose of changing the displacement of the push rod through the swash plate (16) and adjusting nut (17) are provided the handle assy (20) that can be tilted in any direction around the fulcrum of the universal joint (15) center.


The spring (7) works on the case (1) and spring seat (6) and tries to return the push rod (9) to the zero-displacement position irrespective of the output pressure, securing its resetting to the center position.

This also has the effect of a reaction spring to give appropriate control feeling to the operator.

3) OPERATION

The operation of the pilot valve will be described on the basis of the hydraulic circuit diagram shown below and the attached operation explanation drawing.


The diagram shown below is the typical application example of the pilot valve.



2-70

- 1 Pilot valve
- 2 Pilot pump
- 3 Main pump
- 4 Main control valve
- 5 Hydraulic motor
- 6 Hydraulic cylinder


(1) Case where handle is in neutral position



300L2RL03

The force of the spring (5) that determines the output pressure of the pilot valve is not applied to the spool (3). Therefore, the spool is pushed up by the spring (7) to the position of port (1, 3) in the operation explanation drawing. Then, since the output port is connected to tank port T only, the output port pressure becomes equal to tank pressure.

(2) Case where handle is tilted



300L2RL04

When the push rod (9) is stroked, the spool (3) moves downwards.

Then port P is connected with port (1) and the oil supplied from the pilot pump flows through port (1) to generate the pressure.

When the pressure at port (1) increases to the value corresponding to the spring force set by tilting the handle, the hydraulic pressure force balances with the spring force. If the pressure at port (1) increases higher than the set pressure, port P is disconnected from port (1) and port T is connected with port (1). If it decreases lower than the set pressure, port P is connected with port (1) and port T is disconnected from port 1.


In this manner the secondary pressure is kept at the constant value.


Besides, in some type, when the handle is tilted more than a certain angle, the upper end of the spool contacts with the inside bottom of the push rod and the output pressure is left to be connected with port P.


GROUP 6 RCV PEDAL


1. STRUCTURE

The casing (spacer) has the oil inlet port P (primary pressure), and the oil outlet port T (tank). In addition the secondary pressure is taken out through ports 1,2,3 and 4 provided at the bottom face.









Port	Port	Port size
Р	Pilot oil inlet port	
Т	Pilot oil return port	
1	Travel (LH, Forward)	PF 1/4
2	Travel (LH, Backward)	FF 1/4
3	Travel (RH, Forward)	
4	Travel (RH, Backward)	


480A2RP01

CROSS SECTION

The construction of the RCV pedal is shown in the below drawing. The casing has vertical holes in which reducing valves are assembled.

The pressure reducing section is composed of the spool kit (7), spring (5) for setting secondary pressure, return spring (9), stopper (8), and spring seat (6). The spring for setting the secondary pressure has been generally so preset that the secondary pressure is 6.3 ± 1 to 24.9 ± 1.5 kgf/cm² (depending on the type). The spool is pushed against the push rod (13) by the return spring.

When the push rod is pushed down by tilting pedal, the spring seat comes down simultaneously and changes setting of the secondary pressure spring.



480A2RP02

1	Body	13	Push rod	25	Cover
2	Plug	14	Spring pin	26	Socket bolt
3	Plug	15	Seal	27	Cam
4	Spring seat	16	Steel ball	28	Bushing
5	Spring	17	Spring	29	Cam shaft
6	Spring seat	18	Plate	30	Set screw
7	Spool kit	19	Snap ring	31	Set screw
8	Stopper	20	Plug	32	Hex nut
9	Spring	21	O-ring	33	Bellows
10	Rod guide	22	Oil seal	34	Expand
11	O-ring	23	Dust seal	36	Сар
12	Snap ring	24	Piston		

2. FUNCTION

1) FUNDAMENTAL FUNCTIONS

The pilot valve is a valve controls the spool stroke, direction, etc of a main control valve. This function is carried out by providing the spring at one end of the main control valve spool and applying the output pressure (secondary pressure) of the pilot valve to the other end.

For this function to be carried out satisfactorily, the pilot valve is composed of the following elements.

- (1) Inlet port (P) where oil is supplied from hydraulic pump.
- (2) Output port (1, 2, 3 & 4) to apply pressure supplied from inlet port to ends of control valve spools.
- (3) Tank port (T) necessary to control the above output pressure.
- (4) Spool to connect output port to inlet port tank port.
- (5) Mechanical means to control output pressure, including springs that work on the above spools.

2) FUNCTIONS OF MAJOR SECTIONS

The functions of the spool (7) are to receive the supply oil pressure from the hydraulic pump at its port P, and to change over oil paths to determine whether the pressure oil of port P is led to output ports 1, 2, 3 & 4 or the output spool to determine the output pressure.

The spring (5) works on this spool to determine the output pressure.

The change the deflection of this spring, the push rod (13) is inserted and can slide in the plug (20). For the purpose of changing th displacement of the push rod through the cam (27) and adjusting nut (32) are provided the pedal that can be tilted in any direction around the fulcrum of the cam (27) center.


The spring (9) works on the body (1) and spring seat (6) and tries to return the push rod (13) to the zero-displacement position irrespective of the output pressure, securing its resetting to the center position.

This also has the effect of a reaction spring to give appropriate control feeling to the operator.

3) OPERATION


The operation of the pilot valve will be described on the basis of the hydraulic circuit diagram shown below and the attached operation explanation drawing.

The diagram shown below is the typical application example of the pilot valve.



- 1 Pilot valve
- 2 Pilot pump
- 3 Main pump
- 4 Main control valve
- 5 Hydraulic motor
- 6 Hydraulic cylinder


(1) Case where pedal is in neutral position



130ZF2RP03

The force of the spring (5) that determines the output pressure of the pilot valve is not applied to the spool kit (7). Therefore, the spool is pushed up by the spring (9) to the position of 1 and port 2. Then, since the output port is connected to tank port T only, the output port pressure becomes equal to tank pressure.

(2) Case where pedal is tilted



220F2RP04

When the push rod (13) is stroked, the spool kit (7) moves downwards.

Then port P is connected with port 1, and the oil supplied from the pilot pump flows through port 1 to generate the pressure.

When the pressure at port 1 increases to the value corresponding to the spring force set by tilting the handle, the hydraulic pressure force balances with the spring force. If the pressure at port 1 increases higher than the set pressure, port P is disconnected from port 1 and port T is connected with port 1. If it decreases lower than the set pressure, port P is connected with port 1 and port T is disconnected from port 1.

In this manner the secondary pressure is kept at the constant value.


Besides, in some type, when the handle is tilted more than a certain angle, the upper end of the spool contacts with inside bottom of the push rod and the output pressure is left to be connected with port P.

SECTION 3 HYDRAULIC SYSTEM

Group	1	Hydraulic Circuit ·····	3-1
Group	2	Main Circuit	3-4
Group	3	Pilot Circuit	3-7
Group	4	Single Operation	3-16
Group	5	Combined Operation	3-28

GROUP 1 HYDRAULIC CIRCUIT


1. HYDRAULIC CIRCUIT (1/3)





- 1 Main pump
- 2 Main control valve
- 3 Swing motor
- 4 Travel motor
- 5 RCV lever (LH)
- 6 RCV lever (RH)
- 7 RCV pedal
- 8 Boom cylinder (LH)
- 9 Boom cylinder (RH)
- 10 Arm cylinder
- 11 Bucket cylinder
- 12 Turning joint
- 13 Return check valve
- 14 Return check valve
- 15 Hydraulic tank
- 16 Oil cooler
- 17 Air breather
- 18 Return filter w/bypass valve
- 19 Strainer
- 20 Drain filter
- 21 5-cartridge valve
- 22 Pressure sensor
- 23 Pressure sensor
- 24 Pressure sensor25 Terminal block
- 26 Last guard filter
- 27 2-EPPR valve
- 28 Block
- 29 Cross assy
- 30 Solenoid valve
- 31 Screw coupling
- 32 Shockless valve
- 33 Lart guard filter


3-1


2. HYDRAULIC CIRCUIT (2/3)


















- 2 Main control valve
- 13 Check valve
- 14 Check valve
- 16 Oil cooler
- 24 Pressure sensor
- 26 Last guard filter
- 66 Stop valve (option)
- 67 Stop valve (option)
- 68 Proportional relief valve (option)
- 69 Solenoid valve (option)
- 70 Proportional relief valve (option)
- 71 Solenoid valve (option)
- 72 Shuttle valve (option)
- 73 2-way pedal (option)
- 74 EPPR valve (option)
- 82 Adjust cylinder (option)
- 83 Pressure switch (option)
- 84 Port relief valve (option)
- 85 Port relief valve (option)
- 87 Turning joint (option)
- 88 Dozer cylinder-LH (option)
- 89 Dozer cylinder-RH (option)
- 90 Pilot selector valve (option)

Solenoid valve (option)


- 93 Selector valve (option)
- 30 Ociccioi vaive (optioi
- 96 Solenoid valve (option)
- 97 Dozer valve (option)
- 98 Solenoid valve (option)


30K3-27100-02 2OF3


3. HYDRAULIC CIRCUIT (3/3)





<pattern change=""></pattern>	FROM		то	
	ITEM	PORT	ITEM	PORT
61 _{J1 J2 J3 J4}	(5)	2		J1
	9	4	61)	J3
	6	2		J4
		4		J2
	(61)	M1	(25)	D
M1 M2 M3 M4		M2		J
	(0)	МЗ		E
		M4		Н




















- 2 Main control valve
- 3 Swing motor
- 22 Pressure sensor
- 31 Screw coupling (option)
- 60 Solenoid valve (option)
- 61 Pattern change valve (option)
- Boom safety cylinder valve (option)
- 63 Arm safety cylinder valve (option)
- 76 Stop valve (option)
- 77 Stop valve (option)
- 79 Gear pump (option)
- 80 Proportional valve (option)
- 91 Solenoid valve (option)
- 92 3-solenoid valve (option)
- 95 Solenoid valve (option)
- 97 EPPR valve assy (option)

30K3-27100-02 3OF3


GROUP 2 MAIN CIRCUIT

The main hydraulic circuit consists of suction circuit, delivery circuit, return circuit and drain circuit.

The hydraulic system consists of one main pump, one control valve, one swing motor, four cylinders and two travel motors.

The swash plate type variable displacement axial piston pump is used as the main pump and is driven by the engine at ratio 1.0 of engine speed.

1. SUCTION AND DELIVERY CIRCUIT



140L3Cl01

The pumps receive oil from the hydraulic tank through a suction strainer. The discharged oil from the pump flows into the control valve and goes out the tank ports.


The oil discharged from the main pump flows to the actuators through the main control valve.

The main control valve controls the hydraulic functions.

The return oil from the actuators flows to the hydraulic tank through the main control valve and the oil cooler.

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

2. RETURN CIRCUIT



140A3CI02

All oil returned from each actuator returns to the hydraulic tank through the main control valve.

The bypass check valves are provided in the return circuit.

The setting pressure of bypass check valves are 1.5 kgf/cm² (21 psi) and 3.0 kgf/cm² (43 psi). Usually, oil returns to the hydraulic tank from the left side of control valve through oil cooler.

When oil temperature is low, viscosity becomes higher and flow resistance increases when passing through the oil cooler. When the oil pressure exceeds 3.0 kgf/cm² (43 psi), the oil returns directly to the hydraulic tank, resulting in the oil temperature being raised quickly at an appropriate level.


When the oil cooler is clogged, the oil returns directly to the hydraulic tank through bypass check valve (1). The full-flow filter and bypass relief valve are provided in the hydraulic tank.

The oil returned from right and left side of control valve is combined and filtered by the full-flow filter. A bypass relief valve is provided in the full-flow filter.

When the filter element is clogged, the bypass relief valve opens at 1.5 kgf/cm² (21 psi) differential pressure.

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

3. DRAIN CIRCUIT



130A3CI03

Besides internal leaks from the motors and main pump, the oil for lubrication circulates. These oil have to be fed to the hydraulic tank passing through drain filter or return filter.

When the drain oil pressure exceed 1.5 kgf/cm² (21 psi), the oil returns to the hydraulic tank directly.

1) TRAVEL MOTOR DRAIN CIRCUIT

Oil leaked from the right and left travel motors comes out of the drain ports provided in the respective motor casing and join with each other. These oils pass through the turning joint and return to the hydraulic tank after being filtered by the return filter.

2) SWING MOTOR DRAIN CIRCUIT


Oil leaked from the swing motor returns to the hydraulic tank passing through the return filter.

3) MAIN PUMP DRAIN CIRCUIT

Oil leaked from main pump returns to the hydraulic tank passing through the drain filter.

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

GROUP 3 PILOT CIRCUIT



The pilot circuit consists of suction circuit, delivery circuit and return circuit.


The pilot pump is provided with relief valve, receives the oil from the hydraulic tank through the suction strainer.

The discharged oil from the pilot pump flows to the remote control valve through the cross assy, safety lock solenoid valve and line filter and swing parking solenoid valve through the safety lock solenoid valve and line filter.

Also, it flows to the EPPR valves, solenoid valves, main control valve and main pump through the block and/or line filter.

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

1. SUCTION, DELIVERY AND RETURN CIRCUIT




The pilot pump receive oil from the hydraulic tank. The discharged oil from the pilot pump flows to the safety solenoid valve. The oil is filtered by the line filter.

The pilot relief valve is provided in the pilot pump for limiting the pilot circuit pressure.


The oil filtered by line filter flows remote control valve through safety solenoid valve and cross assy. The return oil flow into the hydraulic tank through cross assy.

2. **SAFETY VALVE** (SAFETY LEVER)



When the lever of the safety solenoid valve is moved upward, oil flows into the remote control valve through the line filter, safety solenoid valve and cross assy.

When the lever of the safety solenoid valve is moved downward, oil does not flow into the remote control valve, because of the blocked port.




When carrying out the combined operation of swing and boom up, the boom up operating speed is lowered then normal operation.

To increase working efficiency, swing speed reducing system is used.

The pilot oil from pilot pump flow into **P03** port in main control valve through boom priority EPPR valve. **P03** oil pressure moves swing reducing spool to lower position and oil flow rate to the swing motor decreased.

Then, the boom up speed is increased. This is called the boom priority system.


4. TRAVEL SPEED CONTROL SYSTEM



When the travel speed solenoid valve was placed in the Hi position, the pressure oil from pilot pump through line filter flows to port **Ps** of travel speed change over valve, and the control piston is pushed up, thus minimizing the displacement.

When the travel speed solenoid valve was placed in the Lo position, the oil of **Ps** port return to the tank and the control piston is returned, thus maximizing the displacement.

5. MAIN RELIEF PRESSURE CHANGE SYSTEM




When the power boost switch on the left control lever is pushed ON, the power boost solenoid valve is actuated, the discharged oil from the pilot pump flows into **Pu** port of the main relief valve of main control valve; then the setting pressure of the main relief valve is raised from 330 kgf/cm² (4690 psi) to 360 kgf/cm² (5120 psi) for increasing the digging power.

And even when pressed continuously, it is canceled after 8 seconds.

When the auto power boost function is selected to enable on the cluster, the pressure of the main relief pressure is automatically increased to 360 kgf/cm² (5120 psi) as working condition by the MCU. It is operated max 8 seconds.

6. ARM REGENERATION CUT SYSTEM




When the arm regeneration is selected to disable on the cluster, the arm regeneration solenoid valve is activated. The pilot oil from pilot pump flow into **Pb4** port in main control valve through solenoid valve and the arm regeneration spool is shifted to left.

Then, the oil from arm regeneration passage returns to tank and the arm regeneration function is deactivated.

When the arm regeneration is selected to enable on the cluster, the arm regeneration function is activated and arm in operation speed is increased.

Refer to page 2-42 for the arm regeneration function.

7. SWING PARKING BRAKE RELEASE




When any lever of the swing, arm in, boom up or travel is tilted, the swing brake solenoid valve is shifted to the downward by the MCU that senses the pilot pressure of the RCV control lever.

The discharged oil from pilot pump flows to swing motor PG port through the swing brake solenoid valve. This pressure is applied to swing motor disc, thus the brake is released.

When the RCV control lever is set in the neutral position, the swing brake solenoid valve is shifted to the upward, oil in the swing motor disc cylinder is drained through the the swing brake solenoid valve, thus the brake is applied. For details, refer to page 2-61.

8. SWING PRIORITY SYSTEM




When the swing and arm in control levers are tilted simultaneously, the swing priority EPPR valve is energized by the MCU that senses the swing pilot pressure and Pc3 pressure from the swing priority EPPR valve change the swing priority spool and decreases the oil flow rate to the next section to make the swing operation most preferential.

This is called the swing priority system. For details, refer to page 2-44.

GROUP 4 SINGLE OPERATION


1. BOOM UP OPERATION



When the right control lever is pulled back, the boom spools in the main control valve are moved to the up position by the pilot oil pressure (Pa20, Pa21) from the remote control valve.

The oil from the A1 and A2 pump flows into the main control valve and then goes to the large chamber of boom cylinders. At the same time, the oil from the small chamber of boom cylinders returns to the hydraulic oil tank through the boom 1 spool in the main control valve. When this happens, the boom goes up. The excessive pressure in the boom cylinder head side is prevented by relief valve. When the boom is up and the control lever is returned to neutral position, the circuit for the holding pressure at the head side of the boom cylinder is closed by the boom holding valve. This prevents the hydraulic drift of boom cylinders.

2. BOOM DOWN OPERATION



When the right control lever is pushed forward, the boom 1 spool in the main control valve is moved to the down position by the pilot oil pressure (Pb20) from the remote control valve.


The oil from the A2 pump flows into the main control valve and then goes to the small chamber of boom cylinders. At the same time, the oil from the large chamber of boom cylinders returns to the hydraulic tank through the boom 1 spool in the main control valve.

When the down speed of boom is faster, the oil returned from the large chamber of boom cylinder combines with the oil from the A2 pump, and flows into the small chamber of the cylinder.

This prevents cylinder cavitation by the negative pressure when the A2 pump flow can not match the boom down speed. And the excessive pressure in the boom cylinder rod side is prevented by the relief valve.

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

3. ARM IN OPERATION



When the left control lever is pulled back, the arm spools in the main control valve are moved to the arm in position by the pilot oil pressure (Pc40, Pb3) from the remote control valve.


The oil from the A1 and A2 pump flows into the main control valve and then goes to the large chamber of arm cylinder.

At the same time, the oil from small chamber of arm cylinder returns to the hydraulic oil tank through the arm 1 spool in the main control valve. When this happens, the arm rolls in.

The excessive pressure in the arm cylinder head side is prevented by relief valve.

The cavitation which will happen to the head side of the arm cylinder is also prevented by the makeup valve in the main control valve.


4. ARM OUT OPERATION



When the left control lever is pushed forward, the arm spools in the main control valve are moved to the arm out position by the pilot oil pressure (Pd40, Pd41) from the remote control valve.

The oil from the A1 and A2 pump flows into the main control valve and then goes to the small chamber of arm cylinder. At the same time, the oil from the large chamber of arm cylinder returns to the hydraulic oil tank through the arm 1 spool in the main control valve. When this happens, the arm rolls out. The cavitation which will happen to the rod side of the arm cylinder is also prevented by the make-up valve in the main control valve. When the arm is roll out and the control lever is returned to neutral position, the circuit for the holding pressure at the rod side of the arm cylinder is closed by the arm holding valve. This prevent the hydraulic drift of arm cylinder.

5. BUCKET IN OPERATION



When the right control lever is pulled left, the bucket spool in the main control valve is moved to the roll in position by the pilot oil pressure (Pa5) from the remote control valve.


The oil from the A2 pump flows into the main control valve and then goes to the large chamber of bucket cylinder.

At the same time, the oil from the small chamber of bucket cylinder returns to the hydraulic oil tank through the bucket spool in the main control valve. When this happens, the bucket rolls in.

The excessive pressure in the bucket cylinder head side is prevented by relief valve.

The cavitation which will happen to the head side of the bucket cylinder is also prevented by the make-up valve in the main control valve.

6. BUCKET OUT OPERATION



When the right control lever is pushed right, the bucket spool in the main control valve is moved to the bucket out position by the pilot oil pressure (Pb5) from the remote control valve.


The oil from the A2 pump flows into the main control valve and then goes to the small chamber of bucket cylinder.

At the same time, the oil from the large chamber of bucket cylinder returns to the hydraulic oil tank through the bucket spool in the main control valve. When this happens, the bucket rolls out.

The excessive pressure in the bucket cylinder rod side is prevented by relief valve.

The cavitation which will happen to the rod side of the bucket cylinder is also prevented by the make-up valve in the main control valve.

7. DOZER UP OPERATION




When the dozer control lever is pulled back, the dozer spool in the main control valve is moved to the dozer up position by the pilot oil pressure (Pd6) from the remote control valve.

The oil from the A1 pump flows into the main control valve and then goes to the small chamber of dozer cylinder.

At the same time, the oil from the large chamber of dozer cylinders returns to the hydraulic oil tank through the dozer spool in the main control valve. When this happens, the dozer goes up.

8. DOZER DOWN OPERATION




When the dozer control lever is pushed forward, the dozer spool in the main control valve is moved to the dozer down position by the pilot oil pressure (Pc6) from the remote control valve.

The oil from the A1 pump flows into the main control valve and then goes to the large chamber of dozer cylinder.

At the same time, the oil from the small chamber of dozer cylinders returns to the hydraulic oil tank through the dozer spool in the main control valve. When this happens, the dozer goes down.

9. SWING OPERATION



When the left control lever is pushed left or right, the swing spool in the main control valve is moved to the left or right swing position by the pilot oil pressure (Pc2, Pd2) from the remote control valve.

Also the swing operation preference function is operated by the pilot pressure **Pc3** (refer to page 3-15).


The oil from the A1 pump flows into the main control valve and then goes to the swing motor.

At the same time, the return oil from the swing motor returns to the hydraulic oil tank through the swing spool in the main control valve.

When this happens, the upper structure swings to the left or right.

The swing parking brake, make up valve and the motor brake valve are provided in the swing motor. The cavitation which will happen to the swing motor is also prevented by the make up valve in the swing motor itself.

SWING CIRCUIT OPERATION



TO / FROM MAIN CONTROL VALVE

140L3HC18A

1) MOTOR BRAKE VALVE

Motor brake valve for the swing motor limits to cushion the starting and stopping pressure of swing operation and controls the swing motor operating pressure to 280 kgf/cm² (3990 psi).

2) MAKE UP VALVE

The make up valves prevent cavitation by supplying return oil to the vacuum side of the motor.

3) PARKING BRAKE

This is function as a parking brake only when any one of the swing, arm in, boom up or travel control lever is not operated.

PARKING BRAKE "OFF" OPERATION

When any one of the swing, arm in, travel or boom up control lever is tilted, the swing brake solenoid valve is energized by the MCU that senses the swing pilot oil pressure.

The discharged oil from pilot pump flows to swing motor PG port through the swing brake solenoid valve. This pressure is applied to swing parking brake piston, thus the brake is released.


PARKING BRAKE "ON" OPERATION

When the all control levers are set in the neutral position, the swing brake solenoid valve is de-energized, oil in the swing parking brake chamber is drained through the the swing brake solenoid valve, thus the brake is applied by spring force.

4) ANTI-INVERSION VALVE

This anti-inversion valve absorbs shocks produced as swing motion stops and reduced oscillation cause by swing motion.

^{*} The circuit diagram may differ from the equipment, so please check before a repair.




When the travel levers are pushed forward or reverse position, the travel spools in the main control valve are moved to the forward or reverse travel position by the pilot oil pressure (Pa1, Pb1, Pc1, Pd1) from the remote control valve.

The oil from the each pump flows into the main control valve and then goes to the each travel motor through the turning joint.

The return oil from both travel motors returns to the hydraulic oil tank through the turning joint and the travel spools in the main control valve.

When this happens, the machine moves to the forward or reverse.

TRAVEL CIRCUIT OPERATION



140L3HC19A

Valves are provided on travel motors to offer the following functions.

1) COUNTER BALANCE VALVE

When stopping the motor of slope descending, this valve to prevent the motor over run.


2) OVERLOAD RELIEF VALVE

Relief valve limit the circuit pressure below 350 kgf/cm² (4980 psi) to prevent high pressure generated at a time of stopping the machine. Stopping the motor, this valve sucks the oil from lower pressure passage for preventing the negative pressure and the cavitation of the motor.

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

GROUP 5 COMBINED OPERATION

1. OUTLINE



The oil from the A1 and A2 pump flows through the neutral oil passage, bypass oil passage and confluence oil passage in the main control valve. Then the oil goes to each actuator and operates them. Check valves and orifices are located on these oil passage in the main control valve. These control the oil from the main pumps so as to correspond to the operation of each actuator and smooth the combined operation.


STRAIGHT TRAVEL SPOOL

This straight travel spool for straight travel is provided in the main control valve.

If any actuator is operated when traveling, the straight travel spool is pushed to the right by the pilot oil pressure.

Consequently, the left and right travel oil supply passage are connected, and equivalent amount of oil flows into the left and right travel motors. This keeps the straight travel.

2. COMBINED SWING AND BOOM UP OPERATION



When the swing and boom up functions are operated simultaneously, the swing spool and boom spools in the main control valve are moved to the functional position by the pilot oil pressure (Pc2, Pd2, Pa20, Pa21) from the remote control valve.


The oil from the A1 pump flows into the swing motor through swing spool and the boom cylinders through boom 2 spool.

The oil from the A2 pump flows into the boom cylinders through the boom 1 spool in the right control valve.

The super structure swings and the boom is operated.

Refer to page 3-10 for the boom priority system.

3. COMBINED SWING AND ARM OPERATION



When the swing and arm functions are operated simultaneously, the swing spool and arm spools in the main control valve are moved to the functional position by the pilot oil pressure (Pc2, Pd2, Pc40, Pb3, Pd40, Pd41) from the remote control valve.


The oil from the A1 pump flows into the swing motor through swing spool and the arm cylinder through arm 1 spool.

The oil from the A2 pump flows into the arm cylinder through the arm 2 spool of the right control valve.

The super structure swings and the arm is operated.

Refer to page 3-15 for the swing operation preference function.

4. COMBINED SWING AND BUCKET OPERATION




When the swing and bucket functions are operated simultaneously, the swing spool and bucket spool in the main control valve are moved to the functional position by the pilot oil pressure (Pc2, Pd2, Pa5, Pb5) from the remote control valve.

The oil from the A1 pump flows into the swing motor through the swing spool in the left control valve. The oil from the A2 pump flows into the bucket cylinder through the bucket spool in the right control valve.

The super structure swings and the bucket is operated.

5. COMBINED SWING AND TRAVEL OPERATION



When the swing and travel functions are operated simultaneously, the swing spool and travel spools in the main control valve are moved to the functional position by the pilot oil pressure (Pc2, Pd2, Pa1, Pb1, Pc1, Pd1) from the remote control valve and straight travel spool is pushed to the right by the pilot oil pressure from the pilot pump.


The oil from the A1 pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool.

The oil from the A2 pump flows into the swing motor through in the straight travel spool.

When the pressure of the travel motors is lower than the pressure of the swing motor, some oil from the A2 pump flows into the travel motors through the check valve and orifice in the straight travel spool. This prevents the rapid slowdown of the travel.

The upper structure swings and the machine travels straight.

6. COMBINED BOOM AND TRAVEL OPERATION



When the boom and travel functions are operated simultaneously, the boom spools and travel spools in the main control valve are moved to the functional position by the pilot oil pressure (Pa20, Pa21, Pb20, Pc2, Pd2, Pa1, Pb1, Pc1, Pd1) from the remote control valve and the straight travel spool is pushed to the right by the oil pressure from pilot pump.


The oil from the A1 pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool.

The oil from the A2 pump flows into the boom cylinders through the boom 2 spool and boom 1 spool via the parallel and confluence oil passage in case boom up operation.

When the pressure of the travel motors is lower than the pressure of the boom cylinders, some oil from the A2 pump flows into the travel motors through the check valve and orifice in the straight travel spool. This prevents the rapid slowdown of the travel.

The boom is operated and the machine travels straight.

7. COMBINED ARM AND TRAVEL OPERATION



When the arm and travel functions are operated simultaneously, the arm spools and travel spools in the main control valve are moved to the functional position by the pilot oil pressure (Pc40, Pb3, Pd40, Pd41, Pa1, Pb1, Pc1, Pd1) from the remote control valve and the straight travel spool is pushed to the right by the oil pressure from pilot pump.


The oil from the A1 pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool.

The oil from the A2 pump flows into the arm cylinders through the arm 1 spool and arm 2 spool via the parallel and confluence oil passage.

When the pressure of the travel motors is lower than the pressure of the arm cylinder, some oil from the A2 pump flows into the travel motors through the check valve and orifice in the straight travel spool. This prevents the rapid slowdown of the travel.

The arm is operated and the machine travels straight.

8. COMBINED BUCKET AND TRAVEL OPERATION




When the bucket and travel functions are operated simultaneously, the bucket spool and travel spools in the main control valve are moved to the functional position by the pilot oil pressure (Pa5, Pb5, Pa1, Pb1, Pc1, Pd1) from the remote control valve, and the straight travel spool is pushed to the right by the oil pressure from pilot pump. The oil from the A1 pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool of the control valve.

The oil from the A2 pump flows into the bucket cylinder through the bucket spool via the confluence oil passage.

When the pressure of the travel motors is lower than the pressure of the bucket cylinder, some oil from the A2 pump flows into the travel motors through the check valve and orifice in the straight travel spool. This prevents the rapid slowdown of the travel.

The bucket is operated and the machine travels straight.

9. COMBINED BOOM UP AND BUCKET OPERATION



When the boom up and bucket functions are operated simultaneously, each spool in the main control valve is moved to the functional position by the pilot oil pressure (Pa20, Pa21, Pa5) from the remote control valve.

The oil from the A1 pump flows into the boom cylinders through the boom 2 spool in the left control valve. The oil from the A2 pump flows into the boom cylinders and bucket cylinder through the boom 1 spool, bucket spool and the parallel and confluence oil passage in the right control valve.

Also, when the boom up and bucket in functions are operated simultaneously, the boom up operation preference function is operated by the pilot pressure **P04** and then the bucket spool transfers in the half stroke not full stroke (refer to page 2-38). Therefore, the most of pressurized oil flows into boom 1 spool than the bucket spool to make the boom up operation more preferential.

The boom and bucket are operated.


^{*} The circuit diagram may differ from the equipment, so please check before a repair.

SECTION 4 ELECTRICAL SYSTEM

Group	1 Component Location	4-1
Group	2 Electrical Circuit	4-3
Group	3 Electrical Component Specification	4-23
Group	4 Connectors ·····	4-34


GROUP 1 COMPONENT LOCATION


1. LOCATION 1





1	Cigar lighter	14	Emergency engine stop switch	27	Air compressor switch
2	Aircon and heater switch	15	DC/DC converter	28	Travel switch
3	Remote controller	16	Remote controller unit	28	Swing fine switch
4	Accel dial switch	17	Handsfree control unit	29	Swing lock switch
5	Horn switch	18	Emergency engine connector	30	Machine control unit
6	Breaker operation switch	19	Fuse box assy	32	Around view camera (rear)
7	USB & socket assy	20	Master switch	33	Satellite antenna
8	Cluster	21	RS232 & J1939 service socket	34	Relay - 5P
9	Start switch	22	Radio & USB player	35	Intergrated or AM/FM antenna
10	Service meter	23	Heated seat switch	36	Mobile antenna
11	One touch decel switch	24	Speaker	37	Around view camera (front)
12	Power max switch	25	Quick clamp switch	39	Power relay
13	Safety lever	26	Option attachment switch	40	Warning buzzer

2. LOCATION 2












BOOM SAFETY VALVE


BOOM

5-CARTRIDGE VALVE









Work lamp

- 1
- 2 Fuel sender
- 3 Fuel filler pump
- 4 Beacon lamp
- 5 Battery
- 6 Battery relay
- 7 Horn - high
- 7' Horn - low
- 8 P1 pressure sensor
- 9 P2 pressure sensor
- 10 EPPR pressure sensor
- Overload pressure sensor 11
- 12 Start relay
- 13 Heater relay


14 Alternator

- Travel alarm buzzer 15
- Arm out pressure sensor 16
- 17 Boom up pressure sensor
- 18 Swing pressure sensor
- 19 Boom down pressure sensor
- 20 Arm in pressure sensor
- 21 Attach pressure sensor
- 22 Travel pressure sensor
- 24 5 cartridge valve
- 25 Pump EPPR valve
- Boom priority EPPR valve 26
- 28 Nega-control pressure sensor
- 29 Flow control EPPR valve


- Relay drive unit 30
- PVG 32 controller 31
- 32 Air cleaner indicator
- 33 Earth strap
- Safety solenoid valve 34
- 35 Swing fine solenoid valve
- Swing lock solenoid valve 36
- Quick clamp solenoid valve 38
- Button key control unit 39
- 40 Around view camera controller
- 41 Bucket in pressure sensor
- 42 Bucket out pressure sensor

GROUP 2 ELECTRICAL CIRCUIT

· ELECTRICAL CIRCUIT (1/3)





· ELECTRICAL CIRCUIT (2/3)





20K4-90112-01

· ELECTRICAL CIRCUIT (3/3)









20K3-92031-01


MEMORANDUM

1. POWER CIRCUIT

The negative terminal of battery is grounded to the machine chassis.

When the start switch is in the OFF position, the current flows from the positive battery terminal as shown below.

1) OPERATING FLOW



I/conn : Intermediate connector


2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (battery 1EA)	10~12.5V
CTOD	OFF	② - GND (battery 2EA)	20~25V
STOP		③ - GND (battery relay)	20~25V
		④ - GND (circuit breaker)	20~25V

% GND : Ground

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

POWER CIRCUIT



2. STARTING CIRCUIT

1) OPERATING FLOW

```
Battery (+) terminal → Battery relay [CR-1] → Circuit breaker [CN-60] → Master switch [CS-74A]

I/conn [CN-231 (2)] → Fuse box [No.2] → I/conn [CN-36-1 (7)] → Master switch [CS-74B]

I/conn [CN-5 (36)] → Start switch [CS-2A (1)]

(1) When start key switch is in ON position

Start switch ON [CS-2A (2)] → I/conn [CN-5 (39)]

Battery relay [CR-1] → Battery relay operating (all power is supplied with the electric component)

Start switch ON [CS-2A (3)] → GPS conn [CN-125 (2)→(4)]

I/conn [CN-36-1 (1)] → Power relay [CR-35 (86) → (87)]

Fuse box [No.9~12]

I/conn [CN-4 (4)] → Emergency engine stop sw [CS-33 (2)→(1)]

I/conn [CN-4 (13)] → I/conn [CN-36-1 (2)] → Fuse box [No. 13]

I/conn [CN-36-1 (6)] → ECM IG [CR-45 (86)]
```

(2) When start key switch is in START position

RMS [CN-125A (2)]

Start switch START [CS-2A (6)] → I/conn [CN-5 (35)] → I/conn [CN-36-3 (9)]


- → Anti-restart relay [CR-5 (86) → (87)] → I/conn [CN-36-3 (1)] → ECM start relay [CR-106 (86) → (87)]
- \rightarrow ECM [CN-94 (8) \rightarrow (53)] \rightarrow Start relay [CR-23A (86) \rightarrow (87)] \rightarrow I/conn [CN-6 (1)]
- Start relay [CR-23 (2)] → Starter motor operating

2) CHECK POINT

Engine	Start switch	Check point	Voltage	
		① - GND (battery)		
		② - GND (start switch)		
		③ - GND (battery relay B+)		
RUN	ON	④ - GND (starter B+)	20~25V	
			⑤ - GND (starter M)	
		⑥ - GND (start relay)		
		⑦ - GND (battery relay)		

The circuit diagram may differ from the equipment, so please check before a repair.

STARTING CIRCUIT



3. CHARGING CIRCUIT

When the starter is activated and the engine is started, the operator releases the starting switch to the ON position.

Charging current generated by operating the alternator flows into the battery through the battery relay [CR-1].

The current also flows from the alternator to each electrical component and controller through the fuse box.

1) OPERATING FLOW

(1) Warning flow

Alternator [CN-74 (D⁺)] — I/conn [CN-6 (3)] — MCU alternator level [CN-52 (27)] — Cluster charging warning lamp (via CAN interface)

(2) Charging flow

Alternator "B+" terminal — Starter motor [CN-45 (B+)]

— Battery relay — Battery (+) terminal
— Circuit breaker [CN-60] — Master switch [CS-74A] — I/conn [CN-231 (2)]
— Fuse box [No. 1~8]
— Circuit breaker [CN-95] — I/conn [CN-231 (1)] — Fuse box [No. 14~28]


2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (battery voltage)	
RUN ON		② - GND (battery relay)	
		③ - GND (alternator B ⁺ terminal)	20~25V
		④ - GND (alternator D ⁺ terminal)	
		⑤ - GND (MCU)	

****** GND : Ground

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

CHARGING CIRCUIT




130ZF4EL07

4. HEAD AND WORK LIGHT CIRCUIT

1) OPERATING FLOW

```
Fuse box (No.16) — I/conn [CN-36-2 (4)] — Head light relay [CR-13 (30, 86)]
Fuse box (No.17) — I/conn [CN-36-2 (5)] — Work light relay [CR-4 (30, 86)]
Fuse box (No.11) — I/conn [CN-36-1 (16)] — Membrane controller [CN-376 (1)]
```

(1) Head light switch ON



(2) Work light switch ON

```
Work light switch ON [CN-376 (4)] \longrightarrow Work light relay [CR-4 (85) \rightarrow (87)] \longrightarrow l/conn [CN-12 (2)] \longrightarrow Work light ON [CL-5 (2), CL-6 (2)]
```


2) CHECK POINT

Engine	Start switch	Check point	Voltage	
		① - GND (fuse box)		
		② - GND (head light switch power output)		
	ON		③ - GND (head light relay)	
OTOD		④ - GND (head light)	00.057	
STOP		⑤ - GND (fuse box)	20~25V	
		⑥ - GND (work light switch power output)		
		⑦ - GND (work light relay)		
		8 - GND (work light)		

***** GND : Ground

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

HEAD AND WORK LIGHT CIRCUIT



* The circuit diagram may differ from the equipment, so please check before a repair.

5. BEACON LAMP AND CAB LIGHT CIRCUIT

1) OPERATING FLOW

```
Fuse box (No.19) — Beacon lamp relay [CR-85 (30, 86)]
Fuse box (No.18) — I/conn [CN-36-2 (6)] — Cab light relay [CR-9 (30, 86)]
Fuse box (No.11) — I/conn [CN-36-1 (16)] — Membrane controller [CN-376 (1)]
```

(1) Beacon lamp switch ON

```
Beacon lamp switch ON [CN-376 (15)] — I/conn [CN-36-1 (9)]
— Beacon lamp relay [CR-85 (85)→ (87)] — I/conn [CN-36-3 (7)]
— I/conn [CN-5 (50)] — I/conn [CN-10 (10)] — Beacon lamp ON [CL-7]
```

(2) Cab light switch ON

```
Cab light switch ON [CN-376 (5)] — Cab lamp relay [CR-9 (85) \rightarrow (87)] — I/conn [CN-5 (34, 38)] — I/conn [CN-10 (2)] — Cab light (FR / LH) ON [CL-8 (2)] — I/conn [CN-10 (12)] — Cab light (FR / RH) ON [CL-9 (2)] — I/conn [CN-10 (11)] — Cab light (RR) ON [CL-10 (2)]
```


2) CHECK POINT

Engine	Start switch	Check point	Voltage	
		① - GND (fuse box)		
		② - GND (beacon lamp relay)		
	ON	③ - GND (beacon lamp switch power output)		
CTOD		④ - GND (beacon lamp)	00.057	
STOP		⑤ - GND (fuse box)	20~25V	
			⑥ - GND (cab light relay)	
		⑦ - GND (cab light switch power output)		
		8 - GND (cab light)		

[%] GND: Ground

^{*} The circuit diagram may differ from the equipment, so please check before a repair.

BEACON LAMP AND CAB LIGHT CIRCUIT



6. WIPER AND WASHER CIRCUIT

1) OPERATING FLOW

(1) Start switch ON

Fuse box (No.11) — I/conn [CN-36-1 (16)] — Membrane controller [CN-376 (1)]

Fuse box (No.6) — I/conn [CN-36-1 (11)] — I/conn [CN-5 (18)] — I/conn [CN-17 (5)]

Wiper motor controller [CN-141 (7)]

Wiper motor [CN-21 (4)]

Fuse box (No.21) — I/conn [CN-36-1 (4)] — I/conn [CN-5 (16)] — I/conn [CN-17 (4)]

— Wiper motor controller [CN-141 (6)]

Washer pump [CN-22 (2)]

(2) Wiper switch ON (Intermittent)

Wiper switch ON [CN-376 (12)] → I/conn [CN-5 (20)] → I/conn [CN-17 (8)] → Wiper motor controller [CN-141 (10)→(3)] → Wiper motor [CN-21 (6)] → Intermittently operating

(3) Wiper switch ON (continual)

Wiper switch ON [CN-376 (3)] → I/conn[CN-5 (15)] → I/conn[CN-17 (2)] → Wiper motor controller [CN-141 (2) → (4)] → Wiper motor [CN-21 (2)] → Continual operating

(4) Washer switch ON

Washer switch ON [CN-376 (11)] → I/conn [CN-5 (17)] → I/conn [CN-17 (7)]

- → Wiper motor controller [CN-141 (9) → (8)] → I/conn [CN-17 (6)] → I/conn [CN-5 (19)]
- → Washer pump [CN-22 (1)] → Washer pump operating

Wiper switch ON [CN-376 (3)] → I/conn[CN-5 (15)] → I/conn[CN-17 (2)]

→ Wiper motor controller [CN-141 (2) → (4)] → Wiper motor [CN-21 (2)] → Continual operating

(5) Auto parking (when switch OFF)


Switch OFF [CN-376 (3, 12)] - Wiper motor parking position by wiper motor controller

3) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (fuse box)	
	ON	② - GND (switch power input)	20~25V
		③ - GND (wiper power input)	
STOP		④ - GND (switch power output)	0 ~ 5V
		⑤ - GND (wiper power input)	0 ~ 5V
		⑥ - GND (wiper power output)	24V
		7 - GND (wiper motor)	0 or 24V


GND: Ground

^{*} The circuit diagram may differ from the equipment, so please check before a repair.




^{*} The circuit diagram may differ from the equipment, so please check before a repair.


CONTROLLER CIRCUIT




^{*} The circuit diagram may differ from the equipment, so please check before a repair.

MONITORING CIRCUIT





ELECTRIC CIRCUIT FOR HYDRAULIC (2/2)



GROUP 3 ELECTRICAL COMPONENT SPECIFICATION

Part name	Symbol	Specifications	Check
Battery		12V × 100Ah (2EA)	 Check specific gravity 1.280 over : Over charged 1.280 ~ 1.250 : Normal 1.250 below : Recharging
Battery relay	CR-1	Rated load: 24V 100A (continuity) 1000A (30 seconds)	 ※ Check coil resistance(M4 to M4) Normal : About 50 Ω ※ Check contact Normal : ∞ Ω
Start key	CS-2A	B-BR : 24V 1A B-ACC : 24V 10A B-C : 24V 40A	% Check contact OFF : $\infty \Omega$ (for each terminal) ON : 0Ω (for terminal 1-3 and 1-2) START : 0Ω (for terminal 1-6)
Pressure sensor	OA SUPPLY OB SIG OC RETURN CD-6 CD-7 CD-24 CD-31 CD-32 CD-35 CD-42 CD-43 CD-44 CD-69 CD-70 CD-71 CD-85 CD-86 CD-87 CD-90 CD-91 CD-124	8~30V	* Check contact Normal : 0.1 Ω
Resistor	2 O 3W/200 1 O RS-1	3W 200 Ω	* Check resistance 1-2:200 Ω
Breather heater	2 1 CN-80	24V	-

Part name	Symbol	Specifications	Check
Temperature sensor (hydraulic)	°C 10	-	 Check resistance 50°C : 804Ω 80°C : 310Ω 100°C : 180Ω
SMT CAN	○ C ○ C ○ B B ○ ○ A A ○ CS-2C	-	-
Air cleaner pressure switch	Pa OD-10	N.O TYPE	% Check contact High level : $\infty \Omega$ Low level : 0Ω
Fuel level sender	CD-2	-	* Check resistance Full : 50Ω 6/12 : 350Ω 11/12 : 100Ω 5/12 : 400Ω 10/12 : 150Ω 4/12 : 450Ω 9/12 : 200Ω 3/12 : 500Ω 8/12 : 250Ω 2/12 : 550Ω 7/12 : 300Ω 1/12 : 600Ω Empty warning : 700Ω
Relay (air con blower)	3 4 40 30 20 10 CR-46	24V 16A	% Check resistance Normal : About 200 Ω (for terminal 1-3) $\infty \Omega$ (for terminal 2-4)
Relay	CR-2 CR-4 CR-5 CR-7 CR-9 CR-101 CR-105 CR-106 CR-107 CR-108	24V 16A	% Check resistance Normal : About 160 Ω (for terminal 85-86) 0Ω (for terminal 30-87a) $\infty\Omega$ (for terminal 30-87)

Part name	Symbol	Specifications	Check
Solenoid valve	CN-66 CN-68 CN-70 CN-88 CN-135 CN-140 CN-149 CN-237 CN-262 CN-263 CN-367 CN-368 CN-369 CN-370 CN-419 CN-420 CN-421	24V 1A	% Check resistance Normal : 15~25 Ω (for terminal 1-2)
EPPR valve	CN-75 CN-133 CN-242 CN-309 CN-310 CN-365 CN-366 CN-378	700mA	* Check resistance Normal : 15~25 Ω (for terminal 1-2)
Speaker	O1 O2 CN-23(LH) CN-24(RH)	20W 86±2dB	※ Check resistance Normal : A few Ω
Switch (locking type)	CS-52 CS-67 CS-73 CS-73A CS-99	24V 1.5A	% Check contact Normal ON : 0 Ω (for terminal 7-3) $\infty \Omega$ (for terminal 7-9) OFF: $\infty \Omega$ (for terminal 7-3) 0 Ω (for terminal 7-9)
Room lamp	3 O 2 O 1 O	24V 10W	% Check disconnection Normal : 1.0Ω ON : 0Ω (For terminal 1-2) Ω (For terminal 1-3) OFF : Ω (For terminal 1-2) Ω (For terminal 1-3)
Switch (quick clamp)	CS-67	24V	% Check contact Normal ON : 0 Ω (for terminal 5-3) $\infty \Omega$ (for terminal 5-9) OFF: $\infty \Omega$ (for terminal 5-3) 0 Ω (for terminal 7-9)

Part name	Symbol	Specifications	Check
Switch (DPF)	CS-100	24V	** Check contact Normal I :0 Ω (for terminal 6-10) 0 : ∞ Ω (for terminal 6-4, 6-10) II : ∞ Ω (for terminal 6-10)
Head lamp, Work lamp, Cab lamp	CL-3 CL-4 CL-5 CL-6 CL-8 CL-9 CL-10	24V 65W (H3 Type)	* Check disconnection Normal : 1.2Ω
Beacon lamp	CL-7	24V 70W (H1 Type) 2.4W (LED Type)	※ Check disconnection Normal: A few Ω
Fuel filler pump	CN-61	24V 10A 35 ℓ /min	% Check resistance Normal : 1.0 Ω
Fuel feed pump	2 <u>M</u> 1 CN-145	24V	-
Hour meter	3 h 2 h 1 CN-48	16~32V	Check operation Supply power(24V) to terminal No.2 and connect terminal No.1 and ground

Part name	Symbol	Specifications	Check
Horn	CN-20 CN-25	22~28V 2A	Check operation Supply power(24V) to each terminal and connect ground.
Safety switch	B C O A O O B O C O C S-4	24V 15A (N.C TYPE)	* Check contact Normal : 1.0Ω ON : 0Ω (for terminal A-B) $\propto \Omega$ (for terminal A-C) OFF : $\propto \Omega$ (for terminal A-B) 0Ω (for terminal A-C)
Wiper cut switch	CS-53	24V (N.O TYPE)	% Check contact Normal : 0 Ω (one pin to ground)
Receiver dryer	Pa 2 0 1 0 CN-29	24V 2.5A (N.O TYPE)	% Check contact Normal : $ ∞$ Ω
Radio & USB player	ACC NLL- NLL- NLL- NLL- NLL- NLL- NLL- NL	24V 2A	* Check voltage 20~25V (for terminal 1-3, 3-8)
Washer pump	M 2 1 0 1 0 CN-22	24V 3.8A	% Check contact Normal : 10.7 Ω (for terminal 1-2)

Part name	Symbol	Specifications	Check
Wiper motor	3 0 10 0 20 0 30 0 40 0 60 6 0 CN-21	24V 2A	$\mbox{\@normal{\@norma}\@normal{\@nor$
DC/DC Converter	0 3 0 12V 12V 24V GND 24V CN-138	24V 3A	% Check voltage24V (for terminal 1-2)12V (for terminal 1-3)
Cigar lighter	CL-2	24V 5A 1.4W	 ※ Check coil resistance Normal : About 1MΩ ※ Check contact Normal : ∞ Ω Operating time : 5~15sec
Alternator	CN-74	Delco Remy 24V 65A	% Check contact Normal : 0Ω (for terminal B+-D+) Normal : 24~27.5V
Starter	M M H	24V 4.5kW	% Check contact Normal : 0.1Ω
Travel alarm	CN-81	24V 0.5A	** Check contact Normal: 5.2Ω

Part name	Symbol	Specifications	Check
Air conditioner compressor	CN-28 =	24V 79W	% Check contact Normal : 13.4 Ω
Start relay	CR-23	24V 300A	% Check contact Normal : 0.94Ω (for terminal 1-2)
Blower motor	2 <u>M</u>	24V 14A	% Check resistance Normal : 2.5Ω (for terminal 1-2)
Air conditioner duct sensor (switch)	020-0-0-	1°C OFF 4°C ON	** Check resistance Normal : 0 \Omega (for terminal 1-2), the atmosphere temp : Over 4°C
Door switch	CS-5 CS-29	24V 2W	* Check resistance Normal : About 5MΩ
Switch (power max, one touch decel, horn, breaker)		24V 6A	% Check resistance Normal : $∞ Ω$

Part name	Symbol	Specifications	Check
Circuit breaker	CN60 CN-95	CN-60 : 60A CN-95 : 90A	 Check disconnection Normal : 0 Ω (connect ring terminal and check resist between terminal 1 and 2)
Master switch	CS-74	6~36V	% Check disconnection Normal : 0.1Ω
Breaker pedal switch	CS-26A	-	-
Quick clamp buzzer	CN-113	24V 80mA Min 65dB	-
12V Socket	O1 O2 CN-139	12V 10A	-
Engine emergency stop switch	06 0 4 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	24V	% Check contactNormal0Ω (for terminal 1-2)

Part name	Symbol	Specifications	Check
Air inlet temperature sensor	O 1 AIR INLET TEMP O 2 AIR INLET GND CN-150	-	-
DOC inlet temperature sensor	O 2 DOC INLET TEMP GND O 1 DOC INLET TEMP SIG CN-152	-	-
DPF inlet temperature sensor	O 1 DPF INLET TEMP SIG O 2 DPF INLET TEMP GND CN-153	-	-
DPF pressure sensor	O 1 DPF PS SUPPLY O 2 DPF PS GND O 3 DPF PS SIG CD-154	-	-
WIF sensor	CL-40	-	※ Check disconnection Normal: 68.8~4.94 Ω
Proportional valve sensor	Proportional SIG CO CN-246(RH) CN-247(LH)	-	-

Part name	Symbol	Specifications	Check
Accel dial	CN-142	5V, 8mA	-
Accel dial LED	LED GND 2 LED + CN-267	24V	-
Temperature sensor (A/C incar, A/C ambient, water)	CN-429	-	-
Proportional valve sensor	O 1 SIG. VOLT(Us) O 2 SIG. VOLT(Udc) O 3 GND O 4 ERROR CN-308	-	-
Dozer act pressure switch	Pa 2 0 1 0 CD-50	N.O type	% Check resistance Normal : $∞$ $Ω$ (open)

Part name	Symbol	Specifications	Check
Camera	O 1	7V 100mA	-
Equalizer	0 1 INPUT-24V 0 2 GND 0 3 OUTPUT-12V 0 4 OUTPUT-12V CN-435	-	-
LAMBDA sensor	O 1 LAMBDA PUMP O 5 LAMBDA ADJUST O 3 LAMBDA HEATING O 4 LAMBDA BATT+ O 2 LAMBDA GND O 6 LAMBDA VOLT CD-151	-	-
PVG 32 controller	O1 CAN HI O2 CAN LO O3 GND O4 SAFETY O5 KEY IG GND O7 SV POWER SV GND O9 ROTATE / LH O10 NC NC CN-3	-	-

GROUP 4 CONNECTORS

1. CONNECTOR DESTINATION

Connector	Type	No. of	Destination	Connector part No.	
number	туре	pin	Destination	Female	Male
CN-1	AMP	10	I/conn (Frame harness-Pump PS harness)	S816-010002	S816-110002
CN-2	AMP	16	I/conn (Engine harness-Frame 2 harness)	368047-1	368050-1
CN-3	-	26	I/conn (Frame harness-Engine harness)	1897009-2	1897013-2
CN-3A	TYCO	12	I/conn (Frame harness-PVG controller harness)	174661-2	368537-1
CN-4	AMP	16	l/conn (Console harness LH-Frame harness)	368047-1	368050-1
CN-5	DEUTSCH	60	I/conn (Side harness RH-Frame harness)	DRB16-60SAE-L018	DRB14-60PAE-L018
CN-6	DEUTSCH	6	I/conn (Frame harness-Engine harness)	DT06-6S	DT04-6P
CN-7	AMP	16	I/conn (Console harness RH-Frame harness)	368047-1	368050-1
CN-8	AMP	15	I/conn (Console harness LH-Frame harness)	2-85262-1	368301-1
CN-9	DEUTSCH	12	I/conn (Frame harness- AAVM harness)	DT06-12S	DT04-12PA-P021
CN-10	TYCO	12	I/conn (Cab harness-Side harness RH)	368542-1	368507-1
CN-11	DEUTSCH	8	I/conn (Frame harness-Aircon harness)	DT06-8S	-
CN-12	DEUTSCH	2	I/conn (Frame harness-Boom wire harness)	DT06-2S-EP06	DT04-2P-E005
CN-13	AMP	8	I/conn (Frame harness-Boom floating harness)	174982-2	174984-2
CN-14	DEUTSCH	2	I/conn (Frame harness-Swing parking harness)	DT06-2S-EP06	DT04-2P-E005
CN-15	AMP	8	I/conn (Frame harness-2 way harness)	174982-2	174984-2
CN-16	AMP	6	Emergency engine start & speed control	-	S816-106002
CN-16A	AMP	6	Emergency engine start & speed control	S816-006002	-
CN-16B	AMP	6	Emergency engine start & speed control	S816-006002	S816-106002
CN-17	DEUTSCH	8	I/conn (Side harness RH-Wiper harness)	DT06-8S-EP06	DT04-8P
CN-20	MOLEX	2	Horn	36812-0211	-
CN-21	AMP	6	Wiper motor	S810-006202	-
CN-22	KET	2	Washer tank	MG640605	-
CN-23	KET	2	Speaker-LH	MG610070	-
CN-24	KET	2	Speaker-RH	MG610070	-
CN-25	MOLEX	2	Horn	36812-0211	-
CN-27	KUM	16	Radio & USB player	PK145-16017	-
CN-27A	AMP	8	Radio & USB player	-	S816-108002
CN-28	KUM	1	Air conditioner compressor	NMWP01F-B	-
CN-29	KET	2	Receiver dryer	MG640795	-
CN-36-1	AMP	16	To fuse box	368047-1	-
CN-36-2	KET	8	To fuse box	MG610051	-
CN-36-3	-	15	To fuse box	2-85262-1	-
CN-36-4	KET	2	To fuse box	MG610557-5	-

Connector	_	No. of	D # #	Connecto	r part No.
number	Type	pin	Destination	Female	Male
CN-45	RING-TERM	-	Starter motor B+	S820-108000	-
CN-48	KET	1	Hour meter	2-520193-2	-
CN-51	DEUTSCH	40	MCU	DRC26-40SA	-
CN-52	DEUTSCH	40	MCU	DRC26-40SB	-
CN-53	DEUTSCH	40	MCU (option)	DRC26-40SA	-
CN-56A	AMP	12	Cluster	-	174663-2
CN-56B	AMP	8	Cluster	-	174984-2
CN-60	YAZAKI	2	Circuit breaker	-	7122-4125-50
CN-61	DEUTSCH	2	Fuel filler pump	DT06-2S-EP06	-
CN-66	DEUTSCH	2	Breaker solenoid	DT06-2S-EP06	-
CN-68	DEUTSCH	2	Safety solenoid	DT06-2S-EP06	-
CN-70	DEUTSCH	2	Travel high solenoid	DT06-2S-EP06	-
CN-74	RING-TERM	1	Alternator "D+" terminal	-	S820-105000
CN-75	AMP	2	Pump EPPR valve	S816-002002	-
CN-80	FEP	-	Breather heater	4212110	-
CN-81	DEUTSCH	2	Travel buzzer	DT06-2S-EP06	DT04-2P-E005
CN-88	DEUTSCH	2	Power max solenoid	DT06-2S-EP06	-
CN-93A	DELPHI	10	EIC 1	15326600	-
CN-93B	AMP	62	EIC 2	1-148883-1	-
CN-93	-	60	ECU A1	284742-1	-
CN-94	-	94	ECU K1	284743-1	-
CN-95	-	2	Circuit breaker	-	S813-130201
CN-113	KET	2	Buzzer	MG651205-5	-
CN-125	Econoseal J	4	GPS connector	S816-004002	S816-104002
CN-125A	DEUTSCH	9	RMS	DT06-12S-EP06	HD10-9-96P
CN-126	AMP	10	I/conn (Service tool-Frame harness)	S816-010002	S816-110002
CN-126A	-	9	Service tool	-	HD10-9-96P
CN-133	DEUTSCH	2	Boom priority solenoid	DT06-2S-EP06	-
CN-135	DEUTSCH	2	Arm regeneration solenoid	DT06-2S-EP06	-
CN-138	FASTEN	3	DC/DC Converter	S810-003202	-
CN-139	FASTEN	2	12V socket	172434-2	-
CN-140	DEUTSCH	2	Quick clamp solenoid	DT06-2S-EP06	DT04-2P-E005
CN-141	AMP	13	Wiper motor controller	172498-1	-
CN-142	DEUTSCH	3	Accel dial	DT06-3S-EP06	-
CN-144A	KET	20	Handsfree	MG610240	-
CN-144E	-	8	Handsfree	175964-2	-
CN-145	DEUTSCH	2	Fuel filler pump	DT06-2S-EP06	-
CN-149	DEUTSCH	2	Attach safety solenoid	DT06-2S-EP06	-
CN-156	-	2	Air seat heat	-	S816-102002

Connector	Time	No. of	Dockinskien	Connecto	r part No.
number	Type	pin	Destination	Female	Male
CN-157	AMP	1	Antena power	S822-014002	-
CN-231	-	2	To fuse box	S813-030201	-
CN-237	DEUTSCH	2	Attach conflux solenoid	DT06-2S-EP06	-
CN-242	DEUTSCH	2	Attach EPPR 1	DT06-2S-EP06	-
CN-245	FCI	2	PTC power	-	-
CN-245A	AMP	12	Remote controller assy	368542-1	-
CN-245E	AMP	12	Remote controller assy	174045-2	-
CN-246	AMP	12	USB & socket assy	174045-2	-
CN-246	DEUTSCH	3	Proportional valve-RH	DT06-3S	DT04-3P
CN-246	DEUTSCH	8	USB & socket assy	DT06-08SA-EP06	DT04-8P
CN-247	DEUTSCH	3	Proportional valve-LH	DT06-3S	DT04-3P
CN-249	DEUTSCH	6	Rear view camera	-	DT04-6P
CN-259	AMP	6	Camera	S816-006002	S816-106002
CN-262	DEUTSCH	2	Straight travel solenoid	DT06-2S-EP06	-
CN-263	DEUTSCH	2	2 Piece solenoid	DT06-2S-EP06	-
CN-267	AMP	2	Accel dial LED	S816-002002	-
CN-305	DEUTSCH	12	To PVG controller	DTM06-12SA	-
CN-306	DEUTSCH	12	To PVG controller	DTM06-12SB	-
CN-307	DEUTSCH	3	Proportional-Service tool	DT06-3S-EP06	DT04-3P-E005
CN-308	AMP	4	Proportional-PVG32	2-967059-1	-
CN-309	DEUTSCH	2	Proportional-EPPR valve A1	DT06-2S-EP06	-
CN-310	DEUTSCH	2	Proportional-EPPR valve A2	DT06-2S-EP06	-
CN-365	DEUTSCH	2	Attach relief EPPR valve 1	DT06-2S-EP06	-
CN-366	DEUTSCH	2	Attach relief EPPR valve 2	DT06-2S-EP06	DT04-2P-E005
CN-367	DEUTSCH	2	Boom down floating solenoid	DT06-2S-E005	-
CN-368	DEUTSCH	2	Boom up floating solenoid	DT06-2S-E005	-
CN-369	DEUTSCH	2	Boom down cut off solenoid	DT06-2S-E005	-
CN-370	DEUTSCH	2	Swing fine control solenoid	DT06-2S-EP06	DT04-2P-E005
CN-376	AMP	34	Relay drive unit	4-1437290-1	-
CN-378	DEUTSCH	2	Attach EPPR 2	DT06-2S-EP06	-
CN-398	DEUTSCH	4	Service tool	DT06-4S	-
CN-398	DEUTSCH	4	Service tool	DT06-4S	-
CN-401	FCI	90	AAVM controller	A2C00021583	-
CN-403	DEUTSCH	6	Rear view camera	-	DT04-6P-EP14
CN-404	DEUTSCH	6	LH view camera	-	DT04-6P-EP14
CN-405	DEUTSCH	6	RH view camera	-	DT04-6P-EP14
CN-406	DEUTSCH	3	RS 232	DT06-3S-EP06	DT04-3P-E005
CN-419	DEUTSCH	2	Swing parking solenoid-A1	DT06-2S-EP06	-

Connector	Tuno	No. of	Destination	Connecto	r part No.
number	Туре	pin	Destination	Female	Male
CN-420	DEUTSCH	2	Swing parking solenoid-A2	DT06-2S-EP06	-
CN-421	DEUTSCH	2	Swing parking solenoid-A3	DT06-2S-EP06	-
CN-423	DEUTSCH	4	Tank header unit	DT06-4S	-
CN-425	AMP	2	SCR temperature sensor	282080-1	-
CN-426	AMP	2	DOC temperature sensor	282080-1	-
CN-427	MOLEX	4	Reader-RMS	039012040	026013096
CN-435	DEUTSCH	4	Equalizer	DT06-4S	-
CN-438	FIC	8	Glow plug controller	240PC089S0015	-
CN-BATT	YAZAKI	2	Battery B+	7222-4220-30	-
CN-GND	KET	1	Earth	DT640944-5	-
CN-J7A	AMP	6	NOx sensor (tail)	776433-2	-
CN-J7B	AMP	6	NOx sensor (turbo out)	776433-1	-
· Relay				-	
CR-1	RING-TERM	-	Battery relay	ST710289-2	-
CR-2	-	5	Horn relay	-	-
CR-4	-	5	Work lamp relay	8JA 003 526-001	-
CR-5	-	5	Anti restart relay	-	-
CR-7	-	5	Aircon compressor relay	-	-
CR-9	-	5	Cabin lamp relay	8JA 003 526-001	-
CR-13	-	5	Head lamp relay	8JA 003 526-001	-
CR-23	KET	2	Start relay	-	MG640322
CR-23A	-	-	Start relay	MG612017-5	-
CR-24	RING TERM	1	Preheat relay	S822-014000	-
CR-35	-	5	Power relay	-	-
CR-36	-	5	Preheat relay	-	-
CR-45	-	5	ECU IG relay	8JA 003 526-001	-
CR-85	-	5	Beacon lamp relay	8JA 003 526-001	-
CR-95	-	5	Feed pump relay	8JA 003 526-001	-
CR-105	-	5	Equalizer	8JA 003 526-001	-
CR-106	-	5	ECU battery relay	MG612017-5	-
CR-107	-	5	DPF relay	8JA 003 526-001	-
CR-108	-	5	ECU start relay	8JA 003 526-001	-
· Switch	1	ı		1	1
CS-1	SHUR	1	Door switch	S822-014002	-
CS-2A	WP	6	Start key switch	S814-006100	-
CS-2B	DEUTSCH	3	Start button	DT06-3S-EP06	DT04-3P-E005
CS-4	AMP	3	Safety switch	S816-003002	-
CS-5	DEUTSCH	2	Horn switch	-	DT04-2P-E005
CS-19	DEUTSCH	2	One touch decel switch	-	DT04-2P-E005


Connector	Trees	No. of	Dealisation	Connecto	r part No.
number	Type	pin	Destination	Female	Male
CS-26	DEUTSCH	2	Breaker switch	DT06-2S-EP06	-
CS-26A	AMP	2	Breaker pedal switch	S816-002002	S816-102002
CS-29	DEUTSCH	2	Power max switch	DT06-2S-EP06	-
CS-33	AMP	6	Emergency engine stop switch	S816-006002	S816-106002
CS-52	SWF	12	Adjust & dozer switch	SWF589790	-
CS-53	AMP	1	Wiper cut switch	S822-014002	-
CS-67	SWF	12	Quick clamp switch	SWF589790	-
CS-73	SWF	12	Swing lock switch	SWF589790	-
CS-73A	SWF	12	Swing fine switch	SWF589790	-
CS-74A	AMP	2	Master switch	S813-030201	-
CS-74B	DEUTSCH	2	Master switch	DT06-2S-EP06	-
CS-83	SWF	12	Spare switch	SWF589790	-
CS-99	SWF	12	Air compressor switch	SWF589790	-
CS-100	SWF	12	Spare switch	SWF589790	-
CS-107	SWF	12	Travel straight switch	SWF589790	-
CS-111	SWF	12	Boom floating switch	SWF589790	-
· Light					
CL-1	KET	3	Room lamp	MG651032	-
CL-2	AMP	1	Cigar lighter	S822-014002	S822-114002
CL-3	DEUTSCH	2	Head lamp-LH	DT06-2S-EP06	-
CL-4	DEUTSCH	2	Head lamp-RH	DT06-2S-EP06	-
CL-5	DEUTSCH	2	Work lamp-LH	DT06-2S	-
CL-6	DEUTSCH	2	Work lamp-RH	DT06-2S	-
CL-7	SHUR	1	Beacon lamp	S822-014002	S822-114002
CL-8	DEUTSCH	2	Cab light-LH	DT06-2S-EP06	DT04-2P
CL-9	DEUTSCH	2	Cab light-RH	DT06-2S-EP06	DT04-2P
CL-10	DEUTSCH	2	Cab light-rear	DT06-2S-EP06	DT04-2P
· Sensor, se	endor				
CD-1	AMP	2	Hydraulic oil temp sender	85202-1	-
CD-2	DEUTSCH	2	Fuel sender	DT06-2S-EP06	-
CD-6	DEUTSCH	3	Travel pressure switch	DT06-3S-EP06	-
CD-7	DEUTSCH	3	Working pressure switch	DT06-3S-EP06	-
CD-10	AMP	2	Air cleaner switch	85202-1	-
CD-16	DELPHI	3	Water level sensor	12110293	-
CD-24	DEUTSCH	3	Swing pressure sensor	DT06-3S-EP06	-
CD-31	DEUTSCH	3	Overload pressure sensor	DT06-3S-EP06	DT04-3P-E004
CD-32	DEUTSCH	3	Boom up pressure sensor	DT06-3S-EP06	-
CD-35	DEUTSCH	3	Arm in/out pressure sensor	DT06-3S-EP06	-
CD-42	DEUTSCH	3	Pump pressure sensor 1	DT06-3S-EP06	-

Connector	T	No. of	Dockinskies	Connecto	r part No.
number	Type	pin	Destination	Female	Male
CD-43	DEUTSCH	3	Pump pressure sensor 2	DT06-3S-EP06	-
CD-44	DEUTSCH	3	Pump pressure sensor 3	DT06-3S-EP06	-
CD-45	AMP	3	WIF sensor	282191-1	-
CD-50	KET	2	Dozer pressure sensor	MG640795	-
CD-69	DEUTSCH	3	Attach pressure sensor	DT06-3S-EP06	-
CD-70	DEUTSCH	3	N1 pressure sensor	DT06-3S-EP06	-
CD-71	DEUTSCH	3	N2 pressure sensor	DT06-3S-EP06	-
CD-85	DEUTSCH	3	Boom down sensor	DT06-3S-EP06	-
CD-86	DEUTSCH	3	Arm out pressure sensor	DT06-3S-E005	-
CD-87	DEUTSCH	3	Bucket out pressure sensor	DT06-3S-E005	-
CD-90	DEUTSCH	3	Arm in pressure sensor	DT06-3S-EP06	-
CD-91	DEUTSCH	3	Bucket in pressure sensor	DT06-3S-E005	-
CD-98	AMP	2	Air inlet temperature sensor	776427-1	-
CD-98A	AMP	2	Air intake temperature sensor	776427-1	-
CD-124	DEUTSCH	3	Boom cylinder rod pressure snensor	DT06-3S-E005	-
CD-150	AMP	2	Air inlet temperature sensor	85202-1	-
CD-151	BOSCH	6	Lambda snensor	1 928 404900	-
CD-152	BOSCH	2	DOC inlet temperature sensor	1 928 403876	-
CD-153	BOSCH	2	DPF inlet temperature sensor	1 928 403876	-
CD-154	BOSCH	3	DPF pressure snensor	1 928 403966	-

2. CONNECTION TABLE FOR CONNECTORS

1) PATYPE CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
5	2 5 1 3	1 3 2 5
7	S811-005002	3 7
9	4 9 1 5 S811-009002	1 5 7 7 7 7 7 7 7 9
11	5 11 1 6 S811-011002	1 6 5 11 S811-111002




2) J TYPE CONNECTOR

No. of pin	Receptacle conne	ector (female)	Plug connector	(male)
2		2 S816-002001		2 1 S816-102001
3		3 1 S816-003001		3 1 2 S816-103001
4		3 1 4 2 S816-004001		3 1 S816-104001
8		6 3 1 8 5 2 S816-008001		8 5 2 1000 6 3 1 S816-108001


3) SWP TYPE CONNECTOR

No. of pin	Receptacle connector	(female)	Plug connector (n	nale)
1		S814-001000		S814-101000
2		2 1 S814-002000		1 2 S814-102000
3		3 2 1 S814-003000		2 3 S814-103000
4		2 4 1 3 S814-004000		1 3 2 4 S814-104000




4) CN TYPE CONNECTOR


No. of pin	Receptacle connecto	or (female)	Plug connector (male)
1		1		1
		S810-001202		S810-101202
2		1		1
		S810-002202		S810-102202
3		1 2		1 3
		S810-003202		S810-103202
4		2 4		1 3
		S810-004202		S810-104202




5) 375 FASTEN TYPE CONNECTOR



6) AMP ECONOSEAL CONNECTOR



7) AMP TIMER CONNECTOR




8) AMP 040 MULTILOCK CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
12	7	
	174045-2	

9) AMP 070 MULTILOCK CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
14	1 7 14 173852	

10) AMP FASTIN - FASTON CONNECTOR



11) KET 090 CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	1 2	
	MG610070	


12) KET 090 WP CONNECTORS

No. of pin	Receptacle connector (female)	Plug connector (male)
2	1 2 MG640605	
2	1 2	
	MG640795	

13) KET SDL CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
14	7	
	MG610406	

14) DEUTSCH DT CONNECTORS



Modification

E003: Standard end cap - gray

E004 : Color of connector to be black E005 : Combination - E004 & E003

EP04: End cap

EP06: Combination P012 & EP04

P012: Front seal enhancement - connectors color to black for 2, 3, 4 & 6pin

No. of pin	Receptacle connector (female)	Plug connector (male)
2		1 2
	DT06-2S	DT04-2P
3	1 2 3	2 1 3
	DT06-3S	DT04-3P
4	1 4 2 3	3 2
	DT06-4S	DT04-4P

No. of pin	Receptacle connector (female)	Plug connector (male)
6	3 4	6 1 4 3
	DT06-6S	DT04-6P
8	5 4 8 1	1 8
	DT06-8S	DT04-8P
12	7 6	1 12
	DT06-12S	DT04-12P

15) MOLEX 2CKTS CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	1 2	
	35215-0200	

16) ITT SWF CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
10	1 9	
	SWF593757	

17) MWP NMWP CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
1	1	
	NMWP01F-B	

18) ECONOSEAL J TYPE CONNECTORS

No. of pin	Receptacle connector (female)	Plug connector (male)
1	S816-001002	S816-101002
2	1 2 S816-002002	2 1 S816-102002
3	1 2 3 S816-003002	3 2 1 S816-103002
4	3 4 S816-004002	2 1 4 3 S816-104002


No. of pin	Receptacle connector (female)	Plug connector (male)
6	3 4 6 S816-006002	3 1 6 4 S816-106002
8	5 8 S816-008002	4 1 8 5 S816-108002
10	5 6 10 S816-010002	5 10 6 S816-110002
12	7 12 S816-012002	6 1 12 7 S816-112002

No. of pin	Receptacle connector (female)	Plug connector (male)
15	3 15 HERE E E E E E E E E E E E E E E E E E E	15 3 18 18 19 13
	368301-1	2-85262-1

19) METRI-PACK TYPE CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	12040753	
	12040753	

20) DEUTSCH HD30 CONNECTOR



21) DEUTSCH MCU CONNECTOR

No. of pin	Receptacle connector (Female)	Plug connector (Male)
40	11 21 31 35 36 40 30 DRC26-40SA/B	
	DRC20-405A/B	

22) DEUTSCH SERVICE TOOL CONNECTOR

9 F G B	No. of pin	Receptacle connector (Female)	Plug connector (Male)
HD10-9-96P	9	E A B B H	

23) AMP FUEL WARMER CONNECTOR

No. of pin	Receptacle connector (Female)	Plug connector (Male)
4	3 2 4	
	2-967325-3	

24) DEUTSCH ENGINE ECM CONNECTOR

No. of pin	Receptacle connector (Female)	Plug connector (Male)
50	11 5 6 10 20 20 20 41 45 46 50 40 DRC26-50S-04	

25) DEUTSCH INTERMEDIATE CONNECTOR

No. of pin	Receptacle connector (Female)	Plug connector (Male)
60	1 13 25 31 37 49 24 30 36 49 48 60 DRB16-60SAE-L018	


SECTION 5 MECHATRONICS SYSTEM

Group	1	Outline	5-1
Group	2	Mode Selection System ····	5-3
Group	3	Automatic Deceleration System ·····	5-6
Group	4	Power Boost System	5-7
Group	5	Travel Speed Control System	5-8
Group	6	Automatic Warming Up System	5-9
Group	7	Engine Overheat Prevention System ·····	5-10
Group	8	Variable Power Control System ·····	5-11
Group	9	Attachment Flow Control System	5-12
Group	10	Intelligent Power Control System ·····	5-13
Group	11	Anti-Restart System	5-15
Group	12	Self-Diagnostic System ·····	5-16
Group	13	Engine Control System ·····	5-62
Group	14	EPPR Valve	5-63
Group	15	Monitoring System ····	5-68
Group	16	Fuel Warmer System	5-105
Group	17	1 or 2-Way Optional Piping Pressure Removal System	5-106


GROUP 1 OUTLINE

The ADVANCED CAPO (Computer Aided Power Optimization) system controls engine and pump mutual power at an optimum and less fuel consuming state for the selected work by mode selection, auto-deceleration, power boost function, etc. It monitors machine conditions, for instance, engine speed, coolant temperature, hydraulic oil temperature, and hydraulic oil pressure, etc.

It consists of two MCU, a cluster, an ECM, EPPR valves, and other components. The MCU and the cluster protect themselves from over-current and high voltage input, and diagnose malfunctions caused by short or open circuit in electric system, and display error codes on the cluster.




SYSTEM DIAGRAM



130A5MS01

GROUP 2 MODE SELECTION SYSTEM

1. POWER MODE SELECTION SYSTEM



Mode selection system (micro computer based electro-hydraulic pump and engine mutual control system) optimizes the engine and pump performance.


The combination of 3 power modes (P, S, E) and accel dial position (10 set) makes it possible to use the engine and pump power more effectively corresponding to the work conditions from a heavy and great power requesting work to a light and precise work.

		Engine rpm				Pump EPPR (kgf/cm²)			
Power mode	Application	on Standard		Option		Standard		Option	
		No load	Load	No load	Load	No load	Load	No load	Load
Р	Heavy duty power	1850	1950	1950	1950	10	3	8	3
S	Standard power	1750	1850	1850	1850	12	5	9	4
Е	Economy operation	1650	1750	1750	1750	12	5	10	5
Auto decel	Engine deceleration	1200±50	-	1200±50	-	38	38	38	38
One touch decel	Engine quick deceleration	1100±50	-	1100±50	-	38	38	38	38
Key start	Key switch start position	1000±50	-	1000±50	-	38	38	38	38

- * Power shift (Standard/Option) can be changed by "Service menu" in "Management" on the cluster.
- In work modes, engine speed stays at 1000 rpm if the safety lever is at "LOCK" position. (Low idle goes to 1100 rpm if "UNLOCK")
- * Auto decel, one touch decel and low idle speed may increase to 1400 rpm while automatic exhaust system cleaning is being performed.

2. WORK MODE SELECTION SYSTEM

Work mode consists of the general operation (bucket) and the optional attachment (breaker, crusher).



1) GENERAL WORK MODE (bucket)

This mode is used to general digging work.


2) ATT WORK MODE (breaker, crusher)

It controls the pump flow and system pressure according to the operation of breaker or crusher.

Description	General mode	Work tool		
Description	Bucket	Breaker	Crusher	
Attachment safety solenoid	OFF	-	ON	
Attachment conflux solenoid	OFF	ON/OFF	ON/OFF	
Attachment flow EPPR current	100 mA	100~700 mA	100~700 mA	
Breaker solenoid*	OFF	ON	-	

[★] When breaker operating button is pushed.

3. USER MODE SELECTION SYSTEM




1) Engine speed, idle speed and pump power shift pressure can be adjusted and memorized in the U-mode.

2) LCD segment vs parameter setting

Step (■)	Engine speed (rpm)	Idle speed (rpm)	Power shift pressure (bar)
1	1300	750	0
2	1400	800	3
3	1500	850	6
4	1600	900	9
5	1700	950	12
6	1800	1000	16
7	1850	1050	20
8	1900	1100	26
9	1950	1150	32
10	2000	1200 (auto decel)	38

* Refer to the page 5-86.

3. USER MODE SELECTION SYSTEM



130A5MS04


1) Engine speed, idle speed and pump power shift pressure can be adjusted and memorized in the U-mode.

2) LCD segment vs parameter setting

Step (▮)	Engine speed (rpm)	Idle speed (rpm)	Power shift pressure (bar)
1	1300	750	0
2	1400	800	3
3	1500	850	6
4	1600	900	9
5	1700	950	12
6	1800	1000	16
7	1850	1050	20
8	1900	1100	26
9	1950	1150	32
10	2000	1200 (auto decel)	38

* Refer to the page 5-86.


GROUP 3 AUTOMATIC DECELERATION SYSTEM



1. WHEN AUTO IDLE PILOT LAMP ON

When all of the work equipment control levers including swing and travel levers are at neutral for 4 seconds, MCU sends throttle command to ECM to reduce the engine speed to 1200 rpm. If the control levers are at neutral for 1 minute, MCU reduces the engine speed to 1100 rpm. As the result of reducing the engine speed, fuel consumption and noise are effectively cut down during non-operation of the control levers.

When the auto idle pilot lamp is turned off by pressing the switch or any control lever is operated, the reduced engine speed rises upto the speed before deceleration in a second.




2. WHEN AUTO IDLE PILOT LAMP OFF

The engine speed can be set as desired using the accel dial, and even if the control levers are neutral, the engine speed is not reduced.

* Auto idle function can be activated when accel dial position is over 4.

GROUP 4 POWER BOOST SYSTEM




- When the power boost switch on the left control lever is pushed ON, the power mode is set P mode and maximum digging power is increased by 10 %.
- When the power boost function is activated, the power boost solenoid valve pilot pressure raises the set pressure of the main relief valve to increase the digging power.

Description	Condition	Function
Activated	Power boost switch : ON Accel dial : over 8	- Power mode : P - Accel dial power : 9 - Power boost solenoid : ON - Power boost pilot Imap : ON - Operating time : max 8 seconds
Canceled	Power boost switch : OFF	- Pre-set power mode- Power boost solenoid : OFF- Power boost pilot lamp : OFF

When the auto power boost is set to Enable and power mode is set to P mode on the cluster, the digging power is automatically increased as working conditions by the MCU. It is operated max 8 seconds.

GROUP 5 TRAVEL SPEED CONTROL SYSTEM




130A5MS07

Travel speed can be switched manually by pressing the travel speed switch on the cluster.

Speed	Travel speed solenoid valve	Lamp on cluster	Operation
Low	OFF	Turtle	Low speed, high driving torque in the travel motor
High	ON	Rabbit	High speed, low driving torque in the travel motor

* Default : Turtle (Low speed)

GROUP 6 AUTOMATIC WARMING UP SYSTEM




- 130A5MS08
- The MCU receives the engine coolant temperature from the ECM, and if the coolant temperature is below 30°C, it increases the engine speed from key start rpm to 1200 rpm. At this time the mode does not change. If the coolant temperature sensor has fault, the hydraulic oil temperature signal is substituted.
- 2. In case of the coolant temperature increases up to 30°C, the engine speed is decreased to key start speed. And if an operator changes power mode set during the warming up function, the MCU cancels the automatic warming up function.

3. LOGIC TABLE

Description	Condition	Function
Actuated	- Coolant temperature : Below 30°C (after engine run)	- Power mode : Default (E mode) - Warming up time : 10 minutes (max) - Warming up pilot lamp : ON
Canceled	- Coolant temperature : Above 30°C - Warming up time : Above 10 minutes - Changed power mode set by operator - RCV lever or pedal operating - Auto idle cancel * If any of the above conditions is applicable, the automatic warming up function is canceled	- Power mode : set mode - Warming up pilot lamp : OFF

GROUP 7 ENGINE OVERHEAT PREVENTION SYSTEM




1. If the engine coolant temperature overheated over 103°C or the hydraulic oil temperature overheated over 100°C is overheated over set temperature, the warning lamp is ON and the pump input torque or the engine speed is reduced as below logic table.

2. LOGIC TABLE

Description		Condition	Function		
First step warning	Activated	- Coolant temperature : Above 103°C - Hydraulic oil temperature : Above 100°C	Warning lamp: Pops up and buzzer sounds.Pump input torque is reduced.		
	Canceled	- Coolant temperature : Less than 100°C - Hydraulic oil temperature : Less than 95°C	- Return to pre-set the pump absorption torque.		
Second stop	Activated	- Coolant temperature : Above 107°C - Hydraulic oil temperature : Above 105°C	Emergency warning lamp pops up on the center of LCD and the buzzer sounds.Engine speed is reduced after 10 seconds.		
Second step warning	Canceled	- Coolant temperature : Less than 103°C - Hydraulic oil temperature : Less than 100°C	 Return to pre-set the engine speed. Hold pump absorption torque on the first step warning. 		

GROUP 8 NEW VARIABLE POWER CONTROL SYSTEM




The new variable power control system makes constantly exact pump control through improvement variable engine speed control and response and optimization of control input sensor signal.

It makes fuel saving and smooth control at precise work.

Description	Function		
Description	Stand by	Working	
Engine speed	- 100 ~ 150 rpm lower than working	- Set rpm	
Pump EPPR	- 13 bar	- 8 bar	
Pump flow	- Lower than working	- Normal pump flow	

* The variable power control function can be activated at all of the power mode.

GROUP 9 ATTACHMENT FLOW CONTROL SYSTEM




130A5MS11

• The system is used to control the pump delivery flow according to set of the work tool on the cluster by the attachment flow EPPR valve.

Description	Work tool			
Description	Breaker	Crusher		
Flow level	100 ~ 180 lpm	100 ~ 440 lpm		
Attach safety solenoid	-	ON		
Attach conflux solenoid	ON/OFF	ON/OFF		
Breaker solenoid*	ON	-		

- * Refer to the page 5-86 for the attachment kinds and max flow.
- ★ When breaker operating switch is pushed.

GROUP 10 INTELLIGENT POWER CONTROL SYSTEM



1. When the requirement of pump flow rate is low, IPC mode controls pump flow rate to improve fuel efficiency. The function works only in Balance or Efficiency mode.

Condition	Function		
Arm in with boom up			
Boom down with other actuator	Limitation of account flavourate . A stimulated		
Starting point when swing operation	Limitation of pump flow rate : Activated		
Reduction for fuel when idle condition			
None of upper condition	Limitation of pump flow rate : Canceled		

1) ARM IN WITH BOOM UP

A fuel efficiency is improved by maximizing arm regeneration by reducing pump flow rate during boom up and arm in combination operation.

2) BOOM DOWN WITH OTHER ACTUATOR

The flow for boom-down is replaced with regeneration-flow as much as possible, and fuel consumption is reduced by reducing the flow rate of the pump.

3) STARTING POINT WHEN SWING OPERATION

A technology reduces the amount of flow that is wasted to the swing relief due to the inertia at the beginning of the swing start.


4) REDUCTION FOR FUEL WHEN IDLE CONDITION

A technology reduces energy loss due to unnecessary pump volume increase in idle state before the machine operation.

2. IPC MODE SELECTION


The levels of flow rate limit depends on at IPC mode.





IPC mode	Description
Balance mode	Fuel eifficiency ON, limit level 1
Efficiency mode	Fuel eifficiency ON, limit level 2
Speed mode	Fuel eifficiency OFF

GROUP 11 ANTI-RESTART SYSTEM



130A5MS12

1. ANTI-RESTART FUNCTION

After a few seconds from the engine starts to run, MCU turns off the anti-restart relay to protect the starter from inadvertent restarting.

GROUP 12 SELF-DIAGNOSTIC SYSTEM

1. OUTLINE

When any abnormality occurs in the ADVANCED CAPO system caused by electric parts malfunction and by open or short circuit, the MCU diagnoses the problem and sends the error codes to the cluster and also stores them in the memory.

2. MONITORING

1) Active fault



· The active faults of the MCU, engine ECM can be checked by this menu.

2) Logged fault



· The logged faults of the MCU, engine ECM can be checked by this menu.

3) Delete logged fault



· The logged faults of the MCU, engine ECM can be deleted by this menu.

3. MACHINE ERROR CODES TABLE

DTC	;		Ap	plicat	ion		
HCESPN	FMI	Diagnostic Criteria	G	С	W		
	3	10 seconds continuous, Hydraulic Oil Temp. Measurement Voltage > 3.8V	•				
	4	10 seconds continuous, Hydraulic Oil Temp. Measurement Voltage < 0.3V					
101	(Resu	ults / Symptoms)					
	1. Mo	nitor – Hydraulic oil temperature display failure					
	2. Cor	ntrol Function – Fan revolutions control failure					
	,	king list)					
		-1 (#2), CN-51 (#16) Checking Open/Short					
	2. CD	-1 (#1), CN-51 (#24) Checking Open/Short					
	0	10 seconds continuous, Working Press. Sensor					
		Measurement Voltage > 5.2V					
	1	10 seconds continuous, 0.3V≤ Working Press. Sensor Measurement Voltage					
		< 0.8V					
	4	10 seconds continuous, Working Press. Sensor Measurement Voltage < 0.3V					
	(Pool						
105	(Results / Symptoms)						
	Monitor – Working Press, display failure Control Function — Auto Idla experition failure. Engine veriable berge newer central energing.						
	2. Control Function – Auto Idle operation failure, Engine variable horse power control operation failure						
	(Chec	sking list)					
	٠,	-7 (#B) – CN-52 (#19) Checking Open/Short					
		-7 (#A) – CN-51 (#32) Checking Open/Short					
		-7 (#C) – CN-51 (#31) Checking Open/Short					
	_	10 seconds continuous, Travel Oil Press. Sensor					
	0	Measurement Voltage > 5.2V					
	1	10 seconds continuous, 0.3V ≤ Travel Oil Press. Sensor Measurement					
	'	Voltage < 0.8V					
	4	10 seconds continuous, Travel Oil Press. Sensor					
		Measurement Voltage < 0.3V					
108	,	ılts / Symptoms)					
		nitor – Travel Oil Press. display failure					
	2. Cor	ntrol Function – Auto Idle operation failure, Engine variable horse power control	opera	tion			
	(Char	failure, IPC operation failure, Driving alarm operation failure					
	٠,	Sking list) 6 (#R) CN 53 (#37) Chacking Open/Short					
		-6 (#B) – CN-52 (#27) Checking Open/Short -6 (#A) – CN-51 (#32) Checking Open/Short					
		-6 (#C) – CN-51 (#31) Checking Open/Short					
	J. UD	-0 (#0) - 014-01 (#01) OHEONING OPEN/OHOR					

※ Some error codes are not applied to this machine.

DTC	;		Ap	plicat	ion		
HCESPN	FMI	Diagnostic Criteria	G	С	W		
	0	10 seconds continuous, Main Pump 1 (P1) Press. Sensor Measurement	•				
		Voltage > 5.2V 10 seconds continuous, 0.3V ≤ Main Pump 1 (P1) Press. Sensor					
	1	Measurement Voltage < 0.8V					
		10 seconds continuous, Main Pump 1 (P1) Press. Sensor Measurement					
	4	Voltage < 0.3V					
100	(Resu	lts / Symptoms)					
120	1. Mor	nitor – Main Pump 1 (P1) Press. display failure					
	2. Cor	ntrol Function – Automatic voltage increase operation failure, Overload at compe	nsati	on co	ntrol		
	,	failure					
	l '	king list)					
		-42 (#B) – CN-52 (#22) Checking Open/Short -42 (#A) – CN-51 (#32) Checking Open/Short					
		-42 (#A) – CN-51 (#32) Checking Open/Short					
	0.00	10 seconds continuous, Main Pump 2 (P2) Press. Sensor Measurement					
	0	Voltage > 5.2V					
	1	10 seconds continuous, 0.3V≤ Main Pump 2 (P2) Press. Sensor					
		Measurement Voltage < 0.8V					
	4	10 seconds continuous, Main Pump 2 (P2) Press. Sensor Measurement Voltage < 0.3V	•				
	(Results / Symptoms)						
121	1. Monitor – Main Pump 2 (P2) Press. display failure						
	Control Function – Automatic voltage increase operation failure, Overload at compensation control						
	failure						
	(Chec	king list)					
	1. CD-43 (#B) - CN-52 (#14) Checking Open/Short						
		-43 (#A) – CN-51 (#32) Checking Open/Short					
	3. CD-	-43 (#C) – CN-51 (#31) Checking Open/Short					
	4	(when you had conditions mounting pressure sensor)					
	1	10 seconds continuous, 0.3V ≤ Overload Press. Sensor Measurement Voltage < 0.8V					
		(when you had conditions mounting pressure sensor)					
	4	10 seconds continuous, Overload Press. Sensor					
		Measurement Voltage < 0.3V					
122	(Resu	Its / Symptoms)					
	Monitor – Overload Press. display failure						
	2. Control Function – Overload warning alarm failure						
	l '	king list)					
	1. CD-31 (#B) – CN-52 (#28) Checking Open/Short						
		31 (#A) – CN-51 (#32) Checking Open/Short					
	J. CD.	31 (#C) – CN-51 (#31) Checking Open/Short					

DTC	;	Dia was atta Oritaria	Ар	plicat	ion			
HCESPN	FMI	Diagnostic Criteria	G	С	W			
	0	10 seconds continuous, Negative 1 Press. Sensor						
	U	Measurement Voltage > 5.2V						
	1	10 seconds continuous, 0.3V≤ Negative 1 Press. Sensor Measurement						
		Voltage < 0.8V						
	4	10 seconds continuous, Negative 1 Press. Sensor						
	/D	Measurement Voltage < 0.3V						
123	l '	Its / Symptoms)						
		nitor – Negative 1 Press. display failure	مناييده					
		ntrol Function – IPC operation failure, Option attachment flow control operation faction faction from the control operation from the	allure					
	l '	-70 (#B) – CN-51 (#22) Checking Open/Short						
		-70 (#A) – CN-51 (#32) Checking Open/Short						
		-70 (#C) – CN-51 (#31) Checking Open/Short						
	0.00	10 seconds continuous, Negative 2 Press. Sensor						
	0	Measurement Voltage > 5.2V						
		10 seconds continuous, 0.3V≤ Negative 2 Press. Sensor Measurement						
	1	Voltage < 0.8V						
	4	10 seconds continuous, Negative 2 Press. Sensor						
		Measurement Voltage < 0.3V						
124	(Results / Symptoms)							
	1. Mor	Monitor – Negative 2 Press. display failure						
	2. Cor	ntrol Function – Option attachment flow control operation failure						
	(Chec	king list)						
		-71 (#B) – CN-51 (#28) Checking Open/Short						
		-71 (#A) – CN-51 (#32) Checking Open/Short						
	3. CD-	-71 (#C) – CN-51 (#31) Checking Open/Short						
	0	10 seconds continuous, Boom Up Pilot Press. Sensor						
		Measurement Voltage > 5.2V						
	1	10 seconds continuous, 0.3V≤ Boom Up Pilot Press. Sensor Measurement						
		Voltage < 0.8V			-			
	4	10 seconds continuous, Boom Up Pilot Press. Sensor Measurement < 0.3V						
407	`	Its / Symptoms)						
127	1. Monitor – Boom Up Pilot Press. display failure							
	2. Control Function – Engine/Pump variable horse power control operation failure, IPC operation							
	(Choo	failure, Boom first operation failure king list)						
	l '							
	1. CD-32 (#B) – CN-52 (#23) Checking Open/Short 2. CD-32 (#A) – CN-51 (#32) Checking Open/Short							
		-32 (#C) – CN-51 (#31) Checking Open/Short						
1	0.05	(,,)						

DTC		Discounting Office in	Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W
128	0	(when you had conditions mounting pressure sensor) 10 seconds continuous, Boom Down Pilot Press. Sensor Measurement Voltage > 5.2V	•		
	1	(when you had conditions mounting pressure sensor) 10 seconds continuous, 0.3V≤ Boom Down Pilot Press. Sensor Measurement Voltage < 0.8V	•		
	4	(when you had conditions mounting pressure sensor) 10 seconds continuous, Boom Down Pilot Press. Sensor Measurement Voltage < 0.3V	•		
	1. Mor 2. Cor (Chec 1. CD- 2. CD-	Its / Symptoms) nitor – Boom Down Pilot Press. display failure strol Function – Boom floating operation failure king list) 85 (#B) – CN-52 (#31) Checking Open/Short 85 (#A) – CN-51 (#32) Checking Open/Short 85 (#C) – CN-51 (#31) Checking Open/Short			
	3. OD-	10 seconds continuous, Arm In Pilot Press. Sensor			
	0	Measurement Voltage > 4.8V			
	1	10 seconds continuous, 0.3V≤ Arm In Pilot Press. Sensor Measurement Voltage < 0.8V	•		
	4	10 seconds continuous, Arm In Pilot Press. Sensor Measurement Voltage < 0.3V	•		
129	1. Mor 2. Cor (Chec 1. CD- 2. CD-	Its / Symptoms) nitor – Arm In Pilot Press. display failure strol Function – IPC operation failure king list) 90 (#B) – CN-51 (#21) Checking Open/Short 90 (#A) – CN-51 (#32) Checking Open/Short 90 (#C) – CN-51 (#31) Checking Open/Short			
	0	10 seconds continuous, Arm Out Pilot Press. Sensor Measurement Voltage > 5.2V	•		
	1	10 seconds continuous, 0.3V≤ Arm Out Pilot Press. Sensor Measurement Voltage < 0.8V	•		
130	4	10 seconds continuous, Arm Out Pilot Press. Sensor Measurement Voltage < 0.3V	•		
	1. Mor 2. Cor (Chec 1. CD- 2. CD-	Its / Symptoms) nitor – Arm Out Pilot Press. display failure strol Function – Engine variable horse power control operation failure king list) 86 (#B) – CN-51 (#27) Checking Open/Short 86 (#A) – CN-51 (#32) Checking Open/Short 86 (#C) – CN-51 (#31) Checking Open/Short			

* Some error codes are not applied to this machine.

DTC	;	Discounting Office to	Ар	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	0	10 seconds continuous, Swing Pilot Press. Sensor			
	U	Measurement Voltage > 5.2V			
	1	10 seconds continuous, 0.3V≤ Swing Pilot Press. Sensor Measurement			
		Voltage < 0.8V			
	4	10 seconds continuous, Swing Pilot Press. Sensor			
		Measurement Voltage < 0.3V			
135	١,	Its / Symptoms)			
		nitor – Swing Pilot Press. display failure			
		ntrol Function – IPC operation, Boom first operation failure			
	١,	king list)			
		-24 (#B) – CN-52 (#18) Checking Open/Short			
		-24 (#A) – CN-51 (#32) Checking Open/Short			
	3. CD.	-24 (#C) – CN-51 (#31) Checking Open/Short			
		Monitor – Select Attachment (breaker / crusher)			
	0	10 seconds continuous, Attachment Pilot Press. Sensor Measurement			
		Voltage > 5.2V			
	1	Monitor – Select Attachment (breaker / crusher) 10 seconds continuous, 0.3V≤ Attachment Pilot Press. Sensor Measurement			
	'	Voltage < 0.8V			
		Monitor – Select Attachment (breaker / crusher)			
	4	10 seconds continuous, Attachment Pilot Press. Sensor Measurement			
138		Voltage < 0.3V			
	(Resu	Its / Symptoms)			
	١,	nitor – Attachment Pilot Press. display failure			
		ntrol Function – Option attachment flow control operation failure			
		king list)			
	l '	-69 (#B) – CN-52 (#32) Checking Open/Short			
	2. CD-	-69 (#A) - CN-51 (#32) Checking Open/Short			
	3. CD-	-69 (#C) - CN-51 (#31) Checking Open/Short			
		10 seconds continuous, 0.3V≤ Option Pilot Press. Sensor Measurement			
	1	Voltage < 0.8V			
	4	10 seconds continuous, Option Pilot Press. Sensor			
	-	Measurement Voltage < 0.3V			
100	(Resu	Its / Symptoms)			
139 (N.A)	1. Mor	nitor – Option Pilot Press. display failure			
(14.74)	2. Cor	ntrol Function – Auto Idle operation failure			
	١,	king list)			
		-100 (#B) – CN-52 (#21) Checking Open/Short			
		-100 (#A) - CN-51 (#3) Checking Open/Short			
	3. CD-	-100 (#C) – CN-1 (#6) Checking Open/Short			

DTC	;	Diagnacatic Criteria	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	5	(Detection) (When Pump EPPR Current is more than 10 mA) 10 seconds continuous, Pump EPPR drive current < 0 mA (Cancellation) (When Pump EPPR Current is more than 10 mA) 3 seconds continuous, Pump EPPR drive current ≥10 mA	•		
140	6	 (Detection) 10 seconds continuous, Pump EPPR drive current > 1.0A (Cancellation) 3 seconds continuous, Pump EPPR drive current ≤ 1.0 A 	•		
	,	lits / Symptoms) htrol Function – Pump horse power setting specification difference			
	1. Cor	(Fuel efficiency/speed specification failure)			
	(Chec	king list)			
	l `	-75 (#2) – CN-54 (#28) Checking Open/Short			
		-75 (#1) – CN-54 (#4) Checking Open/Short			
	5	 (Model Parameter) mounting Boom Priority EPPR (Detection) (When Boom Priority EPPR Current is more than 10 mA) 10 seconds continuous, Boom Priority EPPR drive current < 0 mA (Cancellation) (When Boom Priority EPPR Current is more than 10 mA) 3 seconds continuous, Boom Priority EPPR drive current ≥ 10 mA 	•		
141	6	(Detection) 10 seconds continuous, Boom Priority EPPR drive current > 1.0 A (Cancellation) 3 seconds continuous, Boom Priority EPPR drive current ≤ 1.0 A	•		
	1. Cor (Chec 1. CN	olts / Symptoms) Introl Function – Boom first control operation failure Eking list) Introl Function – Boom first control operation failure Introl Function – CN-54 (#34) Checking Open/Short Introl Function – CN-54 (#4) Checking Open/Short			

DTC	;	Dia supposti a Cuitavi a	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	5	(Detection) (When Travel EPPR Current is more than 10 mA) 10 seconds continuous, Travel EPPR drive current = 0 mA (Cancellation) (When Travel EPPR Current is more than 100 mA) 3 seconds continuous, Travel EPPR drive current ≥ 10 mA			•
143 (N.A)	6	 (Detection) 10 seconds continuous, Travel EPPR drive current > 1.0 A (Cancellation) 3 seconds continuous, Travel EPPR drive current ≤ 1.0 A 			•
	1. Cor (Chec	lts / Symptoms) ntrol Function – cruise control operation failure king list) -246 (#2) – CN-54 (#39) Checking Open/Short -246 (#1) – CN-51 (#40) Checking Open/Short			
	5	(Model Parameter) mounting Remote Cooling Fan EPPR (Detection) (When Remote Cooling Fan EPPR Current is more than 10 mA) 10 seconds continuous, Remote Cooling Fan EPPR drive current = 0 mA (Cancellation) (When Remote Cooling Fan EPPR Current is more than 10 mA) 3 seconds continuous, Remote Cooling Fan EPPR drive current ≥ 10 mA	•		
145 (N.A)	6	 (Detection) 10 seconds continuous, Remote Cooling Fan EPPR drive current > 1.0 A (Cancellation) 3 seconds continuous, Remote Cooling Fan EPPR drive current ≤ 1.0 A 	•		
	1. Cor (Chec	lts / Symptoms) htrol Function – Remote fan control operation failure king list) -52 (#1) – CN-51 (#9) Checking Open/Short -52 (#2) – CN-51 (#14) Checking Open/Short			

DTC	·	Dia manadia Oritania	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
164 (N.A)	4	(Detection) (When Working Cutoff Relay is Off) 10 seconds continuous, Working Cutoff Relay drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Working Cutoff Relay is Off) 3 seconds continuous, Working Cutoff Relay drive unit Measurement Voltage > 3.0V (Detection) (When Working Cutoff Relay is On) 10 seconds continuous, Working Cutoff Relay drive current > 6.5 A (Cancellation) (When Working Cutoff Relay is On)			•
	1. Co	3 seconds continuous, Working Cutoff Relay drive current ≤ 6.5 A lts / Symptoms) ntrol Function – (Wheel Excavator) In driving mode, attachment hydraulic pilot profailure sking list) -47 (#85) – CN-54 (#9) Checking Open/Short	ressu	re cut	off
166	4 4	-47 (#30, #86) – CN-45 (#B+ term) Checking Open/Short (Detection) (When Power Max Solenoid is Off) 10 seconds continuous, Power Max Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Power Max Solenoid is Off) 3 seconds continuous, Power Max Solenoid drive unit Measurement Voltage > 3.0V (Detection) (When Power Max Solenoid is On) 5 seconds continuous, Power Max Solenoid drive current > 4.5 A (Cancellation)	•		
	1. Cor (Chec	(When Power Max Solenoid is On) 3 seconds continuous, Power Max Solenoid drive current ≤ 4.5 A lts / Symptoms) ntrol Function – Voltage increase operation failure sking list) -88 (#1) – CN-53 (#13) Checking Open/Short -88 (#2) – Fuse box (#24) Checking Open/Short			

DTC	;	Dia was astic Criteria	Ap	plicati	ion
HCESPN	FMI	Diagnostic Criteria (С	W
167		(Detection) (When Travel Speed Solenoid is Off) 10 seconds continuous, Travel Speed Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Travel Speed Solenoid is Off) 3 seconds continuous, Travel Speed Solenoid drive unit Measurement Voltage > 3.0V		•	
	4	(When Parking mode is not) (Detection) (When Travel Speed Solenoid is Off) 10 seconds continuous, Travel Speed Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Travel Speed Solenoid is Off) 3 seconds continuous, Travel Speed Solenoid drive unit Measurement Voltage > 3.0V			•
	6	(Detection) (When Travel Speed Solenoid is On) 10 seconds continuous, Travel Speed Solenoid drive current > 4.5 A (Cancellation) (When Travel Speed Solenoid is On) 3 seconds continuous, Travel Speed Solenoid drive current ≤ 4.5 A	•		
	1. Cor (Chec	olts / Symptoms) Its / Symptom			
		-70 (#1) - Fuse box (#24) Checking Open/Short			

DTC HCESPN FMI		Diagnostic Criteria	Ар	plicati	on			
HCESPN	FMI	Diagnostic Criteria	G	С	W			
	4	Monitor – Selecting attachment (breaker / crusher) (Detection) (When Attachment Conflux Solenoid is Off) 10 seconds continuous, Attachment Conflux Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Attachment Conflux Solenoid is Off) 3 seconds continuous, Attachment Conflux Solenoid drive unit Measurement	•					
169	6	Voltage > 3.0V (Detection) (When Attachment Conflux Solenoid is On) 10 seconds continuous, Attachment Conflux Solenoid drive Current > 6.5 A (Cancellation) (When Attachment Conflux Solenoid is On) 3 seconds continuous, Attachment Conflux Solenoid drive Current ≤ 6.5 A	•					
	(Resu	Its / symptoms)						
	,							
	Control Function – Option attachment flow control – Joining operation failure (Eco breaker mode, crusher mode)							
	(Checking list)							
	,	-237 (#1) – CN-52 (#16) Checking Open/Short						
		-237 (#2) – Fuse box (#24) Checking Open/Short						
	4	(Model Parameter) mounting Arm Regenerating Solenoid (Detection) (When Arm Regeneration Solenoid is Off) 10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off) 3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V	•					
170	6	(Detection) (When Arm Regeneration Solenoid is On) 10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A	•					
	1. Cor (Chec 1. CN-	lts / symptoms) htrol Function – Arm regeneration operation failure king list) -135 (#1) – CN-52 (#7) Checking Open/Short -135 (#2) – Fuse box (#24) Checking Open/Short						

DTC		D'acceptio Otto in	Ар	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
		Monitor – Selecting attachment (crusher) (Detection)			
		(When Attachment Safety Solenoid is Off)			
	4	10 seconds continuous, Attachment Safety Solenoid drive unit Measurement Voltage ≤ 3.0V	•		
		(Cancellation)			
		(When Attachment Safety Solenoid is Off)			
		3 seconds continuous, Attachment Safety Solenoid drive unit Measurement Voltage > 3.0V			
		(Detection)			
171		(When Attachment Safety Solenoid is On)			
	6	10 seconds continuous, Attachment Safety Solenoid drive current > 6.5 A (Cancellation)	•		
		(When Attachment Safety Solenoid is On)			
		3 seconds continuous, Attachment Safety Solenoid drive current ≤ 6.5 A			
	(Resu	Its / Symptoms)			
	•	ntrol Function – Option attachment flow control – Option spool pilot pressure	e cut	off fa	ailure
		er mode)		•	
	`	king list)			
	•	-149 (#1) – CN-53 (#9) Checking Open/Short			
		-149 (#2) – Fuse box (#24) Checking Open/Short			
		Monitor – Selecting attachment (breaker / crusher)			
		(Detection)			
		(When Breaker Operating Solenoid is Off)			
		10 seconds continuous, Attachment Safety Solenoid drive unit Measurement			
	4	Voltage ≤ 3.0V			
		(Cancellation)			
		(When Breaker Operating Solenoid is Off)			
		3 seconds continuous, Attachment Safety Solenoid drive unit Measurement			
		Voltage > 3.0V (Detection)			
179		(When Breaker Operating Solenoid is On)			
		10 seconds continuous, Attachment Safety Solenoid drive current > 6.5 A	_		
	6	(Cancellation)			
		(When Breaker Operating Solenoid is On)			
		3 seconds continuous, Attachment Safety Solenoid drive current ≤ 6.5 A			
	(Resu	Its / Symptoms)			
	1. Cor	ntrol Function - Option attachment flow control - Breaker operation failure (break	ker m	ode)	
	(Chec	king list)			
	1. CN-	66 (#1) – CN-53 (#8) Checking Open/Short			
	2. CN-	-66 (#2) – Fuse box (#24) Checking Open/Short			

DTC	<u> </u>	Discounting Office to	Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W
181	4	(Model Parameter) mounting Reverse Cooling Fan Solenoid (Detection) (When Reverse Cooling Fan Solenoid is Off) 10 seconds continuous, Reverse Cooling Fan Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Reverse Cooling Fan Solenoid is Off) 3 seconds continuous, Reverse Cooling Fan Solenoid drive unit Measurement Voltage > 3.0V	•		
(N.A)	6	 (Detection) (When Reverse Cooling Fan Solenoid is On) 10 seconds continuous, Reverse Cooling Fan Solenoid drive current > 4.5 A (Cancellation) (When Reverse Cooling Fan Solenoid is On) 3 seconds continuous, Reverse Cooling Fan Solenoid drive current ≤ 4.5 A 	•		
	(Resu	lts / Symptoms)			
	1. Cor	ntrol Function – Cooling Fan reverse control operation failure (not applicable)			
	5	(Detection) (When Attachment Flow EPPR 1 current is equal or more than 300 mA) 10 seconds continuous, Attachment Flow EPPR drive current < 100 mA (Cancellation) (When Attachment Flow EPPR 1 current is equal or more than 300 mA) 3 seconds continuous, Attachment Flow EPPR drive current ≥ 100 mA	•		
188	6	(Detection) 10 seconds continuous, Attachment Flow EPPR 1 drive current > 1.0 A (Cancellation) 3 seconds continuous, Attachment Flow EPPR 1 drive current ≤ 1.0 A	•		
	1. Cor (Chec 1. CN	lts / Symptoms) htrol Function – IPC operation failure, Option attachment flow control operation failure, Option attachment flow control operation failure, IIII (sking list) https://www.edu.com/services/service	ailure		

 $[\]ensuremath{\,\%\,}$ Some error codes are not applied to this machine.

;	Diagnostia Critoria	Application		
FMI	Diagnostic Criteria	G	С	W
5	(Detection) (When Attachment Flow EPPR 2 current is equal or more than 300 mA) 10 seconds continuous, Attachment Flow EPPR drive current < 100 mA (Cancellation) (When Attachment Flow EPPR 2 current is equal or more than 300 mA) 3 seconds continuous, Attachment Flow EPPR drive current ≥ 100 mA	•		
6	(Detection) 10 seconds continuous, Attachment Flow EPPR 2 drive current > 1.0 A (Cancellation)	•		
1. Cor (Chec 1. CN	Its / Symptoms) atrol Function – Option attachment flow control operation failure king list) 378 (#2) – CN-54 (#26) Checking Open/Short			
0	HW145 10 seconds continuous, Attachment flow control EPPR 1 press. Sensor Measurement Voltage > 5.2V HW145 10 seconds continuous,			
4	HW145 10 seconds continuous, Attachment flow control EPPR 1 press. Sensor Measurement Voltage < 0.8V Attachment flow control EPPR 1 press. Sensor Measurement Voltage < 0.3V			
1. Cor (Chec 1. CD- 2. CD-	htrol Function – Driving second pump joining function operation failure king list) 33 (#B) – CN-52 (#11) Checking Open/Short 33 (#A) – CN-51 (#3) Checking Open/Short			
0 1 4	10 seconds continuous, Pump EPPR Press. Sensor Measurement Voltage > 5.2V 10 seconds continuous, 0.3V≤ Pump EPPR Press. Sensor Measurement Voltage < 0.8V 10 seconds continuous, Pump EPPR Press. Sensor Measurement Voltage < 0.3V	•		
1. Mor 2. Cor (Fuel (Chec 1. CD	Its / Symptoms) nitor – Pump EPPR Press. display failure ntrol Function – Pump input horse power control failure, Overload at compensat operation failure efficiency/speed performance failure) king list) -44 (#B) – CN-51 (#13) Checking Open/Short	ion co	ontrol	
	FMI 5 6 (Result 1. Correct 1. CN-2. CN-2. CN-2. CD-3. CD-3. CD-4. COrrect 1. More 2. Correct 1. More 2. Correct 1. CD-2. COrrect 1. CD-2. Correct 1. CD-4. C	Diagnostic Criteria	Diagnostic Criteria G	Diagnostic Criteria G C

* Some error codes are not applied to this machine.

DTC		Diamenatia Cuitaria	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	0	(Mounting pressure sensor) 10 seconds continuous, Boom Cylinder Rod Press. Sensor Measurement Voltage > 5.2V	•		
	1	(Mounting pressure sensor) 10 seconds continuous, 0.3V≤ Boom Cylinder Rod Press. Sensor Measurement Voltage < 0.8V	•		
205 (N.A)	4	(Mounting pressure sensor) 10 seconds continuous, Boom Cylinder Rod Press. Sensor Measurement Voltage < 0.3V	•		
	1. Mor 2. Cor (Chec 1. CD- 2. CD-	Its / Symptoms) nitor – Boom Cylinder Rod Press. display failure nitrol Function – Boom floating control operation failure king list) 124 (#B) – CN-53 (#5) Checking Open/Short 124 (#A) – CN-53 (#3) Checking Open/Short 124 (#C) – CN-53 (#13) Checking Open/Short			
218 (N.A)	4	Mounting pressure sensor (HCESPN128 or HCESPN 205) (Detection) (When Boom Up Floating Solenoid is Off) 10 seconds continuous, Boom Up Floating Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Boom Up Floating Solenoid is Off) 3 seconds continuous, Boom Up Floating Solenoid drive unit Measurement Voltage > 3.0V	•		
	6	(Detection) (When Boom Up Floating Solenoid is On) 10 seconds continuous, Boom Up Floating Solenoid drive current > 6.5 A (Cancellation) (When Boom Up Floating Solenoid is On) 3 seconds continuous, Boom Up Floating Solenoid drive current ≤ 6.5 A	•		
	1. Cor (Chec 1. CD	lts / Symptoms) atrol Function – Boom floating control operation failure king list) 368 (#1) – CN-53 (#20) Checking Open/Short 368 (#2) – CR-35 (#87) Checking Open/Short			

DTC HCESPN FMI		Diagnostia Critoria		Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W	
	4	Mounting pressure sensor (HCESPN 128 or 205) (Detection) (When Boom Down Pilot Pressure Cutoff Solenoid is Off) 10 seconds continuous, Boom Down Pilot Pressure Cutoff Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Boom Down Pilot Pressure Cutoff Solenoid is Off) 3 seconds continuous, Boom Down Pilot Pressure Cutoff Solenoid drive unit Measurement Voltage > 3.0V	•			
220 (N.A)	6	(Detection) (When Boom Down Pilot Pressure Cutoff Solenoid is On) 10 seconds continuous, Boom Down Pilot Pressure Cutoff Solenoid drive current > 6.5 A (Cancellation) (When Boom Down Pilot Pressure Cutoff Solenoid is On) 3 seconds continuous, Boom Down Pilot Pressure Cutoff Solenoid drive current ≤ 6.5 A	•			
	(Resu	Its / Symptoms)				
	Control Function – Boom floating control operation failure					
	(Chec	king list)				
	1. CD-	-369 (#1) – CN-53 (#35) Checking Open/Short				
	2. CD-	-369 (#2) – CR-35 (#87) Checking Open/Short				
	5	Monitor – Selecting attachment (breaker / crusher) (Detection) (When ATT Relief Setting EPPR 1 Current is equal or more than 10 mA) 10 seconds continuous, ATT Relief Setting EPPR 1 drive current = 0 mA (Cancellation) ATT Relief Setting EPPR 1 Current is equal or more than 10 mA) 3 seconds continuous, ATT Relief Setting EPPR 1 drive current ≥ 10 mA	•			
221	6	(Detection) 10 seconds continuous, ATT Relief Setting EPPR 1 drive current > 1.0 A (Cancellation) 3 seconds continuous, ATT Relief Setting EPPR 1 drive current ≤ 1.0 A	•			
	(Resu	lts / Symptoms)				
	1. Cor	ntrol Function – Option attachment flow control – P1 relief pressure setting failure	е			
	(Chec	king list)				
	1. CN-	-365 (#2) – CN-54 (#17) Checking Open/Short				
	2. CN-	-365 (#1) – CN-54 (#9) Checking Open/Short				

DTC	· ·	D	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	5	Monitor – Selecting attachment (crusher) (Detection) (When ATT Relief Setting EPPR 2 Current is equal or more than 10 mA) 10 seconds continuous, ATT Relief Setting EPPR 2 drive current = 0 mA (Cancellation) (When ATT Relief Setting EPPR 2 Current is equal or more than 10 mA) 3 seconds continuous, ATT Relief Setting EPPR 2 drive current ≥ 10mA	•		
222	6	(Detection) 10 seconds continuous, ATT Relief Setting EPPR 2 drive current > 1.0 A (Cancellation) 3 seconds continuous, ATT Relief Setting EPPR 2 drive current ≤ 1.0 A	•		
ı	'	Its / Symptoms)			
	(Chec	ntrol Function – Option attachment flow control – P2 relief pressure setting fail king list) -366 (#2) – CN-54 (#17) Checking Open/Short -366 (#1) – CN-54 (#10) Checking Open/Short	ure		
	3	10 seconds continuous, Fuel Level Measurement Voltage > 3.8V			
	4	10 seconds continuous, Fuel Level Measurement Voltage < 0.3V	•		
301	1. Moi (Chec 1. CD	Its / Symptoms) nitor – Fuel remaining display failure king list) -2 (#2) – CN-51 (#19) Checking Open/Short -2 (#1) – CN-51 (#24) Checking Open/Short			
	4	(Model Parameter) mounting Fuel Warmer Relay (Detection) (When Fuel Warmer Relay is Off) 10 seconds continuous, Fuel Warmer Relay drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Fuel Warmer Relay is Off) 3 seconds continuous, Fuel Warmer Relay drive unit Measurement Voltage > 3.0V	•		
325	1. Cor	(Detection) (When Fuel Warmer Relay is On) 10 seconds continuous, Fuel Warmer Relay drive current > 4.5 A (Cancellation) (When Fuel Warmer Relay is On) 3 seconds continuous, Fuel Warmer Relay drive current ≤ 4.5 A Its / Symptoms) htrol Function – Fuel warmer operation failure king list)	•		
		-46 (#85) – CN-52 (#13) Checking Open/Short -46 (#86) – Fuse box (#23) Checking Open/Short			

DTC		Dia was astic Criteria		Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W	
	0	10 seconds continuous, Transmission Oil Press. Sensor Measurement Voltage > 5.2V			•	
	1	10 seconds continuous, 0.3V≤ Transmission Oil Press. Sensor Measurement Voltage < 0.8V			•	
501	4	10 seconds continuous, Transmission Oil Press. Sensor Measurement Voltage < 0.3V			•	
(N.A)	1. Mo (Chec 1. CD 2. CD	ults / Symptoms) nitor – Transmission Oil Press. display failure, Transmission Oil low pressure war cking list) -5 (#B) – CN-54 (#27) Checking Open/Short -5 (#A) – CN-54 (#3) Checking Open/Short -5 (#C) – CN-54 (#13) Checking Open/Short	rning	failure	•	
	0	10 seconds continuous, Brake Oil Press. Sensor Measurement Voltage > 5.2V 10 seconds continuous, 0.3V≤ Brake Oil Press. Sensor Measurement			•	
	1	Voltage < 0.8V 10 seconds continuous, Brake Oil Press. Sensor				
503	4	Measurement Voltage < 0.3V				
(N.A)	1. Mo (Chec 1. CD 2. CD	ults / Symptoms) nitor – Brake Oil Press. display failure, Brake Oil low pressure warning failure cking list) -3 (#B) – CN-54 (#4) Checking Open/Short -3 (#A) – CN-54 (#3) Checking Open/Short -3 (#C) – CN-54 (#13) Checking Open/Short				
	0	10 seconds continuous, Working Brake Press. Sensor Measurement Voltage > 5.2V			•	
	1	10 seconds continuous, 0.3V≤ Working Brake Press. Sensor Measurement Voltage < 0.8V			•	
505 (N.A)	4	10 seconds continuous, Working Brake Press. Sensor Measurement Voltage < 0.3V			•	
	1. Mo (Chec 1. CD 2. CD	ults / Symptoms) nitor – Working Brake Oil Press. display failure, Working Brake Oil low pressure cking list) -38 (#B) – CN-54 (#5) Checking Open/Short -38 (#A) – CN-54 (#3) Checking Open/Short -38 (#C) – CN-54 (#13) Checking Open/Short	warni	ng fai	lure	

DTC	<u>,</u>	Discounting Officers	Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W
	4	(Detection) (When Parking Relay is Off) 10 seconds continuous, Parking Relay drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Parking Relay is Off) 3 seconds continuous, Parking Relay drive unit Measurement Voltage > 3.0V			•
514 (N.A)	6	(Detection) (When Parking Relay is On) 10 seconds continuous, Parking Relay drive current > 6.5 A (Cancellation) (When Parking Relay is On) 3 seconds continuous, Parking Relay drive current ≤ 6.5 A			•
	(Resu	Its / Symptoms)		1	
	(Chec	ntrol Function – Parking Relay operation failure king list) -66 (#1) – CN-54 (#20) Checking Open/Short -66 (#2) – CN-45 (#B+ term) Checking Open/Short			
	4	(Detection) (When Traveling Cutoff Relay is Off) 10 seconds continuous, Traveling Cutoff Relay drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Traveling Cutoff Relay is Off) 3 seconds continuous, Traveling Cutoff Relay drive unit Measurement Voltage > 3.0V			•
517 (N.A)	6	(Detection) (When Traveling Cutoff Relay is On) 10 seconds continuous, Traveling Cutoff Relay drive current > 6.5 A (Cancellation) (When Traveling Cutoff Relay is On) 3 seconds continuous, Traveling Cutoff Relay drive current ≤ 6.5 A			•
	1. Cor (Chec 1. CR	lts / Symptoms) htrol Function – Traveling Cutoff Relay operation failure king list) -47 (#85) – CN-54 (#9) Checking Open/Short -47 (#86) – CN-45 (#B+ term) Checking Open/Short			

DTC	·	Dia suppostia Cuitavia		Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W	
	4	(Detection) (When Ram Lock Solenoid is Off) 10 seconds continuous, Ram Lock Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Ram Lock Solenoid is Off) 3 seconds continuous, Ram Lock Solenoid drive unit Measurement Voltage > 3.0V			•	
525 (N.A)	6	(Detection) (When Ram Lock Solenoid is On) 10 seconds continuous, Ram Lock Solenoid drive current > 6.5 A (Cancellation) (When Ram Lock Solenoid is On) 3 seconds continuous, Ram Lock Solenoid drive current ≤ 6.5 A			•	
	(Resu	lts / Symptoms)		<u> </u>		
	(Chec	ntrol Function – Ram lock control operation failure king list) -69 (#1) – CN-54 (#8) Checking Open/Short -69 (#2) – CN-45 (#B+ term) Checking Open/Short				
	4	(Detection) (When Creep Solenoid is Off) 10 seconds continuous, Creep Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Creep Solenoid is Off) 3 seconds continuous, Creep Solenoid drive unit Measurement Voltage > 3.0V (Detection)			•	
527 (N.A)	6	 (When Creep Solenoid is On) 10 seconds continuous, Creep Solenoid drive current > 6.5 A (Cancellation) (When Creep Solenoid is On) 3 seconds continuous, Creep Solenoid drive current ≤ 6.5 A 			•	
	1. Cor (Chec 1. CN-	lts / Symptoms) htrol Function – Creep mode operation failure king list) -206 (#1) – CN-54 (#7) Checking Open/Short -206 (#2) – CN-45 (#B+ term) Checking Open/Short				

DTC		Discounting Orbits		plicat	ion		
HCESPN	FMI	Diagnostic Criteria	G	С	W		
	0	10 seconds continuous, Travel Forward Press. Sensor Measurement Voltage > 5.2V			•		
	1	10 seconds continuous, $0.3V \le$ Travel Forward Press. Sensor Measurement Voltage $< 0.8V$			•		
500	4	10 seconds continuous, Travel Forward Press. Sensor Measurement Voltage < 0.3V			•		
530	(Resu	lts / Symptoms)					
(N.A)		nitor – Travel Forward Press. display failure					
		ntrol Function – Driving interoperability power control operation failure king list)					
	•	-73 (#B) – CN-54 (#6) Checking Open/Short					
	2. CD-	73 (#A) – CN-54 (#3) Checking Open/Short					
	3. CD-	73 (#C) – CN-54 (#13) Checking Open/Short					
	1	10 seconds continuous, $0.3V \le$ Travel Reverse Press. Sensor Measurement Voltage $< 0.8V$			•		
	4	10 seconds continuous, Travel Reverse Press. Sensor Measurement Voltage < 0.3V			•		
504	(Results / Symptoms)						
531 (N.A)	1. Monitor – Travel Reverse Press. display failure						
(14.7)	2. Control Function – Driving interoperability power control operation failure						
	(Checking list)						
	1. CD-74 (#B) – CN-54 (#23) Checking Open/Short 2. CD-74 (#A) – CN-54 (#3) Checking Open/Short						
		74 (#A) – CN-54 (#3) Checking Open/Short					
	0	10 seconds continuous, Battery input Voltage > 35V	•				
	1	10 seconds continuous, Battery input Voltage < 18V	•				
705	(Resu	Its / Symptoms)					
700	1. Control Function – Startup impossibility						
	(Checking list)						
	1. CS-	74A (#1) – CN-51 (#1) Checking Open/Short					
	,	(When Engine is equal or more than 400 rpm) 10 seconds continuous,					
	1	Alternator Node D ⁺ Measurement Voltage < 18V					
707	(In case 12v goods, Alternator Node I Measurement Voltage < 9V) (Results / Symptoms)						
707	•	ntrol Function – Battery charging circuit failure					
	(Checking list)						
		74A (#1) – CN-51 (#26) Checking Open/Short					

DTC HCESPN FMI		Dia was astic California	Application			
		Diagnostic Criteria		С	W	
	3	(Model Parameter) Mounting Acc. Dial				
	10 seconds continuous, Acc. Dial Measurement Voltage > 5.2V					
	(Model Parameter) Mounting Acc. Dial					
		10 seconds continuous, Acc. Dial Measurement Voltage < 0.3V				
714	(Resu	Its / Symptoms)				
	1. Moi	nitor – Acc. Dial Voltage display failure				
	2. Cor	ntrol Function – Engine rpm control failure				
		king list)				
	1. CN	-7 (#15) – CN-52 (#33) Checking Open/Short				
		(Detection)				
		(When Travel Alarm (Buzzer) Sound is Off)				
		10 seconds continuous, Travel Alarm (Buzzer) Sound Relay drive unit				
	4	Measurement Voltage ≤ 3.0V				
	7	(Cancellation)				
		(When Travel Alarm (Buzzer) Sound Relay is Off)				
		3 seconds continuous, Travel Alarm (Buzzer) Sound Relay drive unit				
		Measurement Voltage > 3.0V				
		(Detection)				
		(When Travel Alarm (Buzzer) Sound is On)				
722		10 seconds continuous, Travel Alarm (Buzzer) Sound Relay drive				
	6	current > 4.5 A				
	0	(Cancellation)				
		(When Travel Alarm (Buzzer) Sound is On)				
		3 seconds continuous, Travel Alarm (Buzzer) Sound Relay drive				
		current ≤ 4.5 A				
	(Resu	lts / Symptoms)				
	1. Cor	ntrol Function – Driving alarm operation failure				
	(Chec	king list)				
	1. CN	-81 (#1) – CN-52 (#9) Checking Open/Short				
	2. CN	-81 (#2) – Fuse box (#24) Checking Open/Short				
	2	(When mounting the A/C Controller)				
		60 seconds continuous, A/C Controller Communication Data Error				
004	(Resu	lts / Symptoms)				
831	1. Cor	ntrol Function – A/C Controller operation failure				
(N.A)	(Chec	king list)				
	1. CN	-11 (#8) – CN-51 (#22) Checking Open/Short				
	2. CN	-11 (#7) – CN-51 (#32) Checking Open/Short				
	2	60 seconds continuous, Cluster Communication Data Error				
	(Resu	lts / Symptoms)			I	
	,	ntrol Function – Cluster operation failure				
840	(Checking list)					
	,	-56A (#5) – CN-52 (#1) Checking Open/Short				
		-56A (#4) – CN-52 (#2) Checking Open/Short				

DTC		Dia manadia Ositasia		Application			
HCESPN	FMI	Diagnostic Criteria	G	С	W		
	2	10 seconds continuous, ECM Communication Data Error	•				
	(Resu	Its / Symptoms)					
841	1. Control Function – ECM operation failure						
041	(Chec	king list)					
	1. CN-	93 (#22) – CN-52 (#2) Checking Open/Short					
	2. CN-	93 (#46) – CN-52 (#1) Checking Open/Short					
	2	(When mounting the I/O Controller 1)					
		60 seconds continuous, I/O Controller 1 Communication Data Error					
845	(Resu	Its / Symptoms)					
(N.A)	1. Cor	ntrol Function – I/O Controller 1 operation failure					
(14.74)	(Chec	king list)					
	1. CN-	53 (#21) – CN-51 (#23) Checking Open/Short					
	2. CN-	-53 (#31) – CN-51 (#33) Checking Open/Short					
	2	(When mounting the Haptic Controller)					
		60 seconds continuous, Haptic Controller Communication Data Error					
848	(Resu	Its / Symptoms)					
(N.A)	Control Function – Haptic Controller operation failure						
(14.74)	(Checking list)						
		8 (#2) – CN-51 (#22) Checking Open/Short					
	2. CN-	8 (#3) – CN-51 (#32) Checking Open/Short	1				
	2	(When mounting the RMCU)					
		60 seconds continuous, RMCU communication Data Error					
	١,	luts / Symptoms)					
850	1. Control Function – RMCU operation failure						
	(Checking list)						
		125A (#3) – CN-51 (#9) Checking Open/Short					
	2. CN-	-125A (#11) – CN-51 (#8) Checking Open/Short					
	2	(When mounting the I/O Controller 2)					
		60 seconds continuous, I/O Controller 2 communication Data Error					
861 (N.A)	١,	Its / Symptoms)					
		ntrol Function – I/O Controller 2 operation failure					
	١,	king list)					
		54 (#21) – CN-51 (#23) Checking Open/Short			ļ		
	2. CN	54 (#31) – CN-51 (#33) Checking Open/Short					

DTC		Discounts Office	Application				
HCESPN	FMI	Diagnostic Criteria		С	W		
	2	(When mounting the AAVM)					
		60 seconds continuous, AAVM communication Data Error					
	(Resu	Its / Symptoms)					
866	1. Cor	ntrol Function – AAVM operation failure					
	(Chec	king list)					
	1. CN	-401 (#15) – CN-51 (#9) Checking Open/Short					
	2. CN	-401 (#3) – CN-51 (#8) Checking Open/Short					
	2	60 seconds continuous, RDU communication Data Error					
	(Resu	Its / Symptoms)					
867	1. Cor	ntrol Function – RDU operation failure					
007	(Checking list)						
	1. CN-376 (#10) – CN-51 (#9) Checking Open/Short						
	2. CN-376 (#18) – CN-51 (#8) Checking Open/Short						
	2	60 seconds continuous, Switch Controller communication Data Error					
	(Results / Symptoms)						
868	Control Function – Switch Controller operation failure						
	(Chec	king list)					
	1. CN	-56A (#7) - CN-51 (#9) Checking Open/Short					
	2. CN	-56A (#6) – CN-51 (#8) Checking Open/Short					
	2	(When mounting the BKCU)					
		60 seconds continuous, BKCU communication Data Error					
869	(Resu	Its / Symptoms)					
(N.A)	1. Cor	ntrol Function – BKCU operation failure					
	`	king list)					
		2B (#A) – CN-51 (#22) Checking Open/Short					
	2. CS-	2B (#B) – CN-51 (#32) Checking Open/Short					

4. ENGINE FAULT CODE

Fault code J1939 SPN J1939 FMI	ltem	Description
111 629 12	Engine control module critical internal failure	Bad intelligent device or component
122 102 3	Intake manifold 1 pressure sensor circuit	Voltage above normal, or shorted to high source
123 102 4	Intake manifold 1 pressure sensor circuit	Voltage below normal, or shorted to low source
124 102 16	Intake manifold 1 pressure	Data valid but above normal operating range - moderately severe level
125 102 18	Intake manifold 1 pressure	Data valid but below normal operating range - moderately severe level
133 974 3	Remote accelerator pedal or lever position sensor 1 circuit	Voltage above normal, or shorted to high source
134 974 4	Remote accelerator pedal or lever position sensor 1 circuit	Voltage below normal, or shorted to low source
135 100 3	Engine oil rifle pressure 1 sensor circuit	Voltage above normal, or shorted to high source
141 100 4	Engine oil rifle pressure 1 sensor circuit	Voltage below normal, or shorted to low source
143 100 18	Engine oil rifle pressure	Data valid but below normal operating range - moderately severe level
144 110 3	Engine coolant temperature 1 sensor circuit	Voltage above normal, or shorted to high source
145 110 4	Engine coolant temperature 1 sensor circuit	Voltage below normal, or shorted to low source
146 110 16	Engine coolant temperature	Data valid but above normal operating range - moderately severe level
147 91 1	Accelerator pedal or lever position 1 sensor circuit frequency	Data valid but below normal operating range
148 91 0	Accelerator pedal or lever position sensor 1	Data valid but above normal operational range - most severe level
151 110 0	Engine coolant temperature	Data valid but above normal operational range - most severe level

^{*} Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
153 105 3	Intake manifold 1 temperature sensor circuit	Voltage above normal, or shorted to high source
154 105 4	Intake manifold 1 temperature sensor circuit	Voltage below normal, or shorted to low source
187 3510 4	Sensor supply 2 circuit	Voltage below normal, or shorted to low source
197 111 18	Coolant level	Data valid but below normal operating range - moderately severe level
227 3510 3	Sensor supply 2 circuit	Voltage above normal, or shorted to high source
234 190 0	Engine crankshaft speed/position	Data valid but above normal operational range - most severe level
235 111 1	Coolant level	Data valid but below normal operational range - most severe level
237 644 2	External speed command input (Multiple unit synchronization)	Data erratic, intermittent or incorrect
238 3511 4	Sensor supply 3 circuit	Voltage below normal, or shorted to low source
239 3511 3	Sensor supply 3 circuit	Voltage above normal, or shorted to high source
241 84 2	Wheel-based vehicle speed	Data erratic, intermittent or incorrect
242 84 10	Wheel-based vehicle speed sensor circuit tampering has been detected	Abnormal rate of change
271 1347 4	Engine fuel pump pressurizing assembly 1 circuit	Voltage below normal, or shorted to low source
272 1347 3	Engine fuel pump pressurizing assembly 1 circuit	Voltage above normal, or shorted to high source
285 639 9	SAE J1939 multiplexing pgn timeout error	Abnormal update rate
286 639 13	SAE J1939 multiplexing configuration error	Out of calibration

 $[\]fine \fine \fin$

Fault code J1939 SPN J1939 FMI	ltem	Description
288 974 19	SAE J1939 multiplexing remote accelerator pedal or lever position sensor system	Received network data in error
293 441 3	Auxiliary temperature sensor input 1 circuit	Voltage above normal, or shorted to high source
294 441 4	Auxiliary temperature sensor input 1 circuit	Voltage below normal, or shorted to low source
297 1388 3	Auxiliary pressure sensor input 2 circuit	Voltage above normal, or shorted to high source
298 1388 4	Auxiliary pressure sensor input 2 circuit	Voltage below normal, or shorted to low source
322 651 5	Injector solenoid driver cylinder 1 circuit	Current below normal or open circuit
324 653 5	Injector solenoid driver cylinder 3 circuit	Current below normal or open circuit
331 652 5	Injector solenoid driver cylinder 2 circuit	Current below normal or open circuit
332 654 5	Injector solenoid driver cylinder 4 circuit	Current below normal or open circuit
334 110 2	Engine coolant temperature	Data erratic, intermittent or incorrect
343 629 12	Engine control module warning internal hardware failure	Bad intelligent device or component
349 191 16	Transmission output shaft speed	Data valid but above normal operating range - moderately severe level
351 3597 12	Injector power supply	Bad intelligent device or component
352 3509 4	Sensor supply 1 circuit	Voltage below normal, or shorted to low source
386 3509 3	Sensor supply 1 circuit	Voltage above normal, or shorted to high source
415 100 1	Engine oil rifle pressure	Data valid but below normal operational range - most severe level

 $[\]ensuremath{\,\%\,}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
418 97 15	Water in fuel indicator	Data valid but above normal operating range - least severe level
428 97 3	Water in fuel indicator sensor circuit	Voltage above normal, or shorted to high source
429 97 4	Water in fuel indicator sensor circuit	Voltage below normal, or shorted to low source
431 558 2	Accelerator pedal or lever idle validation switch	Data erratic, intermittent or incorrect
432 558 13	Accelerator pedal or lever idle validation switch circuit	Out of calibration
435 100 2	Engine oil rifle pressure	Data erratic, intermittent or incorrect
451 157 3	Injector metering rail 1 pressure sensor circuit	Voltage above normal, or shorted to high source
452 157 4	Injector metering rail 1 pressure sensor circuit	Voltage below normal, or shorted to low source
488 105 16	Intake manifold 1 temperature	Data valid but above normal operating range - moderately severe level
489 191 18	Transmission output shaft speed	Data valid but below normal operating range - moderately severe level
497 1377 2	Multiple unit synchronization switch	Data erratic, intermittent or incorrect
515 3514 3	Sensor supply 6 circuit	Voltage above normal, or shorted to high source
516 3514 4	Sensor supply 6 circuit	Voltage below normal, or shorted to low source
527 702 3	Auxiliary input/output 2 circuit	Voltage above normal, or shorted to high source
529 703 3	Auxiliary input/output 3 circuit	Voltage above normal, or shorted to high source
553 157 16	Injector metering rail 1 pressure	Data valid but above normal operating range - moderately severe level

^{*} Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
559 157 18	Injector metering rail 1 pressure	Data valid but below normal operating range - moderately severe level
584 677 3	Starter relay driver circuit	Voltage above normal, or shorted to high source
585 677 4	Starter relay driver circuit	Voltage below normal, or shorted to low source
599 640 14	Auxiliary commanded dual output shutdown	Special instructions
611 1383 31	Engine shut down hot	Condition exists
649 1378 31	Engine oil change interval	Condition exists
687 103 18	Turbocharger 1 speed	Data valid but below normal operating range - moderately severe level
689 190 2	Engine crankshaft speed/position	Data erratic, intermittent or incorrect
691 1172 3	Turbocharger 1 compressor intake temperature circuit	Voltage above normal, or shorted to high source
692 1172 4	Turbocharger 1 compressor intake temperature circuit	Voltage below normal, or shorted to low source
693 1172 7	Turbocharger 1 compressor intake temperature	Data erratic, intermittent or incorrect
731 723 7	Engine speed / position camshaft and crankshaft misalignment	Mechanical system not responding or out of adjustment
741 1176 3	Turbocharger 1 compressor intake pressure circuit	Voltage above normal, or shorted to high source
742 1176 4	Turbocharger 1 compressor intake pressure circuit	Voltage below normal, or shorted to low source
743 1176 2	Turbocharger 1 compressor intake pressure	Data erratic, intermittent or incorrect

 $[\]ensuremath{\,\mathbb{X}\,}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
769 597 3	Brake switch circuit	Voltage above normal, or shorted to high source
771 597 4	Brake switch circuit	Voltage below normal, or shorted to low source
778 723 2	Engine camshaft speed / position sensor	Data erratic, intermittent or incorrect
1117 3597 2	Power supply lost with ignition on	Data erratic, intermittent or incorrect
1239 2623 3	Accelerator pedal or lever position sensor 2 circuit	Voltage above normal, or shorted to high source
1241 2623 4	Accelerator pedal or lever position sensor 2 circuit	Voltage below normal, or shorted to low source
1242 91 2	Accelerator pedal or lever position sensor 1	Data erratic, intermittent or incorrect
1358 91 3	Accelerator pedal or lever position sensor 1 circuit	Voltage above normal, or shorted to high source
1359 91 4	Accelerator pedal or lever position sensor 1 circuit	Voltage below normal, or shorted to low source
1515 91 19	SAE J1939 multiplexed accelerator pedal or lever sensor system	Received network data in error
1539 1387 3	Auxiliary pressure sensor input 1 circuit	Voltage above normal, or shorted to high source
1621 1387 4	Auxiliary pressure sensor input 1 circuit	Voltage below normal, or shorted to low source
1668 1761 4	Aftertreatment 1 diesel exhaust fluid tank level sensor circuit	Voltage below normal, or shorted to low source
1669 1761 3	Aftertreatment 1 diesel exhaust fluid tank level sensor circuit	Voltage above normal, or shorted to high source
1673 1761 1	Aftertreatment 1 diesel exhaust fluid tank level	Data valid but below normal operational range -most severe level
1677 3031 4	Aftertreatment 1 diesel exhaust fluid tank temperature sensor	Voltage below normal, or shorted to low source

 $[\]ensuremath{\,\%\,}$ Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	Item	Description
1678 3031 3	Aftertreatment 1 diesel exhaust fluid tank temperature sensor	Voltage above normal, or shorted to high source
1679 3031 2	Aftertreatment 1 diesel exhaust fluid tank temperature	Data erratic, intermittent or incorrect
1682 3362 31	Aftertreatment 1 diesel exhaust fluid dosing unit input lines	Condition exists
1685 3364 4	Aftertreatment diesel exhaust fluid quality sensor circuit	Voltage below normal, or shorted to low source
1686 3364 3	Aftertreatment diesel exhaust fluid quality sensor circuit	Voltage above normal, or shorted to high source
1695 3513 3	Sensor supply 5	Voltage above normal, or shorted to high source
1696 3513 4	Sensor supply 5	Voltage below normal, or shorted to low source
1713 3363 16	Aftertreatment 1 diesel exhaust fluid tank heater	Data valid but above normal operating range - moderately severe level
1714 3364 13	Aftertreatment diesel exhaust fluid quality	Out of calibration
1715 3364 11	Aftertreatment diesel exhaust fluid quality	Root cause not known
1843 101 3	Crankcase pressure circuit	Voltage above normal, or shorted to high source
1844 101 4	Crankcase pressure circuit	Voltage below normal, or shorted to low source
1852 97 16	Water in fuel indicator	Data valid but above normal operating range - moderately severe level
1879 3251 3	Aftertreatment diesel particulate filter differential pressure sensor circuit	Voltage above normal
1881 3251 4	Aftertreatment diesel particulate filter differential pressure sensor circuit	Voltage below normal
1883 3251 2	Aftertreatment diesel particulate filter differential pressure sensor	Data erratic, intermittent or incorrect

[※] Some fault codes are not applied to this machine.

Fault code J1939 SPN	ltem	Description
1885 3216	Aftertreatment 1 intake NOx sensor circuit	Voltage below normal, or shorted to low source
1887 3226 4	Aftertreatment 1 outlet NOx sensor circuit	Voltage below normal, or shorted to low source
1921 3251 16	Aftertreatment diesel particulate filter differential pressure	Data valid but above normal operating range
1922 3251 0	Aftertreatment diesel particulate filter differential pressure	Data valid but above normal operating range
1993 4795 31	Aftertreatment 1 diesel particulate filter missing	Condition exists
2185 3512 3	Sensor supply 4 circuit	Voltage above normal, or shorted to high source
2186 3512 4	Sensor supply 4 circuit	Voltage below normal, or shorted to low source
2311 633 31	Electronic fuel injection control valve circuit	Condition exists
2321 190 2	Engine crankshaft speed/position	Data erratic, intermittent or incorrect
2322 723 2	Engine camshaft speed / position sensor	Data erratic, intermittent or incorrect
2373 1209 3	Exhaust gas pressure sensor 1 circuit	Voltage above normal, or shorted to high source
2374 1209 4	Exhaust gas pressure sensor 1 circuit	Voltage below normal, or shorted to low source
2448 111 17	Coolant level	Data valid but below normal operating range - least severe level
2468 190 16	Engine speed	Engine crankshaft speed/position - data valid but above normal operating range - moderately severe level
2554 1209 2	Exhaust gas pressure 1	Data erratic, intermittent or incorrect
2557 697 3	Auxiliary PWM driver 1 circuit	Voltage above normal, or shorted to high source

 $[\]fine \fine \fin$

Fault code J1939 SPN J1939 FMI	Item	Description
2558 697 4	AuxiliaryPWM driver 1 circuit	Voltage below normal, or shorted to low source
2571 2630 3	Engine charge air cooler outlet temperature	Voltage above normal, or shorted to high source
2572 2630 4	Engine charge air cooler outlet temperature	Voltage below normal, or shorted to low source
2639 3251 15	Aftertreatment diesel particulate filter differential pressure	Data valid but above normal operating range
2765 1209 16	Engine injector group 1	Engine injector bank 1 barcodes - out of calibration
2771 3226 9	Aftertreatment 1 outlet NOx sensor	Abnormal update rate
2778 3481 16	Aftertreatment fuel rate	Data valid but above normal operating range - moderately severe level
2973 102 2	Intake manifold 1 pressure	Data erratic, intermittent or incorrect
2976 3361 2	Aftertreatment 1 diesel exhaust fluid dosing unit temperature	Data erratic, intermittent or incorrect
3133 3610 3	Aftertreatment 1 diesel particulate filter outlet pressure sensor circuit	Voltage above normal, or shorted to high source
3134 3610 4	Aftertreatment 1 diesel particulate filter outlet pressure sensor circuit	Voltage below normal, or shorted to low source
3135 3610 2	Aftertreatment 1 diesel particulate filter outlet pressure	Data erratic, intermittent or incorrect
3139 3667 3	Engine air shutoff circuit	Voltage above normal, or shorted to high source
3141 3667 4	Engine air shutoff circuit	Voltage below normal, or shorted to low source
3142 4360 3	Aftertreatment 1 SCR intake temperature sensor circuit	Voltage above normal, or shorted to high source
3144 4360 2	Aftertreatment 1 SCR intake temperature sensor	Data erratic, intermittent or incorrect

[※] Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
3146 4363 3	Aftertreatment 1 SCR outlet temperature sensor circuit	Voltage above normal, or shorted to high source
3147 4363 4	Aftertreatment 1 SCR outlet temperature sensor circuit	Voltage below normal, or shorted to low source
3148 4363 2	Aftertreatment 1 SCR outlet temperature sensor	Data erratic, intermittent or incorrect
3151 4974 31	Aftertreatment 1 SCR catalyst system missing	Condition exists
3165 4363 0	Aftertreatment 1 SCR outlet temperature	Data valid but above normal operational range - most severe
3232 3216 9	Aftertreatment 1 intake NOx sensor	Abnormal update rate
3235 4363 16	Aftertreatment 1 SCR outlet temperature	Data valid but above normal operating range - moderately severe level
3251 4765 16	Aftertreatment 1 diesel oxidation catalyst intake temperature	Data valid but above normal operating range
3253 3242 16	Aftertreatment 1 diesel particulate filter intake temperature	Data valid but above normal operating range
3254 3242 16	Aftertreatment 1 diesel particulate filter intake temperature	Data valid but above normal operating range
3255 3246 16	Aftertreatment 1 diesel particulate filter outlet temperature	Data valid but above normal operating range
3311 3242 0	Aftertreatment 1 diesel particulate filter intake temperature	Data valid but above normal operation
3312 3246 0	Aftertreatment 1 diesel particulate filter outlet temperature	Data valid but above normal operation
3313 4765 4	Aftertreatment 1 diesel oxidation catalyst intake temperature sensor circuit	Voltage below normal, or shorted to low source
3314 4765 3	Aftertreatment 1 diesel oxidation catalyst intake temperature sensor circuit	Voltage above normal, or shorted to high source
3315 4765 2	Aftertreatment 1 diesel oxidation catalyst intake temperature	Data erratic, intermittent or incorrect

[※] Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
3316 3242 4	Aftertreatment 1 diesel particulate filter intake temperature sensor circuit	Voltage below normal, or shorted to low source
3317 3242 3	Aftertreatment 1 diesel particulate filter intake temperature sensor circuit	Voltage above normal, or shorted to high source
3318 3242 2	Aftertreatment 1 diesel particulate filter intake temperature	Data erratic, intermittent or incorrect
3319 3246 3	Aftertreatment 1 diesel particulate filter outlet temperature sensor circuit	Voltage above normal, or shorted to high source
3321 3246 4	Aftertreatment 1 diesel particulate filter outlet temperature sensor circuit	Voltage below normal, or shorted to low source
3322 3246 2	Aftertreatment 1 diesel particulate filter outlet temperature	Data erratic, intermittent or incorrect
3326 91 9	SAE J1939 multiplexed accelerator pedal or lever sensor system	Abnormal update rate
3341 107 16	Engine air filter differential pressure - data valid but above normal operating range	Moderately severe level
3375 5397 31	Aftertreatment diesel particulate filter regeneration too frequent	Condition exists
3376 5319 31	Aftertreatment diesel particulate filter incomplete regeneration	Condition exists
3497 1761 17	Aftertreatment 1 diesel exhaust fluid tank level	Data valid but below normal operating range - least severe level
3498 1761 18	Aftertreatment 1 diesel exhaust fluid tank level	Data valid but below normal operating range - moderately severe level
3527 558 19	Accelerator pedal or lever idle validation switch	Received network data in error
3528 558 9	Accelerator pedal or lever idle validation switch	Abnormal update rate
3545 3226 31	Aftertreatment 1 outlet NOx sensor	Abnormal rate of change
3547 4096 31	Aftertreatment diesel exhaust fluid tank empty	Condition exists

 $[\]fine \fine \fin$

Fault code J1939 SPN J1939 FMI	ltem	Description
3558 3361 3	Aftertreatment 1 diesel exhaust fluid dosing unit	Voltage above normal, or shorted to high source
3559 3361 4	Aftertreatment 1 diesel exhaust fluid dosing unit	Voltage below normal, or shorted to low source
3567 5394 5	Aftertreatment diesel exhaust fluid dosing valve	Current below normal or open circuit
3568 5394 7	Aftertreatment diesel exhaust fluid dosing valve	Mechanical system not responding or out of adjustment
3571 4334 3	Aftertreatment 1 diesel exhaust fluid pressure sensor	Voltage above normal, or shorted to high source
3572 4334 4	Aftertreatment 1 diesel exhaust fluid pressure sensor	Voltage below normal, or shorted to low source
3574 4334 18	Aftertreatment 1 diesel exhaust fluid pressure sensor	Data valid but below normal operating range
3575 4334 16	Aftertreatment 1 diesel exhaust fluid pressure sensor	Data valid but above normal operating range
3577 4376 3	Aftertreatment diesel exhaust fluid return valve	Voltage above normal, or shorted to high source
3578 4376 4	Aftertreatment diesel exhaust fluid return valve	Voltage above normal, or shorted to low source
3583 5031 10	Aftertreatment 1 outlet nox sensor heater	Abnormal rate of change
3596 4334 2	Aftertreatment 1 diesel exhaust fluid pressure sensor	Data erratic, intermittent or incorrect
3641 748 9	Transmission output retarder	Abnormal update rate
3649 5024 10	Aftertreatment 1 intake NOx sensor heater	Abnormal rate of change
3681 3228 2	Aftertreatment 1 outlet NOx sensor power supply	Data erratic, intermittent or incorrect
3682 3218 2	Aftertreatment 1 intake NOx sensor power supply	Data erratic, intermittent or incorrect

^{*} Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
3697 630 12	Engine control module calibration memory	Bad intelligent device or component
3712 5246 0	Aftertreatment SCR operator inducement	Data valid but above normal operational range - most severe level
3714 1569 31	Engine protection torque derate	Condition exists
3725 3216 10	Aftertreatment 1 intake NOx sensor	Abnormal rate of change
3727 5571 7	High pressure common rail fuel pressure relief valve	Mechanical system not responding or out of adjustment
3737 1675 31	Engine starter mode overcrank protection	Condition exists
3741 5571 0	High pressure common rail fuel pressure relief valve	Data valid but above normal operational range
3748 3216 20	Aftertreatment 1 intake NOx sensor	Data not rational - drifted high
3765 442 3	Auxiliary temperature sensor input 2 circuit	Voltage above normal, or shorted to high source
3766 442 4	Auxiliary temperature sensor input 2 circuit	Voltage below normal, or shorted to low source
3838 2978 9	Estimated engine parasitic losses - percent torque	Abnormal update rate
3841 596 2	Cruise control enable switch	Data erratic, intermittent or incorrect
3843 5603 9	Cruise control disable command	Abnormal update rate
3845 5603 31	Cruise control disable command	Condition exists
3866 3364 1	Aftertreatment diesel exhaust fluid quality	Data valid but below normal operational range - most severe level
3868 3364 9	Aftertreatment diesel exhaust fluid quality	Abnormal update rate

^{*} Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
3878 3364 2	Aftertreatment diesel exhaust fluid quality	Data erratic, intermittent or incorrect
4151 5742 9	Aftertreatment diesel particulate filter temperature sensor module	Abnormal update rate
4152 5743 9	Aftertreatment selective catalytic reduction temperature sensor module	Abnormal update rate
4156 5746 4	Aftertreatment 1 diesel exhaust fluid dosing unit heater relay	Voltage below normal, or shorted to low source
4158 5742 12	Aftertreatment diesel particulate filter temperature sensor module	Bad intelligent device or component
4159 5743 12	Aftertreatment selective catalytic reduction temperature sensor module	Bad intelligent device or component
4161 5742 3	Aftertreatment diesel particulate filter temperature sensor module	Voltage above normal, or shorted to high source
4162 5742 4	Aftertreatment diesel particulate filter temperature sensor module	Voltage below normal, or shorted to low source
4163 5742 16	Aftertreatment diesel particulate filter temperature sensor module	Data valid but above normal operating range
4164 5743 3	Aftertreatment selective catalytic reduction temperature sensor module	Voltage above normal, or shorted to high source
4165 5743 4	Aftertreatment selective catalytic reduction temperature sensor module	Voltage below normal, or shorted to low source
4166 5743 16	Aftertreatment selective catalytic reduction temperature sensor module	Data valid but above normal
4168 5745 3	Aftertreatment 1 diesel exhaust fluid dosing unit heater	Voltage above normal, or shorted to high source
4169 5745 4	Aftertreatment 1 diesel exhaust fluid dosing unit heater	Voltage below normal, or shorted to low source
4249 4337 10	Aftertreatment 1 diesel exhaust fluid dosing temperature	Abnormal rate of change
4251 5798 10	Aftertreatment 1 diesel exhaust fluid dosing unit heater temperature	Abnormal rate of change

 $[\]fine \fine \fin$

Fault code J1939 SPN J1939 FMI	ltem	Description
4259 5742 11	Aftertreatment diesel particulate filter temperature sensor module	Root cause not known
4261 5743 11	Aftertreatment selective catalytic reduction temperature sensor module	Root cause not known
4277 3364 10	Aftertreatment diesel exhaust fluid quality	Abnormal rate of change
4284 5793 9	Desired engine fueling state	Abnormal update rate
4452 3226 7	Aftertreatment 1 outlet NOx sensor closed loop operation	Condition exists
4484 3667 7	Engine air shutoff	Mechanical system not responding or out of Adjustment
4526 521 2	Brake pedal position	Data erratic, intermittent or incorrect
4572 3031 9	Aftertreatment 1 diesel exhaust fluid tank temperature	Abnormal update rate
4584 3936 14	Aftertreatment diesel particulate filter system	Special instructions
4585 4792 14	Aftertreatment 1 SCR catalyst system	Special instructions
4677 1761 9	SAE J1939 multiplexing pgn timeout error	Abnormal update rate
4724 702 5	Auxiliary input/output 2 circuit	Current below normal or open circuit
4725 702 6	Auxiliary input/output 2 circuit	Current above normal or grounded circuit
4731 3031 13	Aftertreatment 1 diesel exhaust fluid tank temperature sensor	Out of calibration
4734 701 14	Auxiliary input/output 1	Special instructions
4737 3031 11	Aftertreatment 1 diesel exhaust fluid tank temperature	Root cause not known

[※] Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
4739 1761 11	Aftertreatment 1 diesel exhaust fluid tank level sensor	Root cause not known
4747 3217 20	Aftertreatment intake oxygen sensor	Data not rational - drifted high
4748 3217 21	Aftertreatment intake oxygen sensor	Data not rational - drifted low
4749 3227 20	Aftertreatment outlet oxygen	Data not rational - drifted high
4751 3227 21	Aftertreatment outlet oxygen	Data not rational - drifted low
4768 3521 11	Aftertreatment 1 diesel exhaust fluid property	Root cause not known
4769 1761 10	Aftertreatment 1 diesel exhaust fluid tank level sensor	Abnormal rate of change
4842 3364 15	Aftertreatment diesel exhaust fluid quality	Data valid but above normal operating range - Least severe level
4863 5245 31	Aftertreatment diesel exhaust fluid tank low level indicator	-
4953 3353 3	Alternator 1 status	Voltage above normal, or shorted to high source
4954 3353 4	Alternator 1 status	Voltage below normal, or shorted to low source
5248 1623 13	Tachograph output shaft speed	Out of calibration
5272 649 4	Engine exhaust back pressure regulator control circuit	Voltage below normal, or shorted to low source
5273 649 5	Engine exhaust back pressure regulator control circuit	Current below normal or open circuit
5274 5625 2	Engine exhaust back pressure regulator position	Data erratic, intermittent or incorrect
5275 5625 3	Engine exhaust back pressure regulator position sensor circuit	Voltage above normal, or shorted to high source

 $[\]fine \fine \fin$

Fault code J1939 SPN J1939 FMI	ltem	Description
5276 5625 4	Engine exhaust back pressure regulator position sensor circuit	Voltage above normal, or shorted to low source
5292 520809 31	Excessive time since last engine air shutoff maintenance test	Condition exists
5383 3720 15	Aftertreatment 1 diesel particulate filter ash load percent	Data valid but above normal operating range - least severe level
5576 107 15	Engine air filter differential pressure	Data valid but above normal operating range - least severe level
5632 6918 31	SCR system cleaning inhibited due to inhibit switch	Condition exists
5652 1209 15	Exhaust pressure 1	Data valid but above normal operating range - least severe level
5653 6881 9	SCR operator inducement override switch	Abnormal update rate
5654 6881 13	SCR operator inducement override switch	Out of calibration
5655 4364 31	Aftertreatment 1 scr conversion efficiency	Condition exists
5689 3226 11	Aftertreatment 1 outlet nox sensor	Root cause not known
5715 3521 10	Aftertreatment 1 diesel particulate filter differential pressure	Abnormal rate of change
5716 3610 10	Aftertreatment 1 diesel particulate filter outlet pressure	Abnormal rate of change
5864 4375 3	Aftertreatment 1 diesel exhaust fluid pump command circuit	Voltage above normal or shorted to high source
5865 4375 4	Aftertreatment 1 diesel exhaust fluid pump command circuit	Voltage below normal or shorted to low source
5868 4339 7	Aftertreatment 1 scr feedback control status	Mechanical system not responding or out of adjustment
5935 4334 7	Aftertreatment 1 diesel exhaust fluid pressure	Mechanical system not responding or out of adjustment

^{*} Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
5936 4334 15	Aftertreatment 1 diesel exhaust fluid pressure	Data valid but above normal operating range - least severe level
5938 3750 14	Aftertreatment 1 diesel particulate filter conditions not met for active regeneration	Special instructions
5939 520968 9	Machine constrained operation	Abnormal update rate. No communication or an Invalid data transfer rate has been detected on the J1939 data link between the ECM and the machine
5941 520968 19	Machine constrained operation	Received network data in error. The received J1939 datalink message was not valid.
6256 168 15	Battery 1 voltage	Data valid but below normal operating range - moderately severe level
6257 168 17	Battery 1 voltage	Data valid but below normal operating range - moderately severe level
6263 647 3	Fan control circuit	Voltage above normal, or shorted to high source
6264 647 4	Fan control circuit	Voltage below normal, or shorted to low source
6456 5484 3	Engine fan clutch 2 control circuit	Voltage above normal, or shorted to high source
6457 5484 4	Engine fan clutch 2 control circuit	Voltage below normal, or shorted to low source
6467 1639 15	Fan speed	Data valid but above normal operational range - most severe level
6468 1639 17	Fan speed	Data valid but below normal operational range - most severe level
6471 6799 3	Fan blade pitch position sensor circuit	Voltage above normal, or shorted to high source
6472 6799 4	Fan blade pitch position sensor circuit	Voltage below normal, or shorted to low source
6475 3363 7	Aftertreatment 1 diesel exhaust fluid tank heater	Mechanical system not responding or out of adjustment
6476 3363 18	Aftertreatment 1 diesel exhaust fluid tank heater	Data valid but below normal operating range - moderately severe level

[※] Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	Item	Description
6477 5491 3	Aftertreatment diesel exhaust fluid line heater relay	Voltage above normal, or shorted to high source
6478 5491 4	Aftertreatment diesel exhaust fluid line heater relay	Voltage below normal, or shorted to low source
6479 3363 3	Aftertreatment 1 diesel exhaust fluid tank heater	Voltage above normal, or shorted to high source
6481 3363 4	Aftertreatment 1 diesel exhaust fluid tank heater	Voltage below normal, or shorted to low source
6511 6655 3	Maintain ECM power lamp	Voltage above normal, or shorted to high source
6512 6655 4	Maintain ECM power lamp	Voltage below normal, or shorted to low source
6513 5745 17	Aftertreatment 1 diesel exhaust fluid dosing unit heater	Data valid but below normal operating range
6522 111 3	Coolant level sensor 1 circuit	Voltage above normal, or shorted to high source
6523 111 4	Coolant level sensor 1 circuit	Voltage below normal, or shorted to low source
6526 1761 13	Aftertreatment 1 diesel exhaust fluid tank level sensor	Out of calibration
6527 4376 7	Aftertreatment diesel exhaust fluid return valve	Mechanical system not responding or out of adjust
6529 5746 3	Aftertreatment 1 diesel exhaust fluid dosing unit heater relay	Voltage above normal, or shorted to high source
6531 4340 3	Aftertreatment 1 diesel exhaust fluid line heater 1 circuit	Voltage above normal, or shorted to high source
6532 4340 4	Aftertreatment 1 diesel exhaust fluid line heater 1 circuit	Voltage below normal, or shorted to low source
6533 4342 3	Aftertreatment 1 diesel exhaust fluid line heater 2 circuit	Voltage above normal, or shorted to high source
6534 4342 4	Aftertreatment 1 diesel exhaust fluid line heater 2 circuit	Voltage below normal, or shorted to low source

^{*} Some fault codes are not applied to this machine.

Fault code J1939 SPN	ltem	Description
6535 4344 3	Aftertreatment diesel exhaust fluid line heater 3 circuit	Voltage above normal, or shorted to high source
6536 4344 4	Aftertreatment diesel exhaust fluid line heater 3 circuit	Voltage below normal, or shorted to low source
6556 729 3	Engine intake air heater 1 circuit	Voltage above normal, or shorted to high source
6557 729 4	Engine intake air heater 1 circuit	Voltage below normal, or shorted to low source
6563 976 2	Auxiliary intermediate (PTO) speed switch validation	Data erratic, intermittent or incorrect
6568 3695 2	Aftertreatment regeneration inhibit switch	Data erratic, intermittent or incorrect
6583 441 14	Auxiliary temperature sensor input 1	Special instructions
6584 1388 14	Auxiliary pressure sensor input 2	Special instructions
6595 190 11	Engine speed	Root cause not known
6596 3713 31	Diesel particulate filter active regeneration inhibited due to system timeout	Condition exists
6599 521002 31	Engine cranks slowly	Condition exists
6611 6385 3	Engine starter motor relay control circuit	Voltage above normal or shorted to high source
6612 6385 4	Engine starter motor relay control circuit	Voltage below normal or shorted to low source
6613 5842 14	SCR monitoring system malfunction	Special instructions
6618 70 2	Parking brake switch	Data erratic, intermittent, or incorrect
6619 3515 10	Aftertreatment 1 diesel exhaust fluid temperature 2	Abnormal rate of change

^{*} Some fault codes are not applied to this machine.

Fault code J1939 SPN J1939 FMI	ltem	Description
6654 5626 7	Engine exhaust back pressure regulator	Mechanical system not responding or out of adjustment
6726 4796 31	Aftertreatment 1 diesel oxidation catalyst missing	Condition exists
6752 3364 18	Aftertreatment diesel exhaust fluid quality	Data valid but below normal operating range - moderately severe level
6771 521032 14	Aftertreatment system assembly	Special instructions
6938 5793 9	Desired engine fueling state	Abnormal update rate
6939 7745 9	Engine start request	Abnormal update rate
7133 7745 13	Engine start request	Out of calibration
7134 7746 13	Engine start consent	Out of calibration
7135 103 15	Engine turbocharger speed	Data valid but above normal operating range - least severe level
7745 1569 14	Engine protection torque derate	Special instructions
7393 7745 9	Engine start request	Abnormal update rate
7453 3242 15	Aftertreatment 1 diesel particulate filter intake temperature	Data valid but above normal operating range - least severe level
7454 3246 15	Aftertreatment 1 diesel particulate filter outlet temperature	Data valid but above normal operating range - least severe level


 $[\]ensuremath{\,\times\,}$ Some fault codes are not applied to this machine.

5. AAVM FAULT CODE

Fault Code	Description
A01	AAVM Communication Error -AAVM
A02	AAVM Communication Error -Front Camera
A03	AAVM Communication Error -Rear Camera
A04	AAVM Communication Error -Left Camera
A05	AAVM Communication Error -Right Camera
A06	Manual Setting Fail
A07	No MCU CID
A08	MCU CID Format Error
A09	AAVM Hardware Error -AAVM
A10	AAVM Hardware Error -Front Camera
A11	AAVM Hardware Error -Rear Camera
A12	AAVM Hardware Error -Left Camera
A13	AAVM Hardware Error -Right Camera
A14	MCU CID Model is not registered
A15	MCU CID Model can't be applied

GROUP 13 ENGINE CONTROL SYSTEM

1. MCU and ECM (Engine Control Module)



130A5MS30

2. MCU ASSEMBLY

- To match the pump absorption torque with the engine torque, MCU varies EPPR valve output pressure, which control pump discharge amount whenever feedbacked engine speed drops under the reference rpm of each mode set.
- 2) Three LED lamps on the MCU display as below.

LED lamp	Trouble	Service	
G is turned ON	Normal	-	
G and R are turned ON	Trouble on MCU	· Change the MCU	
G and Y are turned ON	Trouble on serial	· Check if serial communication	
	communication line	lines between MCU and cluster are disconnected	
Three LED are turned OFF	Trouble on MCU power	· Check if the input power wire (24 V, GND) of MCU	
		is disconnected	
		· Check the fuse	

G: green, R: red, Y: yellow

GROUP 14 EPPR VALVE

1. PUMP EPPR VALVE

1) COMPOSITION

EPPR (Electro Proportional Pressure Reducing) valve consists of electro magnet and spool valve installed at main pump.

(1) Electro magnet valve

Receive electric current from MCU and move the spool proportionally according to the specific amount of electric current value.

(2) Spool valve

Is the two way direction control valve for pilot pressure to reduce main pump flow. When the electro magnet valve is activated, pilot pressure enters into flow regulator of main pump.

(3) Pressure and electric current value for each mode

Mode		Engine rpm		Engine rpm (kgf/cm²)	
		No load	load	No load	load
	Р	1900	1900	10	3
Standard	S	1750	1850	12	5
	Е	1650	1750	12	5
	Р	1900	1900	8	3
Option	S	1850	1850	9	4
	Е	1750	1750	10	5

2) HOW TO SWITCH THE POWER SHIFT (STANDARD \(\rightarrow \) OPTION) ON THE CLUSTER

You can switch the EPPR valve pressure set by selecting the power shift (standard ↔ option).

- Management


· Service menu



· Power shift (standard/option): Power shift pressure can be set by option menu.

3) OPERATING PRINCIPLE

(1) Structure




130A5MS31

- 1 Sleeve
- 2 Spring
- 3 Spool

- 4 O-ring
- 5 O-ring
- 6 O-ring


- 7 Retaining ring
- 8 O-ring
- 9 Solenoid valve




- P Pilot oil supply line (pilot pressure)
- T Return to tank
- A Secondary pressure to flow regulator at main pump

(2) Neutral


Pressure line is blocked and A oil returns to tank.






(3) Operating

Secondary pressure enters into A.





130A5MS33


4) EPPR VALVE CHECK PROCEDURE


(1) Check electric current value at EPPR valve

- ① Disconnect connector CN-75 from EPPR valve.
- ② Insert the adapter to CN-75 and install multimeter as figure.
- ③ Start engine.
- 4 Set S-mode and cancel auto decel mode.
- 5 Position the accel dial at 10.
- 6 If rpm display show approx 1750 \pm 50 rpm check electric current at bucket circuit relief position.
- ⑦ Check electric current at bucket circuit relief position.

(2) Check pressure at EPPR valve

- ① Remove plug and connect pressure gauge as figure.
 - · Gauge capacity: 0 to 50 kgf/cm² (0 to 725 psi)
- ② Start engine.
- 3 Set S-mode and cancel auto decel mode.
- 4 Position the accel dial at 10.
- Slowly operate control lever of bucket functions at full stroke over relief and measure the EPPR valve pressure by the the monitoring menu of the cluster.
- 6 If pressure is not correct, adjust it.
- 7 After adjust, test the machine.





2. BOOM PRIORITY EPPR VALVE

1) COMPOSITION


The boom priority EPPR valve is built in a manifold and mainly consisting of valve body and coil. This EPPR valve installed under the solenoid valve.

2) CONTROL


The boom priority EPPR valve has to be controlled by a specific electronic amplifier card, which is supplying the coil with a current 580 mA at $30\,\Omega$ and 24 V.

3) OPERATING PRINCIPLE

(1) Structure



21095MS14



P : Pilot supply line T : Return to tank

A : Secondary pressure to flow MCV

1 O-ring

3 Valve body

5 Connector

2 Support ring

4 Coil

6 Cover cap

(2) Operation

In de-energized mode the inlet port (P) is closed and the outlet port (A) is connected to tank port (T).

In energized mode the solenoid armature presses onto the control spool with a force corresponding to the amount of current. This will set a reduced pressure at port A. The setting is proportional to the amount of current applied.

(3) Maximum pressure relief

If a pressure from outside is applied on port A the valve may directly switch to tank port (T) and protect the system before overload.


2) EPPR VALVE CHECK PROCEDURE


(1) Check electric current value at EPPR valve

- ① Disconnect connector CN-133 from EPPR valve.
- ② Insert the adapter to CN-133 and install multimeter as figure.
- ③ Start engine.
- Set S-mode and cancel auto decel mode.
- ⑥ Check electric current in case of combined boom up and swing operation.

(2) Check pressure at EPPR valve

- ① Remove hose from A5 port and connect pressure gauge as figure.
 - · Gauge capacity: 0 to 50 kgf/cm² (0 to 725 psi)
- ② Start engine.
- 3 Set S-mode and cancel auto decel mode.
- 4 If rpm display approx 1750 \pm 50 rpm check pressure (In case of combined boom up and swing operation).
- ⑤ If pressure is not correct, adjust it.
- 6 After adjust, test the machine.





GROUP 15 MONITORING SYSTEM

1. STRUCTURE

The cluster consists of LCD and switches as shown below. The LCD is to warn the operator in case of abnormal machine operation or conditions for the appropriate operation and inspection.

Also, The LCD is to set and display for modes, monitoring and utilities with the switches.

The switches or touch screen are to set the machine operation modes.

- * The cluster installed on this machine does not entirely guarantee the condition of the machine.
 Daily inspection should be performed according to chapter 6, Maintenance.
- When the cluster provides a warning immediately check the problem, and perform the required action.




130A5MS40

* The warning lamp pops up and/or blinks and the buzzer sounds when the machine has a problem.

The warning lamp lights up or blinks until the problem is cleared. Refer to page 5-73 for details.

- * This cluster is adjustable.
 - · Vertical (forward/backward) : each 15°
 - · Horizontal (left only): 8°



2) CLUSTER CHECK PROCEDURE

(1) Start key: ON

① Check monitor

- a. Buzzer sounding for 4 seconds with HYUNDAI logo on cluster.
- * If the ESL mode is set to the enable, enter the password to start engine.
- ② After initialization of cluster, the operating screen is displayed on the LCD. Also, self diagnostic function is carried out.
 - a. Engine rpm display: 0 rpm
 - b. Engine coolant temperature gauge: White range
 - c. Hydraulic oil temperature gauge: White range
 - d. Fuel level gauge: White range
 - e. DEF/AdBlue® Level gauge: White range

③ Indicating lamp state

- a. Power mode pilot lamp: E mode or U mode
- b. Work mode pilot lamp : General operation mode (bucket)
- c. Travel speed pilot lamp: Low (turtle)

(2) Start of engine

① Check machine condition

- a. RPM display indicates at present rpm
- b. Gauge and warning lamp: Indicate at present condition.
- * When normal condition : All warning lamp OFF
- c. Work mode selection: General work
- d. Power mode selection: E mode or U mode
- e. Travel speed pilot lamp : Low (turtle)

2 When warming up operation

- a. Warming up pilot lamp: ON
- b. After engine started, engine speed increases to 1200 rpm.
- Others same as above.

③ When abnormal condition

- a. The warning lamp pops up and the buzzer sounds.
- b. If BUZZER STOP switch is pressed, buzzer sound is canceled but the warning lamp lights up or blinks until normal condition.
- * The pop-up warning lamp moves to the original position and warning lamp lights up or blinks when the buzzer stop switch is pushed. Also the buzzer stops.

3) CLUSTER CONNECTOR


(1) CN-56A

No.	Name	Signal
1	Battery 24V	20~32Vdc
2	Power IG (24V)	20~32Vdc
3	GND	-
4	CAN 1 (H)	0~5Vdc
5	CAN 1 (L)	0~5Vdc
6	CAN 2 (H)	0~5Vdc
7	CAN 2 (L)	20~32Vdc
8	N.C.	-
9	N.C.	-
10	Aux left	0~5Vdc
11	Aux right	0~5Vdc
12	Aux GND	-

(2) CN-56B

No.	Name	Signal
1	CAM 6.5V	6.3~6.7Vdc
2	CAM GND	-
3	CAM DIFF (H)	0~5Vdc
4	CAM DIFF (L)	0~5Vdc
5	CAM 1	NTSC signal
6	CAM 2	NTSC signal
7	CAM 3	NTSC signal
8	CAM shield	0~5Vdc

NTSC : National Television System Committee



4) GAUGE

(1) Operation screen

When you first turn starting switch ON, the operation screen will appear.



130A3CD21

- 1 RPM / Speed gauge
- 2 Engine coolant temperature gauge
- 3 Hydraulic oil temperature gauge
- 4 Fuel level gauge

- 5 Tripmeter display
- 6 Eco guage
- 7 Accel dial gauge

(2) RPM / Speed gauge



① This displays the engine speed.

(3) Engine coolant temperature gauge



290F3CD53

- ① This gauge indicates the temperature of coolant.
 - · White range: 40-107°C (104-225°F)
 - · Red range : Above 107°C (225°F)
- ② If the indicator is in the red range or lamp pops up and the buzzer sounds, turn OFF the engine and check the engine cooling system.
- If the gauge indicates the red range or even though the machine is in the normal condition range, check the electric device as this can be caused by poor connection of sensor.

(4) Hydraulic oil temperature gauge



290F3CD54

- ① This gauge indicates the temperature of hydraulic oil.
 - · White range: 40-105°C(104-221°F)
 - · Red range : Above 105°C(221°F)
- ② If the indicator is in the red range or lamp pops up and the buzzer sounds reduce the load on the system. If the gauge stays in the red range, stop the machine and check the cause of the problem.
- * If the gauge indicates the red range or lamp blinks in red even though the machine is in the normal condition range, check the electric device as this can be caused by poor connection of sensor.

(5) Fuel level gauge



130A3CD155

- ① This gauge indicates the amount of fuel in the fuel tank.
- If the gauge indicates the red range or lamp blinks in red even though the machine is in the normal condition range, check the electric device as this can be caused by poor connection of sensor.

(6) Tripmeter display



- 290E3CD56
- ① This displays the engine the tripmeter.
- * Refer to page 5-99 for details.

(7) Eco gauge



290F3CD58


- ① This gauge indicates the fuel consumption rate and machine load status so that the operators can operate the machine efficient in regards to fuel consumption.
- ② Fuel consumption rate or machine load is higher if the number of segments are increased.
- ③ The color of Eco gauge indicates operation status.
 - · White: Idle operation
 - · Green: Economy operation
 - · Yellow : Non-economy operation at a medium level.
 - · Red : Non-economy operation at a high level.

(8) Accel dial gauge



① This gauge indicates the level of accel dial.

5) WARNING LAMPS



130A3CD23A

Warning lamps and buzzer

Warnings	When error happened	Lamps and buzzer
All warning lamps except below		·
	Warning lamp pops up on the center of the LCD and the buzzer sounds	
₫ \$	Warning lamp pops up on the center of the LCD and the buzzer sounds	The pop-up warning lamp moves to the original position, blinks and the buzzer stops after 2 seconds elapses.
I SAMMA	Warning lamp pops up on the center of the LCD and the buzzer sounds	 Cluster displays this pop-up when it has communication error with MCU. If communication with MCU become normal state, it will disappear automatically.
⇔	Warning lamp pops up on the center of the LCD and the buzzer sounds	* Refer to page 5-74 for details.
	Warning lamp lights up and the buzzer sounds	* Refer to page 5-76 for details.

* Refer to the operator's manual page 3-14 for the buzzer stop switch



(5) Engine oil pressure warning lamp



290F3CD65

- ① This warning lamp pops up and the buzzer sounds when the engine oil pressure is low.
- ② If the lamp lights up, shut OFF the engine immediately. Check oil level.

(6) Check engine warning lamp



290F3CD66

- ① This warning lamp pops up and the buzzer sounds when the communication between MCU and engine ECM is abnormal, or if the cluster received specific fault code from the engine ECM.
- ② Check the communication line between the two.

 If the communication line is OK, then check the fault codes on the cluster.

(7) Battery charging warning lamp



290F3CD67

- ① This warning lamp pops up and the buzzer sounds when the battery charging voltage is low.
- 2 Check the battery charging circuit when this lamp blinks.

(8) Air cleaner warning lamp



290F3CD68

- ① This warning lamp pops up and the buzzer sounds when the air cleaner is clogged.
- ② Check, clean or replace filter.

(9) Overload warning lamp (opt)



290F3CD69

- ① When the machine is overloaded, the overload warning lamp pops up and the buzzer sounds when the overload switch is ON. (if equipped)
- 2 Reduce the machine load.


(10) Engine stop warning lamp



290F3CD252

- ① This lamp pops up and the buzzer sounds when the maual (stationary) exhuast system cleaning is not performed.
- * Refer to page 5-75-1.
- * Please contact your HD Hyundai Construction Equipment service center or local dealer.
- * "Engine shutdown" cluster message pops up when the exhaust gas temperature reaches above 800° C.

(11) Exhaust system cleaning warning lamp



290F3CD70

① This warning lamp lights up or blinks when exhaust system cleaning is needed as seen in the table below.

Warning lamp					
Exhaust	HEST	Check engine	Stop engine		
= <u>=</u> 3	£3,	<u>(I)</u>	STOP	Description	
Off	Off	Off	Off	Normal operating mode	
On (Amber)	Off	Off	Off	 Manual (stationary) exhaust system cleaning is recommended. * Refer to page 5-75-2. 	
On (Amber)	Off	On (Red)	Off	 Manual exhaust system cleaning must be conducted immediately. Engine power will be reduced automatically if action is not taken. Refer to page 5-75-2. 	
On (Amber)	Off	On (Red)	On (Red)	 These lamps will be ON if manual exhaust system cleaning is not conducted for a certain period of time. Stop the engine immediately. Please contact HD Hyundai Construction Equipment service center or local dealer. 	
Blink (Red)	Off	Off	Off	 The exhaust system cleaning lamp will blink without HEST lamp while automatic exhaust system cleaning is being performed. Low idle speed will increase to 1400 rpm. The machine can be operated as normal operating mode. Fuel consumption may slightly increase. 	
Blink (Red)	On (Amber)	Off	Off	 The exhaust system cleaning lamp will blink with HEST lamp while manual exhaust system cleaning is being performed. The machine must remain stationary at low idle. * Refer to page 5-75-2. 	

(12) Exhaust system cleaning inhibit warning lamp



2609A3CD20

- 1 This warning lamp indicates the exhaust system cleaning switch is pushed to the inhibit position, therefore automatic and manual exhaust system cleaning can not occur.
- * Refer to the operator's manual page 3-34-1 for the exhaust system cleaning switch.


Manual exhaust system cleaning





- Safety button
- HEST warning lamp ON Exhuast warning lamp blink







235A3CD173A

- Manual exhaust system cleaning must be operated in a fireproof area.
- To stop a manual exhaust system cleaning before it has completed, set to the exhaust system cleaning switch to the inhibit position or turn OFF the engine.
- ① Stop and park the machine.

- 2 Pull the safety button and push the switch to position 2 to initiate the manual exhaust system cleaning.
- * Refer to the operator's manual page 3-34-1 for the exhaust system cleaning switch operation.
- * The engine speed may increase to 1400 rpm and exhaust system cleaning begins and it will take approximately 20~30 minutes.
- 3 The exhaust system cleaning warning lamp will blink and HEST warning lamp will light up during the exhaust system cleaning operation.
- ① The exhaust system cleaning and/or HEST warning lamp light will go off when the exhaust system cleaning is completed.

(13) HEST (High exhaust system temperature) warning lamp



2609A3CD21

- ① This warning lamp indicates, when illuminated, that exhaust temperatures are high due to exhaust system cleaning.
- ② The lamp will also illuminate during a manual exhaust system cleaning.
- When this lamp is illuminated, be sure the exhaust pipe outlet is not directed at any surface or material that can melt, burn, or explode.
- ▲ When this lamp is illuminated, the exhaust gas temperature could reach 800°C [1500°F], which is hot enough to ignite or melt common materials, and to burn people.
- ** The lamp does not signify the need for any kind of equipment or engine service; It merely alerts the equipment operator to high exhaust temperatures. It is common for the lamp to illuminate on and off during normal equipment operation as the engine completes exhaust system cleaning cycles.

(14) Water in fuel warning lamp



300A3CD24A

- ① This warning lamp lights up and the buzzer sounds when the water separator is full of water or malfunctioning.
- When this lamp lights up, stop the machine and drain water from the separator.

(15) Seat belt reminder warning lamp



300A3CD25

- ① When operator does not fasten the operator's seat belt, the seat belt reminder warning lamp pops up and the buzzer sounds.
- 2 Fasten the seat belt.

(16) Coolant level warning lamp



760F3CD58

- ① This warning lamp indicates lack of coolant.
- 2 Check and refill coolant.


(17) Engine oil filter warning lamp



300A3CD306

- ① This warning lamp pops up and the buzzer sounds when the engine oil filter is clogged.
- ② Check, clean or replace filter.

6) PILOT LAMPS



(1) Mode pilot lamps

No	Mode	Pilot lamp	Selected mode
		P	Heavy duty power work mode
1	Power mode	S	Standard power mode
		E	Economy power mode
2	User mode	U	User preferable power mode
		L.	General operation - IPC speed mode
	Work tool mode	\triangle	General operation - IPC balance mode
3		£	General operation - IPC efficiency mode
	Work tool mode		Breaker operation mode
		R.	Crusher operation mode
		12	Lifting mode
4	Travel mode	-	Low speed traveling
4	navei mode	(4)	High speed traveling
5	Auto idle mode	n/min	Auto idle

(2) Power max pilot lamp



- ① The lamp will be ON when pushing power max switch on the LH RCV lever.
- ② The power max function operates for a max period of 8 seconds.
- * Refer to the operator's manual page 3-35 for power max function.

(3) Preheat pilot lamp



290F3CD79

- ① Turning the start key switch to the ON position starts preheating in cold weather.
- ② Start the engine after this lamp goes OFF.

(4) Warming up pilot lamp



290F3CD80

- ① This lamp lights up when the coolant temperature is below 30° C (86°F).
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C (86°F), or when 10 minutes have passed since starting the engine.

(5) Decel pilot lamp



300A3CD33

- ① Operating one touch decel switch on the RCV lever makes the lamp light up.
- ② Also, the lamp will light up and engine speed will be reduced automatically to save fuel when all levers and pedals are in the neutral position, and the auto idle function is selected.
- ③ If it follows the case below, decel goes off in the idle state.
 - Auto idle button off
 - Working/Travel
 - One touch decel button off
 - Safety lever unlock
- * Refer to the operator's manual page 3-35.

(6) Fuel warmer pilot lamp



300A3CD34

- ① This lamp lights up when the coolant temperature is below 10° C (50° F) or the hydraulic oil temperature is 20° C (68° F).
- ② The automatic fuel warming is cancelled when the engine coolant temperature is above $60^{\circ}C$ (140°F), and the hydraulic oil temperature is above $45^{\circ}C$ (113°F) since the start switch was ON position.

(7) Maintenance pilot lamp



300A3CD35

- ① This lamp lights up when consumable parts are in need of replacement. It means that the change or replacement interval of parts is 30 hours from the required change interval.
- ② Check the message in maintenance information of main menu. Also, this lamp lights up for 3 minutes when the start switch is switched to the ON position.
- * Refer to page 5-92.

(8) RMCU signal strength pilot lamp (mobile only)



① This lamp indicates RMCU signal strength as below.

: Searching

: Bad

: Normal

: Good

: Excellent

(9) Smart key pilot lamp (opt)



① This lamp lights up when the engine is started by the start button.

② This lamp is red when the a authentication fails, it will be green when it authentication is successful.


* Refer to the page 5-93.

(10) Auto safety lock pilot lamp



300A3CD37A

- ① Auto safety lock system prevents unintended operation of the machine in order to improve safety.
- ② Engine will only start if safety knob is locked.
- ③ If operator unlocks safety knob when RCV lever is pressed, machine is not controlled by RCV lever.
- ▲ If operator unlocks safety knob while any control/function is being operated, the machine will move violently. This could cause serious injury, death or damage to property.
- ① The function is released only by turning the safety knob to the UNLOCK position and the LOCK position again.



145A3CD38

(11) Auto engine shutdown pilot lamp



- ① This lamp lights up when the auto engine shutdown is activated.
- * Refer to page 5-88.

(12) Engine rpm state

		Auto Idle Mode	One Touch Decel	
Function	Safety Knob	n/min	n/min I	RPM State
State 1	Unlock	OFF	OFF	High rpm
State 2	Unlock	OFF	ON	Low rpm
State 3	Unlock	ON	OFF	Auto Idle rpm
State 4	Lock	ON	OFF	Low rpm
State 5	Lock	OFF	ON	Low rpm
State 6	Unlock	ON	ON	Low rpm
State 7	Lock → Unlock	ON	ON	Low → High → Low rpm (few seconds later)
State 8	Lock	ON	OFF	Low rpm
State 9	Lock	ON	ON	Low rpm


7) SWITCHES



130A3CD39

When some of the switches are selected, the pilot lamps are displayed on the LCD. Refer to page 5-77 for details.

(1) Power mode switch



- ① This switch is to select the machine power mode and when pressed, the power mode pilot lamp will be displayed on the section of the monitor.
 - · P : Heavy duty power work.
 - · S : Standard power work.
 - · E : Economy power work.
- ② The pilot lamp changes $E \rightarrow S \rightarrow P \rightarrow E$ in this order.


(2) Work mode switch



- This switch is to select the machine work mode, which shifts from general operation mode to optional attachment operation mode.
 - · 🖯 : General operation mode
 - : Breaker operation mode (if equipped)
 - · S: Crusher operation mode (if equipped)
 - · Lifting mode
 - · Not installed: Breaker or crusher is not installed.
- ※ Refer to page 2-7 for details.
- ② If you press this switch for a time (1 second), quick pop-up will appear. When you select an attachment from the popup, the operation mode will immediately switch to selected attachment.



(3) User mode switch



- ① This switch is used to select the user mode.
- ② Refer to page 5-86 for another set of the user mode.

(4) Travel speed switch



- ① This switch is used to select the travel speed alternatively.
 - · Low speed : High speed
- Do not change the setting of the travel speed switch while machine is moving. Machine stability may be adversely affected.
- ▲ Serious injury or death can result from sudden changes in machine stability.

(5) Auto idle/buzzer stop switch



- ① This switch is used to activate or cancel the auto idle function.
 - · Pilot lamp ON : Auto idle function is activated.
 - · Pilot lamp OFF: Auto idle function is cancelled.
- ② The buzzer sounds when the machine has a problem. In this case, push this switch and buzzer stops, but the warning lamp blinks until the problem is cleared.

(6) Escape/Camera switch



- ① This switch is used to return to the previous menu or parent menu.
- ② In the operation screen, pushing this switch will display the view of the camera on the machine (if equipped).

 Please refer to page 5-99 for the camera.
- ③ If the camera is not installed, this switch is used only ESC function.

(7) Work light switch



- ① This switch is used to operate the work light.
- ② The pilot lamp lights up when this switch is pressed.

(8) Head light switch



- ① This switch is used to operate the head light.
- ② The pilot lamp lights up when this switch is pressed.

(9) Intermittent wiper switch



- ① When this switch is pressed, wipers operate intermittently.
- ② The pilot lamp lights up when this switch is pressed.

(10) Wiper switch



- ① This switch is used to operate the wiper.
- 2 Note that the wiper will self-park when switched off.
- 3 The pilot lamp lights up when this switch is pressed.
- △ If the wiper does not operate with the switch in ON position, turn the switch OFF immediately. Check the cause. If the switch remains ON, motor failure can result.

(11) Washer switch




- ① Washer fluid is sprayed and the wiper is operated only when this switch is pressed.
- ② The pilot lamp lights up when this switch is pressed.

(12) Cab light switch



- ① This switch turns on the cab light.
- ② The pilot lamp lights up when this switch is pressed.

(13) Beacon switch (opt)



- ① This switch activates the rotary light on the cab.
- ② The pilot lamp lights up when this switch is pressed.

(14) Overload switch (opt)



- ① When this switch is activated, buzzer makes sound and overload warning lamp lights up in the event that the machine is or becomes in an overloaded situation.
- ② When the switch is inactivated, buzzer stops and warning lamp goes off.
- ⚠ Overloading the machine could impact the machines stability which could result in tipover hazard. A tipover hazard could result in serious injury or death. Always activate the overload warning device before you handle or lift objects.

(15) Travel alarm switch



- ① This switch is to activate travel alarm function surrounding when the machine travels.
 - · ON : The travel alarm function is activated.
 - · OFF : The travel alarm function is not activated.

(16) Main menu quick touch switch



- ① This switch is to activate the main menu in the cluster.
- * Refer to page 5-85.

8) MAIN MENU

- You can select or set the menu by the touch screen.On the operation screen, tap MENU to access the main menu screen.
- On the sub menu screen, you can tap the menu bar to access functions or applications.

· Operation screen



130A3CD40

(1) Structure

No	Main menu	Sub menu	Description
1	Mode 290F3CD103	Work tool U mode power Boom/Arm speed Auto power boost IPC mode Auto engine shutdown Initial mode Emergency mode	Breaker, Crusher, Not installed User mode only Boom speed, Arm speed Enable, Disable Speed mode, Balance mode, Efficiency mode One time, Always, Disable Key on initial mode / initial work mode, Accel initial mode / step Switch function
2	Monitoring 290F3CD104	Active fault Logged fault Delete logged fault Monitoring	MCU, Engine ECM, AAVM (opt) MCU, Engine ECM, AAVM (opt) All logged fault delete, Initialization canceled Machine information, Switch status, Output status,
3	Management 290F3CD105	Fuel rate information Maintenance information Machine security Machine information Contact Service menu Clinometer Update	General record, Hourly, Daily, Mode record Replacement, Change interval oils and filters ESL mode setting, Password change Model, MCU, Monitor, switch controller, RMCU, Relay drive unit, AAVM (opt) A/S phone number, A/S phone number change Power shift, Operating hour, Breaker mode pump acting, EPPR current level, Overload pressure, Optional piping pressure removal, Fine swing Clinometer setting Cluster, ETC device
4	Display 290F3CD106	Display item Clock Brightness Unit setup Language selection Screen type	Engine speed, Tripmeter A, Tripmeter B, Tripmeter C Clock Manual, Auto Temperature, Pressure, Flow, Distance, Date format Korean, English, ETC A type, B type
5	Utilities 290F3CD107	Tripmeter Camera Auto idle time setting	3 kinds (A, B, C) Camera setting, Auto mode (travel) Time setting

(2) Mode setup


① Work tool (Machine Serial No.: -#0440)



- · Select installed optional attachment
 - A: It can set the user's attachment.
 It is available in setting #1~#10.
 - B : Max flow Set the maximum flow for the attachment. Relief pressure Set the relief pressure.

(2) Mode setup

① Work tool (Machine Serial No.: #0441-)




Operation type

Operation type is used to set the operation of the proportion switch on the RCV lever if equipped proportional function.


- Push : Switch actuation will be deactivated when the proportion switch is released.
- Detent : Switch actuation will remain even if the proportion switch is released.

To deactivate, move the switch in the same direction again or to the opposite direction.

- Proportion : Switch actuation is proportional to the movement of the proportion switch.



② U mode power



235A3CD45B

- Engine high idle rpm, auto idle rpm and pump torque (power shift) can be modulated and memorized separately in U-mode.
- · U-mode can be activated by user mode switch.

Step (■)	Engine speed (rpm)	Idle speed (rpm)	Power shift (bar)
1	1300	750	0
2	1400	800	3
3	1500	850	6
4	1600	900	9
5	1700	950	12
6	1800	1000	16
7	1850	1050	20
8	1900	1100	26
9	1950	1150	32
10	2000	1200 (auto decel)	38

One touch decel & low idle: 1100 rpm

3 Boom/Arm speed



Boom speed

It adjusts the ratio of relative speed in the boom up and swing combination operation.

- Boom priority enable is mainly used in work environments that require high boom up work at a short swing angle of about 45 degrees.
- Boom priority disable is recommended for use in work environments that require high swing speed and acceleration, some slow boom up, and more than 45 degrees.

· Arm speed

This provides ON and OFF of the regeneration function of the arm in operation.

- Enable means that regeneration is ON, and an energy can be used efficiently through automatic regeneration according to the load.
- Disable means that regeneration is always OFF, and it can be effective for heavy digging work.

4 Auto power boost



- · The power boost function can be activated or cancelled.
 - Enable : The digging power is automatically increased as working conditions by the MCU. It is operated max 8 seconds.
 - Disable : Not operated.
- * The auto power boost function is activated in P mode. It does not work in S mode and E mode.

⑤ IPC mode



- · The operator can improve fuel consumption and working speed through IPC mode.
- · IPC mode is working by using inertial energy in specific case.
- · The IPC mode can be selected by this menu.
 - Speed mode / Balance mode / Efficiency mode
- The effect of IPC mode is different at power mode. The fuel efficiency is about 5% in P mode and about 3% in E mode based on Balance mode against Speed mode.
- The manufacturer recommends using the balance mode in IPC mode.
- * The effect is the result of the standard operation. Depending on the operator's working conditions and machine options, the results could be different.
- Please update the cluster programs if this mode is not displayed in the mode setup menu. Refer to page 5-96.

6 Automatic engine shutdown



- · The automatic engine shutdown function can be set by this menu.
 - One time
 - Always
 - Disable
 - Wait time setting: Max 40 minutes, min 2 minutes

7 Initial mode



· Key on initial mode

- Selected the power mode is activated when the engine is started.

· Key on initial work mode

- Not installed
- Last setting
- Work mode

· Accel initial mode

- Last setting value
- User setting value

8 Emergency mode



· This mode can be used when the switches are abnormal on the cluster.

· The cluster switches can be selected by touching each icon.


(3) Monitoring

① Active fault



· The active faults of the MCU, ECM, AAVM (option) can be checked by this menu.

② Logged fault



· The logged faults of the MCU, ECM, AAVM (option) can be checked by this menu.

3 Delete logged fault



· The logged faults of the MCU, ECM, AAVM (option) can be deleted by this menu.

4 Monitoring




- The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu (Analog input).
- The switch status or output status can be confirmed by this menu (Digital input & Digital output).
- . The activated switch or output pilot lamps
 will light up.

(4) Management

① ECO report

This reports the machine's inefficient operation status in order to improve operator's improper working habit.



② Fuel rate information










MENU HYUNDAI PORIOS NA HYUNDAI Reset





235A3CD86A

235A3CD84A

· General record (A)

- Average fuel rate (left) (from "Reset" to now)
 Fuel consumption divided by engine run time (service meter time).
- A days fuel used (right)
 Fuel consumption from 24:00 (or "Reset" time) to now (MCU real time).

· Hourly record (B)

- Hourly fuel rates for past 12 hours (service meter time).
- No record during key-off time.
- One step shift to the right for every one hour.
- Automatic deletion of data from 12 hours and earlier.
- "Reset" deletes all hourly records.

· Daily record (C)

- Daily fuel consumption for past seven days (MCU real time).
- No record during key-off time.
- One step shift to the right at 24:00 for every day.
- Automatically deletes data from 7 days and earlier.
- All daily records deletion by "Reset".

· Mode record (D)

- Average fuel rate for each power mode/accel dial (at least 7) from "Reset" till present.
- No record during idle.
- All records can be deleted by "Reset".

3 Maintenance information



- · Alarm lamp () is ON when oil or filter needs to be changed or replaced.
- · Replacement: The elapsed time will be reset to zero (0).
- · Change interval: The change intervals can be changed in hour increments of 50.
- · Change or relpace interval : Refer to maintenance.

4 Machine security



· ESL mode setting

- ESL: Engine Starting Limit
- ESL mode is desingned to be a theft deterrent or will prevent the unauthorized operation of the machine.
- When you Enable the ESL mode, the password will be required when the starting switch is turned to the on position.
- Machine security

Disable: ESL function is disabled and password is not required to start engine.

Enable (always): The password is required whenever the operator starts engine.


 Interval: The password is required when the operator starts engine first. But the operator can restart the engine within the interval time without inputting the password. The interval time can be set to a maximum 4 hours.

※ Default password : 00000 +
✓

※ Password length: (5~10 digits) + Smart key (option): Refer to next page.

Password change

- The password is 5~10 digits.



* Before first use, please set user password and owner password in advance for machine security.

- Smart key



- Smart key is registered when equipped with optional smart key. If smart key is not inside of the cabin, authentication process fails and the password is needed.
- · Tag management menu is activated when the Smart key menu is Enabled.

You can register and delete the tags.

- Tag management

- · When registering a tag : Only the tag you want to register must be in the cabin.
- · When deleting a tag: All registered tags are deleted.













235A3CD005

Engine Starting Condition

Case	ESL Mode	Smart Key	Condition
1	Disable	Disable	With registered tag: Engine can be started without password input.Without registered tag: Engine can be started without password input.
2	Disable	Enable	If Smart Key is enabled, ESL Mode is automatically enabled. This Case 2 work the same as the Case 4.
3	Enable	Disable	With registered tag: Engine can be started with password input.Without registered tag: Engine can be started with password input.
4	Enable	Enable	With registered tag: Engine can be started without password input.Without registered tag: Engine can be started with password input.

(5) Machine Information



· This can confirm the identification of the model information (ECU), MCU, monitor, switch controller, RMCU, relay driver unit, AAVM (opt).

⑥ Contact (A/S phone number)



Enter the new A/S phone number

7 Service menu



- * This menu can be used only HCE service man and can not be accessible by the owner and the operator.
- · Power shift (standard / option): Power shift pressure can be set by option menu.
- · Operating hours : Operating hours since the machine line out can be checked by this menu.
- · Breaker mode pump acting (1 pump / 2 pump)
- EPPR current level (attach flow EPPR 1 & 2, boom priority EPPR, attach relief pressure EPPR 1& 2)
- · Overload pressure: 100 ~ 350 bar
- Opitonal piping pressure removal (Disable / Enable)
 It is removing the residual pressure remaining in the option line when the quick coupler is operated.
- · Fine swing (Disable / Enable)

® Clinometer


will reset to "O".



· When the machine is on the flatland, if you touch "initialization" on cluster, the values of X, Y

· You can confirm tilt of machine in cluster's operating screen.

9 Update (cluster & ETC devices)



- · ETC devices and cluster can be updated through CAN 2 network.
- · Insert USB memory stick which includes program files, start download.

10 OME (owner menu editing)

The owner of machine can restrict operator access to set functions.



- · Owner can set the status of the function.
 - Enable
 - Disable
- · In the menu, owner can set the list of functions in which they would like to lock or leave unlocked.
- · Owner password (default password : 11111)
 - Owner can manage and change the password.
 - Necessary to input the password to access function menu.



(5) Display

① Display item



- · The center display type of the LCD can be selected by this menu.
- · The engine speed or the tripmeter menu (A,B,C) is displayed on the center display.

2 Clock



- · The first row of boxes indicate Year/Month/Day.
- · The second row shows the current time. (0:00~23:59)

3 Brightness



· If "Auto" is chosen, brightness for day and night can be set accordingly. Also by using the bar in lower side, users can define which an operation interval belongs to day and night. (in bar figure, white area represents night time while orange shows day time)

4 Unit



235A3CD132A

· Temperature : $^{\circ}C \leftrightarrow ^{\circ}F$

· Pressure : bar \leftrightarrow MPa \leftrightarrow kgf/cm²

 $\begin{array}{ll} \cdot \ \, \text{Volume} & : \ell \longleftrightarrow \text{gal} \\ \cdot \ \, \text{Flow} & : |\text{pm} \longleftrightarrow \text{gpm} \\ \cdot \ \, \text{Distance} & : \text{km} \longleftrightarrow \text{mile} \end{array}$

· Date format : $yy/mm/dd \leftrightarrow mm/dd/yy \leftrightarrow dd-mm-yy$


⑤ Language



· User can select preferable language and all displays are changed to the selected language.

(6) Utilities

① Tripmeter



235A3CD144A

- · A maximum of 3 types of tripmeters can be used at the same time.
- Each tripmeter can be turned on by choosing "Start" while it also can be turned off by choosing "Stop".
- · If the tripmeter icon is activated in the operation screen, it can be controlled directly there.

② Camera setting

- · If the rear camera is not installed on the machine, set disable.
- · If the rear camera is installed on the machine, set enable.



· In the operation screen, rear camera screen shows up when ESC/CAM switch is pushed.



290F3CD221

3 Auto idle time setting




 $\cdot\,$ The auto idle time is can be set by this menu.

· Time: 3~30 seconds

- **4 AAVM** (Advanced Around View Monitoring, option)
- · The AAVM switchs of the cluster consist of ESC/CAM and AUTO IDLE/Buzzer stop.



- Escape switch
- · Activates AAVM mode from the beginning if AAVM is installed.
- · While in the AAVM mode, select the ESC switch to return to the home screen.



- Buzzer stop switch
- · AAVM mode detects surrounding pedestrians or objects and the warning buzzer sounds.
- · User can turn OFF the warning sound by pressing the buzzer stop switch.



- · When a worker/pedestrian reaches the green line, which is an external danger area equipped on the cluster, warning buzzer sounds and it displays a green rectangular box recognizing the worker/pedestrian.
 - Stop work immediately. Stop the buzzer by pressing the buzzer stop switch. Then resume work after you confirm that the area is safe and clear of workers/objects.




220A3CD247


When a worker/pedestrian reaches the red line, which is an internal danger area equipped on the cluster, warning buzzer sounds and it displays a red rectangular box recognizing the worker/pedestrian. Stop work immediately. Stop the buzzer by pressing the buzzer stop switch. Then resume work after you confirm that the area is safe and clear of workers/objects.

▲ Failure to comply may result in serious injury or death.

10. WHEN SAFETY SOLENOID DOES NOT OPERATE

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 26.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.
- · Auto safety lock function execution condition : When the RCV pilot pressure increases above certain pressure within the standard time after changing the safety knob LOCK \rightarrow UNLOCK
- · Under the above conditions, the electric current is turned off to the safety solenoid, and the function of RCV and pedal is disabled.






9) AIR CONDITIONER AND HEATER

Full auto air conditioner and heater system automatically keeps the optimum condition in accordance with operator's temperature configuration, sensing ambient and cabin inside temperature.

· Location of air flow ducts



235F3CD06

(1) Power off switch



This switch turns the system ON and OFF.Just before powering OFF, set values are stored.

② Default setting values

Function	Air conditioner	In/outlet	LCD	Temperature	Mode
Value	OFF	Inlet	OFF	Previous sw OFF	Previous sw OFF

(2) Auto switch




- ① Turn the starting switch to ON position, LCD lights ON. Auto air conditioner and heater system automatically keeps the optimum condition in accordance with operator's temperature configuration sensing ambient and cabin inside temperature.
- ② This switch can restart system after system OFF.

(3) Air conditioner switch (compressor switch)



- ① This switch turns the compressor and the LCD ON.
- ② In accordance with the temperature sensed by duct (evaporator) sensor, compressor turns ON or OFF automatically.
- Air conditioner operates to remove vapor and drains water through a drain hose. Water can be sprayed into the cab in case that the drain cock at the ending point of drain hose has a problem. In this case, exchange the drain cock.

(4) Fan speed switch



- ① Fan speed is controlled automatically by setted temperature.
- 2 This switch controls fan speed manually.
 - · There are 8 up/down steps to control fan speed.
 - · The maximum step or the minimum step beeps 5 times.
- 3 This switch makes the system ON.

(5) Temperature control switch



- ① Setting temperature indication
 - a. Type A: 17~32°C, scale: 1°C
- b. Type B: Lo, 18~31°C, Hi, scale: 1°C
- 2 Max cool and max warm beeps 5 times.
- 3 The max cool or the max warm position operates per the following table.

Temperature	Compressor	Fan speed	In/Outlet	Mode
Max cool	ON	Max (Hi)	Recirculation	Vent
Max warm	OFF	Max (Hi)	Fresh	Foot

- ④ Temperature unit can be changed between celsius (°C) and fahrenheit (°F)
 - a. Default status (°C)
 - b. The temperature unit can be changed ($^{\circ}$ C \leftrightarrow $^{\circ}$ F) by pressing temperature switches (Up/Down) simultaneously for more than 5 seconds.

(6) Mode switch



 ① Operating this switch, it beeps and displays symbol of each mode in the following order. (Vent → Vent/Foot → Def/Foot → Def/Vent → Def/ Vent/Foot)

Mode switch		Vent	Vent/Foot	Def/Foot	Def/Vent	Def/Vent/Foot
		- نر	۔ نے		% -	
Outlet	Α	•	•		•	•
	В		•			•
	С			•	•	•

When operating defroster, FRESH AIR/AIR RECIRCULATION switch turns to FRESH AIR mode and air conditioner switch turns ON.


(7) FRESH AIR/AIR RECIRCULATION SWITCH



- ① It is possible to change the air-inlet method.
 - a. Fresh air () Inhaling air from the outside.
 - Check out the fresh air filter periodically to keep a good efficiency.
 - b. Air recirculation ()
 It recycles the heated or cooled air to increase the energy efficiency.
 - Change air occasionally when using recirculation for a long periods
 of time.
 - Check condition of fresh air filter and recirculation filter periodically to maintain good efficiency of the system.

(8) Self diagnosis function

① Procedure



3607A3CD69

② Error check

- · The corresponding error code flickers on the setup temperature display panel, the other symbol will turn OFF.
- · Error code flickers every 0.5 second.
- · If error code is more than two, each code flickers 2 times in sequence.
- · Error code

Error code	Description	Error code	Description
11	Cabin inside sensor	16	Mode actuator 1
12	Ambient sensor	17	Mode actuator 2
14	Duct (evaporator) sensor	18	Intake actuator
15	Temp actuator	-	-

3 Fail safe function

Error description	Fail safe function
Cabin inside sensor (11)	25°C alternate value control
Ambient sensor (12)	20°C alternate value control
Duct (evaporator) sensor (14)	1°C alternate value control
Tomp actuator (15)	If opening amount is 0 %, the alternate value is 0 %
Temp actuator (15)	If not, the alternate value is 100 %
Mode actuator 1, 2 (16, 17)	The alternate value is vent

GROUP 16 FUEL WARMER SYSTEM


1. SPECIFICATION

1) Operating voltage: 24±4 V


2) Power : 350±50 W3) Current : 15 A

2. OPERATION

- 1) The current of fuel warmer system is automatically controlled without thermostat according to fuel temperature.
- 2) At the first state, the 15 A current flows to the fuel warmer and engine may be started in 1~2 minutes.
- 3) If the fuel starts to flow, ceramic-disk in the fuel warmer heater senses the fuel temperature to reduce the current as low as 1.5 A.
 - So, fuel is protected from overheating by this mechanism.



3. ELECTRIC CIRCUIT



GROUP 17 1 or 2-WAY OPTIONAL PIPING PRESSURE REMOVAL SYSTEM

1. OUTLINE

This system can be removed the residual pressure of the optional attachment hydraulic piping when the quick coupler is operated by the switch of the RCV lever and then the oil quick function of the optional attachment is performed.


Oil guick function

In a convention work, the optional attachments such as breaker or grab are installed on the machine and needed to connect hydraulic piping additionally.

But currently, the hydraulic piping connection is not needed by the work man. The attachment is installed on the machine and the hydraulic pipings are connected by a coupler that is built in the quick coupler automatically and the attachment can be ready to operate immediately. This is called the oil quick function.


2. OPERATING PRINCIPLE

This is operated by controlling the setting pressure of the electric type relief valve when you operate the quick coupler with the switch of the RCV lever.



220A5MS104

3. SETTING METHOD



- factory.
- 2) Optional piping pressure removal is set to Enable then the oil quick function is operated. Also, the caution letter is display on the lower side of the cluster.
- 3) The setting condition is saved even if shut the engine off.

4. CAUTION

- 1) When the oil quick function is used, the hydraulic drift and etc can be occurred as the modified equipment specification.
- 2) The status of the cluster must be changed by a manager that is well-acquainted with the function and the operator must be well-informed of the oil quick function and safety work.

SECTION 6 TROUBLESHOOTING

Group	1	Before Troubleshooting	6-1
Group	2	Hydraulic and Mechanical System	6-4
Group	3	Electrical System	6-24
Group	4	Mechatronics System ·····	6-42
Group	5	Air conditioner and Heater System	6-71


GROUP 1 BEFORE TROUBLESHOOTING

1. INTRODUCTION

When a trouble is occurred in the machine, this section will help service men repair the machine with easy.

The trouble of machine is parted Hydraulic & Mechanical system, Electrical system and Mechatronics system. At each system part, service men can check the machine according to the troubleshooting process diagram.

* Before carring out troubleshooting procedure, check monitoring menu in the cluster.




2. DIAGNOSING PROCEDURE

To carry out troubleshooting efficiently, the following steps must be observed.

STEP 1. Study the machine system

Study and know how the machine is operating, how the system is composing, what kinds of function are installed in the machine and what are specifications of the system components by the machine service manual.


Especially, deepen the knowledge for the related parts of the trouble.



STEP 2. Ask the operator

Before inspecting, get the full story of malfunctions from a witness --- the operator.


- 1) How the machine is used and when it is serviced?
- 2) When the trouble was noticed and what work the machine was doing at that time?
- 3) What is the phenomenon of the trouble? Was the trouble getting worse, or did it come out suddenly for the first time?
- 4) Did the machine have any troubles previously? If so, which parts were repaired before.



STEP 3. Inspect the machine

Before starting troubleshooting, check the machine for the daily maintenance points as shown in the operator's manual.


And also check the electrical system including batteries, as the troubles in the electrical system such as low battery voltage, loose connections and blown out fuses will result in malfunction of the controllers causing total operational failures of the machine.



STEP 4. Inspect the trouble actually on the machine


In case that some trouble cannot be confirmed, obtain the details of the malfunction from the operator.

Also, check if there are any in complete connections of the wire harnesses are or not.



STEP 5. Perform troubleshooting


According to where the trouble parts are located, hydraulic & mechanical system part or electrical system part or mechatronics system part, perform troubleshooting the machine refer to the each system part's troubleshooting process diagram.



STEP 6. Trace a cause

Before reaching a conclusion, check the most suspectible causes again. Try to trace what the real cause of the trouble is.

Make a plan of the appropriate repairing procedure to avoid consequential malfunctions.



GROUP 2 HYDRAULIC AND MECHANICAL SYSTEM

1. INTRODUCTION

1) MACHINE IN GENERAL

- (1) If even a minor fault is left intact and operation is continued, a fatal failure may be caused, entailing a large sum of expenses and long hours of restoration.
 - Therefore when even a small trouble occurs, do not rely on your intuition and experience, but look for the cause based on the troubleshooting principle and perform maintenance and adjustment to prevent major failure from occurring. Keep in mind that a fault results from a combination of different causes.
- (2) The following lists up commonly occurring faults and possible causes with this machine. For the troubleshooting of the engine, refer to the coming troubleshooting and repair.
- (3) When carrying out troubleshooting, do not hurry to disassemble the components. It will become impossible to find the cause of the problem.
- (4) Ask user or operator the following.
- ① Was there any strange thing about machine before failure occurred?
- ② Under what conditions did the failure occur?
- 3 Have any repairs been carried out before the failure?
- (5) Check before troubleshooting.
- ① Check oil and fuel level.
- ② Check for any external leakage of oil from components.
- 3 Check for loose or damage of wiring and connections.

2) MACHINE STATUS MONITORING ON THE CLUSTER

(1) The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu.





Alle


Analog 2

(2) Specification


No.	Description	Specification
Note 1	Work pilot pressure	40 ⁺² bar
Note 2	Swing pilot pressure	0~40 bar
Note 3	Boom up pilot pressure	0~40 bar
Note 4	Arm/bucket pilot pressure	0~40 bar
Note 5	Pump 1 regulator pressure	0~50 bar
Note 6	Pump 2 regulator pressure	0~50 bar
Note 7	Pump 1 pressure	330 bar

2. DRIVE SYSTEM

1) UNUSUAL NOISE COMES OUT OF PUMP CONNECTION




2) ENGINE STARTS BUT MACHINE DOES NOT OPERATE AT ALL




3. HYDRAULIC SYSTEM


1) HYDRAULIC OIL IS CLOUDY




2) HYDRAULIC OIL TEMPERATURE HAS RISEN ABNORMALLY



3) CAVITATION OCCURS WITH PUMP




4) HYDRAULIC OIL IS CONTAMINATED




4. SWING SYSTEM


1) BOTH LH AND RH SWING ACTIONS ARE IMPOSSIBLE




2) SWING SPEED IS LOW




3) SWING MOTION IS IMPOSSIBLE IN ONE DIRECTION




4) MACHINE SWINGS BUT DOES NOT STOP




5) THE SWING UNIT DRIFTS WHEN THE MACHINE IS AT REST ON A SLOPE



6) LARGE SHOCK OCCURS WHEN STOP SWINGING




7) LARGE SOUND OCCURS WHEN STOP SWINGING




5. TRAVEL SYSTEM

1) TRAVEL DOES NOT FUNCTION AT ALL ON ONE SIDE




2) SPEED ON ONE SIDE FALLS AND THE MACHINE CURVES




3) MACHINE DOES NOT STOP ON A SLOPE


Machine is pulled forward as sprocket rotates during digging operation.



4) LH AND RH TRAVEL MOTIONS ARE IMPOSSIBLE




5) TRAVEL ACTION IS POWERLESS (travel only)



6) MACHINE RUNS RECKLESSLY ON A SLOPE


Travel brake valve	Cause	Remedy
(counterbalance valve) is faulty.		Disassemble and repair or replace.

7) MACHINE MAKES A CURVED TRAVEL OR DOES NOT TRAVEL AT ALL WHEN TRAVEL AND ATTACHMENT OPERATIONS ARE EXECUTED AT THE SAME TIME




6. ATTACHMENT SYSTEM


1) BOOM OR ARM ACTION IS IMPOSSIBLE AT ALL




2) BOOM, ARM OR BUCKET SPEED IS LOW




3) BOOM, ARM OR BUCKET CYLINDER EXTENDS OR CONTRACTS ITSELF AND ATTACHMENT FALLS




4) BOOM, ARM OR BUCKET POWER IS WEAK




5) ONLY BUCKET OPERATION IS TOTALLY IMPOSSIBLE



6) BOOM MAKES A SQUEAKING NOISE WHEN BOOM IS OPERATED




7) TIME LAG OF MACHINE WORKING IS LARGE.



GROUP 3 ELECTRICAL SYSTEM


1. WHEN STARTING SWITCH IS TURNED ON, CLUSTER DISPLAY DOES NOT APPEAR

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 7, 10.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check voltage

YES	20~32V
NO	0V




2. COMMUNICATION ERROR FLASHES ON THE CLUSTER (HCESPN 840, FMI 2)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check voltage

YES	2V
NO	0V




3. Fig. 3. BATTERY CHARGING WARNING LAMP LIGHTS UP (Starting switch : ON)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check voltage

YES	20~32V
NO	0V



4. OF WHEN COOLANT OVERHEAT WARNING LAMP LIGHTS UP (engine is started)


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






Check Table

OTTOOK TODIO					
Temperature (°C)	0	25	50	80	95
Resistance ($k\Omega$)	30~37	9.3~10.7	3.2~3.8	1.0~1.3	0.7~0.8




5. WHEN AIR CLEANER WARNING LAMP LIGHTS UP (engine is started)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check resistance


YES	MAX 1 Ω
NO	MIN 1MΩ



6. WHEN ENGINE OIL PRESSURE WARNING LAMP LIGHTS UP (engine is started)


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.





7. WHEN HYDRAULIC OIL TEMPERATURE WARNING LAMP LIGHTS UP (engine is started)


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.



B


Check Table

Temperature (°C)	~ -30	~ -10	~ 0	~ 40	~ 70	~ 80	~ 90	~ 100	105~
Resistance (kΩ)	22.22	8.16	5.18	1.06	0.39	0.322	0.243	0.185	0.164
	~31.78	~10.74	~ 6.6	~1.28	~0.476	~0.298	~0.219	~0.167	~0.151



8. WHEN COOLANT TEMPERATURE GAUGE DOES NOT OPERATE


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






Check Table

Temperature (°C)	0	25	50	80	95
Resistance ($k\Omega$)	30~37	9.3~10.7	3.2~3.8	1.0~1.3	0.7~0.8



9. WHEN FUEL GAUGE DOES NOT OPERATE (HCESPN 301, FMI 3 or 4)


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






Check Table


Range	Resistance (Ω)	Range	Resistance (Ω)
Full	50	5/12	400
11/12	100	4/12	450
10/12	150	3/12	500
9/12	200	2/12	550
8/12	250	1/12	600
7/12	300	Empty warning	700
6/12	350	-	-



10. WHEN SAFETY SOLENOID DOES NOT OPERATE


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 26.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.
- · Auto safety lock function execution condition : When the RCV pilot pressure increases above certain pressure within the standard time after changing the safety knob LOCK \rightarrow UNLOCK
- · Under the above conditions, the electric current is turned off to the safety solenoid, and the function of RCV and pedal is disabled.







11. WHEN TRAVEL SPEED 1, 2 DOES NOT OPERATE (HCESPN 167, FMI 4 or 6)


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 24.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






12. TRAVEL ALARM DOES NOT SOUND OR DOES NOT STOP SOUNDING







13. HORN DOES NOT SOUND



14. WHEN ENGINE DOES NOT START (| - + | lights up condition)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 1, 2, 12, 13, 15.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







130A6ES17

15. WHEN STARTING SWITCH ON DOES NOT OPERATE


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted, master switch ON and check open circuit of circuit breaker (CN-60).
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






16. WHEN STARTING SWITCH IS TURNED ON, WIPER MOTOR DOES NOT OPERATE

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and the fuse No. 6, 11 and 21 is not blown out.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







130A6ES19

17. WHEN STARTING SWITCH IS TURNED ON, HEAD LAMP DOES NOT LIGHTS UP

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.11 & 16.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







130A6ES20

6-40

18. WHEN STARTING SWITCH IS TURNED ON, WORK LAMP DOES NOT LIGHTS UP

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.11 & 17.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.





130A6ES21


6-41

GROUP 4 MECHATRONICS SYSTEM


1. ALL ACTUATORS SPEED ARE SLOW

- * Boom, Arm, Bucket, Swing and travel speed are slow, but engine speed is good.
- lpha Spec : P-mode 1900 \pm 50 rpm S -mode 1750 \pm 50 rpm E-mode 1700 \pm 50 rpm
- * Before carrying out below procedure, check all the related connectors are properly inserted and fault code on the cluster.


1) INSPECTION PROCEDURE




Wiring diagram




- (1) **Test 1**: Check resistance at connector CN-75.
- ① Starting switch OFF.
- ② Disconnect connector CN-75 from EPPR valve at main hydraulic pump.
- ③ Check resistance between 2 lines as figure.



- (2) Test 2 : Check electric current at EPPR valve.
- ① Disconnect connector CN-75 from EPPR valve.
- ② Insert the adapter to CN-75 and install multimeter as figure.
- ③ Start engine.
- 4 Set S-mode and cancel auto decel mode.
- (5) Position the accel dial at 10.
- ⑥ If tachometer show approx 1750±50 rpm disconnect one wire harness from EPPR valve.
- ⑦ Check electric current at bucket circuit relief position.




- (3) Test 3: Check pressure at EPPR valve.
 - ① Remove plug and connect pressure gauge as figure.
 - · Gauge capacity : 0 to 50 kgf/cm² (0 to 725 psi)
 - ② Start engine.
 - 3 Set S-mode and cancel auto decel mode.
 - 4 Position the accel dial at 10.
 - Slowly operate control lever of bucket functions at full stroke over relief and measure the EPPR valve pressure by the the monitoring menu of the cluster.
 - 6 If pressure is not correct, adjust it.
 - 7 After adjust, test the machine.




2. ENGINE STALL

* Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE




Wiring diagram



- (1) **Test 4**: Check electric current at EPPR valve.
 - ① Disconnect connector CN-75 from EPPR valve.
 - ② Insert the adapter to CN-75 and install multimeter as figure.
 - ③ Start engine.
 - Set S-mode and cancel auto decel mode.
 - 5 Position the accel dial at 10.
 - 6 If rpm show approx 1750 \pm 50 rpm disconnect one wire harness from EPPR valve.
 - Theck electric current at bucket circuit relief position.




- (2) Test 5 : Check pressure at EPPR valve.
 - ① Remove plug and connect pressure gauge as figure.
 - · Gauge capacity: 0 to 50 kgf/cm² (0 to 725 psi)
 - ② Start engine.
 - ③ Set S-mode and cancel auto decel mode.
 - 4 Position the accel dial at 10.
 - Slowly operate control lever of bucket functions at full stroke over relief and measure the EPPR valve pressure by the the monitoring menu of the cluster.
 - 6 If pressure is not correct, adjust it.
 - 7 After adjust, test the machine.




3. MALFUNCTION OF CLUSTER OR MODE SELECTION SYSTEM

* Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE




Wiring diagram




4. AUTO DECEL SYSTEM DOES NOT WORK (N.A)


- Fault code: HCESPN 105, FMI 0~4 (work pressure sensor)
 HCESPN 108, FMI 0~4 (travel oil pressure sensor)
- * Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE






- (1) Test 7: Check voltage at CN-52 (27) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (27) of CN-52.
- ③ Starting switch ON.
- 4 Check voltage as figure.
- (2) Test 8: Check voltage at CN-52 (19) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper
- ② Insert prepared pin to rear side of connectors: One pin to (19) of CN-52.
- ③ Starting key ON.
- ④ Check voltage as figure.




5. MALFUNCTION OF PUMP 1 PRESSURE SENSOR

- · Fault code: HCESPN 120, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 9: Check voltage at CN-52 (22) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (22) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.




6. MALFUNCTION OF PUMP 2 PRESSURE SENSOR

- · Fault code: HCESPN 121, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 10: Check voltage at CN-51 (14) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (14) of CN-51.
- ③ Starting switch ON.
- ④ Check voltage as figure.




7. MALFUNCTION OF NEGATIVE 1 PRESSURE SENSOR

- · Fault code: HCESPN 123, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 12: Check voltage at CN-51 (22) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (22) of CN-51.
- ③ Starting switch ON.
- ④ Check voltage as figure.




8. MALFUNCTION OF NEGATIVE 2 PRESSURE SENSOR


- · Fault code: HCESPN 124, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE






- (1) Test 13: Check voltage at CN-51 (28) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (28) of CN-51.
- ③ Starting switch ON.
- ④ Check voltage as figure.




9. MALFUNCTION OF SWING PRESSURE SENSOR

- · Fault code: HCESPN 135, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 14: Check voltage at CN-52 (18) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (18) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.




10. MALFUNCTION OF ARM OUT PRESSURE SENSOR

- · Fault code: HCESPN 133, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 15: Check voltage at CN-51 (27) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (27) of CN-51.
- ③ Starting switch ON.
- ④ Check voltage as figure.




11. MALFUNCTION OF BOOM UP PRESSURE SENSOR

- · Fault code: HCESPN 127, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 16: Check voltage at CN-52 (23) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (23) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.




12. MALFUNCTION OF BOOM DOWN PRESSURE SENSOR

- · Fault code: HCESPN 128, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram



- (1) Test 17: Check voltage at CN-52 (31) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (31) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.




13. MALFUNCTION OF POWER MAX


· Fault code: HCESPN 166, FMI 4 or 6

* Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE




Wiring diagram



- (1) Test 18: Check voltage between connector CN-88 (2) GND.
- ① Disconnect connector CN-88 from power max solenoid valve.
- ② Start switch ON.
- ③ Check voltage as figure.



- (2) Test 19: Check resistance of the solenoid valve between CN-88 (1)-(2).
- ① Starting switch OFF.
- ② Disconnect connector CN-88 from power max solenoid valve.
- ③ Check resistance as figure.




14. MALFUNCTION OF BOOM PRIORITY EPPR VALVE


· Fault code: HCESPN 141, FMI 5 or 6

* Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram




15. MALFUNCTION OF ARM REGENERATION SOLENOID

· Fault code: HCESPN 170, FMI 4 or 6

* Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 20: Check voltage at CN-52 (7) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (7) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.



GROUP 5 AIR CONDITIONER & HEATER SYSTEM

1. AIR CONDITIONER DOES NOT OPERATE



1) FAN DOES NOT OPERATE

Cause	Check	Remedy
Fuse is blown or abnormal relay operation	* Fuse * Does relay normally operate?	Replace
Harness short or poor contact	Check any harness short or abnormal contact of connnector	Repair shortage
Fan motor failure	Supply 24V to 2 lead wire from motor and check the operation	Replace
Resistor is broken	Check current flow of resistor with tester	Replace
Fan switch failure	Push fan switch by turn and check the operation	Replace

2) WEAK AIR FLOW FROM FAN MOTOR

Cause	Check	Remedy
Clogged evaporator or obstacles around air inlet	Check if evaporator is contaminated	Clean
Leakage of air flow	Check HVAC case assembly	Adjust
Duct sensor failure	Check if evaporator is frozen	Replace

3) ABNORMAL OPERATION OF FAN MOTOR

Cause	Check	Remedy
Abnormal operation of each step of control	4 step only operate	Replace resistor
	1 or 2 step does not operate	Replace control
	3 or 4 step does not operate	Replace relay

4) COMPRESSOR DOES NOT ROTATE OR HARDLY ROTATE

Cause	Check	Remedy
Loose belt	Belt shaking is severe	Adjust tension
Failure of compressor itself	Belt slip	Repair or Replace
Low voltage of battery	Slip when rotate	Charge battery
Fieldcoil short	Slip when rotate	Replace magnetic clutch
Oily clutch face	Contamination around clutch	Replace magnetic clutch, clean
Fieldcoil is broken	Magnetic clutch does not operate or "∞" resistance	Replace compressor
Leakage of refrigerant or oil inside	Check if wet with oil	Replace compressor Charge refrigerant

5) COMPRESSOR OPERATE NORMALLY AND AIR FLOW IS NORMAL

Cause	Check	Remedy
Shortage of refrigerant	When air con operate during 5~10 min small temperature difference between high and low pressure pipes.	Repair leakage joint Charge refrigerant
Overcharge of refrigerant	*Magnetic clutch on/off rapidly *High pressure over specification *Lukewarm air from nozzle Recharge refrigerant following specification	
	Shortage of refrigerant	Make up refrigerant
	Clogged receive dryer	Replace receive dryer
Lower pressure than normal condition at low side	Clogged expansion valve	Replace expansion valve
	Clogged or crushed pipe	Replace pipe or clean
	Failure of duct sensor	Replace duct sensor

6) COMPRESSOR OPERATE NORMALLY AND AIR FLOW IS NORMAL

Cause	Check	Remedy
Lower pressure than normal condition at	Failure of duct sensor Magnetic clutch off before air temperature sufficiently down	Replace duct sensor or adjust location
low side	Defective compressor gasket When compressor off, high and low pressure balance immediatly	Repair compressor or Replace
Higher pressure than	Failure of condensing Contamination on condenser or insufficient air flow from fan	Clean the condenser Repair fan
normal condition at high side	Overcharge of refrigerant	Adjust refrigerant
	Entrained air	Vacuum and recharge
Lower pressure than normal condition at high side	Shortage of refrigerant	Make up refrigerant

SECTION 7 MAINTENANCE STANDARD

Group	1 Operational Performance Test ······	7-1
Group	2 Major Components ·····	7-21
Group	3 Track and Work Equipment	7-29

GROUP 1 OPERATIONAL PERFORMANCE TEST

1. PURPOSE

Performance tests are used to check:

1) OPERATIONAL PERFORMANCE OF A NEW MACHINE

Whenever a new machine is delivered in parts and reassembled at a customer's site, it must be tested to confirm that the operational performance of the machine meets HD Hyundai Construction Equipment spec.


2) OPERATIONAL PERFORMANCE OF A WORKING MACHINE

With the passage of time, the machine's operational performance deteriorates, so that the machine needs to be serviced periodically to restore it to its original performance level.

Before servicing the machine, conduct performance tests to check the extent of deterioration, and to decide what kind of service needs to be done(by referring to the "Service Limits" in this manual).

3) OPERATIONAL PERFORMANCE OF A REPAIRED MACHINE

After the machine is repaired or serviced, it must be tested to confirm that its operational performance was restored by the repair and/or service work done.




130ZF7MS01

2. TERMINOLOGY

1) STANDARD


Specifications applied to the brand-new machine, components and parts.



130ZF7MS02

2) SERVICE LIMIT

The lowest acceptable performance level. When the performance level of the machine falls below this level, the machine must be removed from work and repaired. Necessary parts and components must be replaced.



130ZF7MS03

3. OPERATION FOR PERFORMANCE TESTS

1) Observe the following rules in order to carry out performance tests accurately and safely.

(1) The machine

Repair any defects and damage found, such as oil or water leaks, loose bolts, cracks and so on, before starting to test.

(2) Test area


- ① Select a hard, flat surface.
- ② Secure enough space to allow the machine to run straight more than 20m, and to make a full swing with the front attachment extended.
- ③ If required, rope off the test area and provide signboards to keep unauthorized personnel away.

(3) Precautions

- ① Before starting to test, agree upon the signals to be employed for communication among coworkers. Once the test is started, be sure to communicate with each other using these signals, and to follow them without fail.
- ② Operate the machine carefully and always give first priority to safety.
- ③ While testing, always take care to avoid accidents due to landslides or contact with high voltage power lines. Always confirm that there is sufficient space for full swings.
- 4 Avoid polluting the machine and the ground with leaking oil. Use oil pans to catch escaping oil. Pay special attention to this when removing hydraulic pipings.

(4) Make precise measurements

- Accurately calibrate test instruments in advance to obtain correct data.
- ② Carry out tests under the exact test conditions prescribed for each test item.
- ③ Repeat the same test and confirm that the test data obtained can be procured repeatedly. Use mean values of measurements if necessary.



(290-7TIER) 7-3

2) ENGINE SPEED

- (1) Measure the engine speed at each power mode
- ** The engine speed at each power mode must meet standard RPM; if not, all other operational performance data will be unreliable. It is essential to perform this test first.

(2) Preparation

- ① Warm up the machine, until the engine coolant temperature reaches 50°C or more, and the hydraulic oil is 50±5°C.
- ② Set the multimodal dial at 10 (Max) position.
- ③ Measure the engine RPM.

(3) Measurement

- ① Start the engine. The engine will run at start idle speed. Measure engine speed with a engine rpm display.
- ② Measure and record the engine speed at each mode (P, S, E).
- ③ Select the P-mode.
- ① Lightly operate the bucket control lever a few times, then return the control lever to neutral; The engine will automatically enter the auto-idle speed after 4 seconds.
- ⑤ Measure and record the auto deceleration speed.



(4) Evaluation

The measured speeds should meet the following specifications.

Unit: rpm

Model	Engine speed	Standard	Remarks
	Ctort idla	1000±50	Safety lever : Lock position
	Start idle	1100±50	Safety lever : Unlock position
HX130A LCR	P mode	1900±20	
HX 130A LCR	S mode	1750±20	
	E mode	1700±20	
	Auto decel	1200±50	
	One touch decel	1100±50	

- Condition: Set the multimodal dial at 10 (Max) position.
- Auto decel, one touch decel and low idle speed may increase to 1400 rpm while automatic
 exhaust system cleaning is being performed.

3) TRAVEL SPEED


(1) Measure the time required for the excavator to travel a 20 m test track.

(2) Preparation


- ① Adjust the tension of both tracks to be equal.
- ② Prepare a flat and solid test track 20m in length, with extra length of 3 to 5 m on both ends for machine acceleration and deceleration.
- 3 Hold the bucket 0.3 to 0.5 m above the ground with the arm and bucket rolled in.
- 4 Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- ① Measure both the low and high speeds of the machine.
- ② Before starting either the low or high speed tests, adjust the travel mode switch to the speed to be tested, then select the following switch positions.
- · Power mode switch: P mode
- 3 Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- 4 Measure the time required to travel 20 m.
- S After measuring the forward travel speed, turn the upperstructure 180 ° and measure the reverse travel speed.
- ⑥ Repeat steps ④ and ⑤ three times in each direction and calculate the average values.



145ZF7MS04



145ZF7MS05

(4) Evaluation

The average measured time should meet the following specifications.

Unit: Seconds / 20 m

Model	Travel speed	Standard	Maximum allowable	Remarks
HX130A LCR	1 Speed	23.3±2.0	29.5	
TIX TOOK LOT	2 Speed	13.5±1.0	17.3	

4) TRACK REVOLUTION SPEED

(1) Measure the track revolution cycle time with the track raised off ground.

(2) Preparation

- ① Adjust the tension of both side tracks to be equal.
- ② On the track to be measured, mark one shoe with chalk.
- ③ Swing the upperstructure 90 °and lower the bucket to raise the track off ground. Keep the boom-arm angle between 90 to 110 °as shown. Place blocks under machine frame.
- 4 Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.




- ① Select the following switch positions.
- · Travel mode switch : 1 or 2 speed
- · Power mode switch : P mode
- · Auto idle switch : OFF
- ② Operate the travel control lever of the raised track in full forward and reverse.
- ③ Rotate 1 turn, then measure time taken for next 3 revolutions.
- ④ Raise the other side of machine and repeat the procedure.
- S Repeat steps 3 and 4 three times and calculate the average values.

(4) Evaluation

The revolution cycle time of each track should meet the following specifications.

Unit: Seconds / 3 revolutions

Model	Travel speed	Standard	Maximum allowable
LIVAGOALOD	1 Speed	26.1±2.0	35.0
HX130A LCR	2 Speed	14.8±2.0	20.6



145ZF7MS06

5) TRAVEL DEVIATION

(1) Measure the deviation by the tracks from a 20m straight line.

(2) Preparation


- ① Adjust the tension of both tracks to be equal.
- 2 Provide a flat, solid test yard 20 m in length, with extra length of 3 to 5 m on both ends for machine acceleration and deceleration.
- 3 Hold the bucket 0.3 to 0.5 m above the ground with the arm and bucket rolled in.
- 4 Keep the hydraulic oil temperature at 50±5°C.

(3) Measurement


- ① Measure the amount of mistracking at high and low travel speeds.
- 2 Before beginning each test, select the following switch positions.
- · Power mode switch : P mode
- 3 Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- ④ Measure the distance between a straight 20 m line and the track made by the machine. (Dimension a)
- (5) After measuring the tracking in forward travel, turn the upperstructure 180 °and measure that in reverse travel.
- 6 Repeat steps 4 and 5 three times and calculate the average values.

(4) Evaluation

Mistrack should be within the following specifications.



145ZF7MS04



(210-7) 7-7(2)

Unit: mm/20 m

Model	Standard	Maximum allowable	Remarks
HX130A LCR	200 below	240	

6) SWING SPEED

(1) Measure the time required to swing three complete turns.

(2) Preparation

- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- 4 Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.




- ① Select the following switch positions.
- · Power mode switch : P mode
- ② Operate swing control lever fully.
- ③ Swing 1 turn and measure time taken to swing next 3 revolutions.
- ④ Repeat steps ② and ③ three time and calculate the average values.

(4) Evaluation

The time required for 3 swings should meet the following specifications.

Unit: Seconds / 3 revolutions

Model	Power mode switch	Standard	Maximum allowable
HX130A LCR	P mode	13.9±1.5	16.9



145ZF7MS07

7) SWING FUNCTION DRIFT CHECK


(1) Measure the swing drift on the bearing outer circumference when stopping after a 360° full speed swing.

(2) Preparation


- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- Make two chalk marks: one on the swing bearing and one directly below it on the track frame.
- Swing the upperstructure 360°.
- 6 Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- ① Conduct this test in the M mode.
- ② Select the following switch positions.
 - · Power mode switch : P mode
- ③ Operate the swing control lever fully and return it to the neutral position when the mark on the upperstructure aligns with that on track frame after swinging 360°.
- Measure the distance between the two marks.
- S Align the marks again, swing 360 °, then test the opposite direction.
- ⑥ Repeat steps ④ and ⑤ three times each and calculate the average values.



145ZF7MS07



(4) Evaluation

The measured drift angle should be within the following specifications.

Unit: Degree

Model	Power mode switch	Standard	Maximum allowable	Remarks
HX130A LCR	P mode	90 below	157.5	

8) SWING BEARING PLAY

(1) Measure the swing bearing play using a dial gauge to check the wear of bearing races and balls.


(2) Preparation

- ① Check swing bearing mounting cap screws for loosening.
- ② Check the lubrication of the swing bearing. Confirm that bearing rotation is smooth and without noise.
- ③ Install a dial gauge on the track frame as shown, using a magnetic base.
- ④ Position the upperstructure so that the boom aligns with the tracks facing towards the front idlers.
- ⑤ Position the dial gauge so that its needle point comes into contact with the bottom face of the bearing outer race.
- 6 Bucket should be empty.

(3) Measurement


- ① With the arm rolled out and bucket rolled in, hold the bottom face of the bucket to the same height of the boom foot pin.

 Record the dial gauge reading (h1).
- ② Lower the bucket to the ground and use it to raise the front idler 50cm. Record the dial gauge reading (h2).
- ③ Calculate bearing play (H) from this data (h1 and h2) as follows.
 H=h2-h1




(210-7) 7-10(1)





Measurement: (h2)



(4) Evaluation

The measured drift should be within the following specifications.

Unit: mm

Model	Standard	Maximum allowable	Remarks
HX130A LCR	0.5 ~ 1.5	3.0	

9) HYDRAULIC CYLINDER CYCLE TIME

(1) Measure the cycle time of the boom, standard arm, and standard bucket cylinders.

(2) Preparation


- ① To measure the cycle time of the boom cylinders:
 - With the arm rolled out and the empty bucket rolled out, lower the bucket to the ground, as shown.
- ② To measure the cycle time of the arm cylinder.
 - With the empty bucket rolled in, position the arm so that it is vertical to the ground. Lower the boom until the bucket is 0.5 m above the ground.
- To measure the cycle time of the bucket cylinder.
 - The empty bucket should be positioned at midstroke between roll-in and roll-out, so that the sideplate edges are vertical to the ground.
- 4 Keep the hydraulic oil temperature at $50\pm5^{\circ}\text{C}$.

(3) Measurement


- ① Select the following switch positions.
- · Power mode switch : P mode
- ② To measure cylinder cycle times.
- Boom cylinders.
 - Measure the time it takes to raise the boom, and the time it takes to lower the boom. To do so, position the boom at one stroke end then move the control lever to the other stroke end as quickly as possible.
- Arm cylinder.

Measure the time it takes to roll in the arm, and the time it takes to roll out the arm. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.


Boom cylinder



Arm cylinder



Bucket cylinder



- Bucket cylinders

Measure the time it takes to roll in the bucket, and the time it takes to roll out the bucket. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.

- Repeat each measurement 3 times and calculate the average values.

(4) Evaluation

The average measured time should meet the following specifications.

Unit: Seconds

Model	Function		Standard	Maximum allowable	Remarks
	Boom raise		3.9±0.4	5.2	
	Boom lower		2.2±0.4	3.2	
		Regen ON	2.6±0.4	4.1	
HX130A LCR	Arm in	Regen OFF	3.0±0.4	4.0	
	Arm out		3.1±0.4	5.8	
	Bucket in		3.7±0.4	4.7	
	Bucket out		2.6±0.4	3.1	

10) DIG FUNCTION DRIFT CHECK

(1) Measure dig function drift, which can be caused by oil leakage in the control valve and boom, standard arm, and standard bucket cylinders, with the loaded bucket. When testing the dig function drift just after cylinder replacement, slowly operate each cylinder to its stroke end to purge air.

(2) Preparation

- Load bucket fully. Instead of loading the bucket, weight(W) of the following specification can be used.
 - · W=M3×1.5

Where:

M³ = Bucket heaped capacity (m³)

1.5 = Soil specific gravity

- ② Position the arm cylinder with the rod 20 to 30 mm extended from the fully retracted position.
- ③ Position the bucket cylinder with the rod 20 to 30 mm retracted from the fully extended position.
- With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin.

(3) Measurement

- ① Stop the engine.
- ② Five minutes after the engine has been stopped, measure the changes in the positions of the boom, arm and bucket cylinders.
- ③ Repeat step ② three times and calculate the average values.
- (4) The measured drift should be within the following specifications.

145ZF7MS11

Unit: mm / 5min

Model	Drift to be measured	Standard	Maximum allowable	Remarks
	Boom cylinder	10 below	20	
HX130A LCR	Arm cylinder	10 below	20	
	Bucket cylinder	40 below	50	

11) CONTROL LEVER OPERATING FORCE

 Use a spring scale to measure the maximum resistance of each control lever at the middle of the grip.

(2) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- ① Start the engine.
- ② Select the following switch positions.
 - · Power mode switch: P mode
- ③ Operate each boom, arm, bucket and swing lever at full stroke and measure the maximum operating force for each.
- ① Lower the bucket to the ground to raise one track off the ground. Operate the travel lever at full stroke and measure the maximum operating force required. When finished, lower the track and then jack-up the other track.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.

(4) Evaluation

The measured operating force should be within the following specifications.

Unit: kgf

Model	Kind of lever	Standard	Maximum allowable	Remarks
	Boom lever	1.5 or below	1.7	
	Arm lever	1.5 or below	1.7	
HX130A LCR	Bucket lever	1.5 or below	1.7	
	Swing lever	1.5 or below	1.7	
	Travel lever	2.1 or below	3.15	

12) CONTROL LEVER STROKE

- (1) Measure each lever stroke at the lever top using a ruler.
- When the lever has play, take a half of this value and add it to the measured stroke.

(2) Preparation

Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- ① Stop the engine.
- ② Measure each lever stroke at the lever top from neutral to the stroke end using a ruler.
- ③ Repeat step ② three times and calculate the average values.

(4) Evaluation

The measured drift should be within the following specifications.

Unit: mm

Model	Kind of lever	Standard	Maximum allowable	Remarks
	Boom lever	85±10	115	
	Arm lever	85±10	115	
HX130A LCR	Bucket lever	85±10	115	
	Swing lever	85±10	115	
	Travel lever	139±10	178	


13) PILOT PRIMARY PRESSURE

(1) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- ① Select the following switch positions.
 - · Power mode switch : P mode
 - · Auto decel switch : OFF
- ② Measure the primary pilot pressure by the monitoring menu of the cluster.



(3) Evaluation

The average measured pressure should meet the following specifications:

Unit: kgf/cm2

Model	Engine speed	Standard	Allowable limits	Remarks
HX130A LCR	P mode	40 +2	-	

14) FOR TRAVEL SPEED SELECTING PRESSURE:

(1) Preparation

- ① Stop the engine.
- ② Loosen the cap and relieve the pressure in the tank by pushing the top of the air breather.
- ③ To measure the speed selecting pressure: Install a connector and pressure gauge assembly to turning joint P port as shown.
- ④ Start the engine and check for on leakage from the adapter.
- \bigcirc Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement


① Select the following switch positions.

Travel mode switch: 1 speed

2 speed

· Mode selector : P mode

- ② Measure the travel speed selecting pressure in the Hi or Lo mode.
- ③ Repeat step ② three times and calculate the average values.



(3) Evaluation

The average measured pressure should be within the following specifications.

Unit: kgf/cm²

Model	Travel speed mode	Standard	Maximum allowable	Remarks
LD/400A LOD	1 Speed	0	-	
HX130A LCR	2 Speed	40±5	-	


15) SWING PARKING BRAKE RELEASING PILOT PRESSURE

(1) Preparation

- ① Stop the engine.
- ② Loosen the cap and relieve the pressure in the tank by pushing the top of the air breather.
- 3 The pressure release L wrench to bleed air.
- ④ Install a connector and pressure gauge assembly to swing motor PG port, as shown.
- ⑤ Start the engine and check for oil leakage from the adapter.
- 6 Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- ① Select the following switch positions.
 - · Power mode switch : P mode
- ② Operate any one of the swing, arm in, boom up or travel function and measure the swing brake control pressure with the brake disengaged. Release the control lever to return to neutral and measure the control pressure when the brake is applied.
- ③ Repeat step ② three times and calculate the average values.



(3) Evaluation

The average measured pressure should be within the following specifications.

Unit: kgf/cm2

Model	Description	Standard	Allowable limits	Remarks
LD/400A LOD	Brake disengaged	40	-	
HX130A LCR	Brake applied	0	-	


16) MAIN PUMP DELIVERY PRESSURE

(1) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- ① Select the following switch positions.
 - · Power mode switch : P mode
- ② Measure the main pump delivery pressure in the P mode (high idle).
- Do not operate any of the RCV lever and pedal.



(3) Evaluation

The average measured pressure should meet the following specifications.

Unit: kgf/cm²

Model	Engine speed	Standard	Allowable limits	Remarks
HX130A LCR	High idle	30±3	-	


17) SYSTEM PRESSURE REGULATOR RELIEF SETTING

(1) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- ① Select the following switch positions.
 - · Power mode switch : P mode
- ② Slowly operate each control lever of boom, arm and bucket functions at full stroke over relief and measure the pressure.
- ③ In the swing function, place bucket against an immovable object and measure the relief pressure.
- ④ In the travel function, lock undercarriage with an immovable object and measure the relief pressure.



130ZF7MS15

(3) Evaluation

The average measured pressure should be within the following specifications.


Unit: kgf/cm2

Model	Function to be tested	Standard	Port relief setting at 20 lpm
	Boom, Arm, Bucket	330 (360)±10	380±10
HX130A LCR	Travel	330±10	-
	Swing	280±10	-

): Power boost

GROUP 2 MAJOR COMPONENT

1. MAIN PUMP



Part name & i	nspection item	Standard dimension	Recommended replacement value	Counter measures
Clearance between piston (1) & cylinder bore (2) (D-d)	d D	0.032	0.056	Replace piston or cylinder.
Play between piston (1) & shoe caulking section (3)	•	0-0.1	0.3	Replace
Thickness of shoe (t)	8	3.9	3.7	assembly of piston & shoe.
Free height of cylinder spring (4) (L)		41.1	40.3	Replace cylinder spring.
Combined height of set plate (5) (H) & spherical bushing (6) (h) (H-h)	h H	17.0	15.8	Replace set plate or spherical bushing.
Surface roughness for valve plate (Sliding face) (7,8), swash plate (shoe plate	Surface roughness necessary to be corrected	3	Z	Lapping
area) (9), & cylinder (2) (Sliding face) Standard surface roughn (Corrected value)		0.4z oi	rlower	Lapping

2. MAIN CONTROL VALVE

Part name	Inspection item	Criteria & measure
Casing	· Existence of scratch, rusting or corrosion.	· In case of damage in following section, replace part.
		 Sliding sections of casing fore and spool, especially land sections applied with holded pressure. Seal pocket section where spool is inserted. Seal section of port where O-ring contacts. Seal section of each relief valve for main, travel, and port. Other damages that may damage normal functions.
Spool	· Existence of scratch, gnawing, rusting or corrosion.	Replacement when its outside sliding section has scratch (especially on seals-contacting section).
	· O-ring seal sections at both ends.	· Replacement when its sliding section has scratch.
	· Insert spool in casing hole, rotate and reciprocate it.	 Correction or replacement when O-ring is damaged or when spool does not move smoothly.
Poppet	· Damage of poppet or spring	· Correction or replacement when sealing is incomplete.
	· Insert poppet into casing and function it.	Normal when it can function lightly without being caught.
Around spring	Rusting, corrosion, deformation or breaking of spring, spring seat, plug or cover.	· Replacement for significant damage.
Around seal	· External oil leakage.	· Correction or replacement.
for spool	Rusting, corrosion or deformation of seal plate.	· Correction or replacement.
Main relief valve,	· External rusting or damage.	· Replacement.
port relief valve & negative control	· Contacting face of valve seat.	· Replacement when damaged.
relief valve	· Contacting face of poppet.	· Replacement when damaged.
	· Abnormal spring.	· Replacement.
	· O-rings, back up rings and seals.	· 100% replacement in general.

3. SWING DEVICE

1) WEARING PARTS

Inspection item	Standard dimension	Recommended replacement value	Counter measures
Clearance between piston and cylinder block bore	0.041	0.060	Replace piston or cylinder block
Thickness of valve plate	6	5.88	Replace
Play between piston and shoe caulking section (δ)	0.025	0.1	Replace assembly of piston and shoe
Thickness of shoe (t)	6.6	6.5	Replace assembly of piston and shoe
Combined height of retainer plate and spherical bushing (H-h)	17.6	17.3	Replace set of retainer plate and sperical bushing
Thickness of friction plate	2.94	2.7	Replace
t	5555	Tuna.	↓h H ↑ ↑
T 140W77MS12			2609A7MS01

2) SLIDING PARTS

Part name	Standard roughness	Allowable roughness	Remark
Shoe	Rmax=1S (Ra=0.2a) (LAPPING)	4S (Ra=0.1a)	
Shoe plate	Rmax=0.4S (Ra=0.1a) (LAPPING)	3S (Ra=0.8a)	
Cylinder	Rmax=0.4S (Ra=0.1a) (LAPPING)	3S (Ra=0.8a)	
Valve plate	Rmax=0.4S (Ra=0.1a) (LAPPING)	2S (Ra=0.5a)	

4. TRAVEL MOTOR

Pro	oblem	Cause	Remedy
Does not start	Pressure is not developed	Pump failure Control valve malfunction	 Check if action other than traveling is available. If faulty, repair. Check if spool moves correctly. Repair if necessary.
	Pressure is developed	 Brake valve failure -Sleeve stick -Check valve stick Motor failure -Valve seat seizure Gear broken and fragment locked Overloaded 	 Replace brake valve Replace Check hydraulic oil for contamination Replace reduction gear Reduce load
Oil leakage	Leakage from engaging surfaces	Scratch on engaging surfacesLoosening by poor bolt tightening	Correct surfaces by oilstone or sandpa- per or replace Check after retightening
	Leakage from casing	· Plug loosened · Crack formed by stone	Retighten Replace reduction gear
	Leakage from floating seal	· Sliding surfaces worn · Creep on O-ring	Replace reduction gear Replace floating seal
	Leakage from hydraulic motor	Bolt loosenedO-ring damagedSealing surface scratched	Tighten properly Replace O-ring Correct by oilstone or sandpaper
Coasts on si	ope excessively	 Poor volumetric efficiency of hydraulic motor Increase of internal leakage of brake valve Parking brake not actuated Spring breakage Wear of friction plate 	Replace hydraulic motorReplace brake valveReplace springReplace parking brake
Excessive to reduction ge	emperature on ar case	Pitting on bearingLack of gear oilHydraulic oil introduced to gear case	Replace reduction gearSupply gear oil properlyCheck motor and replace oil seal
Meanders	Meanders at low pressure	 Delivery rate is different between right and left Motor drain rate is different between right and left 	· Repair pump · Replace motor
	Meanders at high pressure	Delivery rate is different between right and leftMotor drain rate is different between right and left	Repair regulator or pump Replace motor
	Meanders at high pressure	 Relief pressure dropped at right and left brake valve Main relief pressure dropped at right or left of control valve 	Replace brake valve Replace main relief valve
Pump delive	ry is poor	Regulator operation poorExternal leakage of pump is excessive	· Repair regulator · Repair pump
External leal excessive	kage of motor is	-	· Replace motor

5. RCV LEVER

Maintenance check item	Criteria	Remark
Leakage	The valve is to be replaced when the leakage becomes more than 1000 cc/m at neutral handle position, or more than 2000 cc/m during operation.	
Spool	This is to be replaced when the sliding surface has worn more than 10 μ m, compared with the non-sliding surface.	
Push rod	This is to be replaced when the top end has worn more than 1 mm.	
Play at operating section	The pin, shaft, and joint of the operating section are to be replaced when their plays become more than 2 mm due to wears or so on.	' '
Operation stability	When abnormal noises, hunting, primary pressure drop, etc. are generated during operation, and these cannot be remedied, referring to section 6 troubleshooting, replace the related parts.	

Notes 1. It is desirable to replace seal materials, such as O-rings, every disassembling. However, they may be reused, after being confirmed to be free of damage.

6. RCV PEDAL

Maintenance check item	Criteria	Remark
Leakage	The valve is to be replaced when the leakage effect to the system. For example, the primary pressure drop.	Conditions: Primary pressure: 40 kgf/cm² Oil viscosity: 23 cSt
Spool	This is to be replaced when the sliding surface has worn more than 10 μ m, compared with the non-sliding surface.	The leakage at the left condition is estimated to be nearly equal to the above leakage.
Push rod	This is to be replaced when the top end has worn more than 1 mm.	
Play at operating section	The pin, shaft, and joint of the operating section are to be replaced when their plays become more than 2 mm due to wears or so on.	When a play is due to looseness of a tightened section, adjust it.
Operation stability	When abnormal noises, hunting, primary pressure drop, etc. are generated during operation, and these cannot be remedied, referring to section 6. Troubleshooting, replace the related parts.	

Notes 1. It is desirable to replace seal materials, such as O-rings, every disassembling. However, they may be reused, after being confirmed to be free of damage.

7. TURNING JOINT

F	Part name	Maintenance standards	Remedy	
	Sliding surface with sealing sections.	Plating worn or peeled due to seizure or contamination.	Replace	
	Sliding surface between body and	Worn abnormality or damaged more than 0.1 mm (0.0039 in) in depth due to seizure contamination.	Replace	
Body, Stem	stem other than sealing section.	· Damaged more than 0.1 mm (0.0039 in) in depth.	Smooth with oilstone.	
	Sliding surface	· Worn more than 0.5 mm (0.02 in) or abnormality.	Replace	
	with thrust plate.	· Worn less than 0.5 mm (0.02 in).	Smooth	
		Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).	Smooth	
	Sliding surface	· Worn more than 0.5 mm (0.02 in) or abnormality.	Replace	
with thrust plate.		· Worn less than 0.5 mm (0.02 in).	Smooth	
		Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).	Replace	
		· Extruded excessively from seal groove square ring.	Replace	
	-	Square ring Extrusion		
		· Slipper ring 1.5 mm (0.059 in) narrower than seal groove, or narrower than back ring.	Replace	
Seal set	-	1.5mm (max.) (0.059 in)		
		· Worn more than 0.5 mm (0.02 in) ~ 1.5 mm (MAX.) (0.059 in)	Replace	
	-			


8. CYLINDER

Part name	Inspecting section	Inspection item	Remedy	
Piston rod	· Neck of rod pin	· Presence of crack	· Replace	
	· Weld on rod hub	· Presence of crack	· Replace	
· Stepped part to which piston is attached.		· Presence of crack	· Replace	
	· Threads · Presence of crack		· Recondition or replace	
m		· Plating is not worn off to base metal.	· Replace or replate	
		· Rust is not present on plating.	· Replace or replate	
		· Scratches are not present.	· Recondition, replate or replace	
	· Rod	· Wear of O.D.	· Recondition, replate or replace	
	· Bushing at mounting part	· Wear of I.D.	· Replace	
Cylinder tube	· Weld on bottom	· Presence of crack	· Replace	
	· Weld on head	· Presence of crack	· Replace	
	· Weld on hub	· Presence of crack	· Replace	
	· Tube interior	· Presence of faults	· Replace if oil leak is seen	
	· Bushing at mounting part	· Wear on inner surface	· Replace	
Gland	· Bushing	· Flaw on inner surface	· Replace if flaw is deeper than coating	

GROUP 3 TRACK AND WORK EQUIPMENT

1. TRACK

1) TRACK ROLLER




21037MS01

Unit:mm

No.	Check item		Criteria				
4	Outside disposes of flores	Standard size		Repair limit			
'	Outside diameter of flange	Ø 190		_		Rebuild or replace	
2	Outside diameter of tread	Ø150			Ø138		
3	Width of tread	36.5		42.5			
4	Width of flange	26.5		-			
		Standard toler		ance	Standard	Clearance	
5	Clearance between shaft and bushing	size	Shaft	Hole	clearance	limit	Replace bushing
	and bushing	Ø 6 5	-0.25 -0.35	+0.12 +0.075	0.325 to 0.47	2.0	bushing
6	Side clearance of roller	Standard clearance		се	Clearance limit		Danlasa
0	(both side)	0.1 t	o 1.3		2	.0	Replace

2) CARRIER ROLLER




21037MS02

Unit: mm

No.	Check item		Criteria				
4	Outside disperser of flores	Standard size		Repair limit			
'	Outside diameter of flange	Ø175		_		Rebuild or replace	
2	Outside diameter of tread	Ø151		Ø141			
3	Width of tread	37.25		42.25			
4	Width of flange	18	18.25		-		
		Standard size	Standard size & Tolerance		Clearance		
5	Clearance between shaft and bushing	Shaft	Hole	clearance	limit	Replace bushing	
		Ø41.27 ⁰ _{+0.05}	Ø41.5 +0.2 - 0.1	0.13 to 0.48	1.2	busiling	

3) IDLER




21037MS03

Unit: mm

No.	Check item		Criteria				
4	Outside dispretay of flores	Standard size		Repair limit			
1	Outside diameter of flange	Ø	552	-			
2	Outside diameter of tread	Ø	507	Ø 49 7		Rebuild or	
3	Width of protrusion		67		-		
4	Total width	135		-			
5	Width of tread	34		39			
		Standard siz	e & Tolerance	Standard	Standard Clearance		
6	Clearance between shaft	Shaft	Hole	clearance	limit	Replace	
	and bushing	Ø70 _{-0.03}	Ø70.3 ^{+0.05} ₀	0.3 to 0.38	2.0	bushing	
7	Clearance between shaft and support	Ø70 0 0 0 +0.07 +0.03		0.03 to 0.1	1.2	Replace	
8	Side clearance of idler	Standard clearance		Clearance limit		Replace	
	(both side)	0.25	0.25 to 1.15		.0	bushing	

4) TRACK





21037MS04

Unit:mm

No.	Check item	Crit	Remedy	
4	Linkaitah	Standard size	Repair limit	Turn or
'	Link pitch	171.45	175.65	replace
2	Outside diameter of bushing	Ø 53.75 Ø 43.95		
3	Height of grouser	25	16	Rebuild or replace
4	Height of link	94.5	86.5	
5	Tightening torque (Tightening angle method)	Initial tightening torque: 42± Additional tightening angle:	Retighten	

5) TRACK FRAME AND RECOIL SPRING






21037MS05

Unit:mm

No.	Check item		Criteria					
			Standar	d size	Tolerance	Repair limit		
1	Vertical width of idler guide	Track frame	103	3	+2 0	107		
		Idler suppor	rt 100)	0 - 0.5	98	Rebuild or replace	
2	Havizantal width of idlay guida	Track frame	192	2	+2 0	196	Теріасе	
2	Horizontal width of idler guide	Idler suppo	rt 190)	-	188		
		Standard siz		ndard size Repair limit		epair limit		
3	Recoil spring	Free length	Installation length	Installati load		Installation load	Replace	
		Ø192×470	405	8,497k	kg –	6,978kg		

2. WORK EQUIPMENT



Unit:mm

			Р	Pin		Bushing	
Mark	Measuring point (Pin and Bushing)	Normal value	Recomm. service limit	Limit of use	Recomm. service limit	Limit of use	Remedy & Remark
Α	Boom Rear	70	69	68.5	70.5	71	Replace
В	Boom Cylinder Head	70	69	68.5	70.5	71	"
С	Boom Cylinder Rod	70	69	68.5	70.5	71	"
D	Arm Cylinder Head	65	64	63.5	65.5	66	"
Е	Boom Front	70	69	68.5	70.5	71	"
F	Arm Cylinder Rod	65	64	63.5	65.5	66	"
G	Bucket Cylinder Head	65	64	63.5	65.5	66	"
Н	Arm Link	65	64	63.5	65.5	66	"
I	Bucket and Arm Link	65	64	63.5	65.5	66	"
J	Bucket Cylinder Rod	65	64	63.5	65.5	66	"
K	Bucket Link	65	64	63.5	65.5	66	"

SECTION 8 DISASSEMBLY AND ASSEMBLY

Group	1	Precaution	8-1
Group	2	Tightening Torque ····	8-4
Group	3	Pump Device ····	8-7
Group	4	Main Control Valve	8-32
Group	5	Swing Device ·····	8-46
Group	6	Travel Device	8-78
Group	7	RCV Lever	8-110
Group	8	Turning Joint	8-124
Group	9	Boom, Arm and Bucket Cylinder	8-129
Group	10	Undercarriage	8-148
Group	11	Work Equipment ·····	8-160


SECTION 8 DISASSEMBLY AND ASSEMBLY

GROUP 1 PRECAUTIONS

1. REMOVAL WORK

- Lower the work equipment completely to the ground.
 If the coolant contains antifreeze, dispose of it correctly.
- 2) After disconnecting hoses or tubes, cover them or fit blind plugs to prevent dirt or dust from entering.
- 3) When draining oil, prepare a container of adequate size to catch the oil.
- 4) Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake when assembling.
- 5) To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors.
- 6) Fit wires and hoses with tags to show their installation position to prevent any mistake when installing.
- 7) Check the number and thickness of the shims, and keep in a safe place.
- 8) When raising components, be sure to use lifting equipment of ample strength.
- 9) When using forcing screws to remove any components, tighten the forcing screws alternately.
- 10) Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.
- 11) When removing hydraulic equipment, first release the remaining pressure inside the hydraulic tank and the hydraulic piping.
- 12) If the part is not under hydraulic pressure, the following corks can be used.

Nominal	Dimensions					
number	D	d	L			
06	6	5	8			
08	8	6.5	11			
10	10	8.5	12			
12	12	10	15			
14	14	11.5	18			
16	16	13.5	20			
18	18	15	22			
20	20	17	25			
22	22	18.5	28			
24	24	20	30			
27	27	22.5	34			



2. INSTALL WORK

- 1) Tighten all bolts and nuts (sleeve nuts) to the specified torque.
- 2) Install the hoses without twisting or interference.
- 3) Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
- 4) Bend the cotter pin or lock plate securely.
- 5) When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2-3 drops of adhesive.
- 6) When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
- 7) Clean all parts, and correct any damage, dents, burrs, or rust.
- 8) Coat rotating parts and sliding parts with engine oil.
- 9) When press fitting parts, coat the surface with antifriction compound (LM-P).
- 10) After installing snap rings, check that the snap ring is fitted securely in the ring groove (Check that the snap ring moves in the direction of rotation).
- 11) When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
- 12) When using eyebolts, check that there is no deformation or deterioration, and screw them in fully.
- 13) When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- 14) When operating the hydraulic cylinders for the first time after repairing and reassembling the hydraulic cylinders, pumps, or other hydraulic equipment or piping, always bleed the air from the hydraulic cylinders as follows:
- (1) Start the engine and run at low idling.
- (2) Operate the control lever and actuate the hydraulic cylinder 4-5 times, stopping 100mm before the end of the stroke.
- (3) Next, operate the piston rod to the end of its stroke to relieve the circuit. (The air bleed valve is actuated to bleed the air.)
- (4) After completing this operation, raise the engine speed to the normal operating condition.
- If the hydraulic cylinder has been replaced, carry out this procedure before assembling the rod to the work equipment.
- « Carry out the same operation on machines that have been in storage for a long time after completion of repairs.

3. COMPLETING WORK

- 1) If the coolant has been drained, tighten the drain valve, and add water to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
- 2) If the hydraulic equipment has been removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- 3) If the piping or hydraulic equipment, such as hydraulic cylinders, pumps, or motors, have been removed for repair, always bleed the air from the system after reassembling the parts.
- 4) Add the specified amount of grease (molybdenum disulphied grease) to the work equipment related parts.

GROUP 2 TIGHTENING TORQUE

1. MAJOR COMPONENTS

NI.	No. Descriptions		Dallari a	Torque		
No.			Bolt size	kgf · m	lbf ⋅ ft	
1		Engine mounting bolt (engine-bracket, FR)	M12 × 1.75	11.5 ± 1.0	83.2 ± 7.2	
2		Engine mounting bolt (engine-bracket, RR)	M12 × 1.75	11.5 ± 1.0	83.2 ± 7.2	
3		Engine mounting bolt (bracket-frame, FR)	M16 × 2.0	29.7 ± 3.0	215 ± 21.7	
4	Engine	Engine mounting bolt (bracket-frame, RR)	M16 × 2.0	29.7 ± 3.0	215 ± 21.7	
5		Radiator mounting bolt	M16 × 2.0	29.7 ± 4.5	215 ± 32.5	
6		Coupling mounting socket bolt	M16 × 2.0	22.0 ± 1.0	159 ± 7.2	
7		Fuel tank mounting bolt	M20 × 2.5	57.8 ± 5.8	418 ± 42.0	
8		Main pump housing mounting bolt	M10 × 1.5	6.5 ± 0.7	47.0 ± 5.1	
9		Main pump mounting socket bolt	M16 × 2.0	29.7 ± 4.5	215 ± 32.5	
10	Hydraulic system	Main control valve mounting bolt	M12 × 1.75	12.2 ± 1.3	88.2 ± 9.4	
11	9,010	Hydraulic oil tank mounting bolt	M20 × 2.5	57.8 ± 5.8	418 ± 42.0	
12		Turning joint mounting bolt, nut	M12 × 1.75	12.3 \pm 1.3	89.0 ± 9.4	
13		Swing motor mounting bolt	M16 × 2.0	$\textbf{29.6} \pm \textbf{3.2}$	214 ± 23.1	
14	Power	Swing bearing upper part mounting bolt	M18 × 2.5	$\textbf{41.3} \pm \textbf{4.0}$	299 ± 28.9	
15	train	Swing bearing lower part mounting bolt	M16 × 2.0	29.7 ± 3.0	215 ± 21.7	
16	system	Travel motor mounting bolt	M16 × 2.0	$\textbf{23.0} \pm \textbf{2.5}$	166 ± 18.1	
17		Sprocket mounting bolt	M16 × 2.0	29.7 ± 3.0	215 ± 21.7	
18		Upper roller mounting bolt, nut	M16 × 2.0	29.7 ± 3.0	215 ± 21.7	
19		Lower roller mounting bolt	M16 × 2.0	29.7 ± 3.0	215 ± 21.7	
20	Under carriage	Track tension cylinder mounting bolt	M16 × 2.0	29.7 ± 3.0	215 ± 21.7	
21		Track shoe mounting bolt, nut	M16 × 1.5	25.5 ± 2.5	184 ± 18.1	
22		Track guard mounting bolt	M16 × 2.0	29.6 ± 3.2	214 ± 23.1	
23		Counterweight mounting bolt	M36 × 3.0	308 \pm 46	1228 ± 333	
24	Others	Cab mounting bolt	M12 × 1.75	12.8 \pm 3.0	92.6 ± 21.7	
25	Outers	Operator's seat mounting bolt	M 8 × 1.25	4.05 ± 0.8	29.3 ± 5.8	
26		Under cover mounting bolt	M12 × 1.75	12.8 ± 3.0	92.6 ± 21	

^{*} For tightening torque of engine and hydraulic components, see engine maintenance guide and service manual.

2. TORQUE CHART

Use following table for unspecified torque.

1) BOLT AND NUT

(1) Coarse thread

Dolt size	8.8	8Т	10	.9T	12.9T	
Bolt size	kgf⋅m	lbf∙ft	kgf⋅m	lbf⋅ft	kgf⋅m	lbf∙ft
M 6×1.0	0.8 ~ 1.2	5.8 ~ 8.6	1.2 ~ 1.8	8.7 ~ 13.0	1.5 ~ 2.1	10.9 ~ 15.1
M 8 × 1.25	2.0 ~ 3.0	14.5 ~ 21.6	2.8 ~ 4.2	20.3 ~ 30.4	3.4 ~ 5.0	24.6 ~ 36.1
M10 × 1.5	4.0 ~ 6.0	29.0 ~ 43.3	5.6 ~ 8.4	40.5 ~ 60.8	6.8 ~ 10.0	49.2 ~ 72.3
M12 × 1.75	6.8 ~ 10.2	50.0 ~ 73.7	9.6 ~ 14.4	69.5 ~ 104	12.3 ~ 16.5	89.0 ~ 119
M14 × 2.0	10.9 ~ 16.3	78.9 ~ 117	16.3 ~ 21.9	118 ~ 158	19.5 ~ 26.3	141 ~ 190
M16 × 2.0	17.9 ~ 24.1	130 ~ 174	25.1 ~ 33.9	182 ~ 245	30.2 ~ 40.8	141 ~ 295
M18 × 2.5	24.8 ~ 33.4	180 ~ 241	34.8 ~ 47.0	252 ~ 340	41.8 ~ 56.4	302 ~ 407
M20 × 2.5	34.9 ~ 47.1	253 ~ 340	49.1 ~ 66.3	355 ~ 479	58.9 ~ 79.5	426 ~ 575
M22 × 2.5	46.8 ~ 63.2	339 ~ 457	65.8 ~ 88.8	476 ~ 642	78.9 ~ 106	570 ~ 766
M24 × 3.0	60.2 ~ 81.4	436 ~ 588	84.6 ~ 114	612 ~ 824	102 ~ 137	738 ~ 991
M30 × 3.5	120 ~ 161	868 ~ 1164	168 ~ 227	1216 ~ 1641	202 ~ 272	1461 ~ 1967

(2) Fine thread

Bolt size	8.8	ВТ	10	.9T	12.9T	
DOIL SIZE	kgf · m	lbf ⋅ ft	kgf · m	lbf ⋅ ft	kgf · m	lbf ⋅ ft
M 8 × 1.0	2.1 ~ 3.1	15.2 ~ 22.4	3.0 ~ 4.4	21.7 ~ 31.8	3.6 ~ 5.4	26.1 ~ 39.0
M10 × 1.25	4.2 ~ 6.2	30.4 ~ 44.9	5.9 ~ 8.7	42.7 ~ 62.9	7.0 ~ 10.4	50.1 ~ 75.2
M12 × 1.25	7.3 ~ 10.9	52.8 ~ 78.8	10.3 ~ 15.3	74.5 ~ 110	13.1 ~ 17.7	94.8 ~ 128
M14 × 1.5	12.4 ~ 16.6	89.7 ~ 120	17.4 ~ 23.4	126 ~ 169	20.8 ~ 28.0	151 ~ 202
M16 × 1.5	18.7 ~ 25.3	136 ~ 182	26.3 ~ 35.5	191 ~ 256	31.6 ~ 42.6	229 ~ 308
M18 × 1.5	27.1 ~ 36.5	196 ~ 264	38.0 ~ 51.4	275 ~ 371	45.7 ~ 61.7	331 ~ 446
M20 × 1.5	37.7 ~ 50.9	273 ~ 368	53.1 ~ 71.7	384 ~ 518	63.6 ~ 86.0	460 ~ 622
M22 × 1.5	51.2 ~ 69.2	370 ~ 500	72.0 ~ 97.2	521 ~ 703	86.4 ~ 116	625 ~ 839
M24 × 2.0	64.1 ~ 86.5	464 ~ 625	90.1 ~ 121	652 ~ 875	108 ~ 146	782 ~ 1056
M30 × 2.0	129 ~ 174	933 ~ 1258	181 ~ 245	1310 ~ 1772	217 ~ 294	1570 ~ 2126

2) PIPE AND HOSE (FLARE TYPE)

Thread size (PF)	Width across flat (mm)	kgf · m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130.2
1"	41	21	151.9
1-1/4"	50	35	253.2

3) PIPE AND HOSE (ORFS TYPE)

Thread size (UNF)	Width across flat (mm)	kgf · m	lbf · ft
9/16-18	19	4	28.9
11/16-16	22	5	36.2
13/16-16	27	9.5	68.7
1-3/16-12	36	18	130.2
1-7/16-12	41	21	151.9
1-11/16-12	50	35	253.2

4) FITTING

Thread size	Width across flat (mm)	kgf · m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130.2
1"	41	21	151.9
1-1/4"	50	35	253.2

GROUP 3 PUMP DEVICE

1. REMOVAL AND INSTALL

1) REMOVAL

- Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- (4) Loosen the drain plug under the hydraulic tank and drain the oil from the hydraulic tank.
 - Hydraulic tank quantity: 96 ℓ (25.4 U.S. gal)
- (5) Remove socket bolts (11) and disconnect hoses (1,2).

Tightening torque : $8.27\pm1.7~\text{kgf}\cdot\text{m}$ (59.8 $\pm12.3~\text{lbf}\cdot\text{ft}$)

- (6) Disconnect pilot line hoses (5, 6, 7, 8, 9, 10). Tightening torque : 14.7 ± 2.2 kgf· m (106 ± 15.9 lbf· ft)
- (7) Remove socket bolts (12) and disconnect pump suction pipe (4).
- When pump suction tube is disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (8) Sling the pump assembly and remove the pump mounting socket bolts (13).


· Weight: 88 kg (194 lb)


· Mounting socket bolt (13)


Tightening torque : 29.7 \pm 4.5 kgf \cdot m

 $(215\pm32.5 lbf \cdot ft)$

We Pull out the pump assembly from housing. When removing the pump assembly, check that all the hoses have been disconnected.








2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Remove the suction strainer and clean it.
- (3) Replace return filter with new one.
- (4) Remove breather and clean it.
- (5) After adding oil to the hydraulic tank to the specified level.
- (6) Bleed the air from the hydraulic pump.
- ① Remove the air vent plug (2EA).
- ② Tighten plug lightly.
- ③ Start the engine, run at low idling, and check oil come out from plug.
- 4 Tighten plug.
- (7) Start the engine, run at low idling (3~5 minutes) to circulate the oil through the system.
- (8) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2. MAIN PUMP (1/2)


1) STRUCTURE



130A2MP02

111	Drive shaft (F)	272	Pump casing (R)	711	O-ring
113	Drive shaft (R)	312	Valve block	717	O-ring
116	1st Gear	313	Valve plate (R)	723	O-ring
123	Roller bearing	314	Valve plate (L)	724	Square ring
124	Needle bearing	401	Hexagon socket bolt	728	O-ring
127	Bearing spacer	402	Hexagon socket bolt	732	O-ring
141	Cylinder block	406	Hexagon socket bolt	733	O-ring
151	Piston	415	Hexagon socket bolt	734	O-ring
152	Shoe	466	Plug	774	Oil seal
153	Set plate	467	Plug	789	Back up ring
156	Spherical bushing	468	Plug	792	Back up ring
157	Cylinder spring	497	Plug	806	Hexagon head nut
211	Shoe plate	531	Tilting pin	808	Hexagon head nut
212	Swash plate	532	Servo piston	824	Snap ring
214	Tilting bushing	533	Plug (Q min)	886	Spring pin
251	Support	534	Stopper (L)	901	Eye bolt
255	Lock pin	535	Stopper (S)	953	Set screw
261	Seal cover (F)	548	Feed back pin	954	Set screw
263	Seal cover (R)	702	O-ring	981	Name plate
271	Pump casing (F)	710	O-ring	983	Pin

MAIN PUMP (2/2)



130A2MP03

04	Gear pump	128	Bearing spacer	711	O-ring
115	Idler shaft	262	Cover	728	O-ring
117	Gear No. 2	326	Gear case	825	Snap ring
118	Gear No. 3	414	Hexagon socket bolt	826	Snap ring
125	Ball bearing	435	Flange socket bolt	885	Spring pin
126	Roller bearing	468	Plug	886	Pin

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.


Tool name & size	Part name						
Name		Hexagon socket head bolt	PT plug (PT thread)		ROH/VP/UNF plug (PF screw)		Hexagon socket head setscrew
Allen wrench	4	M 5	Е	3P-1/16	-		M 8
	5	M 6	I	3P-1/8	-		M10
	6	M 8	I	3P-1/4	PF-1/4		M12, M14
- B -	8	M10	I	3P-3/8	PF-3/8	}	M16, M18
	10	M12	I	3P-1/2	PF-1/2)	M20
	14	M16, M18	ı	3P-3/4	PF-3/4		-
	17	M20, M22		BP-1	PF-1		-
Double ring spanner,	-	Hexagon bolt		Hexagon nut			VP plug (PF screw)
socket wrench, double (single) open end spanner	19	M12		M12		PF-1/4	
орен ена ѕранне	24	M16	М		116		-
В	27	M18		М	118		PF-1/2
	30	M20		М	20		-
	41	-		-			PF-1
Adjustable angle wrench		Medium size, 1 set					
Screw driver		Minus type screw driver, Medium size, 2 sets					
Hammer	Plastic hammer, 1 set						
Pliers	For snap ring, TSR-160						
Steel bar		Steel bar of key material approx. 10 × 8 × 200					
Torque wrench		Capable of tightening with the specified torques					

(2) Tightening torque

Dort name	Dolt size	Tore	que	Wrench size		
Part name	Bolt size	kgf · m	lbf ⋅ ft	in	mm	
Hexagon socket head bolt	M 5	0.7	5.1	0.16	4	
(material : SCM435)	M 6	1.2	8.7	0.20	5	
	M 8	3.0	21.7	0.24	6	
	M10	5.8	42.0	0.31	8	
	M12	10.0	72.3	0.39	10	
	M14	16.0	116	0.47	12	
	M16	24.0	174	0.55	14	
	M18	34.0	246	0.55	14	
	M20	44.0	318	0.67	17	
PT Plug (material : S45C)	PT1/16	0.7	5.1	0.16	4	
	PT 1/8	1.05	7.59	0.20	5	
turns round the plug	PT 1/4	1.75	12.7	0.24	6	
	PT 3/8	3.5	25.3	0.31	8	
	PT 1/2	5.0	36.2	0.39	10	
PF Plug (material : S45C)	PF 1/4	3.0	21.7	0.24	6	
	PF 3/8	7.55	54.6	0.31	8	
	PF 1/2	10.0	72.3	0.39	10	
	PF 3/4	15.0	109	0.55	14	
	PF 1	19.0	137	0.67	17	
	PF 1 1/4	27.0	195	0.67	17	
	PF 1 1/2	28.0	203	0.67	17	

3) DISASSEMBLY

- (1) Select place suitable to disassembling.
- Select clean place.
- Spread rubber sheet, cloth or so on overhaul workbench top to prevent parts from being damaged.
- (2) Remove dust, rust, etc, from pump surfaces with cleaning oil or so on.
- (3) Remove drain port plug (468) and drain oil pump casing (271, 272).
- (4) Remove hexagon socket head bolts (412, 413) and remove regulator.



140Z98MP11

- (5) Place pump horizontally on workbench with its regulator fitting surface down, and remove flange socket (435) and remove PTO unit (05).
- Be careful about the attaching direction of the PTO unit (05).
- Before bringing regulator fitting surface down, spread rubber sheet on workbench without fail to prevent this surface from being damaged.
- (6) In case the pump is provided without the PTO unit (05), remove the cover (262) with the hexagon socket head cap screws (414).



140Z98MP12



140Z98MP13

(7) Remove flange socket (435) and remove gear pump (04).



(8) Loosen hexagon socket head bolt (401) which tighten pump casing (271, 272) and valve block (312).



140Z98MP15

- (9) Place pump horizontally on workbench with its regulator fitting surface down, and separate pump casing (271,272) from valve block (312).
- * Remove 1st gear (116) when separating pump casing from valve block (312) too.



- (10) Pull out cylinder (141), pistons (151), set screw (153), spherical bush (156) and cylinder springs (157) simultaneously from pump casing (271, 272) straightly over drive shaft (111, 113).
- * Take care not to damage sliding surface of cylinder (141), spherical bush (156), shoes (152), swash plate (212), etc.



140Z98MP17

- (11) Remove hexagon socket head bolts (406) and then seal cover (F, 261).
- In the case removing it is difficult, and hooking pull thin rod into notch, and the cover can be removed easily.
- Since oil seal is fitted on seal cover (F) (261), take care not to damage it at removing the cover.



140Z98MP18

(12) Tapping shaft ends of drive shaft (111, 113) lightly with plastic hammer, remove it from pump casing (271, 272).



140Z98MP19

(13) Remove shoe plate (211) and swash plate (212) from pump casing (271, 272).



140Z98MP20

- (14) Insert thin steel bar into the hole and remove the lock pin (255) from pump casing (271, 272).
- When holding with thin steel bar, do not confuse the unlocking hole with the arc shaped oil passage.



140Z98MP21

- (15) Remove valve plate (313, 314) from valve block (312).
- These may be removed in Work 8.




140Z98MP22

If necessary, remove stopper (L) (534), Qmin. plug (533), servo piston (532) and tilting pin (531) from pump casing (271, 272), and needle bearing (124) from valve block.

- When removing tilting pin, use a protector to prevent pin head from being damaged.
- Since lock tight is applied to fitting areas of tilting pin (531) and servo piston (532), take care not to damage servo piston (532).
- Do not remove needle bearing (124) as far as possible, except the case that considered to be out of its life span.
- Do not loosen hexagon nuts of valve block (312) and Qmin. plug (533).
 If loosened, flow setting will be changed.


4) ASSEMBLY

- (1) For reassembling reverse the disassembling procedures, paying attention to the following items.
- ① Do not fail to repair the parts damaged during disassembling, and repair replacement parts in advance.
- ② Clean each part fully with cleaning oil and dry it with compressed air.
- ③ Do not fail to apply clean working oil to sliding sections, bearings, etc. before assembling them.
- ④ In principle, replace seal parts, such as O-rings, oil seals, etc.
- 5 For fitting bolts, plug, etc., prepare a torque wrench or so on, and tighten them with torques shown in page 8-11, 12.
- ⑤ For the double-pump, take care not to mix up parts of the front pump with those of the rear pump.
- (2) Insert the lock pin (255) after the swash plate support (251) into the pump casing (271, 272), and fit the lock pin (255) into the hole of the swash plate support (251).
- In case the servo piston, tilting pin, stopper (L), stopper (S), and Qmin. plug have been removed, attached then to the pump casing in advance.
- In the tightening work of the servo piston and the tilting pin, use the tool not to damaged the head of the tilting pin and the feed back pin. Besides, apply loctite (of medium strength) to the thread portion.



140798MP23

- (3) Fit tilting bush (214) of swash plate (212) to tilting pin (531), and fit swash plate (212) with shoe plate (211) to swash plate support (251) correctly.
- * Confirm with fingers of both hands that swash plate can be removed smoothly.
- Apply grease to sliding sections of swash plate (212) and swash plate support (251), and drive shaft (111, 113) can be fitted easily.
- Take care not to damage shoe plate (211)





(4) To pump casing (271, 272), fit drive shaft (111, 113) set with bearing (123), bearing spacer (127) and stop ring (824).



140Z98MP25

- (5) In assemble of front pump, assemble seal cover (F) (261) to pump casing (271) and fix it with hexagon socket head bolt (406).
- * Apply grease lightly to oil seal in seal cover (F) (261).
- * For assemble oil seal (774), taking full care not to damage it.



140Z98MP26

(6) Assemble piston cylinder subassembly [cylinder (141), piston subassembly (151, 152), set plate (153), spherical bush (156) and cylinder spring (157)]. Fitting spline phases of cylinder, spherical bush (156) and drive shaft (111, 113), insert piston cylinder subassembly into pump casing (271, 272).



- (7) Fit valve plate (313, 314) to valve block (312), spring pin (886) into pin hole.
- * Take care not to mistake suction/delivery direction of valve plate (312).



140Z98MP28

- (8) Place pump horizontally on workbench with its regulator fitting surface down, and attach pump casing (271, 272) to valve block (312). Fit 1st gear (116) simultaneously.
- Before bringing regulator fitting surface down, spread rubber sheet on workbench without fail to prevent this surface from being damaged.
- ** Take care not to mistake direction of valve block (312). [Clockwise rotation (viewed from input shaft side)]. Fit the valve block (312) with suction flange left when regulator side below, viewed from front side.
- (9) Fix valve block (312) to pump casing (271, 272) with hexagon socket head bolts (401).



140Z98MP29



140Z98MP30

(10) Fit gear pump (04) to pump casing (272) with hexagon socket head bolts (435).



140Z98MP31

(11) Attach the PTO unit (05) by fastening the flange socket (435) to the valve block (312).



140Z98MP32

(12) In case the pump is not provided with the PTO unit (05), attach the cover (262) with the hexagon socket head cap screw (414).



140Z98MP33

- (13) Putting feedback lever (611) of regulator into feedback pin (548) of tilting pin (531), fit regulator with hexagon socket head bolt (415).
- * Take care not to mix up regulator of front pump and that of rear pump.




140Z98MP34


(14) Fit drain port plug (468).


This is the end of reassembling procedures.


3. REGULATOR


1) STRUCTURE (1/2)












130A2MP04

REGULATOR (3/3)



130A2MP05

079	EPPR valve assembly	624	Spring seat (C)	708	O-ring
412	Hexagon socket screw	625	Outer spring	724	Square ring
413	Hexagon socket screw	626	Inner spring	725	O-ring
418	Hexagon socket screw	627	Adjust stem (C)	728	O-ring
437	Hexagon socket screw	628	Adjust screw (C)	730	O-ring
438	Hexagon socket screw	629	Cover (C)	734	O-ring
439	Hexagon socket screw	630	Lock nut	753	O-ring
466	Plug	631	Sleeve, Pf	755	O-ring
496	Plug	641	Pilot cover (C)	757	O-ring
497	Plug	643	Pilot piston	801	Nut
601	Casing	644	Spring seat (Q)	802	Nut
611	Feed back lever	645	Adjust stem (Q)	814	Snap ring
612	Lever 1	646	Pilot spring	836	Snap ring
613	Lever 2	651	Sleeve	874	Pin
614	Center plug	652	Spool	875	Pin
615	Adjust plug	653	Spring seat	887	Pin
616	Plug	654	Return spring	897	Pin
621	Compensator piston	655	Set spring	898	Pin
622	Piston case	656	Valve casing (B)	924	Set screw
623	Compensator rod				

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.

Tool name & size	Part name							
Name B				PT plug T thread)	PO pluç (PF threa		Hexagon socket head setscrew	
Allen wrench	4	M5	BP-1/16		-		M 8	
B	5	M6	ı	BP-1/8	-		M10	
	6	M8	BP-1/4		PO-1/4		M12, M14	
Double ring spanner, socket wrench, double (single) open end spanner		Hexagon head bolt		Hexagon nut			VP plug (PF thread)	
		M 8		М	M 8		-	
Adjustable angle wrench	Small size, Max 36 mm							
Screw driver	Minus type screw driver, Medium size, 2 sets							
Hammer	Plastic hammer, 1 set							
Pliers	For snap ring, TSR-160							
Steel bar	4×100 mm							
Torque wrench	Capable of tightening with the specified torques							
Pincers	-							
Bolt	M4, Length: 50 mm							

(2) Tightening torque


Part name	Bolt size	Tor	que	Wrench size		
Part name	DOIL SIZE	kgf · m	lbf ⋅ ft	in	mm	
Hexagon socket head bolt	M 5	0.7	5.1	0.16	4	
(material : SCM435)	M 6	1.2	8.7	0.20	5	
	M 8	3.0	21.7	0.24	6	
	M10	5.8	42.0	0.31	8	
	M12	10.0	72.3	0.39	10	
	M14	16.0	116	0.47	12	
	M16	24.0	174	0.55	14	
	M18	34.0	246	0.55	14	
	M20	44.0	318	0.67	17	
PT Plug (material : S45C)	PT1/16	0.7	5.1	0.16	4	
Wind a seal tape 1 1/2 to 2 turns round the plug	PT 1/8	1.05	7.59	0.20	5	
	PT 1/4	1.75	12.7	0.24	6	
	PT 3/8	3.5	25.3	0.31	8	
	PT 1/2	5.0	36.2	0.39	10	
PF Plug (material : S35C)	PF 1/4	3.0	21.7	0.24	6	
	PF 1/2	10.0	72.3	0.39	10	
	PF 3/4	15.0	109	0.55	14	
	PF 1	19.0	137	0.67	17	
	PF 1 1/4	27.0	195	0.67	17	
	PF 1 1/2	28.0	203	0.67	17	

3) DISASSEMBLY


Since the regulator consists of small precision finished parts, disassembly and assembly are rather complicated.

For this reason, replacement of a regulator assembly is recommended, unless there is a special reason, but in case disassembly is necessary for an unavoidable reason, read through this manual to the end before starting disassembly.


- (1) Choose a place for disassembly.
- Choose a clean place.
- Spread rubber sheet, cloth, or so on on top of work-bench to prevent parts from being damaged.
- (2) Remove dust, rust, etc. from surfaces of regulator with clean oil.
- (3) Remove hexagon socket head screw (412, 413) and remove regulator main body from pump main body.
- * Take care not to lose O-ring.




- (4) Remove hexagon socket head screw (438) and remove cover (C,629)
- * Cover (C) is fitted with adjusting screw (C, 628), adjusting ring (C, 627), lock nut (630), hexagon nut (801) and adjusting screw (924).
- Do not loosen these screws and nuts. If they are loosened, adjusted pressureflow setting will vary.




- (5) After removing cover (C, 629) subassembly, take out outer spring (625), inner spring (626) and spring seat (C, 624) from compensating section.
 - Then draw out adjusting ring (Q, 645), pilot spring (646) and spring seat (644) from pilot section.
- Adjusting ring (Q,645) can easily be drawn out with M4 bolt.
- (6) Remove hexagon socket head screws (436, 438) and remove pilot cover (641). After removing pilot cover, take out set spring (655) from pilot section.







- (7) Remove snap ring (814) and take out spring seat (653), return spring (654) and sleeve (651).
- Sleeve (651) is fitted with snap ring (836).
- When removing snap ring (814), return spring (654) may pop out. Take care not to lose it.




- (8) Remove prevention plug (616) and take out center plug (614) and adjusting plug (615).
- Center plug (614) and adjusting plug (615) can easily be taken out with M6 bolt.







- (9) Remove lever 2 (613). Do not draw out pin (875).
- Work will be promoted by using pincers or so on.



(10) Draw out pin (874) and remove feedback lever (611).

Push out pin (874, 4 mm in dia.) from above with slender steel bar so that it may not interfere with lever 1 (612).






- (11) Remove lever 1 (612). Do not draw out pin (875).
- (12) Draw out pilot piston (643) and spool (652).
- (13) Draw out piston case (622), compensating piston (621) and compensating rod (623).
- Piston case (622) can be taken out by pushing compensating rod (623) at opposite side of piston case.


This completes disassembly.

4) ASSEMBLY


- For assembly, reverse disassembly procedures, but pay attention to the following items.
- ① Always repair parts that were scored at disassembly.
- ② Get replacement parts ready beforehand. Mixing of foreign matter will cause malfunction.
 - Therefore, wash parts well with cleaning oil, let them dry with jet air and handle them in clean place.
- 3 Always tighten bolts, plugs, etc. to their specified torques.
- ④ Do not fail to coat sliding surfaces with clean hydraulic oil before assembly.
- ⑤ Replace seals such as O-ring with new ones as a rule.
- (2) Put compensating rod (623) into compensating hole of casing (601).
- (3) Put pin force-fitted in lever 1 (612) into groove of compensating rod and fit lever 1 to pin force-fitted in casing.
- (4) Fit spool (652) and sleeve (651) into hole in spool of casing.
- Confirm that spool and sleeve slide smoothly in casing without binding.
- Pay attention to orientation of spool.




- (5) Fit feedback lever (611), matching its pin hole with pin hole in spool. Then insert pin (874).
- Insert pin in feedback lever a little to ease operation.
- * Take care not to mistake direction of feedback lever.




- (6) Put pilot piston (643) into pilot hole of casing.
- Confirm that pilot piston slides smoothly without binding.
- (7) Put pin force-fitted in lever 2 (613) into groove of pilot piston. Then fix lever 2.



- (8) Fit center plug (614) so that pin forcefitted in center plug (614) can be put into pin hole of lever 2.
 - Then install prevention plug (858).
- (9) Insert adjusting plug (615) and fit locking ring.
- ** Take care not to mistake inserting holes for fulcrum plug and adjusting plug. At this point in time move feedback lever to confirm that it has no large play and is free from binding.
- (10) Fit return spring (654) and spring seat (653) into spool hole and attach snap ring (814).







compensating piston (621) and piston case (622) into compensating hole.

Fit pilot cover (641) and tighten it with hexagonal socket head screws (437, 438).

(11) Fit set spring (655) to spool hole and put




- (12) Put spring seat (644), pilot spring (646) and adjusting ring (Q, 645) into pilot hole. Then fix spring seat (624), inner spring (626) and outer spring (625) into compensating hole.
- When fitting spring seat, take care not to mistake direction of spring seat.



(13) Install cover (C, 629) fitted with adjusting screws (628), adjusting ring (C, 627), lock nut (630), hexagon nut (801) and adjusting screw (924).

Then tighten them with hexagonal socket head screws (438).



This completes assembly.

GROUP 4 MAIN CONTROL VALVE

1. REMOVAL AND INSTALL OF MOTOR

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove the wirings for the pressure sensor and so on.
- (5) Remove bolts and disconnect pipe.
- (6) Disconnect pilot line hoses.
- (7) Disconnect pilot piping.
- (8) Sling the control valve assembly and remove the control valve mounting bolt and bracket.

· Weight: 140 kg (309 lb)

· Mounting bolt

Tightening torque: 12.2±1.3 kgf.m


(88.2±9.4 lbf.ft)


(9) Remove the control valve assembly. When removing the control valve assembly, check that all the piping have been disconnected.


2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from below items.
- ① Cylinder (Boom, arm, bucket)
- ② Swing motor
- ③ Travel motor
- See each item removal and install.
- (3) Confirm the hydraulic oil level and recheck the hydraulic oil leak or not.











2. STRUCTURE (1/4)



1	Housing-P1	26	Lock valve kit B	51	Pilot B1 cap
4	Spool assy-travel (LH)	27	Regeneration block	53	Socket head bolt
7	Spool assy-boom 1	33	Plug	56	Plain washer
10	Spool assy-arm 2	41	Plug	58	O-ring
12	Spool assy-arm regen	42	Plug	59	O-ring
14	Spool assy-bucket	45	Poppet	69	O-ring
20	Nega con relief valve	48	Orifice	81	Spring
22	Bucket stroke limiter	49	Coin type filter	82	Pin
24	Holding valve kit A1	50	Pilot A cap		


130A8MC04

STRUCTURE (2/4)



16	Main relief valve	42	Plug	67	O-ring
17	Overload relief valve	43	Poppet	71	O-ring
28	Plug	44	Poppet	72	O-ring
29	Plug	58	O-ring	74	Back up ring
31	Plug	59	O-ring	75	Back up ring
32	Plug	61	O-ring	76	Back up ring
34	Plug	62	O-ring	79	Spring
35	Plug	63	O-ring	80	Spring
39	Plua	66	O-ring		


STRUCTURE (3/4)



2	Housing-P2	26	Lock valve kit B	54	Socket head bolt
3	Spool assy-straight travel	29	Plug	55	Socket head bolt
4	Spool assy-travel (RH)	30	Plug	56	Plain washer
6	Spool assy-swing	40	Plug	57	Spring washer
8	Spool assy-swing priority	46	Sleeve	59	O-ring
9	Spool assy-boom 2	47	Piston	61	O-ring
11	Spool assy-arm 1	50	Pilot A cap	63	O-ring
13	Spool assy-option B	51	Pilot B1 cap	69	O-ring
15	Spool assy-option C	52	Pilot B2 cap	75	Back up ring
25	Holding valve kit A2	53	Socket head bolt		

130A8MC06

STRUCTURE (4/4)



130A8MC07

17	Overload relief valve	37	Plug	65	O-ring
19	Overload relief valve	43	Poppet	67	O-ring
21	Swing logic valve	44	Poppet	68	O-ring
23	ON/OFF valve-option	48	Orifice	72	O-ring
28	Plug	49	Coin type filter	73	O-ring
29	Plug	59	O-ring	77	Back up ring
31	Plug	60	O-ring	78	Back up ring
32	Plug	62	O-ring	79	Spring
34	Plug	63	O-ring	80	Spring
36	Plug	64	O-ring		

3. DISASSEMBLY AND ASSEMBLY

1) GENERAL PRECAUTIONS

- (1) All hydraulic components are manufactured to a high precision. Consequently, before disassembling and assembling them, it is essential to select an especially clean place.
- (2) In handling a control valve, pay full attention to prevent dust, sand, etc. from entering into it.
- (3) When a control valve is to be remove from the machine, apply caps and masking seals to all ports. Before disassembling the valve, recheck that these caps and masking seals are fitted completely, and then clean the outside of the assembly. Use a proper bench for working. Spread paper or a rubber mat on the bench, and disassemble the valve on it.
- (4) Support the body section carefully when carrying or transferring the control valve. Do not lift by the exposed spool, end cover section etc.
- (5) After disassembling and assembling of the component it is desired to carry out various tests (for the relief characteristics, leakage, flow resistance, etc.), but hydraulic test equipment is necessary for these tests. Therefore, even when its disassembling can be carried out technically, do not disassemble such components that cannot be tested, adjusted, and so on. Additionally one should always prepare clean cleaning oil, hydraulic oil, grease, etc. beforehand.

2) TOOLS


Before disassembling the control valve, prepare the following tools beforehand.

Name of tool	Quantity	Size (mm)		
Vice mounted on bench (soft jaws) 1 unit				
Hexagon wrench	Each 1 piece	5, 6, 10, 12 and 14		
Socket wrench	Each 1 piece	27 and 32		
Spanner	Each 1 piece	32 (main relief valve, overload relief valve, negative relief valve) 26 (holding valve)		

3) DISASSEMBLY


(1) Disassembly of spools without holding valve (travel right, travel left)

- ① Loosen hexagon socket head bolts with washer. (hexagon wrench: 5 mm)
- ② Remove the pilot cover.
- * Pay attention not to lose the O-ring under the pilot cover.
- ③ Remove the spool assembly from the body by hand slightly.
- * When extracting each spool from its body, pay attention not to damage the body.
- When extracting each spool assembly, it must be extracted from spring side only.
- * When any abnormal parts are found, replace it with completely new spool assembly.
- When disassembled, tag the components for identification so that they can be reassembled correctly.




(2) Disassembly of spools with holding valve (boom 1, Arm 1 spool)

- ① Loosen hexagon socket head bolts with washer. (hexagon wrench: 5 mm)
- ② Remove the pilot cover with internal parts.
- Pay attention not to lose the O-ring and the poppet under the pilot cover.
- Pay attention not to damage the "piston A" under pilot cover.
- 3 Remove the spool assembly from the body by hand slightly.
- When extracting each spool from its body, pay attention not to damage the body.
- * When extracting each spool assembly, it must be extracted from spring side only.
- When any abnormal parts are found, replace it with completely new spool assembly.
- When disassembled, tag the components for identification so that they can be reassembled correctly.



(3) Disassembly of the holding valve


- ① Remove the pilot cover with the holding valve as described on previous page.
- * Do not disassembled internal parts of the pilot cover.
- ② Loosen the poppet seat and remove the poppet, spring seat, spring and check. (spanner: 26 mm)
- Pay attention not to lose the poppet.
- * Do not disassembled internal parts of the check.



125LCR8MC12

(4) Disassembly of the load check valve and the negative relief valve

- ① The load check valve
 - a. Fix the body to suitable work bench.
 - Pay attention not to damage the body.
 - b. Loosen the plug (hexagon wrench: 10 mm).
 - c. Remove the spring and the load check valve with pincers or magnet.
- ② The negative relief valve
 - a. Loosen the socket (spanner: 32 mm).
 - b. Remove the spring, spring holder, piston and negative control poppet.



14W98MC13

(5) Disassembly of the main and overload relief valve

① Fix the body to suitable work bench.


② Remove the main relief valve.


(spanner: 32 mm)

3 Remove the overload relief valve.

(spanner: 32 mm)

- * When disassembled, tag the relief valve for identification so that they can be reassembled correctly.
- » Pay attention not to damage seat face.
- * When any abnormal parts are found, replace it with completely new relief valve assembly.





(6) Inspection after disassembly

Clean all disassembled parts with clean mineral oil fully, and dry them with compressed air. Then, place them on clean papers or cloths for inspection.

① Control valve

- a. Check whole surfaces of all parts for burrs, scratches, notches and other defects.
- b. Confirm that seal groove faces of body and block are smooth and free of dust, dent, rust etc.
- c. Correct dents and damages and check seat faces within the body, if any, by lapping.
- Pay careful attention not to leave any lapping agent within the body.
- d. Confirm that all sliding and fitting parts can be moved manually and that all grooves and path's are free foreign matter.
- e. If any spring is broken or deformed, replace it with new one.
- f. When a relief valve does not function properly, repair it, following it's the prescribed disassembly and assembly procedures.
- g. Replace all seals and O-rings with new ones.

2 Relief valve

- a. Confirm that all seat faces at ends of all poppets and seats are free of defects and show uniform and consistent contact faces.
- b. Confirm manually that main poppet and seat can slide lightly and smoothly.
- c. Confirm that outside face of main poppet and inside face of seat are free from scratches and so on.
- d. Confirm that springs are free from breakage, deformation, and wear.
- e. Confirm that orifices of main poppet and seat section are not clogged with foreign matter.
- f. Replace all O-rings with new ones.
- g. When any light damage is found in above inspections, correct it by lapping.
- h. When any abnormal part is found, replace it with a completely new relief valve assembly.

4) ASSEMBLY

(1) General precaution

- ① In this assembly section, explanation only is shown.
 - For further understanding, please refer to the figures shown in the previous structure & disassembly section.
- ② Pay close attention to keeping all seals free from handling damage and inspect carefully for damage before using them.
- ③ Apply clean grease or hydraulic oil to the seal so as to ensure it is fully lubricated before assembly.Do not stretch seals so much as to deform them permanently.
- ④ In fitting O-rings, pay close attention not to roll them into their final position in addition, a twisted
- ⑤ O-ring cannot easily untwist itself naturally and could thereby cause inadequate sealing and thereby both internal and external oil leakage.
- ⑥ Tighten fitting bolts for all sections with a torque wrench adjusted to the respective tightening torque.
- ⑦ Do not reuse removed O-rings and seals.

(2) Load check valve

- ① Assemble the load check valve and spring.
- 2 Put O-rings on to plug.
- 3 Tighten plug to the specified torque.
 - · Hexagon wrench: 10 mm
 - · Tightening torque: 6~7 kgf · m (43.4~50.6 lbf · ft)

(3) Negative control relief valve

- ① Assemble the nega-con poppet, piston, spring holder and spring together into body.
- 2 Put O-ring on to plug and tighten the latter to its specified torque.
 - · Hexagon wrench: 12 mm
 - · Tightening torque: 8~9 kgf·m (57.8~65.1 lbf·ft)

(4) Main relief, overload relief valves

Install main relief valve, overload relief valve into the body and tighten to the specified torque.

Component	Tools	Tightening torque		
Component	10015	kgf · m	lbf · ft	
Main relief valve	Spanner 32 mm	8~9	57.8~65.1	
Overload relief valve	Spanner 32 mm	8~9	57.8~65.1	

(5) Main spools

- ① Carefully insert the previously assembled spool assemblies into their respective bores within of body.
- Fit spool assemblies into body carefully and slowly. Do not under any circumstances push them forcibly in.

(6) Pilot covers

- ① Fit spool covers to the non-spring assembly end of the spool, and tighten the hexagonal socket head bolts to the specified torque.
 - · Hexagon wrench: 5 mm
 - · Tightening torque : 1.0~1.1 kgf · m (7.2~7.9 lbf · ft)
- Confirm that O-rings have been fitted.
- ② Fit spring covers to the spring end for the spools, and tighten hexagon socket head bolts to the specified torque.
 - · Hexagon wrench: 5mm
 - · Tightening torque: 1.0~1.1 kgf·m (7.2~7.9 lbf·ft)
- Confirm that O-rings have been fitted.

(7) Holding valves

- ① Assemble the check, spring seat and poppet together into body.
- ② Tighten the poppet seat to the specified torque.
 - · Spanner: 26 mm
 - · Tightening torque : 6~7 kgf · m (43.4~50.6 lbf · ft)
- ③ Fit the "piston A" under pilot cover with internal parts into hole on the poppet seat.
- ④ Tighten hexagon socket head bolt to specified torque.
 - · Hexagon wrench: 5mm
 - · Tightening torque: 1.0~1.1 kgf · m (7.2~7.9 lbf · ft)

GROUP 5 SWING DEVICE

1. REMOVAL AND INSTALL OF MOTOR

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect hose assembly (2).
- (5) Disconnect pilot and grease line hoses (3, 4, 5, 6, 7, 8).
- (6) Sling the swing motor assembly (1) and remove the swing motor mounting socket bolts (9).

· Weight: 34 kg (75 lb)


 \cdot Tightening torque : 29.6 \pm 3.2 kgf \cdot m (214 \pm 23.1 lbf \cdot ft)


- (7) Remove the swing motor assembly.
- When removing the swing motor assembly, check that all the piping have been disconnected.

2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the swing motor.
- Remove the air vent plug.
- ② Pour in hydraulic oil until it overflows from the port.
- ③ Tighten plug lightly.
- 4 Start the engine, run at low idling and check oil come out from plug.
- ⑤ Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.








2. DISASSEMBLY AND ASSEMBLY OF SWING MOTOR

1) STRUCTURE





130ZF2SM22

1	Casing
2	Oil seal
3	Shaft
4	Snap ring
5	Roller bearing
6	Roller bearing
7	Swash plate
8	Cylinder block
9	Spring
10	Ball guide
11	Retainer plate
12	Piston assy
13	Friction plate

14 Separate plate

15	Parking piston
16	Spring
17	Spring pin
18	O-ring
19	O-ring
20	Valve plate
21	Spring pin
22	Valve casing
23	Check valve
24	Spring
25	Plug
26	O-ring
27	Plug
28	O-ring

29 30 31 32	Plug O-ring Relief valve assy Anti-rotating valve assy
33	Plug
34	O-ring
35	O-ring
36	Time delay valve assy
37	Level gauge assy
38	Socket bolt
39	Plug
40	Name plate
41	Rivet

2) DISASSEMBLY

- (1) For easy assembly, put motor on worktable with the spline side of shaft (3) facing downwards.
- * Lay rubber plate on worktable and take care not to damage the components.



125LCR8SM03

(2) Remove snap ring (4) using snap ring plier.



125LCR8SM04

(3) Disassemble level gauge assembly (37) using pipe wrench.



125LCR8SM05

(4) Disassemble two sets of relief valve assembly (31) using 36 mm socket wrench.



125LCR8SM06

(5) Unscrew socket bolt (38) (4EA) using 12 mm hexagon wrench.



125LCR8SM07

- (6) Remove valve plate (20) from valve casing.
- * Take care not to drop the valve plate (20).



125LCR8SM08

(7) Remove O-ring (18) from valve casing.




125LCR8SM09

(8) Remove plug (33) using 10 mm hexagon wrench and take out anti-rotating valve assembly (32). (same for the set on opposite side)



125LCR8SM10

(9) Remove plug (29) (1EA), plug (27) (2EA) using 4 mm, 6 mm hexagon wrench.



125LCR8SM11

(10) Remove plug (25) using 32 mm socket wrench and separate spring; spring (24) and check valve (23). (same for the set on opposite side)



125LCR8SM12

(11) Remove spring (16) (24EA) from parking piston.



125LCR8SM15

(12) Disassemble parking piston (15) from casing using air gun.



125LCR8SM16

(13) Lay casing down horizontally and remove cylinder block assembly from shaft. And remove all friction plate (13) and separator plate (14).



125LCR8SM17

(14) Separate piston assembly (12), ball guide (10), retainer plate (11) and cylinder spring (9).



125LCR8SM18

(15) Remove O-ring (19) from casing.



125LCR8SM19

- (16) Use a magnet to separate swash plate (7) from casing.
- Sliding surface should be carefully treated to avoid scratches and damage.



125LCR8SM20

- (17) Disassemble shaft (3) and cylinderical roller bearing (5).
- Do not remove cylinderical roller bearing (5) unless malfunction is detected, since it is mounted by shrink fit.



125LCR8SM21

(18) Turn casing (1) upside down and remove oil seal (2) using jig.



125LCR8SM22

3) ASSEMBLY

- Even though assembly is accomplished by reversing disassembly steps, be careful of the following.
- ① Repair the damaged part when disassemblying and prepare parts for exchange in advance.
- 2 All parts should be cleaned with cleaner, dried with compressed air.
- 3 Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- 4 Replacement of O-ring and oil seal with new parts is generally recommended.
- (5) Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- 6 When assembling bolt, spread loctite.
- (1) Put casing (1) on worktable. Press oil seal (2) using oil seal jig, until it reach the bottom.
- Spread grease on external diameter of oil seal.



125I CR8SM23

(2) Mount cylinderical roller bearing (5, 6) on shaft (3) using shrink fitting method.



125LCR8SM24

- (3) Assemble shaft assembly in casing using urethane hammer.
- * Take care not to damage oil seal.



125LCR8SM25

- (4) Insert swash plate (7).
- * Take care not to damage sliding surface.



125LCR8SM26

(5) After applying grease on O-ring (19), insert O-ring in casing (1).



125LCR8SM27

(6) Assemble cylinder spring (9) (9EA) in cylinder block (8).



125LCR8SM28

- (7) Assemble ball guide (10) in cylinder block.
- * Take care not to damage sliding surface of cylinder block.



125LCR8SM29

- (8) Insert piston assembly (12) in retainer plate (11).
- * Do not mix piston with other piston (9EA/1set).
- Spread sufficient amount of hydraulic oil on piston assembly.



125LCR8SM30

- (9) Place all 9 pistons simultaneously into the holes of cylinder block.
- * Take care not to damage sliding surface.



125LCR8SM31

- (10) Lay casing down horizontally and put cylinder block assembly in casing.
- Check whether cylinder block assembly rotates smoothly.



125LCR8SM32

(11) Put friction plate (13) in casing.



125LCR8SM33

- (12) Put separator plate (14) in casing.
- Put friction plate and separator plate alternately.



125LCR8SM34

- (13) Assemble O-ring (18) in parking piston (15).
- * Apply grease on O-ring.



125LCR8SM35

- (14) Assemble parking piston (15) in casing using jig.
- * Pay attention to the hole location of parking piston.



125LCR8SM36


(15) Put spring (16) (24EA) in each hole of parking piston.



125LCR8SM37

(16) Assemble plug (27) using 6 mm hexagon wrench.

 \divideontimes Tightening torque : 4.5±0.45 kgf · m (32.5±3.3 lbf · ft)



125LCR8SM41


(17) Assemble plug (29) using 4 mm hexagon wrench.

** Tightening torque : $3.0\pm0.3 \text{ kgf} \cdot \text{m}$ (2.2± lbf · ft)



125LCR8SM42

(18) Assemble anti-rotating valve assembly (32) in valve casing.



125LCR8SM43

(19) Assemble plug (33) using 32 mm hexagon wrench.

** Tightening torque : $14.0\pm1.0 \text{ kgf} \cdot \text{m}$ ($101\pm7.2 \text{ lbf} \cdot \text{ft}$)



125LCR8SM44

(20) Caulk check valve (23) using jig. (same for the set on opposite side)



125LCR8SM45

(21) Assemble spring (24), plug (25). (in that order) (same for the set on opposite side)

% Tightening torque : 25±2.5 kgf \cdot m (181±18.1 lbf \cdot ft)



125LCR8SM46

(22) Assemble spring pin (21) in valve casing using jig.



125LCR8SM47

- (23) Assemble O-ring (18) & cylinderical roller bearing (6) in valve casing.
- W Use jig (press fit or cold shrink fit).




125I CR8SM48

- (24) Apply grease on steel side of valve plate (20) to prevent plate from sliding. Assemble valve plate with the copper side facing upwards.
- Pay attention to the assembly direction.
- * Take care not to damage sliding surface.



125LCR8SM49

- (25) Assemble valve casing by matching its holes and pins of casing and parking piston. And tighten socket bolt (38) (4EA) using 12 mm hexagon wrench.
- ※ Tightening torque: 17.5±1.7 kgf ⋅ m $(127\pm12.7 lbf \cdot ft)$
- Make sure valve plate stays in place.
- When tightening bolts, make sure mating surfaces between casing and valve casing maintain parallel to each other.



- Spread grease on O-ring part of relief valve assembly.
- ※ Tightening torque: 18.0±1.8 kgf ⋅ m $(130\pm13.0 \text{ lbf} \cdot \text{ft})$



125LCR8SM50



125LCR8SM51

(27) Assemble snap ring (4) in shaft by using snap ring plier.



125LCR8SM52

(28) Wrap teflon tape 2 or 3 times around the tap part of level gauge assembly (37).

And assemble it using pipe wrench.



125LCR8SM53


3. REMOVAL AND INSTALL OF REDUCTION GEAR

1) REMOVAL

- Remove the swing motor assembly.
 For details, see removal of swing motor assembly.
- (2) Sling reduction gear assembly (1) and remove dowel pin (3) and mounting bolts (2).
- (3) Remove the reduction gear assembly.

 Reduction gear device weight: 75 kg


 (165 lb)



2) INSTALL


(1) Carry out installation in the reverse order to removal.

 \cdot Tightening torque : 29.6 \pm 3.2 kgf \cdot m (214 \pm 23.1 lbf \cdot ft)



4. DISASSEMBLY AND ASSEMBLY OF REDUCTION GEAR

1) STRUCTURE



125LCR2SM23

1	Ring gear	11	Planetary gear No. 2	21	Carrier pin No. 1
2	Drive shaft	12	Needle bearing No. 2	22	Sun gear No. 1
3	Taper roller bearing	13	Thrust washer No. 2	23	Snap ring
4	Taper roller bearing	14	Carrier pin No. 2	24	Thrust plate
5	Ring nut	15	Spring pin	25	Sleeve
6	Lock plate	16	Sun gear No. 2	26	O-ring
7	Hexagon bolt	17	Carrier No. 1	27	Oil seal
8	Casing	18	Planetary gear No. 1	30	Plug
9	Socket bolt	19	Needle bearing No. 1	31	Parallel pin
10	Carrier No. 2	20	Thrust washer No. 1	32	Thrust washer No. 1

2) DISASSEMBLY

(1) Remove the swing motor, and then place swing reduction gear on the bench.



125I CB8SM60

(2) Disassemble sun gear No.1 (22).



25I CB8SM61

(3) Disassemble carrier No.1 sub assembly.



125LCR8SM62

Carrier No.1 sub assy disassembly

(4) Put carrier No.1 sub assembly on the bench, then remove the snap ring (23).



125LCR8SM63

(5) Disassemble thrust washer No.1 (upper) (32).(3 pcs)



125LCR8SM64

(6) Disassemble planetary gear No.1 (18).(3 pcs)



125LCR8SM65

(7) Disassemble thrust plate (24).



125LCR8SM66

(8) Disassemble needle bearing No.1 (19). (3 pcs)



125LCR8SM67

(9) Disassemble thrust washer No.1 (lower) (20). (3 pcs)



125LCR8SM68

- (10) After placing spring pin (15) to center of carrier pin No.1 (21) with a jig, disassemble it. (3 pcs)
- Do not reuse spring pin, carrier and carrier pin.



125LCR8SM69

(11) Disassemble sun gear No.2 (16).



125LCR8SM70

(12) Disassemble carrier No.2 sub assembly.



125LCR8SM71

Carrier No.2 sub assy disassembly

- (13) After placing spring pin (15) to center of carrier pin No.2 (14) with a press machine, disassemble it.(3 pcs)
- * Do not reuse spring pin.



125LCR8SM72

(14) Disassemble planetary gear No.2.(3 pcs)



125LCR8SM73

(15) Disassemble thrust plate (24).



125LCR8SM74

(16) Disassemble thrust washer No.2 (13).(6 pcs)



125LCR8SM75

(17) Disassemble needle bearing No.2 (12). (3 pcs)



125LCR8SM76

(18) Separate ring gear (1) from casing (8).



125LCR8SM77

(19) Loosen bolt (7) (4 pcs), and disassemble lock plate (6).



125LCR8SM78

(20) Disassemble ring nut (5) by using the jig.



125LCR8SM79

Drive shaft sub assy disassembly

(21) Separate drive shaft sub assembly from casing (8).



125LCR8SM80

(22) Disassemble taper roller bearing (3) and oil seal (27) by using a press machine.



25LCR8SM81

(23) Disassemble sleeve (25) and O-ring (26).



125LCR8SM82

(24) Disassemble the outer ring of taper roller bearing (3) in casing (8) by using the jig.



125LCR8SM83

3) ASSEMBLY

- Even though assembly is accomplished by reversing disassembly steps, be careful of the following.
- ① Repair the damaged part when disassemblying and prepare parts for exchange in advance.
- 2 All parts should be cleaned with cleaner, dried with compressed air.
- 3 Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- 4 Replacement of O-ring and oil seal with new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- 6 When assembling bolt, spread loctite.

Carrier No.1 sub assembly

(1) After heating the carrier No.1 (17), assemble carrier pin No.1 (21) to the side without thehole.




125I CR8SM84

(2) After drilling \emptyset 6 hole, assemble spring pin (15).(3 pcs)



- (3) Caulking is performed on the assembled spring pin unit.
- To cover pins, implement the caulking in two places that are located direction of 180 degrees around assembled spring pin.



125LCR8SM86

(4) Assemble thrust washer No.1 (lower) (20). (3 pcs)



125LCR8SM87

(5) Assemble needle bearing No.1 (19).(3 pcs)



125LCR8SM88

(6) Assemble thrust plate (24).



125LCR8SM89

(7) Assemble planetary gear No.1 (18) of which groove is faced downward.(3 pcs)



125LCR8SM90

(8) Assemble thrust washer No.1 (upper) (32). (3 pcs)



125LCR8SM91

- (9) Assemble snap ring (23) (3 pcs), complete carrier No.1 sub assembly.
- Gear rotation state should be smooth.



125LCR8SM92

Carrier No.2 sub assy assembly

(10) Assemble needle bearing No.2 (12) in the planetary gear No.2 (11).



125LCR8SM93

(11) After spreading grease on thrust washer No.2 (13), assemble it on both upper side and lower side of planetary gear No.2.



125LCR8SM94

(12) Assemble thrust plate (24).



125LCR8SM95

- (13) Assemble planetary gear No.2 in the carrier No.2 (10).(3 pcs)
- * Thrust washer No.2 should notseparated.



125LCR8SM96

(14) Assemble carrier pin No.2 (14) to match the pin hole of the carrier No.2.(3 pcs)




125LCR8SM97

(15) Assemble spring pin (15).(3 pcs)



125LCR8SM98

- (16) Caulking is performed on the assembled spring pin unit.
- * To cover pins, implement the caulking in two places that are located direction of 180 degrees around assembled spring pin.



125LCR8SM99

Drive shaft sub assy assembly

(17) After heating sleeve (25), assemble O-ring (26) to groove of inside diameter in it.



125LCR8SM100

- (18) Shrink fit the sleeve on drive shaft (2).
- Be careful of fully seat at the bottom.



125LCR8SM101


(19) Shrink fit taper roller bearing (3) on drive shaft, complete drive shaft sub assembly.



125LCR8SM102

Casing assembly

(20) Press outer ring of the taper bearing in the casing (8) by using the jig.



125LCR8SM103

- (21) Press in oil seal (27) by using the jig.
- * Be careful of the direction of the assembly.



125LCR8SM104

- (22) Assemble drive shaft sub assembly.
- Be careful of damage of oil seal.



125LCR8SM105

(23) After fixing drive shaft so that it does not fall, and then turn it over, press taper bearing (4).



125LCR8SM106

(24) Assemble ring nut (5) by using the jig. \divideontimes Tightening torque : 3.5 \pm 0.4 kgf \cdot m (25.3 \pm 2.9 lbf \cdot ft)



125LCR8SM107

(25) Place lock plate (6) on the ring nut.



125LCR8SM108

(26) After spreading loctite #242, assemble the bolt (7) (4 pcs).

** Tightening torque : 2.5 \pm 0.25 kgf \cdot m (18.1 \pm 1.8 lbf \cdot ft)




125LCR8SM109

(27) Press parallel pin (31) by using press machine.



- (28) Spread the loctite #515 on the casing with reference to the right detail view.
- * Loctite should not flow into casing.



125LCR8SM111

- (29) Assemble ring gear (1) in accordance with a pin hole on casing.
- * Be careful of damage of the ring gear.



(30) Assemble carrier No.2 sub assembly.



125LCR8SM113

(31) Assemble sun gear No.2 (16).



125I CR8SM114

(32) Assemble carrier No.1 sub assembly.



125LCR8SM115

(33) Assemble sun gear No.1 (22) of which grinding surface is faced downward.



125LCR8SM116

(34) Fill with gear oil 3.5 liter.



125LCR8SM117

GROUP 6 TRAVEL DEVICE


1. REMOVAL AND INSTALL


1) REMOVAL

- (1) Swing the work equipment 90° and lower it completely to the ground.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- A Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove the track shoe assembly.
 For details, see removal of track shoe assembly.
- (5) Remove the cover.
- (6) Remove the hose.
- * Fit blind plugs to the disconnected hoses.
- (7) Remove the bolts and the sprocket.
 - \cdot Tightening torque : 29.7 \pm 3.0 kgf \cdot m (215 \pm 21.7 lbf \cdot ft)
- (8) Sling travel device assembly (1).
- (9) Remove the mounting bolts (2), then remove the travel device assembly.
 - · Weight: 139 kg (306 lb)
 - \cdot Tightening torque : 23 \pm 2.5 kgf \cdot m (166 \pm 18.1 lbf \cdot ft)


2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the travel motor.
- ① Remove the air vent plug.
- 2 Pour in hydraulic oil until it overflows from the port.
- 3 Tighten plug lightly.
- ④ Start the engine, run at low idling, and check oil come out from plug.
- 5 Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.





2. TRAVEL MOTOR



		0	
			27
48	31	47	
55 56	Restrictor Restrictor		
.hh	Besiricion		

130ZF2TM21

1	Casing
2	Plug
3	Oil seal
4	Piston
5	Piston seal
6	Shaft
7	Front ball bearing
8	Rear ball bearing
9	Steel ball
10	Pivot
11	Swash plate
12	Cylinder block
13	Spring
14	Ball guide
15	Retainer plate
16	Piston assy
17	Friction plate
18	Separated plate

19	Parking piston
20	O-ring
21	Back up ring
22	O-ring
23	Back up ring
24	Valve plate
25	Spring pin
26	Spring
27	O-ring
28	Spring pin
29	Parallel pin
30	Rear cover
31	Main spool assy
32	Cover
33	Spring
34	Restrictor
35	Spring

36 O-ring

37	Spring seat
38	Relief valve assy
39	O-ring
40	Spool
41	Plug
42	Spring seat
43	Parallel pin
44	Spring
45	Connector
46	O-ring
47	Hexagon socket head bolt
48	Hexagon socket head bolt
49	Hexagon socket head bolt
50	Check valve
51	Spring
52	Plug
53	O-ring

55	Restrictor
56	Restrictor
57	Name plate
58	Rivet
59	Ring gear
60	Bearing
61	Floating seal assy
62	Nut ring
63	Lock plate
64	Hexagon head bolt
65	Thrust plate
66	Planetary gear No.2
67	Needle bearing
68	Inner race No. 2
69	Thrust washer
70	Sun gear No.2
71	Carrier No.1
72	Planetary gear No.1

31 47	37	36	33 32
Restrictor		73	Needle bearing
Restrictor		74	Inner race No. 1
Name plate		75	Thrust plate
Rivet		76	Hexagon head bolt
Ring gear		77	Countersunk head screw
Bearing		78	Sun gear No.1
Floating seal assy		79	O-ring
Nut ring		80	Cover
Lock plate		81	Hex socket head bolt
Hexagon head bolt		82	Plug
Thrust plate		83	O-ring
Planetary gear No.2		84	Name plate
Needle bearing		85	Rivet
Inner race No. 2		86	Rubber cap
Thrust washer		87	Rubber cap
Sun gear No.2		88	Plain washer
Carrier No.1		89	Hexagon bolt
Planetary gear No.1		90	Thrust plate

49 40 43 42 41 44 38

54 Plug


2) DISASSEMBLY

- (1) Choose a clean place, remove contaminants (dust, etc) and cleans motor before placing it on worktable.
- * Lay the rubber plate on worktable and take care not to damage the component.



125LCR8TM02

(2) Remove the connector (45) using 21 mm socket wrench.



125LCR8TM03

(3) Remove plug (41) using 21 mm socket wrench.




125LCR8TM04

- (4) Disassemble parallel pin (43) and spring (44).
- Do not lose spring.
- * Do not mix spring with other springs.



(5) Remove spring seat (42) and spool (40).



125LCR8TM06

(6) Disassemble relief valve assembly (38) using 26 mm socket wrench. (2 sets)



125LCR8TM07

(7) Disassemble cover (32) using 41 mm socket wrench.




125LCR8TM08

(8) Disassemble spring seat (37) and spring (33). (2 sets)



125LCR8TM09

(9) Separate main spool assembly (31) from rear cover.



125LCR8TM10

(10) Unscrew socket bolt (47) (1EA), (48) (3EA), (49) (6EA) from rear cover.



125LCR8TM11

(11) Remove parallel pin (29).



125LCR8TM12

- (12) From rear cover, disassemble valve plate (24) and O-ring (27).
- * Take care not to damage assembly surface of rear cover.



125LCR8TM13

- (13) Disassemble restrictor (55, 56) (2EA).
- Mark the number on restrictor and its hole to avoid confusing (55) and (56).



1251 CD9TM14

(14) Remove plug (52).



125LCR8TM15

- (15) Remove restrictor (34) and spring (35). (2 sets)
- Do not confuse restrictor (34) and check valve (50).
- * Do not confuse spring (35) and spring (51).
- Do not lose spring.
- Do not mix spring with other springs.



125LCR8TM16

(16) Remove plug (52) using 5 mm hexagon wrench.



125LCR8TM17

- (17) Remove check valve (50) and spring (51). (2 sets)
- Do not confuse restrictor (34) and check valve (50).
- * Do not confuse spring (35) and spring (51).
- * Do not lose spring.
- Do not mix spring with other springs.



125LCR8TM18

- (18) From parking piston, remove spring (26) (12ea).
- Do not lose spring.
- * Do not mix spring with other springs.



125LCR8TM19

(19) Disassemble parking piston (19) using air gun or jig.



125LCR8TM20

(20) From parking piston, separate O-ring (22) and back-up ring (23).



125LCR8TM21

(21) From parking piston separate O-ring (20) and back-up ring (21).



125LCR8TM22

(22) Lay casing down horizontally and remove cylinder block assembly, friction plate (17) (3EA) and separator plate (18) (4EA).




125LCR8TM23

- (23) Separate retainer plate (15) and piston assembly (16).
- * Take care not to damage sliding surface of each component.



125LCR8TM24

- (24) Disassemble ball guide (14) and spring (13) (9EA).
- Do not lose spring.
- Do not mix spring with other springs.



125LCR8TM25

- (25) Disassemble swash plate (11) and pivot (10).
- * Take care not to damage sliding surface.



125LCR8TM26

- (26) Disassemble shaft (6) and ball bearing (7).
- Do not remove ball bearing unless malfunction is detected, since it is mounted by shrink fit.



125LCR8TM27

(27) Disassemble 1, 2 speed piston (4) and steel ball (9) using air gun.



125LCR8TM28

(28) Disassemble piston seal (5).



125LCR8TM29

(29) Turn casing (1) upside down and remove oil seal (3) using jig.



125LCR8TM30

3) ASSEMBLY

- Even though assembly is accomplished by reversing disassembly steps, be careful of the following.
- ① Repair the damaged part when disassemblying and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil sealwith new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values shown table1.
- 6 When assembling bolt, spread Loctite.
- (1) Put casing (1) on the worktable.



125LCR8TM31

(2) After applying grease on the external diameter of oil seal (3), insert oil seal in casing.



125LCR8TM32

(3) After applying grease on pivot (10), insert steel ball in casing.



125LCR8TM33

- (4) After assembling piston seal (5) and steel ball(9) in 1, 2 speed piston (4), insert piston in hole of casing.
- Check whether piston sticks in hole.
- * Use piston seal jig.



125LCR8TM34

- (5) Mount ball bearing (7) on shaft (6) by shrink fit. Insert shaft in casing.
- * Take care not to damage oil seal.



125LCR8TM35

- (6) Assemble swash plate (11) by matching its hole and steel ball.
- * Take care not to damage sliding surface.



125LCR8TM36

(7) Assemble spring (13) (9ea) and ball guide (14) in cylinder block (12) in that order.



125LCR8TM37

- (8) Insert piston assembly (16) in retainer plate (15) and assemble them in cylinder block.
- Spread hydraulic oil on piston assembly.
- * Take care not to damage each component.
- Check cylinder block and piston assembly runs properly.



125LCR8TM38

- (9) Lay casing down horizontally and assemble cylinder block assembly by matching its spline with shaft.
- Make sure swash plate stays in place.
- Check the assembling status of cylinder block by pressing it.



125LCR8TM39

(10) Assemble separator plate (18) (4EA) and friction plate (17) (3EA) alternately.



125LCR8TM40

(11) Insert back-up ring & O-ring in parking piston.



125LCR8TM41

- (12) Align the pin hole of parking piston (19) with oil hole of casing, assemble them using jig.
- Spread grease on O-ring and back-up ring.
- * Take care not to damage components.



125LCR8TM42

(13) Insert spring (26) (12EA) in parking piston.



125LCR8TM43

(14) Insert parallel pin (29) (2EA) in casing.



125LCR8TM44

- (15) Assemble check valve (50) and spring (51) in order.
- Do not confuse check valve (50) and restrictor (34).
- Do not confuse spring (51) and spring (35)



125I CR8TM45


(16) Clamp plug (52) using 5 mm hexagon wrench.

** Tightening torque : $3.0\pm0.3 \text{ kgf} \cdot \text{m}$ (21.7±2.2 lbf · ft)



125LCR8TM46

- (17) Assemble restrictor (34) and spring (35) in order.
- Do not confuse check valve (50) and restrictor (34).
- * Do not confuse spring (51) and spring (35).



125LCR8TM47

(18) Clamp plug (52).

% Tightening torque : 3.0±0.3 kgf · m (21.7±2.2 lbf · ft)



125LCR8TM48

(19) Clamp plug (54).


** Tightening torque : 4.5±0.5 kgf ⋅ m
 ** Tightening to

(32.5±3.6 lbf · ft)



125LCR8TM49

- (20) Assemble restrictor (55) and (56) in rear cover.
- Check whether the restrictor is placed in exact hole.
- * Do not confuse (55) and (56).



125LCR8TM50

(21) Assemble ball bearing (8) in rear cover using jig.




125LCR8TM51

(22) Insert spring pin (25) (2ea) and (28) in rear cover using jig.



125LCR8TM52

- (23) After spreading grease sufficiently to the bottom side of valve plate (24), assemble valve plate in rear cover by matching its holes with pins.
- * Take care not to damage sliding surface.
- Pay attention to the assembly direction.



125I CB8TM53

- (24) Assemble O-ring (27) in rear cover.
- Spread grease on O-ring.



125LCR8TM54

- (25) Put rear cover upon casing, paying attention to the location of pin and hole. And tighten bolt (47), (48) and (49).
- Tightening torque: 17.5±1.8 kgf⋅m
 (127±13.0 lbf⋅ft)
- Make sure valve plate stays in place.
- Check bolt position.



125LCR8TM55

(26) Assemble main spool assembly (31), spring seat (37) and spring (33) in rear cover.



125LCR8TM56

(27) Settle cover (32).

** Tightening torque : $15\pm1.5 \text{ kgf} \cdot \text{m}$ ($108\pm10.8 \text{ lbf} \cdot \text{ft}$)



125LCR8TM57

(28) Insert relief valve (38) in rear cover.

 \divideontimes Tightening torque : 15±1.8 kgf · m (108±13.0 lbf · ft)



125LCR8TM58

(29) After clamping connector (45) to rear cover, assemble spool (40).

** Tightening torque : $5.5\pm0.5 \text{ kgf} \cdot \text{m}$ (39.8±3.6 lbf · ft)



125LCR8TM59

(30) After inserting parallel pin (43), assemble seat-spring (42).



125LCR8TM60

(31) After assembling spring (44) in order, clamp plug (41).



125I CR8TM61


3. TRAVEL REDUCTION GEAR DISASSEMBLY

1) While travel reduction gear is tilted to one side disassemble PF3/8 plug (82), remove gear oil and place motor sideto the bench.



125LCR8TM70

2) Disassemble cover (80) by unscrewing the M10 bolts (81) (12 pcs).



125LCR8TM71

3) Disassemble sun gear No.1 (78).



125LCR8TM72

4) Disassemble carrier No.1 assembly.



125LCR8TM73

Carrier No. 1 sub assy disassembly

5) Disassemble M8 bolt (76) from the carrier assembly. (3 pcs)



125LCR8TM74

6) Disassemble thrust plate No.1 (75) from the carrier assembly.




125LCR8TM75

7) Disassemble planetary gear No.1 (72).(3 pcs)



125LCR8TM76

- 8) Disassemble needle bearing (73).(3 pcs)
- Do not disassemble inner race in the absence of abnormalities.



125LCR8TM77

9) Disassemble Sun gear No.2 (70).



125LCR8TM78

10) Disassemble M10 bolt (64).(4 pcs)



125LCR8TM79

11) Disassemble thrust washer No.2 (65).(4 pcs)



125LCR8TM80

12) Disassemble planetary gear No.2 (66).(4 pcs)



125LCR8TM81

13) Disassemble needle bearing No.2 (67).(4 pcs)



125LCR8TM82

- 14) Disassemble thrust plate No.2 (69).(4 pcs)
- Do not disassemble inner race in the absence of abnormalities.



125LCR8TM83

15) Disassemble M10 bolt (89), plain washer (88) and M8 screw (77).



125LCR8TM84

16) Disassemble lock plate (63).



125LCR8TM85

17) Disassemble nut ring (62) by using the jig.



125LCR8TM86

18) Disassemble ring gear assembly (59) from motor assembly.




125LCR8TM87

19) Disassemble folating seal assembly (61) from ring gear assembly and motor assembly.



125LCR8TM88

- 20) Disassemble bearing (60) (2ea) from ring gear assembly.
- * Do not disassemble bearing in the absence of abnormalities.



125LCR8TM89

4. TRAVEL REDUCTION GEAR ASSEMBLY

- Even though assembly is accomplished by reversing disassembly steps, be careful of the following.
- ① Repair the damaged part when disassemblying and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- 6 When assembling bolt, spread loctite.
- 1) Put carrier No.1 (71) on the jig, and shrink-fit inner race No.1 (74) to carrier pin.(3 places)
- * Do not tilt inner race to one side.
- * Match inner race and end of carrier pin.



125LCR8TM90

2) Assemble needle bearing No.1 (73).(3 pcs)



125LCR8TM91

3) Assemble planetary gear No.1 (72) of which groove is faced downward. (3 places)



125LCR8TM92

4) Assemble thrust plate No.1 (75).



125LCR8TM93

- 5) After spreading loctite #242, assemble the M8 bolt (76).(3 pcs)
- \divideontimes Tightening torque : 2.7 \pm 0.3 kgf \cdot m
- After the assembly, instantly check the noise and interference by rotatong the gear.



125LCR8TM94

6) First, place bearing (60) on the ring gear (59), then put jig on it, then press it with press machine.




125LCR8TM95

- 7) After turning ring gear over, assemble bearing the same way.
- * Be care of nick and safety when turn ring gear over.



125LCR8TM96

- 8) Assemble folating seal assembly (61) by usingthe
- * After assembling, wipe steel-lined section with alcohol.
- * Flatness deviation has to be less than 1 mm.



125LCR8TM97

- 9) Place folating seal assembly on the motor assembly then assemble it.
- * After assembling, wipe steel-lined section with alcohol.
- Flatness deviation has to be less than 1 mm.



125LCR8TM98

- 10) After arriving safely ring gear assembly in the motor assembly, press it with press machine.
- * After press-fitting, clamp ring gear to fixit.
- * When using the press pay attention to bearing damage.



- 11) After assembling nut ring (62) by using the jig, disassemble the clamping.
- ※ Tightening torque: 60 kgf ⋅ m (434 lbf ⋅ ft)




125I CB8TM100

- 12) Place lock plate (63) on the nut ring groove.
- Select best position from one of 4 casing hole to assemble lock plate.




125LCR8TM101

- 13) Place lock plate th the direction which nut ring is loosed and then assemble M10 bolt (89) with M8 screw (77) after spreading loctite #242. (Refer to assembly detail drawing)
- st Tightening torque (M10) : 5.5 \pm 0.6 kgf \cdot m (39.8 \pm 4.3 lbf \cdot ft)
- % Tightening torque (M8) : 2.7 \pm 0.3 kgf \cdot m (19.5 \pm 2.2 lbf \cdot ft)
- Make sure that M8 screw doesn't stick out of lock plate.
- * Assembly detail drawing lock plate.



125LCR8TM102



125LCR8TM103

14) Shrink fit the inner race No.2 (68).(4 pcs)



125LCR8TM104

15) Assemble thrust plate No.2 (69).(4 pcs)



125LCR8TM105

16) Assemble needle bearing No.2 (67).(4 pcs)



125LCR8TM106

17) Assemble planetary gear No.2 (66).(4 pcs)※ Grooves of planetary gear will be facingup.



125LCR8TM107

18) Assemble thrust washer No.2 (65).(4 pcs)



125I CR8TM108

19) After spreading loctite #242, assemble the M10 bolt (64).(4 pcs)

 \divideontimes Tightening torque : 5.5 \pm 0.6 kgf \cdot m (39.8 \pm 4.3 lbf \cdot ft)



125LCR8TM109

20) Assemble sun gear No.2 (70).



125LCR8TM110

21) Assemble carrier No.1 assembly.




125LCR8TM111

22) Assemble sun gear No.1 (72).



125LCR8TM112

23) Spread the loctite #515 on the cover (80) with reference to the right detail view.



125LCR8TM114

24) Place cover (80) to fit the bolt holes.



125LCR8TM115

25) After spreading loctite #242, assemble the M10 bolt (81).(12 pcs)

** Tightening torque : 6.3 \pm 0.7 kgf \cdot m (45.6 \pm 5.1 lbf \cdot ft)



125LCR8TM116

26) Inject the 2.3 $\,\pm\,$ 0.3 liter gear oil to PF3/8 tap section.



125I CR8TM117

27) After assembling the O-ring (83) to the plug (82), assemble it to the cover. (3 pcs)

** Tightening torque : 5.5 \pm 0.5 kgf \cdot m (39.8 \pm 3.6 lbf \cdot ft)



125LCR8TM118

GROUP 7 RCV LEVER


1. REMOVAL AND INSTALL


1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- (4) Loosen the socket bolt (1). Tightening torque : 1.05 \pm 0.2 kgf \cdot m (7.6 \pm 1.45 lbf \cdot ft)
- (5) Remove the cover of the console box.
- (6) Disconnect pilot line hoses (3).
- (7) Remove the pilot valve assembly (2).
- When removing the pilot valve assembly, check that all the hoses have been disconnected.

2) INSTALL


- Carry out installation in the reverse order to removal.
- (2) Confirm the hydraulic oil level and check the hydraulic oil leak or not.





2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE



Plug Case Joint assembly 22 Nut 1 8 15 2 Bushing 9 Push rod 16 Swash plate 23 Boot Adjusting nut Last guard filter 3 Spool 10 O-ring 17 24 Bushing 4 Shim 11 Rod seal 18 25 O-ring Plate 5 Spring 12 19 Plug 26 O-ring 6 Spring seat Spacer Handle assembly 27 Connector 13 20 7 Boot 21 Handle bar Spring 14

300L2RL06

2) TOOLS AND TIGHTENING TORQUE

(1) Tools


Tool name	Remark		
Allen wrench	6 B		
Spanne	22		
	27		
(+) Driver	Length 150		
(-) Driver	Width 4~5		
Torque wrench	Capable of tightening with the specified torques		


(2) Tightening torque


Part name	Item	Cino	Torque			
		Size	kgf · m	lbf ⋅ ft		
Joint	15	M14	3.5	25.3		
Swash plate	16	M14	5.0±0.35	36.2±2.5		
Adjusting nut	17	M14	5.0±0.35	36.2±2.5		
Lock nut	22	M14	5.0±0.35	36.2±2.5		

3) DISASSEMBLY

- * Procedures are based on the type M1.
- (1) Clean pilot valve with kerosene.
- Put blind plugs into all ports
- (2) Fix pilot valve in a vise with copper (or lead) sheets.
- (3) Remove end of boot (23) from case (1) and take it out upwards.









(4) Loosen lock nut (22) and adjusting nut (17) with spanners on them respectively, and take out handle section as one body.




(5) Remove the boot (14).





(6) Loosen adjusting nut (17) and swash plate (16) with spanners on them respectively, and remove them.






- (7) Turn joint anticlockwise to loosen it, utilizing jig (Special tool).
- When return spring (7) is strong in force, plate (12), plug (8) and push rod (9) will come up on loosening joint. Pay attention to this.







(8) Remove plate (12).




- (9) When return spring (7) is weak in force, plug (8) stays in casing because of sliding resistance of O-ring.
- * Take it out with minus screwdriver. Take it out, utilizing external periphery groove of plug and paying attention not to damage it by partial loading.
- During taking out, plug may jump up due to return spring (7) force.
 Pay attention to this.




** Record relative position of reducing valve subassembly and return springs.






- (11) Separate spool (3), spring seat (6), spring (5) and shim (4) individually.
- Pay attention not to damage spool surface.
- Record original position of spring seat (6).
- W Until being assembled, they should be handled as one subassembly group.





(12) Take push rod (9) out of plug (8).




(13) Remove O-ring (10) and seal (11) from plug (8).


Use small minus screwdriver or so on to remove this seal.





(14) Remove lock nut (22) and then boot (23).





(15) Cleaning of parts

- ① Put all parts in rough cleaning vessel filled with kerosene and clean them (rough cleaning).
- If dirty part is cleaned with kerosene just after putting it in vessel, it may be damaged. Leave it in kerosene for a while to loosen dust and dirty oil.
- If this kerosene is polluted, parts will be damaged and functions of reassembled valve will be degraded.
 - Therefore, control cleanliness of kerosene fully.
- ② Put parts in final cleaning vessel filled with kerosene, turning it slowly to clean them even to their insides (finish cleaning).
- ** Do not dry parts with compressed air, since they will be damaged and/or rusted by dust and moisture in air.


(16) Rust prevention of parts

Apply rust-preventives to all parts.


If left as they after being cleaned, they will be rusted and will not display their functions fully after being reassembled.

4) ASSEMBLY


(1) Put shim (4), springs (5) and spring seat (6) onto spool (3) in this order.




- (2) Assemble spring (7) into casing (1).
 Assemble reducing valve subassembly into casing.
- Assemble them to their original positions.




(3) Assemble O-ring (10) onto plug (8).




- (4) Assemble seal (11) to plug (8).
- Assemble seal in such lip direction as shown below.




- (5) Assemble push rod (9) to plug (8).
- * Apply working oil on push-rod surface.




- (6) Assemble plug subassembly to casing.
- When return spring is weak in force, subassembly stops due to resistance of O-ring.




(7) When return spring is strong in force, assemble 4 sets at the same time, utilizing plate (12), and tighten joint (15) temporarily.




- (8) Fit plate (12).
- (9) Tighten joint (15) with the specified torque to casing, utilizing jig.




- (10) Assemble swash plate (16) to joint (15).
- Screw it to position that it contacts with 4 push rods evenly.
- X Do not screw it over.




- (11) Assemble adjusting nut (17), apply spanner to width across flat of plate (16) to fix it, and tighten adjusting nut to the specified torque.
- During tightening, do not change position of disk.




(12) Fit boot (14) to plate.




(13) Fit boot (23) and lock nut (22), and handle subassembly is assembled completely.







(14) Pull out cord and tube through adjusting nut hole provided in direction 60 °to 120 °from casing hole.




- (15) Assemble bushing (18) to plate and pass cord and tube through it.
- Provide margin necessary to operation.




(16) Determine handle direction, tighten lock nut (22) to specified torque to fix handle.



(17) Apply grease to rotating section of joint and contacting faces of disk and push rod.



- (18) Assemble lower end of bellows to casing.
- (19) Inject volatile rust-preventives through all ports and then put blind plugs in ports.



GROUP 8 TURNING JOINT

1. REMOVAL AND INSTALL

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect all hoses.
- (5) Sling the turning joint assembly (1) and remove the mounting bolt (2).

· Weight: 59 kg (130 lb)


 \cdot Tightening torque : 12.3 \pm 1.3 kgf \cdot m (89.0 \pm 9.4 lbf \cdot ft)


- (6) Remove the turning joint assembly.
- When removing the turning joint, check that all the hoses have been disconnected.

2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- * Take care of turning joint direction.
- Assemble hoses to their original positions.
- * Confirm the hydraulic oil level and check the hydraulic oil leak or not.








2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE



160A8TJ03


- 1 Hub
- 2 Shaft
- 3 Cover
- 4 Spacer
- 5 Shim
- 6 Shim

- 7 Slipper seal
- 8 O-ring
- 9 O-ring
- 10 O-ring
- 11 Wear ring
- 12 Retainer ring


- 13 Plug
- 14 Plug
- 15 Hexagon bolt
- 16 Spring washer

2) DISASSEMBLY


- Before the disassembly, clean the turning joint.
- (1) Remove bolts (15), washer (16) and cove r (3).




- (2) Remove shim (6) and O-ring (10).
- (3) Remove retainer ring (12), spacer (4) and shim (5).



- (4) Place hub (1) on a V-block and by using a wood buffer at the shaft end, hit out shaft(2) to about 1/2 from the body with a hammer.
- Take care not to damage the shaft (2) when remove hub (1) or rest it sideway.
- Put a fitting mark on hub (1) and shaft (2).




(5) Remove six slipper seals (7) and O-ring (9), two wear ring (11) from hub (1).




3) ASSEMBLY


- Clean all parts.
- As a general rule, replace oil seals and O-ring.
- Coat the sliding surfaces of all parts with engine oil or grease before installing.
- (1) Fix seven slipper seal (7) and O-ring (9), two wear ring (11) to hub (1).
- (2) Fit O-ring (8) to shaft (2).



(3) Set shaft (2) on block, tap hub (1) with a plastic hammer to install.




- (4) Fit shim (5), spacer (4) and retainer ring (12) to shaft (2).
- (5) Fit O-ring (10) to hub (1).
- (6) Fit shim (6) to shaft (2).



(7) Install cover (3) to body (1) and tighten bolts (15).

 \cdot Torque : 10~12.5 kgf \cdot m $$(72.3{\sim}90.4\ \text{lbf}\cdot\text{ft})$$




GROUP 9 BOOM, ARM, BUCKET AND DOZER CYLINDERS


1. REMOVAL AND INSTALL


1) BUCKET CYLINDER

(1) Removal


- Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- Mean of the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ♠ Escaping fluid under pressure can penetrate the skin causing serious injury.
- Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Set block between bucket cylinder and arm.
- ② Remove bolt (2), nut (3) and pull out pin (1).
- Tie the rod with wire to prevent it from coming out.
 - \cdot Tightening torque (2) : 29.7 \pm 4.5 kgf \cdot m (215 \pm 32.5 lbf \cdot ft)








③ Disconnect bucket cylinder hoses (4) and put plugs (5) on cylinder pipe.



- ④ Sling bucket cylinder assembly (8) and remove bolt (6) then pull out pin (5).
 - \cdot Tightening torque (6) : 12.8 \pm 3.0 kgf \cdot m (92.6 \pm 21.7 lbf \cdot ft)
- ⑤ Remove bucket cylinder assembly (8).
 - · Weight: 96 kg (212 lb)



(2) Install


- ① Carry out installation in the reverse order to removal.
- ♠ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- * Bleed the air from the bucket cylinder.
- Confirm the hydraulic oil level and check
 the hydraulic oil leak or not.

2) ARM CYLINDER


(1) Removal

- Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- Mean of the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ♠ Escaping fluid under pressure can penetrate the skin causing serious injury. Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Set block between arm cylinder and boom.







- ② Remove bolt (2) and pull out pin (1).
- Tie the rod with wire to prevent it from coming out.
 - \cdot Tightening torque (2) : 12.8 \pm 3.0 kgf \cdot m (92.6 \pm 21.7 lbf \cdot ft)



- ④ Disconnect arm cylinder hoses (4) and put plugs on cylinder pipe.
- 5 Disconnect greasing pipings (6).



- 6 Sling arm cylinder assembly (8) and remove bolt (7) then pull out pin (6).
 - \cdot Tightening torque (7) : 12.8 \pm 3.0 kgf \cdot m (92.6 \pm 21.7 lbf \cdot ft)
- 7 Remove arm cylinder assembly (8).
 - · Weight: 118 kg (260 lb)



(2) Install

- ① Carry out installation in the reverse order to removal.
- ♠ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- Bleed the air from the arm cylinder.
- Confirm the hydraulic oil level and check the hydraulic oil leak or not.

3) BOOM CYLINDER


(1) Removal


- Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- Mean of the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- Loosen the breather slowly to release the pressure inside the hydraulic tank.


▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

- Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Disconnect greasing hoses (1).
- ② Sling boom cylinder assembly.
- ③ Remove bolt (4), stopper (5) and pull out pin (2).
 - \cdot Tightening torque (4) : 29.7 \pm 4.5 kgf \cdot m (215 \pm 32.5 lbf \cdot ft)
- Tie the rod with wire to prevent it from coming out.
- ④ Lower the boom cylinder assembly (6) on a stand.











⑤ Disconnect boom cylinder hoses (7) and put plugs on cylinder pipe.



- 6 Remove bolt (9) and pull out pin (8).
 - \cdot Tightening torque (9) : 29.7 \pm 4.5 kgf \cdot m (215 \pm 32.5 lbf \cdot ft)
- 7 Remove boom cylinder assembly (6).
 - · Weight: 98 kg (216 lb)




(2) Install

- ① Carry out installation in the reverse order to removal.
- ♠ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- Bleed the air from the boom cylinder.
- * Conformed the hydraulic oil level and check the hydraulic oil leak or not.


2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE

(1) Bucket cylinder




Internal detail




130ZF8CY01

1	Tube assembly	15	O-ring	29	O-ring
2	Pin bushing	16	Cushion ring	30	Pipe assembly
3	Rod assembly	17	Piston	31	Spring washer
4	Pin bushing	18	Piston seal	32	Hexagon socket bolt
5	Rod cover	19	Wear ring	33	O-ring
6	Rod bushing	20	Dust ring	34	Pipe assembly
7	Retaining ring	21	O-ring	35	Spring washer
8	Buffer seal	22	Back up ring	36	Hexagon socket bolt
9	U-packing	23	Set screw	37	Clamp
10	Back up ring	24	Hexagon socket bolt	38	Spring washer
11	Dust wiper	25	Pipe band assembly	39	Hexagon bolt
12	Retaining ring	26	Pipe band	40	Pin wiper
13	O-ring	27	Spring washer	41	Grease nipple
14	Back up ring	28	Hexagon bolt	42	O-ring

(2) Arm cylinder







130ZF8CY02

1	Tube assembly	16	Cushion ring	31	O-ring
2	Pin bushing	17	Piston	32	Plug
3	Rod assembly	18	Piston seal	33	Pipe band assembly
4	Pin bushing	19	Wear ring	34	Pipe band
5	Rod cover	20	Dust ring	35	Spring washer
6	Rod bushing	21	O-ring	36	Hexagon bolt
7	Retaining ring	22	Back up ring	37	Pipe assembly
8	Buffer seal	23	Piston nut	38	O-ring
9	U-packing	24	Set screw	39	Spring washer
10	Back up ring	25	Cushion plunger	40	Hexagon socket bolt
11	Dust wiper	26	Stop ring	41	Clamp
12	Retaining ring	27	Hexagon socket bolt	42	Spring washer
13	O-ring	28	Check	43	Hexagon bolt
14	Back up ring	29	Spring	44	Pin wiper
15	O-ring	30	Bracket	45	O-ring

(3) Boom cylinder



Internal detail




130ZF8CY03

1	Tube assembly	16	Cushion ring	31	O-ring
2	Pin bushing	17	Piston	32	Spring washer
3	Rod assembly	18	Piston seal	33	Hexagon socket bolt
4	Pin bushing	19	Wear ring	34	Pipe assembly
5	Rod cover	20	Dust ring	35	O-ring
6	Rod bushing	21	O-ring	36	Spring washer
7	Retaining ring	22	Back up ring	37	Hexagon socket bolt
8	Buffer seal	23	Piston nut	38	Hexagon nut
9	U-packing	24	Set screw	39	Clamp
10	Back up ring	25	Hexagon socket bolt	40	Spring washer
11	Dust wiper	26	Pipe band assembly	41	Hexagon bolt
12	Retaining ring	27	Pipe band	42	Pin wiper
13	O-ring	28	Spring washer	43	O-ring
14	Back up ring	29	Hexagon bolt	44	Hex plug
15	O-ring	30	Pipe assembly		


(4) Dozer cylinder

① Type 1



1	Tube assembly	10	O-ring	19	Hexagon socket head bolt
2	Rod assembly	11	Back up ring	20	Pin bushing
3	Gland	12	Piston	21	Dust seal
4	Dry bearing	13	O-ring	22	Pipe assembly
5	Rod seal	14	Back up ring	23	Double pilot check valve
6	Back up ring	15	Piston seal	24	O-ring
7	Buffer ring	16	Wear ring	25	O-ring
8	Dust wiper	17	Steel ball	26	Hexagon socket head bolt
9	Retaining ring	18	Set screw	27	Hexagon socket head bolt

② Type 2



Tube assembly 1 2 Pin bushing Rod assembly 3 Pin bushing 4 Rod cover 5 6 Rod bushing 7 Retaining ring 8 Buffer seal 9 U-packing

10 Back up ring

11 Dust wiper

- 12 Retaining ring
 13 O-ring
 14 Back up ring
 15 O-ring
 16 Piston
 17 Piston seal
 18 Wear ring
 19 Dust ring
 20 O-ring
 21 Back up ring
 22 Set screw
- 23 Hexagon socket bolt
 24 Check valve
 25 Hexagon socket bolt
 26 Pipe assembly
 27 O-ring
 28 Spring washer
 29 Hexagon socket bolt
 30 Pin wiper
 31 Grease nipple

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

Tool name	Remark			
	4			
	6 B			
Allen wrench	8			
	12			
	14			
Channer	7			
Spanner	8			
(-) Driver	Small and large sizes			
Torque wrench	Capable of tightening with the specified torques			


(2) Tightening torque

Part name			Item	Size	Torque		
	Size	kgf · m		lbf ⋅ ft			
	Bucket cylinder		22	M14	17.9±1.8	129±13.0	
	Boom cylinder		25	M14	19±1.0	137±7.2	
Socket head bolt	Arm cylinder		27	M14	19±1.0	137±7.2	
	Dozor ovlindor	Type 1	19	M16	23±2.0	166±14.5	
	Dozer cylinder	Type 2	23	M14	23.5±0.5	170±3.6	
	Bucket cylinder		25	M10	6.5±0.7	47.0±5.1	
	Boom cylinder		33, 37	M8	3.25±0.25	23.5±1.8	
	Arm cylinder		40	M10	5.75±0.25	41.6±1.8	
Pipe mounting socket head bolt		Type 1	26	M8	2.7±0.3	19.5±2.2	
Cooker Hodd bok	Dozer cylinder		27	M10	5.4±0.5	39.1±3.6	
		Type 2	25	M10	5.75±0.25	41.6±1.8	
			29	M8	3.25±0.25	23.5±1.8	
Piston nut	Boom cylinder		23	M48	130±13	940±94	
PISIOTTTUL	Arm cylinder		23	M55	130±13	940±94	
	Bucket cylinder		14	M50	125±12.5	904±90.4	
	Boom cylinder		17	M60	75±7.5	542±54.2	
Piston	Arm cylinder		17	M65	75±7.5	542±54.2	
	Dozer cylinder	Type 1	12	-	150±15	1085±108	
	Rear	r Type 2		M58	130±13	940±94	
	Bucket cylinder		21	M8	2±0.2	14.5±1.4	
	Boom cylinder		24	M8	1.5	10.8	
Set screw	Arm cylinder		24	M8	1.5	10.8	
	Dozor outlindor	Type 1	18	M8	2.7±0.3	19.5±2.2	
	Dozer cylinder	Type 2	22	M8	1.5	10.8	


3) DISASSEMBLY

(1) Remove cylinder head and piston rod


- Procedures are based on the boom cylinder.
- ① Hold the clevis section of the tube in a vise.
- We use mouth pieces so as not to damage the machined surface of the cylinder tube. Do not make use of the outside piping as a locking means.
- Pull out rod assembly (3) about 200 mm (7.1in). Because the rod assembly is rather heavy, finish extending it with air pressure after the oil draining operation.



- 3 Loosen and remove socket bolts (25) of the gland in sequence.
- Cover the extracted rod assembly (3) with rag to prevent it from being accidentally damaged during operation.




- ① Draw out cylinder head and rod assembly together from tube assembly (1).
- Since the rod assembly is heavy in this case, lift the tip of the rod assembly (3) with a crane or some means and draw it out. However, when rod assembly (3) has been drawn out to approximately two thirds of its length, lift it in its center to draw it completely.




Note that the plated surface of rod assembly (1) is to be lifted. For this reason, do not use a wire sling and others that may damage it, but use a strong cloth belt or a rope.

- ⑤ Place the removed rod assembly on a wooden V-block that is set level.
- Cover a V-block with soft rag.




(2) Remove piston and cylinder head

- ① Remove set screw (24) and lock nut (23).
- Since set screw (24) and piston nut (23) is tightened to a high torque, use a hydraulic and power wrench that utilizers a hydraulic cylinder, to remove the lock set screw (24) and piston nut (23).
- ② Remove piston assembly (17), back up ring (22), and O-ring (21).




- 3 Remove the cylinder head assembly from rod assembly (3).
- If it is too heavy to move, move it by striking the flanged part of cylinder head with a plastic hammer.
- Pull it straight with cylinder head assembly lifted with a crane.
 Exercise care so as not to damage the lip of pin bushing (4) and packing (8,9,10,11,12) by the threads of rod assembly (3).




(3) Disassemble the piston assembly

- ① Remove wear ring (19).
- ② Remove dust ring (20) and piston seal (18).
- Exercise care in this operation not to damage the grooves.



(4) Disassemble cylinder head assembly


- ① Remove back up ring (14) and O-ring (13) and O-ring (15).
- ② Remove snap ring (12), dust wiper (11).
- ③ Remove back up ring (10), U-packing (9) and buffer seal (8).
- Exercise care in this operation not to damage the grooves.
- Do not remove seal and ring, if does not damaged.
- Do not remove bushing (6).




3) ASSEMBLY

(1) Assemble cylinder head assembly


- * Check for scratches or rough surfaces if found smooth with an oil stone.
- ① Coat the inner face of rod cover (5) with hydraulic oil.




- ② Coat dust wiper (11) with grease and fit dust wiper (11) to the bottom of the hole of dust seal.
 - At this time, press a pad metal to the metal ring of dust seal.
- ③ Fit snap ring (12) to the stop face.




- ④ Fit back up ring (10), U-packing (9) and buffer seal (8) to corresponding grooves, in that order.
- * Coat each packing with hydraulic oil before fitting it.
- Insert the backup ring until one side of it is inserted into groove.



- W U-packing (9) has its own fitting direction.
 Therefore, confirm it before fitting them.
- Fitting U-packing (9) upside down may damage its lip. Therefore check the correct direction that is shown in fig.




- ⑤ Fit back up ring (14) to rod cover (5).
- Put the backup ring in the warm water of 30~50°C.
- ⑥ Fit O-ring (13) and O-ring (15) to rod cover (5).




(2) Assemble piston assembly


- * Check for scratches or rough surfaces.
 If found smooth with an oil stone.
- ① Coat the outer face of piston (17) with hydraulic oil.



- ② Fit piston seal (18) to piston.
- Put the piston seal in the warm water of 60~100°C for more than 5 minutes.
- After assembling the piston seal, press its outer diameter to fit in.




③ Fit wear ring (19) and dust ring (20) to piston (17).




(3) Install piston and cylinder head

- ① Fix the rod assembly to the work bench.
- ② Apply hydraulic oil to the outer surface of rod assembly (3), the inner surface of piston and cylinder head.
- ③ Insert cylinder head assembly to rod assembly.




- ④ Insert cushion ring (16) to rod assembly.
- Note that cushion ring (16) has a direction in which it should be fitted.



⑤ Fit piston assembly to rod assembly.


· Tightening torque:

Item		kgf · m	lbf · ft
14	Bucket	125 \pm 12.5	904±90.4
17	Boom	75±7.5	542±54.2
	Arm	75±7.5	542±54.2




- ⑥ Boom and arm cylinder Fit piston nut (23) and tighten the set screw (24).
 - · Tightening torque

Item		kgf · m	lbf · ft
23	Boom	130±13	940±94
	Arm		
24		1.5	10.8





- ⑦ Bucket cylinder Tighten the set screw (21).
 - Tightening torque1.5 kgf⋅m (10.8 lbf⋅ft)



(3) Overall assemble

- ① Place a V-block on a rigid work bench. Mount the tube assembly (1) on it and fix the assembly by passing a bar through the clevis pin hole to lock the assembly.
- ② Insert the rod assembly in to the tube assembly, while lifting and moving the rod assembly with a crane.
- Be careful not to damage piston seal by thread of tube assembly.
- ③ Match the bolt holes in the cylinder head flange to the tapped holes in the tube assembly and tighten socket bolts to a specified torque.
- Refer to the table of tightening torque.





GROUP 10 UNDERCARRIAGE


1. TRACK LINK


1) REMOVAL

- (1) Move track link until master pin is over front idler in the position put wooden block as shown.
- (2) Loosen tension of the track link.
- If track tension is not relieved when the grease valve is loosened, move the machine backwards and forwards.
- We Unscrew the grease nipple after release the tension by pushing the poppet only when necessarily required. Grease leaking hole is not existing. So, while unscrew the grease nipple, grease is not leaking until the grease nipple is completely coming out. If the tension is not released in advance, the grease nipple can be suddenly popped out by
- (3) Push out master pin by using a suitable tool

pressurized grease.


- (4) Move the machine slowly in reverse, and lay out track link assembly (1).
- ¾ Jack up the machine and put wooden block under the machine.
- * Don't get close to the sprocket side as the track shoe plate may fall down on your feet.





2) INSTALL


- (1) Carry out installation in the reverse order to removal.
- Adjust the tension of the track link.




2. UPPER ROLLER

1) REMOVAL


(1) Loosen tension of the track link.



(2) Jack up the track link height enough to permit upper roller removal.



- (3) Loosen the lock nut (1).
 - \cdot Tightening torque : 29.7 \pm 4.5 kgf·m (215 \pm 32.5 lbf \cdot ft)
- (4) Open bracket(2) with a screwdriver, push out from inside, and remove upper roller assembly.
 - · Weight: 12 kg (26 lb)




2) INSTALL

(1) Carry out installation in the reverse order to removal.


3. LOWER ROLLER

1) REMOVAL

(1) Loosen tension of the track link.




- (2) Using the work equipment, push up track frame on side which is to be removed.
- After jack up the machine, set a block under the unit.



- (3) Remove the mounting bolt (1) and draw out the lower roller (2).
 - · Weight: 25 kg (54 lb)
 - · Tightening torque (1) : 29.7 \pm 4.5 kgf·m

 $(215\pm32.5 \, lbf \cdot ft)$




2) INSTALL

(1) Carry out installation in the reverse order to removal.

4. IDLER AND RECOIL SPRING


1) REMOVAL

(1) Remove the track link.
For detail, see removal of track link.




(2) Sling the recoil spring (1) and pull out idler and recoil spring assembly from track frame, using a pry.

· Weight: 215 kg (474 lb)




(3) Remove the bolts (2), washers (3) and separate ilder from recoil spring.

 \cdot Tightening torque : 29.7±3.0 kgf \cdot m (215±21.7 lbf \cdot ft)




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- Make sure that the boss on the end face of the recoil cylinder rod is in the hole of the track frame.



3) DISASSEMBLY AND ASSEMBLY OF IDLER

(1) Structure




- 1 Shell
- 2 Shaft
- 3 Seal assembly
- 4 Bushing
- 5 Bracket
- 6 O-ring


- 7 Spring pin
- 8 Plug

(2) Disassembly


- (1) Remove plug and drain oil.
- ② Draw out the spring pin (7), using a press.



- ③ Pull out the shaft (2) with a press.
- ④ Remove seal (3) from idler (1) and bracket (5).
- 5 Remove O-ring (6) from shaft.




⑤ Remove the bushing (4) from idler, using a special tool. Only remove bushing if replacement is necessity.




(3) Assembly


- Before assembly, clean the parts.
- Coat the sliding surfaces of all parts with oil.
- Cool up bushing (4) fully by some dry ice and press it into shell (1).
 Do not press it at the normal temperature, or not knock in with a hammer even after the cooling.




- ② Coat O-ring (6) with grease thinly, and install it to shaft (2).
- ③ Insert shaft (2) into bracket (5) and drive in the spring pin (7).




④ Install seal (3) to shell (1) and bracket (5).




5 Install shaft (2) to shell (1).




 $\ensuremath{\textcircled{6}}$ Install bracket (5) attached with seal (3).




Through the Spring pin (7) with a hammer.





4) DISASSEMBLY AND ASSEMBLY OF RECOIL SPRING

(1) Structure



130ZF8UC30


- 1 Body
- 2 Tie bar
- 3 Spring
- 4 Bracket
- 5 Lock nut

- 6 Lock plate
- 7 Bolt
- 8 Spring washer
- 9 Rod seal
- 10 Back up ring


- 11 Dust seal
- 12 Adjust rod
- 13 Grease valve
- 14 Spring pin

(2) Disassembly


- ① Apply pressure on spring (3) with a press.
- The spring is under a large installed load. This is dangerous, so be sure to set properly.
 - · Spring set load: 8497 kg (18733 lb)
- ② Remove bolt (7), spring washer (8) and lock plate (6).
- ③ Remove lock nut (5).
 Take enough notice so that the press which pushes down the spring, should not be slipped out in its operation.
- 4 Lighten the press load slowly and remove bracket (4) and spring (3).



- ⑤ Remove adjust rod (12) from body (1).
- ⑥ Remove grease valve (13) from adjust rod (12).




Remove rod seal (9), back up ring (10) and dust seal (11).




(3) Assembly

Install dust seal (11), back up ring (10) and rod seal (9) to body (1).


When installing dust seal (11) and rod seal (9), take full care so as not to damage the lip.



- ② Pour grease into body (1), then push in adjust rod (12) by hand.
 After take grease out of grease valve mounting hole, let air out.
- If air letting is not sufficient, it may be difficult to adjust the tension of crawler.
- ③ Fit grease valve (13) to rod (12). • Tightening torque : 13.0 ± 0.5 kgf • m (94.0 ±3.6 lbf • ft)
- 1 12 130ZF8UC34
- Install spring (3) and bracket (4) to body (1).
- ⑤ Apply pressure to spring (3) with a press and tighten lock nut (5).
- * Apply sealant before assembling.
- ** During the operation, pay attention specially to prevent the press from slipping out.




- ⑥ Lighten the press load and confirm the set length of spring (3).
- ⑦ After the setting of spring (3), install lock plate (6), spring washer (8) and bolt (7).



GROUP 11 WORK EQUIPMENT

1. STRUCTURE




130ZF8DA44

2. REMOVAL AND INSTALL


1) BUCKET ASSEMBLY

(1) Removal


① Lower the work equipment completely to ground with back of bucket facing down.



- ② Remove nut (1), bolt (2) and draw out the pin (B).
 - \cdot Tightening torque (2) : 29.7 \pm 4.5 kgf \cdot m (215 \pm 32.5 lbf \cdot ft)




- ③ Remove nut (3), bolt (4) and draw out the pin (A) then remove the bucket assembly.
 - · Weight (0.45 m³): 430 kg (948 lb)
 - \cdot Tightening torque (3) : 29.7 \pm 4.5 kgf \cdot m (215 \pm 32.5 lbf \cdot ft)



(2) Install


- ① Carry out installation in the reverse order to removal.
- ♠ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- Adjust the bucket clearance.
 For detail, see operation manual.





2) ARM ASSEMBLY

(1) Removal

- * Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ♠ Escaping fluid under pressure can penetrated the skin causing serious injury.
- Remove bucket assembly.
 For details, see removal of bucket assembly.
- ② Disconnect bucket cylinder hose (1).
- ▲ Fit blind plugs (5) in the piping at the chassis end securely to prevent oil from spurting out when the engine is started.
- ③ Sling bucket cylinder assembly, remove spring, pin stopper and pull out pin.
- Tie the rod with wire to prevent it from coming out.
- ④ For details, see removal of bucket cylinder assembly.
 Place a wooden block under the cylinder
 - and bring the cylinder down to it.
- ⑤ Remove bolt (2), plate (3) and pull out the pin (4) then remove the arm assembly.
 - · Weight: 364 kg (803 lb)
 - \cdot Tightening torque (2) : 12.8 \pm 3.0 kgf \cdot m (92.6 \pm 21.7 lbf \cdot ft)
- When lifting the arm assembly, always lift the center of gravity.







(2) Install

- ① Carry out installation in the reverse order to removal.
- ♠ When lifting the arm assembly, always lift the center of gravity.
- Bleed the air from the cylinder.

3) BOOM ASSEMBLY


(1) Removal


- Remove arm and bucket assembly.
 For details, see removal of arm and bucket assembly.
- ② Remove boom cylinder assembly from boom.

For details, see removal of boom cylinder assembly.




- ④ Disconnect bucket cylinder hose (2) and arm cylinder hose (1).
- When the hose are disconnected, oil may spurt out.
- 5 Sling boom assembly (3).





- ⑥ Remove bolt (4), plate (5) and pull out the pin (6) then remove boom assembly.
 - · Weight (4.3 m): 702 kg (1548 lb)
 - \cdot Tightening torque (2) : 29.7 \pm 4.5 kgf \cdot m (215 \pm 32.5 lbf \cdot ft)
- When lifting the boom assembly always lift the center of gravity.



(2) Install

- ① Carry out installation in the reverse order to removal.
- ♠ When lifting the arm assembly, always lift the center of gravity.
- Bleed the air from the cylinder.

