

# SECTION 7 MAINTENANCE STANDARD

|         |                                    |      |
|---------|------------------------------------|------|
| Group 1 | Operational Performance Test ..... | 7-1  |
| Group 2 | Major Components .....             | 7-21 |
| Group 3 | Track and Work Equipment .....     | 7-30 |

# SECTION 7 MAINTENANCE STANDARD

## GROUP 1 OPERATIONAL PERFORMANCE TEST

### 1. PURPOSE

Performance tests are used to check:

#### 1) OPERATIONAL PERFORMANCE OF A NEW MACHINE

Whenever a new machine is delivered in parts and reassembled at a customer's site, it must be tested to confirm that the operational performance of the machine meets HD Hyundai Construction Equipment spec.


#### 2) OPERATIONAL PERFORMANCE OF A WORKING MACHINE

With the passage of time, the machine's operational performance deteriorates, so that the machine needs to be serviced periodically to restore it to its original performance level.

Before servicing the machine, conduct performance tests to check the extent of deterioration, and to decide what kind of service needs to be done (by referring to the "Service Limits" in this manual).

#### 3) OPERATIONAL PERFORMANCE OF A REPAIRED MACHINE

After the machine is repaired or serviced, it must be tested to confirm that its operational performance was restored by the repair and/or service work done.




140LC7MS01

## 2. TERMINOLOGY

### 1) STANDARD


Specifications applied to the brand-new machine, components and parts.



140LC7MS02

### 2) SERVICE LIMIT

The lowest acceptable performance level. When the performance level of the machine falls below this level, the machine must be removed from work and repaired. Necessary parts and components must be replaced.



140LC7MS03

### 3. OPERATION FOR PERFORMANCE TESTS

- 1) Observe the following rules in order to carry out performance tests accurately and safely.

#### (1) The machine

Repair any defects and damage found, such as oil or water leaks, loose bolts, cracks and so on, before starting to test.

#### (2) Test area


- ① Select a hard, flat surface.
- ② Secure enough space to allow the machine to run straight more than 20m, and to make a full swing with the front attachment extended.
- ③ If required, rope off the test area and provide signboards to keep unauthorized personnel away.

#### (3) Precautions

- ① Before starting to test, agree upon the signals to be employed for communication among coworkers. Once the test is started, be sure to communicate with each other using these signals, and to follow them without fail.
- ② Operate the machine carefully and always give first priority to safety.
- ③ While testing, always take care to avoid accidents due to landslides or contact with high voltage power lines. Always confirm that there is sufficient space for full swings.
- ④ Avoid polluting the machine and the ground with leaking oil. Use oil pans to catch escaping oil. Pay special attention to this when removing hydraulic pipings.

#### (4) Make precise measurements

- ① Accurately calibrate test instruments in advance to obtain correct data.
- ② Carry out tests under the exact test conditions prescribed for each test item.
- ③ Repeat the same test and confirm that the test data obtained can be procured repeatedly. Use mean values of measurements if necessary.



(290-7TIER) 7-3

## 2) ENGINE SPEED


- (1) Measure the engine speed at each power mode
- ※ The engine speed at each power mode must meet standard RPM; if not, all other operational performance data will be unreliable. It is essential to perform this test first.

### (2) Preparation

- ① Warm up the machine, until the engine coolant temperature reaches 50°C or more, and the hydraulic oil is 50±5°C.
- ② Set the multimodal dial at 10 (Max) position.
- ③ Measure the engine RPM.

### (3) Measurement

- ① Start the engine. The engine will run at start idle speed. Measure engine speed with a engine rpm display.
- ② Measure and record the engine speed at each mode (P, S, E).
- ③ Select the P-mode.
- ④ Lightly operate the bucket control lever a few times, then return the control lever to neutral; The engine will automatically enter the auto-idle speed after 4 seconds.
- ⑤ Measure and record the auto deceleration speed.



### (4) Evaluation

The measured speeds should meet the following specifications.

Unit : rpm

| Model   | Engine speed    | Standard | Remarks |
|---------|-----------------|----------|---------|
| HX140 L | Start idle      | 1000±100 |         |
|         | P mode          | 1850±50  |         |
|         | S mode          | 1750±50  |         |
|         | E mode          | 1650±50  |         |
|         | Auto decel      | 1100±100 |         |
|         | One touch decel | 1000±100 |         |


Condition : Set the multimodal dial at 10 (Max) position.

### 3) TRAVEL SPEED

- (1) Measure the time required for the excavator to travel a 20 m test track.

#### (2) Preparation


- ① Adjust the tension of both tracks to be equal.
- ② Prepare a flat and solid test track 20m in length, with extra length of 3 to 5 m on both ends for machine acceleration and deceleration.
- ③ Hold the bucket 0.3 to 0.5 m above the ground with the arm and bucket rolled in.
- ④ Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .



260A7MS02

#### (3) Measurement

- ① Measure both the low and high speeds of the machine.
- ② Before starting either the low or high speed tests, adjust the travel mode switch to the speed to be tested, then select the following switch positions.
  - Power mode switch : P mode
- ③ Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- ④ Measure the time required to travel 20 m.
- ⑤ After measuring the forward travel speed, turn the upperstructure 180° and measure the reverse travel speed.
- ⑥ Repeat steps ④ and ⑤ three times in each direction and calculate the average values.



260A7MS03

#### (4) Evaluation

The average measured time should meet the following specifications.

Unit : Seconds / 20 m


| Model   | Travel speed | Standard       | Maximum allowable | Remarks |
|---------|--------------|----------------|-------------------|---------|
| HX140 L | 1 Speed      | $21.8 \pm 2.0$ | 27.3              |         |
|         | 2 Speed      | $12.9 \pm 1.0$ | 16.1              |         |

#### 4) TRACK REVOLUTION SPEED

- (1) Measure the track revolution cycle time with the track raised off ground.

##### (2) Preparation

- ① Adjust the tension of both side tracks to be equal.
- ② On the track to be measured, mark one shoe with chalk.
- ③ Swing the upperstructure 90° and lower the bucket to raise the track off ground. Keep the boom-arm angle between 90 to 110° as shown. Place blocks under machine frame.
- ④ Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .



14097MS06

##### (3) Measurement

- ① Select the following switch positions.
  - Travel mode switch : 1 or 2 speed
  - Power mode switch : P mode
  - Auto idle switch : OFF
- ② Operate the travel control lever of the raised track in full forward and reverse.
- ③ Rotate 1 turn, then measure time taken for next 3 revolutions.
- ④ Raise the other side of machine and repeat the procedure.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.

##### (4) Evaluation

The revolution cycle time of each track should meet the following specifications.

Unit : Seconds / 3 revolutions


| Model   | Travel speed | Standard       | Maximum allowable |
|---------|--------------|----------------|-------------------|
| HX140 L | 1 Speed      | $25.1 \pm 2.0$ | 31.4              |
|         | 2 Speed      | $14.7 \pm 2.0$ | 18.4              |

## 5) TRAVEL DEVIATION

- (1) Measure the deviation by the tracks from a 20m straight line.

### (2) Preparation


- ① Adjust the tension of both tracks to be equal.
- ② Provide a flat, solid test yard 20 m in length, with extra length of 3 to 5 m on both ends for machine acceleration and deceleration.
- ③ Hold the bucket 0.3 to 0.5 m above the ground with the arm and bucket rolled in.
- ④ Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .



260A7MS02

### (3) Measurement

- ① Measure the amount of mistracking at high and low travel speeds.
- ② Before beginning each test, select the following switch positions.
  - Power mode switch : P mode
- ③ Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- ④ Measure the distance between a straight 20 m line and the track made by the machine. (Dimension a)
- ⑤ After measuring the tracking in forward travel, turn the upperstructure 180° and measure that in reverse travel.
- ⑥ Repeat steps ④ and ⑤ three times and calculate the average values.



(210-7) 7-7(2)

### (4) Evaluation

Mistrack should be within the following specifications.

Unit : mm / 20 m


| Model   | Standard  | Maximum allowable | Remarks |
|---------|-----------|-------------------|---------|
| HX140 L | 200 below | 240               |         |

## 6) SWING SPEED

- (1) Measure the time required to swing three complete turns.

### (2) Preparation

- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- ③ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- ④ Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .



14097MS07

### (3) Measurement

- ① Select the following switch positions.
  - Power mode switch : P mode
- ② Operate swing control lever fully.
- ③ Swing 1 turn and measure time taken to swing next 3 revolutions.
- ④ Repeat steps ② and ③ three times and calculate the average values.

### (4) Evaluation

The time required for 3 swings should meet the following specifications.

Unit : Seconds / 3 revolutions


| Model   | Power mode switch | Standard       | Maximum allowable |
|---------|-------------------|----------------|-------------------|
| HX140 L | P mode            | $15.6 \pm 1.5$ | 19.5              |

## 7) SWING FUNCTION DRIFT CHECK

- (1) Measure the swing drift on the bearing outer circumference when stopping after a 360° full speed swing.

### (2) Preparation


- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- ③ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- ④ Make two chalk marks: one on the swing bearing and one directly below it on the track frame.
- ⑤ Swing the upperstructure 360°.
- ⑥ Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .



14097MS07

### (3) Measurement

- ① Conduct this test in the M mode.
- ② Select the following switch positions.
  - Power mode switch : P mode
- ③ Operate the swing control lever fully and return it to the neutral position when the mark on the upperstructure aligns with that on track frame after swinging 360°.
- ④ Measure the distance between the two marks.
- ⑤ Align the marks again, swing 360° , then test the opposite direction.
- ⑥ Repeat steps ④ and ⑤ three times each and calculate the average values.



21077MS08

### (4) Evaluation

The measured drift angle should be within the following specifications.

Unit : Degree


| Model   | Power mode switch | Standard | Maximum allowable | Remarks |
|---------|-------------------|----------|-------------------|---------|
| HX140 L | P mode            | 90 below | 157.5             |         |

## 8) SWING BEARING PLAY

- (1) Measure the swing bearing play using a dial gauge to check the wear of bearing races and balls.

### (2) Preparation

- ① Check swing bearing mounting cap screws for loosening.
- ② Check the lubrication of the swing bearing. Confirm that bearing rotation is smooth and without noise.
- ③ Install a dial gauge on the track frame as shown, using a magnetic base.
- ④ Position the upperstructure so that the boom aligns with the tracks facing towards the front idlers.
- ⑤ Position the dial gauge so that its needle point comes into contact with the bottom face of the bearing outer race.
- ⑥ Bucket should be empty.




(210-7) 7-10(1)

### (3) Measurement


- ① With the arm rolled out and bucket rolled in, hold the bottom face of the bucket to the same height of the boom foot pin. Record the dial gauge reading (h1).
- ② Lower the bucket to the ground and use it to raise the front idler 50cm. Record the dial gauge reading (h2).
- ③ Calculate bearing play (H) from this data (h1 and h2) as follows.  

$$H = h2 - h1$$

Measurement : (h1)



Measurement : (h2)



14097MS09

### (4) Evaluation

The measured drift should be within the following specifications.

Unit : mm

| Model   | Standard  | Maximum allowable | Remarks |
|---------|-----------|-------------------|---------|
| HX140 L | 0.5 ~ 1.5 | 3.0               |         |

## 9) HYDRAULIC CYLINDER CYCLE TIME

- (1) Measure the cycle time of the boom, standard arm, and standard bucket cylinders.

### (2) Preparation

- ① To measure the cycle time of the boom cylinders:

With the arm rolled out and the empty bucket rolled out, lower the bucket to the ground, as shown.

- ② To measure the cycle time of the arm cylinder.

With the empty bucket rolled in, position the arm so that it is vertical to the ground. Lower the boom until the bucket is 0.5 m above the ground.

- ③ To measure the cycle time of the bucket cylinder.

The empty bucket should be positioned at midstroke between roll-in and roll-out, so that the sideplate edges are vertical to the ground.

- ④ Keep the hydraulic oil temperature at  $50 \pm 5^\circ\text{C}$ .

### (3) Measurement

- ① Select the following switch positions.

- Power mode switch : P mode

- ② To measure cylinder cycle times.


- Boom cylinders.

Measure the time it takes to raise the boom, and the time it takes to lower the boom. To do so, position the boom at one stroke end then move the control lever to the other stroke end as quickly as possible.


- Arm cylinder.

Measure the time it takes to roll in the arm, and the time it takes to roll out the arm. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.


Boom cylinder



Arm cylinder



Bucket cylinder



14097MS10

- Bucket cylinders

Measure the time it takes to roll in the bucket, and the time it takes to roll out the bucket. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.

- Repeat each measurement 3 times and calculate the average values.

#### (4) Evaluation

The average measured time should meet the following specifications.

Unit : Seconds


| Model   | Function   |           | Standard      | Maximum allowable | Remarks |
|---------|------------|-----------|---------------|-------------------|---------|
| HX140 L | Boom raise |           | $3.4 \pm 0.4$ | 4.4               |         |
|         | Boom lower |           | $2.6 \pm 0.4$ | 3.6               |         |
|         | Arm in     | Regen ON  | $2.6 \pm 0.4$ | 3.6               |         |
|         |            | Regen OFF | $3.1 \pm 0.4$ | 4.0               |         |
|         | Arm out    |           | $2.8 \pm 0.3$ | 3.6               |         |
|         | Bucket in  |           | $3.5 \pm 0.4$ | 4.6               |         |
|         | Bucket out |           | $2.2 \pm 0.3$ | 2.9               |         |

## 10) DIG FUNCTION DRIFT CHECK

- (1) Measure dig function drift, which can be caused by oil leakage in the control valve and boom, standard arm, and standard bucket cylinders, with the loaded bucket.  
When testing the dig function drift just after cylinder replacement, slowly operate each cylinder to its stroke end to purge air.

### (2) Preparation

- ① Load bucket fully. Instead of loading the bucket, weight(W) of the following specification can be used.  
 $W = M^3 \times 1.5$   
 Where :  
 $M^3$  = Bucket heaped capacity ( $m^3$ )  
 $1.5$  = Soil specific gravity
- ② Position the arm cylinder with the rod 20 to 30mm extended from the fully retracted position.
- ③ Position the bucket cylinder with the rod 20 to 30mm retracted from the fully extended position.
- ④ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin.
- ⑤ Keep the hydraulic oil temperature at  $50 \pm 5^\circ C$ .



14097MS11

### (3) Measurement

- ① Stop the engine.
- ② Five minutes after the engine has been stopped, measure the changes in the positions of the boom, arm and bucket cylinders.
- ③ Repeat step ② three times and calculate the average values.

- (4) The measured drift should be within the following specifications.

Unit : mm / 5min

| Model   | Drift to be measured | Standard | Maximum allowable | Remarks |
|---------|----------------------|----------|-------------------|---------|
| HX140 L | Boom cylinder        | 10 below | 20                |         |
|         | Arm cylinder         | 10 below | 20                |         |
|         | Bucket cylinder      | 40 below | 50                |         |

## 11) CONTROL LEVER OPERATING FORCE

- (1) Use a spring scale to measure the maximum resistance of each control lever at the middle of the grip.

### (2) Preparation

- ① Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .

### (3) Measurement

- ① Start the engine.
- ② Select the following switch positions.
- Power mode switch: P mode
- ③ Operate each boom, arm, bucket and swing lever at full stroke and measure the maximum operating force for each.
- ④ Lower the bucket to the ground to raise one track off the ground. Operate the travel lever at full stroke and measure the maximum operating force required. When finished, lower the track and then jack-up the other track.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.

### (4) Evaluation

The measured operating force should be within the following specifications.

Unit : kgf

| Model   | Kind of lever | Standard     | Maximum allowable | Remarks |
|---------|---------------|--------------|-------------------|---------|
| HX140 L | Boom lever    | 1.3 or below | 1.7               |         |
|         | Arm lever     | 1.3 or below | 1.7               |         |
|         | Bucket lever  | 1.3 or below | 1.7               |         |
|         | Swing lever   | 1.3 or below | 1.7               |         |
|         | Travel lever  | 2.1 or below | 3.15              |         |

## 12) CONTROL LEVER STROKE

(1) Measure each lever stroke at the lever top using a ruler.

※ When the lever has play, take a half of this value and add it to the measured stroke.

### (2) Preparation

Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .

### (3) Measurement

- ① Stop the engine.
- ② Measure each lever stroke at the lever top from neutral to the stroke end using a ruler.
- ③ Repeat step ② three times and calculate the average values.

### (4) Evaluation

The measured drift should be within the following specifications.

Unit : mm

| Model   | Kind of lever | Standard     | Maximum allowable | Remarks |
|---------|---------------|--------------|-------------------|---------|
| HX140 L | Boom lever    | $90 \pm 10$  | 115               |         |
|         | Arm lever     | $90 \pm 10$  | 115               |         |
|         | Bucket lever  | $90 \pm 10$  | 115               |         |
|         | Swing lever   | $90 \pm 10$  | 115               |         |
|         | Travel lever  | $142 \pm 10$ | 178               |         |


### 13) PILOT PRIMARY PRESSURE

#### (1) Preparation

- ① Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .

#### (2) Measurement

- ① Select the following switch positions.
  - Power mode switch : P mode
  - Auto decel switch : OFF
- ② Measure the primary pilot pressure by the monitoring menu of the cluster.



#### (3) Evaluation

140L7MS02

The average measured pressure should meet the following specifications:


Unit :  $\text{kgf} / \text{cm}^2$

| Model   | Engine speed | Standard    | Allowable limits | Remarks |
|---------|--------------|-------------|------------------|---------|
| HX140 L | P mode       | $40^{+2}_0$ | -                |         |

**14) FOR TRAVEL SPEED SELECTING PRESSURE:**

### (1) Preparation

- ① Stop the engine.
- ② Loosen the cap and relieve the pressure in the tank by pushing the top of the air breather.
- ③ To measure the speed selecting pressure: Install a connector and pressure gauge assembly to turning joint P port as shown.
- ④ Start the engine and check for on leakage from the adapter.
- ⑤ Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .



21077MS13

## (2) Measurement

- ① Select the following switch positions.  
Travel mode switch : 1 speed  
  2 speed  
· Mode selector         : P mode
- ② Measure the travel speed selecting pressure in the Hi or Lo mode.
- ③ Repeat step ② three times and calculate the average values.

### (3) Evaluation

The average measured pressure should be within the following specifications.


Unit : kgf / cm<sup>2</sup>

| Model   | Travel speed mode | Standard | Maximum allowable | Remarks |
|---------|-------------------|----------|-------------------|---------|
| HX140 L | 1 Speed           | 0        | -                 |         |
|         | 2 Speed           | 40±5     | -                 |         |

## 15) SWING PARKING BRAKE RELEASING PILOT PRESSURE

### (1) Preparation

- ① Stop the engine.
- ② Loosen the cap and relieve the pressure in the tank by pushing the top of the air breather.
- ③ The pressure release L wrench to bleed air.
- ④ Install a connector and pressure gauge assembly to swing motor SH port, as shown.
- ⑤ Start the engine and check for oil leakage from the adapter.
- ⑥ Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .



140WF7MS14

### (2) Measurement

- ① Select the following switch positions.
  - Power mode switch : P mode
- ② Operate the swing function or arm roll in function and measure the swing brake control pressure with the brake disengaged. Release the control lever to return to neutral and measure the control pressure when the brake is applied.
- ③ Repeat step ② three times and calculate the average values.

### (3) Evaluation

The average measured pressure should be within the following specifications.

Unit : kgf / cm<sup>2</sup>

| Model   | Description      | Standard | Allowable limits | Remarks |
|---------|------------------|----------|------------------|---------|
| HX140 L | Brake disengaged | 40       | Over 9           |         |
|         | Brake applied    | 0        | -                |         |


## 16) MAIN PUMP DELIVERY PRESSURE

### (1) Preparation

- ① Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .

### (2) Measurement

- ① Select the following switch positions.
  - Power mode switch : P mode
- ② Measure the main pump delivery pressure in the P mode (high idle).



140L7MS03

### (3) Evaluation

The average measured pressure should meet the following specifications.

Unit :  $\text{kgf} / \text{cm}^2$

| Model   | Engine speed | Standard    | Allowable limits | Remarks |
|---------|--------------|-------------|------------------|---------|
| HX140 L | High idle    | $40^{+2}_0$ | -                |         |


## 17) SYSTEM PRESSURE REGULATOR RELIEF SETTING

### (1) Preparation

- ① Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .

### (2) Measurement

- ① Select the following switch positions.  
· Power mode switch : P mode
- ② Slowly operate each control lever of boom, arm and bucket functions at full stroke over relief and measure the pressure.
- ③ In the swing function, place bucket against an immovable object and measure the relief pressure.
- ④ In the travel function, lock undercarriage with an immovable object and measure the relief pressure.



140L7MS03

### (3) Evaluation

The average measured pressure should be within the following specifications.


Unit :  $\text{kgf} / \text{cm}^2$

| Model   | Function to be tested | Standard           | Port relief setting at 20 lpm |
|---------|-----------------------|--------------------|-------------------------------|
| HX140 L | Boom, Arm, Bucket     | 350 (380) $\pm 10$ | 400 $\pm 10$                  |
|         | Travel                | 350 $\pm 10$       | -                             |
|         | Swing                 | 285 $\pm 10$       | -                             |





( ) : Power boost

## GROUP 2 MAJOR COMPONENT

### 1. MAIN PUMP



14097MP01



| Part name & inspection item   |   | Standard dimension | Recommended replacement value | Counter measures                   |
|---|---|--------------------|-------------------------------|------------------------------------|
| Clearance between piston (1) & cylinder bore (2) (D-d)  |  | 0.028              | 0.056                         | Replace piston or cylinder.        |
| Play between piston (1) & shoe caulking section (3) (δ)   |  | 0-0.1              | 0.3                           | Replace assembly of piston & shoe. |
| Thickness of shoe (t)   |   | 3.9                | 3.7                           |                                    |
| Free height of cylinder spring(4) (L)   |  | 31.3               | 30.5                          | Replace cylinder spring.           |
| Combined height of set plate(5)(H) & spherical bushing(6)(h) (H-h)  |  | 19.0               | 18.3                          | Replace retainer or set plate.     |
| Surface roughness for valve plate (Sliding face)(7,8), swash plate (shoe plate area) (9), & cylinder (2) (Sliding face) | Surface roughness necessary to be corrected   | 3z                 |                               | Lapping                            |
|   | Standard surface roughness (Corrected value)  | 0.4z or lower      |                               |                                    |

## 2. MAIN CONTROL VALVE

| Part name  | Inspection item  | Criteria & measure  |
|--|--|---|
| Casing   | · Existence of scratch, rusting or corrosion.  | · In case of damage in following section, replace part.<br>- Sliding sections of casing fore and spool, especially land sections applied with holded pressure.<br>- Seal pocket section where spool is inserted.<br>- Seal section of port where O-ring contacts.<br>- Seal section of each relief valve for main, travel, and port.<br>- Other damages that may damage normal functions. |
| Spool  | · Existence of scratch, gnawing, rusting or corrosion.<br>· O-ring seal sections at both ends.<br>· Insert spool in casing hole, rotate and reciprocate it.    | · Replacement when its outside sliding section has scratch (especially on seals-contacting section).<br>· Replacement when its sliding section has scratch.<br>· Correction or replacement when O-ring is damaged or when spool does not move smoothly.   |
| Poppet   | · Damage of poppet or spring<br>· Insert poppet into casing and function it.   | · Correction or replacement when sealing is incomplete.<br>· Normal when it can function lightly without being caught.  |
| Around spring  | · Rusting, corrosion, deformation or breaking of spring, spring seat, plug or cover.   | · Replacement for significant damage.   |
| Around seal for spool  | · External oil leakage.<br>· Rusting, corrosion or deformation of seal plate.  | · Correction or replacement.<br>· Correction or replacement.  |
| Main relief valve, port relief valve & negative control relief valve | · External rusting or damage.<br>· Contacting face of valve seat.<br>· Contacting face of poppet.<br>· Abnormal spring.<br>· O-rings, back up rings and seals. | · Replacement.<br>· Replacement when damaged.<br>· Replacement when damaged.<br>· Replacement.<br>· 100% replacement in general.  |

### 3. SWING DEVICE

#### 1) WEARING PARTS

| Inspection item   | Standard dimension | Standard dimension | Counter measures                                    |
|---|--------------------|--------------------|---|
| Clearance between piston and cylinder block bore  | 0.028              | 0.058              | Replace piston or cylinder block                    |
| Play between piston and shoe caulking section ( $\delta$ )  | 0                  | 0.3                | Replace assembly of piston and shoe                 |
| Thickness of shoe (t)   | 5.5                | 5.3                | Replace assembly of piston and shoe                 |
| Combined height of retainer plate and spherical bushing (H-h)   | 6.5                | 6.0                | Replace set of retainer plate and spherical bushing |
| Thickness of friction plate   | 4.0                | 3.6                | Replace   |
| <div style="display: flex; justify-content: space-around; align-items: center;">   </div> |                    |                    |   |

#### 2) SLIDING PARTS


| Part name   | Standard roughness          | Allowable roughness | Remark |
|-------------|-----------------------------|---------------------|--------|
| Shoe        | 0.8-Z (Ra=0.2)<br>(LAPPING) | 3-Z (Ra=0.8)        |        |
| Shoe plate  | 0.4-Z (Ra=0.1)<br>(LAPPING) | 3-Z (Ra=0.8)        |        |
| Cylinder    | 1.6-Z (Ra=0.4)<br>(LAPPING) | 12.5-Z (Ra=3.2)     |        |
| Valve plate | 0.8-Z (Ra=0.2)<br>(LAPPING) | 6.3-Z (Ra=1.6)      |        |

## 4. TRAVEL MOTOR

### 1) TYPE 1

| Problem                                      |                                | Cause   | Remedy  |
|--|--------------------------------|---|---|
| Does not start                               | Pressure is not developed      | <ul style="list-style-type: none"> <li>· Pump failure</li> <li>· Control valve malfunction</li> </ul>   | <ul style="list-style-type: none"> <li>· Check if action other than traveling is available. If faulty, repair.</li> <li>· Check if spool moves correctly. Repair if necessary.</li> </ul>           |
|  | Pressure is developed          | <ul style="list-style-type: none"> <li>· Brake valve failure</li> <li>-Sleeve stick</li> <li>-Check valve stick</li> <li>· Motor failure</li> <li>-Valve seat seizure</li> <li>· Gear broken and fragment locked</li> <li>· Overloaded</li> </ul>         | <ul style="list-style-type: none"> <li>· Replace brake valve</li> <li>· Replace</li> <li>-Check hydraulic oil for contamination</li> <li>· Replace reduction gear</li> <li>· Reduce load</li> </ul> |
| Oil leakage                                  | Leakage from engaging surfaces | <ul style="list-style-type: none"> <li>· Scratch on engaging surfaces</li> <li>· Loosening by poor bolt tightening</li> </ul>   | <ul style="list-style-type: none"> <li>· Correct surfaces by oilstone or sandpaper or replace</li> <li>· Check after retightening</li> </ul>  |
|  | Leakage from casing            | <ul style="list-style-type: none"> <li>· Plug loosened</li> <li>· Crack formed by stone</li> </ul>  | <ul style="list-style-type: none"> <li>· Retighten</li> <li>· Replace reduction gear</li> </ul>   |
|  | Leakage from floating seal     | <ul style="list-style-type: none"> <li>· Sliding surfaces worn</li> <li>· Creep on O-ring</li> </ul>  | <ul style="list-style-type: none"> <li>· Replace reduction gear</li> <li>· Replace floating seal</li> </ul>   |
|  | Leakage from hydraulic motor   | <ul style="list-style-type: none"> <li>· Bolt loosened</li> <li>· O-ring damaged</li> <li>· Sealing surface scratched</li> </ul>  | <ul style="list-style-type: none"> <li>· Tighten properly</li> <li>· Replace O-ring</li> <li>· Correct by oilstone or sandpaper</li> </ul>  |
| Coasts on slope excessively                  |                                | <ul style="list-style-type: none"> <li>· Poor volumetric efficiency of hydraulic motor</li> <li>· Increase of internal leakage of brake valve</li> <li>· Parking brake not actuated</li> <li>-Spring breakage</li> <li>-Wear of friction plate</li> </ul> | <ul style="list-style-type: none"> <li>· Replace hydraulic motor</li> <li>· Replace brake valve</li> <li>· Replace spring</li> <li>· Replace parking brake</li> </ul>                               |
| Excessive temperature on reduction gear case |                                | <ul style="list-style-type: none"> <li>· Pitting on bearing</li> <li>· Lack of gear oil</li> <li>· Hydraulic oil introduced to gear case</li> </ul>   | <ul style="list-style-type: none"> <li>· Replace reduction gear</li> <li>· Supply gear oil properly</li> <li>· Check motor and replace oil seal</li> </ul>  |
| Meanders                                     | Meanders at low pressure       | <ul style="list-style-type: none"> <li>· Delivery rate is different between right and left</li> <li>· Motor drain rate is different between right and left</li> </ul>   | <ul style="list-style-type: none"> <li>· Repair pump</li> <li>· Replace motor</li> </ul>  |
|  | Meanders at high pressure      | <ul style="list-style-type: none"> <li>· Delivery rate is different between right and left</li> <li>· Motor drain rate is different between right and left</li> </ul>   | <ul style="list-style-type: none"> <li>· Repair regulator or pump</li> <li>· Replace motor</li> </ul>   |
|  | Meanders at high pressure      | <ul style="list-style-type: none"> <li>· Relief pressure dropped at right and left brake valve</li> <li>· Main relief pressure dropped at right or left of control valve</li> </ul>   | <ul style="list-style-type: none"> <li>· Replace brake valve</li> <li>· Replace main relief valve</li> </ul>  |
| Pump delivery is poor                        |                                | <ul style="list-style-type: none"> <li>· Regulator operation poor</li> <li>· External leakage of pump is excessive</li> </ul>   | <ul style="list-style-type: none"> <li>· Repair regulator</li> <li>· Repair pump</li> </ul>   |
| External leakage of motor is excessive       |                                | -   | <ul style="list-style-type: none"> <li>· Replace motor</li> </ul>   |


## 2) TYPE 2

| Inspection item   | Standard dimension | Recommended replacement value | Counter measures                        |
|---|--------------------|-------------------------------|---|
| Clearance between piston and cylinder block bore                                    | 0.025              | 0.050                         | Replace piston or cylinder block        |
| Play between piston and shoe caulking section (T)                                   | 0                  | 0.3                           | Replace assembly of piston and shoe     |
| Thickness of shoe (t)   | 4.5                | 4.3                           | Replace assembly of piston and shoe     |
| Combined height of set plate and ball guide (H)                                     | 7.3                | 7.0                           | Replace set of set plate and ball guide |
| Thickness of friction plate   | 3.0                | 2.6                           | Replace                                 |
|  |                    |                               |   |

## 2) SLIDING PARTS


| Part name   | Standard roughness | Remark |
|-------------|--------------------|--------|
| Shoe        | 0.8S               | -      |
| Shoe plate  | 0.8S               | -      |
| Cylinder    | 0.8S               | -      |
| Valve plate | 0.8S               | -      |

## 5. RCV LEVER

| Maintenance check item    | Criteria  | Remark  |
|---------------------------|---|---|
| Leakage                   | The valve is to be replaced when the leakage becomes more than 1000 cc/m at neutral handle position, or more than 2000 cc/m during operation.   | Conditions :<br>Primary pressure : 40 kgf/cm <sup>2</sup><br>Oil viscosity : 23 cSt     |
| Spool                     | This is to be replaced when the sliding surface has worn more than 10 μm, compared with the non-sliding surface.  | The leakage at the left condition is estimated to be nearly equal to the above leakage. |
| Push rod                  |  <p>This is to be replaced when the top end has worn more than 1mm.</p>                                    |   |
| Play at operating section | The pin, shaft, and joint of the operating section are to be replaced when their plays become more than 2 mm due to wears or so on.   | When a play is due to looseness of a tightened section, adjust it.                      |
| Operation stability       | When abnormal noises, hunting, primary pressure drop, etc. are generated during operation, and these cannot be remedied, referring to section 6 troubleshooting, replace the related parts. |   |




Notes 1. It is desirable to replace seal materials, such as O-rings, every disassembling. However, they may be reused, after being confirmed to be free of damage.

## 6. RCV PEDAL

| Maintenance check item    | Criteria   | Remark  |
|---------------------------|--|---|
| Leakage                   | The valve is to be replaced when the leakage effect to the system. For example, the primary pressure drop.   | Conditions :<br>Primary pressure : 40 kgf/cm <sup>2</sup><br>Oil viscosity : 23 cSt     |
| Spool                     | This is to be replaced when the sliding surface has worn more than 10μm, compared with the non-sliding surface.  | The leakage at the left condition is estimated to be nearly equal to the above leakage. |
| Push rod                  |  <p>This is to be replaced when the top end has worn more than 1 mm.</p>                                    |   |
| Play at operating section | The pin, shaft, and joint of the operating section are to be replaced when their plays become more than 2 mm due to wears or so on.  | When a play is due to looseness of a tightened section, adjust it.                      |
| Operation stability       | When abnormal noises, hunting, primary pressure drop, etc. are generated during operation, and these cannot be remedied, referring to section 6. Troubleshooting, replace the related parts. |   |

Notes 1. It is desirable to replace seal materials, such as O-rings, every disassembling. However, they may be reused, after being confirmed to be free of damage.

## 7. TURNING JOINT

| Part name     |   | Maintenance standards  | Remedy                |
|---------------|---|--|-----------------------|
| Body,<br>Stem | Sliding surface with sealing sections.                            | Plating worn or peeled due to seizure or contamination.  | Replace               |
|               | Sliding surface between body and stem other than sealing section. | ·Worn abnormality or damaged more than 0.1 mm (0.0039 in) in depth due to seizure contamination.   | Replace               |
|               |   | ·Damaged more than 0.1 mm (0.0039 in) in depth.  | Smooth with oilstone. |
|               | Sliding surface with thrust plate.                                | ·Worn more than 0.5 mm (0.02 in) or abnormality.   | Replace               |
|               |   | ·Worn less than 0.5 mm (0.02 in).  | Smooth                |
|               |   | ·Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).   | Smooth                |
| Cover         | Sliding surface with thrust plate.                                | ·Worn more than 0.5 mm (0.02 in) or abnormality.   | Replace               |
|               |   | ·Worn less than 0.5 mm (0.02 in).  | Smooth                |
|               |   | ·Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).   | Replace               |
| Seal set      | -   | ·Extruded excessively from seal groove square ring.<br><br>                                    | Replace               |
|               | -   | ·Slipper ring 1.5 mm (0.059 in) narrower than seal groove, or narrower than back ring.<br><br> | Replace               |
|               | -   | ·Worn more than 0.5 mm (0.02 in) ~ 1.5 mm (MAX.) (0.059 in)<br><br>                             | Replace               |


## 8. CYLINDER

| Part name     | Inspecting section                          | Inspection item                          | Remedy                                   |
|---------------|---|--|--|
| Piston rod    | · Neck of rod pin                           | · Presence of crack                      | · Replace                                |
|               | · Weld on rod hub                           | · Presence of crack                      | · Replace                                |
|               | · Stepped part to which piston is attached. | · Presence of crack                      | · Replace                                |
|               | · Threads                                   | · Presence of crack                      | · Recondition or replace                 |
|               | · Plated surface                            | · Plating is not worn off to base metal. | · Replace or replate                     |
|               |   | · Rust is not present on plating.        | · Replace or replate                     |
|               |   | · Scratches are not present.             | · Recondition, replate or replace        |
| Cylinder tube | · Rod                                       | · Wear of O.D.                           | · Recondition, replate or replace        |
|               | · Bushing at mounting part                  | · Wear of I.D.                           | · Replace                                |
|               | · Weld on bottom                            | · Presence of crack                      | · Replace                                |
|               | · Weld on head                              | · Presence of crack                      | · Replace                                |
|               | · Weld on hub                               | · Presence of crack                      | · Replace                                |
| Gland         | · Tube interior                             | · Presence of faults                     | · Replace if oil leak is seen            |
|               | · Bushing at mounting part                  | · Wear on inner surface                  | · Replace                                |
| Gland         | · Bushing                                   | · Flaw on inner surface                  | · Replace if flaw is deeper than coating |
|               |   |  |  |

## GROUP 3 TRACK AND WORK EQUIPMENT

### 1. TRACK

#### 1) TRACK ROLLER




21037MS01

Unit : mm

| No. | Check item                           | Criteria           |                |                 |                    |                 | Remedy             |
|-----|--------------------------------------|--------------------|----------------|-----------------|--------------------|-----------------|--------------------|
| 1   | Outside diameter of flange           | Standard size      |                |                 | Repair limit       |                 | Rebuild or replace |
|     |                                      | Ø190               |                |                 | —                  |                 |                    |
| 2   | Outside diameter of tread            | Ø150               |                |                 | Ø138               |                 |                    |
| 3   | Width of tread                       | 36.5               |                |                 | 42.5               |                 |                    |
| 4   | Width of flange                      | 26.5               |                |                 | -                  |                 |                    |
| 5   | Clearance between shaft and bushing  | Standard size      | tolerance      |                 | Standard clearance | Clearance limit | Replace bushing    |
|     |                                      |                    | Shaft          | Hole            |                    |                 |                    |
|     |                                      | Ø65                | -0.25<br>-0.35 | +0.12<br>+0.075 | 0.325<br>to 0.47   | 2.0             |                    |
| 6   | Side clearance of roller (both side) | Standard clearance |                |                 | Clearance limit    |                 | Replace            |
|     |                                      | 0.1 to 1.3         |                |                 | 2.0                |                 |                    |

## 2) CARRIER ROLLER




21037MS02

Unit : mm

| No. | Check item                          | Criteria                             |                                       |                    |                 | Remedy             |
|-----|-------------------------------------|--------------------------------------|---------------------------------------|--------------------|-----------------|--------------------|
| 1   | Outside diameter of flange          | Standard size                        |                                       | Repair limit       |                 | Rebuild or replace |
|     |                                     | Ø175                                 |                                       | -                  |                 |                    |
| 2   | Outside diameter of tread           | Ø151                                 |                                       | Ø141               |                 |                    |
| 3   | Width of tread                      | 37.25                                |                                       | 42.25              |                 |                    |
| 4   | Width of flange                     | 18.25                                |                                       | -                  |                 |                    |
| 5   | Clearance between shaft and bushing | Standard size & Tolerance            |                                       | Standard clearance | Clearance limit | Replace bushing    |
|     |                                     | Shaft                                | Hole                                  |                    |                 |                    |
|     |                                     | Ø41.27 <sup>0</sup> <sub>+0.05</sub> | Ø41.5 <sup>+0.2</sup> <sub>-0.1</sub> | 0.13 to 0.48       | 1.2             |                    |

### 3) IDLER




21037MS03

Unit : mm

| No. | Check item                          | Criteria                          |                                       |                    |                 | Remedy             |
|-----|-------------------------------------|-----------------------------------|---------------------------------------|--------------------|-----------------|--------------------|
| 1   | Outside diameter of flange          | Standard size                     |                                       | Repair limit       |                 | Rebuild or replace |
|     |                                     | Ø552                              |                                       | -                  |                 |                    |
| 2   | Outside diameter of tread           | Ø507                              |                                       | Ø497               |                 |                    |
| 3   | Width of protrusion                 | 67                                |                                       | -                  |                 |                    |
| 4   | Total width                         | 135                               |                                       | -                  |                 |                    |
| 5   | Width of tread                      | 34                                |                                       | 39                 |                 |                    |
| 6   | Clearance between shaft and bushing | Standard size & Tolerance         |                                       | Standard clearance | Clearance limit | Replace bushing    |
|     |                                     | Shaft                             | Hole                                  |                    |                 |                    |
|     |                                     | Ø70 <sup>0</sup> <sub>-0.03</sub> | Ø70.3 <sup>+0.05</sup> <sub>0</sub>   | 0.3 to 0.38        | 2.0             |                    |
| 7   | Clearance between shaft and support | Ø70 <sup>0</sup> <sub>-0.03</sub> | Ø70 <sup>+0.07</sup> <sub>+0.03</sub> | 0.3 to 0.1         | 1.2             | Replace            |
| 8   | Side clearance of idler (both side) | Standard clearance                |                                       | Clearance limit    |                 | Replace bushing    |
|     |                                     | 0.25 to 1.15                      |                                       | 2.0                |                 |                    |

#### 4) TRACK




21037MS04

Unit : mm

| No. | Check item                                     | Criteria   |              | Remedy             |
|-----|--|--|--------------|--------------------|
|     |  | Standard size  | Repair limit |                    |
| 1   | Link pitch                                     | 171.45   | 175.65       | Turn or replace    |
| 2   | Outside diameter of bushing                    | Ø53.75   | Ø43.95       | Rebuild or replace |
| 3   | Height of grouser                              | 25   | 16           |                    |
| 4   | Height of link                                 | 94.5   | 86.5         |                    |
| 5   | Tightening torque<br>(Tightening angle method) | Initial tightening torque : $42 \pm 4$ kgf·m<br>Additional tightening angle : $32^\circ$ |              | Retighten          |

5) TRACK FRAME AND RECOIL SPRING




21037MS05

Unit : mm

| No. | Check item                      | Criteria      |                     |                   |              | Remedy                |
|-----|---------------------------------|---------------|---------------------|-------------------|--------------|-----------------------|
|     |                                 |               | Standard size       | Tolerance         | Repair limit |                       |
| 1   | Vertical width of idler guide   | Track frame   | 103                 | +2<br>0           | 107          | Rebuild or<br>replace |
|     |                                 | Idler support | 100                 | 0<br>-0.5         | 98           |                       |
| 2   | Horizontal width of idler guide | Track frame   | 192                 | +2<br>0           | 196          |                       |
|     |                                 | Idler support | 190                 | -                 | 188          |                       |
| 3   | Recoil spring                   | Standard size |                     |                   | Repair limit | Replace               |
|     |                                 | Free length   | Installation length | Installation load | Free length  | Installation load     |
|     |                                 | Ø192×470      | 405                 | 8,497kg           | —            | 6,978kg               |

## 2. WORK EQUIPMENT



14097MS01

Unit : mm

| Mark | Measuring point<br>(Pin and Bushing) | Normal<br>value | Pin                         |                 | Bushing                     |                 | Remedy<br>&<br>Remark |
|------|--------------------------------------|-----------------|-----------------------------|-----------------|-----------------------------|-----------------|-----------------------|
|      |                                      |                 | Recomm.<br>service<br>limit | Limit<br>of use | Recomm.<br>service<br>limit | Limit<br>of use |                       |
| A    | Boom Rear                            | 70              | 69                          | 68.5            | 70.5                        | 71              | Replace               |
| B    | Boom Cylinder Head                   | 70              | 69                          | 68.5            | 70.5                        | 71              | "                     |
| C    | Boom Cylinder Rod                    | 70              | 69                          | 68.5            | 70.5                        | 71              | "                     |
| D    | Arm Cylinder Head                    | 70              | 69                          | 68.5            | 70.5                        | 71              | "                     |
| E    | Boom Front                           | 70              | 69                          | 68.5            | 70.5                        | 71              | "                     |
| F    | Arm Cylinder Rod                     | 70              | 69                          | 68.5            | 70.5                        | 71              | "                     |
| G    | Bucket Cylinder Head                 | 70              | 69                          | 68.5            | 70.5                        | 71              | "                     |
| H    | Arm Link                             | 65              | 64                          | 63.5            | 65.5                        | 66              | "                     |
| I    | Bucket and Arm Link                  | 65              | 64                          | 63.5            | 65.5                        | 66              | "                     |
| J    | Bucket Cylinder Rod                  | 70              | 69                          | 68.5            | 70.5                        | 71              | "                     |
| K    | Bucket Link                          | 65              | 64                          | 63.5            | 65.5                        | 66              | "                     |