# SECTION 5 MECHATRONICS SYSTEM


Group	1	Outline	5-1
Group	2	Mode Selection System ·····	5-3
Group	3	Automatic Deceleration System	5-6
Group	4	Power Boost System	5-7
Group	5	Travel Speed Control System	5-8
Group	6	Automatic Warming Up System	5-9
Group	7	Engine Overheat Prevention System ·····	5-10
Group	8	Variable Power Control System ·····	5-11
Group	9	Attachment Flow Control System ·····	5-12
Group	10	Intelligent Power Control System	5-13
Group	11	Anti-Restart System	5-15
Group	12	Self-Diagnostic System ····	5-16
Group	13	Engine Control System ·····	5-49
Group	14	EPPR Valve ·····	5-50
Group	15	Monitoring System ·····	5-55
Group	16	Fuel Warmer System ····	5-89

### SECTION 5 MECHATRONICS SYSTEM


#### **GROUP 1 OUTLINE**

The ADVANCED CAPO (Computer Aided Power Optimization) system controls engine and pump mutual power at an optimum and less fuel consuming state for the selected work by mode selection, auto-deceleration, power boost function, etc. It monitors machine conditions, for instance, engine speed, coolant temperature, hydraulic oil temperature, and hydraulic oil pressure, etc.

It consists of a MCU, a cluster, an ECM, EPPR valves, and other components. The MCU and the cluster protect themselves from over-current and high voltage input, and diagnose malfunctions caused by short or open circuit in electric system, and display error codes on the cluster.




#### SYSTEM DIAGRAM



400SA5MS01

### **GROUP 2 MODE SELECTION SYSTEM**

#### 1. POWER MODE SELECTION SYSTEM



400SA5MS02

Mode selection system (micro computer based electro-hydraulic pump and engine mutual control system) optimizes the engine and pump performance.

The combination of 3 power modes (P, S, E) and acceleration mode (10 set) of haptic controller makes it possible to use the engine and pump power more effectively corresponding to the work conditions from a heavy and great power requesting work to a light and precise work.


	Application	Engine rpm			Power shift by EPPR valve				
Power		Standard		Option		Standard		Option	
mode		Unload	Load	Unload	Load	Current (mA)	Pressure (kgf/cm²)	Current (mA)	Pressure (kgf/cm²)
Р	Heavy duty power	1700	1700	1700	1700	340	10 (7)	300	7 (7)
S	Standard power	1600	1600	1600	1600	350	11 (8)	310	8 (8)
E	Economy operation	1500	1600	1600	1600	400	15 (12)	360	12 (12)
AUTO DECEL	Engine deceleration	1000	-	1000	-	700	38	700	38
One touch decel	Engine quick deceleration	900	-	900	-	700	38	700	38
KEY START	Key switch start position	900	-	900	-	700	38	700	38

\* Power shift (Standard/Option) can be changed by "Service menu" in "Management" on the cluster.

% ():Load

#### 2. WORK MODE SELECTION SYSTEM

Work mode consists of the general operation (bucket) and the optional attachment (breaker, crusher).



#### 1) GENERAL WORK MODE (bucket)

This mode is used to general digging work.


#### 2) ATT WORK MODE (breaker, crusher)

It controls the pump flow and system pressure according to the operation of breaker or crusher.

Description	General mode	Work	c tool
Description	Bucket	Breaker	Crusher
Attachment safety solenoid	OFF	-	ON
Attachment conflux solenoid	OFF	ON/OFF	ON/OFF
Attachment flow EPPR current	100 mA	100~700 mA	100~700 mA
Breaker solenoid*	OFF	ON	-

<sup>★</sup> When breaker operating button is pushed.

#### 3. USER MODE SELECTION SYSTEM




1) High idle rpm, auto idle rpm and EPPR pressure can be adjusted and memorized in the U-mode.

### 2) LCD segment vs parameter setting

Step ( ■ )	Engine speed (rpm)	Idle speed (rpm)	Power shift (bar)
1	1350	800	0
2	1400	850	3
3	1450	900	6
4	1500	950	9
5	1550	1000 (auto decel)	12
6	1600	1050	16
7	1650	1100	20
8	1700	1150	26
9	1750	1200	32
10	1800	1250	38


#### **GROUP 3 AUTOMATIC DECELERATION SYSTEM**



#### 1. WHEN AUTO IDLE PILOT LAMP ON

When all of the work equipment control levers including swing and travel levers are at neutral for 4 seconds, MCU drive the governor moter to reduce the engine speed to 1000 rpm. If the control levers are at neutral for 1 minute, MCU reduces the engine speed to 900 rpm. As the result of reducing the engine speed, fuel consumption and noise are effectively cut down during non-operation of the control levers.

When the auto idle pilot lamp is turned off by pressing the switch or any control lever is operated, the reduced engine speed rises upto the speed before deceleration in a second.




#### 350SA5MS56

#### 2. WHEN AUTO IDLE PILOT LAMP OFF

The engine speed can be set as desired using the accel dial switch, and even if the control levers are neutral, the engine speed is not reduced.

\* Auto idle function can be activated when accel dial position is over 4.

## **GROUP 4 POWER BOOST SYSTEM (NULL)**




- When the power boost switch on the left control lever knob is pushed ON, the power mode is set P mode and maximum digging power is increased by 10 %.
- When the power boost function is activated, the power boost solenoid valve pilot pressure raises the set pressure of the main relief valve to increase the digging power.

Description	Condition	Function
Activated	Power boost switch : ON Multimodal dial : over 8	- Power mode : P - Multimodal dial power : 9 - Power boost solenoid : ON - Power boost pilot Imap : ON - Operating time : max 8 seconds
Canceled	Power boost switch : OFF	<ul><li>- Pre-set power mode</li><li>- Power boost solenoid : OFF</li><li>- Power boost pilot lamp : OFF</li></ul>

When the auto power boost is set to enable and power mode is set to P mode on the cluster, the digging power is automatically increased as working conditions by the MCU. It is operated max 8 seconds.

# **GROUP 5 TRAVEL SPEED CONTROL SYSTEM**




400SA5MS10

Travel speed can be switched manually by pressing the travel speed switch on the cluster.

Speed	Travel speed solenoid valve	Lamp on cluster	Operation
Low	OFF	Turtle	Low speed, high driving torque in the travel motor
High	ON	Rabbit	High speed, low driving torque in the travel motor

Mercal Strate (Low)

### **GROUP 6 AUTOMATIC WARMING UP SYSTEM**




- 400SA5MS07
- 1. The MCU receives the engine coolant temperature thought the temperature sensor, and if the coolant temperature is below 30°C, it increases the engine speed from key start rpm to 1000 rpm. At this time the mode does not change. If the coolant temperature sensor has fault, the hydraulic oil temperature signal is substituted.
- 2. In case of the coolant temperature increases up to 30°C, the engine speed is decreased to key start speed. And if an operator changes power mode set during the warming up function, the MCU cancels the automatic warming up function.

#### 3. LOGIC TABLE

Description	Condition	Function
Actuated	- Coolant temperature : below 30°C (after engine run)	- Power mode : Default (E mode) - Warming up time : 10 minutes (max) - Warming up pilot lamp : ON
Canceled	<ul> <li>Coolant temperature: Above 30°C</li> <li>Warming up time: Above 10 minutes</li> <li>Changed power mode set by operator</li> <li>RCV lever or pedal operating</li> <li>Auto idle cancel</li> <li>If any of the above conditions is applicable, the automatic warming up function is canceled</li> </ul>	- Power mode : set mode - Warming up pilot lamp : OFF

# **GROUP 7 ENGINE OVERHEAT PREVENTION SYSTEM**




1. If the engine coolant temperature or the hydraulic oil temperature is overheated over 100°C, the warning lamp is ON and the pump input torque or the engine speed is reduced as below logic table.

#### 2. LOGIC TABLE

Description		Condition	Function
	Activated	- Coolant temperature : Above 107°C	- Warning lamp : ON , buzzer : OFF - Pump input torque is reduced.
First step	Activated	- Hydraulic oil temperature :	<ul><li>Warning lamp &amp; buzzer : ON</li><li>Pump input torque is reduced.</li></ul>
warning	Canceled	<ul> <li>Coolant temperature :</li> <li>Less than 107°C</li> <li>Hydraulic oil temperature :</li> <li>Less than 100°C</li> </ul>	- Return to pre-set the pump absorption torque.
Second step	Activated	- Coolant temperature : Above 113°C - Hydraulic oil temperature : Above 105°C	<ul><li>Emergency warning lamp pops up on the center of LCD and the buzzer sounds.</li><li>Engine speed is reduced after 10 seconds.</li></ul>
warning	Canceled	- Coolant temperature : Less than 107°C - Hydraulic oil temperature : Less than 100°C	<ul> <li>Return to pre-set the engine speed.</li> <li>Hold pump absorption torque on the first step warning.</li> </ul>

# **GROUP 8 VARIABLE POWER CONTROL SYSTEM**



400SA5MS09


The variable power control system controls the engine and pump mutual power according to RCV lever stroke and pump load.

It makes fuel saving and smooth control at precise work.

Description	Working condition
Power mode	P, S, E
Work mode	General (bucket)
Pressure sensor	Normal

\* The variable power control function can be activated when the power mode is set to all power mode.

# **GROUP 9 ATTACHMENT FLOW CONTROL SYSTEM**




• The system is used to control the pump delivery flow according to set of the work tool on the cluster by the attachment flow EPPR valve.

Description	Work tool		
Description	Breaker	Crusher	
Flow level	100 ~ 250 lpm	100 ~ 580 lpm	
Attach safety solenoid	-	ON	
Attach conflux solenoid	-	ON/OFF	
Breaker solenoid*	ON	-	

- \* Refer to the page 5-75 for the attachment kinds and max flow.
- ★ When breaker operating button is pushed.

# **GROUP 10 INTELLIGENT POWER CONTROL SYSTEM**



1. When the requirement of pump flow rate is low, IPC mode controls pump flow rate to improve fuel efficiency.

Condition*¹	Function
IPC mode : ON*2	
Boom up	
Arm in	Limitation of pump flow rate : Activated
Not travel motion	
Not swing motion	
None of upper condition	Limitation of pump flow rate : Canceled


<sup>\*1</sup> AND condition

<sup>\*2</sup> IPC mode ON/OFF is selected at "Mode setup > IPC mode". See next page.

#### 2. IPC MODE SELECTION

IPC mode ON/OFF and the levels of flow rate limit can be selected at "Mode setup > IPC mode"






145SA5MS19

IPC mode	Description
Balance mode (default)	IPC mode ON, limit level 1
Efficiency mode	IPC mode ON, limit level 2
Speed mode	IPC mode OFF

# GROUP 11 ANTI-RESTART SYSTEM



220S5MS18

#### 1. ANTI-RESTART FUNCTION

After a few seconds from the engine starts to run, MCU turns off the anti-start relay to protect the starter from inadvertent restarting.

## **GROUP 12 SELF-DIAGNOSTIC SYSTEM**

#### 1. OUTLINE

When any abnormality occurs in the ADVANCED CAPO system caused by electric parts malfunction and by open or short circuit, the MCU diagnoses the problem and sends the error codes to the cluster and also stores them in the memory.


#### 2. MONITORING

#### 1) Active fault



· The active faults of the MCU can be checked by this menu.

#### 2) Logged fault



The logged faults of the MCU can be checked by this menu.

#### 3) Delete logged fault



· The logged faults of the MCU can be deleted by this menu.

## 3. MACHINE ERROR CODES TABLE

DTC	;		Ap	plicat	ion				
HCESPN	FMI	Diagnostic Criteria	G	С	W				
	3	10 seconds continuous, Hydraulic Oil Temp. Measurement Voltage > 3.8V	•						
	4	10 seconds continuous, Hydraulic Oil Temp. Measurement Voltage < 0.3V							
	(Resu	ults / Symptoms)							
101	1. Mo	nitor – Hydraulic oil temperature display failure							
	2. Cor	ntrol Function – Fan revolutions control failure							
	(Chec	king list)							
		-1 (#2) – CN-52 (#24) Checking Open/Short							
	2. CD	-1 (#1) – CN-51 (#11) Checking Open/Short							
	0	10 seconds continuous, Working Press. Sensor							
		Measurement Voltage > 5.2V							
	1	10 seconds continuous, 0.3V≤ Working Press. Sensor Measurement							
		Voltage < 0.8V							
	4	10 seconds continuous, Working Press. Sensor							
	<b>/D</b>	Measurement Voltage < 0.3V							
105	(Results / Symptoms)								
		nitor – Working Press. display failure		<b>.</b>					
	2. COI	ntrol Function – Auto Idle operation failure, Engine variable horse power control of failure	opera	lion					
	(Choc	king list)							
	٠,	-7 (#B) – CN-52 (#37) Checking Open/Short							
		-7 (#A) – CN-52 (#37) Checking Open/Short							
		-7 (#C) – CN-51 (#13) Checking Open/Short							
	0.02	10 seconds continuous, Travel Oil Press. Sensor							
	0	Measurement Voltage > 5.2V							
		10 seconds continuous, 0.3V ≤ Travel Oil Press. Sensor Measurement							
	1	Voltage < 0.8V							
	1	10 seconds continuous, Travel Oil Press. Sensor							
	4	Measurement Voltage < 0.3V							
400	(Resu	ults / Symptoms)							
108	1. Mo	nitor – Travel Oil Press. display failure							
	2. Cor	ntrol Function – Auto Idle operation failure, Engine variable horse power control	opera	tion					
		failure, IPC operation failure, Driving alarm operation failure							
	(Chec	cking list)							
		-6 (#B) – CN-52 (#38) Checking Open/Short							
		-6 (#A) – CN-51 (#3) Checking Open/Short							
	3. CD	-6 (#C) – CN-51 (#13) Checking Open/Short							

 $\ensuremath{\,\%\,}$  Some error codes are not applied to this machine.

DTC	;		Ap	plicat	ion		
HCESPN	FMI	Diagnostic Criteria	G	С	W		
	0	10 seconds continuous, Main Pump 1 (P1) Press. Sensor Measurement					
		Voltage > 5.2V					
	1	10 seconds continuous, 0.3V ≤ Main Pump 1 (P1) Press. Sensor					
		Measurement Voltage < 0.8V  10 seconds continuous, Main Pump 1 (P1) Press. Sensor Measurement			_		
	4	Voltage < 0.3V					
	(Resu	Its / Symptoms)					
120	l '	nitor – Main Pump 1 (P1) Press. display failure					
		ntrol Function – Automatic voltage increase operation failure, Overload at compe	nsati	on co	ntrol		
		failure					
	(Chec	king list)					
	1. CD-	-42 (#B) – CN-52 (#29) Checking Open/Short					
	2. CD-	-42 (#A) – CN-51 (#3) Checking Open/Short					
	3. CD-	42 (#C) – CN-51 (#13) Checking Open/Short					
	0	10 seconds continuous, Main Pump 2 (P2) Press. Sensor Measurement					
		Voltage > 5.2V					
	1	10 seconds continuous, 0.3V≤ Main Pump 2 (P2) Press. Sensor Measurement Voltage < 0.8V					
		10 seconds continuous, Main Pump 2 (P2) Press. Sensor Measurement					
	4	Voltage < 0.3V					
	(Results / Symptoms)						
121	1. Mor	nitor – Main Pump 2 (P2) Press. display failure					
	2. Cor	ntrol Function – Automatic voltage increase operation failure, Overload at compe	ensat	ion co	ontrol		
	failure						
	١,	king list)					
		-43 (#B) – CN-52 (#30) Checking Open/Short					
		43 (#A) – CN-51 (#3) Checking Open/Short					
	3. CD-	-43 (#C) – CN-51 (#13) Checking Open/Short					
	4	(when you had conditions mounting pressure sensor)					
	1	10 seconds continuous, 0.3V ≤ Overload Press. Sensor Measurement Voltage < 0.8V					
		(when you had conditions mounting pressure sensor)					
	4	10 seconds continuous, Overload Press. Sensor					
		Measurement Voltage < 0.3V					
122	(Resu	Its / Symptoms)					
	1. Mor	nitor – Overload Press. display failure					
	2. Cor	ntrol Function – Overload warning alarm failure					
	(Chec	king list)					
		-31 (#B) – CN-52 (#39) Checking Open/Short					
		-31 (#A) – CN-51 (#3) Checking Open/Short					
	3. CD-	31 (#C) – CN-51 (#13) Checking Open/Short					

DTC			Ар	plicati	ion					
HCESPN	FMI	Diagnostic Criteria	G	С	W					
		10 seconds continuous, Negative 1 Press. Sensor								
	0	Measurement Voltage > 5.2V								
	1	10 seconds continuous, $0.3V \le$ Negative 1 Press. Sensor Measurement Voltage $< 0.8V$	•							
	4	10 seconds continuous, Negative 1 Press. Sensor Measurement Voltage < 0.3V	•							
123	(Resu	Its / Symptoms)								
	1. Mor	nitor - Negative 1 Press. display failure								
	2. Cor	trol Function – IPC operation failure, Option attachment flow control operation fa	ailure							
	(Chec	king list)								
	1. CD-	70 (#B) – CN-51 (#39) Checking Open/Short								
	2. CD-	70 (#A) – CN-51 (#3) Checking Open/Short								
	3. CD-	70 (#C) – CN-51 (#13) Checking Open/Short								
	0	10 seconds continuous, Negative 2 Press. Sensor								
	0	Measurement Voltage > 5.2V								
	1	10 seconds continuous, 0.3V≤ Negative 2 Press. Sensor Measurement								
	<u>'</u>	Voltage < 0.8V								
	4	10 seconds continuous, Negative 2 Press. Sensor								
	4	Measurement Voltage < 0.3V								
124	(Results / Symptoms)									
	1. Mor	nitor – Negative 2 Press. display failure								
	2. Cor	2. Control Function – Option attachment flow control operation failure								
	(Chec	king list)								
	1. CD-	71 (#B) – CN-51 (#40) Checking Open/Short								
	2. CD-	71 (#A) – CN-51 (#3) Checking Open/Short								
	3. CD-	71 (#C) – CN-51 (#13) Checking Open/Short								
	0	10 seconds continuous, Boom Up Pilot Press. Sensor								
	0	Measurement Voltage > 5.2V								
	1	10 seconds continuous, 0.3V≤ Boom Up Pilot Press. Sensor Measurement								
		Voltage < 0.8V			<u> </u>					
	4	10 seconds continuous, Boom Up Pilot Press. Sensor Measurement < 0.3V								
	(Resu	Its / Symptoms)								
127	1. Mor	nitor – Boom Up Pilot Press. display failure								
	2. Cor	trol Function – Engine/Pump variable horse power control operation failure, IPC	opei	ration						
		failure, Boom first operation failure								
	(Chec	king list)								
	1. CD-	32 (#B) – CN-52 (#35) Checking Open/Short								
	2. CD-	32 (#A) – CN-51 (#3) Checking Open/Short								
	3. CD-	32 (#C) - CN-5 1(#13) Checking Open/Short								

DTC		D:	Application		ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	0	(when you had conditions mounting pressure sensor)  10 seconds continuous, Boom Down Pilot Press. Sensor Measurement Voltage > 5.2V	•		
	1	(when you had conditions mounting pressure sensor)  10 seconds continuous, 0.3V≤ Boom Down Pilot Press. Sensor  Measurement Voltage < 0.8V	•		
128	4	(when you had conditions mounting pressure sensor)  10 seconds continuous, Boom Down Pilot Press. Sensor Measurement Voltage < 0.3V	•		
	1. Mor 2. Cor (Chec 1. CD- 2. CD-	Its / Symptoms) nitor – Boom Down Pilot Press. display failure strol Function – Boom floating operation failure king list) 85 (#B) – CN-52 (#34) Checking Open/Short 85 (#A) – CN-51 (#3) Checking Open/Short 85 (#C) – CN-51 (#13) Checking Open/Short			
	3. OD-	10 seconds continuous, Arm In Pilot Press. Sensor			
	0	Measurement Voltage > 4.8V			
	1	10 seconds continuous, 0.3V≤ Arm In Pilot Press. Sensor Measurement Voltage < 0.8V	•		
	4	10 seconds continuous, Arm In Pilot Press. Sensor Measurement Voltage < 0.3V	•		
129	1. Mor 2. Cor (Chec 1. CD- 2. CD-	Its / Symptoms)  nitor – Arm In Pilot Press. display failure  strol Function – IPC operation failure  king list)  90 (#B) – CN-51 (#10) Checking Open/Short  90 (#A) – CN-51 (#3) Checking Open/Short  90 (#C) – CN-51 (#13) Checking Open/Short			
	0	10 seconds continuous, Bucket in Pilot Press. Sensor Measurement Voltage > 5.2V 10 seconds continuous,	•		
	1	0.3V≤ Bucket in Pilot Press. Sensor  Measurement Voltage < 0.8V	•		
133	4	10 seconds continuous,  Bucket in Pilot Press. Sensor Measurement Voltage < 0.3V	•		
.55	1. Mor 2. Cor (Chec 1. CD- 2. CD-	Its / Symptoms)  nitor – Bucket in Pilot Press. display failure  strol Function – Engine variable horse power control operation failure  king list)  35 (#B) – CN-52 (#28) Checking Open/Short  35 (#A) – CN-51 (#3) Checking Open/Short  35 (#C) – CN-51 (#13) Checking Open/Short			

\* Some error codes are not applied to this machine.

 $\mbox{G : General} \qquad \qquad \mbox{C : Crawler Type} \qquad \qquad \mbox{W : Wheel Type}$ 

DTC	;	Discounting Office to	Ар	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	0	10 seconds continuous, Swing Pilot Press. Sensor			
	0	Measurement Voltage > 5.2V			
	1	10 seconds continuous, 0.3V≤ Swing Pilot Press. Sensor Measurement			
		Voltage < 0.8V			
	4	10 seconds continuous, Swing Pilot Press. Sensor			
		Measurement Voltage < 0.3V			
135	l ,	Its / Symptoms)			
		nitor – Swing Pilot Press. display failure			
		ntrol Function – IPC operation, Boom first operation failure			
	,	king list)			
		24 (#B) – CN-52 (#36) Checking Open/Short			
		24 (#A) – CN-51 (#3) Checking Open/Short			
	3. CD.	24 (#C) – CN-51 (#13) Checking Open/Short			1
		Monitor – Select Attachment(breaker / crusher)			
	0	10 seconds continuous, Attachment Pilot Press. Sensor Measurement			
		Voltage > 5.2V Monitor – Select Attachment(breaker / crusher)			
	1	10 seconds continuous, 0.3V≤ Attachment Pilot Press. Sensor			
	'	Measurement Voltage < 0.8V			
		Monitor – Select Attachment(breaker / crusher)			
	4	10 seconds continuous, Attachment Pilot Press. Sensor Measurement			
138		Voltage < 0.3V			
	(Resu	Its / Symptoms)			
	١,	nitor – Attachment Pilot Press. display failure			
		ntrol Function – Option attachment flow control operation failure			
		king list)			
	1. CD	69 (#B) – CN-52 (#33) Checking Open/Short			
	2. CD-	69 (#A) – CN-51 (#3) Checking Open/Short			
	3. CD-	69 (#C) – CN-51 (#13) Checking Open/Short			
	4	10 seconds continuous, 0.3V≤ Option Pilot Press. Sensor Measurement			
	1	Voltage < 0.8V			
	4	10 seconds continuous, Option Pilot Press. Sensor			
	_ '	Measurement Voltage < 0.3V			
139	,	Its / Symptoms)			
(NA)		nitor – Option Pilot Press. display failure			
(1471)		ntrol Function – Auto Idle operation failure			
	١,	king list)			
		-100 (#B) – CN-52 (#21) Checking Open/Short			
		-100 (#A) – CN-51 (#3) Checking Open/Short			
	3. CD	-100 (#C) – CN-1 (#6) Checking Open/Short			

DTC	;	Dia manatia Critaria	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	5	(Detection)  (When Pump EPPR Current is more than 10 mA)  10 seconds continuous, Pump EPPR drive current < 0 mA  (Cancellation)  (When Pump EPPR Current is more than 10 mA)  3 seconds continuous, Pump EPPR drive current ≥10 mA	•		
140	6	<ul> <li>(Detection)</li> <li>10 seconds continuous, Pump EPPR drive current &gt; 1.0A</li> <li>(Cancellation)</li> <li>3 seconds continuous, Pump EPPR drive current ≤ 1.0 A</li> </ul>	•		
	1. Cor	lts / Symptoms)  htrol Function – Pump horse power setting specification difference  (Fuel efficiency/speed specification failure)  king list)  -75 (#2) – CN-52 (#9) Checking Open/Short			
	2. CN	-75 (#1) – CN-52 (#19) Checking Open/Short			
	5	<ul> <li>(Model Parameter) mounting Boom Priority EPPR</li> <li>(Detection)</li> <li>(When Boom Priority EPPR Current is more than 10 mA)</li> <li>10 seconds continuous, Boom Priority EPPR drive current &lt; 0 mA</li> <li>(Cancellation)</li> <li>(When Boom Priority EPPR Current is more than 10 mA)</li> <li>3 seconds continuous, Boom Priority EPPR drive current ≥ 10 mA</li> </ul>	•		
141	6	<ul> <li>(Detection)</li> <li>10 seconds continuous, Boom Priority EPPR drive current &gt; 1.0 A</li> <li>(Cancellation)</li> <li>3 seconds continuous, Boom Priority EPPR drive current ≤ 1.0 A</li> </ul>	•		
	1. Cor (Chec 1. CN	lts / Symptoms) htrol Function – Boom first control operation failure king list) -133 (#2) – CN-52 (#7) Checking Open/Short -133 (#1) – CN-52 (#17) Checking Open/Short			

DTC	;	Dia supposti a Cuitavi a	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	5	(Detection)  (When Travel EPPR Current is more than 10 mA)  10 seconds continuous, Travel EPPR drive current = 0 mA  (Cancellation)  (When Travel EPPR Current is more than 100 mA)  3 seconds continuous, Travel EPPR drive current ≥ 10 mA			•
143 (NA)	6	<ul><li>(Detection)</li><li>10 seconds continuous, Travel EPPR drive current &gt; 1.0 A</li><li>(Cancellation)</li><li>3 seconds continuous, Travel EPPR drive current ≤ 1.0 A</li></ul>			•
	(Resu	lts / Symptoms)			
	(Chec	ntrol Function – cruise control operation failure king list) -246 (#2) – CN-54 (#39) Checking Open/Short -246 (#1) – CN-51 (#40) Checking Open/Short			
	5	(Model Parameter) mounting Remote Cooling Fan EPPR (Detection)  (When Remote Cooling Fan EPPR Current is more than 10 mA)  10 seconds continuous, Remote Cooling Fan EPPR drive current = 0 mA (Cancellation)  (When Remote Cooling Fan EPPR Current is more than 10 mA)  3 seconds continuous, Remote Cooling Fan EPPR drive current ≥ 10 mA	•		
145 (NA)	6	<ul> <li>(Detection)</li> <li>10 seconds continuous, Remote Cooling Fan EPPR drive current &gt; 1.0 A</li> <li>(Cancellation)</li> <li>3 seconds continuous, Remote Cooling Fan EPPR drive current ≤ 1.0 A</li> </ul>	•		
	1. Cor (Chec 1. CD-	lts / Symptoms) htrol Function – Remote fan control operation failure king list) -385 (#3) – CN-51 (#9) Checking Open/Short -385 (#1) – CN-51 (#14) Checking Open/Short			

DTC		Dia manadia Critaria	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
164 (NA)	4	(Detection)  (When Working Cutoff Relay is Off)  10 seconds continuous, Working Cutoff Relay drive unit Measurement Voltage ≤ 3.0V  (Cancellation)  (When Working Cutoff Relay is Off)  3 seconds continuous, Working Cutoff Relay drive unit Measurement Voltage > 3.0V  (Detection)  (When Working Cutoff Relay is On)  10 seconds continuous, Working Cutoff Relay drive current > 6.5 A  (Cancellation)  (When Working Cutoff Relay is On)	<u>G</u>	C	•
	1. Cor (Chec 1. CR	3 seconds continuous, Working Cutoff Relay drive current ≤ 6.5 A  lits / Symptoms)  ntrol Function – (Wheel Excavator) In driving mode, attachment hydraulic pilot properties failure  sking list)  -47 (#85) – CN-54 (#9) Checking Open/Short  -47 (#30, #86) – Fuse box (#28) Checking Open/Short	ressu	re cut	off
166	4	(Detection)  (When Power Max Solenoid is Off)  10 seconds continuous, Power Max Solenoid drive unit Measurement Voltage ≤ 3.0V  (Cancellation)  (When Power Max Solenoid is Off)  3 seconds continuous, Power Max Solenoid drive unit Measurement Voltage > 3.0V  (Detection)	•		
	1. Cor (Chec	(When Power Max Solenoid is On)  5 seconds continuous, Power Max Solenoid drive current > 4.5 A (Cancellation) (When Power Max Solenoid is On)  3 seconds continuous, Power Max Solenoid drive current ≤ 4.5 A  lts / Symptoms) ntrol Function – Voltage increase operation failure sking list) -88 (#1) – CN-52 (#2) Checking Open/Short	•		

 $\mbox{G : General} \qquad \qquad \mbox{C : Crawler Type} \qquad \qquad \mbox{W : Wheel Type}$ 

DTC	;	Dia manatia Critaria	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
		(Detection) (When Travel Speed Solenoid is Off) 10 seconds continuous, Travel Speed Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Travel Speed Solenoid is Off) 3 seconds continuous, Travel Speed Solenoid drive unit Measurement Voltage > 3.0V		•	
167	4	(When Parking mode is not) (Detection) (When Travel Speed Solenoid is Off) 10 seconds continuous, Travel Speed Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Travel Speed Solenoid is Off) 3 seconds continuous, Travel Speed Solenoid drive unit Measurement Voltage > 3.0V			•
	6	(Detection)  (When Travel Speed Solenoid is On)  10 seconds continuous, Travel Speed Solenoid drive current > 4.5 A  (Cancellation)  (When Travel Speed Solenoid is On)  3 seconds continuous, Travel Speed Solenoid drive current ≤ 4.5 A	•		
	1. Cor (Chec 1. CN	olts / Symptoms) Introl Function – driving in 1/2 transmission operation failure Eking list) Introl Function – driving in 1/2 transmission operation failure Introl Function – driving in 1/2			

Monitor - Selecting attachment(breaker / crusher) (Detection) (Obtection) (	DTC	<del>,</del>	Diagnostic Criteria	Ар	plicati	ion
(Detection) (When Attachment Conflux Solenoid is Off)  10 seconds continuous, Attachment Conflux Solenoid drive unit  4 Measurement Voltage ≤ 3.0V (Cancellation) (When Attachment Conflux Solenoid is Off) 3 seconds continuous, Attachment Conflux Solenoid drive unit Measurement Voltage > 3.0V (Detection) (When Attachment Conflux Solenoid is On) 10 seconds continuous, Attachment Conflux Solenoid drive Current > 6.5 A (Cancellation) (When Attachment Conflux Solenoid is On) 3 seconds continuous, Attachment Conflux Solenoid drive Current ≤ 6.5 A (Results / Symptoms) 1. Control Function – Option attachment flow control – Joining operation failure (Eco breaker mode, crusher mode) (Checking list) 1. CN-237 (#1) – CN-52 (#6) Checking Open/Short  (Model Parameter) mounting Arm Regenerating Solenoid (Detection) (When Arm Regeneration Solenoid is Off) 10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off) 3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V (Cancellation) (When Arm Regeneration Solenoid is On) 10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Results / Symptoms) 1. Control Function – Arm regeneration Solenoid drive current ≤ 4.5 A (Results / Symptoms) 1. Control Function – Arm regeneration operation failure (Checking list) 1. CN-135 (#1) – CN-52 (#1) Checking Open/Short	HCESPN	FMI	Diagnostic Criteria	G	С	W
(Detection)  (When Attachment Conflux Solenoid is On)  10 seconds continuous, Attachment Conflux Solenoid drive Current > 6.5 A (Cancellation) (When Attachment Conflux Solenoid is On) 3 seconds continuous, Attachment Conflux Solenoid drive Current ≤ 6.5 A  (Results / symptoms) 1. Control Function – Option attachment flow control – Joining operation failure (Eco breaker mode, crusher mode) (Checking list) 1. CN-237 (#1) – CN-52 (#6) Checking Open/Short 2. CN-237 (#2) – Fuse box (#30) Checking Open/Short  (Model Parameter) mounting Arm Regenerating Solenoid (Detection) (When Arm Regeneration Solenoid is Off) 10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement 4 Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off) 3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V (Detection) (When Arm Regeneration Solenoid is On) 10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A (Results / symptoms) 1. Control Function – Arm regeneration operation failure (Checking list) 1. CN-135 (#1) – CN-52 (#1) Checking Open/Short		4	(Detection)  (When Attachment Conflux Solenoid is Off)  10 seconds continuous, Attachment Conflux Solenoid drive unit Measurement Voltage ≤ 3.0V  (Cancellation)  (When Attachment Conflux Solenoid is Off)	•		
(Results / symptoms)  1. Control Function – Option attachment flow control – Joining operation failure (Eco breaker mode, crusher mode) (Checking list)  1. CN-237 (#1) – CN-52 (#6) Checking Open/Short  2. CN-237 (#2) – Fuse box (#30) Checking Open/Short  (Model Parameter) mounting Arm Regenerating Solenoid (Detection) (When Arm Regeneration Solenoid is Off)  10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement  4 Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off)  3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V  (Detection) (When Arm Regeneration Solenoid is On)  10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A  (Results / symptoms) 1. Control Function – Arm regeneration operation failure (Checking list) 1. CN-135 (#1) – CN-52 (#1) Checking Open/Short	169	6	(Detection) (When Attachment Conflux Solenoid is On) 10 seconds continuous, Attachment Conflux Solenoid drive Current > 6.5 A (Cancellation) (When Attachment Conflux Solenoid is On)	•		
1. Control Function – Option attachment flow control – Joining operation failure (Eco breaker mode, crusher mode) (Checking list)  1. CN-237 (#1) – CN-52 (#6) Checking Open/Short  2. CN-237 (#2) – Fuse box (#30) Checking Open/Short  (Model Parameter) mounting Arm Regenerating Solenoid (Detection) (When Arm Regeneration Solenoid is Off)  10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement  Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off)  3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V  (Detection) (When Arm Regeneration Solenoid is On) 10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A  (Results / symptoms) 1. Control Function – Arm regeneration operation failure (Checking list) 1. CN-135 (#1) – CN-52 (#1) Checking Open/Short		(Resu				
(Eco breaker mode, crusher mode) (Checking list)  1. CN-237 (#1) — CN-52 (#6) Checking Open/Short  2. CN-237 (#2) — Fuse box (#30) Checking Open/Short  (Model Parameter) mounting Arm Regenerating Solenoid (Detection) (When Arm Regeneration Solenoid is Off)  10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement  4 Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off) 3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V  (Detection) (When Arm Regeneration Solenoid is On) 10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A  (Results / symptoms) 1. Control Function — Arm regeneration operation failure (Checking list) 1. CN-135 (#1) — CN-52 (#1) Checking Open/Short		,				
(Checking list)  1. CN-237 (#1) — CN-52 (#6) Checking Open/Short  2. CN-237 (#2) — Fuse box (#30) Checking Open/Short  (Model Parameter) mounting Arm Regenerating Solenoid (Detection)  (When Arm Regeneration Solenoid is Off)  10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement  4 Voltage ≤ 3.0V  (Cancellation)  (When Arm Regeneration Solenoid is Off)  3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V  (Detection)  (When Arm Regeneration Solenoid is On)  10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A  (Cancellation)  (When Arm Regeneration Solenoid is On)  3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A  (Results / symptoms)  1. Control Function — Arm regeneration operation failure  (Checking list)  1. CN-135 (#1) — CN-52 (#1) Checking Open/Short						
1. CN-237 (#1) – CN-52 (#6) Checking Open/Short 2. CN-237 (#2) – Fuse box (#30) Checking Open/Short  (Model Parameter) mounting Arm Regenerating Solenoid (Detection) (When Arm Regeneration Solenoid is Off) 10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement  Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off) 3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V  (Detection) (When Arm Regeneration Solenoid is On) 10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A  (Results / symptoms) 1. Control Function – Arm regeneration operation failure (Checking list) 1. CN-135 (#1) – CN-52 (#1) Checking Open/Short		,				
2. CN-237 (#2) – Fuse box (#30) Checking Open/Short  (Model Parameter) mounting Arm Regenerating Solenoid (Detection) (When Arm Regeneration Solenoid is Off) 10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement 4 Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off) 3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V  (Detection) (When Arm Regeneration Solenoid is On) 10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A  (Results / symptoms) 1. Control Function – Arm regeneration operation failure (Checking list) 1. CN-135 (#1) – CN-52 (#1) Checking Open/Short		l ,				
(Model Parameter) mounting Arm Regenerating Solenoid (Detection) (When Arm Regeneration Solenoid is Off) 10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement 4 Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off) 3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V  (Detection) (When Arm Regeneration Solenoid is On) 10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A  (Results / symptoms) 1. Control Function – Arm regeneration operation failure (Checking list) 1. CN-135 (#1) – CN-52 (#1) Checking Open/Short						
(Detection) (When Arm Regeneration Solenoid is Off)  10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement  4 Voltage ≤ 3.0V (Cancellation) (When Arm Regeneration Solenoid is Off)  3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V  (Detection) (When Arm Regeneration Solenoid is On)  10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A (Cancellation) (When Arm Regeneration Solenoid is On) 3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A  (Results / symptoms) 1. Control Function – Arm regeneration operation failure (Checking list) 1. CN-135 (#1) – CN-52 (#1) Checking Open/Short		2. OIV				
(NA)  (When Arm Regeneration Solenoid is On)  10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A  (Cancellation)  (When Arm Regeneration Solenoid is On)  3 seconds continuous, Arm Regeneration Solenoid drive current ≤ 4.5 A  (Results / symptoms)  1. Control Function – Arm regeneration operation failure  (Checking list)  1. CN-135 (#1) – CN-52 (#1) Checking Open/Short		4	(Detection)  (When Arm Regeneration Solenoid is Off)  10 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage ≤ 3.0V  (Cancellation)  (When Arm Regeneration Solenoid is Off)  3 seconds continuous, Arm Regeneration Solenoid drive unit Measurement Voltage > 3.0V	•		
<ol> <li>Control Function – Arm regeneration operation failure</li> <li>(Checking list)</li> <li>CN-135 (#1) – CN-52 (#1) Checking Open/Short</li> </ol>		6	(When Arm Regeneration Solenoid is On)  10 seconds continuous, Arm Regeneration Solenoid drive current > 4.5 A  (Cancellation)  (When Arm Regeneration Solenoid is On)	•		
<ol> <li>Control Function – Arm regeneration operation failure</li> <li>(Checking list)</li> <li>CN-135 (#1) – CN-52 (#1) Checking Open/Short</li> </ol>		(Resu	lts / symptoms)			
(Checking list) 1. CN-135 (#1) – CN-52 (#1) Checking Open/Short		l ,				
1. CN-135 (#1) – CN-52 (#1) Checking Open/Short			·			
		l ,				
, , , , , , , , , , , , , , , , , , ,						

DTC		Discussion Cuitavia	Ap	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
	4	Monitor – Selecting attachment(crusher) (Detection) (When Attachment Safety Solenoid is Off) 10 seconds continuous, Attachment Safety Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Attachment Safety Solenoid is Off) 3 seconds continuous, Attachment Safety Solenoid drive unit Measurement Voltage > 3.0V	•		
171	6	(Detection)  (When Attachment Safety Solenoid is On)  10 seconds continuous, Attachment Safety Solenoid drive current > 6.5 A  (Cancellation)  (When Attachment Safety Solenoid is On)  3 seconds continuous, Attachment Safety Solenoid drive current ≤ 6.5 A	•		
	(Resu	Its / Symptoms)			
	,	ntrol Function - Option attachment flow control - Option spool pilot pressur	e cut	off fa	ilure
	(crush	ner mode)			
	(Chec	king list)			
	1. CN-	-149 (#1) – CN-52 (#4) Checking Open/Short			
	2. CN-	-149 (#2) – Fuse box (#30) Checking Open/Short			
	4	Monitor – Selecting attachment(breaker / crusher) (Detection) (When Breaker Operating Solenoid is Off) 10 seconds continuous, Attachment Safety Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Breaker Operating Solenoid is Off) 3 seconds continuous, Attachment Safety Solenoid drive unit Measurement Voltage > 3.0V	•		
179	6	(Detection)  (When Breaker Operating Solenoid is On)  10 seconds continuous, Attachment Safety Solenoid drive current > 6.5 A  (Cancellation)  (When Breaker Operating Solenoid is On)  3 seconds continuous, Attachment Safety Solenoid drive current ≤ 6.5 A	•		
	1. Cor (Chec 1. CN-	lts / Symptoms) htrol Function – Option attachment flow control – Breaker operation failure (breaking list) -66 (#1) – CN-15 (#11) Checking Open/Short -66 (#2) – CR-62 (#5) Checking Open/Short	ker m	ode)	

DTC	,	Diagnostia Critoria	Ар	plicat	ion
HCESPN	FMI	Diagnostic Criteria	G	С	W
181	4	<ul> <li>(Model Parameter) mounting Reverse Cooling Fan Solenoid</li> <li>(Detection)</li> <li>(When Reverse Cooling Fan Solenoid is Off)</li> <li>10 seconds continuous, Reverse Cooling Fan Solenoid drive unit Measurement Voltage ≤ 3.0V</li> <li>(Cancellation)</li> <li>(When Reverse Cooling Fan Solenoid is Off)</li> <li>3 seconds continuous, Reverse Cooling Fan Solenoid drive unit Measurement Voltage &gt; 3.0V</li> </ul>	•		
(NA)	6	(Detection)  (When Reverse Cooling Fan Solenoid is On)  10 seconds continuous, Reverse Cooling Fan Solenoid drive current > 4.5 A  (Cancellation)  (When Reverse Cooling Fan Solenoid is On)  3 seconds continuous, Reverse Cooling Fan Solenoid drive current ≤ 4.5 A	•		
	(Resu	lts / Symptoms)			
	1. Cor	ntrol Function – Cooling Fan reverse control operation failure (not applicable)			
	5	<ul> <li>(Detection)</li> <li>(When Attachment Flow EPPR 1 current is equal or more than 300 mA)</li> <li>10 seconds continuous, Attachment Flow EPPR drive current &lt; 100 mA</li> <li>(Cancellation)</li> <li>(When Attachment Flow EPPR 1 current is equal or more than 300 mA)</li> <li>3 seconds continuous, Attachment Flow EPPR drive current ≥ 100 mA</li> </ul>	•		
188	6	(Detection) 10 seconds continuous, Attachment Flow EPPR 1 drive current > 1.0 A (Cancellation) 3 seconds continuous, Attachment Flow EPPR 1 drive current ≤ 1.0 A	•		
	1. Cor (Chec 1. CN	lts / Symptoms) htrol Function – IPC operation failure, Option attachment flow control operation fills flow list) -242 (#2) – CN-52 (#10) Checking Open/Short -242 (#1) – CN-52 (#20) Checking Open/Short	ailure		

 $<sup>\</sup>ensuremath{\,\%\,}$  Some error codes are not applied to this machine.

DTC	;	Diagnostia Critaria	Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W
189	5	(Detection)  (When Attachment Flow EPPR 2 current is equal or more than 300 mA)  10 seconds continuous, Attachment Flow EPPR drive current < 100 mA  (Cancellation)  (When Attachment Flow EPPR 2 current is equal or more than 300 mA)  3 seconds continuous, Attachment Flow EPPR drive current ≥ 100 mA	•		
	6	(Detection)  10 seconds continuous, Attachment Flow EPPR 2 drive current > 1.0 A  (Cancellation)  3 seconds continuous, Attachment Flow EPPR 2 drive current ≤ 1.0 A	•		
	1. Cor (Chec 1. CN-	lts / Symptoms)  htrol Function – Option attachment flow control operation failure  king list)  -242A (#2) – CN-52 (#40) Checking Open/Short  -242A (#1) – CN-52 (#16) Checking Open/Short			
196 (NA)	0	HW145 10 seconds continuous, Attachment flow control EPPR 1 press. Sensor Measurement Voltage > 5.2V HW145 10 seconds continuous,			
	4	0.3V≤ Attachment flow control EPPR 1 press. Sensor Measurement Voltage < 0.8V  HW145  10 seconds continuous,  Attachment flow control EPPR 1 press. Sensor Measurement Voltage < 0.3V			
	1. Cor (Chec 1. CD- 2. CD-	Its / Symptoms)  Its / Symptoms)  Itrol Function – Driving second pump joining function operation failure king list)  Itrol Function – Driving second pump joining function operation failure king list)  Itrol Function – CN-52 (#34) Checking Open/Short  Itrol Function – CN-52 (#34) Checking Open/Short  Itrol Function – Driving second pump joining function operation failure  Itrol Function – CN-52 (#34) Checking Open/Short			
200	0 1 4	10 seconds continuous, Pump EPPR Press. Sensor Measurement Voltage > 5.2V  10 seconds continuous, 0.3V≤ Pump EPPR Press. Sensor Measurement Voltage < 0.8V  10 seconds continuous, Pump EPPR Press. Sensor Measurement Voltage < 0.3V	•		
	1. Mor 2. Cor (Fuel	Its / Symptoms)  nitor – Pump EPPR Press. display failure  ntrol Function – Pump input horse power control failure, Overload at compensat  operation failure  efficiency/speed performance failure)  king list)	ion cc	ontrol	
	1. CD- 2. CD-	-44 (#B) – CN-52 (#32) Checking Open/Short -44 (#A) – CN-51 (#3) Checking Open/Short -44 (#C) – CN-51 (#13) Checking Open/Short			

DTC		Diagnostia Critoria	Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W
	0	(Mounting pressure sensor)  10 seconds continuous, Boom Cylinder Rod Press. Sensor Measurement Voltage > 5.2V	•		
	1	(Mounting pressure sensor)  10 seconds continuous, 0.3V≤ Boom Cylinder Rod Press. Sensor Measurement Voltage < 0.8V	•		
205 (NA)	4	(Mounting pressure sensor)  10 seconds continuous, Boom Cylinder Rod Press. Sensor Measurement Voltage < 0.3V	•		
	1. Moi 2. Cor (Chec 1. CD 2. CD	lts / Symptoms) nitor – Boom Cylinder Rod Press. display failure ntrol Function – Boom floating control operation failure sking list) -124 (#B) – CN-53 (#5) Checking Open/Short -124 (#A) – CN-53 (#3) Checking Open/Short -124 (#C) – CN-53 (#13) Checking Open/Short			
218 (NA)	4	Mounting pressure sensor (HCESPN128 or HCESPN 205) (Detection) (When Boom Up Floating Solenoid is Off) 10 seconds continuous, Boom Up Floating Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Boom Up Floating Solenoid is Off) 3 seconds continuous, Boom Up Floating Solenoid drive unit Measurement Voltage > 3.0V	•		
	6	(Detection)  (When Boom Up Floating Solenoid is On)  10 seconds continuous, Boom Up Floating Solenoid drive current > 6.5 A  (Cancellation)  (When Boom Up Floating Solenoid is On)  3 seconds continuous, Boom Up Floating Solenoid drive current ≤ 6.5 A	•		
	1. Cor (Chec 1. CN	ults / Symptoms) htrol Function – Boom floating control operation failure king list) -368 (#1) – CN-53 (#20) Checking Open/Short -368 (#2) – Fuse box (#17) Checking Open/Short			

DTC		Discounting Office in		Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W	
	4	Mounting pressure sensor (HCESPN 128 or 205) (Detection) (When Boom Down Pilot Pressure Cutoff Solenoid is Off) 10 seconds continuous, Boom Down Pilot Pressure Cutoff Solenoid drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Boom Down Pilot Pressure Cutoff Solenoid is Off) 3 seconds continuous, Boom Down Pilot Pressure Cutoff Solenoid drive unit Measurement Voltage > 3.0V	•			
220 (NA)	6	(Detection)  (When Boom Down Pilot Pressure Cutoff Solenoid is On)  10 seconds continuous, Boom Down Pilot Pressure Cutoff Solenoid drive current > 6.5 A  (Cancellation)  (When Boom Down Pilot Pressure Cutoff Solenoid is On)  3 seconds continuous, Boom Down Pilot Pressure Cutoff Solenoid drive current ≤ 6.5 A	•			
	1. Cor (Chec 1. CN-	otrol Function – Boom floating control operation failure king list)  -369 (#1) – CN-53 (#35) Checking Open/Short				
	2. CN-	-369 (#2) – Fuse box (#17) Checking Open/Short  Monitor – Selecting attachment(breaker / crusher)  (Detection)  (When ATT Relief Setting EPPR 1 Current is equal or more than 10 mA)  10 seconds continuous, ATT Relief Setting EPPR 1 drive current = 0 mA  (Cancellation)  ATT Relief Setting EPPR 1 Current is equal or more than 10 mA)  3 seconds continuous, ATT Relief Setting EPPR 1 drive current ≥ 10 mA	•			
221 (NA)	6	(Detection) 10 seconds continuous, ATT Relief Setting EPPR 1 drive current > 1.0 A (Cancellation) 3 seconds continuous, ATT Relief Setting EPPR 1 drive current ≤ 1.0 A	•			
	1. Cor (Chec 1. CN-	lts / Symptoms) htrol Function — Option attachment flow control — P1 relief pressure setting failur king list) -365 (#2) — CN-53 (#39) Checking Open/Short -365 (#1) — CN-53 (#40) Checking Open/Short	e			

DTC		Discounting Office in		Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W	
222 (NA)	5	Monitor – Selecting attachment(crusher) (Detection) (When ATT Relief Setting EPPR 2 Current is equal or more than 10 mA) 10 seconds continuous, ATT Relief Setting EPPR 2 drive current = 0 mA (Cancellation) (When ATT Relief Setting EPPR 2 Current is equal or more than 10 mA) 3 seconds continuous, ATT Relief Setting EPPR 2 drive current ≥ 10mA (Detection) 10 seconds continuous, ATT Relief Setting EPPR 2 drive current > 1.0 A (Cancellation)	•			
	<b>/D</b>	3 seconds continuous, ATT Relief Setting EPPR 2 drive current ≤ 1.0 A				
	1. Cor (Chec 1. CN	lts / Symptoms) htrol Function – Option attachment flow control – P2 relief pressure setting fail king list) -366 (#2) – CN-53 (#32) Checking Open/Short -366 (#1) – CN-53 (#33) Checking Open/Short	ure			
	3	10 seconds continuous, Fuel Level Measurement Voltage > 3.8V	•			
	4	10 seconds continuous, Fuel Level Measurement Voltage < 0.3V				
301	(Chec	nitor – Fuel remaining display failure king list) -2 (#2) – CN-52 (#26) Checking Open/Short -2 (#1) – CN-51 (#11) Checking Open/Short				
325	4	(Model Parameter) mounting Fuel Heater Relay (Detection) (When Fuel Heater Relay is Off) 10 seconds continuous, Fuel Heater Relay drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Fuel Heater Relay is Off) 3 seconds continuous, Fuel Heater Relay drive unit Measurement Voltage > 3.0V	•			
	1. Cor (Chec	(Detection)  (When Fuel Heater Relay is On)  10 seconds continuous, Fuel Heater Relay drive current > 4.5 A  (Cancellation)  (When Fuel Heater Relay is On)  3 seconds continuous, Fuel Heater Relay drive current ≤ 4.5 A  lts / Symptoms)  ntrol Function – Fuel heater operation failure  king list)	•			
		-46 (#85) – CN-52 (#12) Checking Open/Short -46 (#30, #86) – Fuse box (#21) Checking Open/Short				

DTC	<u>;</u>	Diagnostia Critoria	Ap	plicat	ion				
HCESPN	FMI	Diagnostic Criteria	G	С	W				
	0	10 seconds continuous, Transmission Oil Press. Sensor Measurement							
		Voltage > 5.2V							
	1	10 seconds continuous, 0.3V≤ Transmission Oil Press. Sensor Measurement Voltage < 0.8V			•				
	4	10 seconds continuous, Transmission Oil Press. Sensor Measurement							
501	4	Voltage < 0.3V							
(NA)	(Resu	ults / Symptoms)							
	1. Mo	nitor – Transmission Oil Press. display failure, Transmission Oil low pressure war	ning	failure	<b>:</b>				
	(Ched	cking list)							
	1. CD	-5 (#B) – CN-54 (#27) Checking Open/Short							
	2. CD	-5 (#A) – CN-54 (#3) Checking Open/Short							
ı	3. CD	-5 (#C) – CN-54 (#13) Checking Open/Short							
	0	10 seconds continuous, Brake Oil Press. Sensor							
	0	Measurement Voltage > 5.2V							
	1	10 seconds continuous, 0.3V≤ Brake Oil Press. Sensor Measurement							
		Voltage < 0.8V							
	4	10 seconds continuous, Brake Oil Press. Sensor							
503		Measurement Voltage < 0.3V							
(NA)	(Results / Symptoms)								
	1. Monitor – Brake Oil Press. display failure, Brake Oil low pressure warning failure								
	(Checking list)								
	1. CD-3 (#B) – CN-54 (#4) Checking Open/Short								
	2. CD-3 (#A) - CN-54 (#3) Checking Open/Short								
	3. CD	-3 (#C) – CN-54 (#13) Checking Open/Short							
	0	10 seconds continuous, Working Brake Press. Sensor Measurement Voltage > 5.2V			•				
	1	10 seconds continuous, 0.3V≤ Working Brake Press. Sensor Measurement							
		Voltage < 0.8V							
505	4	10 seconds continuous, Working Brake Press. Sensor Measurement Voltage < 0.3V			•				
505 (NA)	(Resi	ults / Symptoms)		1	I				
(1471)	Monitor – Working Brake Oil Press. display failure, Working Brake Oil low pressure warning failure								
		(Checking list)							
	1. CD-38 (#B) – CN-54 (#5) Checking Open/Short								
		2. CD-38 (#A) – CN-54 (#3) Checking Open/Short							
		1-38 (#C) – CN-54 (#13) Checking Open/Short							
		( ) - ( -) ( -) ( -)							

DTC	<u>,</u>	Diagnostia Critoria	Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W
	4	(Detection)  (When Parking Relay is Off)  10 seconds continuous, Parking Relay drive unit  Measurement Voltage ≤ 3.0V  (Cancellation)  (When Parking Relay is Off)  3 seconds continuous, Parking Relay drive unit  Measurement Voltage > 3.0V			•
514 (NA)	6	(Detection)  (When Parking Relay is On)  10 seconds continuous, Parking Relay drive current > 6.5 A  (Cancellation)  (When Parking Relay is On)  3 seconds continuous, Parking Relay drive current ≤ 6.5 A			•
	(Resu	Its / Symptoms)		l	
	(Chec	ntrol Function – Parking Relay operation failure king list) -66 (#1) – CN-54 (#20) Checking Open/Short -66 (#2) – Fuse box (#30) Checking Open/Short			
517 (NA)	4	(Detection) (When Traveling Cutoff Relay is Off) 10 seconds continuous, Traveling Cutoff Relay drive unit Measurement Voltage ≤ 3.0V (Cancellation) (When Traveling Cutoff Relay is Off) 3 seconds continuous, Traveling Cutoff Relay drive unit Measurement Voltage > 3.0V			•
	6	(Detection)  (When Traveling Cutoff Relay is On)  10 seconds continuous, Traveling Cutoff Relay drive current > 6.5 A  (Cancellation)  (When Traveling Cutoff Relay is On)  3 seconds continuous, Traveling Cutoff Relay drive current ≤ 6.5 A			•
	1. Cor (Chec 1. CR	lts / Symptoms) htrol Function – Traveling Cutoff Relay operation failure king list) -47 (#85) – CN-54 (#9) Checking Open/Short -47 (#86) – Fuse box (#28) Checking Open/Short			

DTC		Diagnostia Critaria		Application		
HCESPN	FMI	Diagnostic Criteria	G	С	W	
525 (NA)	4	(Detection)  (When Ram Lock Solenoid is Off)  10 seconds continuous, Ram Lock Solenoid drive unit Measurement Voltage ≤ 3.0V  (Cancellation)  (When Ram Lock Solenoid is Off)  3 seconds continuous, Ram Lock Solenoid drive unit Measurement Voltage > 3.0V			•	
	6	(Detection)  (When Ram Lock Solenoid is On)  10 seconds continuous, Ram Lock Solenoid drive current > 6.5 A  (Cancellation)  (When Ram Lock Solenoid is On)  3 seconds continuous, Ram Lock Solenoid drive current ≤ 6.5 A			•	
	(Resu	Its / Symptoms)				
	1. Cor (Chec 1. CN-	ntrol Function – Ram lock control operation failure king list) -69 (#1) – CN-54 (#8) Checking Open/Short -69 (#2) – Fuse box (#33) Checking Open/Short				
	4	(Detection)  (When Creep Solenoid is Off)  10 seconds continuous, Creep Solenoid drive unit  Measurement Voltage ≤ 3.0V  (Cancellation)  (When Creep Solenoid is Off)  3 seconds continuous, Creep Solenoid drive unit  Measurement Voltage > 3.0V			•	
527 (NA)	6	(Detection)  (When Creep Solenoid is On)  10 seconds continuous, Creep Solenoid drive current > 6.5 A  (Cancellation)  (When Creep Solenoid is On)  3 seconds continuous, Creep Solenoid drive current ≤ 6.5 A			•	
	1. Cor (Chec 1. CN-	lts / Symptoms) htrol Function – Creep mode operation failure king list) -206 (#1) – CN-54 (#7) Checking Open/Short -206 (#2) – Fuse box (#30) Checking Open/Short				

DTC		Diamenatia Critaria		plicat	ion			
HCESPN	FMI	Diagnostic Criteria		С	W			
	0	0 10 seconds continuous, Travel Forward Press. Sensor Measurement Voltage > 5.2V						
	1	10 seconds continuous, $0.3V \le$ Travel Forward Press. Sensor Measurement Voltage $< 0.8V$			•			
	4	10 seconds continuous, Travel Forward Press. Sensor Measurement Voltage < 0.3V			•			
530	(Resu	Its / Symptoms)						
(NA)	1. Mor	nitor – Travel Forward Press. display failure						
		ntrol Function – Driving interoperability power control operation failure king list)						
	1. CD-	-73 (#B) – CN-54 (#6) Checking Open/Short						
	2. CD-	73 (#A) – CN-54 (#3) Checking Open/Short						
	3. CD-	-73 (#C) – CN-54 (#13) Checking Open/Short						
	1	10 seconds continuous, $0.3V \le$ Travel Reverse Press. Sensor Measurement Voltage $< 0.8V$			•			
	4	10 seconds continuous, Travel Reverse Press. Sensor Measurement Voltage < 0.3V			•			
504	(Results / Symptoms)							
531	1. Mor	nitor – Travel Reverse Press. display failure						
(NA)	2. Cor	2. Control Function – Driving interoperability power control operation failure						
	(Checking list)							
	1. CD-74 (#B) – CN-54 (#23) Checking Open/Short							
	2. CD-74 (#A) - CN-54 (#3) Checking Open/Short							
	3. CD-	74 (#C) – CN-54 (#13) Checking Open/Short						
	0	10 seconds continuous, Battery input Voltage > 35V						
	1	10 seconds continuous, Battery input Voltage < 18V	•					
705	(Resu	lts / Symptoms)						
	1. Cor	ntrol Function – Startup impossibility						
	(Checking list)							
	1. CS-74A (#1) – CN-51 (#1) Checking Open/Short							
		(When Engine is equal or more than 400 rpm) 10 seconds continuous,						
	1	Alternator Node I Measurement Voltage < 18V						
		(In case 12v goods, Alternator Node I Measurement Voltage < 9V)						
707	,	Its / Symptoms)						
		ntrol Function – Battery charging circuit failure						
	(Checking list)							
	1. CS-	74A (#1) – CN-51 (#2) Checking Open/Short						

 $\ensuremath{\,\%\,}$  Some error codes are not applied to this machine.

G : General C : Crawler Type W : Wheel Type

DTC			Ар	Application			
HCESPN	FMI	Diagnostic Criteria	G	С	W		
	3	(Model Parameter) Mounting Acc. Dial					
	3	10 seconds continuous, Acc. Dial Measurement Voltage > 5.2V					
	4	(Model Parameter) Mounting Acc. Dial					
		10 seconds continuous, Acc. Dial Measurement Voltage < 0.3V					
714	(Resu	Its / Symptoms)					
	1. Mor	nitor – Acc. Dial Voltage display failure					
	2. Cor	ntrol Function – Engine rpm control failure					
	(Chec	king list)					
	1. CN-	-142 (#B) – CN-52 (#23) Checking Open/Short					
		(Detection)					
		(When Travel Alarm (Buzzer) Sound is Off)					
		10 seconds continuous, Travel Alarm (Buzzer) Sound Relay drive unit					
	4	Measurement Voltage ≤ 3.0V					
	4	(Cancellation)					
		(When Travel Alarm (Buzzer) Sound Relay is Off)					
		3 seconds continuous, Travel Alarm (Buzzer) Sound Relay drive unit					
		Measurement Voltage > 3.0V					
		(Detection)					
		(When Travel Alarm (Buzzer) Sound is On)					
722		10 seconds continuous, Travel Alarm (Buzzer) Sound Relay drive					
	6	current > 4.5 A					
		(Cancellation)					
		(When Travel Alarm (Buzzer) Sound is On)					
		3 seconds continuous, Travel Alarm (Buzzer) Sound Relay drive					
		current ≤ 4.5 A					
	(Resu	Its / Symptoms)					
	1. Cor	ntrol Function – Driving alarm operation failure					
	(Chec	king list)					
	1. CN-	-81 (#1) – CN-52 (#13) Checking Open/Short					
	2. CN-	-81 (#2) – Fuse box (#30) Checking Open/Short					
	2	(When mounting the A/C Controller)					
		60 seconds continuous, A/C Controller Communication Data Error					
	(Resu	Its / Symptoms)					
831	1. Cor	ntrol Function – A/C Controller operation failure					
	(Checking list)						
	1. CN-11 (#8) – CN-51 (#22) Checking Open/Short						
	2. CN-	-11 (#7) – CN-51 (#32) Checking Open/Short					
	2	60 seconds continuous, Cluster Communication Data Error	•				
	(Resu	lts / Symptoms)					
	,	ntrol Function – Cluster operation failure					
840		·					
	(Checking list)  1. CN-56A (#7) – CN-51 (#32) Checking Open/Short						
		-56A (#6) – CN-51 (#22) Checking Open/Short					
	2.014	Soft (110) Sit Si (1122) Shooting Openional					

<sup>\*</sup> Some error codes are not applied to this machine.

C : Crawler Type G: General

DTC	;	Dia manatia Critaria		Application				
HCESPN	FMI	Diagnostic Criteria	G	С	W			
	2	10 seconds continuous, ECM Communication Data Error	•					
	(Resu	Its / Symptoms)						
841	1. Cor	ntrol Function – ECM operation failure						
(NA)	(Chec	king list)						
	1. CN-	93 (#17) – CN-51 (#21) Checking Open/Short						
	2. CN-	93 (#18) – CN-51 (#31) Checking Open/Short						
	2	(When mounting the I/O Controller 1)						
		60 seconds continuous, I/O Controller 1 Communication Data Error						
845	(Resu	Its / Symptoms)						
(NA)	1. Cor	ntrol Function – I/O Controller 1 operation failure						
(14/4)	(Chec	king list)						
		-53 (#21) – CN-51 (#23) Checking Open/Short						
	2. CN-	-53 (#31) – CN-51 (#33) Checking Open/Short						
	2	(When mounting the Haptic Controller)						
		60 seconds continuous, Haptic Controller Communication Data Error						
848	(Results / Symptoms)							
(NA)	1. Control Function – Haptic Controller operation failure							
	(Checking list)							
	1. CN-8 (#2) – CN-51 (#22) Checking Open/Short							
	2. CN-	8 (#3) – CN-51 (#32) Checking Open/Short						
	2	(When mounting the RMCU)						
		60 seconds continuous, RMCU communication Data Error						
	١,	luts / Symptoms)						
850		ntrol Function – RMCU operation failure						
	(Checking list)							
		·125A (#3) – CN-51 (#22) Checking Open/Short ·125A (#11) – CN-51 (#32) Checking Open/Short						
	2. OIV	(When mounting the I/O Controller 2)						
	2	60 seconds continuous, I/O Controller 2 communication Data Error						
	(Ragu	Its / Symptoms)						
861	١,							
(NA)	Control Function – I/O Controller 2 operation failure     (Checking list)							
	,	53 (#21) – CN-51 (#23) Checking Open/Short						
		-53 (#31) – CN-51 (#33) Checking Open/Short						
	•.•	\ - / - · · · · · \						

 $\ensuremath{\,\%\,}$  Some error codes are not applied to this machine.

G : General C : Crawler Type W : Wheel Type

DTC		Diagrapatia Critaria		Application			
HCESPN	FMI	Diagnostic Criteria	G	С	W		
	2	(When mounting the AAVM)					
		60 seconds continuous, AAVM communication Data Error					
	(Resu						
866	1. Cor						
	(Chec						
	1. CN-	-401 (#15) – CN-51 (#22) Checking Open/Short					
	2. CN-	401 (#3) – CN-51 (#32) Checking Open/Short					
	2	60 seconds continuous, RDU communication Data Error					
	(Resu	Its / Symptoms)					
867	1. Cor	ntrol Function – RDU operation failure					
007	(Checking list)						
	1. CN-376 (#10) – CN-51 (#22) Checking Open/Short						
	2. CN-376 (#18) – CN-51 (#32) Checking Open/Short						
	2	60 seconds continuous, Switch Controller communication Data Error					
	(Results / Symptoms)						
868	1. Cor						
000	(Checking list)						
	1. CN-	1. CN-56A (#7) – CN-51 (#32) Checking Open/Short					
	2. CN-	-56A (#6) - CN-51 (#22) Checking Open/Short					
	2	(When mounting the BKCU)					
		60 seconds continuous, BKCU communication Data Error					
	(Resu	Its / Symptoms)					
869	1. Cor	ntrol Function – BKCU operation failure					
	(Chec	king list)					
		2B (#A) - CN-51 (#22) Checking Open/Short					
	2. CS-	2B (#B) – CN-51 (#32) Checking Open/Short					

 $\ensuremath{\,\%\,}$  Some error codes are not applied to this machine.

 ${\sf G:General} \qquad \qquad {\sf C:Crawler\,Type} \qquad \qquad {\sf W:Wheel\,Type}$ 

# 4. ENGINE FAULT CODE

Fault code	J1939 SPN	J1939 FMI	Item	Description
111	629	12	Controller #1	Engine control module critical internal failure - bad intelligent device or component
115	612	2	System diagnostic code # 2	Engine speed/position sensor circuit lost both of two signals from the magnetic pickup sensor - data erratic, intermittent, or incorrect
122	102	3	Boost pressure	Intake manifold pressure sensor circuit – voltage above normal, or shorted to high source
123	102	4	Boost pressure	Intake manifold pressure sensor circuit – voltage below normal, or shorted to low source
124	102	16	Boost pressure	Intake manifold 1 pressure - data valid but above normal operational range - moderately severe level
131	91	3	Accelerator pedal position	Accelerator pedal or lever position sensor circuit - voltage above normal, or shorted to high source
132	91	4	Accelerator pedal position	Accelerator pedal or lever position sensor circuit - voltage below normal, or shorted to low source
133	974	3	Remote accelerator	Remote accelerator pedal or lever position sensor circuit – voltage above normal, or shorted to high source
134	974	4	Remote accelerator	Remote accelerator pedal or lever position sensor circuit – voltage below normal, or shorted to low source
135	100	3	Engine oil pressure	Oil pressure sensor circuit - voltage above normal, or shorted to high source
141	100	4	Engine oil pressure	Oil pressure sensor circuit - voltage below normal, or shorted to low source
143	100	18	Engine oil pressure	Oil pressure low – data valid but below normal operational range - moderately severe level
144	110	3	Engine coolant temperature	Coolant temperature sensor circuit – voltage above normal, or shorted to high source
145	110	4	Engine coolant temperature	Coolant temperature sensor circuit – voltage below normal, or shorted to low source
146	110	16	Engine coolant temperature	Coolant temperature high - data valid but above normal operational range - moderately severe level
147	91	1	Accelerator pedal position	Accelerator pedal or lever position sensor circuit – abnormal frequency, pulse width, or period
148	91	0	Accelerator pedal position	Accelerator pedal or lever position sensor circuit – abnormal frequency, pulse width, or period
151	110	0	Engine coolant temperature	Coolant temperature high - data valid but above normal operational range - most severe level
153	105	3	Intake manifold #1 temp	Intake manifold air temperature sensor circuit - voltage above normal, or shorted to high source
154	105	4	Intake manifold #1 temp	Intake manifold air temperature sensor circuit - voltage below normal, or shorted to low source
155	105	0	Intake manifold #1 temp	Intake manifold air temperature high – data valid but above normal operational range - most severe level

<sup>\*</sup> Some fault codes are not applied to this machine.

Fault code	J1939 SPN	J1939 FMI	ltem	Description
187	3510	4	5 Volts dc supply	Sensor supply voltage #2 circuit – voltage below normal, or shorted to low source
193	520199	3	Cruise control	Cruise control (resistive) signal circuit - voltage above normal, or shorted to high source
194	520199	4	Cruise control	Cruise control (resistive) signal circuit - voltage below normal, or shorted to low source
195	111	3	Coolant level	Coolant level sensor circuit - voltage above normal, or shorted to high source
196	111	4	Coolant level	Coolant level sensor circuit - voltage below normal, or shorted to low source
197	111	18	Coolant level	Coolant level - data valid but below normal operational range - moderately severe level
199	1661	4	Engine automatic start lamp	Engine automatic start lamp driver circuit - voltage above normal, or shorted to high source
211	1484	31	J1939 error	Additional auxiliary diagnostic codes logged - condition exists
212	175	3	Oil temperature	Engine oil temperature sensor 1 circuit - voltage above normal, or shorted to high source
213	175	4	Oil temperature	Engine oil temperature sensor 1 circuit - voltage below normal, or shorted to low source
214	175	0	Oil temperature	Engine oil temperature - data valid but above normal operational range - most severe level
221	108	3	Barometric pressure	Barometric pressure sensor circuit – voltage above normal, or shorted to high source
222	108	4	Barometric pressure	Barometric pressure sensor circuit – voltage below normal, or shorted to low source
227	3510	3	5 Volts dc supply	Sensor supply voltage #2 circuit – voltage above normal, or shorted to high source
231	109	3	Coolant pressure	Coolant pressure sensor circuit - voltage above normal, or shorted to high source
232	109	4	Coolant pressure	Coolant pressure sensor circuit - voltage below normal, or shorted to low source
233	109	18	Coolant pressure	Coolant pressure - data valid but below normal operational range - moderately severe level
234	190	0	Engine speed	Engine speed high - data valid but above normal operational range - most severe level
235	111	1	Coolant level	Coolant level low - data valid but below normal operational range - most severe level
237	644	2	External speed input	External speed input (multiple unit synchronization) - data erratic, intermittent, or incorrect
238	3511	4	System diagnostic code # 1	Sensor supply voltage #3 circuit – voltage below normal, or shorted to low source
239	3511	3	System diagnostic code #2	Sensor supply voltage #3 circuit - voltage above normal, or shorted to high source
241	84	2	Wheel-based vehicle speed	Vehicle speed sensor circuit - data erratic, intermittent, or incorrect
242	84	10	Wheel-based vehicle speed	Vehicle speed sensor circuit tampering has been detected – abnormal rate of change

 $<sup>\</sup>ensuremath{\,\mathbb{X}\,}$  Some fault codes are not applied to this machine.

Fault code	J1939 SPN	J1939 FMI	ltem	Description
244	623	4	Red stop lamp	Red stop lamp driver circuit - voltage below normal, or shorted to low source
245	647	4	Fan clutch output device driver	Fan control circuit - voltage below normal, or shorted to low source
249	171	3	Ambient air temperature	Ambient air temperature sensor circuit - voltage above normal, or shorted to high source
256	171	4	Ambient air temperature	Ambient air temperature sensor circuit - voltage below normal, or shorted to low source
261	174	16	Fuel temperature	Engine fuel temperature - data valid but above normal operational range - moderately severe level
263	174	3	Fuel temperature	Engine fuel temperature sensor 1 circuit - voltage above normal, or shorted to high source
265	174	4	Fuel temperature	Engine fuel temperature sensor 1 circuit - voltage below normal, or shorted to low source
268	94	2	Fuel delivery pressure	Fuel pressure sensor circuit - data erratic, intermittent, or incorrect
271	1347	4	Fuel pump pressurizing assembly #1	High fuel pressure solenoid valve circuit – voltage below normal, or shorted to low source
272	1347	3	Fuel pump pressurizing assembly #1	High fuel pressure solenoid valve circuit – voltage above normal, or shorted to high source
281	1347	7	Fuel pump pressurizing assembly #1	High fuel pressure solenoid valve #1 – mechanical system not responding properly or out of adjustment
285	639	9	Sae J1939 datalink	SAE J1939 multiplexing pgn timeout error - abnormal update rate
286	639	13	Sae J1939 datalink	SAE J1939 multiplexing configuration error – out of calibration
287	91	19	Accelerator pedal position	SAE J1939 multiplexing accelerator pedal or lever sensor system error - received network data in error
288	974	19	Remote accelerator	SAE J1939 multiplexing remote accelerator pedal or lever data error - received network data in error
292	441	14	Auxiliary temperature 1	Auxiliary temperature sensor input 1 - special instructions
293	441	3	OEM Temperature	Auxiliary temperature sensor input # 1 circuit - voltage above normal, or shorted to high source
294	441	4	OEM Temperature	Auxiliary temperature sensor input # 1 circuit - voltage below normal, or shorted to low source
295	108	2	Barometric pressure	Barometric pressure sensor circuit - data erratic, intermittent, or incorrect
296	1388	14	Auxiliary pressure	Auxiliary pressure sensor input 1 - special instructions
297	1388	3	Auxiliary pressure	Auxiliary pressure sensor input # 2 circuit - voltage above normal, or shorted to high source
298	1388	4	Auxiliary pressure	Auxiliary pressure sensor input # 2 circuit - voltage below normal, or shorted to low source
319	251	2	Real time clock power	Real time clock power interrupt - data erratic, intermittent, or incorrect

<sup>\*</sup> Some fault codes are not applied to this machine.

Fault code	J1939 SPN	J1939 FMI	ltem	Description
322	651	5	Injector cylinder #01	Injector solenoid cylinder #1 circuit – current below normal, or open circuit
323	655	5	Injector cylinder #05	Injector solenoid cylinder #5 circuit – current below normal, or open circuit
324	653	5	Injector cylinder #03	Injector solenoid cylinder #3 circuit – current below normal, or open circuit
325	656	5	Injector cylinder #06	Injector solenoid cylinder #6 circuit – current below normal, or open circuit
331	652	5	Injector cylinder #02	Injector solenoid cylinder #2 circuit – current below normal, or open circuit
332	654	5	Injector cylinder #04	Injector solenoid cylinder #4 circuit – current below normal, or open circuit
334	110	2	Engine coolant temperature	Coolant temperature sensor circuit – data erratic, intermittent, or incorrect
338	1267	3	Vehicle accessories relay driver	Idle shutdown vehicle accessories relay driver circuit - voltage above normal, or shorted to high source
339	1267	4	Vehicle accessories relay driver	Idle shutdown vehicle accessories relay driver circuit - voltage below normal, or shorted to low source
342	630	13	Calibration memory	Electronic calibration code incompatibility - out of calibration
343	629	12	Controller #1	Engine control module warning internal hardware failure - bad intelligent device or component
349	191	16	Transmission output shaft speed	Transmission output shaft speed - data valid but above normal operational range - moderately severe level
351	3597	12	Controller #1	Injector power supply - bad intelligent device or component
352	3509	4	5 volts DC supply	Sensor supply voltage #1 circuit – voltage below normal, or shorted to low source
386	3509	3	5 volts DC supply	Sensor supply voltage #1 circuit – voltage above normal, or shorted to high source
415	100	1	Engine oil pressure	Oil pressure low – data valid but below normal operational range - most severe level
418	97	15	Water in fuel indicator	Water in fuel indicator high - data valid but above normal operational range - least severe level
422	111	2	Coolant level	Coolant level - data erratic, intermittent, or incorrect
425	175	2	Oil temperature	Engine oil temperature - data erratic, intermittent, or incorrect
428	97	3	Water in fuel indicator	Water in fuel sensor circuit - voltage above normal, or shorted to high source
429	97	4	Water in fuel indicator	Water in fuel sensor circuit - voltage below normal, or shorted to low source
431	558	2	Accelerator pedal low idle switch	Accelerator pedal or lever idle validation circuit - data erratic, intermittent, or incorrect
432	558	13	Accelerator pedal low idle switch	Accelerator pedal or lever idle validation circuit - out of calibration

<sup>\*</sup> Some fault codes are not applied to this machine.

Fault code	J1939 SPN	J1939 FMI	Item	Description
435	100	2	Engine oil pressure	Oil pressure sensor circuit - data erratic, intermittent, or incorrect
441	168	18	Electrical potential (voltage)	Battery #1 voltage low - data valid but below normal operational range – moderately severe level
442	168	16	Electrical potential (voltage)	Battery #1 voltage high - data valid but above normal operational range – moderately severe level
449	157	0	Injector metering rail 1 pressure	Fuel pressure high - data valid but above normal operational range – moderately severe level
451	157	3	Injector metering rail 1 pressure	Injector metering rail #1 pressure sensor circuit - voltage above normal, or shorted to high source
452	157	4	Injector metering rail 1 pressure	Injector metering rail #1 pressure sensor circuit - voltage below normal, or shorted to low source
488	105	16	Intake manifold	Intake manifold 1 temperature - data valid but above normal operational range - moderately severe level
489	191	18	Transmission output shaft speed	Transmission output shaft speed - data valid but below normal operational range - moderately severe level
497	1377	2	Switch circuit	Multiple unit synchronization switch circuit - data erratic, intermittent, or incorrect
523	611	2	System diagnostic code # 1	OEM Intermediate (PTO) speed switch validation - data erratic, intermittent, or incorrect
527	702	3	Circuit - voltage	Auxiliary input/output 2 circuit - voltage above normal, or shorted to high source
528	93	2	Switch - data	Auxiliary alternate torque validation switch - data erratic, intermittent, or incorrect
529	703	3	Circuit - voltage	Auxiliary input/output 3 circuit - voltage above normal, or shorted to high source
546	94	3	Fuel delivery pressure	Fuel delivery pressure sensor circuit - voltage above normal, or shorted to high source
547	94	4	Fuel delivery pressure	Fuel delivery pressure sensor circuit - voltage below normal, or shorted to low source
551	558	4	Accelerator pedal low idle switch	Accelerator pedal or lever idle validation circuit - voltage below normal, or shorted to low source
553	157	16	Injector metering rail 1 pressure	Injector metering rail #1 pressure high – data valid but above normal operational range - moderately severe level
554	157	2	Injector metering rail 1 pressure	Fuel pressure sensor error - data erratic, intermittent, or incorrect
559	157	18	Injector metering rail 1 pressure	Injector metering rail #1 pressure low – data valid but below normal operational range - moderately severe level
584	677	3	Starter solenoid lockout relay driver circuit	Starter relay circuit - voltage above normal, or shorted to high source
585	677	4	Starter solenoid lockout relay driver circuit	Starter relay circuit - voltage below normal, or shorted to low source
595	103	16	Turbocharger 1 speed	Turbocharger #1 speed high - data valid but above normal operational range - moderately severe level

<sup>\*</sup> Some fault codes are not applied to this machine.

Fault code	J1939 SPN	J1939 FMI	ltem	Description
596	167	16	Alternate potential (voltage)	Electrical charging system voltage high – data valid but above normal operational range - moderately severe level
597	167	18	Alternate potential (voltage)	Electrical charging system voltage low – data valid but below normal operational range - moderately severe level
598	167	1	Alternate potential (voltage)	Electrical charging system voltage low – data valid but below normal operational range - most severe level
599	640	14	Engine external protection input	Auxiliary commanded dual output shutdown - special instructions
649	1378	31	Engine oil change interval	Change lubricating oil and filter – condition exists
687	103	18	Turbocharger 1 speed	Turbocharger #1 speed low - data valid but below normal operational range – moderately severe level
689	190	2	Engine speed	Primary engine speed sensor error – data erratic, intermittent, or incorrect
691	1172	3	Turbocharger #1compressor inlet temperature	Turbocharger #1 compressor inlet temperature sensor circuit – voltage above normal, or shorted to high source
692	1172	4	Turbocharger #1compressor inlet temperature	Turbocharger #1 compressor inlet temperature sensor circuit – voltage below normal, or shorted to low source
697	1136	3	Sensor circuit - voltage	ECM internal temperature sensor circuit - voltage above normal, or shorted to high source
698	1136	4	Sensor circuit - voltage	Ecm internal temperature sensor circuit - voltage below normal, or shorted to low source
719	22	3	Crankcase pressure	Extended crankcase blow-by pressure circuit - voltage above normal, or shorted to high source
729	22	4	Crankcase pressure	Extended crankcase blow-by pressure circuit - voltage below normal, or shorted to low source
731	723	7	Engine speed sensor #2	Engine speed/position #2 mechanical misalignment between camshaft and crankshaft sensors - mechanical system not responding properly or out of adjustment
757	2802	31	Electronic control module	Electronic control module data lost - condition exists
778	723	2	Engine speed sensor #2	Engine speed sensor (camshaft) error – data erratic, intermittent, or incorrect
779	703	11	Auxiliary equipment sensor input	Warning auxiliary equipment sensor input # 3 (OEM switch) - root cause not known
951	166	2	Cylinder power	Cylinder power imbalance between cylinders - data erratic, intermittent, or incorrect
1117	3597	2	Power supply	Power lost with ignition on - data erratic, intermittent, or incorrect
1139	651	7	Injector cylinder # 01	Injector cylinder #1 - mechanical system not responding properly or out of adjustment
1141	652	7	Injector cylinder # 02	Injector cylinder #2 - mechanical system not responding properly or out of adjustment
1142	653	7	Injector cylinder # 03	Injector cylinder #3 - mechanical system not responding properly or out of adjustment

 $<sup>\</sup>ensuremath{\,\%\,}$  Some fault codes are not applied to this machine.

Fault code	J1939 SPN	J1939 FMI	ltem	Description
1143	654	7	Injector cylinder # 04	Injector cylinder #4 - mechanical system not responding properly or out of adjustment
1144	655	7	Injector cylinder # 05	Injector cylinder #5 - mechanical system not responding properly or out of adjustment
1145	656	7	Injector cylinder # 06	Injector cylinder #6 - mechanical system not responding properly or out of adjustment
1239	2623	3	Accelerator pedal position	Accelerator pedal or lever position sensor 2 circuit - voltage above normal, or shorted to high source
1241	2623	4	Accelerator pedal position	Accelerator pedal or lever position sensor 2 circuit - voltage below normal, or shorted to low source
1242	91	2	Accelerator pedal position	Accelerator pedal or lever position sensor 1 and 2 - data erratic, intermittent, or incorrect
1256	1563	2	Control module identification input state	Control module identification input state error - data erratic, intermittent, or incorrect
1257	1563	2	Control module identification input state	Control module identification input state error - data erratic, intermittent, or incorrect
1852	97	16	Water in fuel indicator	Water in fuel indicator - data valid but above normal operational range - moderately severe level
1911	157	0	Injector metering rail	Injector metering rail 1 pressure - data valid but above normal operational range - most severe level
2111	52	3	Coolant temperature	Coolant temperature 2 sensor circuit - voltage above normal, or shorted to high source
2112	52	4	Coolant temperature	Coolant temperature 2 sensor circuit - voltage below normal, or shorted to low source
2113	52	16	Coolant temperature	Coolant temperature 2 - data valid but above normal operational range - moderately severe level
2114	52	0	Coolant temperature	Coolant temperature 2 - data valid but above normal operational range - most severe level
2115	2981	3	Coolant pressure	Coolant pressure 2 circuit - voltage above normal, or shorted to high source
2116	2981	4	Coolant pressure	Coolant pressure 2 circuit - voltage below normal, or shorted to low source
2117	2981	18	Coolant pressure	Coolant pressure 2 - data valid but below normal operational range - moderately severe level
2182	1072	3	Engine brake output # 1	Engine brake actuator driver 1 circuit - voltage above normal, or shorted to high source
2183	1072	4	Engine brake output # 1	Engine brake actuator driver 1 circuit - voltage below normal, or shorted to low source
2185	3512	3	System diagnostic code # 1	Sensor supply voltage #4 circuit – voltage above normal, or shorted to high source
2186	3512	4	System diagnostic code # 1	Sensor supply voltage #4 circuit – voltage below normal, or shorted to low source
2195	703	14	Auxiliary equipment sensor	Auxiliary equipment sensor input 3 engine protection critical - special instructions
2215	94	18	Fuel delivery pressure	Fuel pump delivery pressure - data valid but below normal operational range - moderately severe level
2216	94	16	Fuel delivery pressure	Fuel pump delivery pressure - data valid but above normal operational range – moderately severe level

 $<sup>\</sup>ensuremath{\,\mathbb{X}\,}$  Some fault codes are not applied to this machine.

Fault code	J1939 SPN	J1939 FMI	ltem	Description
2217	630	31	Calibration memory	ECM program memory (RAM) corruption - condition exists
2249	157	1	Injector metering rail 1 pressure	Injector metering rail 1 pressure - data valid but below normal operational range - most severe level
2261	94	15	Fuel delivery pressure	Fuel pump delivery pressure - data valid but above normal operational range - least severe level
2262	94	17	Fuel delivery pressure	Fuel pump delivery pressure - data valid but below normal operational range - least severe level
2263	1800	16	Battery temperature	Battery temperature - data valid but above normal operational range - moderately severe level
2264	1800	18	Battery temperature	Battery temperature - data valid but below normal operational range - moderately severe level
2265	1075	3	Electric lift pump for engine fuel	Fuel priming pump control signal circuit – voltage above normal, or shorted to high source
2266	1075	4	Electric lift pump for engine fuel	Fuel priming pump control signal circuit – voltage below normal, or shorted to low source
2292	611	16	Fuel inlet meter device	Fuel inlet meter device - data valid but above normal operational range - moderately severe level
2293	611	18	Fuel inlet meter device	Fuel inlet meter device flow demand lower than expected - data valid but below normal operational range - moderately severe level
2311	633	31	Fuel control valve #1	Fueling actuator #1 circuit error – condition exists
2321	190	2	Engine speed	Engine speed / position sensor #1 - data erratic, intermittent, or incorrect
2322	723	2	Engine speed sensor #2	Engine speed / position sensor #2 - data erratic, intermittent, or incorrect
2345	103	10	Turbocharger 1 speed	Turbocharger speed invalid rate of change detected - abnormal rate of change
2346	2789	15	System diagnostic code #1	Turbocharger turbine inlet temperature (calculated) - data valid but above normal operational range – least severe level
2347	2629	15	System diagnostic code #1	Turbocharger compressor outlet temperature (calculated) - data valid but above normal operational range – least severe level
2363	1073	4	Engine compression brake output # 2	Engine brake actuator circuit #2 – voltage below normal, or shorted to low source
2365	1112	4	Engine brake output # 3	Engine brake actuator driver output 3 circuit - voltage below normal, or shorted to low source
2367	1073	3	Engine compression brake output # 2	Engine brake actuator circuit #2 – voltage above normal, or shorted to high source
2368	1112	3	Engine brake output # 3	Engine brake actuator driver 3 circuit - voltage above normal, or shorted to high source
2372	95	16	Engine fuel filter differential pressure	Fuel filter differential pressure - data valid but above normal operational range - moderately severe level
2373	1209	3	Exhaust gas pressure	Exhaust gas pressure sensor circuit - voltage above normal, or shorted to high source
2374	1209	4	Exhaust gas pressure	Exhaust gas pressure sensor circuit - voltage below normal, or shorted to low source


<sup>※</sup> Some fault codes are not applied to this machine.

Fault code	J1939 SPN	J1939 FMI	Item	Description
2375	412	3	Exhaust gas recirculation temperature	Exhaust gas recirculation temperature sensor circuit - voltage above normal, or shorted to high source
2376	412	4	Exhaust gas recirculation temperature	Exhaust gas recirculation temperature sensor circuit - voltage below normal, or shorted to low source
2377	647	3	Fan clutch output device driver	Fan control circuit - voltage above normal, or shorted to high source
2425	730	4	Intake air heater # 2	Intake air heater 2 circuit - voltage below normal, or shorted to low source
2426	730	3	Intake air heater # 2	Intake air heater 2 circuit - voltage above normal, or shorted to high source
2448	111	17	Coolant level	Coolant level - data valid but below normal operating range - least severe level
2555	729	3	Inlet air heater driver #1	Intake air heater #1 circuit - voltage above normal, or shorted to high source
2556	729	4	Inlet air heater driver #1	Intake air heater #1 circuit - voltage below normal, or shorted to low source
2557	697	3	Auxiliary PWM driver #1	Auxiliary PWM driver #1 - voltage above normal, or shorted to high source
2558	697	4	Auxiliary PWM driver #1	Auxiliary PWM driver #1 - voltage below normal, or shorted to low source
2963	110	15	Engine coolant temperature	Engine coolant temperature high - data valid but above normal operational range - least severe level
2973	102	2	Boost pressure	Intake manifold pressure sensor circuit - data erratic, intermittent, or incorrect

<sup>\*</sup> Some fault codes are not applied to this machine.

# **GROUP 13 ENGINE CONTROL SYSTEM**

## 1. MCU (Machine Control Unit)



220S5MS13

## 2. MCU ASSEMBLY

- To match the pump absorption torque with the engine torque, MCU varies EPPR valve output pressure, which control pump discharge amount whenever feedbacked engine speed drops under the reference rpm of each mode set.
- 2) Three LED lamps on the MCU display as below.

LED lamp	Trouble	Service
G is turned ON	Normal	-
G and R are turned ON	Trouble on MCU	· Change the MCU
G and Y are turned ON	Trouble on serial	· Check if serial communication
	communication line	lines between MCU and cluster are disconnected
Three LED are turned OFF	Trouble on MCU power	· Check if the input power wire (24 V, GND) of MCU
		is disconnected
		· Check the fuse

G: green, R: red, Y: yellow

## **GROUP 14 EPPR VALVE**

#### 1. PUMP EPPR VALVE

#### 1) COMPOSITION

EPPR (Electro Proportional Pressure Reducing) valve consists of electro magnet and spool valve installed at main pump.

#### (1) Electro magnet valve

Receive electric current from MCU and move the spool proportionally according to the specific amount of electric current value.

## (2) Spool valve

Is the two way direction control valve for pilot pressure to reduce main pump flow. When the electro magnet valve is activated, pilot pressure enters into flow regulator of main pump.

## (3) Pressure and electric current value for each mode

Mada	Pressure		Electric current	Engine rpm	
Mode	kgf/cm <sup>2</sup>	psi	(mA)	(at accel dial 10)	
	Р	10	142	340	1700
Standard (Stage : 1.0)	S	11	156	350	1600
(etage : 110)	E	15	213	400	1500
	Р	7	100	300	1700
Option (Stage : 2.0)	S	8	114	310	1600
(etage : 2.0)	Е	12	171	360	1600

#### 2) HOW TO SWITCH THE STAGE (1.0 $\leftrightarrow$ 2.0) ON THE CLUSTER

You can switch the EPPR valve pressure set by selecting the stage  $(1.0 \leftrightarrow 2.0)$ .

#### Management


· Service menu



· Power shift (standard/option): Power shift pressure can be set by option menu.

# 3) OPERATING PRINCIPLE (pump EPPR valve)


# (1) Structure



- 1 Sleeve
- 2 Spring
- 3 Spool

- 4 O-ring
- 5 O-ring


- 6 Solenoid valve
- 7 Connector




- P Pilot oil supply line (pilot pressure)
- T Return to tank
- A Secondary pressure to flow regulator at main pump

## (2) Neutral


Pressure line is blocked and A oil returns to tank.






# (3) Operating

Secondary pressure enters into A.






## 4) EPPR VALVE CHECK PROCEDURE


## (1) Check electric current value at EPPR valve

- ① Disconnect connector CN-75 from EPPR valve.
- ② Insert the adapter to CN-75 and install multimeter as figure.
- ③ Start engine.
- ④ Set S-mode and cancel auto decel mode.
- (5) Position the accel dial at 10.
- 6 If rpm display show approx 1600 $\pm$ 50 rpm check electric current at bucket circuit relief position.
- Theck electric current at bucket circuit relief position.



## (2) Check pressure at EPPR valve

- ① Start engine.
- ② Set S-mode and cancel auto decel mode.
- 3 Position the accel dial at 10.
- ④ Slowly operate control lever of bucket functions at full stroke over relief and measure the EPPR valve pressure by the the monitoring menu of the cluster.
- ⑤ If pressure is not correct, adjust it.
- 6 After adjust, test the machine.



#### 2. BOOM PRIORITY EPPR VALVE

## 1) COMPOSITION


The boom priority EPPR valve is built in a manifold and mainly consisting of valve body and coil. This EPPR valve installed under the solenoid valve.

## 2) CONTROL


The boom priority EPPR valve has to be controlled by a specific electronic amplifier card, which is supplying the coil with a current 580 mA at  $30 \Omega$  and 24 V.

#### 3) OPERATING PRINCIPLE

#### (1) Structure



21095MS14



P : Pilot supply line

T: Return to tank

A: Secondary pressure to flow MCV

1 O-ring

3 Valve body

5 Connector

2 Support ring

4 Coil

6 Cover cap

#### (2) Operation

In de-energized mode the inlet port (P) is closed and the outlet port (A) is connected to tank port (T).


In energized mode the solenoid armature presses onto the control spool with a force corresponding to the amount of current. This will set a reduced pressure at port A. The setting is proportional to the amount of current applied.

### (3) Maximum pressure relief

If a pressure from outside is applied on port A the valve may directly switch to tank port (T) and protect the system before overload.

## 2) EPPR VALVE CHECK PROCEDURE

- (1) Check electric current value at EPPR valve
  - ① Disconnect connector CN-133 from EPPR valve.
  - ② Insert the adapter to CN-133 and install multimeter as figure.
  - ③ Start engine.
  - Set S-mode and cancel auto decel mode.
  - ⑤ If rpm display approx 1600 rpm disconnect one wire harness from EPPR valve.
  - ⑥ Check electric current in case of combined boom up and swing operation.




(combined boom up and swing operation)

Spec: 400~600 mA

Solenoid valve

## (2) Check pressure at EPPR valve

- ① Remove hose from A5 port and connect pressure gauge as figure.
  - · Gauge capacity: 0 to 50 kgf/cm² (0 to 725 psi)
- ② Start engine.
- 3 Set S-mode and cancel auto decel mode.
- ④ If rpm display approx 1600 rpm check pressure (In case of combined boom up and swing operation).
- (5) If pressure is not correct, adjust it.
- ⑥ After adjust, test the machine.



## **GROUP 15 MONITORING SYSTEM**

#### 1. OUTLINE

Monitoring system consists of the monitor part and switch part.

The monitor part gives warnings when any abnormality occurs in the machine and informs the condition of the machine.

Various select switches are built into the monitor panel, which act as the control portion of the machine control system.

#### 2. CLUSTER

#### 1) MONITOR PANEL





\* The warning lamp pops up and/or blinks and the buzzer sounds when the machine has a problem. The warning lamp blinks until the problem is cleared. Refer to page 5-62 for details.

#### 2) CLUSTER CHECK PROCEDURE

### (1) Start key: ON

#### ① Check monitor

- a. Buzzer sounding for 4 seconds with HYUNDAI logo on cluster.
- \* If the ESL mode is set to the enable, enter the password to start engine.
- ② After initialization of cluster, the operating screen is displayed on the LCD. Also, self diagnostic function is carried out.
  - a. Engine rpm display: 0 rpm
  - b. Engine coolant temperature gauge: White range
  - c. Hydraulic oil temperature gauge: White range
  - d. Fuel level gauge: White range

### ③ Indicating lamp state

- a. Power mode pilot lamp: E mode or U mode
- b. Work mode pilot lamp : General operation mode (bucket)
- c. Travel speed pilot lamp: Low (turtle)

## (2) Start of engine

#### ① Check machine condition

- a. RPM display indicates at present rpm
- b. Gauge and warning lamp: Indicate at present condition.
- \* When normal condition: All warning lamp OFF
- c. Work mode selection: General work
- d. Power mode selection: E mode or U mode
- e. Travel speed pilot lamp: Low (turtle)

#### 2 When warming up operation

- a. Warming up pilot lamp: ON
- b. After engine started, engine speed increases to 1000 rpm.
- \* Others same as above.

#### ③ When abnormal condition

- a. The warning lamp lights up and the buzzer sounds.
- b. If BUZZER STOP switch is pressed, buzzer sound is canceled but the lamp warning lights up until normal condition.
- \* The pop-up warning lamp moves to the original position and blink when the buzzer stop switch is pushed. Also the buzzer stops.

# 3. CLUSTER CONNECTOR

# 1) NORMAL TYPE


# (1) CN-56A

No.	Name	Signal
1	Battery 24V	20~32Vdc
2	Power IG {24V}	20~32Vdc
3	GND	-
4	N.C	-
5	N.C	-
6	CAN 2 (H)	0~5Vdc
7	CAN 2 (L)	20~32Vdc
8	N.C	-
9	N.C	-
10	N.C	-
11	N.C	-
12	N.C	-

## (2) CN-56B

No.	Name	Signal
1	CAM + 6.5V	6.3~6.7Vdc
2	CAM GND	-
3	CAM DIFF (H)	0~5Vdc
4	CAM DIFF (L)	0~5Vdc
5	CAM 1	NTSC signal
6	CAM 2	NTSC signal
7	CAM 3	NTSC signal
8	CAM shield	0~5Vdc

NTSC: National Television System Committee




# 2) PREMIUM TYPE (1) CN-56A

No.	Name	Signal
1	Battery 24V	20~32Vdc
2	Power IG {24V}	20~32Vdc
3	GND	-
4	N.C	-
5	N.C	-
6	CAN 2 (H)	0~5Vdc
7	CAN 2 (L)	20~32Vdc
8	N.C	-
9	N.C	-
10	N.C	-
11	N.C	-
12	N.C	-

# (2) CN-56B

No.	Name	Signal
1	CAM + 6.5V	6.3~6.7Vdc
2	CAM GND	-
3	CAM DIFF (H)	0~5V
4	CAM DIFF (L)	0~5V
5	CAM 1	NTSC signal
6	CAM 2	NTSC signal
7	CAM 3	NTSC signal
8	CAM shield	0~5Vdc





## 3) GAUGE

## (1) Operation screen

When you first turn starting switch ON, the operation screen will appear.

Normal type



220S3CD551A

## Premium type



220S3CD151A

- 1 RPM / Speed gauge
- 2 Engine coolant temperature gauge
- 3 Hydraulic oil temperature gauge
- 4 Fuel level gauge

- 5 Tripmeter display
- 6 Eco guage
- 7 Accel dial gauge

\* Operation screen type can be set by the screen type menu of the display (premium type).
Refer to page 5-86 for details.

## (2) RPM / Speed gauge

Normal type



① This displays the engine speed.

Premium type



220S3CD549

### (3) Engine coolant temperature gauge

#### Normal type



Premium type



① This gauge indicates the temperature of coolant.

· White range: 40-113°C (104-212°F) · Red range : Above 113°C (212°F)

- $\ \ \,$  If the indicator is in the red range or  $\ \ \ \ \,$  lamp pops up and the buzzer sounds, turn OFF the engine and check the engine cooling system.
- red even though the machine is in the normal condition range, check the electric device as this can be caused by poor connection of sensor.

220S3CD553

## (4) Hydraulic oil temperature gauge

Normal type



Premium type



220S3CD554

- ① This gauge indicates the temperature of hydraulic oil.
  - · White range: 40-100°C (104-235°F)
  - · Red range : Above 100°C (235°F)
- ② If the indicator is in the red range or lamp pops up and the buzzer sounds reduce the load on the system. If the gauge stays in the red range, stop the machine and check the cause of the problem.
- ※ If the gauge indicates the red range or 


  | Image: | Image: Imag red even though the machine is in the normal condition range, check the electric device as this can be caused by poor connection of electricity or sensor.

## (5) Fuel level gauge





Premium type



- ① This gauge indicates the amount of fuel in the fuel tank.
- ② Fill the fuel when in the red range, or R lamp pops up and the buzzer sounds.
- \* If the gauge indicates the red range or amp blinks in red even though the machine is on the normal condition range, check the electric device as this can be caused by poor connection of electricity or sensor.

## (6) Tripmeter display



220S3CD555

- ① This displays the engine the tripmeter.
- Refer to page 5-87 for details.

### (7) Eco gauge



- ① This gauge indicates the fuel consumption rate and machine load status so that the operators can operate the machine efficient in regards to fuel consumption.
- ② Fuel consumption rate or machine load is higher if the number of segments are increased.
- 3 The color of Eco gauge indicates operation status.
  - · White: Idle operation
  - · Green: Economy operation
  - · Yellow : Non-economy operation at a medium level.
  - · Red : Non-economy operation at a high level.

#### (8) Accel dial gauge



① This gauge indicates the level of accel dial.

## 4) WARNING LAMPS

#### Normal type



## Premium type



## \* Warning lamps and buzzer

Warnings	When error happened	Lamps and buzzer
All warning lamps except below	Warning lamp pops up on the center of the LCD and the buzzer sounds	The pop-up warning lamp moves to the original position, blinks and the buzzer stops when;     the buzzer stop switch is pushed
ESPANA ESPANA	Warning lamp pops up on the center of the LCD and the buzzer sounds	<ul> <li>- the lamp of the LCD is touched</li> <li>· Cluster displays this pop-up when it has communication error with MCU.</li> <li>· If communication with MCU become normal state, it will disappear automatically.</li> </ul>
	Warning lamp pops up on the center of the LCD and the buzzer sounds	* Refer to page 5-63 for details.

\* Refer to page 5-69 for the buzzer stop switch

## (1) Engine coolant temperature warning lamp



290F3CD61

- ① Engine coolant temperature warning is indicated in 2 steps.
  - 100°C over : The → lamp pops up and the buzzer sounds.
  - $-107^{\circ}$ C over: The 1 lamp pops up and the buzzer sounds.
- ② The pop-up ♠, ♠ lamps move to the original position and blinks when the buzzer stop switch will stop and  $\bigcirc$ ,  $\bigcirc$  lamps will blink.
- 3 Check the cooling system when the lamps keep blink.


## (2) Hydraulic oil temperature warning lamp



290F3CD62

- ① Hydraulic oil temperature warning is indicated in 2 steps.
  - 100°C over : The | b | lamp pops up and the buzzer sounds.
- ② The pop-up |∆||, / lamps move to the original position and blinks when the buzzer stop switch when the buzzer will stop and | b | amps will blink.
- 3 Check the hydraulic oil level and hydraulic cooling system.

## (3) Fuel level warning lamp



290F3CD63

- 1 This warning lamp pops up and the buzzer sounds when the fuel level is below 31  $\ell$  (8.2 U.S. gal).
- ② Fill the fuel immediately after the lamp blinks.

## (4) Emergency warning lamp



290F3CD64

- ① This warning lamp pops up and the buzzer sounds when each of the below warnings occurs.
  - Engine coolant overheating (over 107°C)
  - Hydraulic oil overheating (over 105°C)
  - MCU input voltage abnormal
  - Cluster communication data error
  - Engine ECM communication data error
- \* The pop-up warning lamp moves to the original position and blinks when the buzzer stop switch is pushed. The buzzer will stop.
- ② When this warning lamp blinks, machine must be checked and serviced immediately.

## (5) Engine oil pressure warning lamp



290F3CD65

- ① This warning lamp pops up and the buzzer sounds when the engine oil pressure is low.
- ② If the lamp blinks, shut OFF the engine immediately. Check oil level.

## (6) Battery charging warning lamp



290F3CD67

- ① This warning lamp pops up and the buzzer sounds when the battery charging voltage is low.
- ② Check the battery charging circuit when this lamp blinks.

## (7) Air cleaner warning lamp



290F3CD68

- ① This warning lamp pops up and the buzzer sounds when the air cleaner is clogged.
- ② Check, clean or replace filter.

#### (8) Overload warning lamp (opt)



290F3CD69

- ① When the machine is overloaded, the overload warning lamp pops up and the buzzer sounds when the overload switch is ON. (if equipped)
- ② Reduce the machine load.

#### (9) Coolant level warning lamp



760F3CD58

- ① This warning lamp indicates lack of coolant.
- 2 Check and refill coolant.

## 5) PILOT LAMPS

## Normal type



400SA3CD574

## Premium type



400SA3CD74

## (1) Mode pilot lamps

No	Mode	Pilot lamp	Selected mode
		P	Heavy duty power work mode
1	Power mode	S	Standard power mode
		E	Economy power mode
2	User mode	U	User preferable power mode
			General operation - IPC speed mode
			General operation - IPC balance mode
3	Work tool mode		General operation - IPC efficiency mode
			Breaker operation mode
		Ŕ	Crusher operation mode
4	Travel mode		Low speed traveling
4	navei inoue	<b>*</b>	High speed traveling
5	Auto idle mode		Auto idle

## (2) Power max pilot lamp (null)



290F3CD78

- ① The lamp will be ON when pushing power max switch on the LH RCV lever.
- ② The power max function operates for a max period of 8 seconds.
- \* Refer to the operator's manual page 3-36 for power max function.

## (3) Warming up pilot lamp



290F3CD80

- ① This lamp lights up when the coolant temperature is below 30°C (86°F).
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C (86°F), or when 10 minutes have passed since starting the engine.

## (4) Decel pilot lamp



290F3CD81

- ① Operating one touch decel switch on the RCV lever makes the lamp light up.
- ② Also, the lamp will light up. And engine speed will be reduced automatically to save fuel when all levers and pedals are in the neutral position, and the auto idle function is selected.
- \* One touch decel is not available when the auto idle pilot lamp is turned ON.
- Refer to the page operator's manual 3-36.

## (5) Fuel warmer pilot lamp



290F3CD82

- ① This lamp lights up when the coolant temperature is below 10°C (50°F) or the hydraulic oil temperature 20°C (68°F).
- ② The automatic fuel warming is cancelled when the engine coolant temperature is above 60°C (140°F), and the hydraulic oil temperature is above 45°C (113°F) since the start switch was ON position.

## (6) Maintenance pilot lamp



290F3CD83

- ① This lamp lights up when consumable parts are in need of replacement. It means that the change or replacement interval of parts is 30 hours from the required change interval.
- ② Check the message in maintenance information of main menu. Also, this lamp lights up for 3 minutes when the start switch is switched to the ON position.
- \* Refer to the page 5-80.

#### (7) Smart key pilot lamp (premium type, opt)



290F3CD214

- ① This lamp lights up when the engine is started by the start button.
- ② This lamp is red when the a authentication fails, it will be green when it authentication is successful.
- \* Refer to the page 5-81.

#### (8) Auto engine shutdown pilot lamp (premium type, opt)



220A3CD202A

- ① This lamp lights up when the auto engine shutdown is activated
- \* Refer to the page 5-77.

# 6) SWITCHES Normal type



## Premium type



220S3CD86B

When some of the switches are selected, the pilot lamps are displayed on the LCD. Refer to the page 6-65 for details.

## (1) Power mode switch



① This switch is to select the machine power mode and when pressed, the power mode pilot lamp will be displayed on the section of the monitor.

· P : Heavy duty power work.

· S : Standard power work.

② · E : Economy power work.

The pilot lamp changes  $E \rightarrow S \rightarrow P \rightarrow E$  in this order.

### (2) Work mode switch



① This switch is to select the machine work mode, which shifts from general operation mode to optional attachment operation mode.

· 💪 : General operation mode

· 🔊 : Breaker operation mode (if equipped)

: Grusher operation mode (if equipped)

· Not installed : Breaker or crusher is not installed.

\* Refer to the page operator's manual 2-7 for details.

## (3) User mode switch




① This switch is used to select between user mode and general power mode.

- U : User mode

- P/S/E: General power mode

② Refer to the page 5-75 for another set of user mode.

#### (4) Travel speed switch



① This switch is used to select the travel speed alternatively.

: Low speed

4

: High speed

- Do not change the setting of the travel speed switch while machine is moving. Machine stability may be adversely affected
- ▲ Serious injury or death can result from sudden changes in machine stability.

#### (5) Auto idle/ buzzer stop switch



- ① This switch is used to activate or cancel the auto idle function.
  - · Pilot lamp ON : Auto idle function is activated.
  - · Pilot lamp OFF: Auto idle function is cancelled.
- ② The buzzer sounds when the machine has a problem. In this case, push this switch and buzzer stops, but the warning lamp blinks until the problem is cleared.

#### (6) Escape/Camera switch



- ① This switch is used to return to the previous menu or parent menu.
- ② In the operation screen, pushing this switch will display the view of the camera on the machine (if equipped).

  Please refer to page 5-87 for the camera.
- ③ If the camera is not installed, this switch is used only ESC function.

## (7) Work light switch



- ① This switch is used to operate the work light.
- ② The pilot lamp lights up when this switch is pressed.

#### (8) Head light switch



- ① This switch is used to operate the head light.
- ② The pilot lamp lights up when this switch is pressed.

## (9) Intermittent wiper switch



- ① This switch is used to wipe operates intermittently.
- ② The pilot lamp lights up when this switch is pressed.

#### (10) Wiper switch



- ① This switch is used to operate the wiper.
- 2 Note that the wiper will self-park when switched off.
- ③ The pilot lamp lights up when this switch is pressed.
- If the wiper does not operate with the switch in ON position, turn the switch OFF immediately. Check the cause.
  If the switch remains ON, motor failure can result.

#### (11) Washer switch




- ① Washer liquid is sprayed and the wiper is operated only when this switch is pressed.
- ② The pilot lamp lights up when this switch is pressed.

## (12) Cab light switch



- ① This switch turns on the cab light.
- ② The pilot lamp lights up when this switch is pressed.

#### (13) Beacon switch



- ① This switch activates the rotary light on the cab.
- ② The pilot lamp lights up when this switch is pressed.

#### (14) Overload switch



- ① When this switch is activated, buzzer makes sound and over-load warning lamp lights up in the event that the machine is or becomes in an overloaded situation.
- ② When the switch is inactivated, buzzer stops and warning lamp goes off.
- ▲ Overloading the machine could impact the machines stability which could result in tipover hazard. A tipover hazard could result in serious injury or death. Always activate the overload warning device before you handle or lift objects.

#### (15) Travel alarm switch



- ① This switch is to activate travel alarm function surrounding when the machine travels.
  - · ON : The travel alarm function is activated.
  - · OFF : The travel alarm function is not activated.

# (16) Main menu quick touch switch





- ① This switch is to activate the main menu in the cluster.
- \* Refer to the page 5-73.

# 7) MAIN MENU

\* On the operation screen, tap MENU to access the main menu screen.
On the sub menu screen, you can tap the menu bar to access functions or applications.







220S3CD102A


# (1) Structure

No	Main menu	Sub menu	Description
1	Mode 220S3CD103	Work mode U mode power Boom/Arm speed Auto power boost (null) IPC mode Auto engine shutdown (opt) Initial mode Emergency mode	Breaker, Crusher, Not installed User mode only Boom speed Enable, Disable Speed mode, Balance mode, Efficiency mode One time, Always, Disable Key on initial mode / initial work mode Switch function
2	Monitoring 220S3CD104	Active fault Logged fault Delete logged fault Monitoring	MCU, AAVM (opt) MCU, AAVM (opt) All logged fault delete, Initialization canceled Machine information, Switch status, Output status,
3	Management 220S3CD105	Fuel rate information Maintenance information Machine security Machine information  Contact Service menu  Clinometer Update	General record, Hourly, Daily, Mode record Replacement, Change interval oils and filters ESL mode setting, Password change Model, MCU, Monitor RMCU, Relay drive unit, AAVM (opt) A/S phone number, A/S phone number change Power shift, Operating hour, Breaker mode pump acting, EPPR current level, Overload pressure Clinometer setting Cluster, ETC device
4	Display 220S3CD106	Display item Clock Brightness Unit setup Language selection Screen type★	Engine speed, Tripmeter A, Tripmeter B, Tripmeter C Clock Manual, Auto Temperature, Pressure, Flow, Distance, Date format Korean, English, Chinese, ETC A type, B type
5	Utilities 220S3CD107	Tripmeter Camera setting AUX Manual	3 kinds (A, B, C) Number of active, Display order, AAVM (opt)★

★ : premium type

# (2) Mode setup

- \* Illustrations are based on the premium type cluster.
- 1 Work mode



- · Select installed optional attachment
  - A: It can set the user's attachment. It is available in setting #1~#10.
  - B: Max flow Set the maximum flow for the attachment.

# ② U mode power



220S3CD112A

- Engine high idle rpm, auto idle rpm and pump torque (power shift) can be modulated and memorized separately in U-mode.
- · U-mode can be activated by user mode switch.

Step ( ■ )	Engine speed (rpm)	Idle speed (rpm)	Power shift (bar)
1	1350	800	0
2	1400	850	3
3	1450	900	6
4	1500	950	9
5	1550	1000 (auto decel)	12
6	1600	1050	16
7	1650	1100	20
8	1700	1150	26
9	1750	1200	32
10	1800	1250	38

\* One touch decel & low idle: 900 rpm

#### 3 Boom speed



#### · Boom speed

Boom priority function can be activated or cancelled
 Enable - Boom up speed is automatically adjusted as working conditions by the MCU.
 Disable - Normal operation

# Auto power boost (null)




22052001174

· The power boost function can be activated or cancelled.

Enable - The digging power is automatically increased as working conditions by the MCU. It is operated max 8 seconds, then goes off for a period or 1 second and then activates again for 8 seconds and continues this cycle.

Disable - Not operated.

# **⑤ IPC mode**



- · The IPC mode can be selected by this menu.
  - Speed mode
  - Balance mode (default)
  - Efficiency mode

# 6 Automatic engine shutdown (option)



- · The automatic engine shutdown function can be set by this menu.
  - One time
  - Always
  - Disable
  - Wait time setting: Max 40 minutes, min 2 minutes

# 7 Initial mode



· Key on initial mode

- Selected the power mode is activated when the engine is started.

## Key on initial work mode

- Not installed
- Last setting
- Work mode

## **® Emergency mode**





220S3CD249A

- · This mode can be used when the switches are abnormal on the cluster.
- · The cluster switches can be selected by touching each icon.

# (3) Monitoring

#### ① Active fault



· The active faults of the MCU can be checked by this menu.

## ② Logged fault



220S3CD124A

· The logged faults of the MCU can be checked by this menu.

# 3 Delete logged fault



· The logged faults of the MCU can be deleted by this menu.

## **4** Monitoring



- The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu (Analog input).
- The switch status or output status can be confirmed by this menu (Digital input & Digital output).
- The activated switch or output pilot lamps 
  will light up.

#### (4) Management

#### ① Fuel rate information





# · General record (A)

- Average fuel rate (left) (from "Reset" to now) Fuel consumption divided by engine run time (service meter time).
- A days fuel used (right) Fuel consumption from 24:00 (or "Reset" time) to now (MCU real time).

# · Hourly record (B)


- Hourly fuel rates for past 12 hours (service meter time).
- No record during key-off time.
- One step shift to the right for every one hour.
- Automatic deletion of data from 12 hours and earlier.
- "Reset" deletes all hourly records.

# · Daily record (C)

- Daily fuel consumption for past seven days (MCU real time).
- No record during key-off time.
- One step shift to the right at 24:00 for every day.
- Automatically deletes data from 7 days and earlier.
- All daily records deletion by "Reset".

#### · Mode record (D)

- Average fuel rate for each power mode/accel dial (at least 7) from "Reset" till present.
- No record during idle.
- All records can be deleted by "Reset".










220S3CD17A

## 2 Maintenance information



- · Alarm lamp ( ) is ON when oil or filter needs to be changed or replaced.
- · Replacement : The elapsed time will be reset to zero (0).
- · Change interval: The change intervals can be changed in hour increments of 50.
- \* Refer to section, Maintenance chart for further information of maintenance interval.

#### 3 Machine security



#### · ESL mode setting

- ESL: Engine Starting Limit
- ESL mode is desingned to be a theft deterrent or will prevent the unauthorized operation of the machine.
- When you Enable the ESL mode, the password will be required when the starting switch is turned to the on position.
- Machine security

Disable: ESL function is disabled and password is not required to start engine.

Enable (always): The password is required whenever the operator starts engine.

 Interval: The password is required when the operator starts engine first. But the operator can restart the engine within the interval time without inputting the password. The interval time can be set to a maximum 4 hours.

※ Default password : 00000 + 
✓

- Smart key (option) : Refer to next page.

# Password change

- The password is 5~10 digits.



\* Before first use, please set user password and owner password in advance for machine security.



## - Smart key



- Smart key is registered when equipped with optional smart key. If smart key is not inside of the cabin, authentication process fails and the password is needed.
- · Tag management menu is activated when the Smart key menu is Enabled.

You can register and delete the tags.

# - Tag management

- · When registering a tag : Only the tag you want to register must be in the cabin.
- · When deleting a tag: All registered tags are deleted.







Registering \$\displaystyle{\psi}\$




235F3CD005

# Engine Starting Condition

Case	ESL Mode	Smart Key	Condition		
1	Disable		<ul><li>With registered tag: Engine can be started without password input.</li><li>Without registered tag: Engine can be started without password input.</li></ul>		
2	Disable	Enable	If Smart Key is enabled, ESL Mode is automatically enabled. This Case 2 work the same as the Case 4.		
3	3   Engnia   Diegnia   5 5 5		<ul><li>With registered tag: Engine can be started with password input.</li><li>Without registered tag: Engine can be started with password input.</li></ul>		
4	/    Engnia   Engnia		<ul><li>With registered tag: Engine can be started without password input.</li><li>Without registered tag: Engine can be started with password input.</li></ul>		

#### **4** Machine Information



· This can confirm the identification of the model information (ECU), MCU, monitor, switch controller, RMCU, relay driver unit, AAVM (opt).

#### (5) Contact (A/S phone number)



Enter the new A/S phone number

## 6 Service menu



- \* This menu can be used only HCE service man and can not be accessible by the owner and the operator.
- · Power shift (standard/option): Power shift pressure can be set by option menu.
- · Operating hours: Operating hours since the machine line out can be checked by this menu.
- Breaker mode pump acting (null)
- EPPR current level (attach flow EPPR 1 & 2)
- · Overload pressure: 100 ~ 350 bar

#### ⑦ Clinometer




220S3CD153A

- · When the machine is on the flatland, if you touch "initialization" on cluster, the values of X, Y will reset to "O".
- · You can confirm tilt of machine in cluster's operating screen.

# ® Update (cluster & ETC devices)



- · ETC devices and cluster can be updated through





## (5) Display

# ① Display item



- · The center display type of the LCD can be selected by this menu.
- · The engine speed or the tripmeter menu (A,B,C) is displayed on the center display.

# 2 Clock




- · The first row of boxes indicate Year/Month/Day.
- · The second row shows the current time. (0:00~23:59)

# ③ Brightness




· If "Auto" is chosen, brightness for day and night can be set accordingly. Also by using the bar in lower side, users can define which an operation interval belongs to day and night. (in bar figure, white area represents night time while orange shows day time)

# 4 Unit



· User can select preferable language and all displays are changed to the selected language.

# **⑥** Screen type (premium type)



# (6) Utilites

# ① Tripmeter



- · A maximum of 3 kinds of tripmeters can be used at the same time.
- · Each tripmeter can be turned on by choosing "Start". it also can be turned off by choosing "Stop".
- · If the tripmeter icon is activated in the operation screen, it can be controlled directly there.

# ② Camera setting

- · If the rear camera is not installed on the machine, set disable.
- · If the rear camera is installed on the machine, set enable.



· In the operation screen, rear camera screen shows up when ESC/CAM switch is pushed.



5-87

# ③ AAVM (Advanced Around View Monitoring, premium type, opt)

· The AAVM switches of the cluster consist of ESC/CAM and AUTO IDLE/Buzzer stop.



#### - Escape switch

- · Activates AAVM mode from the beginning if AAVM is installed.
- · While in the AAVM mode, select the ESC switch to return to the home screen.



#### - Buzzer stop switch

- · AAVM mode detects surrounding pedestrians or objects and the warning buzzer sounds.
- · User can turn OFF the warning sound by pressing buzzer stop switch.



220A3CD246

- · When a worker/pedestrian reaches the green line, which is an external danger area equipped on the cluster, warning buzzer sounds and it displays a green rectangular box recognizing the worker/pedestrian.
  - Stop work immediately. Stop the buzzer by pressing the buzzer stop switch. Then resume work after you confirm that the area is safe and clear of workers/ objects.



220A3CD247

- When a worker/pedestrian reaches the green line, which is an external danger area equipped on the cluster, warning buzzer sounds and it displays a red rectangular box recognizing the worker/pedestrian. Stop work immediately. Stop the buzzer by pressing the buzzer stop switch. Then resume work after you confirm that the area is safe and clear of workers/ objects.
- A Failure to comply may result in serious injury or death.
- \* In AAVM mode, a touch screen of the LCD is available only. The multimodal dial of the haptic controller is not available.

# **GROUP 16 FUEL WARMER SYSTEM**

#### 1. SPECIFICATION


1) Operating voltage: 24±4 V

2) Power : 350±50 W3) Current : 15 A


#### 2. OPERATION

- The current of fuel warmer system is automatically controlled without thermostat according to fuel temperature.
- 2) At the first state, the 15 A current flows to the fuel warmer and engine may be started in 1~2 minutes.
- If the fuel starts to flow, ceramic-disk in the fuel warmer heater senses the fuel temperature to reduce the current as low as 1.5 A.

So, fuel is protected from overheating by this mechanism.



#### 3. ELECTRIC CIRCUIT



# SECTION 6 TROUBLESHOOTING

Group	1	Before Troubleshooting	6-1
Group	2	Hydraulic and Mechanical System	6-4
Group	3	Electrical System	6-25
Group	4	Mechatronics System ·····	6-43
Group	5	Air conditioner and Heater System	6-72

# SECTION 6 TROUBLESHOOTING


# **GROUP 1 BEFORE TROUBLESHOOTING**

#### 1. INTRODUCTION

When a trouble is occurred in the machine, this section will help an operator to maintain the machine with easy.

The trouble of machine is parted Hydraulic & Mechanical system, Electrical system, Mechatronics system and Air conditioner and heater system. At each system part, an operator can check the machine according to the troubleshooting process diagram.

\* Before carring out troubleshooting procedure, check monitoring menu in the cluster.




#### 2. DIAGNOSING PROCEDURE

To carry out troubleshooting efficiently, the following steps must be observed.

#### STEP 1. Study the machine system

Study and know how the machine is operating, how the system is composing, what kinds of function are installed in the machine and what are specifications of the system components by the machine service manual.

Especially, deepen the knowledge for the related parts of the trouble.



#### STEP 2. Ask the operator

Before inspecting, get the full story of malfunctions from a witness --- the operator.


- 1) How the machine is used and when it is serviced?
- 2) When the trouble was noticed and what work the machine was doing at that time?
- 3) What is the phenomenon of the trouble? Was the trouble getting worse, or did it come out suddenly for the first time?
- 4) Did the machine have any troubles previously? If so, which parts were repaired before.



#### STEP 3. Inspect the machine

Before starting troubleshooting, check the machine for the daily maintenance points as shown in the operator's manual.


And also check the electrical system including batteries, as the troubles in the electrical system such as low battery voltage, loose connections and blown out fuses will result in malfunction of the controllers causing total operational failures of the machine.



# STEP 4. Inspect the trouble actually on the machine


In case that some trouble cannot be confirmed, obtain the details of the malfunction from the operator.

Also, check if there are any in complete connections of the wire harnesses are or not.



#### STEP 5. Perform troubleshooting


According to where the trouble parts are located, hydraulic & mechanical system part or electrical system part or mechatronics system part, perform troubleshooting the machine refer to the each system part's troubleshooting process diagram.



#### STEP 6. Trace a cause

Before reaching a conclusion, check the most suspectible causes again. Try to trace what the real cause of the trouble is.

Make a plan of the appropriate repairing procedure to avoid consequential malfunctions.



# **GROUP 2 HYDRAULIC AND MECHANICAL SYSTEM**


#### 1. INTRODUCTION

# 1) MACHINE IN GENERAL

- (1) If even a minor fault is left intact and operation is continued, a fatal failure may be caused, entailing a large sum of expenses and long hours of restoration.
  - Therefore when even a small trouble occurs, do not rely on your intuition and experience, but look for the cause based on the troubleshooting principle and perform maintenance and adjustment to prevent major failure from occurring. Keep in mind that a fault results from a combination of different causes.
- (2) The following lists up commonly occurring faults and possible causes with this machine. For the troubleshooting of the engine, refer to the coming troubleshooting and repair.
- (3) When carrying out troubleshooting, do not hurry to disassemble the components. It will become impossible to find the cause of the problem.
- (4) Ask user or operator the following.
- ① Was there any strange thing about machine before failure occurred?
- ② Under what conditions did the failure occur?
- 3 Have any repairs been carried out before the failure?
- (5) Check before troubleshooting.
- ① Check oil and fuel level.
- ② Check for any external leakage of oil from components.
- 3 Check for loose or damage of wiring and connections.

#### 2) MACHINE STATUS MONITORING ON THE CLUSTER

(1) The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu.






(2) Specification


No.	Description	Specification		
Note 1	Work pilot pressure	40 <sup>+2</sup> <sub>0</sub> bar		
Note 2	Swing pilot pressure	0~40 bar		
Note 3	Boom up pilot pressure	0~40 bar		
Note 4	Arm/bucket pilot pressure	0~40 bar		
Note 5	Pump 1 regulator pressure	0~50 bar		
Note 6	Pump 2 regulator pressure	0~50 bar		
Note 7	Pump 1 pressure	350 bar		

#### 2. DRIVE SYSTEM

# 1) UNUSUAL NOISE COMES OUT OF PUMP CONNECTION




## 2) ENGINE STARTS BUT MACHINE DOES NOT OPERATE AT ALL




#### 3. HYDRAULIC SYSTEM


# 1) HYDRAULIC OIL IS CLOUDY




# 2) HYDRAULIC OIL TEMPERATURE HAS RISEN ABNORMALLY



# 3) CAVITATION OCCURS WITH PUMP




# 4) HYDRAULIC OIL IS CONTAMINATED




#### 4. SWING SYSTEM


# 1) BOTH LH AND RH SWING ACTIONS ARE IMPOSSIBLE




#### 2) SWING SPEED IS LOW




# 3) SWING MOTION IS IMPOSSIBLE IN ONE DIRECTION




# 4) MACHINE SWINGS BUT DOES NOT STOP




# 5) THE SWING UNIT DRIFTS WHEN THE MACHINE IS AT REST ON A SLOPE



# 6) LARGE SHOCK OCCURS WHEN STOP SWINGING




# 7) LARGE SOUND OCCURS WHEN STOP SWINGING




#### 5. TRAVEL SYSTEM

# 1) TRAVEL DOES NOT FUNCTION AT ALL ON ONE SIDE




#### 2) SPEED ON ONE SIDE FALLS AND THE MACHINE CURVES




#### 3) MACHINE DOES NOT STOP ON A SLOPE


Machine is pulled forward as sprocket rotates during digging operation.



# 4) LH AND RH TRAVEL MOTIONS ARE IMPOSSIBLE




# 5) TRAVEL ACTION IS POWERLESS (travel only)



### 6) MACHINE RUNS RECKLESSLY ON A SLOPE


Travel brake valve	Cause	Remedy
(counterbalance valve) is faulty.		Disassemble and repair or replace.

# 7) MACHINE MAKES A CURVED TRAVEL OR DOES NOT TRAVEL AT ALL WHEN TRAVEL AND ATTACHMENT OPERATIONS ARE EXECUTED AT THE SAME TIME




#### 6. ATTACHMENT SYSTEM


# 1) BOOM OR ARM ACTION IS IMPOSSIBLE AT ALL




# 2) BOOM, ARM OR BUCKET SPEED IS LOW




# 3) BOOM, ARM OR BUCKET CYLINDER EXTENDS OR CONTRACTS ITSELF AND ATTACHMENT FALLS




# 4) BOOM, ARM OR BUCKET POWER IS WEAK




# 5) ONLY BUCKET OPERATION IS TOTALLY IMPOSSIBLE



# 6) BOOM MAKES A SQUEAKING NOISE WHEN BOOM IS OPERATED




# 7) TIME LAG OF MACHINE WORKING IS LARGE.




### **\*\* HOW TO CHECK INTERNAL BOOM CYLINDER LEAKAGE**

1. Lower the bucket teeth to the ground with bucket cylinder fully retracted and arm cylinder rod retracted almost in full.




2. Disconnect hose (A) from rod side of boom cylinder and drain oil from cylinders and hose. (put cups on piping and hose ends)



3. Raise bucket OFF the ground by retracting the arm cylinder rod.

If oil leaks from piping side and boom cylinder rod is retracted there is an internal leak in the cylinder.


If no oil leaks from piping side and boom cylinder rod is retracted, there is an internal leak in the control valve.



# **GROUP 3 ELECTRICAL SYSTEM**


# 1. WHEN STARTING SWITCH IS TURNED ON, MONITOR PANEL DISPLAY DOES NOT APPEAR

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 8, 10.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.



# Check voltage


YES	20~32V
NO	0V



220S6ES01


# 2. COMMUNICATION ERROR FLASHES ON THE CLUSTER (HCESPN 840, FMI 2)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.



### Check voltage


YES	2V	
NO	0V	



300L6ES02


# 3. F + BATTERY CHARGING WARNING LAMP LIGHTS UP (Starting switch : ON)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




### Check voltage

YES	20~32V
NO	0V



# 4. WHEN COOLANT OVERHEAT WARNING LAMP LIGHTS UP (engine is started)


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






#### **Check Table**

Temperature (°C)	0	25	50	80	95
Resistance (kΩ)	30~37	9.3~10.7	3.2~3.8	1.0~1.3	0.7~0.8




# 5. WHEN AIR CLEANER WARNING LAMP LIGHTS UP (engine is started)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.



### Check resistance


YES	<b>MAX 1</b> Ω	
NO	MIN 1MQ	




220S6ES05

# 6. WHEN ENGINE OIL PRESSURE WARNING LAMP LIGHTS UP (engine is started)


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.





#### WHEN HYDRAULIC OIL TEMPERATURE WARNING LAMP LIGHTS UP (engine is started) 7.

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




# Normal type



### **Check Table**


Temperature (°C)	~ -30	~ -10	~ 0	~ 40	~ 70	~ 80	~ 90	~ 100	105~
Resistance (kΩ)	22.22 ~31.78	8.16 ~10.74	5.18 ~ 6.6	1.06 ~1.28	0.39 ~0.476	0.322 ~0.298	0.243	0.185 ~0.167	0.164 0.151





# 8. WHEN COOLANT TEMPERATURE GAUGE DOES NOT OPERATE (HCESPN 304, FMI 3 or 4) GAUGE DOES NOT OPERATE


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






#### **Check Table**

Temperature (°C)	0	25	50	80	95
Resistance ( $k\Omega$ )	30~37	9.3~10.7	3.2~3.8	1.0~1.3	0.7~0.8



# 9. WHEN FUEL GAUGE DOES NOT OPERATE (HCESPN 301, FMI 3 or 4)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.








Premium type




# **Check Table**


Range	Resistance ( $\Omega$ )	Range	Resistance ( $\Omega$ )
- 3	,	3	,
Full	50	5/12	400
11/12	100	4/12	450
10/12	150	3/12	500
9/12	200	2/12	550
8/12	250	1/12	600
7/12	300	Empty warning	700
6/12	350	-	-



## 10. WHEN SAFETY SOLENOID DOES NOT OPERATE


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 25.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






# 11. WHEN TRAVEL SPEED 1, 2 DOES NOT OPERATE (HCESPN 167, FMI 4 or 6)


- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 30.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







220S6ES13

## 12. TRAVEL ALARM DOES NOT SOUND OR DOES NOT STOP SOUNDING







#### 13. HORN DOES NOT SOUND



# 14. WHEN ENGINE DOES NOT START ( | lights up condition)


- · Check supply of the power at engine stop solenoid while starting switch is ON.
- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and fuse No. 1, 2, 5, 9 and 16 burnt out.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






### 15. WHEN STARTING SWITCH ON DOES NOT OPERATE

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted, master switch ON and check blown out of the fuse (CN-60).
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







6-39

### 16. WHEN STARTING SWITCH IS TURNED ON, WIPER MOTOR DOES NOT OPERATE

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and fuse No. 7, 13 and 19 is not blown out.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







220S6ES16

# 17. WHEN STARTING SWITCH IS TURNED ON, HEAD LAMP DOES NOT LIGHTS UP

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.13 and 20.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







220S6ES17

6-41

# 18. WHEN STARTING SWITCH IS TURNED ON, WORK LAMP DOES NOT LIGHTS UP

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse 13 and 17.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.





220S6ES18


6-42

# **GROUP 4 MECHATRONICS SYSTEM**


### 1. ALL ACTUATORS SPEED ARE SLOW

- \* Boom, Arm, Bucket, Swing and travel speed are slow, but engine speed is good.
- lpha Spec : P-mode 1650  $\pm$  50 rpm S -mode 1550  $\pm$  50 rpm E-mode 1450  $\pm$  50 rpm
- \* Before carrying out below procedure, check all the related connectors are properly inserted and fault code on the cluster.

# 1) INSPECTION PROCEDURE




# Wiring diagram




220SA6MS01

# 2) TEST PROCEDURE


- (1) **Test 1**: Check resistance at connector CN-75.
- ① Starting key OFF.
- ② Disconnect connector CN-75 from EPPR valve at main hydraulic pump.
- ③ Check resistance between 2 lines as figure.



- (2) Test 2 : Check electric current at EPPR valve.
- ① Disconnect connector CN-75 from EPPR valve.
- ② Insert the adapter to CN-75 and install multimeter as figure.
- ③ Start engine.
- Set S-mode and cancel auto decel mode.
- (5) Position the accel dial at 10.
- ⑥ If tachometer show approx 1600±50 rpm disconnect one wire harness from EPPR valve.
- ⑦ Check electric current at bucket circuit relief position.




- (3) Test 3: Check pressure at EPPR valve.
- ① Start engine.
- ② Set S-mode and cancel auto decel mode.
- ③ Position the accel dial at 10.
- ④ Slowly operate control lever of bucket functions at full stroke over relief and measure the EPPR valve pressure by the the monitoring menu of the cluster.
- ⑤ If pressure is not correct, adjust it.
- ⑥ After adjust, test the machine.




### 2. ENGINE STALL

\* Before carrying out below procedure, check all the related connectors are properly inserted.

# 1) INSPECTION PROCEDURE




# Wiring diagram



220SA6MS01

# 2) TEST PROCEDURE

- (1) **Test 4**: Check electric current at EPPR valve.
  - ① Disconnect connector CN-75 from EPPR valve.
  - ② Insert the adapter to CN-75 and install multimeter as figure.
  - ③ Start engine.
  - Set S-mode and cancel auto decel mode.
  - 5 Position the accel dial at 10.
  - 6 If rpm show approx 1600 $\pm$ 50 rpm disconnect one wire harness from EPPR valve.
  - Theck electric current at bucket circuit relief position.




- (2) Test 5 : Check pressure at EPPR valve.
  - ① Start engine.
  - ② Set S-mode and cancel auto decel mode.
  - 3 Position the accel dial at 10.
- ④ Slowly operate control lever of bucket functions at full stroke over relief and measure the EPPR valve pressure by the the monitoring menu of the cluster.
- ⑤ If pressure is not correct, adjust it.
- 6 After adjust, test the machine.




### 3. MALFUNCTION OF CLUSTER OR MODE SELECTION SYSTEM

\* Before carrying out below procedure, check all the related connectors are properly inserted.

# 1) INSPECTION PROCEDURE



## Wiring diagram





220S6MS02

### 4. AUTO DECEL SYSTEM DOES NOT WORK

- Fault code: HCESPN 105, FMI 0~4 (work pressure sensor)
   HCESPN 108, FMI 0~4 (travel oil pressure sensor)
- \* Before carrying out below procedure, check all the related connectors are properly inserted.

# 1) INSPECTION PROCEDURE






220S6MS03

# 2) TEST PROCEDURE


- (1) Test 7: Check voltage at CN-52 (38) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (38) of CN-52.
- ③ Starting switch key ON.
- ④ Check voltage as figure.
- (2) Test 8: Check voltage at CN-52 (37) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper
- ② Insert prepared pin to rear side of connectors: One pin to (37) of CN-52.
- 3 Starting switch ON.
- ④ Check voltage as figure.




## 5. MALFUNCTION OF PUMP 1 PRESSURE SENSOR

- · Fault code: HCESPN 120, FMI 0~4
- \* Before carrying out below procedure, check all the related connectors are properly inserted.

# 1) INSPECTION PROCEDURE




## Wiring diagram



400SA6MS05

# 2) TEST PROCEDURE


- (1) Test 9: Check voltage at CN-52 (29) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (29) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.




#### 6. MALFUNCTION OF PUMP 2 PRESSURE SENSOR

- · Fault code: HCESPN 121, FMI 0~4
- \* Before carrying out below procedure, check all the related connectors are properly inserted.

# 1) INSPECTION PROCEDURE




## Wiring diagram



400SA6MS07


- (1) Test 10: Check voltage at CN-52 (30) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (30) of CN-52.
- ③ Starting switch ON.
- 4 Check voltage as figure.




#### 7. MALFUNCTION OF PUMP 3 PRESSURE SENSOR

- · Fault code: HCESPN 125, FMI 0~4
- \* Before carrying out below procedure, check all the related connectors are properly inserted.

## 1) INSPECTION PROCEDURE




#### Wiring diagram



400SA6MS09


- (1) Test 11: Check voltage at CN-52 (32) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (32) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.




#### 8. MALFUNCTION OF NEGATIVE 1 PRESSURE SENSOR

- · Fault code: HCESPN 123, FMI 0~4
- \* Before carrying out below procedure, check all the related connectors are properly inserted.


## 1) INSPECTION PROCEDURE



#### Wiring diagram




- (1) Test 12: Check voltage at CN-52 (39) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (39) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.




#### 9. MALFUNCTION OF NEGATIVE 2 PRESSURE SENSOR

- · Fault code: HCESPN 124, FMI 0~4
- \* Before carrying out below procedure, check all the related connectors are properly inserted.

# 1) INSPECTION PROCEDURE




#### Wiring diagram



400SA6MS13


- (1) Test 13: Check voltage at CN-52 (40) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (40) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.




#### 10. MALFUNCTION OF SWING PRESSURE SENSOR

- · Fault code: HCESPN 135, FMI 0~4
- \* Before carrying out below procedure, check all the related connectors are properly inserted.

## 1) INSPECTION PROCEDURE




## Wiring diagram



220S6MS15


- (1) Test 14: Check voltage at CN-52 (36) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (36) of CN-52.
- ③ Starting switch ON.
- 4 Check voltage as figure.




#### 11. MALFUNCTION OF BUCKET IN PRESSURE SENSOR

- · Fault code: HCESPN 133, FMI 0~4
- \* Before carrying out below procedure, check all the related connectors are properly inserted.

## 1) INSPECTION PROCEDURE




## Wiring diagram



400SA6MS17


- (1) Test 15: Check voltage at CN-52 (28) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (28) of CN-52.
- ③ Starting key ON.
- ④ Check voltage as figure.




#### 12. MALFUNCTION OF BOOM UP PRESSURE SENSOR

- · Fault code: HCESPN 127, FMI 0~4
- \* Before carrying out below procedure, check all the related connectors are properly inserted.

### 1) INSPECTION PROCEDURE




#### Wiring diagram



220S6MS19


- (1) Test 16: Check voltage at CN-52 (35) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (35) of CN-52.
- ③ Starting switch ON.
- ④ Check voltage as figure.




#### 13. MALFUNCTION OF BOOM DOWN PRESSURE SENSOR

- · Fault code: HCESPN 128, FMI 0~4
- \* Before carrying out below procedure, check all the related connectors are properly inserted.


## 1) INSPECTION PROCEDURE



### Wiring diagram



- (1) Test 17: Check voltage at CN-52 (34) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors: One pin to (34) of CN-52.
- ③ Starting switch ON.
- 4 Check voltage as figure.




# 14. MALFUNCTION OF POWER MAX (NULL)


· Fault code: HCESPN 166, FMI 4 or 6

\* Before carrying out below procedure, check all the related connectors are properly inserted.

# 1) INSPECTION PROCEDURE




## Wiring diagram




220S6MS21

- (1) Test 18: Check voltage between connector CN-88 (2) GND.
- ① Disconnect connector CN-88 from power max solenoid valve.
- ② Start switch ON.
- ③ Check voltage as figure.



- (2) Test 19: Check resistance of the solenoid valve between CN-88 (1)-(2).
- ① Starting switch OFF.
- ② Disconnect connector CN-88 from power max solenoid valve.
- ③ Check resistance as figure.



### 15. MALFUNCTION OF BOOM PRIORITY EPPR VALVE


· Fault code: HCESPN 141, FMI 5 or 6

\* Before carrying out below procedure, check all the related connectors are properly inserted.

# 1) INSPECTION PROCEDURE




#### Wiring diagram



220S6MS23

# **GROUP 5 AIR CONDITIONER AND HEATER SYSTEM**

# 1. AIR CONDITIONER DOES NOT OPERATE



### 1) FAN DOES NOT OPERATE

Cause	Check	Remedy
Fuse is blown or abnormal relay operation	* Fuse * Does relay normally operate?	Replace
Harness short or poor contact	Check any harness short or abnormal contact of connnector	Repair shortage
Fan motor failure	Supply 24V to 2 lead wire from motor and check the operation	Replace
Resistor is broken	Check current flow of resistor with tester	Replace
Fan switch failure	Push fan switch by turn and check the operation	Replace

# 2) WEAK AIR FLOW FROM FAN MOTOR

Cause	Check	Remedy
Clogged evaporator or obstacles around air inlet	Check if evaporator is contaminated	Clean
Leakage of air flow	Check HVAC case assembly	Adjust
Duct sensor failure	Check if evaporator is frozen	Replace

# 3) ABNORMAL OPERATION OF FAN MOTOR

Cause	Check	Remedy
Abnormal operation of each step of control	4 step only operate	Replace resistor
	1 or 2 step does not operate	Replace control
	3 or 4 step does not operate	Replace relay

# 4) COMPRESSOR DOES NOT ROTATE OR HARDLY ROTATE

Cause	Check	Remedy
Loose belt	Belt shaking is severe	Adjust tension
Failure of compressor itself	Belt slip	Repair or Replace
Low voltage of battery	Slip when rotate	Charge battery
Fieldcoil short	Slip when rotate	Replace magnetic clutch
Oily clutch face	Contamination around clutch	Replace magnetic clutch, clean
Fieldcoil is broken	Magnetic clutch does not operate or "∞" resistance	Replace compressor
Leakage of refrigerant or oil inside	Check if wet with oil	Replace compressor Charge refrigerant

# 5) COMPRESSOR OPERATE NORMALLY AND AIR FLOW IS NORMAL

Cause	Check	Remedy
Shortage of refrigerant	When air con operate during 5~10 min small temperature difference between high and low pressure pipes.	Repair leakage joint Charge refrigerant
Overcharge of refrigerant	*Magnetic clutch on/off rapidly *High pressure over specification *Lukewarm air from nozzle	Recharge refrigerant following specification
Lower pressure than normal condition at low side	Shortage of refrigerant	Make up refrigerant
	Clogged receive dryer	Replace receive dryer
	Clogged expansion valve	Replace expansion valve
	Clogged or crushed pipe	Replace pipe or clean
	Failure of duct sensor	Replace duct sensor

# 6) COMPRESSOR OPERATE NORMALLY AND AIR FLOW IS NORMAL

Cause	Check	Remedy
Lower pressure than normal condition at low side	Failure of duct sensor Magnetic clutch off before air temperature sufficiently down	Replace duct sensor or adjust location
	Defective compressor gasket When compressor off, high and low pressure balance immediatly	Repair compressor or Replace
Higher pressure than normal condition at high side	Failure of condensing Contamination on condenser or insufficient air flow from fan	Clean the condenser Repair fan
	Overcharge of refrigerant	Adjust refrigerant
	Entrained air	Vacuum and recharge
Lower pressure than normal condition at high side	Shortage of refrigerant	Make up refrigerant