SECTION 1 GENERAL

Group	1	Safety Hints	1-1	
Group	2	Specifications	1-1	0

SECTION 2 STRUCTURE AND FUNCTION

Group	1 Pump Device	2-1
Group	2 Main Control Valve	2-20
Group	3 Swing Device	2-47
Group	4 Travel Device	2-58
Group	5 RCV Lever ·····	2-71
Group	6 RCV Pedal	2-78

SECTION 3 HYDRAULIC SYSTEM

Group	1 Hydraulic Circuit	3-1
Group	2 Main Circuit ·····	3-2
Group	3 Pilot Circuit	3-5
Group	4 Single Operation	3-13
Group	5 Combined Operation	3-25

SECTION 4 ELECTRICAL SYSTEM

Group	1 Component Location	4-1
Group	2 Electrical Circuit	4-3
Group	3 Electrical Component Specification	4-21
Group	4 Connectors	4-29

SECTION 5 MECHATRONICS SYSTEM

Group	1 Outline	5-1
Group	2 Mode selection System	5-3
Group	3 Automatic Deceleration System	5-6
Group	4 Power Boost System	5-7
Group	5 Travel Speed Control System	5-8
Group	6 Automatic Warming Up Function	5-9
Group	7 Engine Overheat Prevention Function	5-10
Group	8 Variable Power Control System	5-11

Group 9 A	Attachment Flow Control System	5-12
Group 10 A	Anti-Restart System	5-13
Group 11 S	Self-Diagnostic System	5-14
Group 12 E	Engine Control System	5-20
Group 13 E	EPPR Valve	5-21
Group 14 M	Nonitoring System	5-26
Group 15 F	Fuel Warmer System	5-51

SECTION 6 TROUBLESHOOTING

Group	1 Before trobleshooting	6-1
Group	2 Hydraulic and Mechanical System	6-4
Group	3 Electrical System	6-24
Group	4 Mechatronics System	6-40

SECTION 7 MAINTENANCE STANDARD

Group	1 Operational Performance Test	7-1
Group	2 Major Components	7-21
Group	3 Track and Work Equipment	7-29

SECTION 8 DISASSEMBLY AND ASSEMBLY

Group	1	Precaution	8-1
Group	2	Tightening Torque	8-4
Group	3	Pump Device	8-7
Group	4	Main Control Valve	8-32
Group	5	Swing Device	8-46
Group	6	Travel Device	8-79
Group	7	RCV Lever	8-111
Group	8	Turning Joint	8-125
Group	9	Boom, Arm and Bucket Cylinder	8-130
Group	10	Undercarriage	8-148
Group	11	Work Equipment ·····	8-160

SECTION 9 COMPONENT MOUNTING TORQUE

Group	1	Introduction guide	9-1
Group	2	Engine system	9-2
Group	3	Electric system	9-4
Group	4	Hydraulic system	9-6
Group	5	Undercarriage	9-9
Group	6	Structure	9-10
Group	7	Work equipment	9-14

1. STRUCTURE

This service manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This service manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into the following sections.

SECTION 1 GENERAL

This section explains the safety hints and gives the specification of the machine and major components.

SECTION 2 STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

SECTION 3 HYDRAULIC SYSTEM

This section explains the hydraulic circuit, single and combined operation.

SECTION 4 ELECTRICAL SYSTEM

This section explains the electrical circuit, monitoring system and each component. It serves not only to give an understanding electrical system, but also serves as reference material for trouble shooting.

SECTION 5 MECHATRONICS SYSTEM

This section explains the computer aided power optimization system and each component.

SECTION 6 TROUBLESHOOTING

This section explains the troubleshooting charts correlating problems to causes.

SECTION 7 MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

SECTION 8 DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

SECTION 9 COMPONENT MOUNTING TORQUE

This section shows bolt specifications and standard torque values needed when mounting components to the machine.

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your HYUNDAI distributor for the latest information.

2. HOW TO READ THE SERVICE MANUAL

Distribution and updating

Any additions, amendments or other changes will be sent to HYUNDAI distributors.

Get the most up-to-date information before you start any work.

Filing method


1. See the page number on the bottom of the page.

File the pages in correct order.

2. Following examples shows how to read the page number.

Example 1

2-3



 Item number(2. Structure and Function)

Consecutive page number for each item.

- 3. Additional pages : Additional pages are indicated by a hyphen(-) and number after the page number. File as in the example.
 - 10 4

10 - 5

Revised edition mark(123...)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

Revisions

Revised pages are shown at the list of revised pages on the between the contents page and section 1 page.

Symbols

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol	Item	Remarks			
	Sofoty	Special safety precautions are necessary when performing the work.			
	Safety	Extra special safety precautions are necessary when performing the work because it is under internal pressure.			
*	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.			

3. CONVERSION TABLE

Method of using the Conversion Table

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

Example

1. Method of using the Conversion Table to convert from millimeters to inches

Convert 55mm into inches.

- (1) Locate the number 50in the vertical column at the left side, take this as (a), then draw a horizontal line from (a).
- (2) Locate the number 5in the row across the top, take this as (b), then draw a perpendicular line down from (b).
- (3) Take the point where the two lines cross as C. This point C gives the value when converting from millimeters to inches. Therefore, 55mm = 2.165 inches.
- 2. Convert 550mm into inches.
 - (1) The number 550 does not appear in the table, so divide by 10(Move the decimal point one place to the left) to convert it to 55mm.
 - (2) Carry out the same procedure as above to convert 55mm to 2.165 inches.
 - (3) The original value(550mm) was divided by 10, so multiply 2.165 inches by 10(Move the decimal point one place to the right) to return to the original value. This gives 550mm = 21.65 inches.

	Millimeters to inches						b		1mm = 0.03937 in		
		0	1	2	3	4	5	6	7	8	9
	0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
	10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
	20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
	30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
	40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
							©				
a	50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
	60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
	70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
	80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
	90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Millimeters to inches

Millimeters to inches

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Kilogram to Pound

1kg = 2.2046lb

									v	
	0	1	2	3	4	5	6	7	8	9
0		2.20	4.41	6.61	8.82	11.02	13.23	15.43	17.64	19.84
10	22.05	24.25	26.46	28.66	30.86	33.07	35.27	37.48	39.68	41.89
20	44.09	46.30	48.50	50.71	51.91	55.12	57.32	59.5.	61.73	63.93
30	66.14	68.34	70.55	72.75	74.96	77.16	79.37	81.57	83.78	85.98
40	88.18	90.39	92.59	94.80	97.00	99.21	101.41	103.62	105.82	108.03
50	110.23	112.44	114.64	116.85	119.05	121.25	123.46	125.66	127.87	130.07
60	132.28	134.48	136.69	138.89	141.10	143.30	145.51	147.71	149.91	152.12
70	154.32	156.53	158.73	160.94	163.14	165.35	167.55	169.76	171.96	174.17
80	176.37	178.57	180.78	182.98	185.19	187.39	189.60	191.80	194.01	196.21
90	198.42	200.62	202.83	205.03	207 <u>.</u> 24	209.44	211.64	213.85	216.05	218.26

Liter to U.S. Gallon

1 *l* = 0.2642 U.S.Gal

	0	1	2	3	4	5	6	7	8	9
0		0.264	0.528	0.793	1.057	1.321	1.585	1.849	2.113	2.378
10	2.642	2.906	3.170	3.434	3.698	3.963	4.227	4.491	4.755	5.019
20	5.283	5.548	5.812	6.6076	6.340	6.604	6.869	7.133	7.397	7.661
30	7.925	8.189	8.454	8.718	8.982	9.246	9.510	9.774	10.039	10.303
40	10.567	10.831	11.095	11.359	11.624	11.888	12.152	12.416	12.680	12.944
50	13.209	13.473	13.737	14.001	14.265	14.529	14.795	15.058	15.322	15.586
60	15.850	16.115	16.379	16.643	16.907	17.171	17.435	17.700	17.964	18.228
70	18.492	18.756	19.020	19.285	19.549	19.813	20.077	20.341	20.605	20.870
80	21.134	21.398	21.662	21.926	22.190	22.455	22.719	22.983	23.247	23.511
90	23.775	24.040	24.304	24.568	24.832	25.096	25.631	25.625	25.889	26.153

Liter to U.K. Gallon

1 *l* = 0.21997 U.K.Gal

	0	1	2	3	4	5	6	7	8	9
0		0.220	0.440	0.660	0.880	1.100	1.320	1.540	1.760	1.980
10	2.200	2.420	2.640	2.860	3.080	3.300	3.520	3.740	3.950	4.179
20	4.399	4.619	4.839	5.059	5.279	5.499	5.719	5.939	6.159	6.379
30	6.599	6.819	7.039	7.259	7.479	7.969	7.919	8.139	8.359	8.579
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.778
50	10.998	11.281	11.438	11.658	11.878	12.098	12.318	12.528	12.758	12.978
60	13.198	13.418	13.638	13.858	14.078	14.298	14.518	14.738	14.958	15.178
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378
80	17.598	17.818	18.037	18.257	18.477	18.697	18.917	19.137	19.357	19.577
90	19.797	20.017	20.237	20.457	20.677	20.897	21.117	21.337	21.557	21.777

kgf ∙	m	to	lbf	•	ft
-------	---	----	-----	---	----

 $1 \text{kgf} \cdot \text{m} = 7.233 \text{lbf} \cdot \text{ft}$

									5	
	0	1	2	3	4	5	6	7	8	9
		7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	396.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	10005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4

kgf/cm2 to lbf/in2

 $1 \text{kgf} / \text{cm}^2 = 14.2233 \text{lbf} / \text{in}^2$

								g.	,	2200001/10-
	0	1	2	3	4	5	6	7	8	9
		14.2	28.4	42.7	56.9	71.1	85.3	99.6	113.8	128.0
10	142.2	156.5	170.7	184.9	199.1	213.4	227.6	241.8	256.0	270.2
20	284.5	298.7	312.9	327.1	341.4	355.6	369.8	384.0	398.3	412.5
30	426.7	440.9	455.1	469.4	483.6	497.8	512.0	526.3	540.5	554.7
40	568.9	583.2	597.4	611.6	625.8	640.1	654.3	668.5	682.7	696.9
50	711.2	725.4	739.6	753.8	768.1	782.3	796.5	810.7	825.0	839.2
60	853.4	867.6	881.8	896.1	910.3	924.5	938.7	953.0	967.2	981.4
70	995.6	1010	1024	1038	1053	1067	1081	1095	1109	1124
80	1138	1152	1166	1181	1195	1209	1223	1237	1252	1266
90	1280	1294	1309	1323	1337	1351	1365	1380	1394	1408
100	1422	1437	1451	1465	1479	1493	1508	1522	1536	1550
110	1565	1579	1593	1607	1621	1636	1650	1664	1678	1693
120	1707	1721	1735	1749	1764	1778	1792	1806	1821	1835
130	1849	2863	1877	1892	1906	1920	1934	1949	1963	1977
140	1991	2005	2020	2034	2048	2062	2077	2091	2105	2119
150	2134	2148	2162	2176	2190	2205	2219	2233	2247	2262
160	2276	2290	2304	2318	2333	2347	2361	2375	2389	2404
170	2418	2432	2446	2460	2475	2489	2503	2518	2532	2546
180	2560	2574	2589	5603	2617	2631	2646	2660	2674	2688
200	2845	2859	2873	2887	2901	2916	2930	2944	2958	2973
210	2987	3001	3015	3030	3044	3058	3072	3086	3101	3115
220	3129	3143	3158	3172	3186	3200	3214	3229	3243	3257
230	3271	3286	3300	3314	3328	3343	3357	3371	3385	3399
240	3414	3428	3442	3456	3470	3485	3499	3513	3527	3542

TEMPERATURE

Fahrenheit-Centigrade Conversion.

A simple way to convert a fahrenheit temperature reading into a centigrade temperature reading or vice verse is to enter the accompanying table in the center or boldface column of figures.

These figures refer to the temperature in either Fahrenheit or Centigrade degrees.

If it is desired to convert from Fahrenheit to Centigrade degrees, consider the center column as a table of Fahrenheit temperatures and read the corresponding Centigrade temperature in the column at the left.

If it is desired to convert from Centigrade to Fahrenheit degrees, consider the center column as a table of Centigrade values, and read the corresponding Fahrenheit temperature on the right.

°C		°F	°C		۴F	°C		°F	°C		°F
-40.4	-40	-40.0	-11.7	11	51.8	7.8	46	114.8	27.2	81	117.8
-37.2	-35	-31.0	-11.1	12	53.6	8.3	47	116.6	27.8	82	179.6
-34.4	-30	-22.0	-10.6	13	55.4	8.9	48	118.4	28.3	83	181.4
-31.7	-25	-13.0	-10.0	14	57.2	9.4	49	120.2	28.9	84	183.2
-28.9	-20	-4.0	-9.4	15	59.0	10.0	50	122.0	29.4	85	185.0
-28.3	-19	-2.2	-8.9	16	60.8	10.6	51	123.8	30.0	86	186.8
-27.8	-18	-0.4	-8.3	17	62.6	11.1	52	125.6	30.6	87	188.6
-27.2	-17	1.4	-7.8	18	64.4	11.7	53	127.4	31.1	88	190.4
-26.7	-16	3.2	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-26.1	-15	5.0	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-25.6	-14	6.8	-6.1	21	69.8	13.3	56	132.8	32.8	91	195.8
-25.0	-13	8.6	-5.6	22	71.6	13.9	57	134.6	33.3	92	197.6
-24.4	-12	10.4	-5.0	23	73.4	14.4	58	136.4	33.9	93	199.4
-23.9	-11	12.2	-4.4	24	75.2	15.0	59	138.2	34.4	94	201.2
-23.3	-10	14.0	-3.9	25	77.0	15.6	60	140.0	35.0	95	203.0
-22.8	-9	15.8	-3.3	26	78.8	16.1	61	141.8	35.6	96	204.8
-22.2	-8	17.6	-2.8	27	80.6	16.7	62	143.6	36.1	97	206.6
-21.7	-7	19.4	-2.2	28	82.4	17.2	63	145.4	36.7	98	208.4
-21.1	-6	21.2	-1.7	29	84.2	17.8	64	147.2	37.2	99	210.2
-20.6	-5	23.0	-1.1	35	95.0	21.1	70	158.0	51.7	125	257.0
-20.0	-4	24.8	-0.6	31	87.8	18.9	66	150.8	40.6	105	221.0
-19.4	-3	26.6	0	32	89.6	19.4	67	152.6	43.3	110	230.0
-18.9	-2	28.4	0.6	33	91.4	20.0	68	154.4	46.1	115	239.0
-18.3	-1	30.2	1.1	34	93.2	20.6	69	156.2	48.9	120	248.0
-17.8	0	32.0	1.7	35	95.0	21.1	70	158.0	51.7	125	257.0
-17.2	1	33.8	2.2	36	96.8	21.7	71	159.8	54.4	130	266.0
-16.7	2	35.6	2.8	37	98.6	22.2	72	161.6	57.2	135	275.0
-16.1	3	37.4	3.3	38	100.4	22.8	73	163.4	60.0	140	284.0
-15.6	4	39.2	3.9	39	102.2	23.3	74	165.2	62.7	145	293.0
-15.0	5	41.0	4.4	40	104.0	23.9	75	167.0	65.6	150	302.0
-14.4	6	42.8	5.0	41	105.8	24.4	76	168.8	68.3	155	311.0
-13.9	7	44.6	5.6	42	107.6	25.0	77	170.6	71.1	160	320.0
-13.3	8	46.4	6.1	43	109.4	25.6	78	172.4	73.9	165	329.0
-12.8	9	48.2	6.7	44	111.2	26.1	79	174.2	76.7	170	338.0
-12.2	10	50.0	7.2	45	113.0	26.7	80	176.0	79.4	172	347.0

Group	1 Safety Hints	1-1
Group	2 Specifications	1-10


GROUP 1 SAFETY

FOLLOW SAFE PROCEDURE

Unsafe work practices are dangerous. Understand service procedure before doing work; Do not attempt shortcuts.

WEAR PROTECTIVE CLOTHING


Wear close fitting clothing and safety equipment appropriate to the job.



WARN OTHERS OF SERVICE WORK

Unexpected machine movement can cause serious injury.

Before performing any work on the excavator, attach a **Do Not Operate** tag on the right side control lever.




USE HANDHOLDS AND STEPS

Falling is one of the major causes of personal injury.

When you get on and off the machine, always maintain a three point contact with the steps and handrails and face the machine. Do not use any controls as handholds.

Never jump on or off the machine. Never mount or dismount a moving machine.

Be careful of slippery conditions on platforms, steps, and handrails when leaving the machine.




PREPARE FOR EMERGENCIES

Be prepared if a fire starts.


Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



PROTECT AGAINST FLYING DEBRIS


Guard against injury from flying pieces of metal or debris; Wear goggles or safety glasses.



PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.


Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



AVOID POWER LINES

Serious injury or death can result from contact with electric lines.

Never move any part of the machine or load closer to electric line than 3m(10ft) plus twice the line insulator length.



KEEP RIDERS OFF EXCAVATOR

Only allow the operator on the excavator. Keep riders off.

Riders on excavator are subject to injury such as being struck by foreign objects and being thrown off the excavator. Riders also obstruct the operator's view resulting in the excavator being operated in an unsafe manner.

MOVE AND OPERATE MACHINE SAFELY

Bystanders can be run over. Know the location of bystanders before moving, swinging, or operating the machine.


Always keep the travel alarm in working condition. It warns people when the excavator starts to move.


Use a signal person when moving, swinging, or operating the machine in congested areas. Coordinate hand signals before starting the excavator.

OPERATE ONLY FORM OPERATOR'S SEAT

Avoid possible injury machine damage. Do not start engine by shorting across starter terminals.

NEVER start engine while standing on ground. Start engine only from operator's seat.







PARK MACHINE SAFELY

Before working on the machine:

- \cdot Park machine on a level surface.
- \cdot Lower bucket to the ground.
- \cdot Turn auto idle switch off.
- \cdot Run engine at 1/2 speed without load for 2 minutes.
- Turn key switch to OFF to stop engine. Remove key from switch.
- \cdot Move pilot control shutoff lever to locked position.
- · Allow engine to cool.

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.


Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load.


Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands.





HANDLE FLUIDS SAFELY-AVOID FIRES


Handle fuel with care; It is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks. Always stop engine before refueling machine. Fill fuel tank outdoors.



Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; They can ignite and burn spontaneously.



BEWARE OF EXHAUST FUMES

Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.

If you must operate in a building, be positive there is adequate ventilation. Either use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring enough outside air into the area.

REMOVE PAINT BEFORE WELDING OR HEATING

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:


• If you sand or grind paint, avoid breathing the dust.


Wear an approved respirator.

 If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.





SERVICE MACHINE SAFELY


Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.


Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.

STAY CLEAR OF MOVING PARTS

Entanglements in moving parts can cause serious injury.

To prevent accidents, use care when working around rotating parts.






AVOID HIGH PRESSURE FLUIDS


Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.





AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials.

Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area. Install fire resisting guards to protect hoses or other materials.



PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; It may explode. Warm battery to 16° C (60° F).



PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


- 1. Filling batteries in a well-ventilated area.
- 2. Wearing eye protection and rubber gloves.
- 3. Avoiding breathing fumes when electrolyte is added.
- 4. Avoiding spilling of dripping electrolyte.
- 5. Use proper jump start procedure.

If you spill acid on yourself:

- 1. Flush your skin with water.
- 2. Apply baking soda or lime to help neutralize the acid.
- 3. Flush your eyes with water for 10-15 minutes. Get medical attention immediately.

If acid is swallowed:

- 1. Drink large amounts of water or milk.
- 2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
- 3. Get medical attention immediately.




USE TOOLS PROPERLY

Use tools appropriate to the work. Makeshift tools, parts, and procedures can create safety hazards.

Use power tools only to loosen threaded tools and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only recommended replacement parts. (See Parts catalogue.)




DISPOSE OF FLUIDS PROPERLY

Improperly disposing of fluids can harm the environment and ecology. Before draining any fluids, find out the proper way to dispose of waste from your local environmental agency.


Use proper containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

DO NOT pour oil into the ground, down a drain, or into a stream, pond, or lake. Observe relevant environmental protection regulations when disposing of oil, fuel, coolant, brake fluid, filters, batteries, and other harmful waste.



REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.




LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.

GROUP 2 SPECIFICATIONS

1. MAJOR COMPONENT




125CR9A2SP01

2. SPECIFICATIONS

1) R125LCR-9A


 \cdot 4.30 m (14' 1") BOOM and 2.26 m (7' 5") ARM



125CR9A2SP02

Description		Unit	Specification
Operating weight		kg (lb)	12500 (27560)
Bucket capacity (SAE heaped), standard		m³ (yd³)	0.40 (0.52)
Overall length	А		6860 (22' 6")
Overall width, with 500 mm shoe	В		2500 (8' 2")
Overall height	С		2740 (9' 0")
Superstructure width	D		2490 (8' 2")
Overall height of cab	E		2900 (9' 6")
Ground clearance of counterweight	F		890 (2' 11")
Engine cover height	G		2215 (7' 3")
Minimum ground clearance	Н	mm (ft-in)	440 (1' 5")
Rear-end distance	I	_	1500 (4' 11")
Rear-end swing radius	ľ		1500 (4' 11")
Distance between tumblers	J		2780 (9' 1")
Undercarriage length	К		3490 (11' 5")
Undercarriage width	L		2500 (8' 2")
Track gauge	М		1990 (6' 6")
Track shoe width, standard	N		500 (20")
Travel speed (low/high)		km/hr (mph)	3.6/6.1 (2.2/3.8)
Swing speed		rpm	12.6
Gradeability		Degree (%)	35 (70)
Ground pressure (500 mm shoe)		kgf/cm²(psi)	0.42 (5.91)
Max traction force		kg (lb)	10300 (22710)

2) R125LCRD-9A




Description		Unit	Specification
Operating weight		kg (lb)	13200 (29100)
Bucket capacity (SAE heaped), standard		m³ (yd³)	0.40 (0.52)
Overall length	А		7580 (24' 10")
Overall width, with 500 mm shoe	В		2500 (8' 2")
Overall height	С		2740 (9' 0")
Superstructure width	D		2490 (8' 2")
Overall height of cab	Е		2900 (9' 6")
Ground clearance of counterweight	F		890 (2' 11")
Engine cover height	G		2215 (7' 3")
Minimum ground clearance	Н		440 (1' 5")
Rear-end distance	I	mm (ft in)	1500 (4' 11")
Rear-end swing radius	ľ	mm (ft-in)	1500 (4' 11")
Distance between tumblers	J		2780 (9' 1")
Undercarriage length	K		3490 (11' 5")
Undercarriage width	L		2500 (8' 2")
Track gauge	М	-	1990 (6' 6")
Track shoe width, standard	Ν		500 (20")
Height of blade	0		580 (1' 11")
Ground clearance of blade up	Р	-	540 (1' 9")
Depth of blade down	Q		530 (1' 9")
Travel speed (low/high)		km/hr (mph)	3.6/6.1 (2.2/3.8)
Swing speed		rpm	12.6
Gradeability		Degree (%)	35 (70)
Ground pressure (500 mm shoe)		kgf/cm²(psi)	0.44 (6.24)
Max traction force		kg (lb)	10300 (22710)

3. WORKING RANGE

1) R125LCR/LCRD-9A

(1) 4.30 m (14' 1") MONO BOOM



				125CR9A2SP04
Description		1.96 m (6' 5") Arm	%2.26 m (7' 5") Arm	2.81 (9' 3") Arm
Max digging reach	Α	7410 mm (24' 4")	7690 mm (25' 3")	8220 mm (27' 0")
Max digging reach on ground	A'	7250 mm (23' 9")	7540 mm (24' 9")	8080 mm (26' 6")
Max digging depth	В	4720 mm (15' 6")	5020 mm (16' 6")	5570 mm (18' 3")
Max digging depth (8ft level)	B'	4460 mm (14' 8")	4790 mm (15' 9")	5380 mm (17' 8")
Max vertical wall digging depth	С	3960 mm (13' 0")	4290 mm (14' 1")	4830 mm (15' 10")
Max digging height	D	7920 mm (26' 0")	8110 mm (26' 7")	8480 mm (27' 10")
Max dumping height	E	5620 mm (18' 5")	5800 mm (19' 0")	6170 mm (20' 3")
Min swing radius	F	2310 mm (7' 6")	2340 mm (7' 8")	2470 mm (8' 1")
		79.3 [86.5] kN	79.3 [86.5] kN	79.3 [86.5] kN
	SAE	8081 [8816] kgf	8081 [8816] kgf	8081 [8816] kgf
Bucket digging force		17815 [19435] lbf	17815 [19435] lbf	17815 [19435] lbf
Bucket diggling loice		91.8 [100.1] kN	91.8 [100.1] kN	91.8 [100.1] kN
	ISO	9358 [10209] kgf	9358 [10209] kgf	9358 [10209] kgf
		20631 [22507] lbf	20631 [22507] lbf	20631 [22507] lbf
		60.6 [66.1] kN	56.1 [61.2] kN	48.3 [52.7] kN
	SAE	6178 [6739] kgf	5716 [6236] kgf	4928 [5376] kgf
Arm crowd force		13619 [14857] Ibf	12602 [13747] lbf	10865 [11852] lbf
		63.2 [68.9] kN	58.3 [63.6] kN	50.0 [54.5] kN
	ISO	6443 [7029] kgf	5943 [6484] kgf	5093 [5556] kgf
		14204 [15495] lbf	13103 [14294] Ibf	12228 [12249] lbf

4. WEIGHT

lterre	R125	LCR-9A	R125L0	CRD-9A	
Item	kg	lb	kg	lb	
Upper structure assembly	6950	15320	+		
Main frame weld assembly	1253	2760	•	_	
Engine assembly	538	1190	+	_	
Main pump assembly	90	200	+	_	
Main control valve assembly	140	310	+	_	
Swing motor assembly	120	260	+	_	
Hydraulic oil tank assembly	125	280	•	_	
Fuel tank assembly	110	240	•	_	
Counterweight	2000	4410	+	_	
Cab assembly	450	990	•	_	
Lower chassis assembly	5230	11530	6030	13290	
Track frame weld assembly	1280	1820	1430	3150	
Swing bearing	195	430	•		
Travel motor assembly	140	310	←		
Turning joint	56	120	←		
Track recoil spring	95	210	\leftarrow		
ldler	108	240	←		
Carrier roller	12	26	+	_	
Track roller	24	53	+	_	
Sprocket	40	88	+	_	
Track-chain assembly (500 mm standard triple grouser shoe)	716	1580	*	_	
Dozer blade assembly		-	485	1070	
Front attachment assembly (4.30 m boom, 2.26 m arm, 0.40 m ³ SAE heaped bucket)	1520	3350	•	_	
4.30 m boom assembly	710	1570	+	_	
2.26 m arm assembly	340	750	•	_	
0.40 m ³ SAE heaped bucket	410	910	+	_	
Boom cylinder assembly	200	440	←		
Arm cylinder assembly	120	270	+	_	
Bucket cylinder assembly	80	180	+	_	
Bucket control rod assembly	90	200	+	_	
Dozer blade cylinder assembly		-	55	120	

5. LIFTING CAPACITIES

1) R125LCR-9A

(1) 4.30 m (14' 1") boom, 2.26 m (7' 5") arm equipped with 0.40 m³ (SAE heaped) bucket and 500 mm (20") triple grouser shoe and 2000 kg (4410 lb) counterweight.

•	ľ	: Rating over-front	
---	---	---------------------	--

• 🖃 : Rating over-side or 360 degree

			Load radius								At max. reach		
Load po	oint	1.5 m	(5 ft)	3.0 m	(10 ft)	4.5 m	(15 ft)	6.0 m	(20 ft)	Capa	acity	Reach	
heigh	ıt	ŀ	╔╋┻	ŀ	╔╋╋	ľ		ŀ	╔╋╋	ľ		m (ft)	
6.0 m	kg					*1780	*1780			*1770	1550	5.97	
(20.0 ft)	lb					*3920	*3920			*3900	3420	(19.6)	
4.5 m	kg					*1820	*1820	*1480	1470	1690	1120	6.90	
(15.0 ft)	lb					*4010	*4010	*3260	3240	3730	2470	(22.6)	
3.0 m	kg			*2850	*2850	*2300	*2300	*2090	1430	1460	940	7.34	
(10.0 ft)	lb			*6280	*6280	*5070	*5070	*4610	3150	3220	2070	(24.1)	
1.5 m	kg			*4670	4290	*2980	2210	2030	1340	1390	890	7.41	
(5.0 ft)	lb			*10300	9460	*6570	4870	4480	2950	3060	1960	(24.3)	
Ground	kg			*5790	3890	3130	2030	1950	1260	1470	940	7.13	
Line	lb			*12760	8580	6900	4480	4300	2780	3240	2070	(23.4)	
-1.5 m	kg	*5690	*5690	*5970	3790	3040	1950	1920	1230	1760	1140	6.42	
(-5.0 ft)	lb	*12540	*12540	*13160	8360	6700	4300	4230	2710	3880	2510	(21.1)	
-3.0 m	kg	*8700	*8700	*5360	3860	3070	1980			*2290	1760	5.08	
(-10 ft)	lb	*19180	*19180	*11820	8510	6770	4370			*5050	3880	(16.7)	

Note 1. Lifting capacity are based on SAE J1097 and ISO 10567.

- 2. Lifting capacity of the ROBEX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The load point is a hook located on the back of the bucket.
- 4. *indicates load limited by hydraulic capacity.
- (2) 4.30 m (14' 1") boom, 1.96 m (6' 5") arm equipped with 0.40 m³ (SAE heaped) bucket and 500 mm (20") triple grouser shoe and 2000 kg (4410 lb) counterweight.

								-				
					Load ı	adius				At max. reach		
Load po	oint	1.5 m	(5 ft)	3.0 m	(10 ft)	4.5 m	(15 ft)	6.0 m	(20 ft)	Capa	acity	Reach
heigh	it	ľ		ľ		ŀ		ľ	⋐⋕⋑	ľ		m (ft)
6.0 m	kg					*1780	*1780			*1900	1740	5.61
(20.0 ft)	lb					*3920	*3920			*4190	3840	(18.4)
4.5 m	kg					*2040	*2040			1840	1230	6.59
(15.0 ft)	lb					*4500	*4500			4060	2710	(21.6)
3.0 m	kg			*3270	*3270	*2500	2410	2110	1410	1570	1020	7.06
(10.0 ft)	lb			*7210	*7210	*5510	5310	4650	3110	3460	2250	(23.2)
1.5 m	kg			*5030	4200	*3160	2190	2030	1340	1500	970	7.13
(5.0 ft)	lb			*11090	9260	*6970	4830	4480	2950	3310	2140	(23.4)
Ground	kg			*5940	3870	3130	2030	1960	1270	1590	1030	6.83
Line	lb			*13100	8530	6900	4480	4320	2800	3510	2270	(22.4)
-1.5 m	kg	*6190	*6190	*5920	3820	3060	1970			1940	1270	6.08
(-5.0 ft)	lb	*13650	*13650	*13050	8420	6750	4340			4280	2800	(19.9)
-3.0 m	kg	*9140	*9140	*5120	3940	3130	2040					
(-10 ft)	lb	*20150	*20150	*11290	8690	6900	4500					

2) R125LCRD-9A (with dozer blade)

(1) 4.30 m (14' 1") boom, 2.26 m (7' 5") arm equipped with 0.40 m³ (SAE heaped) bucket and 500 mm (20") triple grouser shoe and 2000 kg (4410 lb) counterweight with dozer blade down.

						At max. reach						
Load po	oint	1.5 m	(5 ft)	3.0 m	(10 ft)	4.5 m	(15 ft)	6.0 m	(20 ft)	Capa	acity	Reach
heigh	t	ľ	╔╼╋╸	ŀ	╔╋╋	ľ			₢╉╸	ŀ		m (ft)
6.0 m	kg					*1780	*1780			*1770	*1770	5.97
(20.0 ft)	lb					*3920	*3920			*3900	*3900	(19.6)
4.5 m	kg					*1820	*1820	*1480	*1480	*1850	1350	6.90
(15.0 ft)	lb					*4010	*4010	*3260	*3260	*4080	2980	(22.6)
3.0 m	kg			*2850	*2850	*2300	*2300	*2090	1700	*1940	1150	7.34
(10.0 ft)	lb			*6280	*6280	*5070	*5070	*4610	3750	*4280	2540	(24.1)
1.5 m	kg			*4670	*4670	*2980	2630	*2370	1610	*2060	1090	7.41
(5.0 ft)	lb			*10300	*10300	*6570	5800	*5220	3550	*4540	2400	(24.3)
Ground	kg			*5790	4710	*3560	2440	*2630	1530	*2180	1150	7.13
Line	lb			*12760	10380	*7850	5380	*5800	3370	*4810	2540	(23.4)
-1.5 m	kg	*5690	*5690	*5970	4600	*3770	2360	*2660	1500	*2300	1380	6.42
(-5.0 ft)	lb	*12540	*12540	*13160	10140	*8310	5200	*5860	3310	*5070	3040	(21.1)
-3.0 m	kg	*8700	*8700	*5360	4680	*3430	2390			*2290	2100	5.08
(-10 ft)	lb	*19180	*19180	*11820	10320	*7560	5270			*5050	4630	(16.7)

Note 1. Lifting capacity are based on SAE J1097 and ISO 10567.

> 2. Lifting capacity of the ROBEX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.

- 3. The load point is a hook located on the back of the bucket.
- 4. *indicates load limited by hydraulic capacity.
- (2) 4.30 m (14' 1") boom, 1.96 m (6' 5") arm equipped with 0.40 m³ (SAE heaped) bucket and 500 mm (20") triple grouser shoe and 2000 kg (4410 lb) counterweight with dozer blade down.

					5.	,		5				
			Load radius							At max. reach		
Load po	oint	1.5 m	(5 ft)	3.0 m	(10 ft)	4.5 m	(15 ft)	6.0 m	(20 ft)	Cap	acity	Reach
heigh	it	ŀ	╔╋╋	ŀ	╔╋╋	ŀ	⋳⋕⋬	ŀ	╔╋╋	ŀ	╔╋╸	m (ft)
6.0 m	kg					*1780	*1780			*1900	*1900	5.61
(20.0 ft)	lb					*3920	*3920			*4190	*4190	(18.4)
4.5 m	kg					*2040	*2040			*1970	1470	6.59
(15.0 ft)	lb					*4500	*4500			*4340	3240	(21.6)
3.0 m	kg			*3270	*3270	*2500	*2500	*2230	1690	*2070	1250	7.06
(10.0 ft)	lb			*7210	*7210	*5510	*5510	*4920	3730	*4560	2760	(23.2)
1.5 m	kg			*5030	5030	*3160	2610	*2480	1610	*2190	1180	7.13
(5.0 ft)	lb			*11090	11090	*6970	5750	*5470	3550	*4830	2600	(23.4)
Ground	kg			*5940	4690	*3660	2440	*2690	1540	*2320	1250	6.83
Line	lb			*13100	10340	*8070	5380	*5930	3400	*5110	2760	(22.4)
-1.5 m	kg	*6190	*6190	*5920	4640	*3790	2380			*2420	1540	6.08
(-5.0 ft)	lb	*13650	*13650	*13050	10230	*8360	5250			*5340	3400	(19.9)
-3.0 m	kg	*9140	*9140	*5120	4750	*3240	2450					
(-10 ft)	lb	*20150	*20150	*11290	10470	*7140	5400					

6. BUCKET SELECTION GUIDE

1) R125LCR-9A, R125LCRD-9A

(1) General bucket

0.40 m³ SAE	0.45 m³ SAE
heaped bucket	heaped bucket

Capacity		10/i	Width		Recommendation		
Cap	aony	vvidtri		Weight	4.3 m (14' 1") boom		
SAE heaped	CECE heaped	Without side cutter	With side cutter	Weight	1.96 m arm (6' 5")	2.26 m arm (7' 5")	
0.40 m³ (0.52 yd³)	0.36 m³ (0.47 yd³)	760 mm (29.9")	870 mm (32.3")	410 kg (900 lb)			
0.45 m³ (0.59 yd³)	0.40 m³ (0.52 yd³)	830 mm (32.7")	940 mm (37.0")	430 kg (950 lb)			

Applicable for materials with density of 2000 kg/m³ (3370 lb/yd³) or less

Applicable for materials with density of 1600 kg/m³ (2700 lb/yd³) or less

7. UNDERCARRIAGE

1) TRACKS

X-leg type center frame is integrally welded with reinforced box-section track frames. The design includes dry tracks, lubricated rollers, idlers, sprockets, hydraulic track adjusters with shock absorbing springs and assembled track-type tractor shoes with triple grousers.

2) TYPES OF SHOES

				Triple grouser			
Model	Shape	5					
	Shoe width	mm (in)	× 500 (20)	600 (24)	700 (28)		
R125LCR-9A	Operating weight	kg (lb)	12500 (27560)	12600 (27910)	12820 (28260)		
RIZOLOR-9A	Ground pressure	kgf/cm² (psi)	0.42 (5.91)	0.35 (4.99)	0.30 (4.33)		
	Overall width	mm (ft-in)	2500 (8' 2")	2600 (8' 6")	2700 (8' 10")		
	Shoe width	mm (in)	× 500 (20)	600 (24)	700 (28)		
	Operating weight	kg (lb)	13200 (29100)	13360 (29450)	13520 (29810)		
R125LCRD-9A	Ground pressure	kgf/cm² (psi)	0.44 (6.24)	0.37 (5.26)	0.32 (4.57)		
	Overall width	mm (ft-in)	2500 (8' 2")	2600 (8' 6")	2700 (8' 10")		

* : Standard

3) NUMBER OF ROLLERS AND SHOES ON EACH SIDE

literer	Quantity
Item	R125LCR-9A/R125LCRD-9A
Carrier rollers	1 EA
Track rollers	6 EA
Track shoes	43 EA

4) SELECTION OF TRACK SHOE

Suitable track shoes should be selected according to operating conditions.

Method of selecting shoes

Confirm the category from the list of applications in **table 2**, then use **table 1** to select the shoe. Wide shoes (Categories B and C) have limitations on applications. Before using wide shoes, check the precautions, then investigate and study the operating conditions to confirm if these shoes are suitable.

Select the narrowest shoe possible to meet the required flotation and ground pressure. Application of wider shoes than recommendations will cause unexpected problem such as bending of shoes, crack of link, breakage of pin, loosening of shoe bolts and the other various problems.

* Table 1

Track shoe	Specification	Category
500 mm triple grouser	Standard	А
600 mm triple grouser	Option	А
700 mm triple grouser	Option	В

* Table 2

Category	Applications	Applications
A	Rocky ground, river beds, normal soil	Travel at low speed on rough ground with large obstacles such as boulders or fallen trees
В	Normal soil, soft ground	 These shoes cannot be used on rough ground with large obstacles such as boulders or fallen trees Travel at high speed only on flat ground Travel slowly at low speed if it is impossible to avoid going over obstacles

8. SPECIFICATIONS FOR MAJOR COMPONENTS

1) ENGINE

Item	Specification
Model	Perkins 1204E
Туре	4-cycle turbocharged charge air cooled diesel engine
Cooling method	Water cooling
Number of cylinders and arrangement	4 cylinders, in-line
Firing order	1-3-4-2
Combustion chamber type	Direct injection type
Cylinder bore \times stroke	$105 \times 127 \text{ mm} (4.1" \times 5.0")$
Piston displacement	4400 cc (269 cu in)
Compression ratio	16.5 : 1
Rated gross horse power (SAE J1995)	100 Hp (74.3 kW) at 1900 rpm
Maximum torque	45.9 kgf · m (332 lbf · ft) at 1400 rpm
Engine oil quantity	10.5 / (2.8 U.S. gal)
Dry weight	507 kg (1118 lb)
High idling speed	2000 ± 50 rpm
Low idling speed	800 ± 100 rpm
Rated fuel consumption	160 g/Hp ⋅ hr at 1900 rpm
Starting motor	24 V-4.5 kW
Alternator	24 V-85 A
Battery	2×12 V \times 100 Ah

2) MAIN PUMP

Item	Specification
Туре	Variable displacement tandem axis piston pumps
Capacity	2×62.2 cc/rev
Maximum pressure	330 kgf/cm ² (4690 psi) [360 kgf/cm ² (5120 psi)]
Rated oil flow	2 × 123.5 / /min (32.6 U.S. gpm / 27.2 U.K. gpm)
Rated speed	1900 rpm

[]: Power boost

3) GEAR PUMP

Item	Specification		
Туре	Fixed displacement gear pump single stage		
Capacity	15cc/rev		
Maximum pressure	40 kgf/cm² (570 psi)		
Rated oil flow	28.5 l /min (7.5 U.S. gpm / 6.3 U.K. gpm)		

4) MAIN CONTROL VALVE

Item	Specification
Туре	11 spools
Operating method	Hydraulic pilot system
Main relief valve pressure	330 kgf/cm ² (4690 psi)[360 kgf/cm ² (5120 psi)]
Overload relief valve pressure	380 kgf/cm ² (5400 psi)

[]: Power boost

5) SWING MOTOR

Item	Specification
Туре	Fixed displacement axial piston motor
Capacity	71 cc/rev
Relief pressure	285 kgf/cm ² (4050 psi)
Braking system	Automatic, spring applied hydraulic released
Braking torque	31.4 kgf · m (227 lbf · ft)
Brake release pressure	19.2~50 kgf/cm ² (273~711 psi)
Reduction gear type	2 - stage planetary

6) TRAVEL MOTOR

Item	Specification
Туре	Variable displacement axial piston motor
Relief pressure	350 kgf/cm ² (4970 psi)
Capacity (max / min)	67.6/41.4 cc/rev
Reduction gear type	2-stage planetary
Braking system	Automatic, spring applied hydraulic released
Brake release pressure	14.3 kgf/cm ² (203 psi)
Braking torque	33 kgf · m (239 lbf · ft)

7) CYLINDER

	ltem	Specification			
Deem eulinder	Bore dia \times Rod dia \times Stroke	$Ø95 \times Ø70 \times 1015 \text{ mm}$			
Boom cylinder	Cushion	Extend only			
	Bore dia \times Rod dia \times Stroke	ø 110 × ø 75 × 1070 mm			
Arm cylinder	Cushion	Extend and retract			
Ducket evlinder	Bore dia \times Rod dia \times Stroke	Ø 95 × Ø 65 × 855 mm			
Bucket cylinder	Cushion	Extend only			
Dener er lie den (erstiere)	Bore dia \times Rod dia \times Stroke				
Dozer cylinder (option)	Cushion	-			

* Discoloration of cylinder rod can occur when the friction reduction additive of lubrication oil spreads on the rod surface.

* Discoloration does not cause any harmful effect on the cylinder performance.

8) SHOE

Item		Width	Ground pressure	Link quantity	Overall width	
	Standard	500 mm (20")	0.42 kgf/cm ² (5.91 psi)	43	2500 mm (8' 2")	
R125LCR-9A	Ontion	600 mm (24")	0.35 kgf/cm ² (4.99 psi)	43	2600 mm (8' 6")	
	Option	700 mm (28")	0.30 kgf/cm ² (4.33 psi)	43	2700 mm (8' 10")	
	Standard	500 mm (20")	0.44 kgf/cm ² (6.24 psi)	43	2500 mm (8' 2")	
R125LCRD-9A	Ontion	600 mm (24")	0.37 kgf/cm ² (5.26 psi)	43	2600 mm (8'6")	
	Option	700 mm (28")	0.32 kgf/cm ² (4.57 psi)	43	2700 mm (8' 10")	

9) BUCKET

ltom	Cap	Tooth	Width		
Item	SAE heaped CECE heaped		quantity	Without side cutter	With side cutter
R125LCR-9A	0.40 m ³ (0.52 yd ³)	0.36 m ³ (0.47 yd ³)	4	760 mm (29.9")	870 mm (34.3")
R125LCRD-9A	0.45 m ³ (0.59 yd ³)	m ³ (0.59 yd ³) 0.40 m ³ (0.52 yd ³)		830 mm (32.7")	940 mm (37.0")

9. RECOMMENDED OILS

Use only oils listed below. Do not mix different brand oil. Please use HYUNDAI genuine oil and grease.

		Capacity			Ambi	ent temp	erature	°C(°F)		
Service point	Kind of fluid	l (U.S. gal)	-50 -3					10	20	30	40
			(-58) (-2	22) (-4) (1	4) (;	32) ((50)	(68)	(86)	(104)
				*:	SAE 5W	-40					
								5	SAE 30		
Engine	Engine oil	10.5 (2.8)			SAF	E 10W		_			
oil pan		10.0 (2.0)									
						5	AE 10V				
							SAE	15W-40	0 		
Swing drive		3.4 (0.9)		*5	SAE 75V	V-90					
	Gear oil	2.5×2	-				SVE	80W-90	<u>ן</u>		
Final drive		(0.7×2)					JAE	0000-90	<u> </u>		
		Tank:			*ISO V	G 15					
Hydraulic		79 (20.9)				ISO V	G 32				
tank	Hydraulic oil	Hydraulic oil									
		System: 109 (28.8)					ISO V	G 46			
		100 (20.0)						ISO VO	G 68		
				ASTM E	975 NC).1					
Fuel tank	Diesel fuel★1	210 (55.5)					10	TM D97		<u> </u>	
							AS		⁵ NO.2	<u>.</u>	
Fitting											
Fitting (Grease	Grease	As required		*NLGI NO.1							
nipple)							NLC	GI NO.2			
Radiator	Mixture of antifreeze		Ethylene glycol base permanent type (50 : 50)								
(Reservoir tank)	and soft water*2	14.5 (3.8)	* Ethylene	glycol base		1					

SAE : Society of Automotive Engineers

- API : American Petroleum Institute
- **ISO** : International Organization for Standardization
- NLGI : National Lubricating Grease Institute
- $\ensuremath{\textbf{ASTM}}$: American Society of Testing and Materia
- UTTO: Universal Tractor Transmission Oil

- ★1 : Ultra low sulfur diesel
 - sulfur content $\leq 15 \text{ ppm}$
- *2 : Soft water City water or distilled water
- ★ : Cold region Russia, CIS, Mongolia


SECTION 2 STRUCTURE AND FUNCTION

Group	1 Pump Device ·····	2-1
Group	2 Main Control Valve	2-20
Group	3 Swing Device	2-47
Group	4 Travel Device	2-58
Group	5 RCV Lever ·····	2-71
Group	6 RCV Pedal ·····	2-78

GROUP 1 PUMP DEVICE


1. STRUCTURE

The pump device consists of main pump, regulator and gear pump.



1) MAIN PUMP (1/2)

The main pump consists of two piston pumps (front & rear) and valve block.



140Z92MP02

- 111 Drive shaft (F)
- 113 Drive shaft (R)
- 116 1st Gear
- 123 Roller bearing
- 124 Needle bearing
- 127 Bearing spacer
- 141 Cylinder block
- 151 Piston
- 152 Shoe
- 153 Set plate
- 156 Bushing
- 157 Cylinder spring
- 211 Shoe plate
- 212 Swash plate
- 214 Bushing
- 251 Support
- 255 Lock pin
- 261 Seal cover (F)
- 263 Seal cover (R)
- 271 Pump casing (F)


- 272 Pump casing (R)312 Valve block313 Valve plate (R)
- 314 Valve plate (L)
- 401 Hexagon socket bolt
- 401 Tiexagon socket bo
- 402 Hexagon socket bolt
- 406 Hexagon socket bolt415 Hexagon socket bolt
- 415 Hexag
- 466 Plug
- 467 plug
- 468 Plug
- 490 Plug
- 531 Tilting pin
- 532 Servo piston
- 533 Plug
- 534 Stopper (L)
- 535 Stopper (S)
- 548 Pin
- 702 O-ring 710 O-ring

723 O-ring
724 O-ring
728 O-ring
732 O-ring
733 O-ring
734 O-ring
734 O-ring

711 O-ring

717 O-ring

- 774 Oil seal
- 789 Back up ring
- 792 Back up ring
- 806 Nut
- 808 Hexagon head nut
- 824 Snap ring
- 886 Spring pin
- 901 Eye bolt
- 953 Set screw
- 954 Set screw
- 981 Plate
- 983 Pin



04 Gear pump


- 115 Shaft
- 117 Gear No. 2
- 118 Gear No. 3
- 125 Ball bearing
- 126 Roller bearing

128	Bearing spacer	711	0
262	Cover	728	0
326	Gear case	825	R
414	Hexagon socket bolt	826	R
435	Flange socket bolt	885	S
468	Plug	886	Pi


711 O-ring
728 O-ring
825 Retainer ring
826 Retainer ring
885 Spring pin
886 Pin

140Z92MP03


2) REGULATOR (1/2)



418 753 753 439 SECTION E-E (REAR)



A	Delivery port	SAE6000 psi 3/4"
В	Suction port	SAE2500 psi 2 1/2"
Pi	Pilot port	PF 1/4-15
P1	EPPR valve primary port	PF 1/4-13
P2	Companion delivery port	internal




140Z92MP05

079 EPPR valve assembly 412 Hexagon socket screw 413 Hexagon socket screw 418 Hexagon socket screw 437 Hexagon socket screw 438 Hexagon socket screw 439 Hexagon socket screw 466 Plug 496 Plug 601 Casing 611 Feed back lever 612 Lever (1) 613 Lever (2) 614 Center plug 615 Adjust plug 616 Plug 621 Compensator piston 622 Piston case 623 Compensator rod

624 Spring seat (C) 625 Outer spring 626 Inner spring 627 Adjust stem (C) 628 Adjust screw (C) 629 Cover (C) 630 Lock nut 631 Sleeve, Pf 641 Pilot cover 643 Pilot piston 644 Spring seat (Q) 645 Adjust stem (Q) 646 Pilot spring 651 Sleeve 652 Spool 653 Spring seat 654 Return spring 655 Set spring 656 Block cover

708 O-ring 724 O-ring 725 O-ring 728 O-ring 730 O-ring 734 O-ring 753 O-ring 755 O-ring 757 O-ring 801 Nut 802 Nut 814 Snap ring 836 Snap ring 874 Pin 875 Pin 887 Pin 897 Pin 898 Pin 924 Set screw

3) GEAR PUMP



307	Poppet	353	D
308	Seat	354	D
309	Ring	355	Fi
310	Spring	361	Fr
311	Screw	433	FI
312	Nut	434	FI
351	Gear case	435	FI

53	Drive gear	466	Plug
54	Driven gear	700	Ring
55	Filter	710	O-ring
61	Front case	725	O-ring
33	Flange socket	732	O-ring
34	Flange socket	850	Snap ring
35	Flange socket	887	Pin

2-6

2. FUNCTION

1) MAIN PUMP

The pumps may be classified roughly into the rotary group performing a rotary motion and working as the major part of the whole pump function: the swash plate group that varies the delivery rates: and the valve cover group that changes over oil suction and discharge : and the PTO group that transfers drive shaft of gear pump.

(1) Rotary group

The rotary group consists of drive shaft (F) (111), cylinder block (141), piston shoes (151,152), set plate (153), spherical bushing (156) and cylinder spring (157). The drive shaft is supported by bearing (123,124) at its both ends.

The shoe is caulked to the piston to from a spherical coupling. It has a pocket to relieve thrust force generated by loading pressure and to take hydraulic balance so that it slides lightly over the shoe plate (211). The sub group composed by a piston and a shoe is pressed against the shoe plate by the action of the cylinder spring via the set plate and a spherical bushing.


Similarly, the cylinder block is pressed against valve plate (313) by the action of the cylinder spring.

(2) Swash plate group

The swash plate group consists of swash plate (212), shoe plate (211), swash plate support (251), lock pin (255), tilting bushing (214), tilting pin (531) and servo piston (532).

The swash plate is a cylindrical part formed on the opposite side of the sliding surface of the shoe and is supported by the swash support.

If the servo piston moves to the right or left as hydraulic force controlled by the regulator connects to hydraulic chamber located on both sides of the servo piston, the swash plate slides over the swash plate support via the spherical part of the tilting pin to change the tilting angle (α)



140Z92MP09

(3) Valve block group

The valve block group consists of valve block (312), valve plate (313, 314) and spring pin(886).

The valve plate having two kidmey ports is fixed to the valve block and feeds and collects oil to and from the cylinder block.

The oil changed over by the valve plate is connected to an external pipeline by way of the valve block.


(4) PTO group


PTO group consist of 1st gear (116) and 2nd gear (117), 3rd gear (118).

2nd gear and 3rd gear are supported by bearings (125, 126), and it can be mounted to the valve block.

Now, if the drive shaft is driven by a prime mover (electric motor, engine, etc), it rotates the cylinder block via a spline linkage at the same time. If the swash plate is tilted as in Fig (previous page) the pistons arranged in the cylinder block make a reciprocating motion with respect to the cylinder block, while they revolve with the cylinder block.

If you pay attention to a single piston, it performs a motion away from the valve plate (oil sucking process) within 180 degrees, and makes a motion towards the valve plate (oil discharging process) in the rest of 180 degrees. When the swash plate has a tilting angle of zero, the piston makes no stroke and discharges no oil. Concurrently, the auxiliary pump is driven by gears of PTO.





140Z92MP08


2) REGULATOR

Regulator consists of the negative flow control, total horse power control and power shift control function.


(1) Negative flow control

By changing the pilot pressure Pi, the pump tilting angle (delivery flow) is regulated arbitrarily, as shown in the figure.

This regulator is of the negative flow control in which the delivery flow Q decreases as the pilot pressure Pi rises. With this mechanism, when the pilot pressure corresponding to the flow required for the work is commanded, the pump discharges the required flow only, and so it does not consume the power uselessly.



① Flow reducing function



As the pilot pressure Pi rises, the pilot piston (643) moves to the right to a position where the force of the pilot spring (646) balances with the hydraulic force.

The groove (A) in the pilot piston is fitted with the pin (875) that is fixed to lever 2 (613). Therefore, when the pilot piston moves, lever 2 rotates around the fulcrum of point B [fixed by the fulcrum plug (614) and pin (875)]. Since the large hole section (C) of lever 2 contains a protruding pin (897) fixed to the feedback lever (611), the pin (897) moves to the right as lever 2 rotates. Since the opposing-flat section (D) of the feedback lever is fitted with the pin (548) fixed by the tilting pin (531) that swings the swash plate, the feedback lever rotates around the fulcrum of point D, as the pin (897) moves.


Since the feedback lever is connected with the spool (652) via the pin (874), the spool moves to the right.

The movement of the spool causes the delivery pressure P1 to connect to port CL through the spool and to be admitted to the large diameter section of the servo piston. The delivery pressure P1 that is constantly admitted to the small diameter section of the servo piston moves the servo piston to the right due to the area difference, resulting in decrease of the tilting angle.

When the servo piston moves to the right, point D also moves to the right. The spool is fitted with the return spring (654) and is tensioned to the left at all times, and so the pin (897) is pressed against the large hole section (C) of lever 2.

Therefore, as point D moves, the feedback lever rotates around the fulcrum of point C, and the spool is shifted to the left. This causes the opening between the sleeve (651) and spool (652) to close slowly, and the servo piston comes to a complete stop when it closes completely.

② Flow increasing function



As the pilot pressure Pi decreases, the pilot piston (643) moves to the left by the action of the pilot spring (646) and causes lever 2 (613) to rotate around the fulcrum of point B. Since the pin (897) is pressed against the large hole section (C) of lever 2 by the action of the return spring (654) via the spool (652), pin (874), and feedback lever (611), the feedback lever rotates around the fulcrum of point D as lever 2 rotates, and shifts the spool to the left. Port CL opens a way to the tank port as the spool moves. This deprives the large diameter section of the servo piston of pressure, and shifts the servo piston to the left by the discharge pressure P1 in the small diameter section, resulting in an increase in the flow rate.


As the servo piston moves, point D also moves to the left, the feedback lever rotates around the fulcrum of point C, and the spool moves to the right till the opening between the spool and sleeve is closed.

③ Adjustment of flow control characteristic

The flow control characteristic can be adjusted with the adjusting screw. Adjust it by loosening the hexagon nut (801) and by tightening (or loosening) the hexagonal socket head screw (924). Tightening the screw shifts the control chart to the right as shown in the figure.

* Adjusting value

	-		
Speed	Adjustment of flow control characteristic		
	Tightening amount of adjusting screw (924)	Flow control starting pressure change amount	Flow change amount
(min ⁻¹)	(Turn)	(kgf/cm ²)	(1 /min)
1900	+1/4	+1.4	+7.1



(2) Total horsepower control

The regulator decreases the pump tilting angle (delivery flow) automatically to limit the input torque within a certain value with a rise in the delivery pressure P1 of the self pump and the delivery pressure P2 of the companion pump.

(The input horsepower is constant when the speed is constant.)


Since the regulator is of the simultaneous total horsepower type that operates by the sum of load pressures of the two pumps in the tandem double-pump system, the prime mover is automatically prevented from being overloaded, irrespective of the load condition of the two pumps, when horsepower control is under way.

Since this regulator is of the simultaneous total horsepower type, it controls the tilting angles (displacement volumes) of the two pumps to the same value as represented by the following equation :

 $Tin = P1 \times q/2 \pi + P2 \times q/2 \pi$ $= (P1 + P2) \times q/2 \pi$


 $= (P1+P2) \times q/2 \pi$

The horsepower control function is the same as the flow control function and is summarized in the following. (For detailed behaviors of respective parts, refer to the section of flow control).



Delivery pressure, (P1+P2)

① Overload preventive function




140Z92RG03

When the self pump delivery pressure P1 or the companion pump delivery pressure P2 rises, it acts on the stepped part of the compensating piston (621). It presses the compensating rod (623) to the right till the force of the outer spring (625) and inner spring (626) balances with the hydraulic force. The movement of the compensating rod is transmitted to lever 1 (612) via pin (875).

Lever 1 rotates around the pin (875) (E) fixed to the casing (601).

Since the large hole section (F) of lever 1 contains a protruding pin (897) fixed to the feedback lever (611), the feedback lever rotates around the fulcrum of point D as lever 1 rotates, and then the spool (652) is shifted to the right. As the spool moves, the delivery pressure P1 is admitted to the large diameter section of the servo piston via port CL, causes the servo piston move to the right, reduces the pump delivery, flow rate, and prevents the prime mover from being overloaded. The movement of the servo piston is transmitted to the feedback lever via point D. Then the feedback lever rotates around the fulcrum of point F and the spool is shifted to the left. The spool moves till the opening between the spool (652) and sleeve (651) is closed.

② Flow reset function



140Z92RG04

As the self pump delivery pressure P1 or the companion pump delivery pressure P2 decreases, the compensating rod (623) is pushed back by the action of the springs (625 & 626) to rotate lever 1 (612) around point E. Rotating of lever 1 causes the feedback lever (611) to rotate around the fulcrum of point D and then the spool (652) to move to the left. As a result, port CL opens a way to the tank port.

This causes the servo piston to move to the left and the pump's delivery rate to increase.

The movement of the servo piston is transmitted to the spool by the action of the feedback mechanism to move it till the opening between the spool and sleeve is closed.

③ Low tilting angle (low flow) command preferential function

As mentioned above, flow control and horsepower control tilting angle commands are transmitted to the feedback lever and spool via the large-hole sections (C & F) of levers 1 and 2. However, since sections C and F have the pins (\emptyset 4) protruding from the large hole (\emptyset 8), only the lever lessening the tilting angle contacts the pin (897); the hole (\emptyset 8) in the lever of a larger tilting angle command is freed without contacting the pin (897). Such a mechanical selection method permits preference of the lower tilting angle command of the flow control and horsepower control.


④ Adjustment of input horsepower

Since the regulator is of total cumulative horsepower type, adjust the adjusting screws of both the front and rear pumps, when changing the horsepower set values. The pressure change values by adjustment are based on two pumps pressurized at the same time, and the values will be doubled when only one pump is loaded.

a. Adjustment of outer spring

Adjust it by loosening the hexagon nut (630) and by tightening (or loosening) the adjusting screw C (628).


Tightening the screw shifts the control chart to the right and increases the input horsepower as shown in the figure. Since turning the adjusting screw C (628) by N turns changes the setting of the inner spring (626), return the adjusting stem C (627) by $N \times A$ turns at first. (A=1.48)



* Adjusting value

Speed	Adjustment of input horsepower		
	Tightening amount of adjusting screw (C) (628)	Compensa- ting control starting pressure change amount	Input torque change amount
(min -1)	(Turn)	(kgf/cm ²)	(kgf ⋅ m)
1900	+1/4	+15.9	+2.7





Delivery pressure, (P1+P2)


b. Adjustment of inner spring


Adjust it by loosening the hexagon nut (802) and by tightening (or loosening) the adjusting stem C (627).

Tightening the screw increases the flow and then the input horsepower as shown in the figure.

* Adjusting value


Speed	Adjustment of input horsepower		
	Tightening amount of adjusting stem (C) (627)	Flow change amount	Input torque change amount
(min ⁻¹)	(Turn)	(l /min)	(kgf · m)
1900	+1/4	+6.6	+3.1





Delivery pressure, (P1+P2)

(3) Power shift control




140Z92RG05

The set horsepower value is shifted by varying the command current level of the proportional pressure reducing value attached to the pump.

Only one proportional pressure reducing valve is provided.

However, the secondary pressure Pf (power shift pressure) is admitted to the horsepower control section of each pump regulator through the pump's internal path to shift it to the same set horsepower level.



Delivery pressure, (P1+P2)

This function permits arbitrary setting of the pump output power, thereby providing the optimum power level according to the operating condition.

The power shift pressure Pf controls the set horsepower of the pump to a desired level, as shown in the figure.

As the power shift pressure Pf rises, the compensating rod (623) moves to the right via the pin (898) and compensating piston (621).

This decreases the pump tilting angle and then the set horsepower in the same way as explained in the overload preventive function of the horsepower control. On the contrary, the set horsepower rises as the power shift pressure Pf falls.


(4) Adjustment of maximum and minimum flows

① Adjustment of maximum flow

Adjust it by loosening the hexagon nut (808) and by tightening (or loosening) the set screw (954).

The maximum flow only is adjusted without changing other control characteristics.

Speed	Adjustment of max flow		
	Tightening amount of adjusting screw (954)	Flow change amount	
(min -1)	(Turn)	(1 /min)	
1900	+1/4	-3.0	



⁽²⁾ Adjustment of minimum flow


Adjust it by loosening the hexagon nut (806) and by tightening (or loosening) the hexagonal socket head set screw (953). Similarly to the adjustment of the maximum flow, other characteristics are not changed.

However, remember that, if tightened too much, the required horsepower during the maximum delivery pressure (or during relieving) may increase.

Speed	Adjustment of min flow		
	Tightening amount of adjusting screw (953)	Flow change amount	
(min -1)	(Turn)	(<i>l</i> /min)	
1900	+1/4	+3.0	

GROUP 2 MAIN CONTROL VALVE

1. STRUCTURE



VIEW A

 \bigcirc

TRAVEL LEFT

A —

BOOM 1

ARM 2

ARM REGENERATION & OPTION-A(BREAKER)

BUCKET

 \bigcirc

0

60


TRAVEL RIGHT


SWING


BOOM 2 & SWING PRIORITY

DOZER DOWN


ARM 1








Mark	Port name	Port size	Tightening torque
Rs	Make up for swing motor	UNF 1 3/16	18 kgf · m (130 lbf · ft)
Pd40 Pd41 Pa5 Pb5 Pc5 Pd5 Pd6 Pd0 Pd0 Pd0 Pd0 Pd0 Pd0 Pd0 Pai P03 P04 P05 P05 P05 P05 P05 Dr0 Dr1 Dr2 Dr3	Lock valve pilot port (boom) Swing pilot port (RH) Swing pilot port (LH) Arm in confluence pilot port Swing priority pilot port Option A pilot port (breaker) Arm in regeneration cut port Arm in pilot port Lock valve pilot port (arm) Arm in regen-cut signal selector port Arm out pilot port Arm out pilot port Bucket in pilot port Option B pilot port Option C pilot port (dozer blade down) Travel straight pilot port Option C pilot port (dozer blade down) Travel straight pilot port Auto idle signal-attachment Pilot signal port Boom priority pilot port Boom priority pilot port Boom stroke limit port Breaker summation pilot port Pilot pressure port Drain port (boom holding valve) Drain port (arm holding valve)	PF 1/4	3.5~3.9 kgf ⋅ m (25.3~28.2 lbf ⋅ ft)
P3 Pn1 Pn2 A1	Quick clamp port Negative control signal port (P1 port side) Negative control signal port (P2 port side) Travel motor left side port (BW)	PF 3/8	7~8 kgf ⋅ m (50.6~57.8 lbf ⋅ ft)
B1 C1 D1 B2 C2 D2 B4 A5 C5 C6 D5 C6 P1 P2	Travel motor left side port (FW) Travel motor right side port (FW) Travel motor right side port (BW) Boom rod side port Swing motor port (RH) Swing motor port (LH) Option A port (breaker) Bucket head side port Bucket rod side port Option B port Option B port Option C pilot port (dozer down port) Option C pilot port (dozer up port) Pump port (P1 side) Pump port (P2 side)	PF 3/4	15~18 kgf ⋅ m (109~130 lbf ⋅ ft)
A2 C4 D4	Boom head side port Arm head side port Arm rod side port	PF 1	20~25 kgf ⋅ m (115~180 lbf ⋅ ft)
Dr4 Dr5	Drain port (swing logic valve) Drain port (flow summation)	PF 1/8	1.5~1.9 kgf ⋅ m (10.8~13.7 lbf ⋅ ft)
T1	Return port	SAE3000, 1 1/2 (M12×1.75)	8.5~11.5 kgf ⋅ m (61.5~83.1 lbf ⋅ ft)



ousing-P1	43	Load check-poppet
ousing-P2	44	Load check-poppet
ool-straight travel	45	Signal-poppet
ool-travel (LH, RH)	46	Travel straight-sleeve
ool-swing	47	Travel straight-piston
ool-boom 1	48	Orifice signal
ool-swing priority	49	Coin type filter
ool-boom 2	50	Pilot cap
ool-arm 2	51	Pilot cap
ool-arm 1	52	Pilot cap
ool-arm regeneration	53	Socket bolt
ool-option B	54	Socket bolt
ool-bucket	55	Socket bolt
ool-option C (dozer)	56	Washer
ain relief valve	57	Spring washer
verload relief valve	58	O-ring
verload relief valve	59	O-ring
erload relief valve	60	O-ring
egacon relief valve	61	O-ring
ving logic valve	62	O-ring
icket logic valve	63	O-ring
otion on-off valve	64	O-ring
olding valve kit A1	65	O-ring
olding valve kit A2	66	O-ring
olding valve kit B	67	O-ring
egeneration block	68	O-ring
g	69	O-ring
g	70	O-ring
g	71	O-ring
g	72	O-ring
g	73	O-ring
g	74	Backup-ring
ug-parallel	75	Backup-ring
ug-relief cat	76	Backup-ring
ug-relief cat	77	Backup-ring
ug-relief cat	78	Backup-ring
ug-bucket	79	Load check spring
ug-bucket parallel	80	Load check spring
ug-option	81	Poppet signal spring
ug-orifice	82	Pin

2. HYDRAULIC CIRCUIT




3. FUNCTION

1) CONTROL IN NEUTRAL

(1) P1 SIDE

The hydraulic fluid from pump A2 flows into the main control valve through the inlet port "P1", pass the straight travel spool into the P1 bypass passage and P1parallel passage.


The hydraulic fluid from the pump A2 is directed to the tank through the bypass passage of spools : travel left, boom 1, arm 2, arm regeneration & option A and bucket, the negative relief valve of P1, tank passage, and the tank port "T1"




(2) P2 SIDE

The hydraulic fluid from pump A1 flows into the main control valve through the inlet port "P2", into the P2 bypass passage and P2 parallel passage.

The hydraulic fluid from the pump A1 is directed to the tank through the bypass passage of spools : travel right, swing, boom 2 & swing priority, arm 1, option "B" and option "C" (dozer), the negative relief valve of P2, tank passage and the tank port "T1".








14092MC12


2) TRAVEL OPERATION

(1) TRAVEL FORWARD OPERATION



14092MC18

(2) TRAVEL BACKWARD OPERATION




During the travel forward operation, the hydraulic fluid of the pump A2 is supplied to the travel left motor and the hydraulic fluid of the pump A1 is supplied to the other travel right motor.

The pilot pressure from the pilot control valve is supplied to the spring side of pilot port (pb1, pc1).

And it shifts travel right and left spools in the left direction against springs. Hydraulic fluid from the pump A1 flow into the travel right spool through the bypass passage and hydraulic fluid from the pump A2 flow into the travel left spool through the bypass passage.

Then they are directed to the each travel motor through port A1 and C1. As a result, the travel motors turn and hydraulic fluid returns to the tank passage through the travel spools. In case of the reverse operation, the operation is similar.

(3) TRAVEL STRAIGHT FUNCTION



14092MC19

This function keeps straight travel in case of simultaneous operation of other actuators (boom, arm, bucket, swing) during a straight travel.

1 During travel only :

The hydraulic fluid of the pump A1 is supplied to the travel right motor and the pump A2 is supplied to the travel left motor.

Thus, the machine keep travel straight.

O The other actuator operation during straight travel operation :

When the other actuator spool (s) is selected under straight travel operation, the straight travel spool is moved.

The hydraulic fluid from pump A2 is supplied actuator through P2 and P1 parallel pass and travel motors through orifice at side of straight travel spool.

The hydraulic oil fluid from pump A1 is supplied to travel motors (left/right).

Therefore, the other actuator operation with straight travel operation, hydraulic oil fluid from pump A2 is mainly supplied to actuator, and the hydraulic oil fluid form pump A1 is mainly supplied to travel motors (left/right).

Then the machine keeps straight travel.


3) BOOM OPERATION

(1) BOOM UP OPERATION

During boom up operation, the pilot secondary pressure from RCV is supplied to the port Pa20 of the spring side and shifts the boom 1 spool in the left direction. The bypass passage is shut off by the movement of the boom 1 spool and the hydraulic oil fluid from pump A2 is entered P1 parallel passage and then passes through the load check, bridge passage and boom holding valve then flows into the port A2. Following this it flows into the head side of the boom cylinder. (In this case, the boom holding valve is free flow condition)

At the same time, the pilot pressure from RCV is supplied to the port Pa21 of the spring side of boom 2 and shifts the boom 2 spool. The bypass passage is shut off by the movement of the boom 2 spool and the hydraulic oil fluid from pump A1 entered boom summation passage via the P2 parallel passage, the land of the swing priority spool, notch of the boom 2 spool, arm 2 spool and the check. The flows combine in passage and are directed to port A2 and head side of boom cylinder.

At the same time, the flow from rod side of the boom cylinder return to the boom 1 spool through the port B2. Thereafter it is directed to the hydraulic oil tank through the tank passage.



(2) BOOM DOWN OPERATION

During the boom lowing operation, the pilot pressure from RCV is supplied to the port Pb20 of the spring opposite side and shifts the boom 1 spool in the right direction.


The bypass passage is shut off by the movement of the boom 1 spool and the hydraulic fluid from the pump A2 enters the parallel passage and is directed to the port B2 through the load check. Following this, it flows into the rod side of the boom cylinder.

At the same time, the return flow from the head side of the boom cylinder returns to the port A2 and boom holding valve. And it is directed to the hydraulic oil tank through opened tank passage by movement of the boom 1 spool.

Meanwhile some of return flow is directed to P1 parallel passage through the internal passage of the boom 1 spool. (boom regeneration)

In this case, the holding valve is open condition, for details of the boom holding valve, see page following page.

During the boom lowering operation, the fluid from A1 pump is not summation.




4) HOLDING VALVE OPERATION

(1) HOLDING OPERATION

At neutral condition, the pilot piston chamber is connected to drain port through the pilot port. And the piston "B" is supported with spring "B".

Also, the pressured fluid from actuator entered to inside of the holding valve through the periphery hole of check, crevice of the check and the plug and the periphery hole of plug. Then, this pressured oil pushed the poppet to the poppet seat and the check to the seat of body. So the hydraulic fluid from actuator is not escaped and the actuator is not moved.




(2) RELEASE HOLDING OPERATION

The pilot pressure is supplied to the pilot port for release holding valve and shifts the piston "B" in the left direction against the spring "B", and shifts the poppet in the left direction through piston "B" and piston "A" against spring "B" and shifts the spool in the left side.

At same time, the return fluid from actuator returns to the drain port through the periphery hole of check, crevice of the check and the plug, the periphery hole of the plug, in side of holding valve, crevice of the poppet and the poppet seat, the periphery hole of the poppet seat, crevice of socket and spool and internal passage of spool.

When the poppet is opened, pressure of inside of holding valve is decreased and the return fluid from actuator returns to the tank passage through the notch of spool.



5) BUCKET OPERATION

(1) BUCKET IN OPERATION ONLY


During the bucket in operation, the pilot secondary pressure from RCV is supplied to port Pa5 of the spring side and shifts the bucket spool in the left direction.

The bypass passage is shut off by the movement of the bucket spool and the hydraulic fluid from pump A2 entered P1 parallel passage and is directed to the port A5 through the check 1.

At the same time, the hydraulic fluid from P1 bypass passage is directed to the port A5 through the check 2.

Following this it flows into the head side of the bucket cylinder.

The return flow from the rod side of the bucket cylinder returns to the bucket spool through the port B5. Thereafter it is directed to the hydraulic oil tank through the tank passage.




(2) BUCKET OUT OPERATION

During the bucket out operation, the pilot secondary pressure from RCV is supplied to port Pb5 of the spring opposite side and shifts the bucket spool in the right direction.

The bypass passage is shut off by the movement of the bucket spool and the hydraulic fluid from pump A2 entered P1 parallel passage and is directed to the port B5 through the check 1. At the same time, the hydraulic fluid from P1 bypass passage is directed to the port B5 through the check 2.

The return flow from the head side of the bucket cylinder returns to the hydraulic oil tank through the port A5 and the tank passage.




(3) BUCKET IN SLOW OPERATION

This function is used to speed up of the boom by reducing the bucket speed when bucket in operation with boom up operation simultaneously.

When the boom up operation, the boom up pilot pressure is supplied the pilot port of bucket spool stroke limit and the piston is shifted to the right and then the bucket spool stroke is limited and the open of the bucket spool is reduced.

Accordingly, the oil of the bucket spool is reduced and the boom speed up.



6) SWING OPERATION


(1) SWING LEFT & RIGHT OPERATION

During the swing left operation, the pilot secondary pressure from the RCV is supplied to the port Pd2 of the spring side and shift the swing spool in left direction. The bypass passage is shut off by the movement of the swing spool and the hydraulic fluid from pump A1 flows into swing spool through the P2 parallel passage. Then it is directed to swing motor through the port D2.

As the result, swing motor turns and flow from the swing motor returns to the hydraulic oil tank through the port C2, swing spool and the tank passage.

In case of swing right operation, the operation is similar to swing left operation but the pilot secondary pressure from the RCV is supplied to the port Pc2 of the spring opposite side.


Accordingly, the hydraulic fluid from pump A1 flows into swing motor through the port C2 and returns to the hydraulic oil tank through the port D2 and the tank passage.



(2) SWING LEFT OPERATION WITH ARM OR BOOM OPERATION

When combined operation, mostly same as previous page but the fluid from P2 bypass passage is empty.

So only the fluid from parallel passage is supplied to the swing motor. Also, parallel passage is installed the orifice of swing logic valve for supplying the fluid from pump A1 to the boom or the arm operation prior to the swing operation. In case of the swing right operation with arm or boom operation, operation is similar.




7) ARM OPERATION

(1) ARM IN OPERATION

During arm in operation, the pilot secondary pressure from the RCV is supplied to the port Pc40 of spring opposite side and shifts arm 1 spool in the right direction.

The bypass passage is shut off by the movement of the arm 1 spool and the hydraulic oil from the pump A1 flows into the arm cylinder head side through P2 parallel passage, the load check valve, bridge passage and the port C4.

At same time, the pilot secondary pressure from the RCV is supplied to the port Pb3 of spring opposite side and shifts arm 2 spool in the right direction. The bypass passage is shut off by the movement of the arm 2 spool and the hydraulic fluid from the pump A2 flows into the arm summation passage through P1 parallel passage, the check valve, the arm 2 spool and the boom 2 spool. Then it entered the arm cylinder head side with hydraulic fluid from arm 1 spool.




ARM REGENERATION

The return flow from the arm cylinder rod side is pressurized by self weight of arm and so, returns to port D4. The pressurized oil returning to port D4 enters the arm regeneration & breaker spool through the arm holding valve and the arm 1 spool. It is supplied the arm cylinder head through internal passage. This is called the arm regeneration function.

The amount of regeneration fluid is changed by movement of the arm regeneration spool. A few fluids after P2 parallel passage is push piston "C" through the notch of arm regeneration spool and selector spool. At this time, the selector spool is opened by pilot pressure from RCV.

Then, the arm regeneration spool shifts to right side and flow to tank pass increases and regeneration flow decreases. Therefore, pressure of arm cylinder head increases, then, arm regeneration flow decreases.

Furthermore, the arm regeneration cut pressure is supplied to the port Pb4 of spring opposite side and arm regeneration spool is move into the right direction fully. The flow from the arm cylinder rod is returned to the hydraulic oil tank and regeneration function is not activated. (The return fluid is maximum condition)



125LCR2MC22

(2) ARM OUT OPERATION

During arm out operation, the pilot secondary pressure from RCV is supplied to the port Pd40 of spring side and shifts arm 1 spool in the left direction.


The bypass passage is shut off by the movement of the arm 1 spool and the hydraulic fluid from pump A1 flows into arm 1 spool through the P2 parallel passage. Then it enters into the arm cylinder rod side through the load check, bridge passage, arm holding valve and the port D4.

Also, the pilot secondary pressure from RCV is supplied to the port Pd41 of spring side and shifts arm 2 spool in the left direction.

The bypass passage is shut off by the movement of the arm 2 spool and some of the hydraulic fluid from pump A2 bypassed through bypass notch. The rest of hydraulic fluid from pump A2 flows into the arm summation passage through P1 parallel passage, the check valve, arm 2 spool and boom 2 spool.

Then it enters into the arm cylinder rod side with the fluid from the arm 1 spool.

The return flow from the arm cylinder head side returns to the hydraulic tank through the port C4, the arm 1 spool and tank passage.




8) SWING PRIORITY FUNCTION

During swing priority operation, the pilot secondary pressure is supplied to the port Pc3 of the spring side of the swing priority spool and shift swing priority spool in the right direction.


The hydraulic fluid from P2 parallel passage flows into the parallel passage of arm 1 side through swing priority spool and the path "A" and also flows into the boom 2 spool.

When the swing priority spool is neutral condition, the passage is same as normal condition. But due to shifting of the swing priority spool, the fluid from pump A1 flows to swing side more then the boom 2, arm 1, option B and dozer spools to make the swing operation most preferential.




9) DOZER OPERATION

(1) Dozer down operation



14W92MC30

(2) Dozer up operation



14W92MC31

During the dozer down operation, the pilot pressure from the dozer control valve is supplied into the port Pc6 of the spring side and it shifts the dozer spool in the left direction.

The hydraulic fluid from the pump A1 enters the parallel passage and is direction to the head side of the dozer cylinder through port D6.

The return flow from the rod side of the dozer cylinder returns to the dozer spool through C6 port. Thereafter it is directed to the hydraulic tank through tank passage.

In case of the dozer up operation, operation is similar.


10) NEGATIVE RELIEF VALVE OPERATION

When no function is being actuated on P1 side, the hydraulic fluid from the pump A2, flows into the tank passage through the P1 bypass passage and orifice. The restriction caused by this orifice thereby pressurizes. This pressure is transferred as the negative control signal pressure Pn1 to the pump A2 regulator.

It controls the pump regulator so as to minimize the discharge of the pump A2.

The bypass passage is shut off when the shifting of one or more spools and the flow through bypass passage became zero. The pressure of negative control signal becomes zero and the discharge of the pump A2 becomes maximum.


The negative control pressure reaches to the set level, the hydraulic fluid in the passage pushes open negative control valve and escapes into the return passage.



For the pump A1 the same negative control principle.


11) OPERATION OF MAIN RELIEF VALVE

(1) The pressurized oil passes through the orifice (A) of the plunger is filled up in chamber A of the inside space, and seats the plunger against the housing securely.




14W92MC36

(2) When the pressure at (P) becomes equal to the set pressure of the spring the hydraulic oil passes through the piston (A) pushes open the poppet and flows to tank passage (T) through the plunger internal passage, periphery orifice A, chamber A, periphery orifice B and the hole (E).




14W92MC37

(3) Opening the poppet causes the pressure in chamber A to fall and the plunger to open. As the result the pressurized oil at port P runs into tank passage (T).




(4) The pressure at port P becomes lower than set pressure of the spring, the poppet is seated by spring force. Then the pressure at port P becomes equal to set pressure of the spring and the plunger is seated to the socket.



14W92MC39

(5) When the power boost switch is ON, the pilot pressure enters through hole A.


It pushes the piston (B) in the left direction to increase the force of the spring and change the relief set pressure to the high pressure.



12) OPERATION OF OVERLOAD RELIEF VALVE


FUNCTION AS RELIEF VALVE

(1) The pressurized oil passes through the piston A and orifice A is filled up in chamber A of the inside space and seat the plunger against the socket and the socket against the housing securely.




14W92MC41

(2) When the pressure at port P becomes equal to the set pressure of the spring, the pressurized oil pushes open the poppet and flows to tank passage (T) through the plunger internal passage, orifice A, chamber A, periphery orifice B and hole E.




(3) Opening of the poppet causes the pressure in chamber A to fall and the plunger to open. As the result the pressurized oil at port P runs into tank passage (T).




14W92MC43

(4) The pressure at port P becomes lower than set pressure of the spring, the poppet is seated by spring force. Then the pressure at port P becomes equal to set pressure of the spring and the plunger is seated to the socket.



MAKE-UP FUNCTION


(5) When negative pressure exists at port P, the oil is supplied through tank passage (T). When the pressure at tank passage (T) becomes higher than that of at port P, the socket moves in the right direction. Then, sufficient oil passes around the socket from tank passage (T) to port P and fills up the space.




GROUP 3 SWING DEVICE

1. STRUCTURE

Swing device consists swing motor, swing reduction gear. Swing motor include mechanical parking valve, relief valve, make up valve and time delay valve.






Port	Port name	Port size
VA	Main port	ø 13
VB	Main port	ø 13
DR	Drain port	PF 3/8
MU	Make up port PF 3/4	
PG	Brake release stand by port PF 1/4	
SH	Brake release pilot port PF 1/4	
MA, MB	Gauge port PF 1/4	
AU	Air vent port	PF 1/8

125LCR2SM21


1) SWING MOTOR



- 1 Casing
- 2 Oil seal
- Shaft 3
- 4 Snap ring
- 5 Roller bearing
- 6 Roller bearing
- 7 Swash plate
- 8 Cylinder block
- 9 Spring
- 10 Ball guide
- 11 Retainer plate
- 12 Piston assy
- 13 Friction plate
- 14 Separate plate
- 15 Parking piston
- 16 Spring

- 17 Spring pin
- 18 O-ring
- O-ring 19
- 20 Valve plate
- 21 Spring pin
- 22 Valve casing
- 23 Check valve
- 24 Spring
- 25 Plug
- 26 O-ring
- Plug 27
- 28 O-ring
- Plug 29
- 30 O-ring
- 31
- Relief valve assy
- 32 Anti-rotating valve assy

- 33 Plug
- 34 O-ring
- 35 O-ring
- 36 Time delay valve spool
- 37 Spring seat
- 38 Spring
- Restrictor 39
- 40 O-ring
- Level gauge assy 41
- 42 Socket bolt
- 43 Plug
- Expander 44
- Expander 45
- 46 Name plate
- 47 Rivet



125LCR2SM23

- 1 Ring gear
- 2 Drive shaft
- 3 Bearing
- 4 Bearing
- 5 Ring nut
- 6 Lock plate
- 7 Hexagon bolt
- 8 Casing
- 9 Socket bolt
- 10 Carrier No. 2

- 11 Planetary gear No. 2
- 12 Needle bearing No. 2
- 13 Thrust washer No. 2
- 14 Carrier pin No. 2
- 15 Spring pin
- 16 Sun gear No. 2
- 17 Carrier No. 1
- 18 Planetary gear No. 1
- 19 Needle bearing No. 1
- 20 Thrust washer No. 1

- 21 Carrier pin No. 1
- 22 Sun gear No. 1
- 23 Snap ring
- 24 Thrust plate
- 25 Sleeve
- 26 O-ring
- 27 Oil seal
- 30 Plug
- 31 Parallel pin
- 32 Thrust washer No. 1

2. PRINCIPLE OF DRIVING

2.1 Generating the turning force

The high hydraulic supplied from a hydraulic pump flows into a cylinder block (8) through valve casing of motor (22), and valve plate (20).

The high hydraulic is built as flowing on one side of Y-Y line connected by the upper and lower sides of piston (12).


The high hydraulic can generate the force, $F1=P \times A$ (P : supplied pressure, A : water pressure area), like following pictures, working on a piston.

This force, F1, is divided as N1 thrust partial pressure and W1 radial partial pressure, in case of the plate of a tilt angle, α .

W1 generates torque, T=W1+R1, for Y-Y line connected by the upper and lower sides of the piston as following pictures.

The sum of torque (Σ W1×R1), generated from each piston (4~5 pieces) on the side of a high hydraulic, generates the turning force.

This torque transfers the turning force to a cylinder (8) through a piston; because a cylinder is combined with a turning axis and spline, a turning axis rotates and a turning force is sent.



21078TM05


2) MAKE UP VALVE

In the system using this type of motor, there is no counter balance functioning valve and there happens the case of revolution exceeding hydraulic supply of motor. To prevent the cavitation caused by insufficient oil flow there is a make up valve to fill up the oil insufficiency.

A make up valve is provided immediately before the port leading to the hydraulic oil tank to secure feed pressure required when the hydraulic motor makes a pumping action. The boost pressure acts on the hydraulic motor's feed port via the make up valve.


Pressurized oil into the port B, the motor rotate counterclockwise.

If the plunger of MCV moves neutral position, the oil in the motor is drain via left relief valve, the drain oil run into motor via right make up valve, which prevent the cavitation of motor.



21092SM04

3) RELIEF VALVE




- 1 Sleeve
- 2 Poppet
- 3 Poppet seat
- 4 Spring
- 5 Spring seat
- 6 Shim
- 7 Piston
- 8 Stopper
- 9 Plug
- 10 O-ring
- 11 O-ring

(1) Construction of relief valve


The valve casing contains two cartridge type relief valves that stop the regular and reverse rotations of the hydraulic motor. The relief valves relieve high pressure at start or at stop of swing motion and can control the relief pressure in two steps, high and low, in order to insure smooth operation.

(2) Function of relief valve

Figure illustrates how the pressure acting on the relief valve is related to its rising process. Here is given the function, referring to the figure following page.




① Ports (P,R) at tank pressure.



2209A2SM26


② When hydraulic oil pressure (P×A1) reaches the preset force (FSP) of spring (4), the poppet (2) moves to the right as shown.

 $P1 \times A1=Fsp+Pg \times A2$




2209A2SM27

③ The oil flows into chamber (g) via orifice (m) and (n). When the pressure of chamber (g) reaches the preset force (FSP) of spring (4), the piston (7) moves left and stop the piston (7) hits the bottom of stopper (8).



2209A2SM28

(4) When piston (7) hits the bottom of stopper (8), it stops moving to the left any further. As the result, the pressure in chamber (g) equals (Ps). $Ps \times A1=Fsp+Ps \times A2$




2209A2SM29

4) BRAKE SYSTEM

(1) Control valve swing brake system

This is the brake system to stop the swing motion of the excavator during operation. In this system, the hydraulic circuit is throttled by the swing control valve, and the resistance created by this throttling works as a brake force to slow down the swing motion.




(2) Mechanical swing parking brake system

This is function as a parking brake only when all of the RCV lever (except travel pedal) are not operated.

① Brake assembly

Circumferential rotation of separate plate (14) is constrained by the groove located at casing (1). When housing is pressed down by brake spring (16) through friction plate (13), separate plate (14) and parking piston (15), friction force occurs between friction plate and separate plate.

Friction force constrains motion of cylinder block (8). When hydraulic force exceeds spring force, brake is released.



13 Friction plate

1


8

- Parking piston
- 16 Brake spring

② Operating principle


a. When one of the RCV lever (1) is set to the operation position, the each spool is shifted to left or right and the pilot oil flow is blocked. Then the pilot oil go to SH of the time delay valve. This pressure moves spool (5) to the leftward against the force of the spring(8), so pilot pump charged oil (P3) goes to the chamber G through port PG.

This pressure is applied to move the parking piston (15) to the upward against the force of the brake spring (16). Thus, it releases the brake force.



125LCR2SM36

b. When all of the RCV lever (1) are set the neutral position, the spool (5) returns to right.
Then, the parking piston (15) is moved lower by spring force and the return oil from the chamber G flows back to tank port.
At this time, the brake works.





125LCR2SM37


GROUP 4 TRAVEL DEVICE

1. CONSTRUCTION

Travel device consists travel motor and gear box. Travel motor includes brake valve, parking brake and high/low speed changeover mechanism.










VIEW A

Port	Port name Port size	
VA, VB	Valve port PF 3/4	
Ps	Pilot port PF 1/4	
DR	Drain port PF 1/2	
MA, MB	Gauge port PF 1/4	



2. STRUCTURE





- Casing 1
- Plug 2
- Oil seal 3
- 4 Piston
- 5 Piston seal
- 6 Shaft
- Front ball bearing 7
- Rear ball bearing 8
- Steel ball 9
- Steel ball 10
- 11 Swash plate
- 12 Cylinder block
- 13 Spring
- 14 Ball guide
- 15 Retainer plate
- 16 Piston assy
- 17 Friction plate

34 Restrictor

- Hexagon socket head bolt
- 51 Spring


- Plug 52
- 53 O-ring
- 54 Plug
- 55 Restrictor
- 56 Restrictor
- 57 Name plate
- 58 Rivet
- 59 Ring gear
- 60 Bearing
- 61 Floating seal assy
- 62 Nut ring
- 63 Lock plate
- 64 Hexagon head bolt
- 65 Thrust plate No. 2
- 66 Planetary gear No.2
- 67 Needle bearing No.2
- 68 Inner race No. 2

- 69 Thrust washer No. 2
- 70 Sun gear No.2
- 71 Carrier No.1
- 72 Planetary gear No.1
- 73 Needle bearing No.1
- 74 Inner race No. 1
- 75 Thrust plate No. 1
- 76 Hexagon head bolt
- 77 Countersunk head screw
- 78 Sun gear No.1
- 79 Steel ball
- 80 Cover
- 81 Hex socket head bolt
- 82 Plug
- 83 O-ring
- 84 Name plate
- 85 Rivet

3. OPERATION

1) MOTOR

High pressure oil delivered form hydraulic pump is led to inlet port that is provided in the brake valve portion and, through the rear cover (30) and valve plate (24), led to cylinder block (12). The oil flow and direction of shaft rotation are indicated in table.



Inlet port	Outlet port	Direction of shaft rotation (viewing from rear cover)
VB	VA	Right (clockwise)
VA	VB	Left (counterclock wise)

125LCR2TM23

As shown in below figure, high pressure oil is supplied to the pistons which are on one side of the line Y-Y that connects upper and lower dead points and produces force F1.


 $F1 = P \times A$ (P : pressure, A : area of piston section)

The swash plate (11) with inclined angle of $^{\alpha}$ divides this force F1 into thrust force F2 and radial force F31~34.

This radial force is applied to axis Y-Y as turning force and generate drive torque of T.

 $T = r_1 \cdot F31 + r_2 \cdot F32 + r_3 \cdot F33 + r_4 \cdot F34$

This drive torque is transmitted via cylinder block (12) to driving shaft (6).




29092TM07

2) PARKING BRAKE

Parking brake is released when high pressure oil selected by the brake valve portion that is connected directly to the rear cover (30), is applied to the parking piston (19). Otherwise the braking torque is always applied.

This braking torque is generated by the friction between the separated plates (18), inserted into the casing (1), and friction plates (17), coupled to cylinder block (12) by the outer splines.

When no pressure is activated on the parking piston (19), it is pushed by the brake springs (26) and it pushes friction plates (17) and separated plates (18) towards casing (1) and generates the friction force which brakes the rotation of cylinder block (12) and hence the shaft (6).



3) CAPACITY CONTROL MECHANISM

Figure typically shows the capacity control mechanism.

When high speed pilot line is charged with the pressure P_A that overcome the spring (44), the spring (44) is compressed and spool (40) shifts to the right to connect the port P and port C.

Then, the highest pressure is selected by the check valve (50) from inlet and outlet pressure of the motor and high speed pilot line pressure and pushes shifter piston (4). As a result, swash plate (11) turns around the line L which connect the two steel balls (10) as shown by dotted lines. The turn stops at the stopper (1-1) of casing and swash plate (11) keeps the position.


In this case, the piston stroke become shorter and motor capacity become smaller and motor rotates faster, around 1.60 times, by the same volume of oil.

When no pressure is in the high speed pilot line P_A , spool (40) is pushed back by the spring (44) and pressure that pressed the shifter piston (4) is released to the hydraulic tank through restrictor (55).

Here, nine pistons are there and they equally spaced on the swash plate (11). The force that summed up those of pistons comes to almost the center of the swash plate (11) as shown. Since the steel balls (10) are off-set by S from the center, the rotating force of product S and the force moves swash plate (11) to the former position and the speed returns to low.

When the power demand exceeds the engine power, such as in steep slope climbing or turning at high speed mode, the system step down to the low speed automatically. The mechanism is that: pump pressure is led to the port P_B and this pressure activate on pin (43). When the pressure at P_B exceeds predetermined value, spool (40) returns to the left by the counter-pressure against pin (43) and the pressure on the shifter piston (4) through port C is released to the tank and the motor comes to low speed.

When P_{B} goes down, the spool (40) moves to the right and the speed become high.




4) OVERLOAD RELIEF VALVE

(1) Structure

38-5 Piston

This value is screwed in the motor rear cover (30) and consists of : plug (38-1) that is screwed and fixed in the rear cover (30), poppet (38-8) and supports the poppet seat (38-9), spring (38-2) that is operating relief value setting pressure and supports the spring seat (38-3), that is inserted in the sleeve (38-4), piston (38-5) that reduce the shock.



38-10 Back-up ring


(2) Operation

Two pieces of overload valves are located at cross-over position in the counterbalance circuit of brake valve and have the following functions :

- ① When hydraulic motor starts, keep the driving pressure below predetermined value and while accelerating, bypasses surplus oil to return line.
- ② When stopping the motor, keep the brake pressure, that develops on the outlet side of motor, under the predetermined value to stop the inertial force.
- ③ To accelerate sharply while starting, and to mitigate the braking shock while stopping. For these purposes, the developed pressure is kept comparatively low for a short period, then keep the line pressure as normal value. While the pressure is low, meshing of reduction gears, crawler and sprocket etc. can be smoothly done and the shock are absorbed.

When starting, "A" port pressure of overload valve increases, this pressure is applied to the effective diameter of poppet (38-8) which seats on the poppet seat (38-9) and, at the same time, is delivered, via small hole, to the spring seat (38-3) located inside the sleeve (38-4) and the seat bore pressure increases up to "A" port pressure. The poppet (38-8) opposes to spring (38-2) by the force of the pressure exerted on the area difference between poppet seat's effective diameter and spring seat bore and keep the predetermined pressure.

When hydraulically braking, the piston (38-5) is at the left position by the driving pressure, and when "A" port pressure increases, the pressure is applied also to the piston (38-5) through the small hole in the poppet (38-8), sleeve (38-4) and piston (38-5) moves rightward until it touches the stopper in rear cover. In this while, the poppet (38-8) maintains "A" port pressure at comparatively low against the spring (38-2) force and exhaust oil to "B" port side. After the piston reached to the plug, the valve acts the same as at starting.



5) BRAKE VALVE

(1) Structure

The brake valve portion mainly consists of the following parts:


1 Spool

By shifting the spool (31), the discharged oil from hydraulic motor is automatically shut off or restricted according to the condition and give the effect of holding, accelerating, stopping and counterbalance operations.

(See page 2-66, (2) Operation)

② Check valve (built in the spool)

This valve is located in the oil supplying passage to hydraulic motor, and at the same time functions to lock oil displacement. Therefore, this valve serves as not only a suction valve but also a holding valve for hydraulic motor.



(2) Operation

① Holding operation


When the control value is at neutral position, VA and VB ports are connected to the tank, and the spring (33) located on both spool ends holds the spool (31) at central position.


Therefore, the passages from VA to MA and VB to MB are closed, which result in closing MA and MB ports connected to hydraulic motor.

Since the passage to parking brake is connected to the tank line, the brake cylinder pressure is equal to the tank pressure and the brake is applied by the springs. Thus, the rotation of the motor is mechanically prevented.

If external torque is exerted on the motor shaft, the motor would not rotate as usual by this negative parking brake.

In case the brake should be released for some reason, pressure is built on MA or MB port. But, due to oil leakage inside hydraulic motor or so, high-pressure oil escapes from the closed circuit and motor rotates a bit. So, the cavitation tends to occur in the lower pressure side of the closed circuit. Then, the check valve, built in the spool (31), operates to avoid the cavitation and opens the passage from VA to MA or from VB to MB. Then the oil equivalent to the leakage is sucked from the tank line to the closed circuit.






② Accelerating operation

When VA and VB ports are connected respectively to pump and tank by operating the control valve, hydraulic oil from pump is forwarded through VA port to push open the check valve provided inside spool (31), and oil flows to motor via MA port to rotate the motor.

Therefore, the pressure increases and negative brake is released by the pressure supplied from pump. At the same time, the pressure of pilot chamber increases to push and move the spool (31) leftwards, overcoming the spring (33) force. Thus, the return line from MB to VB opens to rotate the motor.

In case inertia load is too big to start rotation, accelerating pressure reaches the set pressure of relief valve and high pressure oil is being relieved while the motor gains the rotational speed. As the rotational speed goes up, the relieved volume decreases, and finally the motor rotates at a fixed speed.





③ Stopping operation

Returning the control valve to neutral position while running the motor, the oil supply is cut off and VA and VB ports are connected to the tank line. Then the pressure of the pilot chamber located on both spool ends become equal, and the spool (31) returns to the neutral position by spring (33) force. Thus, the passage from MA to VA is closed.

Owing to the inertia force of the load, the hydraulic motor tends to continue the rotation. Here, the motor functions as a pump and forwards the oil to MB port but the passage is blocked and MB port pressure increases. Then the relief valve opens to relieve the pressure and rotational speed decelerates and at last the motor stops.

Negative brake release pressure is gradually lowered due to the restrictor and finally the brake works and the motor is mechanically stopped.





④ Counterbalance operation

Counterbalance operation is required to decelerate slowly the hydraulic motor while absorbing inertia force.

In case the hydraulic oil is gradually decreased from pump to VB port, the drive shaft of hydraulic motor tends to rotate faster than that matched to the volume of oil supply.


Consequently, the pilot chamber pressure on MB to VB side decreases and the spring (33) force moves the spool (31) leftwards towards neutral position.


Therefore, the area of passage from MA to VA becomes smaller and the pressure on MA side rises due to increased resistance in the passage and the motor receives hydraulic braking effect.

If the motor rotates slower than that matched to the volume of supplied oil, the pilot chamber pressure on VB port increases, and spool (31) moves rightwards to enlarge the area of passage from MA to VA. Therefore the braking effect becomes smaller and the rotational speed of motor is controlled to correspond to the volume of supplied oil.

In order to give stable counterbalance operation, the restrictors (34) are set in the pilot chamber to damp the spool (31) movement.

The parking brake is released during pressure adjusting action of the spool (31).





6) REDUCTION GEAR

Reduction unit slows down the rotating speed of motor and converts motor torque to strong rotating force.


This reduction unit utilizes two stages, planetary reduction system.

Planetary reduction system consists of sun gear, planetary gears, (planetary) carriers, and ring gear.

When the sun gear (s) is driven through input shaft, planetary pinions (b), rotating on their center, also move, meshing with fixed ring gear (a), around sun gear (s).


This movement is transferred to carrier (k) and deliver the torque.

This mechanism is called planetary gear mechanism.



When the sun gear S1 is driven by input shaft, planetary action occurs among gears S1, a and b and revolution of gear b transfers the rotation of carrier K1 to second sun gear S2, and also evokes planetary action between gear S2, a and d.

This time, because carrier **K2** is fixed to frame, gear **d** drives ring gear **a** and then ring gear **a** rotates to drive sprocket.




29072TM12

GROUP 5 RCV LEVER

1. STRUCTURE

The casing has the oil inlet port P (primary pressure) and the oil outlet port T (tank). In addition the secondary pressure is taken out through ports 1, 2, 3 and 4 provided at the bottom face.



1409S2RL01


CROSS SECTION

The construction of the pilot valve is shown in the attached cross section drawing. The casing has vertical holes in which reducing valves are assembled.

The pressure reducing section is composed of the spool (3), spring (5) for setting secondary pressure, return spring (9), stopper (7), spring seat (6, 12) and shim (4). The spring for setting the secondary pressure has been generally so preset that the secondary pressure is 5 to 20.5 kgf/cm² (depending on the type). The spool is pushed against the push rod (8, 10) by the return spring.

When the push rod is pushed down by tilting the handle, the spring seat comes down simultaneously and changes setting of the secondary pressure spring.

CROSS SECTION



Stopper

2-73

1409S2RL02

2. FUNCTIONS

1) FUNDAMENTAL FUNCTIONS

The pilot valve is a valve that controls the spool stroke, direction, etc of a main control valve. This function is carried out by providing the spring at one end of the main control valve spool and applying the output pressure (secondary pressure) of the pilot valve to the other end.

For this function to be carried out satisfactorily, the pilot valve is composed of the following elements.

- (1) Inlet port (P) where oil is supplied from hydraulic pump.
- (2) Output ports (1, 2, 3 & 4) to apply pressure supplied from inlet port to ends of control valve spools.
- (3) Tank port (T) necessary to control the above output pressure.
- (4) Spool to connect output port to inlet port or tank port.
- (5) Mechanical means to control output pressure, including springs that work on the above spools.

2) FUNCTIONS OF MAJOR SECTIONS

The functions of the spool (3) are to receive the supply oil pressure from the hydraulic pump at its port P, and to change over oil paths to determine whether the pressure oil of port P is led to output ports 1, 2, 3 & 4 or the output port pressure oil to tank port T.

The spring (5) works on this spool to determine the output pressure.

The change the deflection of this spring, the push rod (8,10) is inserted and can slide in the plug (13).

For the purpose of changing the displacement of the push rod through the swash plate (19) and adjusting nut (20) are provided the handle (22) that can be tilted in any direction around the fulcrum of the universal joint (18) center.


The spring (9) works on the case (1) and spring seat (6, 12) and tries to return the push rod (8,10) to the zero-displacement position irrespective of the output pressure, securing its resetting to the center position.

This also has the effect of a reaction spring to give appropriate control feeling to the operator.

3) OPERATION

The operation of the pilot valve will be described on the basis of the hydraulic circuit diagram shown below and the attached operation explanation drawing.

The diagram shown below is the typical application example of the pilot valve.




2 Pilot pump

1

- Main pump 4 Main control valve
- 5 Hydraulic motor

2-70


6 Hydraulic cylinder (1) Case where handle is in neutral position



1409S2RL03

The force of the spring (5) that determines the output pressure of the pilot valve is not applied to the spool (3). Therefore, the spool is pushed up by the spring (9) to the position of port (1, 3) in the operation explanation drawing. Then, since the output port is connected to tank port T only, the output port pressure becomes equal to tank pressure.

(2) Case where handle is tilted



1409S2RL04

When the push rod (10) is stroked, the spool (3) moves downwards.

Then port P is connected with port (1) and the oil supplied from the pilot pump flows through port (1) to generate the pressure.

When the pressure at port (1) increases to the value corresponding to the spring force set by tilting the handle, the hydraulic pressure force balances with the spring force. If the pressure at port (1) increases higher than the set pressure, port P is disconnected from port (1) and port T is connected with port (1). If it decreases lower than the set pressure, port P is connected with port (1) and port T is disconnected from port 1.


In this manner the secondary pressure is kept at the constant value.


Besides, in some type, when the handle is tilted more than a certain angle, the upper end of the spool contacts with the inside bottom of the push rod and the output pressure is left to be connected with port P.


GROUP 6 RCV PEDAL


1. STRUCTURE

The casing (spacer) has the oil inlet port P (primary pressure), and the oil outlet port T (tank). In addition the secondary pressure is taken out through ports 1,2,3 and 4 provided at the bottom face.









Port	Port	Port size
Р	Pilot oil inlet port	
Т	Pilot oil return port	- PF 1/4
1	Travel (LH, Forward)	
2	Travel (LH, Backward)	
3	Travel (RH, Forward)	
4	Travel (RH, Backward)	


21092RP01

CROSS SECTION

The construction of the RCV pedal is shown in the below drawing. The casing has vertical holes in which reducing valves are assembled.

The pressure reducing section is composed of the spool (8), spring (6) for setting secondary pressure, return spring (10), stopper (9), and spring seat (7). The spring for setting the secondary pressure has been generally so preset that the secondary pressure is 5 to 19 kgf/cm² (depending on the type). The spool is pushed against the push rod (14) by the return spring.

When the push rod is pushed down by tilting pedal, the spring seat comes down simultaneously and changes setting of the secondary pressure spring.



- 8 Spool
- 9 Stopper
- 10 Spring
- 11 Rod guide
- 12 O-ring
- 13 Snap ring

- 21 Plug
- 22 O-ring
- 23 Rod seal
- 24 Dust seal
- 25 Cover
- 26 Socket bolt

- 34 Space
- 35 O-ring
- 36 O-ring
- 37 Socket bolt
- 38 Piston

2. FUNCTION

1) FUNDAMENTAL FUNCTIONS

The pilot valve is a valve controls the spool stroke, direction, etc of a main control valve. This function is carried out by providing the spring at one end of the main control valve spool and applying the output pressure (secondary pressure) of the pilot valve to the other end.

For this function to be carried out satisfactorily, the pilot valve is composed of the following elements.

- (1) Inlet port (P) where oil is supplied from hydraulic pump.
- (2) Output port (1, 2, 3 & 4) to apply pressure supplied from inlet port to ends of control valve spools.
- (3) Tank port (T) necessary to control the above output pressure.
- (4) Spool to connect output port to inlet port tank port.
- (5) Mechanical means to control output pressure, including springs that work on the above spools.

2) FUNCTIONS OF MAJOR SECTIONS

The functions of the spool (8) are to receive the supply oil pressure from the hydraulic pump at its port P, and to change over oil paths to determine whether the pressure oil of port P is led to output ports 1, 2, 3 & 4 or the output spool to determine the output pressure.

The spring (6) works on this spool to determine the output pressure.

The change the deflection of this spring, the push rod (14) is inserted and can slide in the plug (21). For the purpose of changing th displacement of the push rod through the cam (27) and adjusting nut (32) are provided the pedal that can be tilted in any direction around the fulcrum of the cam (27) center.


The spring (10) works on the casing (1) and spring seat (7) and tries to return the push rod (14) to the zero-displacement position irrespective of the output pressure, securing its resetting to the center position.

This also has the effect of a reaction spring to give appropriate control feeling to the operator.

3) OPERATION


The operation of the pilot valve will be described on the basis of the hydraulic circuit diagram shown below ant the attached operation explanation drawing.

The diagram shown below is the typical application example of the pilot valve.



- 1 Pilot valve
- 2 Pilot pump
- 3 Main pump
- 4 Main control valve
- 5 Hydraulic motor
- 6 Hydraulic cylinder


(1) Case where pedal is in neutral position



21092RP03

The force of the spring (6) that determines the output pressure of the pilot valve is not applied to the spool (8). Therefore, the spool is pushed up by the spring (10) to the position of port 2 in the operation explanation drawing. Then, since the output port is connected to tank port T only, the output port pressure becomes equal to tank pressure.

(2) Case where pedal is tilted



21092RP04

When the push rod (14) is stroked, the spool (8) moves downwards.

Then port P is connected with port 1, and the oil supplied from the pilot pump flows through port 1 to generate the pressure.

When the pressure at port 1 increases to the value corresponding to the spring force set by tilting the handle, the hydraulic pressure force balances with the spring force. If the pressure at port 1 increases higher than the set pressure, port P is disconnected from port 1 and port T is connected with port 1. If it decreases lower than the set pressure, port P is connected with port 1 and port 1 and port 1.


In this manner the secondary pressure is kept at the constant value.

Besides, in some type, when the handle is tilted more than a certain angle, the upper end of the spool contacts with inside bottom of the push rod and the output pressure is left to be connected with port P.

SECTION 3 HYDRAULIC SYSTEM

Group	1 Hydraulic Circuit ·····	3-1
Group	2 Main Circuit	3-2
Group	3 Pilot Circuit	3-5
Group	4 Single Operation	3-13
Group	5 Combined Operation	3-25

GROUP 1 HYDRAULIC CIRCUIT



SECTION 3 HYDRAULIC SYSTEM


51 Adjust boom safety valve(Option)	$\begin{array}{c}1\\2\\3\\4\\5\\6\\7\\8\\9\\10\\11\\23\\14\\15\\16\\17\\8\\9\\21\\22\\32\\4\\25\\6\\7\\8\\31\\33\\4\\55\\6\\7\\0\\11\\2\\3\\4\\5\\6\\7\\0\\1\\12\\3\\3\\4\\5\\6\\7\\0\\1\\1\\2\\3\\5\\5\\1\\5\\1\\5\\1\\5\\1\\5\\1\\5\\1\\5\\1\\5\\1\\5\\1$	Main pump Main control valve Swing motor Travel motor RCV lever(LH) RCV pedal Boom cylinder(LH) Boom cylinder(RH) Arm cylinder Bucket cylinder Turning joint Check valve Check valve Check valve Hydraulic tank Oil cooler Air breather Bypass valve Strainer Drain filter 5 cartridge valve Pressure sensor Pressure sensor Pressure sensor Pressure sensor Shuttle block Last guard filter Shuttle valve(Option) RCV dozer lever(Option) Boom safety valve(Option) Breaker pedal(Option) Accumulator(Option) Stop valve(Option) Stop valve(Option) Selector valve(Option) Selector valve(Option) Selector valve(Option) Selector valve(Option) Selector valve(Option) Selector valve(Option) Selector valve(Option) Selector valve(Option) Selector valve(Option) Stop valve(Option) Selector valve(Option) Selector valve(Option) Accumulator(Option) Selector valve(Option) Selector valve(Option) Selector valve(Option) Selector valve(Option) Accumulator(Option) Selector valve(Option) Selector valve(Option) Adjust boom cylinder(Option) Adjust boom safety valve(Option)
	47 48 49 50	Quick clamp solenoid valve(Option) Pattern change valve(Option) Pressure switch(Option) Adjust boom cylinder(Option)
	55 56	Solenoid valve(Opt, dozer & adjust) Selector valve(Opt, dozer & adjust)

GROUP 2 MAIN CIRCUIT

The main hydraulic circuit consists of suction circuit, delivery circuit, return circuit and drain circuit. The hydraulic system consists of one main pump, one control valve, one swing motor, four cylinders and two travel motors.

The swash plate type variable displacement axial piston pump is used as the main pump and is driven by the engine at ratio 1.0 of engine speed.

1. SUCTION AND DELIVERY CIRCUIT



(210-7) 3-03


The pumps receive oil from the hydraulic tank through a suction filter. The discharged oil from the pump flows into the control valve and goes out the tank ports.

The oil discharged from the main pump flows to the actuators through the main control valve.

The main control valve controls the hydraulic functions.

The return oil from the actuators flows to the hydraulic tank through the main control valve and the oil cooler.

2. RETURN CIRCUIT



21073Cl01

All oil returned from each actuator returns to the hydraulic tank through the main control valve.

The bypass check valves are provided in the return circuit.

The setting pressure of bypass check valves are 1.5 kgf/cm² (21 psi) and 3.0 kgf/cm² (43 psi). Usually, oil returns to the hydraulic tank from the left side of control valve through oil cooler.


When oil temperature is low, viscosity becomes higher and flow resistance increases when passing through the oil cooler. When the oil pressure exceeds 3.0 kgf/cm² (43 psi), the oil returns directly to the hydraulic tank, resulting in the oil temperature being raised quickly at an appropriate level.

When the oil cooler is clogged, the oil returns directly to the hydraulic tank through bypass check valve (1). The full-flow filter and bypass relief valve are provided in the hydraulic tank.

The oil returned from right and left side of control valve is combined and filtered by the full-flow filter. A bypass relief valve is provided in the full-flow filter.

When the filter element is clogged, the bypass relief valve opens at 1.5 kgf/cm² (21 psi) differential pressure.

3. DRAIN CIRCUIT



21093Cl02

Besides internal leaks from the motors and main pump, the oil for lubrication circulates. These oil have to be fed to the hydraulic tank passing through drain filter.

When the drain oil pressure exceed 1.5 kgf/cm² (21 psi), the oil returns to the hydraulic tank directly.

1) TRAVEL MOTOR DRAIN CIRCUIT

Oil leaked from the right and left travel motors comes out of the drain ports provided in the respective motor casing and join with each other. These oils pass through the turning joint and return to the hydraulic tank after being filtered by drain filter.


2) SWING MOTOR DRAIN CIRCUIT

Oil leaked from the swing motor returns to the hydraulic tank passing through a drain filter.

3) MAIN PUMP DRAIN CIRCUIT

Oil leaked from main pump returns to the hydraulic tank passing through drain filter.

GROUP 3 PILOT CIRCUIT




The pilot circuit consists of suction circuit, delivery circuit and return circuit.

The pilot pump is provided with relief valve, receives the oil from the hydraulic tank through the suction filter.

The discharged oil from the pilot pump flows to the remote control valve through line filter, EPPR valve, solenoid valve assemblies, swing parking brake, main control valve and safety lock solenoid valve.

1. SUCTION, DELIVERY AND RETURN CIRCUIT




125LCR3HC02

The pilot pump receive oil from the hydraulic tank. The discharged oil from the pilot pump flows to the safety solenoid valve through the line filter. The oil is filtered by the line filter. The pilot relief valve is provided in the pilot pump for limiting the pilot circuit pressure.

The oil filtered by line filter flows remote control valve through safety solenoid valve.

The return oil flow from remote control valve is returned to the hydraulic tank.

2. SAFETY SOLENOID VALVE (SAFETY LEVER)




125LCR3HC03

When the lever of the safety solenoid valve is moved upward, oil flows into the remote control valve through solenoid valve and line filter.

When the lever of the safety solenoid valve is moved downward, oil does not flows into the remote control valve, because of the blocked port.

3. BOOM PRIORITY SYSTEM



125LCR3HC04

When carrying out the combined operation of swing and boom up, the boom up operating speed is lowered than normal operation.


To increase working efficiency, swing speed reducing system is used.

The pilot oil from pilot pump flow into **P03** port in main control valve through boom priority EPPR valve. **P03** oil pressure moves swing reducing spool to lower position and oil flow rate to the swing motor decreased.

Then, the boom up speed is increased. This is called the boom priority system.

The boom up speed can be adjusted by the cluster. Refer to page 3-12 of the operator's manual.


4. TRAVEL SPEED CONTROL SYSTEM



125LCR3HC05

When the travel speed switch is pushed, the travel speed solenoid valve is actuated and the discharged oil from the pilot pump flows to the **Ps** port of pilot valve in the travel motors. As a result, the control piston is pushed by the main oil flow, thus the displacement is minimized. When the travel speed switch is pushed once more, the travel speed solenoid valve is return to original position by the force of spring, the hydraulic oil of **Ps** port returns to the hydraulic tank. As a result, the control piston is returned by the main oil flow, thus the displacement is maximized.

5. MAIN RELIEF PRESSURE CHANGE SYSTEM




125LCR3HC06

When the power switch on the left control lever is pushed ON, the power solenoid valve is actuated, the discharged oil from the pilot pump flows into Pu port of the main relief valve of main control valve ; then the setting pressure of the main relief valve is raised from 330 kgf/cm² to 360 kgf/cm² for increasing the digging power.

And even when pressed continuously, it is canceled after 8 seconds.

When the auto power function is selected to enable on the cluster, the pressure of the main relief pressure is automatically increased to 360 kgf/cm² as working condition by the MCU. It is operated max 8 seconds.

6. ARM REGENERATION CUT SYSTEM



125LCR3HC07


When the arm regeneration is selected to disable on the cluster, the arm regeneration solenoid valve is activated. The pilot oil from pilot pump flows into **Pb4** port in main control valve through solenoid valve and the arm regeneration spool is shifted to left.

Then, the oil from arm regeneration passage returns to tank and the arm regeneration function is deactivated.

When the arm regeneration is selected to enable on the cluster, the arm regeneration function is activated and arm in operation speed is increased.

Refer to page 2-37 for the arm regeneration function.

7. SWING PARKING BRAKE RELEASE



125LCR3HC08

When one of the RCV lever (except travel lever) is tilted, the pilot oil flows into SH port through main control valve.


This pressure moves spool so, discharged oil from pilot pump flows into swing motor PG port.

This pressure is applied to swing motor disc, thus the brake is released.

When all of the RCV lever are set in the neutral position, oil in the swing motor disc cylinder is drained, thus the brake is applied.

GROUP 4 SINGLE OPERATION


1. BOOM UP OPERATION



When the right control lever is pulled back, the boom spools in the main control valve are moved to the up position by the pilot oil pressure from the remote control valve.

The oil from the A1 and A2 pump flows into the main control valve and then goes to the large chamber of boom cylinders. At the same time, the oil from the small chamber of boom cylinders returns to the hydraulic oil tank through the boom spool in the main control valve. When this happens, the boom goes up. The excessive pressure in the boom cylinder head side is prevented by relief valve. When the boom is up and the control lever is returned to neutral position, the circuit for the holding pressure at the head side of the boom cylinder is closed by the boom holding valve. This prevents the hydraulic drift of boom cylinder.

2. BOOM DOWN OPERATION



125LCR3HC11


When the right control lever is pushed forward, the boom 1 spool in the main control valve is moved to the down position by the pilot oil pressure from the remote control valve.

The oil from the A2 pump flows into the main control valve and then goes to the small chamber of boom cylinders. At the same time, the oil from the large chamber of boom cylinders returns to the hydraulic tank through the boom 1 spool in the main control valve.

When the down speed of boom is faster, the oil returned from the large chamber of boom cylinder combines with the oil from the A2 pump, and flows into the small chamber of the cylinder.

This prevents cylinder cavitation by the negative pressure when the A2 pump flow can not match the boom down speed. And the excessive pressure in the boom cylinder rod side is prevented by the relief valve.

3. ARM IN OPERATION



125LCR3HC12

When the left control lever is pulled back, the arm spools in the main control valve are moved to the arm in position by the pilot oil pressure from the remote control valve.


The oil from the A1 and A2 pump flows into the main control valve and then goes to the large chamber of arm cylinder.

At the same time, the oil from small chamber of arm cylinder returns to the hydraulic oil tank through the arm spool in the main control valve. When this happens, the arm rolls in.

The excessive pressure in the arm cylinder head side is prevented by relief valve.

The cavitation which will happen to the head side of the arm cylinder is also prevented by the makeup valve in the main control valve.

4. ARM OUT OPERATION




125LCR3HC13

When the left control lever is pushed forward, the arm spools in the main control valve are moved to the arm out position by the pilot oil pressure from the remote control valve.

The oil from the A1 and A2 pump flows into the main control valve and then goes to the small chamber of arm cylinder. At the same time, the oil from the large chamber of arm cylinder returns to the hydraulic oil tank through the arm spool in the main control valve. When this happens, the arm rolls out. The cavitation which will happen to the rod side of the arm cylinder is also prevented by the make-up valve in the main control valve. When the arm is roll out and the control lever is returned to neutral position, the circuit for the holding pressure at the rod side of the arm cylinder is closed by the arm holding valve. This prevent the hydraulic drift of arm cylinder.

5. BUCKET IN OPERATION



125LCR3HC14

When the right control lever is pulled left, the bucket spool in the main control valve is moved to the roll in position by the pilot oil pressure from the remote control valve.


The oil from the A2 pump flows into the main control valve and then goes to the large chamber of bucket cylinder.

At the same time, the oil from the small chamber of bucket cylinder returns to the hydraulic oil tank through the bucket spool in the main control valve. When this happens, the bucket rolls in.

The excessive pressure in the bucket cylinder head side is prevented by relief valve.

The cavitation which will happen to the head side of the bucket cylinder is also prevented by the make-up valve in the main control valve.

6. BUCKET OUT OPERATION



125LCR3HC15


When the right control lever is pushed right, the bucket spool in the main control valve is moved to the bucket out position by the pilot oil pressure from the remote control valve.

The oil from the A2 pump flows into the main control valve and then goes to the small chamber of bucket cylinder.

At the same time, the oil from the large chamber of bucket cylinder returns to the hydraulic oil tank through the bucket spool in the main control valve. When this happens, the bucket rolls out.

The cavitation which will happen to the rod side of the bucket cylinder is also prevented by the make-up valve in the main control valve.

7. DOZER UP OPERATION




125LCR3HC16

When the dozer control lever is pulled back, the dozer spool in the main control valve is moved to the dozer up position by the pilot oil pressure from the remote control valve.

The oil from the A1 pump flows into the main control valve and then goes to the small chamber of dozer cylinder.

At the same time, the oil from the large chamber of dozer cylinders returns to the hydraulic oil tank through the dozer spool in the main control valve. When this happens, the dozer goes up.

8. DOZER DOWN OPERATION




When the dozer control lever is pushed forward, the dozer spool in the main control valve is moved to the dozer down position by the pilot oil pressure from the remote control valve.

The oil from the A1 pump flows into the main control valve and then goes to the large chamber of dozer cylinder.

At the same time, the oil from the small chamber of dozer cylinders returns to the hydraulic oil tank through the dozer spool in the main control valve. When this happens, the dozer goes down.

9. SWING OPERATION



When the left control lever is pushed left or right, the swing spool in the main control valve is moved to the left or right swing position by the pilot oil pressure from the remote control valve.

Also the swing operation preference function is operated by the pilot pressure Pc3 (refer to page 2-34).


The oil from the A1 pump flows into the main control valve and then goes to the swing motor.

At the same time, the return oil from the swing motor returns to the hydraulic oil tank through the swing spool in the main control valve.

When this happens, the upper structure swings to the left or right.

The swing parking brake, make up valve and the motor brake valve are provided in the swing motor. The cavitation which will happen to the swing motor is also prevented by the make up valve in the swing motor itself.

SWING CIRCUIT OPERATION



125LCR2HC18A

1) MOTOR BRAKE VALVE

Motor brake valve for the swing motor limits to cushion the starting and stopping pressure of swing operation and controls the swing motor operating pressure.

2) MAKE UP VALVE

The make up valves prevent cavitation by supplying return oil to the vacuum side of the motor.

3) PARKING BRAKE

This is function as a parking brake only when all of the RCV lever (except dozer lever and travel pedal) are not operated.

PARKING BRAKE "OFF" OPERATION

The parking brake is released by the pilot pressure oil from the pilot pump.

When the RCV lever placed in the operating position, the pilot oil flows into SH port through the MCV. This pressure transferred to the brake release valve and the brake release valve is change over. Then the pilot oil pressure PG lift the brake piston and release the parking brake.


PARKING BRAKE "ON" OPERATION

When all of the RCV lever placed in the neutral position, the pressure of the pilot oil passage down. Then the brake release valve returned to the neutral position and the oil is returned from the brake piston to the tank. And the brake is set to 'ON".

4) ANTI-INVERSION VALVE

This anti-inversion valve absorbs shocks produced as swing motion stops and reduced oscillation cause by swing motion.

10. TRAVEL FORWARD AND REVERSE OPERATION




When the travel levers are pushed forward or reverse position, the travel spools in the main control valve are moved to the forward or reverse travel position by the pilot oil pressure from the remote control valve.

The oil from the each pump flows into the main control valve and then goes to the each travel motor through the turning joint.

The return oil from both travel motors returns to the hydraulic oil tank through the turning joint and the travel spools in the main control valve.

When this happens, the machine moves to the forward or reverse.

TRAVEL CIRCUIT OPERATION



125LCR3HC19A

Valves are provided on travel motors to offer the following functions.

1) COUNTER BALANCE VALVE


When stopping the motor of slope descending, this valve to prevent the motor over run.

2) OVERLOAD RELIEF VALVE

Relief valve limit the circuit pressure below 350 kgf/cm² to prevent high pressure generated at a time of stopping the machine. Stopping the motor, this valve sucks the oil from lower pressure passage for preventing the negative pressure and the cavitation of the motor.

GROUP 5 COMBINED OPERATION

1. OUTLINE



125LCR3HC23

The oil from the A1 and A2 pump flows through the neutral oil passage, bypass oil passage and confluence oil passage in the main control valve. Then the oil goes to each actuator and operates them. Check valves and orifices are located on these oil passage in the main control valve. These control the oil from the main pumps so as to correspond to the operation of each actuator and smooth the combined operation.


STRAIGHT TRAVEL SPOOL

This straight travel spool for straight travel is provided in the main control valve.

If any actuator is operated when traveling, the straight travel spool is pushed to the right by the pilot oil pressure.

Consequently, the left and right travel oil supply passage are connected, and equivalent amount of oil flows into the left and right travel motors. This keeps the straight travel.

2. COMBINED SWING AND BOOM UP OPERATION



When the swing and boom up functions are operated, simultaneously the swing spool and boom spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.


The oil from the A1 pump flows into the swing motor through swing spool and the boom cylinder through boom 2 spool.

The oil from the A2 pump flows into the boom cylinders through the boom 1 spool in the right control valve.

The super structure swings and the boom is operated.

Refer to page 3-8 for the boom priority system.

3. COMBINED SWING AND ARM OPERATION




When the swing and arm functions are operated, simultaneously the swing spool and arm spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the A1 pump flows into the swing motor through swing spool and the arm cylinder through arm 1 spool.

The oil from the A2 pump flows into the arm cylinder through the arm 2 spool of the right control valve.

The super structure swings and the arm is operated.

4. COMBINED SWING AND BUCKET OPERATION




When the swing and bucket functions are operated, simultaneously the swing spool and bucket spool in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the A1 pump flows into the swing motor through the swing spool in the left control valve. The oil from the A2 pump flows into the bucket cylinder through the bucket spool in the right control valve.

The super structure swings and the bucket is operated.

5. COMBINED SWING AND TRAVEL OPERATION



125LCR3HC27


When the swing and travel functions are operated, simultaneously the swing spool and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve and straight travel spool is pushed to the right by the pilot oil pressure from the pilot pump.

The oil from the A1 pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool.

The oil from the A2 pump flows into the swing motor through the swing spool and travel motor through the LH travel spool via the check valve and orifice in the straight travel spool.

The upper structure swings and the machine travels straight.

6. COMBINED BOOM AND TRAVEL OPERATION




When the boom and travel functions are operated, simultaneously the boom spools and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve and the straight travel spool is pushed to the right by the oil pressure from pilot pump.

The oil from the A1 pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool.

The oil from the A2 pump flows into the boom cylinders through the boom 2 spool and boom 1 spool via the parallel and confluence oil passage in case boom up operation. Also, the oil from the A2 pump flows into the travel motors through the LH travel spool via the check valve and orifice in the straight travel spool.

The boom is operated and the machine travels straight.


7. COMBINED ARM AND TRAVEL OPERATION



When the arm and travel functions are operated, simultaneously the arm spools and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve and the straight travel spool is pushed to the right by the oil pressure from pilot pump. The oil from the A1 pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool.

The oil from the A2 pump flows into the arm cylinders through the arm 1 spool and arm 2 spool via the parallel and confluence oil passage. Also, the oil from the A2 pump flows into the travel motors through the LH travel spool via the check valve and orifice in the straight travel spool. The arm is operated and the machine travels straight.

8. COMBINED BUCKET AND TRAVEL OPERATION



When the bucket and travel functions are operated, simultaneously the bucket spool and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve, and the straight travel spool is pushed to the right by the oil pressure from pilot pump. The oil from the A1 pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool of the control valve.


The oil from the A2 pump flows into the bucket cylinder through the bucket spool via the confluence oil passage. Also, the oil from the A2 pump flows into the travel motors through the LH travel spool via the check valve and orifice in the straight travel spool.

The bucket is operated and the machine travels straight.

Group	1	Component Location	4-1
Group	2	Electrical Circuit	4-3
Group	3	Electrical Component Specification	4-21
Group	4	Connectors	4-29

GROUP 1 COMPONENT LOCATION

1. LOCATION 1




- 1 Cigar lighter
- 2 Remote controller
- 3 Air conditioner switch
- 4 Horn switch
- 5 Breaker operation switch
- 6 Accel dial switch
- 7 Handsfree
- 8 Cluster
- 9 Start switch
- 10 Hour meter
- 11 One touch decel switch

- 12 Power max switch
- 13 Safety lever
- 14 Emergency engine stop switch
- 15 Emergency engine connector
- 16 Machine control unit
- 17 DC-DC converter
- 18 Remote control unit
- 19 Handsfree control unit
- 20 Master switch
- 21 RS232 & J1939 service socket
- 22 Radio & USB player

- 23 Heated seat switch
- 24 Fuse box
- 25 Speaker
- 27 Overload switch
- 28 Beacon switch
- 29 Quick clamp switch
- 30 Cab light switch
- 31 Travel alarm switch
- 32 Washer switch
- 33 Wiper switch
- 34 Main light switch

2. LOCATION 2




- 7 Horn
- 8 P1 pressure sensor
- 9 P2 pressure sensor
- 10 P3 pressure sensor
- 17 Air cleaner switch
- 18 Arm/Bucket in pressure sensor


Dozer pressure switch

28


- 19 Boom up pressure sensor
- 20 Swing pressure sensor


GROUP 2 ELECTRICAL CIRCUIT(1/2)






4-4










MEMORANDUM

HYUNDAI HEAVY INDUSTRIES CO., LTD CONSTRUCTION EQUIPMENT DIV.

1. POWER CIRCUIT

The negative terminal of battery is grounded to the machine chassis through master switch. When the start switch is in the OFF position, the current flows from the positive battery terminal as shown below.

1) OPERATING FLOW




* I/conn : Intermediate connector

2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (battery 1EA)	10~12.5V
055	OFF	② - GND (battery 2EA)	20~25V
OFF		③ - GND (battery 2EA)	20~25V
		④ - GND (fusible link)	20~25V

POWER CIRCUIT



2. STARTING CIRCUIT

1) OPERATING FLOW

Battery(+) terminal — Battery relay [CR-1] — Circuit breaker [CN-60] — Master switch [CS-74]

- --- I/conn [CN-231 (2)] --- Fuse box [No.1] --- I/conn [CN-36-1 (7)] --- Master switch [CS-74B]
- → I/conn [CN-5(36)] → Start switch [CS-2(1)]

(1) When start key switch is in ON position

- Start switch ON [CS-2 (2)] - I/conn [CN-5 (60)] - Battery relay [CR-1]

--- Battery relay operating (all power is supplied with the electric component)

└─► Start switch ON [CS-2 (3)] ─► GPS connector [CN-125 (2) →(4)] ─► I/conn [CN-5 (59)]

- → I/conn [CN-36-1 (1)] → Power relay [CR-35 (86) → (87)] → Fuse box [No.10]
- ECM power relay [CR-45 (86) → (87)] → I/conn [CN-4 (4)] → Emergency engine stop switch
- [CS-33 (2)→(1)] → I/conn [CN-4 (13)] → I/conn [CN-36-1 (2)] → Fuse box [No.12]


(2) When start key switch is in START position

```
Start switch START [CS-2 (6)] → I/conn [CN-5 (35)] → I/conn [CN-36-3 (9)] → Anti-restart relay [CR-5 (86) → (87)] → I/conn [CN-36-3 (1)] → I/conn [CN-2 (12)] → Start relay [CR-23]
```

2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (battery)	
		② - GND (start key)	
	START	③ - GND (battery relay M4)	
OPERATING		④ - GND (starter B ⁺)	20~25V
		⑤ - GND (starter M)	
		⑥ - GND (start relay)	
		⑦ - GND (battery relay M8)	

STARTING CIRCUIT



3. CHARGING CIRCUIT

When the starter is activated and the engine is started, the operator releases the key switch to the ON position.

Charging current generated by operating alternator flows into the battery through the battery relay [CR-1].

The current also flows from alternator to each electrical component and controller through the fuse box.

1) OPERATING FLOW

(1) Warning flow

Alternator "I" terminal [CN-74 (2)] → I/conn [CN-2 (14)] → MCU alternator voltage level [CN-51 (39)] Cluster charging warning lamp (Via serial interface)


(2) Charging flow

Alternator "B⁺" terminal — Battery relay(M8) — Battery(+) terminal — Circuit breaker [CN-60] — Master switch [CS-74] — I/conn [CN-231 (2)] — Fuse box

2) CHECK POINT

Engine	Engine Start switch Check point		Voltage
		① - GND (battery voltage)	
		② - GND (battery relay)	
Run	ON	③ - GND (alternator B ⁺ terminal)	20~30V
		④ - GND (alternator I terminal)	
		⑤ - GND (MCU)	

CHARGING CIRCUIT



4. HEAD AND WORK LIGHT CIRCUIT

1) OPERATING FLOW

Fuse box (No.16) --- I/conn [CN-36-2 (4)] --- Head light relay [CR-13 (30,86)] Fuse box (No.17) --- I/conn [CN-36-2 (5)] --- Work light relay [CR-4 (30,86)]

(1) Head light switch ON

Head light switch ON [CN-116 (1)] → I/conn [CN-5 (49)] → Head light relay [CR-13 (85) → (87)]

- → Head light ON [CL-3 (2)] , [CL-4 (1)] , [CL-24 (2)]
- --- I/conn [CN-11 (8)] --- AC & Heater controller illumination ON [4]
- → I/conn [CN-5 (13)] → Remote controller illumination ON [CN-245 (9)]
 - Cigar light [CL-2]
 - USB & Socket illumination ON [CN-246 (7)] Radio & USB player illumination ON [CN-27 (9)]
- I/conn [CN-7 (13)] Accel dial LED [CN-267 (2)]


(2) Work light switch ON

Work light switch ON [CN-116 (2)] → I/conn [CN-5 (50)] → Work light relay [CR-4 (85) → (87)] → I/conn [CN-12 (2)] → Work light ON [CL-5 (2), CL-6 (2)]

2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (fuse box)	
		② - GND (switch power output)	
	ON	③ - GND (head light relay)	
CTOD		④ - GND (head light)	
STOP		⑤ - GND (fuse box)	20~25V
		6 - GND (switch power output)	
		⑦ - GND (work light relay)	
		⑧ - GND (work light)	

HEAD AND WORK LIGHT CIRCUIT



5. BEACON LAMP AND CAB LIGHT CIRCUIT

1) OPERATING FLOW

Fuse box (No.19) → I/conn [CN-36-1 (5)] → I/conn [CN-5 (33)] → Beacon lamp switch [CN-23 (8)] Fuse box (No.18) → I/conn [CN-36-2 (6)] → Cab light relay [CR-9 (30, 86)]

(1) Beacon lamp switch ON

Beacon lamp switch ON [CS-23 (4)] - Switch indicator lamp ON [CS-23 (11)] - I/conn [CN-10 (10)] - Beacon lamp ON [CL-7]


(2) Cab light switch ON

Cab light switch ON [CN-116 (7)] \longrightarrow I/conn [CN-5 (55)] \longrightarrow Cabin lamp relay [CR-9 (85) \rightarrow (87)] \longrightarrow I/conn [CN-5 (34, 38)] \longrightarrow I/conn [CN-10 (2)] \longrightarrow Front cab light ON [CL-8 (2)] \longrightarrow I/conn [CN-10 (12)] \longrightarrow Front cab light ON [CL-9 (2)] \longrightarrow I/conn [CN-10 (11)] \longrightarrow Rear cab light ON [CL-10 (2)]

2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (fuse box)	
STOP	ON	② - GND (switch power input)	20~25V
310F		③ - GND (switch power output)	20~231
		④ - GND (beacon lamp)	
		⑤ - GND (fuse box)	
STOP	ON	⑥ - GND (cabin light relay)	20~25V
SIUP	ON	⑦ - GND (switch power output)	20~231
		⑧ - GND (cab light)	

BEACON LAMP AND CAB LIGHT CIRCUIT



6. WIPER AND WASHER CIRCUIT

1) OPERATING FLOW

(1) Key switch ON

Fuse box (No.10) → I/conn [CN-36-1 (16)] → I/conn [CN-5 (57)] → Switch panel [CN-116 (10)] Fuse box (No.5) → I/conn [CN-36-1 (11)] → I/conn [CN-5 (18)] → I/conn [CN-17 (5)] Wiper motor controller [CN-141(7)]

Wiper motor [CN-21(4)]

Fuse box (No.15) → I/conn [CN-36-1 (4)] → I/conn [CN-5 (24)] → I/conn [CN-17 (4)] →

Wiper motor controller [CN-141 (6)]

--- Washer pump [CN-22 (2)]

(2) Wiper switch ON : 1st step (Intermittent)

Wiper switch ON [CN-116 (3)] \rightarrow I/conn [CN-17 (8)] \rightarrow Wiper motor controller [CN-141 (10) \rightarrow (3)] \rightarrow Wiper motor intermittently operating [CN-21 (6)]

(3) Wiper switch ON : 2nd step (continual)

Wiper switch ON [CN-116(4)] \rightarrow I/conn[CN-17(2)] \rightarrow Wiper motor controller [CN-141(2) \rightarrow (4)] \rightarrow Wiper motor operating [CN-21(2)]

(4) Washer switch ON

Washer switch ON [CN-116 (5)] \longrightarrow I/conn [CN-17 (7)] \longrightarrow Wiper motor controller [CN-141 (9) \rightarrow (8)] \longrightarrow I/conn [CN-17 (6)] \longrightarrow I/conn [CN-5 (19)] \longrightarrow Washer pump [CN-22 (1)] \longrightarrow Washer operating Wiper switch ON [CN-116 (4)] \longrightarrow I/conn[CN-17 (2)] \longrightarrow Wiper motor controller [CN-141 (2) \rightarrow (4)] \longrightarrow Wiper motor operating [CN-21 (2)]


(5) Auto parking (when switch OFF)

Switch OFF [CN-116 (4)] -- Wiper motor parking position by wiper motor controller


2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (fuse box)	24V
	ON	② - GND (switch power input)	Z4V
STOD		③ - GND (switch power output)	0 ~ 5V
STOP		④ - GND (wiper power input)	0~50
		⑤ - GND (wiper power output)	24V
		6 - GND (wiper motor)	0 or 24V


WIPER AND WASHER CIRCUIT




CONTROLLER CIRCUIT



MONITORING CIRCUIT



ELECTRIC CIRCUIT FOR HYDRAULIC



GROUP 3 ELECTRICAL COMPONENT SPECIFICATION

Part name	Symbol	Specifications	Check
Battery		12V × 100Ah (2EA)	 Check specific gravity 1.280 over : Over charged 1.280 ~ 1.250 : Normal 1.250 below : Recharging
Battery relay	CR-1	Rated load : 24V 100A (continuity) 1000A (30seconds)	 ※ Check coil resistance(M4 to M4) Normal : About 50 Ω ※ Check contact Normal : ∞ Ω
Glow plug relay	CR-24	24V 200A	 Check contact Normal : 0.942 Ω (For terminal 1-GND)
Start key		B-BR : 24V 1A B-ACC : 24V 10A B-ST : 24V 40A	 Check contact OFF : ∞ Ω (for each terminal) ON : 0 Ω (for terminal 1-3 and 1-2) START : 0 Ω (for terminal 1-5)
Pressure sensor	O A SUPPLY O B SIG O C RETURN CD-6 CD-7 CD-16 CD-24 CD-31 CD-32 CD-35 CD-42 CD-43 CD-44 CD-69 CD-70	8~30V	* Check contact Normal : 0.1 Ω
Resistor	$ \begin{array}{c c} O & A \\ O & B \\ O & C \\ \hline $	4W	* Check resistance A-B : 120 Ω

Part name	Symbol	Specifications	Check
Glow plug	CN-80	24V 200A	 * Check resistance 0.25~0.12 Ω
Temperature sensor (hydraulic)	CD-1	-	 * Check resistance 50°C : 804 Ω 80°C : 310 Ω 100°C : 180 Ω
Air cleaner pressure switch	Pa 	(N.O TYPE)	 ※ Check contact High level : ∞ Ω Low level : 0 Ω
Fuel sender	CD-2 CD-2 CD-2	-	** Check resistance Full: 50 Ω 6/12 : 350 Ω 11/12: 100 Ω 5/12 : 400 Ω 10/12: 150 Ω 4/12 : 450 Ω 9/12: 200 Ω 3/12 : 500 Ω 8/12: 250 Ω 2/12 : 550 Ω 7/12: 300 Ω 1/12 : 600 Ω Empty warning : 700 Ω
Relay (air con blower)	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	24V 20A	 * Check resistance Normal : About 200 Ω (for terminal 1-3) 0 Ω (for terminal 2-4)
Relay	CR-2 CR-4 CR-5 CR-7 CR-9 CR-13 CR-35 CR-36 CR-45 CR-46 CR-62	24V 16A	 Check resistance Normal : About 160 Ω (for terminal 85-86) 0 Ω (for terminal 30-87a) ∞ Ω (for terminal 30-87)

Part name	Symbol	Specifications	Check
Solenoid valve	CN-66 CN-68 CN-70 CN-88 CN-135 CN-140 CN-149 CN-236 CN-237 CN-262 CN-263	24V 1A	* Check resistance Normal : 15~25 Ω (for terminal 1-2)
EPPR valve	10 20 CN-75 CN-133 CN-242	700mA	* Check resistance Normal : 15~25 Ω (for terminal 1-2)
Speaker	0 1 0 2 CN-23(LH) CN-24(RH)	20W	* Check resistance Normal : A few Ω
Switch (locking type)	CS-23 CS-50 CS-52 CS-67 CS-82 CS-83 CS-99 CS-100 CS-103 CS-104 CS-105	24V 8A	* Check contact Normal ON : 0 Ω (for terminal 3-7, 4-8) $\infty \Omega$ (for terminal 7-9, 8-10) OFF : $\infty \Omega$ (for terminal 3-7, 4-8) 0 Ω (for terminal 7-9, 8-10)
Accel dial	○ A	-	 Check resist Normal : About 5k Ω (for terminal A-C) Check voltage Normal : About 5V (for terminal A-C) : 2~4.5V (for terminal C-B)
Room lamp	30 20 10	24V 10W	* Check disconnection Normal : 1.0Ω ON : 0Ω (For terminal 1-2) $\infty \Omega$ (For terminal 1-3) OFF : $\infty \Omega$ (For terminal 1-2) 0Ω (For terminal 1-3)

Part name	Symbol	Specifications	Check
Head lamp, Work lamp, Cab lamp	CL-3 CL-4 CL-5 CL-6 CL-8 CL-9 CL-10 CL-24	24V 65W (H3 Type)	* Check disconnection Normal : 1.2 Ω
Beacon lamp	CL-7	21V 70W (H1 Type)	* Check disconnection Normal : A few Ω
Fuel filler pump	$ \begin{array}{c} $	24V 10A 35 / /min	* Check resistance Normal : 1.0 Ω
Service meter	3 h 2 h 1 CN-48	16~32V	 Check operation Supply power(24V) to terminal No.2 and connect terminal No.1 and ground
Horn	CN-20 CN-25	DC22~28V 2A	* Check operation Supply power(24V) to each terminal and connect ground.
Safety switch	2 3 1 0 2 2 1 0 2 3 0 CS-4	24V 15A (N.C TYPE)	* Check contact Normal : 0 Ω (for terminal 1-2) $\infty \Omega$ (for terminal 1-3) Operating : $\infty \Omega$ (for terminal 1-2) 0 Ω (for terminal 1-3)

Part name	Symbol	Specifications	Check
Wiper cut switch	CS-53	24V (N.O TYPE)	* Check contact Normal : 0 Ω (one pin to ground)
Receiver dryer	P 0 1 0 2 0 CN-29	24V 2.5A	* Check contact Normal : ∞ Ω
Radio & USB plalyer	CN-22	24V 2A	 * Check voltage 20~25V (for terminal 1-3, 3-8)
Washer pump		24V 3.8A	* Check contact Normal : 10.7 Ω (for terminal 1-2)
Wiper motor	3 1 0 0 0 0 0 0 0 0 0 0 0 0 0	24V 2A	* Check disconnection Normal : 7 Ω (for terminal 2-6)
DC/DC Converter	0 30 12V 2 0 24V 0 1 0 GND 24V CN-138	12V 3A	24V (1-2) 12V (1-3)

Part name	Symbol	Specifications	Check
Cigar lighter	CL-2	24V 5A 1.4W	 * Check coil resistance Normal : About 1M Ω * Check contact Normal : ∞ Ω Operating time : 5~15sec
Alternator	OB+ OL 3~ +4 DU CN-74 0 0 0 0 0 0 0 0 0 0 0 0 0	24V 85A	* Check contact Normal : 0 Ω (for terminal B ⁺ -I) Normal : 24~27.5V
Starter	M M B+ CN-45	Denso 24V 4.5kW	* Check contact Normal : 0.1 Ω
Travel alarm	0 2 0 0 1 0 CN-81	24V 0.5A	* Check contact Normal : 5.2 Ω
Aircon compressor	CN-28	24V 79W	* Check contact Normal : 13.4 Ω
Start relay	CR-23	24V 300A	* Check contact Normal : 0.94 Ω (for terminal 1-2)

Part name	Symbol	Specifications	Check
Blower motor		24V 9.5A	* Check resistance Normal : 2.5 Ω (for terminal 1-2)
Duct sensor (switch)		1°C OFF 4°C ON	* Check resistance Normal : 0 Ω (for terminal 1-2), the atmosphere temp : Over 4°C
Door switch	CS-1	24V 2W	* Check resistance Normal : About 5M Ω
Switch (power max, one touch decal, horn, breaker)	$\begin{bmatrix} - + \\ - $	24V 6A	ະ Check resistance Normal : ∞ Ω
Circuit breaker	CN-60 CN-95	60A	 Check disconnection normal : 0 Ω (connect ring terminal and check resist between terminal 1 and 2)
Master switch	CS-74A CS-74B	6-36V	* Check disconnection Normal : 0.1 Ω

Part name	Symbol	Specifications	Check
Quick clamp buzzer	010 020 CN-113	24V 200mA 107±4dB	-
Socket	01 02 CN-139	12V 10A	-
WIF sensor	02 01 CD-45	-	% Check contact Normal : 68.8 ~ 4.94 Ω

GROUP 4 CONNECTORS

1. CONNECTOR DESTINATION

Connector	Turpo	No. of	Destination	Connecto	or part No.
number	Туре	pin	Destination	Female	Male
CN-1	AMP	12	I/conn (Frame harness-Pump PS harness)	S816-012002	S816-112002
CN-2	AMP	16	I/conn (Frame harness-Engine harness)	S816-016002	S816-116002
CN-3	AMP	26	I/conn (Frame harness-Engine harness)	1897009-2	1897013-2
CN-4	AMP	16	I/conn (Console harness LH-Frame harness)	368047-1	368050-1
CN-5	DEUTSCH	60	I/conn (Side harness RH-Frame harness)	DRB16-60SAE-L018	DRB14-60PAE-L018
CN-7	AMP	16	l/conn (Console harness RH-Frame harness)	368047-1	368050-1
CN-8	AMP	12	l/conn (Console harness RH-Frame harness)	S816-012002	S816-112002
CN-10	DEUTSCH	12	I/conn (Cab harness-Side harness RH)	DT06-12S-EP06	DT04-12P-BE02
CN-11	DEUTSCH	8	I/conn (Frame harness-Aircon harness)	DT06-8S-EP06	-
CN-12	DEUTSCH	2	I/conn (Frame harness-Boom wire harness)	DT06-2S-EP06	DT04-2P-E005
CN-15	AMP	12	l/conn (Frame harness-Two way harness)	S816-012002	S816-112002
CN-16	AMP	6	Emergency engine start & speed control	S816-006002	S816-106002
CN-17	DEUTSCH	8	I/conn (Wiper harness)	DT06-8S-EP06	DT04-8P
CN-20	MOLEX	2	Horn	36812-0211	-
CN-21	AMP	6	Wiper motor	925276-0	-
CN-22	KET	2	Washer pump	MG640605	-
CN-23	KET	2	Speaker-LH	MG610070	-
CN-24	KET	2	Speaker-RH	MG610070	-
CN-25	MOLEX	2	Horn	36812-0211	-
CN-27	KUM	16	Radio & USB player	PK145-16017	-
CN-28	KUM	1	Aircon compressor	NMWP01F-B	-
CN-29	KET	2	Receiver dryer	MG640795	-
CN-36	-	-	Fuse box	21Q7-10910	-
CN-36-1	AMP	16	I/conn (Fuse box-Frame harness)	368047-1	368050-1
CN-36-2	AMP	8	I/conn (Fuse box-Frame harness)	MG610051	-
CN-36-3	AMP	26	I/conn (Fuse box-Frame harness)	1897009-2	-
CN-45	RING-TERM	-	Starter motor B ⁺	S820-308000	-
CN-48	KET	1	Service meter	2-520193-2	-
CN-51	DEUTSCH	40	MCU	DRC26-40SA	-
CN-52	DEUTSCH	40	MCU	DRC26-40SB	-
CN-53	DEUTSCH	40	MCU	DRC26-40SC	-
CN-56	AMP	8	Cluster	-	S816-108002
CN-60	YAZAKI	2	Circuit breaker	-	7122-4125-50
CN-61	DEUTSCH	2	Fuel filler pump	DT06-2S-EP06	-


Connector	T	No. of	Destination	Connecto	or part No.
number	Туре	pin	Destination	Female	Male
CN-66	DEUTSCH	2	Breaker solenoid	DT06-2S-EP06	-
CN-68	DEUTSCH	2	Safety solenoid	DT06-2S-EP06	-
CN-70	DEUTSCH	2	Travel high solenoid	DT06-2S-EP06	-
CN-74	RING-TERM	-	Alternator "I" terminal	-	S820-105000
CN-75	AMP	2	Pump EPPR	S816-002002	-
CN-80	RING-TERM	-	Glow plug	S820-306000	-
CN-81	DEUTSCH	2	Travel buzzer solenoid	DT06-2S-EP06	-
CN-88	DEUTSCH	2	Power max solenoid	DT06-2S-EP06	-
CN-93	DEUTSCH	64	Engine ECM	776469-1	-
CN-95	AMP	2	Fusible link	-	S813-130201
CN-96	AMP	4	Fuel warmer	15300027	-
CN-116	AMP	12	Switch panel	176116	-
CN-125	Econoseal J	4	GPS connector	S816-004002	S816-104002
CN-126	AMP	10	Service tool	S816-010002	S816-110002
CN-133	DEUTSCH	2	Boom priority solenoid	DT06-2S-EP06	-
CN-135	DEUTSCH	2	Arm regeneration solenoid	DT06-2S-EP06	-
CN-138	FASTEN	3	DC/DC Converter	S810-003202	-
CN-139	FASTEN	2	12V socket	172434-2	-
CN-140	DEUTSCH	2	Quick clamp solenoid	DT06-2S-EP06	DT04-2P-E005
CN-141	AMP	13	Wiper motor controller	172498-1	DT04-3P-EP10
CN-142	DEUTSCH	3	Accel dial	DT06-3S-EP06	-
CN-144	KET	20	Handsfree	MG610240	-
CN-149	DEUTSCH	2	Attach safety solenoid	DT06-2S-EP06	-
CN-156	DEUTSCH	2	Air seat	DT04-2P-E005	DT06-2S-EP06
CN-157	AMP	1	Antena power	S822-014002	-
CN-170	AMP	2	Heated seat	S816-002002	S816-102002
CN-173	AMP	2	Resistor	S816-002002	-
CN-231	DEUTSCH	2	I/conn (Master switch-Fuse box)	S813-030201	
CN-236	DEUTSCH	2	Attach pressure solenoid	DT06-2S-EP06	-
CN-237	DEUTSCH	2	Attach conflux solenoid	DT06-2S-EP06	-
CN-242	DEUTSCH	2	Attach flow solenoid	DT06-2S-EP06	DT04-2P-E005
CN-245	AMP	12	Remote controller assy	368542-1	-
CN-246	AMP	12	USB & Socket assy	174045-2	-
CN-247	DEUTSCH	8	Proportional	DT06-08SA-EP06	DT04-8P
CN-249	DEUTSCH	4	Rear view camera	DT06-4S-EP06	DT04-4P-E005
CN-259	AMP	6	Camera	S816-006002	-
CN-262	DEUTSCH	2	Straight travel solenoid	DT06-2S-EP06	-
CN-263	DEUTSCH	2	2 pcs boom solenoid	DT06-2S-EP06	-
CN-267	AMP	2	Accel dial LED	S816-002002	S816-102002


Connector	Tree	No. of	Destination	Connecto	or part No.
number	Туре	pin	Destination	Female	Male
\cdot Relay					
CR-1	RING-TERM	-	Battery relay	ST710285-2	-
CR-2	-	5	Horn relay	-	-
CR-4	-	5	Work lamp relay	BJA003526-001	-
CR-5	-	5	Anti restart relay	-	-
CR-7	-	5	Aircon compressor relay	BJA003526-001	-
CR-9	-	5	Cabin lamp relay	BJA003526-001	-
CR-13	-	5	Head lamp relay	BJA003526-001	-
CR-23	RING TERM	-	Start relay	S814-002001	S814-102001
CR-24	RING TERM	-	Preheat relay	S822-014000	-
CR-35	-	5	Power relay	-	-
CR-36	-	5	Preheat relay	-	-
CR-45	AMP	5	ECM power relay	BJA003526-001	24L1-05100
CR-46	-	5	Fuel warmer relay	BJA003526-001	-
CR-62	-	5	Breaker relay	BJA003526-001	-
 Switch 	1			I	
CS-1	SHUR	1	Door switch	S822-014002	S822-114002
CS-2	WP	6	Start key switch	S816-006100	-
CS-4	DEUTSCH	3	Safety switch	DT06-3S-EP06	-
CS-5	DEUTSCH	2	Horn switch	-	DT04-2P-E005
CS-19	DEUTSCH	2	One touch decel switch	-	DT04-2P-E005
CS-23	SWF	12	Beacon lamp switch	SWF589790	-
CS-26	DEUTSCH	2	Breaker switch	DT06-2S-EP06	-
CS-26A	AMP	2	Breaker pedal switch	S816-002002	S816-102002
CS-33	AMP	6	Emergency engine stop switch	S816-006002	S816-106002
CS-29	DEUTSCH	2	Power max switch	DT06-2S-EP06	-
CS-50	SWF	12	Overload switch	SWF589790	-
CS-52	SWF	12	Econo switch	SWF589790	-
CS-53	AMP	1	Wiper cut switch	S822-014002	-
CS-67	SWF	12	Quick clamp switch	SWF 589790	-
CS-74	AMP	2	Master switch	S813-030201	-
CS-82	SWF	12	Heated seat switch	SWF 589790	-
CS-83	SWF	12	Spare switch	SWF589790	-
CS-99	SWF	12	Air compressor switch	SWF 589790	-
CS-100	SWF	12	Spare switch	SWF 589790	-
CS-103	SWF	12	Spare switch	SWF 589790	-
CS-104	SWF	12	Spare switch	SWF 589790	-
CS-105	SWF	12	Spare switch	SWF 589790	-

Connector	Tupo	No. of	Destination	Connecto	or part No.		
number	Туре	pin	Destination	Female	Male		
• Light	· Light						
CL-1	KET	3	Room lamp	MG651032	-		
CL-2	AMP	1	Cigar light	S822-014002	S822-114002		
CL-3	DEUTSCH	2	Head lamp-LH	DT06-2S-EP06	DT04-2P-E005		
CL-4	DEUTSCH	2	Head lamp-RH	DT06-2S-EP06	DT04-2P-E005		
CL-5	DEUTSCH	2	Work lamp-LH	DT06-2S-EP06	DT04-2P		
CL-6	DEUTSCH	2	Work lamp-RH	DT06-2S-EP06	DT04-2P		
CL-7	SHUR	1	Beacon lamp	S822-014002	S822-114002		
CL-8	DEUTSCH	2	Front cab light-LH	DT06-2S-EP06	DT04-2P		
CL-9	DEUTSCH	2	Front cab light-RH	DT06-2S-EP06	DT04-2P		
CL-10	DEUTSCH	2	Rear cab light-LH	DT06-2S-EP06	DT04-2P		
· Sensor, se	endor						
CD-1	AMP	2	Hydraulic oil temp sender	85202-1	-		
CD-2	DEUTSCH	2	Fuel level sender	DT06-2S-EP06	-		
CD-6	DEUTSCH	3	Travel pressure sensor	DT06-3S-EP06	-		
CD-7	DEUTSCH	3	Working pressure sensor	DT06-3S-EP06	-		
CD-10	AMP	2	Air cleaner switch	85202-1	-		
CD-16	DELPHI	3	Water lever	12110293	-		
CD-24	DEUTSCH	3	Swing sensor	DT06-3S-EP06	-		
CD-31	DEUTSCH	3	Overload sensor	DT06-3S-EP06	-		
CD-32	DEUTSCH	3	Boom up sensor	DT06-3S-EP06	-		
CD-35	DEUTSCH	3	Arm & bucket in sensor	DT06-3S-EP06	-		
CD-42	DEUTSCH	3	Pump pressure 1	DT06-3S-EP06	-		
CD-43	DEUTSCH	3	Pump pressure 2	DT06-3S-EP06	-		
CD-44	DEUTSCH	3	Pump pressure 3	DT06-3S-EP06	-		
CD-45	AMP	3	WIF sensor	776429-3	-		
CD-50	KET	2	Dozer pressure switch	640795	-		
CD-69	DEUTSCH	3	Attach pressure sensor	DT06-3S-EP06	-		
CD-70	DEUTSCH	3	N1 pressure sensor	DT06-3S-EP06	-		
CD-71	DEUTSCH	3	N2 pressure sensor	DT06-3S-EP06	-		


2. CONNECTION TABLE FOR CONNECTORS

1) PA TYPE CONNECTOR







2) J TYPE CONNECTOR





3) SWP TYPE CONNECTOR






4) CN TYPE CONNECTOR






5) 375 FASTEN TYPE CONNECTOR




6) AMP ECONOSEAL CONNECTOR




7) AMP TIMER CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	1 1 1 1 1 1 1 1 1 1	

8) AMP 040 MULTILOCK CONNECTOR



9) AMP 070 MULTILOCK CONNECTOR



10) AMP FASTIN - FASTON CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
6		
	925276-0	

11) KET 090 CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2		
	MG610070	


12) KET 090 WP CONNECTORS

No. of pin	Receptacle connector (female)	Plug connector (male)
2	1 2 MG640605	
2		
	MG640795	

13) KET SDL CONNECTOR


No. of pin	Receptacle connector (female)	Plug connector (male)
14	1 7 14 6 MG610406	


14) DEUTSCH DT CONNECTORS



- * Modification
 - E003 : Standard end cap gray
 - E004 : Color of connector to be black
 - E005 : Combination E004 & E003
 - EP04 : End cap
 - EP06 : Combination P012 & EP04

P012 : Front seal enhancement - connectors color to black for 2, 3, 4 & 6pin





15) MOLEX 2CKTS CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2		
	35215-0200	


16) ITT SWF CONNECTOR


No. of pin	Receptacle connector (female)	Plug connector (male)
10		
	SWF593757	


17) MWP NMWP CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
1	1	
	NMWP01F-B	


18) ECONOSEAL J TYPE CONNECTORS








19) METRI-PACK TYPE CONNECTOR




20) DEUTSCH HD30 CONNECTOR



21) DEUTSCH MCU CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
40	$\begin{array}{c} 1 \\ 1 \\ 1 \\ 2 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3$	
	DRC26-40SA/B	


22) DEUTSCH SERVICE TOOL CONNECTOR




23) AMP FUEL WARMER CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
4		
	2-967325-3	

24) DEUTSCH ENGINE ECM CONNECTOR



25) DEUTSCH INTERMEDIATE CONNECTOR




Group	1	Outline	5-1
Group	2	Mode Selection System	5-3
Group	3	Automatic Deceleration System	5-6
Group	4	Power Boost System ·····	5-7
Group	5	Travel Speed Control System	5-8
Group	6	Automatic Warming Up System	5-9
Group	7	Engine Overheat Prevention System	5-10
Group	8	Variable Power Control System	5-11
Group	9	Attachment Flow Control System	5-12
Group	10	Anti-Restart System ·····	5-13
Group	11	Self-Diagnostic System	5-14
Group	12	Engine Control System	5-20
Group	13	EPPR Valve	5-21
Group	14	Monitoring System ·····	5-26
Group	15	Fuel Warmer System	5-51


GROUP 1 OUTLINE

The ADVANCED CAPO (Computer Aided Power Optimization) system controls engine and pump mutual power at an optimum and less fuel consuming state for the selected work by mode selection, auto-deceleration, power boost function, etc. It monitors machine conditions, for instance, engine speed, coolant temperature, hydraulic oil temperature, and hydraulic oil pressure, etc.

It consists of a MCU, a cluster, an ECM, EPPR valves, and other components. The MCU and the cluster protect themselves from over-current and high voltage input, and diagnose malfunctions caused by short or open circuit in electric system, and display error codes on the cluster.




SYSTEM DIAGRAM



145Z9A5MS01

GROUP 2 MODE SELECTION SYSTEM

1. POWER MODE SELECTION SYSTEM



2609A5MS02

Mode selection system (micro computer based electro-hydraulic pump and engine mutual control system) optimizes the engine and pump performance.


The combination of 3 power modes (P, S, E) and accel dial position (10 set) makes it possible to use the engine and pump power more effectively corresponding to the work conditions from a heavy and great power requesting work to a light and precise work.

		Engine rpm			Power shift by EPPR valve				
Power	Application	Standard		Option		Standard		Option	
mode	Application	Unload	Load	Unload	Load	Current (mA)	Pressure (kgf/cm ²)	Current (mA)	Pressure (kgf/cm ²)
Р	Heavy duty power	1800±50	1900±50	1950±50	1900±50	330±30	10	160±30	0
S	Standard power	1700±50	1800±50	1850±50	1800±50	400±30	15±3	250±30	5±3
E	Economy operation	1600±50	1700±50	1700±50	1800 ± 50	500 ± 30	20±3	400±30	10±3
AUTO DECEL	Engine deceleration	1100±100	-	1100±100	-	700±30	38±3	700±30	38±3
One touch decel	Engine quick deceleration	1000±100	-	1000±100	-	700±30	38±3	700±30	38±3
KEY START	Key switch start position	1000±100	-	1000±100	-	700±30	38±3	700±30	38±3

* Power shift (Standard/Option) can be changed by "Service menu" in "Management" on the cluster.

2. WORK MODE SELECTION SYSTEM

Work mode consists of the general operation (bucket) and the optional attachment (breaker, crusher).



145Z9A5MS02

1) GENERAL WORK MODE (bucket)


This mode is used to general digging work.

2) ATT WORK MODE (breaker, crusher)

It controls the pump flow and system pressure according to the operation of breaker or crusher.

Description	General mode	Work	< tool
Description	Bucket	Breaker	Crusher
Attachment safety solenoid	OFF	ON	ON
Attachment pressure solenoid	OFF	OFF	ON
Attachment conflux solenoid	OFF	OFF	ON/OFF
Attachment flow EPPR current	100 mA	100~700 mA	100~700 mA

3. USER MODE SELECTION SYSTEM




2609A5MS04

1) High idle rpm, auto idle rpm and EPPR pressure can be adjusted and memorized in the U-mode.

2) LCD segment vs p	arameter setting
---------------------	------------------

Step (∎)	Engine speed (rpm)	Idle speed (rpm)	Power shift (bar)
1	1400	800	0
2	1500	850	3
3	1600	900	6
4	1650	950	9
5	1700	1000 (low idle)	12
6	1750	1050	16
7	1800	1100 (decel rpm)	20
8	1850	1150	26
9	1900	1200	32
10	1950	1250	38


GROUP 3 AUTOMATIC DECELERATION SYSTEM



1. WHEN AUTO IDLE PILOT LAMP ON

When all of the work equipment control levers including swing and travel levers are at neutral for 4 seconds, MCU sends throttle command to ECM to reduce the engine speed to 1100 rpm. If the control levers are at neutral for 1 minute, MCU reduces the engine speed to 1000 rpm. As the result of reducing the engine speed, fuel consumption and noise are effectively cut down during non-operation of the control levers.

When the Auto idle pilot lamp is turned off by pressing the switch or any control lever is operated, the reduced engine speed rises upto the speed before deceleration in a second.




2. WHEN AUTO IDLE PILOT LAMP OFF

The engine speed can be set as desired using the accel dial switch, and even if the control levers are neutral, the engine speed is not reduced.

* Auto idle function can be activated when accel dial position is over 4.

GROUP 4 POWER BOOST SYSTEM




- When the power boost switch on the left control lever knob is pushed ON, the power mode is set P mode and maximum digging power is increased by 10 %.
- When the power boost function is activated, the power boost solenoid valve pilot pressure raises the set pressure of the main relief valve to increase the digging power.

Description	Condition	Function
Activated	Power boost switch : ON Accel dial : over 8	 Power mode : P Accel dial power : 9 Power boost solenoid : ON Power boost pilot Imap : ON Operating time : max 8 seconds
Canceled Power boost switch : OFF		 Pre-set power mode Power boost solenoid : OFF Power boost pilot lamp : OFF

When the auto power boost is set to Enable and power mode is set to P mode on the cluster, the digging power is automatically increased as working conditions by the MCU. It is operated max 8 seconds.

GROUP 5 TRAVEL SPEED CONTROL SYSTEM




145Z9A5MS05

Travel speed can be switched manually by pressing the travel speed switch on the cluster.

Speed	Travel speed solenoid valve	Lamp on cluster	Operation	
Low	ow OFF Turtle		Low speed, high driving torque in the travel motor	
High	ON	Rabbit	High speed, low driving torque in the travel motor	

* Default : Turtle (Low)

GROUP 6 AUTOMATIC WARMING UP SYSTEM




2609A5MS08

- The MCU receives the engine coolant temperature from the ECM, and if the coolant temperature is below 30°C, engine speed increases to 1200 rpm after 1 minute from engine start. At this time the mode does not change. If the coolant temperature sensor has fault, the hydraulic oil temperature signal is substituted.
- In case of the coolant temperature increases up to 30°C, the engine speed is decreased to key start speed. And if an operator changes power mode set during the warming up function, the MCU cancels the automatic warming up function.

Description	Condition	Function
Actuated	- Coolant temperature : below 30°C (after engine run)	 Power mode : Default (E mode) Warming up time : 10 minutes (max) Warming up pilot lamp : ON
Canceled	 Coolant temperature : Above 30°C Warming up time : Above 10 minutes Changed power mode set by operator RCV lever or pedal operating Auto idle cancel ※ If any of the above conditions is applicable, the automatic warming up function is canceled 	- Power mode : set mode - Warming up pilot lamp : OFF

3.	LO	GIC	TA	BLE
ν.	LO.			

GROUP 7 ENGINE OVERHEAT PREVENTION SYSTEM




1. If the engine coolant temperature or the hydraulic oil temperature is overheated over 100°C, the warning lamp is ON and the pump input torque or the engine speed is reduced as below logic table.

Description		Condition	Function
First step warning	Activated	 Coolant temperature : Above 103°C Hydraulic oil temperature : Above 100°C 	 Warning lamp : ON , buzzer : OFF Pump input torque is reduced. Warning lamp & buzzer : ON Pump input torque is reduced.
	Canceled	 Coolant temperature : Less than 100°C Hydraulic oil temperature : Less than 95°C 	- Return to pre-set the pump absorption torque.
Second step warning	Activated	 Coolant temperature : Above 107°C Hydraulic oil temperature : Above 105°C 	 Emergency warning lamp pops up on the center of LCD and the buzzer sounds. Engine speed is reduced after 10 seconds.
	Canceled	 Coolant temperature : Less than 103°C Hydraulic oil temperature : Less than 100°C 	 Return to pre-set the engine speed. Hold pump absorption torque on the first step warning.

2. LOGIC TABLE

GROUP 8 VARIABLE POWER CONTROL SYSTEM




• The variable power control system controls the engine and pump mutual power according to RCV lever stroke and pump load.

It makes fuel saving and smooth control at precise work.

Description	Working condition
Power mode	E
Work mode	General (bucket)
Pressure sensor	Normal

* The variable power control function can be activated when the power mode is set to E mode.

GROUP 9 ATTACHMENT FLOW CONTROL SYSTEM




145Z9A5MS06

• The system is used to control the pump delivery flow according to set of the work tool on the cluster by the attachment flow EPPR valve.

Description	Work tool		
Description	Breaker	Crusher	
Flow level	Max 7 step, reduced 10 lpm each step	Max 4 step, reduced 20 lpm each step	
Attach safety solenoid	ON	ON	
Attach pressure solenoid	OFF	ON	
Attach conflux solenoid	OFF	ON/OFF	

* Refer to the page 5-38 for the attachment kinds and max flow.

GROUP 10 ANTI-RESTART SYSTEM



2609A5MS12

1. ANTI-RESTART FUNCTION

After a few seconds from the engine starts to run, MCU turns off the start safety relay to protect the starter from inadvertent restarting.

2. When a replacement or taking-off of the MCU is needed, connect CN-16 and CN-16B to ensure the engine start without the MCU.

GROUP 11 SELF-DIAGNOSTIC SYSTEM

1. OUTLINE

When any abnormality occurs in the ADVANCED CAPO system caused by electric parts malfunction and by open or short circuit, the MCU diagnoses the problem and sends the error codes to the cluster and also stores them in the memory.

2. MONITORING

1) Active fault



· The active faults of the MCU or engine ECM can be checked by this menu.

2) Logged fault



• The logged faults of the MCU or engine ECM can be checked by this menu.

3) Delete fault



• The logged faults of the MCU or engine ECM can be deleted by this menu.

3. MACHINE ERROR CODES TABLE

Error co HCESPN	de FMI	Description
TICESI N	3	Hydraulic oil temperature sensor circuit - Voltage above normal, or shorted to high source.
101	4	Hydraulic oil temperature circuit - Voltage below normal, or shorted to low source.
	0	Working pressure sensor data above normal range.
	1	Working pressure sensor data below normal range.
105	2	Working pressure sensor data error.
	4	Working pressure sensor circuit - Voltage below normal, or shorted to Low source.
	0	Travel oil pressure sensor data above normal range.
100	1	Travel oil pressure sensor data below normal range.
108	2	Travel oil pressure sensor data error.
	4	Travel oil pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Main pump 1 (P1) pressure sensor data above normal range.
	1	Main pump 1 (P1) pressure sensor data below normal range.
120	2	Main pump 1 (P1) pressure sensor data error.
	4	Main pump 1 (P1) pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Main pump 2 (P2) pressure sensor data above normal range.
	1	Main pump 2 (P2) pressure sensor data below normal range.
121	2	Main pump 2 (P2) pressure sensor data error.
	4	Main pump 2 (P2) pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Overload pressure sensor data above normal range.
122	1	Overload pressure sensor data below normal range.
122	2	Overload pressure sensor data error.
	4	Overload pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Negative 1 pressure sensor data above normal range.
123	1	Negative 1 pressure sensor data below normal range.
120	2	Negative 1 pressure sensor data error.
	4	Negative 1 pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Negative 2 Pressure sensor data above normal range.
124	1	Negative 2 Pressure sensor data below normal range.
	2	Negative 2 Pressure sensor data error.
	4	Negative 2 Pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Pilot pump (P3) pressure sensor data above normal range.
125	1	Pilot pump (P3) pressure sensor data below normal range.
	2	Pilot pump (P3) pressure sensor data error.
	4	Pilot pump (P3) pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Boom up pilot pressure sensor data above normal range.
127	1	Boom up pilot pressure sensor data below normal range.
	2	Boom up pilot pressure sensor data error.
	4	Boom up pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
	1	Arm in/out & bucket in pilot pressure sensor data above normal range.
133	2	Arm in/out & bucket in pilot pressure sensor data below normal range.
100	4	Arm in/out & bucket in pilot pressure sensor data error. Arm in/out & bucket in pilot pressure sensor circuit - Voltage below normal, or shorted to low source.

* Some error codes are not applied to this machine.* SPN : Suspect Parameter Number

FMI : Failure Mode Identifier

Error co HCESPN	FMI	Description
	0	Swing pilot pressure sensor data above normal range.
135	1	Swing pilot pressure sensor data below normal range.
	2	Swing pilot pressure sensor data error.
	4	Swing pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Attachment pilot pressure sensor data above normal range.
	1	Attachment pilot pressure sensor data below normal range.
138	2	Attachment pilot pressure sensor data error.
	4	Attachment pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
	5	Pump EPPR valve circuit - Current below normal, or open circuit.
140	6	Pump EPPR valve circuit - Current above normal.
	5	Boom priority EPPR valve circuit - Current below normal, or open circuit.
141	6	Boom priority EPPR valve circuit - Current above normal.
	5	Travel EPPR valve circuit - Current below normal, or open circuit.
143	6	Travel EPPR valve circuit - Current above normal.
	5	Attachment flow EPPR valve circuit - Current below normal, or open circuit.
144	6	Attachment flow EPPR valve circuit - Current above normal.
	5	Remote cooling fan EPPR valve circuit - Current below normal, or open circuit.
145	6	Remote cooling fan EPPR valve circuit - Current above normal.
	5	Left rotate EPPR valve circuit - Current below normal, or open circuit.
150	6	Left rotate EPPR valve circuit - Current above normal.
454	5	Right rotate EPPR valve circuit - Current below normal, or open circuit.
151	6	Right rotate EPPR valve circuit - Current above normal.
450	5	Left tilt EPPR valve circuit - Current below normal, or open circuit.
152	6	Left tilt EPPR valve circuit - Current above normal.
450	5	Right tilt EPPR valve circuit - Current below normal, or open circuit.
153	6	Right tilt EPPR valve circuit - Current above normal.
100	5	Power max solenoid circuit - Current below normal, or open circuit.
166	6	Power max solenoid circuit - Current above normal.
107	5	Travel speed solenoid circuit - Current below normal, or open circuit.
167	6	Travel speed solenoid circuit - Current above normal.
100	5	Attachment pressure solenoid circuit - Current below normal, or open circuit.
168	6	Attachment pressure solenoid circuit - Current above normal.
100	5	Attachment conflux solenoid circuit - Current below normal, or open circuit.
169	6	Attachment conflux solenoid circuit - Current above normal.
170	5	Arm regeneration solenoid circuit - Current below normal, or open circuit.
170	6	Arm regeneration solenoid circuit - Current above normal.
171	5	Attachment safety solenoid circuit - Current below normal, or open circuit.
171	6	Attachment safety solenoid circuit - Current above normal.
101	5	Remote cooling fan reverse solenoid circuit - Current below normal, or open circuit.
181	6	Remote cooling fan reverse solenoid circuit - Current above normal.
201	5	Fuel level sensor circuit - Voltage above normal, or shorted to high source.
301	6	Fuel level sensor circuit - Voltage below normal, or shorted to low source.
004	3	Engine coolant temperature sensor circuit - Voltage above normal, or shorted to hig source.
304	4	Engine coolant temperature sensor circuit - Voltage below normal, or shorted to low source.
310	8	Engine speed signal error - Abnormal frequency or pulse width.
	3	Engine preheat relay circuit - Voltage above normal, or shorted to high source.
322	4	Engine preheat relay circuit - Voltage below normal, or shorted to low source.
	3	Fuel warmer relay circuit - Voltage above normal, or shorted to high source.
325	4	Fuel warmer relay circuit - Voltage below normal, or shorted to low source.

* Some error codes are not applied to this machine.

* SPN : Suspect Parameter Number

FMI : Failure Mode Identifier

HCESPN	de FMI	Description
	3	Potentiometer (G/A) circuit - Voltage above normal, or shorted to high source.
340	4	Potentiometer (G/A) circuit - Voltage below normal, or shorted to low source.
341	5	Governor actuator circuit - Current below normal, or open circuit.
	6	Governor actuator circuit - Current above normal.
	0	Transmission oil pressure sensor data above normal range.
	1	Transmission oil pressure sensor data below normal range.
501	2	Transmission oil pressure sensor data error.
	4	Transmission oil pressure sensor circuit - Voltage below normal, or shorted to low sourc
	0	Brake pressure sensor data above normal range.
	1	Brake pressure sensor data below normal range.
503	2	Brake pressure sensor data error.
	4	Brake pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Working brake pressure sensor data above normal range.
	1	Working brake pressure sensor data below normal range.
505	2	Working brake pressure sensor data error.
	4	Working brake pressure sensor circuit - Voltage below normal, or shorted to low source
	3	Working brake lamp circuit - Voltage above normal, or shorted to high source.
506	4	Working brake lamp circuit - Voltage below normal, or shorted to low source.
500	3	Ram lock lamp circuit - Voltage above normal, or shorted to high source.
520	4	Ram lock lamp circuit - Voltage below normal, or shorted to low source.
	5	Ram lock solenoid circuit - Current below normal, or open circuit.
525	6	Ram lock solenoid circuit - Current above normal.
	0	Travel F pilot pressure sensor data above normal range.
500	1	Travel F pilot pressure sensor data below normal range.
530	2	Travel F pilot pressure sensor data error.
	4	Travel F pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Travel R pilot pressure sensor data above normal range.
501	1	Travel R pilot pressure sensor data below normal range.
531	2	Travel R pilot pressure sensor data error.
	4	Travel R pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
704	3	Hourmeter circuit - Voltage above normal, or shorted to high source.
701	4	Hourmeter circuit - Voltage below normal, or shorted to low source.
705	0	MCU input voltage high.
705	1	MCU input voltage low.
707	1	Alternator node I voltage low.
714	3	Acc. dial circuit - Voltage above normal, or shorted to high source.
/14	4	Acc. dial circuit - Voltage below normal, or shorted to low source.
715	3	Rotate signal input circuit - Voltage above normal, or shorted to high source.
/15	4	Rotate signal input circuit - Voltage below normal, or shorted to low source.
716	3	Tilt signal input circuit - Voltage above normal, or shorted to high source.
716	4	Tilt signal input circuit - Voltage below normal, or shorted to low source.
700	3	Travel alarm (buzzer) circuit - Voltage above normal, or shorted to high source.
722	4	Travel alarm (buzzer) circuit - Voltage below normal, or shorted to low source.
830	12	MCU internal memory error.
840	2	Cluster communication data error.
841	2	ECM communication data error.
843	2	Option #1 (CAN 2) communication data error.
850	2	RMCU communication data error.

 \ast Some error codes are not applied to this machine.

* SPN : Suspect Parameter Number

FMI : Failure Mode Identifier

4. ENGINE FAULT CODE

J1939 Code	Description	Refer to Procedure
27-3	Engine Exhaust Gas Recirculation Valve Position Sensor : Voltage Above Normal	Valve Position Sensor - Test
27-4	Engine Exhaust Gas Recirculation Valve Position Sensor : Voltage Below Normal	Valve Position Sensor - Test
29-2	Accelerator Pedal Position 2 : Erratic, Intermittent, or Incorrect (Engines equipped with a throttle switch)	Throttle Switch Circuit - Test
29-2	Accelerator Pedal Position 2 : Erratic, Intermittent or Incorrect (Engines equipped with an analog throttle)	Analog Throttle Position Sensor Circuit - Test
29-3	Accelerator Pedal Position 2 : Voltage Above Normal (Engines equipped with an analog throttle)	Analog Throttle Position Sensor Circuit - Test
29-3	Accelerator Pedal Position 2 : Voltage Above Normal (Engines equipped with a digital throttle)	Digital Throttle Position Sensor Circuit - Test
29-4	Accelerator Pedal Position 2 : Voltage Below Normal (Engines equipped with an analog throttle)	Analog Throttle Position Sensor Circuit - Test
29-4	Accelerator Pedal Position 2 : Voltage Below Normal (Engines equipped with a digital throttle)	Digital Throttle Position Sensor Circuit - Test
29-8	Accelerator Pedal Position 2 : Abnormal Frequency, Pulse Width or Period	Digital Throttle Position Sensor Circuit - Test
91-2	Accelerator Pedal Position 1 : Erratic, Intermittent, or Incorrect (Engines equipped with a throttle switch)	Throttle Switch Circuit - Test
91-2	Accelerator Pedal Position 1 : Erratic, Intermittent or Incorrect (Engines equipped with an analog throttle)	Analog Throttle Position Sensor Circuit - Test
91-3	Accelerator Pedal Position 1 : Voltage Above Normal (Engines equipped with an analog throttle)	Analog Throttle Position Sensor Circuit - Test
91-3	Accelerator Pedal Position 1 : Voltage Above Normal (Engines equipped with a digital throttle)	Digital Throttle Position Sensor Circuit - Test
91-4	Accelerator Pedal Position 1 : Voltage Below Normal (Engines equipped with an analog throttle)	Analog Throttle Position Sensor Circuit - Test
91-4	Accelerator Pedal Position 1 : Voltage Below Normal (Engines equipped with a digital throttle)	Digital Throttle Position Sensor Circuit - Test
91-8	Accelerator Pedal Position 1 : Abnormal Frequency, Pulse Width or Period	Digital Throttle Position Sensor Circuit - Test
97-15	Water In Fuel Indicator : High - least severe (1)	Fuel System Water Separator Has Water
97-16	Water In Fuel Indicator : High - moderate severity (2)	Fuel System Water Separator Has Water
100-1	Engine Oil Pressure : Low - most severe (3)	Low Engine Oil Pressure
100-3	Engine Oil Pressure : Voltage Above Normal	Engine Pressure Sensor Open or Short Circuit - Test
100-4	Engine Oil Pressure : Voltage Below Normal	Engine Pressure Sensor Open or Short Circuit - Test
100-17	Engine Oil Pressure : Low - least severe (1)	Low Engine Oil Pressure
100-21	Engine Oil Pressure : Data Drifted Low	5 V Sensor Supply Circuit - Test
102-16	Engine Intake Manifold #1 Pressure : High - moderate severity (2)	Intake Manifold Air Pressure Is High

J1939 Code	Description	Refer to Procedure	
105-3	Engine Intake Manifold #1 Temperature : Voltage Above Normal	Engine Temperature Sensor Open or Short Circuit - Test (Passive Sensors)	
105-4	Engine Intake Manifold #1 Temperature : Voltage Below Normal	Engine Temperature Sensor Open or Shor Circuit - Test (Passive Sensors)	
105-15	Engine Intake Manifold #1 Temperature : High - least severe (1)	Intake Manifold Air Temperature Is High	
105-16	Engine Intake Manifold #1 Temperature : High - moderate severity (2)	Intake Manifold Air Temperature Is High	
107-15	Engine Air Filter 1 Differential Pressure : High - least severe (1)	Inlet Air Is Restricted	
108-3	Barometric Pressure : Voltage Above Normal	Engine Pressure Sensor Open or Short Circuit - Test	
108-4	Barometric Pressure : Voltage Below Normal	Engine Pressure Sensor Open or Short Circuit - Test	
108-21	Barometric Pressure : Data Drifted Low	5 V Sensor Supply Circuit - Test	
110-0	Engine Coolant Temperature : High - most severe (3)	Coolant Temperature Is Too High	
110-3	Engine Coolant Temperature : Voltage Above Normal	Engine Temperature Sensor Open or Short Circuit - Test (Passive Sensors)	
110-4	Engine Coolant Temperature : Voltage Below Normal	Engine Temperature Sensor Open or Short Circuit - Test (Passive Sensors)	
110-15	Engine Coolant Temperature : High - least severe (1)	Coolant Temperature Is Too High	
110-16	Engine Coolant Temperature : High - moderate severity (2)	Coolant Temperature Is Too High	
111-1	Engine Coolant Level : Low - most severe (3)	Coolant Level Is Low	
157-3	Engine Injector Metering Rail #1 Pressure : Voltage Above Normal	Engine Pressure Sensor Open or Short Circuit - Test	
157-4	Engine Injector Metering Rail #1 Pressure : Voltage Below Normal	Engine Pressure Sensor Open or Short Circuit - Test	
157-15	Engine Injector Metering Rail #1 Pressure : High - least severe (1)	Fuel Rail Pressure Problem	
157-17	Engine Injector Metering Rail #1 Pressure : Low - least severe (1)	Fuel Rail Pressure Problem	
168-2	Battery Potential / Power Input 1 : Erratic, Intermittent or Incorrect	Ignition Keyswitch Circuit and Battery Supply Circuit - Test	
168-3	Battery Potential / Power Input 1 : Voltage Above Normal	Ignition Keyswitch Circuit and Battery Supply Circuit - Test	
168-4	Battery Potential / Power Input 1 : Voltage Below Normal	Ignition Keyswitch Circuit and Battery Supply Circuit - Test	
172-3	Engine Air Inlet Temperature : Voltage Above Normal	Engine Temperature Sensor Open or Short Circuit - Test (Passive Sensors)	
172-4	Engine Air Inlet Temperature : Voltage Below Normal	Engine Temperature Sensor Open or Short Circuit - Test (Passive Sensors)	
174-3	Engine Fuel Temperature 1 : Voltage Above Normal	Engine Temperature Sensor Open or Short Circuit - Test (Passive Sensors)	
174-4	Engine Fuel Temperature 1 : Voltage Below Normal	Engine Temperature Sensor Open or Short Circuit - Test (Passive Sensors)	

J1939 Code	Description	Refer to Procedure
174-15	Engine Fuel Temperature 1 : High - least severe (1)	Fuel Temperature Is High
174-16	Engine Fuel Temperature 1 : High - moderate severity (2)	Fuel Temperature Is High
190-8	Engine Speed : Abnormal Frequency, Pulse Width or Period	Engine Speed/Timing Sensor Circuit - Test
190-15	Engine Speed : High - least severe (1)	Engine Overspeeds
412-3	Engine Exhaust Gas Recirculation Temperature : Voltage Above Normal	Engine Temperature Sensor Open or Short Circuit - Test (Passive Sensors)
412-4	Engine Exhaust Gas Recirculation Temperature : Voltage Below Normal	Engine Temperature Sensor Open or Short Circuit - Test (Passive Sensors)
412-15	Engine Exhaust Gas Recirculation Temperature : High - least severe (1)	NRS Exhaust Gas Temperature Is High
412-16	Engine Exhaust Gas Recirculation Temperature : High - moderate severity (2)	NRS Exhaust Gas Temperature Is High
558-2	Accelerator Pedal 1 Low Idle Switch : Erratic, Intermittent or Incorrect	Idle Validation Switch Circuit - Test
626-5	Engine Start Enable Device 1 : Current Below Normal	Ether Starting Aid - Test
626-6	Engine Start Enable Device 1 : Current Above Normal	Ether Starting Aid - Test
630-2	Calibration Memory : Erratic, Intermittent or Incorrect	Flash Programming
631-2	Calibration Module : Erratic, Intermittent or Incorrect	ECM Memory - Test
637-11	Engine Timing Sensor : Other Failure Mode	Engine Speed/Timing Sensor Circuit - Test
639-9	J1939 Network #1 : Abnormal Update Rate	CAN Data Link Circuit - Test
649-3	Engine Exhaust Back Pressure Regulator Solenoid : Voltage Above Normal	Motorized Valve - Test
649-5	Engine Exhaust Back Pressure Regulator Solenoid : Current Below Normal	Motorized Valve - Test
649-6	Engine Exhaust Back Pressure Regulator Solenoid : Current Above Normal	Motorized Valve - Test
649-7	Engine Exhaust Back Pressure Regulator Solenoid : Not Responding Properly	Motorized Valve - Test
651-2	Engine Injector Cylinder #01 : Erratic, Intermittent or Incorrect	Injector Data Incorrect - Test
651-5	Engine Injector Cylinder #01 : Current Below Normal	Injector Solenoid Circuit - Test
651-6	Engine Injector Cylinder #01 : Current Above Normal	Injector Solenoid Circuit - Test
652-2	Engine Injector Cylinder #02 : Erratic, Intermittent or Incorrect	Injector Data Incorrect - Test
652-5	Engine Injector Cylinder #02 : Current Below Normal	Injector Solenoid Circuit - Test
652-6	Engine Injector Cylinder #02 : Current Above Normal	Injector Solenoid Circuit - Test
653-2	Engine Injector Cylinder #03 : Erratic, Intermittent or Incorrect	Injector Data Incorrect - Test


J1939 Code	Description	Refer to Procedure
653-5	Engine Injector Cylinder #03 : Current Below Normal	Injector Solenoid Circuit - Test
653-6	Engine Injector Cylinder #03 : Current Above Normal	Injector Solenoid Circuit - Test
654-2	Engine Injector Cylinder #04 : Erratic, Intermittent or Incorrect	Injector Data Incorrect - Test
654-5	Engine Injector Cylinder #04 : Current Below Normal	Injector Solenoid Circuit - Test
654-6	Engine Injector Cylinder #04 : Current Above Normal	Injector Solenoid Circuit - Test
655-2	Engine Injector Cylinder #05 : Erratic, Intermittent or Incorrect (1206E-E66 Engine Only)	Injector Data Incorrect - Test
655-5	Engine Injector Cylinder #05 : Current Below Normal (1206E-E66 Engine Only)	Injector Solenoid Circuit - Test
655-6	Engine Injector Cylinder #05 : Current Above Normal (1206E E66 Engine Only)	Injector Solenoid Circuit - Test
656-2	Engine Injector Cylinder #06 : Erratic, Intermittent or Incorrect (1206E-E66 Engine Only)	Injector Data Incorrect - Test
656-5	Engine Injector Cylinder #06 : Current Below Normal (1206E-E66 Engine Only)	Injector Solenoid Circuit - Test
656-6	Engine Injector Cylinder #06 : Current Above Normal (1206E-E66 Engine Only)	Injector Solenoid Circuit - Test
676-6	Engine Glow Plug Relay : Current Above Normal	Starting Aid (Glow Plug) Relay Circuit - Test
678-3	ECU 8 Volts DC Supply : Voltage Above Normal	Digital Throttle Position Sensor Circuit - Test
678-4	ECU 8 Volts DC Supply : Voltage Below Normal	Digital Throttle Position Sensor Circuit - Test
723-8	Engine Speed Sensor #2 : Abnormal Frequency, Pulse Width or Period	Engine Speed/Timing Sensor Circuit - Test
1075-5	Engine Electric Lift Pump For Engine Fuel Supply : Current Below Normal	Fuel Pump Relay Circuit - Test
1075-6	Engine Electric Lift Pump For Engine Fuel Supply : Current Above Normal	Fuel Pump Relay Circuit - Test
1076-5	Engine Fuel Injection Pump Fuel Control Valve : Current Below Normal	Solenoid Valve - Test
1076-6	Engine Fuel Injection Pump Fuel Control Valve : Current Above Normal	Solenoid Valve - Test
1188-3	Engine Turbocharger 1 Wastegate Drive : Voltage Above Normal	Solenoid Valve - Test
1188-5	Engine Turbocharger 1 Wastegate Drive : Current Below Normal	Solenoid Valve - Test
1188-6	Engine Turbocharger 1 Wastegate Drive : Current Above Normal	Solenoid Valve - Test
1196-9	Anti-theft Component Status States : Abnormal Update Rate	Data Link Circuit - Test
1239-0	Engine Fuel Leakage 1: High - most severe (3)	Fuel Rail Pressure Problem
2659-15	Engine Exhaust Gas Recirculation (EGR) Mass Flow Rate : High - least severe (1)	ТВА
2791-3	Engine Exhaust Gas Recirculation (EGR) Valve Control : Voltage Above Normal	Motorized Valve - Test

J1939 Code	Description	Refer to Procedure
2791-5	Engine Exhaust Gas Recirculation (EGR) Valve Control : Current Below Normal	Motorized Valve - Test
2791-6	Engine Exhaust Gas Recirculation (EGR) Valve Control : Current Above Normal	Motorized Valve - Test
2791-7	Engine Exhaust Gas Recirculation (EGR) Valve Control : Not Responding Properly	Motorized Valve - Test
2882-2	Engine Alternate Rating Select : Erratic, Intermittent, or Incorrect	Mode Selection Circuit - Test
2970-2	Accelerator Pedal 2 Low Idle Switch : Erratic, Intermittent, or Incorrect	Idle Validation Switch Circuit - Test
3242-3	Particulate Trap Intake Gas Temperature : Voltage Above Normal	Engine Temperature Sensor Open or Short Circuit - Test (Active Sensors)
3242-4	Particulate Trap Intake Gas Temperature : Voltage Below Normal	Engine Temperature Sensor Open or Short Circuit - Test (Active Sensors)
3242-17	Particulate Trap Intake Gas Temperature : Low - least severe (1)	Diesel Particulate Filter Temperature Is High
3242-18	Particulate Trap Intake Gas Temperature : Low - moderate severity (2)	Diesel Particulate Filter Temperature Is Low
3358-3	Engine Exhaust Gas Recirculation Inlet Pressure : Voltage Above Normal	Engine Pressure Sensor Open or Short Circuit - Test
3358-4	Engine Exhaust Gas Recirculation Inlet Pressure : Voltage Below Normal	Engine Pressure Sensor Open or Short Circuit - Test
3358-13	Engine Exhaust Gas Recirculation Inlet Pressure : Calibration Required	Sensor Calibration Required - Test
3358-21	Engine Exhaust Gas Recirculation Inlet Pressure : Data Drifted Low	5 V Sensor Supply Circuit - Test
3509-3	Sensor Supply Voltage 1 : Voltage Above Normal	5 V Sensor Supply Circuit - Test
3509-4	Sensor Supply Voltage 1 : Voltage Below Normal	5 V Sensor Supply Circuit - Test
3510-3	Sensor Supply Voltage 2 : Voltage Above Normal	5 V Sensor Supply Circuit - Test
3510-4	Sensor Supply Voltage 2 : Voltage Below Normal	5 V Sensor Supply Circuit - Test
3563-3	Engine Intake Manifold #1 Absolute Pressure : Voltage Above Normal	Engine Pressure Sensor Open or Short Circuit - Test
3563-4	Engine Intake Manifold #1 Absolute Pressure : Voltage Below Normal	Engine Pressure Sensor Open or Short Circuit - Test
3563-13	Engine Intake Manifold #1 Absolute Pressure : Calibration Required	Sensor Calibration Required - Test
3563-21	Engine Intake Manifold #1 Absolute Pressure : Data Drifted Low	5 V Sensor Supply Circuit - Test
3719-0	Particulate Trap #1 Soot Load Percent : High - most severe (3)	Diesel Particulate Filter Collects Excessive Soot
3719-16	Particulate Trap #1 Soot Load Percent : High - moderate severity (2)	Diesel Particulate Filter Collects Excessive Soot
4783-3	Diesel Particulate Filter #1 Mean Soot Signal : Voltage Above Normal	Soot Sensor - Test
4783-4	Diesel Particulate Filter #1 Mean Soot Signal : Voltage Below Normal	Soot Sensor - Test

J1939 Code	Description	Refer to Procedure
4783-9	Diesel Particulate Filter #1 Mean Soot Signal : Abnormal Update Rate	Soot Sensor - Test
4783-12	Diesel Particulate Filter #1 Mean Soot Signal : Failure	Soot Sensor - Test
4783-13	Diesel Particulate Filter #1 Mean Soot Signal : Calibration Required	Soot Sensor - Test
4783-19	Diesel Particulate Filter #1 Mean Soot Signal : Data Error	Soot Sensor - Test
4783-21	Diesel Particulate Filter #1 Mean Soot Signal : Data Drifted Low	Soot Sensor - Test
5019-3	Engine Exhaust Gas Recirculation Outlet Pressure : Voltage Above Normal	Engine Pressure Sensor Open or Short Circuit - Test
5019-4	Engine Exhaust Gas Recirculation Outlet Pressure : Voltage Below Normal	Engine Pressure Sensor Open or Short Circuit - Test
5019-13	Engine Exhaust Gas Recirculation Outlet Pressure : Calibration Required	Sensor Calibration Required - Test
5019-21	Engine Exhaust Gas Recirculation Outlet Pressure : Data Drifted Low	5 V Sensor Supply Circuit - Test
5571-0	High Pressure Common Rail Fuel Pressure Relief Valve : Active	Fuel Rail Pressure Problem
5576-2	Aftertreatment #1 Identification Number Module : Erratic, Intermittent or incorrect	Diesel Particulate Filter Identification Signal - Test
5576-8	Aftertreatment #1 Identification Number Module : Abnormal Frequency, Pulse Width, or Period	Diesel Particulate Filter Identification Signal - Test
5576-14	Aftertreatment #1 Identification Number Module : Special Instruction	Diesel Particulate Filter Identification Signal - Test
5625-3	Exhaust Back Pressure Regulator Position : Voltage Above Normal	Valve Position Sensor - Test
5625-4	Exhaust Back Pressure Regulator Position : Voltage Below Normal	Valve Position Sensor - Test
5629-31	Particulate Trap Active Regeneration Inhibited Due To Low Exhaust Gas Pressure - least severe (1)	Diesel Particulate Filter Collects Excessive Soot

GROUP 12 ENGINE CONTROL SYSTEM

1. MCU and Engine ECM (Electronic Control Module)



2. MCU ASSEMBLY

1

3

- 1) To match the pump absorption torque with the engine torque, MCU varies EPPR valve output pressure, which control pump discharge amount whenever feedbacked engine speed drops under the reference rpm of each mode set.
- 2) Three LED lamps on the MCU display as below.

LED lamp	Trouble	Service
G is turned ON	Normal	-
G and R are turned ON	Trouble on MCU	Change the MCU
G and Y are turned ON	Trouble on serial	Check if serial communication
	communication line	lines between controller and cluster are
		disconnected
Three LED are turned OFF	Trouble on MCU power	\cdot Check if the input power wire (24 V, GND) of
		controller is disconnected
		Check the fuse

Y: yellow G: green, R:red,

GROUP 13 EPPR VALVE

1. PUMP EPPR VALVE

1) COMPOSITION

EPPR (Electro Proportional Pressure Reducing) valve consists of electro magnet and spool valve installed at main pump.

(1) Electro magnet valve

Receive electric current from MCU and move the spool proportionally according to the specific amount of electric current value.

(2) Spool valve

Is the two way direction control valve for pilot pressure to reduce main pump flow. When the electro magnet valve is activated, pilot pressure enters into flow regulator of main pump.

(3) Pressure and electric current value for each mode

Mode		Pressure		Electric current	Engine rpm
		kgf/cm ²	psi	(mA)	(at accel dial 10)
	Р	10	142	330 ± 30	1800 ± 50
Standard (Stage : 1.0)	S	15 ± 3	185 ± 40	400 ± 30	1700 ± 50
(etage : 1.0)	Е	20 ± 3	213 ± 40	500 ± 30	1600 ± 50
	Р	0	0	160 ± 30	1950 ± 50
Option (Stage : 2.0)	S	5 ± 3	71 ± 40	250 ± 30	1850 ± 50
	Е	10 ± 3	142 ± 40	400 ± 30	1700 ± 50

2) HOW TO SWITCH THE STAGE (1.0 \leftrightarrow 2.0) ON THE CLUSTER

You can switch the EPPR valve pressure set by selecting the stage $(1.0 \leftrightarrow 2.0)$.

- Management

 \cdot Service menu







2609A3CD130

· Power shift (standard/option) : Power shift pressure can be set by option menu.

3) OPERATING PRINCIPLE (pump EPPR valve)

(1) Structure







P Pilot oil supply line (pilot pressure)

- T Return to tank
- A Secondary pressure to flow regulator at main pump

(2) Neutral


Pressure line is blocked and A oil returns to tank.






(3) Operating

Secondary pressure enters into A.






4) EPPR VALVE CHECK PROCEDURE

(1) Check electric current value at EPPR valve

- ① Disconnect connector CN-75 from EPPR valve.
- ② Insert the adapter to CN-75 and install multimeter as figure.
- 3 Start engine.
- ④ Set S-mode and cancel auto decel mode.
- 5 Position the accel dial at 10.
- ⑥ If rpm display show approx 1700±50 rpm check electric current at bucket circuit relief position.




(2) Check pressure at EPPR valve

① Remove plug and connect pressure gauge as figure.

Gauge capacity : 0 to 50 kgf/cm²
(0 to 725 psi)

- ② Start engine.
- ③ Set S-mode and cancel auto decel mode.
- 4 Position the accel dial at 10.
- ⑤ If rpm display approx 1700±50 rpm check pressure at relief position of bucket circuit by operating bucket control lever.
- ⑥ If pressure is not correct, adjust it.
- ⑦ After adjust, test the machine.



2. BOOM PRIORITY EPPR VALVE

1) COMPOSITION


The boom priority EPPR valve is built in a manifold and mainly consisting of valve body and coil. This EPPR valve installed under the solenoid valve.

2) CONTROL

The boom priority EPPR valve has to be controlled by a specific electronic amplifier card, which is supplying the coil with a current 580 mA at 30 $_{\Omega}$ and 24 V.

3) OPERATING PRINCIPLE

(1) Structure



O-ring 1 2 Support ring

Т

4 Coil

- Connector 5
- 6 Cover cap

(2) Operation

In de-energized mode the inlet port (P) is closed and the outlet port (A) is connected to tank port (T).


In energized mode the solenoid armature presses onto the control spool with a force corresponding to the amount of current. This will set a reduced pressure at port A. The setting is proportional to the amount of current applied.

(3) Maximum pressure relief

If a pressure from outside is applied on port A the valve may directly switch to tank port (T) and protect the system before overload.


2) EPPR VALVE CHECK PROCEDURE

- (1) Check electric current value at EPPR valve
 - ① Disconnect connector CN-133 from EPPR valve.
 - ② Insert the adapter to CN-133 and install multimeter as figure.
 - ③ Start engine.
 - ④ If rpm display approx 1700±50 rpm check electric current in case of combined boom up and swing operation.



(2) Check pressure at EPPR valve

- ① Remove hose from A5 port and connect pressure gauge as figure.
 - Gauge capacity : 0 to 50 kgf/cm²
 (0 to 725 psi)
- ② Start engine.
- ③ If rpm display approx 1700±50 rpm check pressure at relief position of bucket circuit by operating bucket control lever.
- ④ If pressure is not correct, adjust it.
- (5) After adjust, test the machine.



GROUP 14 MONITORING SYSTEM

1. OUTLINE


Monitoring system consists of the monitor part and switch part.

The monitor part gives warnings when any abnormality occurs in the machine and informs the condition of the machine.

Various select switches are built into the monitor panel, which act as the control portion of the machine control system.

2. CLUSTER

1) MONITOR PANEL




145Z9A5MS14

* The warning lamp pops up and/or blinks and the buzzer sounds when the machine has a problem.

The warning lamp blinks until the problem is cleared. Refer to page 5-49 for details.

- » This cluster is adjustable.
 - \cdot Vertical (forward/backward) : each 15°
 - · Horizontal (left only) : 15°



2) CLUSTER CHECK PROCEDURE

(1) Start key : ON

① Check monitor

- a. Buzzer sounding for 4 seconds with HYUNDAI logo on cluster.
- * If the ESL mode is set to the enable, enter the password to start engine.
- ② After initialization of cluster, the operating screen is displayed on the LCD. Also, self diagnostic function is carried out.
 - a. Engine rpm display : 0 rpm
 - b. Engine coolant temperature gauge : White range
 - c. Hydraulic oil temperature gauge : White range
 - d. Fuel level gauge : White range

③ Indicating lamp state

- a. Power mode pilot lamp : E mode or U mode
- b. Work mode pilot lamp : General operation mode (bucket)
- c. Travel speed pilot lamp : Low (turtle)

(2) Start of engine

1 Check machine condition

- a. RPM display indicates at present rpm
- b. Gauge and warning lamp : Indicate at present condition.
- * When normal condition : All warning lamp OFF
- c. Work mode selection : General work
- d. Power mode selection : E mode or U mode
- e. Travel speed pilot lamp : Low (turtle)

② When warming up operation

- a. Warming up pilot lamp : ON
- b. After engine started, engine speed increases to1200 rpm.
- * Others same as above.


③ When abnormal condition

- a. The warning lamp lights up and the buzzer sounds.
- b. If BUZZER STOP switch is pressed, buzzer sound is canceled but the lamp warning lights up until normal condition.
- * The pop-up warning lamp moves to the original position and blink when the select switch is pushed. Also the buzzer stops.

3. CLUSTER CONNECTOR

No.	Name	Signal
1	Battery 24V	20~32V
2	Camera signal 3	NTSC
3	GND	-
4	Serial + (TX)	0~5V
5	Power IG (24V)	20~32V
6	Camera signal 2	NTSC
7	Camera signal 1	NTSC
8	Serial - (RX)	0~5V

* NTSC : the united states National Television System Committee



2) GAUGE

(1) Operation screen

When you first turn starting switch ON, the operation screen will appear.



- 1 Engine coolant temperature gauge
- 2 Hydraulic oil temperature gauge
- 3 Fuel level gauge
- 4 RPM / Tripmeter display
- ※ Operation screen type can be set by the screen type menu of the display. Refer to page 5-46 for details.

(2) Engine coolant temperature gauge



- $(\ensuremath{\underline{1}})$ This gauge indicates the temperature of coolant.
 - White range : 40-107°C (104-225°F)
 - \cdot Red range : Above 107°C (225°F)
- ② If the indicator is in the red range or \bigcirc lamp blinks in red, turn OFF the engine and check the engine cooling system.
- If the gauge indicates the red range or lamp blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

② If the indicator is in the red range or lamp blinks is red, reduce the load on the system. If the gauge stays in the red range, stop the machine and check the cause of the problem.

If the gauge indicates the red range or ill lamp blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor con-

1) This gauge indicates the temperature of hydraulic oil.

White range : 40-105°C(104-221°F)
 Red range : Above 105°C(221°F)

nection of electricity or sensor.

(3) Hydraulic oil temperature gauge



2609A3CD15

(4) Fuel level gauge




- ① This gauge indicates the amount of fuel in the fuel tank.
- \odot Fill the fuel when the red range, or $\ \begin{tabular}{c} \end{tabular}$ lamp blinks in red.
- If the gauge indicates the red range or not plane blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(5) RPM / Tripmeter display



This displays the engine speed or the tripmeter.
 Refer to page 5-49 for details.

3) WARNING LAMPS



Each warning lamp on the top of the LCD pops up on the center of LCD and the buzzer sounds when the each warning is happened. The pop-up warning lamp moves to the inal position and blinks when the select switch is pushed. And the buzzer stops. Refer to page 5-37 for the select switch.

(1) Engine coolant temperature warning lamp



- ① Engine coolant temperature warning is indicated two steps.
 - 103°C over : The 🕘 lamp blinks and the buzzer sounds.
 - 107°C over : The A lamp pops up on the center of LCD and the buzzer sounds.
- ② The pop-up <u>i</u> lamp moves to the original position and blinks when the select switch is pushed. Also, the buzzer stops and lamp keeps blink.
- ③ Check the cooling system when the lamp keeps ON.

(2) Hydraulic oil temperature warning lamp

21093CD08C

21093CD08A



- ① Hydraulic oil temperature warning is indicated two steps.
 - 100°C over : The 🕅 lamp blinks and the buzzer sounds.
 - 105°C over : The A lamp pops up on the center of LCD and the buzzer sounds.
- ② The pop-up <u>1</u> lamp moves to the original position and blinks when the select switch is pushed. Also, the buzzer stops and <u>3</u> lamp keeps blink.
- ③ Check the hydraulic oil level and hydraulic oil cooling system.

(3) Fuel level warning lamp



- 1 This warning lamp blinks and the buzzer sounds when the level of fuel is below 35 ℓ (9.2 U.S. gal).
- 0 Fill the fuel immediately when the lamp blinks.

21093CD08B


(4) Emergency warning lamp



① This lamp pops up and the buzzer sounds when each of the below warnings is happened.

- Engine coolant overheating (over 107°C)
- Hydraulic oil overheating (over 105°C)
- Pump EPPR circuit abnormal or open
- Attachment flow EPPR circuit abnormal or open
- MCU input voltage abnormal
- Accel dial circuit abnormal or open
- Cluster communication data error
- Engine ECM communication data error
- The pop-up warning lamp moves to the original position and blinks when the select switch is pushed. Also the buzzer stops. This is same as following warning lamps.
- 2 When this warning lamp blinks, machine must be checked and serviced immediately.

(5) Engine oil pressure warning lamp




- ① This lamp blinks when the engine oil pressure is low.
- ② If the lamp blinks, shut OFF the engine immediately. Check oil level.

(6) Check engine warning lamp



- ① This lamp blinks when the communication between MCU and engine ECM on the engine is abnormal, or if the cluster received any fault code from engine ECM.
- ② Check the communication line between them. If the communication line is OK, then check the fault codes on the cluster.

(7) Battery charging warning lamp



21093CD34


This lamp blinks when the battery charging voltage is low.
 Check the battery charging circuit when this lamp blinks.

(8) Air cleaner warning lamp



This lamp blinks when the filter of air cleaner is clogged.
 Check the filter and clean or replace it.

(9) Overload warning lamp (opt)



 When the machine is overload, the overload warning lamp blinks during the overload switch is ON. (if equipped)
 Reduce the machine load.

4) PILOT LAMPS

Work tool mode pilot lamp	
Work mode pilot lamp	—Travel speed pilot lamp
Power/User mode pilot lamp — 🗝 💏 🦙 🖓 🖓 👯 🖉 🛲 🦉 🚱 🍣 🖛 💻 —	— Auto idle pilot lamp
Power max pilot lamp	- Smart key pilot lamp
Preheat pilot lamp	- Entertainment pilot lamp
Warming up pilot lamp	 Maintenance pilot lamp
Decel pilot lamp	- Fuel warmer pilot lamp

2609A3CD22

(1) Mode pilot lamps

No	Mode	Pilot lamp	Selected mode
		Ρ	Heavy duty power work mode
1	Power mode	S	Standard power mode
		E	Economy power mode
2	User mode	U	User preferable power mode
		B	General operation mode
3	Work mode		Breaker operation mode
		4	Crusher operation mode
4	Traval made		Low speed traveling
4	Travel mode	*	High speed traveling
5	Auto idle mode	\bigcirc	Auto idle
6	Work tool mode	594	Oil flow level of breaker or crusher mode


(2) Power max pilot lamp




- The lamp will be ON when pushing power max switch on the LH RCV lever.
- 0 The power max function is operated maximum 8 seconds.
- * Refer to the operator's manual page 3-28 for power max function.

21093CD38

(3) Preheat pilot lamp



(4) Warming up pilot lamp




(5) Decel pilot lamp



- ① Turning the start key switch ON position starts preheating in cold weather.
- ② Start the engine after this lamp is OFF.
- 1 This lamp is turned ON when the coolant temperature is below 30°C(86°F).
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C, or when 10 minutes have passed since starting the engine.
- ① Operating one touch decel switch on the RCV lever makes the lamp ON.
- ② Also, the lamp will be ON and engine speed will be lowered automatically to save fuel consumption when all levers and pedals are at neutral position, and the auto idle function is selected.
- ※ One touch decel is not available when the auto idle pilot lamp is turned ON.
- * Refer to the operator's manual page 3-28.

(6) Fuel warmer pilot lamp



21093CD43

(7) Maintenance pilot lamp



2609A3CD23


- ① This lamp is turned ON when the coolant temperature is below $10^{\circ}C(50^{\circ}F)$ or the hydraulic oil temperature $20^{\circ}C(68^{\circ}F)$.
- ② The automatic fuel warming is cancelled when the engine coolant temperature is above 60°C, or the hydraulic oil temperature is above 45°C since the start switch was ON position.
- This lamp will be ON when the consuming parts are needed to change or replace. It means that the change or replacement interval of the consuming parts remains below 30 hours.
- ② Check the message in maintenance information of main menu. Also, this lamp lights ON for 3 minutes when the start switch is ON position.
- * Refer to the page 5-42.

(8) Entertainment pilot lamp



2609A3CD133


(9) Smart key pilot lamp (opt)



This lamp is on when MP3 or video files are playing.
 Refer to the page 5-48.

- $(\ensuremath{\textcircled{}})$ This lamp is ON when the engine is started by the start button.
- 2 This lamp is red when the a authentication fails, green when succeeds.
- * Refer to the page 5-44.


5) SWITCHES



2609A3CD24

When the switches are selected, the pilot lamps are displayed on the LCD. Refer to the page 5-52 for details.


(1) Power mode switch



① This switch is to select the machine power mode and selected power mode pilot lamp is displayed on the pilot lamp position.

- \cdot P : Heavy duty power work.
- · S : Standard power work.
- · E : Economy power work.
- (2) The pilot lamp changes $E \rightarrow S \rightarrow P \rightarrow E$ in order.

(2) Work mode switch



- This switch is to select the machine work mode, which shifts from general operation mode to optional attachment operation mode.
 - 👃 : General operation mode
 - · 🔊 : Breaker operation mode (if equipped)
 - $\cdot \quad \text{$\widehat{\mathbb{M}}$}$: Crusher operation mode (if equipped)
 - · Not installed : Breaker or crusher is not installed.
- * Refer to the operator's manual page 4-7 for details.

(3) User mode switch



2609A3CD27

(4) Select switch



21093CD45E

- This switch is used to memorize the current machine operating status in the MCU and activate the memorized user mode.
 - Memory : Push more than 2 seconds.
 - \cdot Action : Push within 2 seconds.
 - \cdot Cancel $$: Push this switch once more within 2 seconds.
- $(\ensuremath{\bigcirc}$ This switch is used to select or change the menu and input value.
- (2) Knob push
 - · Long (over 2 sec) : Return to the operation screen
 - \cdot Medium (0.5~2 sec) : Return to the previous screen
 - \cdot Short (below 0.5 sec) $\,:\,$ Select menu
- ③ Knob rotation
 - This knob changes menu and input value.
 - \cdot Right turning : Down direction / Increase input value
 - · Left turning : Up direction / Decreased input value

(5) Auto idle/ buzzer stop switch



- 1 This switch is used to activate or cancel the auto idle function.
 - Pilot lamp ON : Auto idle function is activated.
 - \cdot Pilot lamp OFF : Auto idle function is cancelled.
- ② The buzzer sounds when the machine has a problem. In this case, push this switch and buzzer stops, but the warning lamp blinks until the problem is cleared.

(6) Travel speed control switch



① This switch is used to select the travel speed alternatively.

: Low speed

(7) Escape/Camera switch



2609A3CD30

- This switch is used to return to the previous menu or parent menu.
- ② In the operation screen, pushing this switch will display the view of the camera on the machine (if equipped).
 Display refer to page 5.40 for the semara.
 - Please refer to page 5-49 for the camera.
- ③ If the camera is not installed, this switch is used only ESC function.

6) MAIN MENU

- You can select or set the menu by the select switch or touch screen (M).
 On the operation screen, tap M to access the main menu screen.
 On the sub menu screen, you can tap the menu bar to access functions or applications
 To return to the parent menu screen, tap the top menu bar. To return to operation screen, tap
 (1) icon.
- · Operation screen



* Please refer to select switch, page 5-56 for selection and change of menu and input value.

(1) Structure

No	Main menu	Sub menu	Description
1	Mode 2609A3CD33	Work tool U mode power Boom/Arm speed Auto power boost Initial mode	Breaker, Crusher, Not installed User mode only Boom speed, Arm speed Enable, Disable Default, U mode, P mode
2	Monitoring 2609A3CD34	Active fault Logged fault Delete logged fault Monitoring (analog) Monitoring (digital) Operating hours	MCU, Engine ECM MCU, Engine ECM All logged fault delete, Initialization canceled Machine information Switch status, Output status Operating hours for each mode
3	Management 2609A3CD35	Maintenance information Machine security Machine Information A/S phone number Service menu Clinometer	Replacement, Change interval oils and filters ESL mode setting, Password change Cluster, MCU, Engine, Machine A/S phone number, A/S phone number change grade Power shift, Hourmeter, Replacement history, Lock lever, Upgrade, EPPR current level Clinometer setting
4	Display 2609A3CD36	Display item Clock Brightness,Touch calibration Unit setup Language selection Screen type	Engine speed, Tripmeter A, Tripmeter B, Tripmeter C Clock Manual, Auto, Calibrating the touch screen Temperature, Pressure, Flow, Distance, Date format Korean, English, Chinese A type, B type
5	Utilities 2609A3CD37	Entertainment Tripmeter Camera FMT DMB	Play MP4, codec. 3 kinds (A, B, C) Number of active, Display order, Camera No. FMT setting DMB select, DAB select, Channel scan, Exit

(2) Mode setup

① Work tool



- · A : Select one installed optional attachment.
- · B : Max flow Set the maximum flow for the attachment.
 - Flow level Reduce the operating flow from maximum flow.
 - Breaker Max 7 steps, Reduced 10 lpm each step.
 - Crusher Max 4 steps, Reduced 20 lpm each step.
- * The flow level is displayed with the work mode pilot lamp.

2 U mode power



- Engine high idle rpm, auto idle rpm and pump torque (power shift) can be modulated and memorized separately in U-mode.
- · U-mode can be activated by user mode switch.

Step (∎)	Engine speed (rpm)	Idle speed (rpm)	Power shift (bar)
1	1400	800	0
2	1500	850	3
3	1600	900	6
4	1650	950	9
5	1700	1000	12
6	1750	1050	16
7	1800	1100 (auto decel)	20
8	1850	1150	26
9	1900	1200	32
10	1950	1250	38

* One touch decel & low idle : 1000 rpm

3 Boom/Arm speed



Boom Speed	
Control Type	Manua
Speed Setting	
Arm Speed	
Regeneration	Disabl

· Boom speed

- Control type

Manual - Boom up speed is fixed as set steps.

Auto - Boom up speed is automatically adjusted as working conditions by the MCU.

- Speed setting - Boom up speed is increased as much as activated steps.

Arm speed

Regeneration - Arm regeneration function can be activated or cancelled.
 Enable - Arm in speed is up.
 Disable - Fine operation.

④ Auto power boost



- · The power boost function can be activated or cancelled.
- $\cdot\,$ Enable The digging power is automatically increased as working conditions by the MCU. It is operated max 8 seconds.
- · Disable Not operated.
- 5 Initial mode



- $\cdot\,$ Default The initial power mode is set E mode when the engine is started.
- $\cdot\,$ U mode The initial power mode is set U mode when the engine is started.

(3) Monitoring

① Active fault



· The active faults of the MCU or engine ECM can be checked by this menu.

2 Logged fault



· The logged faults of the MCU or engine ECM can be checked by this menu.

③ Delete logged fault



- · The logged faults of the MCU or engine ECM can be deleted by this menu.
- (4) Monitoring(analog)



- $\cdot\,$ The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu.
- (5) **Monitoring** (digital)



- The switch status or output status can be confirmed by this menu.
- The activated switch or output pilot lamps 🌞 are light ON.

6 Operating hours



 $\cdot\,$ The operating hour of each mode can be confirmed by this menu.

(4) Management

1 Maintenance information



• Alarm(🔅 🔶 🌞) : Gray 🛛 🌣 - Normal Yellow 븢 - First warning Red

- 븆 Second warning
- · Replacement : The elapsed time will be reset to zero (0).
- Change interval : The change or replace interval can be changed in the unit of 50 hours. •
- : Return to the item list screen. · OK
- · Change or relpace interval

No	Item	Interval
1	Engine oil	500
2	Final gear oil	1000
3	Swing gear oil	1000
4	Hydraulic oil	5000
5	Pilot line filter	1000
6	Drain filter	1000
7	Hydraulic oil return filter	1000
8	Engine oil filter	500
9	Fuel filter	500
10	Pre-filter	500
11	Hydraulic tank breather	250
12	Air cleaner (inner & outer)	4000
13	Radiator coolant	2000
14	Swing gear pinion grease	1000

2 Machine security



1



2609A3CD76

5 minute

Disable

-

2609A3CD77

· ESL mode setting

- ESL : Engine Starting Limit
- ESL mode is desingned to be a theft deterrent or will prevent the unauthorized operation of the machine.
- If the ESL mode was selected Enable, the password will be required when the start switch is turned ON.
- Machine security

Disable : Not used ESL function

Enable (always) : The password is required whenever the operator starts engine.



2609A3CD78

- Interval : The password is required when the operator starts engine first. But the operator can restart the engine within the interval time without input-ting the password.

The interval time can be set maximum 4 hours. *** Default password : 00000 ***

% Password length : (5~10 digit) + *





2609A3CD138

- Smart key (option) : Smart key is registered when the operator starts engine by start button first. If smart key is not inside of the cabin, authentication process fails and the password entering is needed.





2609A3CD140



ł

2609A3CD145

· Password change

- The password is 5~10 digits.



2609A3CD79



Enter the current password 2609A3CD80




Enter the new password

¥








Enter the new password again

3 Machine Information



· This can confirm the identification of the cluster, MCU, engine and machine.

④ A/S phone number



2609A3CD89

The new phone number is stored in MCU

2609A3CD90

(5) Service menu



E Standard

2609A3CD130

- · Power shift (standard/option) : Power shift pressure can be set by option menu.
- · Hourmeter : Operating hours since the machine line out can be checked by this menu.
- · Replacement history : Replacement history of the MCU and cluster can be checked by this menu.
- · Lock level (not in use/in use)
- · Upgrade : Firm ware can be upgraded by this menu. (the USB port is located under the cluster)
- · EPPR current level (attach EPPR/boom priority EPPR)


6 Clinometer



- $\cdot\,$ When the machine is on the flatland, if tap the "initialization", the values of X, Y reset "0".
- $\cdot\,$ You can confirm tilt of machine in cluster's operating screen.

(5) Display

① Display item



- · The center display type of the LCD can be selected by this menu.
- The engine speed or each of the tripmeter (A,B,C) is displayed on the center display.




- $\cdot\,$ The first line's three spots "**/**/****" represent Month/Day/Year each.
- $\cdot\,$ The second line shows the current time. (0:00~23:59)

③ Brightness and touch calibration



- If "Auto" is chosen, brightness for day and night can be differently set up. Also by using the bar in lower side, users can define which time interval belongs to day and night. (in bar figure, white area represents night time while orange shows day time)
- Touch calibration When touch awareness goes wrong, this function use.

Fall in the next step if touches the middle point of cross with fingernail. If touches total five points as follows, the setting is completed.




· Date format : $yy/mm/dd \leftrightarrow mm/dd/yy \leftrightarrow dd-Mar-yy$

5 Language



· User can select preferable language and all displays are changed the selected language.

6 Screen type



(6) Utilities

- 1 Entertainment
- · Play MP4 or codec file of external hard disk through USB port.
- · The USB port is located under the cluster.



• Over 1100 engine rpm, the screen turns into the operation screen with MP4 or codec file playing for the safety.

2 Tripmeter



- · Maximum 3 kinds of tripmeters can be used at the same time.
- · Each tripmeter can be turned on by choosing "Start" while it also can be turned off by choosing "Stop".
- · If the tripmeter icon is activated in the operation screen, it can be controlled directly there.

③ Camera setting

- · Three cameras can be installed on the machine and the display order can be set by this menu.
- · If the camera was not equipped, this menu is not useful.



2609A3CD172

- · Turnning the select switch in clockwise direction, the next ordered will be shown and in counter-clockwise direction, the previously ordered will be shown.
- · Push the select switch, the displayed screen will be enlargement.





2609A3CD167



2609A3CD120

640



2609A3CD168

④ FMT setting



- The function that can listen cluster's occurrence sound by inside speaker of cabin making frequency of audio identical in cluster's frequency and machine.
- Turn on the FMT function and sets frequency equally with frequency of audio in cabin.
 - Not in use : Cluster speaker only
 - In use (FMT only) : Cabin speaker only
 - In use (FMT+Built) : Cabin speaker + Cluster speaker

(5) **DMB** (option)



GROUP 15 FUEL WARMER SYSTEM


1. SPECIFICATION


- 1) Operating voltage : $24 \pm 4 V$
- 2) Power : $350 \pm 50 \text{ W}$
- 3) Current : 15 A

2. OPERATION

- The current of fuel warmer system is automatically controlled without thermostat according to fuel temperature.
- At the first state, the 15 A current flows to the fuel warmer and engine may be started in 1~2 minutes.
- 3) If the fuel starts to flow, ceramic-disk in the fuel warmer heater senses the fuel temperature to reduce the current as low as 1.5 A.

So, fuel is protected from overheating by this mechanism.





3. ELECTRIC CIRCUIT

Group	1	Before Troubleshooting	6-1
Group	2	Hydraulic and Mechanical System	6-4
Group	3	Electrical System ·····	6-24
Group	4	Mechatronics System	6-40


GROUP 1 BEFORE TROUBLESHOOTING

1. INTRODUCTION

When a trouble is occurred in the machine, this section will help an operator to maintain the machine with easy.

The trouble of machine is parted Hydraulic & Mechanical system, Electrical system and Mechatronics system. At each system part, an operator can check the machine according to the troubleshooting process diagram.

* Before carring out troubleshooting procedure, check monitoring menu in the cluster.




2. DIAGNOSING PROCEDURE

To carry out troubleshooting efficiently, the following steps must be observed.

STEP 1. Study the machine system

Study and know how the machine is operating, how the system is composing, what kinds of function are installed in the machine and what are specifications of the system components by the machine service manual.

Especially, deepen the knowledge for the related parts of the trouble.



STEP 2. Ask the operator


Before inspecting, get the full story of malfunctions from a witness --- the operator.


- 1) How the machine is used and when it is serviced?
- 2) When the trouble was noticed and what work the machine was doing at that time?
- 3) What is the phenomenon of the trouble? Was the trouble getting worse, or did it come out suddenly for the first time?
- Did the machine have any troubles previously? If so, which parts were repaired before.

STEP 3. Inspect the machine

Before starting troubleshooting, check the machine for the daily maintenance points as shown in the operator's manual.

And also check the electrical system including batteries, as the troubles in the electrical system such as low battery voltage, loose connections and blown out fuses will result in malfunction of the controllers causing total operational failures of the machine.






STEP 4. Inspect the trouble actually on the machine


In case that some trouble cannot be confirmed, obtain the details of the malfunction from the operator.

Also, check if there are any in complete connections of the wire harnesses are or not.



STEP 5. Perform troubleshooting


According to where the trouble parts are located, hydraulic & mechanical system part or electrical system part or mechatronics system part, perform troubleshooting the machine refer to the each system part's troubleshooting process diagram.



STEP 6. Trace a cause

Before reaching a conclusion, check the most suspectible causes again. Try to trace what the real cause of the trouble is.

Make a plan of the appropriate repairing procedure to avoid consequential malfunctions.



GROUP 2 HYDRAULIC AND MECHANICAL SYSTEM


1. INTRODUCTION

1) MACHINE IN GENERAL

- (1) If even a minor fault is left intact and operation is continued, a fatal failure may be caused, entailing a large sum of expenses and long hours of restoration. Therefore when even a small trouble occurs, do not rely on your intuition and experience, but look for the cause based on the troubleshooting principle and perform maintenance and adjustment to prevent major failure from occurring. Keep in mind that a fault results from a combination of different causes.
- (2) The following lists up commonly occurring faults and possible causes with this machine. For the troubleshooting of the engine, refer to the coming troubleshooting and repair.
- (3) When carrying out troubleshooting, do not hurry to disassemble the components. It will become impossible to find the cause of the problem.
- (4) Ask user or operator the following.
- ① Was there any strange thing about machine before failure occurred?
- ② Under what conditions did the failure occur?
- ③ Have any repairs been carried out before the failure?
- (5) Check before troubleshooting.
- ① Check oil and fuel level.
- ② Check for any external leakage of oil from components.
- ③ Check for loose or damage of wiring and connections.

2) MACHINE STATUS MONITORING ON THE CLUSTER

(1) The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu.





Analog 2


3809A6HS01

(2) Specification


No.	Description	Specification	
Note 1	Pilot pump pressure	40 ⁺² bar	
Note 2	Swing pilot pressure	0~40 bar	
Note 3	Boom up pilot pressure	0~40 bar	
Note 4	Arm/bucket pilot pressure	0~40 bar	
Note 5	P1 pump control pressure	0~25 bar	
Note 6	P2 pump control pressure	0~25 bar	
Note 7	Pump 1 pressure	330 bar	

2. DRIVE SYSTEM

1) UNUSUAL NOISE COMES OUT OF PUMP CONNECTION




2) ENGINE STARTS BUT MACHINE DOES NOT OPERATE AT ALL




3. HYDRAULIC SYSTEM


1) HYDRAULIC OIL IS CLOUDY




2) HYDRAULIC OIL TEMPERATURE HAS RISEN ABNORMALLY



3) CAVITATION OCCURS WITH PUMP




4) HYDRAULIC OIL IS CONTAMINATED




4. SWING SYSTEM


1) BOTH LH AND RH SWING ACTIONS ARE IMPOSSIBLE




2) SWING SPEED IS LOW




3) SWING MOTION IS IMPOSSIBLE IN ONE DIRECTION



4) MACHINE SWINGS BUT DOES NOT STOP




5) THE SWING UNIT DRIFTS WHEN THE MACHINE IS AT REST ON A SLOPE




5. TRAVEL SYSTEM

1) TRAVEL DOES NOT FUNCTION AT ALL ON ONE SIDE




2) SPEED ON ONE SIDE FALLS AND THE MACHINE CURVES




3) MACHINE DOES NOT STOP ON A SLOPE


Machine is pulled forward as sprocket rotates during digging operation.



4) LH AND RH TRAVEL MOTIONS ARE IMPOSSIBLE




5) TRAVEL ACTION IS POWERLESS (travel only)



6) MACHINE RUNS RECKLESSLY ON A SLOPE


Travel brake valve	Cause	Remedy
(counterbalance valve) is faulty.		Disassemble and repair or replace.

7) MACHINE MAKES A CURVED TRAVEL OR DOES NOT TRAVEL AT ALL WHEN TRAVEL AND ATTACHMENT OPERATIONS ARE EXECUTED AT THE SAME TIME




6. ATTACHMENT SYSTEM


1) BOOM OR ARM ACTION IS IMPOSSIBLE AT ALL




2) BOOM, ARM OR BUCKET SPEED IS LOW




3) BOOM, ARM OR BUCKET CYLINDER EXTENDS OR CONTRACTS ITSELF AND ATTACHMENT FALLS




4) BOOM, ARM OR BUCKET POWER IS WEAK



5) ONLY BUCKET OPERATION IS TOTALLY IMPOSSIBLE




6) BOOM MAKES A SQUEAKING NOISE WHEN BOOM IS OPERATED




*** HOW TO CHECK INTERNAL BOOM CYLINDER LEAKAGE**

1. Lower the bucket teeth to the ground with bucket cylinder fully retracted and arm cylinder rod retracted almost in full.




 Disconnect hose (A) from rod side of boom cylinder and drain oil from cylinders and hose. (put cups on piping and hose ends)



3. Raise bucket OFF the ground by retracting the arm cylinder rod.

If oil leaks from piping side and boom cylinder rod is retracted there is an internal leak in the cylinder.


If no oil leaks from piping side and boom cylinder rod is retracted, there is an internal leak in the control valve.



GROUP 3 ELECTRICAL SYSTEM


1. WHEN STARTING SWITCH IS TURNED ON, MONITOR PANEL DISPLAY DOES NOT APPEAR

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse No.6 and 9 burnt out.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check voltage


YES	20~32V	
NO	0V	



140Z96ES01


2. COMMUNICATION ERROR FLASHES ON THE CLUSTER (HCESPN 840, FMI 2)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check voltage


YES	2V	
NO	0V	



140Z96ES02


3. [--+] BATTERY CHARGING WARNING LAMP LIGHTS UP(Starting switch : ON)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check voltage


YES	20~32V	
NO	0V	



145Z9A6ES01


4. 4. WHEN COOLANT OVERHEAT WARNING LAMP LIGHTS UP (engine is started)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






Check Table						
Temperature (°C)	0	25	50	80	95	
Resistance (k Ω)	30~37	9.3~10.7	3.2~3.8	1.0~1.3	0.7~0.8	



145Z9A6ES03


5. 🕑 WHEN AIR CLEANER WARNING LAMP LIGHTS UP (engine is started)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check resistance


YES	MAX 1Ω	
NO	MIN 1MΩ	




21096ES05

6. WHEN ENGINE OIL PRESSURE WARNING LAMP LIGHTS UP (engine is started)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- \cdot Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






145Z9A6ES04

7. UNIT WHEN HYDRAULIC OIL TEMPERATURE WARNING LAMP LIGHTS UP (engine is started)


- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.





Check Table


Temperature (°C)	~ -30	~ -10	~ 0	~ 40	~ 70	~ 80	~ 90	~ 100	105~
Resistance (k Ω)		8.16 ~10.74							0.164 0.151



21096ES07


8. WHEN COOLANT TEMPERATURE GAUGE DOES NOT OPERATE (HCESPN 304, FMI 3 or 4)

- · Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






Check Table							
Temperature (°C)	0	25	50	80	95		
Resistance (k Ω)	30~37	9.3~10.7	3.2~3.8	1.0~1.3	0.7~0.8		



145Z9A6ES03


9. WHEN FUEL GAUGE DOES NOT OPERATE(HCESPN 301, FMI 3 or 4)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






Check Table						
Range	Range Resistance (Ω)		Resistance (Ω)			
Full	50	5/12	400			
11/12	100	4/12	450			
10/12	150	3/12	500			
9/12	200	2/12	550			
8/12	250	1/12	600			
7/12	300	Empty warning	700			
6/12	350	-	-			




21096ES09

10. WHEN SAFETY SOLENOID DOES NOT OPERATE

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse No.26 burnt out.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







140Z96ES10

11. WHEN TRAVEL SPEED 1, 2 DOES NOT OPERATE (HCESPN 167, FMI 5 or 6)

- · Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse
 No.24 burnt out.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






140Z96ES11


12. WHEN ENGINE DOES NOT START (______ lights up condition)

 \cdot Before disconnecting the connector, always turn the starting switch OFF.

• Before carrying out below procedure, check all the related connectors are properly inserted and fuse No. 1, 4, 12 and 14 burnt out.

· After checking, insert the disconnected connectors again immediately unless otherwise specified.







145Z9A6ES05

13. WHEN STARTING SWITCH ON DOES NOT OPERATE

- · Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted, master switch ON and check open circuit of fusible link (CN-60).
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






145Z9A6ES06


14. WHEN STARTING SWITCH IS TURNED ON, WIPER MOTOR DOES NOT OPERATE

· Before disconnecting the connector, always turn the starting switch OFF.

 Before carrying out below procedure, check all the related connectors are properly inserted and fuse No. 5, 10 and 15 burnt out.

· After checking, insert the disconnected connectors again immediately unless otherwise specified.








140Z96ES14

15. WHEN STARTING SWITCH IS TURNED ON, HEAD LAMP DOES NOT LIGHTS UP

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse
 No.16 burnt out.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.










145Z9A6ES07

16. WHEN STARTING SWITCH IS TURNED ON, WORK LAMP DOES NOT LIGHTS UP

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse
 No.17 burnt out.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.








GROUP 4 MECHATRONICS SYSTEM


1. ALL ACTUATORS SPEED ARE SLOW

- * Boom, Arm, Bucket, Swing and travel speed are slow, but engine speed is good.
- * Spec : P-mode 1800 \pm 50 rpm S -mode 1700 \pm 50 rpm E-mode 1600 \pm 50 rpm
- * Before carrying out below procedure, check all the related connectors are properly inserted and fault code on the cluster.

1) INSPECTION PROCEDURE




Wiring diagram



145Z9A6MS01


- (1) Test 1 : Check resistance at connector CN-75.
- ① Starting key OFF.
- ② Disconnect connector CN-75 from EPPR valve at main hydraulic pump.
- ③ Check resistance between 2 lines as figure.




- (2) Test 2 : Check electric current at EPPR valve.
- Disconnect connector CN-75 from EPPR valve.
- ② Insert the adapter to CN-75 and install multimeter as figure.
- ③ Start engine.
- ④ Set S-mode and cancel auto decel mode.
- (5) Position the accel dial at 10.
- (6) If tachometer show approx 1700±50 rpm disconnect one wire harness from EPPR valve.
- ⑦ Check electric current at bucket circuit relief position.
- (3) Test 3 : Check pressure at EPPR valve.
 - Remove plug and connect pressure gauge as figure.
 - \cdot Gauge capacity : 0 to 50 kgf/cm²

(0 to 710 psi)

- ② Start engine.
- ③ Set S-mode and cancel auto decel mode.
- 4 Position the accel dial at 10.
- ⑤ If tachometer show approx 1700±50 rpm check pressure at relief position of bucket circuit by operating bucket control lever.
- ⑥ If pressure is not correct, adjust it.
- \bigodot After adjust, test the machine.







2. ENGINE STALL

* Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram





145Z9A6MS01

- (1) Test 4 : Check electric current at EPPR valve.
 - ① Disconnect connector CN-75 from EPPR valve.
 - ② Insert the adapter to CN-75 and install multimeter as figure.
 - ③ Start engine.
 - 4 Set S-mode and cancel auto decel mode.
 - (5) Position the accel dial at 10.
 - ⑥ If tachometer show approx 1700±50 rpm disconnect one wire harness from EPPR valve.
 - ⑦ Check electric current at bucket circuit relief position.

(2) Test 5 : Check pressure at EPPR valve.

- ① Remove plug and connect pressure gauge as figure.
 - \cdot Gauge capacity : 0 to 50 kgf/cm²
 - (0 to 710 psi)
- Start engine.
- 3 Set S-mode and cancel auto decel mode.
- 4 Position the accel dial at 10.
- ⑤ If tachometer show approx 1700±50 rpm check pressure at relief position of bucket circuit by operating bucket control lever.
- 6 If pressure is not correct, adjust it.
- ⑦ After adjust, test the machine.







3. MALFUNCTION OF CLUSTER OR MODE SELECTION SYSTEM

* Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram





140Z96MS03

4. MALFUNCTION OF ACCEL DIAL

* Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE





21096MS04


- (1) Test 6 : Check voltage at CN-52(21) and ground.
- Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (21) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




5. AUTO DECEL SYSTEM DOES NOT WORK

- Fault code : HCESPN 105, FMI 0~4 (work pressure sensor) HCESPN 108, FMI 0~4 (travel oil pressure sensor)
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 7 : Check voltage at CN-52(26) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (26) of CN-52.
- ③ Starting key ON.
- ④ Check voltage as figure.
- (2) Test 8 : Check voltage at CN-52(35) and ground.
- Prepare 1 piece of thin sharp pin, steel or copper
- ② Insert prepared pin to rear side of connectors : One pin to (35) of CN-52.
- ③ Starting key ON.
- ④ Check voltage as figure.




6. MALFUNCTION OF PUMP 1 PRESSURE SENSOR

- · Fault code : HCESPN 120, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 9 : Check voltage at CN-52(29) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (29) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




7. MALFUNCTION OF PUMP 2 PRESSURE SENSOR

- · Fault code : HCESPN 121, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 10 : Check voltage at CN-52(38) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (38) of CN-52.
- 3 Starting key ON.
- 4 Check voltage as figure.




8. MALFUNCTION OF PUMP 3 PRESSURE SENSOR

- · Fault code : HCESPN 125, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 11 : Check voltage at CN-52(36) and ground.
- Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (36) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




9. MALFUNCTION OF NEGATIVE 1 PRESSURE SENSOR

- · Fault code : HCESPN 123, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 12 : Check voltage at CN-52(37) and ground.
- Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (37) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




10. MALFUNCTION OF NEGATIVE 2 PRESSURE SENSOR

- · Fault code : HCESPN 124, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 13 : Check voltage at CN-52(27) and ground.
- Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (27) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




11. MALFUNCTION OF SWING PRESSURE SENSOR

- · Fault code : HCESPN 135, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 14 : Check voltage at CN-52(24) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (24) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




12. MALFUNCTION OF ARM IN/OUT & BUCKET IN PRESSURE SENSOR

- · Fault code : HCESPN 133, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 15 : Check voltage at CN-52(25) and ground.
- Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (25) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




13. MALFUNCTION OF BOOM UP PRESSURE SENSOR

- · Fault code : HCESPN 127, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE




Wiring diagram



2) TEST PROCEDURE


- (1) Test 16 : Check voltage at CN-52(23) and ground.
- Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (23) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




14. MALFUNCTION OF POWER MAX

- · Fault code : HCESPN 166, FMI 5 or 6
- * Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE




Wiring diagram




145Z9A6MS02

2) TEST PROCEDURE

- (1) Test 17: Check voltage between connector CN-88(2) - GND.
- ① Disconnect connector CN-88 from power max solenoid valve.
- ② Start key ON.
- ③ Check voltage as figure.




- (2) Test 18: Check resistance of the solenoid valve between CN-88(1)-(2).
- Starting key OFF.
- ② Disconnect connector CN-88 from power max solenoid valve.
- $\ensuremath{\textcircled{}}$ 3 Check resistance as figure.




15. MALFUNCTION OF BOOM PRIORITY EPPR VALVE

- · Fault code : HCESPN 141, FMI 5 or 6
- * Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram




21096MS15


16. MALFUNCTION OF ARM REGENERATION SOLENOID

- · Fault code : HCESPN 170, FMI 5 or 6
- * Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE




Wiring diagram



140Z96MS16

2) TEST PROCEDURE

- (1) Test 19 : Check voltage at CN-52(1) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (1) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.



Group	1	Operational Performance Test	7-1
Group	2	Major Components	7-21
Group	3	Track and Work Equipment	7-29

SECTION 7 MAINTENANCE STANDARD

GROUP 1 OPERATIONAL PERFORMANCE TEST

1. PURPOSE

Performance tests are used to check:

1) OPERATIONAL PERFORMANCE OF A NEW MACHINE

Whenever a new machine is delivered in parts and reassembled at a customer's site, it must be tested to confirm that the operational performance of the machine meets Hyundai spec.


2) OPERATIONAL PERFORMANCE OF A WORKING MACHINE

With the passage of time, the machine's operational performance deteriorates, so that the machine needs to be serviced periodically to restore it to its original performance level.

Before servicing the machine, conduct performance tests to check the extent of deterioration, and to decide what kind of service needs to be done(by referring to the "Service Limits" in this manual).

3) OPERATIONAL PERFORMANCE OF A REPAIRED MACHINE

After the machine is repaired or serviced, it must be tested to confirm that its operational performance was restored by the repair and/or service work done.




140Z97MS01

2. TERMINOLOGY


1) STANDARD

Specifications applied to the brand-new machine, components and parts.



2) SERVICE LIMIT

The lowest acceptable performance level. When the performance level of the machine falls below this level, the machine must be removed from work and repaired. Necessary parts and components must be replaced.



3. OPERATION FOR PERFORMANCE TESTS

1) Observe the following rules in order to carry out performance tests accurately and safely.


(1) The machine

Repair any defects and damage found, such as oil or water leaks, loose bolts, cracks and so on, before starting to test.

- (2) Test area
- 1 Select a hard, flat surface.
- ② Secure enough space to allow the machine to run straight more than 20m, and to make a full swing with the front attachment extended.
- ③ If required, rope off the test area and provide signboards to keep unauthorized personnel away.
- (3) Precautions
- Before starting to test, agree upon the signals to be employed for communication among coworkers. Once the test is started, be sure to communicate with each other using these signals, and to follow them without fail.
- ② Operate the machine carefully and always give first priority to safety.
- ③ While testing, always take care to avoid accidents due to landslides or contact with high voltage power lines. Always confirm that there is sufficient space for full swings.
- ④ Avoid polluting the machine and the ground with leaking oil. Use oil pans to catch escaping oil. Pay special attention to this when removing hydraulic pipings.

(4) Make precise measurements

- ① Accurately calibrate test instruments in advance to obtain correct data.
- ② Carry out tests under the exact test conditions prescribed for each test item.
- ③ Repeat the same test and confirm that the test data obtained can be procured repeatedly.Use mean values of measurements if necessary.



(290-7TIER) 7-3

2) ENGINE SPEED


- (1) Measure the engine speed at each power mode
- ** The engine speed at each power mode must meet standard RPM; if not, all other operational performance data will be unreliable. It is essential to perform this test first.

(2) Preparation

- ① Warm up the machine, until the engine coolant temperature reaches 50°C or more, and the hydraulic oil is 50±5°C.
- ② Set the accel dial at 10 (Max) position.
- ③ Measure the engine RPM.

(3) Measurement

- Start the engine. The engine will run at start idle speed. Measure engine speed with a engine rpm display.
- ② Measure and record the engine speed at each mode (P, S, E).
- ③ Select the P-mode.
- ④ Lightly operate the bucket control lever a few times, then return the control lever to neutral; The engine will automatically enter the auto-idle speed after 4 seconds.
- ⑤ Measure and record the auto deceleration speed.



(4) Evaluation

The measured speeds should meet the following specifications.

Unit : rpm

Model	Engine speed	Standard	Remarks
	Start idle	1000±100	
	P mode	1800±50	
	S mode	1700±50	
R125LCR-9A	E mode	1600±50	
	Auto decel	1100±100	
	One touch decel	1000±100	

Condition : Set the accel dial at 10 (Max) position.

3) TRAVEL SPEED

(1) Measure the time required for the excavator to travel a 20 m test track.

(2) Preparation

- ① Adjust the tension of both tracks to be equal.
- ② Prepare a flat and solid test track 20m in length, with extra length of 3 to 5 m on both ends for machine acceleration and deceleration.
- ③ Hold the bucket 0.3 to 0.5 m above the ground with the arm and bucket rolled in.
- (4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- ① Measure both the low and high speeds of the machine.
- ② Before starting either the low or high speed tests, adjust the travel mode switch to the speed to be tested, then select the following switch positions.
- · Power mode switch : P mode
- ③ Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- ④ Measure the time required to travel 20 m.
- ⑤ After measuring the forward travel speed, turn the upperstructure 180° and measure the reverse travel speed.
- 6 Repeat steps ④ and ⑤ three times in each direction and calculate the average values.


(4) Evaluation

The average measured time should meet the following specifications.


Unit : Seconds / 20 m

125LCR9A7MS05

Model	Travel speed	Standard	Maximum allowable	Remarks
R125LCR-9A	1 Speed	19.7±2.0	2.5	
	2 Speed	12.2±1.0	15.7	



125LCR9A7MS04



4) TRACK REVOLUTION SPEED

(1) Measure the track revolution cycle time with the track raised off ground.

(2) Preparation

- Adjust the tension of both side tracks to be equal.
- ② On the track to be measured, mark one shoe with chalk.
- ③ Swing the upperstructure 90° and lower the bucket to raise the track off ground. Keep the boom-arm angle between 90 to 110° as shown. Place blocks under machine frame.
- (4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.


(3) Measurement

- 1 Select the following switch positions.
- · Travel mode switch : 1 or 2 speed
- · Power mode switch : P mode
- · Auto idle switch : OFF
- ② Operate the travel control lever of the raised track in full forward and reverse.
- ③ Rotate 1 turn, then measure time taken for next 3 revolutions.
- ④ Raise the other side of machine and repeat the procedure.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.

(4) Evaluation

The revolution cycle time of each track should meet the following specifications.

		l	Init : Seconds / 3 revolutions
Model	Travel speed	Standard	Maximum allowable
	1 Speed	20.5±2.0	27.5
R125LCR-9A	2 Speed	12.6±2.0	17.6



125LCR9A7MS06

5) TRAVEL DEVIATION

 Measure the deviation by the tracks from a 20m straight line.

(2) Preparation

- ① Adjust the tension of both tracks to be equal.
- ② Provide a flat, solid test yard 20 m in length, with extra length of 3 to 5 m on both ends for machine acceleration and deceleration.
- ③ Hold the bucket 0.3 to 0.5 m above the ground with the arm and bucket rolled in.
- (4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement


- ① Measure the amount of mistracking at high and low travel speeds.
- ② Before beginning each test, select the following switch positions.
- · Power mode switch : P mode
- ③ Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- ④ Measure the distance between a straight
 20 m line and the track made by the machine. (Dimension a)
- ⑤ After measuring the tracking in forward travel, turn the upperstructure 180° and measure that in reverse travel.
- 6 Repeat steps ④ and ⑤ three times and calculate the average values.

(4) Evaluation

Mistrack should be within the following specifications.

Unit:mm/20m

Model	Standard	Maximum allowable	Remarks
R125LCR-9A	200 below	240	



6) SWING SPEED

(1) Measure the time required to swing three complete turns.

(2) Preparation

- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- ③ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- (4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- ① Select the following switch positions.
- · Power mode switch : P mode
- ② Operate swing control lever fully.
- ③ Swing 1 turn and measure time taken to swing next 3 revolutions.
- ④ Repeat steps ② and ③ three time and calculate the average values.

(4) Evaluation

The time required for 3 swings should meet the following specifications.

125LCR9A7MS07

		l	Jnit : Seconds / 3 revolutions	_
Model	Power mode switch	Standard	Maximum allowable	
R125LCR-9A	P mode	14.3±1.5	17.4	

7) SWING FUNCTION DRIFT CHECK

 Measure the swing drift on the bearing outer circumference when stopping after a 360° full speed swing.

(2) Preparation


- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- ③ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- ④ Make two chalk marks: one on the swing bearing and one directly below it on the track frame.
- 5 Swing the upperstructure 360°.
- (6) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement


- 1 Conduct this test in the M mode.
- ② Select the following switch positions.
- Power mode switch : P mode
- ③ Operate the swing control lever fully and return it to the neutral position when the mark on the upperstructure aligns with that on track frame after swinging 360°
- ④ Measure the distance between the two marks.
- ⑤ Align the marks again, swing 360°, then test the opposite direction.
- 6 Repeat steps ④ and ⑤ three times each and calculate the average values.

(4) Evaluation

The measured drift angle should be within the following specifications.



125LCR9A7MS07



Unit : Degree

Model	Power mode switch	Standard	Maximum allowable	Remarks
R125LCR-9A	P mode	90 below	157.5	

7-9

8) SWING BEARING PLAY

 Measure the swing bearing play using a dial gauge to check the wear of bearing races and balls.

(2) Preparation


- ① Check swing bearing mounting cap screws for loosening.
- ② Check the lubrication of the swing bearing. Confirm that bearing rotation is smooth and without noise.
- ③ Install a dial gauge on the track frame as shown, using a magnetic base.
- ④ Position the upperstructure so that the boom aligns with the tracks facing towards the front idlers.
- ⑤ Position the dial gauge so that its needle point comes into contact with the bottom face of the bearing outer race.
- 6 Bucket should be empty.

(3) Measurement

- With the arm rolled out and bucket rolled in, hold the bottom face of the bucket to the same height of the boom foot pin. Record the dial gauge reading (h1).
- ② Lower the bucket to the ground and use it to raise the front idler 50cm.
 Descend the dist recurse reading. (b0)
 - Record the dial gauge reading (h2).
- ③ Calculate bearing play (H) from this data (h1 and h2) as follows.
 H=h2-h1


(4) Evaluation

The measured drift should be within the following specifications.




(210-7) 7-10(1)





Measurement : (h2)



125LCR9A7MS09

Unit : mm

Model	Model Standard		Remarks
R125LCR-9A 0.5 ~ 1.5		3.0	

9) HYDRAULIC CYLINDER CYCLE TIME

(1) Measure the cycle time of the boom, standard arm, and standard bucket cylinders.

(2) Preparation

① To measure the cycle time of the boom cylinders:

With the arm rolled out and the empty bucket rolled out, lower the bucket to the ground, as shown.

② To measure the cycle time of the arm cylinder.

With the empty bucket rolled in, position the arm so that it is vertical to the ground. Lower the boom until the bucket is 0.5 m above the ground.

③ To measure the cycle time of the bucket cylinder.

The empty bucket should be positioned at midstroke between roll-in and roll-out, so that the sideplate edges are vertical to the ground.

(4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.


(3) Measurement

- ① Select the following switch positions.
- · Power mode switch : P mode
- 0 To measure cylinder cycle times.
 - Boom cylinders.

Measure the time it takes to raise the boom, and the time it takes to lower the boom. To do so, position the boom at one stroke end then move the control lever to the other stroke end as quickly as possible.

- Arm cylinder.

Measure the time it takes to roll in the arm, and the time it takes to roll out the arm. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.



125LCR9A7MS10

-Bucket cylinders

Measure the time it takes to roll in the bucket, and the time it takes to roll out the bucket. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.

- Repeat each measurement 3 times and calculate the average values.

(4) Evaluation

The average measured time should meet the following specifications.

Unit : Seconds

Model	Functior	1	Standard	Maximum allowable	Remarks
	Boom raise		2.9±0.4	3.8	
	Boom lower		2.5±0.4	3.6	
	Arm in	Regen ON	2.6±0.4	4.1	
R125LCR-9A		Regen OFF	2.9±0.4	3.9	
	Arm out		$2.3 {\pm} 0.3$	4.3	
	Bucket in		3.2±0.4	4.1	
	Bucket out		2.0±0.3	2.6	

10) DIG FUNCTION DRIFT CHECK


 Measure dig function drift, which can be caused by oil leakage in the control valve and boom, standard arm, and standard bucket cylinders, with the loaded bucket.
 When testing the dig function drift just after cylinder replacement, slowly operate each cylinder to its stroke end to purge air.

(2) Preparation

- Load bucket fully. Instead of loading the bucket, weight(W) of the following specification can be used.
- W=M³×1.5 Where :
 - M³ = Bucket heaped capacity (m³)
 - 1.5=Soil specific gravity
- ② Position the arm cylinder with the rod 20 to 30mm extended from the fully retracted position.
- ③ Position the bucket cylinder with the rod
 20 to 30mm retracted from the fully extended position.
- ④ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin.
- (5) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- ① Stop the engine.
- ② Five minutes after the engine has been stopped, measure the changes in the positions of the boom, arm and bucket cylinders.
- ③ Repeat step ② three times and calculate the average values.
- (4) The measured drift should be within the following specifications.



125LCR9A7MS11

Unit	÷	mm /	5min
0.110			0

Model	Drift to be measured	Standard	Maximum allowable	Remarks
	Boom cylinder	10 below	20	
R125LCR-9A	Arm cylinder	10 below	20	
	Bucket cylinder	40 below	50	

11) CONTROL LEVER OPERATING FORCE

 Use a spring scale to measure the maximum resistance of each control lever at the middle of the grip.

(2) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- 1 Start the engine.
- O Select the following switch positions.
- Power mode switch: P mode
- ③ Operate each boom, arm, bucket and swing lever at full stroke and measure the maximum operating force for each.
- ④ Lower the bucket to the ground to raise one track off the ground. Operate the travel lever at full stroke and measure the maximum operating force required. When finished, lower the track and then jack-up the other track.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.

(4) Evaluation

The measured operating force should be within the following specifications.

Unit : kgf

Madal	Kingl of lower	Otorealowel	Maximum allaurable	Demerles
Model	Kind of lever	Standard	Maximum allowable	Remarks
	Boom lever	1.7 or below	2.0	
	Arm lever	1.7 or below	2.0	
R125LCR-9A	Bucket lever	1.4 or below	2.0	
	Swing lever	1.4 or below	2.0	
	Travel lever	2.1 or below	3.15	

12) CONTROL LEVER STROKE

- (1) Measure each lever stroke at the lever top using a ruler.
- When the lever has play, take a half of this value and add it to the measured stroke.

(2) Preparation

Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- 1 Stop the engine.
- ② Measure each lever stroke at the lever top from neutral to the stroke end using a ruler.
- ③ Repeat step ② three times and calculate the average values.

(4) Evaluation

The measured drift should be within the following specifications.

Unit : mm Remarks Model Kind of lever Standard Maximum allowable 134 Boom lever 112 ± 10 Arm lever 112 ± 10 134 R125LCR-9A Bucket lever 90 ± 10 112 Swing lever 90 ± 10 112 Travel lever 139 ± 10 178

13) PILOT PRIMARY PRESSURE

(1) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- Select the following switch positions.
- · Power mode switch : P mode
- · Auto decel switch : OFF
- ② Measure the primary pilot pressure by the monitoring menu of the cluster.

(3) Evaluation

The average measured pressure should meet the following specifications:

140Z97MS12

				Unit : kgf / cm ²
Model	Engine speed	Standard	Allowable limits	Remarks
R125LCR-9A	P mode	40 ⁺² ₀	-	

Coupling

Cluster

Со

Main pump

Monitoring (analog)

14) FOR TRAVEL SPEED SELECTING PRESSURE:

(1) Preparation

- ① Stop the engine.
- ② Loosen the cap and relieve the pressure in the tank by pushing the top of the air breather.
- ③ To measure the speed selecting pressure: Install a connector and pressure gauge assembly to turning joint P port as shown.
- ④ Start the engine and check for on leakage from the adapter.
- (5) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

 Select the following switch positions. Travel mode switch : 1 speed

2 speed


- Mode selector : P mode
- ② Measure the travel speed selecting pressure in the Hi or Lo mode.
- ③ Repeat step ② three times and calculate the average values.

(3) Evaluation

The average measured pressure should be within the following specifications.

Unit : kgf / cm²

Model	Travel speed mode	Standard	Maximum allowable	Remarks
R125LCR-9A	1 Speed	0	-	
	2 Speed	40±5	-	



21077MS13

15) SWING PARKING BRAKE RELEASING PILOT PRESSURE

(1) Preparation

- ① Stop the engine.
- ② Loosen the cap and relieve the pressure in the tank by pushing the top of the air breather.
- ③ The pressure release L wrench to bleed air.
- ④ Install a connector and pressure gauge assembly to swing motor SH port, as shown.
- ⑤ Start the engine and check for oil leakage from the adapter.
- (6) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.


(2) Measurement

- Select the following switch positions.
- Power mode switch : P mode
- ② Operate the swing function or arm roll in function and measure the swing brake control pressure with the brake disengaged. Release the control lever to return to neutral and measure the control pressure when the brake is applied.
- ③ Repeat step ② three times and calculate the average values.

(3) Evaluation

The average measured pressure should be within the following specifications.

				Unit : kgf / cm ²
Model	Description	Standard	Allowable limits	Remarks
R125LCR-9A	Brake disengaged	40	Over 9	
TTZ3EOTESA	Brake applied	0	-	



125LCR9A7MS14


16) MAIN PUMP DELIVERY PRESSURE

(1) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

-) Select the following switch positions.
- Power mode switch : P mode
- ② Measure the main pump delivery pressure in the P mode (high idle).



(3) Evaluation

The average measured pressure should meet the following specifications.

Unit: kgf/cm²

Model	Engine speed	Standard	Allowable limits	Remarks
R125LCR-9A	High idle	40 ⁺² ₀	-	


17) SYSTEM PRESSURE REGULATOR RELIEF SETTING

(1) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- Select the following switch positions.
- Power mode switch : P mode
- ② Slowly operate each control lever of boom, arm and bucket functions at full stroke over relief and measure the pressure.
- ③ In the swing function, place bucket against an immovable object and measure the relief pressure.
- ④ In the travel function, lock undercarriage with an immovable object and measure the relief pressure.



140Z97MS15

(3) Evaluation


The average measured pressure should be within the following specifications.

	-		Unit : kgf / cm ²
Model	Function to be tested	Standard	Port relief setting at 20 lpm
	Boom, Arm, Bucket	330 (360)±10	380±10
R125LCR-9A	Travel	330±10	-
	Swing	285±10	-

(): Power boost

GROUP 2 MAJOR COMPONENT

1. MAIN PUMP



Part name & i	nspection item	Standard dimension	Recommended replacement value	Counter measures
Clearance between piston (1) & cylinder bore (2) (D-d)		0.032	0.056	Replace piston or cylinder.
Play between piston (1) & shoe caulking section (3) $(\delta$)		0-0.1	0.3	Replace assembly of
Thickness of shoe (t)		3.9	3.7	piston & shoe.
Free height of cylinder spring (4) (L)		41.1	40.3	Replace cylinder spring.
Combined height of set plate (5) (H) & spherical bushing (6) (h) (H-h)	h H	17.0	15.8	Replace set plate or spherical bushing.
Surface roughness for valve plate (Sliding face) (7,8), swash plate (shoe plate	Surface roughness necessary to be corrected	3	Z	Lourier
area) (9), & cylinder (2) (Sliding face)	Standard surface roughness (Corrected value)	0.4z o	r lower	Lapping

2. MAIN CONTROL VALVE

Part name	Inspection item	Criteria & measure
Casing	Existence of scratch, rusting or corrosion.	 In case of damage in following section, replace part.
		 Sliding sections of casing fore and spool, especially land sections applied with holded pressure. Seal pocket section where spool is inserted. Seal section of port where O-ring contacts. Seal section of each relief valve for main, travel, and port. Other damages that may damage normal functions.
Spool	• Existence of scratch, gnawing, rusting or corrosion.	 Replacement when its outside sliding section has scratch (especially on seals-contacting section).
	O-ring seal sections at both ends.	 Replacement when its sliding section has scratch.
	 Insert spool in casing hole, rotate and reciprocate it. 	 Correction or replacement when O-ring is damaged or when spool does not move smoothly.
Poppet	Damage of poppet or spring	Correction or replacement when sealing is incomplete.
	Insert poppet into casing and function it.	 Normal when it can function lightly without being caught.
Around spring	Rusting, corrosion, deformation or breaking of spring, spring seat, plug or cover.	Replacement for significant damage.
Around seal	· External oil leakage.	Correction or replacement.
for spool	 Rusting, corrosion or deformation of seal plate. 	Correction or replacement.
Main relief valve,	• External rusting or damage.	· Replacement.
port relief valve & negative control	Contacting face of valve seat.	Replacement when damaged.
relief valve	Contacting face of poppet.	Replacement when damaged.
	Abnormal spring.	· Replacement.
	\cdot O-rings, back up rings and seals.	· 100% replacement in general.

3. SWING DEVICE

1) WEARING PARTS

Inspection item	Standard dimension	Recommended replacement value	Counter measures
Clearance between piston and cylinder block bore	0.041	0.060	Replace piston or cylinder block
Thickness of valve plate	6	5.88	Replace
Play between piston and shoe caulking section (δ)	0.025	0.1	Replace assembly of piston and shoe
Thickness of shoe (t)	6.6	6.5	Replace assembly of piston and shoe
Combined height of retainer plate and spherical bushing (H-h)	17.6	17.3	Replace set of retainer plate and sperical bushing
Thickness of friction plate	2.94	2.7	Replace
	555		↓ ↓h H ↑ ↑
140W77MS12			2609A7MS01

2) SLIDING PARTS

Part name	Standard roughness	Allowable roughness	Remark
Shoe	Rmax=1S (Ra=0.2a) (LAPPING)	4S (Ra=0.1a)	
Shoe plate	Rmax=0.4S (Ra=0.1a) (LAPPING)	3S (Ra=0.8a)	
Cylinder	Rmax=0.4S (Ra=0.1a) (LAPPING)	3S (Ra=0.8a)	
Valve plate	Rmax=0.4S (Ra=0.1a) (LAPPING)	2S (Ra=0.5a)	

4. TRAVEL MOTOR

Pr	oblem	Cause	Remedy
Does not start	Pressure is not developed	 Pump failure Control valve malfunction 	 Check if action other than traveling is available. If faulty, repair. Check if spool moves correctly. Repair if necessary.
	Pressure in developed	 Brake valve failure Sleeve stick Check valve stick Motor failure Valve seat seizure Gear broken and fragment locked Overloaded 	 Replace brake valve Replace Check hydraulic oil for contamination Replace reduction gear Reduce load
Oil leakage	Leakage from engaging sur- faces	 Scratch on engaging surfaces Loosening by poor bolt tightening 	 Correct surfaces by oilstone or sandpaper or replace Check after retightening
	Leakage from casing	 Plug loosened Crack formed by stone 	 Retighten Replace reduction gear
	Leakage from floating seal	 Sliding surfaces worn Creep on O-ring 	 Replace reduction gear Replace floating seal
	Leakage from hydraulic motor	 Bolt loosened O-ring damaged Sealing surface scratched 	 Tighten properly Replace O-ring Correct by oilstone or sandpaper
Coasts on s	lope excessively	 Poor volumetric efficiency of hydraulic motor Increase of internal leakage of brake valve Parking brake not actuated Spring breakage Wear of friction plate 	
Excessive te reduction ge	emperature on ear case	 Pitting on bearing Lack of gear oil Hydraulic oil introduced to gear case 	 Replace reduction gear Supply gear oil properly Check motor and replace oil seal
Meanders	Meanders at low pressure	 Delivery rate is different between right and left Motor drain rate is different between right and left 	
	Meanders at high pressure	 Delivery rate is different between right and left Motor drain rate is different between right and left 	
	Meanders at high pressure	 Relief pressure dropped at right and left brake valve Main relief pressure dropped at right or left of control valve 	
Pump delive	ery is poor	 Regulator operation poor External leakage of pump is excessive 	 Repair regulator Repair pump
External leal excessive	kage of motor is	-	· Replace motor

5. RCV LEVER

Maintenance check item	Criteria	Remark
Leakage	The valve is to be replaced when the leakage becomes more than 1000 cc/m at neutral handle position, or more than 2000 cc/m during operation.	Conditions : Primary pressure : 40 kgf/cm ² Oil viscosity : 23 cSt
Spool	This is to be replaced when the sliding surface has worn more than 10 μ m, compared with the non-sliding surface.	The leakage at the left condition is estimated to be nearly equal to the above leakage.
Push rod	This is to be replaced when the top end has worn more than 1 mm.	
Play at operating section	The pin, shaft, and joint of the operating section are to be replaced when their plays become more than 2 mm due to wears or so on.	
Operation stability	When abnormal noises, hunting, primary pressure drop, etc. are generated during operation, and these cannot be remedied, referring to section 6 troubleshooting, replace the related parts.	

Notes 1. It is desirable to replace seal materials, such as O-rings, every disassembling. However, they may be reused, after being confirmed to be free of damage.

6. RCV PEDAL

Maintenance check item	Criteria	Remark	
Leakage	The valve is to be replaced when the leakage effect to the system. For example, the primary pressure drop.	Conditions : Primary pressure : 40 kgf/cm ² Oil viscosity : 23 cSt	
Spool	This is to be replaced when the sliding surface has worn more than 10μ m, compared with the non-sliding surface.	The leakage at the left condition is estimated to be nearly equal to the above leakage.	
Push rod	This is to be replaced when the top end has worn more than 1 mm.		
Play at operating section	The pin, shaft, and joint of the operating section are to be replaced when their plays become more than 2 mm due to wears or so on.	When a play is due to looseness of a tightened section, adjust it.	
Operation stability	When abnormal noises, hunting, primary pressure drop, etc. are generated during operation, and these cannot be remedied, referring to section 6. Troubleshooting, replace the related parts.		

Notes 1. It is desirable to replace seal materials, such as O-rings, every disassembling. However, they may be reused, after being confirmed to be free of damage.

7. TURNING JOINT


F	Part name	Maintenance standards	Remedy	
	Sliding surface with sealing sections.	Plating worn or peeled due to seizure or contamination.	Replace	
Body, Stem	Sliding surface between body and stem other than sealing section.	 Worn abnormality or damaged more than 0.1 mm (0.0039 in) in depth due to seizure contamination. 	Replace	
		Damaged more than 0.1 mm (0.0039 in) in depth.	Smooth with oilstone.	
	Sliding surface with thrust plate.	• Worn more than 0.5 mm (0.02 in) or abnormality.	Replace	
		• Worn less than 0.5 mm (0.02 in).	Smooth	
		Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).	Smooth	
Cover	Sliding surface with thrust plate.	• Worn more than 0.5 mm (0.02 in) or abnormality.	Replace	
		• Worn less than 0.5 mm (0.02 in).	Smooth	
		Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).	Replace	
Seal set		Extruded excessively from seal groove square ring.	Replace	
	-	Square ring		
		Slipper ring 1.5 mm (0.059 in) narrower than seal groove, or narrower than back ring.	Replace	
	-	1.5mm (max.) (0.059 in)		
		• Worn more than 0.5 mm (0.02 in) ~ 1.5 mm (MAX.) (0.059 in)	Replace	
	-			

8. CYLINDER

Part name	Inspecting section	Inspection item	Remedy		
Piston rod	Neck of rod pin	Presence of crack	· Replace		
	\cdot Weld on rod hub	 Presence of crack 	· Replace		
	Stepped part to which piston is attached.	Presence of crack	Replace		
	· Threads	Presence of crack	· Recondition or replace		
	Plated surface	Plating is not worn off to base metal.	Replace or replate		
		\cdot Rust is not present on plating.	 Replace or replate 		
		 Scratches are not present. 	\cdot Recondition, replate or replace		
	· Rod	· Wear of O.D.	\cdot Recondition, replate or replace		
	\cdot Bushing at mounting part	\cdot Wear of I.D.	· Replace		
Cylinder tube	· Weld on bottom	Presence of crack	· Replace		
	\cdot Weld on head	 Presence of crack 	· Replace		
	\cdot Weld on hub	· Presence of crack	· Replace		
	Tube interior	 Presence of faults 	\cdot Replace if oil leak is seen		
	Bushing at mounting part	• Wear on inner surface	· Replace		
Gland	Bushing	Flaw on inner surface	Replace if flaw is deeper than coating		

1. TRACK

1) TRACK ROLLER




32077MS01

Unit : mm


No.	Check item	Criteria				Remedy		
1	Outside disperter of floores	Standard size		Repair limit		Rebuild or replace		
	Outside diameter of flange	ø 170		-				
2	Outside diameter of tread	ø 140		ø 128				
3	Width of tread	39.5		45.5				
4	Width of flange	20		-				
5	Clearance between shaft and bushing	Standard size	tolerance		Standard		Clearance	
			Shaft	Hole	clearance		limit	Replace bushing
		ø 50	0 -0.03	+0.4 +0.35	0.35 to	0.43	2.0	busiling
6	Side clearance of roller (both side)	Standard clearance		Clearance limit		Replace		
		0.25~0.65		2.0				

2) CARRIER ROLLER




32077MS02

No.	Check item		Crit	eria		Remedy
4	Outside diameter of flange	Standa	ard size	Repair limit		
	Outside diameter of flange	ø ·	136	-		
2	Outside diameter of tread	ø 116		ø 108		Rebuild or replace
3	Width of tread	35.5		39.5		
4	Width of flange	15		-		
		Standard size & Tolerance		Standard	Clearance	
5	Clearance between shaft	Shaft	Hole	clearance	limit	Replace
	and bushing	ø 40 +0.085 +0.065	ø 40 +0.3 +0.25	0.165 to 0.235	2.0	bushing or shaft
6	Clearance between shaft and support	ø 40.8 ⁻ 0.05 - 0.01	ø 40.8 +0.3 +0.1	0.15 to 0.4	1.2	



21037MS03


No.	Check item		Criteria				
4	Outside diameter of protrucion	Standa	ard size	Repair limit			
	Outside diameter of protrusion	ø	510	-			
2	Outside diameter of tread	Ø	470	ø 460		Rebuild or	
3	Width of protrusion	6	57			replace	
4	Total width	135		-			
5	Width of tread	3	4	39			
		Standard size & Tolerance		Standard	Clearance		
6	Clearance between shaft	Shaft	Hole	clearance	limit	Replace	
	and bushing	ø 70 0 -0.03	ø 70.3 +0.05 0	0.3 to 0.38	2.0	bushing	
7	Clearance between shaft and support	ø 70 0 -0.03	ø 70 +0.07 +0.03	0.03 to 0.1	1.2	Rebuild or Replace	
8	Side clearance of idler	Standard clearance		Clearance limit		Replace	
	(both side)	0.25	to 1.15	2.0		bushing	




32077MS04

No.	Check item	Crit	Remedy		
4	Link nitch	Standard size	Repair limit	Turn or	
	Link pitch	171.45	175.45	replace	
2	Outside diameter of bushing	ø 50.6	ø 40.8		
3	Height of grouser	20	16	Rebuild or replace	
4	Height of link	90	82		
5	Tightening torque	Initial tightening torque :	Retighten		

5) TRACK FRAME AND RECOIL SPRING






²¹⁰³⁷MS05

	- 14 I	
	Init	mm
U	/I III.	111111

No.	Check item		Criteria					Remedy
			Standard	l size	Tole	rance	Repair limit	
1	Vertical width of idler guide	Track fram	ə 103			⊦2 0	107	
		Idler suppo	rt 100		- 0 - 0.5		98	Rebuild or replace
2	Horizontal width of idler	Track frame	e 192			⊦2 0	196	
	guide	Idler suppo	rt 190			-	188	
			Standard size			Re		
3	Recoil spring	Free length	Installation length		allation oad	Free lenç	th Installation load	Replace
		Ø 192×470	405	8,4	197kg	-	6.978kg	

2. WORK EQUIPMENT



125LCR7MS15

			P	in	Bushing		Demostr
Mark	Measuring point (Pin and Bushing)	Normal value	Recomm. service limit	Limit of use	Recomm. service limit	Limit of use	Remedy & Remark
А	Boom Rear	70	69	68.5	70.5	71	Replace
В	Boom Cylinder Head	70	69	68.5	70.5	71	"
С	Boom Cylinder Rod	70	69	68.5	70.5	71	"
D	Arm Cylinder Head	65	64	63.5	65.5	66	"
Е	Boom Front	70	69	68.5	70.5	71	"
F	Arm Cylinder Rod	65	64	63.5	65.5	66	"
G	Bucket Cylinder Head	65	64	63.5	65.5	66	"
Н	Arm Link	65	64	63.5	65.5	66	"
I	Bucket and Arm Link	65	64	63.5	65.5	66	"
J	Bucket Cylinder Rod	65	64	63.5	65.5	66	"
К	Bucket Link	65	64	63.5	65.5	66	"

SECTION 8 DISASSEMBLY AND ASSEMBLY

Group	1	Precaution	8-1
Group	2	Tightening Torque	8-4
Group	3	Pump Device	8-7
Group	4	Main Control Valve	8-32
Group	5	Swing Device	8-46
Group	6	Travel Device	8-79
Group	7	RCV Lever ·····	8-111
Group	8	Turning Joint	8-125
Group	9	Boom, Arm and Bucket Cylinder	8-130
Group	10	Undercarriage	8-148
Group	11	Work Equipment	8-160


GROUP 1 PRECAUTIONS

1. REMOVAL WORK

- 1) Lower the work equipment completely to the ground. If the coolant contains antifreeze, dispose of it correctly.
- 2) After disconnecting hoses or tubes, cover them or fit blind plugs to prevent dirt or dust from entering.
- 3) When draining oil, prepare a container of adequate size to catch the oil.
- 4) Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake when assembling.
- 5) To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors.
- 6) Fit wires and hoses with tags to show their installation position to prevent any mistake when installing.
- 7) Check the number and thickness of the shims, and keep in a safe place.
- 8) When raising components, be sure to use lifting equipment of ample strength.
- 9) When using forcing screws to remove any components, tighten the forcing screws alternately.
- 10) Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.
- 11) When removing hydraulic equipment, first release the remaining pressure inside the hydraulic tank and the hydraulic piping.

12) If the	part is not unde	r hydraulic pressur	e, the following c	orks can be used.
,			e,e .eeg e	

Nominal		Dimensions	
number	D	d	L
06	6	5	8
08	8	6.5	11
10	10	8.5	12
12	12	10	15
14	14	11.5	18
16	16	13.5	20
18	18	15	22
20	20	17	25
22	22	18.5	28
24	24	20	30
27	27	22.5	34



2. INSTALL WORK

- 1) Tighten all bolts and nuts (sleeve nuts) to the specified torque.
- 2) Install the hoses without twisting or interference.
- 3) Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
- 4) Bend the cotter pin or lock plate securely.
- 5) When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2-3 drops of adhesive.
- 6) When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
- 7) Clean all parts, and correct any damage, dents, burrs, or rust.
- 8) Coat rotating parts and sliding parts with engine oil.
- 9) When press fitting parts, coat the surface with antifriction compound (LM-P).
- 10) After installing snap rings, check that the snap ring is fitted securely in the ring groove (Check that the snap ring moves in the direction of rotation).
- 11) When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
- 12) When using eyebolts, check that there is no deformation or deterioration, and screw them in fully.
- 13) When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- 14) When operating the hydraulic cylinders for the first time after repairing and reassembling the hydraulic cylinders, pumps, or other hydraulic equipment or piping, always bleed the air from the hydraulic cylinders as follows:
- (1) Start the engine and run at low idling.
- (2) Operate the control lever and actuate the hydraulic cylinder 4-5 times, stopping 100mm before the end of the stroke.
- (3) Next, operate the piston rod to the end of its stroke to relieve the circuit. (The air bleed valve is actuated to bleed the air.)
- (4) After completing this operation, raise the engine speed to the normal operating condition.
- * If the hydraulic cylinder has been replaced, carry out this procedure before assembling the rod to the work equipment.
- * Carry out the same operation on machines that have been in storage for a long time after completion of repairs.

3. COMPLETING WORK

- 1) If the coolant has been drained, tighten the drain valve, and add water to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
- 2) If the hydraulic equipment has been removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- 3) If the piping or hydraulic equipment, such as hydraulic cylinders, pumps, or motors, have been removed for repair, always bleed the air from the system after reassembling the parts.
- 4) Add the specified amount of grease (molybdenum disulphied grease) to the work equipment related parts.

GROUP 2 TIGHTENING TORQUE

1. MAJOR COMPONENTS

Na		Descriptions	Delteine	Torque		
No.	Descriptions		Bolt size	kgf ∙ m	lbf ∙ ft	
1		Engine mounting bolt (engine-bracket)	$M12 \times 1.75$	12.3 ± 1.2	89 ± 8.7	
2		Engine mounting bolt (rubber, fan side)	$M20 \times 2.5$	55 ± 3.5	398 ± 25.3	
3	Fraina	Engine mounting bolt (rubber, flywheel side)	$M20 \times 2.5$	52.1 ± 5.0	377 ± 36.2	
4	Engine	Radiator mounting bolt	$M16 \times 2.0$	29.7 ± 4.5	215 ± 32.5	
5		Coupling mounting socket bolt	$M18 \times 2.5$	32 ± 1.0	231 ± 7.2	
6		Main pump housing mounting bolt	M10 imes 1.5	6.5 ± 0.7	47 ± 5.1	
7		Main pump mounting socket bolt	$M16 \times 2.0$	22 ± 1.5	159 ± 10.8	
8		Main control valve mounting bolt	M12 imes 1.75	12.2 ± 1.3	88.2 ± 9.4	
9	Hydraulic system	Fuel tank mounting bolt	M20 $ imes$ 2.5	45 ± 1.0	325 ± 7.2	
10	eyetetti	Hydraulic oil tank mounting bolt	M20 $ imes$ 2.5	45 ± 1.0	325 ± 7.2	
11		Turning joint mounting bolt, nut	M12 imes 1.75	12.3 ± 1.3	88.9 ± 9.4	
12		Swing motor mounting bolt	$M16 \times 2.0$	29.6 ± 3.2	214 ± 23.1	
13	Power	Swing bearing upper part mounting bolt	$\rm M18 \times 2.5$	41.3 ± 4.0	299 ± 28.9	
14	train	Swing bearing lower part mounting bolt	M16 $ imes$ 1.5	29.7 ± 3.0	215 ± 21.7	
15	system	Travel motor mounting bolt	$M16 \times 2.0$	23 ± 2.5	166 ± 18.1	
16		Sprocket mounting bolt	$M16 \times 2.0$	29.7 ± 3.0	215 ± 21.7	
17		Carrier roller mounting bolt, nut	$M16 \times 2.0$	29.7 ± 3.0	215 ± 21.7	
18		Track roller mounting bolt	$M16 \times 2.0$	29.7 ± 3.0	215 ± 21.7	
19	Under carriage	Track tension cylinder mounting bolt	$M16 \times 2.0$	29.7 ± 3.0	215 ± 21.7	
20		Track shoe mounting bolt, nut	$M16 \times 1.5$	25.5 ± 2.5	184 ± 18.1	
21		Track guard mounting bolt	$M16 \times 2.0$	29.6 ± 3.2	214 ± 23.1	
22		Counterweight mounting bolt	M36 \times 3.0	308 ± 46	2228 ± 333	
23	Others	Cab mounting bolt	M12 imes 1.75	12.8 ± 3.0	92.6 ± 21.7	
24		Operator's seat mounting bolt	M 8 × 1.25	4.05 ± 0.8	29.3 ± 5.8	

* For tightening torque of engine and hydraulic components, see engine maintenance guide and service manual.

2. TORQUE CHART

Use following table for unspecified torque.

1) BOLT AND NUT

(1) Coarse thread

Delteize	8	Т	10T		
Bolt size	kgf ∙ m	lbf ⋅ ft	kgf ∙ m	lbf ⋅ ft	
M 6 × 1.0	0.85 ~ 1.25	6.15 ~ 9.04	1.14 ~ 1.74	8.2 ~ 12.6	
M 8 × 1.25	2.0 ~ 3.0	14.5 ~ 21.7	2.73 ~ 4.12	19.7 ~ 29.8	
M10 × 1.5	4.0 ~ 6.0	28.9 ~ 43.4	5.5 ~ 8.3	39.8 ~ 60	
M12 × 1.75	7.4 ~ 11.2	53.5 ~ 79.5	9.8 ~ 15.8	71 ~ 114	
M14 × 2.0	12.2 ~ 16.6	88.2 ~ 120	16.7 ~ 22.5	121 ~ 167	
M16 × 2.0	18.6 ~ 25.2	135 ~ 182	25.2 ~ 34.2	182 ~ 247	
M18 × 2.5	25.8 ~ 35.0	187 ~ 253	35.1 ~ 47.5	254 ~ 343	
M20 × 2.5	36.2 ~ 49.0	262 ~ 354	49.2 ~ 66.6	356 ~ 482	
M22 × 2.5	48.3 ~ 63.3	350 ~ 457	65.8 ~ 98.0	476 ~ 709	
M24 × 3.0	62.5 ~ 84.5	452 ~ 611	85.0 ~ 115	615 ~ 832	
M30 × 3.5	124 ~ 168	898 ~ 1214	169 ~ 229	1223 ~ 1655	
M36 × 4.0	174 ~ 236	1261 ~ 1703	250 ~ 310	1808 ~ 2242	

(2) Fine thread

Bolt size	8	Т	10T		
DOIL SIZE	kgf ∙ m	lbf ⋅ ft	kgf ∙ m	lbf ⋅ ft	
M 8 × 1.0	2.17 ~ 3.37	15.7 ~ 24.3	3.04 ~ 4.44	22.0 ~ 32.0	
M10 × 1.25	4.46 ~ 6.66	32.3 ~ 48.2	5.93 ~ 8.93	42.9 ~ 64.6	
M12 × 1.25	7.78 ~ 11.58	76.3 ~ 83.7	10.6 ~ 16.0	76.6 ~ 115	
M14 × 1.5	13.3 ~ 18.1	96.2 ~ 130	17.9 ~ 24.1	130 ~ 174	
M16 × 1.5	19.9 ~ 26.9	144 ~ 194	26.6 ~ 36.0	193 ~ 260	
M18 × 1.5	28.6 ~ 43.6	207 ~ 315	38.4 ~ 52.0	278 ~ 376	
M20 × 1.5	40.0 ~ 54.0	289 ~ 390	53.4 ~ 72.2	386 ~ 522	
M22 × 1.5	52.7 ~ 71.3	381 ~ 515	70.7 ~ 95.7	512 ~ 692	
M24 × 2.0	67.9 ~ 91.9	491 ~ 664	90.9 ~ 123	658 ~ 890	
M30 × 2.0	137 ~ 185	990 ~ 1338	182 ~ 248	1314 ~ 1795	
M36 × 3.0	192 ~ 260	1389 ~ 1879	262 ~ 354	1893 ~ 2561	

2) PIPE AND HOSE (FLARE TYPE)

Thread size (PF)	Width across flat (mm)	kgf ∙ m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130.2
1"	41	21	151.9
1-1/4"	50	35	253.2

3) PIPE AND HOSE (ORFS TYPE)

Thread size (UNF)	Width across flat (mm)	kgf ⋅ m	lbf ⋅ ft
9/16-18	19	4	28.9
11/16-16	22	5	36.2
13/16-16	27	9.5	68.7
1-3/16-12	36	18	130.2
1-7/16-12	41	21	151.9
1-11/16-12	50	35	253.2

4) FITTING


Thread size	Width across flat (mm)	kgf ∙ m	lbf ⋅ ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130.2
1"	41	21	151.9
1-1/4"	50	35	253.2


GROUP 3 PUMP DEVICE


1. REMOVAL AND INSTALL

1) REMOVAL

- Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- Escaping fluid under pressure can penetrate the skin causing serious injury.
- (4) Loosen the drain plug under the hydraulic tank and drain the oil from the hydraulic tank.
 - Hydraulic tank quantity : 79 l (20.9 U.S. gal)
- (5) Remove socket bolts (11) and disconnect hoses (1,2).
- (6) Disconnect pilot line hoses (5, 6, 7, 8, 9, 10).
- (7) Remove socket bolts (12) and disconnect pump suction pipe (4).
- When pump suction tube is disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (8) Sling the pump assembly and remove the pump mounting bolts.
 - Weight : 90 kg (200 lb)
- Pull out the pump assembly from housing.
 When removing the pump assembly, check that all the hoses have been disconnected.








2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Remove the suction strainer and clean it.
- (3) Replace return filter with new one.
- (4) Remove breather and clean it.
- (5) After adding oil to the hydraulic tank to the specified level.
- (6) Bleed the air from the hydraulic pump.
- 1 Remove the air vent plug (2EA).
- ② Tighten plug lightly.
- ③ Start the engine, run at low idling, and check oil come out from plug.
- ④ Tighten plug.
- (7) Start the engine, run at low idling (3~5 minutes) to circulate the oil through the system.
- (8) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2. MAIN PUMP (1/3)


1) STRUCTURE



140Z92MP02

Drive shaft (F) 272 Pump casing (R) 711 O-ring 111 312 Valve block 113 Drive shaft (R) 717 O-ring 116 1st Gear 313 Valve plate (R) 723 O-ring 314 Valve plate (L) 123 Roller bearing 724 O-ring 124 Needle bearing 401 Hexagon socket bolt 728 O-ring 127 Bearing spacer 402 Hexagon socket bolt 732 O-ring 141 Cylinder block 406 Hexagon socket bolt 733 O-ring 151 Piston 415 Hexagon socket bolt 734 O-ring 152 Shoe 466 Plug 774 Oil seal 153 Set plate 467 plug 789 Back up ring 156 Bushing 468 Plug 792 Back up ring 157 Cylinder spring 490 Plug 806 Nut 211 Shoe plate Tilting pin 808 Hexagon head nut 531 212 Swash plate 532 Servo piston 824 Snap ring 214 Bushing 533 Plug 886 Spring pin 251 534 Stopper (L) Eye bolt Support 901 953 Set screw 535 Stopper (S) 255 Lock pin 954 Set screw 261 Seal cover (F) 548 Pin 263 Seal cover (R) 702 O-ring 981 Plate 710 O-ring 983 Pin 271 Pump casing (F)

MAIN PUMP (2/3)



2) TOOLS AND TIGHTENING TORQUE

(1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.


Tool name & size	Part name							
Name	В	Hexagon socket head bolt		PT plug T thread)	ROH/VP/UNF plug (PF screw)		Hexagon socket head setscrew	
Allen wrench	4	M 5	E	3P-1/16	-		M 8	
	5	M 6		3P-1/8 -			M10	
	6	M 8 B		BP-1/4	PF-1/4	M12, M14		
	8	M10		BP-3/8	PF-3/8	}	M16, M18	
	10	M12		BP-1/2	PF-1/2	2	M20	
	14	M16, M18	BP-3/4		PF-3/4		-	
	17	M20, M22	BP-1		PF-1		-	
Double ring spanner,	-	Hexagon bolt		Hexagon nut			VP plug (PF screw)	
socket wrench, double (single) open end spanner	19	M12		M12			PF-1/4	
open end spanner	24	M16		M16			-	
В	27	M18		M18			PF-1/2	
	30	M20		M20		-		
	41	-		-		PF-1		
Adjustable angle wrench		Medium size, 1 set						
Screw driver		Minus type screw driver, Medium size, 2 sets						
Hammer		Plastic hammer, 1 set						
Pliers		For snap ring, TSR-160						
Steel bar		Steel bar of key material approx. $10 \times 8 \times 200$						
Torque wrench		Capable of tightening with the specified torques						

(2) Tightening torque

Part name	Bolt size	Tore	que	Wrench size		
	Boil Size	kgf ∙ m	lbf ⋅ ft	in	mm	
Hexagon socket head bolt	M 5	0.7	5.1	0.16	4	
(material : SCM435)	M 6	1.2	8.7	0.20	5	
	M 8	3.0	21.7	0.24	6	
	M10	5.8	42.0	0.31	8	
	M12	10.0	72.3	0.39	10	
	M14	16.0	116	0.47	12	
	M16	24.0	174	0.55	14	
	M18	34.0	246	0.55	14	
	M20	44.0	318	0.67	17	
PT Plug (material : S45C)	PT1/16	0.7	5.1	0.16	4	
Wind a seal tape 1.5 to 2 turns round the plug	PT 1/8	1.05	7.59	0.20	5	
	PT 1/4	1.75	12.7	0.24	6	
	PT 3/8	3.5	25.3	0.31	8	
	PT 1/2	5.0	36.2	0.39	10	
PF Plug (material : S45C)	PF 1/4	3.0	21.7	0.24	6	
	PF 3/8	7.55	54.6	0.31	8	
	PF 1/2	10.0	72.3	0.39	10	
	PF 3/4	15.0	109	0.55	14	
	PF 1	19.0	137	0.67	17	
	PF 1 1/4	27.0	195	0.67	17	
	PF 1 1/2	28.0	203	0.67	17	

3) DISASSEMBLY

- (1) Select place suitable to disassembling.
- * Select clean place.
- Spread rubber sheet, cloth or so on overhaul workbench top to prevent parts from being damaged.
- (2) Remove dust, rust, etc, from pump surfaces with cleaning oil or so on.
- (3) Remove drain port plug (468) and drain oil pump casing (271, 272).
- (4) Remove hexagon socket head bolts (412, 413) and remove regulator.



140Z98MP11

- (5) Place pump horizontally on workbench with its regulator fitting surface down, and remove flange socket (435) and remove PTO unit (05).
- * Be careful about the attaching direction of the PTO unit (05).
- * Before bringing regulator fitting surface down, spread rubber sheet on workbench without fail to prevent this surface from being damaged.
- (6) In case the pump is provided without the PTO unit (05), remove the cover (262) with the hexagon socket head cap screws (414).



140Z98MP12



140Z98MP13

(7) Remove flange socket (435) and remove gear pump (04).



140Z98MP14

- (8) Loosen hexagon socket head bolt (401) which tighten pump casing (271, 272) and valve block (312).

140Z98MP15

- (9) Place pump horizontally on workbench with its regulator fitting surface down, and separate pump casing (271,272) from valve block (312).
- * Remove 1st gear (116) when separating pump casing from valve block (312) too.

140Z98MP16

- (10) Pull out cylinder (141), pistons (151), set screw (153), spherical bush (156) and cylinder springs (157) simultaneously from pump casing (271, 272) straightly over drive shaft (111, 113).
- Take care not to damage sliding surface of cylinder (141), spherical bush (156), shoes (152), swash plate (212), etc.



- (11) Remove hexagon socket head bolts (406) and then seal cover (F, 261).
- * In the case removing it is difficult, and hooking pull thin rod into notch, and the cover can be removed easily.
- Since oil seal is fitted on seal cover (F) (261), take care not to damage it at removing the cover.
- (12) Tapping shaft ends of drive shaft (111, 113) lightly with plastic hammer, remove it from pump casing (271, 272).



140Z98MP18



140Z98MP19

(13) Remove shoe plate (211) and swash plate (212) from pump casing (271, 272).



140Z98MP20

- (14) Insert thin steel bar into the hole and remove the lock pin (255) from pump casing (271, 272).
- When holding with thin steel bar, do not confuse the unlocking hole with the arc shaped oil passage.



140Z98MP21

- (15) Remove valve plate (313, 314) from valve block (312).
- * These may be removed in Work 8.



140Z98MP22

If necessary, remove stopper (L) (534), Qmin. plug (533), servo piston (532) and tilting pin (531) from pump casing (271, 272), and needle bearing (124) from valve block.

- When removing tilting pin, use a protector to prevent pin head from being damaged.
- Since lock tight is applied to fitting areas of tilting pin (531) and servo piston (532), take care not to damage servo piston (532).
- Do not remove needle bearing (124) as far as possible, except the case that considered to be out of its life span.
- Do not loosen hexagon nuts of valve block (312) and Qmin. plug (533).
 If loosened, flow setting will be changed.

4) ASSEMBLY

- (1) For reassembling reverse the disassembling procedures, paying attention to the following items.
- ① Do not fail to repair the parts damaged during disassembling, and repair replacement parts in advance.
- ② Clean each part fully with cleaning oil and dry it with compressed air.
- ③ Do not fail to apply clean working oil to sliding sections, bearings, etc. before assembling them.
- ④ In principle, replace seal parts, such as O-rings, oil seals, etc.
- ⁽⁵⁾ For fitting bolts, plug, etc., prepare a torque wrench or so on, and tighten them with torques shown in page 8-11, 12.
- ⁽⁶⁾ For the double-pump, take care not to mix up parts of the front pump with those of the rear pump.
- (2) Insert the lock pin (255) after the swash plate support (251) into the pump casing (271, 272), and fit the lock pin (255) into the hole of the swash plate support (251).
- In case the servo piston, tilting pin, stopper (L), stopper (S), and Qmin. plug have been removed, attached then to the pump casing in advance.
- In the tightening work of the servo piston and the tilting pin, use the tool not to damaged the head of the tilting pin and the feed back pin. Besides, apply loctite (of medium strength) to the thread portion.



140Z98MP23

- (3) Fit tilting bush (214) of swash plate (212) to tilting pin (531), and fit swash plate (212) with shoe plate (211) to swash plate support (251) correctly.
- * Confirm with fingers of both hands that swash plate can be removed smoothly.
- Apply grease to sliding sections of swash plate (212) and swash plate support (251), and drive shaft (111, 113) can be fitted easily.
- * Take care not to damage shoe plate (211) surface.
- (4) To pump casing (271, 272), fit drive shaft (111, 113) set with bearing (123), bearing spacer (127) and stop ring (824).







140Z98MP25

- (5) In assemble of front pump, assemble seal cover (F) (261) to pump casing (271) and fix it with hexagon socket head bolt (406).
- * Apply grease lightly to oil seal in seal cover (F) (261).
- * For assemble oil seal (774), taking full care not to damage it.



140Z98MP26

(6) Assemble piston cylinder subassembly [cylinder (141), piston subassembly (151, 152), set plate (153), spherical bush (156) and cylinder spring (157)]. Fitting spline phases of cylinder, spherical bush (156) and drive shaft (111, 113), insert piston cylinder subassembly into pump casing (271, 272).



8-18

- (7) Fit valve plate (313, 314) to valve block (312), spring pin (886) into pin hole.
- * Take care not to mistake suction/delivery direction of valve plate (312).

- (8) Place pump horizontally on workbench with its regulator fitting surface down, and attach pump casing (271, 272) to valve block (312). Fit 1st gear (116) simultaneously.
- Before bringing regulator fitting surface down, spread rubber sheet on workbench without fail to prevent this surface from being damaged.
- * Take care not to mistake direction of valve block (312). [Clockwise rotation (viewed from input shaft side)]. Fit the valve block (312) with suction flange left when regulator side below, viewed from front side.
- (9) Fix valve block (312) to pump casing (271, 272) with hexagon socket head bolts (401).



140Z98MP28



140Z98MP29



40Z98MP30

(10) Fit gear pump (04) to pump casing (272) with hexagon socket head bolts (435).





(11) Attach the PTO unit (05) by fastening the flange socket (435) to the valve block (312).



140Z98MP32

(12) In case the pump is not provided with the PTO unit (05), attach the cover (262) with the hexagon socket head cap screw (414).



140Z98MP33

- (13) Putting feedback lever (611) of regulator into feedback pin (548) of tilting pin (531), fit regulator with hexagon socket head bolt (415).
- * Take care not to mix up regulator of front pump and that of rear pump.




140Z98MP34

(14) Fit drain port plug (468).

This is the end of reassembling procedures.

3. REGULATOR

1) STRUCTURE (1/2)




140Z92MP04

жÆ

P1

В

SECTION E-E (REAR)



8-22

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.

			-				
Tool name & size		Part name					
Name	В	Hexagon socketPT plughead bolt(PT thread)		PO plug (PF thread)		Hexagon socket head setscrew	
Allen wrench	4	M5	BP-1/16		-		M 8
B -	5	M6	BP-1/8		-		M10
	6	M8	BP-1/4		PO-1/4		M12, M14
Double ring spanner, socket wrench, double (single) open end spanner	-	Hexagon head bolt Hexag		gon nut		VP plug (PF thread)	
	6	M 8	M		18		-
Adjustable angle wrench	Small size, Max 36 mm						
Screw driver		Minus type screw driver, Medium size, 2 sets					
Hammer		Plastic hammer, 1 set					
Pliers		For snap ring, TSR-160					
Steel bar		4×100 mm					
Torque wrench		Capable of tightening with the specified torques					
Pincers		-					
Bolt	M4, Length : 50 mm						


(2) Tightening torque

Part name	Bolt size	Tor	rque	Wrench size		
	DUIL SIZE	kgf ∙ m	lbf ⋅ ft	in	mm	
Hexagon socket head bolt	M 5	0.7	5.1	0.16	4	
(material : SCM435)	M 6	1.2	8.7	0.20	5	
	M 8	3.0	21.7	0.24	6	
	M10	5.8	42.0	0.31	8	
	M12	10.0	72.3	0.39	10	
	M14	16.0	116	0.47	12	
	M16	24.0	174	0.55	14	
	M18	34.0	246	0.55	14	
	M20	44.0	318	0.67	17	
PT Plug (material : S45C) * Wind a seal tape 1 1/2 to 2	PT1/16	0.7	5.1	0.16	4	
	PT 1/8	1.05	7.59	0.20	5	
turns round the plug	PT 1/4	1.75	12.7	0.24	6	
	PT 3/8	3.5	25.3	0.31	8	
	PT 1/2	5.0	36.2	0.39	10	
PF Plug (material : S35C)	PF 1/4	3.0	21.7	0.24	6	
	PF 1/2	10.0	72.3	0.39	10	
	PF 3/4	15.0	109	0.55	14	
	PF 1	19.0	137	0.67	17	
	PF 1 1/4	27.0	195	0.67	17	
	PF 1 1/2	28.0	203	0.67	17	


3) DISASSEMBLY

Since the regulator consists of small precision finished parts, disassembly and assembly are rather complicated. For this reason, replacement of a regulator assembly is recommended, unless there is a special reason, but in case disassembly is necessary for an unavoidable reason, read through this manual to the end before starting disassembly.

- (1) Choose a place for disassembly.
- * Choose a clean place.
- Spread rubber sheet, cloth, or so on on top of work-bench to prevent parts from being damaged.
- (2) Remove dust, rust, etc. from surfaces of regulator with clean oil.
- (3) Remove hexagon socket head screw (412, 413) and remove regulator main body from pump main body.
- * Take care not to lose O-ring.




- (4) Remove hexagon socket head screw (438) and remove cover (C,629)
- * Cover (C) is fitted with adjusting screw (C, 628), adjusting ring (C, 627), lock nut (630), hexagon nut (801) and adjusting screw (924).
- Do not loosen these screws and nuts.
 If they are loosened, adjusted pressureflow setting will vary.




 (5) After removing cover (C, 629) subassembly, take out outer spring (625), inner spring (626) and spring seat (C, 624) from compensating section.


Then draw out adjusting ring (Q, 645), pilot spring (646) and spring seat (644) from pilot section.

- * Adjusting ring (Q,645) can easily be drawn out with M4 bolt.
- (6) Remove hexagon socket head screws (436, 438) and remove pilot cover (641).After removing pilot cover, take out set spring (655) from pilot section.







- (7) Remove snap ring (814) and take out spring seat (653), return spring (654) and sleeve (651).
- * Sleeve (651) is fitted with snap ring (836).
- When removing snap ring (814), return spring (654) may pop out.
 Take care not to lose it.




- (8) Remove prevention plug (616) and take out center plug (614) and adjusting plug (615).
- Center plug (614) and adjusting plug (615) can easily be taken out with M6 bolt.







- (9) Remove lever (2, 613). Do not draw out pin (875).
- Work will be promoted by using pincers or so on.



(10) Draw out pin (874) and remove feedback lever (611).

Push out pin (874, 4 mm in dia.) from above with slender steel bar so that it may not interfere with lever (1, 612).





- (11) Remove lever (1, 612). Do not draw out pin (875).
- (12) Draw out pilot piston (643) and spool (652).
- (13) Draw out piston case (622), compensating piston (621) and compensating rod (623).
- * Piston case (622) can be taken out by pushing compensating rod (623) at opposite side of piston case.


This completes disassembly.

4) ASSEMBLY


- For assembly, reverse disassembly procedures, but pay attention to the following items.
- Always repair parts that were scored at disassembly.
- ② Get replacement parts ready beforehand. Mixing of foreign matter will cause malfunction.

Therefore, wash parts well with cleaning oil, let them dry with jet air and handle them in clean place.


- ③ Always tighten bolts, plugs, etc. to their specified torques.
- ④ Do not fail to coat sliding surfaces with clean hydraulic oil before assembly.
- ⑤ Replace seals such as O-ring with new ones as a rule.
- (2) Put compensating rod (623) into compensating hole of casing (601).
- (3) Put pin force-fitted in lever (1, 612) into groove of compensating rod and fit lever (1) to pin force-fitted in casing.
- (4) Fit spool (652) and sleeve (651) into hole in spool of casing.
- * Confirm that spool and sleeve slide smoothly in casing without binding.
- * Pay attention to orientation of spool.



- (5) Fit feedback lever (611), matching its pin hole with pin hole in spool. Then insert pin (874).
- Insert pin in feedback lever a little to ease operation.
- * Take care not to mistake direction of feedback lever.




- (6) Put pilot piston (643) into pilot hole of casing.
- * Confirm that pilot piston slides smoothly without binding.
- (7) Put pin force-fitted in lever (2, 613) into groove of pilot piston. Then fix lever (2).




(8) Fit center plug (614) so that pin forcefitted in center plug (614) can be put into pin hole of lever (2).


Then install prevention plug (858).

- (9) Insert adjusting plug (615) and fit locking ring.
- Take care not to mistake inserting holes for fulcrum plug and adjusting plug.
 At this point in time move feedback lever to confirm that it has no large play and is free from binding.
- (10) Fit return spring (654) and spring seat(653) into spool hole and attach snap ring(814).






(11) Fit set spring (655) to spool hole and put compensating piston (621) and piston case (622) into compensating hole.
Fit pilot cover (641) and tighten it with hexagonal socket head screws (437, 438).




- (12) Put spring seat (644), pilot spring (646) and adjusting ring (Q, 645) into pilot hole. Then fix spring seat (624), inner spring (626) and outer spring (625) into compensating hole.
- When fitting spring seat, take care not to mistake direction of spring seat.



(13) Install cover (C, 629) fitted with adjusting screws (628), adjusting ring (C, 627), lock nut (630), hexagon nut (801) and adjusting screw (924).

Then tighten them with hexagonal socket head screws (438).



This completes assembly.

GROUP 4 MAIN CONTROL VALVE


1. REMOVAL AND INSTALL OF MOTOR


1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove the wirings for the pressure sensor and so on.
- (5) Remove bolts and disconnect pipe.
- (6) Disconnect pilot line hoses.
- (7) Disconnect pilot piping.
- (8) Sling the control valve assembly and remove the control valve mounting bolt and bracket.
 - Weight : 140 kg (310 lb)
- (9) Remove the control valve assembly. When removing the control valve assembly, check that all the piping have been disconnected.


2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from below items.
- ① Cylinder (Boom, arm, bucket)
- ② Swing motor
- ③ Travel motor
- * See each item removal and install.
- (3) Confirm the hydraulic oil level and recheck the hydraulic oil leak or not.










2. STRUCTURE (1/4)




125LCR8MC04

- 1 Housing-P1
- 4 Spool assy-travel (LH)
- 7 Spool assy-boom 1
- 10 Spool assy-arm 2
- 12 Spool assy-arm regen
- 14 Spool assy-bucket
- 20 Nega con relief valve
- 22 Bucket stroke limiter
- 24 Holding valve kit A1

- 26 Lock valve kit B
- 27 Regeneration block
- 33 Plug
- 41 Orifice
- 42 Plug
- 45 Poppet
- 48 Orifice
- 49 Coin type filter
- 50 Pilot A cap

- 51 Pilot B1 cap
- 53 Socket head bolt
- 56 Plain washer
- 58 O-ring
- 59 O-ring
- 69 O-ring
- 81 Spring
- 82 Pin

STRUCTURE (2/4)




16	Main relief valve	42	Plug
17	Overload relief valve	43	Poppet
28	Plug	44	Poppet
29	Plug	59	O-ring
31	Plug	61	O-ring
32	Plug	62	O-ring
35	Plug	63	O-ring
38	Plug	66	O-ring
39	Plug	67	O-ring

Plug Poppet 1 Poppet 2 O-ring O-ring O-ring O-ring

- O-ring 71
- 72 O-ring
- 74 Back up ring
- Back up ring 75
- 76 Back up ring
- 79 Spring
- 80 Spring

STRUCTURE (3/4)




- 2 Housing-P2
- 3 Spool assy-straight travel
- 4 Spool assy-travel(RH)
- 6 Spool assy-swing
- 8 Spool assy-swing priority
- 9 Spool assy-boom 2
- 11 Spool assy-arm 1
- 13 Spool assy-option B
- 15 Spool assy-option C
- 25 Holding valve kit A2

- 26 Lock valve kit B
- 29 Plug
- 30 Plug
- 40 Plug
- 46 Sleeve
- 47 Piston
- 50 Pilot A cap
- 51 Pilot B1 cap
- 52 Pilot B2 cap
- 53 Socket head bolt

- 125LCR8MC06
- 54 Socket head bolt
- 55 Socket head bolt
- 56 Plain washer
- 57 Spring washer
- 59 O-ring
- 61 O-ring
- 63 O-ring
- 69 O-ring
- 75 Back up ring

STRUCTURE (4/4)



14098MC07

- Overload relief valve 17
- Overload relief valve 18
- Overload relief valve 19
- 21 Swing logic valve
- 23 **ON/OFF** valve-option
- 28 Plug
- 29 Plug
- 30 Plug
- 31 Plug
- 32 Plug
- 34 Plug

- 36 Plug
- 37 Plug
- Poppet 1 43 44
- Poppet
- Orifice 48
- Coin type filter 49
- 60 O-ring
- 61 O-ring
- 62 O-ring
- 63 O-ring
- 64 O-ring

- 65 O-ring
- 67 O-ring
- O-ring 68
- 72 O-ring
- 73 O-ring
- Back up ring 77
- Back up ring 78
 - 79 Spring
- 80 Spring

3. DISASSEMBLY AND ASSEMBLY

1) GENERAL PRECAUTIONS

- (1) All hydraulic components are manufactured to a high precision. Consequently, before disassembling and assembling them, it is essential to select an especially clean place.
- (2) In handling a control valve, pay full attention to prevent dust, sand, etc. from entering into it.
- (3) When a control value is to be remove from the machine, apply caps and masking seals to all ports. Before disassembling the value, recheck that these caps and masking seals are fitted completely, and then clean the outside of the assembly. Use a proper bench for working. Spread paper or a rubber mat on the bench, and disassemble the value on it.
- (4) Support the body section carefully when carrying or transferring the control valve. Do not lift by the exposed spool, end cover section etc.
- (5) After disassembling and assembling of the component it is desired to carry out various tests (for the relief characteristics, leakage, flow resistance, etc.), but hydraulic test equipment is necessary for these tests. Therefore, even when its disassembling can be carried out technically, do not disassemble such components that cannot be tested, adjusted, and so on. Additionally one should always prepare clean cleaning oil, hydraulic oil, grease, etc. beforehand.


2) TOOLS

Before disassembling the control valve, prepare the following tools beforehand.

Name of tool	Quantity	Size (mm)
Vice mounted on bench (soft jaws)	1 unit	
Hexagon wrench	Each 1 piece	5, 6, 10, 12 and 14
Socket wrench	Each 1 piece	27 and 32
Spanner	Each 1 piece	32 (main relief valve, overload relief valve, negative relief valve)26 (holding valve)


3) **DISASSEMBLY**

- (1) Disassembly of spools without holding valve (travel right, travel left)
 - Loosen hexagon socket head bolts with washer. (hexagon wrench : 5 mm)
 - ② Remove the pilot cover.
 - * Pay attention not to lose the O-ring under the pilot cover.
 - ③ Remove the spool assembly from the body by hand slightly.
 - * When extracting each spool from its body, pay attention not to damage the body.
 - * When extracting each spool assembly, it must be extracted from spring side only.
 - * When any abnormal parts are found, replace it with completely new spool assembly.
 - * When disassembled, tag the components for identification so that they can be reassembled correctly.




(2) Disassembly of spools with holding valve (boom 1, Arm 1 spool)

- Loosen hexagon socket head bolts with washer. (hexagon wrench : 5 mm)
- ② Remove the pilot cover with internal parts.
- * Pay attention not to lose the O-ring and the poppet under the pilot cover.
- * Pay attention not to damage the "piston A" under pilot cover.
- ③ Remove the spool assembly from the body by hand slightly.
- * When extracting each spool from its body, pay attention not to damage the body.
- * When extracting each spool assembly, it must be extracted from spring side only.
- * When any abnormal parts are found, replace it with completely new spool assembly.
- * When disassembled, tag the components for identification so that they can be reassembled correctly.



(3) Disassembly of the holding valve


- 1 Remove the pilot cover with the holding value as described on previous page.
- * Do not disassembled internal parts of the pilot cover.
- ② Loosen the poppet seat and remove the poppet, spring seat, spring and check. (spanner : 26 mm)
- * Pay attention not to lose the poppet.
- * Do not disassembled internal parts of the check.



125LCR8MC12

(4) Disassembly of the load check valve and the negative relief valve


- 1 The load check valve
 - a. Fix the body to suitable work bench.
 - * Pay attention not to damage the body.
 - b. Loosen the plug (hexagon wrench : 10 mm).
 - c. Remove the spring and the load check valve with pincers or magnet.
- ② The negative relief valve
 - a. Loosen the socket (spanner : 32 mm).
 - b. Remove the spring, spring holder, piston and negative control poppet.



14W98MC13

(5) Disassembly of the main and overload relief valve

- ① Fix the body to suitable work bench.
- ② Remove the main relief valve. (spanner : 32 mm)
- ③ Remove the overload relief valve. (spanner : 32 mm)
- * When disassembled, tag the relief valve for identification so that they can be reassembled correctly.
- * Pay attention not to damage seat face.
- * When any abnormal parts are found, replace it with completely new relief valve assembly.



(6) Inspection after disassembly

Clean all disassembled parts with clean mineral oil fully, and dry them with compressed air. Then, place them on clean papers or cloths for inspection.

① Control valve

- a. Check whole surfaces of all parts for burrs, scratches, notches and other defects.
- b. Confirm that seal groove faces of body and block are smooth and free of dust, dent, rust etc.
- c. Correct dents and damages and check seat faces within the body, if any, by lapping.
- * Pay careful attention not to leave any lapping agent within the body.
- d. Confirm that all sliding and fitting parts can be moved manually and that all grooves and path's are free foreign matter.
- e. If any spring is broken or deformed, replace it with new one.
- f. When a relief valve does not function properly, repair it, following it's the prescribed disassembly and assembly procedures.
- g. Replace all seals and O-rings with new ones.

2 Relief valve

- a. Confirm that all seat faces at ends of all poppets and seats are free of defects and show uniform and consistent contact faces.
- b. Confirm manually that main poppet and seat can slide lightly and smoothly.
- c. Confirm that outside face of main poppet and inside face of seat are free from scratches and so on.
- d. Confirm that springs are free from breakage, deformation, and wear.
- e. Confirm that orifices of main poppet and seat section are not clogged with foreign matter.
- f. Replace all O-rings with new ones.
- g. When any light damage is found in above inspections, correct it by lapping.
- h. When any abnormal part is found, replace it with a completely new relief valve assembly.

4) ASSEMBLY

(1) General precaution

① In this assembly section, explanation only is shown.

For further understanding, please refer to the figures shown in the previous structure & disassembly section.

- ② Pay close attention to keeping all seals free from handling damage and inspect carefully for damage before using them.
- ③ Apply clean grease or hydraulic oil to the seal so as to ensure it is fully lubricated before assembly. Do not stretch seals so much as to deform them permanently.
- ④ In fitting O-rings, pay close attention not to roll them into their final position in addition, a twisted
- (5) O-ring cannot easily untwist itself naturally and could thereby cause inadequate sealing and thereby both internal and external oil leakage.
- ⁽⁶⁾ Tighten fitting bolts for all sections with a torque wrench adjusted to the respective tightening torque.
- \bigcirc Do not reuse removed O-rings and seals.

(2) Load check valve

- ① Assemble the load check valve and spring.
- ② Put O-rings on to plug.
- ③ Tighten plug to the specified torque.
 - · Hexagon wrench : 10 mm
 - Tightening torque : 6~7 kgf m (43.4~50.6 lbf ft)

(3) Negative control relief valve

- ① Assemble the nega-con poppet, piston, spring holder and spring together into body.
- ② Put O-ring on to plug and tighten the latter to its specified torque.
 - Hexagon wrench : 12 mm
 - Tightening torque : 8~9 kgf · m (57.8~65.1 lbf · ft)

(4) Main relief, overload relief valves

Install main relief valve, overload relief valve into the body and tighten to the specified torque.

Component	Tools	Tightening torque		
Component		kgf ⋅ m	lbf ⋅ ft	
Main relief valve	Spanner 32 mm	8~9	57.8~65.1	
Overload relief valve	Spanner 32 mm	8~9	57.8~65.1	

(5) Main spools

- ① Carefully insert the previously assembled spool assemblies into their respective bores within of body.
- * Fit spool assemblies into body carefully and slowly. Do not under any circumstances push them forcibly in.

(6) Pilot covers

- ① Fit spool covers to the non-spring assembly end of the spool, and tighten the hexagonal socket head bolts to the specified torque.
 - · Hexagon wrench : 5 mm
 - Tightening torque : 1.0~1.1 kgf m (7.2~7.9 lbf ft)
- * Confirm that O-rings have been fitted.
- ② Fit spring covers to the spring end for the spools, and tighten hexagon socket head bolts to the specified torque.
 - Hexagon wrench : 5mm
 - Tightening torque : 1.0~1.1 kgf·m (7.2~7.9 lbf·ft)
- * Confirm that O-rings have been fitted.

(7) Holding valves

- 1 Assemble the check, spring seat and poppet together into body.
- ② Tighten the poppet seat to the specified torque.
 - · Spanner : 26 mm
 - Tightening torque : 6~7 kgf · m (43.4~50.6 lbf · ft)
- ③ Fit the "piston A" under pilot cover with internal parts into hole on the poppet seat.
- ④ Tighten hexagon socket head bolt to specified torque.
 - · Hexagon wrench : 5mm
 - Tightening torque : 1.0~1.1 kgf m (7.2~7.9 lbf ft)

GROUP 5 SWING DEVICE

1. REMOVAL AND INSTALL OF MOTOR


1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect hose assembly (2).
- (5) Disconnect pilot line hoses (3, 4, 5, 6, 7, 8).
- (6) Sling the swing motor assembly (1) and remove the swing motor mounting socket bolts (9).
 - Motor device weight : 34 kg (75 lb)
- (7) Remove the swing motor assembly.
- When removing the swing motor assembly, check that all the piping have been disconnected.

2) INSTALL

- Carry out installation in the reverse order to removal.
- (2) Bleed the air from the swing motor.
- ① Remove the air vent plug.
- ② Pour in hydraulic oil until it overflows from the port.
- ③ Tighten plug lightly.
- ④ Start the engine, run at low idling and check oil come out from plug.
- 5 Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.








2. DISASSEMBLY AND ASSEMBLY OF SWING MOTOR

1) STRUCTURE



125LCR2SM22

- 1 Casing
- 2 Oil seal
- 3 Shaft
- 4 Snap ring
- 5 Roller bearing
- 6 Roller bearing
- 7 Swash plate
- 8 Cylinder block
- 9 Spring
- 10 Ball guide
- 11 Retainer plate
- 12 Piston assy
- 13 Friction plate
- 14 Separate plate
- 15 Parking piston
- 16 Spring

- 17 Spring pin
- 18 O-ring
- 19 O-ring
- 20 Valve plate
- 21 Spring pin
- 22 Valve casing
- 23 Check valve
- 24 Spring
- 25 Plug
- 26 O-ring
- 27 Plug
- 28 O-ring
- 29 Plug
- 30
- O-ring
- 31 Relief valve assy
- 32 Anti-rotating valve assy

- 33 Plug
- 34 O-ring
- 35 O-ring
- 36 Time delay valve spool
- 37 Spring seat
- 38 Spring
- 39 Restrictor
- 40 O-ring
- 41 Level gauge assy
- 42 Socket bolt
- 43 Plug
- 44 Expander
- 45 Expander
- 46 Name plate
- 47 Rivet

2) DISASSEMBLY

- (1) For easy assembly, put motor on worktable with the spline side of shaft (3) facing downwards.
- * Lay rubber plate on worktable and take care not to damage the components.



125LCR8SM03

(2) Remove snap ring (4) using snap ring plier.



125LCR8SM04

(3) Disassemble level gauge assembly (41) using pipe wrench.



125LCR8SM05

(4) Disassemble two sets of relief valve assembly(31) using 36 mm socket wrench.



(5) Unscrew socket bolt (42) (4EA) using 12 mm hexagon wrench.



125LCR8SM07

- (6) Remove valve plate (20) from valve casing.
- * Take care not to drop the valve plate (20).

(7) Remove O-ring (18) from valve casing.




125LCR8SM08




125LCR8SM09

(8) Remove plug (33) using 10 mm hexagon wrench and take out anti-rotating valve assembly (32). (same for the set on opposite side)



(9) Remove plug (29) (1EA), plug (27) (2EA) using 4 mm, 6 mm hexagon wrench.



125LCR8SM11

(10) Remove plug (25) using 32 mm socket wrench and separate spring ; spring (24) and check valve (23). (same for the set on opposite side)



125LCR8SM12

- (11) Separate each one of O-ring (40) and spring (38).
- * Do not lose spring.
- * Do not mix spring with other springs.



125LCR8SM13

(12) Remove spool (36) and spring seat (37).



(13) Remove spring (16) (24EA) from parking piston.



125LCR8SM15

(14) Disassemble parking piston (15) from casing using air gun.



125LCR8SM16

(15) Lay casing down horizontally and remove cylinder block assembly from shaft.And remove all friction plate (13) and separator plate (14).



125LCR8SM17

(16) Separate piston assembly (12), ball guide (10), retainer plate (11) and spring (9).



(17) Remove O-ring (19) from casing.



125LCR8SM19

- (18) Use a magnet to separate swash plate (7) from casing.
- * Sliding surface should be carefully treated to avoid scratches and damage.



125LCR8SM20

- (19) Disassemble shaft (3) and cylinderical roller bearing (5).
- * Do not remove cylinderical roller bearing (5) unless malfunction is detected, since it is mounted by shrink fit.



125LCR8SM21

(20) Turn casing (1) upside down and remove oil seal (2) using jig.



3) ASSEMBLY

- * Even though assembly is accomplished by reversing disassembly steps, be careful of the following.
- ① Repair the damaged part when disassemblying and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- (5) Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- 6 When assembling bolt, spread loctite.
- Put casing (1) on worktable.
 Press oil seal (2) using oil seal jig, until it reach the bottom.
- * Spread grease on external diameter of oil seal.



125LCR8SM23

(2) Mount cylinderical roller bearing (5, 6) on shaft(3) using shrink fitting method.



- (3) Assemble shaft assembly in casing using urethane hammer.
- * Take care not to damage oil seal.



125LCR8SM25

- (4) Insert swash plate (7).
- * Take care not to damage sliding surface.




125LCR8SM26

(5) After applying grease on O-ring (19), insert O-ring in casing (1).



125LCR8SM27

(6) Assemble spring (9) (9EA) in cylinder block (8).



- (7) Assemble ball guide (10) in cylinder block.
- * Take care not to damage sliding surface of cylinder block.



125LCR8SM29

- (8) Insert piston assembly (12) in retainer plate (11).
- * Do not mix piston with other piston (9EA/1set).
- Spread sufficient amount of hydraulic oil on piston assembly.



125LCR8SM30

- (9) Place all 9 pistons simultaneously into the holes of cylinder block.
- * Take care not to damage sliding surface.



125LCR8SM31

- (10) Lay casing down horizontally and put cylinder block assembly in casing.
- * Check whether cylinder block assembly rotates smoothly.



(11) Put friction plate (13) in casing.



125LCR8SM33

(12) Put separator plate (14) in casing.

* Put friction plate and separator plate alternately.



125LCR8SM34

(13) Assemble O-ring (18) in parking piston (15).* Apply grease on O-ring.



125LCR8SM35

(14) Assemble parking piston (15) in casing using jig.* Pay attention to the hole location of parking piston.



(15) Put spring (16) (24EA) in each hole of parking piston.



125LCR8SM37

- (16) Assemble restrictor (39) in spool (36).
- * Spread loctite #242.

(17) Place spool in casing.



125LCR8SM38



125LCR8SM39

(18) Assemble spring (38) & spring seat (37) in casing.




- (19) Assemble plug (27) using 6 mm hexagon wrench.
- * Tightening torque : 4.5 kgf \cdot m (32.5 lbf \cdot ft)



125LCR8SM41

- (20)Assemble plug (29) using 4 mm hexagon wrench.
- * Tightening torque : $3 \text{ kgf} \cdot \text{m} (21.7 \text{ lbf} \cdot \text{ft})$





125LCR8SM42



125LCR8SM43

- (22) Assemble plug (33) using 32 mm hexagon wrench.
- * Tightening torque : 10 kgf \cdot m (72.3 lbf \cdot ft)



(23) Caulk check valve (23) using jig. (same for the set on opposite side)



125LCR8SM45

- (24) Assemble spring (24), plug (25). (in that order) (same for the set on opposite side)
- * Tightening torque : 15 kgf \cdot m (108 lbf \cdot ft)



125LCR8SM46

(25) Assemble spring pin (21) in valve casing using jig.



125LCR8SM47

- (26) Assemble O-ring (18) & cylinderical roller bearing (6) in valve casing.
- $\ast~$ Use jig (press fit or cold shrink fit).



(27) Apply grease on steel side of valve plate (20) to prevent plate from sliding.

Assemble valve plate with the copper side facing upwards.

- * Pay attention to the assembly direction.
- * Take care not to damage sliding surface.



125LCR8SM49

- (28) Assemble valve casing by matching its holes and pins of casing and parking piston. And tighten bolt; socket (42) (4EA) using 12 mm hexagon wrench.
 - * Tightening torque : 17.5 kgf · m (127 lbf · ft)
 - * Make sure valve plate stays in place.
 - When tightening bolts, make sure mating surfaces between casing and valve casing maintain parallel to each other.

(29) Assemble relief valve assembly (31) using

* Spread grease on O-ring part of relief valve

36 mm socket wrench in valve casing.

* Tightening torque : 18 kgf · m (130 lbf · ft)

assembly.

125LCR8SM50



125LCR8SM51

(30) Assemble snap ring (4) in shaft by using snap ring plier.



(31) Wrap teflon tape 2 or 3 times around the tap part of level gauge assembly (41).And assemble it using pipe wrench.




125LCR8SM53

3. REMOVAL AND INSTALL OF REDUCTION GEAR


1) REMOVAL

- (1) Remove the swing motor assembly.For details, see removal of swing motor assembly.
- (2) Sling reduction gear assembly (1) and remove mounting bolts (2).
- (3) Remove the reduction gear assembly.
 Reduction gear device weight : 75 kg (165 lb)




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
 - \cdot Tightening torque : 17.5 kgf \cdot m (126 lbf \cdot ft)



4. DISASSEMBLY AND ASSEMBLY OF REDUCTION GEAR

1) STRUCTURE



1 Ring gear

- 2 Drive shaft
- 3 Bearing
- 4 Bearing
- 5 Ring nut
- 6 Lock plate
- 7 Hexagon bolt
- 8 Casing
- 9 Socket bolt
- 10 Carrier No. 2

- 11 Planetary gear No. 2
- 12 Needle bearing No. 2
- 13 Thrust washer No. 2
- 14 Carrier pin No. 2
- 15 Spring pin
- 16 Sun gear No. 2
- 17 Carrier No. 1
- 18 Planetary gear No. 1
- 19 Needle bearing No. 1
- 20 Thrust washer No. 1

21 Carrier pin No. 1

125LCR2SM23

- 22 Sun gear No. 1
- 23 Snap ring
- 24 Thrust plate
- 25 Sleeve
- 26 O-ring
- 27 Oil seal
- 30 Plug
- 31 Parallel pin
- 32 Thrust washer No. 1

2) DISASSEMBLY

(1) Remove the swing motor, and then place swing reduction gear on the bench.



125LCR8SM60

(2) Disassemble sun gear No.1 (22).



125LCR8SM61



125LCR8SM62



125LCR8SM63

Carrier No.1 sub assy disassembly

(3) Disassemble carrier No.1 sub assembly.

(4) Put carrier No.1 sub assembly on the bench, then remove the snap ring (23).

(5) Disassemble thrust washer No.1 (upper) (32).(3 pcs)



125LCR8SM64

(6) Disassemble planetary gear No.1 (18).(3 pcs)




125LCR8SM65

(7) Disassemble thrust plate (24).



125LCR8SM66

(8) Disassemble needle bearing No.1 (19).(3 pcs)



(9) Disassemble thrust washer No.1 (lower) (20).(3 pcs)



125LCR8SM68

- (10) After placing spring pin (15) to center of carrier pin No.1 (21) with a jig, disassemble it. (3 pcs)
- * Do not reuse spring pin, carrier and carrier pin.

(11) Disassemble sun gear No.2 (16).

(12) Disassemble carrier No.2 sub assembly.



125LCR8SM70

125LCR8SM69



Carrier No.2 sub assy disassembly

- (13) After placing spring pin (15) to center of carrier pin No.2 (14) with a press machine, disassemble it.(3 pcs)
- * Do not reuse spring pin.



125LCR8SM72

(14) Disassemble planetary gear No.2.(3 pcs)



125LCR8SM73

(15) Disassemble thrust plate (24).



125LCR8SM74



125LCR8SM75

8-67

(16) Disassemble thrust washer No.2 (13).(6 pcs)

(17) Disassemble needle bearing No.2 (12).(3 pcs)



125LCR8SM76

(18) Separate ring gear (1) from casing (8).




125LCR8SM77


(19) Loosen a bolt (7) (4 pcs), and disassemble lock plate (6).



125LCR8SM78



(20) Disassemble nut ring (5) by using the jig.



140L8SM01



125LCR8SM79

Drive shaft sub assy disassembly

(21) Separate drive shaft sub assembly from casing (8).



125LCR8SM80

(22) Disassemble taper bearing (3) and oil seal(27) by using a press machine.

(23) Disassemble sleeve (25) and O-ring (26).



125LCR8SM81



125LCR8SM82

(24) Disassemble the outer ring of taper bearing(3) in casing (8) by using the jig.



3) ASSEMBLY

- * Even though assembly is accomplished by reversing disassembly steps, be careful of the following.
- ① Repair the damaged part when disassemblying and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- (5) Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- 6 When assembling bolt, spread loctite.

Carrier No.1 sub assembly

(1) After heating the carrier No.1 (17), assemble carrier pin No.1 (21) to the side without thehole.




125LCR8SM84

(2) After drilling Ø 6 hole, assemble spring pin (15).(3 pcs)



- (3) Caulking is performed on the assembled spring pin unit.
- * To cover pins, implement the caulking in two places that are located direction of 180 degrees around assembled spring pin.



(4) Assemble thrust washer No.1 (lower) (20). (3 pcs)



125LCR8SM87

(5) Assemble needle bearing No.1 (19).(3 pcs)

(6) Assemble thrust plate (24).



125LCR8SM88



(7) Assemble planetary gear No.1 (18) of which groove is faced downward.(3 pcs)

(8) Assemble thrust washer No.1 (upper) (32).

(3 pcs)



125LCR8SM90

125LCR8SM91

- (9) Assemble snap ring (23) (3 pcs), complete carrier No.1 sub assembly.
- * Gear rotation state should be smooth.



125LCR8SM92

Carrier No.2 sub assy assembly

(10) Assemble needle bearing No.2 (12) in the planetary gear No.2 (11).



(11) After spreading grease on thrust washer No.2 (13), assemble it on both upper side and lower side of planetary gear No.2.



125LCR8SM94

(12) Assemble thrust plate (24).



125LCR8SM95

- (13) Assemble planetary gear No.2 in the carrier No.2 (10).(3 pcs)
- * Thrust washer No.2 should not separated.



125LCR8SM96

(14) Assemble carrier pin No.2 (14) to match the pin hole of the carrier No.2.(3 pcs)




(15) Assemble spring pin (15).(3 pcs)



125LCR8SM98

- (16) Caulking is performed on the assembled spring pin unit.
- To cover pins, implement the caulking in two places that are located direction of 180 degrees around assembled spring pin.



120201100111

Drive shaft sub assy assembly

(17) After heating sleeve (25), assemble O-ring(26) to groove of inside diameter in it.



- (18) Shrink fit the sleeve on drive shaft (2).
- $\, \ast \,$ Be careful of fully seat at the bottom.



(19) Shrink fit taper bearing (3) on drive shaft, complete drive shaft sub assembly.



125LCR8SM102

Casing assembly

- (20) Press outer ring of the taper bearing in the casing (8) by using the jig.

125LCR8SM103





125LCR8SM105

(22) Assemble drive shaft sub assembly.

(21) Press in oil seal (27) by using the jig.

* Be careful of the direction of the assembly.

* Be careful of damage of oil seal.

(23) After fixing drive shaft so that it does not fall, and then turn it over, press taper bearing (4).



125LCR8SM106



125LCR8SM107



125LCR8SM108



125LCR8SM109

(24) Assemble nut ring (5) by using the jig. * Tightening torque : 3.5 ± 0.4 kgf \cdot m (25.3 ± 2.9 lbf \cdot ft)

(25) Place lock plate (6) on the nut ring.

- (26) After spreading loctite #242, assemble the bolt (7) (4 pcs).
- * Tightening torque : 2.5 \pm 0.25 kgf \cdot m (18.1 \pm 1.8 lbf \cdot ft)

(27) Press parallel pin (31) by using press machine.

(28) Spread the loctite #515 on the casing with

reference to the right detail view. * Loctite should not flow into casing.



125LCR8SM110

Loctite #515

125LCR8SM111

- (29) Assemble ring gear (1) in accordance with a pin hole on casing.
- * Be careful of damage of the ring gear.



125LCR8SM112



125LCR8SM113

(30) Assemble carrier No.2 sub assembly.

(31) Assemble sun gear No.2 (16).



125LCR8SM114



125LCR8SM115



125LCR8SM116



125LCR8SM117

(32) Assemble carrier No.1 sub assembly.

(33) Assemble sun gear No.1 (22) of which grinding surface is faced downward.

(34) Fill with gear oil 3.5 liter.

GROUP 6 TRAVEL DEVICE

1. REMOVAL AND INSTALL


1) REMOVAL

- (1) Swing the work equipment 90° and lower it completely to the ground.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove the track shoe assembly.
 For details, see removal of track shoe assembly.
- (5) Remove the cover.
- (6) Remove the hose.
- * Fit blind plugs to the disconnected hoses.
- (7) Remove the bolts and the sprocket.
- (8) Sling travel device assembly (1).
- (9) Remove the mounting bolts (2), then remove the travel device assembly.
 Weight : 140 kg (310 lb)

2) INSTALL


- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the travel motor.
- ① Remove the air vent plug.
- ② Pour in hydraulic oil until it overflows from the port.
- ③ Tighten plug lightly.
- ④ Start the engine, run at low idling, and check oil come out from plug.
- 5 Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.





2. TRAVEL MOTOR


1) STRUCTURE



- Casing 1
- 2 Plug
- Oil seal 3
- 4 Piston
- 5 Piston seal
- Shaft 6
- Front ball bearing 7
- 8 Rear ball bearing
- Steel ball 9
- 10 Steel ball
- Swash plate 11
- 12 Cylinder block
- 13 Spring
- 14 Ball guide
- 15 Retainer plate
- 16 Piston assy
- 17 Friction plate

- 18 Separated plate
- 19 Parking piston
- 20 O-ring
- 21 Back up ring
- 22 O-ring
- 23 Back up ring
- 24 Valve plate
- 25 Spring pin
- 26 Spring
- 27 O-ring
- 28 Spring pin
- 29 Parallel pin
- 30 Rear cover
- 31
- Main spool assy
- 32 Cover
- 33 Spring
- 34 Restrictor

- 35 Spring
- 36 O-ring
- 37 Spring seat
- 38 Relief valve assy
- 39 O-ring
- Spool 40
- 41 Plug
- 42 Spring seat
- 43 Parallel pin
- 44 Spring
- 45 Connector
- O-ring 46
- Hexagon socket head bolt 47
- Hexagon socket head bolt 48
- 49 Hexagon socket head bolt
- 50 Check valve
- 51 Spring



- 52 Plug
- 53 O-ring
- 54 Plug
- 55 Restrictor
- 56 Restrictor
- 57 Name plate
- 58 Rivet
- 59 Ring gear
- 60 Bearing
- 61 Floating seal assy
- 62 Nut ring
- 63 Lock plate
- 64 Hexagon head bolt
- 65 Thrust plate No. 2
- 66 Planetary gear No.2
- 67 Needle bearing No.2
- 68 Inner race No. 2

125LCR2TM21


- 69 Thrust washer No. 2
- 70 Sun gear No.2
- 71 Carrier No.1
- 72 Planetary gear No.1
- 73 Needle bearing No.1
- 74 Inner race No. 1
- 75 Thrust plate No. 1
- 76 Hexagon head bolt
- 77 Countersunk head screw
- 78 Sun gear No.1
- 79 Steel ball
- 80 Cover
- 81 Hex socket head bolt
- 82 Plug
- 83 O-ring
- 84 Name plate
- 85 Rivet

2) DISASSEMBLY

- Choose a clean place, remove contaminants (dust, etc) and cleans motor before placing it on worktable.
- * Lay the rubber plate on worktable and take care not to damage the component.

125LCR8TM02

(2) Remove the connector (45) using 21 mm socket wrench.



125LCR8TM03

(3) Remove plug (41) using 21 mm socket wrench.


(4) Disassemble parallel pin (43) and spring (44).

* Do not mix spring with other springs.

* Do not lose spring.



125LCR8TM04



(5) Remove spring seat (42) and spool (40).



125LCR8TM06

125LCR8TM07

(6) Disassemble relief valve assembly (38) using 26 mm socket wrench. (2 sets)

(7) Disassemble cover (32) using 41 mm socket wrench.



125LCR8TM08

(8) Disassemble spring seat (37) and spring (33). (2 sets)



(9) Separate main spool assembly (31) from rear cover.




125LCR8TM10

(10) Unscrew socket bolt (47) (1EA), (48) (3EA), (49) (6EA) from rear cover.



125LCR8TM11





125LCR8TM12

- (12) From rear cover, disassemble valve plate (24) and O-ring (27).
- * Take care not to damage assembly surface of rear cover.




- (13) Disassemble restrictor (55, 56) (2EA).
- * Mark the number on restrictor and its hole to avoid confusing (55) and (56).




125LCR8TM14

(14) Remove plug (52).




125LCR8TM15

- (15) Remove restrictor (34) and spring (35). (2 sets)
- Do not confuse restrictor (34) and check valve (50).
- * Do not confuse spring (35) and spring (51).
- * Do not lose spring.
- * Do not mix spring with other springs.



125LCR8TM16

(16) Remove plug (52) using 5 mm hexagon wrench.




- (17) Remove check valve (50) and spring (51). (2 sets)
- Do not confuse restrictor (34) and check valve (50).
- * Do not confuse spring (35) and spring (51).
- * Do not lose spring.
- * Do not mix spring with other springs.



125LCR8TM18

- (18) From parking piston, remove spring (26) (12ea).
- * Do not lose spring.
- * Do not mix spring with other springs.





125LCR8TM20

(20) From parking piston, separate O-ring (22) and back-up ring (23).



(21) From parking piston separate O-ring (20) and back-up ring (21).



125LCR8TM22

(22) Lay casing down horizontally and remove cylinder block assembly, friction plate (17) (3EA) and separator plate (18) (4EA).




125LCR8TM23

- (23) Separate retainer plate (15) and piston assembly (16).
- * Take care not to damage sliding surface of each component.



125LCR8TM24

- (24) Disassemble ball guide (14) and spring (13) (9EA).
- * Do not lose spring.
- * Do not mix spring with other springs.



- (25) Disassemble swash plate (11) and steel ball (10).
- * Take care not to damage sliding surface.



125LCR8TM26

- (26) Disassemble shaft (6) and ball bearing (7).
- * Do not remove ball bearing unless malfunction is detected, since it is mounted by shrink fit.



125LCR8TM27

(27) Disassemble 1, 2 speed piston (4) and steel ball(9) using air gun.

(28) Disassemble piston seal (5).



125LCR8TM28



(29) Turn casing (1) upside down and remove oil seal(3) using jig.



125LCR8TM30

3) ASSEMBLY

- * Even though assembly is accomplished by reversing disassembly steps, be careful of the following.
- ① Repair the damaged part when disassemblying and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil sealwith new parts is generally recommended.
- (5) Use a torque wrench to make sure that assembly fasteners are tightened to specified values shown table1.
- 6 When assembling bolt, spread Loctite.
- (1) Put casing (1) on the worktable.



125LCR8TM31

(2) After applying grease on the external diameter of oil seal (3), insert oil seal in casing.




125LCR8TM32

(3) After applying grease on steel ball (10), insert steel ball in casing.



125LCR8TM33

- (4) After assembling piston seal (5) and steel ball (9) in 1, 2 speed piston (4), insert piston in hole of casing.
- * Check whether piston sticks in hole.
- * Use piston seal jig.



* Take care not to damage oil seal.



125LCR8TM34



125LCR8TM35

- (6) Assemble swash plate (11) by matching its hole and steel ball.
- * Take care not to damage sliding surface.



(7) Assemble spring (13) (9ea) and ball guide (14) in cylinder block (12) in that order.



125LCR8TM37

- (8) Insert piston assembly (16) in retainer plate (15) and assemble them in cylinder block.
- * Spread hydraulic oil on piston assembly.
- * Take care not to damage each component.
- * Check cylinder block and piston assembly runs properly.



125LCR8TM38

- (9) Lay casing down horizontally and assemble cylinder block assembly by matching its spline with shaft.
- * Make sure swash plate stays in place.
- * Check the assembling status of cylinder block by pressing it.



125LCR8TM39

(10) Assemble separator plate (18) (4EA) and friction plate (17) (3EA) alternately.




(11) Insert back-up ring & O-ring in parking piston.



125LCR8TM41

125LCR8TM42

- (12) Align the pin hole of parking piston (19) with oil hole of casing, assemble them using jig.
- * Spread grease on O-ring and back-up ring.
- * Take care not to damage components.



(14) Insert parallel pin (29) (2EA) in casing.

125LCR8TM43




- (15) Assemble check valve (50) and spring (51) in order.
- Do not confuse check valve (50) and restrictor (34).
- * Do not confuse spring (51) and spring (35)




125LCR8TM45

(16) Clamp plug (52) using 5 mm hexagon wrench.* Tightening torque : 1.5 kgf · m (10.9 lbf · ft)



125LCR8TM46

- $\left(17\right)Assemble restrictor \left(34\right)$ and spring $\left(35\right)$ in order.
- Do not confuse check valve (50) and restrictor (34).
- * Do not confuse spring (51) and spring (35).



125LCR8TM47



- (18) Clamp plug (52).
- $\ast~$ Tightening torque : 1.5 kgf \cdot m (10.9 lbf \cdot ft)


(19) Clamp plug (54).

* Tightening torque : 3 kgf \cdot m (21.7 lbf \cdot ft)



125LCR8TM49

- (20) Assemble restrictor (55) and (56) in rear cover.
- * Check whether the restrictor is placed in exact hole.
- * Do not confuse (55) and (56).



125LCR8TM50

(21) Assemble ball bearing (8) in rear cover using jig.



125LCR8TM51


(22) Insert spring pin (25) (2ea) and (28) in rear cover using jig.



- (23) After spreading grease sufficiently to the bottom side of valve plate (24), assemble valve plate in rear cover by matching its holes with pins.
- * Take care not to damage sliding surface.
- * Pay attention to the assembly direction.

(24) Assemble O-ring (27) in rear cover.

* Spread grease on O-ring.



125LCR8TM53

125LCR8TM54

- (25) Put rear cover upon casing, paying attention to the location of pin and hole. And tighten bolt (47), (48) and (49).
- * Tightening torque : 17.5 kgf \cdot m (127 lbf \cdot ft)
- * Make sure valve plate stays in place.
- * Check bolt position.



125LCR8TM55

(26) Assemble main spool assembly (31), spring seat(37) and spring (33) in rear cover.



(27) Settle cover (32).

* Tightening torque : 15 kgf \cdot m (108 lbf \cdot ft)



125LCR8TM57

(28) Insert relief valve (38) in rear cover.

* Tightening torque : $15 \text{ kgf} \cdot \text{m}$ (108 lbf $\cdot \text{ft}$)



125LCR8TM58

- (29) After clamping connector (45) to rear cover, assemble spool (40).
- * Tightening torque : 5 kgf \cdot m (36 lbf \cdot ft)




125LCR8TM59

(30) After inserting parallel pin (43), assemble seatspring (42).



- (31) After assembling spring (44) in order, clamp plug (41).
- * Tightening torque : 5 kgf \cdot m (36 lbf \cdot ft)



125LCR8TM61

3. TRAVEL REDUCTION GEAR DISASSEMBLY


1) While travel reduction gear is tilted to one side disassemble PF3/8 plug (24), remove gear oil and place motor side to the bench.



125LCR8TM70

 Disassemble cover (22) by unscrewing the M10 bolts (23) (12 pcs).

3) Disassemble sun gear No.1 (20) and steel ball (21).



125LCR8TM71



125LCR8TM72



125LCR8TM73

4) Disassemble carrier No.1 assembly.

Carrier No. 1 sub assy disassembly

5) Disassemble M8 bolt (18) from the carrier assembly. (3 pcs)



125LCR8TM74

6) Disassemble thrust plate No.1 (17) from the carrier assembly.



125LCR8TM75

7) Disassemble planetary gear No.1 (14).(3 pcs)



125LCR8TM76

- 8) Disassemble needle bearing (15).(3 pcs)
- * Do not disassemble inner race in the absence of abnormalities.



9) Disassemble sun gear No.2 (12).



125LCR8TM78



125LCR8TM79



125LCR8TM80



125LCR8TM81

10) Disassemble M10 bolt (6).(4 pcs)

11) Disassemble thrust washer No.2 (11).(4 pcs)

12) Disassemble planetary gear No.2 (8).(4 pcs)

13) Disassemble needle bearing No.2 (9).(4 pcs)



125LCR8TM82

- 14) Disassemble thrust plate No.2 (7).(4 pcs)
- * Do not disassemble inner race in the absence of abnormalities.

15) Disassemble M10 bolt (6) and M8 screw bolt (19).



125LCR8TM83

125LCR8TM84



125LCR8TM85

16) Disassemble lock plate (5).

17) Disassemble nut ring (4) by using the jig.



125LCR8TM86

18) Disassemble ring gear sub assembly from motor assembly.



125LCR8TM87

19) Disassemble folating seal assembly (3) from ring gear sub assembly and motor assembly.



125LCR8TM89

- 20) Disassemble bearing (2) (2EA) from ring gear assembly.
- * Do not disassemble bearing in the absence of abnormalities.

4. TRAVEL REDUCTION GEAR ASSEMBLY

- * Even though assembly is accomplished by reversing disassembly steps, be careful of the following.
- ① Repair the damaged part when disassemblying and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- (5) Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- 6 When assembling bolt, spread loctite.
- 1) Put carrier No.1 (13) on the jig, and shrink-fit inner race No.1 (16) to carrier pin.(3 places)
- * Do not tilt inner race to one side.
- * Match inner race and end of carrier pin.



125LCR8TM90

2) Assemble needle bearing No.1 (15).(3 pcs)



3) Assemble planetary gear No.1 (14) of which groove is faced downward. (3 places)



125LCR8TM92

4) Assemble thrust plate No.1 (17).



125LCR8TM93

- 5) After spreading loctite #242, assemble the M8 bolt (18).(3 pcs)
- ** Tightening torque : 2.7 \pm 0.3 kgf \cdot m (19.5 \pm 2.2 lbf \cdot ft)
- * After the assembly, instantly check the noise and interference by rotatong the gear.




125LCR8TM94

6) First, place bearing (2) on the ring gear (1), then put jig on it, then press it with press machine.



- 7) After turning ring gear over, assemble bearing the same way.
- * Be care of nick and safety when turn ring gear over.



125LCR8TM96

- 8) Assemble floating seal assembly (3) by using the jig.
- * After assembling, wipe steel-lined section with alcohol.
- * Flatness deviation has to be less than 1 mm.



125LCR8TM97

- 9) Place floating seal assembly on the motor assembly, then assemble it.
- * After assembling, wipe steel-lined section with alcohol.
- * Flatness deviation has to be less than 1 mm.



125LCR8TM98

- 10) After arriving safely ring gear sub assembly in the motor assembly, press it with press machine.
- * After press-fitting, clamp ring gear to fix it.
- When using the press pay attention to bearing damage.



- 11) After assembling nut ring (4) by using the jig, disassemble the clamping.
- * Tightening torque : 60 kgf \cdot m (434 lbf \cdot ft)



125LCR8TM100

12) Place lock plate (5) on the nut ring groove.Select best position from one of 4 casing hole to assemble lock plate.




125LCR8TM101

- Place lock plate th the direction which nut ring is loosed and then assemble M10 bolt (6) with M8 screw (19) after spreading loctite #242.(Refer to assembly detail drawing)
- ** Tightening torque (M10) : 5.5 \pm 0.6 kgf \cdot m (39.8 \pm 4.3 lbf \cdot ft)
- ** Tightening torque (M8) $:2.7 \pm 0.3 \text{ kgf} \cdot \text{m}$ (19.5 $\pm 2.2 \text{ lbf} \cdot \text{ft}$)
- Make sure that M8 bolt doesn't stick out of lock plate.
- * Assembly detail drawing lock plate.



125LCR8TM102



14) Shrink fit the inner race No.2 (10).(4 pcs)



125LCR8TM104

15) Assemble thrust plate No.2 (7).(4 pcs)



125LCR8TM105



125LCR8TM106



125LCR8TM107

16) Assemble needle bearing No.2 (9).(4 pcs)

8-107

- 17) Assemble planetary gear No.2 (8).(4 pcs)
- $\ast~$ Grooves of planetary gear will be facing up.

18) Assemble thrust washer No.2 (11).(4 pcs)



125LCR8TM108

19) After spreading loctite #242, assemble the M10 bolt (6).(4 pcs)

** Tightening torque : 5.5 \pm 0.6 kgf \cdot m (39.8 \pm 4.3 lbf \cdot ft)



125LCR8TM109



125LCR8TM110



125LCR8TM111

21) Assemble carrier No.1 assembly.

20) Assemble sun gear No.2 (12).

22) Assemble sun gear No.1 (20).




125LCR8TM112

23) Place steel ball (21) on the sun gear No.1.



125LCR8TM113



125LCR8TM114

24) Spread the loctite #515 on the cover (22) with

25) Place cover (22) to fit the bolt holes.

reference to the right detail view.



- 26) After spreading loctite #242, assemble the M10 bolt (23).(12 pcs)
- * Tightening torque : 6.3 \pm 0.7 kgf \cdot m (45.6 \pm 5.1 lbf \cdot ft)



125LCR8TM116

27) Inject the 2.5 \pm 0.3 liter gear oil to PF3/8 tap section.

28) After assembling the O-ring (25) to the plug (24),

assemble it to the cover.(3 pcs) * Tightening torque : 5 \pm 0.5 kgf \cdot m



125LCR8TM117



125LCR8TM118

 $(36.2 \pm 3.6 \, \text{lbf} \cdot \text{ft})$

GROUP 7 RCV LEVER

1. REMOVAL AND INSTALL


1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- (4) Loosen the socket bolt (1).
- (5) Remove the cover of the console box.
- (6) Disconnect pilot line hoses (3).
- (7) Remove the pilot valve assembly (2).
- When removing the pilot valve assembly, check that all the hoses have been disconnected.

2) INSTALL


- (1) Carry out installation in the reverse order to removal.
- (2) Confirm the hydraulic oil level and check the hydraulic oil leak or not.





2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE



1409S2RL02

- Case 1
- 2 Plug
- 3 Bushing
- Spool 4 5 Shim
- 6
- Spring 7

9 Push rod 10 Spring

8

Stopper

- 11 Push rod
- 12 Spring
- Spring seat 13 14 Plug
- Spring seat

15	O-ring	22
16	Rod seal	23
17	Plate	24
18	Boot	25
19	Joint assembly	26
20	Swash plate	27
21	Adjusting nut	28

- Lock nut Handle assembly Handle bar Nut Boot Spring pin
- Bushing

2) TOOLS AND TIGHTENING TORQUE

(1) Tools


Tool name		Remark		
Allen wrench	6			
Spappar	22			
Spanner	27			
(+) Driver	Length 150			
(-) Driver	Width 4~5			
Torque wrench		Capable of tightening with the specified torques		


(2) Tightening torque

Part name	Item	Size	Torque	
Faithame			kgf ∙ m	lbf ⋅ ft
Plug	2	PT 1/8	3.0	21.7
Joint	19	M14	3.5	25.3
Swash plate	20	M14	5.0±0.35	36.2±2.5
Adjusting nut	21	M14	5.0±0.35	36.2±2.5
Lock nut	22	M14	5.0±0.35	36.2±2.5


3) DISASSEMBLY

- (1) Clean pilot valve with kerosene.
- * Put blind plugs into all ports
- (2) Fix pilot valve in a vise with copper (or lead) sheets.
- (3) Remove end of boot (26) from case (1) and take it out upwards.
- * For valve with switch, remove cord also through hole of casing.







(4) Loosen lock nut (22) and adjusting nut(21) with spanners on them respectively, and take out handle section as one body.




(5) Remove the boot (18).





(6) Loosen adjusting nut (21) and swash plate (20) with spanners on them respectively, and remove them.






- (7) Turn joint anticlockwise to loosen it, utilizing jig (special tool).
- When return spring (10) is strong in force, plate (17), plug (14) and push rod (11) will come up on loosening joint.
 Pay attention to this.







(8) Remove plate (17).




- (9) When return spring (10) is weak in force, plug (14) stays in casing because of sliding resistance of O-ring.
- * Take it out with minus screwdriver. Take it out, utilizing external periphery groove of plug and paying attention not to damage it by partial loading.
- During taking out, plug may jump up due to return spring (10) force.
 Pay attention to this.
- (10) Remove reducing valve subassembly and return spring (10) out of casing.
- Record relative position of reducing valve subassembly and return springs.







(11) Loosen hexagon socket head plug (2) with hexagon socket screw key.




- (12) For disassembling reducing valve section, stand it vertically with spool (4) bottom placed on flat workbench. Push down spring seat (7) and remove two pieces of semicircular stopper (8) with tip of small minus screwdriver.
- * Pay attention not to damage spool surface.
- * Record original position of spring seat (7).
- Do not push down spring seat more than 6mm.
- (13) Separate spool (4), spring seat (7), spring(6) and shim (5) individually.
- ** Until being assembled, they should be handled as one subassembly group.







(14) Take push rod (11) out of plug (14).




(15) Remove O-ring (15) and rod seal (16) from plug (14).


Use small minus screwdriver or so on to remove this seal.





(16) Remove lock nut (22) and then boot (26).





(16) Cleaning of parts

- Put all parts in rough cleaning vessel filled with kerosene and clean them (rough cleaning).
- If dirty part is cleaned with kerosene just after putting it in vessel, it may be damaged. Leave it in kerosene for a while to loosen dust and dirty oil.
- If this kerosene is polluted, parts will be damaged and functions of reassembled valve will be degraded.

Therefore, control cleanliness of kerosene fully.

- ② Put parts in final cleaning vessel filled with kerosene, turning it slowly to clean them even to their insides (finish cleaning).
- * Do not dry parts with compressed air, since they will be damaged and/or rusted by dust and moisture in air.


(17) Rust prevention of parts

Apply rust-preventives to all parts.


If left as they after being cleaned, they will be rusted and will not display their functions fully after being reassembled.


4) ASSEMBLY

- (1) Tighten hexagon socket head plug (2) to the specified torque.
- * Tighten two bolts alternately and slowly.
- 36078RL15
- (2) Put shim (5), springs (6) and spring seat(7) onto spool (4) in this order.




- (3) Stand spool vertically with its bottom placed on flat workbench, and with spring seat pushed down, put two pieces of semicircular stopper (8) on spring seat without piling them on.
- Assemble stopper (8) so that its sharp edge side will be caught by head of spool. Do not push down spring seat more than 6mm.
- (4) Assemble spring (10) into casing (1).Assemble reducing valve subassembly into casing.
- * Assemble them to their original positions.







(5) Assemble O-ring (15) onto plug (14).




- (6) Assemble rod seal (16) to plug (14).
- * Assemble seal in such lip direction as shown below.




- (7) Assemble push rod (11) to plug (14).
- $\ast~$ Apply working oil on push-rod surface.



- (8) Assemble plug subassembly to casing.
- When return spring is weak in force, subassembly stops due to resistance of O-ring.




(9) When return spring is strong in force, assemble 4 sets at the same time, utilizing plate (17), and tighten joint (19) temporarily.




(10) Fit plate (17).

(11) Tighten joint (19) with the specified torque to casing, utilizing jig.




(12) Assemble swash plate (20) to joint (19).


- Screw it to position that it contacts with 4 push rods evenly.
- * Do not screw it over.




- (13) Assemble adjusting nut (21), apply spanner to width across flat of plate (20) to fix it, and tighten adjusting nut to the specified torque.
- * During tightening, do not change position of disk.




(14) Fit boot (18) to plate.




(15) Fit boot (26) and lock nut (22), and handle subassembly is assembled completely.







(16) Pull out cord and tube through adjusting nut hole provided in direction 60° to 120° from casing hole.




- (17) Assemble bushing (28) to plate and pass cord and tube through it.
- * Provide margin necessary to operation.




(18) Determine handle direction, tighten lock nut (22) to specified torque to fix handle.



(19) Apply grease to rotating section of joint and contacting faces of disk and push rod.



- (20) Assemble lower end of bellows to casing.
- (21) Inject volatile rust-preventives through all ports and then put blind plugs in ports.



GROUP 8 TURNING JOINT


1. REMOVAL AND INSTALL


1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- A Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect all hoses.
- (5) Sling the turning joint assembly (1) and remove the mounting bolt (2).
 - Weight : 50 kg (110 lb)
 - \cdot Tightening torque : 12.3 \pm 1.3 kgf \cdot m (88.9 \pm 9.4 lbf \cdot ft)
- (6) Remove the turning joint assembly.
- * When removing the turning joint, check that all the hoses have been disconnected.

2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- * Take care of turning joint direction.
- * Assemble hoses to their original positions.
- * Confirm the hydraulic oil level and check the hydraulic oil leak or not.








2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE



14098TJ03


- 1 Hub
- 2 Shaft
- 3 Cover
- 4 Spacer
- 5 Shim

- 6 Shim
- 7 Slipper seal
- 8 O-ring
- 9 O-ring
- 10 O-ring


- 11 Wear ring
- 12 Retainer ring
- 13 Plug
- 14 Hexagon bolt
- 15 Spring washer

2) DISASSEMBLY


- * Before the disassembly, clean the turning joint.
- (1) Remove bolts (14), washer (15) and cover(3).




- (2) Remove shim (6) and O-ring (10).
- (3) Remove retainer ring (12), spacer (4) and shim (5).




- (4) Place hub (1) on a V-block and by using a wood buffer at the shaft end, hit out shaft(2) to about 1/2 from the body with a hammer.
- * Take care not to damage the shaft (2) when remove hub (1) or rest it sideway.
- * Put a fitting mark on hub (1) and shaft (2).
- (5) Remove six slipper seals (7) and O-ring(9), two wear ring (11) from hub (1).






3) ASSEMBLY


- * Clean all parts.
- * As a general rule, replace oil seals and O-ring.
- * Coat the sliding surfaces of all parts with engine oil or grease before installing.
- (1) Fix seven slipper seal (7) and O-ring (9), two wear ring (11) to hub (1).
- (2) Fit O-ring (8) to shaft (2).



(3) Set shaft (2) on block, tap hub (1) with a plastic hammer to install.




- (4) Fit shim (5), spacer (4) and retainer ring (12) to shaft (2).
- (5) Fit O-ring (10) to hub (1).
- (6) Fit shim (6) to shaft (2).



(7) Install cover (3) to body (1) and tighten bolts (14).
· Torque : 10~12.5 kgf ⋅ m

(72.3~90.4 lbf · ft)



GROUP 9 BOOM, ARM AND BUCKET CYLINDERS


1. REMOVAL AND INSTALL


1) BUCKET CYLINDER

(1) Removal


- Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- * Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- * Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Set block between bucket cylinder and arm.
- ② Remove bolt (2), nut (3) and pull out pin (1).
- * Tie the rod with wire to prevent it from coming out.








③ Disconnect bucket cylinder hoses (4) and put plugs (5) on cylinder pipe.



- ④ Sling bucket cylinder assembly (8) and remove bolt (6) then pull out pin (5).
- (5) Remove bucket cylinder assembly (8).
 - Weight : 78 kg (172 lb)



(2) Install


- Carry out installation in the reverse order to removal.
- ▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- * Bleed the air from the bucket cylinder.
- * Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2) ARM CYLINDER


(1) Removal

- Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- * Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury. Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Set block between arm cylinder and boom.







- ② Remove bolt (2) and pull out pin (1).
- * Tie the rod with wire to prevent it from coming out.



- ③ Disconnect arm cylinder hoses (4) and put plugs on cylinder pipe.
- ④ Disconnect greasing pipings (5).



- ⑤ Sling arm cylinder assembly(8) and remove bolt (7) then pull out pin (6).
- 6 Remove arm cylinder assembly (8).
 - Weight : 118 kg (260 lb)



(2) Install

- ① Carry out installation in the reverse order to removal.
- ▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- * Bleed the air from the arm cylinder.
- * Confirm the hydraulic oil level and check the hydraulic oil leak or not.

3) BOOM CYLINDER

(1) Removal

- Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- * Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- * Loosen the breather slowly to release the pressure inside the hydraulic tank.
- A Escaping fluid under pressure can penetrate the skin causing serious injury.
- Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.

③ Remove bolt (4), stopper (5) and pull out


* Tie the rod with wire to prevent it from


- ① Disconnect greasing hoses (1).
- 2 Sling boom cylinder assembly.


pin (2).

coming out.











④ Lower the boom cylinder assembly (6) on a stand.

⑤ Disconnect boom cylinder hoses (7) and put plugs on cylinder pipe.



- 6 Remove bolt (9) and pull out pin (8).
- \bigcirc Remove boom cylinder assembly (6).
 - Weight : 96 kg (212 lb)




(2) Install

- Carry out installation in the reverse order to removal.
- ▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- $\ast~$ Bleed the air from the boom cylinder.
- * Conformed the hydraulic oil level and check the hydraulic oil leak or not.

2. DISASSEMBLY AND ASSEMBLY


1) STRUCTURE

(1) Bucket cylinder



Back up ring


8-136



- Tube assembly 1
- 2 Pin bushing
- 3 Rod assembly
- 4 Pin bushing
- 5 Rod cover
- 6 Rod bushing
- 7 Retaining ring
- 8 Buffer seal
- 9 U-packing
- 10 Back up ring
- Dust wiper 11
- 12 Retaining ring
- 13 O-ring
- Back up ring 14
- 15 O-ring

- Cushion ring 16
- Piston 17
- 18 Piston seal
- 19 Wear ring
- 20 Dust ring
- 21 O-ring
- 22 Back up ring
- 23 Piston nut
- 24 Set screw
- 25 Cushion plunger
- 26 Stop ring
- 27 Hexagon socket bolt
- 28 Check
- 29 Spring
- 30 Bracket

- 31 O-ring
- 32 Plug
- 33 Pipe band assembly
- 34 Pipe band
- 35
- Spring washer
- Hexagon bolt 36
- 37 Pipe assembly
- 38 O-ring
- Spring washer 39
- Hexagon socket bolt 40
- Clamp 41
- 42 Spring washer
- 43 Hexagon bolt
- Pin wiper 44
- 45 O-ring



- 3 Rod assembly
- 4 Pin bushing
- 5 Rod cover


1

2

- 6 Rod bushing
- 7 Retaining ring
- 8 Buffer seal
- 9 U-packing
- 10 Back up ring
- 11 Dust wiper
- 12 Retaining ring
- 13 O-ring
- 14 Back up ring
- 15 O-ring

- 18 Piston seal
- 19 Wear ring
- 20 Dust ring
- 21 O-ring
- 22 Back up ring
- 23 Piston nut
- 24 Set screw
- 25 Hexagon socket bolt
- 26 Pipe band assembly
- 27 Pipe band
- 28 Spring washer
- 29 Hexagon bolt
- 30 Pipe assembly

- 33 Hexagon socket bolt
- 34 Pipe assembly
- 35 O-ring
- 36 Spring washer
- 37 Hexagon socket bolt
- 38 Hexagon nut
- 39 Clamp
- 40 Spring washer
- 41 Hexagon bolt
- 42 Pin wiper
- 43 O-ring



1 Tube assembly

- 2 Pin bushing
- 3 Rod assembly
- 4 Pin bushing
- 5 Rod cover
- 6 Rod bushing
- 7 Retaining ring
- 8 Buffer seal
- 9 U-packing
- 10 Back up ring
- 11 Dust wiper

- 12 Retaining ring
- 13 O-ring
- 14 Back up ring
- 15 O-ring
- 16 Piston
- 17 Piston seal
- 18 Wear ring
- 19 Dust ring
- 20 O-ring
- 21 Back up ring
- 22 Set screw

- 23 Hexagon socket bolt
- 24 Check valve
- 25 Hexagon socket bolt
- 26 Pipe assembly
- 27 O-ring
- 28 Spring washer
- 29 Hexagon socket bolt
- 30 Pin wiper
- 31 Grease nipple

2) TOOLS AND TIGHTENING TORQUE

(1) Tools


Tool name	Remark			
	6			
	8 - B			
Allen wrench	14			
	17			
Champer	7			
Spanner	8			
(-) Driver	Small and large sizes			
Torque wrench	Capable of tightening with the specified torques	Capable of tightening with the specified torques		

(2) Tightening torque


Part name		ltem	Size	Torque		
		nem	Size	kgf ∙ m	lbf ⋅ ft	
	Bucket cylinder	24	M14	23.5±0.5	170±3.6	
	Boom cylinder	25	M14	23.5±0.5	170±3.6	
Socket head bolt	Arm cylinder	27	M14	23.5±0.5	170±3.6	
	Deres enlindes	29	M8	3.25±0.25	23.5±1.8	
	Dozer cylinder	23	M14	23.5±0.5	170±3.6	
	Bucket cylinder	32, 36	M10	5.75±0.25	41.6±1.8	
Pipe mounting socket head bolt	Boom cylinder	33, 37	M8	3.25 ± 0.25	23.5±1.8	
	Arm cylinder	40	M10	5.75±0.25	41.6±1.8	
Dioton put	Boom cylinder	23	M48	130±13	940±94	
Piston nut	Arm cylinder	23	M55	130±13	940±94	
	Bucket cylinder	17	M48	130±13	940±94	
	Boom cylinder	17	M60	75±7.5	542±54.2	
Piston	Arm cylinder	17	M65	75±7.5	542±54.2	
	Dozer cylinder - Rear	16	M58	130±13	940±94	

3) DISASSEMBLY


- (1) Remove cylinder head and piston rod
 - * Procedures are based on the boom cylinder.
- 1 Hold the clevis section of the tube in a vise.
- * Use mouth pieces so as not to damage the machined surface of the cylinder tube. Do not make use of the outside piping as a locking means.
- ② Pull out rod assembly (3) about 200 mm (7.1in). Because the rod assembly is rather heavy, finish extending it with air pressure after the oil draining operation.



- ③ Loosen and remove socket bolts (25) of the gland in sequence.
- * Cover the extracted rod assembly (3) with rag to prevent it from being accidentally damaged during operation.




- ④ Draw out cylinder head and rod assembly together from tube assembly (1).
- Since the rod assembly is heavy in this case, lift the tip of the rod assembly (3) with a crane or some means and draw it out. However, when rod assembly (3) has been drawn out to approximately two thirds of its length, lift it in its center to draw it completely.




Note that the plated surface of rod assembly (3) is to be lifted. For this reason, do not use a wire sling and others that may damage it, but use a strong cloth belt or a rope.


- ⑤ Place the removed rod assembly on a wooden V-block that is set level.
- * Cover a V-block with soft rag.



(2) Remove piston and cylinder head


- Remove set screw (24) and piston nut (23).
- Since set screw (24) and piston nut (23) is tightened to a high torque, use a hydraulic and power wrench that utilizers a hydraulic cylinder, to remove the lock set screw (24) and piston nut (23).
- ② Remove piston assembly (17), back up ring (22), and O-ring (21).
- ③ Remove the cylinder head assembly from rod assembly (3).
- If it is too heavy to move, move it by striking the flanged part of cylinder head with a plastic hammer.
- Pull it straight with cylinder head assembly lifted with a crane.
 Exercise care so as not to damage the lip of pin bushing (4) and packing (8,9,10,11,12) by the threads of rod assembly (3).





(3) Disassemble the piston assembly

- ① Remove wear ring (19).
- ② Remove dust ring (20) and piston seal (18).
- * Exercise care in this operation not to damage the grooves.



(4) Disassemble cylinder head assembly


- Remove back up ring (14) and O-ring (13).
- 2 Remove retaining ring (12), dust wiper3 (11).

Remove back up ring (10), U-packing

* (9) and buffer seal (8).
 Exercise care in this operation not to
 * damage the grooves.


Do not remove seal and ring, if does not * damaged.

Do not remove bushing (6).



3) ASSEMBLY


- (1) Assemble cylinder head assembly
 - * Check for scratches or rough surfaces if found smooth with an oil stone.
- ① Coat the inner face of rod cover (5) with hydraulic oil.




② Coat dust wiper (11) with grease and fit dust wiper (11) to the bottom of the hole of dust seal.

At this time, press a pad metal to the metal ring of dust seal.


③ Fit retaining ring (12) to the stop face.




- ④ Fit back up ring (10), U-packing (9) and buffer seal (8) to corresponding grooves, in that order.
- * Coat each packing with hydraulic oil before fitting it.
- Insert the backup ring until one side of it is inserted into groove.



- U-packing (9) has its own fitting direction.
 Therefore, confirm it before fitting them.
- Fitting U-packing (9) upside down may damage its lip. Therefore check the correct direction that is shown in fig.




- ⑤ Fit back up ring (14) to rod cover (5).
- * Put the backup ring in the warm water of $30\sim50^{\circ}$ C.
- ⑥ Fit O-ring (13) to rod cover (5).




(2) Assemble piston assembly


- Check for scratches or rough surfaces.
 If found smooth with an oil stone.
- ① Coat the outer face of piston (17) with hydraulic oil.



- ② Fit piston seal (18) to piston.
- * Put the piston seal in the warm water of 60~100°C for more than 5 minutes.
- * After assembling the piston seal, press its outer diameter to fit in.




③ Fit wear ring (19) and dust ring (20) to piston (17).




(3) Install piston and cylinder head

- ① Fix the rod assembly to the work bench.
- ② Apply hydraulic oil to the outer surface of rod assembly (3), the inner surface of piston and cylinder head.
- ③ Insert cylinder head assembly to rod assembly.




- ④ Insert cushion ring (16) to rod assembly.
- * Note that cushion ring (16) has a direction in which it should be fitted.



(5) Fit piston assembly to rod assembly. Tightoning t e :

•	lightening	torque
•	lightening	torque


	ltem	kgf ∙ m	lbf ∙ ft
	Bucket	130 ± 13	940±94
17	Boom	75±7.5	542 ± 54.2
	Arm	75±7.5	542±54.2



6 Fit piston nut (23) and tighten the set screw (24).


•	Tightening	torque :
---	------------	----------


Item		kgf ∙ m	lbf ∙ ft	
23	Boom Arm	130±13	940±94	
24	7 4111	1.5	10.8	



(3) Overall assemble

- Place a V-block on a rigid work bench. Mount the tube assembly (1) on it and fix the assembly by passing a bar through the clevis pin hole to lock the assembly.
- ② Insert the rod assembly in to the tube assembly, while lifting and moving the rod assembly with a crane.
- * Be careful not to damage piston seal by thread of tube assembly.
- ③ Match the bolt holes in the cylinder head flange to the tapped holes in the tube assembly and tighten socket bolts to a specified torque.
- * Refer to the table of tightening torque.





GROUP 10 UNDERCARRIAGE


1. TRACK LINK


1) REMOVAL

- Move track link until master pin is over front idler in the position put wooden block as shown.
- (2) Loosen tension of the track link.
- If track tension is not relieved when the grease valve is loosened, move the machine backwards and forwards.
- Window Window

Grease leaking hole is not existing. So, while unscrew the grease nipple, grease is not leaking until the grease nipple is completely coming out. If the tension is not released in advance, the grease nipple can be suddenly popped out by pressurized grease.

- (3) Push out master pin by using a suitable tool.
- (4) Move the machine slowly in reverse, and lay out track link assembly (1).
- * Jack up the machine and put wooden block under the machine.
- Don't get close to the sprocket side as the track shoe plate may fall down on your feet.






2) INSTALL

(1) Carry out installation in the reverse order to removal.


Adjust the tension of the track link.




2. CARRIER ROLLER

1) REMOVAL


(1) Loosen tension of the track link.



(2) Jack up the track link height enough to permit carrier roller removal.



- (3) Loosen the lock nut (1).
- (4) Open bracket(2) with a screwdriver, push out from inside, and remove carrier roller assembly.
 - \cdot Weight : 13 kg (29 lb)




2) INSTALL

(1) Carry out installation in the reverse order to removal.


3. TRACK ROLLER

1) REMOVAL


(1) Loosen tension of the track link.



- (2) Using the work equipment, push up track frame on side which is to be removed.
- * After jack up the machine, set a block under the unit.



(3) Remove the mounting bolt (1) and draw out the track roller (2).
Weight : 24.6 kg (54.2 lb)




2) INSTALL

(1) Carry out installation in the reverse order to removal.


4. IDLER AND RECOIL SPRING

1) REMOVAL


Remove the track link.
 For detail, see removal of track link.



- (2) Sling the recoil spring (1) and pull out idler and recoil spring assembly from track frame, using a pry.
 - Weight : 215 kg (474 lb)




(3) Remove the bolts (2), washers (3) and separate ilder from recoil spring.




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- Make sure that the boss on the end face of the recoil cylinder rod is in the hole of the track frame.



3) DISASSEMBLY AND ASSEMBLY OF IDLER

(1) Structure




- 1 Shell
- 2 Shaft
- 3 Seal assembly
- 4 Bushing
- 5 Bracket
- 6 O-ring

- 7 Spring pin
- 8 Plug


8-152

(2) Disassembly

- 1 Remove plug and drain oil.
- ⁽²⁾ Draw out the spring pin (7), using a press.




- 3 Pull out the shaft (2) with a press.
- ④ Remove seal (3) from idler (1) and bracket (5).
- ⁽⁵⁾ Remove O-ring (6) from shaft.



6 Remove the bushing (4) from idler, using a special tool.

Only remove bushing if replacement is necessity.





(3) Assembly

- * Before assembly, clean the parts.
- * Coat the sliding surfaces of all parts with oil.
- Cool up bushing (4) fully by some dry ice and press it into shell (1).


Do not press it at the normal temperature, or not knock in with a hammer even after the cooling.

- ② Coat O-ring (6) with grease thinly, and install it to shaft (2).
- ③ Insert shaft (2) into bracket (5) and drive in the spring pin (7).







4 Install seal (3) to shell (1) and bracket (5).









6 Install bracket (5) attached with seal (3).



⑦ Knock in the spring pin (7) with a hammer.




⑧ Lay bracket (5) on its side. Supply engine oil to the specified level, and tighten plug.



4) DISASSEMBLY AND ASSEMBLY OF RECOIL SPRING

(1) Structure



- 1 Body
- 2 Tie bar
- 3 Spring
- 4 Bracket
- 5 Lock nut

- 6 Lock plate
- 7 Bolt
- 8 Spring washer
- 9 Rod seal
- 10 Back up ring


- 11 Dust seal
- 12 Rod assembly
- 13 Grease valve

(2) Disassembly


- ① Apply pressure on spring (3) with a press.
- The spring is under a large installed load. This is dangerous, so be sure to set properly.
 - Spring set load : 8497 kg (18733 lb)
- ② Remove bolt (7), spring washer (8) and lock plate (6).
- ③ Remove lock nut (5).

Take enough notice so that the press which pushes down the spring, should not be slipped out in its operation.


④ Lighten the press load slowly and remove bracket (4) and spring (3).



- 5 Remove rod (12) from body (1).
- 6 Remove grease value (13) from rod (12).




Remove rod seal (9), back up ring (10) and dust seal (11).



(3) Assembly

Install dust seal (11), back up ring (10) and rod seal (9) to body (1).


When installing dust seal (11) and rod seal (9), take full care so as not to damage the lip.




② Pour grease into body (1), then push in rod (12) by hand.


After take grease out of grease valve mounting hole, let air out.

- If air letting is not sufficient, it may be difficult to adjust the tension of crawler.
- ③ Fit grease valve (13) to rod (12).
 •Tightening torque : 13±1.0 kgf·m (94±7.2 lbf·ft)
- ④ Install spring (3) and bracket (4) to body (1).
- (5) Apply pressure to spring (3) with a press and tighten lock nut (5).
- $\,\, \ensuremath{\overset{\scriptstyle \ensuremath{\scriptstyle \ensurema$
- * During the operation, pay attention specially to prevent the press from slipping out.






- ⑥ Lighten the press load and confirm the set length of spring (3).
- ⑦ After the setting of spring (3), install lock plate (6), spring washer (8) and bolt (7).



GROUP 11 WORK EQUIPMENT

1. STRUCTURE




21078DA44

2. REMOVAL AND INSTALL


1) BUCKET ASSEMBLY

(1) Removal


① Lower the work equipment completely to ground with back of bucket facing down.



② Remove nut (1), bolt (2) and draw out the pin (B).




③ Remove nut (3), bolt (4) and draw out the pin (A) then remove the bucket assembly.
 · Weight (0.40 m³) : 410 kg (910 lb)



(2) Install

- Carry out installation in the reverse order to removal.
- A When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- Adjust the bucket clearance.
 For detail, see operation manual.




2) ARM ASSEMBLY


(1) Removal


- * Loosen the breather slowly to release the pressure inside the hydraulic tank.
- A Escaping fluid under pressure can penetrated the skin causing serious injury.
- Remove bucket assembly.
 For details, see removal of bucket assembly.
- ② Disconnect bucket cylinder hose (1).
- ▲ Fit blind plugs (5) in the piping at the chassis end securely to prevent oil from spurting out when the engine is started.
- ③ Sling arm cylinder assembly, remove spring, pin stopper and pull out pin.
- * Tie the rod with wire to prevent it from coming out.
- ④ For details, see removal of arm cylinder assembly.

Place a wooden block under the cylinder and bring the cylinder down to it.

- ⑤ Remove bolt (2), plate (3) and pull out the pin (4) then remove the arm assembly.
 - Weight (2.26 m) : 340 kg (750 lb)
- When lifting the arm assembly, always lift the center of gravity.







(2) Install

- ① Carry out installation in the reverse order to removal.
- A When lifting the arm assembly, always lift the center of gravity.
- * Bleed the air from the cylinder.


3) BOOM CYLINDER


(1) Removal

- Remove arm and bucket assembly.
 For details, see removal of arm and bucket assembly.
- ⁽²⁾ Remove boom cylinder assembly from boom.


For details, see removal of arm cylinder assembly.

- ③ Disconnect head lamp wiring.
- ④ Disconnect bucket cylinder hose (2) and arm cylinder hose (1).
- When the hose are disconnected, oil may spurt out.
- 5 Sling boom assembly (3).






- 6 Remove bolt (4), plate (5) and pull out the pin (6) then remove boom assembly.
 Weight (4.30 m) : 710 kg (1570 lb)
- When lifting the boom assembly always lift the center of gravity.



(2) Install

- Carry out installation in the reverse order to removal.
- A When lifting the arm assembly, always lift the center of gravity.
- * Bleed the air from the cylinder.



SECTION 9 COMPONENT MOUNTING TORQUE

Group	1	Introduction guide	9-1
Group	2	Engine system ·····	9-2
Group	3	Electric system ······	9-4
Group	4	Hydraulic system ·····	9-6
Group	5	Undercarriage	9-9
Group	6	Structure	9-10
Group	7	Work equipment ·····	9-14


SECTION 9 COMPONENT MOUNTING TORQUE

GROUP 1 INTRODUCTION GUIDE

- 1. This section shows bolt specifications and standard torque values needed when mounting components to the machine.
- Use genuine Hyundai spare parts. We expressly point out that Hyundai will not accept any responsibility for defects resulted from non-genuine parts.


In such cases Hyundai cannot assume liability for any damage.

- * Only metric fasteners can be used and incorrect fasteners may result in machine damage or malfunction.
- * Before installation, clean all the components with a non-corrosive cleaner. Bolts and threads must not be worn or damaged.



GROUP 2 ENGINE SYSTEM

1. ENGINE AND ACCESSORIES MOUNTING




145Z9A9CM01

Item	Size kgf · m		lbf ⋅ ft
1	M 8×1.25	2.5±0.5	18.1±3.6
2	M10×1.5	6.9±1.4	49.9±10.1
3	M12×1.75	12.3±1.2	89±8.7

Item	Size kgf · m		lbf ⋅ ft
4	M20×2.5	55±3.5	398±25.3
5	M20×2.5	52.1±5.0	377±36.2
-	-	-	-

2. COOLING SYSTEM AND FUEL TANK MOUNTING




125LCR9A9CM02

Item	Size	kgf ∙ m	lbf ⋅ ft	Item	Size	kgf ∙ m	lbf ∙ ft
1	M 6×1.0	0.5±0.1	3.6±0.72	5	M10×1.5	6.9±1.4	49.9±10.1
2	M 8×1.25	1.3±0.2	9.4±1.45	6	M16×2.0	29.7±4.5	215±32.5
3	M 8×1.25	2.5±0.5	18.1±3.6	7	M20×2.5	45±1.0	325±7.2
4	M 8×1.25	5.0±0.2	36.2±1.45	8	-	2.3±0.6	16.6±4.3

GROUP 3 ELECTRIC SYSTEM

1. ELECTRIC COMPONENTS MOUNTING 1




145Z9A9CM03

Item	Size	kgf ∙ m	lbf ∙ ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6

Item	Size	kgf ∙ m	lbf ⋅ ft
3	M10×1.5	6.9±1.4	49.9±10.1
4	M12×1.75	12.8±3.0	92.6±21.7

2. ELECTRIC COMPONENTS MOUNTING 2




145Z9A9CM04

\cdot Tightening torque

Item	Size	kgf ∙ m	lbf ⋅ ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6
3	M10×1.5	6.9±1.4	49.9±10.1

GROUP 4 HYDRAULIC SYSTEM

1. HYDRAULIC COMPONENTS MOUNTING 1





125LCR9A9CM05

Item	Size	kgf ∙ m	lbf ∙ ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 6×1.0	1.44±0.3	10.4±2.2
3	M 8×1.25	2.5±0.5	18.1±3.6
4	M 8×1.25	4.05±0.8	29.3±5.8
5	M10×1.5	6.5±0.7	47±5.1
6	M10×1.5	6.9±1.4	49.9±10.1
7	M10×1.5	8.27±1.7	59.8±12.3

Item	Size	kgf ∙ m	lbf ⋅ ft
8	M12×1.75	12.2±1.3	88.2±9.4
9	M12×1.75	14.7±2.2	106±15.9
10	M16×2.0	22±1.5	159±10.8
11	M16×2.0	29.6±3.2	214±23.1
12	M18×2.5	32±1.0	231±7.2
13	M20×2.5	45±1.0	325±7.2
-	-	-	-


2. HYDRAULIC COMPONENTS MOUNTING 2






6

Boom safety lock system






125LCR9A9CM06


Item	Size	kgf ∙ m	lbf ⋅ ft
1	M 8×1.25	4.05±0.8	29.3±5.8
2	M10×1.5	6.9±1.4	49.9±10.1
3	M10×1.5	8.27±1.7	59.8±12.3

Item	Size	kgf ∙ m	lbf ∙ ft
4	M12×1.75	12.3±1.3	88.9±9.4
5	M14×2.0	19.6±2.9	142±21.0
6	M16×2.0	23±2.5	166±18.1


3. HYDRAULIC COMPONENTS MOUNTING 3




BOOM CYLINDER



ARM CYLINDER





BUCKET CYLINDER


DOZER BLADE CYLINDER

125LCR9A9CM07

Item	Size	kgf ∙ m	lbf ∙ ft
1	M 8×1.25	2.7±0.3	19.5±2.2
2	M10×1.5	3. 2± 0.3	23.1±2.2
3	M10×1.5	5.4±0.5	39.1±3.6

Item	Size	kgf ⋅ m	lbf ⋅ ft
4	M12×1.75	9.3±1.9	67.3±13.7
5	M14×2.0	15±2.0	108±14.5
6	M16×2.0	23±2.0	166±14.5

GROUP 5 UNDERCARRIAGE




125LCR9A9CM08

Item	Size	kgf ∙ m	lbf ⋅ ft	ltem	Size	kgf ∙ m	lbf ⋅ ft
1	M 8×1.0	3.74±0.7	27.1±5.1	5	M16×1.5	29.7±3.0	215±21.7
2	M10×1.5	6.9±1.4	49.9±10.1	6	M16×2.0	29.8±3.2	214±23.1
3	M12×1.75	12.8±3.0	92.6±21.7	7	M18×2.5	41.3±4.0	299±28.9
4	M16×1.5	42±4.0	304±28.9	8	M18×2.5	41.3±6.2	299±44.8

GROUP 6 STRUCTURE

1. CAB AND ACCESSORIES MOUNTING




140Z99CM09

Item	Size	kgf ∙ m	lbf ⋅ ft
1	M 6×1.0	1.44±0.3	10.4±2.2
2	M 8×1.25	2.5±0.5	18.1±3.6
3	M10×1.5	4.7±0.9	34±6.5

ltem	Size	kgf ∙ m	lbf ∙ ft
4	M10×1.5	6.9±1.4	49.9±10.1
5	M12×1.75	12.8±3.0	92.6±21.7

2. CAB INTERIOR MOUNTING




140Z99CM10

Item	n Size kgf · m		lbf ⋅ ft
1	M 6×1.0	1.05±0.2	7.6±1.4
2	M 8×1.25	3.43±0.7	24.8±5.1
3	M 8×1.25	4.05±0.8	29.3±5.8

Item	Size	kgf ∙ m	lbf ⋅ ft
4	M10×1.5	6.9±1.4	49.9±10.1
5	M16×2.0	29.7±4.5	215±32.5


3. COWLING MOUNTING



125LCR9A9CM11

Item	Size	kgf ∙ m	lbf ⋅ ft
1	M 8×1.25	2.5±0.5	18.1±3.6
2	M10×1.5	6.9±1.4	49.9±10.1
3	M12×1.75	12.8±3.0	92.6±21.7


4. COUNTERWEIGHT AND COVERS MOUNTING



125LCR9A9CM12

Item	Size	kgf ∙ m	lbf ∙ ft
1	M 8×1.25	2.5±0.5	18.1±3.6
2	M10×1.5	6.9±1.4	49.9±10.1
3	M12×1.75	12.8±3.0	92.6±21.7
4	M36×3.0	308±46	2228±333

GROUP 7 WORK EQUIPMENT



125LCR9A9CM13

Item	Size	kgf ∙ m	lbf ⋅ ft
1	M12×1.75	12.8±3.0	92.6±21.7
2	M16×2.0	29.7±4.5	215±32.5
3	M20×2.5	57.9±8.7	419±62.9