

SECTION 1 GENERAL

Group 1 Safety Hints	1-1
Group 2 Specifications	1-9

SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device	2-1
Group 2 Main Control Valve	2-8
Group 3 Swing Device	2-37
Group 4 Travel Device	2-47
Group 5 RCV Lever	2-58
Group 6 RCV Pedal	2-65

SECTION 3 HYDRAULIC SYSTEM

Group 1 Hydraulic Circuit	3-1
Group 2 Main Circuit	3-2
Group 3 Pilot Circuit	3-5
Group 4 Single Operation	3-9
Group 5 Combined Operation	3-21

SECTION 4 ELECTRICAL SYSTEM

Group 1 Component Location	4-1
Group 2 Monitoring system	4-3
Group 3 Electrical Circuit	4-9
Group 4 Electrical Component Specification	4-21
Group 5 Connectors	4-27

SECTION 5 TROUBLESHOOTING

Group 1 Before Troubleshooting	5-1
Group 2 Hydraulic and Mechanical System	5-4
Group 3 Electrical System	5-24

SECTION 6 MAINTENANCE STANDARD

Group 1 Operational Performance Test	6-1
Group 2 Major Components	6-20
Group 3 Track and Work Equipment	6-31

SECTION 7 DISASSEMBLY AND ASSEMBLY

Group 1 Precaution	7-1
Group 2 Tightening Torque	7-4
Group 3 Pump Device	7-7
Group 4 Main Control Valve	7-22
Group 5 Swing Device	7-36
Group 6 Travel Device	7-54
Group 7 RCV Lever	7-84
Group 8 Turning Joint	7-98
Group 9 Boom, Arm and Bucket Cylinder	7-103
Group 10 Undercarriage	7-123
Group 11 Work Equipment	7-134

SECTION 8 COMPONENT MOUNTING TORQUE

Group 1 Introduction Guide	8-1
Group 2 Engine System	8-2
Group 3 Electric System	8-4
Group 4 Hydraulic System	8-5
Group 5 Undercarriage	8-7
Group 6 Structure	8-8
Group 7 Work Equipment	8-10

1. STRUCTURE

This service manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This service manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into the following sections.

SECTION 1 GENERAL

This section explains the safety hints and gives the specification of the machine and major components.

SECTION 2 STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

SECTION 3 HYDRAULIC SYSTEM

This section explains the hydraulic circuit, single and combined operation.

SECTION 4 ELECTRICAL SYSTEM

This section explains the electrical circuit, monitoring system and each component. It serves not only to give an understanding electrical system, but also serves as reference material for trouble shooting.

SECTION 5 TROUBLESHOOTING

This section explains the troubleshooting charts correlating problems to causes.

SECTION 6 MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

SECTION 7 DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

SECTION 8 COMPONENT MOUNTING TORQUE

This section shows bolt specifications and standard torque values needed when mounting components to the machine.

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your HYUNDAI distributor for the latest information.

2. HOW TO READ THE SERVICE MANUAL

Distribution and updating

Any additions, amendments or other changes will be sent to HYUNDAI distributors.

Get the most up-to-date information before you start any work.

Filing method


1. See the page number on the bottom of the page.

File the pages in correct order.

2. Following examples shows how to read the page number.

Example 1

2 - 3



3. Additional pages : Additional pages are indicated by a hyphen(-) and number after the page number. File as in the example.

10 - 4

10 - 4 - 1

10 - 4 - 2

10 - 5

Added pages

Revised edition mark (①②③...)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

Revisions

Revised pages are shown at the list of revised pages on the between the contents page and section 1 page.

Symbols

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing the work.
		Extra special safety precautions are necessary when performing the work because it is under internal pressure.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.

3. CONVERSION TABLE

Method of using the Conversion Table

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

Example

1. Method of using the Conversion Table to convert from millimeters to inches

Convert 55mm into inches.

- (1) Locate the number 50 in the vertical column at the left side, take this as ①, then draw a horizontal line from ①.
- (2) Locate the number 5 in the row across the top, take this as ②, then draw a perpendicular line down from ②.
- (3) Take the point where the two lines cross as ③. This point ③ gives the value when converting from millimeters to inches. Therefore, 55 mm = 2.165 inches.

2. Convert 550mm into inches.

- (1) The number 550 does not appear in the table, so divide by 10 (Move the decimal point one place to the left) to convert it to 55 mm.
- (2) Carry out the same procedure as above to convert 55 mm to 2.165 inches.
- (3) The original value (550 mm) was divided by 10, so multiply 2.165 inches by 10 (Move the decimal point one place to the right) to return to the original value.
This gives 550 mm = 21.65 inches.

Millimeters to inches

②

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
① 50	1.969	2.008	2.047	2.087	2.126	③ 2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Millimeters to inches

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Kilogram to Pound

1 kg = 2.2046 lb

	0	1	2	3	4	5	6	7	8	9
0		2.20	4.41	6.61	8.82	11.02	13.23	15.43	17.64	19.84
10	22.05	24.25	26.46	28.66	30.86	33.07	35.27	37.48	39.68	41.89
20	44.09	46.30	48.50	50.71	51.91	55.12	57.32	59.5	61.73	63.93
30	66.14	68.34	70.55	72.75	74.96	77.16	79.37	81.57	83.78	85.98
40	88.18	90.39	92.59	94.80	97.00	99.21	101.41	103.62	105.82	108.03
50	110.23	112.44	114.64	116.85	119.05	121.25	123.46	125.66	127.87	130.07
60	132.28	134.48	136.69	138.89	141.10	143.30	145.51	147.71	149.91	152.12
70	154.32	156.53	158.73	160.94	163.14	165.35	167.55	169.76	171.96	174.17
80	176.37	178.57	180.78	182.98	185.19	187.39	189.60	191.80	194.01	196.21
90	198.42	200.62	202.83	205.03	207.24	209.44	211.64	213.85	216.05	218.26

Liter to U.S. Gallon

1 l = 0.2642 U.S.Gal

	0	1	2	3	4	5	6	7	8	9
0		0.264	0.528	0.793	1.057	1.321	1.585	1.849	2.113	2.378
10	2.642	2.906	3.170	3.434	3.698	3.963	4.227	4.491	4.755	5.019
20	5.283	5.548	5.812	6.076	6.340	6.604	6.869	7.133	7.397	7.661
30	7.925	8.189	8.454	8.718	8.982	9.246	9.510	9.774	10.039	10.303
40	10.567	10.831	11.095	11.359	11.624	11.888	12.152	12.416	12.680	12.944
50	13.209	13.473	13.737	14.001	14.265	14.529	14.795	15.058	15.322	15.586
60	15.850	16.115	16.379	16.643	16.907	17.171	17.435	17.700	17.964	18.228
70	18.492	18.756	19.020	19.285	19.549	19.813	20.077	20.341	20.605	20.870
80	21.134	21.398	21.662	21.926	22.190	22.455	22.719	22.983	23.247	23.511
90	23.775	24.040	24.304	24.568	24.832	25.096	25.631	25.625	25.889	26.153

Liter to U.K. Gallon

1 l = 0.21997 U.K.Gal

	0	1	2	3	4	5	6	7	8	9
0		0.220	0.440	0.660	0.880	1.100	1.320	1.540	1.760	1.980
10	2.200	2.420	2.640	2.860	3.080	3.300	3.520	3.740	3.950	4.179
20	4.399	4.619	4.839	5.059	5.279	5.499	5.719	5.939	6.159	6.379
30	6.599	6.819	7.039	7.259	7.479	7.699	7.919	8.139	8.359	8.579
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.778
50	10.998	11.281	11.438	11.658	11.878	12.098	12.318	12.528	12.758	12.978
60	13.198	13.418	13.638	13.858	14.078	14.298	14.518	14.738	14.958	15.178
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378
80	17.598	17.818	18.037	18.257	18.477	18.697	18.917	19.137	19.357	19.577
90	19.797	20.017	20.237	20.457	20.677	20.897	21.117	21.337	21.557	21.777

kgf · m to lbf · ft

1 kgf · m = 7.233 lbf · ft

	0	1	2	3	4	5	6	7	8	9
		7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	296.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	10005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4

kgf/cm² to lbf/in²1 kgf / cm² = 14.2233 lbf / in²

	0	1	2	3	4	5	6	7	8	9
		14.2	28.4	42.7	56.9	71.1	85.3	99.6	113.8	128.0
10	142.2	156.5	170.7	184.9	199.1	213.4	227.6	241.8	256.0	270.2
20	284.5	298.7	312.9	327.1	341.4	355.6	369.8	384.0	398.3	412.5
30	426.7	440.9	455.1	469.4	483.6	497.8	512.0	526.3	540.5	554.7
40	568.9	583.2	597.4	611.6	625.8	640.1	654.3	668.5	682.7	696.9
50	711.2	725.4	739.6	753.8	768.1	782.3	796.5	810.7	825.0	839.2
60	853.4	867.6	881.8	896.1	910.3	924.5	938.7	953.0	967.2	981.4
70	995.6	1010	1024	1038	1053	1067	1081	1095	1109	1124
80	1138	1152	1166	1181	1195	1209	1223	1237	1252	1266
90	1280	1294	1309	1323	1337	1351	1365	1380	1394	1408
100	1422	1437	1451	1465	1479	1493	1508	1522	1536	1550
110	1565	1579	1593	1607	1621	1636	1650	1664	1678	1693
120	1707	1721	1735	1749	1764	1778	1792	1806	1821	1835
130	1849	2863	1877	1892	1906	1920	1934	1949	1963	1977
140	1991	2005	2020	2034	2048	2062	2077	2091	2105	2119
150	2134	2148	2162	2176	2190	2205	2219	2233	2247	2262
160	2276	2290	2304	2318	2333	2347	2361	2375	2389	2404
170	2418	2432	2446	2460	2475	2489	2503	2518	2532	2546
180	2560	2574	2589	5603	2617	2631	2646	2660	2674	2688
200	2845	2859	2873	2887	2901	2916	2930	2944	2958	2973
210	2987	3001	3015	3030	3044	3058	3072	3086	3101	3115
220	3129	3143	3158	3172	3186	3200	3214	3229	3243	3257
230	3271	3286	3300	3314	3328	3343	3357	3371	3385	3399
240	3414	3428	3442	3456	3470	3485	3499	3513	3527	3542

TEMPERATURE

Fahrenheit-Centigrade Conversion.

A simple way to convert a fahrenheit temperature reading into a centigrade temperature reading or vice verse is to enter the accompanying table in the center or boldface column of figures.

These figures refer to the temperature in either Fahrenheit or Centigrade degrees.

If it is desired to convert from Fahrenheit to Centigrade degrees, consider the center column as a table of Fahrenheit temperatures and read the corresponding Centigrade temperature in the column at the left.

If it is desired to convert from Centigrade to Fahrenheit degrees, consider the center column as a table of Centigrade values, and read the corresponding Fahrenheit temperature on the right.

°C		°F	°C		°F	°C		°F	°C		°F
-40.4	-40	-40.0	-11.7	11	51.8	7.8	46	114.8	27.2	81	117.8
-37.2	-35	-31.0	-11.1	12	53.6	8.3	47	116.6	27.8	82	179.6
-34.4	-30	-22.0	-10.6	13	55.4	8.9	48	118.4	28.3	83	181.4
-31.7	-25	-13.0	-10.0	14	57.2	9.4	49	120.2	28.9	84	183.2
-28.9	-20	-4.0	-9.4	15	59.0	10.0	50	122.0	29.4	85	185.0
-28.3	-19	-2.2	-8.9	16	60.8	10.6	51	123.8	30.0	86	186.8
-27.8	-18	-0.4	-8.3	17	62.6	11.1	52	125.6	30.6	87	188.6
-27.2	-17	1.4	-7.8	18	64.4	11.7	53	127.4	31.1	88	190.4
-26.7	-16	3.2	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-26.1	-15	5.0	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-25.6	-14	6.8	-6.1	21	69.8	13.3	56	132.8	32.8	91	195.8
-25.0	-13	8.6	-5.6	22	71.6	13.9	57	134.6	33.3	92	197.6
-24.4	-12	10.4	-5.0	23	73.4	14.4	58	136.4	33.9	93	199.4
-23.9	-11	12.2	-4.4	24	75.2	15.0	59	138.2	34.4	94	201.2
-23.3	-10	14.0	-3.9	25	77.0	15.6	60	140.0	35.0	95	203.0
-22.8	-9	15.8	-3.3	26	78.8	16.1	61	141.8	35.6	96	204.8
-22.2	-8	17.6	-2.8	27	80.6	16.7	62	143.6	36.1	97	206.6
-21.7	-7	19.4	-2.2	28	82.4	17.2	63	145.4	36.7	98	208.4
-21.1	-6	21.2	-1.7	29	84.2	17.8	64	147.2	37.2	99	210.2
-20.6	-5	23.0	-1.1	35	95.0	21.1	70	158.0	51.7	125	257.0
-20.0	-4	24.8	-0.6	31	87.8	18.9	66	150.8	40.6	105	221.0
-19.4	-3	26.6	0	32	89.6	19.4	67	152.6	43.3	110	230.0
-18.9	-2	28.4	0.6	33	91.4	20.0	68	154.4	46.1	115	239.0
-18.3	-1	30.2	1.1	34	93.2	20.6	69	156.2	48.9	120	248.0
-17.8	0	32.0	1.7	35	95.0	21.1	70	158.0	51.7	125	257.0
-17.2	1	33.8	2.2	36	96.8	21.7	71	159.8	54.4	130	266.0
-16.7	2	35.6	2.8	37	98.6	22.2	72	161.6	57.2	135	275.0
-16.1	3	37.4	3.3	38	100.4	22.8	73	163.4	60.0	140	284.0
-15.6	4	39.2	3.9	39	102.2	23.3	74	165.2	62.7	145	293.0
-15.0	5	41.0	4.4	40	104.0	23.9	75	167.0	65.6	150	302.0
-14.4	6	42.8	5.0	41	105.8	24.4	76	168.8	68.3	155	311.0
-13.9	7	44.6	5.6	42	107.6	25.0	77	170.6	71.1	160	320.0
-13.3	8	46.4	6.1	43	109.4	25.6	78	172.4	73.9	165	329.0
-12.8	9	48.2	6.7	44	111.2	26.1	79	174.2	76.7	170	338.0
-12.2	10	50.0	7.2	45	113.0	26.7	80	176.0	79.4	172	347.0

SECTION 1 GENERAL



Group 1 Safety Hints 1-1

Group 2 Specifications 1-9

SECTION 1 GENERAL


GROUP 1 SAFETY

FOLLOW SAFE PROCEDURE

Unsafe work practices are dangerous. Understand service procedure before doing work; Do not attempt shortcuts.

WEAR PROTECTIVE CLOTHING


Wear close fitting clothing and safety equipment appropriate to the job.



WARN OTHERS OF SERVICE WORK

Unexpected machine movement can cause serious injury.

Before performing any work on the excavator, attach a 'Do Not Operate' tag on the right side control lever.




USE HANDHOLDS AND STEPS

Falling is one of the major causes of personal injury.

When you get on and off the machine, always maintain a three point contact with the steps and handrails and face the machine. Do not use any controls as handholds.

Never jump on or off the machine. Never mount or dismount a moving machine.

Be careful of slippery conditions on platforms, steps, and handrails when leaving the machine.




PREPARE FOR EMERGENCIES

Be prepared if a fire starts.


Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



PROTECT AGAINST FLYING DEBRIS


Guard against injury from flying pieces of metal or debris; Wear goggles or safety glasses.



PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.


Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



AVOID POWER LINES

Serious injury or death can result from contact with electric lines.


Never move any part of the machine or load closer to electric line than 3m(10ft) plus twice the line insulator length.



KEEP RIDERS OFF EXCAVATOR

Only allow the operator on the excavator. Keep riders off.

Riders on excavator are subject to injury such as being struck by foreign objects and being thrown off the excavator. Riders also obstruct the operator's view resulting in the excavator being operated in an unsafe manner.




MOVE AND OPERATE MACHINE SAFELY

Bystanders can be run over. Know the location of bystanders before moving, swinging, or operating the machine.

Always keep the travel alarm in working condition. It warns people when the excavator starts to move.

Use a signal person when moving, swinging, or operating the machine in congested areas. Coordinate hand signals before starting the excavator.



OPERATE ONLY FROM OPERATOR'S SEAT

Avoid possible injury machine damage. Do not start engine by shorting across starter terminals.

NEVER start engine while standing on ground. Start engine only from operator's seat.



PARK MACHINE SAFELY

Before working on the machine:

- Park machine on a level surface.
- Lower bucket to the ground.
- Turn auto idle switch off.
- Run engine at 1/2 speed without load for 2 minutes.
- Turn key switch to OFF to stop engine.
Remove key from switch.
- Move pilot control shutoff lever to locked position.
- Allow engine to cool.

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



Explosive release of fluids from pressurized cooling system can cause serious burns.



Handle fuel with care; It is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks. Always stop engine before refueling machine. Fill fuel tank outdoors.



Make sure machine is clean of trash, grease, and debris.



BEWARE OF EXHAUST FUMES

Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.

If you must operate in a building, be positive there is adequate ventilation. Either use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring enough outside air into the area.

REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



ILLUMINATE WORK AREA SAFELY


Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.



SERVICE MACHINE SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.


Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



STAY CLEAR OF MOVING PARTS

Entanglements in moving parts can cause serious injury.

To prevent accidents, use care when working around rotating parts.




AVOID HIGH PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.



AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials.

Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area. Install fire resisting guards to protect hoses or other materials.



PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; It may explode. Warm battery to 16°C (60°F).



PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10-15 minutes. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.




USE TOOLS PROPERLY

Use tools appropriate to the work. Makeshift tools, parts, and procedures can create safety hazards.

Use power tools only to loosen threaded tools and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only recommended replacement parts. (See Parts catalogue.)




DISPOSE OF FLUIDS PROPERLY

Improperly disposing of fluids can harm the environment and ecology. Before draining any fluids, find out the proper way to dispose of waste from your local environmental agency.


Use proper containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

DO NOT pour oil into the ground, down a drain, or into a stream, pond, or lake. Observe relevant environmental protection regulations when disposing of oil, fuel, coolant, brake fluid, filters, batteries, and other harmful waste.



REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.




LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.

GROUP 2 SPECIFICATIONS


1. MAJOR COMPONENT



1692SP01

2. SPECIFICATIONS

1) 1.80 m (5' 11") MONO BOOM, 0.96 m (3' 2") ARM, WITH BOOM SWING POST




1692SP02

Description		Unit	Specification
Operating weight (canopy/cabin)		kg (lb)	1650 (3640) / 1820 (4010)
Bucket capacity (SAE heaped), standard		m ³ (yd ³)	0.04 (0.05)
Overall length	A	mm (ft-in)	3840 (12' 7")
Overall width, with 230 mm shoe (extension crawler)	B		980~1250 (3' 3" ~ 4' 1")
Overall height	C		2300 (7' 7")
Overall height of canopy	E		2300 (7' 7")
Ground clearance of counterweight	F		415 (1' 4")
Minimum ground clearance	H		150 (0' 6")
Rear-end distance	I		1065 (3' 6")
Rear-end swing radius	I'		1065 (3' 6")
Distance between tumblers	J		1230 (4' 0")
Undercarriage length	K		1590 (5' 3")
Undercarriage width (extension crawler)	L		980~1250 (3' 3" ~ 4' 1")
Track gauge (extension crawler)	M		750~1020 (2' 6" ~ 3' 4")
Track shoe width, standard	N		230 (9")
Height of blade	O		250 (0' 10")
Ground clearance of blade up	P		170 (0' 7")
Depth of blade down	Q		240 (0' 9")
Travel speed (low/high)		km/hr (mph)	2.2/4.1 (1.4/2.5)
Swing speed		rpm	9.3
Gradeability		Degree (%)	30 (58)
Ground pressure 230 mm rubber shoe (canopy/cabin)		kgf/cm ² (psi)	0.28 (3.92) / 0.30 (4.31)
Max traction force		kg (lb)	1550 (3420)

3. WORKING RANGE

1) 1.80 m (5' 11") MONO BOOM WITH BOOM SWING POST



1692SP03


Description		0.96 m (3' 2") Arm	
Max digging reach	A	3970 mm (13' 0")	
Max digging reach on ground	A'	3880 mm (12' 9")	
Max digging depth	B	2250 mm (7' 5")	
Max vertical wall digging depth	C	1785 mm (5' 10")	
Max digging height	D	3670 mm (12' 0")	
Max dumping height	E	2550 mm (8' 4")	
Min swing radius	F	1615 mm (5' 4")	
Boom swing radius (left/right)		60°/60°	
Bucket digging force	SAE	13.1 kN	
		1340 kgf	
		2950 lbf	
	ISO	15.1 kN	
		1540 kgf	
		3400 lbf	
Arm crowd force	SAE	9.0 kN	
		920 kgf	
		2030 lbf	
	ISO	9.4 kN	
		960 kgf	
		2120 lbf	













4. WEIGHT

Item	kg	lb
Upperstructure assembly	940	2070
Main frame weld assembly	230	510
Engine assembly	75	165
Main pump assembly	17	37
Main control valve assembly	25	55
Swing motor assembly	23	50
Hydraulic oil tank assembly	20	44
Fuel tank assembly	15	33
Boom swing post	35	80
Counterweight	60	130
Canopy assembly	47	104
Front guard	12	26
Lower chassis assembly	530	1170
Track frame weld assembly	150	330
Swing bearing	20	44
Travel motor assembly	18	40
Turning joint	20	44
Track recoil spring	11	24
Idler	15	33
Track roller	3	7
Sprocket	4	9
Rubber track (230 mm)	66	146
Dozer blade assembly	60	130
Front attachment assembly (1.8 m boom, 0.96 m arm, 0.04 m ³ SAE heaped bucket)	200	440
1.8 m boom assembly	65	140
0.96 m arm assembly	30	70
0.04 m ³ SAE heaped bucket	40	90
Boom cylinder assembly	17	37
Arm cylinder assembly	15	33
Bucket cylinder assembly	11	24
Bucket control link assembly	10	22
Dozer cylinder assembly	11	24
Boom swing cylinder assembly	11	24
Extension cylinder assembly	8	18

5. LIFTING CAPACITIES

Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outrigger	
R16-9	Canopy	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	960	60	230	-	-	Down	-	-



Lift-point height (A)		Lift-point radius (B)										At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		Capacity		Reach
														m (ft)
3.0 m (9.8 ft)	kg											*400	*400	2.20
	lb											*880	*880	(7.2)
2.5 m (8.2 ft)	kg							*370	340			*340	290	2.76
	lb							*820	750			*750	640	(9.1)
2.0 m (6.6 ft)	kg							*390	340	*390	260	*310	240	3.10
	lb							*860	750	*860	570	*680	530	(10.2)
1.5 m (4.9 ft)	kg					*530	460	*450	330	*410	250	*310	220	3.30
	lb					*1170	1010	*990	730	*900	550	*680	490	(10.8)
1.0 m (3.3 ft)	kg					*730	440	*530	320	*450	250	*320	210	3.39
	lb					*1610	970	*1170	710	*990	550	*710	460	(11.1)
0.5 m (1.6 ft)	kg					*870	420	*610	310	*480	240	*340	200	3.39
	lb					*1920	930	*1340	680	*1060	530	*750	440	(11.1)
Ground Line	kg					*910	410	*650	300	*500	240	*390	210	3.29
	lb					*2010	900	*1430	660	*1100	530	*860	460	(10.8)
-0.5 m (-1.6 ft)	kg	*800	*800	*1090	640	*880	410	*630	300	*480	240	*450	230	3.08
	lb	*1760	*1760	*2400	1410	*1940	900	*1390	660	*1060	530	*990	510	(10.1)
-1.0 m (-3.3 ft)	kg	*1230	*1230	*1120	640	*770	420	*550	310			*460	270	2.74
	lb	*2710	*2710	*2470	1410	*1700	930	*1210	680			*1010	600	(9.0)
-1.5 m (-4.9 ft)	kg			*760	660	*520	430					*440	390	2.15
	lb			*1680	1460	*1150	950					*970	860	(7.1)

Note 1. Lifting capacity are based on SAE J1097 and ISO 10567.

2. Lifting capacity of the Robex series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.

3. The lift-point is bucket pivot mounting pin on the arm (without bucket mass).

4. *Indicates load limited by hydraulic capacity.

※ Lifting capacities are based upon a standard machine conditions.

Lifting capacities will vary with different work tools, ground conditions and attachments.



The difference between the weight of a work tool attachment must be subtracted.


Consult your Hyundai dealer regarding the lifting capacities for specific work tools and attachments.













▲ Failure to comply to the rated load can cause possible personal injury or property damage.

Make adjustments to the rated load as necessary for non-standard configurations.


Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Canopy, Track extended	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	960	60	230	-	-	Down	-	-













 : Rating over-front
  : Rating over-side or 360 degree




Lift-point height (A)		Lift-point radius (B)										At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		Capacity		Reach
														m (ft)
3.0 m (9.8 ft)	kg lb											*400 *880	*400 *880	2.20 (7.2)
2.5 m (8.2 ft)	kg lb							*370 *820	*370 *820			*340 *750	*340 *750	2.76 (9.1)
2.0 m (6.6 ft)	kg lb							*390 *860	*390 *860	*390 *860	310 680	*310 *680	300 660	3.10 (10.2)
1.5 m (4.9 ft)	kg lb					*530 *1170	*530 *1170	*450 *990	410 900	*410 *900	310 680	*310 *680	270 600	3.30 (10.8)
1.0 m (3.3 ft)	kg lb					*730 *1610	550 1210	*530 *1170	400 880	*450 *990	300 660	*320 *710	250 550	3.39 (11.1)
0.5 m (1.6 ft)	kg lb					*870 *1920	530 1170	*610 *1340	390 860	*480 *1060	300 660	*340 *750	250 550	3.39 (11.1)
Ground Line	kg lb					*910 *2010	520 1150	*650 *1430	380 840	*500 *1100	300 660	*390 *860	260 570	3.29 (10.8)
-0.5 m (-1.6 ft)	kg lb	*800 *1760	*800 *1760	*1090 *2400	820 1810	*880 *1940	520 1150	*630 *1390	380 840	*480 *1060	290 640	*450 *990	280 620	3.08 (10.1)
-1.0 m (-3.3 ft)	kg lb	*1230 *2710	*1230 *2710	*1120 *2470	830 1830	*770 *1700	520 1150	*550 *1210	380 840			*460 *1010	340 750	2.74 (9.0)
-1.5 m (-4.9 ft)	kg lb			*760 *1680	*760 *1680	*520 *1150	*520 *1150					*440 *970	*440 *970	2.15 (7.1)













Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Cabin	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	960	60	230	-	-	Down	-	-




Lift-point height (A)		Lift-point radius (B)										At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		Capacity		Reach
														m (ft)
3.0 m (9.8 ft)	kg lb											*400 *880	380 840	2.20 (7.2)
2.5 m (8.2 ft)	kg lb							*370 *820	310 680			*340 *750	260 570	2.76 (9.1)
2.0 m (6.6 ft)	kg lb							*390 *860	310 680	*390 *860	230 510	*310 *680	220 490	3.10 (10.2)
1.5 m (4.9 ft)	kg lb					*530 *1170	420 930	*450 *990	300 660	*410 *900	230 510	*310 *680	190 420	3.30 (10.8)
1.0 m (3.3 ft)	kg lb					*730 *1610	390 860	*530 *1170	290 640	*450 *990	220 490	*320 *710	180 400	3.39 (11.1)
0.5 m (1.6 ft)	kg lb					*870 *1920	380 840	*610 *1340	280 620	*480 *1060	210 460	*340 *750	180 400	3.39 (11.1)
Ground Line	kg lb					*910 *2010	370 820	*650 *1430	270 600	*500 *1100	210 460	*390 *860	190 420	3.29 (10.8)
-0.5 m (-1.6 ft)	kg lb	*800 *1760	*800 *1760	*1090 *2400	570 1260	*880 *1940	370 820	*630 *1390	270 600	*480 *1060	210 460	*450 *990	200 440	3.08 (10.1)
-1.0 m (-3.3 ft)	kg lb	*1230 *2710	1210 2670	*1120 *2470	580 1280	*770 *1700	370 820	*550 *1210	270 600			*460 *1010	240 530	2.74 (9.0)
-1.5 m (-4.9 ft)	kg lb			*760 *1680	590 1300	*520 *1150	380 840					*440 *970	350 770	2.15 (7.1)













Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Cabin, Track extended	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	960	60	230	-	-	Down	-	-




Lift-point height (A)		Lift-point radius (B)										At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		Capacity		Reach
														m (ft)
3.0 m (9.8 ft)	kg lb											*400 *880	*400 *880	2.20 (7.2)
2.5 m (8.2 ft)	kg lb							*370 *820	*370 *820			*340 *750	320 710	2.76 (9.1)
2.0 m (6.6 ft)	kg lb							*390 *860	380 840	*390 *860	280 620	*310 *680	270 600	3.10 (10.2)
1.5 m (4.9 ft)	kg lb					*530 *1170	520 1150	*450 *990	370 820	*410 *900	280 620	*310 *680	240 530	3.30 (10.8)
1.0 m (3.3 ft)	kg lb					*730 *1610	490 1080	*530 *1170	360 790	*450 *990	270 600	*320 *710	230 510	3.39 (11.1)
0.5 m (1.6 ft)	kg lb					*870 *1920	470 1040	*610 *1340	350 770	*480 *1060	270 600	*340 *750	220 490	3.39 (11.1)
Ground Line	kg lb					*910 *2010	470 1040	*650 *1430	340 750	*500 *1100	260 570	*390 *860	230 510	3.29 (10.8)
-0.5 m (-1.6 ft)	kg lb	*800 *1760	*800 *1760	*1090 *2400	740 1630	*880 *1940	470 1040	*630 *1390	340 750	*480 *1060	260 570	*450 *990	250 550	3.08 (10.1)
-1.0 m (-3.3 ft)	kg lb	*1230 *2710	*1230 *2710	*1120 *2470	750 1650	*770 *1700	470 1040	*550 *1210	340 750			*460 *1010	300 660	2.74 (9.0)
-1.5 m (-4.9 ft)	kg lb			*760 *1680	*760 *1680	*520 *1150	480 1060					*440 *970	430 950	2.15 (7.1)













Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Canopy	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	960	60	230	-	-	Up	-	-





Lift-point height (A)		Lift-point radius (B)										At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		Capacity		Reach
														m (ft)
3.0 m	kg											*400	340	2.20
(9.8 ft)	lb											*880	750	(7.2)
2.5 m	kg							*370	290			*340	240	2.76
(8.2 ft)	lb							*820	640			*750	530	(9.1)
2.0 m	kg							*390	280	320	210	300	200	3.10
(6.6 ft)	lb							*860	620	710	460	660	440	(10.2)
1.5 m	kg					*530	380	410	280	310	210	270	180	3.30
(4.9 ft)	lb					*1170	840	900	620	680	460	600	400	(10.8)
1.0 m	kg					560	360	400	260	310	200	260	170	3.39
(3.3 ft)	lb					1230	790	880	570	680	440	570	370	(11.1)
0.5 m	kg					540	340	390	250	300	200	250	170	3.39
(1.6 ft)	lb					1190	750	860	550	660	440	550	370	(11.1)
Ground	kg					530	330	380	250	300	190	260	170	3.29
Line	lb					1170	730	840	550	660	420	570	370	(10.8)
-0.5 m	kg	*800	*800	850	510	530	330	380	250	300	190	290	190	3.08
(-1.6 ft)	lb	*1760	*1760	1870	1120	1170	730	840	550	660	420	640	420	(10.1)
-1.0 m	kg	*1230	1010	860	510	540	340	390	250			340	220	2.74
(-3.3 ft)	lb	*2710	2230	1900	1120	1190	750	860	550			750	490	(9.0)
-1.5 m	kg			*760	530	*520	350					*440	320	2.15
(-4.9 ft)	lb			*1680	1170	*1150	770					*970	710	(7.1)



Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Canopy, Track extended	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	960	60	230	-	-	Up	-	-















Lift-point height (A)		Lift-point radius (B)										At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		Capacity		Reach
														m (ft)
3.0 m (9.8 ft)	kg lb											*400 *880	*400 *880	2.20 (7.2)
2.5 m (8.2 ft)	kg lb							*370 *820	*370 *820			*340 *750	*340 *750	2.76 (9.1)
2.0 m (6.6 ft)	kg lb							*390 *860	*390 *860	320 710	300 660	300 660	280 620	3.10 (10.2)
1.5 m (4.9 ft)	kg lb					*530 *1170	*530 *1170	410 900	390 860	310 680	290 640	270 600	250 550	3.30 (10.8)
1.0 m (3.3 ft)	kg lb					560 1230	520 1150	400 880	380 840	310 680	290 640	260 570	240 530	3.39 (11.1)
0.5 m (1.6 ft)	kg lb					540 1190	500 1100	390 860	360 790	300 660	280 620	250 550	240 530	3.39 (11.1)
Ground Line	kg lb					530 1170	490 1080	380 840	360 790	300 660	280 620	260 570	250 550	3.29 (10.8)
-0.5 m (-1.6 ft)	kg lb	*800 *1760	*800 *1760	850 1870	770 1700	530 1170	490 1080	380 840	360 790	300 660	280 620	290 640	270 600	3.08 (10.1)
-1.0 m (-3.3 ft)	kg lb	*1230 *2710	*1230 *2710	860 1900	780 1720	540 1190	490 1080	390 860	360 790			340 750	320 710	2.74 (9.0)
-1.5 m (-4.9 ft)	kg lb			*760 *1680	*760 *1680	*520 *1150	510 1120					*440 *970	*440 *970	2.15 (7.1)


Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Cabin	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	960	60	230	-	-	Up	-	-













 : Rating over-front
  : Rating over-side or 360 degree


Lift-point height (A)		Lift-point radius (B)										At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		Capacity		Reach
														m (ft)
3.0 m	kg											*400	310	2.20
(9.8 ft)	lb											*880	680	(7.2)
2.5 m	kg							*370	260			320	220	2.76
(8.2 ft)	lb							*820	570			710	490	(9.1)
2.0 m	kg							380	250	280	190	270	180	3.10
(6.6 ft)	lb							840	550	620	420	600	400	(10.2)
1.5 m	kg					530	340	370	250	280	190	240	160	3.30
(4.9 ft)	lb					1170	750	820	550	620	420	530	350	(10.8)
1.0 m	kg					500	320	360	240	270	180	230	150	3.39
(3.3 ft)	lb					1100	710	790	530	600	400	510	330	(11.1)
0.5 m	kg					480	300	350	230	270	180	220	150	3.39
(1.6 ft)	lb					1060	660	770	510	600	400	490	330	(11.1)
Ground	kg					470	300	340	220	260	170	230	150	3.29
Line	lb					1040	660	750	490	570	370	510	330	(10.8)
-0.5 m	kg	*800	*800	760	450	470	300	340	220	260	170	250	170	3.08
(-1.6 ft)	lb	*1760	*1760	1680	990	1040	660	750	490	570	370	550	370	(10.1)
-1.0 m	kg	*1230	910	770	460	480	300	340	220			300	200	2.74
(-3.3 ft)	lb	*2710	2010	1700	1010	1060	660	750	490			660	440	(9.0)
-1.5 m	kg			*760	470	490	310					440	280	2.15
(-4.9 ft)	lb			*1680	1040	1080	680					970	620	(7.1)















Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Cabin, Track extended	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	960	60	230	-	-	Up	-	-




Lift-point height (A)		Lift-point radius (B)										At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		Capacity		Reach
														m (ft)
3.0 m (9.8 ft)	kg											*400	*400	2.20
	lb											*880	*880	(7.2)
2.5 m (8.2 ft)	kg							*370	360			320	300	2.76
	lb							*820	790			710	660	(9.1)
2.0 m (6.6 ft)	kg							380	360	280	270	270	250	3.10
	lb							840	790	620	600	600	550	(10.2)
1.5 m (4.9 ft)	kg					530	490	370	350	280	260	240	230	3.30
	lb					1170	1080	820	770	620	570	530	510	(10.8)
1.0 m (3.3 ft)	kg					500	460	360	340	270	260	230	210	3.39
	lb					1100	1010	790	750	600	570	510	460	(11.1)
0.5 m (1.6 ft)	kg					480	450	350	330	270	250	220	210	3.39
	lb					1060	990	770	730	600	550	490	460	(11.1)
Ground Line	kg					470	440	340	320	260	250	230	220	3.29
	lb					1040	970	750	710	570	550	510	490	(10.8)
-0.5 m (-1.6 ft)	kg	*800	*800	760	690	470	440	340	320	260	250	250	240	3.08
	lb	*1760	*1760	1680	1520	1040	970	750	710	570	550	550	530	(10.1)
-1.0 m (-3.3 ft)	kg	*1230	*1230	770	700	480	440	340	320			300	280	2.74
	lb	*2710	*2710	1700	1540	1060	970	750	710			660	620	(9.0)
-1.5 m (-4.9 ft)	kg			*760	710	490	450					440	410	2.15
	lb			*1680	1570	1080	990					970	900	(7.1)















Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Canopy	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	960	60	230	-	-	Up	-	-




Lift-point height (A)		Lift-point radius (B)												At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		3.5 m (11.5 ft)		Capacity		Reach
																m (ft)
2.5 m	kg							*320	*320					*280	260	2.96
(8.2 ft)	lb							*710	*710					*620	570	(9.7)
2.0 m	kg							*340	340	*350	260			*260	220	3.27
(6.6 ft)	lb							*750	750	*770	570			*570	490	(10.7)
1.5 m	kg					*460	*460	*410	330	*380	250			*260	200	3.45
(4.9 ft)	lb					*1010	*1010	*900	730	*840	550			*570	440	(11.3)
1.0 m	kg					*660	440	*500	320	*420	250	*340	190	*270	190	3.54
(3.3 ft)	lb					*1460	970	*1100	710	*930	550	*750	420	*600	420	(11.6)
0.5 m	kg					*830	420	*580	310	*460	240	*370	190	*280	190	3.54
(1.6 ft)	lb					*1830	930	*1280	680	*1010	530	*820	420	*620	420	(11.6)
Ground Line	kg			*640	620	*900	410	*630	300	*490	230			*320	190	3.45
	lb			*1410	1370	*1980	900	*1390	660	*1080	510			*710	420	(11.3)
-0.5 m	kg	*700	*700	*990	620	*890	400	*640	300	*490	230			*370	210	3.25
(-1.6 ft)	lb	*1540	*1540	*2180	1370	*1960	880	*1410	660	*1080	510			*820	460	(10.7)
-1.0 m	kg	*1050	*1050	*1210	630	*810	410	*580	300					*430	240	2.93
(-3.3 ft)	lb	*2310	*2310	*2670	1390	*1790	900	*1280	660					*950	530	(9.6)
-1.5 m	kg	*1510	1340	*910	640	*620	420							*430	320	2.42
(-4.9 ft)	lb	*3330	2950	*2010	1410	*1370	930							*950	710	(7.9)















Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Canopy, Track extended	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	1120	60	230	-	-	Down	-	-





Lift-point height (A)		Lift-point radius (B)												At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		3.5 m (11.5 ft)		Capacity		Reach
																m (ft)
2.5 m (8.2 ft)	kg lb							*320 *710	*320 *710					*280 *620	*280 *620	2.96 (9.7)
2.0 m (6.6 ft)	kg lb							*340 *750	*340 *750	*350 *770	310 680			*260 *570	*260 *570	3.27 (10.7)
1.5 m (4.9 ft)	kg lb					*460 *1010	*460 *1010	*410 *900	*410 *900	*380 *840	310 680			*260 *570	250 550	3.45 (11.3)
1.0 m (3.3 ft)	kg lb					*660 *1460	550 1210	*500 *1100	400 880	*420 *930	300 660	*340 *750	240 530	*270 *600	240 530	3.54 (11.6)
0.5 m (1.6 ft)	kg lb					*830 *1830	530 1170	*580 *1280	380 840	*460 *1010	300 660	*370 *820	240 530	*280 *620	230 510	3.54 (11.6)
Ground Line	kg lb			*640 *1410	*640 *1410	*900 *1980	520 1150	*630 *1390	380 840	*490 *1080	290 640			*320 *710	240 530	3.45 (11.3)
-0.5 m (-1.6 ft)	kg lb	*700 *1540	*700 *1540	*990 *2180	810 1790	*890 *1960	510 1120	*640 *1410	370 820	*490 *1080	290 640			*370 *820	260 570	3.25 (10.7)
-1.0 m (-3.3 ft)	kg lb	*1050 *2310	*1050 *2310	*1210 *2670	820 1810	*810 *1790	520 1150	*580 *1280	370 820					*430 *950	300 660	2.93 (9.6)
-1.5 m (-4.9 ft)	kg lb	*1510 *3330	*1510 *3330	*910 *2010	830 1830	*620 *1370	530 1170							*430 *950	400 880	2.42 (7.9)


Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Cabin	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	1120	60	230	-	-	Down	-	-

















Lift-point height (A)		Lift-point radius (B)												At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		3.5 m (11.5 ft)		Capacity		Reach
																m (ft)
2.5 m	kg							*320	310					*280	230	2.96
(8.2 ft)	lb							*710	680					*620	510	(9.7)
2.0 m	kg							*340	310	*350	230			*260	200	3.27
(6.6 ft)	lb							*750	680	*770	510			*570	440	(10.7)
1.5 m	kg					*460	420	*410	300	*380	230			*260	180	3.45
(4.9 ft)	lb					*1010	930	*900	660	*840	510			*570	400	(11.3)
1.0 m	kg					*660	400	*500	290	*420	220	*340	170	*270	170	3.54
(3.3 ft)	lb					*1460	880	*1100	640	*930	490	*750	370	*600	370	(11.6)
0.5 m	kg					*830	370	*580	270	*460	210	*370	170	*280	170	3.54
(1.6 ft)	lb					*1830	820	*1280	600	*1010	460	*820	370	*620	370	(11.6)
Ground	kg			*640	550	*900	360	*630	270	*490	210			*320	170	3.45
Line	lb			*1410	1210	*1980	790	*1390	600	*1080	460			*710	370	(11.3)
-0.5 m	kg	*700	*700	*990	560	*890	360	*640	260	*490	210			*370	180	3.25
(-1.6 ft)	lb	*1540	*1540	*2180	1230	*1960	790	*1410	570	*1080	460			*820	400	(10.7)
-1.0 m	kg	*1050	*1050	*1210	560	*810	360	*580	260					*430	210	2.93
(-3.3 ft)	lb	*2310	*2310	*2670	1230	*1790	790	*1280	570					*950	460	(9.6)
-1.5 m	kg	*1510	1200	*910	580	*620	370							*430	290	2.42
(-4.9 ft)	lb	*3330	2650	*2010	1280	*1370	820							*950	640	(7.9)


Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Cabin, Track extended	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	1120	60	230	-	-	Down	-	-















 : Rating over-front
  : Rating over-side or 360 degree





Lift-point height (A)		Lift-point radius (B)												At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		3.5 m (11.5 ft)		Capacity		Reach
																m (ft)
2.5 m	kg							*320	*320					*280	*280	2.96
(8.2 ft)	lb							*710	*710					*620	*620	(9.7)
2.0 m	kg							*340	*340	*350	280			*260	240	3.27
(6.6 ft)	lb							*750	*750	*770	620			*570	530	(10.7)
1.5 m	kg					*460	*460	*410	370	*380	280			*260	220	3.45
(4.9 ft)	lb					*1010	*1010	*900	820	*840	620			*570	490	(11.3)
1.0 m	kg					*660	500	*500	360	*420	270	*340	210	*270	210	3.54
(3.3 ft)	lb					*1460	1100	*1100	790	*930	600	*750	460	*600	460	(11.6)
0.5 m	kg					*830	470	*580	340	*460	260	*370	210	*280	210	3.54
(1.6 ft)	lb					*1830	1040	*1280	750	*1010	570	*820	460	*620	460	(11.6)
Ground	kg			*640	*640	*900	460	*630	330	*490	260			*320	210	3.45
Line	lb			*1410	*1410	*1980	1010	*1390	730	*1080	570			*710	460	(11.3)
-0.5 m	kg	*700	*700	*990	730	*890	460	*640	330	*490	260			*370	230	3.25
(-1.6 ft)	lb	*1540	*1540	*2180	1610	*1960	1010	*1410	730	*1080	570			*820	510	(10.7)
-1.0 m	kg	*1050	*1050	*1210	730	*810	460	*580	330					*430	270	2.93
(-3.3 ft)	lb	*2310	*2310	*2670	1610	*1790	1010	*1280	730					*950	600	(9.6)
-1.5 m	kg	*1510	*1510	*910	750	*620	470							*430	360	2.42
(-4.9 ft)	lb	*3330	*3330	*2010	1650	*1370	1040							*950	790	(7.9)


Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Canopy	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	1120	60	230	-	-	Up	-	-

















Lift-point height (A)		Lift-point radius (B)												At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		3.5 m (11.5 ft)		Capacity		Reach
																m (ft)
2.5 m	kg							*320	290					*280	220	2.96
(8.2 ft)	lb							*710	640					*620	490	(9.7)
2.0 m	kg							*340	280	320	210			*260	180	3.27
(6.6 ft)	lb							*750	620	710	460			*570	400	(10.7)
1.5 m	kg					*460	390	*410	280	310	210			250	160	3.45
(4.9 ft)	lb					*1010	860	*900	620	680	460			550	350	(11.3)
1.0 m	kg					560	360	400	260	310	200	240	160	240	160	3.54
(3.3 ft)	lb					1230	790	880	570	680	440	530	350	530	350	(11.6)
0.5 m	kg					540	340	390	250	300	200	240	160	240	150	3.54
(1.6 ft)	lb					1190	750	860	550	660	440	530	350	530	330	(11.6)
Ground	kg			*640	490	530	330	380	240	290	190			240	160	3.45
Line	lb			*1410	1080	1170	730	840	530	640	420			530	350	(11.3)
-0.5 m	kg	*700	*700	840	490	520	330	380	240	290	190			260	170	3.25
(-1.6 ft)	lb	*1540	*1540	1850	1080	1150	730	840	530	640	420			570	370	(10.7)
-1.0 m	kg	*1050	980	850	500	530	330	380	240					300	200	2.93
(-3.3 ft)	lb	*2310	2160	1870	1100	1170	730	840	530					660	440	(9.6)
-1.5 m	kg	*1510	1000	860	510	540	340							410	260	2.42
(-4.9 ft)	lb	*3330	2200	1900	1120	1190	750							900	570	(7.9)



Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Canopy, Track extended	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	1120	60	230	-	-	Up	-	-



 : Rating over-front
  : Rating over-side or 360 degree

















Lift-point height (A)		Lift-point radius (B)												At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		3.5 m (11.5 ft)		Capacity		Reach
																m (ft)
2.5 m	kg							*320	*320					*280	*280	2.96
(8.2 ft)	lb							*710	*710					*620	*620	(9.7)
2.0 m	kg							*340	*340	320	300			*260	260	3.27
(6.6 ft)	lb							*750	*750	710	660			*570	570	(10.7)
1.5 m	kg					*460	*460	*410	390	310	290			250	230	3.45
(4.9 ft)	lb					*1010	*1010	*900	860	680	640			550	510	(11.3)
1.0 m	kg					560	520	400	370	310	290	240	230	240	220	3.54
(3.3 ft)	lb					1230	1150	880	820	680	640	530	510	530	490	(11.6)
0.5 m	kg					540	500	390	360	300	280	240	220	240	220	3.54
(1.6 ft)	lb					1190	1100	860	790	660	620	530	490	530	490	(11.6)
Ground	kg			*640	*640	530	480	380	350	290	280			240	230	3.45
Line	lb			*1410	*1410	1170	1060	840	770	640	620			530	510	(11.3)
-0.5 m	kg	*700	*700	840	760	520	480	380	350	290	270			260	250	3.25
(-1.6 ft)	lb	*1540	*1540	1850	1680	1150	1060	840	770	640	600			570	550	(10.7)
-1.0 m	kg	*1050	*1050	850	760	530	480	380	350					300	280	2.93
(-3.3 ft)	lb	*2310	*2310	1870	1680	1170	1060	840	770					660	620	(9.6)
-1.5 m	kg	*1510	*1510	860	780	540	490							410	380	2.42
(-4.9 ft)	lb	*3330	*3330	1900	1720	1190	1080							900	840	(7.9)



Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Cabin	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	1120	60	230	-	-	Up	-	-


 : Rating over-front
  : Rating over-side or 360 degree


















Lift-point height (A)		Lift-point radius (B)												At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		3.5 m (11.5 ft)		Capacity		Reach
																m (ft)
2.5 m	kg							*320	260					*280	190	2.96
(8.2 ft)	lb							*710	570					*620	420	(9.7)
2.0 m	kg							*340	260	280	190			240	160	3.27
(6.6 ft)	lb							*750	570	620	420			530	350	(10.7)
1.5 m	kg					*460	350	370	250	280	190			220	150	3.45
(4.9 ft)	lb					*1010	770	820	550	620	420			490	330	(11.3)
1.0 m	kg					500	320	360	230	270	180	210	140	210	140	3.54
(3.3 ft)	lb					1100	710	790	510	600	400	460	310	460	310	(11.6)
0.5 m	kg					480	300	350	220	270	170	210	140	210	130	3.54
(1.6 ft)	lb					1060	660	770	490	600	370	460	310	460	290	(11.6)
Ground	kg			*640	440	470	290	340	220	260	170			210	140	3.45
Line	lb			*1410	970	1040	640	750	490	570	370			460	310	(11.3)
-0.5 m	kg	*700	*700	750	440	460	290	330	210	260	170			230	150	3.25
(-1.6 ft)	lb	*1540	*1540	1650	970	1010	640	730	460	570	370			510	330	(10.7)
-1.0 m	kg	*1050	880	750	440	470	290	340	210					270	170	2.93
(-3.3 ft)	lb	*2310	1940	1650	970	1040	640	750	460					600	370	(9.6)
-1.5 m	kg	*1510	900	770	460	480	300							360	230	2.42
(-4.9 ft)	lb	*3330	1980	1700	1010	1060	660							790	510	(7.9)


Model	Type	Boom	Arm	Counterweight	Shoe	Wheel	Dozer		Outtriger	
R16-9	Cabin, Track extended	Length [mm]	Length [mm]	weight [kg]	width [mm]	width [mm]	Front	Rear	Front	Rear
		1800	1120	60	230	-	-	Up	-	-

 : Rating over-front
  : Rating over-side or 360 degree



Lift-point height (A)		Lift-point radius (B)												At max. reach		
		1.0 m (3.3 ft)		1.5 m (4.9 ft)		2.0 m (6.6 ft)		2.5 m (8.2 ft)		3.0 m (9.8 ft)		3.5 m (11.5 ft)		Capacity		Reach
																m (ft)
2.5 m	kg							*320	*320					*280	270	2.96
(8.2 ft)	lb							*710	*710					*620	600	(9.7)
2.0 m	kg							*340	*340	280	270			240	230	3.27
(6.6 ft)	lb							*750	*750	620	600			530	510	(10.7)
1.5 m	kg					*460	*460	370	350	280	260			220	210	3.45
(4.9 ft)	lb					*1010	*1010	820	770	620	570			490	460	(11.3)
1.0 m	kg					500	470	360	340	270	260	210	200	210	200	3.54
(3.3 ft)	lb					1100	1040	790	750	600	570	460	440	460	440	(11.6)
0.5 m	kg					480	440	350	320	270	250	210	200	210	200	3.54
(1.6 ft)	lb					1060	970	770	710	600	550	460	440	460	440	(11.6)
Ground	kg			*640	*640	470	430	340	320	260	240			210	200	3.45
Line	lb			*1410	*1410	1040	950	750	710	570	530			460	440	(11.3)
-0.5 m	kg	*700	*700	750	680	460	430	330	310	260	240			230	220	3.25
(-1.6 ft)	lb	*1540	*1540	1650	1500	1010	950	730	680	570	530			510	490	(10.7)
-1.0 m	kg	*1050	*1050	750	680	470	430	340	310					270	250	2.93
(-3.3 ft)	lb	*2310	*2310	1650	1500	1040	950	750	680					600	550	(9.6)
-1.5 m	kg	*1510	*1510	770	700	480	440							360	340	2.42
(-4.9 ft)	lb	*3330	*3330	1700	1540	1060	970							790	750	(7.9)

6. BUCKET SELECTION GUIDE



0.04 m³ SAE
heaped bucket


Capacity		Width		Weight	Recommendation
					1.8 m (5' 11") boom
SAE heaped	CECE heaped	Without side cutter	With side cutter		0.96 m (3' 2") arm
0.04m ³ (0.05 yd ³)	0.03 m ³ (0.04 yd ³)	390 mm (15.4")	440 mm (17.3")	40 kg (88 lb)	Applicable for materials with density of 1600 kgf/m ³ (2700 lb /yd ³) or less

7. UNDERCARRIAGE

(1) TRACKS

X-leg type center frame is integrally welded with reinforced box-section track frames. The design includes dry tracks, lubricated rollers, idlers, sprockets, hydraulic track adjusters with shock absorbing springs and assembled track-type tractor shoes with triple grousers.

(2) TYPES OF SHOES

Model	Shapes		Rubber track
			
R16-9	Shoe width	mm (in)	230 (9")
	Operating weight	kg (lb)	1650 (3640)
	Ground pressure	kgf/cm ² (psi)	0.28 (3.92)
	Overall width	mm (ft-in)	1250 (4' 1")

(3) NUMBER OF ROLLERS AND SHOES ON EACH SIDE

Item	Quantity
Track rollers	3 EA

8. SPECIFICATIONS FOR MAJOR COMPONENTS

1) ENGINE

Item	Specification
Model	Mitsubishi L3E
Type	4-cycle vertical overhead valve, diesel fuel
Cooling method	Water cooling
Number of cylinders and arrangement	3 cylinders, in-line
Firing order	1-3-2
Combustion chamber type	Swirl chamber type
Cylinder bore × stroke	76 × 70 mm (2.99" × 2.76")
Piston displacement	952 cc (58.1 cu in)
Compression ratio	23 : 1
Rated gross horse power (SAE J1995)	16.8 Hp at 2300 rpm (12.5 kW at 2300 rpm)
Maximum torque at 1600 rpm	5.4 kgf · m (39 lbf · ft)
Engine oil quantity	4.2 ℓ (1.1 U.S. gal)
Dry weight	75 kg (165 lb)
High idling speed	2500+ 30 rpm
Low idling speed	1600 ± 25 rpm
Rated fuel consumption	208 g/Hp · hr at 2300 rpm (279 g/kW · hr at 2300 rpm)
Starting motor	12V-1.7 kW
Alternator	12V-40 A
Battery	1 × 12 V × 80 Ah

2) MAIN PUMP

Item	Specification
Type	Variable displacement tandem axis piston pumps
Capacity	2 × 7.4 cc/rev
Rated oil flow	2 × 17.0 ℓ /min (4.5 U.S. gpm / 3.7 U.K. gpm)
Rated speed	2300 rpm

3) GEAR PUMP

Item	Specification
Type	Fixed displacement gear pump single stage
Capacity	4.5/2.7 cc/rev
Rated oil flow	10.4/6.2 ℓ /min (2.7/1.6 U.S. gpm / 2.3/1.4 U.K. gpm)

4) MAIN CONTROL VALVE

Item	Specification
Type	Sectional, 9 spools (12 blocks)
Operating method	Hydraulic pilot system
Main relief valve pressure	210 kgf/cm ² (2990 psi)
Overload relief valve pressure	230 kgf/cm ² (3270 psi)

5) SWING MOTOR

Item	Specification
Type	Fixed displacement axial piston motor
Capacity	18.1 cc/rev
Relief pressure	165 kgf/cm ² (2350 psi)
Reduction gear type	1 - stage planetary

6) TRAVEL MOTOR

Item	Specification
Type	Variable displacement axial piston motor
Relief pressure	210 kgf/cm ² (2990 psi)
Reduction gear type	2-stage planetary

7) CYLINDER

Item		Specification
Boom cylinder	Bore dia × Rod dia × Stroke	Ø60 × Ø40 × 465 mm
	Cushion	Extend only
Arm cylinder	Bore dia × Rod dia × Stroke	Ø60 × Ø40 × 400 mm
	Cushion	Extend and retract
Bucket cylinder	Bore dia × Rod dia × Stroke	Ø55 × Ø35 × 345 mm
	Cushion	-
Boom swing cylinder	Bore dia × Rod dia × Stroke	Ø55 × Ø30 × 355 mm
	Cushion	-
Dozer cylinder	Bore dia × Rod dia × Stroke	Ø65 × Ø30 × 93 mm
	Cushion	-

※ Discoloration of cylinder rod can occur when the friction reduction additive of lubrication oil spreads on the rod surface.

※ Discoloration does not cause any harmful effect on the cylinder performance.

8) BUCKET

Item	Capacity		Tooth quantity	Width	
	SAE heaped	CECE heaped		Without side cutter	With side cutter
Standard	0.04 m ³ (0.05 yd ³)	0.03 m ³ (0.04 yd ³)	3	390 mm (15.4")	440 mm (17.3")

9. RECOMMENDED OILS

HYUNDAI genuine lubricating oils have been developed to offer the best performance and service life for your equipment. These oils have been tested according to the specifications of HYUNDAI and, therefore, will meet the highest safety and quality requirements.

We recommend that you use only HYUNDAI genuine lubricating oils and grease officially approved by HYUNDAI.

Service point	Kind of fluid	Capacity ℓ (U.S. gal)	Ambient temperature °C(°F)								
			-50 (-58)	-30 (-22)	-20 (-4)	-10 (14)	0 (32)	10 (50)	20 (68)	30 (86)	40 (104)
Engine oil pan	Engine oil	4.2 (1.1)	★SAE 5W-40								
								SAE 30			
				SAE 10W							
				SAE 10W-30							
					SAE 15W-40						
Final drive	Gear oil	0.33×2 (0.09×2)	★SAE 75W-90								
					SAE 85W-140						
Hydraulic tank	Hydraulic oil	Tank; 20 (5.3)	★ISO VG 15								
		System; 30 (7.9)			ISO VG 46, HBHO VG 46★ ³						
					ISO VG 68						
Fuel tank	Diesel fuel★ ¹	25 (6.6)	★ASTM D975 NO.1								
						ASTM D975 NO.2					
Fitting (grease nipple)	Grease	As required	★NLGI NO.1								
						NLGI NO.2					
Radiator (reservoir tank)	Mixture of antifreeze and soft water★ ²	4(1.1)	Ethylene glycol base permanent type (50 : 50)								
			★Ethylene glycol base permanent type (60 : 40)								

SAE : Society of Automotive Engineers

API : American Petroleum Institute

ISO : International Organization for Standardization

NLGI : National Lubricating Grease Institute

ASTM : American Society of Testing and Material

UTTO : Universal Tractor Transmission Oil

★ : Cold region

Russia, CIS, Mongolia

★¹ : Ultra low sulfur diesel

- sulfur content ≤ 15 ppm

★² : Soft water

City water or distilled water

★³ : Hyundai Bio Hydraulic Oil

- For more information, contact HYUNDAI dealers.


※ Using any lubricating oils other than HYUNDAI genuine products may lead to a deterioration of performance and cause damage to major components.

※ Do not mix HYUNDAI genuine oil with any other lubricating oil as it may result in damage to the systems of major components.

※ Do not use any engine oil other than that specified above, as it may clog the diesel particulate filter(DPF).

※ For HYUNDAI genuine lubricating oils and grease for use in regions with extremely low temperatures, please contact HYUNDAI dealers.

6. BUCKET SELECTION GUIDE



0.04 m³ SAE
heaped bucket


Capacity		Width		Weight	Recommendation
					1.8 m (5' 11") boom
SAE heaped	CECE heaped	Without side cutter	With side cutter		0.96 m (3' 2") arm
0.04m ³ (0.05 yd ³)	0.03 m ³ (0.04 yd ³)	390 mm (15.4")	440 mm (17.3")	40 kg (88 lb)	Applicable for materials with density of 1600 kgf/m ³ (2700 lb /yd ³) or less

7. UNDERCARRIAGE

(1) TRACKS

X-leg type center frame is integrally welded with reinforced box-section track frames. The design includes dry tracks, lubricated rollers, idlers, sprockets, hydraulic track adjusters with shock absorbing springs and assembled track-type tractor shoes with triple grousers.

(2) TYPES OF SHOES

Model	Shapes		Rubber track
			
R16-9	Shoe width	mm (in)	230 (9")
	Operating weight	kg (lb)	1650 (3640)
	Ground pressure	kgf/cm ² (psi)	0.28 (3.92)
	Overall width	mm (ft-in)	1250 (4' 1")

(3) NUMBER OF ROLLERS AND SHOES ON EACH SIDE

Item	Quantity
Track rollers	3 EA

8. SPECIFICATIONS FOR MAJOR COMPONENTS

1) ENGINE

Item	Specification
Model	Mitsubishi L3E
Type	4-cycle vertical overhead valve, diesel fuel
Cooling method	Water cooling
Number of cylinders and arrangement	3 cylinders, in-line
Firing order	1-3-2
Combustion chamber type	Swirl chamber type
Cylinder bore × stroke	76 × 70 mm (2.99" × 2.76")
Piston displacement	952 cc (58.1 cu in)
Compression ratio	23 : 1
Rated gross horse power (SAE J1995)	16.8 Hp at 2300 rpm (12.5 kW at 2300 rpm)
Maximum torque at 1600 rpm	5.4 kgf · m (39 lbf · ft)
Engine oil quantity	4.2 ℓ (1.1 U.S. gal)
Dry weight	75 kg (165 lb)
High idling speed	2500+ 30 rpm
Low idling speed	1600 ± 25 rpm
Rated fuel consumption	208 g/Hp · hr at 2300 rpm (279 g/kW · hr at 2300 rpm)
Starting motor	12V-1.7 kW
Alternator	12V-40 A
Battery	1 × 12 V × 80 Ah

2) MAIN PUMP

Item	Specification
Type	Variable displacement tandem axis piston pumps
Capacity	2 × 7.4 cc/rev
Rated oil flow	2 × 17.0 ℓ /min (4.5 U.S. gpm / 3.7 U.K. gpm)
Rated speed	2300 rpm

3) GEAR PUMP

Item	Specification
Type	Fixed displacement gear pump single stage
Capacity	4.5/2.7 cc/rev
Rated oil flow	10.4/6.2 ℓ /min (2.7/1.6 U.S. gpm / 2.3/1.4 U.K. gpm)

4) MAIN CONTROL VALVE

Item	Specification
Type	Sectional, 9 spools (12 blocks)
Operating method	Hydraulic pilot system
Main relief valve pressure	210 kgf/cm ² (2990 psi)
Overload relief valve pressure	230 kgf/cm ² (3270 psi)

5) SWING MOTOR

Item	Specification
Type	Fixed displacement axial piston motor
Capacity	18.1 cc/rev
Relief pressure	165 kgf/cm ² (2350 psi)
Reduction gear type	1 - stage planetary

6) TRAVEL MOTOR

Item	Specification
Type	Variable displacement axial piston motor
Relief pressure	210 kgf/cm ² (2990 psi)
Reduction gear type	2-stage planetary

7) CYLINDER

Item		Specification
Boom cylinder	Bore dia × Rod dia × Stroke	Ø60 × Ø40 × 465 mm
	Cushion	Extend only
Arm cylinder	Bore dia × Rod dia × Stroke	Ø60 × Ø40 × 400 mm
	Cushion	Extend and retract
Bucket cylinder	Bore dia × Rod dia × Stroke	Ø55 × Ø35 × 345 mm
	Cushion	-
Boom swing cylinder	Bore dia × Rod dia × Stroke	Ø55 × Ø30 × 355 mm
	Cushion	-
Dozer cylinder	Bore dia × Rod dia × Stroke	Ø65 × Ø30 × 93 mm
	Cushion	-

※ Discoloration of cylinder rod can occur when the friction reduction additive of lubrication oil spreads on the rod surface.

※ Discoloration does not cause any harmful effect on the cylinder performance.

8) BUCKET

Item	Capacity		Tooth quantity	Width	
	SAE heaped	CECE heaped		Without side cutter	With side cutter
Standard	0.04 m ³ (0.05 yd ³)	0.03 m ³ (0.04 yd ³)	3	390 mm (15.4")	440 mm (17.3")

9. RECOMMENDED OILS

HYUNDAI genuine lubricating oils have been developed to offer the best performance and service life for your equipment. These oils have been tested according to the specifications of HYUNDAI and, therefore, will meet the highest safety and quality requirements.

We recommend that you use only HYUNDAI genuine lubricating oils and grease officially approved by HYUNDAI.

Service point	Kind of fluid	Capacity ℓ (U.S. gal)	Ambient temperature °C(°F)								
			-50 (-58)	-30 (-22)	-20 (-4)	-10 (14)	0 (32)	10 (50)	20 (68)	30 (86)	40 (104)
Engine oil pan	Engine oil	4.2 (1.1)	★SAE 5W-40								
								SAE 30			
				SAE 10W							
				SAE 10W-30							
					SAE 15W-40						
Final drive	Gear oil	0.33×2 (0.09×2)	★SAE 75W-90								
					SAE 85W-140						
Hydraulic tank	Hydraulic oil	Tank; 20 (5.3)	★ISO VG 15								
		System; 30 (7.9)			ISO VG 46, HBHO VG 46★ ³						
					ISO VG 68						
Fuel tank	Diesel fuel★ ¹	25 (6.6)	★ASTM D975 NO.1								
						ASTM D975 NO.2					
Fitting (grease nipple)	Grease	As required	★NLGI NO.1								
						NLGI NO.2					
Radiator (reservoir tank)	Mixture of antifreeze and soft water★ ²	4(1.1)	Ethylene glycol base permanent type (50 : 50)								
			★Ethylene glycol base permanent type (60 : 40)								

SAE : Society of Automotive Engineers

API : American Petroleum Institute

ISO : International Organization for Standardization

NLGI : National Lubricating Grease Institute

ASTM : American Society of Testing and Material

UTTO : Universal Tractor Transmission Oil

★ : Cold region

Russia, CIS, Mongolia

★¹ : Ultra low sulfur diesel

- sulfur content ≤ 15 ppm

★² : Soft water

City water or distilled water

★³ : Hyundai Bio Hydraulic Oil

- For more information, contact HYUNDAI dealers.

※ Using any lubricating oils other than HYUNDAI genuine products may lead to a deterioration of performance and cause damage to major components.

※ Do not mix HYUNDAI genuine oil with any other lubricating oil as it may result in damage to the systems of major components.

※ Do not use any engine oil other than that specified above, as it may clog the diesel particulate filter(DPF).

※ For HYUNDAI genuine lubricating oils and grease for use in regions with extremely low temperatures, please contact HYUNDAI dealers.

SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device	2-1
Group 2 Main Control Valve	2-8
Group 3 Swing Device	2-37
Group 4 Travel Device	2-47
Group 5 RCV Lever	2-58
Group 6 RCV Pedal	2-65

SECTION 2 STRUCTURE AND FUNCTION


GROUP 1 HYDRAULIC PUMP

1. GENERAL

This is a variable displacement double-piston pump for discharge with equal displacements from one cylinder block. This pump is so compact as to appear a single pump though this is actually a double pump.

Because this pump has one swash plate, the tilting angle is the same for two pumps. Tilting of the pump changes in response to the total pressure of A1 + A2. Namely, the output is controlled to the constant value so that the relationship between the discharge pressure and flow rate Q becomes constant, $(A1 + A2) * Q = \text{Constant}$.

The third pump and pilot pump can be connected to the same shaft via a coupling.




1692MP01

Description of the ports

Port	Port name	Port size
S1	Suction port	SAE 1 1/4
A1, A2, A3, A4	Discharge port	PF 3/8

2. MAJOR COMPONENTS AND FUNCTIONS



1692MP02

- | | | | |
|---|----------------------|----|------------------|
| 1 | Drive shaft assembly | 7 | Gear pump |
| 2 | Swash plate assembly | 8 | Housing |
| 3 | Cylinder barrel | 9 | Oil seal |
| 4 | Port plate assembly | 10 | Bearing |
| 5 | Spring seat assembly | 11 | Stopper assembly |
| 6 | Piston | 12 | Spring |

This is a variable displacement double-piston pump for discharge with two equal displacements from one cylinder block. Because this is one cylinder barrel, there is only one suction port.

The oil is divided into two equal flows by the control plate in the cover and directed to two discharge ports provided in the cover.

The discharge pressure directed to the piston tilts the hanger by overcoming the spring force.

Since the piston stroke changes according to the tilting angle of the hanger, the flow can be changed.

The simultaneous tilting angle constant-output control method is employed.

The pilot pump can be connected to the same shaft via a coupling.

1) PRINCIPLE OF OPERATION

(1) Function of pump




Figure 1 Working principle of PVD pump




Figure 2 Working principle of Conventional type

R27Z92MP05


This pump adopts a new method using even numbered pistons to make functions of two same volume pumps available in one casing of a swash plate type variable volume piston pump.

Conventional valve plate has one suction groove and one discharge groove respectively as shown in figure 2. But this method adopts one common suction groove and two discharge grooves on the outer side (A1) and the inner side (A2) as shown in figure 1, the piston room in the cylinder barrel opens to either the outer side (A1) or the inner side (A2) discharge groove of the valve plate alternately, and the discharges are performed independently on the inner side and the outer side.

Since this model has even numbered pistons, same No of pistons open to the outer side and the inner side of the valve plate. All pistons are of same swash plate, so the discharges from the outer side (A1) and the inner side (A2) are equal.

Also, since only one swash plate is used, the discharges from A1 and A2 ports changes equally when the swash plate angle of rake changes in variable controls. So, there is no difference between the two discharges.

2) CONTROL FUNCTIONS



R27Z92MP04

(1) Constant horse power variable structure



The pump output flow rate is variable depending on an angle of the swash plate which is controlled according to the pump output pressure. This control enables the pump consumption horse power to be sustained at the maximum. The tilt point of the swash plate is the balls located behind the swash plate. The load F_1 from the pistons is in the direction shown in the illustration and generates a clockwise moment against the swash plate. Against this force the spring (force F_2) is located in the opposite direction to keep the horse power constant and set at the appointed load. As the pressure increases, the above clockwise moment increases, and when it overcomes the counter-clockwise moment created by the spring force, the spring is sagged and the swash plate angle gets smaller. Then the output flow rate is reduced to keep the horse power constant. This prevents engine stall and the engine horse power can be utilized at the maximum.

(2) Power shift mode (Reduced horse power control by A3 pressure)

This control keeps the maximum value of the pump consumption horse power including the third pump (gear pump) constant. When the A3 (gear pump) pressure acts on the rod G, a clockwise moment proportion to the pressure acts on the swash plate and the A-Q characteristic shifts so that the total pump consumption horse power including the gear pump horse power is kept constant.

3) CONTROL / ADJUSTMENT PROCEDURE

- (1) Loosen the hexagonal nut.
- (2) Tighten or loosen the adjusting screw to set the power shifting line.



R27Z92MP07

3. ADJUSTMENT

This hydraulic pump has been set and inspected according to specified input power and control. Readjustment of all the adjusting portions may lead to the loss of functions specified for each control and the pump proper may be excluded from the scope of guarantee. Never attempt operating the adjusting screw, etc.

4. INSTALLATION

- (1) Install the pump so that the input shaft becomes horizontal.
- (2) Install the pump in a position lower than the lowest oil level in the tank to allow continuous flow of the oil into the pump.
- (3) Since the pump is installed directly to the diesel engine, always use a flexible hose. Install the suction pipe firmly to prevent suction of an air.
- (4) Use the high-pressure type flexible hoses for the discharge ports A1~A2.
- (5) After installation, fill the pump housing with the hydraulic oil.
- (6) Do not direct the external drain piping from within the oil.

5. DRIVE

- (1) Use a flexible coupling for connection to the motor.
- (2) Insert the coupling firmly onto the input shaft. Do not hammer the coupling during insertion.
- (3) The input shaft must rotate clockwise when viewed from the shaft end.

6. HYDRAULIC OIL

The hydraulic oil to be used must be a general petroleum, hydraulic oil or wear-resistant hydraulic oil (ISO 3448, VG 32~56 or equivalent).

The applicable viscosity range is as follows :

Maximum allowable viscosity : 1000 mm²/s

Minimum allowable viscosity : 10 mm²/s

Recommended viscosity range : 15 ~ 36 mm²/s

7. STARTING PROCEDURE

※ **Before start up, check the following points and observe the cautions :**

- (1) Check if the tank has been washed clean.
- (2) Check if the piping is clean and installed in such a manner as to prevent stress on the pump.
- (3) Check if the piping is connected correctly according to the piping (circuit) diagram.
- (4) Check if the joint and flange are correctly tightened.
- (5) Check if the joint between the motor and pump is correctly installed.
- (6) Check if the motor rotation direction agrees with the pump rotation direction.
- (7) Check if the specific hydraulic oil is supplied through the filter and filled in the tank to the specified position of the oil level gauge.
- (8) Check if the filter has the specified filtration accuracy (10 μm or less).
- (9) Check if the filter has been installed correctly relative to the flow direction.
- (10) Check if the pump housing is filled with oil.
- (11) Check if the control valve is set to the bypass position.
- (12) Start the motor. If necessary, carry out warm-up operation at low speed.
- (13) Check, without any load on the system, if the actuator operates correctly.


- (14) When the motor has reached the operation speed, check the operation while applying the load to the actuator.
- (15) Check the monitoring or measuring instrument if installed.
- (16) Check the noise level.
- (17) Check the oil level in the tank. Supply the oil. If required.
- (18) Check the setting of the pressure control valve while applying the load to the actuator.
- (19) Check the parts for any leakage.
- (20) Stop the motor.
- (21) Retighten all the bolts and plugs even when they have proved to be free from Leakage.
(Be sure to remove the pressure from the circuit before retightening.)
- (22) Check the oil level in the tank.
- (23) Check if the pump and actuator function correctly.
- (24) Irregular operation of the actuator indicates that an air is left still in the circuit. When the air is bled completely from the circuit, all the parts operate smoothly without any irregular movement and there is no bubble in the oil of the tank.
- (25) Check the oil temperature.
- (26) Stop the motor.
- (27) Check the filter if the element is fouled.
- (28) If the element is heavily fouled, carry out flushing in the circuit.

※ **To prevent damage to the pump, be sure to observe the following cautions during the operation which may allow entry of the actuator, hydraulic oil change, etc :**

- (1) After oil supply, fill the pump housing with the hydraulic oil.
- (2) Start the pump with the speed of 1000 rpm or less and take care not to allow the oil level to lower below the specified level of the oil level gauge.
- (3) When bleeding an air from the hydraulic circuit, keep the motor speed at 1000 rpm or less. Operate each actuator for three or more cycles and carry out idling for 5 minutes or more.

GROUP 2 MAIN CONTROL VALVE


1. OUTLINE



1692MC01

Mark	Port name	Port size	Tightening torque	Mark	Port name	Port size	Tightening torque
P1	P1 (A1) pump port	PF 1/2	6~7 kgf · m	A10	Bucket out port	PF 3/8	4.0~5.0 kgf · m
P2	P2 (A2) pump port			B10	Bucket in port		
T1	Tank return port			Pa1	Dozer down pilot port	PF 1/4	2.5~3.0 kgf · m
T2	Tank return port			Pb1	Dozer up pilot port		
P3	P3 (A3) pump port	Pa2	Boom swing (RH) pilot port				
A1	Dozer	Pb2	Boom swing (LH) pilot port				
B1	Dozer	Pa3	Swing (RH) pilot port				
A2	Boom swing (RH) port	Pb3	Swing (LH) pilot port				
B2	Boom swing (LH) port	Pa5	Arm out pilot port				
A3	Swing (LH) port	Pb5	Arm in pilot port				
B3	Swing (RH) port	Pa6	Travel [LH/RR] pilot port				
A4	Option port	Pb6	Travel [LH/FW] pilot port				
B4	Option port	Pa7	Travel [RH/RR] pilot port				
A5	Arm out port	Pb7	Travel [RH/FW] pilot port				
B5	Arm in port	Pa8	Boom up pilot port				
A6	Travel [LH/RR] port	Pb8	Boom down pilot port				
B6	Travel [LH/FW] port	Pa10	Bucket out pilot port				
A7	Travel [RH/RR] port	Pb10	Bucket in pilot port				
B7	Travel [RH/FW] port	Pp1	Travel signal input port				
A9	Boom up port	Pb8	Boom lock valve release port				
B8	Boom down port	Dr1	Travel drain port				
		Dr2	Boo lock valve drain port				


2. STRUCTURE (1/3)



1692MC02

1	Dozer work block	2-9	Cover-pilot	4-7	O-ring
1-1	Body-work	2-10	Bolt-soc head w/washer	4-8	Cover-pilot
1-2	Spool assy	3	Swing work block	4-9	Bolt-soc head w/washer
1-3	Poppet	3-1	Body-work	4-10	Plug
1-4	Spring	3-2	Spool assy	4-11	O-ring
1-5	O-ring	3-3	Poppet	4-12	Plug
1-6	Plug	3-4	Spring	4-13	Piston
1-7	O-ring	3-5	O-ring	4-14	O-ring
1-8	Cover-pilot	3-6	Plug	4-15	Body-pilot
1-9	Cover-pilot	3-7	O-ring	4-16	Bolt-soc head w/washer
1-10	Bolt-soc head w/washer	3-8	Cover-pilot	4-17	Orifice
2	Boom swing work block	3-9	Cover-pilot	4-18	Filter-coin type
2-1	Body-work	3-10	Bolt-soc head w/washer	14	Relief valve
2-2	Spool assy	4	Connecting block	16	Plug
2-3	Poppet	4-1	Body-work	17	O-ring
2-4	Spring	4-2	Spool assy	22	O-ring
2-5	O-ring	4-3	Poppet	23	Bolt-tie
2-6	Plug	4-4	Spring	24	Nut-hex
2-7	O-ring	4-5	O-ring	25	Anticavitation valve
2-8	Cover-pilot	4-6	Plug		


STRUCTURE (2/3)



1692MC03

5	PTO work block	6-2	Spool assy	7-4	Plug
5-1	Body-work	6-3	Poppet	7-5	O-ring
5-2	Spool assy	6-4	Spring	7-6	Cover-pilot
5-3	Poppet	6-5	O-ring	7-7	Cover-pilot
5-4	Spring	6-6	Plug	7-8	Bolt-soc head w/washer
5-5	O-ring	6-7	O-ring	8	Inlet work block
5-6	Plug	6-8	Cover-pilot	13	Relief valve
5-7	O-ring	6-9	Cover-pilot	15	Overload relief valve
5-8	Cover-pilot	6-10	Bolt-soc head w/washer	17	O-ring
5-9	Cover-pilot	7	Travel work block	18	O-ring
5-10	Bolt-soc head w/washer	7-1	Body work	19	O-ring
6	Arm work block	7-2	Spool assy		
6-1	Body-work	7-3	O-ring		


STRUCTURE (3/3)



1692MC04

9	Travel work block	10-8	Cover-pilot	12-3	Poppet	105	Spacer
9-1	Body-work	10-9	Cover-pilot	12-4	Spring	106	Ring-retaining
9-2	Spool assy	10-10	Bolt-soc head w/washer	12-5	O-ring	107	Spring A-lock valve
9-3	Poppet	11	Boom lock valve	12-6	Plug	108	Spring seat
9-4	Spring	11-1	Body-work	12-7	O-ring	109	Pin
9-5	O-ring	11-2	O-ring	12-8	Cover-pilot	110	Poppet
9-6	Plug	11-3	Plug	12-9	Cover-pilot	111	Ring-retaining
9-7	O-ring	11-4	Poppet	12-10	Bolt-soc head w/washer	112	O-ring
9-8	Cover-pilot	11-5	Spring	15	Overload relief valve	113	Guide-piston
9-9	Cover-pilot	11-6	Plug	17	O-ring	114	Piston A1
9-10	Bolt-soc head w/washer	11-7	O-ring	18	O-ring	115	Piston B
10	Boom work block	11-8	Plug	19	O-ring	116	O-ring
10-1	Body-work	11-9	O-ring	20	O-ring	117	Connector
10-2	Spool assy	11-10	O-ring	21	O-ring	118	Ball-steel
10-3	Poppet	11-11	Plug	25	Anticavitation valve	119	Plug
10-4	Spring	11-12	O-ring	101	Cover-lock valve	120	Bolt-hex. socket head
10-5	O-ring	12	Bucket work block	102	Lock valve		
10-6	Plug	12-1	Body-work	103	Seal		
10-7	O-ring	12-2	Spool assy	104	Filter		

3. HYDRAULIC CIRCUIT



1692MC05

4. FUNCTION

1) IN NEUTRAL (When all spools are in neutral position)

P1 : The oil discharged from the hydraulic pump flows into control valve P1 port, and then flows through P1 and P2 supply body the P1 side travel spool. The oil flows through the bypass passage in the direction of travel → boom → bucket spool, and then flows from the bypass passage to the tank passage in the bucket section.

P2 : The oil discharged for the hydraulic pump flows into the control valve from P2 port, and then flows through P1 and P2 supply body to the P2 side travel spool. The oil flows through the bypass passage in the direction of travel → arm → PTO spool, and the flows from the bypass passage to the tank passage in the PTO section.


P3 : The oil discharged from the hydraulic pump flows into the control valve from P3 port, and then flows through the parallel passage of dozer, boom swing, and swing. The oil that has followed into the parallel passage flows through the bypass passage in the direction of dozer → Boom swing → swing spool, the connecting spool land, the P2 side parallel passage, the bypass passage from arm to PTO spool, the bypass passage in the PTO section, and then to the tank passage.

※ **Since each line (P1, P2, P3) is supplied with oil from the pump, the section is operatable; therefore, do not operate the control valve except the working time.**

- P1 line : Travel, boom, bucket
- P2 line : Travel, arm, PTO
- P3 line : Dozer, boom swing, arm, PTO, boom (up only)

P_{P1} : When P_{P1} port is applied with pilot pressure, the oil flows into the travel independent passage via an orifice.

With the spool in neutral, the oil flows into Dr1 port provided in the P1 and P2 supply body.



Hydraulic oil flow in neutral

R35Z72MCV11


2) TRAVEL OPERATION

For the travel operation, both Pa pressurization and Pb pressurization are the same on operation so that only Pa pressurization is explained as follows.

When left (right) travel reverse is operated, the secondary pressure from the remote control valve is applied to Pa6 [Pa7] port to change over the travel spool. The oil flowed from P2 [P1] port flows through the supply body into the P2 [P1] side bypass passage. The oil flowed into the P2 [P1] side bypass passage flows through A6 [A7] port that has been opened by the spool changeover to the travel motor. On the other hand, the oil returned from the travel motor flows into the control valve from B6 [B7] port and then to the tank passage has been opened after the spool changeover.

The oil flowed from Pp1 port flows through the orifice passage provided in the P3 supply section into the travel independent signal passage.

Although the travel independent passage (see page 2-14) in the travel section that has been opened during neutral is blocked after the both travel spools changeover, the travel independent signal passage is connected to the drain port via the bucket section. Accordingly, when the bucket section has not changed over, the connecting spool in the P3 supply section does not change over because the pressure in the travel independent signal passage is equal to the drain pressure.



Operation during travel(Forward)

R35Z72MCV12

3) BOOM OPERATION

Boom up operation

When the boom up operation is carried out, the secondary pressure from the remote control valve is applied to Pa8 port to change over the boom spool. Since Pa8 port is connected to boom up port through the piping, the pressure oil supplied to boom up port changes over the connecting spool through the connecting piston in the P3 supply section

Also, since the P1 side bypass passage is shut off at the boom section after the boom spool changeover, the oil flowed from P1 port flows through the check valve provided above the bypass passage in the travel section into the P1 side parallel passage.

On the other side, after the connecting spool changeover the oil flowed into P3 port.

- ① Flows through the internal passage in connecting spool and the check valve in the P3 supply section into the P1 side parallel passage.
- ② The oil flows through the P3 side parallel passage and P3 side bypass passage and then:
 - a. Flows through the check valve in the P3 supply section into the P1 side parallel passage.
 - b. Some oil flows through the orifice passage provided in the connecting spool and the check valve in the P3 supply section into the P2 side parallel passage.

The oil flowed into the P1 side parallel passage is connected with the oil from P1 pump.


The oil flowed into the P2 side parallel passage flows through the bypass passages in the arm section and PTO section to the tank passage.

Since the passage connected to the boom lock valve and the bridge passage are opened after the boom spool changeover, the oil flowed into the P1 side parallel passage flows through the load check valve in the boom section and the bridge passage into the boom lock valve section


The oil flowed into the boom lock valve section opens the lock valve (free flow condition), flows into A9 port, and the to the head side of the boom cylinder.

On the other hand, the oil returned from the rod side of the boom cylinder flows into B8 port to the tank passage that has opened with the spool's notch after the spool changeover. Then, the boom cylinder extends to raise the boom.

P1 side circuit



P3 side (Connecting side) circuit



Boom up operation

R35Z72MCV13

Boom down operation

When the boom down operation is carried out, the secondary pressure from the remote control valve is applied to Pb8 port to change over the boom spool.


Since Pb8 port is connected to Pb8' port through the piping, the pressure is also applied to pb8' port (Boom lock valve release port) to release the boom lock valve.

(For the explanation of boom lock valve operation, see pages 2-19, 20)

Since the bypass passage is shut off at the boom section after the spool changeover (some oil flows through the orifice passage provided in the boom spool's bypass passage to the downstream side of the bypass passage), the oil flowed from P1 port flows through the check valve provided above the bypass passage in the travel section into the P1 side parallel passage.

Also, since a passage between B8 port and bridge passage is opened with the spool's notch after the spool changeover, the oil flowed into the P1 side parallel passage flows through the load check valve in the boom section into B8 port via the bridge passage and then into the rod side of the boom cylinder.

On the other side, the oil returned from the head side of the boom cylinder flows into A9 port to the tank passage that has been opened with the spool's notch after the spool changeover through the boom lock valve that has been released by Pb8' port pressure. Then, the boom cylinder retracts to lower the boom.



Boom down operation

R35Z72MCV14

4) Operation of boom lock valve

(1) Holding

In the boom spool neutral condition,


- The pilot piston chamber (a) is connected to the drain passage through the pilot port (Pb8') for releasing the boom lock valve.
- The piston chamber (b) is also connected to the drain passage through the drain port (Dr2).

Therefore, the piston (B) maintains the condition shown in the figure.

The boom cylinder holding pressure (shown in half-tone dot meshing) is applied to the lock valve chamber as shown in the figure to :

- Press the needle valve against the needle valve seat.
- Press the lock valve against the body seat.

Then, oil leakage from the boom cylinder head side is prevented to stop the movement of the boom cylinder due to leakage.



Operation of boom lock valve (holding)


R35Z72MCV15

(2) Release

When the pilot pressure is applied to the pilot port (Pb8') for boom lock valve release, the piston (B) moves rightward to open the needle valve through the piston (A1).

Then, the oil returned from the boom cylinder flows through the passage in the direction of lock valve's orifice → lock valve chamber → needle valve seat → check valve into the lock valve's downstream side chamber (boom section).

When the lock valve's downstream chamber is connected to the tank passage after the boom spool changeover and the needle valve is released, the pressure in the lock valve chamber decreases to open the lock valve by the oil returned from the boom cylinder. The returned oil flows into the tank passage with the boom spool's notch to operate the cylinder.



Operation of boom lock valve (release)

R35Z72MCV16

5) BUCKET OPERATION


Bucket in operation

When the bucket in operation is carried out, the secondary pressure from the remote control valve flows into Pb10 port to change over the bucket spool.

Since the P1 side bypass passage is shut off at the bucket section after the bucket spool changeover, the oil flowed from P1 port flows through the check valve provided above the bypass passage in the travel section into the P1 side parallel passage.

Also, since a passage between B10 port and the bridge passage is opened after the spool changeover, the oil flowed into the P1 side parallel passage flows through the load check valve in the bucket section into B10 port via the bridge passage and then the head side of the bucket cylinder.

On the other hand, the oil returned from the rod side of the bucket cylinder flows into A10 port to the tank passage that has opened with the spool's notch after the spool changeover. Then, the bucket cylinder extends to make the bucket in.




Bucket in operation

Bucket out operation

When the bucket out operation is carried out, the secondary pressure from the remote control valve flows into Pa10 port to change over the bucket spool.

Since the P1 side bypass passage is shut off at the bucket section after the bucket spool changeover, the oil flowed from P1 port flows through the check valve provided above the bypass passage in the travel section into the P1 side parallel passage.

Also, since a passage between A10 port and the bridge passage is opened after the spool changeover, the oil flowed into the P1 side parallel passage flows through the load check valve in the bucket section into A10 port via the bridge passage and then the rod side of the bucket cylinder. On the other hand, the oil returned from the head side of the bucket cylinder flows into B10 port to the tank passage that has opened after the spool changeover.



Bucket out operation

R35Z72MCV18

6) ARM OPERATION

Arm in operation


When the arm in operation is carried out, the secondary pressure from the remote control valve is applied to Pb5 port to change over the arm spool. The secondary pressure is also applied to the pilot chamber (arm in port) on the connecting section spring chamber side that has been connected through the piping. Therefore, when the operation is carried out together with the boom up operation at the same time, the connecting spool is hard to change over against the pilot pressure for arm in operation.

Since the P2 port bypass passage is shut off at the arm section after the arm spool change over, the oil flowed from P2 port flows through the travel section and a passage between travel section and arm section into the P2 side parallel passage.

Also, since the oil flowed from P3 port flows through the direction of dozer → boom swing → swing section and then into the P2 side parallel passage via the check valve in the P3 supply section, the connecting flow of P2 pump and P3 pump is supplied to the P2 side parallel passage. [Although the P3 side bypass passage is also connected to the P1 side parallel passage through the check valve in the P3 section, there is no oil flow into the P1 side as long as the P1 side sections (boom , bucket) are not operated.]

Since a passage between B5 port and the bridge passage is opened after the spool changeover, the oil flowed into the P2 side parallel passage flows through the load check valve in the arm section into B5 port via the bridge passage and then into the head side of the arm cylinder.

On the other hand, the oil returned from the rod side of the arm cylinder flows into A5 port to the tank passage that has opened with the spool's notch after the spool changeover. Then, the arm cylinder extends to make the arm in.



Arm in operation

R35Z72MCV19

Arm out operation


When the arm out operation is carried out, the secondary pressure from the remote control valve is applied to Pa5 port to change over the arm spool.

Since the P2 side bypass passage is shut off at the arm section after the arm spool changeover, the oil flowed from P2 port flows through the travel section and a passage between travel section and arm section into the P2 side parallel passage.

Also, since the oil flowed from P3 port flows through the direction of dozer → boom swing → swing section and then into the P2 side parallel passage via the check valve in the P3 supply section, the connecting flow of P2 pump and P3 pump is supplied to the P2 side parallel passage. [Although the P3 side bypass passage is also connected to the P1 side parallel passage through the check valve in the P3 section, there is no oil flow into the P1 side as long as the P1 side sections (boom , bucket) are not operated.]

Since a passage between A5 port and the bridge passage is opened after the spool changeover, the oil flowed into the P2 side parallel passage flows through the load check valve in the arm section into A5 port via the bridge passage and then into the rod side of the arm cylinder.

On the other hand, the oil returned from the head side of the arm cylinder flows into B5 port to the tank passage that has opened after the spool changeover. Then, the arm cylinder retracts to make the arm out.



Arm out operation

R35Z72MCV20

7) PTO OPERATION

For the PTO operation, both Pa pressurization and Pb pressurization are the same on operation so that only Pa pressurization is explained as follows.


When the PTO operation (Pa4 pressurization) is carried out, the secondary pressure from the remote control valve is applied to Pa4 port to change over the PTO spool. Since the P2 side bypass passage is shut off at the PTO section after the PTO spool changeover, the oil flowed from P2 port flows through the travel section and a passage between travel section and arm section into the P2 side parallel passage.

Also, since the oil flowed from P3 port flows through the direction of dozer → boom swing → swing section and then into the P2 side parallel passage via the check valve in the P3 supply section, the connecting flow of P2 pump and P3 pump is supplied to the P2 parallel passage.

[Although the P3 side bypass passage is also connected to the P1 side parallel passage through the check valve in the P3 section, there is no oil flow into the P1 side as long as the P1 side sections (boom , bucket) are not operated.]

Since a passage between A4 port and the bridge passage is opened after the spool changeover, the oil flowed into the P2 side parallel passage flows through the load check valve in the PTO section into A4 port via the bridge passage and then into the actuator for PTO.

On the other hand, the oil returned from actuator for PTO flows into B4 port to the tank passage that has opened after the spool changeover.



PTO operation

R35Z72MCV21

8) DOZER OPERATION


Dozer up operation

When the dozer up operation is carried out, the secondary pressure from the remote control valve is applied to Pa1 port to change over the dozer spool.

Since the P3 side bypass passage is shut off at the dozer section after the dozer spool changeover, the oil flowed from P3 port through the P3 side parallel passage flows into A1 port through the load check valve in the dozer section and the bridge passage since A1 port and the bridge passage have been opened after the spool changeover and then into the rod side of the dozer cylinder.

On the other hand, the oil returned from the head side of the dozer cylinder flows into B1 port to the tank passage that has opened after the spool changeover.

Then, the dozer cylinder retracts to raise the dozer.




Dozer up operation

When the dozer down operation is carried out, the secondary pressure from the remote control valve is applied to Pb1 port to change over the dozer spool.

On the other hand, the oil returned from the rod side of the dozer cylinder flows into A1 port to the tank passage that has opened with the spool's notch after the spool changeover.

Then, the dozer cylinder extends to lower the dozer.



Dozer down operation

9) BOOM SWING OPERATION



Boom left swing operation

When the boom left swing operation is carried out, the secondary pressure from the remote control valve is applied to Pb2 port to change over the boom swing spool.

Since the P3 side bypass passage is shut off at the boom swing section after the boom swing spool changeover, the oil flowed from P3 port through the P3 side parallel passage flows into B2 port through the load check valve in the boom swing section and the bridge passage since B2 port and the bridge passage have been opened after the spool changeover and then into the rod side of the boom swing cylinder.

On the other hand, the oil returned from the head side of the boom swing cylinder flows into A2 port to the tank passage that has opened with the spool's notch after the spool changeover.

Then, the boom swing cylinder retracts to swing the attachment left.



Boom left swing operation

R35Z72MCV24


Boom right swing operation

When the boom right swing operation is carried out, the secondary pressure from the remote control valve is applied to Pa2 port to change over the boom swing spool.

Since the P3 side bypass passage is shut off at the boom swing section after the boom swing spool changeover, the oil flowed from P3 port through the P3 side parallel passage flows into A2 port through the load check valve in the boom swing section and the bridge passage since A2 port and the bridge passage have been opened after the spool changeover and then into the head side of the boom swing cylinder.

On the other hand, the oil returned from the rod side of the boom swing cylinder flows into B2 port to the tank passage that has opened with the spool's notch after the spool changeover.

Then, the boom swing cylinder extends to swing the attachment right.



T1

Boom right swing operation

R35Z72MCV25

(10) SWING OPERATION


For the swing operation, both Pa pressurization and Pb pressurization are the same on operation so that only Pa pressurization is explained as follows.

When the right swing operation is carried out, the secondary pressure from the remote control valve is applied to Pa3 port to change over the swing spool.

Since the P3 side bypass passage is shut off at the swing section after the swing spool changeover, the oil flowed from P3 port through the P3 side parallel passage flows into A3 port through the load check valve in the swing section and the bridge passage since A3 port and the bridge passage have been opened after the spool changeover and then into the swing motor.

On the other hand, the oil returned from the swing motor flows into B3 port to the tank passage that has opened with the spool's notch after the spool changeover.

Then, the upper swing body swings right.



Right swing operation

(11) COMBINED CONTROL OPERATION ①

Boom up + Arm in + bucket

When the above combined control is carried out, the secondary pressure from the remote control valve is applied to each spool to change over them. Since the secondary pressure for arm in operation is also applied to the pilot chamber on the connecting section spring chamber side according to the piping, the connecting spool operates against the secondary pressure developed from boom up operation and arm in operation.

(Boom up operation secondary pressure - Arm in operation secondary pressure = connecting spool changeover pressure)


When all the above combined operations are carried out in full lever operation (full changeover), the oil supplied from P1 pump is supplied to the boom and bucket and the oil from P2 pump to the arm. Since the connecting spool changeover pressure becomes "0" as mentioned above, the connecting spool cannot change over and the oil from P3 pump flows to the P1 and P2 side parallel passages through the connecting section. Accordingly, much oil flows to the arm side normally because of its low working load.

In this condition, since gradually restricting the arm in operation (returning the lever) causes the secondary pressure for arm in operation to decrease, the connecting spool changeover pressure to increase, the connecting spool to start changing over, and the passage to the arm side to be narrowed, the oil supplied from P3 pump flows abundantly into the P1 side (Boom, bucket).


As mentioned above, the oil supplied from P3 pump flows suitably into each attachment according to the control input during the above combined control, resulting in a well-balanced and efficient working speed.

Besides, since the oil flow to the bucket whose working load is less than the boom is restricted with an orifice (the orifice of boom priority) provided before the bucket section in the P1 side parallel passage, much oil flows into the boom section. As a result, the working speed balance between both attachments is maintained during the combined operation of boom and bucket.

P3 side (Connecting side) circuit



P1 side circuit(the orifice of boom priority)



Oil flow during combined operation

R35Z72MCV27

(12) COMBINED CONTROL OPERATION ②

Both travels + bucket

When the both travels operation is carried out together with the bucket operation at the same time, the oil flowed from Pp1 port flows through the orifice passage and into the travel independent signal passage; both travels and the bucket spool changeover make a passage to the drain port shut off.


Then, the travel independent passage becomes the same pressure as Pp1 port pressure (pilot primary pressure).

When the travel independent passage becomes Pp1 pressure, the Pp1 pressure is applied to the connecting spool to change over the connecting spool.

Since the bypass passage from P3 to P2 side, which is a passage to the tank, is restricted, the oil from P3 side flows into the P1 side parallel passage that is connected through a check valve.

With this circuit arrangement, the bucket section is supplied with pressure oil from P3 during both travels operation, the simultaneous operation becomes possible.

Besides, since each of P1 and P2 is used independently during both travels and only P3 is used for bucket operation, stable travel is possible to continue even if there is change in the bucket load.



Travel independence operation


R35Z72MCV28

(13) MAIN AND PORT RELIEF VALVE OPERATION

Main relief valve operation

Main relief valves (MRV) are different in the uses for P1/P2 and P3; however, their structures and operation are the same.


- ① Pressure oil flows through the inside of the piston built in the pressure regulating valve (poppet-main V') and the orifice B and then into the internal chamber A until it is filled up. The filled up pressure causes both of the pressure regulating valve and the socket and body seat to be seated securely.



MRV operation (1)

R35Z72MCV29


- ② When the oil pressure at port P increases up to the setting pressure of regulating valve spring, the pressure oil is applied to the regulating valve via the piston to open the regulating valve. Then, the pressure oil flows through a passage in the direction of piston inside → orifice B → chamber A → circular orifice C → Drill hole D and the external of socket and then into the tank passage.



MRV operation (2)

R35Z72MCV30

- ③ Since the pressure inside the chamber A decreases when the regulating valve is opened, which causes the pressure regulating valve to open to let the pressure oil port P flows into the tank passage through drill hole E.




MRV operation (3)

R35Z72MCV31

- ④ Also, since the regulating valve is pressed to the seat by regulating valve spring when the pressure at port P decreases below the setting pressure of regulating valve spring, the pressure inside chamber A becomes the same as the pressure at port P to cause the pressure regulating valve to be pressed to the seat, resulting in the original condition (①).

Overload relief valve (ORV) operation ①


- ① Pressure oil flows through the inside of the piston built in the pressure regulating valve (poppet-main V') and the orifice B and then into the internal chamber A until it is filled up. The filled up pressure causes both of the pressure regulating valve and socket and body seat to be seated securely.



ORV operation (1)

R35Z72MCV32


- ② When the oil pressure at port P increases up to the setting pressure of regulating valve spring, the pressure oil is applied to the regulating valve via the piston to open the regulating valve. Then, the pressure oil flows through a passage in the direction of piston inside → orifice B → chamber A → circular orifice C → Drill hole D and the external of socket and then into the tank passage.



ORV operation (2)

R35Z72MCV33

- ③ Since the pressure inside the chamber A decreases when the regulating valve is opened, which causes the pressure regulating valve to open to let the pressure oil port P flows into the tank passage through drill hole E.




ORV operation (3)

R35Z72MCV34

- ④ Also, since the regulating valve is pressed to the seat by regulating valve spring when the pressure at port P decreases below the setting pressure of regulating valve spring, the pressure inside chamber A becomes the same as the pressure at port P to cause the pressure regulating valve to be pressed to the seat, resulting in the original condition (①).

Overload relief valve (ORV) operation ② 【Operation during suction】

If there is negative pressure at port P (or the tank passage pressure is higher than P pressure), the socket is applied with press and open force. Then, the opening between body seat and socket increases to cause the oil to flow into port P from the tank passage, filling up the space.




ORV operation (during suction)

R35Z72MCV35

Anti cavitation valve (ACV) operation

If there is negative pressure at actuator port, the tank pressure makes the socket pressed and opened.

Since the passage the seat and the socket is opened by the socket transfer, the oil discharged from the tank flows into the actuator port through this passage.



ACV operation

1692MC06



GROUP 3 SWING DEVICE

1. STRUCTURE

Swing device consists swing motor and swing reduction gear.

1) SWING MOTOR


Swing motor include mechanical relief valve, make up valve and check valve.



1692SM01

Port	Port name	Port size
A	Main port	PF 3/8
B	Main port	PF 3/8
DR	Drain port	PF 3/8
T	Make up port	PF 3/8


2) COMPONENTS (1/2)



1692SM06

201	Body	212	Retainer	225	Pin	304	Piston
202	Plate	213	Pin	226	Pin	305	Cap
203	Shaft	214	Filter	243	Relief valve	306	Spring
204	Cylinder barrel	215	Spring C	246	Check valve	307	Spacer
205	Valve plate	216	Bearing	247	Plug	308	O-ring
206	Piston	217	Bearing	248	Spring	309	O-ring
207	Shoe	218	O-ring	249	O-ring	310	O-ring
208	Shoe holder	221	Snap ring	301	Seat	311	O-ring
209	Barrel holder	223	Screw	302	Retainer	312	Back up-ring
210	Swash plate	224	Spring pin	303	Poppet		


COMPONENTS (2/2)



1692SM07

101	Body	114	O-ring	123	Oil seal
102	Carrier 1	115	Thrust plate 1	124	Screw
104	Pinion shaft	119	Preload collar	128	Ring
111	Needle	121	Bearing	129	Ring 1
113	Seal ring	122	Bearing		

2. OPERATION PRINCIPLE



1692SM02

3. OPERATION

The swing motor consists of a planetary gear speed reducer, a hydraulic motor and the hydraulic valves.

1) REDUCTION GEAR SECTION

(1) Function

The speed reducer of swing motor is a simple planetary gear type with single stage. The high output speed of the hydraulic motor is reduced to low speed with high torque and obtaining the pinion shaft rotation.

(2) Operation


The s1 gear is attached to the hydraulic motor shaft, and the s1 output speed is reduced between the gears (s1, b1, a1).

This reduced output speed is transmitted to the pinion shaft, and drives the machine.

The gear ratio of single stages simple planetary speed reducer is calculated using the following formula.

$$R = \frac{Z_{s1}}{Z_{s1} + Z_{a1}}$$

※ Z ** : Number of gear teeth.



2) HYDRAULIC MOTOR SECTION


(1) Function

This hydraulic motor is an axial piston type, and changes the hydraulic energy supplied from the pump to the rotary motion.

(2) Structure

Through a hydraulic valve, the pressurized oil is supplied to the valve plate (5). When the pressurized oil is supplied to the A port, this pressurized oil pushes the piston (6) in the cylinder barrel (4). This pushing force is changed to the rotational power by the swash plate (7) and transmitted to the shaft (3) which is connected to the cylinder barrel (4) with the spline. The return flow from the cylinder port is going out through the B port of the valve plate (5).

To reverse rotation, pressurized oil is supplied to the B port and returning oil exits through the A port.



1692SM04

3) HYDRAULIC VALVE SECTION


(1) Shockless relief valve

The shockless relief valve consists of the direct relief valve (poppet) and the piston for changing the spring force with two stages.

When the hydraulic motor is stopped, even after closing IN and OUT port of the hydraulic motor, the motor tries to run with inertia. Motor works as like a pump, and the pressure (brake pressure) is made on the OUT port side. The shockless relief valve releases this brake pressure with two stages of operation. This makes the shock smooth, and prevents the motor being damaged. It also makes the start of the motor smooth.

① First stage


When the P1 pressure is going up, the poppet opens due to the pressure of the spring force F1.




1692SM09

② Second stage

When P1 pressure enters the second chamber through the orifice A and B, the piston moves to its stroke-end. With this action, the spring is compressed, the spring force becomes stronger, and the P1 pressure is increased to the setting pressure Ps.



1692SM10




1692SM11

With the above two stages of operation, the motor starts and stops smoothly.

(2) Check valve

When the swing motor is decelerated by operating the control valve, it continues to be moved by the inertia of the machine. Then, it works as pump, and the pressure of C chamber tends to become negative. However, when B port pressure is below cracking pressure of the relief valve, all flow in A port goes out from B port through the motor.

Therefore, if C chamber can get flow only from the control valve, the flow will not be enough to prevent the negative pressure; as a result, cavitation could occur. The check valve works to supply the flow from T port to C chamber; and prevents cavitation.




1692SM05

4. HANDLING

1) MOUNTING

(1) Pilot dimension D

$$D = \varnothing 110h8 \begin{smallmatrix} 0 \\ -0.054 \end{smallmatrix}$$



1692SM08

- (2) When installing the motor to the machine, do not force the sections and/or strike them with a heavy object as damage may result. The best method is to use the mounting bolts as a guide and slowly slide it into place.
- (3) Use the specified bolts (equivalent grade 10.9 or higher) for mounting the motor, and tighten using the following torque.

Bolt size	Torque
M12	$10 \pm 1 \text{ kgf} \cdot \text{m}$ ($72.3 \pm 7.2 \text{ lbf} \cdot \text{ft}$)

2) PIPING

- (1) Pay attention to the rotation direction and piping.

Rotation direction (from view of output shaft)

Direction	IN Port	OUT port
Clockwise	B port	A port
Counter clockwise	A port	B port

- (2) When assembling the motor to the machine, fill hydraulic oil into the motor body through the drain port for lubrication before connecting the drain port.
- (3) The permissible drain pressure is limited by the oil seal. Pay attention to the drain piping so that the drain pressure does not exceed the limit. The permissible drain pressure is 2.0 kgf/cm^2 (28.4 psi).
- (4) Fine filtration prolongs the hydraulic system life and ensures high reliability. Install a $10 \mu\text{m}$ filter, or better in the circuit.

3) GEAR LUBRICATION OIL

The gearbox is lubricated with drain oil from the hydraulic motor. When shipped, the gearbox is empty. Fill hydraulic oil through the drain port before use.

Replacement of the hydraulic oil in the gearbox is not required.

4) GENERAL PRECAUTION

- (1) Always pay attention to oil leaks and loose bolts, detect and correct these problems as soon as possible to prevent damage to the motor or machine. Making a check sheet is recommended.
- (2) Pay attention to the temperature of the reduction gear body. The permissible maximum temperature is 100°C.





GROUP 4 TRAVEL DEVICE

1. CONSTRUCTION

Travel device consists travel motor and gear box.


Travel motor includes counterbalance valve, parking brake and high/low speed changeover mechanism.

Port	Port name	Port size
A	Main port	PF 3/8
B	Main port	PF 3/8
DR1, DR2	Drain port	PF 1/4
PP	2 speed control port	PF 1/8



HYDRAULIC CIRCUIT


2) STRUCTURE (1/3)



1692TM02

202	Body 2	210	Swash plate	218	O-ring
203	Shaft	211	Control piston	219	Oil seal
204	Cylinder barrel	212	Pin	220	Ball
205	Valve plate	213	Spring C	221	Snap ring
206	Piston	214	Retainer	222	Screw
207	Shoe	215	Bearing	223	Spring pin
208	Shoe holder	216	Bearing	224	Pin
209	Barrel holder	217	O-ring	225	Plug


STRUCTURE (2/3)



1692TM03

301	Body 1	309	Spring V3	317	O-ring
302	Spool	310	Plug	318	O-ring
303	Check valve	311	Plug	319	O-ring
304	Spring guide	312	Plug	320	Choke
305	Spool	313	Choke	321	Pin
306	Shuttle spool	314	Ring	322	Plug
307	Spring V1	315	Plug		
308	Spring V2	316	Plug		


STRUCTURE (3/3)



1692TM04

101	Body	113	Snap ring	121	Thrust washer	134	Thrust washer
102	Cover	114	Thrust plate	122	Snap ring	135	Plug
104	Carrier 2	115	Slide ring	123	Snap ring	136	O-ring
106	Gear B1	116	Needle	127	Spring pin	137	Snap ring
107	Gear B2	117	Needle	129	O-ring	139	O-ring
108	Gear S1	118	Floating seat (Incl 119)	130	O-ring	140	Snap ring
110	Ring			131	Plug		
111	Pin B2	119	O-ring	132	Name plate		
112	Seal ring	120	Bearing	133	Hydraulic motor		

2. DRAWING OF OPERATIONAL PRINCIPLE



1692TM05

3. OPERATION

Travel motor consists of a hydraulic motor "Fixed parts" and a planetary gear speed reducer "Rotating parts".

1) REDUCTION GEAR SECTION

(1) Function

The speed reducer of travel motor is a simple planetary gear type with two stages. The high output speed of the hydraulic motor is reduced to low speed with high torque.

(2) Operation

The S2 gear is attached to the hydraulic motor shaft and the S2 output speed is reduced between the gears (s2, b2, a2) as a first stage speed reducer.

The reduced output speed of this first stage is reduced again between the gears (s1, b1, a1) which are connected to the carrier 2 with the spline.

This reduced output speed of the second stage is transmitted to the body case "rotating parts" through the inner gears (a1, a2) and drives the machine.


The gear ratio of 2 stage simple planetary speed reducer is calculated using the following formula.

$$R = \frac{Z_{s1}}{Z_{s1} + Z_{a1}} \times \frac{Z_{s2}}{Z_{s2} + Z_{a2}}$$

※ Z** : Number of teeth

With the travel motor, the body case rotating, so the gear ratio is ;

$$R' = \frac{1}{1 - 1/R}$$




2) HYDRAULIC MOTOR SECTION

(1) Function

This hydraulic motor is an axial piston type, and changes the hydraulic energy supplied from the pump to the rotary motion.

(2) Structure



R27Z92TM06

Through a hydraulic valve, the pressurized oil is supplied to the valve plate (5).

When the pressurized oil is supplied to the A port, this pressurized oil pushes the piston (6) in the cylinder barrel (4). This pushing force is changed to the rotational power by the swash plate (7) and transmitted to the shaft (3) which is connected to the cylinder barrel (4) with the spline. The return flow from the cylinder port is going out through the B port of the valve plate (5). To reverse rotation, pressurized oil is supplied to the B port and returning oil exits through the A port.

(3) 2 Speed motor operation

The swash plate, which has surface I and II in the opposite side to the shoe sliding surface, is supported by the 2 balls which are fixed to the body 2.

Since the balls are located in the eccentric position, in the low speed range, the surface I is faced to the body 2 by the oil pressure in the piston and the spring force in the cylinder barrel. The swash plate angle is α (Max. capacity).

When the pressurized oil is supplied to the (PP) port, the two-speed spool moves to the high position.


And the pressurized oil of inlet is led to the control chamber through the two-speed spool.

The control piston moves forward until the surface II of the swash plate is in contact with the body 2, and the swash plate angle becomes β .

The capacity of the hydraulic motor is made small.

The pressurized oil of the (PP) port is shut off (or the engine is stopped), the two-speed spool moves to the low position.

And the control chamber is led to the tank port through the two-speed spool and the swash plate position comes to the low speed by the spring force.




3) HYDRAULIC VALVE SECTION

(1) Counter-balance valve

When the pressurized oil is supplied from the A port, the pressurized oil opens the check valve (3) and flows into the hydraulic motor inlet A' port. At the same time, the pressurized oil goes through the orifice C into the chamber D, pushes the spring (4) and moves the spool (2) to right. Then the returned oil from the hydraulic motor flows into the B port, goes through area E and drives the hydraulic motor. When the pressurized oil is supplied from the B port, the hydraulic motor rotates in reverse.


Even the pressurized oil of the A port is shut off, the hydraulic motor tries to rotate by inertia force. When the pressurized oil from the A port is shut off, the spool (2) tries to return to left by the spring (4) force. At this time, the oil in the chamber D tries to go out to the A port through the orifice C, but due to the throttle effect of orifice C, the spool (2) speed is reduced. With the orifice and notches on the spool, the returned oil is controlled gradually and the hydraulic motor stops smoothly.



1692TM08

4. HANDLING

1) MOUNTING



1692TM09

- (1) When installing the motor to the machine and/or attaching the sprocket to the motor, do not force the sections and/or strike them with a heavy object as damage may result. The best method is to use the mounting bolts as a guide and slowly slide it into place.
- (2) Use the specified bolts (equivalent grade 12.9 or higher) for mounting the motor and the sprocket, and tighten using the following torque.

Bolt size	Torque
M10	5~6.5 kgf · m (36.2~47.0 lbf · ft)


2) PIPING

- (1) Pay attention to the rotating direction and piping.
- (2) When shipped, rubber plugs (or steel plugs for drain ports) are attached to the piping ports. When piping, pay attention as not to introduce dirt or welding scale into the ports.
- (3) One of two drain ports is used as a drain line. Use the upper side port, and fill with 100 cm³ of hydraulic oil, then connect the piping.
- (4) The permissible drain pressure is limited by the oil seal. Therefore, pay attention to the size of drain piping so that the drain pressure does not exceed the limit especially in a low temperature environment. The permissible drain pressure is 3 kgf/cm² (42.7 psi) (rated) and 10 kgf/cm² (142 psi) (peak).
- (5) Fine filtration prolongs the hydraulic system life and ensures high reliability. Install a 10 μ filter, or better in the circuit.

3) GEAR LUBRICATING OIL

- (1) Use diesel engine oil SAE-30-CD or equivalent as gear lubricating oil.
(When shipped, Idemitsu Apolol Diesel Motive S-330 is used.)
- (2) Any recommended gear oil can be used, but drain old oil completely, and do not mix.
- (3) When shipped, gear box is pre-filled. Take the following steps to refill. All plugs are sealed by O-ring.
 - ① Remove the oil supply port plug.
 - ② Fill the oil from the oil supply port up to the "LEVEL".
 - ③ Check the oil amount and install the oil supply port plug.

	Tightening torque
Oil supply, discharge port plugs	4.69~5.20 kgf · m (33.9~37.6 lbf · ft)



1692TM10

※ Remove the oil supply port plug before discharge port plug, when remove both the oil supply port plug and discharge port plug.

- (4) Gear oil amount : 0.33ℓ (0.09 U.S. gal)
- (5) Gear oil change period
 - First change : 200 hours or 2 months
 - Second and after : 1000 hours or 1 year


4) GENERAL PRECAUTIONS

- (1) Always pay attention to oil leaks and loose bolts, detect and correct these problems as soon as possible to prevent damage to the motor or machine. Making a check sheet is recommended.


GROUP 5 RCV LEVER

1. STRUCTURE

The casing has the oil inlet port P (primary pressure) and the oil outlet port T (tank). In addition the secondary pressure is taken out through ports 1,2,3 and 4 provided at the bottom face.



R35Z72RL01



Port	LH	RH	Port size
P	Pilot oil inlet port	Pilot oil inlet port	PF 1/4
T	Pilot oil return port	Pilot oil return port	
1	Arm in port	Boom up port	
2	Right swing port	Bucket out port	
3	Arm out port	Boom down port	
4	Left swing port	Bucket in port	

CROSS SECTION


The construction of the pilot valve is shown in the attached cross section drawing. The casing has vertical holes in which reducing valves are assembled.

The pressure reducing section is composed of the spool (11), spring (8, 9) for setting secondary pressure, return spring (4), stopper (7), spring seat (5, 6) and spring seat (10). The spring for setting the secondary pressure has been generally so preset that the secondary pressure is 5 to 20.5 kgf/cm² (depending on the type). The spool is pushed against the push rod (12, 13) by the return spring.

When the push rod is pushed down by tilting the handle, the spring seat comes down simultaneously and changes setting of the secondary pressure spring.

1	Case	12	Push rod (1, 3)	23	Connector
2	Plug	13	Push rod (2, 4)	24	Nut
3	O-ring	14	Plug	25	Nut
4	Spring	15	O-ring	26	Insert
5	Spring seat (1, 3)	16	Rod seal	27	Boot
6	Spring seat (2, 4)	17	Plate (A)	28	Handle
7	Stopper	18	Bushing	29	Switch assembly
8	Spring (1, 3)	19	Machine screw	30	Screw
9	Spring (2, 4)	20	Joint assembly	31	Plate
10	Spring seat	21	Swash plate	32	Boot
11	Spool	22	Hex nut		

CROSS SECTION



R35Z72RL02

2. FUNCTIONS

1) FUNDAMENTAL FUNCTIONS

The pilot valve is a valve that controls the spool stroke, direction, etc of a main control valve. This function is carried out by providing the spring at one end of the main control valve spool and applying the output pressure (secondary pressure) of the pilot valve to the other end.

For this function to be carried out satisfactorily, the pilot valve is composed of the following elements.

- (1) Inlet port (P) where oil is supplied from hydraulic pump.
- (2) Output ports (1, 2, 3 & 4) to apply pressure supplied from inlet port to ends of control valve spools.
- (3) Tank port (T) necessary to control the above output pressure.
- (4) Spool to connect output port to inlet port or tank port.
- (5) Mechanical means to control output pressure, including springs that work on the above spools.

2) FUNCTIONS OF MAJOR SECTIONS

The functions of the spool (11) are to receive the supply oil pressure from the hydraulic pump at its port P, and to change over oil paths to determine whether the pressure oil of port P is led to output ports 1, 2, 3 & 4 or the output port pressure oil to tank port T.

The spring (8, 9) works on this spool to determine the output pressure.

The change the deflection of this spring, the push rod (12, 13) is inserted and can slide in the plug (14).

For the purpose of changing the displacement of the push rod through the switch plate (21) and adjusting nut (22) are provided the handle (28) that can be tilted in any direction around the fulcrum of the universal joint (20) center.


The spring (4) works on the case (1) and spring seat (5, 6) and tries to return the push rod (12, 13) to the zero-displacement position irrespective of the output pressure, securing its resetting to the center position.

This also has the effect of a reaction spring to give appropriate control feeling to the operator.

3) OPERATION

The operation of the pilot valve will be described on the basis of the hydraulic circuit diagram shown below and the attached operation explanation drawing.

The diagram shown below is the typical application example of the pilot valve.




2-70 (140-7TIER)

1 Pilot valve
2 Pilot pump

3 Main pump
4 Main control valve

5 Hydraulic motor
6 Hydraulic cylinder


(1) Case where handle is in neutral position



R35Z72RL03

The force of the spring (8) that determines the output pressure of the pilot valve is not applied to the spool (11). Therefore, the spool is pushed up by the spring (4) to the position of port (1, 3) in the operation explanation drawing. Then, since the output port is connected to tank port T only, the output port pressure becomes equal to tank pressure.

(2) Case where handle is tilted



R35Z72RL04

When the push rod (12) is stroked, the spool (11) moves downwards.

Then port P is connected with port (1) and the oil supplied from the pilot pump flows through port (1) to generate the pressure.




When the pressure at port (1) increases to the value corresponding to the spring force set by tilting the handle, the hydraulic pressure force balances with the spring force. If the pressure at port (1) increases higher than the set pressure, port P is disconnected from port (1) and port T is connected with port (1). If it decreases lower than the set pressure, port P is connected with port (1) and port T is disconnected from port 1.

In this manner the secondary pressure is kept at the constant value.


GROUP 6 RCV PEDAL

1. STRUCTURE


The casing has the oil inlet port P (primary pressure), and the oil outlet port T (tank). In addition the secondary pressure is taken out through ports 1,2,3 and 4 provided at the bottom face.



VIEW "A"



R35Z72RCP01




Port	Port name	Port size
P	Pilot oil inlet port	PF 1/4
T	Pilot oil return port	
1	Travel (LH, Backward)	
2	Travel (LH, Forward)	
3	Travel (RH, Backward)	
4	Travel (RH, Forward)	

CROSS SECTION

The construction of the RCV pedal is shown in the below drawing. The casing has vertical holes in which reducing valves are assembled.

The pressure reducing section is composed of the spool (19), spring (22) for setting secondary pressure, return spring (23), spring seat (20) and washer (21). The spring for setting the secondary pressure has been generally so preset that the secondary pressure is 5 to 19 kgf/cm² (depending on the type). The spool is pushed against the push rod (10) by the return spring.

When the push rod is pushed down by tilting pedal, the spring seat comes down simultaneously and changes setting of the secondary pressure spring.



R35Z72RCP02

1	Casing (1)	11	Shim	21	Washer
2	Casing (2)	12	Spring seat	22	Spring
3	Cover	13	Piston	23	Spring
4	Plug	14	Steel ball	24	Spring
5	Grease cap	15	Plug	25	Cam shaft
6	Packing	16	Plug	26	Bushing
7	O-ring	17	O-ring	27	Cam
8	O-ring	18	Hex soc head screw	28	Steel ball
9	O-ring	19	Spool	29	Set screw
10	Push rod	20	Spring seat	30	Bellows

2. FUNCTION

1) FUNDAMENTAL FUNCTIONS

The pilot valve is a valve controls the spool stroke, direction, etc of a main control valve. This function is carried out by providing the spring at one end of the main control valve spool and applying the output pressure (secondary pressure) of the pilot valve to the other end.

For this function to be carried out satisfactorily, the pilot valve is composed of the following elements.

- (1) Inlet port (P) where oil is supplied from hydraulic pump.
- (2) Output port (1, 2, 3 & 4) to apply pressure supplied from inlet port to ends of control valve spools.
- (3) Tank port (T) necessary to control the above output pressure.
- (4) Spool to connect output port to inlet port tank port.
- (5) Mechanical means to control output pressure, including springs that work on the above spools.

2) FUNCTIONS OF MAJOR SECTIONS

The functions of the spool (19) are to receive the supply oil pressure from the hydraulic pump at its port P, and to change over oil paths to determine whether the pressure oil of port P is led to output ports 1, 2, 3 & 4 or the output spool to determine the output pressure.

The spring (22) works on this spool to determine the output pressure.

The change the deflection of this spring, the push rod (10) is inserted and can slide in the plug (4).

For the purpose of changing the displacement of the push rod through the cam (27) and steel ball (28) are provided the pedal that can be tilted in any direction around the fulcrum of the cam (27) center.


The spring (23) works on the casing (1) and washer (21) and tries to return the push rod (10) to the zero-displacement position irrespective of the output pressure, securing its resetting to the center position.

This also has the effect of a reaction spring to give appropriate control feeling to the operator.

3) OPERATION

The operation of the pilot valve will be described on the basis of the hydraulic circuit diagram shown below and the attached operation explanation drawing.

The diagram shown below is the typical application example of the pilot valve.




140LC-7 기타2-76

1 Pilot valve
2 Pilot pump

3 Main pump
4 Main control valve

5 Hydraulic motor
6 Hydraulic cylinder


(1) Case where pedal is in neutral position



R35Z72RCP04

The force of the spring (22) that determines the output pressure of the pilot valve is not applied to the spool (19). Therefore, the spool is pushed up by the spring (23) to the position of port 2 in the operation explanation drawing. Then, since the output port is connected to tank port T only, the output port pressure becomes equal to tank pressure.

(2) Case where pedal is tilted



R35Z72RCP05

When the push rod (10) is stroked, the spool (19) moves downwards.

Then port P is connected with port 1, and the oil supplied from the pilot pump flows through port 1 to generate the pressure.


When the pressure at port 1 increases to the value corresponding to the spring force set by tilting the handle, the hydraulic pressure force balances with the spring force. If the pressure at port 1 increases higher than the set pressure, port P is disconnected from port 1 and port T is connected with port 1. If it decreases lower than the set pressure, port P is connected with port 1 and port T is disconnected from port 1.

In this manner the secondary pressure is kept at the constant value.


3. BOOM SWING PEDAL

1) STRUCTURE

The casing has the oil inlet P (primary pressure) and the oil return port (tank).
In addition the secondary pressure is taken out through port 1 and port 2 provided at the housing bottom face.




R35Z72RSP01



Port	Port name	Port size
P	Pilot oil inlet port	PF 1/4
T	Pilot oil return port	
1	Boom swing (LH)	
2	Boom swing (RH)	

2) COMPONENT



R35Z72RSP02


1	Body	8	Stopper	15	DU bush
2	Plug	9	Spring	16	Wrench bolt
3	O-ring	10	Plug	17	Cam
4	Spool	11	O-ring	18	Pin
5	Spring seat	12	Rod seal	19	Adjust screw
6	Spring	13	Push rod	20	Socket bolt
7	Spring seat	14	Cover	21	Bellows

4. DOZER LEVER


1) STRUCTURE

The casing has the oil inlet P (primary pressure) and the oil return port (tank).

In addition the secondary pressure is taken out through port 1 and port 2 provided at the housing bottom face.




R35Z72DL01



Hydraulic circuit

Port	Port	Port size
P	Pilot oil inlet port	PF 1/4
T	Pilot oil return port	PF 1/4
1	Dozer blade up port	PF 1/4
2	Dozer blade down port	PF 1/4

2) COMPONENT



R35Z72DL02

1	Body	9	Stopper	17	Pin
2	Plug	10	Plug	18	Socket bolt
3	O-ring	11	Rod seal	19	Nut
4	Spring	12	O-ring	20	Snap ring
5	Spring seat	13	Push rod	21	Spring pin
6	Spool	14	Cover	22	Bellows
7	Spring seat	15	Wrench bolt	23	Lever
8	Spring	16	Guide		


SECTION 3 HYDRAULIC SYSTEM

Group 1	Hydraulic Circuit	3-1
Group 2	Main Circuit	3-2
Group 3	Pilot Circuit	3-5
Group 4	Single Operation	3-9
Group 5	Combined Operation	3-21

SECTION 3 HYDRAULIC SYSTEM


GROUP 1 HYDRAULIC CIRCUIT

Machine serial number : ~#1446









- 1 MAIN PUMP
- 2 MAIN CONTROL VALVE
- 3 SWING MOTOR
- 4 TRAVEL MOTOR
- 5 RCV LEVER-LH
- 6 RCV LEVER-RH
- 7 SOLENOID VALVE
- 8 TURNING JOINT
- 9 BUCKET CYLINDER
- 10 BOOM CYLINDER
- 11 DOZER CYLINDER
- 12 ARM CYLINDER
- 13 BOOM SWING CYLINDER
- 15 OIL COOLER
- 16 RETURN CHECK VALVE
- 17 RETURN FILTER
- 18 SUCTION STRAINER
- 19 HYD TANK
- 20 STOP VALVE
- 21 ACCUMULATOR
- 22 RCV PEDAL
- 23 RCV PEDAL
- 24 RCV DOZER
- 25 3 WAY VALVE
- 26 SOLENOID SELECTOR
- 27 FRAME EXTENSION CYL

HYDRAULIC CIRCUIT (1/2), Machine serial number : #1447~ (swing motor with parking brake)



30MJ-74000(1/2)

HYDRAULIC CIRCUIT (2/2), Machine serial number : #1447~ (swing motor with parking brake)



- 14-2 TERMINAL ASSY
- 21 SOLENOID VALVE
- 30 ACCUMULATOR
- 31 LEVER PATTERN VALVE
- 32 PRESSURE SWITCH
- 33 SHUTTLE VALVE
- 36 TRAVEL MOTOR


GROUP 2 MAIN CIRCUIT

The main hydraulic circuit consists of suction circuit, delivery circuit, return circuit and drain circuit.

The hydraulic system consists of one main pump, one control valve, one swing motor, four cylinders and two travel motors.

The swash plate type variable displacement axial piston pump is used as the main pump and is driven by the engine at ratio 1.0 of engine speed.

1. SUCTION AND DELIVERY CIRCUIT



3-02 (140-7 TIER)


The pumps receive oil from the hydraulic tank through a suction filter. The discharged oil from the pump flows into the control valve and goes out the tank ports.

The oil discharged from the main pump flows to the actuators through the control valve.

The control valve controls the hydraulic functions.

The return oil from the actuators flows to the hydraulic tank through the control valve and the oil cooler.

2. RETURN CIRCUIT



R35Z73HC02

All oil returned from each actuator returns to the hydraulic tank through the control valve.

The bypass check valves are provided in the return circuit.

The setting pressure of bypass check valves are 1.5 kgf/cm² (21 psi). Usually, oil returns to the hydraulic tank from the left side of control valve through oil cooler.

When oil temperature is low, viscosity becomes higher and flow resistance increases when passing through the oil cooler. When the oil pressure exceeds 1.5 kgf/cm² (21 psi), the oil returns directly to the hydraulic tank, resulting in the oil temperature being raised quickly at an appropriate level.


When the oil cooler is clogged, the oil returns directly to the hydraulic tank through bypass check valve.

The full-flow filter and bypass relief valve are provided in the hydraulic tank.

The oil returned from right and left side of control valve is combined and filtered by the full-flow filter. A bypass relief valve is provided in the full-flow filter.

When the filter element is clogged, the bypass relief valve opens at 1.5 kgf/cm² (21 psi) differential pressure.

3. DRAIN CIRCUIT



R35Z73HC43

Besides internal leaks from the motors and main pump, the oil for lubrication circulates.


1) TRAVEL MOTOR DRAIN CIRCUIT

Oil leaked from the right and left travel motors comes out of the drain ports provided in the respective motor casing and join with each other. These oils pass through the turning joint and return to the hydraulic tank after being filtered by return filter.

2) SWING MOTOR DRAIN CIRCUIT

Oil leaked from the swing motor returns to the hydraulic tank passing through a return filter with oil drained from the travel circuit .

GROUP 3 PILOT CIRCUIT




1693HC00

The pilot circuit consists of suction circuit, delivery circuit and return circuit.

The pilot pump is provided with relief valve, receives the oil from the hydraulic tank through the suction filter.

The discharged oil from the pilot pump flows to the remote control valve through solenoid valve assemblies, swing parking brake, main control valve and safety lock solenoid valve.

1. SUCTION, DELIVERY AND RETURN CIRCUIT




1693HC03

The pilot pump receive oil from the hydraulic tank. The discharged oil from the pilot pump flows to the safety solenoid valve. The pilot relief valve is provided in the solenoid valve for limiting the pilot circuit pressure.

The oil filtered by line filter flows remote control valve, MCV and swing port through safety solenoid valve.

The return oil flow into the hydraulic tank.

2. SAFETY VALVE (SAFETY LEVER)




1693HC04

When the lever of the safety solenoid valve is moved downward, oil flows into the remote control valve through solenoid valve.

When the lever of the safety solenoid valve is moved upward, oil does not flow into the remote control valve, because of the blocked port.

3. TRAVEL SPEED CONTROL SYSTEM



1693HC05

When the travel speed switch is pushed, the travel speed solenoid valve is actuated and the discharged oil from the pilot pump flows to the PP port of pilot valve in the travel motors.


As a result, the control piston is pushed by the main oil flow, thus the displacement is minimized.

When the travel speed switch is pushed once more, the travel speed solenoid valve is return to original position by the force of spring, the hydraulic oil of PP port returns to the hydraulic tank.

As a result, the control piston is returned by the main oil flow, thus the displacement is maximized.

GROUP 4 SINGLE OPERATION

1. BOOM UP OPERATION




1693HC10

When the right control lever is pulled back, the boom spools in the main control valve are moved to the up position by the pilot oil pressure from the remote control valve.

The oil from the A1 and A3 pump flows into the main control valve and then goes to the large chamber of boom cylinders. At the same time, the oil from the small chamber of boom cylinders returns to the hydraulic oil tank through the boom spool in the main control valve. When this happens, the boom goes up. The excessive pressure in the boom cylinder bottom end circuit is prevented by relief valve. When the boom is up and the control lever is returned to neutral position, the circuit for the holding pressure at the bottom end of the boom cylinder is closed by the boom holding valve. This prevents the hydraulic drift of boom cylinder.

2. BOOM DOWN OPERATION




1693HC11

When the right control lever is pushed forward, the boom spools in the main control valve are moved to the down position by the pilot oil pressure from the remote control valve. Since Pb8 port is connected Pb8' port through the piping, boom holding valve is also released.

The oil from the A1 pump flows into the main control valve and then goes to the small chamber of boom cylinders. At the same time, the oil from the large chamber of boom cylinders returns to the hydraulic tank through the boom spool in the main control valve.

The cavitation in the boom cylinder rod end circuit is prevented by the make-up valve.

3. ARM ROLL IN OPERATION



1693HC12


When the left control lever is pulled back, the arm spools in the main control valve are moved to the roll in position by the pilot oil pressure from the remote control valve.

The oil from the A2 and A3 pump flows into the main control valve and then goes to the large chamber of arm cylinder.

At the same time, the oil from small chamber of arm cylinder returns to the hydraulic oil tank through the arm spool in the main control valve. When this happens, the arm rolls in.

The cavitation and excessive pressure in the bottom of the arm cylinder is also prevented by the make-up valve and the relief valve in the main control valve.

4. ARM ROLL OUT OPERATION



1693HC13


When the left control lever is pushed forward, the arm spool in the main control valve are moved to the roll out position by the pilot oil pressure from the remote control valve.

The oil from the A2 and A3 pump flows into the main control valve and then goes to the small chamber of arm cylinder.

At the same time, the oil from the large chamber of arm cylinder returns to the hydraulic oil tank through the arm spool in the main control valve. When this happens, the arm rolls out.

The cavitation and excessive pressure in the rod of the arm cylinder is also prevented by the make-up valve and relief valve in the main control valve.

5. BUCKET ROLL IN OPERATION



1693HC14


When the right control lever is pulled left, the bucket spool in the main control valve is moved to the roll in position by the pilot oil pressure from the remote control valve.

The oil from the A1 pump flows into the main control valve and then goes to the large chamber of bucket cylinder.

At the same time, the oil from the small chamber of bucket cylinder returns to the hydraulic oil tank through the boom spool in the main control valve. When this happens, the bucket rolls in.

The cavitation and excessive pressure in the bottom of the bucket cylinder is also prevented by the make-up valve and relief valve in the main control valve.

6. BUCKET ROLL OUT OPERATION



1693HC15


When the right control lever is pushed right, the bucket spool in the main control valve is moved to the roll out position by the pilot oil pressure from the remote control valve.

The oil from the A1 pump flows into the main control valve and then goes to the small chamber of bucket cylinder.

At the same time, the oil from the large chamber of bucket cylinder returns to the hydraulic oil tank through the bucket spool in the main control valve. When this happens, the bucket rolls out.

The cavitation which will happen to the rod of the bucket cylinder is also prevented by the make-up valve in the main control valve.

7. SWING OPERATION




1693HC16

When the left control lever is pushed left or right, the swing spool in the main control valve is moved to the left or right swing position by the pilot oil pressure from the remote control valve.

The oil from the A3 pump flows into the main control valve and then goes to the swing motor.

At the same time, the return oil from the swing motor returns to the hydraulic oil tank through the swing spool in the main control valve. When this happens, the superstructure swings to the left or right. The make up valve and the overload relief valve are provided in the swing motors. The cavitation which will happen to the swing motor is also prevented by the make up valve in the swing motor itself.

SWING CIRCUIT OPERATION



1693HC20


1) MOTOR BRAKE VALVE

Motor brake valve for the swing motor limits to cushion the starting and stopping pressure of swing operation.

2) MAKE UP VALVE

The make up valves prevent cavitation by supplying return oil to the vacuum side of the motor.


8. TRAVEL FORWARD AND REVERSE OPERATION



1693HC17

When the travel levers are pushed forward or reverse position, the travel spools in the main control valve are moved to the forward or reverse travel position by pilot pressure oil. The oil from the both pumps flows into the main control valve and then goes to the both travel motors through the turning joint. The return oil from both travel motors returns to the hydraulic oil tank through the turning joint and the travel spools in the main control valve. When this happens, the machine moves to the forward or reverse.

TRAVEL CIRCUIT OPERATION



1693HC21

Valves are provided on travel motors to offer the following functions.


1) COUNTERBALANCE VALVE

When stopping the motor of slope descending, this valve to prevent the motor over run.

2) SPEED CHANGE MECHANISM (auto)

Auto two speed control mechanism consists of two spools and spring. This valve automatically changes motor displacement in portion to motor pressure.

9. DOZER UP OPERATION




1693HC18

When the dozer control lever is pulled back, the dozer spool in the main control valve is moved to the dozer up position by the pilot oil pressure from the remote control valve.

The oil from the A3 pump flows into the main control valve and then goes to the small chamber of dozer cylinders.

At the same time, the oil from the large chamber of dozer cylinders returns to the hydraulic oil tank through the dozer spool in the main control valve. When this happens, the dozer goes up.

10. DOZER DOWN OPERATION



1693HC19


When the dozer control lever is pushed forward, the dozer spool in the main control valve is moved to the dozer down position by the pilot oil pressure from the remote control valve.

The oil from the A3 pump flows into the main control valve and then goes to the large chamber of dozer cylinders.

At the same time, the oil from the small chamber of dozer cylinders returns to the hydraulic oil tank through the dozer spool in the main control valve. When this happens, the dozer blade is down.

GROUP 5 COMBINED OPERATION

1. OUTLINE



1693HC30

The oil from the A1, A2, A3 pump flows through the neutral oil passage, bypass oil passage and confluence oil passage in the main control valve. Then the oil goes to each actuator and operates them. Check valves and orifices are located on these oil passage in the main control valve. These control the oil from the main pumps so as to correspond to the operation of each actuator and smooth the combined operation.

INDEPENDENT TRAVEL SYSTEM


This independent travel system for straight travel is provided in the main control valve.

If any actuator(s) on A1 and A2 pump side is operated when traveling, the travel selector spool is moved to the selected side by the pilot oil pressure.

Consequently, the pressure oil from A1 and A2 pump are supplied to the right and left travel motor and oil from A3 pump flows into the other operated actuator.

This keeps the straight travel.

2. COMBINED SWING AND BOOM OPERATION



1693HC31


When the swing and boom functions are operated, simultaneously the selector spool, swing spool and boom spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the A1 pump and solenoid from the A3 pump flows into the boom cylinder through boom.

The oil from the A3 pump flows into the swing motor through the swing spool.

The superstructure swings and the boom is operated.

3. COMBINED SWING AND ARM OPERATION



1693HC32


When the swing and arm functions are operated, simultaneously the swing spool and arm spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the A3 pump flows into the swing motor through swing spool.

The oil from the A2 pump flows into the arm cylinder through the arm.

The superstructure swings and the arm is operated.

4. COMBINED SWING AND BUCKET OPERATION




1693HC33

When the swing and bucket functions are operated, simultaneously the swing spool and bucket spool in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the A3 pump flows into the swing motor through the swing spool.

The oil from the A1 pump flows into the bucket cylinder through the bucket spool.

5. COMBINED SWING, BOOM, ARM AND BUCKET OPERATION



1693HC34

When the swing, boom, arm and bucket functions are operated, simultaneously each spool in the main control valve is moved to the functional position by the pilot oil pressure from the remote control valve.


The oil from the A2 pump flows into the arm cylinder through, arm spool.

The oil from the A1 pump flows into the boom cylinders and bucket cylinder through the boom spool, bucket spool.

The oil from the A3 pump flows into the swing motor through the swing spool.

The superstructure swings and the boom, arm and bucket are operated.

6. COMBINED SWING AND TRAVEL OPERATION



1693HC35

When the swing and travel functions are operated, simultaneously the swing spool and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve and the travel levers.


The oil from the A3 pump flows into the swing motor through the swing spool.

The oil from the A1 pump flows into the travel motor through the RH travel spool.

The oil from the A2 pump flows into the travel motor through the LH travel spool.

The superstructure swings and the machine travels straight.

7. COMBINED BOOM AND TRAVEL OPERATION




1693HC36

When the boom and travel functions are operated, simultaneously the boom spools and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the A1 and A2 pumps flows into the travel motors through travel RH and travel LH spools.

The oil from the A3 pump flows into the boom cylinders through boom spool via the travel selector spool. The boom is operated and the machine travels straight.

8. COMBINED ARM AND TRAVEL OPERATION



1693HC37


When the arm and travel functions are operated, simultaneously the arm spools and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the A1 and A2 pumps flows into the travel motors through travel spools.

The oil from the A3 pump flows into the arm cylinder through arm spool via the travel selector spool.

The arm is operated and the machine travels straight.

9. COMBINED BUCKET AND TRAVEL OPERATION



1693HC38

When the bucket and travel functions are operated, simultaneously the bucket spool and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve, and the travel selector spool is pushed to the up by the oil pressure from pilot pump. The oil from the A1 and A2 pumps flows into the travel motors.

The oil from the A3 pump flows into the bucket cylinder through bucket spool via the travel selector spool.

The bucket is operated and the machine travels straight.


SECTION 4 ELECTRICAL SYSTEM

Group 1 Component Location	4-1
Group 2 Monitoring system	4-3
Group 3 Electrical Circuit	4-9
Group 4 Electrical Component Specification	4-21
Group 5 Connectors	4-27

SECTION 4 ELECTRICAL SYSTEM

GROUP 1 COMPONENT LOCATION


1. LOCATION 1



1694EL02

- | | | |
|-------------------------------|----------------------------|---------------------|
| 1 Cigar light | 4 Extension crawler switch | 7 Fuse box |
| 2 Start switch | 5 Master switch | 8 Main light switch |
| 3 Travel speed control switch | 6 Horn switch | |

2. LOCATION 2



1694EL01

- | | | | | | |
|---|-----------------------------|---|-------------|---|--------------------------|
| 1 | Air cleaner pressure switch | 4 | Relay | 7 | Water temperature sender |
| 2 | Work lamp | 5 | Power relay | 8 | Travel alarm buzzer |
| 3 | Horn | 6 | Battery | | |

GROUP 2 MONITORING SYSTEM

1. OUTLINE


Monitoring system consists of the monitor part and switch part.

The monitor part gives warnings when any abnormality occurs in the machine and informs the condition of the machine.

Various select switches are built into the monitor panel, which act as the control portion of the machine control system.

2. CLUSTER (MACHINE SERIAL NO.: ~#1210)

1) MONITOR PANEL



R35Z73CD01

2) CLUSTER CHECK PROCEDURE

(1) Start key : ON

- ① Check monitor initial 6 seconds
 - a. All lamps light up.
 - ② Check monitor after 2 seconds : Indicate machine condition
 - a. Tachometer : 0 rpm
 - b. Fuel gauge : Pointed at appropriate level
 - c. Engine coolant temperature gauge : Pointed at appropriate level
 - d. Warning lamp
- ※ During start key ON the engine oil pressure lamp and battery charging lamp go on, but it is not abnormal.


(2) Start of engine

- ① Check machine condition
 - a. Tachometer pointed at present rpm
 - b. Gauge and warning lamp : Indicate at present condition.
- ※ When normal condition : All warning lamp OFF
- ② When abnormal condition
 - a. The lamp lights up.
 - b. The lamp light up until normal condition.


3) CLUSTER CONNECTOR

(1) CONNECTOR


CN-56	
POWER IG 12V	1 ○
LAMP, ENG OIL PRESSURE	2 ○
LAMP, CHARGE	3 ○
LAMP, WATER TEMP	4 ○
LAMP, AIR-CLEANER	5 ○
LAMP, FUEL EMPTY	6 ○
LAMP, AIR-HEATER	7 ○
LAMP, QUICK CLAMP	8 ○
LAMP, ILLUMINATION	9 ○
GAUGE, WATER TEMP	10 ○
GAUGE, FUEL LEVEL	11 ○
RETURN, AIR-HEATER	12 ○
BUZZER(+)	13 ○
NC	14 ○
EARTH	15 ○
NC	16 ○
NC	17 ○
CN-48	
HOURLMETER(B +)	1 ○
HOURLMETER(SIG +)	2 ○
HOURLMETER(-)	3 ○



CN-56




Cluster



CN-48

(2) CLUSTER DETAIL



R35Z74EL23

4) CLUSTER FUNCTION


1) GAUGES AND DISPLAYS



(1) Service meter




- ① This meter shows the total operation hours of the machine.
- ② Always ensure the operating condition of the meter during the machine operation.
Inspect and service the machine based on hours as indicated in chapter 6, maintenance.


(2) Fuel gauge



- ① This gauge indicates the amount of fuel in the fuel tank.
- ② Fill the fuel when the red range or warning lamp  ON.
- ※ If the gauge illuminates the red range or warning lamp  ON even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(3) Engine coolant temperature gauge



- ① This indicates the temperature of coolant.
 - Red range : Above 105°C (221°F)
- ② When the red range pointed or warning lamp  ON, engine do not abruptly stop but run it at medium speed to allow it to cool gradually, then stop it.
Check the radiator and engine.
- ※ If the engine is stopped without cooled down running, the temperature of engine parts will rise suddenly, this could cause severe engine trouble.


2) WARNING AND PILOT LAMPS

(1) Fuel low level warning lamp




- ① This lamp blinks when the level of fuel is below 2.0 l (0.5 U.S. gal).
- ② Fill the fuel immediately when the lamp blinks.

(2) Engine coolant temperature warning lamp




- ① This lamp blinks when the temperature of coolant is over the normal temperature 110°C (230°F) .
- ② Check the cooling system when the lamp blinks.

(3) Engine oil pressure warning lamp




- ① This lamp blinks after starting the engine because of the low oil pressure.
- ② If the lamp blinks during engine operation, shut OFF engine immediately. Check oil level.

(4) Air cleaner warning lamp




- ① This lamp blinks when the filter of air cleaner is clogged.
- ② Check the filter and clean or replace it.

(5) Battery charging warning lamp




- ① This lamp blinks when the starting switch is ON, it is turned OFF after starting the engine.
- ② Check the battery charging circuit when this lamp blinks during engine operation.

(6) Preheat pilot lamp



- ① When the start switch turn to HEAT position, pilot lamp comes ON.
- ② Refer to "4-2) STARTING ENGINE" of operator's manual for details.

(7) Quick clamp warning lamp




- ① When the quick clamp switch turned ON, this lamp turn ON and the buzzer sounds.
- ② This lamp turned OFF and the buzzer stop when the quick clamp switch turned OFF.

CLUSTER (MACHINE SERIAL NO.: #1211~)

The cluster consists of gauges and lamps as shown below, to warn the operator in case of abnormal machine operation or conditions for the appropriate operation and inspection.

- Gauges : Indicate operating status of the machine.
- Warning lamp : Indicate abnormality of the machine (red).
- Pilot lamp : Indicate operating status of the machine.


- ※ The cluster installed on this machine does not entirely guarantee the condition of the machine. Daily inspection should be performed according to chapter 6, Maintenance.
- ※ When the cluster provides a warning, immediately check the problem and perform the required action.



17Z9A3CD03B


1) GAUGES AND DISPLAYS



(1) Service meter




- ① This meter shows the total operation hours of the machine.
 - ② Always ensure the operating condition of the meter during the machine operation.
- Inspect and service the machine based on hours as indicated in chapter 6, maintenance.


(2) Fuel gauge



- ① This gauge indicates the amount of fuel in the fuel tank.
 - ② Fill the fuel when the red range or warning lamp  ON.
- ※ If the gauge illuminates the red range or warning lamp  ON even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(3) Engine coolant temperature gauge



- ① This indicates the temperature of coolant.
 - Red range : Above 115°C (239°F)
 - ② When the red range pointed or warning lamp  ON, engine do not abruptly stop but run it at medium speed to allow it to cool gradually, then stop it.
- Check the radiator and engine.
- ※ If the engine is stopped without cooled down running, the temperature of engine parts will rise suddenly, this could cause severe engine trouble.


2) WARNING AND PILOT LAMPS

(1) Fuel low level warning lamp




- ① This lamp blinks and buzzer sounds when the level of fuel is low.
- ② Fill the fuel immediately when the lamp blinks.

(2) Engine coolant temperature warning lamp




- ① This lamp blinks and buzzer sounds when the temperature of coolant is over the normal temperature 115°C (239°F) .
- ② Check the cooling system when the lamp blinks.

(3) Engine oil pressure warning lamp




- ① This lamp blinks and buzzer sounds after starting the engine because of the low oil pressure.
- ② If the lamp blinks during engine operation, shut OFF engine immediately. Check oil level.

(4) Battery charging warning lamp




- ① This lamp blinks and buzzer sounds when the starting switch is ON, it is turned OFF after starting the engine.
- ② Check the battery charging circuit when this lamp blinks during engine operation.

(5) Engine preheat pilot lamp




- ① When the start switch turn to HEAT position, pilot lamp comes ON.
- ② Refer to "4-2) STARTING ENGINE" of operator's manual for details.

(6) Quick clamp lock pilot lamp



- ① When the quick clamp switch turned ON, this lamp turn ON and the buzzer sounds.
- ② This lamp turned OFF and the buzzer stop when the quick clamp switch turned OFF.


(7) Travel speed pilot lamp



- ① When this lamp turned ON, the machine travel high speed.
- ② Refer to the travel speed control switch in page 3-9 of operator's manual for details.


3) BUTTONS

(1) Up/left button




- ① Move in menu (up, left)
- ② Increase input value.

(2) Down/right button




- ① Move in menu (down, right)
- ② Decrease input value.

(3) Menu button



- ① Current display to next display.


(4) Enter and buzzer stop button



- ① Select menu (enter).
- ② Stop buzzer sound when sound is ON.

4) OLED display

(1) Main display




① **Service meter** : This meter shows the total operation hours of the machine.

※ **Always ensure the operating condition of the service meter during the machine operation.**

② **Engine rpm** : This displays the engine speed.

③ **Engine run status** : This displays the engine run status.

(2) Machine security



① ESL (Engine Starting Limit) mode setting

- ESL mode is designed to be a theft deterrent or will prevent the unauthorized operation of the machine.
- If the ESL mode was selected Always, the password will be required when the start switch is turned ON.
- Disable : Not used ESL function.

Always: The password is required whenever the operator start engine.

Interval : The password is required when the operator start engine first. But the operator can restart the engine within the interval time without inputting the password.

The interval time can be set maximum 2 days.


Interval time

- If set interval time to 5 minutes, ESL system is activated after 5 minutes. Therefore, the password does not need to restart engine within 5 minutes.


※ **Default password : 00000**

② Password change

- Input 5 to 10 digits and press Enter.



GROUP 3 ELECTRICAL CIRCUIT




MEMORANDUM

1. POWER CIRCUIT

The negative terminal of battery is grounded to the machine chassis.

When the start switch is in the OFF position, the current flows from the positive battery terminal as shown below.

1) OPERATING FLOW




※ I/conn : Intermediate connector

2) CHECK POINT

Engine	Start switch	Check point	Voltage
OFF	OFF	① - GND (Battery) ② - GND (Master switch) ③ - GND (Fusible link)	10~12.5 V

※ GND : Ground


POWER CIRCUIT



2. STARTING CIRCUIT


1) OPERATING FLOW

Battery(+) terminal → Master switch [CS-74] → Fusible link [CN-60]



※ Start switch : ON

Start switch ON



※ Start switch : START

Start switch START [CS-46 (4)] → Start relay [CR-23 (C1) → (2)] → Starter [CN-45 (S)] → Start motor operating

2) CHECK POINT

Engine	Start switch	Check point	Voltage
Operating	Start	① - GND (Battery) ② - GND (Start key) ③ - GND (Starter B ⁺) ④ - GND (Starter M)	10~12.5 V

※ GND : Ground

[illegible]

4-14

3. CHARGING CIRCUIT


When the starter is activated and the engine is started, the operator releases the key switch to the ON position.

Charging current generated by operating alternator flows into the battery.


The current also flows from alternator to each electrical component and controller through the fuse box.

1) OPERATING FLOW

(1) Warning flow



(2) Charging flow




2) CHECK POINT

Engine	Start switch	Check point	Voltage
ON	ON	① - GND (Battery voltage) ② - GND (Alternator B ⁺ terminal) ③ - GND (Cluster)	10~12.5 V

※ GND : Ground

CHARGING CIRCUIT



1694EL06

4. HEAD AND WORK LIGHT CIRCUIT

1) OPERATING FLOW

Fuse box (No.6) → I/conn [CN-2 (6)] → I/conn [CN-3 (8)] → Light switch [CS-21 (1)]

Fuse box (No.5) → I/conn [CN-2 (10)] → I/conn [CN-3 (13)] → Light switch [CS-21 (4)]

(1) Main light switch ON : 1st step

Cabin light switch ON [CS-21 (5,7)] → I/conn [CN-3 (2)] → I/conn [CN-5 (8)]
 → Cluster illumination ON [CN-56 (9)]
 → Cigar light illumination ON [CL-2]
 → Head light ON [CL-4(1)]

(2) Main light switch ON : 2nd step


Work light switch ON [CS-21 (2)] → I/conn [CN-3 (14)] → Work light ON [CL-5 (2)]

2) CHECK POINT


Engine	Start switch	Check point	Voltage
STOP	ON	① - GND (Fuse box) ② - GND (Switch power input) ③ - GND (Switch power output) ④ - GND (Head light) ⑤ - GND (Fuse box) ⑥ - GND (Switch power input) ⑦ - GND (Switch power output) ⑧ - GND (Work light)	10~12.5 V

※ GND : Ground

HEAD AND WORK LAMP CIRCUIT




MONITORING CIRCUIT









1694EL08







ELECTRIC CIRCUIT FOR HYDRAULIC















1694EL09







GROUP 4 ELECTRICAL COMPONENT SPECIFICATION


Part name	Symbol	Specification	Check
Battery		12V × 58Ah (5h rating)	※ Check specific gravity 1.280 over : Over charged 1.280 ~ 1.250 : Normal 1.250 below : Recharging
Start key		12V	※ Check contact OFF : ∞ Ω (for each terminal) ON : 0 Ω (for terminal 1-3 and 1-2) START : 0 Ω (for terminal 1-5)
Pressure switch (for engine oil)		0.5 kgf/cm ² (N.C TYPE)	※ Check resistance Normal : 0 Ω (CLOSE)
Air cleaner pressure switch		Pressure: 635 mmH ₂ O (N.O TYPE)	※ Check contact Normal : ∞ Ω
Relay		12V 60A	※ Rated coil current 1.2±0.3A
Fuel sender		-	※ Check resistance Full : 30 Ω Low : 100 Ω Empty warning : 200 Ω

Part name	Symbol	Specification	Check
Relay	 CR-2	12V 20A	※ Check resistance Normal : About 200 Ω (for terminal 1-3) : 0 Ω (for terminal 2-4)
Relay	 CR-35	12V 70A	※ Rated coil current 1.2 ± 0.3 A
Solenoid valve	 CN-70 CN-68 CN-140 CN-258	12V 1A	※ Check resistance Normal : 15~25 Ω (for terminal 1-2)
Solenoid valve (engine stop)	 CN-79	12V	※ Coil resistance : 1.8 Ω
Switch (looking type)	 CS-8 CS-16 CS-23 CS-83	12V 16A	※ Check contact Normal OFF - ∞ Ω (for terminal 1-5,2-6) - 0 Ω (for terminal 5-7,6-8)
Pressure switch	 CD-11 CD-12	10bar (N.C type)	※ Check contact Normal : 0.1 Ω

Part name	Symbol	Specification	Check
Quick clamp switch	 CS-67	12V 16A	※ Check contact Normal OFF - $\infty \Omega$ (For terminal 1-5,2-6) - 0Ω (For terminal 5-7,6-8)
Lamp	 CL-4 CL-5	12V 55W (H3 TYPE)	※ Check disconnection Normal : 1.2Ω
Horn	 CN-20	12V 6A	132 ± 5 dB
Safety switch	 CS-4	Micro 12V 15A	※ Check contact Normal : 0Ω Operating : $\infty \Omega$
Horn switch	 CS-5 CS-16	12V 10A	※ Check contact Normal : 0Ω
Water temp sender	 CD-8	-	※ Check contact 50°C : $0.748 \sim 0.904 \Omega$ 67°C : $0.538 \sim 0.650 \Omega$ 102°C : $0.185 \sim 0.167 \Omega$ 110°C : $0.143 \sim 0.130 \Omega$ 135°C : $0.076 \sim 0.100 \Omega$

Part name	Symbol	Specification	Check
Light switch	 <p>CS-21</p>	12V 16A	※ Check contact Normal : $\infty \Omega$
Cigar lighter	 <p>CL-2</p>	12V 10A 1.4W	※ Check coil resistance Normal : About 1M Ω ※ Check contact Normal : $\infty \Omega$ Operating time : 5~15sec
Starter	 <p>CN-45</p>	12V	※ Check contact Normal : 0.1 Ω
Alternator	 <p>CN-74</p>	12V 40A	※ Check contact Normal : 0 Ω (For terminal B ⁺ -1) Normal : 10 ~ 12.5V
Travel alarm	 <p>CN-81</p>	12V	-
Fuel feed pump	 <p>CN-145</p>	12V	-

Part name	Symbol	Specification	Check
Master switch	 CS-74	12V 1000A	-
Glow timer	 CR-24, CR-36	12V	-
Air-heater	 CN-80	12V 42A 500W	-
Safety relay	 CN-165	12V 1400rpm/ Alternator	※ Contact capacity : Rush : 100A Steady-State : 50A (30sec)
Detector	 CN-167	12V	-
Control time relay	 CR-77 CR-79	12V	-

Part name	Symbol	Specification	Check
Fusible link	 CN-60	27A	※ Check coil resistance Normal : 3.26m Ω /m

GROUP 5 CONNECTORS









1. CONNECTOR DESTINATION







Connector number	Type	No. of pin	Destination	Connector part No.	
				Female	Male
CN-1	AMP	2	I/conn (RH console harness-main harness)	S813-030200	S813-130200
CN-2	AMP	15	I/conn (Main harness-RH console harness)	2-85262-1	368301-1
CN-3	AMP	15	I/conn (Main harness-LH console harness)	2-85262-1	368301-1
CN-4	AMP	4	I/conn (FR RH side harness-main harness)	S810-004202	S810-104202
CN-5	AMP	2	I/conn (Relay harness-main harness)	S813-030201	S813-130201
CN-20	DEUTSCH	2	Horn	DT06-2S-P012	-
CN-36	-	-	Fuse box body	F12890010	-
CN-45	RING TERM	1	Starter	ST710258-2	-
	KET	1	Starter	MG630063	-
CN-48	AMP	3	Hour meter	S810-003202	
CN-56	AMP	17	Cluster	172500-1	-
CN-60	AMP	2	Fusible link	-	S831-130200
CN-68	DEUTSCH	2	Safety solenoid	DT06-2S-P012	-
CN-70	DEUTSCH	2	Travel HI-LO solenoid	DT06-2S-P012	-
CN-74	AMP	2	Alternator	174298-1	-
	-	1		7123-2115	-
	RING TERM	1		S820-305002	-
CN-79	-	1	Fuel cut-off solenoid	S822-014000	-
CN-80	RING TERM	1	Pre heater	GP110021	-
CN-81	SWP	1	Travel buzzer	S822-014000	S822-114000
CN-140	DEUTSCH	2	Quick clamp	DT06-2S-EP06	DT04-2P-E005
CN-145	AMP	2	Fuel feed pump	174298-1	-
CN-165	KET	6	Safety relay	MG610049	-
CN-167	KET	8	Detector	S810-008202	-
CN-258	-	1	Extension valve	DT06-2S-P012	-
LAMP					
CL-2	AMP	3	Cigar light	S810-003202	-
CL-4	DEUTSCH	2	Head lamp	DT06-2S-P012	DT04-2P-E004
CL-5	DEUTSCH	2	Work lamp	DT06-2S-P012	DT04-2P-E004
RELAY					
CR-2	AMP	4	Horn relay	S810-004202	-
CR-23	KET	2	Start relay	MG610043	-
	YAZAKI			S810-001302	
CR-24	SUMITOMO	6	Safety relay	6195-0021	-
CR-35	KET	4	Power relay	MG612017-5	-

Connector number	Type	No. of pin	Destination	Connector part No.	
				Female	Male
CR-36	SUMITOMO	2	Safety relay	6195-0060	-
CR-77	KET	4	Control timer	MG620046	-
CR-79	KET	3	Control timer	MG620044	-
SENSOR					
CD-2	AMP	3	Fuel sender	S816-003002	S816-102002
CD-8	AMP	2	Water temp sender	85202-1	-
CD-9	-	1	Water temp switch	7123-2115	-
CD-10	-	1	Air cleaner	S823-025212	-
CD-11	KET	2	Travel pressure switch	MG640795	-
CD-12	KET	2	Travel pressure switch	MG640795	-
CD-18	-	1	Engine oil pressure	7123-2115	-
DO-1	-	2	Diode	S816-002002	21EA-50570
DO-6	-	2	Diode	S816-002002	21EA-50550
SWITCH					
CS-2	-	2	Start key switch	S813-030201	-
CS-4	AMP	3	Safety switch	-	S814-102001
CS-5	-	1	Horn switch	S822-014002	-
	-	1		-	S822-114002
CS-8	-	10	Travel speed switch	250-10PRG	-
CS-16	-	10	Travel alarm switch	250-10PRG	-
CS-21	-	10	Light switch	250-10PRG	-
CS-23	SWF	10	Spare	593757	-
CS-46	KET	4	Start switch	MG651926	-
CS-67	SWF	10	Quick clamp switch	593757	-
CS-74	RING TERM	1	Battery (+)	ST710287-2	-
CS-83	-	10	Extension valve switch	250-10PRG	-









2. CONNECTION TABLE FOR CONNECTORS

1) PA TYPE CONNECTOR









No. of pin	Receptacle connector (female)	Plug connector (male)
5	 <p>S811-005002</p>	 <p>S811-105002</p>
7	 <p>S811-007002</p>	 <p>S811-107002</p>
9	 <p>S811-009002</p>	 <p>3S811-109002</p>
11	 <p>S811-011002</p>	 <p>S811-111002</p>









No. of pin	Receptacle connector (female)	Plug connector (male)
13	 <p>S811-013002</p>	 <p>S811-113002</p>
17	 <p>S811-017002</p>	 <p>S811-117002</p>
21	 <p>S811-021002</p>	 <p>S811-121002</p>

2) J TYPE CONNECTOR









No. of pin	Receptacle connector (female)	Plug connector (male)
2	 <p>S816-002001</p>	 <p>S816-102001</p>
3	 <p>S816-003001</p>	 <p>S816-103001</p>
4	 <p>S816-004001</p>	 <p>S816-104001</p>
8	 <p>S816-008001</p>	 <p>S816-108001</p>





3) SWP TYPE CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
1	 <p>S814-001000</p>	 <p>S814-101000</p>
2	 <p>S814-002000</p>	 <p>S814-102000</p>
3	 <p>S814-003000</p>	 <p>S814-103000</p>
4	 <p>S814-004000</p>	 <p>S814-104000</p>



No. of pin	Receptacle connector (female)	Plug connector (male)
6	 <p>S814-006000</p>	 <p>S814-106000</p>
8	 <p>S814-008000</p>	 <p>S814-108000</p>
12	 <p>S814-012000</p>	 <p>S814-112000</p>
14	 <p>S814-014000</p>	 <p>S814-114000</p>

4) CN TYPE CONNECTOR



No. of pin	Receptacle connector (female)	Plug connector (male)
1	 <p>S810-001202</p>	 <p>S810-101202</p>
2	 <p>S810-002202</p>	 <p>S810-102202</p>
3	 <p>S810-003202</p>	 <p>S810-103202</p>
4	 <p>S810-004202</p>	 <p>S810-104202</p>

No. of pin	Receptacle connector (female)	Plug connector (male)
6	 <p>S810-006202</p>	 <p>S810-106202</p>
8	 <p>S810-008202</p>	 <p>S810-108202</p>


5) 375 FASTEN TYPE CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	 <p>S810-002402</p>	 <p>S810-102402</p>


6) AMP ECONOSEAL CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
36	 <p>344111-1</p>	 <p>344108-1</p>


7) AMP TIMER CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	 <p>85202-1</p>	



8) AMP 040 MULTILOCK CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
12	 <p>174045-2</p>	


9) AMP 070 MULTILOCK CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
14	 <p>173852</p>	



10) AMP FASTIN - FASTON CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
6	 <p>925276-0</p>	 <p>480003-9</p>


11) KET 090 CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	 <p>MG610070</p>	

12) KET 090 WP CONNECTORS


No. of pin	Receptacle connector (female)	Plug connector (male)
2	 <p>MG640605</p>	
2	 <p>MG640795</p>	

13) KET SDL CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
14	<div><p>MG610406</p></div>	

14) DEUTSCH DT CONNECTORS

DT 06 - 3S - ★★★★★



※ Modification

E003 : Standard end cap - gray

E004 : Color of connector to be black







E005 : Combination - E004 & E003

EP04 : End cap


EP06 : Combination P012 & EP04

P012 : Front seal enhancement - connectors color to black for 2, 3, 4 & 6pin


No. of pin	Receptacle connector (female)	Plug connector (male)
2	<p>DT06-2S</p>	<p>DT04-2P</p>
3	<p>DT06-3S</p>	<p>DT04-3P</p>
4	<p>DT06-4S</p>	<p>DT04-4P</p>

No. of pin	Receptacle connector (female)	Plug connector (male)
6	 <p>DT06-6S</p>	 <p>DT04-6P</p>
8	 <p>DT06-8S</p>	 <p>DT04-8P</p>
12	 <p>DT06-12S</p>	 <p>DT04-12P</p>


15) MOLEX 2CKTS CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	 <p>35215-0200</p>	

16) ITT SWF CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
10	 <p>SWF593757</p>	

17) MWP NMWP CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
1	 <p>NMWP01F-B</p>	

SECTION 5 TROUBLESHOOTING



Group 1 Before Troubleshooting 5-1

Group 2 Hydraulic and Mechanical System 5-4

Group 3 Electrical System 5-24


GROUP 1 BEFORE TROUBLESHOOTING

1. INTRODUCTION

When a trouble is occurred in the machine, this section will help an operator to maintain the machine with easy.

The trouble of machine is parted Hydraulic & Mechanical system and Electrical system.

At each system part, an operator can check the machine according to the troubleshooting process diagram.




2. DIAGNOSING PROCEDURE

To carry out troubleshooting efficiently, the following steps must be observed.

STEP 1. Study the machine system

Study and know how the machine is operating, how the system is composing, what kinds of function are installed in the machine and what are specifications of the system components by the machine service manual.


Especially, deepen the knowledge for the related parts of the trouble.



STEP 2. Ask the operator

Before inspecting, get the full story of malfunctions from a witness --- the operator.


- 1) How the machine is used and when it is serviced?
- 2) When the trouble was noticed and what work the machine was doing at that time?
- 3) What is the phenomenon of the trouble?
Was the trouble getting worse, or did it come out suddenly for the first time?
- 4) Did the machine have any troubles previously? If so, which parts were repaired before.



STEP 3. Inspect the machine

Before starting troubleshooting, check the machine for the daily maintenance points as shown in the operator's manual.


And also check the electrical system including batteries, as the troubles in the electrical system such as low battery voltage, loose connections and blown out fuses will result in malfunction of the controllers causing total operational failures of the machine.



STEP 4. Inspect the trouble actually on the machine


In case that some trouble cannot be confirmed, obtain the details of the malfunction from the operator.

Also, check if there are any incomplete connections of the wire harnesses or not.



STEP 5. Perform troubleshooting


According to where the trouble parts are located, hydraulic & mechanical system part or electrical system part or mechatronics system part, perform troubleshooting the machine refer to the each system part's troubleshooting process diagram.



STEP 6. Trace a cause

Before reaching a conclusion, check the most susceptible causes again. Try to trace what the real cause of the trouble is.

Make a plan of the appropriate repairing procedure to avoid consequential malfunctions.



GROUP 2 HYDRAULIC AND MECHANICAL SYSTEM

1. INTRODUCTION

1) MACHINE IN GENERAL

- (1) If even a minor fault is left intact and operation is continued, a fatal failure may be caused, entailing a large sum of expenses and long hours of restoration.

Therefore when even a small trouble occurs, do not rely on your intuition and experience, but look for the cause based on the troubleshooting principle and perform maintenance and adjustment to prevent major failure from occurring. Keep in mind that a fault results from a combination of different causes.

- (2) The following lists up commonly occurring faults and possible causes with this machine. For the troubleshooting of the engine, refer to the coming troubleshooting and repair.

- (3) When carrying out troubleshooting, do not hurry to disassemble the components.
It will become impossible to find the cause of the problem.

- (4) Ask user or operator the following.


- ① Was there any strange thing about machine before failure occurred?
- ② Under what conditions did the failure occur?
- ③ Have any repairs been carried out before the failure?

- (5) Check before troubleshooting.


- ① Check oil and fuel level.
- ② Check for any external leakage of oil from components.
- ③ Check for loose or damage of wiring and connections.

2. DRIVE SYSTEM

1) UNUSUAL NOISE COMES OUT OF PUMP CONNECTION



2) ENGINE STARTS BUT MACHINE DOES NOT OPERATE AT ALL



3. HYDRAULIC SYSTEM


1) HYDRAULIC OIL IS CLOUDY

		Cause	Remedy
<div>Drop hydraulic oil sample on hot plate and check if foams come up.</div>	YES	Water is mixed.	Put hydraulic oil still, separate water and dispose it or replace hydraulic oil.
	NO	Air is intruded.	Check suction line and return line and eliminate the air intruding source.


2) HYDRAULIC OIL TEMPERATURE HAS RISEN ABNORMALLY

		Cause	Remedy	
<div>Is hydraulic oil volume proper?</div>	NO	(a)	Replenish specified oil to the standard level.	
	YES		Clean oil cooler.	
			Secure air circulation route.	
	Is not oil cooler clogged and is anything blocking air circulation?		YES	Adjust belt tension or replace belt.
			NO	
	Is fan belt tension proper?		YES	Reduce load.
NO				
(a)	Is not the set pressure of main relief, relief and travel relief valve lower than the standard level?	YES		
	NO	Is main relief valve used very often?	YES	

3) CAVITATION OCCURS WITH PUMP




4) HYDRAULIC OIL IS CONTAMINATED




4. SWING SYSTEM


1) BOTH LH AND RH SWING ACTIONS ARE IMPOSSIBLE




2) SWING SPEED IS LOW




3) SWING MOTION IS IMPOSSIBLE IN ONE DIRECTION



4) MACHINE SWINGS BUT DOES NOT STOP




5) THE SWING UNIT DRIFTS WHEN THE MACHINE IS AT REST ON A SLOPE




5. TRAVEL SYSTEM

1) TRAVEL DOES NOT FUNCTION AT ALL ON ONE SIDE




2) SPEED ON ONE SIDE FALLS AND THE MACHINE CURVES




3) MACHINE DOES NOT STOP ON A SLOPE


Machine is pulled forward as sprocket rotates during digging operation.



4) LH AND RH TRAVEL MOTIONS ARE IMPOSSIBLE




5) TRAVEL ACTION IS POWERLESS (travel only)



6) MACHINE RUNS RECKLESSLY ON A SLOPE




7) MACHINE MAKES A CURVED TRAVEL OR DOES NOT TRAVEL AT ALL WHEN TRAVEL AND ATTACHMENT OPERATIONS ARE EXECUTED AT THE SAME TIME




6. ATTACHMENT SYSTEM


1) BOOM OR ARM ACTION IS IMPOSSIBLE AT ALL




2) BOOM, ARM OR BUCKET SPEED IS LOW




3) BOOM, ARM OR BUCKET CYLINDER EXTENDS OR CONTRACTS ITSELF AND ATTACHMENT FALLS



4) BOOM, ARM OR BUCKET POWER IS WEAK



5) ONLY BUCKET OPERATION IS TOTALLY IMPOSSIBLE




6) BOOM MAKES A SQUEAKING NOISE WHEN BOOM IS OPERATED


		Cause	Remedy
Is boom foot pin greased sufficiently?	YES		Frictional noise occurs between the sliding faces of boom cylinder's oil seal and boom proper. ※ Frictional noise will disappear if they are kept used.
	NO	Boom foot pin has run out of grease.	Supply grease to it. ※ If seizure is in an initial stage, supply sufficient grease. If seizure is in a grown state, correct it by paper lapping or with an oil stone.

※ HOW TO CHECK INTERNAL BOOM CYLINDER LEAKAGE

1. Lower the bucket teeth to the ground with bucket cylinder fully retracted and arm cylinder rod retracted almost in full.




2. Disconnect hose (A) from rod side of boom cylinder and drain oil from cylinders and hose. (Put cups on piping and hose ends)



3. Raise bucket OFF the ground by retracting the arm cylinder rod.

If oil leaks from piping side and boom cylinder rod is retracted there is an internal leak in the cylinder.


If no oil leaks from piping side and boom cylinder rod is retracted, there is an internal leak in the control valve.



GROUP 3 ELECTRICAL SYSTEM


1. WHEN STARTING SWITCH IS TURNED ON, MONITOR PANEL DISPLAY DOES NOT APPEAR

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 7.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check voltage

YES	10 ~ 12.5V
NO	0V




2. BATTERY CHARGING WARNING LAMP LIGHTS UP (starting switch : ON)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check voltage



YES	10 ~ 12.5V
NO	0V



1695TS03

3. WHEN COOLANT OVERHEAT WARNING LAMP LIGHTS UP (Engine is started)


- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



1695TS04


4. WHEN AIR CLEANER WARNING LAMP LIGHTS UP (Engine is started)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check resistance


YES	MAX 1Ω
NO	MIN $1M \Omega$



1695TS05


5. WHEN ENGINE OIL PRESSURE WARNING LAMP LIGHTS UP (Engine is started)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check resistance



YES	MAX 1Ω
NO	MIN 1MΩ



1695TS06

6. WHEN COOLANT TEMPERATURE GAUGE DOES NOT OPERATE


- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check Table

Temperature	50° C	80° C	100° C	120° C (red range)
Item				
Unit Resistance (Ω)	350	118	63.5	36.2

CLUSTER




CN-56



CN-5

WATER TEMP SENSOR





CD-8



7. WHEN FUEL GAUGE DOES NOT OPERATE (Check warning lamp ON/OFF)




- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check Table



Item	Temperature		
	Empty	1/2	Full
Unit resistance (Ω)	90	38	10

CLUSTER



8. WHEN SAFETY SOLENOID DOES NOT OPERATE



- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.10.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



1695TS09

9. WHEN TRAVEL SPEED 1, 2 DOES NOT OPERATE



- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.8.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.




1695TS10

10. WHEN STARTING SWITCH IS TURNED ON, HEAD LAMP DOES NOT LIGHTS UP

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.6.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.





- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.5.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.





12. WHEN ENGINE DOES NOT START

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



13. WHEN STARTING SWITCH ON DOES NOT OPERATE

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and master switch ON.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



SECTION 6 MAINTENANCE STANDARD

Group 1	Operational Performance Test	6-1
Group 2	Major Components	6-20
Group 3	Track and Work Equipment	6-31

SECTION 6 MAINTENANCE STANDARD

GROUP 1 OPERATIONAL PERFORMANCE TEST

1. PURPOSE

Performance tests are used to check:

1) OPERATIONAL PERFORMANCE OF A NEW MACHINE

Whenever a new machine is delivered in parts and reassembled at a customer's site, it must be tested to confirm that the operational performance of the machine meets Hyundai spec.


2) OPERATIONAL PERFORMANCE OF A WORKING MACHINE

With the passage of time, the machine's operational performance deteriorates, so that the machine needs to be serviced periodically to restore it to its original performance level.

Before servicing the machine, conduct performance tests to check the extent of deterioration, and to decide what kind of service needs to be done (by referring to the "Service Limits" in this manual).

3) OPERATIONAL PERFORMANCE OF A REPAIRED MACHINE

After the machine is repaired or serviced, it must be tested to confirm that its operational performance was restored by the repair and/or service work done.




1696MS01

2. TERMINOLOGY

1) STANDARD


Specifications applied to the brand-new machine, components and parts.



1696MS02

2) SERVICE LIMIT

The lowest acceptable performance level. When the performance level of the machine falls below this level, the machine must be removed from work and repaired. Necessary parts and components must be replaced.



1696MS03

3. OPERATION FOR PERFORMANCE TESTS

- 1) Observe the following rules in order to carry out performance tests accurately and safely.

(1) The machine

Repair any defects and damage found, such as oil or water leaks, loose bolts, cracks and so on, before starting to test.

(2) Test area


- ① Select a hard, flat surface.
- ② Secure enough space to allow the machine to run straight more than 20m, and to make a full swing with the front attachment extended.
- ③ If required, rope off the test area and provide signboards to keep unauthorized personnel away.

(3) Precautions

- ① Before starting to test, agree upon the signals to be employed for communication among coworkers. Once the test is started, be sure to communicate with each other using these signals, and to follow them without fail.
- ② Operate the machine carefully and always give first priority to safety.
- ③ While testing, always take care to avoid accidents due to landslides or contact with high voltage power lines. Always confirm that there is sufficient space for full swings.
- ④ Avoid polluting the machine and the ground with leaking oil. Use oil pans to catch escaping oil. Pay special attention to this when removing hydraulic pipings.

(4) Make precise measurements

- ① Accurately calibrate test instruments in advance to obtain correct data.
- ② Carry out tests under the exact test conditions prescribed for each test item.
- ③ Repeat the same test and confirm that the test data obtained can be procured repeatedly. Use mean values of measurements if necessary.



7-3 (140-7)

2) ENGINE SPEED

(1) Measure the engine speed at the maximum RPM.

※ **The engine speed must meet standard RPM; if not, all other operational performance data will be unreliable. It is essential to perform this test first.**

(2) Preparation and measurement

- ① Warm up the machine, until the engine coolant temperature reaches 50°C or more, and the hydraulic oil is $50 \pm 5^\circ\text{C}$.
- ② Set the accel lever at the maximum stroke.
- ③ Measure the engine RPM.

(3) Evaluation

The measured speeds should meet the following specifications.

Unit : rpm


Model	Engine speed	Standard	Remarks
R16-9	Low idle	1600 ± 100	
	High idle	2500 ± 50	

3) TRAVEL SPEED

- (1) Measure the time required for the excavator to travel a 20m test track.

(2) Preparation


- ① Adjust the tension of both tracks to be equal.
- ② Prepare a flat and solid test track 20m in length, with extra length of 3 to 5m on both ends for machine acceleration and deceleration.
- ③ Hold the bucket 0.3 to 0.5m above the ground with the arm and bucket rolled in.
- ④ Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.



1696MS04

(3) Measurement

- ① Measure both the low and high speeds of the machine.
- ② Before starting either the low or high speed tests, adjust the travel mode switch to the speed to be tested.
- ③ Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- ④ Measure the time required to travel 20m.
- ⑤ After measuring the forward travel speed, turn the upperstructure 180° and measure the reverse travel speed.
- ⑥ Repeat steps ④ and ⑤ three times in each direction and calculate the average values.



1696MS05

(4) Evaluation

The average measured time should meet the following specifications.

Unit : Seconds / 20m


Model	Travel speed	Standard	Maximum allowable	Remarks
R16-9	1 Speed	32.7 ± 2.0	40.8	
	2 Speed	17.6 ± 1.0	22.0	

4) TRACK REVOLUTION SPEED

- (1) Measure the track revolution cycle time with the track raised off ground.

(2) Preparation

- ① Adjust the tension of both side tracks to be equal.
- ② On the track to be measured, mark one shoe with chalk.
- ③ Swing the upperstructure 90° and lower the bucket to raise the track off ground. Keep the boom-arm angle between 90 to 110° as shown. Place blocks under machine frame.
- ④ Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.



1696MS06

(3) Measurement

- ① Select the following switch positions.
 - Travel mode switch : 1 or 2 speed
- ② Operate the travel control lever of the raised track in full forward and reverse.
- ③ Rotate 1 turn, then measure time taken for next 3 revolutions.
- ④ Raise the other side of machine and repeat the procedure.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.

(4) Evaluation

The revolution cycle time of each track should meet the following specifications.

Unit : Seconds / 3 revolutions


Model	Travel speed	Standard	Maximum allowable
R16-9	1 Speed	16.5 ± 2.0	20.6
	2 Speed	8.9 ± 2.0	11.1

5) TRAVEL DEVIATION

- (1) Measure the deviation by the tracks from a 20m straight line.

(2) Preparation


- ① Adjust the tension of both tracks to be equal.
- ② Provide a flat, solid test yard 20 m in length, with extra length of 3 to 5 m on both ends for machine acceleration and deceleration.
- ③ Hold the bucket 0.3 to 0.5 m above the ground with the arm and bucket rolled in.
- ④ Keep the hydraulic oil temperature at $50 \pm 5^\circ\text{C}$.



1696MS07

(3) Measurement

- ① Measure the amount of mistracking at high and low travel speeds.
- ② Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- ③ Measure the distance between a straight 20m line and the track made by the machine. (Dimension a)
- ④ After measuring the tracking in forward travel, turn the upperstructure 180° and measure that in reverse travel.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.



7-7(2) 140-7

(4) Evaluation

Mistrack should be within the following specifications.

Unit : mm / 20 m


Model	Standard	Maximum allowable	Remarks
R16-9	200 below	240	

6) SWING SPEED

- (1) Measure the time required to swing three complete turns.

(2) Preparation

- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- ③ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- ④ Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.



1696MS08

(3) Measurement

- ① Operate swing control lever fully.
- ② Swing 1 turn and measure time taken to swing next 2 revolutions.
- ③ Repeat steps ① and ② three times and calculate the average values.

(4) Evaluation

The time required for 2 swings should meet the following specifications.

Unit : Seconds / 2 revolutions


Model	Standard	Maximum allowable	Remarks
R16-9	12.9 ± 1.0	16.1	

7) SWING FUNCTION DRIFT CHECK

- (1) Measure the swing drift on the bearing outer circumference when stopping after a 360° full speed swing.

(2) Preparation


- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- ③ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- ④ Make two chalk marks: one on the swing bearing and one directly below it on the track frame.
- ⑤ Swing the upperstructure 360°.
- ⑥ Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.



1696MS09

(3) Measurement

- ① Operate the swing control lever fully and return it to the neutral position when the mark on the upperstructure aligns with that on track frame after swinging 360°
- ② Measure the distance between the two marks.
- ③ Align the marks again, swing 360° , then test the opposite direction.
- ④ Repeat steps ② and ③ three times each and calculate the average values.



1696MS10

(4) Evaluation

The measured drift angle should be within the following specifications.

Unit : Degree


Model	Standard	Maximum allowable	Remarks
R16-9	40 below	50	

8) SWING BEARING PLAY

- (1) Measure the swing bearing play using a dial gauge to check the wear of bearing races and balls.

(2) Preparation

- ① Check swing bearing mounting cap screws for loosening.
- ② Check the lubrication of the swing bearing. Confirm that bearing rotation is smooth and without noise.
- ③ Install a dial gauge on the track frame as shown, using a magnetic base.
- ④ Position the upperstructure so that the boom aligns with the tracks facing towards the front idlers.
- ⑤ Position the dial gauge so that its needle point comes into contact with the bottom face of the bearing outer race.
- ⑥ Bucket should be empty.




7-10(1) 140-7

(3) Measurement

- ① With the arm rolled out and bucket rolled in, hold the bottom face of the bucket to the same height of the boom foot pin. Record the dial gauge reading (h1).
- ② Lower the bucket to the ground and use it to raise the front idler 50 cm. Record the dial gauge reading (h2).
- ③ Calculate bearing play (H) from this data (h1 and h2) as follows.


$$H = h2 - h1$$

Measurement : h1



1696MS18

Measurement : h2



1696MS11

(4) Evaluation

The measured drift should be within the following specifications.

Unit : mm

Model	Standard	Maximum allowable	Remarks
R16-9	0.5 ~ 1.2	2.4	

9) HYDRAULIC CYLINDER CYCLE TIME

- (1) Measure the cycle time of the boom, standard arm, and standard bucket cylinders.

(2) Preparation

- ① To measure the cycle time of the boom cylinders:
With the arm rolled out and the empty bucket rolled out, lower the bucket to the ground, as shown.
- ② To measure the cycle time of the arm cylinder:
With the empty bucket rolled in, position the arm so that it is vertical to the ground. Lower the boom until the bucket is 0.5m above the ground.
- ③ To measure the cycle time of the bucket cylinder:
The empty bucket should be positioned at midstroke between roll-in and roll-out, so that the sideplate edges are vertical to the ground.
- ④ Keep the hydraulic oil temperature at $50 \pm 5^\circ\text{C}$.

(3) Measurement

- ① To measure cylinder cycle times.


- Boom cylinders

Measure the time it takes to raise the boom, and the time it takes to lower the boom. To do so, position the boom at one stroke end then move the control lever to the other stroke end as quickly as possible.


- Arm cylinder

Measure the time it takes to roll in the arm, and the time it takes to roll out the arm. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.


Boom cylinder



Arm cylinder



Bucket cylinder



1696MS12

- Bucket cylinders

Measure the time it takes to roll in the bucket, and the time it takes to roll out the bucket. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.

- Repeat each measurement 3 times and calculate the average values.

(4) Evaluation

The average measured time should meet the following specifications.

Unit : Seconds


Model	Function	Standard	Maximum allowable	Remarks
R16-9	Boom raise	2.4 ± 0.4	3.0	
	Boom lower	2.4 ± 0.4	3.0	
	Arm in	2.4 ± 0.4	3.0	
	Arm out	1.7 ± 0.4	2.3	
	Bucket load	3.0 ± 0.4	3.7	
	Bucket dump	2.2 ± 0.4	2.8	
	Boom swing (LH)	4.8 ± 0.4	5.9	
	Boom swing (RH)	3.5 ± 0.4	4.3	
	Dozer up (raise)	1.6 ± 0.3	1.9	
	Dozer down (lower)	1.9 ± 0.3	2.2	

10) DIG FUNCTION DRIFT CHECK

- (1) Measure dig function drift, which can be caused by oil leakage in the control valve and boom, standard arm, and standard bucket cylinders, with the loaded bucket. When testing the dig function drift just after cylinder replacement, slowly operate each cylinder to its stroke end to purge air.

(2) Preparation

- ① Load bucket fully. Instead of loading the bucket, weight (W) of the following specification can be used.
 - $W = M^3 \times 1.5$Where :
 M^3 = Bucket heaped capacity(m^3)
1.5= Soil specific gravity
- ② Position the arm cylinder with the rod 20 to 30mm extended from the fully retracted position.
- ③ Position the bucket cylinder with the rod 20 to 30 mm retracted from the fully extended position.
- ④ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin.
- ⑤ Keep the hydraulic oil temperature at $50 \pm 5^\circ\text{C}$.



1696MS13

(3) Measurement

- ① Stop the engine.
- ② Five minutes after the engine has been stopped, measure the changes in the positions of the boom, arm and bucket cylinders.
- ③ Repeat step ② three times and calculate the average values.

(4) Evaluation

The measured drift should be within the following specifications.

Unit : mm / 5 min

Model	Drift to be measured	Standard	Maximum allowable	Remarks
R16-9	Boom cylinder	10 below	20	
	Arm cylinder	20 below	30	
	Bucket cylinder	20 below	30	

11) CONTROL LEVER OPERATING FORCE

- (1) Use a spring scale to measure the maximum resistance of each control lever at the middle of the grip.

(2) Preparation

- ① Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.

(3) Measurement

- ① Start the engine.
- ② Operate each boom, arm, bucket and swing lever at full stroke and measure the maximum operating force for each.
- ③ Lower the bucket to the ground to raise one track off the ground. Operate the travel lever at full stroke and measure the maximum operating force required. When finished, lower the track and then jack-up the other track.
- ④ Repeat steps ② and ③ three times and calculate the average values.

(4) Evaluation

The measured operating force should be within the following specifications.

Unit : kgf

Model	Kind of lever	Standard	Maximum allowable	Remarks
R16-9	Boom lever	1.4 or below	1.9	
	Arm lever	1.4 or below	1.9	
	Bucket lever	1.4 or below	1.9	
	Swing lever	1.4 or below	1.9	
	Travel lever	2.0 or below	2.5	

12) CONTROL LEVER STROKE

(1) Measure each lever stroke at the lever top using a ruler.

※ When the lever has play, take a half of this value and add it to the measured stroke.

(2) Preparation

Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.

(3) Measurement

- ① Stop the engine.
- ② Measure each lever stroke at the lever top from neutral to the stroke end using a ruler.
- ③ Repeat step ② three times and calculate the average values.

(4) Evaluation

The measured drift should be within the following specifications.

Unit : kgf

Model	Kind of lever	Standard	Maximum allowable	Remarks
R16-9	Boom lever	87 ± 10	109	
	Arm lever	87 ± 10	109	
	Bucket lever	87 ± 10	109	
	Swing lever	87 ± 10	109	
	Travel lever	86 ± 10	105	

13) PILOT PRIMARY PRESSURE

(1) Preparation

- ① Stop the engine.
- ② Loosen the cap of screw coupling at the fitting near pilot pump and connect pressure gauge.
- ③ Start the engine and check for oil leakage from the port.
- ④ Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.

(2) Measurement


- ① Measure the primary pilot pressure.

(3) Evaluation

The average measured pressure should meet the following specifications:

Unit : kgf / cm^2

Model	Standard	Remarks
R16-9	30 ± 5	




1696MS14

15) MAIN PUMP DELIVERY PRESSURE

(1) Preparation

- ① Stop the engine.
- ② To measure the main pump pressure.
Loosen the cap of screw coupling and connect pressure gauge to the main pump gauge port(G1, G2, G3) as shown.
- ③ Start the engine and check for oil leakage from the port.
- ④ Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.



(2) Measurement

- ① Measure the main pump delivery pressure at high idle.

1696MS15

(3) Evaluation

The average measured pressure should meet the following specifications.


Unit : kgf / cm^2

Model	Engine speed	Standard	Allowable limits	Remarks
R16-9	High idle	20 ± 5	-	

16) SYSTEM PRESSURE REGULATOR RELIEF SETTING

(1) Preparation

- ① Stop the engine.
- ② To measure the system relief pressure.
Loosen the cap of screw coupling and connect pressure gauge to the main pump gauge port(G1, G2, G3) as shown.
- ③ Start the engine and check for oil leakage from the port.
- ④ Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.



(2) Measurement

- ① Slowly operate each control lever of boom, arm and bucket functions at full stroke over relief and measure the pressure.
- ② In the swing function, place bucket against an immovable object and measure the relief pressure.
- ③ In the travel function, lock undercarriage with an immovable object and measure the relief pressure.

1696MS15

(3) Evaluation

The average measured pressure should be within the following specifications.

Unit : kgf / cm^2

Model	Function to be tested	Standard
R16-9	Boom, Arm, Bucket	210 ± 10
	Travel	210 ± 10
	Swing	170 ± 10

GROUP 2 MAJOR COMPONENT

1. MAIN PUMP

Before inspection, wash the parts well and dry them completely.


Inspect the principal parts with care and replace them with new parts when any abnormal wear exceeding the allowable limit or damage considered harmful is found.

Replace the seal also when any remarkable deformation and damage are found.

1) INSPECTION POINTS WHEN DISASSEMBLED


Part	Extent of the damage	Inspection standard	Action
Shaft (3)	Excessive wear on the seal surface.	Worn depth : 0.025 mm or more	Replace the shaft.
Valve plate (5)	Excessive wear or damages on the sliding surface.	Worn depth : 0.020 mm or more	Replace the cylinder barrel kit.
Cylinder barrel (4)	Excessive wear or damages on the sliding surface.	Worn depth : 0.020 mm or more	Replace the cylinder barrel kit.
	Clearance between the pistons.	0.050 mm or more	Replace the cylinder barrel kit.
Piston (6), Shoe (7)	Wear of joint section	Play between the shoe and the piston. 0.2 mm or more by hand operation.	Replace the cylinder barrel kit.
Seals (O-rings, gasket, etc.)	Damage, excessive rust	-	Replace each part.

Installation part of oil seal




Piston assembly

Cylinder barrel



Shoe



R27Z96MC01

2) TROUBLESHOOTING AND COUNTERMEASURE

No.	Trouble	Possible cause	Countermeasure
1	Overload to engine	<ul style="list-style-type: none"> Speed is higher than standard Setting pressure is higher than specifications Damage of internal parts of pump 	<ul style="list-style-type: none"> Readjust it as standard Readjust it as spec Repair or replace
2	Low pump flow or low pressure	<ul style="list-style-type: none"> Speed down of engine Wrong coupling Damage of internal parts of pump 	<ul style="list-style-type: none"> Readjust of engine speed Repair or replace Repair or replace
3	Abnormal noise or abnormal vibration (cavitations)	<ul style="list-style-type: none"> Air in the oil Water in the oil Clog of suction filter High suction pressure Damage of piston shoe Installation condition is no good Wrong coupling 	<ul style="list-style-type: none"> Check piping Bleed the air in the hydraulic circuit Replace oil Clean or replace Correction Replace Correction Replace
4	Oil leakage	<ul style="list-style-type: none"> Damage of O-ring or packing Loosened plug Leaking from oil seal 	<ul style="list-style-type: none"> Replace Tight up Replace Replace of oil seal

2. MAIN CONTROL VALVE

Part name	Inspection item	Criteria & measure
Block	<ul style="list-style-type: none"> Existence of scratch, rusting or corrosion. 	<ul style="list-style-type: none"> In case of damage in following section, replace part. Sliding sections of casing fore and spool, especially land sections applied with holded pressure. Seal pocket section where spool is inserted. Seal section of port where O-ring contacts. Seal section of each relief valve for main, travel, and port. Other damages that may damage normal functions.
Spool	<ul style="list-style-type: none"> Existence of scratch, gnawing, rusting or corrosion. O-ring seal sections at both ends. Insert spool in casing hole, rotate and reciprocate it. 	<ul style="list-style-type: none"> Replacement when its outside sliding section has scratch (Especially on seals-contacting section). Replacement when its sliding section has scratch. Correction or replacement when O-ring is damaged or when spool does not move smoothly.
Poppet	<ul style="list-style-type: none"> Damage of poppet or spring Insert poppet into casing and function it. 	<ul style="list-style-type: none"> Correction or replacement when sealing is incomplete. Normal when it can function lightly without being caught.
Around spring	<ul style="list-style-type: none"> Rusting, corrosion, deformation or breaking of spring, spring seat, plug or cover. 	<ul style="list-style-type: none"> Replacement for significant damage.
Around seal for spool	<ul style="list-style-type: none"> External oil leakage. Rusting, corrosion or deformation of seal plate. 	<ul style="list-style-type: none"> Correction or replacement. Correction or replacement.
Main relief valve, port relief valve & Anti cavitation valve	<ul style="list-style-type: none"> External rusting or damage. Contacting face of valve seat. Contacting face of poppet. Abnormal spring. O-rings, back up rings and seals. 	<ul style="list-style-type: none"> Replacement. Replacement when damaged. Replacement when damaged. Replacement. 100% replacement in general.






3. SWING MOTOR

1) POSSIBLE REASONS FOR THE TROUBLE AND ITS COUNTERMEASURES

Trouble	Possible reasons		Countermeasure
Motor does not move. The supplied pressure is enough.	Relief valve	Setting pressure is too low.	Replace the relief valve assembly.
		Faulty operation.	
	Hydraulic motor	Burned inner parts.	Replace the hydraulic motor assembly.
		Too much internal leakage.	
	Reduction gear	Damage to the gears.	Replace the reduction gear assembly.
	Overload	-	Remove the overload.
Insufficient torque	Relief valve	Setting pressure is too low.	Replace the relief valve assembly.
		Faulty operation.	
	Hydraulic motor	Burned sliding parts.	Replace the hydraulic motor assembly.
		Too much internal leakage.	
	Reduction gear	Damage to the gears.	Replace the pinion kit, carrier kit.
		Damage to bearings.	
Abnormal noise	Cavitation noise	Insufficient flow.	Adjust the piping.
	Hydraulic motor	Damage to sliding parts.	Replace the hydraulic motor assembly.
		Damage to the gears.	
	Reduction gear	Damage to bearings	Replace the pinion kit, carrier kit.
		Damage to the gear surface.	
Oil leakage	Body gasket	Damage to O-rings.	Replace the O-ring
		Loose bolts.	Re-tighten the loose bolts.
	Pinion gear	Damage to oil seal.	Replace the pinion kit.
Delay in start up, or delay in stopping	Relief valve	Faulty operation.	Replace the relief valve assembly.
	Check valve	Internal leakage.	Replace the body H kit.
Excessive heat generation	Hydraulic motor	Burned or damaged sliding parts.	Replace the hydraulic motor assembly.
	Reduction gear	Damage to the gears.	Replace the pinion kit, carrier kit.
		Damage to bearings	

2) STANDARD FOR PARTS INSPECTION

(1) Reduction gear section

Part	Extent of the damage	Inspection standard	Action
A internal gear	Excessive wear of the surface	Pitching area 5% or more of the gear surface 	Replace the pinion kit.
Carrier 1	Damage to spline section	By visual	Replace the carrier kit.
S1 gear b1 gear	Excessive wear of the surface	Pitching area 5% or more of the gear surface 	Replace the carrier kit.
	Excessive wear of the bearing surface	By visual pitching, flaking 	
Ring	Excessive wear of the bearing surface	By visual pitching, flaking 	Replace the carrier kit.
Roller	Excessive wear of the bearing surface	By visual pitching, flaking 	Replace the carrier kit.
Other (screw, etc.)	Damage, excessive rust	-	Replace each part.

(2) Hydraulic motor section

Part	Extent of the damage	Inspection standard	Action
Shaft	Excessive wear of the spline section	Worn depth : 25 μ m or more	Replace the hydraulic motor assembly.
Cylinder barrel	Excessive wear to the sliding surface of the valve plate	Worn depth : 20 μ m or more	Replace the cylinder barrel kit.
Valve plate	Excessive wear to the sliding surface of the cylinder barrel	Worn depth : 20 μ m or more	Replace the cylinder barrel kit.
Piston shoe	Wear of joint section of shoe	Play of piston and shoe : 0.3 mm or more by hand operation	Replace the cylinder barrel kit.
Swash plate	Excessive wear to the sliding surface of the shoe	Worn depth : 0.1 mm or more	Replace the swash plate kit.
Other (screw, etc.)	Damage, excessive rust	-	Replace each part.

4. TRAVEL MOTOR

1) MAINTENANCE STANDARD FOR TRAVEL MOTOR

Travel motors basically don't require maintenance except changing the reducer lubricant. Don't disassemble the motor unless there are problem with it. Refer to the following standards for parts (kits) replacement.

(1) Reducer

No.	Part name	Point to be checked	Standard	Action
1	Body (internal gear)	Engaging tooth surface with B1 and B2 gears	No pitching with 5% or greater (ratio of engaging area to tooth surface) No abnormal damage	Replace
2	Carrier 2	Spline tooth surface	No abnormal damage, wear	Replace whole carrier 2 kit
		Loose of B2 pins	No loose by hand	
3	B1 gears	Tooth surface	No pitching with 5% or greater (ratio of engaging area to tooth surface) No abnormal damage	Replace
		Needle rolling contact surface	No flaking and pitching	
4	B2 gears	Tooth surface	No pitching with 5% or greater (ratio of engaging area to tooth surface) No abnormal damage	Replace whole carrier 2 kit
		Needle rolling contact surface	No flaking and pitching	
5	S1 gear	Tooth surface	No pitching with 5% or greater (ratio of engaging area to tooth surface) No abnormal damage	Replace whole carrier 2 kit
6	S2 gear	Engaging tooth surface with B2 gears	No pitching with 5% or greater (ratio of engaging area to tooth surface) No abnormal damage	Replace
		Spline tooth surface	No abnormal damage, wear	
7	B2 pins	Needle rolling contact surface	No flaking and pitching	Replace whole carrier 2 kit
8	Floating seals	Seat surface	No abnormal damage, wear	Replace
		O-ring surface	No damage, deformation, and hardening	
9	Angular ball bearings	Rolling contact surface	No abnormal damage, flaking	Replace
10	Needles	Rolling contact surface	No flaking and pitching	Replace whole carrier 2 kit
11	O-rings	Surface, hardness	No damage, deformation, and hardening	Replace

(2) Hydraulic valve and motor




No.	Part name	Point to be checked	Standard	Action
12	Body 1	Spool sliding contact surface	No abnormal damage, wear	Replace whole body 1 kit
13	Counter valve spool Two-speed spool Shuttle spool	Body 1 sliding contact surface	No abnormal damage, wear	Replace whole body 1 kit
14	Body 2	Spline tooth surface	No abnormal damage, wear	Replace whole body 2 kit
		Control piston sliding contact surface	No abnormal damage, wear Clearance between piston and body 2 is 0.023 mm or smaller	
		Swash plate installation surface	No abnormal damage, wear	
		Ball sliding contact surface	No abnormal damage, wear	
15	Shaft	Spline tooth surface	No abnormal damage, wear	Replace shaft kit
		Oil seal sliding contact surface	No abnormal damage, wear (0.025 mm or greater)	
16	Cylinder barrel	Piston sliding contact surface	No abnormal damage, wear Clearance between piston and cylinder barrel is 0.030 mm or smaller	Replace cylinder barrel kit
		Valve plate sliding contact surface	No abnormal damage, wear (0.020 mm or greater)	Lap or replace cylinder barrel kit
17	Valve plate	Cylinder barrel sliding contact surface	No abnormal damage, wear (0.020 mm or greater)	Lap or replace cylinder barrel kit
18	Pistons Shoes	Cylinder barrel sliding contact surface	No abnormal damage, wear (0.020 mm or greater)	Replace cylinder barrel kit
		Swash plate sliding contact surface	No abnormal damage, wear (0.020 mm or greater)	Lap or replace cylinder barrel kit
		Loose of shoe calking part	Loose is smaller than 0.3 mm	Replace cylinder barrel kit
19	Shoe holder	Barrel holder sliding contact surface	No abnormal damage, wear	Replace cylinder barrel kit
20	Barrel holder	Spline tooth surface	No abnormal damage, wear	Replace cylinder barrel kit
		Shoe holder sliding contact surface	No abnormal damage, wear	
21	Swash plate	Shoe sliding contact surface	No abnormal damage, wear (0.020 mm or greater)	Lap or replace
		Ball sliding contact surface	No abnormal damage, wear	Replace
22	Control piston	Body 2 sliding contact surface	Clearance between piston and body 2 is 0.023 mm or smaller	Replace body 2 kit
23	Oil seal	Lip surface	No abnormal damage, wear and deformation	Replace
24	Ball bearing	Rolling contact surface	No abnormal damage, flaking	Replace
25	Springs	Surface	No crack	Replace
26	O-rings	Surface and hardness	No damage, deformation, and hardening	Replace

2) FAILURE DIAGNOSIS OF TRAVEL MOTOR

Failure detail	Major causes	Countermeasure
Doesn't start	Operating defect in hydraulic equipment except travel motors	Inspect and repair or replace each equipment. Check that normal working pressure is supplied to the motor inlet port.
	Defect in reducer - Damage of inner parts	Replace the damaged part (kit).
	Defect in hydraulic motor - Oil leakage due to abnormal wear of the sliding parts - Damage of inner parts	Replace the worn part (kit). Replace the damaged part (kit).
	Defect in hydraulic valve - Spool doesn't move Foreign object is caught in the spool sliding part.	Remove the foreign object. In case of much leakage, replace the body 1 kit.
	Choke is clogged	Remove the foreign object.
Doesn't stop or stop slowly	Defect in hydraulic valve - Spool doesn't return Foreign object is caught in the spool sliding part.	Remove the foreign object. In case of much leakage, replace the body 1 kit.
	Choke is clogged. Spring is damaged. - Check valve doesn't close due to foreign object being caught on the seat.	Remove the foreign object. Replace the body 1 kit. Remove the foreign object. In case of much leakage, replace the body 1 kit.
Rotating speed is slow	Prescribed flow rate is not supplied to the motor due to operating defect in the pump.	Inspect and repair or replace the pump.
	Volumetric efficiency declines due to defect in the motor. - Abnormal wear of sliding parts	Replace the worn part (kit).
	Volumetric efficiency declines due to defect in the hydraulic valve. - Abnormal wear of main spool and two speed spool sliding part	Replace body 1 kit.

Failure detail	Major causes	Countermeasure
Doesn't change to two speed	Operating defect in hydraulic equipment except travel motors	Inspect and repair or replace each equipment. Check that normal pressure is supplied to the pilot port.
	Defect in the hydraulic valve - Two speed spool doesn't move due to foreign object being caught in the spool sliding part. - Choke in the two speed pilot line is clogged.	Remove the foreign object. In case of much leakage, replace the body 1 kit. Remove the foreign object.
	Defect in the hydraulic motor - Control piston doesn't move. Foreign object is caught in the piston sliding part.	Remove the foreign object. In case of much leakage, replace the body 2 kit.
	Oil leakage due to abnormal wear of the sliding part. Oil leakage due to damage of O-ring located between body 1 and body 2.	Replace the worn part (kit). Replace the O-ring.
Doesn't change to one speed	Operating defect in hydraulic equipment except travel motors	Inspect and repair or replace each equipment. Check that normal pressure is supplied to the pilot port.
	Defect in the hydraulic valve - Two speed spool doesn't move. Foreign object is caught in the spool sliding part. Damage of spring - Choke in the two speed pilot line is clogged.	Remove the foreign object. In case of much leakage, replace the body 1 kit. Replace the body 1 kit. Remove the foreign object.
Tracking deviation	Same as No.3, 4 and 5	-
Oil leakage	Oil leakage due to damage of O-rings. - Damage of O-ring located in the reducer cover. - Damage of O-rings located between body 1 and body 2.	Replace the O-ring. Replace the O-ring.
	Oil leakage from the floating seals - Abnormal wear of the seat surface or damage of the O-ring. - Pressure in the reducer casing rises due to damage of the oil seal.	Replace the floating seal. Replace the oil seal.

5. TURNING JOINT

Parts Name		Check Points	Measures
Body, Stem	Sliding surface with sealing sections.	Plating worn or peeled due to seizure or contamination.	Replace
	Sliding surface between body and stem other than sealing section.	• Worn abnormality or damaged more than 0.1 mm (0.0039 in) in depth due to seizure contamination.	Replace
		• Damaged more than 0.1 mm (0.0039 in) in depth.	Smooth with oilstone.
	Sliding surface with thrust plate.	• Worn more than 0.5 mm (0.02 in) or abnormality.	Replace
		• Worn less than 0.5 mm (0.02 in).	Smooth
		• Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).	Smooth
Cover	Sliding surface with thrust plate.	• Worn more than 0.5 mm (0.02 in) or abnormality.	Replace
		• Worn less than 0.5 mm (0.02 in).	Smooth
		• Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).	Replace
Seal set	-	• Extruded excessively from seal groove square ring. 	Replace
	-	• Slipper ring 1.5 mm (0.059 in) narrower than seal groove, or narrower than back ring. 	Replace
	-	• Worn more than 0.5 mm (0.02 in) ~ 1.5 mm (MAX.) (0.059 in) 	Replace


6. CYLINDER

Part name	Inspecting section	Inspection item	Remedy
Piston rod	• Neck of rod pin	• Presence of crack	• Replace
	• Weld on rod hub	• Presence of crack	• Replace
	• Stepped part to which piston is attached.	• Presence of crack	• Replace
	• Threads	• Presence of crack	• Recondition or replace
	• Plated surface	• Plating is not worn off to base metal.	• Replace or replate
		• Rust is not present on plating.	• Replace or replate
		• Scratches are not present.	• Recondition, replate or replace
Cylinder tube	• Rod	• Wear of O.D.	• Recondition, replate or replace
	• Bushing at mounting part	• Wear of I.D.	• Replace
	• Weld on bottom	• Presence of crack	• Replace
	• Weld on head	• Presence of crack	• Replace
	• Weld on hub	• Presence of crack	• Replace
	• Tube interior	• Presence of faults	• Replace if oil leak is seen
Gland	• Bushing	• Flaw on inner surface	• Replace if flaw is deeper than coating

GROUP 3 TRACK AND WORK EQUIPMENT

1. TRACK SHOE

1) RUBBER SHOE SPEC




R5576MC17

Unit : mm

No	Check item	Criteria		Remedy
		Standard size	Repair limit	
1	Link pitch	48	50	Replace
2	Height of grouser	25	5	
3	Width of link	30	40	

2. IDLER




R27Z96MC23

Unit : mm

No	Check item		Criteria		Remedy
			Standard size	Repair limit	
1	Outside diameter of flange	Rubber	250	-	Rebuild or replace
2	Outside diameter of thread	Rubber	210	204	
3	Width of flange		23	17	

3. TRACK ROLLER




R35Z76MC19

Unit : mm

No	Check item		Criteria		Remedy
			Standard size	Repair limit	
1	Outside diameter of flange	Rubber	100	-	Rebuild or replace
2	Outside diameter of thread	Rubber	70	64	
3	Width of flange		22	16	

4. TENSION CYLINDER




1696MS16

Unit : mm

No	Check item	Criteria					Remedy
			Standard size		Repair limit		
1	Vertical width of idler guide	Track frame	51		53		Rebuild
		Idler support	50		48		Rebuild or replace
2	Horizontal width of idler guide	Track frame	151		155		Rebuild
		Idler guide	150		146		Rebuild or replace
3	Recoil spring	Standard size			Repair limit		Replace
		Free length	Installed length	Installed load	Free length	Installed load	
		261	223	880 kg	-	700 kg	

5. SPROCKET




R27Z96MC22

Unit : mm

No	Check item	Criteria		Remedy
		Standard size	Repair limit	
1	Wear out of sprocket tooth lower side diameter	253	247	Rebuild or Replace
2	Wear out of sprocket tooth upper side diameter	292	-	
3	Wear out of sprocket tooth upper side width	16	-	
4	Wear out of sprocket tooth lower side width	22	16	

6. WORK EQUIPMENT



1696MS17

Unit : mm

Mark	Measuring point (Pin and Bushing)	Normal value	Pin		Bushing		Remedy & Remark
			Recomm. service limit	Limit of use	Recomm. service limit	Limit of use	
A	Boom rear	35	34	33.5	35.5	36	Replace
B	Boom cylinder head	30	29	28.5	30.5	31	"
C	Boom cylinder rod	30	29	28.5	30.5	31	"
D	Arm cylinder head	30	29	28.5	30.5	31	"
E	Boom front	30	29	28.5	30.5	31	"
F	Arm cylinder rod	30	29	28.5	30.5	31	"
G	Bucket cylinder head	30	29	28.5	30.5	31	"
H	Arm link	30	29	28.5	30.5	31	"
I	Bucket and arm link	30	29	28.5	30.5	31	"
J	Bucket cylinder rod	30	29	28.5	30.5	31	"
K	Bucket link	30	29	28.5	30.5	31	"
L	Boom swing post	45	44	43.5	45.5	46	"
M	Boom swing cylinder	30	29	28.5	30.5	31	"
N	Blade cylinder	30	29	28.5	30.5	31	"
O	Blade and frame link	30	29	28.5	30.5	31	"

SECTION 7 DISASSEMBLY AND ASSEMBLY

Group 1	Precaution	7-1
Group 2	Tightening Torque	7-4
Group 3	Pump Device	7-7
Group 4	Main Control Valve	7-22
Group 5	Swing Device	7-36
Group 6	Travel Device	7-54
Group 7	RCV Lever	7-84
Group 8	Turning Joint	7-98
Group 9	Boom, Arm and Bucket Cylinder	7-103
Group 10	Undercarriage	7-123
Group 11	Work Equipment	7-134


SECTION 7 DISASSEMBLY AND ASSEMBLY

GROUP 1 PRECAUTIONS

1. REMOVAL WORK

- 1) Lower the work equipment completely to the ground.
If the coolant contains antifreeze, dispose of it correctly.
- 2) After disconnecting hoses or tubes, cover them or fit blind plugs to prevent dirt or dust from entering.
- 3) When draining oil, prepare a container of adequate size to catch the oil.
- 4) Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake when assembling.
- 5) To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors.
- 6) Fit wires and hoses with tags to show their installation position to prevent any mistake when installing.
- 7) Check the number and thickness of the shims, and keep in a safe place.
- 8) When raising components, be sure to use lifting equipment of ample strength.
- 9) When using forcing screws to remove any components, tighten the forcing screws alternately.
- 10) Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.
- 11) When removing hydraulic equipment, first release the remaining pressure inside the hydraulic tank and the hydraulic piping.
- 12) If the part is not under hydraulic pressure, the following corks can be used.

Nominal number	Dimensions		
	D	d	L
06	6	5	8
08	8	6.5	11
10	10	8.5	12
12	12	10	15
14	14	11.5	18
16	16	13.5	20
18	18	15	22
20	20	17	25
22	22	18.5	28
24	24	20	30
27	27	22.5	34



2. INSTALL WORK

- 1) Tighten all bolts and nuts (sleeve nuts) to the specified torque.
- 2) Install the hoses without twisting or interference.
- 3) Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
- 4) Bend the cotter pin or lock plate securely.
- 5) When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2-3 drops of adhesive.
- 6) When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
- 7) Clean all parts, and correct any damage, dents, burrs, or rust.
- 8) Coat rotating parts and sliding parts with engine oil.
- 9) When press fitting parts, coat the surface with antifriction compound (LM-P).
- 10) After installing snap rings, check that the snap ring is fitted securely in the ring groove (Check that the snap ring moves in the direction of rotation).
- 11) When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
- 12) When using eyebolts, check that there is no deformation or deterioration, and screw them in fully.
- 13) When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- 14) When operating the hydraulic cylinders for the first time after repairing and reassembling the hydraulic cylinders, pumps, or other hydraulic equipment or piping, always bleed the air from the hydraulic cylinders as follows:
 - (1) Start the engine and run at low idling.
 - (2) Operate the control lever and actuate the hydraulic cylinder 4-5 times, stopping 100 mm before the end of the stroke.
 - (3) Next, operate the piston rod to the end of its stroke to relieve the circuit. (The air bleed valve is actuated to bleed the air.)
 - (4) After completing this operation, raise the engine speed to the normal operating condition.
 - ※ If the hydraulic cylinder has been replaced, carry out this procedure before assembling the rod to the work equipment.Carry out the same operation on machines that have been in storage for a long time after completion of repairs.

3. COMPLETING WORK

- 1) If the coolant has been drained, tighten the drain valve, and add water to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
- 2) If the hydraulic equipment has been removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- 3) If the piping or hydraulic equipment, such as hydraulic cylinders, pumps, or motors, have been removed for repair, always bleed the air from the system after reassembling the parts.
- 4) Add the specified amount of grease (Molybdenum disulphide grease) to the work equipment related parts.

GROUP 2 TIGHTENING TORQUE

1. MAJOR COMPONENTS

No.	Descriptions		Bolt size	Torque	
				kgf · m	lbf · ft
1	Engine	Engine mounting bolt (engine-bracket)	M10 × 1.25	7.4±1.5	53.5±11.0
2		Engine mounting bolt (bracket-frame)	M12 × 1.75	12.3±1.5	89±11.0
3		Radiator mounting bolt, nut	M 8 × 1.25	1.17±0.1	8.5±0.7
4		Coupling mounting bolt	M10 × 1.5	5.15±0.25	37.2±1.8
5	Hydraulic system	Main pump mounting bolt	M12 × 1.75	10±1.0	72±7.2
6		Main control valve mounting bolt	M10 × 1.5	6.9±1.4	50±10.0
7		Fuel tank mounting bolt	M10 × 1.5	6.9±1.4	50±10.0
8		Hydraulic oil tank mounting bolt	M10 × 1.5	6.9±1.4	50±10.0
9		Turning joint mounting bolt, nut	M10 × 1.5	6.9±1.4	50±10.0
10	Power train system	Swing motor mounting bolt	M12 × 1.75	12.8±3.0	93±22.0
11		Swing bearing upper mounting bolt	M12 × 1.75	12.8±3.0	93±22.0
12		Swing bearing lower mounting bolt	M12 × 1.75	12.8±3.0	93±22.0
13		Travel motor mounting bolt	M10 × 1.5	6.9±1.4	50±10.0
14		Sprocket mounting bolt	M10 × 1.5	6.9±0.7	50±5.1
15	Under carriage	Track roller mounting bolt	M12 × 1.75	12.3±1.2	89±8.7
17	Others	Counterweight mounting bolt	M16 × 2.0	29.7±4.5	215±32.5
18		Canopy mounting bolt, nut	M12 × 1.75	12.8±3.0	92±22.0
19		Operator's seat mounting bolt	M 8 × 1.25	1.17±0.1	8.5±0.7

※ For tightening torque of engine and hydraulic components, see each component disassembly and assembly.

2. TORQUE CHART

Use following table for unspecified torque.

1) BOLT AND NUT

(1) Coarse thread

Bolt size	8T		10T	
	kgf · m	lbf · ft	kgf · m	lbf · ft
M 6 × 1.0	0.85 ~ 1.25	6.15 ~ 9.04	1.14 ~ 1.74	8.2 ~ 12.6
M 8 × 1.25	2.0 ~ 3.0	14.5 ~ 21.7	2.7 ~ 4.1	19.5 ~ 29.7
M10 × 1.5	4.0 ~ 6.0	28.9 ~ 43.4	5.5 ~ 8.3	39.8 ~ 60
M12 × 1.75	7.4 ~ 11.2	53.5 ~ 81.0	9.8 ~ 15.8	70.9 ~ 114
M14 × 2.0	12.2 ~ 16.6	88.2 ~ 120	16.7 ~ 22.5	121 ~ 163
M16 × 2.0	18.6 ~ 25.2	135 ~ 182	25.2 ~ 34.2	182 ~ 247
M18 × 2.5	25.8 ~ 35.0	187 ~ 253	35.1 ~ 47.5	254 ~ 344
M20 × 2.5	36.2 ~ 49.0	262 ~ 354	49.2 ~ 66.6	356 ~ 482
M22 × 2.5	48.3 ~ 63.3	349 ~ 458	65.8 ~ 98.0	476 ~ 709
M24 × 3.0	62.5 ~ 84.5	452 ~ 611	85.0 ~ 115	615 ~ 832
M30 × 3.0	124 ~ 168	898 ~ 1214	169 ~ 229	1223 ~ 1656
M36 × 4.0	174 ~ 236	1261 ~ 1704	250 ~ 310	1808 ~ 2242

(2) Fine thread

Bolt size	8T		10T	
	kgf · m	lbf · ft	kgf · m	lbf · ft
M 8 × 1.0	2.2 ~ 3.4	15.9 ~ 24.6	3.0 ~ 4.4	21.7 ~ 31.8
M10 × 1.2	4.5 ~ 6.7	32.5 ~ 48.5	5.9 ~ 8.9	42.7 ~ 64.4
M12 × 1.25	7.8 ~ 11.6	56.4 ~ 83.9	10.6 ~ 16.0	76.7 ~ 116
M14 × 1.5	13.3 ~ 18.1	96.2 ~ 131	17.9 ~ 24.1	130 ~ 174
M16 × 1.5	19.9 ~ 26.9	144 ~ 195	26.6 ~ 36.0	192 ~ 260
M18 × 1.5	28.6 ~ 43.6	207 ~ 315	38.4 ~ 52.0	278 ~ 376
M20 × 1.5	40.0 ~ 54.0	289 ~ 391	53.4 ~ 72.2	386 ~ 522
M22 × 1.5	52.7 ~ 71.3	381 ~ 516	70.7 ~ 95.7	511 ~ 692
M24 × 2.0	67.9 ~ 91.9	491 ~ 665	90.9 ~ 123	658 ~ 890
M30 × 2.0	137 ~ 185	990 ~ 1339	182 ~ 248	1314 ~ 1796
M36 × 3.0	192 ~ 260	1390 ~ 1880	262 ~ 354	1894 ~ 2562

2) PIPE AND HOSE (FLARE type)

Thread size (PF)	Width across flat (mm)	kgf · m	lbf · ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

3) PIPE AND HOSE (ORFS type)

Thread size (UNF)	Width across flat (mm)	kgf · m	lbf · ft
9/16-18	19	4	28.9
11/16-16	22	5	36.2
13/16-16	27	9.5	68.7
1-3/16-12	36	18	130
1-7/16-12	41	21	152
1-11/16-12	50	35	253

4) FITTING

Thread size	Width across flat (mm)	kgf · m	lbf · ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130
1"	41	21	152
1-1/4"	50	35	253

GROUP 3 PUMP DEVICE

1. REMOVAL AND INSTALL

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.


- (4) Loosen the drain plug under the hydraulic tank and drain the oil from the hydraulic tank.

- Hydraulic tank quantity : 20 l
(5.3 U.S.gal)

- (5) Disconnect hoses (71) and remove connectors (32, 33).
- (6) Disconnect pilot line hoses (70, 72) and remove connectors (10, 30, 32).
- (7) Remove socket bolts (54) and disconnect pump suction tube (9).

※ When pump suction tube is disconnected, the oil inside the piping will flow out, so catch it in oil pan.

- (8) Sling the pump assembly and remove the pump mounting bolts.
 - Weight : 17 kg (37 lb)
- ※ Pull out the pump assembly from housing. When removing the pump assembly, check that all the hoses have been disconnected.




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Remove the suction strainer and clean it.
- (3) Replace return filter with new one.
- (4) Remove breather and clean it.
- (5) After adding oil to the hydraulic tank to the specified level.
- (6) Bleed the air from the hydraulic pump.
 - ① Remove the air vent plug (1EA).
 - ② Tighten plug lightly.
 - ③ Start the engine, run at low idling, and check oil come out from plug.
 - ④ Tighten plug.
- (7) Start the engine, run at low idling (3~5 minutes) to circulate the oil through the system.
- (8) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2. MAIN PUMP


1) STRUCTURE (1/2)



1697PM01

1	Body S	14	Spring C	30	Ball bearing
3	Shaft	15	Spring T1	32	Oil seal
4	Cylinder barrel	18	Spring holder	33	Dish spring
6	Piston	19	Spring guide	34	Snap ring
7	Shoe	20	Pin	35	Snap ring
8	Shoe holder	21	Rod G	36	Snap ring
9	Barrel holder	23	Washer	39	O-ring
10	Swash plate	24	Retainer	42	Plug
11	Needle	25	Stopper pin A	43	O-ring
12	Ball	26	Stopper pin B	51	Plug

STRUCTURE (2/2)



1697PM02

2	Body H	49	Plug	67	Collar
5	Valve plate	56	Spring pin	68	Screw
13	Packing	60	Screw	69	O-ring
27	Pin	61	Nut	70	Washer
31	Needle bearing	62	Seal washer	71	O-ring
40	O-ring	65	Gear pump	72	O-ring
44	Screw	66	Coupling		


3. ASSEMBLE AND DISASSEMBLE

1) General precautions

- (1) Before disassembling, it is important to have fully understood the internal structure of the pump.
 - ※ The gasket (13), oil seal (32) and O-rings will be probably damaged when you disassemble it, so be sure to have prepared spares.
- (2) After having drained oil inside the pump, wash the pump and put it on a working bench covered with clean paper, cloth, or rubber mat for disassembling and assembling. Then, disassemble and assemble the pump slowly and carefully with necessary tools. Use care not to scratch even slightly, and take proper measures to prevent foreign matters from entering the assembly.

2) Tools

Tool name	Size	Quantity
Hexagon wrench	4, 6, 8 mm	1 each
Circlip player	For hole	1
Spanner wrench	13 mm	1
Torque wrench	45N (JIS B 4650) 90N (JIS B 4650)	1 1
Resin hammer	-	1
Special tooling for oil seal	See below	1
Seal kit	-	1 set
Grease	-	Small amount



Special tooling for oil seal


R27Z97MP98

3) DISASSEMBLING

(1) Disassembling of gear pump

Remove two screws (68) with spanner wrench 13 mm, and after that remove gear pump (65), collar (67) and coupling (66).


- ※ Coupling (66) and collar (67) may be attached with gear pump kit (65).



(2) Remove the adjustment screw


Loose hexagon nut (61) with spanner wrench 13 mm, then remove the adjustment screw (60) with hexagon wrench 4 mm.

- ※ Suggest you to measure the outside length of the adjustment screw. Because it is a good help when you readjust it after reassembling.



(3) Separation of body S and body H

Remove five screws (44) with hexagon wrench 8 mm.




- ※ If you tap the part of inserted spring of body H with hummer softly, it is easy for separation.




(4) Disassembling of body S kit

Remove spring T1 (15) from body S kit, then take off spring holder (18).




(5) Disassembling of body S kit

Remove cylinder barrel kit.



(6) Disassembling of body S kit


Remove swash plate (10) and two balls (12).



(7) Disassembling of body S kit

Remove stopper pin A (25), stopper pin B (26), dish springs (33), washer (23), rod G (21) and rod C (22).

- ※ The length of the stopper pin A and B is different. Pay attention not to swap when reassembling.
- ※ Refer to the parts list about number and position of washer (23).




(8) Disassembling of body S kit

Remove snap ring (34) from body S (1).




(9) Disassembling of body S kit

Tap the end of shaft (3) with hammer, then oil seal (32) and shaft with bearing (30) come off.



(10) Disassembling of body H kit


Remove spring guide (19) and valve plate (5) from body H.



(11) Disassembling of cylinder barrel kit

Remove shoe holder (8) on which piston shoe assemblies (6) and (7) are set and disassemble it in the order of barrel holder (9) and needle (11).

Also, take off snap ring (35), retainer (24), spring C (14) and retainer (24), which are set in the cylinder barrel (4) in this order.



4) ASSEMBLING

(1) Precautions during assembling



Reverse the above procedures for assembling.

When assembling, be very careful to wash parts in clean oil, to prevent dusts and water from adhering to parts entering assemblies and not to scratch on the sliding surfaces of all parts.

- ※ Apply small quantity of grease to the periphery of O-rings to be set in socket and spigot joints to prevent the O-rings from being damaged.

(2) Assembling of cylinder barrel kit

Set retainer (24), spring C (14), retainer (24) and snap ring (35) in the shaft center hole of cylinder barrel (4) in this order, and carefully set shoe holder (8), on which needle (11), barrel holder (9) and ten piston shoe assemblies have already been set, in cylinder barrel from the opposite side.





(3) Assembling of body S kit

Set shaft (3) with bearing (30), oil seal (32) and snap ring (34) in this order into body S (1).

- ※ Use new oil seal for assembling. Before assembling, apply a small quantity of grease to the periphery of oil seal lip and tap it together with the special tooling with hammer.


When assembling, put body S (1) onto body H (2) tentatively for easy work.



(4) Assembling of body S kit

Set each four dish springs (33) and washers (23) to stopper pin A (25) and stopper pin B (26), then set them into body S (1).


- ※ Pay attention to the direction of the dish washer and refer to the parts list about number and position of washers (23).
- ※ Pin A and pin B have different length. Set them to the original position. Otherwise, pump displacement changes, and engine stall or insufficient speed can occur.



(5) Assembling of body S kit

Set rod G (21) and rod C (22) into body S (1).


- ※ Pay attention to the direction of the rod G and rod C. (See cross section drawing for the direction.)



(6) Assembling of body S kit


Put two balls (12) in the hole of swash plate (10) and install it in body S.

※ Apply grease on the balls if they drop out.




(7) Assembling of body S kit

Assemble cylinder barrel kit into the body S (1).




(8) Assembling of body S kit

Set spring T1 (15) to spring holder (18), then set them together into the hole on swash plate (10).



(9) Assembling of body H kit


Set spring guide (19) in body H (2).



(10) Assembling of body H kit

Place valve plate (5) slowly on body H (2) by positioning it with spring pin (56).


- ※ V notch copper alloy side of valve plate slides with cylinder barrel (4) and be careful not to set the valve plate to a wrong direction.



(11) Assembling of body S kit with body H kit

Place O-ring (40) on body S.


- ※ Use new O-ring for assembling.



(12) Assembling of body S kit with body H kit

Set pin (20) and pin (27) on body S.


- ※ Pay attention to the position of each pin. Pin (27) has a hole.



(13) Assembling of body S kit with body H kit

Place O-ring (40) on body H.


- ※ Use new O-ring for assembling.



(14) Assembling of body S kit with body H kit

Place packing (13), position it with locating pin (27) on body S.

※ Use new packing for assembling.




(15) Assembling of body S kit with body H kit

Set two screws (M10×65) into the upper side two screw holes, and tighten them until the distance between body S and body H comes to 5 to 10 mm.

Then set three screws (44) into the three screw holes, after that, replace the upper side two screws (M10×65) to the regular size screws (44) and fix them.


· Tightening torque : 5.2~6.6 kgf · m
(37.6~47.7 lbf · ft)



(16) Installation of the adjusting screw

Fasten the adjusting screw (60) with hexagon wrench 4 mm, then adjust the outside length of adjusting screw and fix locknut (61) with spanner wrench 13 mm. At that time, change the seal washer (62) to new one.


· Tightening torque : 1.5~2.0 kgf · m
(10.8~14.5 lbf · ft)



(17) Installation of gear pump kit


Place O-ring (69, 71, 72) on the installation side of body H.

※ Use new O-ring for assembling.



(18) Installation of gear pump kit


Set collar (67) and coupling (66).



(19) Installation of gear pump kit

Install gear pump kit (65) and fix it by two screws (68) and washers (70) with spanner wrench 13 mm.

- Tightening torque : 2.0~2.4 kgf · m
(14.5~17.3 lbf · ft)



(20) Inspection of assembling

After completed the assembling of pump, make sure that pump shaft rotates smoothly by hand.



GROUP 4 MAIN CONTROL VALVE

1. REMOVAL AND INSTALL OF MOTOR

1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ **Escaping fluid under pressure can penetrate the skin causing serious injury.**
 - ※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect hydraulic hose.
- (5) Disconnect pilot line hoses.
- (6) Sling the control valve assembly and remove the control valve mounting bolt.
 - Weight : 25 kg (55 lb)
- (7) Remove the control valve assembly.

When removing the control valve assembly, check that all the piping have been disconnected.




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from below items.
 - ① Cylinder (boom, arm, bucket)
 - ② Swing motor
 - ③ Travel motor
 - ※ See each item removal and install.
- (3) Confirm the hydraulic oil level and recheck the hydraulic oil leak or not.




2. STRUCTURE (1/3)



1692MC02

- | | | |
|-----------------------------|-----------------------------|-----------------------------|
| 1 Dozer work block | 2-9 Cover-pilot | 4-7 O-ring |
| 1-1 Body-work | 2-10 Bolt-soc head w/washer | 4-8 Cover-pilot |
| 1-2 Spool assy | 3 Swing work block | 4-9 Bolt-soc head w/washer |
| 1-3 Poppet | 3-1 Body-work | 4-10 Plug |
| 1-4 Spring | 3-2 Spool assy | 4-11 O-ring |
| 1-5 O-ring | 3-3 Poppet | 4-12 Plug |
| 1-6 Plug | 3-4 Spring | 4-13 Piston |
| 1-7 O-ring | 3-5 O-ring | 4-14 O-ring |
| 1-8 Cover-pilot | 3-6 Plug | 4-15 Body-pilot |
| 1-9 Cover-pilot | 3-7 O-ring | 4-16 Bolt-soc head w/washer |
| 1-10 Bolt-soc head w/washer | 3-8 Cover-pilot | 4-17 Orifice |
| 2 Boom swing work block | 3-9 Cover-pilot | 4-18 Filter-coin type |
| 2-1 Body-work | 3-10 Bolt-soc head w/washer | 14 Relief valve |
| 2-2 Spool assy | 4 Connecting block | 16 Plug |
| 2-3 Poppet | 4-1 Body-work | 17 O-ring |
| 2-4 Spring | 4-2 Spool assy | 22 O-ring |
| 2-5 O-ring | 4-3 Poppet | 23 Bolt-tie |
| 2-6 Plug | 4-4 Spring | 24 Nut-hex |
| 2-7 O-ring | 4-5 O-ring | 25 Anticavitation valve |
| 2-8 Cover-pilot | 4-6 Plug | |


STRUCTURE (2/3)



1692MC03

5	PTO work block	6-2	Spool assy	7-4	Plug
5-1	Body-work	6-3	Poppet	7-5	O-ring
5-2	Spool assy	6-4	Spring	7-6	Cover-pilot
5-3	Poppet	6-5	O-ring	7-7	Cover-pilot
5-4	Spring	6-6	Plug	7-8	Bolt-soc head w/washer
5-5	O-ring	6-7	O-ring	8	Inlet work block
5-6	Plug	6-8	Cover-pilot	13	Relief valve
5-7	O-ring	6-9	Cover-pilot	15	Overload relief valve
5-8	Cover-pilot	6-10	Bolt-soc head w/washer	17	O-ring
5-9	Cover-pilot	7	Travel work block	18	O-ring
5-10	Bolt-soc head w/washer	7-1	Body work	19	O-ring
6	Arm work block	7-2	Spool assy		
6-1	Body-work	7-3	O-ring		

STRUCTURE (3/3)



1692MC04

9	Travel work block	10-8	Cover-pilot	12-3	Poppet	105	Spacer
9-1	Body-work	10-9	Cover-pilot	12-4	Spring	106	Ring-retaining
9-2	Spool assy	10-10	Bolt-soc head w/washer	12-5	O-ring	107	Spring A-lock valve
9-3	Poppet	11	Boom lock valve	12-6	Plug	108	Spring seat
9-4	Spring	11-1	Body-work	12-7	O-ring	109	Pin
9-5	O-ring	11-2	O-ring	12-8	Cover-pilot	110	Poppet
9-6	Plug	11-3	Plug	12-9	Cover-pilot	111	Ring-retaining
9-7	O-ring	11-4	Poppet	12-10	Bolt-soc head w/washer	112	O-ring
9-8	Cover-pilot	11-5	Spring	15	Overload relief valve	113	Guide-piston
9-9	Cover-pilot	11-6	Plug	17	O-ring	114	Piston A1
9-10	Bolt-soc head w/washer	11-7	O-ring	18	O-ring	115	Piston B
10	Boom work block	11-8	Plug	19	O-ring	116	O-ring
10-1	Body-work	11-9	O-ring	20	O-ring	117	Connector
10-2	Spool assy	11-10	O-ring	21	O-ring	118	Ball-steel
10-3	Poppet	11-11	Plug	25	Anticavitation valve	119	Plug
10-4	Spring	11-12	O-ring	101	Cover-lock valve	120	Bolt-hex. socket head
10-5	O-ring	12	Bucket work block	102	Lock valve		
10-6	Plug	12-1	Body-work	103	Seal		
10-7	O-ring	12-2	Spool assy	104	Filter		

3. DISASSEMBLY AND ASSEMBLY

1) GENERAL PRECAUTIONS

- (1) All hydraulic components are manufactured to a high precision. Consequently, before disassembling and assembling them, it is essential to select an especially clean place.
- (2) In handling a control valve, pay full attention to prevent dust, sand, etc. from entering into it.
- (3) When a control valve is to be removed from the machine, apply caps and masking seals to all ports. Before disassembling the valve, recheck that these caps and masking seals are fitted completely, and then clean the outside of the assembly. Use a proper bench for working. Spread paper or a rubber mat on the bench, and disassemble the valve on it.
- (4) Support the body section carefully when carrying or transferring the control valve. Do not lift by the exposed spool, end cover section etc.
- (5) After disassembling and assembling of the component it is desired to carry out various tests (for the relief characteristics, leakage, flow resistance, etc.), but hydraulic test equipment is necessary for these tests. Therefore, even when its disassembling can be carried out technically, do not disassemble such components that cannot be tested, adjusted, and so on. Additionally one should always prepare clean cleaning oil, hydraulic oil, grease, etc. beforehand.

2) TOOLS



Before disassembling the control valve, prepare the following tools beforehand.

Name of tool	Quantity	Size (mm)
Vice mounted on bench (soft jaws)	1 unit	
Hexagon wrench	Each 1 piece	5, 6, 10, 12 and 14
Socket wrench	Each 1 piece	5 and 6
Spanner	Each 1 piece	13, 21 and 30
Rod	1 piece	Less than 10 × 250

3) DISASSEMBLY



(1) Disassembly of spools (pilot type)

- ① Loosen hexagon socket head bolts (10) with washer.
(Hexagon wrench : 5 mm)
- ② Remove the pilot cover (8).
 - ※ Pay attention not to lose the O-ring (7) under the pilot cover.
- ③ Remove the spool assembly (2) from the body by hand slightly.
 - ※ When extracting each spool from its body, pay attention not to damage the body.
 - ※ When extracting each spool assembly, it must be extracted from spring side only.
 - ※ When any abnormal parts are found, replace it with completely new spool assembly.
 - ※ When disassembled, tag the components for identification so that they can be reassembled correctly.



(2) Disassembly of holding valve (boom 1)

- ① Loosen hexagon socket head bolts(120).
(Hexagon wrench : 5 mm)
- ② Remove the holding valve.
 - ※ Pay attention not to lose the O-ring and the poppet under the pilot cover.
 - ※ Pay attention not to damage the "piston A" under pilot cover.
 - ※ When any abnormal parts are found, replace it with completely new holding valve assembly.
 - ※ When disassembled, tag the components for identification so that they can be reassembled correctly.



(3) Disassembly of the load check valve and the negative relief valve

① The load check valve



a. Fix the body to suitable work bench.

※ Pay attention not to damage the body.

b. Loosen the plug (6)



(Hexagon wrench : 10 mm).

c. Remove the O-ring (5), spring (4) and the load check valve (3) with pincers or magnet.




(4) Disassembly of the main and overload relief valve

- ① Fix the body to suitable work bench.
 - ② Remove the main relief valve (14).
(Spanner : 30 mm)
 - ③ Remove the overload relief valve (15).
(Spanner : 22 mm)
- ※ When disassembled, tag the relief valve for identification so that they can be reassembled correctly.
 - ※ Pay attention not to damage seat face.
 - ※ When any abnormal parts are found, replace it with completely new relief valve assembly.




(5) Disassembly of the block assembly

- ① Fix the body to suitable work bench.
- ② Remove the nut (24).
(Spanner : 13 mm)



※ Do not removed the tie bolt (23).



(6) Inspection after disassembly

Clean all disassembled parts with clean mineral oil fully, and dry them with compressed air. Then, place them on clean papers or cloths for inspection.

① Control valve

- a. Check whole surfaces of all parts for burrs, scratches, notches and other defects.
- b. Confirm that seal groove faces of body and block are smooth and free of dust, dent, rust etc.
- c. Correct dents and damages and check seat faces within the body, if any, by lapping.
 - ※ Pay careful attention not to leave any lapping agent within the body.
- d. Confirm that all sliding and fitting parts can be moved manually and that all grooves and path's are free foreign matter.
- e. If any spring is broken or deformed, replace it with new one.
- f. When a relief valve does not function properly, repair it, following it's the prescribed disassembly and assembly procedures.
- g. Replace all seals and O-rings with new ones.

② Relief valve

- a. Confirm that all seat faces at ends of all poppets and seats are free of defects and show uniform and consistent contact faces.
- b. Confirm manually that main poppet and seat can slide lightly and smoothly.
- c. Confirm that outside face of main poppet and inside face of seat are free from scratches and so on.
- d. Confirm that springs are free from breakage, deformation, and wear.
- e. Confirm that orifices of main poppet and seat section are not clogged with foreign matter.
- f. Replace all O-rings with new ones.
- g. When any light damage is found in above inspections, correct it by lapping.
- h. When any abnormal part is found, replace it with a completely new relief valve assembly.



4) ASSEMBLY

(1) General precaution

- ① In this assembly section, explanation only is shown.
For further understanding, please refer to the figures shown in the previous structure & disassembly section.
- ② Pay close attention to keeping all seals free from handling damage and inspect carefully for damage before using them.
- ③ Apply clean grease or hydraulic oil to the seal so as to ensure it is fully lubricated before assembly.
- ④ Do not stretch seals so much as to deform them permanently.
- ⑤ In fitting O-rings, pay close attention not to roll them into their final position in addition, a twisted O-ring cannot easily untwist itself naturally and could thereby cause inadequate sealing and thereby both internal and external oil leakage.
- ⑥ Tighten fitting bolts for all sections with a torque wrench adjusted to the respective tightening torque.
- ⑦ Do not reuse removed O-rings and seals.



(2) Load check valve

- ① Assemble the load check valve (3) and O-ring (5), spring (4).
- ② Put O-rings on to plug (6).
- ③ Tighten plug to the specified torque.
 - Hexagon wrench : 8 mm
 - Tightening torque : 3.7 kgf · m
(26.7 lbf · ft)




(3) Main relief, port relief valves

- ① Install the main relief valve (14).
 - Spanner : 30 mm
 - Tightening torque : 6 kgf · m (43.4 lbf · ft)
- ② Install the over load relief valve (15).
 - Spanner : 22 mm
 - Tightening torque : 4 kgf · m (28.9 lbf · ft)




(4) Main spools

- ① Carefully insert the previously assembled spool assemblies into their respective bores within of body.
- ※ Fit spool assemblies into body carefully and slowly. Do not under any circumstances push them forcibly in.



(5) Covers of pilot type



- ① Fit spool covers (8) tighten the hexagonal socket head bolts (10) with washer to the specified torque.
- Hexagon wrench : 5mm
 - Tightening torque : 1~1.1kgf · m (7.2~7.9lbf · ft)
- ※ Confirm that O-rings (7) have been fitted.



(6) Holding valve

- ① Fit the holding valve to the body and tighten hexagon socket head bolt (120) to specified torque.

- Hexagon wrench : 5 mm
- Tightening torque : 1.1 kgf · m (7.9 lbf · ft)



GROUP 5 SWING DEVICE

1. REMOVAL AND INSTALL OF MOTOR

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ **Escaping fluid under pressure can penetrate the skin causing serious injury.**

※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.



- (4) Disconnect hose assembly (59, 61, 76).
- (5) Disconnect pilot line hoses (23, 29).
- (6) Sling the swing motor assembly (1) and remove the swing motor mounting bolts (50).

※ Motor device weight : 23 kg (50 lb)


- (7) Remove the swing motor assembly.
- ※ When removing the swing motor assembly, check that all the piping have been disconnected.

2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the swing motor.
 - ① Remove the air vent plug.
 - ② Pour in hydraulic oil until it overflows from the port.
 - ③ Tighten plug lightly.
 - ④ Start the engine, run at low idling and check oil come out from plug.
 - ⑤ Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.




2. COMPONENTS (1/2)



1692SM06

201	Body	212	Retainer	225	Pin	304	Piston
202	Plate	213	Pin	226	Pin	305	Cap
203	Shaft	214	Filter	243	Relief valve	306	Spring
204	Cylinder barrel	215	Spring C	246	Check valve	307	Spacer
205	Valve plate	216	Bearing	247	Plug	308	O-ring
206	Piston	217	Bearing	248	Spring	309	O-ring
207	Shoe	218	O-ring	249	O-ring	310	O-ring
208	Shoe holder	221	Snap ring	301	Seat	311	O-ring
209	Barrel holder	223	Screw	302	Retainer	312	Back up-ring
210	Swash plate	224	Spring pin	303	Poppet		

COMPONENTS (2/2)



1692SM07

101	Body	114	O-ring	123	Oil seal
102	Carrier 1	115	Thrust plate 1	124	Screw
104	Pinion shaft	119	Preload collar	128	Ring
111	Needle	121	Bearing	129	Ring 1
113	Seal ring	122	Bearing		

1) GENERAL ATTENTION

Please pay attention following points.

- (1) Working should be done at the clean place and pay attention not to attach dust, paint cake and water. And prepare the clean box to put into the disassembled parts.
- (2) Before disassembling, clean up the dust which is attached to the outside of the swing motor and take out paint which is attached to the binding parts by the wire brush.
- (3) To make the original position when assembling, make a marking before disassembling.
- (4) Give special care to protect parts from damage.
- (5) Wash parts with washing oil sufficiently.
- (6) Check parts whether there is friction loss or seize and take out burr with sand paper.
- (7) Change the seals and snap rings to new ones.

2) DISASSEMBLY AND ASSEMBLY PROCEDURE

As the swing motor composes 2 blocks (hydraulic motor and reduction gear), explain each block disassembly and assembly procedure.

And please refer to the page 7-37~38.

3) TOOLS FOR DISASSEMBLY AND ASSEMBLY

No.	Tool	
1	Preset type hand torque wrench	45 N (JIS B4650)
2		90 N (JIS B4650)
4	Hexagon bar bit for above wrench	Two-plane width 6
5		Two-plane width 8
6	Single purpose type hand torque wrench	$T = 15 \pm 1.5 \text{ kgf} \cdot \text{m}$ ($108 \pm 10.8 \text{ lbf} \cdot \text{ft}$) Two-plane 36
8	Hexagon bar wrench	Two-plane width 6
9		Two-plane width 8
10	Spanner	Two-plane width 36
11	Minus driver	Width 6~10
12	Snap ring pliers	∅ 28 For hole
13	Hammer	-
14	Plastic hammer	-
15	Other	Grease
16		(Oil designated hydraulic oil)
17		Wire brush
18		Sand paper
19		Anti-loose adhesive (three bond #1305)


3. DISASSEMBLY

1) HYDRAULIC MOTOR

- (1) Loose the hexagon socket head cap bolts (124), and take out the hydraulic motor assembly from the reduction gear body.

· Tools required :
Hexagon bar wrench : 6 mm


- ※ When taking out the hydraulic motor assembly from the reduction gear body, the drain port should be open.
When it is difficult to take out, insert the minus driver into the binding face to the body and take out the burr completely.



- (2) Take out the relief valve assembly.

· Tools required :
Spanner : 36 mm


- ※ Do not disassemble the relief valve assembly, unless it is necessary.



- (3) Loose the hexagon socket head cap bolts (223), and take out the plates (202).

· Tools required :
Hexagon bar wrench : 8 mm

- ※ Pay attention not to drop out the swash plate (210).



- (4) Take out the swash plate (210) and the shaft kit from the plate S (202).


- ※ When it is difficult to take out the shaft, hit the opposite side slightly by the plastic hammer.

As the bearing (216) is pressed into the shaft, do not disassemble unless it is necessary to change the bearing.



(5) Take out the filter (214) and the parallel pin (225) from the plate S (202).

- Filter (214) : 2 pcs
- Parallel pin (225) : 3 pcs




(6) Take out the cylinder barrel kit.

※ The small parts are easily dispersed, pay attention not to miss.


The valve plate (205) is sometime attached, pay attention not to drop out.




(7) Take out the piston (206) and the shoe (207) assembly, the shoe holder (208), the barrel holder (209) and the pin (213).




(8) Take out the snap ring (221), the retainer (212) and the spring C (215).



1697SM11




(9) Take out the valve plate (205).




(10) Loose the plug (247), and take out the check valve (246) and the spring (248). (2 locations)

- Tools required :
Hexagon bar wrench : 8 mm



2) REDUCTION GEAR

- (1) Take out the thrust plate (115).




- (2) Take out carrier 1 (102), the b1 gears (106), the needles (111) and the rings (129).

Needle (111) : 18 pcs / b1 gear 1pc

b1 gear (106) : 3 pcs

Ring (129) : 3 pcs


- ※ The small parts are easily dispersed.
Pay attention not to miss.




- (3) Take out the ring (128) and the pre-load collar (119).

- ※ To attach the minus driver to the gap of 2 pcs pre-load collar, and take out by hitting with the hammer.

As pre-adjusted the gap with the bearing, do not disassemble unless it is necessary.




R27Z97SM21



- (4) Take out the pinion shaft (104).


- ※ To secure the drawing space of the pinion shaft, attach the approximate 100 mm pad to the flange part, and push out the pinion shaft (104) by the press.

As pre-adjusted the gap with the bearing, do not disassemble unless it is necessary.




(5) Take out the out ring of the bearing (121, 122), and the oil seal (123).

- ※ As it is difficult to take out the outer ring of the bearing (121, 122), do not disassemble unless it is necessary.
Do not use again the oil seal.



(6) Take out the inner ring of the bearing (121) and the ring seal (113).


- ※ As the inner ring of the bearing (121) is press-fitting one, do not disassemble unless it is necessary.
Do not use again the ring seal (113).



4. ASSEMBLY

1) HYDRAULIC MOTOR SECTION

- (1) Press-fit the bearing (217) and spring pin (224) into the body H (201).



- (2) Insert the 2 check valves (246) (1 pc/side), 2 springs (248) (1pc/side) and 2 plugs (247) (1pc/side) with O-ring (249) in that order into the body H (201).

· Tools required :



Hexagon bar wrench : 8 mm

Torque wrench

- ※ Apply grease slightly to the O-ring and assemble to pay attention not biting the seals.



· Plug tightening torque :

$6 \pm 0.3 \text{ kgf} \cdot \text{m}$ ($43.4 \pm 2.17 \text{ lbf} \cdot \text{ft}$)




- (3) Place the valve plate (205) onto the body H (201).


- ※ The steel face of the valve plate should be downside and assemble.



- (4) Place the retainer (212), spring C (215) and retainer (212) in that order into the cylinder barrel (204), and then secure them with the snap ring (221).




R27Z97SM38




1697SM26

- (5) Make the shoe holder assembly which has the 9 piston-shoe (206, 207) assemblies placed on the shoe holder (208).




1697SM27

- (6) Place the 3 pins (213), barrel holder (209) and the shoe holder assembly onto the cylinder barrel (204) to make up a cylinder barrel assembly.



R27Z97SM41




1697SM28


- (7) Place the filter (214) and the parallel pins (225) into the plate S (202).

Filter (214) : 2 pc

Parallel pin (225) : 1 pcs




- (8) Place the shaft assembly into the plate S.



- (9) Place the swash plate (210) onto the plate S (202).

In case the swash plate drops out, apply grease to the plate S side of it.




- (10) Join the body H (201) and the plate S (202).

※ Align the serration of the shaft which is assembled to the plate S to the serration of the cylinder barrel assembly which is assembled to the body H.



(11) Bolt the plate S (202) together with the 8 hexagon socket head cap bolts (223).



- Tools required :
Hexagon bar wrench : 8 mm
Torque wrench
- Plug tightening torque :
 $6 \pm 0.3 \text{ kgf} \cdot \text{m}$ ($43.4 \pm 2.17 \text{ lbf} \cdot \text{ft}$)



(12) Screw up the relief valve assembly.
(both side)

- Tools required :
Spanner : 36 mm
Torque wrench
- Plug tightening torque :
 $15 \pm 1.5 \text{ kgf} \cdot \text{m}$ ($108 \pm 10.8 \text{ lbf} \cdot \text{ft}$)

※ Once the relief valve is disassembled, replace the O-ring and the back up ring in the below, and screw the cap with the following torque.




R27Z97SM54

2) REDUCTION GEAR SECTION


(1) Press-fit the oil seal (123) into the body (101).

※ Pay attention to the direction of the oil seal, use round steel plate for pressing to prevent misalignment.

Steel plate outer diameter : $\varnothing 61.5$




1697SM03




R27Z97SM57

(2) Place the ring seal (113) onto the pinion shaft (104).

※ Pay attention to direction of the ring seal.




R27Z97SM58



1697SM35


(3) Press-fit the inner ring of the bearing (121) to the pinion shaft (104).

※ After press fitting, apply grease onto the surface of the rollers, and turn them manually so that the grease can spread to the whole roller surface.




1697SM36

- (4) Press-fit the outer ring of the bearing (122) into the body (101).




- (5) Press-fit the outer ring of the bearing (121) into the body (101).



- (6) Fill grease in the bearing (121) section of the body (101).

- ※ Grease amount : approx. 80% of the space inside the outer ring.




- (7) Insert the pinion shaft (104) into the body (101).

- ※ Pay attention not to damage the lip of the oil seal.





- (8) Turn over the body (101), then press-fit inner ring of the bearing (122).




- (9) Fix the pinion shaft (104) with the 2 pre-load collars (119).


※ Thickness of the pre-load collar must be adjusted for the below L dimension.
Standard's +0 to +0.05 mm



- (10) Place the ring (128) over the pinion shaft.





- (11) Align the spline of the carrier 1 (102) to the pinion shaft (104) and place the carrier 1 (102) into the body.




(12) Place the 3 rings (129) (1 pc/pin) onto the 3 pins of the carrier 1 (102).

- ※ Pay attention to direction of the ring.
Beveling part of the ring should be down side.




(13) Place the thrust plate (115) onto the carrier 1.

- ※ Larger size holes are aligned to the pins.




(14) Place the 3 b1 gears (106) (1 ps/pin) and 54 needles (111) (18 pc/pin) in that order onto the 3 pins of the carrier 1.

- ※ Pay attention not to drop the needles in the body.




(15) Place the thrust plate (115) onto the carrier 1.

- ※ Smaller size holes are aligned to the pins.




(16) Fill body (101) with hydraulic oil.

- ※ Oil : ISO VG 46 or equivalent
Oil amount : 3 to 4 mm below top of the thrust plate
Wipe oil off flange surface if it is spilled.



(17) Place the O-ring (114) onto the body (101).




(18) Join the hydraulic motor and the body, and then bolt them together with the 4 hexagon socket head cap bolts (124).

- Tools required :
Hexagon bar wrench : 6 mm
Torque wrench

- ※ Align the shaft of the motor to the b1 gear.
Apply anti-loose adhesive to the screws.

- Plug tightening torque :
 $3 \pm 0.3 \text{ kgf} \cdot \text{m}$ ($21.7 \pm 2.17 \text{ lbf} \cdot \text{ft}$)



GROUP 6 TRAVEL DEVICE

1. REMOVAL AND INSTALL


1) REMOVAL

- (1) Swing the work equipment 90° and lower it completely to the ground.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.


- (4) Remove the track shoe assembly.
For details, see removal of track shoe assembly.
- (5) Remove the cover.
- (6) Remove the hose.
※ Fit blind plugs to the disconnected hoses.
- (7) Remove the bolts and the sprocket.
- (8) Sling travel device assembly (1).
- (9) Remove the mounting bolts (2), then remove the travel device assembly.
· Weight : 36 kg (80 lb)



2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the travel motor.
 - ① Remove the air vent plug.
 - ② Pour in hydraulic oil until it overflows from the port.
 - ③ Tighten plug lightly.
 - ④ Start the engine, run at low idling, and check oil come out from plug.
 - ⑤ Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.


2) STRUCTURE (1/3)



1692TM02

202	Body 2	210	Swash plate	218	O-ring
203	Shaft	211	Control piston	219	Oil seal
204	Cylinder barrel	212	Pin	220	Ball
205	Valve plate	213	Spring C	221	Snap ring
206	Piston	214	Retainer	222	Screw
207	Shoe	215	Bearing	223	Spring pin
208	Shoe holder	216	Bearing	224	Pin
209	Barrel holder	217	O-ring	225	Plug


STRUCTURE (2/3)



1692TM03

301	Body 1	309	Spring V3	317	O-ring
302	Spool	310	Plug	318	O-ring
303	Check valve	311	Plug	319	O-ring
304	Spring guide	312	Plug	320	Choke
305	Spool	313	Choke	321	Pin
306	Shuttle spool	314	Ring	322	Plug
307	Spring V1	315	Plug		
308	Spring V2	316	Plug		

STRUCTURE (3/3)



1692TM04

101	Body	113	Snap ring	121	Thrust washer	134	Thrust washer
102	Cover	114	Thrust plate	122	Snap ring	135	Plug
104	Carrier 2	115	Slide ring	123	Snap ring	136	O-ring
106	Gear B1	116	Needle	127	Spring pin	137	Snap ring
107	Gear B2	117	Needle	129	O-ring	139	O-ring
108	Gear S1	118	Floating seat (Incl 119)	130	O-ring	140	Snap ring
110	Ring			131	Plug		
111	Pin B2	119	O-ring	132	Name plate		
112	Seal ring	120	Bearing	133	Hydraulic motor		

3) MAINTENANCE INSTRUCTION

(1) Necessary tool to assemble

No.	Necessary tool	
1 2 3	Torque wrenches	12N (JIS B4650) 90N (JIS B4650) 180N (JIS B4650)
4 5 6	Hexagon socket	Hexagon size : 4 mm Hexagon size : 6 mm Hexagon size : 8 mm
7	Socket wrenches	Hexagon size : 27 mm
8 9 10	Hexagon socket wrenches	Hexagon size : 4 mm Hexagon size : 6 mm Hexagon size : 8 mm
11	Screwdrivers	Width : 6~10 mm
12 13 14 15 16	Snap ring pliers	ø 28 mm for hole ø 15 mm for shaft ø 18 mm for shaft ø 26 mm for shaft ø 90 mm for shaft
17	Plastic hammer	-
18 19 20 21	Other	Grease Oil Sand paper C-clamps

2. DISASSEMBLY

1) GENERAL PRECAUTIONS


- (1) Before disassembling the TM motors, check the items to be inspected and, for remedy against trouble, closely examine the nature of the trouble, so that the motor can be disassembled effectively.
- (2) To disassemble the motor, use the disassembling procedures described in section 2-2, and select a clean place.
- (3) Place a rubber or vinyl sheet or other such protective materials on your working bench to protect the surface of the motor to be serviced.
- (4) During disassembly, give a match mark to the mating surfaces of each part.
- (5) Arrange removed parts in order so that they will not become damaged or missing during disassembly.
- (6) Once seals have been disassembled, they should be replaced even if damage is not observed. Have replacement seals ready on hand before starting your disassembling job.

2) REDUCTION GEAR SECTION

(1) Remove the two plugs (PF3/8).

- Tools required :
Hexagon size : 8 mm

※ Remove the plug of "LEVEL" side first.



(2) Remove the snap-ring.

※ Put the screwdriver into the notch of the body, and then pull the snap-ring.




(3) Remove the cover.



(4) Remove the slide ring from the cover.



(5) Remove the O-ring from the body.



(6) Remove the carrier 2 kit from the body.




(7) Remove the three snap rings, three thrust washers, three b2 gears, forty-nine needles and three thrust washers.


- ※ The thrust washers on both sides of the b2 gears are the same.
- ※ The b2 pins and spring pins are not able to disassemble, because they are press-fitted.




(8) Remove the snap ring from the carrier 2.





(9) Remove the s1 gear from the carrier 2.



(10) Remove the four snap rings and the four thrust plate.




(11) Remove the four b1 gears, ninety-six needles, four thrust washers and four rings.



(12) Remove the snap ring.

- ※ Tighten the speed reducer flange and the motor flange with C-clamps or a hydraulic press (see the illustration) to make it easy.



(13) Remove the speed reducer with the iron balls with retainer and the internal ring of bearing.




(14) Remove the iron balls with retainer from the speed reducer.

- ※ Pay attention not to lose the balls from retainer.




- (15) Remove the seal ring from the speed reducer.



- (16) Remove the iron balls with retainer and the internal ring of bearing from the hydraulic motor.

※ Pay attention not to lose the balls from retainer.



- (17) Remove the floating seat with O-ring from the hydraulic motor.




3) HYDRAULIC MOTOR SECTION

- (1) Remove the seven hexagon socket head cap bolts.


· Tools required :
Hexagon size : 6 mm

- ※ If you fix the motor with a vice, protect it with aluminum plates or equivalent.



- (2) Remove the body 1 from the body 2.

- ※ Pay attention not to come off and damage the valve plate.




- (3) Remove the valve plate.




- (4) Remove the two O-rings from the body 1.

- ※ The bearing and spring pins are not able to disassemble, because they are press-fitted.




- (5) Remove the cylinder barrel assembly from the body 2.


※ Pay attention not to lose the each part.



- (6) Remove the seven piston-shoe assemblies, shoe holder, barrel holder, three pins.



- (7) Remove the snap ring, retainer, spring-C and retainer.



- (8) Remove the swash plate and two balls from the body 2.



(9) Remove the shaft from the body 2.

※ The bearing is not able to disassemble,
because they are press-fitted.



(10) Remove the control piston from the body 2.



(11) Remove the oil seal from the body 2.

(12) Remove the pin from the body 2.




(13) Remove the two plugs with O-rings from
the body 1.

• Tools required :
Hexagon size : 27 mm




(14) Remove the two spring V2, two rings and spool assembly.

※ The spool assembly is not able to disassemble.



(15) Remove the two plugs with O-rings from the body 1.

· Tools required :
Hexagon size : 8 mm




(16) Remove the spring V3 and two speed spool.




(17) Remove the two plugs from the body 1.

- Tools required :
Hexagon size : 4 mm




(18) Remove the two needles and shuttle spool.



3. ASSEMBLY

1) HYDRAULIC MOTOR SECTION



- (1) Press-fit the bearing and the spring pin into the body 1.



- (2) Insert the spool assembly, two rings (1pc/side) and two springs (1pc/side) in that order into the body 1, and then screw the two plugs (1pc/side) with two O-rings (1pc/side).

※ The spool assembly is not able to disassemble.

- Plugs tightening torque :
13~17 kgf · m (94~123 lbf · ft)
- Hexagon size : 27 mm







(3) Insert the spring V3 and two speed spool into the body 1, and screw the two plugs (1pc/side) with two O-rings (1pc/side).


- Plugs tightening torque :
4.69~5.2 kgf · m (33.9~37.6 lbf · ft)
- Hexagon size : 8 mm

※ Pay attention to the direction of the spool.
(See cross sectional drawing for the direction, page 7-56~58).



- (4) Insert the shuttle spool and two needles (1pc/side) into the body 1, and then screw them in with the two plugs (1pc/side).

- Plugs tightening torque :
0.6 kgf · m (4.3 lbf · ft, both sides)
- Hexagon size : 4 mm




- (5) Place two O-rings onto the body 1.




(6) Press-fit the oil seal into the body 2.

- ※ Apply grease to the periphery of the oil seal.
- ※ Pay attention to the direction of the oil seal, and do not slant it.



R27Z97TM52



(7) Place the pin into the body 2.




(8) Press-fit the bearing with the shaft.




(9) Insert the control piston into the body 2.

- ※ Assemble the control piston, which spherical surface should be upper side.





(10) Place the shaft into the body 2.

- ※ Pay attention not to damage the oil seal with the shaft.
- A oil which damaged should be replaced.




(11) Place the two balls and the swash plate onto the body 2.

- ※ Apply oil to the working face of the swash plate.
- ※ In case the swash plate drops out, apply grease to the back of it.



(12) Place the retainer, spring C and retainer in that order into the cylinder barrel, and then secure them with the snap ring.




- (13) Place the piston-shoe assemblies into the shoe holder.




- (14) Place the three pins, barrel holder and piston-shoe assemblies in that order into the cylinder barrel.

- ※ Apply oil to the inside of the cylinders, then lower the pistons into the cylinder barrel.
- ※ Pay attention to the order of pins, barrel holder and piston-shoe assemblies.



- (15) Insert the cylinder barrel assembly into the body 2 so that the shoes contact the swash plate.




- (16) Fill the body 2 with 0.1ℓ hydraulic oil for lubrication.

(17) Place the valve plate onto the body 1.

- ※ The copper face of the valve plate should be uppermost.
- ※ Apply oil to the copper face of the valve plate.
- ※ In case the valve plate drops out, apply grease to the steel face of it.



(18) Join the body 1 to the body 2.



(19) Bolt them with seven hexagon socket head cap bolts.


- Bolt tightening torque :
2.9~3.1 kgf · m (21.0~22.4 lbf · ft)
- Hexagon size : 6 mm

- ※ If you fix the motor with a vice, protect it with aluminum plates or equivalent.




2) REDUCTION GEAR SECTION

- (1) Place the floating seal with O-ring into the hydraulic motor.



- (2) Place inner ring, retainer with balls of the bearing in that order, onto the hydraulic motor.

- ※ Pay attention to the direction of the inner ring and the retainer.
(See cross sectional drawing for the direction.)
- ※ Pay attention not to disassemble the balls from the retainer.




- (3) Put the seal ring with O-ring onto the body.

- ※ Apply grease to the O-ring to make it easy, and then wipe grease from the seal surface.



(4) Join the body to the motor.

- ※ Wipe grease from the seal surface.
- ※ Tighten the speed reducer flange and the motor flange with C-cramps or a hydraulic press.



1697TM95




(5) Place retainer with balls, inner ring of the bearing in that order the hydraulic motor.

- ※ Pay attention to the direction of the inner ring and the retainer.
- ※ Pay attention not to disassemble the balls from retainer.
(See cross sectional drawing for the direction.)




(6) Fix the bearing with the snap ring.

- ※ The pre-load for the bearings is adjusted by thickness of the snap ring.






- (7) Place the four rings (1pc/1pin), four thrust washers (1pc/1pin), four b1 gears (1pc/1pin) and ninety-six needles (24pcs/1pin) in that order onto the body 2.

※ Pay attention to the direction of the ring.
The chamfer on the caliber of the ring direction is motor side.



1697TM94




- (8) Place thrust plate onto the gears and secure it with four snap rings.


※ Pay attention to the direction of the thrust plate. The convex side should be uppermost. (see cross sectional drawing for the direction, page 7-56~58).

※ Pay attention to the direction of the snap ring. The edge side should be uppermost.

※ Pay attention not to open the snap ring too much. A snap ring which loses tension should be replaced.





- (9) Press-fit the three b2 pins and three spring pins (1pc/pin) into the carrier 2.




- (10) Put the S1 gear to the carrier 2, and then secure them with the snap ring.


- ※ Pay attention to the direction of the snap ring. The edge side should be uppermost.
- ※ Pay attention not to open the snap ring too much. A snap ring which loses tension should be replaced.



- (11) Place the three thrust washers (1pc/1pin), three b2 gears (1pc/1pin), forty-nine needles (13pcs/1pin) and the three thrust washers (1pc/1pin), in that order the carrier 2 and secure them with the three snap rings.

- ※ Pay attention to the direction of the snap ring. The edge side should be uppermost.
- ※ Pay attention not to open the snap ring too much. A snap ring which loses tension should be replaced.






(12) Place the carrier 2 assembly into the body.



(13) Place the O-ring to the body.

- ※ Apply grease to the O-ring.
- ※ Pay attention not the rubbish in the O-ring groove.




(14) Place the slide ring onto the cover.

- ※ Apply grease to the slide ring to prevent it dropping out.




(15) Fill 0.33 ℓ gear oil in the body and insert cover.

- ※ Pay attention not to damage the O-ring.
- ※ The "DRAIN" side tapped hole should be aligned with notches of the body.



1697TM89



(16) Put the snap ring into the groove of the body to secure the cover.


- ※ Put the flat blade-flared tip screwdriver to the end of the snap ring, and tap it in the direction of the circumference.



(17) Screw the three plugs (size : PF3/8) with O-rings (1pc/plug) to the cover.

- Plug tightening torque (PF3/8) :
4.69~5.2 kgf · m (33.9~37.6 lbf · ft)
- Hexagon size : 8 mm (PF3/8)

※ Screw the plug of "DRAIN" side first.



GROUP 7 RCV LEVER


1. REMOVAL AND INSTALL

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

- (4) Loosen the socket bolt(1).
 - (5) Remove the cover of the console box.
 - (6) Disconnect pilot line hoses(3).
 - (7) Remove the pilot valve assembly(2).
- ※ When removing the pilot valve assembly, check that all the hoses have been disconnected.




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE




R35Z72RL02

1	Case	12	Push rod (1, 3)	23	Connector
2	Plug	13	Push rod (2, 4)	24	Nut
3	O-ring	14	Plug	25	Nut
4	Spring	15	O-ring	26	Insert
5	Spring seat (1, 3)	16	Rod seal	27	Boot
6	Spring seat (2, 4)	17	Plate (A)	28	Handle
7	Stopper	18	Bushing	29	Switch assembly
8	Spring (1, 3)	19	Machine screw	30	Screw
9	Spring (2, 4)	20	Joint assembly	31	Plate
10	Spring seat	21	Swash plate	32	Boot
11	Spool	22	Hex nut		

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

Tool name	Remark	
(L) Hexagonal wrench	10	
Spanner	22	
	27	
(+) Driver	Length 150	
(-) Driver	Width 4~5	
Torque wrench	Capable of tightening with the specified torques	


3) DISASSEMBLY

(1) Clean pilot valve with kerosene.


※ Put blind plugs into all ports.

(2) Fix pilot valve in a vise with copper (or lead) sheets.


(3) Remove end of boot (32) from case (1) and take it out upwards.




※ For valve with switch, remove cord also through hole of casing.





(4) Loosen lock nut (24) and adjusting nut (22) with spanners on them respectively, and take out handle section as one body.



(5) Remove the boot (32).





- (6) Loosen adjusting nut(22) and plate(31) with spanners on them respectively, and remove them.




- (7) Turn joint anticlockwise to loosen it, utilizing jig (special tool).

※ When return spring(8, 9) is strong in force, plate(31), plug(14) and push rod(12, 13) will come up on loosening joint.

Pay attention to this.



(8) Remove plate (31).




(9) When return spring (8, 9) is weak in force, plug (14) stays in casing because of sliding resistance of O-ring.

※ Take it out with minus screwdriver.

Take it out, utilizing external periphery groove of plug and paying attention not to damage it by partial loading.


※ During taking out, plug may jump up due to return spring (8, 9) force.

Pay attention to this.




(10) Remove reducing valve subassembly and return spring (8, 9) out of casing.

※ Record relative position of reducing valve subassembly and return springs.




(11) Loosen hexagon socket head plug (2) with hexagon socket screw key.




(12) For disassembling reducing valve section, stand it vertically with spool (11) bottom placed on flat workbench. Push down spring seat (5, 6) and remove two pieces of semicircular stopper (7) with tip of small minus screwdriver.

- ※ Pay attention not to damage spool surface.
- ※ Record original position of spring seat (5, 6).
- ※ Do not push down spring seat more than 6 mm.




(13) Separate spool (11), spring seat (5, 6), spring (8, 9) and spring seat (10) individually.

- ※ Until being assembled, they should be handled as one subassembly group.





(14) Take push rod (12, 13) out of plug (14).





(15) Remove O-ring (15) and seal (16) from plug (14).

Use small minus screwdriver or so on to remove this seal.





(16) Remove lock nut (24) and then boot (27).



(17) Cleaning of parts

- ① Put all parts in rough cleaning vessel filled with kerosene and clean them (rough cleaning).
 - ※ If dirty part is cleaned with kerosene just after putting it in vessel, it may be damaged. Leave it in kerosene for a while to loosen dust and dirty oil.
 - ※ If this kerosene is polluted, parts will be damaged and functions of reassembled valve will be degraded.
Therefore, control cleanliness of kerosene fully.
- ② Put parts in final cleaning vessel filled with kerosene, turning it slowly to clean them even to their insides (finish cleaning).
 - ※ Do not dry parts with compressed air, since they will be damaged and/or rusted by dust and moisture in air.


(18) Rust prevention of parts.

- Apply rust-preventives to all parts.
- ※ If left as they are after being cleaned, they will be rusted and will not display their functions fully after being reassembled.


4) ASSEMBLY

- (1) Tighten hexagon socket head plug (2) to the specified torque.

※ Tighten two bolts alternately and slowly.




- (2) Put spring seat (10), springs (8, 9) and spring seat (5, 6) onto spool (11) in this order.




- (3) Stand spool vertically with its bottom placed on flat workbench, and with spring seat pushed down, put two pieces of semicircular stopper (7) on spring seat without piling them on.

※ Assemble stopper (7) so that its sharp edge side will be caught by head of spool. Do not push down spring seat more than 6 mm.




- (4) Assemble spring (8, 9) into casing.
Assemble reducing valve subassembly into casing.

※ Assemble them to their original positions.




(5) Assemble O-ring (15) onto plug (14).




(6) Assemble seal (16) to plug (14).

※ Assemble seal in such lip direction as shown below.




(7) Assemble push rod (12, 13) to plug (14).

※ Apply working oil on push-rod surface.




(8) Assemble plug subassembly to casing.

※ When return spring is weak in force, subassembly stops due to resistance of O-ring.




(9) When return spring is strong in force, assemble 4 sets at the same time, utilizing plate (31), and tighten joint (20) temporarily.

(10) Fit plate (31).




(11) Tighten joint (20) with the specified torque to casing, utilizing jig.




(12) Assemble plate (21) to joint (20).

- ※ Screw it to position that it contacts with 4 push rods evenly.
- ※ Do not screw it over.




(13) Assemble adjusting nut (22), apply spanner to width across flat of plate (21) to fix it, and tighten adjusting nut to the specified torque.



- ※ During tightening, do not change position of disk.




(14) Fit boot (32) to plate.




(15) Fit boot (27) and lock nut (24), and handle subassembly is assembled completely.




(16) Pull out cord and tube through adjusting nut hole provided in direction 60° to 120° from casing hole.




- (17) Assemble bushing (18) to plate and pass cord and tube through it.
※ Provide margin necessary to operation.




- (18) Determine handle direction, tighten lock nut (21) to specified torque to fix handle.



- (19) Apply grease to rotating section of joint and contacting faces of disk and push rod.



- (20) Assemble lower end of bellows to casing.
(21) Inject volatile rust-preventives through all ports and then put blind plugs in ports.



GROUP 8 TURNING JOINT

1. REMOVAL AND INSTALL

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.



※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.

- (4) Disconnect all hoses.
- (5) Sling the turning joint assembly (1) and remove the mounting bolt (2).
 - Weight : 20 kg (44 lb)
 - Tightening torque : $6.9 \pm 1.4 \text{ kgf} \cdot \text{m}$
($49.9 \pm 10.1 \text{ lbf} \cdot \text{ft}$)
- (6) Remove the turning joint assembly.

※ When removing the turning joint, check that all the hoses have been disconnected.


2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- ※ Take care of turning joint direction.
- ※ Assemble hoses to their original positions.
- ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.



2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE



1697TJ02

- 1 Hub
- 2 Shaft
- 3 Cover
- 4 Spacer
- 5 Slipper seal


- 6 O-ring
- 7 O-ring
- 8 O-ring
- 9 Back-up ring
- 10 Retainer ring

- 11 Plug
- 12 Hexagon bolt
- 13 Spring washer

2) DISASSEMBLY


※ Before the disassembly, clean the turning joint.

- (1) Remove bolts (12), washer (13) and cover (3).



- (2) Remove O-ring (8).


- (3) Remove retainer ring (10) and spacer (4).




- (4) Place hub (1) on a V-block and by using a wood buffer at the shaft end, hit out shaft (2) to about 1/2 from the body with a hammer.

※ Take care not to damage the shaft (2) when remove hub (1) or rest it sideways.

※ Put a fitting mark on hub (1) and shaft (2).




- (5) Remove nine slipper seals (5), O-ring (7), back-up ring (9), and O-ring (6) from hub (1).




3) ASSEMBLY

- ※ Clean all parts.
- ※ As a general rule, replace oil seals and O-ring.
- ※ Coat the sliding surfaces of all parts with engine oil or grease before installing.

- (1) Fix nine slipper seal (5) and O-ring (7), back-up ring (9) and O-ring (6) to hub (1).




- (2) Set hub (1) on block, install shaft (2) into hub (1) by hand.




- (3) Fit spacer (4) and retainer ring (10) to shaft (2).

- (4) Fit O-ring (8) to hub (1).



- (5) Install cover (3) to hub, tighten bolts (12) with washer (13).



GROUP 9 BOOM, ARM AND BUCKET CYLINDERS

1. REMOVAL AND INSTALL

1) BUCKET CYLINDER


(1) Removal

- ※ Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- ※ Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.

▲ Loosen the breather slowly to release the pressure inside the hydraulic tank. Escaping fluid under pressure can penetrate the skin causing serious injury.


- ※ Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.

- ① Set block between bucket cylinder and arm.




- ② Remove bolt (2), nut (3) and pull out pin (1).


- ※ Tie the rod with wire to prevent it from coming out.



- ③ Disconnect bucket cylinder hoses (4) and put plugs (5) on cylinder pipe.



- ④ Sling bucket cylinder assembly (9) and remove bolt (6) and nut (7) then pull out pin (8).
- ⑤ Remove bucket cylinder assembly (9).
 - Weight : 11 kg (24 lb)



(2) Install

- ① Carry out installation in the reverse order to removal.

▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.

- ※ Bleed the air from the bucket cylinder.
- ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2) ARM CYLINDER

(1) Removal


- ※ Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- ※ Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.

▲ Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.


- ※ Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.

- ① Set block between arm cylinder and boom.




- ② Remove bolt and nut (2) and pull out pin (1).


- ※ Tie the rod with wire to prevent it from coming out.



- ③ Disconnect arm cylinder hoses (4) and put plugs on cylinder pipe.



- ⑤ Sling arm assembly (8) and remove bolt and nut (7) then pull out pin (6).
- ⑥ Remove arm cylinder assembly (8).
 - Weight : 15 kg (33 lb)



(2) Install

- ① Carry out installation in the reverse order to removal.

▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.

- ※ Bleed the air from the arm cylinder.
- ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.

3) BOOM CYLINDER

(1) Removal


- ※ Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- ※ Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.

▲ Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.


- ※ Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.

① Sling boom cylinder assembly.




③ Remove bolt and nut (2) and pull out pin (1).


- ※ Tie the rod with wire to prevent it from coming out.




④ Lower the boom cylinder assembly (3) on a stand.



- ⑤ Disconnect boom cylinder hoses(4) and put plugs on cylinder pipe.



- ⑥ Remove bolt (6) and pull out pin (5).
⑦ Remove boom cylinder assembly (3).
• Weight : 17 kg (37 lb)



(2) Install

- ① Carry out installation in the reverse order to removal.


▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.

- ※ Bleed the air from the boom cylinder.
- ※ Confirmed the hydraulic oil level and check the hydraulic oil leak or not.

2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE


(1) Bucket cylinder



1697CY03

1	Tube assembly	9	O-ring	17	O-ring
2	Rod assembly	10	Back-up ring	18	Back up ring
3	Gland	11	O-ring	19	Pin bushing
4	Dust wiper	12	Piston	20	Dust seal
5	Retaining ring	13	Piston seal	21	Dust ring
6	Bushing	14	Wear ring	22	O-ring
7	Rod seal	15	Set screw	23	Grease nipple
8	Back-up ring	16	Steel ball		


(2) Arm cylinder



1697CY04

1	Tube assembly	11	O-ring	21	Check valve
2	Rod assembly	12	Piston	22	Spring
3	Gland	13	Piston seal	23	O-ring
4	Dust wiper	14	Wear ring	24	Plug
5	Retaining ring	15	Dust ring	25	Pin bushing
6	Rod seal	16	O-ring	26	Dust seal
7	Back-up ring	17	Back up ring	27	O-ring
8	Bushing	18	Set screw	28	O-ring
9	O-ring	19	Steel ball	29	Grease nipple
10	Back-up ring	20	Cushion ring		


(3) Boom cylinder



1697CY18

- | | | | | | |
|---|----------------|----|--------------|----|---------------|
| 1 | Tube assembly | 10 | Back-up ring | 19 | Cushion ring |
| 2 | Rod assembly | 11 | O-ring | 20 | Pin bushing |
| 3 | Gland | 12 | Piston | 21 | Dust seal |
| 4 | Dust wiper | 13 | Piston seal | 22 | Dust ring |
| 5 | Retaining ring | 14 | Wear ring | 23 | O-ring |
| 6 | Bushing | 15 | O-ring | 24 | Grease nipple |
| 7 | Rod seal | 16 | Back up ring | 25 | Grease nipple |
| 8 | Back-up ring | 17 | Set screw | | |
| 9 | O-ring | 18 | Steel ball | | |


(4) Dozer cylinder



1697CY19

- | | | |
|------------------|-----------------|------------------|
| 1 Tube assembly | 10 Back-up ring | 19 Spacer |
| 2 Rod assembly | 11 O-ring | 20 O-ring |
| 3 Gland | 12 Piston | 21 Bushing |
| 4 Dust wiper | 13 Piston seal | 22 Dust seal |
| 5 Retaining ring | 14 Wear ring | 23 Dust ring |
| 6 Rod seal | 15 Set screw | 24 O-ring |
| 7 Back-up ring | 16 Steel ball | 25 Grease nipple |
| 8 DU bushing | 17 O-ring | 26 Grease nipple |
| 9 O-ring | 18 Back-up ring | |


(5) Boom swing cylinder



1697CY20

- | | | | | | |
|---|----------------|----|--------------|----|---------------|
| 1 | Tube assembly | 9 | O-ring | 17 | Back up ring |
| 2 | Rod assembly | 10 | Back-up ring | 18 | Set screw |
| 3 | Gland | 11 | O-ring | 19 | Steel ball |
| 4 | Dust wiper | 12 | Piston | 20 | Pin bushing |
| 5 | Retaining ring | 13 | Piston seal | 21 | Dust seal |
| 6 | Rod seal | 14 | Wear ring | 22 | O-ring |
| 7 | Back-up ring | 15 | Dust ring | 23 | Grease nipple |
| 8 | DU bushing | 16 | O-ring | | |

(6) Extension cylinder




1697CY21

- | | | | | | |
|---|----------------|----|--------------|----|---------------|
| 1 | Tube assembly | 9 | O-ring | 17 | O-ring |
| 2 | Rod assembly | 10 | Back-up ring | 18 | Back-up ring |
| 3 | Gland | 11 | O-ring | 19 | Pin bushing |
| 4 | Dust wiper | 12 | Piston | 20 | Dust seal |
| 5 | Retaining ring | 13 | Piston seal | 21 | Dust ring |
| 6 | Rod seal | 14 | Wear ring | 22 | O-ring |
| 7 | Back-up ring | 15 | Set screw | 23 | Grease nipple |
| 8 | DU bushing | 16 | Steel ball | | |

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

Tool name	Remark	
Allen wrench	8	
	3	
Spanner	M22	
Hook spanner	Suitable size (80~120 mm)	
(-) Driver	Small and large sizes	
Torque wrench	Capable of tightening with the specified torques	

(2) Tightening torque

Part name		Item	Size	Torque	
				kgf · m	lbf · ft
Gland	Boom cylinder	3	M65	52 ± 5.0	376 ± 36.2
	Arm cylinder	3	M65	52 ± 5.0	376 ± 36.2
	Bucket cylinder	3	M60	48 ± 5.0	347 ± 36.2
	Dozer cylinder	3	M70	56 ± 5.0	405 ± 36.2
	Boom swing cylinder	3	M60	48 ± 4.8	347 ± 34.7
	Extension cylinder	3	M55	44 ± 4.5	318 ± 32.5
Piston	Boom cylinder	12	M28	70 ± 7.0	506 ± 50.6
	Arm cylinder	12	M28	70 ± 7.0	506 ± 50.6
	Bucket cylinder	12	M24	60 ± 6.0	434 ± 43.4
	Dozer cylinder	12	M24	60 ± 6.0	434 ± 43.4
	Boom swing cylinder	12	M24	60 ± 6.0	434 ± 43.4
	Extension cylinder	12	M20	50 ± 5.0	362 ± 36.2

3) DISASSEMBLY


※ Procedures are based on the boom cylinder.

(1) Remove cylinder head and piston rod

① Hold the clevis section of the tube in a vise.


※ Use mouth pieces so as not to damage the machined surface of the cylinder tube. Do not make use of the outside piping as a locking means.

② Pull out rod assembly (2) about 200 mm (7.1 in). Because the rod assembly is rather heavy, finish extending it with air pressure after the oil draining operation.




③ Loosen and remove the gland (3) by hook spanner.

※ Cover the extracted rod assembly (2) with rag to prevent it from being accidentally damaged during operation.




④ Draw out cylinder head and rod assembly together from tube assembly (1).

※ Since the rod assembly is heavy in this case, lift the tip of the rod assembly (2) with a crane or some means and draw it out. However, when rod assembly (2) has been drawn out to approximately two thirds of its length, lift it in its center to draw it completely.




Note that the plated surface of rod assembly (2) is to be lifted. For this reason, do not use a wire sling and others that may damage it, but use a strong cloth belt or a rope.

- ⑤ Place the removed rod assembly (2) on a wooden V-block that is set level.
- ※ Cover a V-block with soft rag.




(2) Remove piston and gland

- ① Remove set screw (17).
- ② Remove piston assembly (12), back up ring (16), O-ring (15) and cushion ring (19).




- ④ Remove the gland assembly from rod assembly (2).
 - ※ If it is too heavy to move, move it by striking the flanged part of gland with a plastic hammer.
 - ※ Pull it straight with gland assembly lifted with a crane.
- Exercise care so as not to damage the lip of packing (7, 8, 9, 10, 11) by the threads of rod assembly (2).




(3) Disassemble the piston assembly

- ① Remove wear ring (14).
 - ② Remove dust ring (22) and piston seal (13).
- ※ Exercise care in this operation not to damage the grooves.



(4) Disassemble gland assembly

- ① Remove back-up ring (10) and O-ring (9).
 - ② Remove retaining ring (5), dust wiper (4).
 - ③ Remove back up ring (8), rod seal (7).
 - ④ Remove the dry bushing (6).
- ※ Exercise care in this operation not to damage the grooves.
- ※ Do not remove seal and ring, if does not damaged.




4) ASSEMBLY

(1) Assemble cylinder head assembly

- ※ Check for scratches or rough surfaces if found smooth with an oil stone.


- ① Coat the inner face of gland (3) with hydraulic oil.



- ② Coat dust wiper (4) with grease and fit dust wiper (4) to the bottom of the hole of dust seal.

At this time, press a pad metal to the metal ring of dust seal.


- ③ Fit retain ring (5) to the stop face.



- ④ Fit back up ring (8), rod seal (7) to corresponding grooves, in that order.


- ※ Coat each packing with hydraulic oil before fitting it.

- ※ Insert the backup ring until one side of it is inserted into groove.




- ※ Rod seal (7) has its own fitting direction. Therefore, confirm it before fitting them.

- ※ Fitting rod seal (7) upside down may damage its lip. Therefore check the correct direction that is shown in fig.




- ⑤ Fit back up ring (10) to gland (3).
- ※ Put the backup ring in the warm water of 30~50°C .
- ⑥ Fit O-ring (9) to gland (3).




(2) Assemble piston assembly


- ※ Check for scratches or rough surfaces.
If found smooth with an oil stone.
- ① Coat the outer face of piston (12) with hydraulic oil.



- ② Fit piston seal (13) to piston.
- ※ Put the piston seal in the warm water of 60~100°C for more than 5 minutes.
- ※ After assembling the piston seal, press its outer diameter to fit in.




- ③ Fit wear ring (14) and dust ring (22) to piston (12).




(3) Install piston and cylinder head


- ① Fix the rod assembly to the work bench.
- ② Apply hydraulic oil to the outer surface of rod assembly (2), the inner surface of piston and gland.
- ③ Insert gland assembly to rod assembly.




- ④ Insert cushion ring (19) to rod assembly.
- ※ Note that cushion ring (19) has a direction in which it should be fitted.



- ⑤ Fit piston assembly to rod assembly.





- ⑥ Fit set screw (17).
- Tightening torque :
 $2 \pm 0.2 \text{ kgf} \cdot \text{m}$ ($14.5 \pm 1.45 \text{ lbf} \cdot \text{ft}$)



(3) Overall assemble

- ① Place a V-block on a rigid work bench.
Mount the tube assembly (1) on it and fix the assembly by passing a bar through the clevis pin hole to lock the assembly.
- ② Insert the rod assembly in to the tube assembly, while lifting and moving the rod assembly (2) with a crane.
 - ※ Be careful not to damage piston seal (13) by thread of tube assembly (1).
- ③ Match the bolt holes in the cylinder head flange to the tapped holes in the tube assembly and tighten socket bolts to a specified torque.
 - ※ Refer to the table of tightening torque.




GROUP 10 UNDERCARRIAGE


1. RUBBER TRACK

1) REMOVAL

- (1) Loosen tension of the rubber track.
 - ※ If track tension is not relieved when the grease valve is loosened, move the machine backwards and forwards.




- (2) Remove the rubber track from lower frame using pry.



2) INSTALL


- (1) Carry out installation in the reverse order to removal.
 - ※ Adjust the tension of the rubber track.



2. TRACK ROLLER


1) REMOVAL

- (1) Loosen tension of the rubber track.




- (2) Using the work equipment, push up track frame on side which is to be removed.

※ After jack up the machine, set a block under the unit.



- (3) Remove the mounting bolt (1) and draw out the track roller (2).

- Weight : 3 kg (7 lb)
- Tightening torque : $12.3 \pm 1.2 \text{ kgf} \cdot \text{m}$
($89 \pm 8.7 \text{ lbf} \cdot \text{ft}$)




2) INSTALL

- (1) Carry out installation in the reverse order to removal.


3. IDLER AND RECOIL SPRING

1) REMOVAL

- (1) Remove the track link.
For detail, see removal of track link.
- (2) Sling the idler (1) and pull out idler and recoil spring assembly from track frame, using a pry.
 - Weight : 15 kg (33 lb)




- (3) Pull out yoke and spring weld assembly from track frame, using a pry.
 - Weight : 11 kg (24 lb)




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
 - ※ Make sure that the boss on the end face of the recoil cylinder rod is in the hole of the track frame.



3) DISASSEMBLY AND ASSEMBLY OF IDLER

(1) Structure




1697UC06


- | | | | | | |
|---|---------|---|--------------|---|-----------|
| 1 | Shell | 4 | Ball bearing | 7 | Snap ring |
| 2 | Bracket | 5 | Pin | 8 | Snap ring |
| 3 | Shaft | 6 | Oil seal | 9 | Plug |

(2) Disassembly


- ① Remove plug and drain oil.
- ② Draw out the spring pin (5), using a press.




- ③ Remove brackets (2) from shaft.



- ④ Remove seal assembly (6) from shell (1) by pry.
- ※ Do not reuse seal assembly after removal.
- ⑤ Remove snap ring (7) from shell (1)




- ⑥ Draw out the ball bearing (4) with shaft (3) using press.
- ⑦ Remove the ball bearing (4) from shaft, using a special tool.
- ※ Only remove ball bearing if replacement is necessity.




(3) Assembly


- ※ Before assembly, clean the parts.
- ※ Coat the sliding surfaces of all parts with oil.
- ① Do not press it at the normal temperature, assemble ball bearing (4) to shaft (3) by press.




- ② Insert shaft (3) with ball bearing (4) assembly to shell (1).




- ③ Assemble snap ring (7) and seal assembly (6).




- ④ Assemble bracket (2) to shell (1).




- ⑤ Install bracket (2) attached with seal (6).



- ⑥ Knock in the spring pin (5) with a hammer.




- ⑦ Lay bracket (2) on its side.
Supply engine oil to the specified level,
and tighten plug.



4) DISASSEMBLY AND ASSEMBLY OF RECOIL SPRING

(1) Structure



1697UC13

- | | | | | | |
|---|------------|---|--------------|----|------------|
| 1 | Cylinder | 5 | Castle nut | 9 | Packing |
| 2 | Piston rod | 6 | Split pin | 10 | Valve assy |
| 3 | Bracket | 7 | O-ring | | |
| 4 | Spring | 8 | Back-up ring | | |


(2) Disassembly

- ① Apply pressure on bracket (3) with a press.


The spring is under a large installed load. This is dangerous, so be sure to set properly.

- Spring set load : 875 kg (1930 lb)


- ※ Remove split pin (6) and nut (5).
- ② Take enough notice so that the press which pushes down the spring, should not be slipped out in its operation.
 - ③ Lighten the press load slowly and remove bracket (6) and spring (4).



- ⑤ Remove piston rod (1) from cylinder (2).
- ⑥ Remove grease valve (10) from piston rod (1).




- ⑦ Remove packing (9), back-up ring (8) and O-ring (7) from cylinder (1).



(3) Assembly


- ① Install O-ring (7), back-up ring (8), and packing (9) cylinder (1).




- ② Pour grease into cylinder (1), then push in piston rod (2) by hand.
After take grease out of grease valve mounting hole, let air out.

※ If air letting is not sufficient, it may be difficult to adjust the tension of crawler.


- ③ Fit grease valve (10) to piston rod (2).
• Tightening torque : $10 \pm 0.5 \text{ kgf} \cdot \text{m}$
($72.4 \pm 3.6 \text{ lbf} \cdot \text{ft}$)




- ④ Install piston rod (2) to cylinder (1).



- ⑤ Install spring (4) to cylinder (1).
- ⑥ Apply pressure to bracket (3) with a press and tighten nut (5).
- ※ During the operation, pay attention specially to prevent the press from slipping out.
- ⑦ Tighten nut (5) and insert split pin (6).





- ⑧ Lighten the press load and confirm the set length of spring (4).
 - Spring length : 223 mm (8.8")




GROUP 11 WORK EQUIPMENT


1. STRUCTURE




SECTION A-A




SECTION B-B



SECTION C-C



SECTION D-D



SECTION E-E


1697AT01

2. REMOVAL AND INSTALL


1) BUCKET ASSEMBLY

(1) Removal


- ① Lower the work equipment completely to ground with back of bucket facing down.



- ② Remove nut (1), bolt (2) and draw out the pin (4).



- ③ Remove nut (1), bolt (2) and draw out the pin (3) then remove the bucket assembly.
 - Weight : 40 kg (90 lb)




(2) Install

- ① Carry out installation in the reverse order to removal.

▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.

※ Adjust the bucket clearance.
For detail, see operator's manual.



2) ARM ASSEMBLY

(1) Removal

- ※ Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

- ① Remove bucket assembly.

For details, see removal of bucket assembly.

- ② Disconnect bucket cylinder hose (4).

▲ Fit blind plugs (5) in the piping at the chassis end securely to prevent oil from spurting out when the engine is started.

- ③ Sling arm cylinder assembly, remove spring, pin stopper and pull out pin.

- ※ Tie the rod with wire to prevent it from coming out.




- ④ For details, see removal of arm cylinder assembly.

Place a wooden block under the cylinder and bring the cylinder down to it.

- ⑤ Remove bolt (1) and pull out the pin (2) then remove the arm assembly.

· Weight : 30 kg (70 lb)

- ※ When lifting the arm assembly, always lift the center of gravity.



(2) Install

- ① Carry out installation in the reverse order to removal.


▲ When lifting the arm assembly, always lift the center of gravity.

- ※ Bleed the air from the cylinder.


3) BOOM CYLINDER

(1) Removal


- ① Remove arm and bucket assembly.
For details, see removal of arm and bucket assembly.
- ② Remove boom cylinder assembly from boom.
For details, see removal of arm cylinder assembly.



- ③ Disconnect head lamp wiring.
- ④ Disconnect bucket cylinder hose (2) and arm cylinder hose (1).
※ When the hose are disconnected, oil may spurt out.
- ⑤ Sling boom assembly (3).




- ⑥ Remove bolt (3), nut (4) and pull out the pin (5) then remove boom assembly.
· Weight : 65 kg (140 lb)
※ When lifting the boom assembly always lift the center of gravity.



(2) Install

- ① Carry out installation in the reverse order to removal.
- ▲ When lifting the arm assembly, always lift the center of gravity.
- ※ Bleed the air from the cylinder.




SECTION 8 COMPONENT MOUNTING TORQUE

Group 1	Introduction guide	8-1
Group 2	Engine system	8-2
Group 3	Electric system	8-4
Group 4	Hydraulic system	8-5
Group 5	Undercarriage	8-7
Group 6	Structure	8-8
Group 7	Work equipment	8-10

SECTION 8 COMPONENT MOUNTING TORQUE


GROUP 1 INTRODUCTION GUIDE

1. This section shows bolt specifications and standard torque values needed when mounting components to the machine.
 2. Use genuine Hyundai spare parts.
We expressly point out that Hyundai will not accept any responsibility for defects resulted from non-genuine parts.
In such cases Hyundai cannot assume liability for any damage.
- ※ **Only metric fasteners can be used and incorrect fasteners may result in machine damage or malfunction.**
 - ※ **Before installation, clean all the components with a non-corrosive cleaner. Bolts and threads must not be worn or damaged.**



GROUP 2 ENGINE SYSTEM

1. ENGINE AND ACCESSORIES MOUNTING




1698CM01

• Tightening torque

Item	Size	kgf · m	lbf · ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6
3	M10×1.5	6.9±1.4	49.9±10.1

Item	Size	kgf · m	lbf · ft
4	M10×1.25	12.8±3.0	93±22.0
5	M12×1.75	12.3±1.5	88.9±10.8

2. COOLING SYSTEM AND FUEL TANK MOUNTING



1698CM02


• Tightening torque

Item	Size	kgf · m	lbf · ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6

Item	Size	kgf · m	lbf · ft
3	M 10×1.5	6.9±1.4	49.9±10.1
4	M 12×1.75	12.8±3.0	92.6±21.7

GROUP 3 ELECTRIC SYSTEM

1. ELECTRIC COMPONENTS MOUNTING 1



1698CM03


• Tightening torque

Item	Size	kgf · m	lbf · ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6

Item	Size	kgf · m	lbf · ft
3	M10×1.5	6.9±1.4	49.9±10.1

GROUP 4 HYDRAULIC SYSTEM

1. HYDRAULIC COMPONENTS MOUNTING 1




1698CM05

· Tightening torque


Item	Size	kgf · m	lbf · ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6

Item	Size	kgf · m	lbf · ft
3	M10×1.5	6.9±1.4	49.9±10.1
4	M12×1.75	12.8±3.0	93±22.0


2. HYDRAULIC COMPONENTS MOUNTING 2



Boom cylinder




Arm cylinder




Bucket cylinder



Extension cylinder



Boom swing cylinder



Blade cylinder

1698CM07

• Tightening torque


1) Gland

Item	Size	kgf · m	lbf · ft
Boom cylinder	M65	52 ± 5.0	376 ± 36.2
Arm cylinder	M65	52 ± 5.0	376 ± 36.2
Bucket cylinder	M60	48 ± 5.0	347 ± 36.2
Dozer cylinder	M70	56 ± 5.0	405 ± 36.2
Boom swing cylinder	M60	48 ± 4.8	347 ± 34.7
Extension cylinder	M55	44 ± 4.5	318 ± 32.5

2) Piston

Item	Size	kgf · m	lbf · ft
Boom cylinder	M28	70 ± 7.0	506 ± 50.6
Arm cylinder	M28	70 ± 7.0	506 ± 50.6
Bucket cylinder	M24	60 ± 6.0	434 ± 43.4
Dozer cylinder	M24	60 ± 6.0	434 ± 43.4
Boom swing cylinder	M24	60 ± 6.0	434 ± 43.4
Extension cylinder	M20	50 ± 5.0	362 ± 36.2

GROUP 5 UNDERCARRIAGE



1698CM08


• Tightening torque

Item	Size	kgf · m	lbf · ft
1	M10 × 1.5	6.9 ± 0.7	49.9 ± 5.1
2	M10 × 1.5	6.9 ± 1.4	49.9 ± 10.1

Item	Size	kgf · m	lbf · ft
3	M12 × 1.75	12.8 ± 3.0	93 ± 22.0

GROUP 6 STRUCTURE

1. CANOPY AND ACCESSORIES MOUNTING




1698CM09

• Tightening torque

Item	Size	kgf · m	lbf · ft
1	M 8 × 1.25	2.5 ± 0.5	18.1 ± 3.6
2	M10 × 1.5	6.9 ± 1.4	50 ± 10

Item	Size	kgf · m	lbf · ft
3	M12 × 1.75	12.8 ± 3.0	92.6 ± 21.7

2. COWLING MOUNTING




1698CM10

・ Tightening torque

Item	Size	kgf · m	lbf · ft
1	M 8×1.25	2.5±0.5	18.1±3.6
2	M10×1.5	6.0±1.4	43.4±10.1

Item	Size	kgf · m	lbf · ft
3	M16×2.0	29.7±4.5	215±32.5

GROUP 7 WORK EQUIPMENT



1698CM11

· Tightening torque

Item	Size	kgf · m	lbf · ft
1	M10 × 1.5	6.0 ± 1.4	43.4 ± 10.1
2	M12 × 1.75	12.8 ± 3.0	92.6 ± 21.7

Item	Size	kgf · m	lbf · ft
3	M16 × 1.5	31.3 ± 4.7	226 ± 34