SECTION 1 GENERAL

Group	1	Safety Hints	1-1
Group	2	Specifications	1-10

SECTION 2 STRUCTURE AND FUNCTION

Group	1 Pump Device	2-1
Group	2 Main Control Valve	2-20
Group	3 Swing Device	2-46
Group	4 Travel Device	2-58
Group	5 RCV Lever ·····	2-71
Group	6 RCV Pedal	2-78

SECTION 3 HYDRAULIC SYSTEM

Group 1 Hydraulic Circuit	3-1
Group 2 Main Circuit	
Group 3 Pilot Circuit ·····	
Group 4 Single Operation	3-13
Group 5 Combined Operation	3-23

SECTION 4 ELECTRICAL SYSTEM

Group	1 Component Location	4-1
Group	2 Electric Circuit	4-3
Group	3 Electrical Component Specification	4-21
Group	4 Connectors	4-29

SECTION 5 MECHATRONICS SYSTEM

Group	1 Outline	5-1
Group	2 Mode selection System ·····	5-3
Group	3 Automatic Deceleration System	5-6
Group	4 Power Boost System	5-7
Group	5 Travel Speed Control System	5-8
Group	6 Automatic Warming Up System	5-9
Group	7 Engine Overheat Prevention System	5-10
Group	8 Variable power Control System	5-11
Group	9 Attachment Flow Control System	5-12

Group 10 Anti-rest	art System	5-13
Group 11 Self-Dia	gnostic System ·····	5-14
Group 12 Engine (Control System	5-27
Group 13 EPPR (B	Electro Proportional Pressure Reducing) Valve	5-28
Group 14 Monitori	ng System ·····	5-33
Group 15 Fuel Wa	rmer System ·····	5-56

SECTION 6 TROUBLESHOOTING

Group	1 Before Troubleshooting	6-1
Group	2 Hydraulic and Mechanical System	6-4
Group	3 Electrical System	6-24
Group	4 Mechatronics System	6-40

SECTION 7 MAINTENANCE STANDARD

Group	1 Operational Performance Test	7-1
Group	2 Major Components	7-21
Group	3 Track and Work Equipment	7-29

SECTION 8 DISASSEMBLY AND ASSEMBLY

Group	1	Precaution	8-1
Group	2	Tightening Torque	8-4
Group	3	Pump Device	8-7
Group	4	Main Control Valve	8-31
Group	5	Swing Device	8-51
Group	6	Travel Device	8-71
Group	7	RCV Lever ·····	8-103
Group	8	Turning Joint	8-117
Group	9	Boom, Arm and Bucket Cylinder	8-122
Group	10	Undercarriage	8-139
Group ⁻	11	Work Equipment	8-151

SECTION 9 COMPONENT MOUNTING TORQUE

Group	1 Introduction guide	9-1
Group	2 Engine system ·····	9-2
Group	3 Electric system ·····	9-4
Group	4 Hydraulic system	9-6
	5 Undercarriage	
Group	6 Structure	9-10
	7 Work equipment	

1. STRUCTURE

This service manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This service manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into the following sections.

SECTION 1 GENERAL

This section explains the safety hints and gives the specification of the machine and major components.

SECTION 2 STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

SECTION 3 HYDRAULIC SYSTEM

This section explains the hydraulic circuit, single and combined operation.

SECTION 4 ELECTRICAL SYSTEM

This section explains the electrical circuit, monitoring system and each component. It serves not only to give an understanding electrical system, but also serves as reference material for trouble shooting.

SECTION 5 MECHATRONICS SYSTEM

This section explains the computer aided power optimization system and each component.

SECTION 6 TROUBLESHOOTING

This section explains the troubleshooting charts correlating problems to causes.

SECTION 7 MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

SECTION 8 DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

SECTION 9 COMPONENT MOUNTING TORQUE

This section shows bolt specifications and standard torque values needed when mounting components to the machine.

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your HYUNDAI distributor for the latest information.

2. HOW TO READ THE SERVICE MANUAL

Distribution and updating

Any additions, amendments or other changes will be sent to HYUNDAI distributors.

Get the most up-to-date information before you start any work.

Filing method

1. See the page number on the bottom of the page.

File the pages in correct order.

2. Following examples shows how to read the page number.

Example 1



- Item number(2. Structure and Function)

Consecutive page number for each item.

- 3. Additional pages : Additional pages are indicated by a hyphen(-) and number after the page number. File as in the example.
 - 10 4

10 - 5

Revised edition mark(123...)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

Revisions

Revised pages are shown at the list of revised pages on the between the contents page and section 1 page.

Symbols

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol	Item	Remarks		
	Safety	Special safety precautions are necessary when performing the work.		
	Salety	Extra special safety precautions are necessary when performing the work because it is under internal pressure.		
*	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.		

3. CONVERSION TABLE

Method of using the Conversion Table

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

Example

1. Method of using the Conversion Table to convert from millimeters to inches

Convert 55mm into inches.

- (1) Locate the number 50in the vertical column at the left side, take this as (a), then draw a horizontal line from (a).
- (2) Locate the number 5in the row across the top, take this as (b), then draw a perpendicular line down from (b).
- (3) Take the point where the two lines cross as (2). This point (2) gives the value when converting from millimeters to inches. Therefore, 55mm = 2.165 inches.
- 2. Convert 550mm into inches.
 - (1) The number 550 does not appear in the table, so divide by 10(Move the decimal point one place to the left) to convert it to 55mm.
 - (2) Carry out the same procedure as above to convert 55mm to 2.165 inches.
 - (3) The original value(550mm) was divided by 10, so multiply 2.165 inches by 10(Move the decimal point one place to the right) to return to the original value. This gives 550mm = 21.65 inches.

	Millimeters to inches				b			1mm =	1mm = 0.03937 in			
		0	1	2	3	4	5	6	7	8	9	
Ī	0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354	
	10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748	
	20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142	
	30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536	
	40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929	
							©					
a	50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323	
	60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717	
	70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110	
	80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504	
	90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898	

Millimotoro to incheo

Millimeters to inches

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Kilogram to Pound

1kg = 2.2046lb

									3	
	0	1	2	3	4	5	6	7	8	9
0		2.20	4.41	6.61	8.82	11.02	13.23	15.43	17.64	19.84
10	22.05	24.25	26.46	28.66	30.86	33.07	35.27	37.48	39.68	41.89
20	44.09	46.30	48.50	50.71	51.91	55.12	57.32	59.5.	61.73	63.93
30	66.14	68.34	70.55	72.75	74.96	77.16	79.37	81.57	83.78	85.98
40	88.18	90.39	92.59	94.80	97.00	99.21	101.41	103.62	105.82	108.03
50	110.23	112.44	114.64	116.85	119.05	121.25	123.46	125.66	127.87	130.07
60	132.28	134.48	136.69	138.89	141.10	143.30	145.51	147.71	149.91	152.12
70	154.32	156.53	158.73	160.94	163.14	165.35	167.55	169.76	171.96	174.17
80	176.37	178.57	180.78	182.98	185.19	187.39	189.60	191.80	194.01	196.21
90	198.42	200.62	202.83	205.03	207.24	209.44	211.64	213.85	216.05	218.26

Liter to U.S. Gallon

1 l = 0.2642 U.S.Gal

	0	1	2	3	4	5	6	7	8	9
0		0.264	0.528	0.793	1.057	1.321	1.585	1.849	2.113	2.378
10	2.642	2.906	3.170	3.434	3.698	3.963	4.227	4.491	4.755	5.019
20	5.283	5.548	5.812	6.6076	6.340	6.604	6.869	7.133	7.397	7.661
30	7.925	8.189	8.454	8.718	8.982	9.246	9.510	9.774	10.039	10.303
40	10.567	10.831	11.095	11.359	11.624	11.888	12.152	12.416	12.680	12.944
50	13.209	13.473	13.737	14.001	14.265	14.529	14.795	15.058	15.322	15.586
60	15.850	16.115	16.379	16.643	16.907	17.171	17.435	17.700	17.964	18.228
70	18.492	18.756	19.020	19.285	19.549	19.813	20.077	20.341	20.605	20.870
80	21.134	21.398	21.662	21.926	22.190	22.455	22.719	22.983	23.247	23.511
90	23.775	24.040	24.304	24.568	24.832	25.096	25.631	25.625	25.889	26.153

Liter to U.K. Gallon

1 *l* = 0.21997 U.K.Gal

	0	1	2	3	4	5	6	7	8	9
0		0.220	0.440	0.660	0.880	1.100	1.320	1.540	1.760	1.980
10	2.200	2.420	2.640	2.860	3.080	3.300	3.520	3.740	3.950	4.179
20	4.399	4.619	4.839	5.059	5.279	5.499	5.719	5.939	6.159	6.379
30	6.599	6.819	7.039	7.259	7.479	7.969	7.919	8.139	8.359	8.579
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.778
50	10.998	11.281	11.438	11.658	11.878	12.098	12.318	12.528	12.758	12.978
60	13.198	13.418	13.638	13.858	14.078	14.298	14.518	14.738	14.958	15.178
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378
80	17.598	17.818	18.037	18.257	18.477	18.697	18.917	19.137	19.357	19.577
90	19.797	20.017	20.237	20.457	20.677	20.897	21.117	21.337	21.557	21.777

kgf ∙	m	to	lbf	•	ft
-------	---	----	-----	---	----

 $1 \text{kgf} \cdot \text{m} = 7.233 \text{lbf} \cdot \text{ft}$

	0	1	2	3	4	5	6	7	8	9
		7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	396.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	10005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4

kgf/cm² to lbf/in²

1kgf / cm² = 14.2233lbf / in²

									/ UIII = 14.	
	0	1	2	3	4	5	6	7	8	9
		14.2	28.4	42.7	56.9	71.1	85.3	99.6	113.8	128.0
10	142.2	156.5	170.7	184.9	199.1	213.4	227.6	241.8	256.0	270.2
20	284.5	298.7	312.9	327.1	341.4	355.6	369.8	384.0	398.3	412.5
30	426.7	440.9	455.1	469.4	483.6	497.8	512.0	526.3	540.5	554.7
40	568.9	583.2	597.4	611.6	625.8	640.1	654.3	668.5	682.7	696.9
50	711.2	725.4	739.6	753.8	768.1	782.3	796.5	810.7	825.0	839.2
60	853.4	867.6	881.8	896.1	910.3	924.5	938.7	953.0	967.2	981.4
70	995.6	1010	1024	1038	1053	1067	1081	1095	1109	1124
80	1138	1152	1166	1181	1195	1209	1223	1237	1252	1266
90	1280	1294	1309	1323	1337	1351	1365	1380	1394	1408
100	1422	1437	1451	1465	1479	1493	1508	1522	1536	1550
110	1565	1579	1593	1607	1621	1636	1650	1664	1678	1693
120	1707	1721	1735	1749	1764	1778	1792	1806	1821	1835
130	1849	2863	1877	1892	1906	1920	1934	1949	1963	1977
140	1991	2005	2020	2034	2048	2062	2077	2091	2105	2119
150	2134	2148	2162	2176	2190	2205	2219	2233	2247	2262
160	2276	2290	2304	2318	2333	2347	2361	2375	2389	2404
170	2418	2432	2446	2460	2475	2489	2503	2518	2532	2546
180	2560	2574	2589	5603	2617	2631	2646	2660	2674	2688
200	2845	2859	2873	2887	2901	2916	2930	2944	2958	2973
210	2987	3001	3015	3030	3044	3058	3072	3086	3101	3115
220	3129	3143	3158	3172	3186	3200	3214	3229	3243	3257
230	3271	3286	3300	3314	3328	3343	3357	3371	3385	3399
240	3414	3428	3442	3456	3470	3485	3499	3513	3527	3542

TEMPERATURE

Fahrenheit-Centigrade Conversion.

A simple way to convert a fahrenheit temperature reading into a centigrade temperature reading or vice verse is to enter the accompanying table in the center or boldface column of figures.

These figures refer to the temperature in either Fahrenheit or Centigrade degrees.

If it is desired to convert from Fahrenheit to Centigrade degrees, consider the center column as a table of Fahrenheit temperatures and read the corresponding Centigrade temperature in the column at the left.

If it is desired to convert from Centigrade to Fahrenheit degrees, consider the center column as a table of Centigrade values, and read the corresponding Fahrenheit temperature on the right.

°C		°F	°C		°F	°C		°F	°C		°F
-40.4	-40	-40.0	-11.7	11	51.8	7.8	46	114.8	27.2	81	117.8
-37.2	-35	-31.0	-11.1	12	53.6	8.3	47	116.6	27.8	82	179.6
-34.4	-30	-22.0	-10.6	13	55.4	8.9	48	118.4	28.3	83	181.4
-31.7	-25	-13.0	-10.0	14	57.2	9.4	49	120.2	28.9	84	183.2
-28.9	-20	-4.0	-9.4	15	59.0	10.0	50	122.0	29.4	85	185.0
-28.3	-19	-2.2	-8.9	16	60.8	10.6	51	123.8	30.0	86	186.8
-27.8	-18	-0.4	-8.3	17	62.6	11.1	52	125.6	30.6	87	188.6
-27.2	-17	1.4	-7.8	18	64.4	11.7	53	127.4	31.1	88	190.4
-26.7	-16	3.2	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-26.1	-15	5.0	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-25.6	-14	6.8	-6.1	21	69.8	13.3	56	132.8	32.8	91	195.8
-25.0	-13	8.6	-5.6	22	71.6	13.9	57	134.6	33.3	92	197.6
-24.4	-12	10.4	-5.0	23	73.4	14.4	58	136.4	33.9	93	199.4
-23.9	-11	12.2	-4.4	24	75.2	15.0	59	138.2	34.4	94	201.2
-23.3	-10	14.0	-3.9	25	77.0	15.6	60	140.0	35.0	95	203.0
-22.8	-9	15.8	-3.3	26	78.8	16.1	61	141.8	35.6	96	204.8
-22.2	-8	17.6	-2.8	27	80.6	16.7	62	143.6	36.1	97	206.6
-21.7	-7	19.4	-2.2	28	82.4	17.2	63	145.4	36.7	98	208.4
-21.1	-6	21.2	-1.7	29	84.2	17.8	64	147.2	37.2	99	210.2
-20.6	-5	23.0	-1.1	35	95.0	21.1	70	158.0	51.7	125	257.0
-20.0	-4	24.8	-0.6	31	87.8	18.9	66	150.8	40.6	105	221.0
-19.4	-3	26.6	0	32	89.6	19.4	67	152.6	43.3	110	230.0
-18.9	-2	28.4	0.6	33	91.4	20.0	68	154.4	46.1	115	239.0
-18.3	-1	30.2	1.1	34	93.2	20.6	69	156.2	48.9	120	248.0
-17.8	0	32.0	1.7	35	95.0	21.1	70	158.0	51.7	125	257.0
-17.2	1	33.8	2.2	36	96.8	21.7	71	159.8	54.4	130	266.0
-16.7	2	35.6	2.8	37	98.6	22.2	72	161.6	57.2	135	275.0
-16.1	3	37.4	3.3	38	100.4	22.8	73	163.4	60.0	140	284.0
-15.6	4	39.2	3.9	39	102.2	23.3	74	165.2	62.7	145	293.0
-15.0	5	41.0	4.4	40	104.0	23.9	75	167.0	65.6	150	302.0
-14.4	6	42.8	5.0	41	105.8	24.4	76	168.8	68.3	155	311.0
-13.9	7	44.6	5.6	42	107.6	25.0	77	170.6	71.1	160	320.0
-13.3	8	46.4	6.1	43	109.4	25.6	78	172.4	73.9	165	329.0
-12.8	9	48.2	6.7	44	111.2	26.1	79	174.2	76.7	170	338.0
-12.2	10	50.0	7.2	45	113.0	26.7	80	176.0	79.4	172	347.0

Group	1	Safety Hints	1-1
Group	2	Specifications	1-10


GROUP 1 SAFETY

FOLLOW SAFE PROCEDURE

Unsafe work practices are dangerous. Understand service procedure before doing work; Do not attempt shortcuts.

WEAR PROTECTIVE CLOTHING


Wear close fitting clothing and safety equipment appropriate to the job.



WARN OTHERS OF SERVICE WORK

Unexpected machine movement can cause serious injury.

Before performing any work on the excavator, attach a **Do Not Operate** tag on the right side control lever.




USE HANDHOLDS AND STEPS

Falling is one of the major causes of personal injury.

When you get on and off the machine, always maintain a three point contact with the steps and handrails and face the machine. Do not use any controls as handholds.

Never jump on or off the machine. Never mount or dismount a moving machine.

Be careful of slippery conditions on platforms, steps, and handrails when leaving the machine.




PREPARE FOR EMERGENCIES

Be prepared if a fire starts.


Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



PROTECT AGAINST FLYING DEBRIS


Guard against injury from flying pieces of metal or debris; Wear goggles or safety glasses.



PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.


Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



AVOID POWER LINES

Serious injury or death can result from contact with electric lines.

Never move any part of the machine or load closer to electric line than 3m(10ft) plus twice the line insulator length.



KEEP RIDERS OFF EXCAVATOR

Only allow the operator on the excavator. Keep riders off.

Riders on excavator are subject to injury such as being struck by foreign objects and being thrown off the excavator. Riders also obstruct the operator's view resulting in the excavator being operated in an unsafe manner.

MOVE AND OPERATE MACHINE SAFELY

Bystanders can be run over. Know the location of bystanders before moving, swinging, or operating the machine.


Always keep the travel alarm in working condition. It warns people when the excavator starts to move.


Use a signal person when moving, swinging, or operating the machine in congested areas. Coordinate hand signals before starting the excavator.

OPERATE ONLY FORM OPERATOR'S SEAT

Avoid possible injury machine damage. Do not start engine by shorting across starter terminals.

NEVER start engine while standing on ground. Start engine only from operator's seat.







PARK MACHINE SAFELY

Before working on the machine:

- \cdot Park machine on a level surface.
- \cdot Lower bucket to the ground.
- · Turn auto idle switch off.
- \cdot Run engine at 1/2 speed without load for 2 minutes.
- Turn key switch to OFF to stop engine. Remove key from switch.
- \cdot Move pilot control shutoff lever to locked position.
- · Allow engine to cool.

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.


Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load.

Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands.





HANDLE FLUIDS SAFELY-AVOID FIRES


Handle fuel with care; It is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks. Always stop engine before refueling machine. Fill fuel tank outdoors.



Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; They can ignite and burn spontaneously.



BEWARE OF EXHAUST FUMES

Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.

If you must operate in a building, be positive there is adequate ventilation. Either use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring enough outside air into the area.

REMOVE PAINT BEFORE WELDING OR HEATING

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:


• If you sand or grind paint, avoid breathing the dust.


Wear an approved respirator.

 If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.





SERVICE MACHINE SAFELY


Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.


Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.

STAY CLEAR OF MOVING PARTS

Entanglements in moving parts can cause serious injury.

To prevent accidents, use care when working around rotating parts.






AVOID HIGH PRESSURE FLUIDS


Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.





AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials.

Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area. Install fire resisting guards to protect hoses or other materials.



PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; It may explode. Warm battery to $16^{\circ}C$ ($60^{\circ}F$).



PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


- 1. Filling batteries in a well-ventilated area.
- 2. Wearing eye protection and rubber gloves.
- 3. Avoiding breathing fumes when electrolyte is added.
- 4. Avoiding spilling of dripping electrolyte.
- 5. Use proper jump start procedure.

If you spill acid on yourself:

- 1. Flush your skin with water.
- 2. Apply baking soda or lime to help neutralize the acid.
- 3. Flush your eyes with water for 10-15 minutes. Get medical attention immediately.

If acid is swallowed:

- 1. Drink large amounts of water or milk.
- 2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
- 3. Get medical attention immediately.




USE TOOLS PROPERLY

Use tools appropriate to the work. Makeshift tools, parts, and procedures can create safety hazards.

Use power tools only to loosen threaded tools and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only recommended replacement parts. (See Parts catalogue.)




DISPOSE OF FLUIDS PROPERLY

Improperly disposing of fluids can harm the environment and ecology. Before draining any fluids, find out the proper way to dispose of waste from your local environmental agency.


Use proper containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

DO NOT pour oil into the ground, down a drain, or into a stream, pond, or lake. Observe relevant environmental protection regulations when disposing of oil, fuel, coolant, brake fluid, filters, batteries, and other harmful waste.



REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.





LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.

GROUP 2 SPECIFICATIONS


1. MAJOR COMPONENT





38092SP01

2. SPECIFICATIONS




38092SP02

Description		Unit	Specification
Operating weight		kg (lb)	38200 (84220)
Bucket capacity (SAE heaped), standard		m³ (yd³)	1.62 (2.12)
Overall length	A		11120 (36' 6")
Overall width, with 600 mm shoe	В		3340 (10'11")
Overall height	С		3450 (11' 4")
Superstructure width	D		2980 (9' 9")
Overall height of cab	E		3175 (10' 5")
Ground clearance of counterweight	F		1290 (4' 3")
Engine cover height	G		3190 (10' 6")
Minimum ground clearance	Н	mm (ft-in)	550 (1' 10")
Rear-end distance	I		3350 (11' 1")
Rear-end swing radius	ľ		3415 (11' 2")
Distance between tumblers	J		4340 (14' 3")
Undercarriage length	К		5280 (17' 4")
Undercarriage width	L		3340 (11' 0")
Track gauge	М		2740 (9' 0")
Track shoe width, standard	N		600 (24")
Travel speed (low/high)		km/hr (mph)	3.0/4.8 (1.9/3.0)
Swing speed		rpm	9.3
Gradeability		Degree (%)	35 (70)
Ground pressure (600 mm shoe)		kgf/cm²(psi)	0.68 (9.67)
Max traction force		kg (lb)	32000 (70550)

3. WORKING RANGE

1) 6.5 m (21' 4") BOOM




38092SP03

Description		2.5 m (8' 2") Arm	*3.2 m (10' 6") Arm	3.9 m (12' 10") Arm	4.3 m (14' 1") Arm
Max digging reach	А	10720 mm (35' 2")	11250 mm (36'11")	11870 mm (38'11")	12380 mm (40' 7")
Max digging reach on ground	A'	10490 mm (34' 5")	11040 mm (36' 3")	11670 mm (38' 3")	12180 mm (40' 0")
Max digging depth	В	6820 mm (22' 5")	7520 mm (24' 8")	8220 mm (27' 0")	8620 mm (28' 3")
Max digging depth (8ft level)	B'	6640 mm (21' 9")	7360 mm (24' 2")	8080 mm (26' 6")	8490 mm (27'10")
Max vertical wall digging depth	С	5930 mm (19' 5")	6330 mm (20' 9")	7040 mm (23' 1")	7540 mm (24' 9")
Max digging height	D	10590 mm (34' 9")	10570 mm (34' 8")	10800 mm (35' 5")	11360 mm (37' 3")
Max dumping height	Е	7370 mm (24' 2")	7410 mm (24' 4")	7640 mm (25' 1")	8160 mm (26' 9")
Min swing radius	F	4530 mm (14'10")	4450 mm (14' 7")	4440 mm (14' 7")	4460 mm (14' 8")
		201.0 [219.3] kN	201.0 [219.3] kN	201.0 [219.3] kN	201.0 [219.3] kN
	SAE	20500 [22360] kgf	20500 [22360] kgf	20500 [22360] kgf	20500 [22360] kgf
Pueket diaging force		45190 [49300] lbf	45190 [49300] lbf	45190 [49300] lbf	45190 [49300] lbf
Bucket digging force		228.5 [249.3] kN	228.5 [249.3] kN	228.5 [249.3] kN	228.5 [249.3] kN
	ISO	23300 [25420] kgf	23300 [25420] kgf	23300 [25420] kgf	23300 [25420] kgf
		51370 [56040] lbf	51370 [56040] lbf	51370 [56040] lbf	51370 [56040] lbf
		184.4 [201.1] kN	152.0 [165.8] kN	135.3 [147.6] kN	124.5 [135.9] kN
	SAE	18800 [20510] kgf	15500 [16910] kgf	13800 [15050] kgf	12700 [13850] kgf
Arm around force		41450 [45220] lbf	34170 [37280] lbf	30420 [33190] lbf	28000 [30550] lbf
Arm crowd force		192.2 [209.7] kN	156.9 [171.2] kN	139.3 [151.9] kN	128.5 [140.1] kN
	ISO	19600 [21380] kgf	16000 [17450] kgf	14200 [15490] kgf	13100 [14290] kgf
		43210 [47140] lbf	35270 [38480] lbf	31310 [34160] lbf	28880 [31510] lbf

[]: Power boost *: STD


· 6.15 m (20' 2") BOOM



38092SP03

Description		2.5 m (8' 2") Arm					
Max digging reach	А	10330 mm (33'11")					
Max digging reach on ground	A'	10100 mm (33' 2")					
Max digging depth	В	6450 mm (21' 2")					
Max digging depth (8ft level)	B'	6270 mm (20' 7")					
Max vertical wall digging depth	С	5490 mm (18' 0")					
Max digging height	D	10320 mm (33'10")					
Max dumping height	E	7120 mm (23' 4")					
Min swing radius	F	4220 mm (13'10")					
		201.0 [219.3] kN					
	SAE	20500 [22360] kgf					
Pueket diaging force		45190 [49300] lbf					
Bucket digging force		228.5 [249.3] kN					
	ISO	23300 [25420] kgf					
		51370 [56040] lbf					
		184.4 [201.1] kN					
	SAE	18800 [20510] kgf					
Arm crowd force		41450 [45220] lbf					
		192.2 [209.7] kN					
	ISO	19600 [21380] kgf					
		43210 [47140] lbf					

[]: Power boost



38092SP03

Description		5.1 m (16' 9") Arm
Max digging reach	Α	15280 mm (50' 2")
Max digging reach on ground	A'	15120 mm (49' 7")
Max digging depth	В	11230 mm (36'10")
Max digging depth (8ft level)	Β'	11120 mm (36' 6")
Max vertical wall digging depth	С	10060 mm (33' 0")
Max digging height	D	13350 mm (43'10")
Max dumping height	Е	10150 mm (33' 4")
Min swing radius	F	5900 mm (19' 4")
		201.0 [220.4] kN
	SAE	20500 [22470] kgf
Pueket diaging force		45190 [49550] lbf
Bucket digging force		228.5 [250.3] kN
	ISO	23300 [25530] kgf
		51370 [56280] lbf
		109.8 [119.8] kN
	SAE	11200 [12220] kgf
Arm around force		24690 [26930] lbf
Arm crowd force		112.8 [123.0] kN
	ISO	11500 [12550] kgf
		25350 [27650] lbf

[]: Power boost

4. WEIGHT

literer		R380	LC-9
Item	-	kg	lb
Upperstructure assembly		15040	33160
Main frame weld assembly		2995	6600
Engine assembly		740	1630
Main pump assembly		190	420
Main control valve assembly		340	750
Swing motor assembly		360	790
Hydraulic oil tank assembly		340	750
Fuel tank assembly		230	510
Countonuciebt	6.5, 6.15 m boom	6500	14330
Counterweight	8.6 m boom	8100	17860
Cab assembly		490	1080
Lower chassis assembly		14310	31550
Track frame weld assembly		5415	11940
Swing bearing		590	1300
Travel motor assembly		400	880
Turning joint		65	140
Track recoil spring and idler		270	600
Idler		230	510
Carrier roller		40	90
Track roller		80	180
Track-chain assembly (600 mm star	ndard triple grouser shoe)	2420	5340
Front attachment assembly (6.5 m t 1.62 m ³ SAE heaped bucket)	boom, 3.2 m arm,	7670	16910
6.5 m boom assembly		2930	6460
3.2 m arm assembly		1340	2950
1.62 m ³ SAE heaped bucket		1280	2820
Boom cylinder assembly		370	820
Arm cylinder assembly		490	1080
Bucket cylinder assembly		320	710
Bucket control linkage assembly		370	820

5. LIFTING CAPACITIES

1) 6.5 m (21' 4") boom, 3.2 m (10' 6") arm equipped with 1.62 m³ (SAE heaped) bucket and 600 mm (24") triple grouser shoe and 6500 kg (14330 lb) counterweight.

							Lood	radiua						٨+		ach
Lood			Load radius										ALT	nax. re	acn	
Load		1.5 m	(5.0 ft)	3.0 m (10.0 ft)	4.5 m (15.0 ft)	6.0 m (20.0 ft)	7.5 m (25.0 ft)	9.0 m (30.0 ft)	Сар	acity	Reach
heigh		ľ	⋳ ⋕	ľ		ľ	⋳⋣⋼	ľ	⋳⋕⋼	ľ	⋳⋣⋼	ľ	⋳⋕⋻	ľ)	m (ft)
9.0 m (30 ft)	kg Ib													*5950 *13120	*5950 *13120	7.97 (26.1)
7.5 m (25.0 ft)	kg Ib									*4560 *10050	*4560 *10050			*6020 *13270	4820 10630	9.12 (29.9)
6.0 m (20.0 ft)	kg Ib									*6620 *14590	*6620 *14590			*6110 *13470	4010 8840	9.87 (32.4)
4.5 m	kg							*8260	*8260	*7320	6530	*4450	*4450	*6190	3550	10.32
(15.0 ft)	lb							*18210	*18210	*16140	14400	*9810	*9810	*13650	7830	(33.9)
3.0 m	kg					*13520	*13520	*9960	8910	*8240	6150	*6360	4430	5940	3310	10.50
(10.0 ft)	lb					*29810	*29810	*21960	19640	*18170	13560	*14020	9770	13100	7300	(34.4)
1.5 m	kg					*16390	12870	*11570	8270	*9170	5790	*7510	4230	5890	3250	10.45
(5.0 ft)	lb					*36130	28370	*25510	18230	*20220	12760	*16560	9330	12990	7170	(34.3)
Ground	kg			*13090	*13090	*17880	12230	*12690	7820	*9880	5520	*7070	4090	6130	3380	10.14
Line	lb			*28860	*28860	*39420	26960	*27980	17240	*21780	12170	*15590	9020	13510	7450	(33.3)
-1.5 m	kg	*13720	*13720	*17520	*17520	*18150	12020	*13170	7600	9750	5370			6730	3740	9.57
(-5.0 ft)	lb	*30250	*30250	*38620	*38620	*40010	26500	*29030	16760	21500	11840			14840	8250	(31.4)
-3.0 m	kg	*17880	*17880	*22800	*22800	*17430	12080	*12880	7580	9750	5370			*7730	4490	8.65
(-10.0 ft)	lb	*39420	*39420	*50270	*50270	*38430	26630	*28400	16710	21500	11840			*17040	9900	(28.4)
-4.5 m	kg	*22600	*22600	*21880	*21880	*15520	12390	*11510	7790					*7690	6200	7.25
(-15.0 ft)	lb	*49820	*49820	*48240	*48240	*34220	27320	*25380	17170					*16950	13670	(23.8)
-6.0 m	kg					*11410	*11410									
(-20.0 ft)	lb					*25150	*25150									

· I Rating over-front · I Rating over-side or 360 degree

Note 1. Lifting capacity are based on SAE J1097 and ISO 10567.

2. Lifting capacity of the ROBEX series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.

3. The load point is a hook located on the back of the bucket.

4. *indicates load limited by hydraulic capacity.

. ,				5.	,		0				
				Load ı	radius				At	max. rea	ch
Load point	3.0 m ((10.0 ft)	4.5 m (15.0 ft)	6.0 m (20.0 ft)	7.5 m (25.0 ft)	Capa	acity	Reach
height	ŀ	⋳	ŀ	╔╼╋╸	ŀ	╔╋╸	ŀ	⋳╴╉╸╸	ľ		m (ft)
9.0 m kg (30.0 ft) lb									*7580 *16710	*7580 *16710	6.65 (21.8)
7.5 m kg (25.0 ft) lb									*7420 *16360	6190 13650	8.02 (26.3)
6.0 m kg (20.0 ft) lb					*8590 *18940	*8590 *18940	*6510 *14350	*6510 *14350	*7460 *16450	4980 10980	8.88 (29.1)
4.5 m kg (15.0 ft) lb	*18270 *40280	*18270 *40280	*12170 *26830	*12170 *26830	*9790 *21580	9680 21340	*8620 *19000	6560 14460	7480 16490	4350 9590	9.38 (30.8)
3.0 m kg (10.0 ft) lb			*15380 *33910	14190 31280	*11300 *24910	9030 19910	*9350 *20610	6250 13780	7050 15540	4040 8910	9.58 (31.4)
1.5 m kg (5.0 ft) lb			*17740 *39110	13080 28840	*12640 *27870	8450 18630	*10060 *22180	5940 13100	7010 15450	3980 8770	9.52 (31.2)
Ground kg Line lb	*13400 *29540	*13400 *29540	*18580 *40960	12560 27690	*13410 *29560	8060 17770	10120 22310	5710 12590	7360 16230	4170 9190	9.19 (30.2)
-1.5 m kg (-5.0 ft) lb	*21020 *46340	*21020 *46340	*18170 *40060	12420 27380	*13400 *29540	7880 17370	10010 22070	5610 12370	8290 18280	4710 10380	8.53 (28.0)
-3.0 m kg (-10 ft) lb	*22960 *50620	*22960 *50620	*16580 *36550	12540 27650	*12330 *27180	7930 17480			*8180 *18030	5950 13120	7.47 (24.5)
-1.5 m kg (-10 ft) lb	*17870 *39400	*17870 *39400	*13110 *28900	12970 28590							

(2) 6.15 m (20' 2") boom, 2.5 m (8' 2") arm equipped with 1.62 m³ (SAE heaped) bucket and 600 mm (24") triple grouser shoe and 6500 kg (14330 lb) counterweight.

(3) 8.6 m (28' 3") boom, 5.1 m (16' 9") arm equipped with 1.46 m³ (SAE heaped) bucket and 600 mm (24") triple grouser shoe and 8100 kg (17860 lb) counterweight.

										Load	radius	;								At m	nax. re	each
Load point		1.5 m ((5.0 ft)	3.0 m (10.0 ft)	4.5 m (15.0 ft)	6.0 m (20.0 ft)	7.5 m (25.0 ft)	9.0 m (30.0 ft)	10.5 m	(35.0 ft)	12.0 m	(40.0 ft)	13.5 m	(45.0 ft)	Сар	acity	Reach
heigh		ľ	.	ľ	⋐⋣⋑	ľ	╔╋╋	ŀ	⋐⋣⋣	ľ)	ŀ	⋐⋣⋑	ŀ	⋳⋕⋑	ŀ	⊫₽	ŀ	⋐⋕₽	ŀ	╔╋╋	m (ft)
9.0 m	kg													*3010	*3010					*3030	2510	12.91
(30 ft)	lb													*6640	*6640					*6680	5530	(42.4)
7.5 m	kg													*3110	*3110	*2630	*2630			*3100	2100	13.61
(25.0 ft)	lb													*6860	*6860	*5800	*5800			*6830	4630	(44.7)
6.0 m	kg													*3360	*3360	*3300	2820			*3180	1820	14.10
(20.0 ft)	lb													*7410	*7410	*7280	6220			*7010	4010	(46.3)
4.5 m	kg											*4100	*4100	*3730	3670	*3520	2680			*3290	1640	14.40
(15.0 ft)	lb											*9040	*9040	*8220	8090	*7760	5910			*7250	3620	(47.2)
3.0 m	kg					*10920	*10920	*7400	*7400	*5710	*5710	*4750	4620	*4160	3410	*3790	2520	*1720	*1720	3310	1530	14.53
(10.0 ft)	lb					*24070	*24070	*16310	*16310	*12590	*12590	*10470	10190	*9170	7520	*8360	5560	*3790	*3790	7300	3370	(47.7)
1.5 m	kg					*10890	*10890	*8990	8120	*6710	5760	*5420	4230	*4610	3150	*4090	2350	*1900	1730	3270	1480	14.49
(5.0 ft)	lb					*24010	*24010	*19820	17900	*14790	12700	*11950	9330	*10160	6940	*9020	5180	*4190	3810	7210	3260	(47.5)
Ground	kg					*10400	*10400	*10190	7440	*7560	5280	*6010	3900	*5030	2930	*4370	2210			3320	1500	14.28
Line	lb					*22930	*22930	*22470	16400	*16670	11640	*13250	8600	*11090	6460	*9630	4870			7320	3310	(46.9)
-1.5 m	kg			*7990	*7990	*11720	11200	*10930	7060	*8180	4970	*6480	3670	*5370	2770	4390	2110			3470	1590	13.90
(-5.0 ft)	lb			*17610	*17610	*25840	24690	*24100	15560	*18030	10960	*14290	8090	*11840	6110	9680	4650			7650	3510	(45.6)
-3.0 m	kg	*8910	*8910	*10270	*10270	*13880	11160	*11250	6900	*8540	4800	*6780	3530	5420	2670	4340	2060			3760	1770	13.31
(-10.0 ft)	lb	*19640	*19640	*22640	*22640	*30600	24600	*24800	15210	*18830	10580	*14950	7780	11950	5890	9570	4540			8290	3900	(43.7)
-4.5 m	kg	*11090	*11090	*12810	*12810	*15320	11300	*11200	6910	*8610	4760	*6850	3490	5400	2660					*4230	2080	12.50
(-15.0 ft)	lb	*24450	*24450	*28240	*28240	*33770	24910	*24690	15230	*18980	10490	*15100	7690	11900	5860					*9330	4590	(41.0)
-6.0 m	kg	*13540	*13540	*15800	*15800	*14460	11590	*10750	7050	*8340	4850	*6630	3570	*5260	2770					*4390	2610	11.41
(-20.0 ft)	lb	*29850	*29850	*34830	*34830	*31880	25550	*23700	15540	*18390	10690	*14620	7870	*11600	6110					*9680	5750	(37.4)
-7.5 m	kg	*16440	*16440	*18490	*18490	*12970	12050	*9770	7350	*7580	5080	*5850	3790							*4450	3570	9.94
(-25.0 ft)	lb	*36240	*36240	*40760	*40760	*28590	26570	*21540	16200	*16710	11200	*12900	8360							*9810	7870	(32.6)
-9.0 m	kg			*14620	*14620	*10500	*10500	*7900	7870	*5800	5550											
(-30.0 ft)	lb			*32230	*32230	*23150	*23150	*17420	17350	*12790	12240											

6. BUCKET SELECTION GUIDE

1) GENERAL BUCKET

				C C C C C C C C C C C C C C C C C C C
1.46 m ³ SAE heaped bucket	% 1.62 m ³ SAE heaped bucket	1.86 m ³ SAE heaped bucket	2.10 m ³ SAE heaped bucket	2.32 m ³ SAE heaped bucket


							Recomm	endation		
Сар	acity	Wi	dth	Weight		6.5 m (21'	4") boom	1	6.15 m (20' 2") boom	8.6 m (28' 3") boom
SAE heaped	CECE heaped	Without side cutter	With side cutter		2.5 m arm (8' 2")	3.2 m arm (10' 6")	3.9 m arm (12' 10")	4.3 m arm (14' 1")	2.5 m arm (8' 2")	5.1 m arm (16' 9")
1.46 m ³ (1.91 yd ³)	1.27 m³ (1.66 yd³)	1380 mm (54.3")	1510 mm (59.4")	1170 kg (2580 lb)						
* 1.62 m ³ (2.12 yd ³)	1.40 m ³ (1.83 yd ³)	1440 mm (56.7")	1570 mm (61.8")	1280 kg (2820 lb)						
1.86 m ³ (2.43 yd ³)	1.60 m ³ (2.1 yd ³)	1620 mm (63.8")	1750 mm (68.9")	1390 kg (3060 lb)						
2.10 m ³ (2.75 yd ³)	1.80 m ³ (2.4 yd ³)	1810 mm (71.3")	1940 mm (76.4")	1520 kg (3350 lb)						
2.32 m ³ (3.03 yd ³)	2.00 m ³ (2.62 yd ³)	1990 mm (78.3")	2120 mm (83.5")	1760 kg (3880 lb)						

* : Standard bucket

Applicable for materials with density of 2000 kg/m³ (3370 lb/yd³) or less
 Applicable for materials with density of 1600 kg/m³ (2700 lb/yd³) or less

Applicable for materials with density of 1100 kg/m³ (1850 lb/yd³) or less

2) HEAVY DUTY AND ROCK-HEAVY DUTY BUCKET



						Re	commenda	tion	
Сар	acity	Wi	dth	Weight		6.5 m (21	4") boom		6.15 m (20' 2") boom
SAE heaped	CECE heaped	Without side cutter	With side cutter		2.5 m arm (8' 2")	3.2 m arm (10' 6")	3.9 m arm (12' 10")	4.3 m arm (14' 1")	2.5 m arm (8' 2")
1.62 m ³ (2.12 yd ³)	1.40 m³ (1.83 yd³)	1540 mm (60.6")	-	1570 kg (3460 lb)					
⊙1.44 m³ (1.88 yd³)	1.27 m³ (1.66 yd³)	1280 mm (50.4")	-	1565 kg (3450 lb)					
⊙1.62 m ³ (2.12 yd ³)	1.40 m³ (1.83 yd³)	1545 mm (60.8")	-	1610 kg (3550 lb)					
⊙1.86 m³ (2.43 yd³)	1.60 m ³ (2.1 yd ³)	1725 mm (67.9")	-	1710 kg (3770 lb)					

♦ : Heavy duty bucket

 \odot : Rock-heavy duty bucket



Applicable for materials with density of 2000 kg/m³ (3370 lb/yd³) or less Applicable for materials with density of 1600 kg/m³ (2700 lb/yd³) or less Applicable for materials with density of 1100 kg/m³ (1850 lb/yd³) or less

7. UNDERCARRIAGE

1) TRACKS

X-leg type center frame is integrally welded with reinforced box-section track frames. The design includes dry tracks, lubricated rollers, idlers, sprockets, hydraulic track adjusters with shock absorbing springs and assembled track-type tractor shoes with triple grousers.

2) TYPES OF SHOES

					Triple grouse	r					
Model	Shapes	5									
	Shoe width	mm (in)	600 (24)	700 (28)	750 (30)	800 (32)	900 (36)				
R380LC-9	Operating weight	kg (lb)	38200 (84220)	38650 (85210)	38875 (85700)	39100 (86200)	39550 (87190)				
1100020-9	Ground pressure	kgf/cm² (psi)	0.68 (9.67)	0.59 (8.39)	0.56 (7.96)	0.52 (7.39)	0.47 (6.68)				
	Overall width	mm (ft-in)	3340 (10' 11")	3440 (11' 3")	3490 (11' 5")	3540 (11' 7")	3640 (11' 11")				

3) NUMBER OF ROLLERS AND SHOES ON EACH SIDE

Item	Quantity
Carrier rollers	2 EA
Track rollers	9 EA
Track shoes	51 EA

4) SELECTION OF TRACK SHOE

Suitable track shoes should be selected according to operating conditions.

Method of selecting shoes

Confirm the category from the list of applications in **table 2**, then use **table 1** to select the shoe. Wide shoes (categories B and C) have limitations on applications. Before using wide shoes, check the precautions, then investigate and study the operating conditions to confirm if these shoes are suitable.

Select the narrowest shoe possible to meet the required flotation and ground pressure. Application of wider shoes than recommendations will cause unexpected problem such as bending of shoes, crack of link, breakage of pin, loosening of shoe bolts and the other various problems.

* Table 1

Track shoe	Specification	Category
600 mm triple grouser	Standard	А
700 mm triple grouser	Option	В
750 mm triple grouser	Option	В
800 mm triple grouser	Option	С
900 mm triple grouser	Option	С

* Table 2

Category	Applications	Applications
A	Rocky ground, river beds, normal soil	Travel at low speed on rough ground with large obstacles such as boulders or fallen trees
В	Normal soil, soft ground	 These shoes cannot be used on rough ground with large obstacles such as boulders or fallen trees Travel at high speed only on flat ground Travel slowly at low speed if it is impossible to avoid going over obstacles
С	Extremely soft gound (swampy ground)	 Use the shoes only in the conditions that the machine sinks and it is impossible to use the shoes of category A or B These shoes cannot be used on rough ground with large obstacles such as boulders or fallen trees Travel at high speed only on flat ground Travel slowly at low speed if it is impossible to avoid going over obstacles

8. SPECIFICATIONS FOR MAJOR COMPONENTS

1) ENGINE

Item	Specification
Model	Cummins QSL / HYUNDAI HE8.9
Туре	4-cycle turbocharged charger air cooled diesel engine
Cooling method	Water cooling
Number of cylinders and arrangement	6 cylinders, in-line
Firing order	1-5-3-6-2-4
Combustion chamber type	Direct injection type
Cylinder bore \times stroke	114×145 mm (4.49"×5.70")
Piston displacement	8900 cc (540 cu in)
Compression ratio	17.8 : 1
Rated gross horse power (SAE J1995)	296 Hp at 1850 rpm (221 kW at 1850 rpm)
Maximum torque	148 kgf · m (1070 lbf · ft) at 1400 rpm
Engine oil quantity	31.7 l (8.4 U.S. gal)
Dry weight	740 kg (1630 lb)
Low idling speed	800±100 rpm
High idling speed	1700+50 rpm
Rated fuel consumption	164.8 g/Hp ⋅ hr at 1850 rpm
Starting motor	Denso (24V-7.5 kW)
Alternator	Delco Remy 24V-50A
Battery	$2 \times 12V \times 160Ah$

2) MAIN PUMP

Item	Specification				
Туре	Variable displacement tandem axis piston pumps				
Capacity	2×175 cc/rev				
Maximum pressure	330 kgf/cm ² (4690 psi) [360 kgf/cm ² (5120 psi)]				
Rated oil flow	2 × 306 / /min (80.8 U.S. gpm / 67.3 U.K. gpm)				
Rated speed	1750 rpm				

[]: Power boost

3) GEAR PUMP

Item	Specification				
Туре	Fixed displacement gear pump single stage				
Capacity	15cc/rev				
Maximum pressure	40 kgf/cm ² (570 psi)				
Rated oil flow	27 <i>l</i> /min (7.1 U.S. gpm/5.9 U.K. gpm)				

4) MAIN CONTROL VALVE

Item	Specification				
Туре	9 spools				
Operating method	Hydraulic pilot system				
Main relief valve pressure	330 kgf/cm ² (4690 psi) [360 kgf/cm ² (5120 psi)]				
Overload relief valve pressure	390 kgf/cm ² (5550 psi)				

[]: Power boost

5) SWING MOTOR

Item	Specification				
Туре	Axial piston motor				
Capacity	233 cc/rev				
Relief pressure	290 kgf/cm ² (4120 psi)				
Braking system	Automatic, spring applied hydraulic released				
Braking torque	107 kgf · m (773 lbf · ft)				
Brake release pressure	30~50 kgf/cm ² (427~711 psi)				
Reduction gear type	2 - stage planetary				

6) TRAVEL MOTOR

Item	Specification				
Туре	Variable displacement axial piston motor				
Relief pressure	360 kgf/cm ² (5120 psi)				
Capacity (max / min)	185.2/114.2 cc/rev				
Reduction gear type	3-stage planetary				
Braking system	Automatic, spring applied hydraulic released				
Brake release pressure	8.5 kgf/cm ² (121 psi)				
Braking torque	44.4 kgf · m (321 lbf · ft)				

7) CYLINDER

Ite	Specification			
De ere er linder	Bore dia $ imes$ Rod dia $ imes$ Stroke	ø 160 $ imes$ ø 110 $ imes$ 1500 mm		
Boom cylinder	Cushion	Extend only		
Arm cylinder	Bore dia $ imes$ Rod dia $ imes$ Stroke	ø 170 \times ø 120 \times 1760 mm		
	Cushion	Extend and retract		
Bucket cylinder	Bore dia $ imes$ Rod dia $ imes$ Stroke	ø 150 $ imes$ ø 105 $ imes$ 1295 mm		
	Cushion	Extend only		

* Discoloration of cylinder rod can occur when the friction reduction additive of lubrication oil spreads on the rod surface.

* Discoloration does not cause any harmful effect on the cylinder performance.

8) SHOE

Item		Width	Ground pressure	Link quantity	Overall width
	Standard 600 mm (24"		0.68 kgf/cm ² (9.67 psi)	51	3340 mm (10' 11")
R380LC-9 Option	700 mm (28")	0.59 kgf/cm ² (8.39 psi)	51	3440 mm (11' 3")	
	Ontion	750 mm (30")	0.56 kgf/cm ² (7.96 psi)	51	3490 mm (11' 5")
	Oplion	800 mm (32")	0.52 kgf/cm ² (7.39 psi)	51	3540 mm (11' 7")
		900 mm (36")	0.47 kgf/cm ² (6.68 psi)	51	3640 mm (11' 11")

9) BUCKET

Item		Cap	acity	Tooth	Width			
		SAE heaped	CECE heaped	quantity	Without side cutter	With side cutter		
	Standard	1.62 m ³ (2.12 yd ³)	1.40 m³ (1.8 yd³)	5	1440 mm (56.7")	1570 mm (61.8")		
		1.46 m³ (1.91 yd³)	1.27 m³ (1.66 yd³)	4	1380 mm (54.3")	1510 mm (59.4")		
		1.62 m ³ (2.12 yd ³) 1.40 m ³ (1.83 yd ³)		5	1540 mm (60.6")	-		
		©1.44 m³ (1.88 yd³)	1.27 m³ (1.66 yd³)	5	1280 mm (50.4")	-		
R380LC-9	R380LC-9	©1.62 m³ (2.12 yd³)	1.40 m³ (1.83 yd³)	5	1545 mm (60.8")	-		
			©1.86 m³ (2.43 yd³)	1.60 m³ (2.1 yd³)	5	1725 mm (67.9")	-	
		1.86 m³ (2.43 yd³)	1.60 m³ (2.1 yd³)	5	1620 mm (63.8")	1750 mm (68.9")		
		2.10 m ³ (2.75 yd ³)	1.80 m³ (2.4 yd³)	6	1810 mm (71.3")	1940 mm (76.4")		
		2.32 m ³ (3.03 yd ³)	2.00 m ³ (2.62 yd ³)	6	1990 mm (78.3")	2120 mm (83.5")		

♦ : Heavy duty bucket

◎ : Rock bucket (esco type)

9. RECOMMENDED OILS

Use only oils listed below. Do not mix different brand oil. Please use HYUNDAI genuine oil and grease.

		Capacity				Ambi	ent temp	erature °	C(°F)		
Service point	Kind of fluid	ℓ (U.S. gal)	-50	-30						20 3	
			(-58)	(-22)) (-	-4) ('	14) (32) (5	50) (6	68) (86	6) (104)
			★ SAE 5W-40								
									SA	E 30	
Engine	F	00 5 (0 0)									
oil pan	Engine oil	33.5 (8.8)				SAE	10W				
							S	AE 10W-	30		
								SAE 1	5W-40		
								+			
Swing drive		8.0 (2.1)			*5	SAE 75W	/-90				
	Gear oil		-								
Final drive		7.0×2						SAE 8	80W-90		
		(1.8×2)								ļ	
	Hydraulic oil	Tank:				★ISO V	'G 15				
		210					ISO V	G 32			
Hydraulic tank		(55.5)									_
		System: 415						ISO VG	46		
		(110)							SO VG 6	8	
				★A	STM D)975 NO	0.1				
Fuel tank	Diesel fuel	550 (145)									
								AST	M D975	NO.2	
Fitting						★NLC	GINO.1	1			
(grease nipple)	Grease	As required						NI GI	NO.2		
									NO.2	· · · · ·	
		eze 50 (13.2)									
Radiator	Mixture of antifreeze		Ethylene glycol base permanent type (50 : 50							: 50)	
(reservoir tank)	and water		★Ethy	lene gly	ycol base p	permanent t	ype (60 : 40)				
			,								

SAE : Society of Automotive Engineers

★ : Cold region

Russia, CIS, Mongolia

API : American Petroleum Institute

ISO : International Organization for Standardization

NLGI : National Lubricating Grease Institute

ASTM : American Society of Testing and Material


SECTION 2 STRUCTURE AND FUNCTION


Group	1 Pump Device ·····	2-1
Group	2 Main Control Valve	2-20
Group	3 Swing Device	2-46
Group	4 Travel Device	2-58
Group	5 RCV Lever ·····	2-71
Group	6 RCV Pedal	2-78


GROUP 1 PUMP DEVICE

1. STRUCTURE

The pump device consists of main pump, regulator and gear pump.








Port	Port name	Port size
A1, 2	Delivery port	SAE6000psi 1"
B1	Suction port	SAE2000psi 3"
Dr	Drain port	PF 3/4 - 23
Pi1, i2	Pilot port	PF 1/4 - 15
Pm1, m2	Qmax cut port	PF 1/4 - 15
Psv1, sv2	Servo assist port	PF 1/4 - 15
a1, 2, 4,5	Gauge port	PF 1/4 - 15
a3	Gauge port	PF 1/4 - 14
A3	Gear pump delivery port	PF 1/2 - 19
B3	Gear pump suction port	PF 3/4 - 20
PB	Gauge port	PT 1/8

1) MAIN PUMP(1/2)

The main pump consists of two piston pumps (front & rear) and valve block.




38092MP02


- 04 Gear pump 111 Drive shaft (F) 113 Drive shaft (R) 114 Spline coupling 123 Roller bearing 124 Needle bearing 127 Bearing spacer 130 Booster 012 Cylinder block 151 Piston 152 Shoe 153 Set plate 156 Bushing 157 Cylinder spring 211 Shoe plate 212 Swash plate 214 Bushing 251 Support plate
- 261 Seal cover (F)
- 271 Pump casing 311 Valve cove r(F) 312 Valve cover (R) 313 Valve plate (R) 314 Valve plate (L) 401 Hexagon socket bolt 402 Hexagon socket bolt 406 Hexagon socket bolt 466 VP Plug 468 VP Plug 490 Plug 492 Plug 531 Tilting pin 532 Servo piston 534 Stopper (L) 535 Stopper (S) 548 Feedback pin
- 702 O-ring
- 706 O-ring

- 710 O-ring
 717 O-ring
 719 O-ring
 724 O-ring
 725 O-ring
 728 O-ring
 732 O-ring
 732 O-ring
 734 Oil seal
 789 Back up ring
 792 Back up ring
 792 Back up ring
 808 Hexagon head nut
 824 Snap ring
 885 Pin
 886 Spring pin
- 901 Eye bolt
- 953 Set screw
- 954 Adjust screw

2) FRONT REGULATOR (1/2)



SECTION B-B



Port	Port name	Port size
Pi1,Pi2	Pilot port	PF 1/4-15
Psv1,Psv2	Servo assist port	PF 1/4-15

А

B

P<u>ş</u>v

FRONT

V I L

Hydraulic circuit


P2


Pf⊦

Pi


38092RG01

3) REAR REGULATOR (1/2)





4) GEAR PUMP



- 351 Gear case
- 434 Flange socket 435 Flange socket
- 850 Snap ring 887 Pin

2. FUNCTION

1) MAIN PUMP

The pumps may classified roughly into the rotary group performing a rotary motion and working as the major part of the whole pump function: the swash plate group that varies the delivery rates: and the valve cover group that changes over oil suction and discharge.

(1) Rotary group

The rotary group consists of drive shaft (F)(111), cylinder block (012), piston shoes (151,152), set plate (153), spherical bush (156) and cylinder spring (157). The drive shaft is supported by bearing (123,124) at its both ends.


The shoe is caulked to the piston to from a spherical coupling. It has a pocket to relieve thrust force generated by loading pressure and the take hydraulic balance so that it slides lightly over the shoe plate (211). The sub group composed by a piston and a shoe is pressed against the shoe plate by the action of the cylinder spring via a retainer and a spherical bush. Similarly, the cylinder block is pressed against valve plate (313) by the action of the cylinder spring.

(2) Swash plate group


The swash plate group consists of swash plate (212), shoe plate (211), swash plate support (251), tilting bush (214), tilting pin (531) and servo piston (532).

The swash plate is a cylindrical part formed on the opposite side of the sliding surface of the shoe and is supported by the swash support.

If the servo piston moves to the right and left as hydraulic force controlled by the regulator is admitted to hydraulic chamber located on both sides of the servo piston, the swash plate slides over the swash plate support via the spherical part of the tilting pin to change the tilting angle (α)



32092MP03



(3) Valve block group


The valve block group consists of valve cover (F, 311), valve cover (F, 312), valve plate (313, 314), spline coupling (114), booster (130) and valve plate pin (885).

The valve plate having two melon-shaped ports is fixed to the valve block and feeds and collects oil to and from the cylinder block.

The oil changed over by the valve plate is connected to an external pipeline by way of the valve block.

Now, if the drive shaft is driven by a prime mover (electric motor, engine, etc), it rotates the cylinder block via a spline linkage at the same time. If the swash plate is tilted as in Fig (previous page) the pistons arranged in the cylinder block make a reciprocating motion with respect to the cylinder block, while they revolve with the cylinder block.

If you pay attention to a single piston, it performs a motion away from the valve plate (oil sucking process) within 180 degrees, and makes a motion towards the valve plate (or oil discharging process) in the rest of 180 degrees. When the swash plate has a tilting angle of zero, the piston makes no stroke and discharges no oil.



38092MP04


2) REGULATOR

Regulator consists of the negative flow control, total horse power control and power shift control function.


(1) Negative flow control

By changing the pilot pressure Pi, the pump tilting angle (delivery flow) is regulated arbitrarily, as shown in the figure.

This regulator is of the negative flow control in which the delivery flow Q decreases as the pilot pressure Pi rises. With this mechanism, when the pilot pressure corresponding to the flow required for the work is commanded, the pump discharges the required flow only, and so it does not consume the power uselessly.



① Flow reducing function



As the pilot pressure Pi rises, the pilot piston (643) moves to the right to a position where the force of the pilot spring (646) balances with the hydraulic force.

The groove (A) in the pilot piston is fitted with the pin (875) that is fixed to lever 2 (613). Therefore, when the pilot piston moves, lever 2 rotates around the fulcrum of point B [Fixed by the fulcrum plug (614) and pin (875)]. Since the large hole section (C) of lever 2 contains a protruding pin (897) fixed to the feedback lever (611), the pin (897) moves to the right as lever 2 rotates. Since the opposing-flat section (D) of the feedback lever is fitted with the pin (548) fixed by the tilting pin (531) that swings the swash plate, the feedback lever rotates around the fulcrum of point D, as the pin (897) moves.


Since the feedback lever is connected with the spool (652) via the pin (874), the spool moves to the right.

The movement of the spool causes the delivery pressure P1 to connect to port CL through the spool and to be admitted to the large diameter section of the servo piston. The delivery pressure P1 that is constantly admitted to the small diameter section of the servo piston moves the servo piston to the right due to the area difference, resulting in decrease of the tilting angle.

When the servo piston moves to the right, point D also moves to the right. The spool is fitted with the return spring (654) and is tensioned to the left at all times, and so the pin (897) is pressed against the large hole section (C) of lever 2.

Therefore, as point D moves, the feedback lever rotates around the fulcrum of point C, and the spool is shifted to the left. This causes the opening between the sleeve (651) and spool (652) to close slowly, and the servo piston comes to a complete stop when it closes completely.

② Flow increasing function



As the pilot pressure Pi decreases, the pilot piston (643) moves to the left by the action of the pilot spring (646) and causes lever 2 (613) to rotate around the fulcrum of point B. Since the pin (897) is pressed against the large hole section (C) of lever 2 by the action of the return spring (654) via the spool (652), pin (874), and feedback lever (611), the feedback lever rotates around the fulcrum of point D as lever 2 rotates, and shifts the spool to the left. Port CL opens a way to the tank port as the spool moves. This deprives the large diameter section of the servo piston of pressure, and shifts the servo piston to the left by the discharge pressure P1 in the small diameter section, resulting in an increase in the flow rate.


As the servo piston moves, point D also moves to the left, the feedback lever rotates around the fulcrum of point C, and the spool moves to the right till the opening between the spool and sleeve is closed.

③ Adjustment of flow control characteristic

The flow control characteristic can be adjusted with the adjusting screw. Adjust it by loosening the hexagon nut (801) and by tightening (or loosening) the hexagonal socket head screw (924). Tightening the screw shifts the control chart to the right as shown in the figure.

/ lajaoanig			
Speed	Adjustment of flow control characteristic		
opeed	Tightening amount of adjusting screw (924)	Flow control starting pressure change amount	Flow change amount
(min -1)	(Turn)	(kgf/cm ²)	(1 /min)
1750	+1/4	+1.6	+18.3

* Adjusting values are shown in table.



(2) Total horsepower control

The regulator decreases the pump tilting angle (delivery flow) automatically to limit the input torque within a certain value with a rise in the delivery pressure P1 of the self pump and the delivery pressure P2 of the companion pump.

(The input horsepower is constant when the speed is constant.)


Since the regulator is of the simultaneous total horsepower type that operates by the sum of load pressures of the two pumps in the tandem double-pump system, the prime mover is automatically prevented from being overloaded, irrespective of the load condition of the two pumps, when horsepower control is under way.

Since this regulator is of the simultaneous total horsepower type, it controls the tilting angles (displacement volumes) of the two pumps to the same value as represented by the following equation :


 $Tin = P1 \times q / 2\pi + P2 \times q / 2\pi$

= (P1+P2) \times q / 2 π

The horsepower control function is the same as the flow control function and is summarized in the following. (for detailed behaviors of respective parts, refer to the section of flow control).



1 Overload preventive function




R130RE01

When the self pump delivery pressure P1 or the companion pump delivery pressure P2 rises, it acts on the stepped part of the compensating piston (621). It presses the compensating rod (623) to the right till the force of the outer spring (625) and inner spring (626) balances with the hydraulic force. The movement of the compensating rod is transmitted to lever 1 via pin (875). Lever 1 rotates around the pin (875) (E) fixed to the casing (601).

Since the large hole section (F) of lever 1 contains a protruding pin (897) fixed to the feedback lever (611), the feedback lever rotates around the fulcrum of point D as lever 1 rotates, and then the spool (652) is shifted to the right. As the spool moves, the delivery pressure P1 is admitted to the large diameter section of the servo piston via port CL, causes the servo piston move to the right, reduces the pump delivery flow rate, and prevents the prime mover from being overloaded. The movement of the servo piston is transmitted to the feedback lever via point D. Then the feedback lever rotates around the fulcrum of point F and the spool is shifted to the left. The spool moves till the opening between the spool (652) and sleeve (651) is closed.

② Flow reset function



R130RE11

As the self pump delivery pressure P1 or the companion pump delivery pressure P2 decreases, the compensating rod (623) is pushed back by the action of the springs (625 & 626) to rotate lever 1 (612) around point E. Rotating of lever 1 causes the feedback lever (611) to rotate around the fulcrum of point D and then the spool (652) to move to the left. As a result, port CL opens a way to the tank port.

This causes the servo piston to move to the left and the pump's delivery rate to increase.

The movement of the servo piston is transmitted to the spool by the action of the feedback mechanism to move it till the opening between the spool and sleeve is closed.

③ Low tilting angle (low flow) command preferential function

As mentioned above, flow control and horsepower control tilting angle commands are transmitted to the feedback lever and spool via the large-hole sections (C & F) of levers 1 and 2. However, since sections C and F have the pins (\emptyset 4) protruding from the large hole (\emptyset 8), only the lever lessening the tilting angle contacts the pin (897); the hole (\emptyset 8) in the lever of a larger tilting angle command is freed without contacting the pin (897). Such a mechanical selection method permits preference of the lower tilting angle command of the flow control and horsepower control.

④ Adjustment of input horsepower


Since the regulator is of total cumulative horsepower type, adjust the adjusting screws of both the front and rear pumps, when changing the horsepower set values. The pressure change values by adjustment are based on two pumps pressurized at the same time, and the values will be doubled when only one pump is loaded.

a. Adjustment of outer spring

Adjust it by loosening the hexagon nut (630) and by tightening (or loosening) the adjusting screw C (628). Tightening the screw shifts the control chart to the right and increases the input horsepower as shown in the figure. Since turning the adjusting screw C by N turns changes the setting of the inner spring (626), return the adjusting screw QI (627) by N × A turns at first. (A=1.85)

* Adjusting values are shown in table.

Speed	Adjustment of outer spring		
opood	Tightening amount of adjusting screw (C) (628)	Compensating control starting pressure change amount	Input torque change amount
(min -1)	(Turn)	(kgf/cm ²)	(kgf ⋅ m)
1750	+1/4	+17.7	+8.5



Delivery pressure, (P1+P2)


b. Adjustment of inner spring

Adjust it by loosening the hexagon nut (802) and by tightening (or loosening) the adjusting screw QI (627).


Tightening the screw increases the flow and then the input horsepower as shown in the figure.

* Adjusting valves are shown in table.

Adjustment of inner spring			r spring
	Tightening amount of adjusting screw (QI) (627)	Flow change amount (lpm)	Input torque change amount
(min -1)	(Turn)	(kgf/cm ²)	(kgf · m)
1750	+1/4	+16.7	+9.2




(3) Power shift control



R130RE13

The set horsepower valve is shifted by varying the command current level of the proportional pressure reducing valve attached to the pump. Only one proportional pressure reducing valve is provided.

However, the secondary pressure Pf (power shift pressure) is admitted to the horsepower control section of each pump regulator through the pump's internal path to shift it to the same set horsepower level.



This function permits arbitrary setting of the

pump output power, thereby providing the optimum power level according to the operating condition.

The power shift pressure Pf controls the set horsepower of the pump to a desired level, as shown in the figure.

As the power shift pressure Pf rises, the compensating rod (623) moves to the right via the pin (898) and compensating piston (621).

This decreases the pump tilting angle and then the set horsepower in the same way as explained in the overload preventive function of the horsepower control. On the contrary, the set horsepower rises as the power shift pressure Pf falls.

(4) Adjustment of maximum and minimum flows

① Adjustment of maximum flow

Adjust it by loosening the hexagon nut (808) and by tightening (or loosening) the set screw (954).

The maximum flow only is adjusted without changing other control characteristics.


Speed	Adjustment of max flow spring		
	Tightening amount of adjusting screw (954)	Flow change amount	
(min -1)	(Turn)	(1 /min)	
1750	+1/4	-6.7	


⁽²⁾ Adjustment of minimum flow

Adjust it by loosening the hexagon nut (808) and by tightening (or loosening) the hexagonal socket head set screw (953). Similarly to the adjustment of the maximum flow, other characteristics are not changed.

However, remember that, if tightened too much, the required horsepower during the maximum delivery pressure (or during relieving) may increase.


Speed	Adjustment of min flow spring		
	Tightening amount of adjusting screw (953)	Flow change amount	
(min -1)	(Turn)	(1 /min)	
1750	+1/4	+6.7	






GROUP 2 MAIN CONTROL VALVE

1. STRUCTURE (1/4)



3607A2MC12


]
Mark	Port name	Port size	Tightening torque
(R3)	-		
R4	Make up port		
(P3)	-	G-1	15~18 kgf ⋅ m (108.5~130 lbf ⋅ ft)
(P4)	-		(100.0*100 101 11)
(Ck2)	-		
PAa	Arm 1 (in) pilot port		
PBa	Arm 1 (out) pilot port		
PAb	Boom (down) pilot port		
PBb	Boom (up) pilot port		
PAc	Bucket (in) pilot port		
PBc	Bucket (out) pilot port		
PAL	Travel right (reverse) pilot port		
PBL	Travel right (forward) pilot port		
PAr	Travel left (reverse) pilot port		
PBr	Travel left (forward) pilot port		
PAs	Swing (left) pilot port		
PBs	Swing (right) pilot port		
PAa2	Arm 2 (in) pilot port		
PBa2	Arm 2 (out) pilot port	G-3/8	7~8 kgf ⋅ m
PBb2	Boom (up) confluence pilot port	0. 0, 0	(50.6~57.8 lbf ⋅ ft)
(PAo)	Optional pilot port		
(PBo)	Optional pilot port		
PAbs	Boom (down) stroke limitter pilot port		
PAcs	Bucket (in) stroke limitter pilot port		
Pca	Bypass cut spool (P2 side) pilot port		
(Pcb)	Bypass cut spool (P1 side) pilot port		
Dra	Drain port		
Drb	Drain port		
(PTa)	-		
(PTb)	-		
(P1g)	Quick clamp solenoid valve supply port		
(P2g)	-		
(Psp)	Swing priority		
P	Pilot port		
Pa	Pilot port		
Px	Pressure port for attachment		
Py	Pressure port for travel	0.1/1	3.5~4.0 kgf ⋅ m
(PL2)	Option(Bo) port relief valve pilot port for	G-1/4	(25.3~29 lbf · ft)
	switching to high pressure		
Pns	Boom priority valve pilot port		
P2c1	Lock valve (boom head side) pilot port		
P2c2	Lock valve (arm rod side) pilot port		




3607A2MC12


Mark


Port name	Port size	Tightoning torquo
	I UIT SIZE	Tightening torque
ressure (boom1 side) port ressure (arm1 side) port	G-1/4	3.5~4.0 kgf ⋅ m (25.3~29 lbf ⋅ ft)
alve pilot port for switching to high	G-1/8	1.5~1.9 kgf ⋅ m (10.8~13.7 lbf ⋅ ft)
r head side port (in) r rod side port (out) ler rod side port (down) ler head side port (up) der head side port (in) der rod side port (out) otor (reverse) otor (forward) motor (forward) t	M14	14~18 kgf ⋅ m (101~130 lbf ⋅ ft)
A1 side) A2 side)	M12	8.5~11 kgf ⋅ m (61.5~80 lbf ⋅ ft)
r port (left) r port (right)	M10	5~6.5 kgf · m (36~47 lbf · ft)




STRUCTURE (4/4)








SECTION G - G






SECTION H - H

3607A2MC11A

2. FUNCTION

1) HYDRAULIC CIRCUIT



2) OPERATION

(1) Neutral positions of spools


When all spools are in the neutral positions, the pressurized oil discharged from the hydraulic pump (A1) passes through Port P1, the main path (1), the bypass circuit (2) passing the spools for boom1, bucket and arm 2, and boom 1 side negative control orifice, and returns to the hydraulic oil tank through the tank port (T1).

The pressure upstream the boom 1 side negative control orifice (the negative control signal pressure) is led from port N1 to the regulator on the hydraulic pump (A1) side, and controls the pump discharge flow rate to its minimum value.

The oil discharged from the hydraulic pump (A2) passes through port P2, the main path (3), the bypass circuit (2) passing the spools for swing, boom confluence (boom 2), option and arm 1, and the arm 1 side negative control orifice, and returns to the hydraulic oil tank through the tank port (T1).


The pressure upstream the arm 1 side negative control orifice (the negative control signal pressure) is led from port N2 to the regulator on the hydraulic pump (A2) side, and controls the pump discharge flow rate to its minimum value.

When any of nine main spools is changed over, the bypass circuit (2) is cut off and the hydraulic oil at port N1 or N2 in the negative control circuit is shut off.



(2) Travel operation

When pilot port PBL of the travel left spool is pressurized, the bypass circuit (2) in the arm 2 side is shut off and pressurized oil from port P2 passes through port BL and flows to the travel motor. On the other hand, the return oil from the travel motor passes through port AL and returns to the hydraulic oil tank through the tank port (T1).




(3) Arm

① Arm out operation

During the arm out operation the pilot pressure enters through ports PBa and PBa2. When the pressure enters through port PBa, the spool transfers in the left direction in figure. The hydraulic oil entering through port P2 Passes through the main path (3) and flows to the bypass circuit (2), but the bypass circuit is shut off due to transfer of the arm 1 spool. Therefore, the hydraulic oil from the parallel circuit pushes open the check valve (511) and flows through the U-shaped path to the arm1 spool (302). Then, it flows around the periphery of the arm 1 spool (302) to port Ba, and is supplied to the arm cylinder rod side (R).

On the other hand, the oil entering through port P1 passes in the main path (1), and flows into the bypass circuit (2), and the bypass circuit is shut off due to transfer of the arm 2 spool (394). Oil from the parallel circuit pushes open the check valve (514) and oil from the bypass circuit pushes open the check valve (511) and flows through the U-shaped path to the arm 2 spool (394). Then, it flows around the periphery of arm 2 spool in the inside path and joins into port Ba. Besides, the return oil from the arm cylinder head side (H) passes through port Aa, flows into tank line in arm 1 side and in arm 2 side and returns to the hydraulic oil tank through the tank port (T1).



② Arm in operation

During the arm in operation, the pilot pressure enters through ports PAa and PAa2. When the pressure enters through port PAa, the spool transfers in the right direction in figure MC17A. The hydraulic oil entering through port P2 passes through the main path (3) and flows to the bypass circuit (2), but the bypass circuit is shut off due to transfer of the arm 1 spool. Therefore, the hydraulic oil from the parallel circuit pushes open the check valve (511) and flows through the U-shaped path to the arm 1 spool (302). Then, it flows around the periphery of the arm1 spool to port Aa, and is supplied to the arm cylinder head side (H).

Besides, the oil entering through port P1 passes in the main path (1), and flows into the bypass circuit (2), and the bypass circuit is shut off due to transfer of the arm 2 spool (394). Oil from the parallel circuit pushes open the check valve (514) and oil from the bypass circuit pushes open the check valve (514) and oil from the bypass circuit pushes open the check valve (511) and flows through the U-shaped path to the arm 2 spool (394). Then, it flows around the periphery of arm 2 spool in the inside path and joins into port Aa.


On the other hand, the return oil from the arm cylinder rod side (R) is pressurized by self-weight of the arms and so on, and returns to port Ba. The pressurized oil returning to Port Ba enters into the spool through the outside hole (a) of the arm1 spool (302). During a light load only, it pushes open the sleeve check valve and part of oil flows the U-shaped path reversely from the spool hole (c), and joins into port Aa. The rest of oil returns to the hydraulic oil tank through the tank port (T1).

This is called the arm regeneration function.

When the pressure in the arm cylinder head side (H) increases, the piston (d) and sub-spool (e) are transferred in the right direction, and at the same time the sleeve check valve (f) is closed by its backpressure. This shuts off the arm regeneration function, and the return oil from the arm cylinder rod side (R) enters from port Ba through the periphery hole (a) of the arm1 spool into the spool, flows out through the periphery hole (b) of the spool, and returns through the tank port (T1) to the hydraulic oil tank.


On the other hand, the pressurized oil entering through port P1 joins into port Aa through the inside path similarly to the case of the arm stretching operation.

· During light load only



3607A2MC17A

 \cdot The pressure in the arm cylinder head side (H) increases.



3607A2MC17B


(4) Boom

① Boom up operation

During the boom up operation, the pilot pressure enters through port PBb and moves the boom 1 spool in the left direction in figure. The pressurized oil entering through port P1 passes through the main path (1) and flows to the bypass circuit (2), but the bypass circuit is shut off due to transfer of the boom 1 spool. Therefore, the pressurized oil flows into the parallel circuit, pushes open the check valve (511), and flows through U-shaped path to the boom1 spool (303). When the stroke of the boom 1 spool is small, the oil enters through the periphery hole (d) of the spool to the inside of the spool, and flows out to port Bb through the periphery hole (e). When the stroke of the boom 1 spool is large, the oil flows out to port Bb through the periphery of the spool.

At the same time, the pilot pressure enters also through Port PBb2 to transfer the boom 2 spool (393) in the left direction in figure. Though the pressurized oil enters into port P2, the bypass is shut off due to transfer of the boom 2 spool. Therefore, the oil flows in the parallel circuit and flows through the U-shaped path to the boom 2 spool. Then, the oil passes through the periphery of the boom 2 spool, pushes open the check valve (511), joins into port Bb in the inside path, and is supplied to the boom cylinder head side (H). (Boom confluent flow)

On the other hand, the return oil from the boom cylinder rod side (R) enters through port Ab and returns to the hydraulic oil tank through the tank port (T1).



② Boom down operation

During the boom down operation, the pilot pressure enters through port PAb and transfers the boom1 spool in the right direction in figure. The pressurized oil entering through port P1 passes through the main path (1) and flows to the bypass circuit (2), but the bypass circuit is shut off due to transfer of the boom 1 spool. Therefore, the pressurized oil flows into the parallel circuit, pushes open the check valve (511), and flows through the U-shaped path to the boom 1 spool (303). Then, it flows around the periphery of the boom 1 spool to port Ab and is supplied to the boom cylinder rod side (R).


On the other hand, the return oil from the boom cylinder head side (H) passes to the notch of the boom 1 spool.

Since this return oil has a sufficient pressure caused by the weight of the boom, it passes through the path inside the spool, pushes the poppet A in the spool in the left direction shown in the figure, flows around the outside of the spool. Then, it is supplied again to the boom cylinder rod side (R) as hydraulic oil to lower the boom. (Boom regeneration)

Besides, a part of the return oil from the boom cylinder flows from the check valve B (boost check) into the tank.

The boost check boosts the hydraulic oil flowing to the tank to secure the sufficient regeneration flow rate.

During the boom down and arm stretching operation, the pilot pressure enters through port PAbs and the boom 1 spool transfers in the half stroke not full stroke.




(5) Bucket

① Bucket in operation

During the bucket in operation, the pilot pressure enters through port PAc and transfers the bucket spool in the right direction in figure. The pressurized oil entering through port P1 passes through the main path (1) and flows through the bypass circuit (2), but the bypass circuit is shut off due to transfer of the bucket spool. Therefore, the pressurized oil flows into the parallel circuit, pushes open the check valve (511), and flows through the U-shaped path to the bucket spool (304). Then, it flows through the periphery of the spool to port Ac and is supplied to the bucket cylinder head side (H).

On the other hand, the return oil from the bucket cylinder rod side (R) enters through port Bc, passes around the periphery of the spool, and returns to the hydraulic oil tank through the tank port (T1).


During the boom up and bucket in operation, the pilot pressure enters through Port PAcs and the bucket spool transfers in the half stroke not full stroke. Therefore, the most of pressurized oil entering through Port P1 flows to the boom 1 spool (304) than the bucket spool (304) to make the boom up operation most preferential.



2 Bucket out operation

During the bucket out operation, the pilot pressure enters through port PBc and transfers the bucket spool in the left direction in figure. The pressurized oil entering through port P1 passes through the main path (1) and flows through the bypass circuit (2), but the bypass circuit is shut off due to transfer of the bucket spool. Therefore, the pressurized oil flows into the parallel circuit, pushes open the check valve (511), and flows through the U-shaped path to the bucket spool (304). Then, it flows through the periphery of the spool to port Bc and is supplied to the bucket cylinder rod side (R).

On the other hand, the return oil from the bucket cylinder head side (H) enters through port Ac, passes around the periphery of the spool, and returns to the hydraulic oil tank through the tank port (T1).



(6) Swing

1 Independent swing operation

During the swing operation, the pilot pressure enters through port PAs (or PBs) and transfers the swing spool. The pressurized oil entering through Port P2 flows to Port As (or Bs) and is supplied to the swing motor. The return oil from the swing motor enters Port Bs (or As) and returns to the hydraulic oil tank through the tank port (T1).


② Swing operation preference function

[Pilot Circuit]

The pilot pressure enters through Port PSp to transfer the swing priority spool (395).

[Main Circuit]

Due to transfer of the swing priority spool, the open area of the swing priority spool decreases, and the most of the pressurized oil entering through port P2 flows to the swing side to make the swing operation most preferential.



(7) Travel straight operation

Simultaneous operating of both travel spools and other spool. A case where both travel spools and swing spool are changed over will be considered. (The pilot ports PAL, PAr and PAs are pressurized.)

[Pilot Circuit]


Since the side bypass sections of both travel spools close and the side bypass section of the downstream-side swing closes, the pilot pressure from the port Pa enters through the port PTa to transfer the travel straight spool.

[Main Circuit]

After changeover of the travel straight spool, the port P2 and both travel spools are connected preferentially and the port P1 and the parallel paths of swing, boom 2, option and arm 1 / boom 1, bucket and arm 2 are connected preferentially. Therefore, the pressurized oil entering through port P2 passes through mainly ports AL and Ar, and flows to both travel motors separately.

On the other hand, the pressurized oil entering through port P1 flows to port As and is supplied to the swing motor.

When the pressure of port P2 is lower than the pressure of port P1, part of oil entering through port P1 flows into port P2 side. Therefore, it prevents the rapid slowdown of travel.



(8) Function of lock valve

The lock valve is fitted between the arm cylinder rod side (R) and the arm1 spool (302). It decreases the leakage by the pressure of the cylinder.

Another lock valve is similarly fitted between the boom cylinder head side (H) and the boom1 spool (303). It decreases the leakage by the pressure of the cylinder.


① Neutral positions of spools

The following is the case of the boom 1 spool.

(The case of the arm 1 spool is in the same way.)

During the boom 1 spool is in neutral position, the lock valve is kept in the position shown in figure. The spool (511) in lock valve is pushed to the seat of the bush (541) by the force of the spring (512).


In this position, pressurized oil from the boom cylinder head side (H) enters through hole (a), the periphery of the spool and hole (b), and it pushes the poppet to the casing seat, and the leakage is decreased.



② Boom down operation

During the boom down operation, pilot pressure enters through port P2c1 and PAb. Pilot pressure transfers the spool (511) in lock valve assy in the right direction in figure. By the transfer of the spool, firstly the hole (a) is blocked and pressurized oil from the boom cylinder head side (H) does not enter to spring chamber (RH). Secondly, oil in spring chamber (RH) enters through hole (b) and flows to port Dr3'.

Therefore, the poppet is lifted by the pressure of the boom cylinder head side (H) and the function of the lock valve is released.



3607A2MC25


③ Boom up operation

During the boom up operation, the pilot pressure enters through port PBb. The oil flowing from the boom 1 spool pushes open the poppet (513) and flows to Port Bb.

(9) Function of boom priority valve

During both the swing operation and the boom hoisting operation, the pilot pressure enters through ports PAs(or PBs), PBb and Pns. The pressure Pns transfers the piston (356) and the spool (107) to the down direction, and the path from (a) to (b) is closed. Hereby, the pressurized oil pushes open the poppet (102), passes in the path (c) and (d), enters into the chamber (e), and the poppet (101) is pushed to the casing seat. Therefore, the most of pressurized oil entering through port P2 flows to the boom priority spool (393) than the swing spool (305) to make the boom hoisting operation most preferential.


On the other hand, in the independent swing operation, the pilot pressure does not enter through ports Pns, and the path from (a) to (b) is not closed, and oil of chamber (e) flows to the path (a) and (b). The pressurized oil entering through port P2 pushes open the poppet (101) and flows to the swing spool (305).



(10) Function of main relief valve

The main relief valve is fitted in the casing B and functions as follows :

- The hydraulic oil is filled up in the inside space chamber (A) from the path (P) through a hole of the body (101) and a restriction of the plunger (511), and seats the plunger (511) against body (101) securely.
- ② When the pressure in the path (P) becomes equal to the set load of the spring (512), the poppet (401) opens to make the hydraulic oil flow through a hole of the seat (2) (641), around the poppet (401) and into the low pressure path (R).
- ③ Opening of the poppet (401) causes the pressure in the chamber (A) to fall and the plunger (511) to open. As the result the pressurized oil in the path (P) runs into the low pressure path (R) directly.
- ④ When the pressurized oil higher than pressure 2.2MPa enters through the port PL1, it pushes the piston (302) to change the relief set pressure of the spring (512) to the high pressure.




(11) Function of port relief valve


The port relief value is fitted between the cylinder port and low-pressure path. In addition to the relief value, this serves also as an anti-cavitation check value, and functions as follows:

(1) Function as relief valve


① The pressurized oil passes through hole A of the piston (301), is filled up in chamber B of the inside space, and seat the plunger (511) against the seat (541) securely.




3607A2MC28




② When the pressure in the path (P) becomes equal to the set pressure of the spring (621 or 622), the pressurized oil pushes open the poppet (611), flows around it, and flows to the low pressure path (R) through Hole C.




3607A2MC30



③ Opening of the poppet (611) causes the pressure in chamber B to fall and the plunger (511) to open. As the result the pressurized oil in the path (P) runs into the low pressure path (R) directly.



3607A2MC32




3607A2MC33

④ When the pressurized oil higher than pressure 1.5MPa enters through the port PL, it pushes the piston (614) to change the relief set pressure of the spring (622) to the high pressure.


(2) Function as anti-cavitation check valve

When any negative pressure exists in the path (p), the oil is supplied through the path (R). When the pressure at (R) becomes higher than that in the path (P), the seat (541) moves in the right direction.

Then, sufficient oil passes around the seat (541) from the path (R) to the path (P) and prevents cavitation.




3607A2MC34




(12) Function of negative control relief valve


The negative control relief valve is fitted between the downstream of the center bypass path and low-pressure path, and functions as follows :

- When the pressure in the path (P) falls below the set level of the spring (621),the poppet (611) is in the condition shown in the figure. The pressure acting area of the poppet (611) is reduced to (ØB-ØA), as the area ØB is cancelled by the area ØA of the damping rod (631).
- ② In this condition, the pressurized oil in the path (P) runs out to the path (R) through the orifice (c).






③ When the pressure in the path (P) goes over the set pressure of the spring(621), the poppet (611) opens. Then, the pressurized oil in the path (P) passes around the outside of the poppet (611) and flows to the low-pressure path (R).




The relation between the flow rate Q and pressure P of the hydraulic oil that flows from the path (P) to the low-pressure path (R) is as shown in the diagram.




GROUP 3 SWING DEVICE

1. STRUCTURE

Swing device consists swing motor, swing reduction gear. Swing motor include mechanical parking valve, relief valve, make up valve and time delay valve.








Port	Port name	Port size	
A	Main port	SAE 1"	
В	Main port	SAE 1"	
Dr	Drain port	PF 1/2	
Mu	Make up port	PF 1 1/4	
SH	Brake release stand byport	PF 1/4	
PG	Brake release pilot port	PF 1/4	
GA, GB	Gauge port	PF 1/4	
Am	Motor air bleed port	PF 1/4	
AGr	R/G air bleed port	PT 1/8	
SGr	Grease filling port	PT 1/8	
Dr(R/G)	Gear oil drain port	PT 1/2	
SGo	Gear oil filling port	PT 3/4	

38092SM01A

1) SWING MOTOR








SECTION A-A

38092SM02

- 1 Body
- 2 Oil seal
- 3 Roller bearing
- 4 Snap ring
- 5 Shaft
- 6 Pin
- 7 Stop ring
- 8 Shoe plate
- 9 Cylinder block
- 10 Spring
- 11 Ball guide seat
- 12 Ball guide
- 13 Set plate
- 14 Piston assy

- 15 Friction plate
- 16 Plate
- 17 Brake piston
- 18 O-ring
- 19 Spring
- 20 Valve plate
- 21 Pin
- 22 Needle bearing
- 23 Rear cover
- 24 Wrench bolt
- 25 Wrench bolt
- 26 Poppet
- 27 Spring
- 28 Plug

- 29 O-ring
- 30 Relief valve assy
- 31 Time delay valve
- 32 Wrench bolt
- 33 Plug
- 34 Swing reactionless valve assy
- 35 Plug
- 36 O-ring
- 37 Back up ring
- 38 O-ring
- 39 O-ring
- 40 Bushing



38092SM03

- 1 Casing
- 2 Drive shaft
- 3 Roller bearing
- 4 Spacer ring
- 5 Oil seal
- 6 Roller bearing
- 7 Carrier assy 2
- 8 Carrier 2
- 9 Planetary gear 2
- 10 Pin assy 2
- 11 Pin 2
- 12 Bushing 2
- 13 Spring pin
- 14 Thrust washer
- 15 Spring pin

- 16 Carrier assy 1
- 17 Carrier 1
- 18 Planetary gear 1
- 19 Pin 1
- 20 Needle cage
- 21 Side plate 1
- 22 Side plate 2
- 23 Stop ring
- 24 Spring pin
- 25 Thrust ring
- 26 Sun gear 2
- 27 Sun gear 1
- 28 Ring gear
- 29 Knock pin
- 30 Cover plate

- 31 Hexagon bolt
- 32 Spacer
- 33 Pinion gear
- 34 Lock plate
- 35 Hexagon bolt
- 36 Lock washer
- 37 Plug
- 38 Plug
- 39 Socket bolt
- 40 Cover
- 41 O-ring
- 42 Hexagon socket bolt
- 45 Air breather assy
- 46 Gauge pipe
- 47 Gauge bar

2. FUNCTION

1) ROTARY PART

When high pressurized oil enters a cylinder through port (a), which is the inlet of balance plate (1), hydraulic pressure acting on the piston causes axial force F. The pressure force F works via the piston (2) upon the return plate (3) which acts upon the swash plate (4) via an hydrostatic bearing. Force F1 perpendicular to swash plate (4) and force F2 perpendicular to cylinder center.


Being transferred to the cylinder block (5) through piston, force F2 causes rotational moment at surroundings of cylinder.

Since cylinder block has 9 equidistantly arrayed pistons, rotational torque is transmitted to cylinder shaft in order by several pistons connected to the inlet port of high pressurized oil. When the direction of oil flow is reversed, rotational direction of cylinder is also reversed. Output torque is given by the equation.

$$T = \frac{p \times q}{2\pi} , q = Z \cdot A \cdot PCD \cdot tan\theta , F_1 = \frac{F}{COS\theta} , F_2 = F tan\theta , S = PCD \times tan\theta$$

Where p: Effective difference of pressure (kgf/cm²)

- q : Displacement (cc/rev)
- T : Output torque (kgf \cdot cm)
- Z : Piston number
- A : Piston area (cm²)
- θ : Tilting angle of swash plate (degree)
- S : Piston stroke (cm)



36072SM04A


2) MAKE UP VALVE

In the system using this type of motor, there is no counter balance functioning valve and there happens the case of revolution exceeding hydraulic supply of motor. To prevent the cavitation caused by insufficient oil flow there is a make up valve to fill up the oil insufficiency.

A make up valve is provided immediately before the port leading to the hydraulic oil tank to secure feed pressure required when the hydraulic motor makes a pumping action. The boost pressure acts on the hydraulic motor's feed port via the make up valve.


Pressurized oil into the port B, the motor rotate counterclockwise.

If the plunger of MCV moves neutral position, the drain oil from Mu port run into motor via right make up valve, which prevent the cavitation of motor.



36072SM05

3) RELIEF VALVE




- 1 Body
- 2 Seat
- 3 Plunger
- 4 Spring
- 5 Adjusting screw
- 6 Piston
- 7 Sleeve
- 8 O-ring
- 9 Back up ring
- 10 O-ring

(1) Construction of relief valve


The valve casing contains two cartridge type relief valves that stop the regular and reverse rotations of the hydraulic motor. The relief valves relieve high pressure at start or at stop of swing motion and can control the relief pressure in two steps, high and low, in order to insure smooth operation.

(2) Function of relief valve

Figure illustrates how the pressure acting on the relief valve is related to its rising process. Here is given the function, referring to the figure following page.




Ports (P, R) at tank pressure.



36072SM07


(2) When hydraulic oil pressure (P×A1) reaches the preset force (FsP) of spring (4), the plunger (3) moves to the right as shown. $P_1 \times A_1 = F_{SP+}P_g \times A_2$

$$P1 = \frac{Fsp + Pg \times A2}{A1}$$



36072SM08


③ The oil flow chamber g via orifice m and n. When the pressure chamber g reaches the preset force (Fsp) of spring (4), the piston (6) moves left and stop the piston (6) hits the bottom of sleeve (7).



36072SM09

④ When piston (6) hits the end of sleeve (7), it stops moving to the left any further. As the result, the pressure in chamber (g) equals (Ps). Γ. . n Ρ A₂

$$PS \times A1 = FSP + PS \times A2$$




36072SM10

4) BRAKE SYSTEM

(1) Control valve swing brake system

This is the brake system to stop the swing motion of the excavator for during operation. In this system, the hydraulic circuit is throttled by the swing control valve, and the resistance created by this throttling works as a brake force to slow down the swing motion.



R130SM05


(2) Mechanical swing parking brake system

The mechanical swing parking brake system is installed to prevent the upper structure from swinging downhill because of its own weight when the excavator is parked on a slope since it completely eliminates the hydraulic drift of swing motion while the excavator is on a slop, work can be done more easily and safely.

① Brake assembly

Circumferential rotation of separate plate (12) is constrained by the groove located at housing (5). When housing is pressed down by brake spring (16) through friction plate (11), separate plate (12) and brake piston (13), friction force occurs there.


Cylinder block (9) is constrained by this friction force and brake acts, while brake releases when hydraulic force exceeds spring force.



② Operating principle

a. When one of the RCV lever (1) is set to the operation position, the each spool is shifted to left or right and the pilot oil flow is blocked. Then the pilot oil go to SH of the time delay valve (3). This pressure moves spool (5) to the leftward against the force of the spring(8), so pilot pump charged oil (P3) goes to the chamber G through port PG.


This pressure is applied to move the piston (6) to the upward against the force of the spring (9). Thus, it releases the brake force.



36072SM12

b. When all of the RCV lever (1) are set the neutral position, the spool (5) returns to right.
 Then, the piston (6) is moved lower by spring force and the return oil from the chamber G flows back to tank port.

At this time, the brake works.




36072SM13A

c. When the swing control (1) lever is set the neutral position the spool (5) returns right in the time delay valve (3).

Then, the piston (6) is moved lower by spring force and the return and the return oil from the chamber G flows back to D-port through orifice (10) of the poppet (7).

At this time, the poppet (7) works to make a time lag for 5 seconds.





38092SM04

GROUP 4 TRAVEL DEVICE

1. CONSTRUCTION (TYPE 1)

Travel device consists travel motor and gear box. Travel motor include counter balance valve, cross over relief valve.






VIEW X

Dr *-	
	Hi Hi Hi Hi Hi Hi Hi Hi Hi Hi Hi Hi Hi H
	Hydraulic Cricuit

		3607A2TM01	
Port	Port name	Port size	
А	Main port	SAE 6000 psi 1"	
В	Main port	SAE 6000 psi 1"	
Pi	Pilot port	PF 1/4	
Dr	Drain port	PF 1/2	
Ν	Negative brake release port	NPTF 1/16	
Pa, Pb	Pressure gauge port	PF 1/4	
Pr	Brake release pressure gauge port	PF 1/4	
L	Level gauge	PF 1/2	
GIN	Gear oil inlet port	PF 1/2	
GOUT	Gear oil drain port	PF 1/2	

1) TRAVEL MOTOR (1/2)




- 101 Drive shaft
- 102 Roller bearing
- 103 Needle bearing
- 107 Snap ring
- 111 Cylinder block
- 113 Spherical bushing
- 114 Cylinder spring
- 121 Piston
- 122 Shoe
- 123 Set plate
- 131 Valve plate
- 201 Swash plate
- 272 Shaft casing

- 303 Valve casing
- 351 Reducing valve
- 352 Cover
- 435 Snap ring
- 451 Pin
- 461 Plug
- 472 O-ring 491 Oil seal
- 502 Piston
- 503 Shoe 504 Pivot ball
- 545 Orifice
- 545 Office
- 546 Orifice

- 547 O-ring
- 702 Brake piston
- 703 Orifice
- 704 Orifice
- 705 Brake spring
- 707 O-ring
- 708 O-ring
- 741 Separation plate
- 742 Friction plate
- 801 Name plate
- 802 Rivet

TRAVEL MOTOR (2/2)



3607A2TM03

- 022 Counterbalance spool 350 Relief valve
- 361 Washer
- 362 Counterbalance spring
- 364 Counterbalance cover
- 365 O-ring
- 366 Hex socket bolt
- 401 Hex socket bolt
- 402 Hex socket bolt
 464 VP plug
 485 O-ring
 509 O-ring
 531 Tilting spool
 533 Tilting spring
 541 Seat
 542 Stopper
- 543
 Steel ball

 564
 Plug


 567
 VP plug

 569
 RO plug

 571
 RO plug

 572
 O-ring

2) REDUCTION GEAR



3607A2TRG01


- 1 Ring gear
- 2 Housing
- 4 Side cover
- 5 Carrier 1
- 6 Carrier 2
- 9 Sun gear 1
- 10 Sun gear 2
- 11 Sun gear 3
- 12 Planetary gear 1
- 13 Planetary gear 2
- 14 Planetary gear 3
- 16 Pin 2
- 17 Pin 3
- 18 Side plate

- 19 Side plate
- 20 Side plate
- 21 Needle cage
- 22 Needle cage
- 23 Needle cage
- 24 Inner ring
- 25 Floating bushing
- 26 Thrust ring
- 27 Thrust ring
- 29 Socket bolt
- 30 Socket bolt
- 32 RO plug
- 33 Angular bearing
- 34 Floating seal

- 35 Shim
- 36 Spring pin
- 37 Snap ring
- 44 Snap ring
- 45 Clip
- 46 W clip
- 47 Nut ring
- 51 Name plate
- 52 Rivet
- 53 Washer
- 54 Set screw
- 81 O-ring
- 82 O-ring
- 83 O-ring

2. FUNCTION

1) GENERATION OF TORQUE



The pressurized oil delivered from the hydraulic pump flows to valve casing (303) of the motor, passes through the brake valve mechanism, and is introduced into cylinder block (111) via valve plate (131). This oil constructively introduced only to one side of (Y1)- (Y2) connecting the upper and lower dead points of stroke of piston (121). The pressurized oil led to one side in cylinder block (111) pushes each piston (121) four or five and generates a forec [F (kgf) = P (kgf/cm²) × A (cm²)].

This force acts on swash plate (201), and is resolves into components (F2 and F3) because swash plate (201) is fixed at an angle (α) with the axis of drive shaft (101).

Radial component (F3) generates respective torques ($T=F3 \times ri$) for (Y1)- (Y2). This residual of torque [T=S ($F3 \times ri$)] rotates cylinder block (111) via piston (121).


Since the cylinder block (111) is spline coupled with drive shaft (101).

So the drive shaft (101) rotates and the torque is transmitted.

2) RELIEF VALVE

The relief valve mainly has the following two functions :

- (1) To keep the starting pressure of the hydraulic motor at a constant value and bypass to the return line excessive oil generated at the motor inlet depending upon the acceleration speed of the driven inertia.
- (2) To generate a brake pressure at the outlet during stopping of the driven inertia, and stop it forcedly.



3607A2TM06


The chamber A is always connected to the port A of the motor.

When the pressure at port A increases and the force pushing poppet A is higher than the set pressure of the spring, then poppet A is pushed up from the contact surface of seat A, and oil flows from chamber A to port B.

3) NEGATIVE BRAKE

The negative brake is released applying to the brake piston (702) the pressure led through the built-in counterbalance spool sub-assembly (022).

With no pressure working, the brake force is always ensured.




3607A2TM07

The brake force is the friction force generated on the surfaces of the friction plates (742) splinecoupled with the cylinder block (111), when their rotation is restricted by the shaft casing (272), separation plate (741), and brake piston (702).

Without pressure being applied to the brake piston, the brake piston is pushed by fourteen brake springs (705), and the friction plate and separation plate are held between the brake and shaft casing. This holding force functions as the friction force. This friction force restrains the shaft (101) spline-coupled with the cylinder block, and this function is the brake.

4) PRESSURE RELEASE VALVE (Flow control valve)



3607A2TM08A

This brake is of a backpressure-insensitive type. In other words, since the counterbalance spool used be overlapped at the neutral position, the pressure release valve prevents the circuit backpressure from working into the brake chamber when the machine stops traveling and works, and so the specified brake torque is available even on a slope.

During normal traveling, the pressure coming through the counterbalance valve is applied to the brake chamber to release the break, and is also applied to the pressure release valve section.

This pressure release valve is of a constant differential pressure type, and irrespective of the working pressure, the passing flow is constant and approximately 1 to 2 *l* / min.

When the condition changes from traveling to stop, the counterbalance spool returns to its neutral position. The brake piston is pushed by the brake spring, and the oil in the brake chamber flow to the motor drain line via the pressure release valve. Then the brake torque is generated.


5) RELEASING METHOD OF NEGATIVE BRAKE

In releasing the negative brake without applying the brake releasing pressure, follow the procedures shown below.

Details of work	Tools	
Remove two plugs (564) from the valve casing (303).		
(For their position, see the attached installation dimension)		
Tighten an M10 screw of 135 mm in length into a tapped hole	Socket wrench	
of the brake piston (702). Then the condition having the brake	6 mm	
release pressure is attained and the brake is released.	8 mm	

Note : Even with the negative brake released, the hydraulic motor will not turn. When it is difficult to generate the working pressure due to failure of the pump or so, and the whole machine is to be pulled for transportation without removing the hydraulic motor, connect pressure measurement ports A_M and B_M with a short hose or something. Then the machine can be pulled slowly.

6) COUNTERBALANCE VALVE



Suppose port Bv is connected to the hydraulic pump and Port Av, to the tank. The oil supplied from the hydraulic pump passes through Bv, Cv and C' in sequence, pushes up the poppet of the check valve, passes through K to Port Bm, and is supplied to the hydraulic motor to turn it.

3607A2TRG03

Therefore, the pump discharge oil pressure increases, and the pressure is led via passage G to spring room E and via the ball check valve to dumping room M. When the pressure in rooms E and M exceeds the value equivalent to the force of the spring which holds the spool at its neutral position, the spool begins to move left. Since the working oil in room N flows into room F via throttle 1' or clearance 2' and that in room F is discharged via passage G' through port Av to the tank, the spool moves left to have passage L-Dm-D'-Dv composed. In addition, passage Cv-H-P is also composed, and the pump discharge pressure in port Bv is led to port P.

Because of the throttle or clearance provided for the working oil flow from room N, this changeover motion of the spool is comparatively slow.

When the pump discharge pressure is higher, the spool movement is larger and the above opening area of the spool is larger.

When the pump discharge pressure falls, pressures in rooms E and M fall and the spool will move right due to the spring on the room F side.

Since working oil in room M flows to room E via throttle 1 and that in room E, to port Bv via passage G, the spool moves right.

When the pressure at port Bv falls down to the tank pressure, the pressure in room E also falls to the tank pressure and becomes equal to that in room F, and so the spool returns to its neutral position.


7) DISPLACEMENT CHANGEOVER SECTION

As a supporting mechanism for the swash plate (201) on which the shoes (122) slide, the pillar system is adopted to support the load with semi-cylindrical sliding bearings provided at both ends of the mechanism.

The capacity is changed by changing the tilting angle of this swash plate.


This is a mechanism that swash plate was pushed by tilting position, and the tilting angle of the swash plate is decided in two positions (large and small) by controlling the flows to and from these piston rooms with the displacement changeover valve section.

(1) External pilot pressure : Pi = 0 Large displacement



3607A2TM04

By means of the built-in high pressure selector mechanism in the valve casing (303), the high pressure oil working on the motor functions to port P of the displacement-changeover valve. This pressure becomes the servo pressure. Since the spool (531) assembled in the displacement changeover valve is pressed to plug (571) by thy spring (533), the high pressure oil at port P is enclosed.




3607A2TM05

The force working on the spool (531) of the displacement-changeover valve becomes higher than that of the spring (533), and the spool moves left. The high pressure oil flows from port P of the displacement-changeover valve through port S and passage B to room C where it works. The displacement changeover piston (502) is pushed light by the high pressure oil and the swash

plate moves in the arrowed direction. The swash plate moves until it touched stopper S, and then is fixed there.

8) REDUCTION GEAR

The reduction gear is composed of a three-stage planetary gear mechanism shown in the following figure. Since the sun gear is designed to have a floating mechanism, errors of the gears and carrier pin hole pitches will not affect the gears' lives heavily.



3607A2TRG04

The input rotation of the hydraulic motor is transmitted to No. 1 sun gear (S1) and this drives No. 1 planetary gears (P1). This No. 1 planetary gears (P1) drive No.1 ring gear (R1) with the same force as the meshing tangential force with No. 1 sun gear (S1), and also No. 1 carrier (C1) with the same force as the meshing reaction force. In other words, No. 1 planetary gears (P1) revolve rotating. This rotation of No. 1 carrier (C1) becomes the output of the 1st stage, and is transmitted directly to No. 2 sun gear (S2).

(No. 1 carrier is spline-coupled with No. 2 sun gear.) Similarly the revolution of No. 2 planetary gear (P2) are transmitted via No.2 carrier (C2) to No. 3 sun gear (S3). Since No. 3 carrier (C3) supporting No. 3 planetary gears (P3) are fixed, No. 3 planetary gears (P3) do not revolve, but rotates to drive No. 3 ring gear (R3).

Therefore, the rotating case is driven by the overall driving torque of No1, 2 and 3 ring gears. This reduction ratio is expressed as shown below:

$$i = \frac{(ZS1 + ZR1) (ZS2 + ZR2) (ZS3 + ZR3)}{ZS1 \cdot ZS2 \cdot ZS3} - 1$$

where Z: Number of teeth of each gear


The direction of rotation is reverse to that of the input shaft.

■ TRAVEL MOTOR (TYPE 2)

1. CONSTRUCTION

Travel device consists travel motor and gear box.

Travel motor includes brake valve, parking brake and high/low speed changeover mechanism.



2-	7	0	_	1
2-	7	0	-	1

Dr

Ma, Mb

Ν

Drain port

Gage port

Brake release port


PF 1/2

PF 1/4

PF 1/4

2. SPECIFICATION

1) TRAVEL MOTOR



Shaft casing
Plug
Orifice
Orifice screw
Swash piston
Swash ball
Brake pin
Shaft
Roller bearing
Stop ring
Lock ring
Swash plate
Cylinder block
Cylinder spring


15 Spacer 16 Ball guide Set plate 17 18 Piston & Shoe assy 19 Friction plate 20 Separator plate 21 Brake piston 22 Piston ring 23 Piston ring 24 O-ring Brake spring 25 26 Valve casing 27 Valve plate pin 28 Valve plate

29 Needle bearing 30 O-ring 31 Swash spool 32 Swash spring 33 Plug 34 O-ring 35 O-ring 36 Seat 37 Steel ball 38 Stopper 39 Plug 40 O-ring 41 Plug 42 O-ring

Delief velve ees
Relief valve assy
Main spool
Check
Spring
Plug
O-ring
Spring seat
Spring
Cover
Spring
Spool
Steel ball
Spring
Plug

57	Spring seat
58	O-ring
59	Orifice
60	Wrench bolt
61	Name plate
62	Rivet
63	Oil seal
64	Snap ring
65	Wrench bolt
66	Wrench bolt
67	Spring pin
72	Floating seal
73	Hub
74	Bearing

75	Shim
76	Bearing guide
77	Wrench bolt
78	Carrier
79	Planetary gear
80	Plate
81	Needle bearing
82	Bearing bushing
83	Pin
84	Spring pin
85	Thrust plate
86	Sun gear
87	Snap ring
88	Carrier



3809A2TM22

90 Plate 91 Needle bearing 92 Pin

89 Planetary gear

- 93 Spring pin
- 94 Sun gear
- 95 Snap ring
- 96 Carrier
- 97 Planetary gear
- 98 Needle bearing Pin
- 99
- 100 Coupling
- 101 Ring gear
- 102 Wrench bolt

- 103 Planetary pin
- 104 Drive gear
- 105 End cover
- 106 Plate
- 107 Wrench bolt
- 108 O-ring
- 109 Ring
- 110 Ring
- 111 Plug
- 112 O-ring
- 113 Bushing


3. PRINCIPLE OF DRIVING

Travel motor comprises with rotary, relief valve, parking brake, counterbalance valve and 2-speed control.

1) WORKING OF ROTARY PART

In the figure below, axis direction power F occurs, when the high pressure oil flows in the cylinder block through to the valve plate (1) port, and the piston moves to the left hand side.

This power F, which takes shoe (2) as a medium, split into F1 power vertical to swash plate (3), and F2 power perpendicular from an axis. Through F2 power, cylinder block rotate with piston and shoe, while shoe (2) moves on the swash plate with piston. There are 9 pistons inserted into the cylinder block and they rotate with the cylinder block by taking high pressure gas in order at the entrance. When you reverse the flow of the high pressure oil, piston and cylinder block rotate in the opposite direction above the shoe plate.




2) WORKING OF RELIEF VALVE

When the port from control valve to motor is closed, traveling movement stops. However, motor continues rotating because of the traveling inertia of the machine's upper body.

By doing so, motor is damaged by the gradual rising of the pressure at the exit.

To prevent this damage, relief valve discharge the gradual rising pressure from the exit to the entrance which has lower pressure.



- Setting pressure : 360 kgf/cm²
- Back pressure : 5 kgf/cm²
- Cracking pressure : 330 kgf/cm² over

- AT THE BEGINNING OF TRAVELING

RELIEF VALVE A


Traveling manipulation lever works to rise the pressure of RA port up. When this pressure oil press plunger to the right, and then sustain the power of the spring, the plunger moves to the right and release the pressure oil of RA port to RB port (stage 1).


The plunger moves slowly by the pressure oil which flows into chamber 1 through orifice 1.

The pressure oil flowed into chamber 1 flows into chamber 2 through orifice 2, and at this point, the plunger moves to the left again, when the spring is compressed by the flowed pressure oil which press the spool to the left. (stage 2).

When the RA port pressure goes up much more and the set pressure overcome the power of the compressed spring again, the plunger moves to the right and the pressure has of RA port is released to RB port.

Thus, at the early stage of the relief-valve operation, it works primarily at lower pressure, after then, shock is reduced during rotating at the set pressure as the secondary operation.






- DURING TRAVELING OPERATION

RELIEF VALVE B

During traveling operation, RA port pressure goes up and RB port pressure goes down. Thus RA port pressure oil flows into chamber 3, and pushes plunger to the left with a high pressure and the power of the spring.



RELIEF VALVE B


3809A2TM26

- WHEN IT STOP

RELIEF VALVE B

When it stops or operates reversely, RA port pressure is extremely lowered and RB port pressure gradually goes up because of the swing inertia from the upper swing part of machine.

Consequently, relief valve B operates as the same order as relief valve A, and maintains the set pressure by releasing the high pressure of RB port to RA port.



RELIEF VALVE B

3) WORKING OF PARKING BRAKE


Parking brake consists of many wet friction plate. The brake is usually held with the power of spring, and it only removed by traveling pressure of motor.

• Parking brake OFF

If worker operates the traveling control lever, traveling working pressurized oil into IN PORT flows from spool chamber through counter orifice.

Pressurized oil pushes counter balance spool to right.

Then notch of spool opens the brake line. At the same time, pressurized oil flow to brake chamber of motor from brake line. Brake piston to force of brake spring moves to right and brake lift.




Parking brake ON

If worker leave lever in neutral, pressurized oil supply to in port of motor stop. If pressurized oil supply stop, in port pressure decline and pressurized oil of spool chamber moves to oil tank through counter orifice. Therefore counter balance spool return in neutral. If spool leave in neutral, notch (a) part of spool obstructed and brake pressurized oil obstructed.

Brake pressurized oil line obstructed. So pressurized oil supply to brake chamber obstructed.

Therefore if pressure of brake chamber decline, brake piston to force of brake spring moves to left and push friction plate.

If brake force happens, brake stop. And pressurized oil to brake chamber drain to motor casing internal through line \bigcirc to counter spool center.




4) COUNTERBALANCE VALVE

• Function of counterbalance valve

- (1) Parking brake off and operation of motor
- (2) When motor descend in slope, traveling velocity control.
- (3) After motor stop in slope, slip prevention.
- (4) When motor stop, supplement the flow.

• NEUTRAL



5) HOW TO WORK


(1) When motor travel

If worker operates the traveling control lever, traveling working pressurized oil into IN PORT flows from spool chamber through counter orifice.

If spool moves to right, notch of spool open line (a) of brake pressurized oil.

Then pressurized oil lift the brake. At the same time, notch of counterbalance spool opens the line (b).

Flowed pressurized oil to A port opens check valve and cylinder block of motor rotate.



(2) When motor stop


If worker leave lever in neutral, pressurized oil supply to in port of motor stop.

If pressurized oil supply stop, A port pressure decline and pressurized oil of spool chamber moves to oil tank through counter orifice. Therefore counterbalance spool return in neutral.

If counterbalance spool moves to left, line (b) by notch of counterbalance spool obstructed and brake pressurized oil obstructed.

At the same time, line (a) by notch of counterbalance valve obstructed. Therefore brake obstructed.

If brake force happens, brake stop.



6) TWO SPEED (LOW SPEED - HIGH SPEED) CHANGEOVER EQUIPMENT


Rotation speed of track motor is depended on slope angle of swash plate (12). When swash plate angle is Max, the motor rotates at low speed. When swash plate angle is Min, the motor rotates at high speed.

· Low speed

- When the pilot pressure on spool (31) is disconnected, pilot pressure does not pass to pilot port A. Two speed changeover spool (31) moves right by the spring (32) force.
- High pressure oil of (a) port (or (b) port) of cylinder block flow to P port of two speed changeover spool (31) through shuttle valve.


Pressurized oil of two speed changeover spool flow to chamber A of swash piston (5) through S2 port.

- Swash plate moves to increase swash angle, so the motor rotates at low speed.



• High speed

- The pilot pressure on spool (31) of the displacement changeover valve overcomes the force of spring (32), and the spool moves left.
- High pressure oil of ⓐ port (or ⓑ port) of cylinder block flow to P port of two speed changeover spool (31) through shuttle valve.
- Swash plate moves to decrease swash angle, so the motor rotates at high speed.



4. REDUCTION GEAR

1) PLANETARY GEAR MECHANISM

Reduction unit slows down the rotating speed of motor and converts motor torque to strong rotating force.


This reduction unit utilizes two stages, planetary reduction system.

Planetary reduction system consists of sun gear, planetary gears, carriers and ring gear.

When the sun gear (s) is driven through input shaft, planetary pinions (b), rotating on their center, also move, meshing with fixed ring gear (a), around sun gears (s).

This movement is transferred to carrier (k) and deliver the torque.


This mechanism is called planetary gear mechanism.



2) TWO STAGES REDUCTION GEAR

When the sun gear S1 is driven by input shaft, planetary action occurs among gears S1, a and b and revolution of gear b transfers the rotation of carrier K1 to second sun gear S2, and also evokes planetary action between gear S2, a and d.

This time, because carrier K2 is fixed to frame, gear d drives ring gear a and then ring gear a rotates to drive sprocket.




29072TM12

GROUP 5 RCV LEVER

1. STRUCTURE

The casing has the oil inlet port P (primary pressure) and the oil outlet port T (tank). In addition the secondary pressure is taken out through ports 1, 2, 3 and 4 provided at the bottom face.




CROSS SECTION

The construction of the pilot valve is shown in the attached cross section drawing. The casing has vertical holes in which reducing valves are assembled.

The pressure reducing section is composed of the spool (4), spring (6) for setting secondary pressure, return spring (10), stopper (8), spring seat (7, 13) and shim (5). The spring for setting the secondary pressure has been generally so preset that the secondary pressure is 5 to 20.5 kgf/cm² (depending on the type). The spool is pushed against the push rod (9, 11) by the return spring. When the push rod is pushed down by tilting the handle, the spring seat comes down simultaneously

and changes setting of the secondary pressure spring.



3 Bushing

Plug

1

2

- 4 Spool
- 5 Shim
- 6 Spring
- 7 Spring seat
- 10 Spring
- 11 Push rod
- 12 Spring
- Spring seat 13
- 14 Plug
- 17 Plate 24 18 Boot 25 19 Joint assembly 26 27 20 Swash plate 21 Adjusting nut 28

32092RL01

- Lock nut
- Handle assembly
- Handle bar
- Nut
- Boot
- Spring pin
- Bushing

2. FUNCTIONS

1) FUNDAMENTAL FUNCTIONS

The pilot value is a value that controls the spool stroke, direction, etc of a main control value. This function is carried out by providing the spring at one end of the main control value spool and applying the output pressure (secondary pressure) of the pilot value to the other end.

For this function to be carried out satisfactorily, the pilot valve is composed of the following elements.

- (1) Inlet port (P) where oil is supplied from hydraulic pump.
- (2) Output ports (1, 2, 3 & 4) to apply pressure supplied from inlet port to ends of control valve spools.
- (3) Tank port (T) necessary to control the above output pressure.
- (4) Spool to connect output port to inlet port or tank port.
- (5) Mechanical means to control output pressure, including springs that work on the above spools.

2) FUNCTIONS OF MAJOR SECTIONS

The functions of the spool (4) are to receive the supply oil pressure from the hydraulic pump at its port P, and to change over oil paths to determine whether the pressure oil of port P is led to output ports 1, 2, 3 & 4 or the output port pressure oil to tank port T.

The spring (6) works on this spool to determine the output pressure.

The change the deflection of this spring, the push rod (9,11) is inserted and can slide in the plug (14).

For the purpose of changing the displacement of the push rod through the swash plate (20) and adjusting nut (21) are provided the handle (23) that can be tilted in any direction around the fulcrum of the universal joint (19) center.


The spring (10) works on the case (1) and spring seat (7, 13) and tries to return the push rod (9,11) to the zero-displacement position irrespective of the output pressure, securing its resetting to the center position.

This also has the effect of a reaction spring to give appropriate control feeling to the operator.

3) OPERATION

The operation of the pilot valve will be described on the basis of the hydraulic circuit diagram shown below and the attached operation explanation drawing.

The diagram shown below is the typical application example of the pilot valve.




2 Pilot pump

1

- 4 Main control valve

2-70


6 Hydraulic cylinder (1) Case where handle is in neutral position



21092RL03

The force of the spring (6) that determines the output pressure of the pilot valve is not applied to the spool (4). Therefore, the spool is pushed up by the spring (10) to the position of port (1, 3) in the operation explanation drawing. Then, since the output port is connected to tank port T only, the output port pressure becomes equal to tank pressure.

(2) Case where handle is tilted



21092RL04

When the push rod (11) is stroked, the spool (4) moves downwards.

Then port P is connected with port (1) and the oil supplied from the pilot pump flows through port (1) to generate the pressure.

When the pressure at port (1) increases to the value corresponding to the spring force set by tilting the handle, the hydraulic pressure force balances with the spring force. If the pressure at port (1) increases higher than the set pressure, port P is disconnected from port (1) and port T is connected with port (1). If it decreases lower than the set pressure, port P is connected with port (1) and port T is disconnected from port 1.


In this manner the secondary pressure is kept at the constant value.


Besides, in some type, when the handle is tilted more than a certain angle, the upper end of the spool contacts with the inside bottom of the push rod and the output pressure is left to be connected with port P.


GROUP 6 RCV PEDAL


1. STRUCTURE

The casing (spacer) has the oil inlet port P (primary pressure), and the oil outlet port T (tank). In addition the secondary pressure is taken out through ports 1,2,3 and 4 provided at the bottom face.










Port	Port	Port size
Р	Pilot oil inlet port	
Т	Pilot oil return port	
1	Travel (LH, forward)	PF 1/4
2	Travel (LH, backward)	
3	Travel (RH, forward)	
4	Travel (RH, backward)	

CROSS SECTION

The construction of the RCV pedal is shown in the below drawing. The casing has vertical holes in which reducing valves are assembled.

The pressure reducing section is composed of the spool (8), spring (6) for setting secondary pressure, return spring (10), stopper (9), and spring seat (7). The spring for setting the secondary pressure has been generally so preset that the secondary pressure is 5 to 19 kg/cm² (depending on the type). The spool is pushed against the push rod (14) by the return spring.

When the push rod is pushed down by tilting pedal, the spring seat comes down simultaneously and changes setting of the secondary pressure spring.



- 9 Stopper 10 Spring
- Rod guide 11
- 12
- O-ring
- 13 Snap ring

- 22 O-ring
- 23 Rod seal
- 24 Dust seal
- Cover 25
- Socket bolt 26

- O-ring 35
- 36 O-ring
- Socket bolt 37
- Piston 38

2. FUNCTION

1) FUNDAMENTAL FUNCTIONS

The pilot valve is a valve controls the spool stroke, direction, etc of a main control valve. This function is carried out by providing the spring at one end of the main control valve spool and applying the output pressure (secondary pressure) of the pilot valve to the other end.

For this function to be carried out satisfactorily, the pilot valve is composed of the following elements.

- (1) Inlet port (P) where oil is supplied from hydraulic pump.
- (2) Output port (1, 2, 3 & 4) to apply pressure supplied from inlet port to ends of control valve spools.
- (3) Tank port (T) necessary to control the above output pressure.
- (4) Spool to connect output port to inlet port tank port.
- (5) Mechanical means to control output pressure, including springs that work on the above spools.

2) FUNCTIONS OF MAJOR SECTIONS

The functions of the spool (8) are to receive the supply oil pressure from the hydraulic pump at its port P, and to change over oil paths to determine whether the pressure oil of port P is led to output ports 1, 2, 3 & 4 or the output spool to determine the output pressure.

The spring (6) works on this spool to determine the output pressure.

The change the deflection of this spring, the push rod (14) is inserted and can slide in the plug (21). For the purpose of changing th displacement of the push rod through the cam (27) and adjusting nut (32) are provided the pedal that can be tilted in any direction around the fulcrum of the cam (27) center.


The spring (10) works on the casing (1) and spring seat (7) and tries to return the push rod (14) to the zero-displacement position irrespective of the output pressure, securing its resetting to the center position.

This also has the effect of a reaction spring to give appropriate control feeling to the operator.

3) OPERATION


The operation of the pilot valve will be described on the basis of the hydraulic circuit diagram shown below ant the attached operation explanation drawing.

The diagram shown below is the typical application example of the pilot valve.



- 1 Pilot valve
- 2 Pilot pump
- 3 Main pump
- 4 Main control valve
- 5 Hydraulic motor
- 6 Hydraulic cylinder


(1) Case where pedal is in neutral position



21092RP03

The force of the spring (6) that determines the output pressure of the pilot valve is not applied to the spool (8). Therefore, the spool is pushed up by the spring (10) to the position of port 2 in the operation explanation drawing. Then, since the output port is connected to tank port T only, the output port pressure becomes equal to tank pressure.

(2) Case where pedal is tilted



21092RP04

When the push rod (14) is stroked, the spool (8) moves downwards.

Then port P is connected with port 1, and the oil supplied from the pilot pump flows through port 1 to generate the pressure.

When the pressure at port 1 increases to the value corresponding to the spring force set by tilting the handle, the hydraulic pressure force balances with the spring force. If the pressure at port 1 increases higher than the set pressure, port P is disconnected from port 1 and port T is connected with port 1. If it decreases lower than the set pressure, port P is connected with port 1 and port 1 and port 1.


In this manner the secondary pressure is kept at the constant value.

Besides, in some type, when the handle is tilted more than a certain angle, the upper end of the spool contacts with inside bottom of the push rod and the output pressure is left to be connected with port P.

SECTION 3 HYDRAULIC SYSTEM

Group	1 Hydraulic Circuit ·····	3-1
Group	2 Main Circuit	3-2
Group	3 Pilot Circuit	3-5
Group	4 Single Operation	3-13
Group	5 Combined Operation	3-23

GROUP 1 HYDRAULIC CIRCUIT




SECTION 3 HYDRAULIC SYSTEM

GROUP 2 MAIN CIRCUIT

The main hydraulic circuit consists of suction circuit, delivery circuit, return circuit and drain circuit. The hydraulic system consists of one main pump, one control valve, one swing motor, four cylinders and two travel motors.

The swash plate type variable displacement tandem axial piston pump is used as the main pump and is driven by the engine at ratio 1.0 of engine speed.

1. SUCTION AND DELIVERY CIRCUIT



3-02


The pumps receive oil from the hydraulic tank through a suction filter. The discharged oil from the pump flows into the control valve and goes out the tank ports.

The oil discharged from the main pump flows to the actuators through the control valve.

The control valve controls the hydraulic functions.

The return oil from the actuators flows to the hydraulic tank through the control valve and the oil cooler.

2. RETURN CIRCUIT



29073CI01

All oil from each actuator returns to the hydraulic tank through the control valve.

The bypass check valves are provided in the return circuit.

The setting pressure of bypass check valves are 1.5 kgf/cm² (21psi) and 3.0 kgf/cm² (43psi). Usually, oil returns to the hydraulic tank from the left side of control valve through oil cooler.

When oil temperature is low, viscosity becomes higher and flow resistance increases when passing through the oil cooler. The oil pressure exceeds 3.0 kgf/cm² (43psi), the oil returns directly to the hydraulic tank, resulting in the oil temperature being raised quickly at an appropriate level.


When the oil cooler is clogged, the oil returns directly to the hydraulic tank through bypass check valve (1).

The full-flow filter and bypass relief valve are provided in the hydraulic tank.

The oil from right and left side of control valve is combined and filtered by the return filter. A bypass relief valve is provided in the full-flow filter.

When the filter element is clogged, the bypass relief valve opens at 1.5 kgf/cm² (21psi) differential pressure.

3. DRAIN CIRCUIT



21093Cl02

Besides internal leaks from the motors and main pump, the oil for lubrication circulates. These oil have to be fed to the hydraulic tank passing through drain filter and full flow filter in the hydraulic tank. When the drain oil pressure exceed 1.5 kgf/cm² (21psi), the oil returns to the hydraulic tank directly.

1) TRAVEL MOTOR DRAIN CIRCUIT

Oil leaking from the right and left travel motors comes out of the drain ports provided in the respective motor casing and join with each other. These oils pass through the turning joint and return to the hydraulic tank after being filtered by full flow filter in the hydranlic tank.


2) SWING MOTOR DRAIN CIRCUIT

Oil leaking from the swing motor come out and return to the hydraulic tank passing through a drainfilter.

3) MAIN PUMP DRAIN CIRCUIT

Oil leaking from main pump come out and return to the hydraulic tank passing through drain filter.

GROUP 3 PILOT CIRCUIT




38093Cl01

The pilot circuit consists of suction circuit, delivery circuit and return circuit.

The pilot pump is provided with relief valve, receives the oil from the hydraulic tank through the suction filter.

The discharged oil from the pilot pump flows to the remote control valve through line filter, EPPR valve, solenoid valve assemblies, swing parking brake, main control valve and safety lock solenoid valve.

1. SUCTION, DELIVERY AND RETURN CIRCUIT




The pilot pump receive oil from the hydraulic tank. The discharged oil from the pilot pump flows to the safety solenoid valve through the line filter. The oil is filtered by the line filter. The pilot relief valve is provided in the pilot pump for limiting the pilot circuit pressure.

The oil filtered by line filter flows remote control valve through safety solenoid valve.

The return oil from remote control valve returned to hydraulic tank.


2. SAFETY SOLENOID VALVE (SAFETY LEVER)



When the lever of the safety solenoid value is moved downward, oil flows into the remote control value through solenoid value and line filter.

When the lever of the safety solenoid valve moved upward, oil does not flows into the remote control valve, because of blocked by the spool.

3. BOOM PRIORITY SYSTEM



38093HC04


When carrying out the combined operation of swing and boom up, the boom up operating speed is lowered then normal operation.

To increase working efficiency, swing speed reducing system is used.

The pilot oil from pilot pump flow into **Pns** port in main control valve through boom EPPR valve. **Pns** oil pressure moves swing reducing spool to right direction and oil flow rate to the swing motor decreased.


Then, the boom up speed is increased. This is called the boom priority system.

4. TRAVEL SPEED CONTROL SYSTEM



When the travel speed switch is pushed, the travel speed solenoid valve is actuated and the discharged oil from the pilot pump flows to the **Pi** port of pilot valve in the travel motors. As a result, the control piston is pushed by the main oil flow, thus the displacement is minimized. When the travel speed switch is pushed once more, the travel speed solenoid valve is return to original position by the force of spring, the hydraulic oil of **Pi** port returns to the hydraulic tank. As a result, the control piston is returned by the main oil flow, thus the displacement is maximized.


5. MAIN RELIEF PRESSURE CHANGE CIRCUIT



38093HC06

When the power max switch on the left control lever is pushed ON, the power max solenoid valve is actuated, the discharged oil from the pilot pump flow into PL1 port of the main relief valve of main control valve ; Then the setting pressure of the main control valve is raises from 330 kgf/cm² to 360 kgf/ cm² for increasing the digging power. And even when press continuously, it is canceled after 8

6. SWING PARKING BRAKE RELEASE




When one of the RCV lever (except travel lever) is tilted, the pilot oil flows into SH port through main control valve.

This pressure moves spool so, discharged oil from pilot valve flows to swing motor PG port.

This pressure is applied to swing motor disc, thus the brake is released.

When all of the RCV lever are set in the neutral position, oil in the swing motor disc cylinder is drained, thus the brake is applied.

7. SWING PRIORITY SYSTEM




When carrying out the combined operation of swing and arm of the left control valve, the swing speed can be lowered than operating speed of arm.

PSp pressure from the swing shuttle block change the swing priority spool and decreases the oil flow rate to the next section to make the swing operation most preferential.

This is called the swing priority system. For details, refer to page 2-35.

GROUP 4 SINGLE OPERATION

1. BOOM UP OPERATION



38093HC10

When the RH control lever is pulled back, the boom spools in the main control valve are moved to the up position by the pilot oil pressure from the remote control valve.

The oil from the front and rear pump flows into the main control valve and then goes to the large chamber of boom cylinders.


At the same time, the oil from the small chamber of boom cylinders returns to the hydraulic oil tank through the boom spool in the main control valve. When this happens, the boom goes up.

The excessive pressure in the boom cylinder bottom end circuit is prevented by relief valve.

When the boom is up and the control lever is returned to neutral position, the circuit for the holding pressure at the bottom end of the boom cylinder is closed by the boom holding valve.

This prevents the hydraulic drift of boom cylinder.

2. BOOM DOWN OPERATION



38093HC11


When the RH control lever is pushed forward, the boom 1 spools in the main control valve are moved to the down position by the pilot oil pressure from the remote control valve.

The oil from the rear pump flows into the main control valve and then goes to the small chamber of boom cylinders. At the same time, the oil from the large chamber of boom cylinders returns to the hydraulic tank through the boom 1 spool in the main control valve.

When the down speed of boom is faster, the oil returned from the large chamber of boom cylinder combines with the oil from the rear pump, and flows into the small chamber of the boom cylinder.

This prevents cylinder cavitation by the negative pressure when the rear pump flow can not match the boom down speed. And the excessive pressure in the boom cylinder rod end circuit is prevented by the relief valve.

3. ARM IN OPERATION



38093HC12

When the LH control lever is pulled back, the arm spools in the main control valve are moved the to roll in position by the pilot oil pressure from the remote control valve.


The oil from the front and rear pump flows into the main control valve and then goes to the large chamber of arm cylinder.

At the same time, the oil from small chamber of arm cylinder returns to the hydraulic oil tank through the arm spool in the main control valve. When this happens, the arm rolls in.

The excessive pressure in the arm cylinder head side is prevented by relief valve.

The cavitation which will happen to the head side of the arm cylinder is also prevented by the makeup valve in the main control valve.

4. ARM OUT OPERATION



38093HC13

When the LH control lever is pushed forward, the arm spools in the main control valve are moved to the roll out position by the pilot oil pressure from the remote control valve.

The oil from the front and rear pump flows into the main control valve and then goes to the small chamber of arm cylinder.


At the same time, the oil from the large chamber of arm cylinder returns to the hydraulic oil tank through the arm spools in the main control valve. When this happens, the arm rolls out.

The excessive pressure in the arm cylinder rod side is prevented by relief valve.

When the arm is roll out and the control lever is returned to neutral position, the circuit for the holding pressure at the rod side of the arm cylinder is closed by the arm holding valve.

The cavitation which will happen to the rod side of the arm cylinder is also prevented by the make-up valve in the main control valve.

5. BUCKET IN OPERATION



38093HC14

When the RH control lever is pulled left, the bucket spool in the main control valve is moved to the roll in position by the pilot oil pressure from the remote control valve.


The oil from the rear pump flows into the main control valve and then goes to the large chamber of bucket cylinder. The oil form the front pump flows into the large chamber of bucket cylinder through confluence oil passage in the main control valve by bypass cut pilot pressure (Pca).

At the same time, the oil from the small chamber of bucket cylinder returns to the hydraulic oil tank through the boom spool in the main control valve. When this happens, the bucket rolls in.

The excessive pressure in the bucket cylinder head side is prevented by relief valve.

The cavitation which will happen to the head side of the bucket cylinder is also prevented by the make-up valve in the main control valve.

6. BUCKET OUT OPERATION



38093HC15

When the RH control lever is pushed right, the bucket spool in the main control valve is moved to the roll out position by the pilot oil pressure from the remote control valve.


The oil from the rear pump flows into the main control valve and then goes to the small chamber of bucket cylinder.

At the same time, the oil from the large chamber of bucket cylinder returns to the hydraulic oil tank through the bucket spool in the main control valve. When this happens, the bucket rolls out.

The excessive pressure in the bucket cylinder rod side is prevented by relief valve.

The cavitation which will happen to the rod side of the bucket cylinder is also prevented by the makeup valve in the main control valve.

7. SWING OPERATION



When the LH control lever is pushed left or right, the swing spool in the main control valve is moved to the left or right swing position by the pilot oil pressure from the remote control valve.

Also the swing operation preference function is operated by the pilot pressure Psp (refer to page 2-35).


The oil from the front pump flows into the main control valve and then goes to the swing motor.

At the same time, the return oil from the swing motor returns to the hydraulic oil tank through the swing spool in the main control valve.

When this happens, the upper structure swings to the left or right.

The swing parking brake, make up valve and the motor brake valve are provided in the swing motor. The cavitation which will happen to the swing motor is also prevented by the make up valve in the swing motor itself.

SWING CIRCUIT OPERATION



1) MOTOR BRAKE VALVE

Motor brake valve for the swing motor limits to cushion the starting and stopping pressure of swing operation and controls the swing motor operating pressure.

2) MAKE UP VALVE

The make up valves prevent cavitation by supplying return oil to the vacuum side of the motor.

3) PARKING BRAKE

This is function as a parking brake only when all of the RCV lever (except travel pedal) are not operated.

PARKING BRAKE "OFF" OPERATION

The parking brake is released by the pilot pressure oil from the pilot pump.

When the RCV lever placed in the operating position, the pilot oil flows into SH port through the MCV. This pressure transferred to the brake release valve and the brake release valve is change over. Then the pilot oil pressure PG lift the brake piston and release the parking brake.


PARKING BRAKE "ON" OPERATION

When all of the RCV lever placed in the neutral position, the pressure of the pilot oil passage down. Then the brake release valve returned to the neutral position and the oil is returned from the brake piston to the tank. And the brake is set to 'ON".

4) ANTI-INVERSION VALVE

This anti-inversion valve absorbs shocks produced as swing motion stops and reduced oscillation cause by swing motion.

8. TRAVEL FORWARD AND REVERSE OPERATION




When the travel levers are pushed forward or reverse position, the travel spools in the main control valve are moved to the forward or reverse travel position by the pilot oil pressure from the remote control valve.

The oil from the each pump flows into the main control valve and then goes to the each travel motor through the turning joint.

The return oil from both travel motors returns to the hydraulic oil tank through the turning joint and the travel spools in the main control valve.

When this happens, the machine moves to the forward or reverse.

TRAVEL CIRCUIT OPERATION



38093HC19

Valves are provided on travel motors to offer the following functions.

1) COUNTER BALANCE VALVE


When stopping the motor of slope descending, this valve to prevent the motor over run.

2) OVERLOAD RELIEF VALVE

Relief valve limit the circuit pressure below 360 kgf/cm² to prevent high pressure generated at a time of stopping the machine. Stopping the motor, this valve sucks the oil from lower pressure passage for preventing the negative pressure and the cavitation of the motor.

GROUP 5 COMBINED OPERATION

1. OUTLINE



38093HC20

The oil from the front and rear pump flows through the neutral oil passage, bypass oil passage and confluence oil passage in the main control valve. Then the oil goes to each actuator and operates them. Check valves and orifices are located on these oil passage in the main control valve. These control the oil from the main pumps so as to correspond to the operation of each actuator and smooth the combined operation.


STRAIGHT TRAVEL SPOOL

This straight travel spool is provided in the main control valve.

If any actuator is operated when traveling, the straight travel spool is pushed to the right by the pilot oil pressure from the pilot pump.

Consequently, the left and right travel oil supply passage are connected, and equivalent amount of oil flows into the left and right travel motors. This keeps the straight travel.

2. COMBINED SWING AND BOOM UP OPERATION



38093HC21


When the swing and boom up functions are operated, simultaneously the swing spool and boom spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the front pump flows into the swing motor through swing spool and the boom cylinder through boom 2 spool.

The oil from the rear pump flows into the boom cylinders through the boom 1 spool in the right control valve. The upper structure swings and the boom is operated.

Refer to page 3-8 for the boom priority system.

3. COMBINED SWING AND ARM OPERATION



38093HC22


When the swing and arm functions are operated, simultaneously the swing spool and arm spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the front pump flows into the swing motor through swing spool and the arm cylinder through arm 1 spool.

The oil from the rear pump flows into the arm cylinder through the arm 2 spool of the right control valve. The upper structure swings and the arm is operated.

Refer to page 2-35 for the swing operation preference function.

4. COMBINED SWING AND BUCKET OPERATION



38093HC23


When the swing and bucket functions are operated, simultaneously the swing spool and bucket spool in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the front pump flows into the swing motor through the swing spool in the left control valve.

The oil from the rear pump flows into the bucket cylinder through the bucket spool in the right control valve.

The upper structure swings and the bucket is operated.

5. COMBINED SWING AND TRAVEL OPERATION



38093HC24A


When the swing and travel functions are operated, simultaneously the swing spool and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve and straight travel spool is pushed to the right by the pilot oil pressure from the pilot pump.

The oil from the front pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool.

The oil from the rear pump flows into the swing motor through the swing spool and travel motor through the LH travel spool via the check valve and orifice in the straight travel spool.

The upper structure swings and the machine travels straight.

6. COMBINED BOOM AND TRAVEL OPERATION




When the boom and travel functions are operated, simultaneously the boom spools and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve and the straight travel spool is pushed to the right by the oil pressure from pilot pump.

The oil from the front pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool.

The oil from the rear pump flows into the boom cylinders through the boom 2 spool and boom 1 spool via the parallel and confluence oil passage in case boom up operation. Also, the oil from the rear pump flows into the travel motors through the LH travel spool via the check valve and orifice in the straight travel spool.

The boom is operated and the machine travels straight.

7. COMBINED ARM AND TRAVEL OPERATION




38093HC26

When the arm and travel functions are operated, simultaneously the arm spools and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve and the straight travel spool is pushed to the right by the oil pressure from pilot pump.

The oil from the front pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool.

The oil from the rear pump flows into the arm cylinders through the arm 1 spool and arm 2 spool via the parallel and confluence oil passage. Also, the oil from the rear pump flows into the travel motors through the LH travel spool via the check valve and orifice in the straight travel spool. The arm is operated and the machine travels straight.

8. COMBINED BUCKET AND TRAVEL OPERATION




38093HC27

When the bucket and travel functions are operated, simultaneously the bucket spool and travel spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve, and the straight travel spool is pushed to the right by the oil pressure from pilot pump. The oil from the front pump flows into the travel motors through the RH travel spool of the left control valve and the LH travel spool of the right control valve via the straight travel spool of the control valve.

The oil from the rear pump flows into the bucket cylinder through the bucket spool via the confluence oil passage. Also, the oil from the rear pump flows into the travel motors through the LH travel spool via the check valve and orifice in the straight travel spool.

The bucket is operated and the machine travels straight.

9. COMBINED BOOM UP AND BUCKET OPERATION



38093HC28


When the boom up and bucket functions are operated, simultaneously each spool in the main control valve is moved to the functional position by the pilot oil pressure from the remote control valve. Also, the boom up operation preference function is operated by the pilot pressure PAcs (refer to page 2-33).

The oil from the front pump flows into the boom cylinders through the boom 2 spool in the left control valve. The oil from the rear pump flows into the boom cylinders and bucket cylinder through the boom 1 spool, bucket spool and the parallel and confluence oil passage in the right control valve. The boom and bucket are operated.

Group	1	Component Location	4-1
Group	2	Electrical Circuit	4-3
Group	3	Electrical Component Specification	4-21
Group	4	Connectors	4-29

GROUP 1 COMPONENT LOCATION

1. LOCATION 1




- 1 Cigar light
- awitch namel 10 Day
- 2 Aircon & heater switch panel 12
- 3 Remote controller
- 4 Accel dial switch
- 5 Horn switch
- 6 Breaker operation switch
- 7 Handsfree
- 8 Cluster
- 9 Starting switch
- 10 Service meter

- 11 Safety lever
 - 2 Power max switch
- 13 One touch decel switch
- 14 Fuse box
- 15 Master switch
- 16 Emergency engine connector
- 17 MCU
- 18 RS232 & J1939 service socket
- 19 Radio & CD/MP3 player
- 20 Heated seat switch

- 21 Speaker
- 22 Overload switch
- 23 Beacon switch
- 24 Quick clamp switch
- 25 Cab light switch
- 26 Travel alarm switch
- 27 Washer switch
- 28 Wiper switch
- 29 Main light switch

2. LOCATION 2



38094EL02


- 1 Lamp
- 2 Fuel sender
- 3 Fuel filler pump
- 4 Beacon lamp
- 5 Battery
- 6 Battery relay
- 7 Horn
- 8 P1 pressure sensor
- 9 P2 pressure sensor

- 10 P3 pressure sensor
- 11 Overload pressure sensor
- 12 Heater relay
- 13 Start relay
- 14 Alternator
- 15 Air cleaner switch
- 16 Travel alarm buzzer
- 17 Arm / bucket in pressure sensor
- 18 Boom up pressure sensor

- 19 Swing pressure sensor
- 20 Nega control 1 pressure sensor
- 21 Nega control 2 pressure sensor
- 22 Attach pressure sensor
- 23 Travel pressure sensor
- 24 Solenoid valve
- 25 Pump EPPR valve
- 26 Boom priority EPPR valve


GROUP 2 ELECTRICAL CIRCUIT

· ELECTRICAL CIRCUIT (1/2)



38094EL03B

· ELECTRICAL CIRCUIT (2/2)



38094EL04A


MEMORANDUM

HYUNDAI HEAVY INDUSTRIES CO., LTD CONSTRUCTION EQUIPMENT DIV.

1. POWER CIRCUIT

The negative terminal of battery is grounded to the machine chassis through master switch. When the start switch is in the OFF position, the current flows from the positive battery terminal as shown below.

1) OPERATING FLOW




% I/conn : Intermediate connector

2) CHECK POINT

Engine	Start switch	Check point	Voltage
	① - GND (battery 1EA) ② - GND (battery 2EA)	① - GND (battery 1EA)	10~12.5V
OFF		② - GND (battery 2EA)	20~25V
	UFF	③ - GND (battery 2EA)	20~25V
		④ - GND (fusible link)	20~25V

* GND : Ground

POWER CIRCUIT



38094EL05

2. STARTING CIRCUIT

1) OPERATING FLOW

Battery(+) terminal — Battery relay [CR-1] — Fusible link [CN-60] — Master switch [CS-74A] — Fuse box [No.4] — Master switch [CS-74B] — I/conn [CN-5(36)] — Start switch [CS-2(1)]

(1) When start key switch is in ON position

→ Start switch ON [CS-2 (2)] → I/conn [CN-5 (60)] → Battery relay [CR-1]

--- Battery relay operating (all power is supplied with the electric component)

└─► Start switch ON [CS-2 (3)] ─► GPS conn [CN-125 (2)→(4)] ─► I/conn [CN-5 (59)]

--- Power relay [CR-35 (86) \rightarrow (87)]--- Fuse box [No.10]

ECM power relay [CR-45 (2) \rightarrow (5)] \rightarrow Fuse box [No.8]


(2) When start key switch is in START position

Start switch START [CS-2 (6)] \rightarrow I/conn [CN-5 (35)] \rightarrow Anti-restart relay [CR-5 (2) \rightarrow (5)] \rightarrow I/conn [CN-2 (7)] \rightarrow Start relay [CR-23]

2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (battery)	
		② - GND (start key)	
		③ - GND (battery relay M4)	
OPERATING	START	④ - GND (starter B ⁺)	20~25V
		5 - GND (starter M)	
		⑥ - GND (start relay)	
		⑦ - GND (battery relay M8)	

STARTING CIRCUIT



38094EL06

3. CHARGING CIRCUIT

When the starter is activated and the engine is started, the operator releases the key switch to the ON position.

Charging current generated by operating alternator flows into the battery through the battery relay [CR-1].

The current also flows from alternator to each electrical component and controller through the fuse box.

1) OPERATING FLOW

(1) Warning flow

Alternator "I" terminal — I/conn [CN-2 (9)] — MCU alternator level [CN-51 (39)] — Cluster charging warning lamp(Via serial interface)

(2) Charging flow


Alternator "B⁺" terminal — Battery relay(M8) – Battery(+) terminal – Fusible link [CN-60] – Master switch [CS-74A] – Fuse box

2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (battery voltage)	
		② - GND (battery relay)	
Run	ON	③ - GND (alternator B ⁺ terminal)	20~25V
		④ - GND (alternator I terminal)	
		⑤ - GND (MCU)	

* GND : Ground

CHARGING CIRCUIT



38094EL07

4. HEAD AND WORK LIGHT CIRCUIT

1) OPERATING FLOW

Fuse box (No.15) — Work light relay [CR-4 (30,86)] Fuse box (No.18) — Head light relay [CR-13 (30,86)]

(1) Head light switch ON

Head light switch ON [CN-116 (1)] \longrightarrow I/conn [CN-5 (49)] \longrightarrow Head light relay [CR-13 (85) \rightarrow (87)]

- -- Head light ON [CL-3 (1), CL-4 (1), CL-24 (1)]
- -- I/conn [CN-11 (8)] -- AC & Heater controller illumination ON [4]
- └─► I/conn [CN-5 (13)] ┌─► Remote controller illumination ON [CN-245 (9)]

Cigar light [CL-2]

- → USB & Socket illumination ON [CN-246 (7)]
- Radio & CD/MP3 player illumination ON [CN-27 (9)]

(2) Work light switch ON


Work light switch ON [CN-116 (2)] → I/conn [CN-5 (50)] → Work light relay [CR-4 (85) → (87)] → I/conn [CN-12 (2)] → Work light ON [CL-5 (2), CL-6 (2), CL-36 (2), CL-37 (2)]

2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (fuse box)	
		② - GND (switch power output)	
	OP ON (head light relay) (3) - GND (head light) (5) - GND (fuse box)	③ - GND (head light relay)	20, 25)/
STOD		④ - GND (head light)	
510P		20~25V	
		6 - GND (switch power output)	
		⑦ - GND (work light relay)	
		⑧ - GND (work light)	

* GND : Ground

HEAD AND WORK LIGHT CIRCUIT



38094EL08

5. BEACON LAMP AND CAB LIGHT CIRCUIT

1) OPERATING FLOW

Fuse box (No.27) → I/conn [CN-5 (33)] → Beacon lamp switch [CN-23 (8)] Fuse box (No.16) → Cab light relay [CR-9 (30, 86)]

(1) Beacon lamp switch ON

Beacon lamp switch ON [CS-23 (4)] - Switch indicator lamp ON [CS-23 (11)] - I/conn [CN-10 (10)] - Beacon lamp ON [CL-7]

(2) Cab light switch ON


Cab light switch ON [CN-116 (7)] - I/conn [CN-5 (55)] - Cab lamp relay [CR-9 (85) \rightarrow (87)] -- I/conn [CN-5 (34, 38)] - I/conn [CN-10 (11)] - Cab light ON [CL-8 (2)] I/conn [CN-10 (12)] - Cab light ON [CL-9 (2), CL-10 (2)]

2) CHECK POINT

Engine	Start switch	Check point	Voltage
		① - GND (fuse box)	
		② - GND (switch power input)	
	ON	③ - GND (switch power output)	
STOP		④ - GND (beacon lamp)	20~25V
310F		⑤ - GND (fuse box)	20~23V
		⑥ - GND (cabin light relay)	
		⑦ - GND (switch power output)	
		⑧ - GND (cab light)	

* GND : Ground

BEACON LAMP AND CAB LIGHT CIRCUIT



6. WIPER AND WASHER CIRCUIT

1) OPERATING FLOW

(1) Key switch ON

Fuse box (No.11) -- I/conn [CN-5 (57)] -- Switch panel [CN-116 (10)] Fuse box (No.6) -- I/conn [CN-5 (18)] -- I/conn [CN-17 (5)] -- Wiper motor controller [CN-141(7)] Fuse box (No.17) -- I/conn [CN-5 (24)] -- I/conn [CN-17 (4)] -- Wiper motor controller [CN-141 (6)] -- Washer pump [CN-22 (2)]

(2) Wiper switch ON : 1st step (Intermittent)

Wiper switch ON [CN-116 (3)] \rightarrow I/conn [CN-17 (8)] \rightarrow Wiper motor controller [CN-141 (10) \rightarrow (3)] \rightarrow Wiper motor intermittently operating [CN-21 (6)]

(3) Wiper switch ON : 2nd step (continual)

Wiper switch ON [CN-116(4)] \rightarrow I/conn[CN-17(2)] \rightarrow Wiper motor controller [CN-141(2) \rightarrow (4)] \rightarrow Wiper motor operating [CN-21(2)]

(4) Washer switch ON

Washer switch ON [CN-116 (5)] \longrightarrow l/conn [CN-17 (7)] \longrightarrow Wiper motor controller [CN-141 (9) \rightarrow (8)] \longrightarrow l/conn [CN-17 (6)] \longrightarrow l/conn [CN-5 (19)] \longrightarrow Washer pump [CN-22 (1)] \longrightarrow Washer operating Wiper switch ON [CN-116 (4)] \longrightarrow l/conn[CN-17 (2)] \longrightarrow Wiper motor controller [CN-141 (2) \rightarrow (4)] \longrightarrow Wiper motor operating [CN-21 (2)]

(5) Auto parking (when switch OFF)


Switch OFF [CN-116 (4)] -- Wiper motor parking position by wiper motor controller

2) CHECK POINT


Engine	Start switch	Check point	Voltage
		① - GND (fuse box)	24V
		② - GND (switch power input)	24 V
DOTO	ON ④ - 0 ⑤ - 0	③ - GND (switch power output)	0 ~ 5V
STOP		④ - GND (wiper power input)	0~50
		⑤ - GND (wiper power output)	24V
		6 - GND (wiper motor)	0 or 24V

* GND : Ground


WIPER AND WASHER CIRCUIT




CONTROLLER CIRCUIT



MONITORING CIRCUIT



ELECTRIC CIRCUIT FOR HYDRAULIC



GROUP 3 ELECTRICAL COMPONENT SPECIFICATION

Part name	Symbol	Specifications	Check
Battery		12V × 100Ah (2EA)	 Check specific gravity 1.280 over : Over charged 1.280 ~ 1.250 : Normal 1.250 below : Recharging
Battery relay	CR-1	Rated load : 24V 100A (continuity) 1000A (30seconds)	 * Check coil resistance(M4 to M4) Normal : About 50 Ω * Check contact Normal : ∞ Ω
Glow plug relay	CR-24	24V 200A	 Check contact Normal : 0.942 Ω (For terminal 1-GND)
Start key	CS-2	B-BR : 24V 1A B-ACC : 24V 10A B-ST : 24V 40A	* Check contact OFF : $\infty \Omega$ (for each terminal) ON : 0Ω (for terminal 1-3 and 1-2) START : 0Ω (for terminal 1-5)
Pressure sensor	○ A / SUPPLY ○ B / SIG ○ C / RETURN CD-6 CD-7 CD-24 CD-31 CD-32 CD-35 CD-42 CD-43 CD-44 CD-69 CD-70 CD-71	8~30V	* Check contact Normal : 0.1 Ω
Resistor	$ \begin{array}{c c} O & A \\ O & B \\ O & C \\ \end{array} $ CN-173	4W	 * Check resistance A-B : 120 Ω

Part name	Symbol	Specifications	Check
Glow plug	CN-80	24V 200A	 Check resistance 0.25~0.12 Ω
Temperature sensor (hydraulic)	CD-1	-	 * Check resistance 50°C : 804 Ω 80°C : 310 Ω 100°C : 180 Ω
Air cleaner pressure switch	Pa 	(N.O TYPE)	 * Check contact High level : ∞ Ω Low level : 0 Ω
Fuel sender	020 010 CD-2	-	** Check resistance Full: 50 Ω 6/12 : 350 Ω 11/12: 100 Ω 5/12 : 400 Ω 10/12: 150 Ω 4/12 : 450 Ω 9/12: 200 Ω 3/12 : 500 Ω 8/12: 250 Ω 2/12 : 550 Ω 7/12: 300 Ω 1/12 : 600 Ω Empty warning : 700 Ω
Relay (air con blower)	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	24V 20A	 Check resistance Normal : About 200 Ω (for terminal 1-3) 0 Ω (for terminal 2-4)
Relay	CR-2 CR-5 CR-36 CR-45 CR-62	24V 16A	 Check resistance Normal : About 160 Ω (for terminal 1-2) 0 Ω (for terminal 3-4) ∞ Ω (for terminal 3-5)

Part name	Symbol	Specifications	Check
Relay	0 30 87a 87 85 0 86 87a 87 85 0 85 930 86 0 87a 30 86 0 87a 30 86 0 87a 0 85 0 87a 0 85 0 87a 0 86 0 87a 0 87 0 87 0 87	24V 16A	 Check resistance Normal : About 160 Ω (for terminal 85-86) 0 Ω (for terminal 30-87a) ∞ Ω (for terminal 30-87)
Solenoid valve	I 1 CN-66 CN-68 CN-88 CN-140 CN-155 CN-236 CN-237	24V 1A	 Check resistance Normal : 15~25 Ω (for terminal 1-2)
EPPR valve	1 0 2 0 CN-75 CN-133 CN-154 CN-238 CN-239 CN-240 CN-241 CN-242	700mA	 Check resistance Normal : 15~25 Ω (for terminal 1-2)
Speaker	0 1 0 2 CN-23(LH) CN-24(RH)	20W	* Check resistance Normal : A few Ω
Switch (locking type)	(CS-23 CS-50 CS-52) (CS-67 CS-73 CS-82 CS-83 CS-99 CS-100	24V 8A	* Check contact Normal ON : 0 Ω (for terminal 3-7, 4-8) $\infty \Omega$ (for terminal 7-9, 8-10) OFF : $\infty \Omega$ (for terminal 3-7, 4-8) 0 Ω (for terminal 7-9, 8-10)
Accel dial	O A O + B O S O C O - CN-142	-	 * Check resist Normal : About 5k Ω (for terminal A-C) * Check voltage Normal : About 5V (for terminal A-C) : 2~4.5V (for terminal C-B)

Part name	Symbol	Specifications	Check
Room lamp	30 20 10 CL-1	24V 10W	* Check disconnection Normal : 1.0 Ω ON : 0 Ω (For terminal 1-2) $\infty \Omega$ (For terminal 1-3) OFF : $\infty \Omega$ (For terminal 1-2) 0Ω (For terminal 1-3)
Head lamp, Work lamp, Cab lamp	CL-3 CL-4 CL-5 CL-6 CL-8 CL-9 CL-10 CL-24 CL-36 CL-37	24V 65W (H3 Type)	* Check disconnection Normal : 1.2 Ω
Beacon lamp	CL-7	21V 70W (H1 Type)	* Check disconnection Normal : A few Ω
Fuel filler pump	$ \begin{array}{c} $	24V 10A 35 <i>i</i> /min	* Check resistance Normal : 1.0 Ω
Hour meter	3 h 2 h 1 CN-48	16~32V	 Check operation Supply power(24V) to terminal No.2 and connect terminal No.1 and ground
Horn	CN-20 CN-25	DC22~28V 2A	* Check operation Supply power(24V) to each terminal and connect ground.

Part name	Symbol	Specifications	Check
Safety switch	2 3 0 1 0 0 2 0 2 1 0 2 0 2 0 0 2 0 0 2 0 0 0 0 2 0 0 0 0	24V 15A (N.C TYPE)	* Check contact Normal : 0 Ω (for terminal 1-2) $\infty \Omega$ (for terminal 1-3) Operating : $\infty \Omega$ (for terminal 1-2) 0 Ω (for terminal 1-3)
Wiper cut switch	CS-53	24V (N.O TYPE)	* Check contact Normal : 0 ፬ (one pin to ground)
Receiver dryer	P 2 CN-29	24V 2.5A	* Check contact Normal : ∞ Ω
Radio & CD/MP3 player	CN-22	24V 2A	 * Check voltage 20~25V (for terminal 1-3, 3-8)
Washer pump	M 10 CN-22	24V 3.8A	* Check contact Normal : 10.7 Ω (for terminal 1-2)
Wiper motor	3 0 0 0 0 0 0 0 0 0 0 0 0 0	24V 2A	* Check disconnection Normal : 7 Ω (for terminal 2-6)

Part name	Symbol	Specifications	Check
DC/DC Converter	0 3 0 12V 12V 2 0 24V 0 1 0 GND 24V CN-138	12V 3A	24V (1-2) 12V (1-3)
Cigar lighter	CL-2	24V 5A 1.4W	 * Check coil resistance Normal : About 1M Ω * Check contact Normal : ∞ Ω Operating time : 5~15sec
Alternator	$ \begin{array}{c c} B+ & G \\ & 3 & + \\ & GND & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & &$	Delco Remy 24V 55A	 * Check contact Normal : 0 Ω (for terminal B⁺-I) Normal : 24~27.5V
Starter	M M B+ CN-45	Denso 24V 4.5kW	* Check contact Normal : 0.1 Ω
Travel alarm	CN-81	24V 0.5A	* Check contact Normal : 5.2 Ω
Aircon compressor	CN-28 =	24V 79W	* Check contact Normal : 13.4 Ω

Part name	Symbol	Specifications	Check
Start relay	CR-23	24V 300A	* Check contact Normal : 0.94 Ω (for terminal 1-2)
Blower motor		24V 9.5A	* Check resistance Normal : 2.5 Ω (for terminal 1-2)
Duct sensor (switch)		1°C OFF 4°C ON	* Check resistance Normal : 0 Ω (for terminal 1-2), the atmosphere temp : Over 4°C
Door switch	CS-1	24V 2W	* Check resistance Normal : About 5M Ω
Switch (power max, one touch decel, horn, breaker)	$ \begin{array}{c c} \hline & & & \\ \hline \\ CS-5 & CS-19 \\ CS-26 & CS-29 \end{array} $	24V 6A	ະ Check resistance Normal : ∞ Ω
Fusible link	CN-60 CN-95	60A	 Check disconnection Normal : 0 Ω (connect ring terminal and check resist between terminal 1 and 2)

Part name	Symbol	Specifications	Check
Master switch	CS-74	6-36V	* Check disconnection Normal : 0.1 Ω

GROUP 4 CONNECTORS

1. CONNECTOR DESTINATION

Connector	Туре	No. of	Destination	Connecto	r part No.
number	туре	pin	Destination	Female	Male
CN-1	AMP	10	I/conn (Frame harness-Pump PS harness)	S816-010002	S816-110002
CN-2	AMP	12	I/conn (Frame harness-Engine harness)	S816-012002	S816-112002
CN-3	AMP	15	I/conn (Frame harness-Engine harness)	2-85262-1	368301-1
CN-4	AMP	16	l/conn (Console harness LH-Frame harness)	S816-012002	S816-116002
CN-5	DEUTSCH	60	I/conn (Side harness RH-Frame harness)	DRB16-60SAE-L018	DRB12-60PAE-L018
CN-7	AMP	16	l/conn (Console harness RH-Frame harness)	368047-1	S816-116002
CN-8	AMP	12	l/conn (Console harness RH-Frame harness)	S816-012002	S816-112002
CN-10	DEUTSCH	12	I/conn (Cab harness-Side harness RH)	DT06-12S-EP06	DT04-12P-BE02
CN-11	DEUTSCH	8	I/conn (Frame harness-Aircon harness)	DT06-8S-EP06	-
CN-12	DEUTSCH	2	I/conn (Frame harness-Boom wire harness)	DT06-2S-EP06	DT04-2P-E004
CN-14	AMP	8	I/conn (Frame harness-Bucket EPPR)	S816-008002	S816-108002
CN-15	AMP	12	I/conn (Frame harness-Breaker solenoid)	S816-012002	S816-112002
CN-16	AMP	6	Emergency engine start & speed control	S816-006002	S816-106002
CN-17	DEUTSCH	8	I/conn (Wiper harness-Side harness RH)	DT06-8S-EP06	DT04-8P
CN-20	MOLEX	2	Horn	36825-0211	-
CN-21	AMP	6	Wiper motor	925276-0	-
CN-22	KET	2	Washer pump	MG640605	-
CN-23	KET	2	Speaker-LH	MG610070	-
CN-24	KET	2	Speaker-RH	MG610070	-
CN-25	MOLEX	2	Horn	36825-0211	-
CN-27	KUM	16	Radio & CD/MP3 player	PK145-16017	-
CN-28	KUM	1	Aircon compressor	NMWP01F-B	-
CN-29	KET	2	Receiver dryer	MG640795	-
CN-36	AMP	12	Fuse & relay box	S816-012002	-
CN-45	RING-TERM	-	Starter motor B ⁺	S820-308000	-
CN-48	AMP	1	Hour meter	2-520193-2	-
CN-51	DEUTSCH	40	MCU	DRC26-40SA	-
CN-52	DEUTSCH	40	MCU	DRC26-40SB	-
CN-53	DEUTSCH	40	MCU	DRC26-40SC	-
CN-56	DEUTSCH	6	Cluster	-	DT04-6P-E005
CN-60	YAZAKI	2	Fusible link	21N4-01320	7122-4125-50
CN-61	DEUTSCH	2	Fuel filler pump	DT06-2S-EP06	-
CN-66	DEUTSCH	2	Breaker solenoid	DT06-2S-EP06	-
CN-68	DEUTSCH	2	Safety solenoid	DT06-2S-EP06	-
CN-70	DEUTSCH	2	Travel high solenoid	DT06-2S-EP06	-


Connector	Tupo	No. of	Destination	Connecto	or part No.
number	Туре	pin	Destination	Female	Male
CN-74	RING-TERM	2	Alternator "I" terminal	S820-105000	-
CN-75	AMP	2	Pump EPPR	S816-002002	-
CN-80	RING-TERM	-	Glow plug	S820-306000	-
CN-81	DEUTSCH	2	Travel buzzer solenoid	DT06-2S-EP06	-
CN-88	DEUTSCH	2	Power max solenoid	DT06-2S-EP06	-
CN-93	DEUTSCH	50	ECM	DRC26-50S-04	-
CN-94	DEUTSCH	4	ECM earth	DTP06-4S-EP06	-
CN-95	KET	2	Fusible link	21N4-01311	S813-130201
CN-96	AMP	4	Fuel warmer	2-967325-3	-
CN-116	AMP	12	Switch panel	176116	-
CN-125	Econoseal J	4	GPS connector	S816-004002	S816-104002
CN-126	AMP	10	Service tool	S816-010002	S816-110002
CN-133	DEUTSCH	2	Boom priority solenoid	DT06-2S-EP06	-
CN-138	FASTEN	3	DC/DC Converter	S810-003202	-
CN-139	FASTEN	2	12V socket	172434-2	-
CN-140	DEUTSCH	2	Quick clamp solenoid	DT06-2S-EP06	DT04-2P-E005
CN-141	AMP	13	Wiper motor controller	172498-1	DT04-3P-EP10
CN-144	KET	20	Handsfree	MG610240	-
CN-147	AMP	4	Fuel-heater	2-967325-3	-
CN-149	DEUTSCH	2	Attach safety solenoid	DT06-2S-EP06	-
CN-154	DEUTSCH	2	Cooling fan	DT06-2S-EP06	
CN-155	AMP	2	Reverse solenoid	85202-1	
CN-156	DEUTSCH	2	Air seat	DT06-2S-EP06	DT04-2P-E005
CN-170	AMP	2	Heated seat	174352-2	174354-2
CN-173	DEUTSCH	3	Resistor	DT06-3S-EP06	DT04-3P-EP10
CN-236	DEUTSCH	2	Attach pressure solenoid	DT06-2S-EP06	-
CN-237	DEUTSCH	2	Attach conflux solenoid	DT06-2S-EP06	-
CN-242	DEUTSCH	2	Attach flow solenoid	DT06-2S-EP06	DT04-2P-E005
CN-244	MTA	2	CAN 2	-	01.00705
CN-245	AMP	12	Remocon	368542-1	-
CN-246	KET	12	USB & Socket assy	MG610240	-
CN-247	DEUTSCH	8	PWM convert	DT06-08SA-EP06	DT04-8P
CN-249	DEUTSCH	4	Rear view camera	DT06-4S-EP06	DT04-4P-E005
CN-255	AMP	2	PTC Power	S813-030201	-
CN-256	AMP	8	Proportional	-	S816-108002
CN-258	KET	1	Air compressor power	MG640944-5	MG650943-5
CN-259	DEUTSCH	2	Camera	DT06-2S-EP06	DT04-2P-E005


Connector	Tura	No. of	Destinction	Connecto	or part No.
number	Туре	pin	Destination	Female	Male
· Relay					
CR-1	RING-TERM	-	Battery relay	ST710285-2	-
CR-2	-	5	Horn relay	-	-
CR-4	-	5	Working lamp relay	-	-
CR-5	-	5	Anti restart relay	-	-
CR-7	-	5	Aircon compressor relay	-	-
CR-9	-	5	Head lamp relay	-	-
CR-13	-	5	Cabin lamp relay	-	-
CR-23	KET	2	Start relay	S814-002001	S814-102001
CR-24	RING TERM	1	Preheat relay	S822-014000	-
CR-35	-	5	Power relay	-	-
CR-36	-	5	Preheat relay	-	-
CR-45	-	5	ECM power relay	-	-
CR-46	-	5	Fuel warmer relay	-	-
CR-62	-	5	Breaker relay	-	-
· Switch					1
CS-1	SHUR	1	Door switch	S822-014002	S822-114002
CS-2	DEUTSCH	6	Start key switch	DT06-12S	-
CS-4	DEUTSCH	3	Safety switch	DT06-3S-EP06	-
CS-5	DEUTSCH	2	Horn switch	-	DT04-2P-E005
CS-19	DEUTSCH	2	One touch decel switch	-	DT04-2P-E005
CS-20	AMP	1	Safety switch	S822-014002	-
CS-23	SWF	12	Beacon lamp switch	SWF589790	-
CS-26	DEUTSCH	2	Breaker switch	DT06-2S-EP06	-
CS-26A	AMP	2	Breaker pedal switch	S816-002002	S816-102002
CS-27	SWF	10	Breaker switch	SWF 593757	-
CS-29	DEUTSCH	2	Power max switch	DT06-2S-EP06	-
CS-50	SWF	12	Overload switch	SWF589790	-
CS-52	SWF	10	Econo switch	SWF 593757	-
CS-53	AMP	1	Wiper cut switch	S822-014002	-
CS-67	SWF	12	Quick clamp switch	SWF 589790	-
CS-73	SWF	12	Reverse fan switch	SWF 589790	-
CS-74	AMP	2	Master switch	S813-030201	-
CS-82	SWF	12	Spare switch	SWF 589790	-
CS-83	SWF	12	Spare switch	SWF 589790	-
CS-99	SWF	12	Spare switch	SWF 589790	-
CS-100	SWF	12	Spare switch	SWF 589790	-
CS-142	DEUTSCH	3	Accel dial switch	DT06-3S-EP06	-

Connector number Typ	Tupo	be No. of pin	Destination	Connector part No.		
	туре		Destination	Female	Male	
· Light	· Light					
CL-1	KET	3	Room lamp	MG651032	-	
CL-2	AMP	1	Cigar light	S822-014002	S822-114002	
CL-3	DEUTSCH	2	Head lamp-LH	DT06-2S-EP06	-	
CL-4	DEUTSCH	2	Head lamp-RH	DT06-2S-EP06	DT04-2P-E005	
CL-5	DEUTSCH	2	Work lamp-LH	DT06-2S-EP06	DT04-2P	
CL-6	DEUTSCH	2	Work lamp-RH	DT06-2S-EP06	DT04-2P	
CL-7	SHUR	1	Beacon lamp	S822-014002	S822-114002	
CL-8	DEUTSCH	2	Cab lamp-LH	DT06-2S-EP06	DT04-2P	
CL-9	DEUTSCH	2	Cab lamp-RH	DT06-2S-EP06	DT04-2P	
CL-10	DEUTSCH	2	Cab lamp-RH	DT06-2S-EP06	DT04-2P	
CL-24	DEUTSCH	2	Rear work lamp	DT06-2S-EP06	DT04-2P-E005	
CL-36	DEUTSCH	2	Work lamp-LH	DT06-2S-EP06	DT04-2P	
CL-37	DEUTSCH	2	Work lamp-RH	DT06-2S-EP06	DT04-2P	
\cdot Sensor, se	ndor			·		
CD-1	AMP	2	Hydraulic oil temp sender	85202-1	-	
CD-2	DEUTSCH	2	Fuel sender	DT06-2S-EP06	-	
CD-6	DEUTSCH	3	Travel pressure switch	DT06-3S-EP06	-	
CD-7	DEUTSCH	3	Working pressure switch	DT06-3S-EP06	-	
CD-10	RING TERM	-	Air cleaner switch	ST730135-2	S820-104002	
CD-24	DEUTSCH	3	Swing sensor	DT06-3S-EP06	-	
CD-31	DEUTSCH	3	Overload sensor	DT06-3S-EP06	DT04-3P-E005	
CD-32	DEUTSCH	3	Boom up sensor	DT06-3S-EP06	-	
CD-35	DEUTSCH	3	Arm & bucket in sensor	DT06-3S-EP06	-	
CD-42	DEUTSCH	3	Pump pressure 1	DT06-3S-EP06	-	
CD-43	DEUTSCH	3	Pump pressure 2	DT06-3S-EP06	-	
CD-44	DEUTSCH	3	Pump pressure 3	DT06-3S-EP06	-	
CD-45	DEUTSCH	2	WIF sensor	DT06-2S-EP06	-	
CD-69	DEUTSCH	3	Attach pressure sensor	DT06-3S-EP06	-	
CD-70	DEUTSCH	3	N1 pressure sensor	DT06-3S-EP06	-	
CD-71	DEUTSCH	3	N2 pressure sensor	DT06-3S-EP06	-	


2. CONNECTION TABLE FOR CONNECTORS

1) PA TYPE CONNECTOR







2) J TYPE CONNECTOR





3) SWP TYPE CONNECTOR






4) CN TYPE CONNECTOR






5) 375 FASTEN TYPE CONNECTOR




6) AMP ECONOSEAL CONNECTOR




7) AMP TIMER CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	1 1 1 1 1 2 85202-1	


8) AMP 040 MULTILOCK CONNECTOR



9) AMP 070 MULTILOCK CONNECTOR



10) AMP FASTIN - FASTON CONNECTOR



11) KET 090 CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2		
	MG610070	


12) KET 090 WP CONNECTORS

No. of pin	Receptacle connector (female)	Plug connector (male)
2	1 2 MG640605	
2	1 () () () () () () () () () (

13) KET SDL CONNECTOR


No. of pin	Receptacle connector (female)	Plug connector (male)
14	1 7 14 6 MG610406	


14) DEUTSCH DT CONNECTORS



- * Modification
 - E003 : Standard end cap gray
 - E004 : Color of connector to be black
 - E005 : Combination E004 & E003
 - EP04 : End cap
 - EP06 : Combination P012 & EP04

P012 : Front seal enhancement - connectors color to black for 2, 3, 4 & 6pin






15) MOLEX 2CKTS CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2		
	35215-0200	


16) ITT SWF CONNECTOR





17) MWP NMWP CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
1	1	
	NMWP01F-B	


18) ECONOSEAL J TYPE CONNECTORS








19) METRI-PACK TYPE CONNECTOR




20) DEUTSCH HD30 CONNECTOR



21) DEUTSCH MCU CONNECTOR

No. of pin	Receptacle connector (Female)	Plug connector (Male)
40	$\begin{array}{c} 1 \\ 1 \\ 2 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3 \\ 3$	
	DRC26-40SA/B/C	


22) DEUTSCH SERVICE TOOL CONNECTOR




23) AMP FUEL WARMER CONNECTOR

No. of pin	Receptacle connector (Female)	Plug connector (Male)
4		
	2-967325-3	

24) DEUTSCH ENGINE ECM CONNECTOR



25) DEUTSCH INTERMEDIATE CONNECTOR




SECTION 5 MECHATRONICS SYSTEM

Group	1	Outline	5-1
Group	2	Mode Selection System	5-3
Group	3	Automatic Deceleration System	5-6
Group	4	Power Boost System ·····	5-7
Group	5	Travel Speed Control System	5-8
Group	6	Automatic Warming Up System	5-9
Group	7	Engine Overheat Prevention System	5-10
Group	8	Variable Power Control System	5-11
Group	9	Attachment Flow Control System	5-12
Group	10	Anti-Restart System	5-13
Group	11	Self-Diagnostic System ·····	5-14
Group	12	Engine Control System ·····	5-27
Group	13	EPPR Valve	5-28
Group	14	Monitoring System ·····	5-33
Group	15	Fuel Warmer System	5-56


GROUP 1 OUTLINE

The ADVANCED CAPO (Computer Aided Power Optimization) system controls engine and pump mutual power at an optimum and less fuel consuming state for the selected work by mode selection, auto-deceleration, power boost function, etc. It monitors machine conditions, for instance, engine speed, coolant temperature, hydraulic oil temperature, and hydraulic oil pressure, etc.

It consists of a MCU, a cluster, an ECM, EPPR valves, and other components. The MCU and the cluster protect themselves from over-current and high voltage input, and diagnose malfunctions caused by short or open circuit in electric system, and display error codes on the cluster.




SYSTEM DIAGRAM



GROUP 2 MODE SELECTION SYSTEM

1. POWER MODE SELECTION SYSTEM



21095MS02

Mode selection system (micro computer based electro-hydraulic pump and engine mutual control system) optimizes the engine and pump performance.


The combination of 3 power modes (P, S, E) and accel dial position (10 set) makes it possible to use the engine and pump power more effectively corresponding to the work conditions from a heavy and great power requesting work to a light and precise work.

		Engine rpm			Power shift by EPPR valve				
Power	Application	Standard		Opt	tion	Standard		Option	
mode		Unload	Load	Unload	Load	Current (mA)	Pressure (kgf/cm ²)	Current (mA)	Pressure (kgf/cm ²)
Р	Heavy duty power	1700±50	1650±50	1800±50	1750 ± 50	230±30	4	160±30	0
S	Standard power	1600 ± 50	1550±50	1700±50	$1650\!\pm\!50$	270±30	6±3	230 ± 30	4±3
E	Economy operation	1500 ± 50	1550±50	1600 ± 50	$1650\!\pm\!50$	340±30	11±3	330 ± 30	9±3
AUTO DECEL	Engine deceleration	1000±100	-	1000±100	-	700±30	38±3	700±30	38±3
One touch decel	Engine quick deceleration	800±100	-	800±100	-	700±30	38±3	700±30	38±3
KEY START	Key switch start position	800±100	-	800±100	-	700±30	38±3	700±30	38±3

* Power shift (Standard/Option) can be changed by "Service menu" in "Management" on the cluster.

2. WORK MODE SELECTION SYSTEM

Work mode consists of the general operation (bucket) and the optional attachment (breaker, crusher).



21095MS03

1) GENERAL WORK MODE (bucket)


This mode is used to general digging work.

2) ATT WORK MODE (breaker, crusher)

It controls the pump flow and system pressure according to the operation of breaker or crusher.

Deservition	General mode	Work	< tool
Description	Bucket	Breaker	Crusher
Attachment safety solenoid	OFF	ON	ON
Attachment pressure solenoid	OFF	OFF	ON
Attachment conflux solenoid	OFF	OFF	ON/OFF
Attachment flow EPPR current	100 mA	100~700 mA	0~700 mA

3. USER MODE SELECTION SYSTEM




21095MS03A

1) High idle rpm, auto idle rpm and EPPR pressure can be adjusted and memorized in the U-mode.

2) LCD segment vs	parameter setting
-------------------	-------------------

Step (∎)	Engine speed (rpm)	Idle speed (rpm)	Power shift (bar)
1	1350	700	0
2	1400	750	3
3	1450	800 (low idle)	6
4	1500	850	9
5	1550	900	12
6	1600	950	16
7	1650	1000 (decel rpm)	20
8	1700	1050	26
9	1750	1100	32
10	1800	1150	38


GROUP 3 AUTOMATIC DECELERATION SYSTEM



1. WHEN AUTO IDLE PILOT LAMP ON

When all of the work equipment control levers including swing and travel levers are at neutral for 4 seconds, MCU sends throttle command to ECM to reduce the engine speed to 1000 rpm. If the control levers are at neutral for 1 minute, MCU reduces the engine speed to 800 rpm. As the result of reducing the engine speed, fuel consumption and noise are effectively cut down during non-operation of the control levers.

When the Auto idle pilot lamp is turned off by pressing the switch or any control lever is operated, the reduced engine speed rises upto the speed before deceleration in a second.




2. WHEN AUTO IDLE PILOT LAMP OFF

The engine speed can be set as desired using the accel dial switch, and even if the control levers are neutral, the engine speed is not reduced.

* Auto idle function can be activated when accel dial position is over 4.

GROUP 4 POWER BOOST SYSTEM




- When the power boost switch on the left control lever knob is pushed ON, the power mode is set P mode and maximum digging power is increased by 10 %.
- When the power boost function is activated, the power boost solenoid valve pilot pressure raises the set pressure of the main relief valve to increase the digging power.

Description Condition		Function
Activated	Power boost switch : ON Accel dial : over 8	 Power mode : P Accel dial power : 9 Power boost solenoid : ON Power boost pilot lamp : ON Operating time : max 8 seconds
Canceled	Power boost switch : OFF	 Pre-set power mode Power boost solenoid : OFF Power boost pilot lamp : OFF

When the auto power boost is set to Enable and power mode is set to P mode on the cluster, the digging power is automatically increased as working conditions by the MCU. It is operated max 8 seconds.

GROUP 5 TRAVEL SPEED CONTROL SYSTEM




21095MS07

Travel speed can be switched manually by pressing the travel speed switch on the cluster.

Speed	Travel speed solenoid valve	Lamp on cluster	Operation
Low	OFF	Turtle	Low speed, high driving torque in the travel motor
High	ON	Rabbit	High speed, low driving torque in the travel motor

* Default : Turtle (Low)

GROUP 6 AUTOMATIC WARMING UP SYSTEM




21095MS08

- The MCU receives the engine coolant temperature from the ECM, and if the coolant temperature is below 30°C, it increases the engine speed from key start rpm to 1200rpm. At this time the mode does not change. If the coolant temperature sensor has fault, the hydraulic oil temperature signal is substituted.
- In case of the coolant temperature increases up to 30°C, the engine speed is decreased to key start speed. And if an operator changes power mode set during the warming up function, the MCU cancels the automatic warming up function.

Description	Condition	Function
- Coolant temperature : Actuated below 30°C (after engine run)		 Power mode : Default (E mode) Warming up time : 10 minutes (max) Warming up pilot lamp : ON
Canceled	 Coolant temperature : Above 30°C Warming up time : Above 10 minutes Changed power mode set by operator RCV lever or pedal operating Auto idle cancel ※ If any of the above conditions is applicable, the automatic warming up function is canceled 	- Power mode : set mode - Warming up pilot lamp : OFF

3.	LOGIC	TABLE
Ο.	LOGIO	

GROUP 7 ENGINE OVERHEAT PREVENTION SYSTEM




21095MS09

1. The engine coolant temperature or the hydraulic oil temperature is overheated over 100°C, the warning lamp is ON and the pump input torque or the engine speed is reduced as below logic table.

Description		Condition	Function
First step	Activated	 Coolant temperature : Above 103°C Hydraulic oil temperature : Above 100°C 	 Warning lamp : ON , buzzer : OFF Pump input torque is reduced. Warning lamp & buzzer : ON Pump input torque is reduced.
warning	Canceled	 Coolant temperature : Less than 100°C Hydraulic oil temperature : Less than 95°C 	- Return to pre-set the pump absorption torque.
Second step warning	Activated	- Coolant or hydraulic oil temperature : Above 105°C	Emergency warning lamp pops up on the center of LCD and the buzzer sounds.Engine speed is reduced after 10 seconds.
	Canceled	 Coolant temperature : Less than 103°C Hydraulic oil temperature : Less than 100°C 	 Return to pre-set the engine speed. Hold pump absorption torque on the first step warning.

GROUP 8 VARIABLE POWER CONTROL SYSTEM



21095MS10


• The variable power control system controls the engine and pump mutual power according to RCV lever stroke and pump load.

It makes fuel saving and smooth control at precise work.

Description	Working condition
Power mode	E
Work mode	General (bucket)
Pressure sensor	Normal

* The variable power control function can be activated when the power mode is set to E mode.

GROUP 9 ATTACHMENT FLOW CONTROL SYSTEM




21095MS11

• The system is used to control the pump delivery flow according to set of the work tool on the cluster by the attachment flow EPPR valve.

Description	Work tool		
Description	Breaker	Crusher	
Flow level	Max 7 step, reduced 10 lpm each step	Max 4 step, reduced 20 lpm each step	
Attach safety solenoid	ON	ON	
Attach pressure solenoid	OFF	ON	
Attach conflux solenoid	OFF	ON/OFF	

* Refer to the page 5-45 for the attachment kinds and max flow.

GROUP 10 ANTI-RESTART SYSTEM



21095MS12

1. ANTI-RESTART FUNCTION

After a few seconds from the engine starts to run, MCU turns off the start safety relay to protect the starter from inadvertent restarting.

2. When a replacement or taking-off of the MCU is needed, connect CN-16 and CN-16B to ensure the engine start without the MCU.

GROUP 11 SELF-DIAGNOSTIC SYSTEM

1. OUTLINE

When any abnormality occurs in the ADVANCED CAPO system caused by electric parts malfunction and by open or short circuit, the MCU diagnoses the problem and sends the error codes to the cluster and also stores them in the memory.

2. MONITORING

1) Active fault

🛆 👌 - 🖏 📰 🗁 Monitoring 🕔	9 & O -O		9 9 0 ÷0.			Monitoring
M Active Fault		M Active Fault		M	Active Fault	MC
Delete Logged Fault	*	Logged Fault			HCESPN : 101	FMI: 3
Monitoring(Analog)	P				HCESPN : 101	FMI:4
Monitoring(Digital)		2			HCESPN : 105	FMI:0
Operating Hours	•	Monitoring(Ana Engine ECM	►		HCESPN : 105 HCESPN : 105	FMI : 1 FMI : 2
		Monitoring(Digit	▶			
	: 🗟 🖙 🚗	Operating Hours	-		Hydraulic Oil Tempera	ature Sensor Circuit nal, or Shorted to High Source (or Open Circuit)
	21093CD66			\$	- voltage Above Norm	iai, or shorted to High Source (or Open Circuit)
		E 🖕 🕅 🗑 👯 🖉 🖉	## 🖓 👁 🜧 👘	Е	6	Contact: 0522028806
			21093CD66A			21093C

· The active faults of the MCU or engine ECM can be checked by this menu.

2) Logged fault

🛆 👌 - 🖏 📾 Monitoring 🛞 🌻 🖨 🕕 - 🏷	🛆 😓 👶 🚟 🖬 Monitoring 🕕	9 🕀 🛈 😳	🛆 🖨 🖧 📰 🖃 Monitoring 🕕	0 🕀 🕕
M Active Fault Logged Fault > Device Logged Fault > Monitory(Andyg) > Monitory(Digital) > Contract Notes > E 21093CD66C	Active Fault Logged Fa Delete Logged MOU Montoring(And Engine ECM Montoring(Digit Cperating Hours		Logged Fault HCSBPN: 127 FMI: 0 HCSBPN: 127 FMI: 2 HCSBPN: 128 FMI: 2 HCSBPN: 129 FMI: 2 HCSBPN: 120 FCONTRAL Range (or Open Chruit)	MCU
	E 👂 🦅 🗟 👯 🖉 🛲	21093CD66D	E 🎉 Contact: 0522028806	21093CD66

• The logged faults of the MCU or engine ECM can be checked by this menu.

3) Delete fault



• The logged faults of the MCU or engine ECM can be deleted by this menu.

3. MACHINE ERROR CODES TABLE

Error co HCESPN	FMI	Description
	3	Hydraulic oil temperature sensor circuit - Voltage above normal, or shorted to high source.
101	4	Hydraulic oil temperature circuit - Voltage below normal, or shorted to low source.
	0	Working pressure sensor data above normal range.
105	1	Working pressure sensor data below normal range.
105	2	Working pressure sensor data error.
	4	Working pressure sensor circuit - Voltage below normal, or shorted to Low source.
	0	Travel oil pressure sensor data above normal range.
100	1	Travel oil pressure sensor data below normal range.
108	2	Travel oil pressure sensor data error.
	4	Travel oil pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Main pump 1 (P1) pressure sensor data above normal range.
	1	Main pump 1 (P1) pressure sensor data below normal range.
120	2	Main pump 1 (P1) pressure sensor data error.
	4	Main pump 1 (P1) pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Main pump 2 (P2) pressure sensor data above normal range.
	1	Main pump 2 (P2) pressure sensor data below normal range.
121	2	Main pump 2 (P2) pressure sensor data error.
	4	Main pump 2 (P2) pressure sensor circuit - Voltage below normal, or shorted to lov source.
	0	Overhead pressure sensor data above normal range.
100	1	Overhead pressure sensor data below normal range.
122	2	Overhead pressure sensor data error.
	4	Overhead pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Negative 1 pressure sensor data above normal range.
123	1	Negative 1 pressure sensor data below normal range.
120	2	Negative 1 pressure sensor data error.
	4	Negative 1 pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Negative 2 Pressure sensor data above normal range.
124	1	Negative 2 Pressure sensor data below normal range.
124	2	Negative 2 Pressure sensor data error.
	4	Negative 2 Pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Pilot pump (P3) pressure sensor data above normal range.
125	1	Pilot pump (P3) pressure sensor data below normal range.
120	2	Pilot pump (P3) pressure sensor data error.
	4	Pilot pump (P3) pressure sensor circuit - Voltage below normal, or shorted to low source.
127	0	Boom up pilot pressure sensor data above normal range.
	1	Boom up pilot pressure sensor data below normal range.
	2	Boom up pilot pressure sensor data error.
	4	Boom up pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Arm in/out & bucket in pilot pressure sensor data above normal range.
105	1	Arm in/out & bucket in pilot pressure sensor data below normal range.
133	2	Arm in/out & bucket in pilot pressure sensor data error.
	4	Arm in/out & bucket in pilot pressure sensor circuit - Voltage below normal, or shorted to low source.

Error co HCESPN	FMI	Description
	0	Swing pilot pressure sensor data above normal range.
	1	Swing pilot pressure sensor data below normal range.
135	2	Swing pilot pressure sensor data error.
	4	Swing pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Attachment pilot pressure sensor data above normal range.
	1	Attachment pilot pressure sensor data below normal range.
138	2	Attachment pilot pressure sensor data error.
	4	Attachment pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
	5	Pump EPPR valve circuit - Current below normal, or open circuit.
140	6	Pump EPPR valve circuit - Current above normal.
	5	Boom priority EPPR valve circuit - Current below normal, or open circuit.
141	6	Boom priority EPPR valve circuit - Current above normal.
	5	Travel EPPR valve circuit - Current below normal, or open circuit.
143	6	Travel EPPR valve circuit - Current above normal.
	5	Attachment flow EPPR valve circuit - Current below normal, or open circuit.
144	6	Attachment flow EPPR valve circuit - Current above normal.
	5	Remote cooling fan EPPR valve circuit - Current below normal, or open circuit.
145	6	Remote cooling fan EPPR valve circuit - Current above normal.
	5	Left rotate EPPR valve circuit - Current below normal, or open circuit.
150	6	Left rotate EPPR valve circuit - Current above normal.
	5	
151		Right rotate EPPR valve circuit - Current below normal, or open circuit.
	6 5	Right rotate EPPR valve circuit - Current above normal.
152		Left tilt EPPR valve circuit - Current below normal, or open circuit.
	6	Left tilt EPPR valve circuit - Current above normal.
153	5	Right tilt EPPR valve circuit - Current below normal, or open circuit.
	6	Right tilt EPPR valve circuit - Current above normal.
166	5	Power max solenoid circuit - Current below normal, or open circuit.
	6	Power max solenoid circuit - Current above normal.
167	5	Travel speed solenoid circuit - Current below normal, or open circuit.
	6	Travel speed solenoid circuit - Current above normal.
168	5	Attachment pressure solenoid circuit - Current below normal, or open circuit.
	6	Attachment pressure solenoid circuit - Current above normal.
169	5	Attachment conflux solenoid circuit - Current below normal, or open circuit.
	6	Attachment conflux solenoid circuit - Current above normal.
170	5	Arm regeneration solenoid circuit - Current below normal, or open circuit.
	6	Arm regeneration solenoid circuit - Current above normal.
171	5	Attachment safety solenoid circuit - Current below normal, or open circuit.
	6	Attachment safety solenoid circuit - Current above normal.
181	5	Remote cooling fan reverse solenoid circuit - Current below normal, or open circuit.
	6	Remote cooling fan reverse solenoid circuit - Current above normal.
301	5	Fuel level sensor circuit - Voltage above normal, or shorted to high source.
	6	Fuel level sensor circuit - Voltage below normal, or shorted to low source.
	3	Engine coolant temperature sensor circuit - Voltage above normal, or shorted to hig
304		source.
	4	Engine coolant temperature sensor circuit - Voltage below normal, or shorted to low
010		source.
310	8	Engine speed signal error - Abnormal frequency or pulse width.
322	3	Engine preheat relay circuit - Voltage above normal, or shorted to high source.
	4	Engine preheat relay circuit - Voltage below normal, or shorted to low source.
325 -	3	Fuel warmer relay circuit - Voltage above normal, or shorted to high source.
	4	Fuel warmer relay circuit - Voltage below normal, or shorted to low source.

Error co HCESPN	FMI	Description
	3	Potentiometer (G/A) circuit - Voltage above normal, or shorted to high source.
340	4	Potentiometer (G/A) circuit - Voltage below normal, or shorted to low source.
341 -	5	Governor actuator circuit - Current below normal, or open circuit.
	6	Governor actuator circuit - Current above normal.
	0	Transmission oil pressure sensor data above normal range.
501	1	Transmission oil pressure sensor data below normal range.
501	2	Transmission oil pressure sensor data error.
	4	Transmission oil pressure sensor circuit - Voltage below normal, or shorted to low source
	0	Brake pressure sensor data above normal range.
500	1	Brake pressure sensor data below normal range.
503	2	Brake pressure sensor data error.
	4	Brake pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Working brake pressure sensor data above normal range.
505	1	Working brake pressure sensor data below normal range.
505	2	Working brake pressure sensor data error.
	4	Working brake pressure sensor circuit - Voltage below normal, or shorted to low source.
500	3	Working brake lamp circuit - Voltage above normal, or shorted to high source.
506	4	Working brake lamp circuit - Voltage below normal, or shorted to low source.
500	3	Ram lock lamp circuit - Voltage above normal, or shorted to high source.
520	4	Ram lock lamp circuit - Voltage below normal, or shorted to low source.
505	5	Ram lock solenoid circuit - Current below normal, or open circuit.
525	6	Ram lock solenoid circuit - Current above normal.
	0	Travel F pilot pressure sensor data above normal range.
500	1	Travel F pilot pressure sensor data below normal range.
530	2	Travel F pilot pressure sensor data error.
	4	Travel F pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
	0	Travel R pilot pressure sensor data above normal range.
501	1	Travel R pilot pressure sensor data below normal range.
531	2	Travel R pilot pressure sensor data error.
	4	Travel R pilot pressure sensor circuit - Voltage below normal, or shorted to low source.
704	3	Hourmeter circuit - Voltage above normal, or shorted to high source.
701	4	Hourmeter circuit - Voltage below normal, or shorted to low source.
705	0	MCU input voltage high.
705	1	MCU input voltage low.
707	1	Alternator node I voltage low.
744	3	Acc. dial circuit - Voltage above normal, or shorted to high source.
714	4	Acc. dial circuit - Voltage below normal, or shorted to low source.
74 5	3	Rotate signal input circuit - Voltage above normal, or shorted to high source.
715	4	Rotate signal input circuit - Voltage below normal, or shorted to low source.
710	3	Tilt signal input circuit - Voltage above normal, or shorted to high source.
716	4	Tilt signal input circuit - Voltage below normal, or shorted to low source.
700	3	Travel alarm (buzzer) circuit - Voltage above normal, or shorted to high source.
722	4	Travel alarm (buzzer) circuit - Voltage below normal, or shorted to low source.
830	12	MCU internal memory error.
840	2	Cluster communication data error.
841	2	ECM communication data error.
843	2	Option #1 (CAN 2) communication data error.
850	2	RCM communication data error.

4. ENGINE FAULT CODE

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
111 629 12	Engine control module critical internal failure - Bad intelligent device or component. Error internal to the ECM related to memory hardware failures or internal ECM voltage supply circuits.	engine dying, or hard starting.
115 612 2	Engine magnetic crankshaft speed/position lost both of two signals - Data erratic, intermittent, or incorrect. The ECM has detected that the primary engine speed sensor and the backup engine speed sensor signals are reversed.	
122 102 3	Intake manifold 1 pressure sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the intake manifold pressure circuit.	
123 102 4	Intake manifold 1 pressure sensor circuit - Voltage below normal, or shorted to low Source. Low signal voltage or open circuit detected at the intake manifold pressure circuit.	
124 102 16	Intake manifold 1 pressure - Data valid but above normal operational range - Moderately severe level. Intake manifold pressure has exceeded the maximum limit for the given engine rating.	Engine power derate.
131 91 3	Accelerator pedal or lever position sensor 1 circuit - Voltage above normal, or shorted to high source. High voltage detected at accelerator pedal position circuit.	Limp home power only.
132 91 4	Accelerator pedal or lever position sensor 1 circuit - Voltage below normal, or shorted to low source. Low voltage detected at accelerator pedal position signal circuit.	Limp home power only.
133 974 3	Remote accelerator pedal or lever position sensor 1 circuit - Voltage above normal, or shorted to high source. High voltage detected at remote accelerator pedal position circuit.	accelerator position will be set to zero percent.
134 974 4	Remote accelerator pedal or lever position sensor 1 circuit - Voltage below normal, or shorted to low source. Low voltage detected at remote accelerator pedal position signal circuit.	accelerator position will be set to zero percent.
135 100 3	Engine oil rifle pressure 1 sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the engine oil pressure circuit.	
141 100 4	Engine oil rifle pressure 1 sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at engine oil pressure circuit.	
143 100 18	Engine oil rifle pressure - Data valid but below normal operational range - Moderately severe level.	
144 110 3	Engine coolant temperature 1 sensor circuit - Voltage above normal, or shorted to high source. High signal voltage or open circuit detected at engine coolant temperature circuit.	controlled by ECM. No engine protection for

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
145 110 4	Engine Coolant Temperature 1 Sensor Circuit - Voltage Below Normal, or Shorted to Low Source. Low signal voltage detected at engine coolant temperature circuit.	controlled by ECM. No engine protection for
146 110 16	Engine Coolant Temperature - Data Valid but Above Normal Operational Range - Moderately Severe Level. Engine coolant temperature signal indicates engine coolant temperature is above engine protection warning limit.	from time of alert.
147 91 1	Accelerator Pedal or Lever Position 1 Sensor Circuit Frequency - Data Valid but Below Normal Operational Range - Most Severe Level. A frequency of less than 100 Hz has been detected at the frequency throttle input to the ECM.	
148 91 0	Accelerator Pedal or Lever Position Sensor 1 - Data Valid but Above Normal Operational Range - Most Severe Level. A frequency of more than 1500 Hz has been detected at the frequency throttle input to the ECM.	
151 110 0	Engine Coolant Temperature - Data Valid but Above Normal Operational Range - Most Severe Level. Engine coolant temperature signal indicates engine coolant temperature above engine protection critical limit.	from time of alert. If Engine Protection Shutdown feature is enabled, engine will shut
153 105 3	Intake Manifold 1 Temperature Sensor Circuit - Voltage Above Normal, or Shorted to High Source. High signal voltage detected at intake manifold air temperature circuit.	
154 105 4	Intake Manifold 1 Temperature Sensor Circuit - Voltage Below Normal, or Shorted to Low Source. Low signal voltage detected at intake manifold air temperature circuit.	controlled by ECM. No engine protection for
155 105 0	Intake Manifold 1 Temperature - Data Valid but Above Normal Operational Range - Most Severe Level. Intake manifold air temperature signal indicates intake manifold air temperature above engine protection critical limit.	from time of alert. If Engine Protection Shutdown feature is enabled, engine will shut
187 520195 4	Sensor Supply 2 Circuit - Voltage Below Normal, or Shorted to Low Source. Low voltage detected at the sensor supply number 2 circuit.	Engine power derate.
195 111 3	Coolant Level Sensor 1 Circuit - Voltage Above Normal, or Shorted to High Source. High signal voltage detected at engine coolant level circuit.	
196 111 4	Coolant Level Sensor 1 Circuit - Voltage Below Normal, or Shorted to Low Source. Low signal voltage detected at engine coolant level circuit.	None on performance.
197 111 18	Coolant Level - Data Valid but Below Normal Operational Range - Moderately Severe Level. Low coolant level has been detected.	None on performance.
221 108 3	Barometric Pressure Sensor Circuit - Voltage Above Normal, or Shorted to High Source. High signal voltage detected at barometric pressure circuit.	Engine power derate.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
222 108 4	Barometric Pressure Sensor Circuit - Voltage Below Normal, or Shorted to Low Source. Low signal voltage detected at barometric pressure circuit.	Engine power derate.
227 520195 3	Sensor Supply 2 Circuit - Voltage Above Normal, or Shorted to High Source. High voltage detected at sensor supply number 2 circuit.	Engine power derate.
234 190 0	Engine Crankshaft Speed/Position - Data Valid but Above Normal Operational Range - Most Severe Level. Engine speed signal indicates engine speed above engine protection limit.	below the overspeed limit.
235 111 1	Coolant Level - Data Valid but Below Normal Operational Range - Most Severe Level. Low engine coolant level detected.	
237 644 2	External Speed Command Input (Multiple Unit Synchronization) - Data Erratic, Intermittent, or Incorrect. Communication between multiple engines may be intermittent.	
238 520196 4	Sensor Supply 3 Circuit - Voltage Below Normal, or Shorted to Low Source. Low voltage detected on the +5 volt sensor supply circuit to the engine speed sensor.	Possible hard starting and rough running.
241 84 2	Wheel-based vehicle speed - Data erratic, intermittent, or incorrect. The ECM lost the vehicle speed signal.	
242 84 10	Wheel-based vehicle speed sensor circuit tampering has been detected - Abnormal rate of change. Signal indicates an intermittent connection or VSS tampering.	speed without VSS parameter value. Cruise
245 647 4	Fan control circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the fan control circuit when commanded on.	all.
268 94 2	Injector metering rail 1 pressure - data erratic, intermittent, or incorrect. The ECM has detected that the fuel pressure signal is not changing.	
271 1347 4	Fuel pump pressurizing assembly 1 circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the fuel pump actuator circuit.	
272 1347 3	Fuel pump pressurizing assembly 1 circuit - Voltage above normal, or shorted to high source. High signal voltage or open circuit detected at the fuel pump actuator circuit.	Engine will not run or engine will run poorly.
275 1347 7	Fuel pumping element number 1 (front) - Mechanical system not responding properly or out of adjustment.	Engine will not run or possible low power.
281 1347 7	Fuel pump pressurizing assembly 1 - Mechanical system not responding properly or out of adjustment.	
285 639 9	SAE J1939 multiplexing PGN timeout error - Abnormal update rate. The ECM expected information from a multiplexed device but did not receive it soon enough or did not receive it at all.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
286 639 13	SAE J1939 multiplexing configuration error - Out of calibration. The ECM expected information from a multiplexed device but only received a portion of the necessary information.	properly.
287 91 19	SAE J1939 multiplexed accelerator pedal or lever sensor system - received network data In error. The OEM vehicle electronic control unit (VECM) detected a fault with its accelerator pedal.	
288 974 19	SAE J1939 Multiplexing Remote Accelerator Pedal or Lever Position Sensor Circuit - Received Network Data In Error. The OEM vehicle electronic control unit (VECU) detected a fault with the remote accelerator.	throttle. Engine may only idle. The primary or cab accelerator may be able to be used.
292 441 14	Auxiliary temperature Sensor Input 1 - Special instructions.	Possible engine power derate.
293 441 3	Auxiliary temperature sensor input 1 circuit - Voltage above normal, or shorted to high source. High signal voltage or open circuit detected at the OEM auxiliary temperature circuit.	
294 441 4	Auxiliary temperature sensor input 1 circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the OEM auxiliary temperature circuit.	
296 1388 14	Auxiliary pressure sensor input 1 - Special instructions.	Possible engine power derate.
297 1388 3	Auxiliary pressure sensor input 1 circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the OEM pressure circuit.	
298 1388 4	Auxiliary pressure sensor input 1 circuit - Voltage below normal, or shorted to low source. Low signal voltage or open circuit detected at the OEM pressure circuit.	
319 251 2	Real time clock power interrupt - Data erratic, intermittent, or incorrect. Real time clock lost power.	
322 651 5	Injector solenoid driver cylinder 1 circuit - Current below normal, or open circuit. High resistance detected on injector number 1 circuit or no current detected at number 1 injector driver or return pin when the voltage supply at the harness is on.	
323 655 5	Injector solenoid driver cylinder 5 circuit - Current below normal, or open circuit. High resistance detected on injector number 5 circuit or no current detected at number 5 injector driver or return pin when the voltage supply at the harness is on.	
324 653 5	Injector solenoid driver cylinder 3 circuit - Current below normal, or open circuit. High resistance detected on injector number 3 circuit or no current detected at number 3 injector driver or return pin when the voltage supply at the harness is on.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
325 656 5	Injector solenoid driver cylinder 6 circuit - Current below normal, or open circuit. High resistance detected on injector number 6 circuit or no current detected at number 6 injector driver or return pin when the voltage supply at the harness is on.	
331 652 5	Injector solenoid driver cylinder 2 circuit - Current below normal, or open circuit. High resistance detected on injector number 2 circuit or no current detected at number 2 injector driver or return pin when the voltage supply at the harness is on.	
332 654 5	Injector solenoid driver cylinder 4 circuit - Current below normal, or open circuit. High resistance detected on injector number 4 circuit or no current detected at number 4 injector driver or return pin when the voltage supply at the harness is on.	
334 110 2	Engine coolant temperature - Data erratic, intermittent, or incorrect. The engine coolant temperature reading is not changing with engine operating conditions.	temperature.
342 630 13	342 630Electronic calibration code incompatibility - Out of calibration. An incompatible calibration has been engine dying, or hard star	
343 629 12	Engine control module warning internal hardware failure - Bad intelligent device or component. Internal ECM failure.	
351 627 12	Injector power supply - Bad intelligent device or component. The ECM measured injector boost voltage is low.	
352 1079 4	Sensor supply 1 circuit - Voltage below normal, or shorted to low source. Low voltage detected at sensor supply number 1 circuit.	
386 1079 3	Sensor supply 1 circuit - Voltage above normal, or shorted to high source. High voltage detected at sensor supply number 1 circuit.	
415 100 1	Engine oil rifle pressure - Data valid but below normal operational range - Most severe level. Oil pressure signal indicates oil pressure below the engine protection critical limit.	from time of alert. If engine protection
418 97 15	Water in fuel indicator - Data valid but above normal operational range - Least severe level. water has been detected in the fuel filter.	
428 97 3	Water in fuel indicator sensor circuit - Voltage above normal, or shorted to high source. High voltage detected at the water in fuel circuit.	
429 97 4	Water in fuel indicator sensor circuit - Voltage below normal, or shorted to low source. Low voltage detected at the water in fuel circuit.	
431 558 2	Accelerator pedal or lever idle validation switch - Data erratic, intermittent, or incorrect. Voltage detected simultaneously on both idle validation and off-idle validation switches.	Engine will only idle.

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
432 558 13	Accelerator pedal or lever idle validation circuit - Out of calibration. Voltage at idle validation on-idle and off-idle circuit does not match accelerator pedal position.	
435 100 2	Engine oil rifle pressure - Data erratic, intermittent, or incorrect. An error in the engine oil pressure switch signal was detected by the ECM.	
441 168 18	Battery 1 voltage - Data valid but below normal operational range - Moderately severe level. ECM supply voltage is below the minimum system voltage level.	
442 168 16	Battery 1 Voltage - Data valid but above normal operational range - Moderately severe level. ECM supply voltage is above the maximum system voltage level.	components.
449 157 0	Injector metering rail 1 pressure - Data valid but above normal operational range - Most severe level.	higher injection pressures (especially at idle or light load). Engine power is reduced.
451 157 3	Injector metering rail 1 pressure sensor circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the rail fuel pressure sensor circuit.	
452 157 4	Injector metering rail 1 pressure sensor circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the rail fuel pressure sensor circuit.	
488 105 16	Intake manifold 1 temperature - Data valid but above normal operational range - Moderately severe level. Intake manifold air temperature signal indicates intake manifold air temperature is above the engine protection warning limit.	
497 1377 2	Multiple unit synchronization switch - Data erratic, intermittent, or incorrect.	None on performance.
523 611 2	Auxiliary intermediate (PTO) speed switch validation - Data erratic, intermittent, or incorrect.	
527 702 3	Auxiliary input/output 2 circuit - Voltage above normal, or shorted to high source. High signal voltage or open circuit has been detected at the auxiliary input/output 2 circuit.	
528 93 2	Auxiliary alternate torque validation switch - Data erratic, intermittent, or incorrect.	None on performance.
529 703 3	Auxiliary input/output 3 circuit - Voltage above normal, or shorted to high source. Low signal voltage has been detected at the auxiliary input/ output 2 circuit.	
553 157 16	Injector metering rail 1 pressure - Data valid but above normal operational range - Moderately severe level. The ECM has detected that fuel pressure is higher than commanded pressure.	smoke.


Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)		
554 157 2	Injector metering rail 1 pressure - Data erratic, Intermittent, or incorrect. The ECM has detected that the fuel pressure signal is not changing.	c, Either the engine will not start or the engine wi d not have starter lockout protection.		
559 157 18	Injector metering rail 1 pressure - Data Valid but Below Normal Operational Range - Moderately Severe Level. The ECM has detected that fuel pressure is lower than commanded pressure.	The engine will not have starter lockout protection.		
584 677 3	Starter relay driver circuit - Voltage above normal, or shorted to high source. Open circuit or high voltage detected at starter lockout circuit.	estimated turbocharger speed.		
585 677 4	Starter relay driver circuit - Voltage below normal, or shorted to low source. Low voltage detected at starter lockout circuit.			
595 103 16	Turbocharger 1 speed - Data valid but above normal operational range - Moderately severe level. High turbocharger speed has been detected.			
599 640 14	Auxiliary commanded dual output shutdown - Special instructions.	None or possible engine noise associated with higher injection pressures (especially at idle or light load). Engine power is reduced.		
687 103 18	Turbocharger 1 speed - Data valid but below normal operational range - Moderately severe level. Low turbocharger speed detected by the ECM.	Engine power derate.		
689 190 2	Engine crankshaft speed/position - Data erratic, intermittent, or incorrect. Loss of signal from crankshaft sensor.	Engine power derate.		
691 1172 3	Turbocharger 1 compressor inlet temperature circuit - Voltage above normal, or shorted to high source. High signal voltage detected at turbocharger compressor inlet air temperature circuit.	smoke, hard start, and rough idle possible.		
692 1172 4	Turbocharger 1 compressor inlet temperature circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at turbocharger compressor inlet air tempera	engine dying, or hard starting.		
731 723 7	Engine speed / position camshaft and crankshaft misalignment - Mechanical system not responding properly or out of adjustment. mechanical misalignment between the crankshaft and camshaft engine speed sensors.			
757 611 31	Electronic control module data lost - Condition exists. Severe loss of data from the ECM.	Possible poor starting. Engine power derate.		
778 723 2	erratic, intermittent, or incorrect. The ECM has detected an error in the camshaft position sensor signal.	trip information, and maintenance monitor data may be inaccurate.		
779 703 11	Auxiliary equipment sensor input 3 - Root cause not known.	Engine will shut down.		

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)
1117 627 2	Power supply lost with ignition on - Data erratic, intermittent, or incorrect. Supply voltage to the ECM fell below 6.2 volts momentarily, or the ECM was not allowed to power down correctly (retain battery voltage for 30 seconds after key OFF).	
1633 625 2	OEM datalink cannot transmit - Data erratic, intermittent, or incorrect. Communications within the OEM datalink network is intermittent.	5 ,
2185 520197 3	Sensor supply 4 circuit - Voltage above normal, or shorted to high source. High voltage detected at +5 volt sensor supply circuit to the accelerator pedal position sensor.	smoke.
2186 520197 4	Sensor supply 4 circuit - Voltage below normal, or shorted to low source. Low voltage detected at +5 volt sensor supply circuit to the accelerator pedal position sensor.	higher injection pressure (especially at idle or light load)
2249 157 1	Injector metering rail 1 pressure - Data valid but below normal operational range - Most severe level. The ECM has detected that fuel pressure is lower than commanded pressure.	
2265 1075 3	Electric lift pump for engine fuel supply circuit - Voltage above normal, or shorted to high source. High voltage or open detected at the fuel lift pump signal circuit.	
2266 1075 4	Electric lift pump for engine fuel supply circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the fuel lift pump circuit.	from the primary to the backup speed sensor.
2311 633 31	Electronic fuel injection control valve circuit - Condition exists. Fuel pump actuator circuit resistance too high or too low.	Possible low power.
2321 190 2	Engine crankshaft speed/position - Data erratic, intermittent, or incorrect. crankshaft engine speed sensor intermittent synchronization.	•
2322 723 2	Engine camshaft speed / position sensor - Data erratic, intermittent, or incorrect. Camshaft engine speed sensor intermittent synchronization.	
2345 103 10	Turbocharger 1 Speed - Abnormal rate of change. The turbocharger speed sensor has detected an erroneous speed value.	
2346 2789 15	(Calculated) - Data valid but above normal operational range - Least severe level. Turbocharger turbine inlet temperature has exceeded the engine protection limit.	
2347 2790 15	(Calculated) - Data valid but above normal operational range - Least severe level.	
2377 647 3	Fan control circuit - Voltage above normal, or shorted to high source. Open circuit or high voltage detected at the fan control circuit.	

Fault code J1939 SPN J1939 FMI	Reason	Effect (only when fault code is active)	
2384 641 4	VGT actuator driver circuit - Voltage below normal, or shorted to low source. Low voltage detected at turbocharger control valve circuit.	-	
2385 641 3	VGT actuator driver circuit - Voltage above normal, or shorted to high source. Open circuit or high voltage detected at turbocharger control valve circuit.	the time.	
2555 729 3	Intake air heater 1 circuit - Voltage above normal, or shorted to high source. High voltage detected at the intake air heater signal circuit.		
2556 729 4	Intake air heater 1 circuit - Voltage below normal, or shorted to low source. Low voltage detected at the intake air heater signal circuit.		
2557 697 3	Auxiliary PWM driver 1 circuit - Voltage above normal, or shorted to high source. High signal voltage detected at the analog torque circuit.		
2558 697 4	Auxiliary PWM driver 1 circuit - Voltage below normal, or shorted to low source. Low signal voltage detected at the analog torque circuit.		
2973 102 2	Intake manifold 1 pressure - Data erratic, intermittent, or incorrect. The ECM has detected an intake manifold pressure signal that is too high or low for current engine operating conditions.		

GROUP 12 ENGINE CONTROL SYSTEM

1. MCU and Engine ECM (Electronic Control Module)



38095MS02

2. MCU ASSEMBLY

1) To match the pump absorption torque with the engine torque, MCU varies EPPR valve output pressure, which control pump discharge amount whenever feedbacked engine speed drops under the reference rpm of each mode set.

2)	Three LED	lamps on	the MCU	display	as below.
-/					

LED lamp	Trouble	Service		
G is turned ON	Normal	-		
G and R are turned ON Trouble on MCU		· Change the MCU		
G and Y are turned ON Trouble on serial		Check if serial communication		
	communication line	lines between controller and cluster are		
		disconnected		
Three LED are turned OFF	Trouble on MCU power	\cdot Check if the input power wire (24 V, GND) of		
		controller is disconnected		
		Check the fuse		

G: green, R: red, Y: yellow

GROUP 13 EPPR VALVE

1. PUMP EPPR VALVE

1) COMPOSITION

EPPR (Electro Proportional Pressure Reducing) valve consists of electro magnet and spool valve installed at main pump.

(1) Electro magnet valve

Receive electric current from MCU and move the spool proportionally according to the specific amount of electric current value.

(2) Spool valve

Is the two way direction control valve for pilot pressure to reduce main pump flow. When the electro magnet valve is activated, pilot pressure enters into flow regulator of main pump.

Mode	Mada		Pressure		Engine rpm
wode		kgf/cm ²	psi	(mA)	(at accel dial 10)
	Р	4 ± 3	57 ± 40	230 ± 30	1700 ± 50
Standard (Stage : 1.0)	S	6 ± 3	85 ± 40	270 ± 30	1600 ± 50
	Е	11 ± 3	156 ± 40	340 ± 30	1500 ± 50
	Р	0 ± 3	0 ± 40	160 ± 30	1800 ± 50
Option (Stage : 2.0)	S	4 ± 3	57 ± 40	230 ± 30	1650 ± 50
(2.3.337.2.10)	Е	9 ± 3	128 ± 40	330 ± 30	1650 ± 50

(3) Pressure and electric current value for each mode


2) HOW TO SWITCH THE STAGE (1.0 ↔ 2.0) ON THE CLUSTER

You can switch the EPPR valve pressure set by selecting the stage $(1.0 \leftrightarrow 2.0)$.

Management

-


Service menu




· Power shift (standard/option) : Power shift pressure can be set by option menu.

3) OPERATING PRINCIPLE (pump EPPR valve)

(1) Structure







P Pilot oil supply line (pilot pressure)

- T Return to tank
- A Secondary pressure to flow regulator at main pump

(2) Neutral


Pressure line is blocked and A oil returns to tank.






(3) Operating

Secondary pressure enters into A.






4) EPPR VALVE CHECK PROCEDURE


(1) Check electric current value at EPPR valve

- ① Disconnect connector CN-75 from EPPR valve.
- ② Insert the adapter to CN-75 and install multimeter as figure.
- 3 Start engine.
- ④ Set S-mode and cancel auto decel mode.
- 5 Position the accel dial at 10.
- ⑥ If rpm display show approx 1750±50 rpm check electric current at bucket circuit relief position.
- ⑦ Check electric current at bucket circuit relief position.

(2) Check pressure at EPPR valve

- ① Remove plug and connect pressure gauge as figure.
 - Gauge capacity : 0 to 50 kgf/cm² (0 to 725 psi)
- 0 Start engine.
- ③ Set S-mode and cancel auto decel mode.
- 4 Position the accel dial at 10.
- ⑤ If tachometer show approx 1750±50 rpm check pressure at relief position of bucket circuit by operating bucket control lever.
- ⑥ If pressure is not correct, adjust it.
- $\ensuremath{\overline{\mathcal{O}}}$ After adjust, test the machine.





2. BOOM PRIORITY EPPR VALVE

1) COMPOSITION


The boom priority EPPR valve is built in a manifold and mainly consisting of valve body and coil. This EPPR valve installed under the solenoid valve.

2) CONTROL

The boom priority EPPR valve has to be controlled by a specific electronic amplifier card, which is supplying the coil with a current 580 mA at 30 $_{\Omega}\,$ and 24 V.

3) OPERATING PRINCIPLE

(1) Structure



1 O-ring 2 Support ring

Т

4 Coil

- Connector 5
- 6 Cover cap

(2) Operation

In de-energized mode the inlet port (P) is closed and the outlet port (A) is connected to tank port (T).


In energized mode the solenoid armature presses onto the control spool with a force corresponding to the amount of current. This will set a reduced pressure at port A. The setting is proportional to the amount of current applied.

(3) Maximum pressure relief

If a pressure from outside is applied on port A the valve may directly switch to tank port (T) and protect the system before overload.


2) EPPR VALVE CHECK PROCEDURE

- (1) Check electric current value at EPPR valve
 - ① Disconnect connector CN-133 from EPPR valve.
 - ② Insert the adapter to CN-133 and install multimeter as figure.
 - ③ Start engine.
 - ④ If rpm display approx 1750±50 rpm disconnect one wire harness from EPPR valve.
 - © Check electric current in case of combined boom up and swing operation.



(2) Check pressure at EPPR valve

- ① Remove hose from A5 port and connect pressure gauge as figure.
 - Gauge capacity : 0 to 50 kgf/cm² (0 to 725 psi)
- ② Start engine.
- ③ If rpm display approx 1750±50 rpm check pressure at relief position of bucket circuit by operating bucket control lever.
- ④ If pressure is not correct, adjust it.
- (5) After adjust, test the machine.



GROUP 14 MONITORING SYSTEM

1. OUTLINE


Monitoring system consists of the monitor part and switch part.

The monitor part gives warnings when any abnormality occurs in the machine and informs the condition of the machine.

Various select switches are built into the monitor panel, which act as the control portion of the machine control system.

2. CLUSTER

1) MONITOR PANEL



21095MS30

2) CLUSTER CHECK PROCEDURE

(1) Start key : ON

① Check monitor

- a. Buzzer sounding for 4 seconds with HYUNDAI logo on cluster.
- * If the ESL mode is set to the enable, enter the password to start engine.
- ② After initialization of cluster, the operating screen is displayed on the LCD. Also, self diagnostic function is carried out.
 - a. Engine rpm display : 0 rpm
 - b. Engine coolant temperature gauge : White range
 - c. Hydraulic oil temperature gauge : White range
 - d. Fuel level gauge : White range

③ Indicating lamp state

- a. Power mode pilot lamp : E mode or U mode
- b. Work mode pilot lamp : General operation mode (bucket)
- C. Travel speed pilot lamp : Low (turtle)

(2) Start of engine

1 Check machine condition

- a. RPM display indicates at present rpm
- b. Gauge and warning lamp : Indicate at present condition.
- * When normal condition : All warning lamp OFF
- c. Work mode selection : General work
- d. Power mode selection : E mode or U mode
- e. Travel speed pilot lamp : Low (turtle)

② When warming up operation

- a. Warming up pilot lamp : ON
- b. After engine started, engine speed increases to 1200 rpm.
- * Others same as above.


③ When abnormal condition

- a. The warning lamp lights up and the buzzer sounds.
- b. If BUZZER STOP switch is pressed, buzzer sound is canceled but the lamp warning lights up until normal condition.
- * The pop-up warning lamp moves to the original position and blink when the select switch is pushed. Also the buzzer stops.

3. CLUSTER CONNECTOR

No.	Name	Signal
1	Battery 24V	20~32V
2	Signal 3	NTSC
3	GND	-
4	Serial + (TX)	0~5V
5	Power IG (24V)	20~32V
6	Signal 2	NTSC
7	Camera signal	NTSC
8	Serial - (RX)	0~5V

* NTSC : the united states National Television Systems Committee



2) GAUGE

(1) Operation screen



- 1 Engine coolant temperature gauge
- 2 Hydraulic oil temperature gauge
- 3 Fuel level gauge
- 4 RPM / Tripmeter display

* Operation screen type can be set by the screen type menu of the display. Refer to page 5-54 for details.

(2) Engine coolant temperature gauge



- $\ensuremath{\textcircled{}}$ This gauge indicates the temperature of coolant.
 - · White range : 40-107°C (104-225°F)
 - Red range : Above 107°C (225°F)
- ② If the indicator is in the red range or 🔄 lamp blinks in red, turn OFF the engine and check the engine cooling system.
- * If the gauge indicates the red range or \bigcirc lamp blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(3) Hydraulic oil temperature gauge



${\scriptstyle (\!\!\!\!)}$ This gauge indicates the temperature of hydraulic oil.

- White range : 40-105°C(104-221°F)
- Red range : Above 105°C(221°F)
- ② If the indicator is in the red range or 🔊 lamp blinks is red, reduce the load on the system. If the gauge stays in the red range, stop the machine and check the cause of the problem.
- * If the gauge indicates the red range or 🖾 lamp blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(4) Fuel level gauge



21093CD07F

(5) RPM / Tripmeter display




- This gauge indicates the amount of fuel in the fuel tank.
- 2 Fill the fuel when the red range, or 3 lamp blinks in red.
- * If the gauge indicates the red range or \square lamp blinks in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

 $\ensuremath{\textcircled{}}$ This displays the engine speed or the tripmeter.

* Refer to page 5-54 for details.

3) WARNING LAMPS



* Each warning lamp on the top of the LCD pops up on the center of LCD and the buzzer sounds when the each warning is happened. The pop-up warning lamp moves to the original position and blinks when the select switch is pushed. And the buzzer stops. Refer to page 5-43 for the select switch.

(1) Engine coolant temperature



- ${\scriptstyle (\!\!\!\!\!]}$ Engine coolant temperature warning is indicated two steps.
 - 103°C over : The \bigoplus lamp blinks and the buzzer sounds.
 - 107°C over : The *i* lamp pops up on the center of LCD and the buzzer sounds.
- ② The pop-up (1) lamp moves to the original position and blinks when the select switch is pushed. Also, the buzzer stops and (2) lamp keeps blink.
- ③ Check the cooling system when the lamp keeps ON.

(2) Hydraulic oil temperature



21093CD08C

21093CD08A

(3) Fuel level



- Hydraulic oil temperature warning is indicated two steps.
 - 100°C over : The 🖾 lamp blinks and the buzzer sounds.
 - 105°C over : The (i) lamp pops up on the center of LCD and the buzzer sounds.
- ② The pop-up <u>i</u> lamp moves to the original position and blinks when the select switch is pushed. Also, the buzzer stops and <u>i</u> lamp keeps blink.
- ③ Check the hydraulic oil level and hydraulic oil cooling system.
- ① This warning lamp blinks and the buzzer sounds when the level of fuel is below 75 *l* (19.8 U.S. gal).
- O Fill the fuel immediately when the lamp blinks.

21093CD08B


(4) Emergency warning lamp



 This lamp pops up and the buzzer sounds when each of the below warnings is happened.

- Engine coolant overheating (over 107°C)
- Hydraulic oil overheating (over 105°C)
- Pump EPPR circuit abnormal or open
- Attachment flow EPPR circuit abnormal or open
- MCU input voltage abnormal
- Accel dial circuit abnormal or open
- Cluster communication data error
- Engine ECM communication data error
- * The pop-up warning lamp moves to the original position and blinks when the select switch is pushed. Also the buzzer stops. This is same as following warning lamps.
- ② When this warning lamp blinks, machine must be checked and serviced immediately.

(5) Engine oil pressure warning lamp



- ① This lamp blinks when the engine oil pressure is low.
- ② If the lamp blinks, shut OFF the engine immediately. Check oil level.


(6) Check engine warning lamp



- ① This lamp blinks when the communication between MCU and engine ECM on the engine is abnormal, or if the cluster received any fault code from engine ECM.
- ② Check the communication line between them. If the communication line is OK, then check the fault codes on the cluster.
- ③ This lamp blinks when "Engine check water in fuel" is displayed in the message box then check water separator.

(7) Battery charging warning lamp

29093CD03




This lamp blinks when the battery charging voltage is low.
 Check the battery charging circuit when this lamp blinks.

(8) Air cleaner warning lamp



This lamp blinks when the filter of air cleaner is clogged.
 Check the filter and clean or replace it.

(9) Overload warning lamp (opt)



 When the machine is overload, the overload warning lamp blinks during the overload switch is ON. (if equipped)
 Reduce the machine load.

4) PILOT LAMPS

Work tool mode pilot lamp Work mode pilot lamp Power/User mode pilot lamp Preheat pilot lamp Worming up pilot lamp	Message display Travel speed pilot lamp Auto idle pilot lamp Maintenance pilot lamp Fuel warmer pilot lamp
Warming up pilot lamp	Decel pilot lamp 21093CD09
	210930009

(1) Mode pilot lamps

No	Mode	Pilot lamp	Selected mode
		Ρ	Heavy duty power work mode
1	Power mode	S	Standard power mode
		Ε	Economy power mode
2	User mode	U	User preferable power mode
		b	General operation mode
3	Work mode		Breaker operation mode
		4	Crusher operation mode
4	Travel mode		Low speed traveling
4	Travel mode	*	High speed traveling
5	Auto idle mode	3	Auto idle
6	Work tool mode		Oil flow level of breaker or crusher mode
7	Message display		"Setting is completed" display after selection

(2) Power max pilot lamp



21093CD38

- ① The lamp will be ON when pushing power max switch on the LH RCV lever.
- O The power max function is operated maximum 8 seconds.
- * Refer to the operator's manual page 3-26 for power max function.

(3) Preheat pilot lamp



(4) Warming up pilot lamp



(5) Decel pilot lamp



- ① Turning the start key switch ON position starts preheating in cold weather.
- ② Start the engine after this lamp is OFF.
- (1) This lamp is turned ON when the coolant temperature is below $30^{\circ}C(86^{\circ}F)$.
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C, or when 10 minutes have passed since starting the engine.
- ① Operating one touch decel switch on the RCV lever makes the lamp ON.
- ② Also, the lamp will be ON and engine speed will be lowered automatically to save fuel consumption when all levers and pedals are at neutral position, and the auto idle function is selected.
- * One touch decel is not available when the auto idle pilot lamp is turned ON.
- $\,\times\,$ Refer to the operator's manual page 3-26.

(6) Fuel warmer pilot lamp



21093CD43

(7) Maintenance pilot lamp




10°C (50°F) or the hydraulic oil temperature 20°C (68°F). ② The automatic fuel warming is cancelled when the engine

① This lamp is turned ON when the coolant temperature is below

- coolant temperature is above 60°C, or the hydraulic oil temperature is above 45°C since the start switch was ON position.
- This lamp will be ON when the consuming parts are needed to change or replace. It means that the change or replacement interval of the consuming parts remains below 30 hours.
- ② Check the message in maintenance information of main menu. Also, this lamp lights ON for 3 minutes when the start switch is ON position.


5) SWITCHES



21093CD45

When the switches are selected, the pilot lamps are displayed on the LCD. Refer to the page 5-40 for details.

(1) Power mode switch



① This switch is to select the machine power mode and selected power mode pilot lamp is displayed on the pilot lamp position.

- \cdot P : Heavy duty power work.
- \cdot S : Standard power work.
- \cdot E : Economy power work.
- ② The pilot lamp changes $E \rightarrow S \rightarrow P \rightarrow E$ in order.

(2) Work mode switch



 This switch is to select the machine work mode, which shifts from general operation mode to optional attachment operation mode.

- B : General operation mode
- $\cdot \, \mathscr{O} \,$: Breaker operation mode (if equipped)
- :Crusher operation mode (if equipped)
- \cdot Not installed : Breaker or crusher is not installed.
- * Refer to the operator's manual page 4-6 for details.

(3) User mode switch



(4) Select switch



21093CD45E

- ① This switch is used to memorize the current machine operating status in the MCU and activate the memorized user mode.
 - \cdot Memory : Push more than 2 seconds.
 - · Action : Push within 2 seconds.
 - · Cancel : Push this switch once more within 2 seconds.
- 0 Refer to the page 5-45 for another set of user mode.
- ① This switch is used to select or change the menu and input value.
- 2 Knob push
 - · Long (over 2 sec) : Return to the operation screen
 - \cdot Medium (0.5~2 sec) $\,$: Return to the previous screen
 - Short (below 0.5 sec) : Select menu
- ③ Knob rotation
 - This knob changes menu and input value.
 - · Right turning : Down direction / Increase input value
 - · Left turning : Up direction / Decreased input value

(5) Auto idle/ buzzer stop switch




- 1 This switch is used to activate or cancel the auto idle function.
 - Pilot lamp ON : Auto idle function is activated.
 - \cdot Pilot lamp OFF : Auto idle function is cancelled.
- ② The buzzer sounds when the machine has a problem. In this case, push this switch and buzzer stops, but the warning lamp blinks until the problem is cleared.

(6) Travel speed control switch



- 1 This switch is used to select the travel speed alternatively.
 - : High speed
 - + : Low speed

(7) Escape/Camera switch



- ① This switch is used to return to the previous menu or parent menu.
- ② In the operation screen, pushing this switch will display the view of the camera on the machine (if equipped).
 - Please refer to page 5-55 for the camera.
- ③ If the camera is not installed, this switch is used only ESC function.

6) MAIN MENU



* Please refer to select switch, page 5-43 for selection and change of menu and input value.

(1) Structure


No	Main menu	Sub menu	Description
1	Mode 21093CD64D	Work tool U mode power Boom/Arm speed Auto power boost Initial mode Cluster switch (back up)	Breaker, Crusher, Not installed User mode only Boom speed, Arm speed Enable, Disable Default, U mode Switch function
2	Monitoring 21093CD64E	Active fault Logged fault Delete logged fault Monitoring (analog) Monitoring (digital) Operating hours	MCU, Engine ECM MCU, Engine ECM All logged fault delete, Initialization canceled Machine information Switch status, Output status Operating hours for each mode
3	Management 21093CD64F	Maintenance information Machine security Machine Information A/S phone number Service menu	Replacement, Change interval oils and filters ESL mode setting, Password change Cluster, MCU, Engine, Machine A/S phone number, A/S phone number change Power shift, Hourmeter, Replacement history, Update
4	Display 21093CD64G	Display item Clock Brightness Unit Language Screen type	Engine speed, Tripmeter A, Tripmeter B, Tripmeter C Clock Manual, Auto Temperature, Pressure, Flow, Date format Korean, English, Chinese A type, B type
5	Utilities 21093CD64H	Tripmeter DMB Entertainment Camera setting Message box	3 kinds (A, B, C) DMB select, DAB select, Channel scan, Exit Play MP4, codec. Basic direction, Display switching, Full screen Record for fault, attachment etc.

(2) Mode setup

① Work tool

Work Tool	Breaker 🕨					wet Test		
U Mode Power	Þ		Work Tool	Breaker 🕨		Work Tool	Bre	eaker
	•		U Mode Power Breaker	•	A			
	Disable		Boom/Arm Spe	•		Mary Elans	1000	
	Default	2	Crusher			Max. Flow	1000	lpm
	•		Auto Power Bo Not installed	Disable				
一一一百百万日		Ď	Initial Mode	Default			 3	
A O M O ~			Cluster Switches(Back Up)	• ▶				
	21093CD65	\$			ਸ			
		E	🖌 🕅 🖉 🖉	a 🖗 👁 🔶	Е	Setting	is completed	
				21093CD65A			210930	CD
			А				В	

- · A : Select one installed optional attachment.
- · B : Max flow Set the maximum flow for the attachment.
 - Flow level Reduce the operating flow from maximum flow.
 - Breaker Max 7 steps, Reduced 10 lpm each step.
 - Crusher Max 4 steps, Reduced 20 lpm each step.
- * The flow level is displayed with the work mode pilot lamp.
- 2 U mode power



	()	(rpm)	(rpm)	(bar)
	1	1350	700	0
	2	1400	750	3
	3	1450	One touch decel low idle (800)	6
	4	1500	850	9
)	5	1550	900	12
	6	1600	950	16
	7	1650	Auto decel rpm (1000)	20
	8	1700	1050	26
	9	1750	1100	32
	10	1800	1150	38

Idle speed

(rpm)

Engine

speed

Power

shift

- Engine high idle rpm, auto idle rpm and pump torque • (power shift) can be modulated and memorized separately in U-mode.
- · U-mode can be activated by user mode switch.

3 Boom/Arm speed



Boom speed

- Control type

Manual - Boom up speed is fixed as set steps.

Auto - Boom up speed is automatically adjusted as working conditions by the MCU.

- Speed setting - Boom up speed is increased as much as activated steps.

· Arm speed

- Regeneration - Arm regeneration function can be activated or cancelled. Enable - Arm in speed is up. Disable - Fine operation.

④ Auto power boost



- · The power boost function can be activated or cancelled.
- Enable The digging power is automatically increased as working conditions by the MCU. It is operated max 8 seconds.
- · Disable Not operated.

(5) Initial mode



- $\cdot\,$ Default The initial power mode is set E mode when the engine is started.
- $\cdot\,$ U mode The initial power mode is set U mode when the engine is started.
- 6 Cluster switch (back up)



- The cluster switch can be selected and changed by this menu when the switches are abnormal on the cluster.
- In order to exit "Cluster switch" mode, please put the cursor on the ESC/CAM switch by turning the select switch and push the select switch.
- In "Cluster switch", other switches except "Select switch" do not work.

(3) Monitoring

① Active fault



· The active faults of the MCU or engine ECM can be checked by this menu.

2 Logged fault



• The logged faults of the MCU or engine ECM can be checked by this menu.

③ Delete logged fault



• The logged faults of the MCU or engine ECM can be deleted by this menu.

④ Monitoring (analog)



• The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu.

(5) Monitoring (digital)



- · The switch status or output status can be confirmed by this menu.
- The activated switch or output pilot lamps 🐥 are light ON.


6 Operating hours



• The operating hour of each mode can be confirmed by this menu.

(4) Management

① Maintenance information



Yellow 🔶 - First warning

븆 - Second warning


- · Replacement : The elapsed time will be reset to zero (0).
- Change interval : The change or replace interval can be changed in the unit of 50 hours. •
- : Return to the item list screen. OK •

Red

· Change or replace interval

No	Item	Interval
1	Engine oil	500
2	Final gear oil	1000
3	Swing gear oil	1000
4	Hydraulic oil	5000
5	Pilot line filter	1000
6	Drain filter	1000
7	Hydraulic oil return filter	1000
8	Engine oil filter	500
9	Fuel filter	500
10	Pre-filter	500
11	Hydraulic tank breather	250
12	Air cleaner (inner)	500
13	Radiator coolant	2000
14	Swing gear pinion grease	1000

2 Machine security





21093CD67EE

ESL M

21093CD67H

ESL Mode S

ESL Mo

<mark>.</mark> ă

8

¢ 1

Ε

· ESL mode

- ESL : Engine Starting Limit
- ESL mode is designed to be a theft deterrent or will prevent the unauthorized operation of the machine.
- If the ESL mode was selected Enable, the password will be required when the start switch is turned ON.
- Disable : Not used ESL function
- Enable (always) : The password is required whenever the operator start engine.
- Enable (interval) : The password is required when the operator start engine first. But the operator can restart the engine within the interval time without in putting the password. The interval time can be set maximum 4

hours.



21093CD67U

Password Chy

Enter the current password 21093CD67V

le (Always

Password change

- The password is 5~10 digits.





21093CD67XX

Enter the new password 21093CD67VV

The new password is stored in the MCU.


Enter the new password again

③ Machine Information



· This can confirm the identification of the cluster, MCU, engine and machine.

4 A/S phone number



21093CD67ZZ

- · Power shift (standard/option) : Power shift pressure can be set by option menu.
- · Hourmeter : Operating hours since the machine line out can be checked by this menu.
- Replacement history : Replacement history of the MCU and cluster can be checked by this menu.
- · Update : Firm ware can be upgraded by this menu. (the USB port is located under the cluster)

(5) Display

① Display item




- · The center display type of the LCD can be selected by this menu.
- The engine speed or each of the tripmeter (A,B,C) is displayed on the center display.
- 2 Clock



- The first line's three spots "**/**/***" represent Month/Day/Year each.
- The second line shows the current time. (0:00~23:59)

③ Brightness




If "Auto" is chosen, brightness for day and night can be differently set up. Also by using the bar in lower side, users can define which time interval belongs to day and night. (in bar figure, gray area represents night time while white shows day time)

4 Unit




- · Temperature : $^{\circ}C \leftrightarrow ^{\circ}F$
- $\cdot \quad \text{Pressure} \qquad : \text{bar} \leftrightarrow \text{MPa} \leftrightarrow \text{kgf/cm}^2$
- · Flow : $lpm \leftrightarrow gpm$
- $\cdot \ \mbox{Date format} \ : yy/mm/dd \leftrightarrow mm/dd/yy \leftrightarrow dd-Mar-yy$
- **5** Language



· User can select preferable language and all displays are changed the selected language.

6 Screen type



(6) Utilities

1) Tripmeter



- · Maximum 3 kinds of tripmeters can be used at the same time.
- Each tripmeter can be turned on by choosing "Start" while it also can be turned off by choosing "Stop".
- · If the tripmeter icon is activated in the operation screen, it can be controlled directly there.



- · DMB select : TV channel can be selected by this menu.
- · DAB select : Audio channel can be selected by this menu.
- · Channel scan : This menu can be used other region for TV/Audio.
- · Exit : Exit DMB menu

③ Entertainment

- · Play MP4 or codec file of external hard disk through USB port.
- The USB port is located under the cluster.



④ Camera setting



- · Three cameras can be installed on the machine.
- $\cdot\,$ The display order can be set by this menu.



- · If the camera was not equipped, this menu is not useful.
- · In the operation screen, if the ESC/CAM switch is pushed, the first ordered display camera will be viewed.
- Turning the select switch in clockwise direction, the next ordered will be shown and in counter-clockwise direction, the previously ordered will be shown.
- · Push the select switch, the displayed screen will be enlargement.

5 Message box

· The history of the machine operating status can be checked by this menu.



GROUP 15 FUEL WARMER SYSTEM


1. SPECIFICATION

- 1) Operating voltage : $24 \pm 4 V$
- 2) Power : 350 \pm 50 W
- 3) Current : 15 A

2. OPERATION

- The current of fuel warmer system is automatically controlled without thermostat according to fuel temperature.
- At the first state, the 15 A current flows to the fuel warmer and engine may be started in 1~2 minutes.
- 3) If the fuel starts to flow, ceramic-disk in the fuel warmer heater senses the fuel temperature to reduce the current as low as 1.5 A.

So, fuel is protected from overheating by this mechanism.



145 5W 58 1.2Gr ECM POWER RY POWER RY FUSE BOX 韓韓韓韓韓 「材 财 Ň 内 M 材. 邥 材 应应应应 CN-36 ECM ROOM LAMP/CASSETTE T AIR CON/HEATER WIPER FUEL FILLER PUMP 0 1-4 02 05 05 08 08 08 08 085 CABIN LAMP(OPT) CIGAR LIGHTER SWITCH PANEL ASTER -USTER ONVERTER JEL HEATER AMF .8WOr 2WR AC& HEATER LAMP 8WOr 8W ΥË VORK LAMP SAFETY SOL SOLENOIDE 88.0 2Gr 2W ACU_EPPR SOLENOIDE MCU CONT SSETTE CN-9 CLUSTER PRE-HEAT 020 VIPER START EAD L SPARE MCU QM CN-60 12R Ň Ň ſ FUSIBLE LINK CN-93 050 <u>M</u> 0 39 POWER IG 07 080 Ĵ₽÷Ĵ CN-94 BATT (+) 010 BATTER) (12VX2) 2W 03 BATT (+) BATT RY 01/0 2B 02 BATT (-) 01 BATT (-) M 21/20 2B лзо (BATTERY (-) TERMINAL) 6140 6150 0090 2H CN-51 CN-125 ĥ BATTERY POWER 24V(+) CN-52 FUEL WARMER RY MCU 0 8 9 GPS CONN E FUEL WARMER °t₽t START KEY SW FUEL WARMER RY

3. ELECTRIC CIRCUIT

21095MS20

Group	1 Before Troubleshooting	6-1
Group	2 Hydraulic and Mechanical System	6-4
Group	3 Electrical System	6-24
Group	4 Mechatronics System	6-40


GROUP 1 BEFORE TROUBLESHOOTING

1. INTRODUCTION

When a trouble is occurred in the machine, this section will help an operator to maintain the machine with easy.

The trouble of machine is parted Hydraulic & Mechanical system, Electrical system and Mechatronics system. At each system part, an operator can check the machine according to the troubleshooting process diagram.

* Before carring out troubleshooting procedure, check monitoring menu in the cluster.




2. DIAGNOSING PROCEDURE

To carry out troubleshooting efficiently, the following steps must be observed.

STEP 1. Study the machine system

Study and know how the machine is operating, how the system is composing, what kinds of function are installed in the machine and what are specifications of the system components by the machine service manual.

Especially, deepen the knowledge for the related parts of the trouble.



STEP 2. Ask the operator


Before inspecting, get the full story of malfunctions from a witness --- the operator.


- 1) How the machine is used and when it is serviced?
- 2) When the trouble was noticed and what work the machine was doing at that time?
- 3) What is the phenomenon of the trouble? Was the trouble getting worse, or did it come out suddenly for the first time?
- Did the machine have any troubles previously? If so, which parts were repaired before.

STEP 3. Inspect the machine

Before starting troubleshooting, check the machine for the daily maintenance points as shown in the operator's manual.

And also check the electrical system including batteries, as the troubles in the electrical system such as low battery voltage, loose connections and blown out fuses will result in malfunction of the controllers causing total operational failures of the machine.






STEP 4. Inspect the trouble actually on the machine


In case that some trouble cannot be confirmed, obtain the details of the malfunction from the operator.

Also, check if there are any in complete connections of the wire harnesses are or not.



STEP 5. Perform troubleshooting


According to where the trouble parts are located, hydraulic & mechanical system part or electrical system part or mechatronics system part, perform troubleshooting the machine refer to the each system part's troubleshooting process diagram.



STEP 6. Trace a cause

Before reaching a conclusion, check the most suspectible causes again. Try to trace what the real cause of the trouble is.

Make a plan of the appropriate repairing procedure to avoid consequential malfunctions.



GROUP 2 HYDRAULIC AND MECHANICAL SYSTEM


1. INTRODUCTION

1) MACHINE IN GENERAL

- If even a minor fault is left intact and operation is continued, a fatal failure may be caused, entailing a large sum of expenses and long hours of restoration. Therefore when even a small trouble occurs, do not rely on your intuition and experience, but look for the cause based on the troubleshooting principle and perform maintenance and adjustment to prevent major failure from occurring. Keep in mind that a fault results from a combination of different causes.
- (2) The following lists up commonly occurring faults and possible causes with this machine. For the troubleshooting of the engine, refer to the coming troubleshooting and repair.
- (3) When carrying out troubleshooting, do not hurry to disassemble the components. It will become impossible to find the cause of the problem.
- (4) Ask user or operator the following.
- ① Was there any strange thing about machine before failure occurred?
- ② Under what conditions did the failure occur?
- ③ Have any repairs been carried out before the failure?
- (5) Check before troubleshooting.
- ① Check oil and fuel level.
- ② Check for any external leakage of oil from components.
- ③ Check for loose or damage of wiring and connections.

2) MACHINE STATUS MONITORING ON THE CLUSTER

(1) The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu.







No.	Description	Specification
Note 1	Pilot pump pressure	40 ⁺² bar
Note 2	Swing pilot pressure	0~40 bar
Note 3	Boom up pilot pressure	0~40 bar
Note 4	Arm/bucket pilot pressure	0~40 bar
Note 5	P1 pump control pressure	0~25 bar
Note 6	P2 pump control pressure	0~25 bar
Note 7	Pump 1 pressure	350 bar

2. DRIVE SYSTEM

1) UNUSUAL NOISE COMES OUT OF PUMP CONNECTION




2) ENGINE STARTS BUT MACHINE DOES NOT OPERATE AT ALL




3. HYDRAULIC SYSTEM


1) HYDRAULIC OIL IS CLOUDY




2) HYDRAULIC OIL TEMPERATURE HAS RISEN ABNORMALLY



3) CAVITATION OCCURS WITH PUMP




4) HYDRAULIC OIL IS CONTAMINATED




4. SWING SYSTEM


1) BOTH LH AND RH SWING ACTIONS ARE IMPOSSIBLE




2) SWING SPEED IS LOW




3) SWING MOTION IS IMPOSSIBLE IN ONE DIRECTION



4) MACHINE SWINGS BUT DOES NOT STOP




5) THE SWING UNIT DRIFTS WHEN THE MACHINE IS AT REST ON A SLOPE




5. TRAVEL SYSTEM

1) TRAVEL DOES NOT FUNCTION AT ALL ON ONE SIDE




2) SPEED ON ONE SIDE FALLS AND THE MACHINE CURVES




3) MACHINE DOES NOT STOP ON A SLOPE


Machine is pulled forward as sprocket rotates during digging operation.



4) LH AND RH TRAVEL MOTIONS ARE IMPOSSIBLE




5) TRAVEL ACTION IS POWERLESS (travel only)



6) MACHINE RUNS RECKLESSLY ON A SLOPE


Travel brake valve	Cause	Remedy
(counterbalance valve) is faulty.		Disassemble and repair or replace.

7) MACHINE MAKES A CURVED TRAVEL OR DOES NOT TRAVEL AT ALL WHEN TRAVEL AND ATTACHMENT OPERATIONS ARE EXECUTED AT THE SAME TIME




6. ATTACHMENT SYSTEM


1) BOOM OR ARM ACTION IS IMPOSSIBLE AT ALL




2) BOOM, ARM OR BUCKET SPEED IS LOW




3) BOOM, ARM OR BUCKET CYLINDER EXTENDS OR CONTRACTS ITSELF AND ATTACHMENT FALLS




4) BOOM, ARM OR BUCKET POWER IS WEAK



5) ONLY BUCKET OPERATION IS TOTALLY IMPOSSIBLE




6) BOOM MAKES A SQUEAKING NOISE WHEN BOOM IS OPERATED




**** HOW TO CHECK INTERNAL BOOM CYLINDER LEAKAGE**

1. Lower the bucket teeth to the ground with bucket cylinder fully retracted and arm cylinder rod retracted almost in full.




 Disconnect hose (A) from rod side of boom cylinder and drain oil from cylinders and hose. (put cups on piping and hose ends)



3. Raise bucket OFF the ground by retracting the arm cylinder rod.

If oil leaks from piping side and boom cylinder rod is retracted there is an internal leak in the cylinder.


If no oil leaks from piping side and boom cylinder rod is retracted, there is an internal leak in the control valve.



GROUP 3 ELECTRICAL SYSTEM


1. WHEN STARTING SWITCH IS TURNED ON, MONITOR PANEL DISPLAY DOES NOT APPEAR

- · Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.7, 13.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check voltage

YES	20~32V
NO	0V




2. COMMUNICATION ERROR FLASHES ON THE CLUSTER (HCESPN 840, FMI 2)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check voltage

YES	2V
NO	0V




3. **BATTERY CHARGING WARNING LAMP LIGHTS UP**(Starting switch : ON)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- \cdot Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check voltage

YES	20~32V		
NO	0V		




4. **WHEN COOLANT OVERHEAT WARNING LAMP LIGHTS UP** (engine is started)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






Check Table							
Temperature (°C)	0	25	50	80	95		
Resistance (k Ω)	30~37	9.3~10.7	3.2~3.8	1.0~1.3	0.7~0.8		



21093CD08A


5. 🕑 WHEN AIR CLEANER WARNING LAMP LIGHTS UP (engine is started)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.




Check resistance


YES	MAX 1Ω
NO	MIN 1MΩ



6. WHEN ENGINE OIL PRESSURE WARNING LAMP LIGHTS UP (engine is started)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- \cdot Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






6-29

7. UNIT WHEN HYDRAULIC OIL TEMPERATURE WARNING LAMP LIGHTS UP (engine is started)


- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- \cdot Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






Check Table

Temperature (°C)	~ -30	~ -10	~ 0	~ 40	~ 70	~ 80	~ 90	~ 100	105~
Resistance (k Ω)		8.16 ~10.74							




8. WHEN COOLANT TEMPERATURE GAUGE DOES NOT OPERATE (HCESPN 304, FMI 3 or 4)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






Check Table							
Temperature (°C)	0	25	50	80	95		
Resistance (k Ω)	30~37	9.3~10.7	3.2~3.8	1.0~1.3	0.7~0.8		




9. WHEN FUEL GAUGE DOES NOT OPERATE(HCESPN 301, FMI 3 or 4)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- · Before carrying out below procedure, check all the related connectors are properly inserted.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







Check Table Range Resistance (Ω) Range Resistance (Ω) 5/12 Full 50 400 11/12 100 4/12 450 10/12 150 3/12 500 9/12 200 2/12 550 1/12 600 8/12 250 7/12 300 700 Empty warning 6/12 350 -_



10. WHEN SAFETY SOLENOID DOES NOT OPERATE


- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.23.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.






11. WHEN TRAVEL SPEED 1, 2 DOES NOT OPERATE (HCESPN 167, FMI 5 or 6)

- \cdot Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.28 .
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







12. WHEN ENGINE DOES NOT START (______ lights up condition)

 \cdot Before disconnecting the connector, always turn the starting switch OFF.

• Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 1, 4, 8, 20.


· After checking, insert the disconnected connectors again immediately unless otherwise specified.






13. WHEN STARTING SWITCH ON DOES NOT OPERATE

- · Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted, master switch ON and check open circuit of fusible link (CN-60).
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.







14. WHEN STARTING SWITCH IS TURNED ON, WIPER MOTOR DOES NOT OPERATE

· Before disconnecting the connector, always turn the starting switch OFF.

Before carrying out below procedure, check all the related connectors are properly inserted and the fuse No. 6, 11 and 17 is not blown out.

· After checking, insert the disconnected connectors again immediately unless otherwise specified.







SWITCH PANEL


21096ES14

15. WHEN STARTING SWITCH IS TURNED ON, HEAD LAMP DOES NOT LIGHTS UP

- · Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.18.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.










16. WHEN STARTING SWITCH IS TURNED ON, WORK LAMP DOES NOT LIGHTS UP

- · Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No.15.
- · After checking, insert the disconnected connectors again immediately unless otherwise specified.








GROUP 4 MECHATRONICS SYSTEM


1. ALL ACTUATORS SPEED ARE SLOW

- * Boom, Arm, Bucket, Swing and travel speed are slow, but engine speed is good.
- * Spec : P-mode 1850 \pm 50 rpm S -mode 1750 \pm 50 rpm E-mode 1600 \pm 50 rpm
- * Before carrying out below procedure, check all the related connectors are properly inserted and fault code on the cluster.

1) INSPECTION PROCEDURE




Wiring diagram



21096MS01

2) TEST PROCEDURE

- (1) Test 1 : Check resistance at connector CN-75.
- ① Starting key OFF.
- ② Disconnect connector CN-75 from EPPR valve at main hydraulic pump.
- ③ Check resistance between 2 lines as figure.




- (2) Test 2 : Check electric current at EPPR valve.
- ① Disconnect connector CN-75 from EPPR valve.
- ② Insert the adapter to CN-75 and install multimeter as figure.
- ③ Start engine.
- ④ Set S-mode and cancel auto decel mode.
- 5 Position the accel dial at 10.
- 6 If rpm show approx 1750 \pm 50 rpm disconnect one wire harness from EPPR valve.
- ⑦ Check electric current at bucket circuit relief position.


(3) Test 3 : Check pressure at EPPR valve.

- ① Remove plug and connect pressure gauge as figure.
 - \cdot Gauge capacity : 0 to 50 kgf/cm²

(0 to 725 psi)

- 0 Start engine.
- ③ Set S-mode and cancel auto decel mode.
- 4 Position the accel dial at 10.
- ⑤ If rpm show approx 1750±50 rpm check pressure at relief position of bucket circuit by operating bucket control lever.
- ⑥ If pressure is not correct, adjust it.
- $\ensuremath{\overline{\mathcal{O}}}$ After adjust, test the machine.







2. ENGINE STALL

* Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE




Wiring diagram




21096MS01

2) TEST PROCEDURE

- (1) Test 4 : Check electric current at EPPR valve.
 - ① Disconnect connector CN-75 from EPPR valve.
 - ② Insert the adapter to CN-75 and install multimeter as figure.
 - ③ Start engine.
 - ④ Set S-mode and cancel auto decel mode.
 - 5 Position the accel dial at 10.
 - $^{(6)}$ If rpm show approx 1750 \pm 50 rpm disconnect one wire harness from EPPR valve.
 - ⑦ Check electric current at bucket circuit relief position.
- (2) Test 5 : Check pressure at EPPR valve.
- ① Remove plug and connect pressure gauge as figure.
 - Gauge capacity : 0 to 50 kgf/cm² (0 to 725 psi)
- ② Start engine.
- ③ Set S-mode and cancel auto decel mode.
- 4 Position the accel dial at 10.
- ⑤ If rpm show approx 1750±50 rpm check pressure at relief position of bucket circuit by operating bucket control lever.
- ⑥ If pressure is not correct, adjust it.
- $\ensuremath{\overline{\mathcal{O}}}$ After adjust, test the machine.







3. MALFUNCTION OF CLUSTER OR MODE SELECTION SYSTEM

* Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram





21096MS03

4. MALFUNCTION OF ACCEL DIAL

* Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE






21096MS04

2) TEST PROCEDURE


- (1) Test 6 : Check voltage at CN-52(21) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (21) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




5. AUTO DECEL SYSTEM DOES NOT WORK

- Fault code : HCESPN 105, FMI 0~4 (work pressure sensor) HCESPN 108, FMI 0~4 (travel oil pressure sensor)
- * Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE




Wiring diagram



21096MS05

2) TEST PROCEDURE


- (1) Test 7 : Check voltage at CN-52(26) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (26) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.
- (2) Test 8 : Check voltage at CN-52(35) and ground.
- Prepare 1 piece of thin sharp pin, steel or copper
- ② Insert prepared pin to rear side of connectors : One pin to (35) of CN-52.
- ③ Starting key ON.
- ④ Check voltage as figure.




6. MALFUNCTION OF PUMP 1 PRESSURE SENSOR

- · Fault code : HCESPN 120, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 9 : Check voltage at CN-52(29) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (29) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




7. MALFUNCTION OF PUMP 2 PRESSURE SENSOR

- · Fault code : HCESPN 121, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 10 : Check voltage at CN-52(38) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (38) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




8. MALFUNCTION OF PUMP 3 PRESSURE SENSOR

- · Fault code : HCESPN 125, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 11 : Check voltage at CN-52(36) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (36) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




9. MALFUNCTION OF NEGATIVE 1 PRESSURE SENSOR

- · Fault code : HCESPN 123, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 12 : Check voltage at CN-52(37) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (37) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




10. MALFUNCTION OF NEGATIVE 2 PRESSURE SENSOR

- · Fault code : HCESPN 124, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 13 : Check voltage at CN-52(27) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (27) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




11. MALFUNCTION OF SWING PRESSURE SENSOR

- · Fault code : HCESPN 135, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 14 : Check voltage at CN-52(24) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (24) of CN-52.
- 3 Starting key ON.
- 4 Check voltage as figure.




12. MALFUNCTION OF ARM IN/OUT & BUCKET IN PRESSURE SENSOR

- · Fault code : HCESPN 133, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 15 : Check voltage at CN-52(25) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (25) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




13. MALFUNCTION OF BOOM UP PRESSURE SENSOR

- · Fault code : HCESPN 127, FMI 0~4
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE



Wiring diagram




- (1) Test 16 : Check voltage at CN-52(23) and ground.
- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Insert prepared pin to rear side of connectors : One pin to (23) of CN-52.
- ③ Starting key ON.
- 4 Check voltage as figure.




14. MALFUNCTION OF POWER MAX

- · Fault code : HCESPN 166, FMI 4 or 6
- * Before carrying out below procedure, check all the related connectors are properly inserted.


1) INSPECTION PROCEDURE




Wiring diagram



- (1) Test 17: Check voltage between connector CN-88(2) - GND.
- Disconnect connector CN-88 from power max solenoid valve.
- ② Start key ON.
- ③ Check voltage as figure.




- (2) Test 18: Check resistance of the solenoid valve between CN-88(1)-(2).
- 1 Starting key OFF.
- ② Disconnect connector CN-88 from power max solenoid valve.
- $\ensuremath{\textcircled{}}$ $\ensuremath{\textcircled{}}$ \ensuremath{\textcircled{}} $\ensuremath{\textcircled{}}$ $\ensuremath{\textcircled{}}$ $\ensuremath{\textcircled{}}$ $\ensuremath{\textcircled{}}$ $\ensuremath{\textcircled{}}$ \ensuremath{\textcircled{}} $\ensuremath{\textcircled{}}$ $\ensuremath{\$




15. MALFUNCTION OF BOOM PRIORITY EPPR VALVE

- · Fault code : HCESPN 141, FMI 5 or 6
- * Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram



Group	1	Operational Performance Test	7-1
Group	2	Major Components	7-21
Group	3	Track and Work Equipment	7-29

SECTION 7 MAINTENANCE STANDARD

GROUP 1 OPERATIONAL PERFORMANCE TEST

1. PURPOSE

Performance tests are used to check:

1) OPERATIONAL PERFORMANCE OF A NEW MACHINE

Whenever a new machine is delivered in parts and reassembled at a customer's site, it must be tested to confirm that the operational performance of the machine meets Hyundai spec.


2) OPERATIONAL PERFORMANCE OF A WORKING MACHINE

With the passage of time, the machine's operational performance deteriorates, so that the machine needs to be serviced periodically to restore it to its original performance level.

Before servicing the machine, conduct performance tests to check the extent of deterioration, and to decide what kind of service needs to be done (by referring to the "Service Limits" in this manual).

3) OPERATIONAL PERFORMANCE OF A REPAIRED MACHINE


After the machine is repaired or serviced, it must be tested to confirm that its operational performance was restored by the repair and/or service work done.



2. TERMINOLOGY


1) STANDARD

Specifications applied to the brand-new machine, components and parts.



2) SERVICE LIMIT

The lowest acceptable performance level. When the performance level of the machine falls below this level, the machine must be removed from work and repaired. Necessary parts and components must be replaced.



3. OPERATION FOR PERFORMANCE TESTS

1) Observe the following rules in order to carry out performance tests accurately and safely.

(1) The machine

Repair any defects and damage found, such as oil or water leaks, loose bolts, cracks and so on, before starting to test.

(2) Test area


- ① Select a hard, flat surface.
- ② Secure enough space to allow the machine to run straight more than 20 m, and to make a full swing with the front attachment extended.
- ③ If required, rope off the test area and provide signboards to keep unauthorized personnel away.

(3) Precautions

- Before starting to test, agree upon the signals to be employed for communication among coworkers. Once the test is started, be sure to communicate with each other using these signals, and to follow them without fail.
- ② Operate the machine carefully and always give first priority to safety.
- ③ While testing, always take care to avoid accidents due to landslides or contact with high voltage power lines. Always confirm that there is sufficient space for full swings.
- ④ Avoid polluting the machine and the ground with leaking oil. Use oil pans to catch escaping oil. Pay special attention to this when removing hydraulic pipings.

(4) Make precise measurements

- Accurately calibrate test instruments in advance to obtain correct data.
- ② Carry out tests under the exact test conditions prescribed for each test item.
- ③ Repeat the same test and confirm that the test data obtained can be procured repeatedly. Use mean values of measurements if necessary.



2) ENGINE SPEED


- (1) Measure the engine speed at each power mode
- * The engine speed at each power mode must meet standard RPM; if not, all other operational performance data will be unreliable. It is essential to perform this test first.

(2) Preparation

- ① Warm up the machine, until the engine coolant temperature reaches 50° C or more, and the hydraulic oil is $50\pm 5^{\circ}$ C.
- ② Set the accel dial at 10 (max) position.
- ③ Select the P-mode switch.
- 4 Measure the engine RPM.

(3) Measurement

- ① Start the engine. The engine will run at start idle speed. Measure engine speed with a engine rpm display.
- ② Measure and record the engine speed at each mode (P, S, E).
- ③ Select the P-mode.
- ④ Lightly operate the bucket control lever a few times, then return the control lever to neutral; The engine will automatically enter the auto-idle speed after 4 seconds.
- ⑤ Measure and record the auto deceleration speed.



(4) Evaluation

The measured speeds should meet the following specifications.

Unit : rpm

			•····•
Model	Engine speed	Standard	Remarks
	Start idle	800±100	
	P mode	1700±50	
R380LC-9	S mode	1600±50	
R300LC-9	E mode	1500±50	
	Auto decel	1000±100	
	One touch decel	800±100	

Condition : Set the accel dial at 10 (max) position.

3) TRAVEL SPEED

(1) Measure the time required for the excavator to travel a 20 m test track.

(2) Preparation

- ① Adjust the tension of both tracks to be equal.
- ② Prepare a flat and solid test track 20 m in length, with extra length of 3 to 5 m on both ends for machine acceleration and deceleration.
- ^③ Hold the bucket 0.3 to 0.5 m above the ground with the arm and bucket rolled in.
- (4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- ① Measure both the low and high speeds of the machine.
- ② Before starting either the low or high speed tests, adjust the travel mode switch to the speed to be tested, then select the following switch positions.
- · Power mode switch : P mode
- ③ Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- ④ Measure the time required to travel 20 m.
- ⑤ After measuring the forward travel speed, turn the upperstructure 180° and measure the reverse travel speed.
- (6) Repeat steps (4) and (5) three times in each direction and calculate the average values.


(4) Evaluation


The average measured time should meet the following specifications.

Unit : Seconds / 20 m

21077MS05

Model	Travel speed	Standard	Maximum allowable	Remarks
	1 Speed	24±2.0	30	
R380LC-9	2 Speed	15.3±1.0	19.1	





4) TRACK REVOLUTION SPEED

(1) Measure the track revolution cycle time with the track raised off ground.

(2) Preparation

- Adjust the tension of both side tracks to be equal.
- ② On the track to be measured, mark one shoe with chalk.
- ③ Swing the upperstructure 90° and lower the bucket to raise the track off ground. Keep the boom-arm angle between 90 to 110° as shown. Place blocks under machine frame.
- (4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.


(3) Measurement

- ① Select the following switch positions.
- · Travel mode switch : 1 or 2 speed
- Power mode switch : P mode
- · Auto decel switch : OFF
- ② Operate the travel control lever of the raised track in full forward and reverse.
- ③ Rotate 1 turn, then measure time taken for next 3 revolutions.
- ④ Raise the other side of machine and repeat the procedure.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.

(4) Evaluation

The revolution cycle time of each track should meet the following specifications.

		l	Init : Seconds / 3 revolutions
Model	Travel speed	Standard	Maximum allowable
R380LC-9	1 Speed	39.6±2.0	49.5
n300LC-9	2 Speed	25.3±1.0	31.6



5) TRAVEL DEVIATION

(1) Measure the deviation by the tracks from a 20m straight line.

(2) Preparation

- ① Adjust the tension of both tracks to be equal.
- ② Provide a flat, solid test yard 20 m in length, with extra length of 3 to 5 m on both ends for machine acceleration and deceleration.
- ③ Hold the bucket 0.3 to 0.5 m above the ground with the arm and bucket rolled in.
- (4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement


- ① Measure the amount of mistracking at high and low travel speeds.
- ② Before beginning each test, select the following switch positions.
- · Power mode switch : P mode
- ③ Start traveling the machine in the acceleration zone with the travel levers at full stroke.
- ④ Measure the distance between a straight
 20m line and the track made by the machine. (dimension a)
- ⑤ After measuring the tracking in forward travel, turn the upperstructure 180° and measure that in reverse travel.
- ⑥ Repeat steps ④ and ⑤ three times and calculate the average values.

(4) Evaluation

Mistrack should be within the following specifications.

Unit : mm / 20 m

Model	Standard	Maximum allowable	Remarks
R380LC-9	200 below	250	



7-7

6) SWING SPEED

(1) Measure the time required to swing three complete turns.

(2) Preparation

- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- ③ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- (4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- ① Select the following switch positions.
- · Power mode switch : P mode
- ② Operate swing control lever fully.
- ③ Swing 1 turn and measure time taken to swing next 3 revolutions.
- ④ Repeat steps ② and ③ three time and calculate the average values.

(4) Evaluation

The time required for 3 swings should meet the following specifications.

290LC7MS03

Unit : Seconds / 3 revolutions

Model	Power mode switch	Standard	Maximum allowable
R380LC-9	P mode	19.4±2.0	24.3

7) SWING FUNCTION DRIFT CHECK

 Measure the swing drift on the bearing outer circumference when stopping after a 360° full speed swing.

(2) Preparation


- ① Check the lubrication of the swing gear and swing bearing.
- ② Place the machine on flat, solid ground with ample space for swinging. Do not conduct this test on slopes.
- ③ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin. The bucket must be empty.
- ④ Make two chalk marks: one on the swing bearing and one directly below it on the track frame.
- (5) Swing the upperstructure 360°.
- (6) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement


- ① Conduct this test in the P mode.
- 0 Select the following switch positions.
- · Power mode switch : P mode
- ③ Operate the swing control lever fully and return it to the neutral position when the mark on the upperstructure aligns with that on track frame after swinging 360°.
- ④ Measure the distance between the two marks.
- ⑤ Align the marks again, swing 360°, then test the opposite direction.
- 6 Repeat steps ④ and ⑤ three times each and calculate the average values.

(4) Evaluation

The measured drift angle should be within the following specifications.



21097MS07



Unit : Degree

Model	Power mode switch	Standard	Maximum allowable	Remarks
R380LC-9	P mode	90 below	112.5	

8) SWING BEARING PLAY

 Measure the swing bearing play using a dial gauge to check the wear of bearing races and balls.

(2) Preparation

- ① Check swing bearing mounting cap screws for loosening.
- ② Check the lubrication of the swing bearing. Confirm that bearing rotation is smooth and without noise.
- ③ Install a dial gauge on the track frame as shown, using a magnetic base.
- ④ Position the upperstructure so that the boom aligns with the tracks facing towards the front idlers.
- ⑤ Position the dial gauge so that its needle point comes into contact with the bottom face of the bearing outer race.
- 6 Bucket should be empty.

(3) Measurement

- With the arm rolled out and bucket rolled in, hold the bottom face of the bucket to the same height of the boom foot pin. Record the dial gauge reading (h1).
- ② Lower the bucket to the ground and use it to raise the front idler 50cm.

Record the dial gauge reading (h2).

 ③ Calculate bearing play(H) from this data (h1 and h2) as follows.
 H=h2-h1


(4) Evaluation

The measured drift should be within the following specifications.


Unit : mm


21077MS09

Model	Standard	Maximum allowable	Remarks
R380LC-9	0.5 ~ 1.5	3.0	



7-10(1)





9) HYDRAULIC CYLINDER CYCLE TIME

 Measure the cycle time of the boom, standard arm, and standard bucket cylinders.

(2) Preparation

① To measure the cycle time of the boom cylinders:

With the arm rolled out and the empty bucket rolled out, lower the bucket to the ground, as shown.

② To measure the cycle time of the arm cylinder.

With the empty bucket rolled in, position the arm so that it is vertical to the ground. Lower the boom until the bucket is 0.5 m above the ground.

③ To measure the cycle time of the bucket cylinder.

The empty bucket should be positioned at midstroke between roll-in and roll-out, so that the sideplate edges are vertical to the ground.

(4) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.


(3) Measurement


- ① Select the following switch positions.
- · Power mode switch : P mode
- ② To measure cylinder cycle times.
- Boom cylinders.


Measure the time it takes to raise the boom, and the time it takes to lower the boom. To do so, position the boom at one stroke end then move the control lever to the other stroke end as quickly as possible.


- Arm cylinder.

Measure the time it takes to roll in the arm, and the time it takes to roll out the arm. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.









-Bucket cylinders

Measure the time it takes to roll in the bucket, and the time it takes to roll out the bucket. To do so, position the bucket at one stroke end, then move the control lever to the other stroke end as quickly as possible.

-Repeat each measurement 3 times and calculate the average values.

(4) Evaluation

The average measured time should meet the following specifications.

				Unit . Seconds
Model	Function	Standard	Maximum allowable	Remarks
	Boom raise	4.0±0.4	4.8	
	Boom lower	2.8±0.4	3.6	
R380LC-9	Arm in	3.1±0.4	3.9	
NJOULU-9	Arm out	2.8±0.3	3.4	
	Bucket load	2.8±0.4	3.6	
	Bucket dump	2.9±0.3	3.5	

Unit : Seconds

10) DIG FUNCTION DRIFT CHECK

 Measure dig function drift, which can be caused by oil leakage in the control valve and boom, standard arm, and standard bucket cylinders, with the loaded bucket.
 When testing the dig function drift just after cylinder replacement, slowly operate each cylinder to its stroke end to purge air.

(2) Preparation

- Load bucket fully. Instead of loading the bucket, weight (W) of the following specification can be used.
 - \cdot W=M³×1.5

Where :


M³ = Bucket heaped capacity (m³)

1.5=Soil specific gravity

- ② Position the arm cylinder with the rod 20 to 30 mm extended from the fully retracted position.
- ③ Position the bucket cylinder with the rod 20 to 30 mm retracted from the fully extended position.
- ④ With the arm rolled out and bucket rolled in, hold the bucket so that the height of the bucket pin is the same as the boom foot pin.
- (5) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- 1 Stop the engine.
- ② Five minutes after the engine has been stopped, measure the changes in the positions of the boom, arm and bucket cylinders.
- ③ Repeat step ② three times and calculate the average values.
- (4) The measured drift should be within the following specifications.



21077MS11

Unit:mm/5min

Model	Drift to be measured	Standard	Maximum allowable	Remarks
	Boom cylinder	10 below	15	
R380LC-9	Arm cylinder	10 below	15	
	Bucket cylinder	40 below	50	

11) CONTROL LEVER OPERATING FORCE

 Use a spring scale to measure the maximum resistance of each control lever at the middle of the grip.

(2) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- 1 Start the engine.
- O Select the following switch positions.
- Power mode switch : P mode
- ③ Operate each boom, arm, bucket and swing lever at full stroke and measure the maximum operating force for each.
- ④ Lower the bucket to the ground to raise one track off the ground. Operate the travel lever at full stroke and measure the maximum operating force required. When finished, lower the track and then jack-up the other track.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.

(4) Evaluation

The measured operating force should be within the following specifications.

Unit : kgf

Model	Kind of lever	Standard	Maximum allowable	Remarks
	Boom lever	1.6 or below	2.0	
	Arm lever	1.6 or below	2.0	
R380LC-9	Bucket lever	1.3 or below	1.7	
	Swing lever	1.3 or below	1.7	
	Travel lever	2.1 or below	3.15	

12) CONTROL LEVER STROKE

- (1) Measure each lever stroke at the lever top using a ruler.
- When the lever has play, take a half of this value and add it to the measured stroke.

(2) Preparation

Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(3) Measurement

- 1 Stop the engine.
- ② Measure each lever stroke at the lever top from neutral to the stroke end using a ruler.
- ③ Repeat step ② three times and calculate the average values.

(4) Evaluation

The measured drift should be within the following specifications.

Unit : mm

Model	Kind of lever	Standard	Maximum allowable	Remarks
R380LC-9	Boom lever	101±10	125	
	Arm lever	101 ± 10	125	
	Bucket lever	90±10	115	
	Swing lever	90±10	115	
	Travel lever	142±10	178	


13) PILOT PRIMARY PRESSURE

(1) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- 1 Select the following switch positions.
- · Power mode switch : P mode
- · Auto decel switch : OFF
- ② Measure the primary pilot pressure by the monitoring menu of the cluster.



21097MS12

(3) Evaluation

The average measured pressure should meet the following specifications:

Unit : kgf / cm²

Model	Engine speed	Standard	Allowable limits	Remarks
R380LC-9	P mode	40±5	-	

14) FOR TRAVEL SPEED SELECTING PRESSURE

(1) Preparation

- ① Stop the engine.
- ② Remove the top cover of the hydraulic tank oil supply port with a wrench.
- ③ Push the pressure release button to bleed air.
- ④ To measure the speed selecting pressure: Install a connector and pressure gauge assembly to turning joint P port as shown.
- ⑤ Start the engine and check for on leakage from the adapter.
- (6) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement


① Select the following switch positions.Travel mode switch : 1 speed

2 speed

- · Power mode switch : P mode
- ⁽²⁾ Measure the travel speed selecting pressure in the Hi or Lo mode.
- ③ Lower the bucket to the ground to raise the track off the ground. Operate the travel lever at full stroke and measure the fast speed pressure.
- ④ Repeat steps ② and ③ three times and calculate the average values.

(3) Evaluation

The average measured pressure should be within the following specifications.



Unit: kgf/cm²

				<u> </u>
Model	Travel speed mode	Standard	Maximum allowable	Remarks
	1 Speed	0	-	
R380LC-9	2 Speed	40±5	-	

15) SWING PARKING BRAKE RELEASING PRESSURE

(1) Preparation

- 1 Stop the engine.
- ② Loosen the cap and relieve the pressure in the tank by pushing the top of the air breather.
- ③ Install a connector and pressure gauge assembly to swing motor SH port, as shown.
- ④ Start the engine and check for oil leakage from the adapter.
- (5) Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- ① Select the following switch positions.
- · Power mode switch: P mode
- ② Operate the swing function or arm roll in function and measure the swing brake control pressure with the brake disengaged. Release the control lever to return to neutral and measure the control pressure when the brake is applied.

Repeat step O three times and calculate the average values.


(3) Evaluation

The average measured pressure should be within the following specifications.

Unit: kgf/cm²

32097MS02

Model	Description	Standard	Allowable limits	Remarks
	Brake disengaged	40	31~49	
R380LC-9	Brake applied	0	-	




16) MAIN PUMP DELIVERY PRESSURE

(1) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- Select the following switch positions.
- Power mode switch : P mode
- ② Measure the main pump delivery pressure by the monitoring menu of the cluster.



(3) Evaluation

The average measured pressure should meet the following specifications.

Unit : kgf / cm²

Model	Engine speed	Standard	Allowable limits	Remarks
R380LC-9	High ilde	40±5	-	


17) SYSTEM PRESSURE REGULATOR RELIEF SETTING

(1) Preparation

① Keep the hydraulic oil temperature at $50\pm5^{\circ}$ C.

(2) Measurement

- 1 Select the following switch positions.
- $\cdot\,$ Power mode switch : P mode
- ② Slowly operate each control lever of boom, arm and bucket functions at full stroke over relief and measure the pressure.
- ③ In the swing function, place bucket against an immovable object and measure the relief pressure.
- ④ In the travel function, lock undercarriage with an immovable object and measure the relief pressure.



21097MS15

Unit: kgf/cm²

(3) Evaluation


The average measured pressure should be within the following specifications.

			0
Model	Function to be tested	Standard	Allowable allowable
	Boom, Arm, Bucket	330 (360)±10	370±10
R380LC-9	Travel	$360\!\pm\!10$	-
	Swing	290±10	-

(): Power boost

GROUP 2 MAJOR COMPONENT

1. MAIN PUMP



Part name &	inspection item	Standard dimension	Recommended replacement value	Counter measures
Clearance between piston(1) & cylinder bore(2) (D-d)		0.043	0.070	Replace piston or cylinder.
Play between piston(1) & shoe caulking section(3) $(\delta$)		0-0.1	0.3	Replace assembly of
Thickness of shoe (t)		5.4	5.0	piston & shoe.
Free height of cylinder spring(4) (L)		47.9	47.1	Replace cylinder spring.
Combined height of set plate(5) & spherical bushing(6) (H-h)	H	23.8	22.8	Replace retainer or set plate.
Surface roughness for valve plate (sliding face)	Surface roughness necessary to be corrected	:	3z	
(7,8), swash plate (shoe plate area) (9), & cylinder(2) (sliding face)	Standard surface roughness (corrected value)	0.4z or lower		Lapping

2. MAIN CONTROL VALVE

Part name	Inspection item	Criteria & measure
Casing	Existence of scratches, rust or corrosion.	In case of damage in following section, replace casing.
		 Sliding sections of casing hole and spool, especially land sections applied with held pressure. Seal pocket section where spool is inserted. Sealing section of port where O-ring contacts. Sealing section of each relief valve for main and port. Sealing section of plug. Other damages that may damage normal function.
Spool	Existence of scratch, gnawing, rusting or corrosion.	 Replacement when its outside sliding section has scratch (especially on seals- contacting section).
	\cdot O-ring seal sections at both ends.	 Replacement when its sliding section has scratch.
	Insert spool into casing hole, rotate and reciprocate it.	 Correction or replacement when O-ring is damaged or when spool does not move smoothly.
Poppet	Damage of spring	· Replacement.
	Damage of poppet	Correction or replacement when sealing is incomplete.
	 Insert poppet into casing and function it. 	Normal when it can function lightly and smoothly without sticking.
Spring and related parts	Rusting, corrosion, deformation or breakage of spring, spring seat, plug or cover.	Replacement for significant damage.
Around seal	External oil leakage.	Correction or replacement.
for spool	Rusting, corrosion or deformation of seal plate.	Correction or replacement.
Main relief valve,	External rusting or damage.	· Replacement.
port relief valve & control relief valve	· Contacting face of valve seat.	· Replacement when damaged.
	Contacting face of poppet.	· Replacement when damaged.
	\cdot O-rings and back up rings.	Replacement in principle.

3. SWING DEVICE

1) WEARING PARTS

Inspection item	Standard dimension	Recommended replacement value	Counter measures
Clearance between piston and cylinder block bore	0.028	0.058	Replace piston or cylinder block
Play between piston and shoe caulking section (δ)	0	0.3	Replace assembly of piston and shoe
Thickness of shoe (t)	5.5	5.3	Replace assembly of piston and shoe
Combined height of retainer plate and spherical bushing (H-h)	6.5	6.0	Replace set of retainer plate and sperical bushing
Thickness of friction plate	4.0	3.6	Replace
			H H

2) SLIDING PARTS

Part name	Standard roughness	Allowable roughness	Remark
Shoe	0.8-Z (Ra=0.2) (LAPPING)	3-Z (Ra=0.8)	
Shoe plate	0.4-Z (Ra=0.1) (LAPPING)	3-Z (Ra=0.8)	
Cylinder	1.6-Z (Ra=0.4) (LAPPING)	12.5-Z (Ra=3.2)	
Valve plate	0.8-Z (Ra=0.2) (LAPPING)	6.3-Z (Ra=1.6)	


4. TRAVEL MOTOR

Replace parts in accordance with the following standards. However, if a part is damaged significantly in terms of its appearance, replace it irrespective of the standards.


1) HYDRAULIC MOTOR

Part name & inspection item	Standard dimension	Recommended value for replacement	Remedy
Clearance between piston & cylinder bore (D-d)	0.052 mm	0.077 mm	Replacement
Clearance caulked part between piston and shoe (δ)	0.1 mm	0.3 mm	Replacement
Thickness of shoe	5.5 mm	5.3 mm	Replacement
Assembled height of spherical bush and set plate (H-h)	23.8 mm	23.3 mm	Replacement as a set
Free length of cylinder spring	40.9 mm	40.3 mm	Replacement
Shaft over pin dia. Output spline Cylinder spline	43.91 (ø5) 49.06 (ø5)	43.31 mm 48.46 mm	Replacement if either one reaches replacement value.
Spline over dia. Spline in cylinder Spline in spherical bushing	35.25 (Ø5)	35.75 mm	Replacement
Thickness of separation plate Thickness of friction plate	1.5 mm 3.9 mm	1.3 mm 3.7 mm	Replacement
Free length of brake spring	42.4 mm	41.4 mm	Replacement
Displacement over teeth Over pin dia. of friction plate internal teeth	50.02 (7teeth) 152.97 (Ø5)	49.42 mm 153.57 mm	Replacement Replacement
Roughness of sliding surfaces Swash plate/shoe Cylinder block/valve plate	0.4 - z 0.4 - z	3 - z 3 - z	Each independent lapping Mutual lapping
Roller bearing Needle bearing	-	-	Replacement if flaking is found on rolling surface.
O-ring Oil seal	-	-	Replacement at every disassembly, in principle.


Part name & inspection item	Standard dimension	Recommended value for replacement	Remedy
Bolt	-	-	Replacement if elongation is found.




clearance between piston and cylinder bore : D-d



Thickness of shoe : t



Play at caulking between piston and shoe : δ



Assembled height of set plate and spherical bushing : H-h

2) REDUCTION GEAR

Part name	& inspection item	Standard dimension	Recommended value for replacement	Remedy	
Pitting or crack of gear		-	Pitting area rate : 10%	Replacement pitting or crack is found	
Motor driving gea	r external	Overpin 43.91 (ø5)	43.31 mm	(Z=14)	
No. 1 sun gar inte	rnal spline	Overpin 30.25 (ø 5)	30.85 mm	Replacement (Z=14)	
Reduction ratio	No. 1 sun gear	Displacement 42.22 (4teeth)	41.92 mm	Do. (Z=23)	
i = 70.145	'0.145Displacement 43.98 (4teeth)43.68 mm	Do. (Z=26)			
No. 1 carrier inter	nal spline	Overpin 81.562 (Ø 5)	82.162 mm	Do. (Z=23)	
No. 2 sun gear		Displacement 31.40 (3teeth)	31.10 mm	Do. (Z=23)	
No. 2 planetary ge	ear	Displacement 43.67 (4teeth)	43.37 mm	Do. (Z=26)	
No. 2 carrier inter	nal spline	Overpin 112.24 (ø10)	112.84 mm	Do. (Z=25)	
No. 3 sun gear		Displacement 54.92 (4teeth)	54.62 mm	Do. (Z=25)	
No. 3 planetary gear		Displacement 54.93 (3teeth)	54.63 mm	Do. (Z=22)	
Ring gear (3rd sta	ages)	Overpin 348.74 (ø 8.5)	349.34 mm	Do. (Z=71)	
Crack and flaking of bearing inner/outer races and rollers		-	-	Replacement if crack or flaking is found.	
Crack and flaking planetary gears a		-	-	Replacement if crack or flaking is found.	

Part name & inspection item	Standard dimension	Recommended value for replacement	Remedy
Radial clearance of needle bearing	0.01-0.04 mm	0.07 mm	Replacement of abnormal parts as a set.
Crack of spline contact part	-	-	Replacement if such damage as crack, crevice of chipping is found.
Backlash of spline contact part	0.1-0.3 mm	0.5 mm	Dimension check and replacement according to following standards.
Thrust ring (026)	7 mm thick	6.6 mm	Replacement if severe wear or
Thrust ring (027)	8 mm thick	7.6 mm	seizure is found on sliding surface.
Floating seal	-	-	Replacement of scratch or rust is found in sliding surface. Replacement if O-ring is deformed of damaged.
Gear oil	SAE 85W-140 (API GL-5)	-	1st time : 500hr 2nd time and later : Every 2000hr After disassembling, fill with new oil without fail. The above times are measured with engine hour meter.

5. RCV LEVER

Maintenance check item	Criteria	Remark
Leakage	The valve is to be replaced when the leakage becomes more than 1000 cc/m at neutral handle position, or more than 2000 cc/m during operation.	Conditions : Primary pressure : 40 kgf/cm ² Oil viscosity : 23 cSt
Spool	This is to be replaced when the sliding surface has worn more than 10 μ m, compared with the non-sliding surface.	The leakage at the left condition is estimated to be nearly equal to the above leakage.
Push rod		
	This is to be replaced when the top end has worn more than 1 mm.	
Play at operating section	The pin, shaft, and joint of the operating section are to be replaced when their plays become more than 2 mm due to wears or so on.	When a play is due to looseness of a tightened section, adjust it.
Operation stability	When abnormal noises, hunting, primary pressure drop, etc. are generated during operation, and these cannot be remedied, referring to section 6. Troubleshooting, replace the related parts.	

Notes 1. It is desirable to replace seal materials, such as O-rings, every disassembling. However, they may be reused, after being confirmed to be free of damage.

6. RCV PEDAL

Maintenance check item	Criteria	Remark
Leakage	The valve is to be replaced when the leakage effect to the system. For example, the primary pressure drop.	Conditions : Primary pressure : 40 kgf/cm ² Oil viscosity : 23 cSt
Spool	This is to be replaced when the sliding surface has worn more than 10μ m, compared with the non-sliding surface.	The leakage at the left condition is estimated to be nearly equal to the above leakage.
Push rod	<u>1 mm</u>	
	This is to be replaced when the top end has worn more than 1 mm.	
Play at operating section	The pin, shaft, and joint of the operating section are to be replaced when their plays become more than 2 mm due to wears or so on.	When a play is due to looseness of a tightened section, adjust it.
Operation stability	When abnormal noises, hunting, primary pressure drop, etc. are generated during operation, and these cannot be remedied, referring to section 6. Troubleshooting, replace the related parts.	

Notes 1. It is desirable to replace seal materials, such as O-rings, every disassembling. However, they may be reused, after being confirmed to be free of damage.

7. TURNING JOINT


F	Part name	Maintenance standards	Remedy
	Sliding surface with sealing sections.	Plating worn or peeled due to seizure or contamination.	Replace
	Sliding surface between body and	 Worn abnormality or damaged more than 0.1 mm (0.0039 in) in depth due to seizure contamination. 	Replace
Body, Stem	stem other than sealing section.	Damaged more than 0.1 mm (0.0039 in) in depth.	Smooth with oilstone.
Otem	Sliding surface	• Worn more than 0.5 mm (0.02 in) or abnormality.	Replace
	with thrust plate.	• Worn less than 0.5 mm (0.02 in).	Smooth
		Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).	Smooth
	Sliding surface	• Worn more than 0.5 mm (0.02 in) or abnormality.	Replace
Cover	with thrust plate.	• Worn less than 0.5 mm (0.02 in).	Smooth
		Damage due to seizure or contamination remediable within wear limit (0.5 mm) (0.02 in).	Replace
		Extruded excessively from seal groove square ring.	Replace
	-	Square ring	
		Slipper ring 1.5 mm (0.059 in) narrower than seal groove, or narrower than back ring.	Replace
Seal set	-	1.5mm (max.) (0.059 in)	
		• Worn more than 0.5 mm (0.02 in) ~ 1.5 mm (MAX.) (0.059 in)	Replace
	-		

8. CYLINDER

Part name	Inspecting section	Inspection item	Remedy	
Piston rod	Neck of rod pin	Presence of crack	· Replace	
	• Weld on rod hub	Presence of crack	· Replace	
	Stepped part to which piston is attached.	Presence of crack	· Replace	
	· Threads	Presence of crack	Recondition or replace	
		Plating is not worn off to base metal.	Replace or replate	
	Plated surface	\cdot Rust is not present on plating.	Replace or replate	
		 Scratches are not present. 	\cdot Recondition, replate or replace	
	· Rod	· Wear of O.D.	\cdot Recondition, replate or replace	
	Bushing at mounting part	• Wear of I.D.	· Replace	
Cylinder tube	Weld on bottom	Presence of crack	· Replace	
	\cdot Weld on head	Presence of crack	· Replace	
	• Weld on hub	Presence of crack	· Replace	
	Tube interior	Presence of faults	\cdot Replace if oil leak is seen	
	Bushing at mounting part	\cdot Wear on inner surface	· Replace	
Gland	Bushing	Flaw on inner surface	Replace if flaw is deeper than coating	

1. TRACK

1) TRACK ROLLER




21037MS01

U	nit	÷	mm

No.	Check item		Criteria				
4	Outside diameter of flange	Standa	Standard size		Repair limit		
	Outside diameter of flange	øź	250	-	-		
2	Outside diameter of tread	øź	200	Ø	ø 188		
3	Width of tread	54	54.6		60.6		
4	Width of flange	34.4		-			
		Standard size & tolerance		Standard	Clearance		
5	Clearance between shaft	Shaft	Hole	clearance	limit	Replace	
	and bushin	ø 85 -0.25 -0.35	ø 85 +0.176 +0.029	0.279 to 0.526	2.0	bushing	
6	Side clearance of roller Standard clearance		Clearar	Clearance limit			
0	(Both side)	0.12~1.3		2	2.0		


2) CARRIER ROLLER



21037MS02

No.	Check item		Criteria				
-	Outside dispectar of flores	Standa	ard size	Repair limit			
	Outside diameter of flange	ø 200		-		-	
2	Outside diameter of tread	ø 191		ø 181		Rebuild or replace	
3	Width of tread	51		56			
4	Width of flange	20		-			
			e & tolerance	Standard	Clearance		
5	Clearance between shaft	Shaft	Hole	clearance	limit	Replace	
	and support	ø 57.15 0 -0.1	ø 57.15 +0.3 +0.1	0.1 to 0.4	1.2	bushing	


Unit : mm



21037MS03

Unit:mm

No.	Check item		Criteria			
1	Outside disperator of protection	Standa	ard size	Repai	Repair limit	
	Outside diameter of protrusion	Ø	646	-	-	
2	Outside diameter of tread	ø	594	ø 5	580	Rebuild or replace
3	Width of protrusion	1(02	-	-	ropiaco
4	Total width	20	03	-		
5	Width of tread	50.5		57.5		
		Standard siz	e & tolerance	Standard	Clearance	
6	Clearance between shaft	Shaft	Hole	clearance	limit	Replace
	and support Ø 85 0 -0.035		ø 85.35 +0.05 0	0.35 to 0.435	2.0	bushing
7	Clearance between shaft and support	ø 85 0 -0.035	ø 85 +0.09 +0.036	0.036 to 0.125	1.2	Replace
8	Side clearance of idler	learance of idler Standard of		clearance Clearance limit		Bonlaco
0	(Both side)	0.25 to 1.2		2.0		Replace





21037MS04

Unit : mm

No.	Check item	Crit	Remedy	
4	Link nitch	Standard size Repair limit		Turn or
'	Link pitch	215.9	220.9	replace
2	Outside diameter of bushing	ø 71	ø 60.4	
3	Height of grouser	36	21	Rebuild or replace
4	Height of link	129	115	
5	Tightening torque	Initial tightening torque : 140 \pm	Retighten	

5) TRACK FRAME AND RECOIL SPRING






21037MS05

11	nıt	٠	mm
U	'I III.		111111

No.	Check item		Criteria						
			Standar	d size	Tole	erance	Repair limit		
1 Vertica	Vertical width of idler guide	Track fram	e 123	3	+2 -1		127		
		Idler suppo	rt 120)		0 1.5	116	Rebuild or replace	
2	2 Horizontal width of idler guide		e 292	2		+2 -1	296		
		Idler suppo	rt 290)		-	287		
		Standard size		Repair limit					
3	Recoil spring	Free length	Installation length	Installa Ioad		Free lengt	h Installation load	Replace	
		ø 254 × 740	595	24500) kg	-	19600 kg		

1. WORK EQUIPMENT



21077MS20

			P	Pin		Bushing	
Mark	Measuring point (Pin and Bushing)	Normal value	Recomm. service limit	Limit of use	Recomm. service limit	Limit of use	Remedy & Remark
Α	Boom Rear	120	119	118.5	120.5	121	Replacement
В	Boom Cylinder Head	100	99	98.5	100.5	101	"
С	Boom Cylinder Rod	110	109	108.5	110.5	111	"
D	Arm Cylinder Head	110	109	108.5	110.5	111	"
E	Boom Front	110	109	108.5	110.5	111	"
F	Arm Cylinder Rod	110	109	108.5	110.5	111	"
G	Bucket Cylinder Head	90	89	88.5	90.5	91	"
н	Arm Link	90	89	88.5	90.5	91	"
1	Bucket and Arm Link	100	99	98.5	100.5	101	"
J	Bucket Cylinder Rod	90	89	88.5	90.5	91	"
К	Bucket Link	100	99	98.5	100.5	101	"

Unit:mm

SECTION 8 DISASSEMBLY AND ASSEMBLY


Group	1	Precaution	8-1
Group	2	Tightening Torque	8-4
Group	3	Pump Device	8-7
Group	4	Main Control Valve	8-31
Group	5	Swing Device	8-51
Group	6	Travel Device	8-71
Group	7	RCV Lever ·····	8-103
Group	8	Turning Joint	8-117
Group	9	Boom, Arm and Bucket Cylinder	8-122
Group	10	Undercarriage	8-139
Group	11	Work Equipment	8-151

GROUP 1 PRECAUTIONS

1. REMOVAL WORK

- 1) Lower the work equipment completely to the ground. If the coolant contains antifreeze, dispose of it correctly.
- 2) After disconnecting hoses or tubes, cover them or fit blind plugs to prevent dirt or dust from entering.
- 3) When draining oil, prepare a container of adequate size to catch the oil.
- 4) Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake when assembling.
- 5) To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors.
- 6) Fit wires and hoses with tags to show their installation position to prevent any mistake when installing.
- 7) Check the number and thickness of the shims, and keep in a safe place.
- 8) When raising components, be sure to use lifting equipment of ample strength.
- 9) When using forcing screws to remove any components, tighten the forcing screws alternately.
- 10) Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.
- 11) When removing hydraulic equipment, first release the remaining pressure inside the hydraulic tank and the hydraulic piping.
- 12) If the part is not under hydraulic pressure, the following corks can be used.

Nominal	Dimensions				
number	D	d	L		
06	6	5	8		
08	8	6.5	11		
10	10	8.5	12		
12	12	10	15		
14	14	11.5	18		
16	16	13.5	20		
18	18	15	22		
20	20	17	25		
22	22	18.5	28		
24	24	20	30		
27	27	22.5	34		



2. INSTALL WORK

- 1) Tighten all bolts and nuts(Sleeve nuts) to the specified torque.
- 2) Install the hoses without twisting or interference.
- 3) Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
- 4) Bend the cotter pin or lock plate securely.
- 5) When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2-3 drops of adhesive.
- 6) When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
- 7) Clean all parts, and correct any damage, dents, burrs, or rust.
- 8) Coat rotating parts and sliding parts with engine oil.
- 9) When press fitting parts, coat the surface with antifriction compound(LM-P).
- 10) After installing snap rings, check that the snap ring is fitted securely in the ring groove(Check that the snap ring moves in the direction of rotation).
- 11) When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
- 12) When using eyebolts, check that there is no deformation or deterioration, and screw them in fully.
- 13) When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- 14) When operating the hydraulic cylinders for the first time after repairing and reassembling the hydraulic cylinders, pumps, or other hydraulic equipment or piping, always bleed the air from the hydraulic cylinders as follows:
 - (1) Start the engine and run at low idling.
 - (2) Operate the control lever and actuate the hydraulic cylinder 4-5 times, stopping 100mm before the end of the stroke.
 - (3) Next, operate the piston rod to the end of its stroke to relieve the circuit. (The air bleed valve is actuated to bleed the air.)
 - (4) After completing this operation, raise the engine speed to the normal operating condition.
 - * If the hydraulic cylinder has been replaced, carry out this procedure before assembling the rod to the work equipment.
 - * Carry out the same operation on machines that have been in storage for a long time after completion of repairs.

3. COMPLETING WORK

- 1) If the coolant has been drained, tighten the drain valve, and add water to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
- 2) If the hydraulic equipment has been removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- 3) If the piping or hydraulic equipment, such as hydraulic cylinders, pumps, or motors, have been removed for repair, always bleed the air from the system after reassembling the parts.
- 4) Add the specified amount of grease (molybdenum disulphied grease) to the work equipment related parts.

GROUP 2 TIGHTENING TORQUE

1. MAJOR COMPONENTS

No.		Descriptions		Tor	que
INO.		Descriptions	Bolt size	kgf∙m	lbf ∙ ft
1		Engine mounting bolt, nut	$M24 \times 3.0$	90 ± 7.0	651 ± 51
2	Francisco	Radiator mounting bolt	M16 × 2.0	22 ± 1.0	159 ± 7.2
3	Engine	Coupling mounting socket bolt	$M20 \times 2.5$	46.5 ± 2.5	336 ± 18.1
4		Main pump housing mounting bolt	M10 × 1.5	2.81 ± 0.3	20.3 ± 2.2
5		Main pump mounting socket bolt	$M20 \times 2.5$	42 ± 4.5	304 ± 32.5
6		Main control valve mounting bolt	M16 × 2.0	29.7 ± 4.5	215 ± 32.5
7	Hydraulic system	Fuel tank mounting bolt	$M20 \times 2.5$	46 ± 5.0	333 ± 36
8	oyotom	Hydraulic oil tank mounting bolt	$M20 \times 2.5$	46 ± 5.0	333 ± 36
9		Turning joint mounting bolt, nut	M12 × 1.75	12.3 ± 1.3	88.9 ± 9.4
10		Swing motor mounting bolt	M24 $ imes$ 3.0	97.8 ± 15	707 ± 108
11	Power	Swing bearing upper part mounting bolt	$M24 \times 3.0$	97.8 ± 10	707 ± 72.3
12	train	Swing bearing lower part mounting bolt	$M24 \times 3.0$	97.8 ± 10	707 ± 72.3
13	system	Travel motor mounting bolt	M20 × 2.5	43.8 ± 4.0	317 ± 29
14		Sprocket mounting bolt	$M20 \times 2.5$	57 ± 3.0	412 ± 21.7
15		Carrier roller mounting bolt, nut	M16 × 2.0	29.7 ± 4.0	215 ± 28.9
16		Track roller mounting bolt	$M22 \times 2.5$	77.4 ± 11	560 ± 79.6
17	Under carriage	Track tension cylinder mounting bolt	M16 × 2.0	29.6 ± 3.2	214 ± 23.1
18		Track shoe mounting bolt, nut	M24 × 1.5	140 ± 5.0	1010 ± 36.2
19		Track guard mounting bolt	M24 × 3.0	77.4 ± 11	560 ± 79.6
20		Counterweight mounting bolt	M36 × 3.0	337 ± 33	2440 ± 72.3
21	Others	Cab mounting bolt	M12 × 1.75	12.8 ± 3.0	92.6 ± 21.7
22		Operator's seat mounting bolt	M 8 × 1.25	4.05 ± 0.8	29.3 ± 5.8

* For tightening torque of engine and hydraulic components, see each component disassembly and assembly.

2. TORQUE CHART

Use following table for unspecified torque.

1) BOLT AND NUT

(1) Coarse thread

Bolt size	8	3T	10T		
DOIL SIZE	kg∙m	lb ∙ ft	kg∙m	lb ⋅ ft	
M 6×1.0	0.85 ~ 1.25	6.15 ~ 9.04	1.14 ~ 1.74	8.2 ~ 12.6	
M 8×1.25	2.0 ~ 3.0	14.5 ~ 21.7	2.73 ~ 4.12	19.7 ~ 29.8	
M10 × 1.5	4.0 ~ 6.0	28.9 ~ 43.4	5.5 ~ 8.3	39.8 ~ 60	
M12 × 1.75	7.4 ~ 11.2	53.5 ~ 79.5	9.8 ~ 15.8	71 ~ 114	
M14 × 2.0	12.2 ~ 16.6	88.2 ~ 120	16.7 ~ 22.5	121 ~ 167	
M16 × 2.0	18.6 ~ 25.2	135 ~ 182	25.2 ~ 34.2	182 ~ 247	
M18 × 2.5	25.8 ~ 35.0	187 ~ 253	35.1 ~ 47.5	254 ~ 343	
M20 × 2.5	36.2 ~ 49.0	262 ~ 354	49.2 ~ 66.6	356 ~ 482	
M22 × 2.5	48.3 ~ 63.3	350 ~ 457	65.8 ~ 98.0	476 ~ 709	
M24 × 3.0	62.5 ~ 84.5	452 ~ 611	85.0 ~ 115	615 ~ 832	
M30 × 3.5	124 ~ 168	898 ~ 1214	169 ~ 229	1223 ~ 1655	
M36 × 4.0	174 ~ 236	1261 ~ 1703	250 ~ 310	1808 ~ 2242	

(2) Fine thread

Bolt size	8	3T	1	ОТ
Boit Size	kg∙m	lb • ft	kg∙m	lb∙ft
M 8×1.0	2.17 ~ 3.37	15.7 ~ 24.3	3.04 ~ 4.44	22.0 ~ 32.0
M10 × 1.25	4.46 ~ 6.66	32.3 ~ 48.2	5.93 ~ 8.93	42.9 ~ 64.6
M12 × 1.25	7.78 ~ 11.58	76.3 ~ 83.7	10.6 ~ 16.0	76.6 ~ 115
M14 × 1.5	13.3 ~ 18.1	96.2 ~ 130	17.9 ~ 24.1	130 ~ 174
M16 × 1.5	19.9 ~ 26.9	144 ~ 194	26.6 ~ 36.0	193 ~ 260
M18 × 1.5	28.6 ~ 43.6	207 ~ 315	38.4 ~ 52.0	278 ~ 376
M20 × 1.5	40.0 ~ 54.0	289 ~ 390	53.4 ~ 72.2	386 ~ 522
M22 × 1.5	52.7 ~ 71.3	381 ~ 515	70.7 ~ 95.7	512 ~ 692
M24 × 2.0	67.9 ~ 91.9	491 ~ 664	90.9 ~ 123	658 ~ 890
M30 × 2.0	137 ~ 185	990 ~ 1338	182 ~ 248	1314 ~ 1795
M36 × 3.0	192 ~ 260	1389 ~ 1879	262 ~ 354	1893 ~ 2561
M36 × 4.0	174 ~ 236	1261 ~ 1704	250 ~ 310	1808 ~ 2242

2) PIPE AND HOSE (FLARE TYPE)

Thread size (PF)	Width across flat (mm)	kgf⋅m	lbf·ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130.2
1"	41	21	151.9
1-1/4"	50	35	253.2

3) PIPE AND HOSE (ORFS TYPE)

Thread size (UNF)	Width across flat (mm)	kgf⋅m	lbf∙ft
9/16-18	19	4	28.9
11/16-16	22	5	36.2
13/16-16	27	9.5	68.7
1-3/16-12	36	18	130.2
1-7/16-12	41	21	151.9
1-11/16-12	50	35	253.2

4) FITTING

Thread size	Width across flat(mm)	kgf⋅m	lbf∙ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130.2
1"	41	21	151.9
1-1/4"	50	35	253.2

GROUP 3 PUMP DEVICE


1. REMOVAL AND INSTALL


1) REMOVAL


- Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- A Escaping fluid under pressure can penetrate the skin causing serious injury.
- (4) Loosen the drain plug under the hydraulic tank and drain the oil from the hydraulic tank.


 \cdot Hydraulic tank quantity : 230 ℓ

- (5) Remove socket bolts (5) and disconnect pipes (1, 2).
- (6) Disconnect pilot line hoses (6, 7, 8, 9, 10, 11, 12, 13).
- (7) Remove socket bolts (4) and disconnect pump suction tube (3).
- When pump suction tube is disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (8) Sling the pump assembly and remove the pump mounting bolts.Weight : 190 kg (420 lb)
- Pull out the pump assembly from housing. When removing the pump assembly, check that all the hoses have been disconnected.










2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Remove the suction strainer and clean it.
- (3) Replace return filter with new one.
- (4) Remove breather and clean it.
- (5) After adding oil to the hydraulic tank to the specified level.
- (6) Bleed the air from the hydraulic pump.
- 1 Remove the air vent plug (2EA).
- ② Tighten plug lightly.
- ③ Start the engine, run at low idling, and check oil come out from plug.
- ④ Tighten plug.
- (7) Start the engine, run at low idling (3~5 minutes) to circulate the oil through the system.
- (8) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2. MAIN PUMP (1/2)

1) STRUCTURE



36072MP02

04 Gear pump 111 Drive shaft (F) 113 Drive shaft (R) 114 Spline coupling 123 Roller bearing 124 Needle bearing 127 Bearing spacer 130 Booster 012 Cylinder block 151 Piston 152 Shoe 153 Set plate 156 Bushing 157 Cylinder spring 211 Shoe plate 212 Swash plate 214 Bushing

251 Support plate

261 Seal cover (F)

- 271 Pump casing 311 Valve cove r(F) 312 Valve cover (R) 313 Valve plate (R) 314 Valve plate (L) 401 Hexagon socket bolt 402 Hexagon socket bolt 406 Hexagon socket bolt 466 VP Plug 468 VP Plug 490 Plug 492 Plug 531 Tilting pin 532 Servo piston 534 Stopper (L) 535 Stopper (S) 548 Feedback pin 702 O-ring
- 702 O-ring 706 O-ring

719 O-ring 724 O-ring 725 O-ring 728 O-ring 732 O-ring 774 Oil seal 789 Back up ring 792 Back up ring Hexagon head nut 808 824 Snap ring 885 Pin 886 Spring pin 901 Eye bolt 953 Set screw 954 Adjust screw

710 O-ring

717 O-ring

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.


Tool name & size	Part name							
Allen wrench	В	Hexagon socket head bolt (PT plug T thread)	PO plug (PF thread)		Hexagon socket head setscrew	
	4	M 5	E	3P-1/16	-		M 8	
	5	M 6		BP1/8	-		M10	
B 	6	M 8		BP-1/4	PO-1/4	ŀ	M12, M14	
	8	M10		BP-3/ 8	PO-3/8	3	M16, M18	
	17	M20, M22		BP-1	PO-1, 1 1/4,	1 1/2	-	
Double ring spanner, socket wrench, double (single)	-	Hexagon head bolt		Hexagon head bolt		VP plug (PF thread)		
open end spanner	19	M12		M12		VP-1/4		
	24	M16	M16		M16		-	
B +	27 M18			M18		VP-1/2		
	30	M20		M20		-		
	36	-		-		VP-3/4		
Adjustable angle wrench		Medium size, 1 set						
Screw driver		Minus type screw driver, Medium size, 2 sets						
Hammer	Plastic hammer, 1 set							
Pliers	For snap ring, TSR-160							
Steel bar	Steel bar of key material approx. $10 \times 8 \times 200$							
Torque wrench		Capable of tightening with the specified torques						

(2) Tightening torque

Dert nome	Dolt oizo	Tor	que	Wrend	ch size
Part name	Bolt size	kgf ∙ m	lbf ⋅ ft	in	mm
Hexagon socket head bolt	M 5	0.7	5.1	0.16	4
(material : SCM435)	M 6	1.2	8.7	0.20	5
	M 8	3.0	21.7	0.24	6
	M10	5.8	42.0	0.31	8
	M12	10.0	72.3	0.39	10
	M14	16.0	116	0.47	12
	M16	24.0	174	0.55	14
	M18	34.0	246	0.55	14
	M20	44.0	318	0.67	17
PT plug (material : S45C)	PT1/16	0.7	5.1	0.16	4
* Wind a seal tape 1 1/2 to 2 turns round the plug	PT 1/8	1.05	7.59	0.20	5
	PT 1/4	1.75	12.7	0.24	6
	PT 3/8	3.5	25.3	0.31	8
	PT 1/2	5.0	36.2	0.39	10
PF plug (material : S45C)	PF 1/4	3.0	21.7	0.24	6
	PF 1/2	10.0	72.3	0.39	10
	PF 3/4	15.0	109	0.55	14
	PF 1	19.0	137	0.67	17
	PF 1 1/4	27.0	195	0.67	17
	PF 1 1/2	28.0	203	0.67	17


3) DISASSEMBLY


- (1) Select place suitable to disassembling.
- * Select clean place.
- Spread rubber sheet, cloth or so on on overhaul workbench top to prevent parts from being damaged.
- (2) Remove dust, rust, etc, from pump surfaces with cleaning oil or so on.
- (3) Remove drain port plug (468) and let oil out of pump casing (front and rear pump).
- (4) Remove hexagon socket head bolts (412, 413) and remove regulator.




- (5) Loosen hexagon socket head bolts (401) which tighten swash plate support (251), pump casing (271) and valve cover (F, 311).
- If gear pump and so on are fitted to rear face of pump, remove them before starting this work.
- (6) Loosen hexagon socket head bolts (402) which tighten swash plate support (251), pump casing (271) and valve cover (R, 312).


- (7) Place pump horizontally on workbench with its regulator-fitting surface down, and separate pump casing (271) from valve cover (F, 311).
- Before bringing this surface down, spread rubber sheet on workbench without fail to prevent this surface from being damaged.
- (8) Separate valve cover (F, 311) from valve cover (R, 312) and pull out booster (130), spline coupling (114).
- (9) Separate valve cover (R, 312) from pump casing and then pull out the cylinder block (012) of pump casing (271) straightly over drive shaft(R, 113). Pull out also pistons (151), set plate (153), spherical bush (156) and cylinder springs (157) simultaneously.
- * Take care not to damage sliding surfaces of cylinder, spherical bushing, shoes, swash plate, etc.
- (10) Remove hexagon socket head bolts (406) and then seal cover (F, 261).
- Fit bolt into pulling-out tapped hole of seal cover (F), and cover can be removed easily.
- Since oil seal is fitted on seal cover (F), take care not to damage it when removing cover.









(11) Tapping lightly fitting flange section of swash plate support (251) on its pump casing side, separate swash plate support from pump casing.




(12) Remove shoe plate (211) and swash plate (212) from pump casing (271).



(13) Tapping lightly shaft ends of drive shafts(111, 113) with plastic hammer, take out drive shafts from swash plate supports.




- (14) Remove valve plates (313, 314) from valve cover (311, 312).
- * These may be removed in work 7, 9.



- (15) If necessary, remove stopper (L, 534), stopper (S, 535), servo piston (532) and tilting pin (531) from pump casing (271), and needle bearing (124) from valve cover (311, 312).
- * In removing tilting pin, use a protector to prevent pin head from being damaged.
- Since loctite is applied to fitting areas of tilting pin and servo piston, take care not to damage servo piston.
- Do not remove needle bearing as far as possible, except when it is considered to be out of its life span.
- Do not loosen hexagon nuts of valve cover and swash plate support.
 If loosened, flow setting will be changed.
- (16) This is the end of disassembling procedures.

4) ASSEMBLY


- For reassembling reverse the disassembling procedures, paying attention to the following items.
- ① Do not fail to repair the parts damaged during disassembling, and prepare replacement parts in advance.
- ② Clean each part fully with cleaning oil and dry it with compressed air.
- ③ Do not fail to apply clean working oil to sliding sections, bearings, etc. before assembling them.
- In principle, replace seal parts, such as O-rings, oil seals, etc.
- ⑤ For fitting bolts, plug, etc., prepare a torque wrench or so on, and tighten them with torques shown in page 8-10, 11.
- ⑥ For the double-pump, take care not to mix up parts of the front pump with those of the rear pump.
- (2) Fit swash plate support (251) to pump casing (271), tapping the former lightly with a hammer.
- * After servo piston, tilting pin, stopper (L) and stopper (S) are removed, fit them soon to pump casing in advance for reassembling.
- In tightening servo piston and tilting pin, use a protector to prevent tilting pin head and feedback pin from being damaged. In addition, apply loctite (medium strength) to their threaded sections.





- (3) Place pump casing with its regulator fitting surface down, fit tilting bush of swash plate to tilting pin (531) and fit swash plate (212) to swash plate support (251) correctly.
- * Confirm with fingers of both hands that swash plate can be removed smoothly.
- * Apply grease to sliding sections of swash plate and swash plate support, and drive shaft can be fitted easily.
- (4) To swash plate support (251), fit drive shaft (111) set with bearing (123), bearing spacer (127) and snap ring (824).
- * Do not tap drive shaft with hammer or so on.
- Assemble them into support, tapping outer race of bearing lightly with plastic hammer.


Fit them fully, using steel bar or so on.

- (5) Assemble seal cover(F, 261) to pump casing(271) and fix it with hexagon socket head bolts(406).
- * Apply grease lightly to oil seal in seal cover(F).
- * Assemble oil seal, taking full care not to damage it.
- * For tandem type pump, fit rear cover(263) and seal cover(262) similarly.
- (6) Assemble piston cylinder subassembly [cylinder block (012), piston subassembly (151, 152), set plate (153), spherical bushing (156) and cylinder spring (157)].
 Fit spline phases of retainer and cylinder. Then, insert piston cylinder subassembly into pump casing (271).











- (7) Fit valve plate (313) to valve cover (F, 311), and fit valve plate (314) to valve cover (R, 312), entering pin into pin hole.
- * Take care not to mistake suction / delivery directions of valve plate.


- (8) Fit valve block (R, 312) to pump casing (271) and fit spline coupling (114) and booster(130) to shaft (R, 113).
- * Take care not to mistake direction of valve cover.
- Fit valve cover with regulator up and with delivery flange left, viewed from front side. Take care not to mistake direction of booster (130).

(Refer to the sectional drawing)


- (9) Fit valve cover (F, 311) to valve cover (R) and tighten hexagon socket head bolts (402).
- (10) Fit pump casing (271) with shaft (F, 111) to valve cover (F, 311) and tighten hexagon socket head bolts (401).
- Mate spline phases of shaft (F) and spline coupling, with shaft (F) been rotating.







- (11) Putting feedback pin of tilting pin into feedback lever of regulator, fit regulator and tighten hexagon socket head bolts (412,413).
- * Take care not to mistake regulator of front pump for that of rear pump.





(12) Fit drain port plug (468).


This is the end of reassembling procedures.


3. REGULATOR

1) STRUCTURE(1/2)









Port	Port name	Port size
Pi1,Pi2	Pilot port	PF 1/4-15
Psv1,Psv2	Servo assist port	PF 1/4-15

38092RG01

2) STRUCTURE (2/2) 734 653 654 836 651 652 601 624 629 630 628 655 802 641 <u>_</u>dt_c Ъ the_ 0 p ĊΨ Ð) o d 814 627 C ⊐> D 898 ją. 631 753 732 733 622 763 625 756 626 887 621 623 SECTION A-A 38092BG03 408 Hexagon socket bolt 627 Adjust stem (C) 730 O-ring 412 Hexagon socket bolt 628 Adjust screw (C) 732 O-ring 413 Hexagon socket bolt 629 Cover (C) 733 O-ring 436 Hexagon socket bolt 630 Lock nut 734 O-ring 438 Hexagon socket bolt 631 Sleeve, pf 735 O-ring 466 Plug 641 Pilot cover 753 O-ring 496 Plug 755 O-ring 643 Pilot piston 541 Seat 644 Spring seat (Q) 756 O-ring 543 Stopper 645 Adjust stem (Q) 763 O-ring 545 Steel ball 646 Pilot spring 801 Hexagon nut 601 Casing 651 Sleeve 814 Snap ring 611 Feedback lever 652 Spool 836 Stop ring 612 Lever(1) 653 Spring seat 858 Snap ring 613 Lever(2) 654 Return spring 874 Pin 875 Pin 614 Center plug 655 Set spring 876 615 Adjust plug 696 Port cover Pin 621 Compensator piston 697 Check valve plate 887 Pin 897 Pin 622 Piston case 708 O-ring 623 Compensator rod 722 O-ring 898 Pin 624 Spring seat (C) 724 O-ring 924 Set screw 625 Outer spring 725 O-ring

728 O-ring

626 Inner spring

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.

Tool name & size		Part name					
Allen wrench		Hexagon socket head bolt					Hexagon socket head setscrew
	4	M 5	E	3P-1/16	-		M 8
	5	M 6	BP1/8		-		M10
	6	M 8	BP-1/4		PO-1/4		M12, M14
Double ring spanner, socket wrench, double (single) open end spanner	-	Hexagon head bolt Hexagon h		head nut VP plug (PF thread)			
	6	M8		Μ	18		-
Adjustable angle wrench		Small size, Max 36 mm					
Screw driver		Minus type screw driver, Medium size, 2 sets					
Hammer		Plastic hammer, 1 set					
Pliers		For snap ring, TSR-160					
Steel bar		4×100 mm					
Torque wrench		Capable of tightening with the specified torques					
Pincers		-					
Bolt	M4, Length : 50mm						


(2) Tightening torque

Part name	Bolt size	Torque		Wrench size	
	DUIL SIZE	kgf ∙ m	lbf ⋅ ft	in	mm
Hexagon socket head bolt	M 5	0.7	5.1	0.16	4
(material : SCM435)	M 6	1.2	8.7	0.20	5
	M 8	3.0	21.7	0.24	6
	M10	5.8	42.0	0.31	8
	M12	10.0	72.3	0.39	10
	M14	16.0	116	0.47	12
	M16	24.0	174	0.55	14
	M18	34.0	246	0.55	14
	M20	44.0	318	0.67	17
PT plug (material : S45C)	PT1/16	0.7	5.1	0.16	4
Wind a seal tape 1 1/2 to 2 turns round the plug	PT 1/8	1.05	7.59	0.20	5
	PT 1/4	1.75	12.7	0.24	6
	PT 3/8	3.5	25.3	0.31	8
	PT 1/2	5.0	36.2	0.39	10
PF plug (material : S35C)	PF 1/4	3.0	21.7	0.24	6
	PF 1/2	10.0	72.3	0.39	10
	PF 3/4	15.0	109	0.55	14
	PF 1	19.0	137	0.67	17
	PF 1 1/4	27.0	195	0.67	17
	PF 1 1/2	28.0	203	0.67	17

3) DISASSEMBLY


Since the regulator consists of small precision finished parts, disassembly and assembly are rather complicated. For this reason, replacement of a regulator assembly is recommended, unless there is a special reason, but in case disassembly is necessary for an unavoidable reason, read through this manual to the end before starting disassembly.

- (1) Choose a place for disassembly.
- * Choose a clean place.
- Spread rubber sheet, cloth, or so on on top of work-bench to prevent parts from being damaged.
- (2) Remove dust, rust, etc. from surfaces of regulator with clean oil.
- (3) Remove hexagon socket head screw (412, 413) and remove regulator main body from pump main body.
- * Take care not to lose O-ring.



- (4) Remove hexagon socket head screw (438) and remove cover (C,629)
- * Cover (C) is fitted with adjusting screw (C,QI) (628), adjusting stem (C, 627), lock nut (630), hexagon nut (801) and set screw (924).


Do not loosen these screws and nuts. If they are loosened, adjusted pressureflow setting will vary.




(5) After removing cover (C, 629) subassembly, take out outer spring (625), inner spring (626) and spring seat (C, 624) from compensating section.
Then draw out adjusting stem (Q, 645), pilot spring (646) and spring seat (644)

from pilot section. * Adjusting stem (Q,645) can easily be

- drawn out with M4 bolt.
- (6) Remove hexagon socket head screws (436, 438) and remove pilot cover (641).After removing pilot cover, take out set spring (655) from pilot section.







(7) Remove snap ring (814) and take out spring seat (653), return spring (654) and sleeve (651).

Sleeve (651) is fitted with snap ring (836).


- When removing snap ring (814), return spring (654) may pop out.
- * Take care not to lose it.

- (8) Remove locking ring (858) and take out fulcrum plug (614) and adjusting plug (615).
- Fulcrum plug (614) and adjusting plug (615) can easily be taken out with M6 bolt.







- (9) Remove lever2 (613). Do not draw out pin (875).
- Work will be promoted by using pincers or so on.



- (10) Draw out pin (874) and remove feedback lever (611).
- * Push out pin (874, 4 mm in dia.) from above with slender steel bar so that it may not interfere with lever1 (612).





- (11) Remove lever1 (612). Do not draw out pin (875).
- (12)Draw out pilot piston (643) and spool (652).
- (13) Draw out piston case (622), compensating piston (621) and compensating rod (623).
- * Piston case (622) can be taken out by pushing compensating rod (623) at opposite side of piston case.


This completes disassembly.

4) ASSEMBLY


- For assembly, reverse disassembly procedures, but pay attention to the following items.
- Always repair parts that were scored at disassembly.
- ② Get replacement parts ready beforehand.

Mixing of foreign matter will cause malfunction.


- ③ Therefore, wash parts well with cleaning oil, let them dry with jet air and handle them in clean place.
- ④ Always tighten bolts, plugs, etc. to their specified torques.
- Do not fail to coat sliding surfaces with clean hydraulic oil before assembly.
 Replace seals such as O-ring with new ones as a rule.
- (2) Put compensating rod (623) into compensating hole of casing(601).
- (3) Put pin force-fitted in lever1 (612) into groove of compensating rod and fit lever 1 to pin force-fitted in casing.
- (4) Fit spool (652) and sleeve (651) into hole in spool of casing.
- * Confirm that spool and sleeve slide smoothly in casing without binding.
- * Pay attention to orientation of spool.




- (5) Fit feedback lever (611), matching its pin hole with pin hole in spool. Then insert pin (874).
- Insert pin in feedback lever a little to ease operation.
- * Take care not to mistake direction of feedback lever.




- (6) Put pilot piston (643) into pilot hole of casing.
- Confirm that pilot piston slides smoothly without binding.
- (7) Put pin force-fitted in lever2 (613) into groove of pilot piston. Then fix lever (2).




- (8) Fit fulcrum plug (614) so that pin forcefitted in fulcrum plug (614) can be put into pin hole of lever (2). Then fix locking ring (858).
- (9) Insert adjusting plug (615) and fit locking ring.
- Take care not to mistake inserting holes for fulcrum plug and adjusting plug.
 At this point in time move feedback lever to confirm that it has no large play and is free from binding.
- (10) Fit return spring (654) and spring seat (653) into spool hole and attach snap ring (814).






(11) Fit set spring (655) to spool hole and put compensating piston (621) and piston case (622) into compensating hole.Fit pilot cover (641) and tighten it with hexagonal socket head screws (436, 438).




- (12) Put spring seat (644), pilot spring (646) and adjusting stem (Q, 645) into pilot hole. Then fix spring seat (624), inner spring (626) and outer spring (625) into compensating hole.
- When fitting spring seat, take care not to mistake direction of spring seat.



(13) Install cover (C, 629) fitted with adjusting screws (628, 925), adjusting stem (C, 627), lock nut (630), hexagon nut (802) and set screw (924).

Then tighten them with hexagonal socket head screws (438).

This completes assembly.



GROUP 4 MAIN CONTROL VALVE

1. REMOVAL AND INSTALL


1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove bolts and disconnect pipes.
- (5) Disconnect pilot line hoses.
- (6) Disconnect pilot pipes.
- (7) Sling the control valve assembly and remove the control valve mounting bolts.
 Weight : 340 kg (750 lb)
- (8) Remove the control valve assembly. When removing the control valve assembly, check that all the piping have been disconnected.


2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from below items.
- ① Cylinder (Boom, arm, bucket)
- ② Swing motor
- ③ Travel motor
- $\ast~$ See each item removal and install.
- (3) Confirm the hydraulic oil level and recheck the hydraulic oil leak or not.












2. STRUCTURE (1/4)



STRUCTURE (2/4)




STRUCTURE (3/4)



8-34

STRUCTURE (4/4)



155 Plug165 O-ring202 Spring cover208 Spool cover211 Plug

- 212 O-ring
- 251 Plug
- 262 O-ring 263 O-ring
- 265 O-ring

- 273 Hex screw301 Travel spool kit
- 303 Boom spool kit
- 303 BOOM SPOOLKIL
- 304 Bucket spool kit
- 313 Plug
- 326 Spring
- 327 Spring
- 337 Rod
- 391 Travel straight spool kit
- 392 By pass cut spool

394 A/Confluence spool kit

38098MC04

- 551 Plug
- 561 O-ring
- 603 Port relief assy
- 604 Port relief assy
- 611 Negative relief valve assy
- 754 Flange
- 763 O-ring
- 764 Socket screw

3. DISASSEMBLY AND ASSEMBLY

1) GENERAL PRECAUTIONS

- (1) All hydraulic components must be worked with precision working. Then, before disassembling and assembling them, it is essential to select an especially-clean place.
- (2) In handling a control valve, pay full attention to prevent dust, sand, etc. from entering into it.
- (3) When a control value is to be removed from the machine, apply caps and masking seals to all ports. Before disassembling the value, re-check that these caps and masking seals are fitted completely, and then clean the outside of the assembly. Use a proper bench for working, spread a paper or rubber mat on the bench, and disassemble the value on it.
- (4) Support the body section carefully in carrying, transferring and so on of the control valve. Do not support the lever, exposed spool, end cover section or so on without fail.
- (5) After disassembling and assembling of the component, it is desired to carry out various tests (for the relief characteristics, leakage, flow resistance, etc.), but the hydraulic test equipment is necessary to these tests.

Therefore, even when its disassembling can be carried out technically, do not disassemble such component that cannot be tested, adjusted, and so on.

Besides, prepare clean cleaning oil, hydraulic oil, grease, etc. beforehand.

2) TOOLS

Before disassembling the control valve, prepare the following tools beforehand.


Name of tool	Quantity	Size (mm)
Vise bench	1 unit	-
Box wrench	Each 1 piece	22, 27, 32 & 36
Hexagon key wrench	Each 1 piece	5, 8, 12 & 17
Loctite #262	1 pc	-
Spanner	1 pc	10, 22, 24, 32 (Main relief valve), 36


3) DISASSEMBLING

- (1) Place control valve on working bench.
- * Disassemble it in clean place and pay attention not to damage flange face.
- (2) Disassembling of main spool (travel, bucket, swing, option, arm 2, boom 2, swing priority):
- ① Loosen hexagon socket head bolts (273) and remove spring cover (201), (206).
 - \cdot Hexagon key wrench : 8 mm


In removing bucket spring cover (206), at first remove plug (558) and piston (356). • Hexagon key wrench : 17 mm

- ② Remove spool, spring, spring seats (shim) and spacer bolt in spool assembly condition from casing.
- When pulling out spool assembly from casing, pay attention not to damage casing.






- ③ Hold spool in mouthpiece-attached vise. Remove spacer bolt (336) and disassemble spring (, shim) and spring seats.
 - \cdot Hexagon key wrench : 12 mm



(3) Disassembling of arm 1 spool :

- ① Loosen hexagon socket head bolts (273) and remove spring cover (201).
 · Hexagon key wrench : 8 mm
- ② Remove arm 1 spool (302), spring (371), spring seat (332) and spacer bolt (336) in spool assembly condition from casing.
- When pulling out spool assembly from casing, pay attention not to damage casing.
- ③ Hold arm 1 spool (302) in mouthpieceattached vise. Remove spacer bolt (336) and disassemble spring (371) and spring seats (332).
 - · Hexagon key wrench : 12 mm
- ④ Do not disassemble arm 1 spool (302) more than these conditions.





(4) Disassembling of travel straight spool :

- Loosen hexagon socket head bolts (273), remove spring cover, and pull out travel straight spool (391), spring (373), spring seat (332) and spacer bolt (336) in spool assembly condition from casing.
 Hexagon key wrench : 8 mm
- When pulling out spool assembly from casing, pay attention not to damage casing.
- Pold travel straight spool (391) in mouthpiece-attached vise, remove spacer bolt (336) and disassemble spring (373) and spring seats (332).
 Hexagon key wrench : 12 mm
- ③ Do not disassemble travel straight spool
 - (391) more than these conditions.

(5) Disassembling of boom 1 spool :


 In removing boom1 spring cover (206), at first remove plug (558) and piston (355).

· Hexagon key wrench : 17 mm

Loosen hexagon socket head bolts (273), remove spring cover (206) and pull out boom1 spool (303), plug (313), spring (371), spring seats (332) and spacer bolt(336) in spool assembly condition from casing.

 \cdot Hexagon key wrench : 8 mm

When pulling out spool assembly from casing, pay attention not to damage casing.



· Hexagon key wrench : 12 mm

Remove plug (313).

- Spanner : 27 mm
- ③ Do not disassemble boom1 spool (303) more than these conditions.

(6) Disassembly of covers :


- Remove hexagon socket head bolts (273), and remove spool cover (202) and (208).
 - Hexagon key wrench : 8 mm

In removing boom1 spool cover (208), at first remove plug (211).

 \cdot Box wrench : 22mm









- (7) Removal of main relief valve and port relief valves :
- Remove main relief valve (601) and port relief valve (603), (604), (605) from casing.
 - Main relief valve : Spanner 32 mm
 - \cdot Port relief value $\,$: Box wrench 36 mm, Spanner 36mm

(8) Removal of lock valve assembly :


- ① Loosen hexagon socket head bolts and remove lock valve assembly (252).
 - \cdot Hexagon key wrench : 5 mm







(9) Removal of bypass cut spool :

- ^① Remove plug (251), spring (326 & 327), rod (337), and bypass cut spool (392).
 - \cdot Box wrench : 27 mm






- (10) Disassembly of negative control relief valve :
 - ① Remove plug (551).
 - \cdot Hexagon key wrench : 17 mm





⁽²⁾ Remove poppet (611), spring (621) and damping rod(631).




(11) Disassembly of check valve :

- ① Remove plug (551) and take out poppet (511) and spring (522).
 · Hexagon key wrench : 17 mm
- ② Loosen hexagon socket head bolts (274) and remove load check cover (203) and take out poppet (551) and spring (522).
 · Hexagon key wrench : 8 mm
- ③ Remove plug (553) and take out poppet (513) and spring (522).
 - Hexagon key wrench : 17 mm
- ④ Remove plug (552) and take out poppet (512) and spring (523).
 - \cdot Hexagon key wrench : 12 mm
- ⑤ Remove plug sub (557) and take out poppet (511) and spring (522).
 - \cdot Box wrench : 32 mm







(12) Disassembly of boom priority valve :

- ① Loosen hexagon socket head bolts (276, 277) and remove cover sub (205) and poppet sub (515) of boom priority valve.
 · Hexagon key wrench : 8 mm
- ⁽²⁾ Hold cover sub (205) in mouthpieceattached vise, remove poppet sub (515).
- ③ Cover sub (205) : Hold cover in mouthpiece-attached vise, Loosen plug (559), and remove piston (356).

Box wrench : 24 mm


- Poppet sub (515) : Remove assy of poppet (101, 102), plug (103) and spring (104) from bush (106).
- ⁽⁵⁾ Remove spring (105) and spool (107).
- ⑥ Do not disassemble ass'y in above④ more than these conditions.





(13) Disassembly of casing :

- ① Except when required specially, do not disassemble tie bolts of casing A.
- ⁽²⁾ Since plugs not described in above disassembling procedures are blind plugs for sacrifice holes and blind plugs for casing sanitation, do not disassemble them as far as not required specially.



(14) Inspection after disassembling :

Clean all disassembled parts with clean mineral oil fully, and dry them with compressed air. Then, place them on clean papers or cloths for inspection.

① Control valve:

- a. Check whole surfaces of all parts for burrs, scratches, notches and other defects.
- b. Confirm that seal groove faces of casing and block are smooth and free of dust, dent, rust etc.
- c. Correct dents and damages on check seat faces of casing, if any, by lapping.
- * Pay attention not to leave lapping agent in casing.
- d. Confirm that all sliding and fitting parts can be moved manually and that all grooves and paths are free from foreign matter.
- e. If any spring is broken or deformed, replace it with new one.
- f. When relief valve do not function properly, repair it, following its disassembling assembling procedures.
- g. Replace all seats and O-rings with new ones.

2 Relief valve:

- a. Confirm that all seat faces at ends of all poppets and seats are free of defects and are uniform contact faces.
- b. Confirm manually that main poppet and seat can slide lightly and smoothly.
- c. Confirm that outside face of main poppet and inside face of seat are free from scratches and so on.
- d. Confirm that springs are free from breaking, deformation, and wear.
- e. Confirm that orifices of main poppet and seat section are not clogged with foreign matter.
- f. Replace all O-rings with new ones.
- g. When any light damage is found in above inspections, correct it by lapping.
- h. When any abnormal part is found, replace it with a relief valve assembly.

4) ASSEMBLING


- (1) In this assembling section, explanation only is shown. Refer to figures and photographs shown in disassembling section.
- (2) Figure in () shown after part name in explanation sentence shows number in construction figure.

(3) Cautions in assembling seals

- ① Pay attention to keep seals free from defects in its forming and damages in its handling.
- ⁽²⁾ Apply grease, hydraulic oil or so on to seals and seal-fitting sections for full lubrication.
- ^③ Do not stretch seals so much to deform them permanently.
- ⁽⁴⁾ In fitting O-ring, pay attention not to roll it into its position. In addition, twisted O-ring cannot remove its twisting naturally with ease after being fitted, and causes oil leakage.
- ⁽⁵⁾ Tighten fitting bolts at all sections with torque wrench to their respective tightening torques shown in "Maintenance Standards".


(4) Assembly of check valve :

 Assemble poppets (511,513 & 512) and springs (522 & 523).
 Put O-rings (561) onto plugs (551 & 553).
 Put O-rings (563) onto plugs (552).
 Put O-rings (264) on cover (203).
 Tighten the latters with their specified torques.



* Use poppets, springs and plugs in following groups.

Poppet	Spring	Plug or cover	Remember that
511	522	203, 204, 551, 557	511 in 10 positions
512	523	552	512 in 2 positions
513	522	553	513 in 2 positions
514	525	204	514 in 1 positions



No.	Hexagon	Tightening torque			
INO.	key wrench	kgf ∙ m	lbf ⋅ ft		
(551)	17 mm	37.7~41.8	273~302		
(274)	8 mm	5.3~6.3	38.3~45.6		
(553)	17 mm	37.7~41.8	273~302		
(552)	12 mm	23.5~27.5	170~197		
(557)	(box wrench) 32 mm	20.4~25.5	148~184		

② Bucket, option confluence plug sub :

If you want bucket confluence or option confluence effective, loosen rod (401) and tighten lock nut (712).

If you want to cancel bucket confluence or option confluence, tighten rod (401) and lock nut (712).

- Spanner : 10 mm for (401)
- Tightening torque : 3.0~4.0 kgf · m (21.7~28.9 lbf · ft)
- \cdot Spanner : 24 mm for (712)
- Tightening torque : 4.0~5.0 kgf · m (28.9~36.2 lbf · ft)

(5) Assemble boom priority valve :

 Put O-ring (108) onto bush (106), and assemble spool (107) and spring (105).

Assemble assy of poppet (101, 102), plug (103) and spring (104) into bush (106).

Assemble bush sub in above ② into cover (205) and assemble them into casing, and tighten hexagon socket head bolts (276, 277)

 \cdot Hexagon key wrench : 8mm


 Tightening torque : 5.3~6.3 kgf · m (38.3~45.6 lbf · ft)


Assemble piston (356) in cover (205), and tighten plug (559)


- · Box wrench : 24mm
- Tightening torque : 20.4~25.5 kgf · m (147.5~184.4 lbf · ft)

(6) Assembling of negative control relief valve

- Assemble poppet (611), spring (621),and damping rod (631) to casing A (101) & casing B(102). Put O-ring (561) onto plug (551) and tighten the latter with its specified torque.
 - · Hexagon key wrench: 17 mm
 - Tightening torque : 37.7~41.8 kgf · m (272.7~302.3 lbf · ft)







(7) Assembly of bypass cut valve


 Assemble bypass cut spool (392), spring (326 & 327) and rod (337) into casing A (101) & casing B(102).


Put O-ring (265) onto plug (251) and tighten the latter with its specified torque.

- · Box wrench : 27 mm
- Tightening torque : 7.95~10.0 kgf · m (57.5~72.3 lbf · ft)

(8) Assembling of lock valve assembly

- Fit O-ring (163) to lock valve assembly (252) and tighten hexagon socket head bolts with specified torque.
 - · Hexagon key wrench : 5 mm
 - Tightening torque : 1.0~1.42 kgf · m (7.2~10.2 lbf · ft)







(9) Assembling of main relief valve and port ① relief valve :

Assemble main relief valve (601) and port relief valves (603, 604, & 605) to casing and tighten it with specified torque.

Itom	Size	Tightening torque		
Item	Size	kgf∙m	lbf ∙ ft	
Main relief valve	Spanner 32 mm			
Port relief valve	Spanner 36 mm Box wrench 36 mm	12.2~14.3	88.2~103	







(10) Assembling of travel straight spool :


- Hold end of travel straight spool (391) in mouthpiece-attached vise, set spring seat (332) and spring (373) and tighten spacer bolt (336) with specified torque.
- ** Before tightening spacer bolt (336), apply Loctite #262 to it.
 - Hexagon key wrench : 12 mm
 - Tightening torque : 3.77~4.18 kgf · m (27.2~30.2 lbf · ft)
- ② Fit spool assemblies of items ① above into casing B (102).
- * Fit spool assemblies into casing B (102) carefully and slowly. Do not push them forcibly without fail.

(11) Assembling of boom1 spool :

- Hold the middle of boom 1 spool (303) in mouthpiece-attached vise, set spring seat (332) and spring (371) and tighten spacer bolt (336) with specified torque, and tighten plug(313) with specified torque.
- ** Before tightening spacer bolt (336) and plug (313), apply Loctite #262 to them.
 - Spacer bolt (336) : Hexagon key
 wrench 12 mm
 - Tightening Torque : 3.77~4.18 kgf · m (27.2~30.2 lbf · ft)
 - · Plug (313) : Spanner 27mm
 - Tightening Torque : 3.77~4.18 kgf · m (27.2~30.2 lbf · ft)
- ② Fit spool assemblies of Items ① above into casing B (102).
- * Fit spool assemblies into casing B (102) carefully and slowly. Do not push them forcibly without fail.









(12) Assembling of arm1 spool :

- Hold end of arm1 spool (302) in mouthpiece-attached vise, set spring seats (332) and spring (371) and tighten spacer bolt (336) with specified torque.
- * Before tightening spacer bolt (336), apply Loctite #262 to it.
 - Hexagon key wrench : 12 mm
 - Tightening Torque : 3.77~4.18 kgf ⋅ m (27.2~30.2 lbf ⋅ ft)
- ② Fit spool assemblies of Items ① above into casing A (101).
- Fit spool assemblies into casing A (101) carefully and slowly.
 Do not push them forcibly without fail.
- (13) Assembling of main spool (travel (301), bucket (304), swing (305), option (308), arm 2 (394), boom 2 (393), swing priority (395)
 - Hold end of each spool in mouthpieceattached vise, set spring seats, springs (,shim(335) for arm 2, boom 2 and swing priority spool) and tighten spacer bolt (336) with specified torque.
 - * Before tightening spacer bolt (336), apply Loctite #262 to it.
 - Hexagon key wrench : 12 mm
 - Tightening Torque : 3.77~4.18 kgf · m (27.2~30.2 lbf · ft)
 - ② Insert spool assemblies of Items ① above into casing.
 - * Fit spool assemblies into casing A (101) and casing B (102) carefully and slowly.

Do not push them forcibly without fail.





(14) Assembling of cover :

- Fit spool covers (202) and (208) to sides reverse to spring sides spools, and tighten hexagon socket head bolts (273) with specified torque.
- * Confirm that O-rings (262) have been fitted to spool cover (202), O-ring (263) to boom 1 spool cover (208).
 - Hexagon key wrench : 8 mm
 - Tightening torque : 5.3~6.3 kgf · m (38.3~45.6 lbf · ft)
- ② Boom1 spool cover :

Put O-ring (212) onto plug (211) and tighten the latter onto boom 1 spool cover (208) with its specified torque.


- Box wrench : 22 mm
- Tightening torque : 3.5~4.0 kgf · m (25.3~29 lbf · ft)
- ③ Fit spring covers (201), (206) to spring sides of spools, and tighten hexagon socket head bolts (273) with specified torque.
- * Confirm that O-rings (263) have been fitted.
 - Hexagon key wrench : 8mm
 - Tightening torque : 5.3~6.3 kgf · m (38.3~45.5 lbf · ft)
- ④ Bucket spring cover :


Assemble piston (356) to bucket spring cover (206). Put O-ring (561) onto plug (558) and tighten the latter with specified torque.


- · Hexagon key wrench : 17mm
- Tightening torque : 20.1~25.1 kgf · m (144.6~180.8 lbf · ft)
- (5) Boom spring cover:

Assemble piston (355) to boom1 spring cover (206). Put O-ring (561) onto plug (558) and tighten the latter with specified torque.

- Hexagon key wrench : 17mm
- Tightening torque : 20.1~25.1 kgf · m (144.6~180.8 lbf · ft)







GROUP 5 SWING DEVICE

1. REMOVAL AND INSTALL OF MOTOR

1) REMOVAL


- Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect hoses (2, 3, 4, 5, 6, 7, 8, 9).
- (5) Sling the swing motor assembly (1) and remove the swing motor mounting bolts (10).


•Motor device weight : 75 kg(165 lb) •Tightening torque :97.8±15 kgf·m (707±108 lbf·ft)


- (6) Remove the swing motor assembly.
- When removing the swing motor assembly, check that all the piping have been disconnected.

2) INSTALL

- Carry out installation in the reverse order to removal.
- (2) Bleed the air from the swing motor.
- ① Remove the air vent plug.
- ② Pour in hydraulic oil until it over flows from the port.
- ③ Tighten plug lightly.
- ④ Start the engine, run at low idling, and check oil come out from plug.
- ⑤ Tighten plug fully.
- (3) Confirmed the hydraulic oil level and check the hydraulic oil leak or not.










2. SWING MOTOR

1) STRUCTURE







SECTION A-A

38092SM02

- 1 Body
- 2 Oil seal
- 3 Roller bearing
- 4 Snap ring
- 5 Shaft
- 6 Pin
- 7 Stop ring
- 8 Shoe plate
- 9 Cylinder block
- 10 Spring
- 11 Ball guide seat
- 12 Ball guide
- 13 Set plate
- 14 Piston assy

- 15 Friction plate
- 16 Plate
- 17 Brake piston
- 18 O-ring
- 19 Spring
- 20 Valve plate
- 21 Pin
- 22 Needle bearing
- 23 Rear cover
- 24 Wrench bolt
- 25 Wrench bolt
- 26 Poppet
- 27 Spring
- 28 Plug

- 29 O-ring
- 30 Relief valve assy
- 31 Time delay valve
- 32 Wrench bolt
- 33 Plug
- 34 Swing reactionless valve assy
- 35 Plug
- 36 O-ring
- 37 Back up ring
- 38 O-ring
- 39 O-ring
- 40 Bushing

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

Tool name	Remark			
Allen wrench	5			
	6			
	12			
	17			
Socket for socket wrench, spanner	36			
Torque wrench	Capable of tightening with the specified torques			
Snap ring plier(for holes, axis)	Snap ring(4)			
Solder hammer	Needle bearing(22), pin(6, 21)			
Oil seal inserting jig	Oil seal(2)			
Induction heating apparatus for bearing	Roller bearing(3)			

(2) Tightening torque

Part name	Item	Size	Torque		Wrench size	
			kgf ∙ m	lbf ∙ ft	in	mm
Wrench bolt	24	M14	20.9	151.2	0.47	12
Wrench bolt	25	M14	20.9	151.2	0.47	12
Relief valve	30	M33	18.0	130.2	1.42	36
Wrench bolt	32	PF 1/4	6.9	49.9	0.20	5
Plug	33	PF 1/4	20.9	151.2	0.24	6

2) DISASSEMBLING

- (1) Disassemble the sub of a TURNING AXIS
 - Unloosing wrench bolt (32) and disassemble time delay valve assy (31) from rear cover (23)



3607A8SM01/01A

② Hang rear cover (23) on hoist, unloose wrench bolt (24, 25) and disassemble from body (1).



3607A8SM02

③ Using a jig, disassemble break piston (17) from body (1).



3607A8SM03

 ④ Disassemble respectively cylinder block assy, fricktion plate (15), plate (16) from body (1).



⁽⁵⁾ Disassemble shoe plate (8) from body (1).

⁶ Using a plier jig, disassemble snap ring

(4) and shaft assy (5).



3607A8SM05



3607A8SM06/06A

(2) Disassemble cylinder block assy sub

- Disassemble pistion assy (14), set plate (13) from cylinder block assy.
- <image><image>
- ② Disassemble ball guide (12), friction plate (15), plate (16) and ball guide seat (11) from cylinder block (9).



3607A8SM08A/08B

3 Disassemble spring (10) from cylinder block (9).



3607A8SM09

(3) Disassemble rear cover assy sub

① Disassemble pin (6, 21) and valve plate (20) from rear cover (23).



3607A8SM10/10A

2 Using a torque wrench, disassemble relief valve assy (30) 2 set from rear cover (23).



 $\ensuremath{\textcircled{}}$ Disassemble make up check valve assy with a torque wrench from rear cover (23).



3607A8SM12/12/

4) ASSEMBLING

- (1) Assemble the sub of a turning axls
- Put roller bearing (3) on preheater and provide heat to inner wheel (compress ing temp : 290°C for 2 minutes)
 - \cdot Roller bearing $\times 1 \text{EA}$



- ② After assembling and compressing preheated roller bearing (3), stop ring (7) into shaft (5).
 - \cdot Stop ring $\times 1$ EA
 - $\cdot \; \text{Shaft} \times \; \text{1EA}$




3607A8SM22/22A

- ^③ Using a compressing tool and steel stick, assemble oil seal (2) into body (1).
 - \cdot Oil seal $\times 1 \text{EA}$



3607A8SM23/23A

④ Insert above shaft sub into body (1) and assemble it with a hammer.



5 Fix snap ring (4) to shaft with a plier jig. \cdot Snap ring $\times 1\text{EA}$



3607A8SM06

- ⁽⁶⁾ Spread grease on shoe plate (8) and assemble on the body.
 - \cdot Shoe plate $\times 1 \text{EA}$



3607A8SM05


- (2) Assemble the sub of cylinder block assy
- Assemble spring (10) 9 set into cylinder block (9).
 - \cdot Spring \times 9EA



- ② Assemble ball guide (12) and ball guide seat (11) into cylinder block (9).
 - \cdot Ball guide $\times 1 \text{EA}$



- ③ Assemble piston assy (14) 9 set into set plate (13).
 - · Piston assy \times 9EA
 - \cdot Set plate $\times 1 \text{EA}$




3607A8SM27

4 Assemble above item 2 and 3.



3607A8SM28

(5) Assemble cylinder block assy into body (1).



- ⑥ Assemble 4 set of lining plate (16), friction plate (15) respectively into body.
 - · Lining plate $\times 4EA$
 - \cdot Friction plate $\times 4\text{EA}$




- Assemble O-ring (18) into break piston (17).
 - \cdot O-ring $\times 2\text{EA}$



3607A8SM30

Insert break piston assy into body (1) and assemble spring (19) into break piston (17).

 \cdot Spring \times 19EA



3607A8SM31/31A

- (3) Assemble the sub of rear cover assy sub
- After assembling needle bearing (22) into rear cover (23), with a hammer assemble pin (6, 21).



3607A8SM32/32A

- 2 Assemble respectively make up check valve assy spring (27), poppet (26), plug (28) into rear cover (23) after then screw it torque wrench.
 - \cdot Make up check sub $\times 2set$
 - \cdot Spring $\times 2\text{EA}$
 - \cdot Check $\times 3\text{EA}$



3607A8SM33/12A

③ Assemble relief valve assy (30) 2set into rear cover (23) with a torque wrench.



8607A8SM34/11A

- ④ Spreading grease on valve plate (20), assemble into rear cover (23).
 - \cdot Valve plate $\times\,1\text{EA}$



3607A8SM10/10A

5 Lift up rear cover assy on body (1) by a crane and assemble it with a wrench bolt (24, 25).



6 Assemble time delay valve assy (31) into rear cover (23) with a wrench bolt (32).



3607A8SM01/01A

(4) Air pressing test

Be sure of leakage, after press air into assembled motor.



14078SM232

(5) Leakage check


After cleaning motor by color check No.1, paint No.3 and be sure of leakage.



14078SM233/233A

(6) Mount test bench


Mounting motor test bench, test the availability of each part.



220078SM14

3. REDUCTION GEAR

1) STRUCTURE



1 Casing

- 2 Drive shaft
- 3 Roller bearing
- 4 Spacer ring
- 5 Oil seal

6 Roller bearing

- 7 Carrier 2
- 8 Carrier 2
- 9 Planetary gear 2
- 10 Pin 2
- 11 Pin 2
- 12 Bushing 2
- 13 Spring pin
- 14 Thrust washer
- 15 Spring pin
- 16 Carrier 1

- 17 Carrier 1
- 18 Planetary gear 1
- 19 Pin 1
- 20 Needle cage
- 21 Side plate 1
- 22 Side plate 2
- 23 Stop ring
- 24 Spring pin
- 25 Thrust ring
- 26 Sun gear 2
- 27 Sun gear 1
- 28 Ring gear
- 29 Knock pin
- 30 Cover plate
- 31 Hexagon bolt
- 32 Spacer

33 Pinion gear

38092SM03

- 34 Lock plate
- 35 Hexagon bolt
- 36 Lock washer
- 37 Plug
- 38 Plug
- 39 Socket bolt
- 40 Cover
- 41 O-ring
- 42 Hexagon socket bolt
- 43 Plug
- 45 Air breather assy
- 46 Gauge pipe
- 47 Gauge bar

2) DISASSEMBLY

(1) Removal of cover

- * Loosen the socket bolt (24) with 16mm hexagonal socket and remove the cover (37).
- (2) Removal of sun gear 1 and thrust ring assembly

Remove carrier 1(16), install eye bolt to tap hole (M10) and remove carrier 1 assembly itself.



3607A8SR03

(3) Removal of sun gear 2


Remove sun gear 2 (26), install eye bolt to tap (M10) of carrier 2 (8) and remove carrier 2 assembly itself.




3607A8SR04

(4) Disassembly of 2nd carrier assembly

- Insert spring pin (15) into pin assy 2(11) by hammering.
- * Do not reuse spring pin after removal.



② Remove pin assy 2 (11) from carrier 2 (7), planetary gear 2 (9) and thrust washer (14) with hands.



3607A8SR06

(5) Removal of ring gear

Remove ring gear (28) from casing (1).

 Fluid packing is applied on contacting face of ring gear and gear casing. Therefore, remove ring gear from casing by minus screw driver.



3607A8SR07

(6) Removal of drive shaft (2) assembly

 Spread off the corners of spacer (32), cover plate (30) and hex bolt (31) with a tool.



- ② Install hydraulic press at the end face of shaft, and remove drive shaft(2), spacer ring (4), and roller bearing (3) as assembly.
- * Do not reuse oil seal after removal.



③ Remove roller bearing (6) from gear casing (1).



3607A8SR10

④ Remove oil seal (5) from gear casing (1).



3607A8SR11

(7) Disassembly of shaft assembly

Insert motor side of shaft (2) into steel tube (inner dia : \emptyset 145 mm) and push the end of output shaft side with hydraulic press and then remove roller bearing (3), and spacer ring (4) as assembly from drive shaft (2).



3) ASSEMBLY

(1) Assembly of drive shaft assembly

- After assembly drive shaft (2), heat roller bearing (3) up to 50°C plus surrounding temperature and assemble it to shaft with hydraulic press and then assemble spacer ring (4) in this order.
- * Pay attention to the assembling direction of cover plate (30).



3607A8SR13

(2) Installation of oil seal

Remove oil from assembled face of oil seal of gear casing (1) and oil seal (5). Apply fluid packing (three bond of white color) on outer face of oil seal and assemble at pressing jig of gear casing. After inserting with press, lubricate oil seal with grease.



3607A8SR14

(3) Assembly of drive shaft assembly

- Be careful lest oil seal lip damage by spline of drive shaft (2).
 Assemble drive shaft assembly by using seal guide.
- ② Put drive shaft of gear casing (1) upward. Assemble drive shaft assembly to gear casing by tightening eye bolt into tap hole (M16) of output side of drive shaft (2).
- * Place support (approx 150 mm) below of gear case (1) for seal protector contact with work table.



(4) Install of roller bearing

Put gear casing under output shaft and heat roller bearing (6) up to 50°C plus surrounding temperature and then assemble it to the shaft.



3607A8SR16

(5) Assembly of ring gear

 Remove oil from mating faces between gear casing (1) and ring gear (28), and knock pin (29). Assemble collar of gear casing and apply fluid packing (three bond of grey color).





3607A8SR17



(6) Assembly of carrier 2 assembly

- Assemble planetary gear 2 (9) to carrier 2 (8) with thrust washer (14) and insert pin assy 2 (11).
- * Lubricate gear oil to inside of gear and outside of shaft.



- ② Insert spring pin (15) by hammering.
- Insert as the clearance between spring pins toward planetary gear 2 (9).



3607A8SR20

(7) Assembly of carrier 2 assembly and sun gear 2

- Mount eye bolt into tap hole (M10) of carrier 2 (8) and lift carrier assembly and then insert carrier assembly being engaged with internal teeth of ring gear (28). Rotate carrier assembly lightly so that splines of drive shaft (2) are engaged.
- ② Insert sun gear 2 (26) to planetary gear 2 (9).




3607A8SR21



(8) Assembly of sun gear 1, carrier 1 assembly

 Mount eye bolt into tap hole (M10) of lift carrier assembly and then insert carrier assembly being engaged with internal teeth of ring gear (28).

Rotate holder assembly lightly so that sun gear 2 (26) is engaged with teeth of carrier 1 (17).



② Insert sun gear 1 (27) to planetary gear 1 (18).



3607A8SR24

(9) Check rotation of sun gear by turning plunge part of gear casing with hands.


(10) Assembly of cover

Remove oil from mating faces between ring gear (28) and cover (40) and apply fluid packing.

Assemble cover (40) and tighten socket bolt (39) with 16mm hexagonal socket. Tightening torque : $28.5 \pm 3.0 \text{ kgf} \cdot \text{m}$

(206±21.7lbf ⋅ ft)

This completes assembly



GROUP 6 TRAVEL DEVICE

■ TRAVEL MOTOR (TYPE 1)

1. REMOVAL AND INSTALL


1) REMOVAL

- Swing the work equipment 90° and lower it completely to the ground.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove the track shoe assembly.For details, see removal of track shoe assembly.
- (5) Remove the cover.
- (6) Remove the hoses.
- * Fit blind plugs to the disconnected hoses.
- (7) Remove the bolts and the sprocket.
- (8) Sling travel device assembly (1).
- (9) Remove the mounting bolts (2), then remove the travel device assembly.
 Weight : 380 kg(840 lb)

2) INSTALL


- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the travel motor.
- Remove the air vent plug.
- ② Pour in hydraulic oil until it overflows from the port.
- ③ Tighten plug lightly.
- ④ Start the engine, run at low idling, and check oil come out from plug.
- ⑤ Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.





2. TRAVEL MOTOR (TYPE 1)

1) STRUCTURE (1/2)




- 101 Drive shaft
- 102 Roller bearing
- 103 Needle bearing
- 107 Snap ring
- 111 Cylinder block
- 113 Spherical bushing
- 114 Cylinder spring
- 121 Piston
- 122 Shoe
- 123 Set plate
- 131 Valve plate
- 201 Swash plate
- 272 Shaft casing

- 303 Valve casing
- 351 Reducing valve
- 352 Cover
- 435 Snap ring
- 451 Pin
- 461 Plug
- 472 O-ring
- 491 Oil seal
- 502 Piston
- 503 Shoe
- 504 Pivot ball
- 545 Orifice
- 546 Orifice

- 547 O-ring
- 702 Brake piston
- 703 Orifice
- 704 Orifice
- 705 Brake spring
- 707 O-ring
- 708 O-ring
- 741 Separation plate
- 742 Friction plate
- 801 Name plate
- 802 Rivet

STRUCTURE (2/2)



3607A2TM03

- 022 Counterbalance spool350 Relief valve361 Washer362 Counterbalance spring
- 364 Counterbalance cover
- 365 O-ring
- 366 Hex socket
- 300 Hex Sockel
- 401 Hex socket
- 402 Hex socket bolt
 464 VP plug
 485 O-ring
 509 O-ring
 531 Tilting spool
 533 Tilting spring
 541 Seat
 542 Stopper
- 543 Steel ball
 564 Plug
 567 VP plug
 569 RO plug
 571 RO plug
 572 O-ring

2) TOOLS AND TIGHTENING TORQUE

(1) Tools


Tool name	Remark			
Allen wrench	2			
	2.5			
	4			
	6 B			
	8			
	10			
	17			
Socket for socket wrench, spanner	19			
	22.4			
	27			
	42			
Torque wrench	Capable of tightening with the specified torques.			
Plier(For hole, TPR-90)	For snap ring(435)			
Plier(For shaft)	For snap ring(107)			
(-) Driver	-			
Plastic hammer	Wooden hammer allowed. Nominal 1 or so			
Steel rod approx	7×7×200mm, Bearing(102, 103)			
Monkey wrench	-			
Oil seal inserting jig	-			
Bearing plier	-			
Seal tape	-			

(2) Tightening torque

Part name It	Itom	Item Size	Torque		Wrench size	
	nem		kgf ∙ m	lbf ∙ ft	in	mm
Socket bolt	366	M12×45	10	72.3	0.39	10
Socket bolt	401	M20×100	44	318	0.67	17
Socket bolt	402	M20×50	44	318	0.67	17
Plug	461	NPTF 1/16	0.9	6.5	0.16	4
VP Plug	464	PF 1/4	11	79.6	1.06	27
Orifice	545, 546	NPTF 1/16	0.7	5.1	0.16	4
Plug	564	PT 1/2	2.2	15.9	0.24	6
VP Plug	567	PF 1/4	3.7	26.8	0.75	19
Plug	569	PF 1/4	3.7	26.8	0.24	6
Plug	571	PF 3/8	7.5	54.2	0.31	8
Orifice	703	M4×0.7	0.35	2.5	0.08	2
Orifice	704	M5×0.8	0.7	5.1	0.1	2.5

3. TRAVEL REDUCTION GEAR (TYPE 1)

1) STRUCTURE



3607A2TRG01

- 1 Ring gear
- 2 Housing
- 4 Side cover
- 5 Carrier 1
- 6 Carrier 2
- 9 Sun gear 1
- 10 Sun gear 2
- 11 Sun gear 3
- 12 Planetary gear 1
- 13 Planetary gear 2
- 14 Planetary gear 3
- 16 Pin 2
- 17 Pin 3
- 18 Side plate

- 19 Side plate
- 20 Side plate
- 21 Needle cage
- 22 Needle cage
- 23 Needle cage
- 24 Inner ring
- 25 Floating bushing
- 26 Thrust ring
- 27 Thrust ring
- 29 Socket bolt
- 30 Socket bolt
- 32 RO plug
- 33 Angular bearing
- 34 Floating seal

- 35 Shim
- 36 Spring pin
- 37 Snap ring
- 44 Snap ring
- 45 Clip
- 46 W clip
- 47 Nut ring
- 51 Name plate
- 52 Rivet
- 53 Washer
- 54 Set screw
- 81 O-ring
- 82 O-ring
- 83 O-ring

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

Tool name		Remark		
Allen wrench	4	B		
	8			
	10			
	14			
Spanner	27			
Torque wrench	Capa	ble of tightening with the specified torques.		
Plier (for shaft)	Snap	Snap ring (037, 044)		
(-) Driver	For re	For removing floating seal		
Plastic hammer	Wood	Wooden hammer allowed		
Eye bolt	M8, N	M8, M10, M16, M20, For lifting-up		
Press (1 ton)	Angu	Angular bearing (033)		
Depth gauge straight edge	100m	100mm depth, for adjusting shins (053)		
Tap M16	For re	For removing screw lock in tapped holes		
Oil stone	For fir	For finishing mating faces		
Punch	For p	For preventing spring pin from coming out		
Loctite (three bond 1373B)	Set so	Set screw (054)		
Loctite	Socket bolt (029)			
Nut ring inserting jig	Nut ring (047)			

(2) Tightening torque

Part name	Item	Size	Torque		Wrench size	
			kgf ∙ m	lbf ⋅ ft	in	mm
Socket bolt	29	M16×100	30	217	0.55	14
	30	M8×20	3.5	25.3	0.24	6
Plug	32	PF 1/2	11	79.6	0.39	10
Set screw	54	M8×16	1.0	7.2	0.24	6

4. DISASSEMBLING

1) GENERAL PRECAUTIONS

- (1) Pay attention to not damaging contact surfaces for O-rings, oil seals, etc. and contact/sliding surfaces for gears, pins, bearings, etc.
- (2) This motor can be disassembled even in a state on the reduction gear.However, in that case, pay full attention to preventing mud, dust, etc. from entering in it.
- (3) The numerical in parentheses following each part name indicates its part number shown in the attached **assembly drawings.**
- (4) The piping side of the motor is referred to as the rear side, and the output side as the front side.

2) DISASSEMBLY OF REDUCTION GEAR

- (1) Select a disassembling place.
- * Select a clean place.
- * Spread rubber sheet or cloth on work bench to prevent parts from being damaged.
- (2) Remove dust, mud, etc. from reduction gear surfaces with washing oil or so.
- (3) Place reduction gear with its gear oil drain port or level gauge at the lowest position, and drain reduction gear oil.
- Receive gear oil with clean vessel and check it for abnormalities. Renew gear oil.
- (4) Place reduction gear with its side cover(4) upward, and remove socket bolt (30), and remove side cover (4) and O-ring (81).



370078TM01

(5) Remove sun gear 1 (9).



(6) Remove carrier 1 (5), together with planetary gears 1 (12), sun gear 2 (10), etc. fitted.




370078TM03

(7) Disassembling of carrier 1 subassembly

- Remove snap ring (44), and then remove side plate (18), planetary gear 1 (12), needle cage (21) and side plate (18).
- If flaking is observed on the inner ring surface replace inner ring. In this case, replace planetary gear 1 and needle cage simultaneously.
- ② Remove circlip (45), and then remove carrier 1 (5) from sun gear 2 (10).



370078TM04



370078TM05

③ Remove thrust ring (26).



- (8) Remove carrier 2 (6), with planetary gears 2 (13), sun gear 3 (11), etc. fitted.
- Use M10 eyebolt. In this case, thrust ring (26) is removed simultaneously.



370078TM07

(9) Disassembling of carrier 2 subassembly

- Push in spring pin (36), and remove pin 2 (16), from carrier 2.
- * Carry out the following check in advance. If any abnormality should be found, carry out disassembling.
 - Is there any crevice, crack or pitting on tooth surface of planetary gear?
 - When turning planetary gear lightly, is there any abnormal noise or eccentric clearance? Carry out check similarly to the above for carrier 3.
- Remove side plate (20), planetary gear 2 (13), and needle bearing (22) from carrier 2.
- ③ Remove thrust ring (26).



370078TM08



370078TM09

- ④ Remove snap ring (46), and remove carrier 2 (6) from sun gear 3 (11).
- (5) Remove thrust ring (27) from sun gear 3 (11).



- (10) Remove socket bolt (29), and then screw two M8 eyebolts on front side of ring gear (1), lift up ring gear with crane, and remove O-ring (82) from housing (2).
- It is difficult to separate them, because it is assembled by LOCTITE.
 In this case, if you can use wrench and pipe, it is easy to separate them.
- (11) Remove snap ring (37) and then remove pin 3 (17) from shaft casing (272).



370078TM11



370078TM12



370078TM13

(12) Remove side plate (20), planetary gear 3(14), needle cage (23), floating bushing(25) from shaft casing (272).



- (13) Remove set screw (54) from nut ring (47), and then remove nut ring (47) from shaft casing (272).
- * When disassembling nut ring, remove dust, mud, etc. from set screw hole by blasting compressed air. And remove the nut ring by using the special tool for removing the nut ring.
- (14) Remove housing (2), angular bearing (33), floating seal (34) from shaft casing (272).
- * Screw two M16 eye bolts on front side of housing (2). Lift up housing (2) with crane.
- (15) Remove floating seal (34) from housing (2), paying attention to not damaging it.
- * Pay attention to O-ring and sheet faces.



370078TM15



370078TM17



370078TM18

- (16) Remove floating seal (34) from casing (272), pay attention to not damaging it.
- * Pay attention to O-ring and sheet faces.



- (17) Remove angular bearing (33) from housing (2).
- * Bearing should be renewed once it is removed.



370078TM20

3) DISASSEMBLY OF MOTOR

- (1) Disassembling of motor main body
- ① Place hydraulic motor on bench with its output shaft down.



370078TM21

Loosen relief valve (350), reducing valve (351), cover (352), plug, etc.
 They are fitted to valve casing (303).



370078TM22



③ Remove plug (564) from valve casing (303). And then screw two M10 \times 135 bolts on the holes of compelling brake release. Sub assembly (valve casing & brake piston)



370078TM24

④ Remove socket bolts (401, 402) that assemble valve casing (303).



370078TM25

5 Remove the above socket bolt, and then separate valve casing sub-assembly and remove valve plate (131).



- 6 Pull out friction plate (742) and separation plate (741) from cylinder block (111).
- * In this case, motor should be located in horizontally.



- ⑦ Pull out cylinder block and piston subassembly.
- * After placing the motor horizontally, take out cylinder block from casing.
- * Be careful not to damage the sliding parts of the cylinder block, spherical bushing and shoe.
- ⁽⁸⁾ Remove swash plate (201).



370078TM28



370078TM29



370078TM30

Image Take out snap ring (435), and then hit front side end face of shaft (101) lightly with plastic hammer or so to remove from casing (272).

⁽⁹⁾ Remove pivot ball (504) and tilting piston

sub assembly.

 Do not remove cylinderical roller bearing (102) as far as it remains normal.



- 1 Take out oil seal (491) from shaft casing (272).
- * Do not reuse the disassembling oil seal (491).



370078TM32

- (2) Disassembling of valve casing subassembly
- ① Remove two M10×135 bolts for compelling brake release. Disassemble brake piston from valve casing.


⁽²⁾ Remove plug (571), tilting spring (533), and tilting spool (531) from valve casing.



370078TM33



- ③ Remove socket bolts (366), counterbalance cover (364), and counterbalance spool assembly.
- * When any abnormality is found in counterbalance spool, counterbalance spring, etc. replace with the counter balance spool sub assembly as a set.



- ④ Remove plug (569), stopper (542), steel ball (543) and seat (541).
- When no abnormality is found in displacement changeover, it is not necessary to overhaul it specifically.
 And don't remove needle bearing (103) as far as it remains normal.



370078TM36

(3) Disassembling of cylinder subassembly

 Pull out set plate (123), piston (121), and shoe (122) sub-assembly.



370078TM37

② Remove spherical bush (113) and cylinder spring (114).
 That is all of the disassembling work.
 The pins (451) force-fitted to the valve casing cannot be removed.



5. ASSEMBLING

1) GENERAL CAUTIONS


(1) Clean each part fully with washing oil and dry it by blasting compressed air. It is better not to use waste cloths as much as possible.

However, if they are to be used, use clean ones, and pay attention to not leaving lint and so on. Don't clean the friction plate with washing oil without fail.

- (2) Use the torque wrench in tightening fitting screws and plugs to their respective torque shown in page 8-74, 8-76.
- (3) When hammering is required, use the plastic hammer and try to hit parts lightly.
- (4) Similarly to the disassembling procedures, the numeral in parentheses following each part name indicates its item number shown in the attached assembly drawings.

2) ASSEMBLY OF MOTOR

- (1) Assembling driving shaft sub-assembly
- Put roller bearing (102) on drive shaft (101), and assemble snap ring (107) by using the plier.
- Roller bearing is press fit by the heat to drive shaft.
- * Pay attention to not damaging oil seal sliding area of driving shaft.
- * Pay attention to not fitting snap ring the other way around.



(2) Assembling of valve casing subassembly

- ① Tighten plugs (461, 564) into valve casing (303) with specified torque.
 - · Plug(461) : 0.9 kgf · m (6.5 lbf · ft)
 - · Plug(564) : 2.2 kgf · m (15.9 lbf · ft)

2 Interference-fit pin (451).



370078TM40



- ③ Interference-fit needle bearing (103).
- * It is necessary when needle bearing was disassembled from the valve casing.



370078TM42

- ④ Assemble seat (541), steel ball (543), stopper (542) and RO plug (569) in the order named.
 - Tightening torque : 3.7 kgf \cdot m (26.8 lbf \cdot ft)
- * Pay attention to not assembling seat and stopper the other way around.
- ⑤ Assemble counterbalance spool (360), washer (361), spring (362) in the order named.



370078TM43



370078TM44

- ⁽⁶⁾ Fit counterbalance cover (364) by tightening socket bolt (366).
 - \cdot Tightening torque : 10 kgf \cdot m (72.3 lbf \cdot ft)
- * Confirm that O-ring (365) has been inserted in cover.



⑦ Assemble tilting spool (531), tilting spring (533) and plug (571) in the order named. \cdot Tightening torque : 7.5 kgf \cdot m (54.2 lbf \cdot ft)



370078TM46

- 8 Assemble orifice (703) and tighten them into brake piston (702) to specified torque.
 - \cdot Tightening torque : 0.35 kgf \cdot m (2.5 lbf \cdot ft)



370078TM47

9 Assemble brake spring (705) in brake piston (702). And then screw two $M10\!\times\!135$ bolts on the holes for compelling brake release. Sub-assembly (valve casing & brake

piston)

※ After finishing assembly, two M10×135 bolts will be removed.

(3) Assembling of cylinder sub-assembly

- ① Fit cylinder spring (114) and spherical bush (113) to cylinder block (111).
- * Match spline phase of cylinder block (111) to that of spherical bush.





⁽²⁾ Put piston (121), shoe (122) subassembly in set plate (123) and then assemble them to cylinder block (111).



370078TM50

(4) Assembling of motor main body

- Tighten plug (461) and orifice (545, 546) into shaft casing (272) to specified torque.
 - \cdot Plug (461) : 0.9 kgf \cdot m (6.5 lbf \cdot ft)
 - Plug (545, 546) : 0.7 kgf m (5.1 lbf ft)



370078TM51



370078TM51A

② Interference-fit oil seal (491) into shaft casing (272) by special tool.



370078TM52

- ③ Interference-fit the shaft sub-assembly. And then assemble snap ring (435).
- * Interference-fit outer race of cylindrical roller bearing (102) by hitting lightly with hammer, utilizing key.



370078TM53



370078TM54A

④ Assemble tilting piston sub-assembly and pivot ball (504) into shaft casing (272).



370078TM54



370078TM54A

- (5) Assemble swash plate (201) onto pivot ball (504).
- * Apply grease on sliding area of swash plate rear surface.
- * Confirm with finger tips of both hands if swash plate moves smoothly.
- 6 Change position of shaft casing (272) from vertical one to horizontal one. And then mount cylinder block subassembly.
- * Pay attention to not dropping swash plate.
- ⑦ Change position of shaft casing (272) from horizontal one to vertical one.



370078TM55



370078TM56



370078TM57

- ⑧ Fit separation plate (741) and friction plate (742) into cylinder block (111).
- * Mate hole of separation plate each other.



370078TM27

- * Do not reuse the disassembling O-ring (707, 708).
- Coat the O-ring with grease.(O-ring can be protected by grease)
- Image: The second se
 - Socket bolt (401, 402) Tightening torque : 44 kgf · m (318 lbf · ft)
- * Apply grease on valve plate rear surface and pay attention to not dropping valve plate.
- * Use guide bolt.
- * Apply grease on roller of needle bearing and pay attention to easy to assemble with driving shaft.
- * Use crane in assembling valve casing to shaft casing.



370078TM59



370078TM60



370078TM60A

- Ighten to specified torque plugs, relief valve (350), reducing valve (351), etc. fitted to valve casing sub-assembly.
 - · Tightening torque :
 - Relief valve (350) : 18 kgf \cdot m (130 lbf \cdot ft)
 - Reducing valve (351) : 4.5 kgf \cdot m (32.5 lbf \cdot ft)





370078TM61A

¹² Mount cover (352).



370078TM63

- Disassemble two M10×135 bolts on the holes for compelling brake release. And then assemble plug (564).
 - · Tightening torque : 2.2 kgf · m (15.9 lbf · ft)



370078TM24

3) ASSEMBLY OF REDUCTION GEAR

- (1) Place housing (2) with its front side up, and fit angular bearings (33) with their back faces mated.
- Fit angular bearings one by one with press or key hammer.
- When housing is to be reused, remove screw lock of its tapped holes with M16 tap.




- (2) Fit O-ring to floating seal (34) without twisting it, and then to housing (2).
- * Apply grease to O-ring thinly.
- * Do not reuse the disassembling O-ring.



370078TM65

- (3) Similarly, fit floating seal to shaft casing (272) of hydraulic motor.
- * Do not reuse the disassembling O-ring.



* Pay attention to not damaging sliding faces of floating seal.



370078TM67

370078TM66

- (5) Assemble shim (35) to nut ring (47).
- * Apply grease between shim and nut ring.



- (6) Insert nut ring assembled shim to shaft casing, and then tighten it to specified torque, utilizing special tool.
- * After tighten it to maximum torque and then disassemble, and then tighten it to specified torque.
 - Tightening torque : 60 kgf · m (434 lbf · ft)
- (7) After assemble set screw (54) affixed LOCTITE, and punch at hole to lock it. Pay attention to not be lifted nut ring (47).
- * Screw the set screw, until upper side of set screw is lower than tilting side of nut ring.
 - Loctite specifications : Three bond 1373B
 - Tightening torque : 1 kgf \cdot m (7.2 lbf \cdot ft)
- (8) Assemble thrust ring (27) into shaft casing (272).
- * Pay attention to not assembling thrust ring (27) the other way around. (Oil groove is located upside.)

- (9) Put needle cage (23) into inside of planetary gears 3 (14), and insert them into shaft casing, holding them between side plates (20).
- * Mate pin hole of shaft casing with center of planetary gear.



370078TM70



370078TM71



370078TM72



(10) Insert pin 3 (17) into shaft casing, and then assemble snap ring (37).



370078TM74



370078TM74A

- (11) Assemble O-ring (82) to housing (2), and then assemble ring gear (1).Pay attention to its meshing planetary gear 3 (14) and ring gear (1), utilizing crane.
- * Applying grease to O-ring thinly.
- * Do not reuse the disassembling O-ring.

370078TM75

- (12) Assemble ring gear (1) and housing (29).(Screw socket bolt (29), and tighten it to specified torque, with torque wrench.)
 - \cdot Tightening torque : 30 kgf \cdot m (217 lbf \cdot ft)
 - Loctite specifications : #636



(13) Assembling carrier 2 sub-assembly

- ① Assemble carrier 2 (6) to sun gear 3 (11), and fit clip (46).
- ② Place carrier 2 with sun gear 3 up.



370078TM77

⁽³⁾ Put needle cage (22) into inside of planetary gear 2 (13), and insert them into carrier 2, holding them between side plates (19).




370078TM78

④ Insert pins 2 (16) into carrier 2.



370078TM78A

- ⑤ Insert spring pin (36) into pin holes of carrier 2 and pin 2, and punch at two points as figure to lock it.
- Mate pin hole of carrier 2 with center of planetary gear.





(14) Screw two M10 eyebolts into carrier 2 sub-assembly, and assemble it with crane, paying attention to its meshing with planetary gear 2 and ring gear.



370078TM80

(15) Assembling of carrier 1 sub-assembly

- Interference-fit inner ring (24) to carrier 1 (5).
- * Inner ring is press-fit by the heat to carrier 1 (5).

370078TM81

② Assemble carrier 1 (5) to sun gear 2 (10), and fit clip (45).



370078TM82

- ③ Assemble thrust ring (26) to sun gear 2 (10).
- * Pay attention to not assembling thrust ring (26) the other way around. (Oil groove is located upside.)



 ④ Put needle cage (21) into inside of planetary gear 1 (12), and assemble them, holding them between side plates (18). Then fit snap ring (44) on them.




370078TM84

(16) Assemble carrier 1 (5) sub-assembly to ring gear (1).Paying attention to its meshing with carrier 1 sub-assembly and ring gear (1).



370078TM85

(17) Assemble sun gear 1 (9) to drive shaft(101) paying attention to its meshing with sungear and drive shaft (101).



(18) Measure height "A" from sun gear 1 end face to ring gear (1) mating face with straight edge and depth gage.



(19) Measure height "B" from side cover (4) mating face to center hold bottom with straight edge and depth gage.



370078TM88

(20) Obtain optimum thickness with the following formula.

 $1.5 \sim 2.0 = (B+A)$

- (Thickness of thrust ring + thickness of washer)
- Keep axial clearance between sun gear and washer 1.5~2.0 mm.
- m

370078TM89

- (21) Place washer (53) of above-selected thickness and thrust ring (26) to center of side cover (4).
- Pay attention to not assembling thrust ring
 (26) the other way around and punch it
 (Oil groove is located upside)

370078TM90

(22) Assemble O-ring (81) into ring gear.And degrease and dry mating faces of side cover & ring gear. Then lift side cover(4) up, and place it on ring gear.And tighten socket bolt (30) to specified torque to fix side cover.

Tightening torque : 3.5 kgf · m (25.3 lbf · ft)



(23) Tighten plug (32) to specified torque at side cover (4).

 \cdot Tightening torque : 11.0 kgf \cdot m (79.6 lbf \cdot ft)

That is all of the assembling work. After fitting the motor this reduction gear, supply oil until overflows from the level gauge.



370078TM92

4) CHECKING FACTS AFTER ASSEMBLY

(1) Air test of reduction gear

Disassemble plug (32) of reduction gear part.

When compressed air(0.3 kgf/cm²) is inserted that in water during the 2 minutes, it should be not happened air bubble.

· Gear oil : 5.5 liter (SAE 85W-140, API GL-5 or better)

(2) Air test of hydraulic motor

One port should be opened, the others port should be closed.

When compressed air (3 kgf/cm²) is inserted opened port in water during the 2 minutes, it should be not happened air bubble.

• Working fluid : 1.5 liter

■ TRAVEL MOTOR (TYPE 2)


1. REMOVAL AND INSTALL


1) REMOVAL

- (1) Swing the work equipment 90° and lower it completely to the ground.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove the track shoe assembly.For details, see removal of track shoe assembly.
- (5) Remove the cover.
- (6) Remove the hose.
- % Fit blind plugs to the disconnected hoses.
- (7) Remove the bolts and the sprocket.
- (8) Sling travel device assembly (1).
- (9) Remove the mounting bolts (2), then remove the travel device assembly.
 Weight : 425 kg (940 lb)
- Ū

2) INSTALL


- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the travel motor.
- ① Remove the air vent plug.
- ② Pour in hydraulic oil until it overflows from the port.
- ③ Tighten plug lightly.
- ④ Start the engine, run at low idling, and check oil come out from plug.
- 5 Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.





2. SPECIFICATION

1) TRAVEL MOTOR



1	Shaft casing
2	Plug
3	Orifice
4	Orifice screw
5	Swash piston
6	Swash ball
7	Brake pin
8	Shaft
9	Roller bearing
10	Stop ring
11	Lock ring
12	Swash plate
13	Cylinder block
14	Cylinder spring


15 Spacer 16 Ball guide Set plate 17 18 Piston & Shoe assy 19 Friction plate 20 Separator plate 21 Brake piston 22 Piston ring 23 Piston ring 24 O-ring Brake spring 25 26 Valve casing 27 Valve plate pin 28 Valve plate

29 Needle bearing 30 O-ring 31 Swash spool 32 Swash spring 33 Plug 34 O-ring 35 O-ring 36 Seat 37 Steel ball 38 Stopper 39 Plug 40 O-ring 41 Plug 42 O-ring

40				
43	43 Relief valve assy			
44	Main spool			
45	Check			
46	Spring			
47	Plug			
48	O-ring			
49	Spring seat			
50	Spring			
51	Cover			
52	Spring			
53	Spool			
54	Steel ball			
55	Spring			
56	Plug			

57	Spring seat
58	O-ring
59	Orifice
60	Wrench bolt
61	Name plate
62	Rivet
63	Oil seal
64	Snap ring
65	Wrench bolt
66	Wrench bolt
67	Spring pin
72	Floating seal
73	Hub
74	Bearing

75	Shim
76	Bearing guide
77	Wrench bolt
78	Carrier
79	Planetary gear
80	Plate
81	Needle bearing
82	Bearing bushing
83	Pin
84	Spring pin
85	Thrust plate
86	Sun gear
87	Snap ring
88	Carrier



3809A2TM22

90 Plate 91 Needle bearing 92 Pin

Planetary gear

93 Spring pin

89

- 94 Sun gear
- 95 Snap ring
- 96 Carrier
- 97 Planetary gear
- 98 Needle bearing Pin
- 99
- 100 Coupling
- 101 Ring gear
- 102 Wrench bolt

- 103 Planetary pin
- 104 Drive gear
- 105 End cover
- 106 Plate
- 107 Wrench bolt
- 108 O-ring
- 109 Ring
- 110 Ring
- 111 Plug
- 112 O-ring
- 113 Bushing

2) TOOL AND TIGHTENING TORQUE

(1) Tools

Name of tools	B-size	Name of part applied		
	4	Plug (2), Orifice screw (3, 4)		
Hexagonal	8	Plug (33)		
L-Wrench	10	Wrench bolt (60)		
	27	Hex (43)		
Socket wrench/	19	Hp plug (39)		
spanner	27	Hp plug (41)		
Snap-ring plier (for holes, axis)		Ring stop (10), Snap ring (64)		
Hammer		Needle bearing (29), Pin (7, 27)		
Torque wrench		Size : 500 kgf · m, 3000 kgf · m		
Jig for oil seal assembling	g	Oil seal (63)		
Heating tool for bearing		Roller bearing (11)		

(2) Tightening torque

NO.	Part name	Standard	Size	Torque	
		Slandard		kgf ∙ m	lbf ⋅ ft
2	Plug	NPTF 1/16	4	0.9±0.2	6.51±1.45
3, 4	Orifice screw	NPTF 1/16	4	0.7	5.06
33	Plug	PF 3/8	8	7.5	54.25
39	HP plug	PF 1/4	19	3.7	26.76
41	HP plug	PF 1/2	27	11	79.56
43	Relief valve	HEX 27	27	18±1.0	130±7.0
60	Wrench bolt	M12×35L	10	13	94.03
65	Wrench bolt	M16×50L	14	13	94.03
66	Wrench bolt	M16×100L	14	6.7	48.46

2. DISASSEMBLING

1) GENERAL INSTRUCTIONS


- (1) Generally, hydraulic equipment is precisely manufactured and clearances between each parts are very narrow. Therefore, disassembling and assembling works should be performed on the clean place where dusts hardly gather. Tools and kerosene to wash parts should also be clean and handled with great care.
- (2) When motor is removed from the host machine, wash around the ports sufficiently and put the plugs so that no dust and/or water may invade. Take off these plugs just before the piping works when re-attach it to the host machine.
- (3) Before disassembling, review the sectional drawing and prepare the required parts, depending on the purpose and the range of disassembling.
 Seals, O-rings, etc., if once disassembled, are not reusable.
 There are some parts that should be replaced as a subassembly.
 Consult with the parts manual in advance.
- (4) The piston can be inserted to whichever cylinder block for the initial assembling. However, their combination should not be changed if they are once used. To reuse them, put the matching mark on both pistons and cylinder block before disassembling.
- A Take great care not to pinch your hand between parts while disassembling nor let fall parts on your foot while lifting them.

2) DISASSEMBLEING

- (1) Set up the motor assembly on the workbench for disassembly.
- When you spin the disassembly-assembly jig at 90°, please fix the motor drain plug (56) to the bottom.

3809A2TM040

3809A2TM041



* Please inspect whether there are some kinds of foreign substance (metal powders, processed chips and others) during drain oil.



(4) Please disassemble the hexagonal socket

bolt (65, 66) fixing the valve casing.



3809A2TM042

<u>65,66</u>

3809A2TM043

- (5) Disassemble the valve plate (28) after the valve casing sub.
- % If abrasion on the valve plate, please change to new product.



3809A2TM044A

3809A2TM044

- (6) Remove brake springs (25) and take the brake piston out by screwing a M16 screw into the brake piston.
- * Number of brake springs is 10.



3809A2TM045A

- (7) Remove the cylinder and piston assembly.
- % It is easer to work by placing the motor shaft horizontal.



3809A2TM046



3809A2TM047

(8) Take swash plate (12) out.

(9) Take swash piston kit out.

(10) Take swash ball (06) out.



3809A2TM048



3809A2TM049


- (11) Take out shaft (8) from shaft casing (1) by striking the bottom part lightly with a hammer.
- * Be careful not to damage the roller bearing (9).




3809A2TM050

(12) Take valve casing sub out.

- * Be careful not to damage the needle bearing (29).
- Remove automatic control spring (32), automatic control spool (31).




3809A2TM051



3809A2TM052

② Take out main spool cover (51) from valve casing (26). Remove spring (52), spool (53), spring seat (49), spring (50) and main spool (44) in sequence.



3809A2TM053A

3809A2TM053

③ Remove relief valve assembly (43).



3809A2TM054

- (13) Take cylinder sub out.
 - ① Remove set plate (17) and piston (18) sub.




3809A2TM055

2 Remove friction plates (19) and separate plates (20) from cylinder block (13).



3809A2TM056

③ Remove ball guide (16), spacer (15), cylinder spring (14).







3809A2TM058

3809A2TM059

* Disassembly has completed.

Check that the motor parts are broken or not.

3) ASSEMBLING TRAVEL MOTOR

(1) Shaft sub assembly

- ① Fit bearing spacer to shaft (08) and press-fit roller bearing (09).
- * Press the roller bearing after preheating.



3809A2TM060




3809A2TM061

- a. Induction heating apparatus temperature : $100^{\circ}C$
- b. Be careful not to damage the sliding surface for the seal on the shaft.



3809A2TM062


- 2 Insert stop ring (10) with snap ring pliers.
- * Pay attention to the direction of the stop ring. (round direction is bearing direction.)



3809A2TM063

(2) Assemble valve casing sub assembly

- ① Tighten plugs (2) to valve casing (26) to the specified torque.
 - a. Apply loctite to the plug, and tighten them to the specified torque.
 - Tightening torque : 70~110 kgf · cm



3809A2TM064

2 Press-fit pin (27).

The pin's length will be 5 mm from valve plate with contacted area using a hammer.



3809A2TM065

③ Assemble needle bearing (29). - Tools : Press-fit jig and hammer.



3809A2TM066

④ Assemble seat (36), ball (37), stopper (38), O-ring (40) and HP plug (39) in sequence.





3809A2TM068

* Pay attention to the direction of the seat and stopper.

- · Tightening torque : 370 kgf · cm
- ⑤ Assemble HP plug (39) to the specified torque.
 - · 5 places
 - · Tightening torque : 370 kgf · cm



3809A2TM069

⑥ Mount relief valve (43) to the specified torque.


 \cdot Tightening torque : 2200 kgf \cdot cm



3809A2TM070A

3809A2TM070

⑦ Assemble main spool cover (51), spring (52), spool (53), spring seat (49), spring (50), and main spool (44) in sequence.




3809A2TM071A

3809A2TM071

- (8) Assemble automatic control spool (31), spring (32), O-ring (35).
 - · Tightening torque : 750 kgf · cm





0000772

Insert O-ring (30) to valve casing. Apply grease to the O-ring.




3809A2TM074

- ① Assemble drain plug (41) to the specified torque.
 - \cdot Tightening torque : 1100 kgf \cdot cm




(3) Assemble cylinder sub assembly

① Fit cylinder spring (14), spacer (15) and ball guide (16) to cylinder block (13). Align the phase of the cylinder and the splineof the ball guide.




② Assemble friction plates (19) and separate plates (20).



③ Insert the assembly of piston shoe (18) to retainer set plate (17) and fit it to the cylinder block (13).








3809A2TM079

- (4) Fit oil-seal (63).



3809A2TM080

(5) Assemble plug (02) to the specified torque.



3809A2TM081

- 1 Apply loctite to the plug and assemble.
- (2) Tightening torque : 70~110 kgf \cdot cm

(6) Fit pins (7).

- Tools : Hammer
 - Pin (7) : Please keep the length at 19 mm from surface of the shaft casing.
 - Pin (7) numbers 4 EA



3809A2TM082



3809A2TM083

(7) Assemble the shaft sub assembly.



3809A2TM084



3809A2TM085



3809A2TM086



3809A2TM087

(8) Assemble swash plate (12).

(9) Assemble swash piston kit assembly.

(10)Assemble swash ball (06).


- (11)Work when the shaft casing is at the vertical direction.
- * Be careful not to drop the swash plate.



3809A2TM088

(12)Fit the cylinder sub assembly.* Align the separate plates (20) to the pin.

(13) Place the motor vertical again.



3809A2TM089



3809A2TM090

3809A2TM091

(14)Fit piston ring (22), piston ring (23) to brake piston (21).

- (15)Fit the brake piston (21) to the shaft casing (01).
- * Pay attention to the direction of the brake piston.



3809A2TM092

(16)Mount brake springs (25).

① Numbers : Springs - 10EA , Holes - 10EA



3809A2TM093

(17) Tighten orifice (03, 04) to the specified torque. 1 Numbers and size : (03) 1 EA - Ø 0.6

(04) 1 EA - Ø 0.8 2 Tightening torque : 70 kgf \cdot cm



3809A2TM094

- (18)Mount valve plate (26) to valve casing and tighten it with hexagonal socket bolt (66).
 - ① Apply grease to the valve plate back and be careful not to drop the valve plate.
 - ② When you assemble the valve casing to shaft casing, please use a crane.
 - ③ The hole (Ø 5) of valve plate will be located for inlet and outlet port of valve casing.
 - ④ Coat grease to swash spool of swash spring.
 Tightening torque : 2400 kgf · cm
 - Bolt tightening torque : 1800 \pm 100 kgf \cdot cm

(19) Tighten relief valves (43) to the specified



3809A2TM095



3809A2TM096



3809A2TM097


* Assembly has completed.


torque.


3. DISASSEMBLING REDUCTION GEAR

1) DISASSEMBLY


- (1) Loosen drain plug (41).
 - Do not remove drain plug (41) at once.
 - Because gear oil was compressed, plug and oil protrude suddenly.









(3) Overturn the traveling device.




(4) After loosening bolt (37), take cover (35) off.




(5) Remove drive gear (34) and No.3 carrier (26).




(6) Remove No.2 sun gear B (24).




(7) Remove No.2 carrier B (18).









(9) Remove No.1 carrier A (8).




(10)Remove coupling (30).




(11)After loosening bolt (7), remove bearing guide (6) and shim (5).




- (12)After loosening bolt (32), remove ring gear (31).
 - Tools : I-bolt, Hoist




(13)Remove hub (3) from assembly (1). - Tools : I-bolt, Hoist




(14)Remove angular bearing (4) from hub (3).




(15)Remove floating seal (2) and angular bearing (4) at opposite of hub (3).





(16)Remove planetary gear C (27) from No.3 carrier C (26).

(17)After removing pin (29), remove No.3 planetary gear C (27), needle bearing (11) and plate C (20).



(18)Remove No.2 carrier B (18) assy.

(19) Remove No.1 carrier A (8) assy.

* Disassembly has completed.

4. ASSEMBLING REDUCTION GEAR

- General precautions

Clean every part by kerosene and dry them by air blow.

Surfaces to be applied by loctite must be decreased by solvent.

Check every part for any abnormals.

Each hexagon socket head bolt should be used with loctite No. 242 applied on its threads.

Apply gear oil slightly on each part before assembling.

Take great care not to pinch your hand between parts or tools while assembling nor let fall parts on your foot while lifting them.

Inspection before reassembling

Thrust washer

 \cdot Check if there are seizure, abnormal wear or uneven wear.

 \cdot Check if wear is over the allowable limit.

Gears

 \cdot Check if there are pitting or seizure on the tooth surface.

 \cdot Check if there are cracks on the root of tooth by die check.

Bearings

 \cdot Rotate by hand to see if there are something unusual such as noise or uneven rotation.

Floating seal

· Check flaw or score on sliding surface or on O-rings.

1) Track gearbox, assembly


Before assembly track gearbox

Please observe following item.

- Wash all parts cleanly using solvent and dry all parts perfectly using compressed air.
- Check metal dust in casing and cleansing solution.
- Before application packing, please remove oil certainly.
- Before insert needle bearing, apply grease to bearing inlet enough.
- Apply lubricant to rotation part and sliding part.
- Damaged part or discolored part exchanges by new parts.

(1) Assemble hub


1 Press fit angular bearing (4) to hub (3).




- ② Assemble floating seal (2) to hub (3) using press jig (F1).
 - Remove completely the oil of surface that O-ring and O-ring contact.
 - Dry completely the floating seal.
 - After assembling the floating seal, check floating seal angle (within 1 mm).
 - After assembling the floating seal, coat lubricant to the sliding surface of the floating seal.
- ③ Assemble floating seal (2) to track motor (1) using press jig (F1).


Assembling sequence is same with sequence (2).

- Remove completely the oil of surface that O-ring and O-ring contact.
- Dry completely the floating seal.
- After assembling floating seal, coat lubricant to the sliding surface of the floating seal.







(2) Assemble thrust plate (15) to spline surface of track motor (1).




(3) Insert the assembly of hub (3) to track motor (1).




- (4) Stick bearing (4) to track motor (1) using press jig (F1).
 - Don't heat the bearing.
 - Don't hit the bearing retainer.
 - Spin the hub. (two times ~ three times)
 - Measure "a" size of figure.




- (5) After assembling shim (5), assemble bearing guide (6) using bolt (7).
 - Select thickness of shim (5) and assembly.
 - Apply loctite #262 to bolt (7).
 - \cdot Tightening torque : 1300 kgf $\cdot\,\text{cm}$




(6) Assemble bearing guide.According to the hub turn, we can check it goes on smoothly or not.




- (7) Assemble No.1 carrier A (8) sub.
- ① Mount bearing bushing (12) to No.1 planetary gear A (9).
 - Bearing bushing numbers : 18EA
 - Insert needle and coat grease.




- ② Mount No.1 planetary gear A (9) and plate A (10) to No.1 carrier A (8).
 - Align the hole of carrier and needle inside diameter.




- ③ Put pin (13) on holes of No.1 carrier A (8).
- * Align the holes of the carrier and pin holes.
- * Beat on it lightly with hammer and put in.




 ④ Assemble carrier (8) and pin (13) striking pin (14) by hammer.
 After assembly pin (14), caulking.




5 Complete remainder by equal method.




- (8) Assemble No.2 carrier B (18) sub.
- ① Mount needle (21) to No.2 planetary gear B (19).
 - Needle numbers : 15 EA
 - Insert needle and coat grease.



- ② Insert No.2 planetary gear B (19) and plate B (20) to No.2 carrier B (18).
 - Align the holes of the carrier and pin holes.





- ③ Put pin (22) on holes of No.2 carrier B (18).
- * Align the holes of the carrier and pin holes.
- * Beat on it lightly with hammer and put in.




- ④ Assemble carrier (18) and pin (22), striking pin (23) by hammer.
 - If the pin's divided side is not located in the above, it will be damaged during operation.
 - After assembly pin, caulking.

(5) Complete remainder by equal method.







- (9) Assemble No.3 carrier C (26) sub.
- Insert needle bearing (28) to No.3 planetary gear C (27). Insert needle and coat grease.



- ② Insert No.3 planetary gear C (27) and plate C (20) to No.3 carrier C (26).
 - Align the holes of the carrier and inside diameter of needle bearing.



- ③ Put pin (29) on holes of No.3 carrier C (26).
- * Align the holes of the carrier and pin holes.
- * Beat on it lightly with hammer and put in.



29


29

23

Slit

- (4) Assemble carrier (26) and pin (29) striking pin (23) by hammer.
 - If the pin's divided side is not located in the above, it will be damaged during operation.
 - After assembly pin, caulking.


(5) Complete remainder by equal method.




23

26


- (10)Press-fit parallel pin (33) to the surface of hub (3).
 - Parallel pin numbers : 8EA




(11)Insert thrust plate (15) to shaft casing of track motor (1).Press-fit No.1 carrier A (8) assy to shaft casing spline using hoist.



(12)Press-fit ring (39, 40) to the No.1 carrier A (8) assy.




(13)Mounting O-ring (38) into hub (3), and assemble ring gear (31) to hub (3).




(14) Tighten hub and ring gear.


- Bolt numbers : 24 EA
- Tightening torque : 1800 kgf · cm




(15)Insert coupling (30) to spline of shaft.




(16)Assemble snap ring (17) to sun gear A(16).Insert sun gear A (16) to carrier A.




(17) Assemble carrier B (18) to ring gear (31).



(18) Assemble plate (36) to carrier B (18).




(19)Assemble snap ring (25) to sun gear B(24).Insert carrier B to sun gear B (24).




(20)Assemble carrier C (26) assy to ring gear (31).


After assembling, check whether gear rotate or not.




(21)Assemble carrier C (26) to drive gear (34).




(22) Assemble plate (36) to carrier C (26).



(23) Press-fit bushing (43) to cover (35).




(24)Assemble cover (35).




(25)Assemble cover (35) and tighten them to the specified torque.


· Tightening torque : 750 kgf · cm



(26)Inject gear oil and assemble plug (41) of cover (35).

- Volume of gear oil : 4.5 liter





* Assembly has completed.

GROUP 7 RCV LEVER


1. REMOVAL AND INSTALL


1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- (4) Loosen the socket bolt (1).
- (5) Remove the cover of the console box.
- (6) Disconnect pilot line hoses (3).
- (7) Remove the pilot valve assembly (2).
- When removing the pilot valve assembly, check that all the hoses have been disconnected.

2) INSTALL


- (1) Carry out installation in the reverse order to removal.
- (2) Confirm the hydraulic oil level and check the hydraulic oil leak or not.





2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE



32092RL01

- 1 Case
- 2 Plug
- 3 Bushing
- 4 Spool
- 5 Shim
- 6 Spring
- 7 Spring seat

10 Spring Push rod 11 12 Spring 13 Spring seat Plug 14

Stopper

Push rod

8

9

15 O-ring 16 Rod seal 23 17 Plate 24 25 18 Boot 19 Joint assembly 26 20 Swash plate 27 28 Adjusting nut

22 Lock nut Handle assembly Handle bar Nut Boot

- Spring pin
- Bushing

21

2) TOOLS AND TIGHTENING TORQUE

(1) Tools


Tool name	Remark		
Allen wrench	6 <u>B</u>		
Spanne	22		
	27		
(+) Driver	Length 150		
(-) Driver	Width 4~5		
Torque wrench	Capable of tightening with the specified torques		


(2) Tightening torque

Part name	Item	Size	Torque	
	item		kgf ∙ m	lbf ⋅ ft
Plug	2	PT 1/8	3.0	21.7
Joint	19	M14	3.5	25.3
Swash plate	20	M14	5.0±0.35	36.2±2.5
Adjusting nut	21	M14	5.0±0.35	36.2±2.5
Lock nut	22	M14	5.0±0.35	36.2±2.5


3) DISASSEMBLY

- (1) Clean pilot valve with kerosene.
- * Put blind plugs into all ports
- (2) Fix pilot valve in a vise with copper (or lead) sheets.
- (3) Remove end of boot (26) from case (1) and take it out upwards.
- * For valve with switch, remove cord also through hole of casing.







(4) Loosen lock nut (22) and adjusting nut(21) with spanners on them respectively, and take out handle section as one body.




(5) Remove the boot (18).





(6) Loosen adjusting nut (21) and swash plate (20) with spanners on them respectively, and remove them.






- (7) Turn joint anticlockwise to loosen it, utilizing jig (Special tool).
- When return spring (10) is strong in force, plate (17), plug (14) and push rod (11) will come up on loosening joint.
 Pay attention to this.







(8) Remove plate (17).




- (9) When return spring (10) is weak in force, plug (14) stays in casing because of sliding resistance of O-ring.
- * Take it out with minus screwdriver. Take it out, utilizing external periphery groove of plug and paying attention not to damage it by partial loading.
- During taking out, plug may jump up due to return spring (10) force.
 Pay attention to this.
- (10) Remove reducing valve subassembly and return spring (10) out of casing.
- Record relative position of reducing valve subassembly and return springs.







(11) Loosen hexagon socket head plug(2) with hexagon socket screw key.




- (12) For disassembling reducing valve section, stand it vertically with spool (4) bottom placed on flat workbench. Push down spring seat (7) and remove two pieces of semicircular stopper (8) with tip of small minus screwdriver.
- * Pay attention not to damage spool surface.
- * Record original position of spring seat (7).
- Do not push down spring seat more than 6mm.



- (13) Separate spool (4), spring seat (7), spring(6) and shim (5) individually.
- * Until being assembled, they should be handled as one subassembly group.





(14) Take push rod (11) out of plug (14).




(15) Remove O-ring (15) and seal (16) from plug (14).


Use small minus screwdriver or so on to remove this seal.





(16) Remove lock nut (22) and then boot (26).





(16) Cleaning of parts

- Put all parts in rough cleaning vessel filled with kerosene and clean them (rough cleaning).
- If dirty part is cleaned with kerosene just after putting it in vessel, it may be damaged. Leave it in kerosene for a while to loosen dust and dirty oil.
- If this kerosene is polluted, parts will be damaged and functions of reassembled valve will be degraded.

Therefore, control cleanliness of kerosene fully.

- ② Put parts in final cleaning vessel filled with kerosene, turning it slowly to clean them even to their insides (finish cleaning).
- Do not dry parts with compressed air, since they will be damaged and/or rusted by dust and moisture in air.


(17) Rust prevention of parts

Apply rust-preventives to all parts.


If left as they after being cleaned, they will be rusted and will not display their functions fully after being reassembled.


4) ASSEMBLY

- (1) Tighten hexagon socket head plug (2) to the specified torque.
- * Tighten two bolts alternately and slowly.
- 36078RL15
- (2) Put shim (5), springs (6) and spring seat(7) onto spool (4) in this order.




- (3) Stand spool vertically with its bottom placed on flat workbench, and with spring seat pushed down, put two pieces of semicircular stopper (8) on spring seat without piling them on.
- Assemble stopper (8) so that its sharp edge side will be caught by head of spool. Do not push down spring seat more than 6mm.
- (4) Assemble spring (10) into casing (1).Assemble reducing valve subassembly into casing.
- * Assemble them to their original positions.







(5) Assemble O-ring (15) onto plug (14).




- (6) Assemble seal (16) to plug (14).
- * Assemble seal in such lip direction as shown below.




- (7) Assemble push rod (11) to plug (14).
- $\ast~$ Apply working oil on push-rod surface.



- (8) Assemble plug subassembly to casing.
- When return spring is weak in force, subassembly stops due to resistance of O-ring.




(9) When return spring is strong in force, assemble 4 sets at the same time, utilizing plate (17), and tighten joint (19) temporarily.




(10) Fit plate (17).

(11) Tighten joint (19) with the specified torque to casing, utilizing jig.




(12) Assemble swash plate (20) to joint (19).


- Screw it to position that it contacts with 4 push rods evenly.
- * Do not screw it over.




- (13) Assemble adjusting nut (21), apply spanner to width across flat of plate (20) to fix it, and tighten adjusting nut to the specified torque.
- During tightening, do not change position of disk.




(14) Fit boot (18) to plate.




(15) Fit boot (26) and lock nut (22), and handle subassembly is assembled completely.







(16) Pull out cord and tube through adjusting nut hole provided in direction 60° to 120° from casing hole.




- (17) Assemble bushing (27) to plate and pass cord and tube through it.
- * Provide margin necessary to operation.




(18) Determine handle direction, tighten lock nut (22) to specified torque to fix handle.



(19) Apply grease to rotating section of joint and contacting faces of disk and push rod.



- (20) Assemble lower end of bellows to casing.
- (21) Inject volatile rust-preventives through all ports and then put blind plugs in ports.



GROUP 8 TURNING JOINT

1. REMOVAL AND INSTALL


1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- A Escaping fluid under pressure can penetrate the skin causing serious injury.
- When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect all hoses.
- (5) Sling the turning joint assembly (1) and remove the mounting bolt (2).
 - Weight : 55 kg (120 lb)
 - Tightening torque : $12.3 \pm 1.3 \text{ kgf} \cdot \text{m}$ ($89 \pm 9.4 \text{ lbf} \cdot \text{ft}$)
- (6) Remove the turning joint assembly.
- * When removing the turning joint, check that all the hoses have been disconnected.

2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- * Take care of turning joint direction.
- * Assemble hoses to their original positions.
- * Confirm the hydraulic oil level and check the hydraulic oil leak or not.








2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE



21098TJ01


- 1 Hub
- 2 Shaft
- 3 Cover
- 4 Spacer
- 5 Shim

- 6 Shim
- 7 Slipper seal
- 8 O-ring
- 9 O-ring
- 10 O-ring


- 11 Wear ring
- 12 Retainer ring
- 13 Plug
- 14 Hexagon bolt
- 15 Spring washer

2) DISASSEMBLY


- * Before the disassembly, clean the turning joint.
- (1) Remove bolts (14), washer (15) and cover (3).




- (2) Remove shim (6) and O-ring (10).
- (3) Remove retainer ring (12), spacer (4) and shim (5).




- (4) Place hub (1) on a V-block and by using a wood buffer at the shaft end, hit out shaft(2) to about 1/2 from the body with a hammer.
- * Take care not to damage the shaft (2) when remove hub (1) or rest it sideway.
- * Put a fitting mark on hub (1) and shaft (2).
- (5) Remove six slipper seals (7) and O-ring(9), two wear ring (11) from hub (1).






3) ASSEMBLY


- * Clean all parts.
- * As a general rule, replace oil seals and O-ring.
- * Coat the sliding surfaces of all parts with engine oil or grease before installing.
- (1) Fix seven slipper seal (7) and O-ring (9), two wear ring (11) to hub (1).
- (2) Fit O-ring (8) to shaft (2).




(3) Set shaft (2) on block, tap hub (1) with a plastic hammer to install.



- (4) Fit shim (5), spacer (4) and retainer ring (12) to shaft (2).
- (5) Fit O-ring (10) to hub (1).
- (6) Fit shim (6) to shaft (2).





GROUP 9 BOOM, ARM AND BUCKET CYLINDER


1. REMOVAL AND INSTALL

1) BUCKET CYLINDER


(1) Removal

- Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- * Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- A Loosen the breather slowly to release the pressure inside the hydraulic tank.
- Escaping fluid under pressure can penetrate the skin causing serious injury.
 Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Set block between bucket cylinder and arm.







- 2 Remove nuts (3), bolt (2) and pull out pin (1).
- * Tie the rod with wire to prevent it from coming out.



③ Disconnect bucket cylinder hoses (4) and put plugs (5) on cylinder pipe.



- ④ Sling bucket cylinder assembly, and remove bolt (6), plate (7) then pull out pin (5).
- 5 Remove bucket cylinder assembly (8).
 - Weight : 320 kg (710 lb)




- ① Carry out installation in the reverse order to removal.
- A When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- * Bleed the air from the bucket cylinder.
- * Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2) ARM CYLINDER


(1) Removal

- Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- * Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- A Loosen the breather slowly to release the pressure inside the hydraulic tank.
- Escaping fluid under pressure can penetrate the skin causing serious injury.
 Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Set block between arm cylinder and boom.







- 2 Remove bolt (2) and pull out pin (1).
- * Tie the rod with wire to prevent it from coming out.



- ③ Disconnect arm cylinder hoses (4) and put plugs on cylinder pipe.
- 4 Disconnect greasing pipings (5).



- ⁽⁵⁾ Sling arm assembly (9), and remove bolt(7), plate (8) then pull out pin (6).
- 6 Remove arm cylinder assembly (9).
 - · Weight : 490 kg (1080 lb)





- ① Carry out installation in the reverse order to removal.
- A When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- * Bleed the air from the arm cylinder.
- * Confirm the hydraulic oil level and check the hydraulic oil leak or not.

3) BOOM CYLINDER


(1) Removal

- Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- ▲ Loosen the breather slowly to release the pressure inside the hydraulic tank.
- Escaping fluid under pressure can penetrate the skin causing serious injury.
 Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Disconnect greasing hoses (1).
- 2 Sling boom cylinder assembly.







- ③ Remove bolt (4), stop plate (5) and pull out pin (2).
- * Tie the rod with wire to prevent it from coming out.




④ Lower the boom cylinder assembly (6) on a stand.



⑤ Disconnect boom cylinder hoses (7), and put plugs on cylinder pipe.



- ⁽⁶⁾ Remove bolt (9) and pull out pin (8).
- \bigcirc Remove boom cylinder assembly (6).
 - Weight : 370 kg (820 lb)




- ① Carry out installation in the reverse order to removal.
- A When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- * Confirm the hydraulic oil level and check the hydraulic oil leak or not.


2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE

(1) Bucket cylinder



Internal detail





38098CY01A

- 1 Tube assembly
- 2 Rod assembly
- 3 Gland
- 4 Du bushing
- 5 Snap ring
- 6 Rod seal
- 7 Back up ring
- 8 Buffer ring
- 9 Dust wiper
- 10 Snap ring
- 11 O-ring

- 12 Back up ring
- 13 Cushion ring
- 14 Piston
- 15 Piston seal
- 16 Wear ring
- 17 Dust ring
- 18 O-ring
- 19 Back up ring
- 20 Lock nut
- 21 Hexagon socket screw
- 22 O-ring

- 23 Hexagon socket head bolt
- 24 Pin bushing
- 25 Pin bushing
- 26 Dust seal
- 27 Band assembly
- 28 Pipe assembly (R)
- 29 Pipe assembly (B)
- 30 O-ring
- 31 Hexagon socket head bolt






38098CY02


- 1 Tube assembly
- 2 Rod assembly
- 3 Gland
- 4 Du bushing
- 5 Snap ring
- 6 Rod seal
- 7 Back up ring
- 8 Buffer ring
- 9 Dust wiper
- 10 Snap ring
- 11 O-ring
- 12 Back up ring
- 13 Cushion ring

- 14 Piston
- 15 Piston seal
- 16 Wear ring
- 17 Dust ring
- 18 O-ring
- 19 Back up ring
- 20 Lock nut
- 21 Hexagon socket screw
- 22 O-ring
- 23 Hexagon socket head bolt
- 24 Pin bushing
- 25 Dust seal
- 26 Check valve

- 27 Coil spring
- 28 O-ring
- 29 Plug
- 30 Band assembly (R)
- 31 Band assembly (B)
- 32 Pipe assembly (R)
- 33 Pipe assembly (B)
- 34 O-ring
- 35 O-ring
- 36 Hexagon socket head bolt
- 37 Hexagon socket head bolt



Internal detail



- 1 Tube assembly
- 2 Rod assembly
- 3 Gland
- 4 Du bushing
- 5 Snap ring
- 6 Rod seal
- 7 Back up ring
- 8 Buffer ring
- 9 Dust wiper
- 10 Snap ring
- 11 O-ring

- 12 Back up ring
- 13 Cushion ring
- 14 Piston
- 15 Piston seal
- 16 Wear ring
- 17 Dust ring
- 18 O-ring
- 19 Back up ring
- 20 Lock washer
- 21 Hexagon socket screw
- 22 O-ring

- 38098CY03
- 23 Hexagon socket head bolt
- 24 Pin bushing (R)
- 25 Pin bushing (B)
- 26 Dust seal
- 27 Dust seal
- 28 Band assembly
- 29 Pipe assembly (R)
- 30 Pipe assembly (B)
- 31 O-ring
- 32 Hexagon socket head bolt

2) TOOLS AND TIGHTENING TORQUE

(1) Tools


Allen wrench	10	- B-	
	19		
Spanner	19		
(-) Driver	Small and large sizes		
Torque wrench	Capable of tightening with the specified torques		

(2) Tightening torque


Part name		ltem	Size	Torque	
				kgf∙m	lbf ⋅ ft
	Bucket cylinder	23	M20	46±5	333±36.1
Socket head bolt	Boom cylinder	23	M22	63±6	456±43.4
	Arm cylinder	23	M22	63±6	456±43.4
	Bucket cylinder	31	M12	9.4±1	68.0±7.2
	Boom cylinder	32	M12	9.4±1	68.0±7.2
Socket head bolt	Arm cylinder	36	M12	9.4±1	68.0±7.2
		37	M12	9.4±1	68.0±7.2
	Bucket cylinder	20	M76	100±10	723±72.3
Lock nut	Boom cylinder	20	M80	150±15	1085±108
	Arm cylinder	20	M90	150±15	1085±108
	Bucket cylinder	14	-	150±15	1085±109
Piston	Boom cylinder	14	-	200±20	1447±145
	Arm cylinder	14	-	200±20	1447±145

3) DISASSEMBLY


- (1) Remove cylinder head and piston rod
 - * Procedures are based on the bucket cylinder.
- ① Hold the clevis section of the tube in a vise.
- * Use mouth pieces so as not to damage the machined surface of the cylinder tube. Do not make use of the outside piping as a locking means.
- ⁽²⁾ Pull out rod assembly (2) about 200mm (7.1in). Because the rod assembly is rather heavy, finish extending it with air pressure after the oil draining operation.



- ③ Loosen and remove socket bolts (23) of the gland in sequence.
- * Cover the extracted rod assembly (2) with rag to prevent it from being accidentally damaged during operation.




- ④ Draw out cylinder head and rod assembly together from tube assembly (1).
- Since the rod assembly is heavy in this case, lift the tip of the rod assembly (2) with a crane or some means and draw it out. However, when rod assembly (2) has been drawn out to approximately two thirds of its length, lift it in its center to draw it completely.




Note that the plated surface of rod assembly (2) is to be lifted. For this reason, do not use a wire sling and others that may damage it, but use a strong cloth belt or a rope.


- ⑤ Place the removed rod assembly on a wooden V-block that is set level.
- * Cover a V-block with soft rag.



(2) Remove piston and cylinder head


- ① Loosen socket set screw (21) and remove set screw (21).
- Since set screw (21) and lock nut (20) is tightened to a high torque, use a hydraulic and power wrench that utilizers a hydraulic cylinder, to remove the lock set screw (21) and lock nut (20).
- ⁽²⁾ Remove piston assembly (14), back up ring (19), and O-ring (18).
- ③ Remove the cylinder head assembly from rod assembly (2).
- If it is too heavy to move, move it by striking the flanged part of cylinder head with a plastic hammer.
- Pull it straight with cylinder head assembly lifted with a crane.
 Exercise care so as not to damage the lip of rod bushing (4) and packing (5,6,7,8,9,10) by the threads of rod assembly (2).






(3) Disassemble the piston assembly

- 1 Remove wear ring (16).
- ② Remove dust ring (17) and piston seal (15).
- * Exercise care in this operation not to damage the grooves.




(4) Disassemble cylinder head assembly

- Remove back up ring (12) and O-ring (11).
- ② Remove snap ring (10), dust wiper (9).
- ③ Remove back up ring (7), rod seal (6), buffer ring (8) and snap ring (5).
- * Exercise care in this operation not to damage the grooves.
- * Do not remove seal and ring, if does not damaged.
- * Do not remove bushing (4).



3) ASSEMBLY


- (1) Assemble cylinder head assembly
- * Check for scratches or rough surfaces if found smooth with an oil stone.
- ① Coat the inner face of gland (3) with hydraulic oil.




② Coat dust wiper (9) with grease and fit dust wiper (9) to the bottom of the hole of dust seal.

At this time, press a pad metal to the metal ring of dust seal.


③ Fit snap ring (10) to the stop face.




- ④ Fit back up ring (7), rod seal (6) and buffer ring (8) to corresponding grooves, in that order.
- * Coat each packing with hydraulic oil before fitting it.
- Insert the backup ring until one side of it is inserted into groove.



- * Rod seal (6) has its own fitting direction. Therefore, confirm it before fitting them.
- * Fitting rod seal (6) upside down may damage its lip. Therefore check the correct direction that is shown in fig.




- \bigcirc Fit back up ring (12) to gland (3).
- * Put the backup ring in the warm water of $30 \sim 50^{\circ}$ C.
- ⁶ Fit O-ring (11) to gland (3).




(2) Assemble piston assembly


- * Check for scratches or rough surfaces. If found smooth with an oil stone.
- ① Coat the outer face of piston (14) with hydraulic oil.



- ② Fit piston seal (15) to piston.
- * Put the piston seal in the warm water of 60~100°C for more than 5 minutes.
- * After assembling the piston seal, press its outer diameter to fit in.




③ Fit wear ring (16) and dust ring (17) to piston (14).





(3) Install piston and cylinder head

- 1 Tix the rod assembly to the work bench.
- ② Apply hydraulic oil to the outer surface of rod assembly (2), the inner surface of piston and cylinder head.
- ③ Insert cylinder head assembly to rod assembly.



- ④ Insert cushion ring (13) to rod assembly.
- * Note that cushion ring (13) has a direction in which it should be fitted.






⑥ Fit lock nut (20) and tighten the set screw (21).


•	Tightening	torque :
---	------------	----------


Item		kgf ∙ m	lbf ∙ ft
Bucket	20	$100\!\pm\!10$	723±72.3
DUCKEL	21	5.4 ± 0.5	391 ± 3.6
Boom	21	$150\!\pm\!15$	$1085\!\pm\!108$
Arm	22	5.4±0.5	39.1±3.6



(3) Overall assemble

- Place a V-block on a rigid work bench. Mount the tube assembly (1) on it and fix the assembly by passing a bar through the clevis pin hole to lock the assembly.
- ② Insert the rod assembly in to the tube assembly, while lifting and moving the rod assembly with a crane.
- * Be careful not to damage piston seal by thread of tube assembly.
- ③ Match the bolt holes in the cylinder head flange to the tapped holes in the tube assembly and tighten socket bolts to a specified torque.
- * Refer to the table of tightening torque.







GROUP 10 UNDERCARRIAGE

1. TRACK LINK

1) REMOVAL


- (1) Move track link until master pin is over front idler in the position put wooden block as shown.
- (2) Loosen tension of the track link.
- If track tension is not relieved when the grease valve is loosened, move the machine backwards and forwards.
- (3) Push out master pin by using a suitable tool.
- (4) Move the machine slowly in reverse, and lay out track link assembly (1).
- * Jack up the machine and put wooden block under the machine.
- * Don't get close to the sprocket side as the track shoe plate may fall down on your feet.





2) INSTALL


- (1) Carry out installation in the reverse order to removal.
- * Adjust the tension of the track link.




2. CARRIER ROLLER

1) REMOVAL


(1) Loosen tension of the track link.



(2) Jack up the track link height enough to permit carrier roller removal.



- (3) Loosen the lock nut (1).
- (4) Open bracket (2) with a screwdriver, push out from inside, and remove carrier roller assembly.
 - \cdot Weight : 40 kg (88 lb)




2) INSTALL

(1) Carry out installation in the reverse order to removal.


3. TRACK ROLLER

1) REMOVAL


(1) Loosen tension of the track link.



- (2) Using the work equipment, push up track frame on side which is to be removed.
- * After jack up the machine, set a block under the unit.



(3) Remove the mounting bolts (1) and draw out the track roller (2).Weight : 80 kg (176.4 lb)




2) INSTALL

(1) Carry out installation in the reverse order to removal.


4. IDLER AND RECOIL SPRING

1) REMOVAL


(1) Remove the track link. For detail, see removal of track link.



- (2) Sling the recoil spring (1) and pull out idler and recoil spring assembly from track frame, using a pry.
 - · Weight : 420 kg (930 lb)




(3) Remove the bolts (2), washers (3) and separate ilder from recoil spring.




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- Make sure that the boss on the end face of the recoil cylinder rod is in the hole of the track frame.



3) DISASSEMBLY AND ASSEMBLY OF IDLER

(1) Structure



36078UC01

1 Shell

2

3

Bushing


Shaft

- 4 O-ring
 - 5 Seal assembly
 - 6 Bracket


- 7 Spring pin
- 8 Plug

(2) Disassembly


- 1 Remove plug and drain oil.
- ② Draw out the spring pin (7), using a press.



- \bigcirc Pull out the shaft (3) with a press.
- ④ Remove seal (5) from shell (1) and bracket (6).
- ⁽⁵⁾ Remove O-ring (4) from shaft.



- ⁽⁶⁾ Remove the bushing (2) from shell, using a special tool.
- * Only remove bushing if replacement is necessity.





(3) Assembly

- * Before assembly, clean the parts.
- * Coat the sliding surfaces of all parts with oil.
- Cool up bushing (2) fully by some dry ice and press it into shell (1).


Do not press it at the normal temperature, or not knock in with a hammer even after the cooling.

- ⁽²⁾ Coat O-ring (4) with grease thinly, and install it to shaft (3).
- ③ Insert shaft (3) into bracket (6) and drive in the spring pin (7).







4 Install seal (5) to shell (1) and bracket (6).




⁽⁵⁾ Install shaft (3) to shell (1).




⁽⁶⁾ Install bracket (6) attached with seal (5).



⑦ Knock in the spring pin (7) with a hammer.




 & Lay bracket (6) on its side.
 Supply engine oil to the specified level, and tighten plug.



4) DISASSEMBLY AND ASSEMBLY OF RECOIL SPRING

(1) Structure




36078UC02


- 1 Body
- 2 Tie bar
- 3 Spring
- 4 Bracket
- 5 Lock nut


- 6 Lock plate
- 7 Hexagon bolt
- 8 Spring washer
- 9 Rod packing
- 10 Back up ring
- 11 Dust seal
- 12 Rod
- 13 Grease valve
- 14 Tube stopper
- 15 Spring pin

(2) Disassembly

- \bigcirc Apply pressure on spring (3) with a press.
- * The spring is under a large installed load. This is dangerous, so be sure to set properly.
- $\cdot~$ Spring set load : 21100 $\pm~$ 1688 kg (46517 $\pm~$ 3721 lb)
- ② Remove bolt (7), spring washer (8) and lock plate (6).
- ③ Remove lock nut (5). Take enough notice so that the press which pushes down the spring, should not be slipped out in its operation.
- ④ Lighten the press load slowly and remove bracket (4) and spring (3).
- ⁽⁵⁾ Remove rod (12) from body (1).
- ⁽⁶⁾ Remove grease valve (13) from rod (12).








Remove rod packing (9), back up ring (10) and dust seal (11).

(3) Assembly


- Install dust seal (11), back up ring (10) and rod packing (9) to body (1).
- When installing dust seal (11) and rod packing (9), take full care so as not to damage the lip.




② Pour grease into body (1), then push in rod (12) by hand.


After take grease out of grease valve mounting hole, let air out.

- If air letting is not sufficient, it may be difficult to adjust the tension of crawler.
- ③ Fit grease valve (13) to rod (12).
 •Tightening torque : 13±1.0 kgf·m (94±7.2 lbf·ft)
- ④ Install spring (3) and bracket (4) to body (1).
- (5) Apply pressure to spring (3) with a press and tighten lock nut (5).
- * Apply sealant before assembling.
- During the operation, pay attention specially to prevent the press from slipping out.






- ⁽⁶⁾ Lighten the press load and confirm the set length of spring (3).
- ⑦ After the setting of spring (3), install lock plate (6), spring washer (8) and bolt (7).



GROUP 11 WORK EQUIPMENT

1. STRUCTURE




21078DA44

2. REMOVAL AND INSTALL


1) BUCKET ASSEMBLY

(1) Removal


① Lower the work equipment completely to ground with back of bucket facing down.




② Remove nuts (1), bolt (2) and draw out the pin (B).



③ Remove nuts (3), bolt (4) and draw out the pin (A).



- Carry out installation in the reverse order to removal.
- A When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- Adjust the bucket clearance.
 For detail, see operator's manual.





2) ARM ASSEMBLY


(1) Removal

- * Loosen the breather slowly to release the pressure inside the hydraulic tank.
- A Escaping fluid under pressure can penetrated the skin causing serious injury.
- Remove bucket assembly.
 For details, see removal of bucket assembly.
- ② Disconnect bucket cylinder hose(1).
- ▲ Fit blind plugs (5) in the piping at the chassis end securely to prevent oil from spurting out when the engine is started.
- ③ Sling arm cylinder assembly, remove spring, pin stopper and pull out pin.
- Tie the rod with wire to prevent it from coming out.
 For details, see removal of arm cylinder assembly.
- ④ Place a wooden block under the cylinder and bring the cylinder down to it.
- ⑤ Remove bolt (2), plate (3) and pull out the pin (4) then remove the arm assembly.
 - Weight : 1243 kg(2740 lb)
- When lifting the arm assembly, always lift the center of gravity.

- ① Carry out installation in the reverse order to removal.
- A When lifting the arm assembly, always lift the center of gravity.
- * Bleed the air from the cylinder.







3) BOOM ASSEMBLY


(1) Removal


- 1 Remove arm and bucket assembly.
- $_{\ensuremath{\textcircled{O}}}$ For details, see removal of arm and bucket assembly.

Remove boom cylinder assembly from boom.


For details, see removal of arm cylinder assembly.

- ③ Disconnect head lamp wiring.
- Disconnect bucket cylinder hoses (2) and arm cylinder hoses (1).
- When the hoses are disconnected, oil may spurt out.
- (5) Sling boom assembly (3).






- 6 Remove bolt (4), plate (5) and pull out the pin (6) then remove boom assembly.
 Weight : 2600 kg (5730 lb)
- * When lifting the boom assembly always lift the center of gravity.



- ① Carry out installation in the reverse order to removal.
- A When lifting the arm assembly, always lift the center of gravity.
- * Bleed the air from the cylinder.



SECTION 9 COMPONENT MOUNTING TORQUE


Group	1 Introduction guide ······	9-1
	2 Engine system ·····	
Group	3 Electric system	9-4
Group	4 Hydraulic system	9-6
Group	5 Undercarriage	9-9
Group	6 Structure	9-10
Group	7 Work equipment	9-14

SECTION 9 COMPONENT MOUNTING TORQUE GROUP 1 INTRODUCTION GUIDE

- 1. This section shows bolt specifications and standard torque values needed when mounting components to the machine.
- Use genuine Hyundai spare parts. We expressly point out that Hyundai will not accept any responsibility for defects resulted from non-genuine parts.


In such cases Hyundai cannot assume liability for any damage.

- * Only metric fasteners can be used and incorrect fasteners may result in machine damage or malfunction.
- Before installation, clean all the components with a non-corrosive cleaner.
 Bolts and threads must not be worn or damaged.



GROUP 2 ENGINE SYSTEM


ENGINE AND ACCESSORIES MOUNTING



38099CM01

Item	Size	kgf ∙ m	lbf ⋅ ft	ltem	Size	kgf ∙ m	lbf ∙ ft
1	M 8×1.25	2.5±0.5	18.1±3.6	4	M12×1.75	12.8±3.0	92.6±21.7
2	M10×1.5	6.9±1.4	49.9±10.1	5	M24×3.0	90±7.0	651 ± 51
3	M12×1.75	10.0±2.0	72.3±14.5	-	-	-	-

COOLING SYSTEM AND FUEL TANK MOUNTING




38099CM02

Item	Size	kgf ∙ m	lbf ∙ ft
1	M 6×1.0	0.5±0.2	3.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6
3	M10×1.5	6.9±1.4	49.4±10.1
4	M12×1.75	12.8±3.0	92.6±21.7

Item	Size	kgf ∙ m	lbf ∙ ft
5	M16×2.0	29.7±4.5	215±32.5
6	M20×2.5	46±5.1	333±36.9
7	-	2.3±0.6	16.6±4.3
-	-	-	-

GROUP 3 ELECTRIC SYSTEM


ELECTRIC COMPONENTS MOUNTING 1



Item	Size	kgf ∙ m	lbf ⋅ ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6

Item	Size	kgf ∙ m	lbf ∙ ft
3	M10×1.5	6.9±1.4	49.9±10.1
4	M12×1.75	12.8±3.0	92.6±21.7


ELECTRIC COMPONENTS MOUNTING 2



Item	Size	kgf ∙ m	lbf ∙ ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6

Item	Size	kgf ∙ m	lbf ∙ ft
3	M10×1.5	6.9±1.4	49.9±10.1
-	-	-	-

GROUP 4 HYDRAULIC SYSTEM




HYDRAULIC COMPONENTS MOUNTING 1



Item	Size	kgf ∙ m	lbf ⋅ ft
1	M 6×1.0	1.05±0.2	7.6±1.45
2	M 8×1.25	2.5±0.5	18.1±3.6
3	M10×1.5	5.3±0.5	38.3±3.6
4	M10×1.5	6.9±1.4	49.9±10.1
5	M12×1.75	12.3±1.3	92.5±21.6

Item	Size	kgf ∙ m	lbf ⋅ ft
6	M16×2.0	29.7±4.5	215±32.5
7	M20×2.5	42±4.5	304±32.5
8	M20×2.5	46±5.1	333±36.9
9	M20×2.5	46.5±2.5	336±18.1
10	M24×3.0	97.8±15	707±108

HYDRAULIC COMPONENTS MOUNTING 2




38099CM06

\cdot Tightening torque

Item	Size	kgf ∙ m	lbf ∙ ft
1	M 8×1.25	4.05±0.8	29.3±5.8
2	M10×1.5	6.9±1.4	49.9±10.1
3	M12×1.75	12.3±1.3	88.9±9.4

Item	Size	kgf ∙ m	lbf ⋅ ft		
4	M12×1.75	12.8±3.0	92.6±21.7		
5	M16×2.0	29.7±4.5	215±32.5		
6	M20×2.5	58±6.0	420±43.4		

HYDRAULIC COMPONENTS MOUNTING 3



ARM CYLINDER

BUCKET CYLINDER

38099CM07


Item	Size	kgf ∙ m	lbf ∙ ft
1	M10×1.5	3.2±0.3	23.1±2.2
2	M12×1.75	5.5±0.6	39.8±4.3
3	M12×1.75	9.4±1.0	68.0±7.2
4	M16×2.0	14±1.4	101 ± 10.1

Item	Size kgf · m		lbf ⋅ ft		
5	M20×2.5	46±5.0	333±36.2		
6	M22×2.5	63±6.0	456±43.4		
7	M22×2.5	4.1	29.6		
8	M27×3.0	5.1	36.9		

GROUP 5 UNDERCARRIAGE

UNDERCARRIAGE MOUNTING


ADJUST COMPONENT



Item	Size	kgf ∙ m	lbf ⋅ ft	Item	Size	kgf ∙ m	lbf ∙ ft
1	M10×1.5	6.9±1.4	49.9±10.1	6	M20×2.5	57±3.0	412±21.7
2	M12×1.75	12.8±3.0	92.6±21.7	7	M22×2.5	77.4±11	560±79.6
3	M12×1.25	13.3±2.7	96.2±19.5	8	M24×1.5	140±5.0	1010±36
4	M16×2.0	29.7±4.0	215±28.9	9	M24×3.0	97.8±10	707±72.3
5	M16×2.0	26.6±3.2	214±23.1	10	$M24 \times 3.0$	77.4±11	560±79.6

GROUP 6 STRUCTURE

CAB AND ACCESSORIES MOUNTING




38099CM09

Item	Size	kgf ∙ m	lbf ∙ ft
1	M 6×1.0	0.49±0.1	3.5±0.7
2	M 8×1.25	2.5±0.5	18.1±3.6
3	M10×1.5	4.7±0.9	34±6.5

Item	Size	kgf ∙ m	lbf ∙ ft
4	M10×1.5	6.9±1.4	49.9±10.1
5	M12×1.75	12.8±3.0	92.6±21.7
-	-	-	-

CAB INTERIOR MOUNTING




38099CM10

lbf · ft

49.9±10.1 59.8±12.3 215±32.5

Item	Size	kgf ∙ m	lbf ⋅ ft	Item	Size	kgf ∙ m
1	M 6×1.0	0.49±0.1	3.5±0.7	4	M10×1.5	6.9±1.4
2	M 8×1.25	$4.05\!\pm\!0.8$	29.3±5.8	5	M10×1.5	8.27±1.7
3	M 8×1.25	2.5±0.5	18.1±3.6	6	M16×2.0	29.7±4.5


COWLING MOUNTING



Tightening torque	•	Tightening	torque
-------------------	---	------------	--------

Item	Size	kgf ∙ m	lbf ⋅ ft	Item	Size	kgf ∙ m	lbf ∙ ft
1	M 8×1.25	2.5±0.5	18.1±3.6	3	M12×1.75	12.8±3.0	92.6±21.7
2	M10×1.5	6.9±1.4	49.9±10.1	4	M16×2.0	29.7±4.5	215±32.5

COUNTERWEIGHT AND COVERS MOUNTING




38099CM12

Item	Size	kgf ∙ m	lbf ∙ ft
1	M10×1.5	6.9±1.4	49.9±10.1
2	M12×1.75	12.8±3.0	92.6±21.7

Item	Size	kgf ∙ m	lbf ∙ ft
3	M36×3.0	308±46	2228±333
-	-	-	-

GROUP 7 WORK EQUIPMENT



38099CM13

•	Tighte	ning	torg	ue

Item	Size	kgf ∙ m	lbf ⋅ ft
1	M16×2.0	29.7±4.5	215±32.5
2	M20×2.5	57.9±8.7	419±62.9
3	M22×2.5	81.9±16.1	592±116

Item	Size	kgf ∙ m	lbf ⋅ ft
4	M24×30	100±15	723±108
5	M30×3.5	199±30	1439±217
-	-	-	-