


SECTION 4 ELECTRICAL SYSTEM

| | |
|--|-------|
| Group 1 Component Location | 4-1 |
| Group 2 Monitoring system | 4-3 |
| Group 3 Electrical Circuit | 4-63 |
| Group 4 Electrical Component Specification | 4-82 |
| Group 5 Connectors | 4-91 |
| Group 6 Fault codes | 4-110 |

SECTION 4 ELECTRICAL SYSTEM

GROUP 1 COMPONENT LOCATION


1. LOCATION 1



55W9A4EL01

| | | | | | |
|---|--------------------------|----|-----------------------------|----|---------------------------|
| 1 | Head light switch | 10 | Cluster | 19 | DPF switch |
| 2 | Work light switch | 11 | Hazard switch | 20 | Master switch |
| 3 | Travel alarm switch | 12 | Select switch | 21 | Fuse box |
| 4 | Cab light switch | 13 | Multifunction switch (RH) | 22 | Speaker |
| 5 | Beacon switch | 14 | Quick clamp switch (opt) | 23 | Radio & USB player |
| 6 | Breaker selection switch | 15 | Boom offset switch | 24 | Cigar light |
| 7 | Start switch | 16 | Auto ram lock switch | 25 | Horn switch |
| 8 | Breaker operation switch | 17 | Overload switch (opt) | 26 | Aircon and heater switch |
| 9 | Accel dial switch | 18 | Air compressor switch (opt) | 27 | Multifunction switch (LH) |

2. LOCATION 2



- | | | |
|-------------------------|------------------------------|------------------------|
| 1 Horn | 6 Fuel filler pump | 11 Combination lamp |
| 2 Head lamp | 7 Washer pump | 12 Number plate lamp |
| 3 Flasher position lamp | 8 Filler pump toggle switch | 13 Relays |
| 4 Battery | 9 Machine control unit (MCU) | 14 Travel alarm buzzer |
| 5 Battery relay | 10 Fuel sender | |

GROUP 2 MONITORING SYSTEM (machine serial No.:~#0578)

1. OUTLINE

Monitoring system consists of the monitor part and switch part.

The monitor part gives warnings when any abnormality occurs in the machine and informs the condition of the machine.

Various select switches are built into the monitor panel, which act as the control portion of the machine control system.

2. CLUSTER

1) MONITOR PANEL



55W9A4EL20

3. CLUSTER FUNCTION

1) GAUGES AND DISPLAYS

(1) Operation screen

When you first turn starting switch ON, the operation screen will appear.




- | | | |
|-----------------------------|--------------------|--------------|
| 1 Engine coolant temp gauge | 3 Fuel level gauge | 5 Accel dial |
| 2 Hydraulic oil temp gauge | 4 Engine rpm | |

* Operation screen type can be set by the screen type menu of the display.


Refer to page 4-22 for details.

(2) Engine coolant temperature gauge



- ① This gauge indicates the temperature of coolant.
 - Black range : 40-115°C (104-239°F)
 - Red range : Above 115°C (239°F)
 - ② If the indicator is in the red range or lamp lights ON in red, turn OFF the engine and check the engine cooling system.
- * If the gauge indicates the red range or lamp lights ON in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(3) Hydraulic oil temperature gauge




- ① This gauge indicates the temperature of hydraulic oil.
 - Black range : 40-105°C (104-221°F)
 - Red range : Above 105°C (221°F)
 - ② If the indicator is in the red range or lamp lights ON in red, reduce the load on the system. If the gauge stays in the red range, stop the machine and check the cause of the problem.
- * If the gauge indicates the red range or lamp lights ON in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(4) Fuel level gauge




- ① This gauge indicates the amount of fuel in the fuel tank.
- ② Fill the fuel when the red range, or lamp lights ON in red.
- * If the gauge indicates the red range or lamp lights ON in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(5) Engine rpm display



- ① This displays the engine speed.

(6) Accel dial display



- ① This displays acceleration dial level from 0 to 10 step.

3) COMMUNICATION ERROR AND LOW VOLTAGE WARNING POP-UP

(1) Communication error pop-up




- ① Cluster displays this communication error pop-up when it has communication error with MCU.
- ② Communication error pop-up displays at operation screen only. Just buzzer alarm at the other screen.
- ③ If communication with MCU become normal state, it will disappear automatically.

(2) Low voltage warning pop-up



- ① Cluster displays this low voltage warning pop-up when the battery voltage is low.
- ② Low voltage warning pop-up displays at operation screen only. Just buzzer alarm at the other screen.
- ③ This pop-up will disappear with using touch screen or buzzer stop switch. While the battery voltage is low, buzzer sounds every minute.
- ④ When the battery voltage is higher than 11.5 V, the pop-up off.


4) WARNING LAMPS



559A3CD08EA


- ※ Each warning lamp on the left-top of the LCD pops up on the center of LCD and the buzzer sounds when the each warning is happened. The pop-up warning lamp moves to the original position and lights ON when the buzzer stop switch is pushed or the pop-up is touched. And the buzzer stops. Refer to page 4-14 for the switch.
- ※ When the warning lamps light ON more than 4, you can check all lamps with next page button (\leftarrow , \rightarrow) near the warning lamps.

(1) Engine coolant temperature warning lamp




- ① The lamp pops up on the center of LCD and the buzzer sounds when the engine coolant temperature is over 115°C.
- ② The pop-up lamp moves to the original position and lights ON when the buzzer stop switch is pushed or pop-up is touched. Also, the buzzer stops and lamp keeps ON.
- ③ Check the cooling system when the lamp keeps ON.

(2) Hydraulic oil temperature warning lamp



- ① The lamp pops up on the center of LCD and the buzzer sounds when the hydraulic oil temperature is over 105°C.
- ② The pop-up lamp moves to the original position and lights ON when the buzzer stop switch is pushed or pop-up is touched. Also, the buzzer stops and lamp keeps ON.
- ③ Check the hydraulic oil level and hydraulic oil cooling system.

(3) Fuel level warning lamp



- ① This warning lamp lights ON and the buzzer sounds when the level of fuel is below 10%.
- ② Fill the fuel immediately when the lamp is ON.


(4) Emergency warning lamp



21093CD30

- ① This lamp pops up and the buzzer sounds when each of the below warnings are happened.
 - Engine coolant overheating (over 115°C)
 - Hydraulic oil overheating (over 105°C)
 - MCU input voltage abnormal
 - Accel dial circuit abnormal or open
- ※ The pop-up warning lamp moves to the original position and lights ON when the buzzer stop switch is pushed or pop-up is touched. Also the buzzer stops.
This is same as following warning lamps.
- ② When this warning lamp lights ON, machine must be checked and serviced immediately.


(5) Engine oil pressure warning lamp



21093CD32


- ① This lamp lights ON when the engine oil pressure is low.
- ② If the lamp lights ON, shut OFF the engine immediately.
Check oil level.

(6) Check engine warning lamp



- ① This lamp lights ON when the communication between MCU and engine ECM on the engine is abnormal, or if the cluster received any fault code from engine ECM.
- ② Check the communication line between them.
If the communication line is OK, then check the fault codes on the cluster.
- ③ Also, this lamp pops up when the level of DPF soot is high.
※ Refer to the page 4-8 for the DPF warning lamp.

(7) Battery charging warning lamp



21093CD34


- ① This lamp lights ON when the battery charging voltage is low.
- ② Check the battery charging circuit when this lamp is ON.

(8) Air cleaner warning lamp



- ① This lamp lights ON when the filter of air cleaner is clogged.
- ② Check the filter and clean or replace it.


(9) Overload warning lamp (opt)



21093CD36

- ① When the machine is overload, the overload warning lamp lights ON during the overload switch is ON. (if equipped)
- ② Reduce the machine load.
Initiate a manual regeneration

(10) DPF (diesel particulate filter) warning lamp




2609A3CD19

- ① This warning lamp lights ON or OFF when the regeneration is needed.
 - ② This warning lamp lights ON while DPF regeneration inhibit switch is in "Regeneration inhibited" state, when stationary regeneration is permitted.
 - ③ This warning lamp lights ON during reset regeneration standby or in back up mode.
 - ④ This warning lamp lights flash during reset regeneration standby DPF regeneration inhibit switch is in "Regeneration inhibited" state.
- ※ Consequences of delaying regeneration
- Poor performance caused by increasing exhaust gas pressure.
 - Higher fuel consumption
 - Shorter filter lifetime


| Condition | Warning lamp | | | Remedy |
|-------------|--------------|--------------------|-------------------|--|
| | DPF | Check engine or | Stop engine or | |
| Normal | Off | Off | Off | <ul style="list-style-type: none"> · Automatic regeneration |
| Soot low | On | Off | Off | <ul style="list-style-type: none"> · Push DPF switch to OFF position if DPF switch is in inhibit position. · Engine power may be reduced automatically (soot medium) |
| Soot midium | Blink | Off | Off | |
| Soot high | On | On | Off | <ul style="list-style-type: none"> · Engine power and speed will be reduced automatically · Initiate a manual regeneration |
| Stop | On | Off | On | <ul style="list-style-type: none"> · Stop the engine immediatary. · Please contact your Hyundai service center or local dealer. |

* Manual regeneration method of DPF




- * Manual regeneration applies if the machine is in a fireproof area and there is no plan to turn off the machine during the regeneration.
- ① Stop and park the machine.
- ② The accel dial to the lowest position and operate the engine in idling.
- ③ Pull the safety button and push the switch to position ② to initiate the manual regeneration of DPF.
- * Refer to the page 4-62 for the switch operation.
- * The engine speed may increase gradually to high idle rpm and DPF regeneration begins and it will take approximately 25~30 minutes.
- ④ When the manual regeneration starts, the DPF warning lamp turns OFF and the regeneration acknowledge lamp and HEST warning lamp will light ON during the regeneration function is operating.
- ⑤ The regeneration acknowledge lamp and HEST warning lamp will light OFF when the regeneration function is completed.

(11) HEST (High exhaust system temperature) warning lamp




- ① This warning lamp indicates, when illuminated, that exhaust temperatures are high due to regeneration of the DPF.
- ② The lamp will also illuminate during a manual regeneration.
- ③ When this lamp is illuminated, be sure the exhaust pipe outlet is not directed at any surface or material that can melt, burn, or explode.
- ⚠ When this lamp is illuminated, the exhaust gas temperature could reach 600°C [1112°F], which is hot enough to ignite or melt common materials, and to burn people.**
- * The lamp does not signify the need for any kind of equipment or engine service; It merely alerts the equipment operator to high exhaust temperatures. It will be common for the lamp to illuminate on and off during normal equipment operation as the engine completes regeneration.

(12) Emission system fail warning lamp



- ① This warning lamp indicates there are faults related to the emission system.
- ② The lamp lights ON when each of the below warnings is happened.
 - a. The EGR valve malfunctions.
 - b. Electrical malfunction of the EGR control sensors.
(disconnection, short)
 - c. Tampering with the EGR control sensors.
- ③ This warning lamp can be shown together with DPF warning lamp or engine fail lamp or engine stop warning lamp when diagnosis DPF systems.
- * Please contact your Hyundai service center or local dealer.


(13) DPF regeneration inhibit warning lamp



2609A3CD20

- ① This warning lamp indicates, when illuminated, the DPF switch is pushed inhibit position, therefore automatic and manual regeneration can not occur.
- ※ Refer to the page 4-62 for the DPF switch.


(14) DPF regeneration acknowledge warning lamp



559A3CD10


- ① This warning lamp lights ON stationary regeneration is in process.
- ② This warning lamp lights ON, when stationary regeneration is in process after DPF regeneration request switch is pressed and hold for more than 3 seconds.
- ③ This warning lamp lights flash when stationary regeneration standby or regeneration interlock switch is in "regeneration permitted (interlock enabled) status.
- ④ This warning lamp lights flash while stationary regeneration standby or back mode, when DPF regeneration inhibit switch in "Regeneration permitted" status and regeneration interlock switch is in regeneration permitted status.

(15) Stop engine warning lamp




- ① If the lamp lights ON, stop the engine immediately and check the engine.
- ② Check the fault codes on the monitor.
- ※ Please contact your Hyundai service center or local dealer.

(16) Brake oil pressure warning lamp



- ① The lamp lights ON when the oil pressure of service brake drops below the normal range.
- ② When the lamp is ON, stop the engine and check for its cause.
- ※ Do not operate until any problems are corrected.

5) PILOT LAMPS




55W9A3CD02

* When the pilot lamps light ON more than 3, you can check all lamps with next page button (◀, ▶).

(1) Mode pilot lamps


| No | Mode | Pilot lamp | Selected mode |
|----|----------------|-------------|----------------------------|
| 1 | Power mode | P | Heavy duty power work mode |
| | | S | Standard power mode |
| 2 | Travel mode | ◀ | Low speed traveling |
| | | ▶ | High speed traveling |
| 3 | Auto idle mode | 怠速 | Auto idle status |
| | | 怠速 n/min | Auto idle mode |

(2) Preheat pilot lamp



- ① Turning the start key switch ON position starts preheating in cold weather.
- ② Start the engine after this lamp is OFF.


(3) Warming up pilot lamp



21093CD40


- ① This lamp is turned ON when the coolant temperature is below 30°C(86°F).
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C, or when 10 minutes have passed since starting the engine.

(4) Auto idle status/ mode pilot lamp




- ① The auto idle pilot lamp will be ON when the idle mode is selected.
- ② The auto idle status pilot lamp will be ON when all levers and pedals are at neutral position, and the auto idle mode is selected.

(5) Maintenance pilot lamp



- ① This lamp will be ON when the consuming parts are needed to change or replace. It means that the change or replacement interval of the consuming parts remains below 30 hours.
- ② Check the message in maintenance information of main menu. Also, this lamp lights ON for 3 minutes when the start switch is ON position.
※ Refer to the page 4-20.


(6) Boom swing pilot lamp



559A3CD31

- ① This lamp is ON when the boom swing pedal is operated.


(7) High beam pilot lamp



55WI3CD50

- ① This lamp works when the illuminating direction is upward.
- ② This lamp comes ON when the dimmer switch is operated, e.g, when passing another vehicle.


(8) Parking brake pilot lamp



55W73CD04

- ① When the parking brake is actuated, the lamp lights ON.
※ Check the lamp is OFF before driving.

(9) Ram lock pilot lamp



20W73CD37

- ① This pilot lamp lights ON when ram lock switch is rear position.
- ② Also, the pilot lamp lights ON when the parking switch is ON or service brake is applied.


6) SWITCHES



559A3CD47

※ When the switches are selected, the pilot lamps are displayed on the LCD. Refer to the page 4-11 for details.


(1) Power mode switch



559A3CD25

- ① This switch is to select the machine power mode and selected power mode pilot lamp is displayed on the pilot lamp position.
 - P : Heavy duty power work.
 - S : Standard power work.
- ② The pilot lamp changes S → P → S in order.


(2) Select switch



5510CD50C

- ① This switch is used to select or change the menu and input value.
- ② Knob push
 - Long (over 2 sec) : Return to the operation screen
 - Medium (0.5~2 sec) : Return to the previous screen
 - Short (below 0.5 sec) : Select menu
- ③ Knob rotation
 - This knob changes menu and input value.
 - Right turning : Down direction / Increase input value
 - Left turning : Up direction / Decreased input value

(3) Auto idle/ buzzer stop switch



559A3CD50D

① This switch is used to activate or cancel the auto idle function.

※ Refer to the page 4-12 for details.

② The buzzer sounds when the machine has a problem.

In this case, push this switch and buzzer stops, but the warning lamp blinks until the problem is cleared.

(4) Travel speed control switch



55I33CD50B

① This switch is used to select the travel speed alternatively.

· : Low speed

· : High speed

(5) Escape/ Camera switch



559A3CD50E

① This switch is used to return to the previous menu or parent menu.

② In the operation screen, pushing this switch will display the view of the camera on the machine (if equipped).

Please refer to page 4-24 for the camera.

③ If the camera is not installed, this switch is used only ESC function.

7) MAIN MENU

· Operation screen



Tap
M or
Press
→
Press
ESC/CAM

Main menu screen



Sub menu screen



※ Please refer to select switch, page 4-14 for selection and change of menu and input value.

(1) Structure

| No | Main menu | Sub menu | Description |
|----|-----------------------------|--|---|
| 1 | Monitoring 55I3CD51A | Active fault - Machine Active fault - Engine Logged fault - Machine Logged fault - Engine Monitoring (Analog) Monitoring (Digital) - Input Monitoring (Digital) - Output | MCU ECU MCU ECU Machine information Switch status Output status |
| 2 | Management 55I3CD51B | ESL mode setting Change password Maintenance information Machine Information A/S phone number Service menu | ESL mode setting Password change Replacement, Change interval oils and filters Cluster, MCU, Engine, Machine A/S phone number, A/S phone number change Delete logged faults, Software download, Operating hour, power shift |
| 3 | Display 55I3CD51C | Clock Screen type Brightness setting Unit setting Language Calibration | Clock A type, B type, C type Manual, Auto Temperature, Pressure 12 language Calibrating the touch screen |
| 4 | Utilities 55I3CD51D | Camera setting Mode Video | Number of active, Display order, Camera No. Operation mode select Play music and video file |

(2) Monitoring

① Active fault - Machine



- The active faults of the MCU can be checked by this menu.

② Active fault - Engine



- The active faults of engine ECU can be checked by this menu.

③ Logged fault - Machine/ Engine



- The logged faults of the MCU or engine ECU can be checked by this menu.
- Only for the service person.

④ Monitoring (Analog)



- The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu.

⑤ Monitoring (Digital) - Input



- The switch status can be confirmed by this menu.
- The activated switchs are blue light ON.

⑥ Monitoring (Digital) - Output



- The output status can be confirmed by this menu.
- The output pilot lamps are blue light ON.

(3) Management

① ESL mode setting



· ESL mode setting

- ESL : Engine Starting Limit
- ESL mode is designed to be a theft deterrent or will prevent the unauthorized operation of the machine.
- If the ESL mode was selected Enable, the password will be required when the start switch is turned ON.
- Disable : Not used ESL function

Enable (always) : The password is required whenever the operator starts engine.

Enable (Interval): The password is required when the operator starts engine first.

But the operator can restart the engine within the interval time without inputting the password.

The interval time can be set maximum 2 days.

※ Default password : 00000

※ Password length : 5~10 digit

② Change password

- The password is 5~10 digits.



Enter the current password

Enter the new password



The new password is stored in the MCU.

Enter the new password again

③ Maintenance information



- Elapse : Maintenance elapsed time.
- Interval : The change or replace interval can be changed in the unit of 50 hours.
- History-Hour : Maintenance replacement history.
- Replacement : The elapsed time will be reset to zero (0).
- **Change or relpace interval**

| No | Item | Interval |
|----|-----------------------------|----------|
| 1 | Engine oil | 500 |
| 2 | Final gear oil | 1000 |
| 3 | Swing gear oil | 1000 |
| 4 | Hydraulic oil | 5000 |
| 5 | Pilot line filter | 1000 |
| 6 | Hydraulic oil return filter | 1000 |
| 7 | Engine oil filter | 500 |
| 8 | Fuel filter | 500 |
| 9 | Pre-filter | 500 |
| 10 | Hydraulic tank breather | 250 |
| 11 | Air cleaner | 500 |
| 12 | Radiator coolant | 2000 |
| 13 | Swing gear pinion grease | 1000 |

④ Machine Information



- This can confirm the identification of the cluster, MCU, engine and machine.

⑤ A/S phone number



- The A/S phone number can be checked and changed.

⑥ Service menu



- Delete logged fault : Logged faults of MCU or engine ECU can be deleted.
- S/W download : Update and display software about operating system, application, image and font.
- Operating hours : Operating hours since the machine line out can be checked.
- Power shift : Set power shift mode (standard/option)

(4) Display

① Clock




- The first line's three spots "****-**-**" represent Year/Month/Day each.
- The second line shows the current time. (AM, PM/0:00~12:59)

② Screen type



- The screen type (A,B,C) of the LCD can be selected by this menu.

③ Brightness setting calibration



- If "Auto" is chosen, brightness for day and night can be differently set up. Also, users can define which day time interval. (Set day starting time and ending time)

④ Unit setting



- Temperature : $^{\circ}\text{C} \leftrightarrow ^{\circ}\text{F}$
- Pressure : bar \leftrightarrow MPa \leftrightarrow kgf/cm 2 \leftrightarrow psi


⑤ Language



- User can select preferable language and all displays are changed the selected language.

⑥ Calibration

- When touch awareness goes wrong, this function use.
Fall in the next step if touches the middle point of cross with fingernail.
If touches total five points as follows, the setting is completed.



(5) Utilities

① Camera setting

- Three cameras can be installed on the machine and the display order can be set by this menu.
- If the camera was not equipped, this menu is not useful.



- In the operation screen, if the ESC/CAM switch is pushed, rear view camera display or stop.
- Turning the select switch in clockwise direction, the next ordered will be shown and in counter-clockwise direction, the previously ordered will be shown. Also, you can change camera channel using touch the screen.
- Push the select switch or touch the screen, the displayed screen will be enlargement.




② Mode



- When this cluster's buttons are not work, you can control using touch screen instead of these buttons.
- You can only control in this mode screen.

③ Video

- Play MP4 or codec file of external hard disk through USB port.
- The USB port is located under the cluster.



- Over 1100 engine rpm, the screen turns into the operation screen with MP4 or codec file playing for the safety.

| No. | Function | Control | No. | Function | Control |
|-----|------------------|----------------------------|-----|-----------------------------|-------------------------|
| 1 | Previous track | Power mode switch or touch | 7 | Sound volume | Speed switch or touch |
| 2 | Next track | Speed switch or touch | 8 | Stop | ESC/CAM button or touch |
| 3 | Play | Touch | 9 | File name | - |
| 4 | Pause | Touch | 10 | Current time/ Total time | - |
| 5 | Contents display | Touch | 11 | Current playing time | - |
| 6 | Mute | Touch | - | - | - |

MONITORING SYSTEM (machine serial No.: #0579~)

1) STRUCTURE

The cluster consists of LCD and switches as shown below. The LCD is to warn the operator in case of abnormal machine operation or conditions for the appropriate operation and inspection.

Also, The LCD is to set and display for modes, monitoring and utilities with the switches.

The switches or touch screen are to set the machine operation modes.

- ※ The cluster installed on this machine does not entirely guarantee the condition of the machine.
Daily inspection should be performed according to chapter 6, Maintenance.
- ※ When the cluster provides a warning immediately check the problem, and perform the required action.



HX60A3CD100B

- ※ The warning lamp pops up, lights ON (on the left-top side) and the buzzer sounds when the machine has a problem.

The warning lamp lights ON until the problem is cleared. Refer to page 4-29 for details.

2) GAUGE

(1) Operation screen

When you first turn starting switch ON, the operation screen will appear.



HX60A3CD101A

- 1 Engine coolant temp gauge
2 Hydraulic oil temp gauge

- 3 Fuel level gauge
4 Engine rpm

- 5 Accel dial
6 Clinometer


(2) Engine coolant temperature gauge



290F3CD53

- ① This gauge indicates the temperature of coolant.
 - Black range : 40-115°C (104-239°F)
 - Red range : Above 115°C (239°F)
- ② If the indicator is in the red range or lamp lights ON in red, turn OFF the engine and check the engine cooling system.
※ If the gauge indicates the red range or lamp lights ON in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(3) Hydraulic oil temperature gauge



290F3CD54

- ① This gauge indicates the temperature of hydraulic oil.
 - Black range : 40-105°C (104-221°F)
 - Red range : Above 105°C (221°F)
- ② If the indicator is in the red range or lamp lights ON in red, reduce the load on the system. If the gauge stays in the red range, stop the machine and check the cause of the problem.
※ If the gauge indicates the red range or lamp lights ON in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(4) Fuel level gauge



HX60A3CD55A

- ① This gauge indicates the amount of fuel in the fuel tank.
- ② Fill the fuel when the red range, or  lamp lights ON in red.
- ※ If the gauge indicates the red range or  lamp lights ON in red even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

(5) Engine rpm display



HX60A3CD105K

- ① This displays the engine speed.

(6) Accel dial display



290F3CD59

- ① This displays acceleration dial level from 0 to 10 step.

3) COMMUNICATION ERROR AND LOW VOLTAGE WARNING POP-UP

(1) Communication error pop-up



HX60A3CD107A

- ① Cluster displays this communication error pop-up when it has communication error with MCU.
- ② Communication error pop-up displays at operation screen only. Just buzzer alarm at the other screen.
- ③ If communication with MCU become normal state, it will disappear automatically.


(2) Low voltage warning pop-up



HX60A3CD108

- ① Cluster displays this low voltage warning pop-up when the battery voltage is low.
- ② Low voltage warning pop-up displays at operation screen only. Just buzzer alarm at the other screen.
- ③ This pop-up will disappear with using touch screen or buzzer stop switch. While the battery voltage is low, buzzer sounds every minute.
- ④ When the battery voltage is higher than 11.5 V, the pop-up off.


4) WARNING LAMPS



HX60A3CD109C

- ※ Each warning lamp on the left-top of the LCD pops up on the center of LCD and the buzzer sounds when the each warning is happened. The pop-up warning lamp moves to the original position and lights ON when the buzzer stop switch is pushed or the pop-up is touched. And the buzzer stops. Refer to page 4-38 for the switch.
- ※ When the warning lamps light ON more than 4, you can check all lamps with next page button (◀, ▶) near the warning lamps.


(1) Engine coolant temperature warning lamp



290F3CD61

- ① The lamp pops up on the center of LCD and the buzzer sounds when the engine coolant temperature is over 115°C or more.
- ② The pop-up lamp moves to the original position and lights ON when the buzzer stop switch is pushed or pop-up is touched. Also, the buzzer stops and lamp keeps ON.
- ③ Check the cooling system when the lamp keeps ON.


(2) Hydraulic oil temperature warning lamp



290F3CD62

- ① The lamp pops up on the center of LCD and the buzzer sounds when the hydraulic oil temperature is over 105°C or more.
- ② The pop-up lamp moves to the original position and lights ON when the buzzer stop switch is pushed or pop-up is touched. Also, the buzzer stops and lamp keeps ON.
- ③ Check the hydraulic oil level and hydraulic oil cooling system.

(3) Fuel level warning lamp



290F3CD63

- ① This warning lamp lights ON and the buzzer sounds when the level of fuel is below 10%.
- ② Fill the fuel immediately when the lamp is ON.


(4) Emergency warning lamp



290F3CD64

- ① This lamp pops up and the buzzer sounds when each of the below warnings are happened.
 - Engine coolant overheating (over 115°C)
 - Hydraulic oil overheating (over 105°C)
 - MCU input voltage abnormal
 - Accel dial circuit abnormal or open
- ※ The pop-up warning lamp moves to the original position and lights ON when the buzzer stop switch is pushed or pop-up is touched. Also the buzzer stops.
This is same as following warning lamps.
- ② When this warning lamp lights ON, machine must be checked and serviced immediately.

(5) Engine oil pressure warning lamp



290F3CD65

- ① This lamp lights ON when the engine oil pressure is low.
- ② If the lamp lights ON, shut off the engine immediately. Check oil level.


(6) Check engine warning lamp



290F3CD66

- ① This lamp lights ON when the communication between MCU and engine ECM on the engine is abnormal, or if the cluster received any fault code from engine ECM.
- ② Check the communication line between them.
If the communication line is OK, then check the fault codes on the cluster.
- ③ Also, this lamp pops up when the level of DPF soot is high.
※ Refer to the page 4-31 for the DPF warning lamp.


(7) Battery charging warning lamp



290F3CD67

- ① This lamp lights ON when the battery charging voltage is low.
- ② Check the battery charging circuit when this lamp is ON.


(8) Air cleaner warning lamp



290F3CD68

- ① This lamp lights ON when the filter of air cleaner is clogged.
- ② Check the filter and clean or replace it.


(9) Overload warning lamp (option)



21093CD36

- ① When the machine is overload, the overload warning lamp lights ON during the overload switch is ON. (if equipped)
- ② Reduce the machine load.
Initiate a manual regeneration

(10) DPF (diesel particulate filter) warning lamp




2609A3CD19

- ① This warning lamp lights ON or OFF when the regeneration is needed.
 - ② This warning lamp lights ON while DPF regeneration inhibit switch is in "Regeneration inhibited" state, when stationary regeneration is permitted.
 - ③ This warning lamp lights ON during reset regeneration standby or in back up mode.
 - ④ This warning lamp lights flash during reset regeneration standby DPF regeneration inhibit switch is in "Regeneration inhibited" state.
- * Consequences of delaying regeneration
- Poor performance caused by increasing exhaust gas pressure.
 - Higher fuel consumption
 - Shorter filter lifetime

| Condition | Warning lamp | | | Remedy |
|-------------|--------------|------------------------------|-----------------------------|--|
| | DPF | Check engine (pop up) | Stop engine (pop up) | |
| Normal | Off | Off | Off | <ul style="list-style-type: none"> - Automatic regeneration |
| Soot low | On | Off | Off | <ul style="list-style-type: none"> - Push DPF switch to OFF position if DPF switch is in inhibit position. (see 4-62 page) - Engine power may be reduced automatically (soot medium) |
| Soot medium | Blink | Off | Off | |
| Soot high | On | On | Off | <ul style="list-style-type: none"> - Engine power and speed will be reduced automatically - Initiate a manual regeneration |
| Stop | On | Off | On | <ul style="list-style-type: none"> - Stop the engine immediatary. - Please contact your Hyundai service center or local dealer. |

* Manual regeneration method of DPF



- * Manual regeneration applies if the machine is in a fireproof area and there is no plan to turn off the machine during the regeneration.
- ① Stop and park the machine.
- ② Turn the accel dial to the lowest position and operate the engine in idling.
- ③ Pull the safety button and push the switch to position ② to initiate the manual regeneration of DPF.
- * Refer to the page 4-62 for the switch operation.
- * The engine speed may increase gradually to high idle rpm and DPF regeneration begins and it will take approximately 25~30 minutes.
- ④ When the manual regeneration starts, the DPF warning lamp turns OFF and the regeneration acknowledge lamp and HEST warning lamp will light ON during the regeneration function is operating.
- ⑤ The regeneration acknowledge lamp and HEST warning lamp will light OFF when the regeneration function is completed.


(11) HEST (High exhaust system temperature) warning lamp



2609A3CD21


- ① This warning lamp indicates, when illuminated, that exhaust temperatures are high due to regeneration of the DPF.
- ② The lamp will also illuminate during a manual regeneration.
- ③ When this lamp is illuminated, be sure the exhaust pipe outlet is not directed at any surface or material that can melt, burn, or explode.
- ⚠** When this lamp is illuminated, the exhaust gas temperature could reach 600°C [1112°F], which is hot enough to ignite or melt common materials, and to burn people.
- * The lamp does not signify the need for any kind of equipment or engine service; It merely alerts the equipment operator to high exhaust temperatures. It will be common for the lamp to illuminate on and off during normal equipment operation as the engine completes regeneration.

(12) Brake oil pressure warning lamp



- ① The lamp lights ON when the oil pressure of service brake drops below the normal range.
- ② When the lamp is ON, stop the engine and check for its cause.
- * Do not operate until any problems are corrected.


(13) Emission system fail warning lamp



300A3CD15

- ① This warning lamp indicates there are faults related to the emission system.
 - ② The lamp lights ON when each of the below warnings is happened.
 - a. The EGR valve malfunctions.
 - b. Electrical malfunction of the EGR control sensors.
(disconnection, short)
 - c. Tampering with the EGR control sensors.
 - ③ This warning lamp can be shown together with DPF warning lamp or engine fail lamp or engine stop warning lamp when diagnosis DPF systems.
- * Please contact your Hyundai service center or local dealer.


(14) DPF regeneration inhibit warning lamp



2609A3CD20

- ① This warning lamp indicates, when illuminated, the DPF switch is pushed inhibit position, therefore automatic and manual regeneration can not occur.
- * Refer to the page 4-62 for the DPF switch.

(15) DPF regeneration acknowledge warning lamp



559A3CD10

- ① This warning lamp lights ON stationary regeneration is in process.
- ② This warning lamp lights ON, when stationary regeneration is in process after DPF regeneration request switch is pressed and hold for more than 3 seconds.
- ③ This warning lamp lights flash when stationary regeneration standby or regeneration interlock switch is in "regeneration permitted (interlock enabled) status.
- ④ This warning lamp lights flash while stationary regeneration standby or back mode, when DPF regeneration inhibit switch is in "Regeneration permitted" status and regeneration interlock switch is in regeneration permitted status.

(16) Engine stop warning lamp



- ① If the lamp lights ON, stop the engine immediately and check the engine.
 - ② Check the fault codes on the monitor.
- * Please contact your Hyundai service center or local dealer.

5) PILOT LAMPS




HW60A3CD112C

- * The left and the right movement buttons (\blacktriangleleft and \triangleright) are activated when nine indicator or more light, and touching the button shifts to the previous/next page. The buttons are not activated when eight indicators or less light.

(1) Mode pilot lamp

| Sequence | Mode | Pilot lamp | Selected mode |
|----------|----------------|----------------------|----------------------------|
| 1 | Power mode | P | Heavy duty power work mode |
| | | S | Standard power mode |
| 2 | Travel mode | Low speed traveling | |
| | | High speed traveling | |
| 3 | Auto idle mode | Auto n/min | Auto idle mode |
| | | n/min | Auto idle status |


(2) Engine preheat pilot lamp



290F3CD79


- ① Turning the start switch ON automatically starts preheating.
- ② Start the engine after this indicator turns off.
See Page 4-4.

(3) Warming up pilot lamp



- ① This lamp is turned ON when the coolant temperature is below 30°C (86°F).
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C, or when 10 minutes have passed since starting the engine.

(4) Auto idle status/ mode pilot lamp




- ① The auto idle mode pilot lamp will be ON when the idle mode is selected.
- ② The auto idle status pilot lamp will be ON when all levers and pedals are at neutral position, and the auto idle mode is selected.
- ③ One of the lever or pedal is operated, the status lamp will be OFF and the engine speed returns to the previous conditions.

(5) Maintenance pilot lamp




- ① This lamp will be ON when the consuming parts are needed to change or replace. It means that the change or replacement interval of the consuming parts remains below 30 hours.
- ② Check the message in maintenance information of main menu. Also, this lamp lights ON for 3 minutes when the start switch is ON position.
※ Refer to the page 4-43.

(6) Fuel warmer pilot lamp




- ① This lamp is turned ON when the coolant temperature is below 10°C (50°F) or the hydraulic oil temperature 20°C (68°F).
- ② The automatic fuel warming is cancelled when the engine coolant temperature is above 60°C, and the hydraulic oil temperature is above 45°C since the start switch was ON position.

(7) Optional flow control pilot lamp



- ① The indicator lights when activating (performing) the optional flow control function.
※ Refer to the Page 4-43.


(8) High beam pilot lamp



55WI3CD50

- ① This lamp works when the illuminating direction is upward.
- ② This lamp comes ON when the dimmer switch is operated, e.g., when passing another vehicle.

(9) Parking brake pilot lamp



55W73CD04

- ① When the parking brake is actuated, the lamp lights ON.
- ※ Check the lamp is OFF before driving.


6) SWITCHES



HX60A3CD117D

* Selecting the switch displays the indicator on LCD. See Page 4-34 for further information.


(1) Power mode switch



HX60A3CD118

- ① This switch selects the system power mode, and the selected power mode indicator is displayed on the indicator position.
 - P : High-load work
 - S : Standard load work
- ② The indicators shifts in the sequence of S → P → S.

(2) Select switch




HX60A3CD119

- ① The switch is used for selecting or changing the menus and input values.
- ② Knob pressing
 - Pressing short (0.5 sec. or less) : Menu selecting
- ③ Knob turning

This knob is used for changing menus and input values :

 - Right turning : Increasing downward direction and input value
 - Left turning : Decreasing upward direction and input value

(3) Auto idle switch



HX60A3CD120

- ① This switch is used for operating or canceling the auto idle function.

* See Page 4-34 for further information.

(4) Buzzer stop switch




HX60A3CD121

- ① The buzzer sounds when the system fails.

In such a case, press the switch to stop the buzzer. The alarm indication is kept lit until trouble is resolved.

(5) Camera switch




HX60A3CD122

- ① Pressing this switch on the operation screen of the main menu displays the area illuminated by the camera mounted on the system (if the camera is mounted).

See Page 4-53 for information of the camera.


(6) Escape switch



HX60A3CD123

- ① This switch is used for return to the previous or the next menu.

(7) Travel speed switch



HX60A3CD104

- ① This switch is used for changing driving speed.

↗ : High speed

↘ : Low speed

* Do not operate the driving speed switch during driving.

System stability may adversely be affected.

⚠ Rapid change of system stability may cause injury or death of driver.

7) MAIN MENU

Main menu screen



HX60A3CD124A

Tap
MENU
or

Press
SELECTOR
←
Press
ESC

Sub menu screen



HX60A3CD125A


- ※ See “Selection Switch” on page 4-37 for further information on selection and change of the menus and input values.
- ※ Touching the main menu switch, or pressing the selection switch prompts the sub-menu screen.

(1) Structure

| No. | Main menu | Sub-menu | Description |
|-----|---|---|---|
| 1 |  | Active fault Logged fault Delete logged fault Monitoring | List of active fault of system/engine List of logged fault of system/engine Deleting specifics of logged fault (system/engine) Monitoring (conditions of system, switch, and output) |
| 2 |  | Maintenance info. Aux flow setting ELS mode setting Machine information Contact Cluster update Service menu | Checking and initialization of service Interval of oil and filters Optional attachment setting ELS mode setting/user password changing Information of cluster, MCU, engine system Display and change of contact information for after-sales services System and application updating Power shift, Operation hours, Main gauge type, Display RPM, DPF filter exchange, AVCU setting, Adding language |
| 3 |  | Clock adjust Brightness setting Unit setting Language selection | Current time setting Manual, auto Temperature, Distance, Pressure, Flow, Volumn 24 languages |
| 4 |  | Entertainment Camera setting Clinometer setting Emergency mode | Video/music file playing Setup of number of active cameras, display sequences, and camera numbers Initializing slope sensor Back-up switch for failed cluster switch |


(2) Monitoring

① Active fault - system



- You may use this menu to check active fault of MCU.

② Active fault - engine




- You may use this menu to check active fault of engine ECM.

③ Logged fault - system/engine




- You may use this menu to check fault logged on system MCU or engine ECM.
- The menu is accessible by maintenance engineer only.

④ Delete logged fault



- Delete logged fault: You are allowed to delete fault logged on system MCU or engine ECM.
(Deletion can be deleted only while the engine is kept stopped.)

⑤ Monitoring (system conditions)



- You may use this menu to check the system conditions such as engine rotation rate, oil temperature, voltage and pressure.

⑥ Monitoring (switch conditions)



- You may use this menu to check digital switch information of the system.
- The operation switch lights blue.

⑦ Monitoring (output conditions)



- You may use this menu to check digital output information of the system.
- Output lights blue.

(3) Management

① Maintenance info.



- Elapsed: Time elapsed since inspection and maintenance is displayed.
- Change interval: You are allowed of changing exchange cycle in 50 hours.
- History-Hourmeter: History of inspection, maintenance and exchange is displayed.
- Replacement: Elapsed time is reset to zero.
- Change or replace interval**

| No | Item | Interval |
|----|-----------------------------|----------|
| 1 | Engine oil | 500 |
| 2 | Final gear oil | 1000 |
| 3 | Swing gear oil | 1000 |
| 4 | Hydraulic oil | 5000 |
| 5 | Pilot line filter | 1000 |
| 6 | Hydraulic oil return filter | 1000 |
| 7 | Engine oil filter | 500 |
| 8 | Fuel filter | 500 |
| 9 | Pre-filter | 500 |
| 10 | Hydraulic tank breather | 1000 |
| 11 | Air cleaner | 1000 |
| 12 | Radiator coolant | 2000 |
| 13 | Swing gear pinion grease | 1000 |

② Aux flow setting

a. Optional attachment setup



- Setup up to three optional attachments.


- Rotary grapple (4-way)
- Grapple (2-way)
- Auger (2-way)

* Each option attachment operating in one of two user modes (Type A and B)


b. Proportional flow control setting

You may use this menu to set the values of individual option attachments.

a) Rotary setup




- Rotary selecting
RCV, button, and flow setup.



- RCV setup
 - It is possible to set operating RCV for rotary operation to LH or RH .
 - Selecting rotary RCV to LH automatically sets grapple RCV to RH.



- Button setup (rotating clockwise)
 - Selecting clockwise rotating direction to LH automatically sets counterclockwise rotating direction to RH.



- Flow setup
 - You may set flow between Level 1 and 5.

b) Grapple setting



- Grapple selection
RCV, button and flow setup

- RCV setup
 - It is possible to set RCV for grapple operation to LH or RH.
 - Selecting grapple RCV to RH automatically sets rotary RCV to LH.


- Button setup (Close)
 - Setting Close to RH automatically sets Open to LH.

- Flow setup
 - Setting between Level 1 and 5.

- Never forget to select Change button **once** flow setting is complete.

- ※ Saved setting is stored in each icon, and value finally stored becomes active.
- ※ You may use any stored values by pressing Icon button.
- ※ It is possible to perform two user's settings per attachment (A and B), and to store up to six values.
(Two for 4-way, four for 2-way)

c) Checking settings



※ Operating optional attachment function activates the symbol  on the bottom of the main screen.

※ You are allowed of checking settings as follows in the course of Menu - Administrator Functions - Optional Attachment.

(a) Rotary setup

- Rotary RCV setup : LH
- Rotary flow level : 3
- CW direction control : LH
- CCW direction control : RH

(b) Grapple setup

- Grapple RCV setup : RH
- Grapple flow level : 3
- Open control : LH
- Close control : RH

③ ESL mode setting



- The ESL mode setting is designed to prevent theft and unauthorized operation of the system.
- When selecting the ESL mode setting to continuous operation, password should be entered when turning the Start button ON.
- Disabled : The ESL mode setting function does not operate.
Continuous operation : Password should be entered whenever operator starts the engine.
Enable(interval): Password should be entered when operator starts the engine first. It is not required to enter the password until restart within specified time.
You may set the specified time up to two days.

※ Default password : 00000

※ Length of password : 5-10 digits

④ Changing password

- The length of the password is between 5 and 10 digits.



Entering current password



Selecting Change Password



Storing new password in MCU



Entering new password again



Entering new password

⑤ Machine information



- On this screen, you may check information of the instrument panel, the system controller (MCU), the engine and the system.

⑥ Contact



- You may check or change the contact information for after-sales services.

⑦ Cluster update



Selecting Cluster Update



Entering user's password

- It is possible to update the cluster and CAN.

※ Do not turn power off while updating.

a. Application update



Selecting application items



Selecting files to update



Selecting OK




Completed




In progress

b. System update



⑧ Service menu




Entering service password

- Power shift : Set the power shift mode (default/option).
- Operating hours : You may check operating hours of the system in individual modes after acceptance of the system.
- Main gauge type : It is possible to display engine rotation rate or fuel level on the main gage of the main screen.
- Display RPM : It is possible to set display of numeric value of engine rotation rate on the main gauge of the main screen.
- DPF filter exchange : You may initialize parameters relevant to DPF of engine ECU after cleaning the DPF filter.
- AVCU setting : You may select Standard, 2-Way or 4-Way dependent upon the system options.
- Adding language : It is possible to update language displayed on the cluster when it is required to correct language.

* The service menu is accessible by maintenance engineer only. Do not attempt unauthorized adjustment.


(4) Display

① Clock adjust



- "****_**-**" on the first line indicates year/month/day.
- The second line indicates current time (00:00 - 12:59 am/pm)

② Brightness setting



- Selecting "Auto" allows setting brightness different in day and night. It is also allowed to set hours in daytime. (Setting beginning day time and ending day time)

③ Unit setting



- Metric: Units are changed to metric units.
- U.S. units: Units are changed to U.S. units.
- User setting : Units are changed to user setting.

| Item | Metric system | U.S. unit | User's setup |
|-------------|---------------|-----------|-------------------------------------|
| Temperature | °C | °F | °C, °F |
| Distance | km | mile | km, mile |
| Pressure | bar | Mpa | bar, Mpa, kgf/cm ² , psi |
| Flow | lpm | gpm | lpm, gpm |
| Volume | l | gal | l, gal |

④ Language selection



- You may select your language (from 24 languages), and all the information is displayed in the selected language.

(5) Utilities

① Entertainment



- You may play MP4 or CODEC files of detachable hard disk through USB port.
- USB port is on the left of the instrument panel.
- When engine rotation rate exceeds 1100 rpm or higher, the screen is switched to the operation screen even while MP4 or CODEC file is played for safety. When engine rotation rate drops to 1100 rpm or lower, animation clip is played again.

⚠ Do not play animation clip while operating the system to prevent risks of accident.

② Camera setting




- You may install three cameras on the system, and set display sequence on this menu.
- If no camera is installed, this menu is disabled.
- When rotating Select switch clockwise, the screen of the next camera is displayed. When rotating the switch counterclockwise, the screen of the previous camera is displayed. You may also change the camera channel by touching the screen.
- You may display or hide the mini instrument panel by pressing Select switch or touching the screen.

(Mini instrument panel displayed → hidden → displayed)



- Pressing ESC switch or touching X icon on the screen terminates the camera mode.

③ Clinometer setting




- Pressing "Default" when the system is kept on flat surface resets X and Y values to zero.
- You may check gradient of the system on the operating screen of the instrument panel.

④ Emergency mode




- When the switch or the acceleration dial of the monitor fails, the switch is displayed on LCD, and you are allowed to perform operation by touching the screen.
- Such operation is allowed only on this mode screen.

4. SWITCHES



55W9A3CD20

1) STARTING SWITCH




(1) There are three positions, OFF, ON and START.

- (OFF) : None of electrical circuits activate.
- |- (ON) : All the systems of machine operate.
- (START) : Use when starting the engine.

Release key immediately after starting.


- * Key must be in the ON position with engine running to maintain electrical and hydraulic function and prevent serious machine damage.

2) ACCEL DIAL




- (1) There are 10 dial setting.
- (2) Setting 1 is low idle and setting 10 is high idle.
 - By rotating the accel dial to right : Engine speed increased.
 - By rotating the accel dial to left : Engine speed decreased.

3) HEAD LIGHT SWITCH




- (1) This switch is used to operate the head light.
 - Press the switch once, the head light comes ON and the pilot lamp ON.
 - Press the switch once more, the head light and pilot lamp turn off.

4) WORK LIGHT




- (1) This switch is used to operate the work light.
 - Press the switch once, the work light comes ON and the pilot lamp ON.
 - Press the switch once more, the work light and pilot lamp turn off.

5) TRAVEL ALARM SWITCH




- (1) This switch is used to alarm surroundings when the machine travels to forward and backward.
- (2) On pressing this switch, the alarm operates only when the machine is traveling.

6) CAB LIGHT SWITCH




- (1) This switch turns on the cab light on the cab.

7) BEACON SWITCH (option)




- (1) This switch turns ON the rotary light on the cab.
- (2) The below indicator lamp is turned ON when operating this switch.

8) BREAKER SELECTION SWITCH (option)




- (1) This switch is used to operate breaker.
- * The breaker operates only when this switch is pressed.

9) QUICK CLAMP SWITCH (option)




- (1) This switch is used to engage or disengage the moving hook on quick clamp.

10) BOOM OFFSET SWITCH



- (1) This switch is used to swing the boom to the right or left direction.
- (2) The indicator lamp turned ON when selected this switch.

11) AUTO RAM LOCK SWITCH




(1) This switch activates front axle oscillation cylinder to locking position for increase of stability.

- ON : Set front axle to locking position for excavation work or travels even ground. Also, the ram lock pilot lamp comes ON at the travel pilot lamp.
- AUTO : Set front axle to locking or unlocking as table.

* Refer to page 4-32 for select switch.

| Select switch (parking/working/ traveling) | Ram lock | Conditions |
|--|-----------|--|
| Parking (P) | Locking | · Always |
| Traveling (T) | Unlocking | · Always |
| Working (W) | Locking | · FNR lever in neutral position · Service brake pedal is depressed. |
| | Unlocking | · FNR lever in forward/reverse position and service brake pedal is not depressed. · 2 way pedal is equipped and service brake pedal is not depressed. |

12) MASTER SWITCH




(1) This switch is used to shut off the entire electrical system.

- (2) I : The battery remains connected to the electrical system.
O : The battery is disconnected from the electrical system.


* Never turn the master switch to O (OFF) with the engine running. It could result in engine and electrical system damage.

13) HORN SWITCH



(1) This switch is at the top of left side control lever.
On pressing, the horn sounds.


14) BREAKER OPERATION SWITCH



(1) On pressing this switch, the breaker operates only when the breaker selection switch on the switch panel is selected.

15) RH MULTI FUNCTION SWITCH

(1) FNR lever



① This lever changes travel direction of machine.

- F : Machine moves forward
- N : Neutral position
- R : Machine moves backward


▲ Travel direction will be reversed if lower structure is positioned with dozer in front.

② The warning buzzer sounds when the lever is in the reverse position.

▲ If this lever is not in the neutral position, engine does not start.

▲ Be sure to stop the machine when changing the direction forward or backward while traveling.

(2) Travel speed switch




① This switch is for selecting travelling speed between high and low.

- Low speed (−) : 11.3 km/hr (7.0 mph), turtle mark
- High speed (=) : 30 km/hr (19.0 mph), rabbit mark

▲ In case of changing the travel speed, be sure to stop the machine completely.

16) AIR COMPRESSOR SWITCH (option)




(1) This switch is used to activate the air compressor.

(2) The indicator lamp turned ON when selected this switch.


17) LH MULTI FUNCTION SWITCH

(1) Direction indication lamp switch




- ① This switch is used to warn or signal the turning direction of the machine to other machines or equipment.
- ② Push the lever to forward for turning right (↑), pull the lever to backward for turning left (↓).
- ③ The turning pilot lamp comes ON at the travel pilot lamp on the steering column.

(2) Dimmer switch




- ① This switch is used to turn the head lights direction.
- ② Switch positions.
 - Up (↖) : To flash for passing
 - Middle (○) : Head lights low beam ON
 - Down (↙) : Head lights high beam ON
- ③ If you release the switch when it's in up position, the switch will return to middle.

(3) WIPER SWITCH




- ① When the switch is in J position, the wiper moves intermittently.
- ② When placed in I or II position, the wiper moves continuously.

(4) WASHER SWITCH




- ① If you push the grip of the lever, washer liquid will be sprayed and the wiper will be activated 2-3 times.
- * Check the quantity of washer liquid in the tank. If the level of the washer liquid is LOW, add the washer liquid (in cold, winter days) or water. The capacity of tank is 1.5 liter.

(5) HORN SWITCH



- ① This switch is at the end of left side multifunction switch. On pressing, the horn sounds.


18) HAZARD SWITCH



- (1) Use for parking, or roading machine.
- (2) LH and RH turn signal lamps come ON at the same time by this switch.

* If the switch is left ON for a long time, the battery may be discharged.

19) SELECT SWITCH (parking / working / traveling)




14W93CD47J

- (1) This switch is used to select the operation mode as below.
 - Parking ((P)) : The parking brake is applied.
 - Working (W) : The machine needs to be working.
 - Traveling (T) : The machine needs to be traveling.

20) TURNING PILOT LAMP


(1) Left turning pilot lamp



14W93CD54A

- (1) This lamp flashes with sound when the LH multifunction switch is move to backward position.


(2) Right turning pilot lamp



14W93CD54B

- ① This lamp flashes with sound when the LH multifunction switch is move to forward position.


21) OVERLOAD SWITCH (option)



559A3CD39

- (1) When this switch pressed ON position, buzzer makes sound and overload warning lamp comes ON in case that the machine is overload.
- (2) When it pressed OFF position, buzzer stops and warning lamp goes out.

22) DPF (diesel particulate filter) SWITCH



(1) This switch is used to select the regeneration function of the DPF.

(2) Inhibit position (①)

- ① The inhibit position disallows any automatic or manual regeneration of the DPF.
- ② This may be used by operator to prevent regeneration when the machine is operating in a hazardous environment concerned about high temperature.
- ③ It is strongly recommended that this position is only activated when high temperatures may cause a hazardous condition.

(3) OFF position

This position will initiate a automatic regeneration of the DPF.


(4) Manual regeneration position (②)


- ① This position will only initiate a manual regeneration of the DPF when the machine is in non-mission condition, engine must run at low idle speed and DPF soot levels are high enough to allow regeneration.
- ② HEST lamp will be illuminated during the entire regeneration.
- * Refer to the page 4-9 for details.
- * This switch can be move to the manual regeneration position (②) only when the safety button is pulled to backward.
- * Also, this switch return to the OFF position when released the manual regeneration position (②).


GROUP 3 ELECTRICAL CIRCUIT

· ELECTRICAL CIRCUIT (1/3)

- MACHINE SERIAL NO. : -#0482










• ELECTRICAL CIRCUIT (2/3)




- MACHINE SERIAL NO. : -#0482







ELECTRICAL CIRCUIT (3/3)



20M9-95130-00

MEMORANDUM

1. POWER CIRCUIT

The negative terminal of battery is grounded to the machine chassis through master switch.

When the start switch is in the OFF position, the current flows from the positive battery terminal as shown below.

1) OPERATING FLOW

Battery → Battery relay → Fusible link (CN-60) → I/conn [CN-13 (2)] → Master switch [CS-74A]




* I/conn : Intermediate connector

2) CHECK POINT

| Engine | Start switch | Check point | Voltage |
|--------|--------------|--|----------|
| OFF | OFF | ① - GND (battery) ② - GND (relay) ③ - GND (fusible link) | 10~12.5V |

* GND : Ground

POWER CIRCUIT




55W9A4EL05

2. STARTING CIRCUIT

1) OPERATING FLOW

Battery (+) terminal → Battery relay[CR-1] → Fusible link [CN-60]
→ I/conn [CN-13 (2)] → Master switch [CS-74A] → Fuse box No.1 → Start key [CS-2 (1)]

* Start switch : ON



Battery relay [CR-1] : Battery relay operating (all power is supplied with the electric component)

→ Start switch ON [CS-2 (3)] → Fuse box (all power is supplied with electric component)

* Start switch : START

Start switch START [CS-2 (5)]


- I/conn [CN-4 (36)] → ECU [CN-93A (35) → (28, 73)] → I/conn [CN-18 (2, 3)]
- Anti-restart relay [CR-5 (30,86) → (87)] → I/conn [CN-18 (12)]
- Start relay [CR-23 (1) → (2)] → Start motor operating

2) CHECK POINT

| Engine | Start switch | Check point | Voltage |
|-----------|--------------|--|----------|
| Operating | Start | <p>① - GND (battery) ② - GND (start key) ③ - GND (battery relay M4) ④ - GND (starter B⁺) ⑤ - GND (starter M) ⑥ - GND (start relay) ⑦ - GND (battery relay M8)</p> | 10~12.5V |

* GND : Ground

STARTING CIRCUIT



3. CHARGING CIRCUIT

When the starter is activated and the engine is started, the operator releases the key switch to the ON position.

Charging current generated by operating alternator flows into the battery through the Battery relay (CR-1).

The current also flows from alternator to each electrical component and controller through the fuse box.

1) OPERATING FLOW

(1) Warning flow

Alternator "L" terminal → MCU [CN-51 (20)] → Cluster warning lamp

(2) Charging flow


Alternator "B⁺" terminal → Battery relay → Battery (+) terminal

2) CHECK POINT

| Engine | Start switch | Check point | Voltage |
|--------|--------------|--|----------|
| ON | ON | ① - GND (battery voltage) ② - GND (battery relay) ③ - GND (alternator B ⁺ terminal) ④ - GND (alternator L terminal) ⑤ - GND (MCU) | 10~12.5V |


* GND : Ground

CHARGING CIRCUIT



4. HEAD AND WORK LIGHT CIRCUIT

1) OPERATING FLOW



(1) Main light switch ON : 1st step

Head light switch ON [CN-116 (3)] → Head lamp power relay [CR-78 (85)→(87)]
 → I/conn [CN-8 (11)] → I/conn [CN-97 (11)] → Multifunction sw left lever [(4)→(5)]
 → I/conn [CN-97 (10)] → I/conn [CN-8 (3)] → Head light low relay [CR-13 (86),(87)]
 → I/conn [CN-8 (2)] → Head light ON [CL-3 (1), CL-4 (1)] : Head light ON

(2) Main light switch ON : 2nd step

Head light switch [CN-116 (3)] → Head lamp power relay [CR-78 (85)→(87)]
 → I/conn [CN-8 (11)] → I/conn [CN-97 (11)] → Multifunction sw left lever [(4)→(3)]
 → I/conn [CN-97 (9)] → I/conn [CN-8 (1)]
 → Head light high relay [CR-14 (86)→(87)] → I/conn [CN-8 (8)]
 → Head light ON [CL-3 (2), CL-4 (2)] : Head light high beam ON

(3) Work lamp switch ON :


Work lamp switch ON [CS-116 (2)] → Work lamp relay [CR-3 (85)→(87)] → I/conn [CN-8 (14)]
 → I/conn [CN-12 (2)] → Work lamp ON [CL-5 (2), CL-6 (2)] : Work lamp ON

2) CHECK POINT

| Engine | Start switch | Check point | Voltage |
|--------|--------------|--|----------|
| STOP | ON | ① - GND (fuse box) ② - GND (switch power input) ③ - GND (switch power output) ④ - GND (head light) ⑤ - GND (fuse box) ⑥ - GND (switch power input) ⑦ - GND (switch power output) ⑧ - GND (work light) | 10~12.5V |

* GND : Ground

HEAD AND WORK LAMP CIRCUIT



5. BEACON LAMP AND CAB LAMP CIRCUIT

1) OPERATING FLOW

Fuse box (No.13) → Beacon lamp relay [CR-85 (30) → (85)] → Switch panel [CN-116 (6)]

Fuse box (No.11) → Cab lamp relay [CR-9 (30) → (85)] → Switch panel [CN-116 (7)]

(1) Beacon lamp switch ON

Switch panel [CN-116 (6)] → Beacon lamp relay [CR-85 (85) → (87)] → I/conn [CN-6 (5)]

→ Beacon lamp [CL-7]

(2) Cab lamp switch ON

Switch panel [CN-116 (7)] → Cab lamp relay [CR-9 (85) → (87)] → I/conn [CN-6 (8)]


→ Cab light [CL-9 (2), CL-10 (2)]

2) CHECK POINT

| Engine | Start switch | Check point | Voltage |
|--------|--------------|--|----------|
| STOP | ON | ① - GND (fuse box) ② - GND (switch power input) ③ - GND (switch power output) ④ - GND (beacon & cab lamp) | 10~12.5V |

* GND : Ground

BEACON AND CAB LAMP CIRCUIT




55W9A4EL09

6. WIPER AND WASHER CIRCUIT

1) OPERATING FLOW

(1) Key switch ON



(2) Wipe switch ON : 1st step (intermittent)

Multifunction switch left lever (2) → I/conn [CN-98 (5)] → I/conn [CN-4 (13)]
 → Int wiper relay [CR-6 (6)] : Wiper motor intermittently operating → Int wiper relay [CR-6 (6) → (3)]
 → I/conn [CN-4 (12)] → I/conn [CN-98 (4)] → Multifunction switch left lever (6) → (2)
 → I/conn [CN-98 (2)] → I/conn [CN-4 (10)] → Wiper relay [CR-4 (85)] : Wiper relay operating
 → Wiper relay [CR-4 (87) → (30)] → Wiper motor [CN-21 (4)] : Wiper motor operating

(3) Wiper switch ON : 2nd or 3rd step

Multifunction switch left lever (2) → I/conn [CN-98 (2)] → I/conn [CN-4 (10)]
 → Wiper relay [CR-4 (85)] : Wiper relay operating → Wiper relay [CR-4 (87) → (30)]
 → Wiper motor operating [CN-21(1)] : Wiper motor operating

(4) Auto parking (when switch OFF)

Wiper switch OFF

```

graph LR
    A[Wiper switch OFF] --> B[Wiper relay OFF]
    A --> C[Int wiper relay OFF]
  
```

→ Wiper motor [CN-21 (3) → (1)] → Wiper relay [CR4 (87a) → (30)]
 → Wiper motor [CN-21 (4)] : Wiper motor parking position

(5) Washer switch ON


Multifunction sw left lever (7) → I/conn [CN-98 (8)] → Washer pump [CN-22 (1)] : Washer pump operating

2) CHECK POINT


| Engine | Start switch | Check point | Voltage |
|--------|--------------|---|----------|
| STOP | ON | ① - GND (fuse box) ② - GND (wiper motor) | 10~12.5V |

※ GND : Ground


WIPER AND WASHER CIRCUIT




MONITORING CIRCUIT




ILLUMINATION CIRCUIT



COMBINATION LAMP CIRCUIT















ELECTRIC CIRCUIT FOR HYDRAULIC















GROUP 4 ELECTRICAL COMPONENT SPECIFICATION







| Part name | Symbol | Specification | Check |
|-------------------------------------|--------|--|--|
| Battery | | 12V × 100Ah | <ul style="list-style-type: none"> * Check specific gravity 1.280 over : Over charged 1.280 ~ 1.250 : Normal 1.250 below : Recharging |
| Battery relay | | Rated load : 12V 100A (continuity) 1000A (30 second) | <ul style="list-style-type: none"> * Check coil resistance Normal : about 12Ω * Check contact Normal : $\infty\Omega$ |
| Start key | | 12V | <ul style="list-style-type: none"> * Check contact OFF : $\infty\Omega$ (for each terminal) ON : 0Ω (for terminal 1-3 and 1-2) START : 0Ω (for terminal 1-5) |
| Pressure switch (for engine oil) | | 0.5 kgf/cm² (N.C TYPE) | <ul style="list-style-type: none"> * Check resistance Normal : 0Ω (CLOSE) |
| Temperature sensor | | - | <ul style="list-style-type: none"> * Check resistance 50°C : 804Ω 80°C : 310Ω 100°C : 180Ω |







| Part name | Symbol | Specification | Check |
|-----------------------------|---|--|---|
| Air cleaner pressure switch |  CD-10 | Pressure: 635mmH ₂ O (N.O TYPE) | * Check contact Normal : $\infty \Omega$ |
| Fuel sender |  CD-2 | - | * Check resistance Full : 100 Ω Low : 500 Ω Empty warning : 700 Ω |
| Relay |  CR-2 CR-3 CR-4 CR-5 CR-6 CR-7 CR-9 CR-13 CR-14 CR-29 CR-30 CR-33 CR-36 CR-36A CR-38 CR-45 CR-62 CR-65 CR-63(1), (2) CR-75 CR-78 CR-80 CR-85 | 12V 20A | * Check resistance Normal : About 200 Ω (for terminal 85-86) : 0 Ω (for terminal 30-87a) |
| Relay |  CR-23 CR-24 CR-47 | 12V 60A | * Rated coil current 1.2±0.3A |
| Solenoid valve |  CN-66 CN-68 CN-69 CN-70 CN-71 CN-121 CN-122 CN-123 CN-140 CN-246 | 12V 1A | * Check resistance Normal : 15~25 Ω (for terminal 1-2) |
| Speaker |  CN-23(LH) CN-24(RH) | 4 Ω 20W | * Check resistance Normal : 4 Ω |







| Part name | Symbol | Specification | Check |
|--------------------------|--|----------------------|--|
| Switch (looking type) |  CS-47 CS-50 CS-67 CS-99 | 12V 16A | ※ Check contact Normal OFF - $\infty \Omega$ (for terminal 1-5,2-6) - 0Ω (for terminal 5-7,6-8) |
| Work lamp |  CL-5 CL-6 CL-9 CL-10 CL-19 CL-20 | 12V 55W (H3 TYPE) | ※ Check disconnection Normal : 1.2Ω |
| Room lamp |  CL-1 | 12V 10W | ※ Check disconnection Normal : A few Ω |
| Fuel filler pump |  CN-61 | 12V 35 l/min | ※ Check operation Supply power(for terminal 1) : 12V |
| Fuel feed pump |  CN-145 | 12V | - |
| Horn |  CN-20 CN-25 | 12V | $100 \pm 5 \text{dB}$ |



| Part name | Symbol | Specification | Check |
|----------------------|---|----------------------|--|
| Safety switch |  CS-4 CS-4A | Micro | ※ Check contact Normal : 0Ω (for terminal A-B) : $\infty\Omega$ (for terminal A-C) Operating : $\infty\Omega$ (for terminal A-B) : 0Ω (for terminal A-C) |
| Cut-off solenoid |  CN-79 | 12V | ※ Check operation. |
| Pressure sensor |  CD-3 CD-4 CD-7 CD-26 CD-31 CD-32 CD-38 CD-73 | 8-30V | ※ Check contact Normal : 0.1Ω |
| Beacon lamp |  CL-7 | 12V (strobe type) | ※ Check disconnection Normal : A few Ω |
| Auto cruise switch |  CS-23 | 12V 16A | ※ Check contact Normal : $\infty\Omega$ |
| Auto ram lock switch |  CS-100 | 12V 16A | ※ Check contact Normal : 0Ω |

| Part name | Symbol | Specification | Check |
|--------------------|---|---------------|--|
| Washer pump |  CN-22 | 12V 3.8A | * Check contact Normal : 3Ω (for terminal 1-2) |
| Cigar lighter |  CL-2 | 12V 10A 1.4W | * Check coil resistance Normal : About $1M\Omega$ * Check contact Normal : $\infty\Omega$ Operating time : 5~15sec |
| Wiper motor |  CN-21 | 12V 3A | * Check contact Normal : 6Ω (for terminal 2-6) |
| Int wiper relay |  CR-6 | 12V 12A | - |
| Radio & USB player |  CN-27A | 12V 3A | * Check voltage 10 ~ 12.5V (for terminal 10-14,11-14) |
| Receiver dryer |  CN-29 | 12V | * Check contact Normal : 0Ω |

| Part name | Symbol | Specification | Check |
|------------------------------|---|--------------------------------------|---|
| Starter |  CN-45 | 12V | * Check contact Normal : 0.1Ω |
| Alternator |  CN-74 | 12V 80A | * Check contact Normal : 0Ω (for terminal B ⁺ -1) Normal : 10 ~ 12.5V |
| Travel buzzer |  CN-81 | 12V | - |
| Compressor |  CN-28 | 12V 38W | - |
| Air con fan motor |  CN-83 | 12V 8.5A | - |
| Circuit breaker manual reset |  CN-60 CN-95 | 12V, 30A (CN-65) 12V, 60A (CN-95) | - |

| Part name | Symbol | Specification | Check |
|-------------------------------|--|------------------------|--|
| Rear combination lamp-LH, RH |  CL-15 CL-16 | 12V 21W×2 12V 21/5W | * Normal : 4.8Ω (for terminal 1-4) Normal : 2.1Ω (for terminal 2-4, 4-5, 4-6) |
| Front combination lamp-LH, RH |  CL-24 CL-25 | 12V 21W 12V 5W | * Normal : 4.8Ω (for terminal 1-2) Normal : 2.1Ω (for terminal 2-3) |
| Head lamp -LH, RH |  CL-3 CL-4 | 12V 60/55W | * Normal : 1.0Ω (for terminal 1-3, 2-3) Normal : 1.5Ω (for terminal 1-2) |
| Master switch |  | 12V 1000A | - |
| Preheater |  CN-80 | 12V 42A 500W | - |
| Accel dial |  CN-142 | - | * Check resistance Normal : about 5KΩ (for terminal A-C) * Check voltage Normal : about 5V (for terminal A-C) : 2-4.5V (for terminal C-B) |

| Part name | Symbol | Specification | Check |
|---------------------------|--|-------------------|--|
| Timer |  CR-50 | 12V | - |
| 12V socket |  CN-139 | 12V 120W | - |
| Dust sensor (switch) |  | 1°C OFF 4°C ON | ※ Check resistance Normal : 0Ω (for terminal 1-2) The atmosphere temp : over 4°C |
| Resistor |  RS-1 | 3W | ※ Check resistance A-B : 120Ω |
| Relay (air con blower) |  | 12V 20A | ※ Check resistance Normal : About 200Ω (for terminal 1-3) 0Ω (for terminal 2-4) |
| Radio & USB player |  CN-27 | 12V 2A | ※ Check voltage 10~16V (for terminal 1-3, 3-8) |

| Part name | Symbol | Specification | Check |
|-----------------------|---|----------------------|-------|
| Quick clamp buzzer |  CN-113 | 12V 60mA 65dB Min | - |
| DPF switch |  CS-100 | 12V 16A | - |

GROUP 5 CONNECTORS

1. CONNECTOR DESTINATION

| Connector number | Type | No. of pin | Destination | Connector part No. | |
|------------------|---------|------------|--|--------------------|--------------|
| | | | | Female | Male |
| CN-1 | AMP | 36 | I/conn (Cab room harness-Main harness) | 1743059-2 | 1743062-2 |
| CN-3 | YAZAKI | 2 | I/conn (Cab room harness) | S813-030201 | S813-130201 |
| CN-4 | AMP | 36 | I/conn (Cab room harness-Frame harness) | 1743059-2 | 1743062-2 |
| CN-6 | DEUTSCH | 8 | I/conn (Frame harness-Console harness) | S816-008002 | - |
| CN-7 | AMP | 20 | I/conn (Main harness-Console harness) | 936777-2 | 936780-2 |
| CN-8 | AMP | 15 | I/conn (Cab room harness-Cab harness) | 2-85262-1 | 368301-1 |
| CN-11 | KET | 2 | Flasher unit | S810-002202 | - |
| CN-12 | AMP | 2 | I/conn (Boom harness-Main harness) | S816-002002 | S816-102002 |
| CN-13 | KET | 2 | Master switch | MG620558 | - |
| CN-14 | KET | 2 | Earth | - | 610557 |
| CN-16 | AMP | 6 | Emergency engine start | S816-006002 | S816-106002 |
| CN-16A | AMP | 6 | Emergency engine start | S816-006002 | - |
| CN-16B | AMP | 6 | Emergency engine start | S816-006002 | - |
| CN-18 | AMP | 16 | I/conn (Cab room harness-Main harness) | 368047-1 | 368050-1 |
| CN-20 | DEUTSCH | 2 | Horn | DT06-2S-EP06 | - |
| CN-21 | AMP | 8 | Wiper motor | S816-102002 | - |
| CN-22 | KET | 2 | Washer tank | MG640605 | - |
| CN-23 | KET | 2 | Speaker LH | HG610070 | - |
| CN-24 | KET | 2 | Speaker RH | HG610070 | - |
| CN-25 | DEUTSCH | 2 | Horn | DT06-2S-EP06 | - |
| CN-27 | - | 16 | Cassette radio | PK145-16017 | - |
| CN-27A | - | 8 | Cassette radio | - | S816-108002 |
| CN-28 | AMP | 1 | Air-con comp | S810-001002 | - |
| CN-29 | KET | 2 | Receiver dryer | MG640795 | - |
| CN-31 | DEUTSCH | 8 | I/conn (Cab room harness-Aircon harness) | DT06-8S-EP06 | DT04-8S-EP06 |
| CN-36 | - | - | Fuse box | 21L7-00250 | - |
| CN-45 | TERM | 1 | Starter | ST710246-2 | - |
| CN-51 | AMP | 70 | MCU | 1-968879-1 | - |
| CN-52 | DEUTSCH | 24 | Governor DC motor controller | DRC26-24SA | - |
| CN-56 | AMP | 10 | Cluster | - | S816-110002 |
| CN-57 | AMP | 16 | Cluster | 175966-2 | - |
| CN-60 | YAZAKI | 2 | Fusible link | - | 7122-4125-50 |
| CN-61 | TERM | 1 | Fuel filler pump | S822-014000 | - |
| CN-66 | DEUTSCH | 2 | Breaker solenoid | DT06-2S-EP06 | - |
| CN-68 | DEUTSCH | 2 | Safety solenoid | DT06-2S-EP06 | - |
| CN-69 | DEUTSCH | 2 | Ram lock solenoid | DT06-2S-EP06 | - |
| CN-70 | DEUTSCH | 2 | Travel solenoid | DT06-2S-EP06 | - |

| Connector number | Type | No. of pin | Destination | Connector part No. | |
|------------------|----------|------------|----------------------|--------------------|--------------|
| | | | | Female | Male |
| CN-71 | DEUTSCH | 2 | Parking solenoid | DT06-2S-EP06 | - |
| CN-74 | KET | 2 | Alternator | MG640188-5 | - |
| CN-80 | YAZAKI | 1 | Air heater | 7323-3010 | - |
| CN-81 | DEUTSCH | 2 | Travel buzzer | DT06-2S-EP06 | DT04-2P-E005 |
| CN-83 | KET | 2 | Air-con fan | MG640188-5 | - |
| CN-92AB | KET | 1 | Safety | S814-001100 | S814-101100 |
| CN-93A | AMP | 74 | ECU | 3-1355136-3 | - |
| CN-93B | AMP | 60 | ECU | 1897635-2 | - |
| CN-95 | KET | 2 | Fusible link | - | 610557 |
| CN-97 | AMP | 12 | Multifunction switch | S816-012002 | S816-112002 |
| CN-98 | AMP | 10 | Multifunction switch | S816-010002 | S816-110002 |
| CN-99 | AMP | 8 | Multifunction switch | S816-008002 | S816-108002 |
| CN-113 | - | 2 | Buzzer | S810-002202 | - |
| CN-116 | AMP | 12 | Switch panel | 368542-1 | - |
| CN-121 | DEUTSCH | 2 | Boom swing solenoid | DT06-2S-EP06 | - |
| CN-122 | DEUTSCH | 2 | Forward solenoid | DT06-2S-EP06 | - |
| CN-123 | DEUTSCH | 2 | Reverse solenoid | DT06-2S-EP06 | - |
| CN-126 | DEUTSCH | 4 | RS232 | DT06-4S-EP06 | DT06-4P-E005 |
| CN-139 | AMP | 2 | 12V socket | S810-002202 | - |
| CN-140 | DEUTSCH | 2 | Quick clamp solenoid | DT06-2S-EP06 | DT04-2P-E005 |
| CN-142 | DEUTSCH | 3 | Accel dial | DT06-3S-EP06 | - |
| CN-144A | KET | 20 | Handfree | MG610240 | - |
| CN-144B | KET | 8 | Handfree | 175964-2 | - |
| CN-145 | YAZAKI | 2 | Fuel feed pump | 7123-6423-30 | - |
| CN-148 | DEUTSCH | 6 | Service tool | DTM06-6S-E008 | ST710285-2 |
| CN-157 | - | 1 | Antena power | S822-014000 | - |
| CN-170 | PACKARD | 2 | Seat heat switch | 12052641 | - |
| CN-193 | SUMITOMO | 6 | EGR step motor | 6195-0021 | - |
| CN-194 | YAZAKI | 3 | Rack actuator | 7323-7414-40 | - |
| CN-243 | DEUTSCH | 4 | RS232 connector | DT06-4S-EP06 | DT04-4P-E004 |
| CN-245A | AMP | 12 | Remote controller | 368542-1 | - |
| CN-245B | AMP | 12 | Remote controller | 174045-2 | - |
| CN-246 | AMP | 12 | USB and socket | 174045-2 | - |
| CN-258 | - | 1 | Aircon comp power | 21N4-01311 | - |
| CN-259 | AMP | 6 | Aux camera | S816-006002 | S816-106002 |
| CN-263 | DEUTSCH | 2 | Air comp relay | DT06-2S-EP06 | DT04-2P-E005 |
| CN-289 | - | 6 | Amp assy | MG610049 | - |
| CN-300A | AMP | 6 | DPF pressure | 1438153-5 | - |
| CN-300B | FCI | 2 | DPF mid temp | 54200206 | - |
| CN-300C | FCI | 2 | DPF inlet temp | 54200208 | - |

















| Connector number | Type | No. of pin | Destination | Connector part No. | |
|------------------|---------|------------|---------------------------|--------------------|-------------|
| | | | | Female | Male |
| CN301 | AMP | 8 | EGR sensor | 776532-1 | - |
| CN302 | AMP | 12 | EGR valve | 776533-1 | - |
| CN303 | AMP | 12 | Engine sensor | 776533-2 | - |
| CN304 | AMP | 12 | C/rail | 776533-3 | - |
| · LAMP | | | | | |
| CL-1 | KET | 2 | Room lamp | MG610392 | - |
| CL-2 | AMP | 3 | Cigar lighter | S810-003201 | - |
| CL-3 | KET | 3 | Head lamp | S810-003702 | - |
| CL-4 | KET | 3 | Head lamp | S810-003702 | - |
| CL-5 | DEUTSCH | 2 | Work lamp | DT06-2S-EP06 | - |
| CL-7 | - | 1 | Beacon lamp | S822-014000 | S822-114000 |
| CL-9 | DEUTSCH | 2 | Cabin lamp | DT06-2S-EP06 | - |
| CL-10 | DEUTSCH | 2 | Cabin lamp | DT06-2S-EP06 | - |
| CL-15 | DEUTSCH | 6 | Rear combination lamp-LH | DT06-6S-EP06 | - |
| CL-16 | DEUTSCH | 6 | Rear combination lamp-RH | DT06-6S-EP06 | - |
| CL-19 | AMP | 2 | Side maker lamp-LH | S816-002002 | - |
| CL-20 | AMP | 2 | Side maker lamp-RH | S816-002002 | - |
| CL-21 | KET | 2 | Number plate lamp | GP890469 | - |
| CL-24 | KET | 3 | Front combination lamp-LH | S814-003001 | - |
| CL-25 | KET | 3 | Front combination lamp-RH | S814-003001 | - |
| · RELAY | | | | | |
| CR-1 | AMP | 2 | Battery relay | S816-002002 | S816-102002 |
| CR-2 | HELLA | 5 | Horn relay | SJA003526-001 | - |
| CR-3 | HELLA | 5 | Work lamp relay | SJA003526-001 | - |
| CR-4 | HELLA | 5 | Wiper relay | SJA003526-001 | - |
| CR-5 | HELLA | 5 | Anti-restart relay | SJA003526-001 | - |
| CR-6 | AMP | 6 | Int wiper relay | S810-006002 | - |
| CR-7 | HELLA | 4 | Aircon comp relay | SJA003526-001 | - |
| CR-9 | HELLA | 4 | Cabin lamp relay | SJA003526-001 | - |
| CR-11 | HELLA | 3 | Flasher unit relay | SJA003526-001 | - |
| CR-13 | HELLA | 4 | Head lamp low relay | SJA003526-001 | - |
| CR-14 | HELLA | 4 | Head lamp high relay | SJA003526-001 | - |
| CR-18 | HELLA | 5 | Ram lock | SJA003526-001 | - |
| CR-23 | KET | 2 | Start relay | S814-002001 | - |
| | HMC | 2 | | S810-002302 | - |
| CR-24 | KET | 2 | Air heater relay | S814-002001 | - |
| | HMC | 2 | | S810-002302 | - |
| CR-29 | HELLA | 4 | Forward relay | SJA003526-001 | - |
| CR-30 | HELLA | 4 | Reverse relay | SJA003526-001 | - |
| CR-33 | HELLA | 4 | Air-con fan relay | SJA003526-001 | - |













| Connector number | Type | No. of pin | Destination | Connector part No. | |
|------------------|----------|------------|----------------------------|--------------------|--------------|
| | | | | Female | Male |
| CR-36A | HELLA | 4 | Pre-heater relay | SJA003526-001 | - |
| CR-38 | HELLA | 4 | Neutral relay | SJA003526-001 | - |
| CR-45 | HELLA | 4 | ECU power relay | SJA003526-001 | - |
| CR-53 | HELLA | 2 | Timer stop lamp | S810-002202 | - |
| CR-62 | HELLA | 4 | Breaker relay | SJA003526-001 | - |
| CR-63B | HELLA | 4 | Stop lamp relay | SJA003526-001 | - |
| CR-67 | AMP | 6 | Rack actuator | S816-002002 | - |
| CR-68 | AMP | 6 | ECU main power | S816-002002 | - |
| CR-71 | HELLA | 4 | Boom swing relay | SJA003526-001 | - |
| CR-75 | HELLA | 4 | Illumination relay | SJA003526-001 | - |
| CR-78 | HELLA | 4 | Head lamp relay | SJA003526-001 | - |
| CR-80 | HELLA | 5 | EGR valve | SJA003526-001 | - |
| CR-85 | HELLA | 4 | Beacon lamp relay | SJA003526-001 | - |
| · SENDER | | | | | |
| CD-1 | AMP | 2 | Hydraulic temp sender | 85202-1 | - |
| CD-2 | AMP | 2 | Fuel sender | - | S816-102002 |
| CD-3 | DEUTSCH | 3 | Brake oil pressure switch | DT06-3S-EP06 | - |
| CD-4 | DEUTSCH | 3 | Stop lamp pressure switch | DT06-3S-EP06 | - |
| CD-7 | DEUTSCH | 3 | Working pressure switch | DT06-3S-EP06 | - |
| CD-8 | AMP | 2 | Water temp sender | 1-178390-2 | - |
| CD-10 | KET | 1 | Air cleaner switch | ST730057-2 | - |
| CD-17 | SUMITOMO | 2 | Tacho sensor | 6189-0552 | - |
| CD-18 | YAZAKI | 1 | Engine oil pressure switch | 7123-5014 | - |
| CD-26 | DEUTSCH | 3 | Parking pressure switch | DT06-3S-EP06 | - |
| CD-30 | AMP | 2 | Water temp | 85202-1 | - |
| CD-31 | DEUTSCH | 3 | Overload pressure switch | DT06-3S-EP06 | - |
| CD-32 | DEUTSCH | 3 | Boom up pressure switch | DT06-3S-EP06 | - |
| CD-38 | DEUTSCH | 3 | Working brake | DT06-3S-EP06 | - |
| CD-62 | YAZAKI | 3 | CSD | 7323-7414-40 | - |
| CD-73 | DEUTSCH | 3 | Forward pressure switch | DT06-3S-EP06 | - |
| · SWITCH | | | | | |
| CS-2 | KET | 6 | Start key switch | S814-006000 | - |
| CS-4 | AMP | 3 | Safety switch | S816-003002 | - |
| CS-4A | AMP | 3 | Safety switch | - | 174359-2 |
| CS-5 | DEUTSCH | 2 | Horn-switch | - | DT04-2P-E005 |
| CS-16 | KET | 2 | Fuel pump switch | S810-002201 | - |
| CS-26 | DEUTSCH | 2 | Breaker switch | - | DT04-2P-E005 |
| CS-29 | DEUTSCH | 2 | Spare | DT06-2S-EP06 | - |
| CS-47 | SWF | 12 | Boom swing switch | 589790 | - |
| CS-50 | SWF | 12 | Overload switch | 589790 | - |

| Connector number | Type | No. of pin | Destination | Connector part No. | |
|------------------|--------|------------|------------------------|--------------------|------|
| | | | | Female | Male |
| CS-67 | SWF | 12 | Quick clamp switch | 589790 | - |
| CS-74 | YAZAKI | 2 | Master switch | MG620558 | - |
| CS-99 | SWF | 12 | Air comp switch | 589790 | - |
| CS-100 | SWF | 12 | Ram lock switch | 589790 | - |
| CS-106 | SWF | 12 | DPF switch | 589790 | - |
| · DIODE | | | | | |
| DO-1 | - | 2 | Diode (alternator) | 21EA-50550 | - |
| DO-2 | - | 2 | Diode (fuel feed pump) | 21EA-50550 | - |
| DO-3 | - | 2 | Diode (neutral) | 21EA-50550 | - |

















2. CONNECTION TABLE FOR CONNECTORS

1) PA TYPE CONNECTOR

















| No. of pin | Connector (female) | Connector (male) |
|------------|--|---|
| 5 |   |   |
| | S811-005002 | S811-105002 |
| 7 |   |   |
| | S811-007002 | S811-107002 |
| 9 |   |   |
| | S811-009002 | 3S811-109002 |
| 11 |   |   |
| | S811-011002 | S811-111002 |

















| No. of pin | Connector (female) | Connector (male) |
|------------|---|--|
| 13 |   S811-013002 |   S811-113002 |
| 17 |   S811-017002 |   S811-117002 |
| 21 |   S811-021002 |   S811-121002 |

2) J TYPE CONNECTOR

















| No. of pin | Connector (female) | Connector (male) |
|------------|---|--|
| 2 |   S816-002001 |   S816-102001 |
| 3 |   S816-003001 |   S816-103001 |
| 4 |   S816-004001 |   S816-104001 |
| 8 |   S816-008001 |   S816-108001 |









3) SWP TYPE CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|--|---|
| 1 |   |   |
| 2 |   |   |
| 3 |   |   |
| 4 |   |   |





| No. of pin | Connector (female) | Connector (male) |
|------------|--|---|
| 6 |   S814-006000 |   S814-106000 |
| 8 |   S814-008000 |   S814-108000 |
| 12 |   S814-012000 |   S814-112000 |
| 14 |   S814-014000 |   S814-114000 |

4) CN TYPE CONNECTOR



| No. of pin | Connector (female) | Connector (male) |
|------------|--|---|
| 1 |   |   |
| 2 |   |   |
| 3 |   |   |
| 4 |   |   |

| No. of pin | Connector (female) | Connector (male) |
|------------|---|--|
| 6 |   |   |
| 8 |   |   |


5) 375 FASTEN TYPE CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|--|--|
| 2 |   S810-002402 |   S810-102402 |



6) AMP ECONOSEAL CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|--|---|
| 36 |  344111-1 |  344108-1 |



7) AMP TIMER CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|--|------------------|
| 2 |  85202-1 | |





8) AMP 040 MULTILOCK CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|--|------------------|
| 12 |   174045-2 | |


9) AMP 070 MULTILOCK CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|---|------------------|
| 14 |   173852 | |



10) AMP FASTIN - FASTON CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|--|--|
| 6 |   925276-0 |   480003-9 |


11) KET 090 CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|---|------------------|
| 2 |  MG610070 | |

12) KET 090 WP CONNECTORS

| No. of pin | Connector (female) | Connector (male) |
|------------|---|------------------|
| 2 |  MG640605 | |
| 2 |  MG640795 | |

13) KET SDL CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|---|------------------|
| 14 |  MG610406 | |

14) DEUTSCH DT CONNECTORS

DT_06 - 3S - ★★★★

Modifications (see below)

Number of contacts (P : Pin, S : Socket)

04 : Receptacle, 06 : Plug

Deutsch connectors

* Modification

E003 : Standard end cap - gray







E004 : Color of connector to be black







E005 : Combination - E004 & E003

EP04 : End cap


EP06 : Combination P012 & EP04

P012 : Front seal enhancement - connectors color to black for 2, 3, 4 & 6pin


| No. of pin | Connector (female) | Connector (male) |
|------------|--|---|
| 2 |  DT06-2S |  DT06-2P |
| 3 |  DT06-3S |  DT06-3P |
| 4 |  DT06-4S |  DT06-4P |

| No. of pin | Connector (female) | Connector (male) |
|------------|---|--|
| 6 |  DT06-6S |  DT06-6P |
| 8 |  DT06-8S |  DT06-8P |
| 12 |  DT06-12S |  DT06-12P |


15) MOLEX 2CKTS CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|---|------------------|
| 2 |  35215-0200 | |

16) ITT SWF CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|---|------------------|
| 10 |  SWF593757 | |

17) MWP NMWP CONNECTOR

| No. of pin | Connector (female) | Connector (male) |
|------------|--|------------------|
| 1 |  NMWP01F-B | |

GROUP 6 FAULT CODES

1. MACHINE FAULT CODE

| Fault code | | Description |
|------------|-----|---|
| HCESPN | FMI | |
| 101 | 3 | Hydraulic oil temperature sensor circuit - voltage above normal or shorted to high source (or open circuit) |
| | 4 | Hydraulic oil temperature sensor circuit - voltage below normal or shorted to low source |
| 105 | 0 | Working pressure sensor data above normal range (or open circuit) |
| | 1 | Working pressure sensor data below normal range |
| | 2 | Working pressure sensor data error |
| | 4 | Working pressure sensor circuit - voltage below normal, or shorted to low source |
| 108 | 0 | Travel oil pressure sensor data above normal range (or open circuit) |
| | 1 | Travel oil pressure sensor data below normal range |
| | 2 | Travel oil pressure sensor data error |
| | 4 | Travel oil pressure sensor circuit - voltage below normal or shorted to low source |
| 122 | 0 | Overload pressure sensor data above normal range (or open circuit) |
| | 1 | Overload pressure sensor data below normal range |
| | 2 | Overload pressure sensor data error |
| | 3 | Overload pressure sensor circuit - voltage below normal or shorted to low source |
| 301 | 3 | Fuel level sensor circuit - voltage above normal or shorted to high source (or open circuit) |
| | 4 | Fuel level sensor circuit - voltage below normal or shorted to low source |
| 503 | 0 | Brake pressure sensor data above normal range (or open circuit) |
| | 1 | Brake pressure sensor data below normal range |
| | 2 | Brake pressure sensor data error |
| | 4 | Brake pressure sensor data - voltage below normal or shorted to low source |
| 505 | 0 | Working brake pressure sensor data above normal range (or open circuit) |
| | 1 | Working brake pressure sensor data below normal range |
| | 2 | Working brake pressure sensor data error |
| | 4 | Working brake pressure sensor circuit - voltage below normal, or shorted to low source |
| 530 | 0 | Travel fwd pilot pressure sensor data above normal range (or open circuit) |
| | 1 | Travel fwd pilot pressure sensor data below normal range |
| | 2 | Travel fwd pilot pressure sensor data error |
| | 4 | Travel fwd pilot pressure sensor circuit - voltage below normal, or shorted to low source |
| | 14 | Travel fwd pilot pressure sensor circuit - special instructions |
| | 16 | Travel fwd pilot pressure sensor circuit - voltage valid but above normal operational range |
| 701 | 4 | Hour meter circuit - voltage below normal, or shorted to low source |
| 705 | 0 | MCU input voltage high |
| | 1 | MCU input voltage low |
| 707 | 1 | Alternator node I voltage low (or open circuit) |
| 714 | 3 | Acc. dial circuit - voltage above normal, or shorted to high source (or open circuit) |
| | 4 | Acc. dial circuit - voltage below normal, or shorted to low source |
| 840 | 2 | Cluster communication data error |
| 841 | 2 | ECM communication data error |
| IDSP | | Water in fuel warning |
| Lo bat | | Low battery warning |

2. ENGINE FAULT CODE

| Fault code | | Description | |
|------------|-----|--|---|
| YANMAR SPN | FMI | Area | Status |
| 522400 | 2 | Crankshaft speed sensor | Crankshaft signal error |
| | 5 | | No signal from crankshaft |
| 522401 | 2 | Camshaft speed sensor | Camshaft signal error |
| | 5 | | No signal from camshaft |
| | 7 | | Angle offset error |
| 523249 | 5 | Crankshaft speed sensor, Camshaft speed sensor | Crankshaft/camshaft, speed sensor non-input (simultaneous) |
| 91 | 3 | Accelerator sensor 1 | Accelerator sensor 1 error (voltage high) |
| | 4 | | Accelerator sensor 1 error (voltage low) |
| 28 | 3 | Accelerator sensor 2 | Accelerator sensor 2 error (voltage high) |
| | 4 | | Accelerator sensor 2 error (voltage low) |
| 522624 | 7 | Accelerator sensor 1 + 2 | Dual accelerator sensor error (closed position) |
| 522623 | 7 | | Dual accelerator sensor error (open position) |
| 29 | 3 | Accelerator sensor 3 | Accelerator sensor 3 error (voltage high) |
| | 4 | | Accelerator sensor 3 error (voltage low) |
| | 8 | Pulse sensor | Pulse accelerator sensor error (pulse communication) |
| 28 | 0 | Accelerator sensor 3 | Accelerator sensor 3 error (foot pedal in open position) |
| | 1 | | Accelerator sensor 3 error (foot pedal in closed position) |
| 51 | 3 | Intake throttle position sensor | Intake throttle position sensor error (voltage high) |
| | 4 | | Intake throttle position sensor error (voltage low) |
| 102 | 3 | EGR low pressure side pressure sensor | ERG low pressure side pressure sensor error (excessive sensor output) |
| | 4 | | ERG low pressure side pressure sensor error (insufficient sensor output) |
| | 13 | | ERG low pressure side pressure sensor error (abnormal learning value) |
| | 10 | | ERG low pressure side pressure sensor error (detected value error) |
| 1209 | 3 | EGR pressure sensor (high-pressure side) | ERG high pressure side pressure sensor error (excessive sensor output) |
| | 4 | | ERG high pressure side pressure sensor error (insufficient sensor output) |
| | 13 | | ERG high pressure side pressure sensor error (abnormal learning value) |
| | 10 | | ERG high pressure side pressure sensor error (detected value error) |
| 110 | 3 | Engine coolant temperature sensor | Engine coolant temperature sensor error (excessive sensor output) |
| | 4 | | Engine coolant temperature sensor error (insufficient sensor output) |
| | 10 | | Engine coolant temperature sensor error (detected value error) |
| | 0 | | Engine coolant temperature high (overheat) |
| 172 | 3 | Ambient air temperature sensor | Ambient air temperature sensor error (voltage high) |
| | 4 | | Ambient air temperature sensor error (voltage low) |

| Fault code | | Description | |
|------------|-----|--|--|
| YANMAR SPN | FMI | Area | Status |
| 174 | 3 | Fuel temperature sensor | Fuel temperature sensor error (voltage high) |
| | 4 | | Fuel temperature sensor error (voltage low) |
| | 0 | | Fuel temperature high |
| 157 | 3 | Rail pressure sensor | Rail pressure sensor error (voltage high) |
| | 4 | | Rail pressure sensor error (voltage low) |
| 3251 | 3 | DPF differential pressure sensor | DPF differential pressure sensor error (excessive sensor output) |
| | 4 | | DPF differential pressure sensor abnormal rise in differential pressure |
| | 0 | | DPF differential pressure sensor error abnormal rise in differential pressure |
| | 13 | | DPF differential pressure sensor error (abnormal learning value) |
| 4795 | 31 | DPF substrate/DPF differential pressure sensor | DPF substrate/DPF differential pressure sensor error (DPF substrate removal/DPF differential pressure sensor detected value error) |
| 3609 | 3 | DPF high pressure side pressure sensor | DPF high pressure side pressure sensor error (excessive sensor output) |
| | 4 | | DPF high pressure side pressure sensor error (insufficient sensor output) |
| | 10 | | DPF high pressure side pressure sensor error (detected value error) |
| 3242 | 3 | DPF intermediated temperature sensor | DPF inlet temperature sensor error (excessive sensor output) |
| | 4 | | DPF inlet temperature sensor error (insufficient sensor output) |
| | 10 | | DPF inlet temperature sensor error (detected value error) |
| | 0 | | DPF inlet temperature sensor abnormal temperature (abnormally high) |
| 3250 | 3 | DPF intermediate temperature sensor | DPF intermediate temperature sensor error (excessive sensor output) |
| | 4 | | DPF intermediate temperature sensor error (insufficient sensor output) |
| | 10 | | DPF intermediate temperature sensor error (detected value error) |
| | 1 | | DPF intermediate temperature sensor abnormal temperature (abnormally low) |
| 108 | 3 | Atmospheric pressure sensor | Atmospheric pressure sensor error (excessive sensor output) |
| | 4 | | Atmospheric pressure sensor error (insufficient sensor output) |
| | 10 | | Atmospheric pressure sensor error (characteristic error) |
| 173 | 3 | Exhaust manifold temperature sensor | Exhaust manifold temperature sensor error (excessive sensor output) |
| | 4 | | Exhaust manifold temperature sensor error (insufficient sensor output) |
| | 10 | | Exhaust manifold temperature sensor error (detected value error) |
| 1485 | 7 | Main relay | Main relay contact sticking |
| | 2 | | Main relay early opening |

| Fault code | | Description | |
|------------|-----|--|---|
| YANMAR SPN | FMI | Area | Status |
| 522243 | 5 | Starting aid relay | Starting aid relay disconnection |
| | 6 | | Starting aid relay relay GND short circuit |
| 654 | 5 | Injector (No.1 cylinder) | Disconnection (injector-specific) |
| | 6 | | Coil short circuit |
| | 3 | | Short circuit |
| 653 | 5 | Injector (No.2 cylinder) | Disconnection (injector-specific) |
| | 6 | | Coil short circuit |
| | 3 | | Short circuit |
| 652 | 5 | Injector (No.3 cylinder) | Disconnection (injector-specific) |
| | 11 | | Coil short circuit |
| | 3 | | Short circuit |
| 651 | 5 | Injector (No.4 cylinder) | Disconnection (injector-specific) |
| | 6 | | Coil short circuit |
| | 3 | | Short circuit |
| 4257 | 12 | All injectors | Injector drive IC error |
| 2797 | 6 | | Injector drive circuit (Bank1) short circuit (4TN: common circuit for No.1, No4 and all 3TN cylinders) |
| 2798 | 6 | | Injector drive circuit (Bank2) short circuit (4TN: circuit for No.2 and 3 cylinders) |
| 523462 | 13 | Injector (correction value) | Inujector (No.1 cylinder) correction value error |
| 523463 | 13 | | Inujector (No.2 cylinder) correction value error |
| 523464 | 13 | | Inujector (No.3 cylinder) correction value error |
| 522465 | 13 | | Inujector (No.4 cylinder) correction value error |
| 522571 | 3 | SCV (MPROP) | SCV (MPROP) L side VB short circuit |
| | 6 | | SCV (MPROP) L side GND short circuit |
| 633 | 3 | | SCV (MPROP) H side VB short circuit |
| | 6 | | SCV (MPROP) H side GND short circuit |
| | 5 | | SCV (MPROP) disconnection |
| 522572 | 6 | | SCV (MPROP) drive current (high level) |
| | 11 | | SCV (MPROP) pump overload error |
| 157 | 0 | Rail pressure error | Rail pressure too high |
| | 18 | | Rail pressure deviation error (low rail pressure) |
| | 15 | | Rail pressure deviation errer (high rail pressure) |
| | 16 | PLV (common rail pressure limit valve) | PLV open valve |
| 523469 | 0 | | Rail pressure fault (The times of PLV valve opening error) |
| 523470 | 0 | | Rail pressure fault (The time of PLV valve opening error) |
| 523489 | 0 | | Rail pressure fault (The actual rail pressure is too high during PRV limp home) |
| 523498 | 9 | | Rail pressure fault (contrilled rail pressure error after PLV valve opening) |
| 523491 | 0 | Rail pressure control | Rail pressure fault (injector B/F temperature error during PLV4 limp home) |
| 523460 | 7 | | Rail pressure fault (operation time error during RPS limp home) |

| Fault code | | Description | |
|------------|-----|-------------------------------|--|
| YANMAR SPN | FMI | Area | Status |
| 190 | 16 | Intake throttle drive circuit | Overspeed |
| 2950 | 5 | | No-load of throttle valve drive H bridge circuit |
| | 3 | | Power short circuit of throttle valve drive H bridge output 1 |
| | 4 | | GND short circuit of throttle valve drive H bridge output 1 |
| | 6 | | Overload on the drive H bridge circuit of throttle valve |
| | 3 | | VB power short circuit of throttle valve drive H bridge output 2 |
| 2951 | 4 | | GND short circuit of throttle valve drive H bridge output 1 |
| | 7 | | Throttle valve sticking (sticking open) |
| 2950 | 7 | | Throttle valves sticking (sticking closed) |
| 522596 | 9 | | TSC1 (SA1) reception timeout |
| 522597 | 9 | | TSC1 (SA2) reception timeout |
| 522599 | 9 | CAN 2 | Y_ECR1 reception timeout |
| 522600 | 9 | | Y_EC reception timeout |
| 522601 | 9 | | Y_RSS reception timeout |
| 237 | 31 | | VI_reception timeout |
| | 13 | | VI_reception data error |
| 522609 | 9 | | Y_ETCP1 reception timeout |
| 522618 | 9 | | EBC1 reception timeout |
| 522619 | 9 | | Y_DPFIF reception timeout |
| 522730 | 12 | | Immobilizer error (CAN communication) |
| 1202 | 2 | | Immobilizer error (system) |
| 522610 | 9 | CAN 1 | CAN 1 (for EGR): reception timeout from the EGR valve |
| 522611 | 9 | | CAN 1 (for exhaust throttle): reception timeout |
| 2791 | 0 | EGR valve | EGR overvoltage error |
| | 1 | | EGR low voltage error |
| | 7 | | EGR feedback error |
| | 9 | | EGR ECM data error |
| | 12 | | Disconnection in EGR motor coils |
| 522579 | 12 | | Short circuit in EGR motor coils |
| 522580 | 12 | | EGR position sensor error |
| 522581 | 7 | | EGR valve sticking error |
| 522183 | 7 | | EGR initialization error |
| 522184 | 1 | | EGR high temperature thermistor error |
| 522617 | 1 | Exhaust throttle | EGR low temperature thermistor error |
| 522746 | 12 | | EGR target value out of range |
| 522747 | 12 | | Exhaust throttle (voltage fault) |
| 522748 | 12 | | Exhaust throttle (motor fault) |
| 522749 | 12 | | Exhaust throttle (sensor system fault) |
| | 12 | | Exhaust throttle (MPU fault) |
| 522750 | 12 | | Exhaust throttle (PCB fault) |
| 522751 | 19 | | Exhaust throttle (CAN fault) |

| Fault code | | Description | |
|------------|-----|--|---|
| YANMAR SPN | FMI | Area | Status |
| 630 | 12 | EEPROM | EEPROM memory deletion error |
| 522576 | 12 | | EEPROM memory reading error |
| 522578 | 12 | | EEPROM memory writing error |
| 522585 | 12 | ECU internal fault | CY 146 SPI communication fault |
| 522588 | 12 | | Excessive voltage of supply 1 |
| 522589 | 12 | | Insufficient voltage of supply 1 |
| 522590 | 12 | | Sensor supply voltage error 1 |
| 522591 | 12 | | Sensor supply voltage error 2 |
| 522592 | 12 | | Sensor supply voltage error 3 |
| 522744 | 4 | | Actuator drive circuit 1 short to ground |
| 522994 | 4 | | Actuator drive circuit 2 short to ground |
| 523471 | 6 | | Actuator drive circuit 3 chort to ground |
| 523473 | 12 | | AD converter fault 1 |
| 523474 | 12 | | AD converter fault 2 |
| 523475 | 12 | | External monitoring IC and CPU fault 1 |
| 523476 | 12 | | External monitoring IC and CPU fault 2 |
| 523477 | 12 | | ROM fault |
| 523478 | 12 | | Shutoff path fault 1 |
| 523479 | 12 | | Shutoff path fault 2 |
| 523480 | 12 | | Shutoff path fault 3 |
| 523481 | 12 | | Shutoff path fault 4 |
| 523482 | 12 | | Shutoff path fault 5 |
| 523483 | 12 | | Shutoff path fault 6 |
| 523484 | 12 | | Shutoff path fault 7 |
| 523485 | 12 | | Shutoff path fault 8 |
| 523486 | 12 | | Shutoff path fault 9 |
| 523487 | 12 | | Shutoff path fault 10 |
| 523488 | 0 | | Recognition error of engine speed |
| 3059 | 5 | Breather heater (optional parts for 4TNV86CT and 4TNV98CT) | Breather heater disconnection |
| | 4 | | Breather heater short circuit (GND) |
| | 3 | | Breather heater short circuit (VB) |
| 522323 | 0 | Air cleaner switch | Air cleaner clogged alarm |
| 522329 | 0 | Water weparator switch | Water separator alarm |
| 167 | 5 | Charge switch | Charge switch disconnection |
| | 1 | | Charge alarm |
| 100 | 4 | Oil pressure switch | Oil pressure switch disconnection |
| | 1 | | Low oil pressure alarm |
| 522573 | 0 | DPF | Excessive PM accumulation (method C) |
| 522574 | 0 | | Excessive PM accumulation (method P) |
| 522575 | 7 | | Regeneration failure (stationary regeneration failure) |
| 522577 | 11 | | Regeneration failure (staonary regeneration not performed) |
| 3250 | 0 | DPF intermediate temperature sensor | DPF intermediate temperature sensor abnormal rise in temperature (post-injection malfunction) |

| Fault code | | Description | |
|------------|-----|------------------|--|
| YANMAR SPN | FMI | Area | Status |
| 3720 | 16 | DPF OP interface | Ash cleaning request 1 |
| | 0 | | Ash cleaning request 2 |
| 3719 | 16 | | Stationary regeneration standby |
| | 0 | | Backup mode |
| 3695 | 14 | | Reset regeneration is inhibited |
| 3719 | 9 | | Regeneration failure (recovery regeneration failure) |
| | 7 | | Recovery regeneration is inhibited |