


## **SECTION 4 ELECTRICAL SYSTEM**

Group 1 Component Location .....	4-1
Group 2 Monitoring system .....	4-3
Group 3 Electrical Circuit .....	4-16
Group 4 Electrical Component Specification .....	4-32
Group 5 Connectors .....	4-39

## SECTION 4 ELECTRICAL SYSTEM

### GROUP 1 COMPONENT LOCATION


#### 1. LOCATION 1



55Z94EL02

- |                            |                            |                                |
|----------------------------|----------------------------|--------------------------------|
| 1 Head light switch        | 8 Breaker operation switch | 15 Fuse box                    |
| 2 Work light switch        | 9 Accel dial switch        | 16 Cigar lighter               |
| 3 Travel alarm switch      | 10 Quick clamp switch      | 17 Horn switch                 |
| 4 Cab light switch         | 11 Wiper switch            | 18 Radio & CD/MP3 player       |
| 5 Beacon lamp switch       | 12 Washer switch           | 19 Aircon & heater controller  |
| 6 Breaker selection switch | 13 Master switch           | 20 Boom offset switch (-#0839) |
| 7 Start switch             | 14 Speaker                 |                                |

## 2. LOCATION 2



55Z94EL03

- |                 |                       |                               |
|-----------------|-----------------------|-------------------------------|
| 1 Lamp          | 6 Fuel filler pump    | 11 Engine oil pressure switch |
| 2 Horn          | 7 Washer pump         | 12 Start relay                |
| 3 Master switch | 8 Fuel sender         | 13 Travel alarm buzzer        |
| 4 Battery       | 9 Temperature sender  | 14 MCU                        |
| 5 Battery relay | 10 Air clearer switch | 15 ECU                        |

## GROUP 2 MONITORING SYSTEM

### 1. OUTLINE


Monitoring system consists of the monitor part and switch part.

The monitor part gives warnings when any abnormality occurs in the machine and informs the condition of the machine.

Various select switches are built into the monitor panel, which act as the control portion of the machine control system.

### 2. CLUSTER

#### 1) MONITOR PANEL



60CR93CD02

## 2) CLUSTER CHECK PROCEDURE

### (1) Start key : ON

#### ① Check monitor initial 6 seconds

- a. All lamps light up.
- b. Buzzer sound.

#### ② Check monitor after 3 seconds : Indicate machine condition

- a. Tachometer : 0 rpm
- b. Fuel gauge : Pointed at appropriate level
- c. Engine coolant temperature gauge : Pointed at appropriate level
- d. Warning lamp
  - ※ During start key ON the engine oil pressure lamp and battery charging lamp go on, but it is not abnormal.
  - ※ When engine coolant temperature below 30°C, the warming up lamp lights up and then operating the preheat switch.

### (2) Start of engine

#### ① Check machine condition

- a. Tachometer pointed at present rpm
- b. Gauge and warning lamp : Indicate at present condition.
- ※ When normal condition : All warning lamp OFF
- c. Travel speed pilot lamp : Low (turtle)

#### ② When abnormal condition

- a. The lamp lights up and the buzzer sounds.
- b. If BUZZER STOP switch is pressed, buzzer sound is canceled but the lamp light up until normal condition.


### 3. CLUSTER CONNECTOR

#### 1) CN-56 CONNECTOR

No.	Signal	Input/ Output
1	Null	-
2	Null	-
3	Alternator signal	Input
4	Over heat signal	Input
5	Tacho signal	Input
6	Null	-
7	Null	-
8	Travel relay	Output
9	Power 12V	-
10	Power IG 12V	-
11	Null	-
12	Illumination	Input
13	Null	-
14	Null	-
15	Fuel level sender	Input
16	Hyd oil temp sendor	Input
17	Water temp sender	Input
18	GND	-
19	GND	-
20	GND	-

CN-56

10	9	8	7	6	5	4	3	2	1
20	19	18	17	16	15	14	13	12	11



#### 2) CN-57 CONNECTOR

No.	Signal	Input/ Output
1	Null	-
2	Engine oil pressure switch	Input
3	Air cleaner signal	-
4	Boom swing signal	-
5	Null	-
6	Null	-
7	Null	-
8	Null	-
9	Program dump	-
10	Null	-
11	COM-GND	Input
12	RS232-RX	Input
13	RS232-TX	Output
14	RS485-RX	Input
15	RS485-TX	Output
16	Pre heat signal	Input

CN-57


8	7	6	5	4	3	2	1
16	15	14	13	12	11	10	9

5594EL15

## 4. CLUSTER FUNCTION

### 1) GAUGES AND DISPLAYS

#### (1) LCD display



① **Service meter** : This meter shows the total operation hours of the machine.

※ Always ensure the operating condition of the meter during the machine operation.


※ The last unit  $\frac{1}{10}$  indicates 1/10 of  $\frac{1}{10}$  hours.

(for example :  $\frac{1}{10}$  indicates 6 minutes)

② **Clock** : This displays the current time.

※ Refer to the "menu switch" for the setting time/ESL switch.

#### (2) Fuel gauge




① This gauge indicates the amount of fuel in the fuel tank.

② Fill the fuel when the red range or warning lamp  blinks.

※ If the gauge indicate the red range or warning lamp  ON. Even though the machine is on the normal condition, check the electric device as that can be caused by the poor connection of electricity or sensor.

#### (3) Engine coolant temperature gauge




① This indicates the temperature of coolant.

② When the red range pointed or warning lamp  blinks, engine do not abruptly stop but run it at medium speed to allow it to cool gradually, then stop it.

Check the radiator and engine.

※ If the engine is stopped without cooled down running, the temperature of engine parts will rise suddenly, this could cause severe engine trouble.

#### (4) Engine rpm gauge



① This gauge displays the number of engine revolutions per minute.


## 2) WARNING AND PILOT LAMPS

### (1) Fuel low level warning lamp




- ① This lamp blinks and the buzzer sounds when the level of fuel is below 18 ℥ (4.8 U.S. gal).
- ② Fill the fuel immediately when the lamp blinks.

### (2) Hydraulic oil temperature warning lamp




- ① This warning lamp operates and the buzzer sounds when the temperature of hydraulic oil is over 105°C (221°F) .
- ② Check the hydraulic oil level when the lamp blinks.
- ③ Check for debris between oil cooler and radiator.

### (3) Overheat warning lamp



- ① This lamp blinks and the buzzer sounds when the temperature of coolant is over the normal temperature 110°C (230°F) .
- ② Check the cooling system when the lamp blinks.

### (4) Engine oil pressure warning lamp




- ① This lamp blinks and the buzzer sounds after starting the engine because of the low oil pressure.
- ② If the lamp blinks during engine operation, shut OFF engine immediately. Check oil level.

### (5) Air cleaner warning lamp



- ① This lamp blinks and the buzzer sounds when the filter of air cleaner is clogged.
- ② Check the filter and clean or replace it.


**(6) Battery charging warning lamp**



R5573CD16

- ① This lamp blinks and the buzzer sounds when the starting switch is ON, it is turned OFF after starting the engine.
- ② Check the battery charging circuit when this lamp blinks during engine operation.


**(7) Warming up pilot lamp**



R5573CD18

- ① This lamp is turned ON when the coolant temperature is below 30°C (86°F).
- ② The automatic warming up is cancelled when the engine coolant temperature is above 30°C, or when 10 minutes have passed since starting.


**(8) Preheat pilot lamp**



R5573CD19

- ① When engine preheating switch is turned ON, pilot lamp comes ON.
- ② Refer to the preheating switch for details.


**(9) Travel speed pilot lamp (high)**



R5573CD20

- ① When this lamp turned ON, the machine travel high speed.
- ② Refer to the travel speed select switch for details.


**(10) Travel speed pilot lamp (low)**



R5573CD21

- ① When this lamp turned ON, the machine travel low speed.
- ② Refer to the travel speed select switch for details.

**(11) Auto idle pilot lamp**




- ① If the control lever and pedal are not moved for several seconds with auto idle switch pressed, the indicator illuminates and engine speed is decelerated.
- ② If the auto idle switch is pressed once more or the control lever or pedal is moved, the indicator turns off and the number of engine revolution is turned to the previous condition.

**(12) M mode pilot lamp**




- ① This lamp is ON when the M mode switch is pressed.
- ② Engine is operated with a maximum speed.

**(13) Boom offset pilot lamp (-#0839)**




- ① This lamp is ON when the boom offset switch is pressed.

## (6) Menu and enter switch




① These switches are used to set time or set ESL (Engine Start Limit) function.

- The Enter button (◎) is used to select a function.
- The Menu button (◎) is used to select a menu or return to the time display menu.



### ② Setting time

- Press Enter button (◎) to set time, then the screen will be changed to a display for time setting as a following picture and time cipher will blink.
- **Set hours** : When the cipher for hour blinks, press up (▲) or down (▼) button and set the hour.
- **Set minutes**: When the cipher for minute blinks, press up (▲) or down (▼) button and set the minute.



### ③ Set ESL (Engine Start Limit) function


- Press Menu button (◎), the display is changed from the time display menu to ESL function menu.
- Select YES or NO by Move button (▲, ▼) and set the ESL function by the Enter button (◎).
  - YES : ESL function is activated.
  - NO : ESL function is cancelled.

### ④ Set the interval time

- Select ESL function to YES and press the Enter button (◎), then the display is changed to the interval time set menu.
- Set the interval time by move button (▲, ▼) and press the Enter button (◎).
- You can finish setting the interval time by inputting the password and pressing the Enter button (◎) once more.
- Interval times : 5 kinds (0, 10, 30, 60 minutes, 1day)


\* If the ESL function is set to YES, the password is required when a operator starting engine first.

But the operator can restart the engine within the interval time period without inputting the password.



## ⑤ Change password

- Select ESL function to YES and press the Menu button (Ⓐ), the display is shifted to the password change menu.
- Input a new password (Sn : - - - -) after enter the current password successfully (SC : - - - -).
- Push enter (◎) button for a second to finish the setting after the new password is entered once again (SA : - - - -).
- When the setting is done, the display will blink 3 times and return to the time display screen.



## ⑥ Check machine and engine diagnostic codes

- If the F : Code is displayed on the LCD display, you can check faults of the machine and/or engine.
- The machine fault code is displayed by pressing the Menu button (Ⓐ) and the engine fault code is displayed by pressing the Menu button (Ⓑ) once more.
- Other fault codes can be displayed by using the Move up / down button (Ⓐ, Ⓑ).

\* Refer to the following pages for the fault codes.

## ⑦ Machine fault code


Fault code		Description
HCESPN	FMI	
105	0	Working pressure sensor data above normal range (or open circuit)
	1	Working pressure sensor data below normal range
	2	Working pressure sensor data error
	4	Working pressure sensor circuit - voltage below normal, or shorted to low source
	14	Working pressure sensor circuit - special instructions
	16	Working pressure sensor circuit - voltage valid but above normal operational range
	18	Working pressure sensor circuit - voltage valid but below normal operational range
167	4	Travel speed solenoid circuit - voltage below normal, or shorted to low source (or open circuit)
	6	Travel speed solenoid circuit - current above normal
503	0	Brake pressure sensor data above normal range (or open circuit)
	1	Brake pressure sensor data below normal range
	2	Brake pressure sensor data error
	4	Brake pressure sensor data - voltage below normal, or shorted to low source
	16	Brake pressure sensor data - voltage valid but above normal operational range
	18	Brake pressure sensor data - voltage valid but below normal operational range
	0	Working brake pressure sensor data above normal range (or open circuit)
505	1	Working brake pressure sensor data below normal range
	2	Working brake pressure sensor data error
	4	Working brake pressure sensor circuit - voltage below normal, or shorted to low source
	16	Working brake pressure sensor circuit - voltage valid but above normal operational range
	18	Working brake pressure sensor circuit - voltage valid but below normal operational range
	0	Ram lock solenoid circuit - voltage below normal, or shorted to low source (or open circuit)
525	4	Ram lock solenoid circuit - current above normal
	6	Ram lock solenoid circuit - current above normal
530	0	Travel fwd pilot pressure sensor data above normal range (or open circuit)
	1	Travel fwd pilot pressure sensor data below normal range
	2	Travel fwd pilot pressure sensor data error
	4	Travel fwd pilot pressure sensor circuit - voltage below normal, or shorted to low source
	14	Travel fwd pilot pressure sensor circuit - special instructions
	16	Travel fwd pilot pressure sensor circuit - voltage valid but above normal operational range
	18	Travel fwd pilot pressure sensor circuit - voltage valid but below normal operational range
701	4	Hour meter circuit - voltage below normal, or shorted to low source
705	0	MCU input voltage high
	1	MCU input voltage low
707	1	Alternator node I voltage low (or open circuit)
714	3	Acc. dial circuit - voltage above normal, or shorted to high source (or open circuit)
	4	Acc. dial circuit - voltage below normal, or shorted to low source
830	12	MCU internal memory error
840	2	Cluster communication data error
841	2	ECM communication data error
850	2	RMCU communication data error

## ⑧ Engine fault code

Fault code		Description
YANMAR SPN	FMI	
1210	4	Engine fuel rack position sensor : shorted to low source
	3	Engine fuel rack position sensor : shorted to high source
91	4	Accelerator pedal position sensor "A" : shorted to low source
	3	Accelerator pedal position sensor "A" : shorted to high source
	2	Accelerator pedal position sensor "A" : intermittent fault
	1	Accelerator pedal position sensor "A" : below normal operational range (SAE J1843)
	0	Accelerator pedal position sensor "A" : above normal operational range (SAE J1843)
	15	Accelerator pedal position sensor "A" : not available (SAE J1843)
29	4	Accelerator pedal position sensor "B" : shorted to low source
	3	Accelerator pedal position sensor "B" : shorted to high source
	2	Accelerator pedal position sensor "B" : intermittent fault
	1	Accelerator pedal position sensor "B" : below normal operational range (SAE J1843)
	0	Accelerator pedal position sensor "B" : above normal operational range (SAE J1843)
	8	Accelerator pedal position sensor "B" : communication fault
	15	Accelerator pedal position sensor "B" : not available (SAE J1843)
108	4	Barometric pressure sensor : shorted to low source
	3	Barometric pressure sensor : shorted to high source
	2	Barometric pressure sensor : intermittent fault
1136	4	E-ECU internal temperature sensor : shorted to low source
	3	E-ECU internal temperature sensor : shorted to high source
	2	E-ECU internal temperature sensor : intermittent fault
	0	E-ECU internal temperature : too high
110	4	Engine coolant temperature sensor : shorted to low source
	3	Engine coolant temperature sensor : shorted to high source
	2	Engine coolant temperature sensor : intermittent fault
	0	Engine coolant temperature : too high
1079	4	Sensor 5V : shorted to low source
	3	Sensor 5V : shorted to high source
	2	Sensor 5V : intermittent fault
158	1	E-ECU system voltage : too low
	0	E-ECU system voltage : too high
1078	4	Engine fuel injection pump speed sensor : shorted to low source
522402	4	Auxiliary speed sensor : shorted to low source
522241	4	Engine fuel rack actuator relay : open circuit
	3	Engine fuel rack actuator relay : short circuit
	7	Engine fuel rack actuator relay : mechanical malfunction
	2	Engine fuel rack actuator relay : intermittent fault
522243	4	Air heater relay : open circuit
	3	Air heater relay : short circuit
	2	Air heater relay : intermittent fault


### 3) SWITCHES

#### (1) Travel speed control switch




- ① This switch is to control the travel speed which is changed to high speed (rabbit mark) by pressing the switch and low speed (turtle mark) by pressing it again.

#### (2) Auto idle switch




- ① This switch is used to actuate or cancel the auto idle function.  
② When the switch actuated and all control levers and pedals are at neutral position, engine speed will be lowered automatically to save fuel consumption.

#### (3) M mode switch




- ① This switch is used to maximum power.  
② When this switch is pressed, the M mode pilot lamp is ON or OFF.

#### (4) Move (down) & buzzer stop switch



- ① When the starting switch is turned ON first, normally the alarm buzzer sounds for 6 seconds during lamp check operation.  
② The lamp lights ON and the buzzer sounds when the machine has a problem.  
In this case, press this switch and buzzer stops, but the lamp lights until the problem is cleared.  
③ This switch is used to move down or decrease input value.  
※ Refer to page 4-11.


#### (5) Move (up) switch



- ① This switch is used to move up or increase input value.  
※ Refer to page 4-11.

Fault code		Description
YANMAR SPN	FMI	
522242	4	Cold start device : open circuit
	3	Cold start device : short circuit
	2	Cold start device : intermittent fault
522251	4	EGR stepping motor "A" : open circuit
	3	EGR stepping motor "A" : short circuit
522252	4	EGR stepping motor "B" : open circuit
	3	EGR stepping motor "B" : short circuit
522253	4	EGR stepping motor "C" : open circuit
	3	EGR stepping motor "C" : short circuit
522254	4	EGR stepping motor "D" : open circuit
	3	EGR stepping motor "D" : short circuit
100	4	Oil pressure switch : shorted to low source
	1	Oil pressure : too low
167	4	Battery charge switch : shorted to low source
	1	Battery charge : charge warning
522314	0	Engine coolant temperature : abnormal temperature
522323	0	Air cleaner : mechanical malfunction
522329	0	Oily water separator : mechanical malfunction
190	0	Engine speed : over speed condition
638	4	Engine fuel rack actuator : shorted to low source
	3	Engine fuel rack actuator : shorted to high source
	7	Engine fuel rack actuator : mechanical malfunction
639	12	High speed CAN communication : communication fault
630	2	E-ECU internal fault : EEPROM check sum error (data set 2)
	12	E-ECU internal fault : EEPROM error
628	12	E-ECU internal fault : flashROM check sum error (main software)
	2	E-ECU internal fault : flashROM check sum error (data set 1)
	2	E-ECU internal fault : flashROM check sum error (data set 2)
1485	4	E-ECU main relay : shorted to low source
522727	12	E-ECU internal fault : cyclic redundancy check of sub-CPU error
	12	E-ECU internal fault : acknowledgement of sub-CPU error
	12	E-ECU internal fault : communication with sub-CPU error
522728	12	E-ECU internal fault : engine map data version error
522730	12	Immobilizer : CAN communication fault
	8	Immobilizer : pulse communication fault
1202	2	Immobilizer : system fault

GROUP 3 ELECTRICAL CIRCUIT




**MEMORANDUM**

## 1. POWER CIRCUIT

The negative terminal of battery is grounded to the machine chassis.

When the start switch is in the OFF position, the current flows from the positive battery terminal as shown below.

### 1) OPERATING FLOW




※ I/conn : Intermediate connector

### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
OFF	OFF	① - GND (battery) ② - GND (battery relay) ③ - GND (fusible link)	10~12.5V

※ GND : Ground

## POWER CIRCUIT




## 2. STARTING CIRCUIT


### 1) OPERATING FLOW

Battery (+) terminal → Battery relay [CR-1] → Fusible link [CN-60]  
 → I/conn [CN-3 (2)] → Master switch [CS-74] → Fuse box No.1 → Start key [CS-2 (1)]

\* Start switch : ON



\* Start switch : START




### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
Operating	Start	① – GND (battery) ② – GND (start key) ③ – GND (battery relay M4) ④ – GND (starter B <sup>+</sup> ) ⑤ – GND (starter M) ⑥ – GND (start relay) ⑦ – GND (battery relay M8)	10~12.5V

\* GND : Ground

## STARTING CIRCUIT



### 3. CHARGING CIRCUIT


When the starter is activated and the engine is started, the operator releases the key switch to the ON position.

Charging current generated by operating alternator flows into the battery through the Battery relay (CR-1).

The current also flows from alternator to each electrical component and controller through the fuse box.

#### 1) OPERATING FLOW

##### (1) Warning flow



##### (2) Charging flow




#### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
Operating	Start	<p>① – GND (battery voltage) ② – GND (battery relay) ③ – GND (alternator B<sup>+</sup> terminal) ④ – GND (alternator L terminal) ⑤ – GND (cluster)</p>	10~12.5V

\* GND : Ground

## CHARGING CIRCUIT



## 4. HEAD AND WORK LAMP CIRCUIT

### 1) OPERATING FLOW

Fuse box (No.10) → Head lamp relay [CR-13 (86) → (85)] → Switch panel [CN-116 (1)]

Fuse box (No.11) → Work lamp relay [CR-3 (86) → (85)] → Switch panel [CN-116 (2)]

#### (1) Head lamp switch ON

Head lamp switch ON [CN-116(1)] → Head lamp relay [CR-13 (85) → (87)]

- I/conn [CN-4 (2)] → Head lamp ON [CL-3, 4 (2)]
- I/conn [CN-5 (1)] → I/conn [CN-7 (11)] → Cigar lighter [CL-2 (1)]
- Remote controller illumination ON [CN-245 (9)]
- MP3 & Radio player illumination ON [CN-27 (9)]
- USB & Socket illumination ON [CN-246 (7)]
- Cluster illumination ON [CN-56 (12)]
- I/conn [CN-2 (8)] → AC/Heater controller illumination ON

#### (2) Work lamp switch ON

Work light switch ON [CN-116 (2)] → Work lamp [CR-3 (85) → (87)] → I/conn [CN-4 (8)]


I/conn [CN-12 (2)] → Work lamp ON [CL-5 (2)]

### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
STOP	ON	① - GND (fuse box) ② - GND (switch power input) ③ - GND (switch power output) ④ - GND (head light)	10~12.5V
STOP	ON	⑤ - GND (fuse box) ⑥ - GND (switch power input) ⑦ - GND (switch power output) ⑧ - GND (work light)	10~12.5V

\* GND : Ground

## HEAD AND WORK LAMP CIRCUIT



## 5. BEACON LAMP AND CAB LAMP CIRCUIT

### 1) OPERATING FLOW

Fuse box (No.18) → Beacon lamp relay [CR-85(30) → (85)] → Switch panel [CN-116 (6)]

Fuse box (No.20) → Cab lamp relay [CR-9 (30) → (85)] → Switch panel [CN-116 (7)]

#### (1) Beacon lamp switch ON

Beacon lamp switch ON [CN-116 (6)] → Beacon lamp relay [CR-85 (87)] → I/conn [CN-6 (1)]

→ Beacon lamp ON [CL-7]

#### (2) Cab lamp switch ON

Cab lamp switch ON [CN-116 (7)] → Cab lamp relay [CR-9 (87)] → I/conn [CN-6 (4)]


→ Cab lamp ON [CL-9, 10]

### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
STOP	ON	① - GND (fuse box) ② - GND (switch power input) ③ - GND (switch power output) ④ - GND (beacon & cab lamp)	10~12.5V

\* GND : Ground

## BEACON LAMP CIRCUIT




55Z94EL08

## 6. WIPER AND WASHER CIRCUIT

### 1) OPERATING FLOW

#### (1) Key switch ON



#### (2) Wipe switch ON : 1st step (low speed)

Wiper switch ON [CS-3 (8) → (7)] → Int wiper relay [CR-6 (6) → (3)] → Wiper relay [CR-4 (85) → (30)]  
 → Washer motor operating [CN-21 (4)]

#### (3) Wiper switch ON : 2nd step (washer)

Wiper switch ON [CS-3 (7)] → Int wiper relay [CR-6 (1)]

```

graph LR
    A[Wiper switch ON [CS-3 (7)]] --> B[Int wiper relay [CR-6 (1)]]
    B --> C[Washer switch [CS-30 (6)]]
    B --> D[Wiper relay [CR-4 (85) → (30)]]
    B --> E[Wiper motor operating [CN-21(1)]]
  
```

Washer switch ON [CS-30 (6)] → I/conn [CN-5 (3)] → Washer pump operating [CN-22 (1)]

#### (4) Auto parking (when switch OFF)


Switch OFF → Wiper motor [CN-21 (1)] → Wiper switch [CS-3 (5) → (8)] → Int wiper relay [CR-6 (6) → (3)]  
 → Wiper relay [CR-4 (85) → (30)] → Wiper motor [CN-21 (4)]  
 → Wiper motor parking position by wiper motor controller

### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
STOP	ON	① - GND (fuse box) ② - GND (switch power input) ③ - GND (switch power output) ④ - GND (wiper motor)	10~12.5V


\* GND : Ground

## WIPER AND WASHER CIRCUIT




55Z94EL09

## MONITORING CIRCUIT















## ELECTRIC CIRCUIT FOR HYDRAULIC









## GROUP 4 ELECTRICAL COMPONENT SPECIFICATION






Part name	Symbol	Specification	Check
Battery		12V × 100Ah	<ul style="list-style-type: none"> <li>* Check specific gravity</li> <li>1.280 over : over charged</li> <li>1.280 ~ 1.250 : normal</li> <li>1.250 below : recharging</li> </ul>
Battery relay	 CR-1	Rated load : 12V 100A (continuity) 1000A (30 second)	<ul style="list-style-type: none"> <li>* Check coil resistance Normal : about <math>12\Omega</math></li> <li>* Check contact Normal : <math>\infty\Omega</math></li> </ul>
Start key	 CS-2	12V	<ul style="list-style-type: none"> <li>* Check contact OFF : <math>\infty\Omega</math> (for each terminal) ON : <math>0\Omega</math> (for terminal 1-3 and 1-2) START : <math>0\Omega</math> (for terminal 1-5)</li> </ul>
Pressure switch (for engine oil)	 CD-18	0.5 kgf/cm <sup>2</sup> (N.C TYPE)	<ul style="list-style-type: none"> <li>* Check resistance Normal : <math>0\Omega</math> (CLOSE)</li> </ul>
Temperature sensor	 CD-8	-	<ul style="list-style-type: none"> <li>* Check resistance 50°C : <math>804\Omega</math> 80°C : <math>310\Omega</math> 100°C : <math>180\Omega</math></li> </ul>






Part name	Symbol	Specification	Check
Air cleaner pressure switch	 CD-10	12-24V Max. Load : 6W	* Restriction limits 6.2 kPa ± 8% at 23°C
Fuel sender	 CD-2	-	* Check resistance Full : 100Ω Low : 500Ω Empty warning : 700Ω
Relay	 CR-2 CR-3 CR-4 CR-5 CR-7 CR-9 CR-12 CR-13 CR-24 CR33 CR-36 CR-62 CR-85	12V 20A	* Check resistance Normal : about 200Ω (for terminal 85-86) : 0Ω (for terminal 30-87a) : ∞Ω (for terminal 30-87)
Relay	 CR-23 CR-47	12V 60A	* Rated coil current 1.2±0.3A
Solenoid valve	 CN-66 CN-68 CN-70 CN-140	12V 1.87A	* Check resistance Normal : 15~25Ω (for terminal 1-2)
Speaker	 CN-23(LH) CN-24(RH)	80±22dB	* Check resistance Normal : 4Ω

Part name	Symbol	Specification	Check
Boom swing switch	 CS-47	12V 16A	※ Check contact Normal OFF - $\infty \Omega$ (for terminal 1-5,2-6) - $0 \Omega$ (for terminal 5-7,6-8)
Quick clamp switch	 CS-67	12V 16A	※ Check contact Normal OFF - $\infty \Omega$ (for terminal 1-5,2-6) - $0 \Omega$ (for terminal 5-7,6-8)
Lamp	 CL-5    CL-6 CL-9    CL-10	12V 55W (H3 TYPE)	※ Check disconnection Normal : $1.2 \Omega$
Room lamp	 CL-1	12V 10W	※ Check disconnection Normal : a few $\Omega$
Fuel filler pump	 CN-145	12V 35 l/min	※ Check operation Supply power (for terminal 1) : 12V
Horn	 CN-20   CN-25	12V 3.5A	100~115 dB (A) (at 13V 2m)

Part name	Symbol	Specification	Check
Safety switch	 CS-4	Micro	※ Check contact Normal : $0\Omega$ (for terminal A-B) $\infty\Omega$ (for terminal A-C) Operating : $\infty\Omega$ (for terminal A-B) $0\Omega$ (for terminal A-C)
Pressure switch	 CD-11      CD-12	DC24V 2A 10bar (N.O type)	※ Check contact Normal : $0.1\Omega$
Pressure sensor	 CD-7	8~30V	※ Check contact Normal : $0.1\Omega$
Beacon lamp	 CL-7	12V (Strobe type)	※ Check disconnection Normal : a few $\Omega$
Wiper switch	 CS-3	12V 16A	※ Check contact Normal : $\infty\Omega$
Washer pump	 CN-22	12V 3.8A	※ Check contact Normal : $3\Omega$ (for terminal 1-2)

Part name	Symbol	Specification	Check
Cigar lighter		12V 10A 1.4W	* Check coil resistance Normal : about $1M\Omega$ * Check contact Normal : $\infty\Omega$ Operating time : 5~15sec
Wiper motor		12V 3A	* Check contact Normal : $6\Omega$ (for terminal 2-6)
Radio & CD/MP3 player		DC 14.4V Negative ground Load impedance : $4\Omega \times 4$	* Check voltage 10 ~ 12.5V (for terminal 1-3, 3-8)
Receiver dryer		12V	* Check contact Normal : $0\Omega$
Starter		12V 3.0kW	* Check contact Normal : $0.1\Omega$
Alternator		12V 80A	* Check contact Normal : $0\Omega$ (for terminal B+-1) Normal : 24 ~ 27.5V

Part name	Symbol	Specification	Check
Travel buzzer		12V 107±4dB at 4ft	-
Compressor		12V 38W	-
Air con fan motor		12V 8.5A	-
Fuel feed pump		12V Max. 20A	-
Master switch		12V 180A (In Countinous capaty) 1000A (In rush)	-

Part name	Symbol	Specification	Check
Preheater	 CN-80	12V 42A 500W	-
12V socket	 CN-139	12V 120W	-
Duct sensor		1°C OFF 4°C ON	※ Check resistance Normal : 0Ω (for terminal 1-2) the atmosphere temp : over 4°C
Accel dial	 CN-142	Input voltage : 5Vdc±2% Operating current : 8 mA (Normal) 10 mA (Max)	※ Check resistance Normal : about 5kΩ (for terminal A-C) ※ Check voltage Normal : about 5V (for terminal A-C) : 2~4.5V (for terminal C-B)
Int wiper relay	 CR-6	12V 12A	Wiper motor off time : 4.5±1 sec
Fusible link	 CN-60 CN-95	60A	※ Check disconnection Normal : 0Ω (connect ring terminal and check resist between terminal 1 and 2)

## GROUP 5 CONNECTORS

### 1. CONNECTOR DESTINATION

















Connector number	Type	No. of pin	Destination	Connector part No.	
				Female	Male
CN-1	AMP	12	Cabin room harness - Main harness	S816-012002	174663-2
CN-2	AMP	12	Aircon harness - Cabin room harness	S816-012002	174663-2
CN-3	YAZAKI	2	Fusible link - Fuse box	S813-030201	S813-130201
CN-4	AMP	15	Cabin room harness - Main harness	2-85262-1	368301-1
CN-5	AMP	15	Cabin room harness - Main harness	2-85262-1	368301-1
CN-6	DEUTSCH	4	Cabin harness - Cabin room lamp harness	DT06-4S-EP06	DT04-4P-E005
CN-7	KET	20	Console harness - Main harness	MG610240	-
CN-8	AMP	12	Cabin harness	S816-012002	-
CN-12	AMP	2	Boom harness - Work lamp harness	-	S816-102002
CN-13	AMP	10	Bottom harness	174655-2	-
CN-14	AMP	15	Bottom harness	2-85262-1	-
CN-15	AMP	15	Bottom harness	-	368301-1
CN-17	AMP	12	Bottom harness	-	174663-2
CN-19	YAZAKI	2	Bottom harness	-	S813-130201
CN-20	DEUTSCH	2	Horn	DT06-2S-EP06	-
CN-21	AMP	12	Wiper harness	S816-012002	-
CN-22	KET	2	Washer tank	MG640605	-
CN-23	KET	2	Speaker LH	MG610070	-
CN-24	KET	2	Speaker RH	MG610070	-
CN-25	DEUTSCH	2	Horn	DT06-2S-EP06	-
CN-27	-	16	Cassette radio	PK145-16017	-
CN-28	AMP	1	Air-con comp	S810-001202	-
CN-29	KET	2	Receiver dryer	MG640795	-
CN-36	-	-	Fuse box	21L7-00250	-
CN-45	TERM	1	Starter	ST710246-2	-
CN-48	AMP	40	MCU	DRC26-40SA	-
CN-51	DEUTSCH	40	Governor DC motor controller	DRC26-40SA	S816-103002
CN-55	AMP	2	Travel alarm PS	S816-002002	S816-102002
CN-56	AMP	20	Cluster	175967-2	-
CN-57	AMP	16	Cluster	175966-2	-
CN-60	YAZAKI	2	Fusible link	-	7122-4125-50
CN-61	TERM	1	Fuel filler pump	S822-014000	S822-114000
CN-66	DEUTSCH	2	Breaker solenoid	DT06-2S-EP06	-
CN-68	DEUTSCH	2	Safety solenoid	DT06-2S-EP06	-
CN-70	DEUTSCH	2	Travel HI-LO solenoid	DT06-2S-EP06	-
CN-74	KET	2	Alternator	ST710285-2	-













Connector number	Type	No. of pin	Destination	Connector part No.	
				Female	Male
CN-76	KET	6	DC motor	MG640515-4	-
CN-79	YAZAKI	3	Fuel cut-off solenoid	S813-060300	-
CN-80	AMP	1	Pre heater	ST710384-2	-
CN-81	DEUTSCH	2	Travel buzzer	DT06-2S-EP06	DT04-2P-E005
CN-83	AMP	2	Air-con fan	MG640188-5	-
CN-92	KET	1	Anti-restart relay	S814-001100	-
CN-95	YAZAKI	2	Fusible link	-	S813-130201
CN-116	AMP	12	Switch panel	368542-1	-
CN-126	DEUTSCH	4	RS232 connector	DT06-4S-EP06	-
CN-139	AMP	2	12V socket	S810-002202	-
CN-140	DEUTSCH	2	Quick coupler	DT06-2S-EP06	DT04-2P-E005
CN-142	DEUTSCH	3	Accel dial	DT06-3S-EP06	-
CN-144	AMP	2	Handsfree	S810-002202	-
CN-145	KET	2	Fuel feed pump	7123-6423-30	-
CN-148	DEUTSCH	6	Service tool	DTM06-6S-E008	-
CN-170	PACKARD	2	Seat heat switch	12162017	-
CN-243	DEUTSCH	4	RS232 connector	DT06-4S-EP06	-
CN-245	AMP	12	Remote controller assy	368542-1	-
CN-246	AMP	12	USB & Socket assy	174045-2	-
CN-258	KET	1	Aircon comp power	MG640944-5	MG650943-5
CN-263	DEUTSCH	2	Aircon comp relay	DT06-2S-EP06	DT04-2P-E005
<b>· LAMP</b>					
CL-1	KET	2	Room lamp	MG610392	-
CL-2	AMP	3	Cigar light	S810-003202	-
CL-3	DEUTSCH	2	Head lamp	DT06-2S-EP06	DT04-2P-E005
CL-4	DEUTSCH	2	Head lamp	DT06-2S-EP06	DT04-2P-E005
CL-5	DEUTSCH	2	Work lamp	DT06-2S-EP06	-
CL-6	DEUTSCH	2	Work lamp	DT06-2S-EP06	-
CL-7	-	1	Beacon lamp	-	S822-114000
CL-9	DEUTSCH	2	Cabin lamp	DT06-2S-EP06	-
CL-10	DEUTSCH	1	Cabin lamp	DT06-2S-EP06	-
<b>· RELAY</b>					
CR-1	AMP	2	Battery relay	S816-002002	S816-102002
CR-2	AMP	4	Horn relay	S810-004002	-
CR-3	HELLA	4	Work lamp	SJA003526-001	-
CR-4	HELLA	4	Wiper	SJA003526-001	-
CR-5	HELLA	4	Anti-restart relay	SJA003526-001	-
CR-6	KET	6	Int wiper relay	S810-006002	-
CR-7	HELLA	4	Aircon component	SJA003526-001	-

Connector number	Type	No. of pin	Destination	Connector part No.	
				Female	Male
CR-9	HELLA	4	Cabin lamp	SJA003526-001	-
CR-12	HELLA	4	Travel relay	SJA003526-001	-
CR-13	HELLA	4	Head lamp	SJA003526-001	-
CR-23	KET	2	Start relay	S814-002001	-
CR-24	KET	2	Air heater relay	S814-002001	-
CR-33	AMP	4	Air-con fan relay	S810-004002	-
CR-36	HELLA	4	Pre-heater relay	SJA003526-001	-
CR-45	HELLA	4	ECU IG power	SJA003526-001	-
CR-47	KET	2	Fuel cut-off relay	S814-002001	-
CR-50	KET	4	Timer relay	MG610047-5	-
CR-62	HELLA	4	Breaker	SJA003526-001	-
CR-67	Sumitomo Denso	6	ECU main power	6020-6161	-
CR-68	Sumitomo Denso	6	Rack actuator	6020-6161	-
CR-71	HELLA	4	Boom swing	SJA003526-001	-
CR-85	HELLA	4	Beacon lamp	SJA003526-001	-
<b>· SENDER</b>					
CD-1	AMP	2	Hydraulic temp sender	85202-1	-
CD-2	AMP	2	Fuel sender	-	S816-102002
CD-7	DEUTSCH	3	Auto idle pressure switch	DT06-3S-EP06	-
CD-10	KET	1	Air cleaner switch	ST730057-2	-
CD-11	-	2	Travel pressure switch	MG640795	-
CD-12	-	2	Travel pressure switch	MG640795	-
CD-18	AMP	1	Engine oil pressure	ST710345-1	-
CD-30	AMP	2	Water temp	85202-1	-
CD-45	-	2	WIF sensor	-	S816-102003
DO-1	-	2	Diode	21EA-50570	-
DO-2	-	2	Diode	21EA-50570	-
DO-3	-	2	Diode	21EA-50570	-
<b>· SWITCH</b>					
CS-2	KET	6	Start key switch	S814-006000	-
CS-3	SWF	12	Wiper switch	585790	-
CS-4	AMP	3	Safety switch	S816-003002	-
CS-5	-	1	Horn-LH switch	-	DT04-2P-E005
CS-26	DEUTSCH	2	Breaker switch	DT06-2S-EP06	-
CS-30	SWF	12	Wiper washer	585790	-
CS-47	SWF	12	Boom swing switch	585790	-
CS-67	SWF	12	Quick coupler switch	589790	-
CS-74	YAZAKI	2	Master switch	S813-030201	S813-130201
CS-99	SWF	12	Auto idle switch	589790	-

















## 2. CONNECTION TABLE FOR CONNECTORS

### 1) PA TYPE CONNECTOR

















No. of pin	Receptacle connector (female)	Plug connector (male)
5	  S811-005002	  S811-105002
7	  S811-007002	  S811-107002
9	  S811-009002	  S811-109002
11	  S811-011002	  S811-111002

















No. of pin	Receptacle connector (female)	Plug connector (male)
13	  S811-013002	  S811-113002
17	  S811-017002	  S811-117002
21	  S811-021002	  S811-121002

## 2) J TYPE CONNECTOR









No. of pin	Receptacle connector (female)	Plug connector (male)
2	  S816-002001	 
3	  S816-003001	  S816-103001
4	  S816-004001	  S816-104001
8	  S816-008001	  S816-108001





### 3) SWP TYPE CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
1	  S814-001000	  S814-101000
2	  S814-002000	  S814-102000
3	  S814-003000	  S814-103000
4	  S814-004000	  S814-104000





No. of pin	Receptacle connector (female)	Plug connector (male)
6	  S814-006000	  S814-106000
8	  S814-008000	  S814-108000
12	  S814-012000	  S814-112000
14	  S814-014000	  S814-114000

#### 4) CN TYPE CONNECTOR



No. of pin	Receptacle connector (female)	Plug connector (male)
1	 S810-001202	 S810-101202
2	 S810-002202	 S810-102202
3	 S810-003202	 S810-103202
4	 S810-004202	 S810-104202

No. of pin	Receptacle connector (female)	Plug connector (male)
6	 <p>S810-006202</p>	 <p>S810-106202</p>
8	 <p>S810-008202</p>	 <p>S810-108202</p>


### 5) 375 FASTEN TYPE CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	  S810-002402	  S810-102402



### 6) AMP ECONOSEAL CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
36	 344111-1	 344108-1



### 7) AMP TIMER CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	 85202-1	





### 8) AMP 040 MULTILOCK CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
12	  174045-2	


### 9) AMP 070 MULTILOCK CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
14	  173852	



### 10) AMP FASTIN - FASTON CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
6	  925276-0	  480003-9


## 11) KET 090 CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
6	 MG610070	


## 12) KET 090 WP CONNECTORS

No. of pin	Receptacle connector (female)	Plug connector (male)
2	 MG640605	
2	 MG640795	

### 13) KET SDL CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
14	 MG610406	

## 14) DEUTSCH DT CONNECTORS



### \* Modification

E003 : Standard end cap - gray







E004 : Color of connector to be black













E005 : Combination - E004 & E003

EP04 : End cap


EP06 : Combination P012 & EP04

P012 : Front seal enhancement - connectors color to black for 2, 3, 4 & 6pin


No. of pin	Receptacle connector (female)	Plug connector (male)
2	 DT06-2S	 DT06-2P
3	 DT06-3S	 DT06-3P
4	 DT06-4S	 DT06-4P

No. of pin	Receptacle connector (female)	Plug connector (male)
6	 	 
8	 	 
12	 	 


### 15) MOLEX 2CKTS CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
2	 35215-0200	

### 16) ITT SWF CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
10	 SWF593757	

### 17) MWP NMWP CONNECTOR

No. of pin	Receptacle connector (female)	Plug connector (male)
1	 NMWP01F-B	