SECTION 6 TROUBLESHOOTING

Group 1 Before Troubleshooting ····· 6-1
Group 2 Hydraulic and Mechanical System ····· 6-4
Group 3 Electrical System ····· 6-24
Group 4 Mechatronics System ····· 6-39

SECTION 6 TROUBLESHOOTING

GROUP 1 BEFORE TROUBLESHOOTING

1. INTRODUCTION

When a trouble is occurred in the machine, this section will help an operator to maintain the machine with easy.

The trouble of machine is parted Hydraulic & Mechanical system, Electrical system and Mechatronics system. At each system part, an operator can check the machine according to the troubleshooting process diagram.

※ **Before carring out troubleshooting procedure, check monitoring menu in the cluster.**



2. DIAGNOSING PROCEDURE

To carry out troubleshooting efficiently, the following steps must be observed.

STEP 1. Study the machine system

Study and know how the machine is operating, how the system is composing, what kinds of function are installed in the machine and what are specifications of the system components by the machine service manual.
Especially, deepen the knowledge for the related parts of the trouble.



STEP 2. Ask the operator

Before inspecting, get the full story of malfunctions from a witness --- the operator.

1) How the machine is used and when it is serviced?
2) When the trouble was noticed and what work the machine was doing at that time?
3) What is the phenomenon of the trouble? Was the trouble getting worse, or did it come out suddenly for the first time?
4) Did the machine have any troubles previously? If so, which parts were repaired before.



STEP 3. Inspect the machine

Before starting troubleshooting, check the machine for the daily maintenance points as shown in the operator's manual.

And also check the electrical system including batteries, as the troubles in the electrical system such as low battery voltage, loose connections and blown out fuses will result in malfunction of the controllers causing total operational failures of the machine.



STEP 4. Inspect the trouble actually on the machine

In case that some trouble cannot be confirmed, obtain the details of the malfunction from the operator.
Also, check if there are any in complete connections of the wire harnesses are or not.



STEP 5. Perform troubleshooting

According to where the trouble parts are located, hydraulic & mechanical system part or electrical system part or mechatronics system part, perform troubleshooting the machine refer to the each system part's troubleshooting process diagram.



STEP 6. Trace a cause

Before reaching a conclusion, check the most suspectible causes again. Try to trace what the real cause of the trouble is.

Make a plan of the appropriate repairing procedure to avoid consequential malfunctions.



GROUP 2 HYDRAULIC AND MECHANICAL SYSTEM

1. INTRODUCTION

1) MACHINE IN GENERAL

(1) If even a minor fault is left intact and operation is continued, a fatal failure may be caused, entailing a large sum of expenses and long hours of restoration.
Therefore when even a small trouble occurs, do not rely on your intuition and experience, but look for the cause based on the troubleshooting principle and perform maintenance and adjustment to prevent major failure from occurring. Keep in mind that a fault results from a combination of different causes.

(2) The following lists up commonly occurring faults and possible causes with this machine. For the troubleshooting of the engine, refer to the coming troubleshooting and repair.

(3) When carrying out troubleshooting, do not hurry to disassemble the components.
It will become impossible to find the cause of the problem.

(4) Ask user or operator the following.
① Was there any strange thing about machine before failure occurred?
② Under what conditions did the failure occur?
③ Have any repairs been carried out before the failure?

(5) Check before troubleshooting.
① Check oil and fuel level.
② Check for any external leakage of oil from components.
③ Check for loose or damage of wiring and connections.

2) MACHINE STATUS MONITORING ON THE CLUSTER

(1) The machine status such as the engine rpm, oil temperature, voltage and pressure etc. can be checked by this menu.



Analog 1 Analog 2

(2) Specification

No.	Description	Specification
Note 1	Pilot pump pressure	40^{+2}_{0} bar
Note 2	Swing pilot pressure	0~40 bar
Note 3	Boom up pilot pressure	0~40 bar
Note 5	P1 pump negative pressure	0~38 bar
Note 6	P2 pump negative pressure	0~38 bar
Note 7	Pump 1 pressure	350 bar

2. DRIVE SYSTEM

1) UNUSUAL NOISE COMES OUT OF PUMP CONNECTION



Cause	Remedy
Coupling element is broken.	Disassemble and repair.
	Replace hub or retighten setscrew.

2) ENGINE STARTS BUT MACHINE DOES NOT OPERATE AT ALL



Cause	Remedy
	Replenish specified oil to the standard level.
Hydraulic pump is broken.	Disassemble and repair.
	See item 1 at page 6-5
ⓐ	
	Clean pilot piping interior or repair piping.
RCV and safety solenoid valve is faulty.	Disassemble and repair.
Pilot relief valve in gear pump is faulty.	Repair or replace.
Gear pump is broken.	Disassemble and repair.

3. HYDRAULIC SYSTEM

1) HYDRAULIC OIL IS CLOUDY



Cause	Remedy
Water is mixed.	Put hydraulic oil still, separate water and dispose it or replace hydraulic oil.
Air is intruded.	Check suction line and return line and eliminate the air intruding source.

2) HYDRAULIC OIL TEMPERATURE HAS RISEN ABNORMALLY



Cause	Remedy
Oil cooler clogged. Bypass check valve is defective. ⓐ	Replenish specified oil to the standard level. Clean oil cooler. Replace
	Adjust belt tension or replace belt.
	Readjust set pressure.
	Reduce load.

3) CAVITATION OCCURS WITH PUMP



Cause	Remedy
	Replenish specified oil to the standard level. Replace oil with one of proper viscosity. Clean suction strainer. Check for air intrusion in suction line and retighten or replace parts.

4) HYDRAULIC OIL IS CONTAMINATED



Cause	Remedy
	Replace hydraulic oil to be specified. Flush with hydraulic oil and replace return filter.

4. SWING SYSTEM

1) BOTH LH AND RH SWING ACTIONS ARE IMPOSSIBLE



Cause	Remedy
ⓐ	Replenish specified oil to the standard level.
Safety solenoid valve faulty or not operated.	Repair or replace.
Gear pump faulty.	Repair or replace.
Pump connection coupling is broken.	Disassemble and repair.
Hydraulic pump is out of order.	Disassemble and repair.
Swing control valve spool is stuck.	Disassemble and repair.
ⓑ	
ⓒ	
Hydraulic pump is broken.	Disassemble and repair.
Swing parking brake release valve is broken.	Disassemble and repair.
Swing reduction unit is broken.	Disassemble and repair.
Swing motor is broken.	Disassemble and repair.
Pilot relief valve in gear pump is faulty.	Disassemble and repair or replace.
Gear pump is out of order.	Disassemble and repair.
RCV is broken.	Clean pilot piping interior or repair piping. Disassemble and repair.

2) SWING SPEED IS LOW



3) SWING MOTION IS IMPOSSIBLE IN ONE DIRECTION



Cause	Remedy
Swing port relief valve is faulty.	Disassemble and repair.
Shuttle valve is faulty.	Disassemble and repair.
Swing control valve spool is stuck.	Disassemble and repair.
RCV is faulty.	Disassemble and repair.
	Clean pilot piping interior or repair piping.

4) MACHINE SWINGS BUT DOES NOT STOP



Cause	Remedy
Pilot relief valve is faulty.	Disassemble and repair or replace.
Gear pump is broken.	Disassemble and repair.
RCV is faulty.	Disassemble and repair.
Swing spool is stuck.	Disassemble and repair.
Return spring is faulty.	Disassemble and replace.

5) THE SWING UNIT DRIFTS WHEN THE MACHINE IS AT REST ON A SLOPE



Cause	Remedy
ⓐ	
Shuttle valve is faulty.	Disassemble and replace.
Brake spring is faulty.	Disassemble and replace.
Return spring of swing control valve is faulty.	Disassemble and replace.
Swing port relief valve is faulty.	Disassemble and repair or replace.
Swing motor is broken.	Disassemble and repair.
	Adjust swing relief valve pressure or replace swing relief valve.

5. TRAVEL SYSTEM

1) TRAVEL DOES NOT FUNCTION AT ALL ON ONE SIDE



2) SPEED ON ONE SIDE FALLS AND THE MACHINE CURVES



Cause	Remedy
Brake valve is defective.	Disassemble and repair or replace.
Relief valve built in travel motor is faulty.	Disassemble and repair.
ⓐ	
Control system is faulty .	Disassemble, inspect and repair.
Control valve spool is stuck.	Disassemble and repair.
Travel relief valve is faulty.	Disassemble and repair or replace.
Hydraulic pump is broken.	Disassemble and repair.
External pilot piping is clogged or oil is leaking from it.	Disassemble and clean.
Travel motor's parking brake is not released properly.	Disassemble and clean pilot piping.
Travel motor is faulty.	Disassemble and repair.

3) MACHINE DOES NOT STOP ON A SLOPE

Machine is pulled forward as sprocket rotates during digging operation.



Cause	Remedy
Friction plate is faulty.	Disassemble and repair.
Clogged	Disassemble and clean pilot piping.
Travel motor is defective.	Disassemble and repair.
Brake valve is faulty.	Disassemble and repair or replace.

4) LH AND RH TRAVEL MOTIONS ARE IMPOSSIBLE



Cause	Remedy
	Inspect according to the procedure "Travel does not function at all on one side." However, a case where both LH and RH travel motions are disabled is extremely seldom statistically.
Hydraulic pump is faulty.	Disassemble and repair.
Travel relief valve is faulty.	Disassemble and repair or replace.
Coupling at pump connection is broken.	Disassemble and repair.
	Replenish hydraulic oil.

5) TRAVEL ACTION IS POWERLESS (travel only)



Cause	Remedy
ⓐ	
Travel motor is faulty.	Disassemble and repair.
Travel brake valve is defective.	Disassemble and repair or replace.
Travel relief valve is faulty.	Disassemble and repair or replace.
Hydraulic circuit that releases travel parking brake is clogged with dirt.	Disassemble and clean.
Parking brake piston in travel motor is stuck.	Disassemble and repair.
Travel reduction unit is defective.	Disassemble and repair.

6) MACHINE RUNS RECKLESSLY ON A SLOPE

Cause	Remedy
	Disassemble and repair or replace.

7) MACHINE MAKES A CURVED TRAVEL OR DOES NOT TRAVEL AT ALL WHEN TRAVEL AND ATTACHMENT OPERATIONS ARE EXECUTED AT THE SAME TIME



Cause	Remedy
	Normal.
Straight spool is faulty.	Repair or replace.
	Remove dirt on signal orifice.
Pilot relief valve is defective.	Disassemble and repair or replace.
Gear pump is broken.	Disassemble and repair.

6. ATTACHMENT SYSTEM

1) BOOM OR ARM ACTION IS IMPOSSIBLE AT ALL



2) BOOM, ARM OR BUCKET SPEED IS LOW



Cause	Remedy
	Normal.
Flow summation check valve is stuck.	Disassemble and repair.
Hydraulic pump is faulty.	Disassemble and repair.
Port relief valve is faulty.	Disassemble and repair or replace.
Cylinder is faulty.	Disassemble and repair.
MCV spool is stuck.	Disassemble and repair.
	Clean pilot piping interior or repair piping.
RCV is defective.	Disassemble and repair.
Pilot relief valve is faulty.	Disassemble and repair or replace.
Gear pump is broken.	Disassemble and repair.
	Adjust engine revolution.
	Clean orifice in control valve.
	Clean pilot piping interior or repair piping.
RCV is faulty.	Disassemble and repair.

3) BOOM, ARM OR BUCKET CYLINDER EXTENDS OR CONTRACTS ITSELF AND ATTACHMENT FALLS



Cause	Remedy
Port relief valve is faulty.	Disassemble and repair or replace.
Control valve's return spring is faulty.	Disassemble and replace.
	Locate the cause of hydraulic oil temperature rise and lower it to proper level. Replace with genuine hydraulic oil or equivalent.
Pressure tightness between control valve casing and spool is poor.	Disassemble and repair.
Contact surface between poppet and seat is poor.	Disassemble and repair.
Cylinder is faulty.	Disassemble and repair.

4) BOOM, ARM OR BUCKET POWER IS WEAK



Cause	Remedy
Cylinder is faulty.	Check according to the procedure in Item "Speed is low".
Port relief valve is faulty.	Disassemble and repair.
Main relief valve is defective.	Adjust pressure, repair or replace.

5) ONLY BUCKET OPERATION IS TOTALLY IMPOSSIBLE



Cause	Remedy
Port relief valve is defective.	Disassemble and repair or replace.
Cylinder interior is broken.	Disassemble and repair.
MCV spool is stuck.	Disassemble and repair.
RCV is faulty.	Disassemble and repair.
Main relief valve is faulty.	Adjust pressure, repair or replace.
Hydraulic pump is broken.	Disassemble and repair.

6) BOOM MAKES A SQUEAKING NOISE WHEN BOOM IS OPERATED



YES

NO

Cause	Remedy
	Frictional noise occurs between the sliding faces of boom cylinder's oil seal and boom proper. ※ Frictional noise will disappear if they are kept used.
Boom foot pin has run out of grease.	Supply grease to it. ※ If seizure is in an initial stage, supply sufficient grease. If seizure is in a grown state, correct it by paper lapping or with an oil stone.

※ HOW TO CHECK INTERNAL BOOM CYLINDER LEAKAGE

1. Lower the bucket teeth to the ground with bucket cylinder fully retracted and arm cylinder rod retracted almost in full.



2. Disconnect hose (A) from rod side of boom cylinder and drain oil from cylinders and hose. (put cups on piping and hose ends)



3. Raise bucket OFF the ground by retracting the arm cylinder rod.

   If oil leaks from piping side and boom cylinder rod is retracted there is an internal leak in the cylinder.
   If no oil leaks from piping side and boom cylinder rod is retracted, there is an internal leak in the control valve.



1. WHEN STARTING SWITCH IS TURNED ON, MONITOR PANEL DISPLAY DOES NOT APPEAR

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse No.7 and 8 burnt out.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Cause	Remedy
Defective cluster	Replace
Disconnection in wiring harness or poor contact between CN-5-CN-56	Repair or replace (after clean)
Disconnection in wiring harness or poor contact between CN-5 (6) and (5)-GND or fuse No.7, 13	Repair or replace (after clean)

Check voltage

YES	20~32V
NO	0V



2. ⚠ COMMUNICATION ERROR FLASHES ON THE CLUSTER (HCESPN 840, FMI 2)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check voltage

YES	2V
NO	0V



3. BATTERY CHARGING WARNING LAMP LIGHTS UP (Starting switch : ON)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check voltage

YES	20~32V
NO	0V



4. WHEN COOLANT OVERHEAT WARNING LAMP LIGHTS UP (engine is started)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check Table

Temperature (˚C)	0	25	50	80	95
Resistance (kΩ)	30~37	9.3~10.7	3.2~3.8	1.0~1.3	0.7~0.8



5. WHEN AIR CLEANER WARNING LAMP LIGHTS UP (engine is started)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check resistance

YES	MAX 1Ω
NO	MIN 1MΩ



6. WHEN ENGINE OIL PRESSURE WARNING LAMP LIGHTS UP (engine is started)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.





7. WHEN HYDRAULIC OIL TEMPERATURE WARNING LAMP LIGHTS UP (engine is started)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Cause	Remedy
High temperature	Check hydraulic oil temperature (105˚C±2˚C),
Defective temp sensor	Replace
Short circuit between temp sensor and MCU	Repair or replace
Defective MCU	Replace



Check Table

Temperature (˚C)	~ -30	~ -10	~ 0	~ 40	~ 70	~ 80	~ 90	~ 100	105~
Resistance (kΩ)	22.22 ~31.78	8.16 ~10.74	5.18 ~ 6.6	1.06 ~1.28	0.39 ~0.476	0.322 ~0.298	0.243 ~0.219	0.185 ~0.167	0.164 0.151



8. WHEN FUEL GAUGE DOES NOT OPERATE

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check Table

Range	Resistance (Ω)	Range	Resistance (Ω)
Full	50	5/12	400
11/12	100	4/12	450
10/12	150	3/12	500
9/12	200	2/12	550
8/12	250	1/12	600
7/12	300	Empty warning	700
6/12	350	-	-



9. WHEN SAFETY SOLENOID DOES NOT OPERATE

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse No.23 burnt out.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.





10. WHEN TRAVEL SPEED 1, 2 DOES NOT OPERATE (HCESPN 167, FMI 4 or 6)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse No. 25 burnt out.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.





11. WHEN ENGINE DOES NOT START ([-+] lights up condition)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and short of fuse No. 1, 4, 8, 9, 20.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.





12. WHEN STARTING SWITCH ON DOES NOT OPERATE

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted, master switch ON and check open circuit of fusible link (CN-60).
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Cause	Remedy
Disconnection in wiring harness or poor contact between DO-3 (2)-CR-1 or defective battery relay	Repair or replace (after clean)
Disconnection in wiring harness or poor contact between CS-2 (2)-CN-5(60)- DO-3 (2)	Repair or replace (after clean)
Defective start key switch	Replace
Disconnection in wiring harness or poor contact between CS-2 (1)-CN-5 (36)	Replace
Disconnection in wiring harness or poor contact between CS-74B (1)-CN-5 (36)	Charge or replace (after clean)
ⓐ	
Battery discharged	Replace
Defective master switch	Replace
Disconnection in wiring harness or poor contact between CS-74 (2) -CR-1	Charge or replace (after clean)



13. WHEN STARTING SWITCH IS TURNED ON, WIPER MOTOR DOES NOT OPERATE

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse No. 6, 11 and 17 burnt out.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Cause	Remedy
Defective wiper cut switch	Replace
Short circuit in wiring harness or poor contact between CN-141 (11)- CS-53	Repair or replace (after clean)
Defective switch panel	Replace
1)Recheck fuse No.11	Replace
2)Disconnection in wiring harness or poor contact between CN-116(10)-Fuse	Repair or replace (after clean)
Defective switch panel	Replace
1) Recheck fuse No.6	Replace
2) Disconnection in wiring harness or poor contact between CN-141(7)-Fuse, CN-21(6)-Fuse	Repair or replace (after clean)
1) Recheck fuse No.17	Replace
2) Disconnection CN-141(6)-Fuse	Repair or replace (after clean)
Disconnection in wiring harness or poor contact	Repair or replace (after clean)
Defective wiper motor	Replace
Defective wiper motor controller	Replace



14. WHEN STARTING SWITCH IS TURNED ON, HEAD LAMP DOES NOT LIGHTS UP

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse No.18 burnt out.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Cause	Remedy
Defective bulb	Replace
Disconnection in wiring harness or poor contact between CR-13 (87)-CL-4 (1) or CR-13(87)-CL-3(1)	Repair or replace (after clean)
Defective switch panel	Replace
Disconnection in wiring harness or poor contact between CN-116 (1)-CR-13 (87)	Repair or replace (after clean)
Disconnection in wiring harness or poor contact between CR-13 (30) and chassis or CR-13 (86) - chassis	Repair or replace (after clean)
Recheck fuse No. 18	Replace



15. WHEN STARTING SWITCH IS TURNED ON, WORK LAMP DOES NOT LIGHTS UP

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and fuse No.15 burnt out.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.





1. ALL ACTUATORS SPEED ARE SLOW

※ Boom, Arm, Bucket, Swing and travel speed are slow, but engine speed is good.
※ Spec : P-mode 1850 ± 50 rpm S -mode 1750 ± 50 rpm E-mode 1650 ± 50 rpm
※ Before carrying out below procedure, check all the related connectors are properly inserted and fault code on the cluster.

1) INSPECTION PROCEDURE



Wiring diagram



2) TEST PROCEDURE

(1) Test 1 : Check resistance at connector CN-75.

① Starting key OFF.

② Disconnect connector CN-75 from EPPR valve at main hydraulic pump.

③ Check resistance between 2 lines as figure.



(2) Test 2 : Check electric current at EPPR valve.

① Disconnect connector CN-75 from EPPR valve.

② Insert the adapter to CN-75 and install multimeter as figure.

③ Start engine.

④ Set S-mode and cancel auto decel mode.

⑤ Position the accel dial at 10.

⑥ If rpm display approx 1750 ±50 rpm check electric current at bucket circuit relief position.



(3) Test 3 : Check pressure at EPPR valve.

① Remove plug and connect pressure gauge as figure.

· Gauge capacity : 0 to 50 kgf/cm² (0 to 710 psi)

② Start engine.

③ Set S-mode and cancel auto decel mode.

④ Position the accel dial at 10.

⑤ If rpm display approx 1750±50 rpm check pressure at relief position of bucket circuit by operating bucket control lever.

⑥ If pressure is not correct, adjust it.

⑦ After adjust, test the machine.



2. ENGINE STALL

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram



2) TEST PROCEDURE

(1) Test 4 : Check electric current at EPPR valve.

① Disconnect connector CN-75 from EPPR valve.
② Insert the adapter to CN-75 and install multimeter as figure.
③ Start engine.
④ Set S-mode and cancel auto decel mode.
⑤ Position the accel dial at 10.
⑥ If rpm display approx 1750 ±50 rpm check electric current at bucket circuit relief position.



(2) Test 5 : Check pressure at EPPR valve.

① Remove plug and connect pressure gauge as figure.
・ Gauge capacity : 0 to 50 kgf/cm² (0 to 710 psi)
② Start engine.
③ Set S-mode and cancel auto decel
④ mode.
⑤ Position the accel dial at 10.
If rpm display approx 1750±50 rpm check pressure at relief position of bucket circuit
⑥ by operating bucket control lever.
⑦ If pressure is not correct, adjust it.
After adjust, test the machine.



3. MALFUNCTION OF CLUSTER OR MODE SELECTION SYSTEM

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram



4. MALFUNCTION OF ACCEL DIAL

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE





2) TEST PROCEDURE

(1) Test 6 : Check voltage at CN-52(23) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (23) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



5. AUTO DECEL SYSTEM DOES NOT WORK

· Fault code : HCESPN 105, FMI 0~4 (work pressure sensor)
HCESPN 108, FMI 0~4 (travel oil pressure sensor)

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Cause	Remedy
Defective MCU	Replace
Defective travel pressure switch	Replace
Short circuit or poor connection between CN-51(3)-CD-6(A) and / or CN-51(13)-CD-6(C) (fault code 108 displayed)	Replace or repair
Defective work pressure sensor	Replace
Short circuit or poor connection between CN-51(3)-CD-7(A) and / or CN-51(13)-CD-7(C) (fault code 105 displayed)	Replace or repair

Wiring diagram



2) TEST PROCEDURE

(1) Test 7 : Check voltage at CN-52(38) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (38) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

(2) Test 8 : Check voltage at CN-52(37)and ground.

① Prepare 1 piece of thin sharp pin, steel or copper

② Insert prepared pin to rear side of connectors : One pin to (37) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



6. MALFUNCTION OF PUMP 1 PRESSURE SENSOR

· Fault code : HCESPN 120, FMI 0~4

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Cause	Remedy
Defective MCU	Replace
Detective P1 pressure sensor	Replace or repair
Short circuit or poor connection between CN-52 (29)-CD-42 (B)	Replace or repair
Short circuit or poor connection between CD-42 (A)-CN-51(3) or CD-42(C)- CN-51 (13)	Replace or repair

Wiring diagram



2) TEST PROCEDURE

(1) Test 9 : Check voltage at CN-52(29) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (29) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



7. MALFUNCTION OF PUMP 2 PRESSURE SENSOR

· Fault code : HCESPN 121, FMI 0~4

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Cause	Remedy
Defective MCU	Replace
Detective P2 pressure sensor	Replace or repair
Short circuit or poor connection between CN-52 (30)-CD-43 (B)	Replace or repair
Short circuit or poor connection between CD-43 (A)-CN-51(3) or CD-43(C)- CN-51 (13)	Replace or repair

Wiring diagram



2) TEST PROCEDURE

(1) Test 10 : Check voltage at CN-52(30) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (30) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



8. MALFUNCTION OF PUMP 3 PRESSURE SENSOR(EPPR PRESSURE)

· Fault code : HCESPN 125, FMI 0~4

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Cause	Remedy
Defective MCU	Replace
Short circuit or poor connection between CN-52-(32)-CN-1(5)	Replace or repair
Detective P3 pressure sensor	Replace or repair
Short circuit or poor connection between CN-1(5)-CD-44(B)	Replace or repair
Short circuit or poor connection between CD-44(A)-CN-1(2) or CD-44(C)-CN-1(4)	Replace or repair
Short circuit or poor connection between CN-1(2)-CN-51(3) or CN-1 (4) - CN-51(13)	Replace or repair

Wiring diagram



2) TEST PROCEDURE

(1) Test 11 : Check voltage at CN-52(32) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (32) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



9. MALFUNCTION OF SWING PRESSURE SENSOR

· Fault code : HCESPN 135, FMI 0~4

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram



2) TEST PROCEDURE

(1) Test 12 : Check voltage at CN-52(36) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (36) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



10. MALFUNCTION OF BOOM UP PRESSURE SENSOR

· Fault code : HCESPN 127, FMI 0~4

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram



2) TEST PROCEDURE

(1) Test 13: Check voltage at CN-52(35) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (35) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



11. MALFUNCTION OF ARM/BUCKET PRESSURE SENSOR

· Fault code : HCESPN 133, FMI 0~4

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram



2) TEST PROCEDURE

(1) Test 14: Check voltage at CN-52(34) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (34) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



12. MALFUNCTION OF NEGATIVE 1 PRESSURE SENSOR

· Fault code : HCESPN 123, FMI 0~4

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram



2) TEST PROCEDURE

(1) Test 15 : Check voltage at CN-52(39) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (39) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



13. MALFUNCTION OF NEGATIVE 2 PRESSURE SENSOR

· Fault code : HCESPN 124, FMI 0~4

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Cause	Remedy
Defective MCU	Replace
Detective boom up pressure sensor	Replace or repair
Short circuit or poor connection between CN-52 (40)-CD-71 (B)	Replace or repair
Short circuit or poor connection between CD-71 (A)-CN-51(3) or CD-71(C)- CN-51 (13)	Replace or repair

Wiring diagram



2) TEST PROCEDURE

(1) Test 16 : Check voltage at CN-52(40) and ground.

① Prepare 1 piece of thin sharp pin, steel or copper.

② Insert prepared pin to rear side of connectors : One pin to (40) of CN-52.

③ Starting key ON.

④ Check voltage as figure.

SPEC : Actuator operating : 1~5 V



14. MALFUNCTION OF POWER MAX

· Fault code : HCESPN 166, FMI 4 or 6

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram



2) TEST PROCEDURE

(1) Test 17: Check voltage between connector CN-88(2) - GND.

① Disconnect connector CN-88 from power max solenoid valve.

② Start key ON.

③ Check voltage as figure.



(2) Test 18: Check resistance of the solenoid valve between CN-88(1)-(2).

① Starting key OFF.

② Disconnect connector CN-88 from power max solenoid valve.

③ Check resistance as figure.



15. MALFUNCTION OF BOOM PRIORITY EPPR VALVE

· Fault code : HCESPN 141, FMI 5 or 6

※ Before carrying out below procedure, check all the related connectors are properly inserted.

1) INSPECTION PROCEDURE



Wiring diagram