

## BEFORE SERVICING THIS MACHINE

It is the responsibility of the owner and all service and maintenance personnel to avoid accidents and serious injury by keeping this machine properly maintained.

It also is the responsibility of the owner and all service and maintenance personnel to avoid accidents and serious injury while servicing the machine.

No one should service or attempt to repair this machine without proper training and supervision.

All service and maintenance personnel should be thoroughly familiar with the procedures and precautions contained in this manual.

All personnel also must be aware of any federal, state, provincial or local laws or regulations covering the use and service of construction equipment.

The procedures in this manual do not supersede any requirements imposed by federal, state, provincial or local laws.

Hyundai can not anticipate every possible circumstance or environment in which this machine may be used and serviced.

All personnel must remain alert to potential hazards.

Work within your level of training and skill.

Ask your supervisor if you are uncertain about a particular task. Do not try to do too much too fast.

Use your common sense.

### ※ How to set the language of cluster

User can select preferable language and all displays are changed the selected language.

#### Normal type



#### Premium type



220S0SG510

220S0SG10

※ Please refer to the page 3-29 for the cluster.

## TABLE TO ENTER SERIAL NO. AND DISTRIBUTOR

|                         |  |
|-------------------------|--|
| Machine Serial No.      |  |
| Engine Serial No.       |  |
| Manufacturing year      |  |
| Manufacturer<br>Address | Hyundai Construction Equipment India Ltd.<br>A-2, Chakan Industrial Premises,<br>Khalumbre, Khed., Dist.Pune 410 510 |