

CONTENTS

EC declaration of conformity	0-1	5. Operation of the working device	4-9
Foreword	0-2	6. Traveling of the machine	4-10
Before servicing this machine	0-3	7. Efficient working method	4-15
Table to enter S/No and distribution	0-4	8. Adjustment of the work equipment	4-22
EC regulation approved	0-5	9. Operation in the special work sites	4-23
Safety labels	0-6	10. Storage	4-25
Machine data plate	0-16	11. SCR system cleaning	4-27
Guide (direction, S/No, symbol)	0-17	12. Open the engine hood	4-28
1. SAFETY HINTS		5. TRANSPORTATION	
1. Before operating the machine	1-1	1. Road traveling	5-1
2. During operating the machine	1-15	2. Preparation for transportation	5-2
3. During maintenance	1-24	3. Loading the machine	5-3
4. Parking	1-28	4. Fixing the machine	5-4
 		5. Loading and unloading by crane	5-6
2. SPECIFICATIONS		6. Towing the machine	5-7
1. Major components	2-1	 	
2. Specifications	2-2	6. MAINTENANCE	
3. Weight	2-6	1. Instructions	6-1
4. Specification for major components	2-7	2. Tightening torque	6-5
 		3. Spec of fuel, coolant and lubricants	6-8
3. CONTROL DEVICES		4. Maintenance check list	6-10
1. Cab devices	3-1	5. Maintenance chart	6-13
2. Cluster	3-2	6. Service instruction	6-15
3. Monitors	3-13	7. Electrical system	6-46
4. Switches	3-44	8. Air conditioner and heater	6-49
5. Control device	3-49	 	
6. Air conditioner and heater	3-52	7. TROUBLESHOOTING GUIDE	
7. Others	3-55	1. Engine	7-1
 		2. Electrical system	7-2
4. OPERATION		3. Power train system	7-3
1. Suggestion for new machine	4-1	4. Hydraulic system	7-4
2. Check before starting the engine	4-2	 	
3. Starting and stop the engine	4-3	INDEX	
4. Warming-up operation	4-8	8-1	