

# CONTENTS

EC declaration of conformity .....	0-1	<b>5. TRANSPORTATION</b>	
Before servicing this machine .....	0-2	1. Road traveling .....	5-1
Table to enter S/No and distribution .....	0-3	2. Preparation for transportation .....	5-2
Safety labels .....	0-4	3. Loading the machine .....	5-3
Machine data plate .....	0-13	4. Fixing the machine .....	5-4
Guide (direction, S/No, symbol) .....	0-14	5. Loading and unloading by crane .....	5-6
		6. Towing the machine .....	5-7
<b>1. SAFETY HINTS</b>			
1. Safety rules .....	1-1		
<b>2. SPECIFICATIONS</b>			
1. Major components .....	2-1	1. Instructions .....	6-1
2. Specifications .....	2-2	2. Tightening torque .....	6-5
3. Weight .....	2-6	3. Spec of fuel, coolant and lubricants .....	6-8
4. Specification for major components .....	2-7	4. Maintenance check list .....	6-10
<b>3. CONTROL DEVICES</b>			
1. Cab devices .....	3-1	5. Maintenance chart .....	6-13
2. Cluster .....	3-2	6. Service instruction .....	6-15
3. Monitors .....	3-10	7. Electrical system .....	6-44
4. Switches .....	3-44	8. Air conditioner and heater .....	6-47
5. Control device .....	3-49		
6. Air conditioner and heater .....	3-53		
7. Others .....	3-56		
<b>4. OPERATION</b>			
1. Suggestion for new machine .....	4-1	<b>7. TROUBLESHOOTING GUIDE</b>	
2. Check before starting the engine .....	4-2	1. Engine .....	7-1
3. Starting and stop the engine .....	4-3	2. Electrical system .....	7-2
4. Warming-up operation .....	4-8	3. Power train system .....	7-3
5. Operation of the working device .....	4-9	4. Hydraulic system .....	7-4
6. Traveling of the machine .....	4-10		
7. Efficient working method .....	4-15		
8. Adjustment of the work equipment .....	4-22		
9. Operation in the special work sites .....	4-23		
10. Storage .....	4-25		
11. Open the engine hood .....	4-27		
12. Attachment manually lowering .....	4-30		
<b>8. OTHERS</b>			
1. Central grease lubrication system .....	8-1		
2. Quick coupler .....	8-9		
<b>INDEX</b> .....			
			9-1

## FOREWORD

This manual contains several instructions and safety recommendations regarding driving, handling, lubrication, maintenance, inspection, and adjustment of the machine.

The manual is to promote safety maintenance and enhance machine performance.

Keep this manual handy and have all personnel read it periodically.

If you sell the machine, be sure to give this manual to the new owners.

This machine complies with the EC directive "2006/42/EC".

**1. Read and understand** this manual before operating the machine.

This operator's manual may contain attachments and optional equipment that are not available in your area. Please consult your local Hyundai distributor for those items you require.

Improper operation and maintenance of this machine can be hazardous and could result in serious injury or death.

Some actions involved in the operation and maintenance of the machine can cause a serious accident if they are not done in a manner described in this manual.

The procedures and precautions are given in this manual apply only to the intended uses of the machine.

If you use your machine for any unintended uses that are not specifically prohibited, you must be sure that it is safe for you and others. In no event should you or others engage in prohibited uses of actions as described in this manual.

Some illustrations in this manual show details or attachments that can be different from your machine. Covers and guards might have been removed for illustrative purposes.

**2. Inspect** the jobsite and **follow** the safety recommendations in the **safety hints** section before operating the machine.

**3. Use genuine Hyundai spare parts** for the replacement of parts.

We expressly point out that Hyundai will not accept any responsibility for defects resulting from non-genuine parts or non-workmanlike repair.

In such cases, Hyundai cannot assume liability for any damage.

Continuing improvements in the design of this machine can lead to changes in detail which may not be reflected in this manual. Consult Hyundai or your Hyundai distributor for the latest available information for your machine or questions regarding information in this manual.