

3. OTHERS

Trouble	Service	Remark
Track slip out of place. Excessive wear of the sprocket.	• Adjust tension of track.	
Bucket either rises slowly or not at all.	• Add oil to specified level.	
Slow speed of travel, swing, boom, arm and bucket.	• Add oil to specified level.	
Unusual noise emitted from pump.	• Clean the hydraulic tank strainer.	
Excessive oil temperature rise of hydraulic oil.	• Clean the oil cooler. • Adjust fan belt tension. • Add oil to specified level.	