3. OTHERS

Trouble	Service	Remark
Track slip out of place. Excessive wear of the sprocket.	i /Adjust tension of track.	
Bucket either rises slowly or not at all.	; /Add oil to specified level.	
Slow speed of travel, swing, boom, arm and bucket.	; /Add oil to specified level.	
Unusual noise emitted from pump.	i Clean the hydraulic tank strainer.	
Excessive oil temperature rise of hydraulic oil.	; Clean the oil cooler.	
	i /Adjust fan belt tension.	
	; /Add oil to specified level.	