

3. OTHERS

| Trouble | Service | Remark |
|---|--|--------|
| Track slip out of place. Excessive wear of the sprocket. | · Adjust tension of track. | |
| Bucket either rises slowly or not at all. | · Add oil to specified level. | |
| Slow speed of travel, swing, boom, arm and bucket. | · Add oil to specified level. | |
| Unusual noise emitted from pump. | · Clean the hydraulic tank strainer. | |
| Excessive oil temperature rise of hydraulic oil. | · Clean the oil cooler. · Adjust fan belt tension. · Add oil to specified level. | |