

MACHINE DATA PLATE

Diagram of a general machine data plate. It features the Hyundai logo and company address at the top. Below are three numbered fields: 1 for Equipment, 2 for Model, and 3 for Serial Number. To the right, two more numbered fields are present: 4 for Operating Weight and 5 for Engine Power (PS/KW/rpm). A warning at the bottom states 'DO NOT DEFACE OR REMOVE THIS PLATE'.

Diagram of a machine data plate for EU compliance. It includes the CE mark and Hyundai logo. The layout is similar to the general plate, with numbered fields 1-3 on the left and 4-6 on the right. Field 6 is for the Manufacturing Year. A warning at the bottom states 'DO NOT DEFACE OR REMOVE THIS PLATE'.

FOR EU ONLY

Diagram of a machine data plate for FOPS/FOG certification. It includes the Hyundai logo and company address. Numbered fields 2 and 3 point to the Machine name and FOPS/FOG S/NO. respectively. A section for Standards lists SAE and ISO requirements. A warning at the bottom states 'DO NOT DEFACE OR REMOVE THIS PLATE'.

FOR FOPS/FOG

Diagram of a machine data plate for ROPS certification. It includes the Hyundai logo and company address. Numbered fields 2 and 3 point to the Machine name and ROPS/TOPS/FOG S/NO. respectively. Field 7 points to the Max. Certified Weight. A section for Standards lists ISO 12117-2:2008. A warning at the bottom states 'ANY MODIFICATION OR ALTERATION ON THIS STRUCTURES WITHOUT AUTHORIZATION AVOID THE CERTIFICATION.'

ROPS

2609A0FW01

- | | | | | | |
|---|--------------------------|---|--------------|---|--------------------|
| 1 | Equipment | 2 | Model name | 3 | Serial number |
| 4 | Operating weight | 5 | Engine power | 6 | Manufacturing year |
| 7 | Maximum certified weight | | | | |

※ The machine serial number assigned to this particular machine and should be used when requesting information or ordering service parts for this machine from your authorized HYUNDAI dealer. The machine serial number is also stamped on the frame.