

MACHINE DATA PLATE

Diagram of a general machine data plate. It features the Hyundai logo and company address at the top. Below are three numbered boxes: 1 for Equipment, 2 for Model, and 3 for Serial Number. To the right, two more numbered boxes are present: 4 for Operating Weight and 5 for Engine Power (PS/KW/rpm). A warning at the bottom states 'DO NOT DEFACE OR REMOVE THIS PLATE'.

Diagram of a machine data plate for EU use. It includes the CE mark and Hyundai logo. The layout is similar to the general plate but includes a box for 'MFG. YEAR' (6) instead of engine power. The warning at the bottom is 'DO NOT DEFACE OR REMOVE THIS PLATE'.

FOR EU ONLY

Diagram of a machine data plate for FOPS/FOG. It includes the Hyundai logo and company address. The plate has three numbered boxes: 2 for FOPS/FOG S/NO. and 3 for Standards. The standards section lists 'MEETS SAE : J1040 MAY 94 / J231 JAN 81' and 'MEETS ISO : 3471 1994 (E) / 3449 1992 (E)'. A warning at the bottom states 'DO NOT DEFACE OR REMOVE THIS PLATE'.

FOR FOPS/FOG

Diagram of a machine data plate for ROPS. It includes the Hyundai logo and company address. The plate has two numbered boxes: 2 for ROPS/TOPS/FOG S/NO. and 7 for Max. Certified Weight. The standards section lists 'MEETS ISO 12117-2:2008'. A warning at the bottom states 'ANY MODIFICATION OR ALTERATION ON THIS STRUCTURES WITHOUT AUTHORIZATION AVOID THE CERTIFICATION.'

ROPS

2609A0FW01

- | | | |
|----------------------------|----------------|----------------------|
| 1 Equipment | 2 Model name | 3 Serial number |
| 4 Operating weight | 5 Engine power | 6 Manufacturing year |
| 7 Maximum certified weight | | |

※ The machine serial number assigned to this particular machine and should be used when requesting information or ordering service parts for this machine from your authorized HYUNDAI dealer. The machine serial number is also stamped on the frame.