

# CONTENTS

Foreword .....	0-1	4. Mode selection system .....	4-6
Before servicing this machine .....	0-2	5. Operation of working device .....	4-11
EC regulation approved .....	0-3	6. Traveling of the machine .....	4-12
Table to enter S/No and distribution .....	0-4	7. Efficient working method .....	4-15
Safety labels .....	0-5	8. Operation in the special work sites .....	4-19
Machine data plate .....	0-16	9. Storage .....	4-21
Guide (Direction, S/No, Symbol) .....	0-17		
<b>SAFETY HINTS</b>			
1. Before operating the machine .....	1-1	1. Preparation for transportation .....	5-1
2. During operating the machine .....	1-16	2. Dimension and weight .....	5-2
3. During maintenance .....	1-23	3. Disassembling for transportation .....	5-5
4. Parking .....	1-26	4. Loading the machine .....	5-7
5. Bucket selection guide .....	2-5	5. Fixing the machine .....	5-9
6. Undercarriage .....	2-6	6. Adjustable track gauge .....	5-10
<b>SPECIFICATIONS</b>			
1. Major components .....	2-1		
2. Specifications .....	2-2		
3. Working range .....	2-3		
4. Weight .....	2-4		
5. Bucket selection guide .....	2-5		
6. Undercarriage .....	2-6		
7. Specification for major components .....	2-8		
8. Recommended oils .....	2-11		
<b>CONTROL DEVICES</b>			
1. Cab devices .....	3-1		
2. Cluster .....	3-2		
3. Switches .....	3-23		
4. Levers and pedals .....	3-28		
5. Auto conditioner and heater .....	3-31		
6. Others .....	3-35		
<b>OPERATION</b>			
1. Suggestions for new machines .....	4-1		
2. Check before starting the engine .....	4-2		
3. Starting and stopping the engine .....	4-3		
4. Mode selection system .....	4-6		
5. Operation of working device .....	4-11		
6. Traveling of the machine .....	4-12		
7. Efficient working method .....	4-15		
8. Operation in the special work sites .....	4-19		
9. Storage .....	4-21		
<b>TRANSPORTATION</b>			
1. Preparation for transportation .....	5-1		
2. Dimension and weight .....	5-2		
3. Disassembling for transportation .....	5-5		
4. Loading the machine .....	5-7		
5. Fixing the machine .....	5-9		
6. Adjustable track gauge .....	5-10		
<b>MAINTENANCE</b>			
1. Instruction .....	6-1		
2. Tightening torque .....	6-6		
3. Fuel, coolant and lubricants .....	6-9		
4. Maintenance check list .....	6-11		
5. Maintenance chart .....	6-16		
6. Service instruction .....	6-18		
7. Electrical system .....	6-40		
8. Air conditioner and heater .....	6-43		
<b>TROUBLESHOOTING GUIDE</b>			
1. Engine .....	7-1		
2. Electrical system .....	7-2		
3. Others .....	7-3		
<b>Others</b>			
1. Central grease lubrication system .....	8-1		
<b>INDEX</b> .....			
	9-1		