

## SECTION 1 GENERAL

|                                    |      |
|------------------------------------|------|
| Group 1 Safety hints .....         | 1-1  |
| Group 2 Specifications .....       | 1-5  |
| Group 3 Periodic replacement ..... | 1-15 |

## SECTION 2 REMOVAL AND INSTALLATION OF UNIT

|                                                |      |
|------------------------------------------------|------|
| Group 1 Major componets .....                  | 2-1  |
| Group 2 Removal and installation of unit ..... | 2-2  |
| Group 3 Maintenance for hose .....             | 2-17 |

## SECTION 3 POWER TRAIN SYSTEM

|                                              |      |
|----------------------------------------------|------|
| Group 1 Structure and operation .....        | 3-1  |
| Group 2 Inspection and troubleshooting ..... | 3-15 |
| Group 3 Disassembly and assembly .....       | 3-66 |

## SECTION 4 BRAKE SYSTEM

|                                                      |     |
|------------------------------------------------------|-----|
| Group 1 Structure and function .....                 | 4-1 |
| Group 2 Operational checks and troubleshooting ..... | 4-5 |
| Group 3 Tests and adjustments .....                  | 4-7 |

## SECTION 5 STEERING SYSTEM

|                                                      |      |
|------------------------------------------------------|------|
| Group 1 Structure and function .....                 | 5-1  |
| Group 2 Operational checks and troubleshooting ..... | 5-13 |
| Group 3 Disassembly and assembly .....               | 5-17 |

## SECTION 6 HYDRAULIC SYSTEM

|                                                      |      |
|------------------------------------------------------|------|
| Group 1 Structure and function .....                 | 6-1  |
| Group 2 Operational checks and troubleshooting ..... | 6-35 |
| Group 3 Disassembly and assembly .....               | 6-40 |

## SECTION 7 ELECTRICAL SYSTEM

|                                       |      |
|---------------------------------------|------|
| Group 1 Component location .....      | 7-1  |
| Group 2 Electrical circuit .....      | 7-4  |
| Group 3 Component specification ..... | 7-19 |
| Group 4 Connector destination .....   | 7-20 |
| Group 5 Troubleshooting .....         | 7-24 |

## SECTION 8 MAST

|                                                      |      |
|------------------------------------------------------|------|
| Group 1 Structure .....                              | 8-1  |
| Group 2 Operational checks and troubleshooting ..... | 8-5  |
| Group 3 Adjustment .....                             | 8-8  |
| Group 4 Removal and installation .....               | 8-11 |