

CONTENTS

FOREWORD

A message to hyundai lift truck operators	0-1
Introduction	0-2
How to use this manual	0-3
Safety labels	0-5
Guide (Direction, Serial number, Symbols)	0-9

1. GENERAL SAFETY RULES

1. Daily inspection	1-1
2. Do's and dont's	1-2
3. No riders	1-4
4. Pedestrians	1-5
5. Operator protection	1-6
6. Fork safety	1-7
7. Pinch points	1-8
8. Travel	1-9
9. Surface and capacity	1-10
10. Parking	1-11
11. Lifting, jacking and blocking	1-12
12. Loading and unloading by crane	1-17

2. OPERATING HAZARDS

1. Loose loads	2-1
2. Long and wide loads	2-2
3. Rear swing	2-2
4. Low overhead clearance	2-3
5. Fast turns and high loads	2-4
6. Right-angle stacking	2-4
7. Chain slack	2-5
8. Pallets and skids	2-5
9. Caution for electrical lines	2-6
10. Solid tire	2-7

3. KNOW YOUR TRUCK

1. General locations	3-1
2. Data plates	3-3
3. Instruments and controls	3-4
4. Instruments panel	3-6

5. Operating switches and levers	3-13
6. Battery connector	3-19
7. Support and safety parts	3-19

4. DAILY SAFETY INSPECTION

1. Inspecting your truck	4-1
2. Visual checks	4-2
3. Functional checks	4-3
4. Concluding the inspection	4-3

5. OPERATING PROCEDURES

1. Before operating the truck	5-1
2. Starting from a safe condition	5-1
3. Starting the truck	5-2
4. Controlling speed	5-4
5. Braking	5-4
6. Plugging	5-4
7. Operating safely	5-5
8. Load handling	5-7
9. Shut down procedure	5-13

6. EMERGENCY PROCEDURES

1. Emergency precautions	6-1
2. Mast emergency lowering	6-2

7. PLANNED MAINTENANCE

1. Introduction	7-1
2. Lift truck maintenance	7-1
3. Planned maintenance	7-1
4. Planned maintenance intervals	7-2
5. Major component locations	7-3
6. Daily maintenance checks	7-5
7. Periodic maintenance checks	7-6
8. Safe maintenance practices	7-7
9. Maintenance guide	7-9
10. Visual inspection	7-14
11. Checking the hydraulic fluid	7-16
12. Critical fastener checks	7-16
13. Air cleaning the truck	7-17

14. Electric truck battery maintenance	7-18
15. Battery handling	7-19
16. Battery charging	7-20
17. Battery installation & removal from truck	7-23
18. Battery cleaning and care	7-25
19. New machine oil	7-27
20. Recommended lubricants	7-27

8. SPECIFICATIONS

1. Specification	8-1
2. Specification for major components	8-3
3. Tightening torque	8-5