

CONTENTS

A MESSAGE TO HD HYUNDAI LIFT TRUCK OPERATORS	1
INTRODUCTION	2
HOW TO USE THIS MANUAL	3
SAFETY LABELS	5
GUIDE	11
1. DIRECTION	11
2. SERIAL NUMBER	11
3. SYMBOLS	11
4. VIBRATION AND NOISE	12
5. STRENGTH OF CHAIN	12
6. OPERATING TEMPERATURE	12
CHAPTER 1 SAFETY HINTS	13
1. DAILY INSPECTION	13
2. DO'S AND DON'TS	14
3. SEAT BELTS	16
4. NO RIDERS	17
5. PEDESTRIANS	18
6. OPERATOR PROTECTION	19
7. FORK SAFETY	20
8. PINCH POINTS	21
9. TRAVEL	22
10. GRADES, RAMPS, SLOPES AND INCLINES	23
11. TIP OVER	24
12. SURFACE AND CAPACITY	26
13. PARKING	27
14. LIFTING, JACK-UP AND BLOCKING	28
15. LIFTING OF LIFT TRUCK	33
16. SIDE SHIFT AND PORK POSITIONER (OPT)	34

CHAPTER 2 OPERATING HAZARDS	37
1. LOOSE LOADS	37
2. LONG AND WIDE LOADS	38
3. REAR SWING	38
4. LOW OVERHEAD CLEARANCE	39
5. FAST TURNS AND HIGH LOADS	39
6. DROP-OFFS	40
7. RIGHT ANGLE STACKING	40
8. CHAIN SLACK	41
9. PALLETS AND SKIDS	41
10. CAUTION FOR ELECTRICAL LINES	42
11. SOLID TIRE	43
12. WEIGHT INDICATOR (OPTION)	43
CHAPTER 3 KNOW YOUR TRUCK	44
1. GENERAL LOCATIONS	44
2. NAME PLATE	45
3. CAB DEVICES	46
4. CLUSTER	47
5. SWITCHES AND LEVERS	59
6. OPERATOR'S SEAT ADJUSTMENT	63
7. BATTERY COVER	64
CHAPTER 4 OPERATOR MAINTENANCE AND CARE	65
1. SAFETY INSPECTION	65
2. VISUAL CHECKS	66
3. FUNCTIONAL CHECKS	67
4. CONCLUDING THE INSPECTION	67
CHAPTER 5 STARTING AND OPERATING PROCEDURES	68
1. BEFORE OPERATING THE TRUCK	68
2. STARTING FROM A SAFE CONDITION	68
3. BEFORE OPERATING THE TRUCK	69

4. SPEED ADJUSTMENT	71
5. BRAKE OPERATION	71
6. PLUGGING	71
7. OPERATING SAFELY	72
8. LOAD HANDLING.....	74
9. SHUT DOWN PROCEDURE	80
CHAPTER 6 EMERGENCY PROCEDURES.....	81
1. HOW TO TOW A DISABLED TRUCK	81
2. EMERGENCY MAST LOWERING.....	83
CHAPTER7PLANNED MAINTENANCE AND LUBRICATION	84
1. INTRODUCTION.....	84
2. SAFE MAINTENANCE PRACTICES	85
3. INSTRUCTIONS BEFORE MAINTENANCE	87
4. MAJOR COMPONENT LOCATIONS.....	90
5. MAINTENANCE CHECKLIST	91
6. HOW TO PERFORM PLANNED MAINTENANCE.....	92
7. VISUAL INSPECTION.....	96
8. CHANGE OF HYDRAULIC OIL AND CONSUMABLES	99
9. TORQUE CHECKS.....	100
10. AIR CLEANING.....	100
11. BATTERY MAINTENANCE	101
12. BATTERY HANDLING.....	102
13. BATTERY CHARGING.....	103
14. BATTERY REPLACEMENT	105
15. BATTERY MAINTENANCE	109
16. LITHIUM ION BATTERY (OPT)	110
17. LITHIUM ION BATTERY CHARGER (OPT).....	114
18. CAMERA (OPT)	116
19. STORAGE	120
20. LUBRICANTS FOR NEW TRUCK.....	121

21. RECOMMENDED LUBRICANT	121
22. SCHEMATIC DIAGRAM.....	122
CHAPTER 8 SPECIFICATIONS.....	127
1. SPECIFICATION TABLE	127
2. SPECIFICATION FOR MAJOR COMPONENTS.....	128
3. FASTENING TORQUE.....	131
Appendix.....	132