







- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 7 Safety valve
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Accumulator
- 14 Pressure sensor
- 15 Brake valve(option)
- 16 Pressure switch
- 17 Hydraulic tank
- 18 Air breather
- 19 Return filter
- 20 By pass valve
- 21 Strainer
- 22 Oil cooler
- 23 Pressure filter
- 24 Pressure sensor
- 25 Fan motor(option)
- 26 Motor pump(option)
- 27 Check block(option)
- 28 Pressure sensor(option)
- 29 Check valve(option)
- 30 Ride control valve(option)
- 31 Accumulator(option)
- 32 Quick couple cylinder(option)
- 33 Solenoid valve(option)
- 34 Check valve




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Priority valve
- 7 Cut off valve
- 8 Brake valve
- 10 Steering cylinder
- 11 Bucket cylinder
- 12 Boom cylinder
- 13 Pilot supply unit
- 14 Line filter
- 15 Safety valve
- 17 Accumulator
- 18 Pressure switch
- 19 Pressure sensor
- 20 Line filter
- 21 Oil cooler
- 22 Fan motor(option)
- 23 Air breather
- 24 Hydraulic tank
- 25 Return filter
- 26 By pass valve
- 27 Shockless valve
- 28 Motor pump assy
- 29 Check valve
- 30 Pressure sensor
- 31 Ride control valve(option)
- 32 Accumulator(option)
- 33 Pressure switch(option)
- 35 Pressure sensor




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 7 Safety valve
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Pressure sensor
- 14 Brake valve(option)
- 15 Pressure switch
- 16 Hydraulic tank
- 17 Air breather
- 18 Return filter
- 19 By pass valve
- 20 Strainer
- 21 Oil cooler
- 22 Pressure filter
- 23 Pressure sensor
- 24 Fan motor(option)
- 25 Motor block
- 26 Motor pump(option)
- 27 Check block(option)
- 28 Pressure sensor(option)
- 29 Check valve(option)
- 30 Ride control valve(option)
- 31 Accumulator(option)
- 32 Quick couple cylinder(option)
- 33 Solenoid valve(option)
- 34 Check valve
- 35 Accumulator




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 7 Safety valve
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Accumulator
- 14 Pressure sensor
- 15 Brake valve(option)
- 16 Pressure switch
- 17 Hydraulic tank
- 18 Air breather
- 19 Return filter
- 20 By pass valve
- 21 Strainer
- 22 Oil cooler
- 23 Pressure filter
- 24 Pressure sensor
- 25 Fan motor(option)
- 26 Motor pump(option)
- 27 Check block(option)
- 28 Pressure sensor(option)
- 29 Check valve(option)
- 30 Ride control valve(option)
- 31 Accumulator(option)
- 32 Quick couple cylinder(option)
- 33 Solenoid valve(option)
- 34 Check valve




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 7 Safety valve
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Pressure sensor
- 14 Brake valve(option)
- 15 Pressure switch
- 16 Hydraulic tank
- 17 Air breather
- 18 Return filter
- 19 By pass valve
- 20 Strainer
- 21 Oil cooler
- 22 Pressure filter
- 23 Pressure sensor
- 24 Fan motor(option)
- 25 Motor block
- 26 Motor pump(option)
- 27 Check block(option)
- 28 Pressure sensor(option)
- 29 Check valve(option)
- 30 Ride control valve(option)
- 31 Accumulator(option)
- 32 Quick couple cylinder(option)
- 33 Solenoid valve(option)
- 34 Check valve
- 35 Accumulator




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 7 Safety valve
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Accumulator
- 14 Pressure sensor
- 15 Brake valve(option)
- 16 Pressure switch
- 17 Hydraulic tank
- 18 Air breather
- 19 Return filter
- 20 By pass valve
- 21 Strainer
- 22 Hyd oil cooler
- 23 Pressure filter
- 24 Pressure sensor
- 25 Fan motor(option)
- 26 Motor pump(option)
- 27 Check block(option)
- 28 Pressure sensor(option)
- 29 Check valve(option)
- 30 Ride control valve(option)
- 31 Accumulator(option)
- 32 Quick couple cylinder(option)
- 33 Solenoid valve(option)
- 34 Check valve




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Priority valve
- 7 Cut off valve
- 8 Brake valve
- 10 Steering cylinder
- 11 Bucket cylinder
- 12 Boom cylinder
- 13 Pilot supply unit
- 14 Line filter
- 15 Safety valve
- 16 Accumulator
- 17 Accumulator
- 18 Pressure switch
- 19 Pressure sensor
- 20 Line filter
- 21 Oil cooler
- 22 Fan motor
- 23 Air breather
- 24 Hydraulic tank
- 25 Return filter
- 26 By pass valve
- 27 Shockless valve
- 28 Motor pump assy
- 29 Check valve
- 30 Pressure sensor
- 31 Ride control valve(option)
- 32 Accumulator
- 33 Pressure switch
- 35 Pressure sensor




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 7 Safety valve
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Accumulator
- 14 Pressure sensor
- 15 Brake valve(option)
- 16 Pressure switch
- 17 Hydraulic tank
- 18 Air breather
- 19 Return filter
- 20 By pass valve
- 21 Strainer
- 22 Hyd oil cooler
- 23 Pressure sensor
- 24 Fan motor(option)
- 25 Directional valve
- 26 Motor pump(option)
- 27 Check block(option)
- 28 Pressure sensor(option)
- 29 Check valve(option)
- 30 Ride control valve(option)
- 31 Accumulator(option)
- 32 Quick couple cylinder(option)
- 33 Solenoid valve(option)
- 34 Check valve




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 7 Safety valve
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Accumulator
- 14 Pressure sensor
- 15 Brake valve(option)
- 16 Pressure switch
- 17 Hydraulic tank
- 18 Air breather
- 19 Return filter
- 20 By pass valve
- 21 Strainer
- 22 Hyd oil cooler
- 23 Pressure filter
- 24 Pressure sensor
- 25 Fan motor(option)
- 26 Motor pump(option)
- 27 Check block(option)
- 28 Pressure sensor(option)
- 29 Check valve(option)
- 30 Ride control valve(option)
- 31 Accumulator(option)
- 32 Quick couple cylinder(option)
- 33 Solenoid valve(option)
- 34 Check valve




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 7 Safety valve
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Accumulator
- 14 Pressure sensor
- 15 Brake valve(option)
- 16 Pressure switch
- 17 Hydraulic tank
- 18 Air breather
- 19 Return filter
- 20 By pass valve
- 21 Strainer
- 22 Hyd oil cooler
- 23 Pressure sensor
- 24 Fan motor(option)
- 25 Directional valve
- 26 Motor pump(option)
- 27 Check block(option)
- 28 Pressure sensor(option)
- 29 Check valve(option)
- 30 Ride control valve(option)
- 31 Accumulator(option)
- 32 Quick couple cylinder(option)
- 33 Solenoid valve(option)
- 34 Check valve





- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Accumulator
- 7 Steering valve(option)
- 8 Controller(option)
- 9 Joystick(option)
- 10 Safety valve
- 11 Shuttle valve
- 12 Boom cylinder
- 13 Bucket cylinder
- 14 Steering cylinder
- 15 Cut off valve
- 16 Accumulator
- 17 Pressure sensor
- 18 Brake valve(option)
- 19 Pressure switch
- 20 Hydraulic tank
- 21 Air breather
- 22 Return filter
- 23 By pass valve
- 24 Strainer
- 25 Oil cooler
- 26 Pressure filter
- 27 Check valve
- 28 Pressure sensor
- 29 Fan motor(option)
- 30 Motor pump(option)
- 31 Check block(option)
- 32 Pressure sensor(option)
- 33 Check valve(option)
- 34 Ride control valve(option)
- 35 Accumulator(option)
- 36 Quick couple cylinder(option)
- 37 Solenoid valve(option)
- 38 Stop valve






- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Accumulator
- 7 Steering valve(option)
- 8 Controller(option)
- 9 Joystick(option)
- 10 Safety valve
- 11 Shuttle valve
- 12 Boom cylinder
- 13 Bucket cylinder
- 14 Steering cylinder
- 15 Cut off valve
- 16 Accumulator
- 17 Pressure sensor
- 18 Brake valve(option)
- 19 Pressure switch
- 20 Hydraulic tank
- 21 Air breather
- 22 Return filter
- 23 By pass valve
- 24 Strainer
- 25 Hyd oil cooler
- 26 Check valve
- 27 Pressure sensor
- 28 Fan motor(option)
- 29 Directional valve
- 30 Motor pump(option)
- 31 Check block(option)
- 32 Pressure sensor(option)
- 33 Check valve(option)
- 34 Ride control valve(option)
- 35 Accumulator(option)
- 36 Quick couple cylinder(option)
- 37 Solenoid valve(option)
- 38 Stop valve
- 39 Accumulator







- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Accumulator
- 7 Steering valve(option)
- 8 Controller(option)
- 9 Joystick(option)
- 10 Safety valve
- 11 Shuttle valve
- 12 Boom cylinder
- 13 Bucket cylinder
- 14 Steering cylinder
- 15 Cut off valve
- 16 Accumulator
- 17 Pressure sensor
- 18 Brake valve(option)
- 19 Pressure switch
- 20 Hydraulic tank
- 21 Air breather
- 22 Return filter
- 23 By pass valve
- 24 Strainer
- 25 Oil cooler
- 26 Pressure filter
- 27 Check valve
- 28 Pressure sensor
- 29 Fan motor(option)
- 30 Motor pump(option)
- 31 Check block(option)
- 32 Pressure sensor(option)
- 33 Check valve(option)
- 34 Ride control valve(option)
- 35 Accumulator(option)
- 36 Quick couple cylinder(option)
- 37 Solenoid valve(option)
- 38 Stop valve




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Accumulator
- 7 Steering valve(option)
- 8 Controller(option)
- 9 Joystick(option)
- 10 Safety valve
- 11 Shuttle valve
- 12 Boom cylinder
- 13 Bucket cylinder
- 14 Steering cylinder
- 15 Cut off valve
- 16 Accumulator
- 17 Pressure sensor
- 18 Brake valve(option)
- 19 Pressure switch
- 20 Hydraulic tank
- 21 Air breather
- 22 Return filter
- 23 By pass valve
- 24 Strainer
- 25 Hyd oil cooler
- 26 Check valve
- 27 Pressure sensor
- 28 Fan motor(option)
- 29 Directional valve
- 30 Motor pump(option)
- 31 Check block(option)
- 32 Pressure sensor(option)
- 33 Check valve(option)
- 34 Ride control valve(option)
- 35 Accumulator(option)
- 36 Quick couple cylinder(option)
- 37 Solenoid valve(option)
- 38 Stop valve
- 39 Accumulator




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Accumulator
- 7 Steering valve(option)
- 8 Controller(option)
- 9 Joystick(option)
- 10 Safety valve
- 11 Shuttle valve
- 12 Boom cylinder
- 13 Bucket cylinder
- 14 Steering cylinder
- 15 Cut off valve
- 16 Accumulator
- 17 Accumulator
- 18 Pressure sensor
- 19 Brake valve(option)
- 20 Pressure switch
- 21 Hydraulic tank
- 22 Air breather
- 23 Return filter
- 24 By pass valve
- 25 Strainer
- 26 Oil cooler
- 27 Pressure filter
- 28 Check valve
- 29 Pressure sensor
- 30 Fan motor(option)
- 31 Motor pump(option)
- 32 Check block(option)
- 33 Pressure sensor(option)
- 34 Check valve(option)
- 35 Ride control valve(option)
- 36 Accumulator(option)
- 37 Quick couple cylinder(option)
- 38 Solenoid valve(option)
- 39 Stop valve







- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Accumulator
- 7 Steering valve(option)
- 8 Controller(option)
- 9 Joystick(option)
- 10 Safety valve
- 11 Shuttle valve
- 12 Boom cylinder
- 13 Bucket cylinder
- 14 Steering cylinder
- 15 Cut off valve
- 16 Accumulator
- 17 Accumulator
- 18 Pressure sensor
- 19 Brake valve(option)
- 20 Pressure switch
- 21 Hydraulic tank
- 22 Air breather
- 23 Return filter
- 24 By pass valve
- 25 Strainer
- 26 Hyd oil cooler
- 27 Check valve
- 28 Pressure sensor
- 29 Fan motor(option)
- 30 Directional valve
- 31 Motor pump(option)
- 32 Check block(option)
- 33 Pressure sensor(option)
- 34 Check valve(option)
- 35 Ride control valve(option)
- 36 Accumulator(option)
- 37 Quick couple cylinder(option)
- 38 Solenoid valve(option)
- 39 Stop valve




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Flow amplifier
- 7 Controller(option)
- 8 Joystick(option)
- 9 Proportional valve(option)
- 10 LS compensating valve(option)
- 11 Shuttle valve(option)
- 12 Pressure sensor(option)
- 13 Safety valve
- 14 Shuttle valve
- 15 Boom cylinder
- 16 Bucket cylinder
- 17 Steering cylinder
- 18 Cut off valve
- 19 Accumulator
- 20 Accumulator
- 21 Pressure sensor
- 22 Brake valve(option)
- 23 Pressure switch
- 24 Hydraulic tank
- 25 Air breather
- 26 Return filter
- 27 By pass valve
- 28 Strainer
- 29 Oil cooler
- 30 Pressure filter
- 31 Check valve
- 32 Pressure sensor
- 33 Fan motor(option)
- 34 Motor pump(option)
- 35 Check block(option)
- 36 Pressure sensor(option)
- 37 Check valve(option)
- 38 Ride control valve(option)
- 39 Accumulator(option)
- 40 Quick couple cylinder(option)
- 41 Solenoid valve(option)
- 42 Stop valve(option)







- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Flow amplifier
- 7 Controller(option)
- 8 Joystick(option)
- 9 Proportional valve(option)
- 10 LS compensating valve(option)
- 11 Shuttle valve(option)
- 12 Pressure sensor(option)
- 13 Safety valve
- 14 Shuttle valve
- 15 Boom cylinder
- 16 Bucket cylinder
- 17 Steering cylinder
- 18 Cut off valve
- 19 Accumulator
- 20 Accumulator
- 21 Pressure sensor
- 22 Brake valve(option)
- 23 Pressure switch
- 24 Hydraulic tank
- 25 Air breather
- 26 Return filter
- 27 By pass valve
- 28 Strainer
- 29 Oil cooler
- 30 Check valve
- 31 Pressure sensor
- 32 Fan motor(option)
- 33 Directional valve
- 34 Motor pump(option)
- 35 Check block(option)
- 36 Pressure sensor(option)
- 37 Check valve(option)
- 38 Ride control valve(option)
- 39 Accumulator(option)
- 40 Quick couple cylinder(option)
- 41 Solenoid valve(option)
- 42 Stop valve(option)




- 1 Steering pump
- 2 Working pump
- 3 Fan & brake pump
- 4 Main control valve(option)
- 5 RCV lever(option)
- 6 Steering unit
- 7 Flow amplifier
- 8 Controller(option)
- 9 Joystick(option)
- 10 Proportional valve(option)
- 11 LS compensating valve(option)
- 12 Shuttle valve(option)
- 13 Pressure sensor(option)
- 14 Safety valve
- 15 Shuttle valve
- 16 Boom cylinder
- 17 Bucket cylinder
- 18 Steering cylinder
- 19 Cut off valve
- 20 Accumulator
- 21 Pressure sensor
- 22 Brake valve(option)
- 23 Pressure switch
- 24 Hydraulic tank
- 25 Air breather
- 26 Return filter
- 27 By pass valve
- 28 Strainer
- 29 Oil cooler
- 30 Pressure filter
- 31 Check valve
- 32 Pressure sensor
- 33 Fan motor(option)
- 34 Motor pump(option)
- 35 Check block(option)
- 36 Pressure sensor(option)
- 37 Check valve(option)
- 38 Ride control valve(option)
- 39 Accumulator(option)
- 40 Accumulator(option)
- 41 Quick couple cylinder(option)
- 42 Solenoid valve(option)
- 43 Stop valve(option)







- 1 Steering pump
- 2 Working pump
- 3 Fan & brake pump
- 4 Main control valve(option)
- 5 RCV lever(option)
- 6 Steering unit
- 7 Flow amplifier
- 8 Controller(option)
- 9 Joystick(option)
- 10 Proportional valve(option)
- 11 LS compensating valve(option)
- 12 Shuttle valve(option)
- 13 Pressure sensor(option)
- 14 Safety valve
- 15 Shuttle valve
- 16 Boom cylinder
- 17 Bucket cylinder
- 18 Steering cylinder
- 19 Cut off valve
- 20 Accumulator
- 21 Pressure sensor
- 22 Brake valve(option)
- 23 Pressure switch
- 24 Hydraulic tank
- 25 Air breather
- 26 Return filter
- 27 By pass valve
- 28 Strainer
- 29 Oil cooler
- 30 Check valve
- 31 Pressure sensor
- 32 Fan motor(option)
- 33 Directional valve
- 34 Motor pump(option)
- 35 Check block(option)
- 36 Pressure sensor(option)
- 37 Check valve(option)
- 38 Ride control valve(option)
- 39 Accumulator(option)
- 40 Accumulator(option)
- 41 Quick couple cylinder(option)
- 42 Solenoid valve(option)
- 43 Stop valve(option)
- 44 EH controller
- 45 Remote control block
- 46 Stop valve(option)




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(OPT 1)
- 4 RCV lever(OPT 2)
- 5 Steering unit
- 6 Check valve
- 7 Safety valve
- 7-1 Filter element
- 7-2 Accumulator
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Accumulator
- 14 Pressure sensor
- 15 Brake valve(OPT 3)
- 16 Pressure switch
- 17 Hydraulic tank
- 18 Air breather
- 18-1 Element
- 19 Return filter
- 20 By pass valve
- 21 Strainer
- 22 Oil cooler
- 23 Pressure sensor
- 24 Fan motor
- 25 Directional valve
- 26 Motor pump(OPT 4)
- 27 Check block(OPT 4)
- 28 Pressure sensor(OPT 4)
- 29 Check valve(OPT 4)
- 30 Ride control valve(OPT 5)
- 31 Accumulator(OPT 5)
- 32 Quick couple cylinder(OPT 6)
- 33 Solenoid valve(OPT 6)
- 34 Accumulator
- 35 Orifice




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve
- 4 RCV lever(OPT 1)
- 5 Steering unit
- 6 Check valve
- 7 Safety valve
- 7-1 Filter element
- 7-2 Accumulator
- 8 Boom cylinder
- 9 Bucket cylinder
- 10 Steering cylinder
- 11 Cut off valve
- 12 Accumulator
- 13 Accumulator
- 14 Pressure sensor
- 15 Brake valve(OPT 2)
- 16 Pressure switch
- 17 Hydraulic tank
- 18 Air breather
- 18-1 Element
- 19 Return filter
- 20 By pass valve
- 21 Strainer
- 22 Oil cooler
- 23 Pressure sensor
- 24 Fan motor
- 25 Directional valve
- 26 Motor pump(OPT 3)
- 27 Check block(OPT 3)
- 28 Pressure sensor(OPT 3)
- 29 Check valve(OPT 3)
- 30 Ride control valve(OPT 4)
- 31 Accumulator(OPT 4)
- 32 Quick couple cylinder(OPT 5)
- 33 Solenoid valve(OPT 5)
- 34 Accumulator
- 35 Orifice




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(opt 1)
- 4 Fan motor
- 5 Directional valve
- 6 HYD oil cooler
- 7 Check valve
- 8 Controller
- 9 Boom lowering valve(opt 2)
- 10 Remote control block(opt 2)
- 11 RCV-EH lever(opt 2)
- 12 FNR joystick(opt 3)
- 13 Safety valve
- 13-1 Filter element
- 14 Shuttle valve
- 15 Boom cylinder
- 16 Bucket cylinder
- 17 Steering cylinder
- 18 Steering unit
- 19 Steering valve(opt 4)
- 20 Joystick steering(opt 4)
- 21 Accumulator
- 22 Orifice
- 23 Pressure sensor
- 24 Brake valve(opt 5)
- 25 Pressure switch
- 26 Cut off valve
- 27 Accumulator
- 28 Accumulator
- 29 Pressure sensor
- 30 Hydraulic tank
- 31 Air breather
- 31-1 Element
- 32 Return filter
- 33 By pass valve
- 34 Strainer
- 35 Motor pump(opt 6)
- 36 Check block(opt 6)
- 37 Pressure sensor(opt 6)
- 38 Check valve(opt 6)
- 39 Ride control valve(opt 7)
- 40 Accumulator(opt 7)
- 41 Quick couple cylinder(opt 8)
- 42 Solenoid valve(opt 8)




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve
- 4 Fan motor
- 5 Directional valve
- 6 HYD oil cooler
- 7 Check valve
- 8 Controller
- 9 Boom lowering valve(opt 2)
- 10 Remote control block(opt 2)
- 11 RCV-EH lever(opt 2)
- 12 FNR joystick(opt 3)
- 13 Safety valve
- 13-1 Filter element
- 14 Shuttle valve
- 15 Boom cylinder
- 16 Bucket cylinder
- 17 Steering cylinder
- 18 Steering unit
- 19 Steering valve(opt 4)
- 20 Joystick steering(opt 4)
- 21 Accumulator
- 22 Orifice
- 23 Pressure sensor
- 24 Brake valve(opt 5)
- 25 Pressure switch
- 26 Cut off valve
- 27 Accumulator
- 28 Accumulator
- 29 Pressure sensor
- 30 Hydraulic tank
- 31 Air breather
- 31-1 Element
- 32 Return filter
- 33 By pass valve
- 34 Strainer
- 35 Motor pump(opt 6)
- 36 Check block(opt 6)
- 37 Pressure sensor(opt 6)
- 38 Check valve(opt 6)
- 39 Ride control valve(opt 7)
- 40 Accumulator(opt 7)
- 41 Quick couple cylinder(opt 8)
- 42 Solenoid valve(opt 8)




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(opt 1)
- 4 RCV-EH lever(opt 2)
- 5 EH - joystick(opt 2)
- 6 Steering unit
- 7 Accumulator
- 8 Steering valve
- 9 Joystick steering(opt 3)
- 10 Safety valve
- 10-1 Filter element
- 11 Shuttle valve
- 12 Boom cylinder
- 13 Bucket cylinder
- 14 Steering cylinder
- 15 Cut off valve
- 16 Accumulator
- 17 Accumulator
- 18 Pressure sensor
- 19 Brake valve(opt 4)
- 20 Pressure switch
- 21 Hydraulic tank
- 22 Air breather
- 22-1 Element
- 23 Return filter
- 24 By pass valve
- 25 Strainer
- 26 HYD oil cooler
- 27 Check valve
- 28 Pressure sensor
- 29 Fan motor
- 30 Directional valve
- 31 Motor pump(opt 5)
- 32 Check block(opt 5)
- 33 Pressure sensor(opt 5)
- 34 Check valve(opt 5)
- 35 Ride control valve(opt 6)
- 36 Accumulator(opt 6)
- 37 Quick couple cylinder(opt 7)
- 38 Solenoid valve(opt 7)
- 39 EH - controller
- 40 Remote control block(opt 1)
- 41 Boom lowering valve




- 1 Main pump
- 2 Fan & brake pump
- 3 Main control valve(opt 1)
- 4 RCV lever(opt 2)
- 5 Control unit
- 6 Remote control block(opt 1)
- 7 Steering unit
- 8 Flow amplifier
- 9 Electric joystick(opt 3)
- 10 Proportional valve(opt3)
- 11 LS compensating valve(opt3)
- 12 Shuttle valve(opt3)
- 13 Pressure sensor(opt3)
- 14 Safety valve
- 14-1 Filter element
- 15 Shuttle valve
- 16 Boom cylinder
- 17 Bucket cylinder
- 18 Steering cylinder
- 19 Cut off valve
- 20 Accumulator
- 21 Accumulator
- 22 Pressure sensor
- 23 Brake valve(opt 4)
- 24 Pressure switch
- 25 Hydraulic tank
- 26 Air breather
- 26-1 Element
- 26-2 Strainer
- 27 Return filter
- 28 By pass valve
- 29 Strainer
- 30 HYD oil cooler
- 31 Check valve
- 32 Pressure sensor
- 33 Fan motor
- 34 Directional valve
- 35 Motor pump(opt 5)
- 36 Check block(opt 5)
- 37 Pressure sensor(opt 5)
- 38 Check valve(opt 5)
- 39 Ride control valve(opt 6)
- 40 Accumulator(opt 6)
- 41 Quick couple cylinder(opt 7)
- 42 Solenoid valve(opt 7)
- 43 Boom lowering valve
- 44 FNR - joystick(opt 3)
- 45 Accumulator
- 46 Orifice




- 1 Steering pump
- 2 Working pump
- 3 Fan & brake pump
- 4 Main control valve(opt 1)
- 5 RCV lever(opt 2)
- 6 EH - controller
- 7 Remote control block(opt 1)
- 8 Steering unit
- 9 Flow amplifier
- 10 Electric joystick(opt 3)
- 11 Proportional valve(opt3)
- 12 LS compensating valve(opt3)
- 13 Shuttle valve(opt3)
- 14 Pressure sensor(opt3)
- 15 Safety valve
- 15-1 Filter element
- 16 Shuttle valve
- 17 Boom cylinder
- 18 Bucket cylinder
- 19 Steering cylinder
- 20 Cut off valve
- 21 Accumulator
- 22 Pressure sensor
- 23 Brake valve(opt 4)
- 24 Pressure switch
- 25 Hydraulic tank
- 26 Air breather
- 26-1 Element
- 27 Strainer
- 28 Return filter
- 29 By pass valve
- 30 Strainer
- 31 HYD oil cooler
- 32 Check valve
- 33 Pressure sensor
- 34 Fan motor
- 35 Directional valve
- 36 Motor pump(opt 5)
- 37 Check block(opt 5)
- 38 Pressure sensor(opt 5)
- 39 Check valve(opt 5)
- 40 Ride control valve(opt 6)
- 41 Accumulator(opt 6)
- 42 Accumulator(opt 6)
- 43 Quick couple cylinder(opt 7)
- 44 Solenoid valve(opt 7)
- 45 Boom lowering valve
- 46 FNR - joystick(opt 8)
- 47 Accumulator
- 48 Orifice




- 1 Main pump assy
- 2 Main control valve(2-spool)
- 3 Boom cylinder
- 4 Bucket cylinder
- 5 Steering cylinder
- 6 Flow divider
- 7 Steering unit
- 8 Return filter
- 9 By pass valve
- 10 Air breather
- 11 Hydraulic oil tank




- 1 Main & Pilot pump
- 2 Main control valve(option)
- 3 RCV lever(option)
- 4 Steering unit
- 5 Priority valve
- 6 Boom cylinder
- 7 Bucket cylinder
- 8 Steering cylinder
- 9 Pressure select valve
- 10 Hydraulic tank
- 11 Air breather
- 12 Return filter
- 13 Safety valve




- 1 Main pump assy
- 2 Main control valve(2-spool)
- 3 Boom cylinder
- 4 Bucket cylinder
- 5 Steering cylinder
- 6 Priority valve
- 7 Steering unit
- 8 Return filter
- 9 By pass valve
- 10 Air breather
- 11 Hydraulic oil tank






- 1 Implement pump
- 2 Steering pump
- 3 Main control valve 2-spool
- 4 Steering unit
- 5 Steering valve
- 6 Boom cylinder
- 7 Bucket cylinder
- 8 Steering cylinder
- 9 Hydraulic tank
- 10 Air breather
- 11 Return filter
- 12 Oil cooler
- 13 Orifice



- 1 Implement pump
- 2 Steering & pilot pump
- 3 Main control valve(option)
- 4 RCV lever(option)
- 5 Steering unit
- 6 Steering valve
- 7 Boom cylinder
- 8 Bucket cylinder
- 9 Steering cylinder
- 10 Pressure select valve
- 11 Hydraulic tank
- 12 Air breather
- 13 Return filter
- 14 Oil cooler
- 15 Orifice
- 16 Safety valve



- 1 Implement pump
- 2 Steering pump
- 3 Main control valve 2-spool
- 4 Steering unit
- 5 Steering valve
- 6 Boom cylinder
- 7 Bucket cylinder
- 8 Steering cylinder
- 9 Hydraulic tank
- 10 Air breather
- 11 Return filter
- 12 Oil cooler
- 13 Orifice