



- | | |
|----|----------------------------------|
| 1 | Main pump |
| 2 | Main control valve (loader) |
| 3 | Main control valve (backhoe) |
| 4 | Steering unit |
| 5 | Remote control valve-LH |
| 6 | Remote control valve-RH |
| 7 | Stabilizer lever |
| 8 | Pilot supply unit |
| 9 | 5-cartridge sol valve (option) |
| 10 | Line filter |
| 11 | Accumulator |
| 12 | Ride control valve (option) |
| 13 | Pilot check valve (option) |
| 14 | Safety lock valve (option) |
| 15 | Swing damping valve (option) |
| 16 | Double pilot check valve |
| 17 | Breaker valve (option) |
| 18 | Return check valve |
| 19 | By-pass check valve |
| 20 | Air breather |
| 21 | Boom cylinder |
| 22 | Dipper cylinder |
| 23 | Bucket cylinder |
| 24 | Swing cylinder |
| 25 | Extension cylinder (option) |
| 26 | Clamp cylinder |
| 27 | Stabilizer cylinder |
| 28 | Loader boom cylinder |
| 29 | Clam cylinder-LH (option) |
| 30 | Clam cylinder-RH (option) |
| 31 | Oil cooler |
| 32 | Suction strainer |
| 33 | Return filter |
| 34 | Pattern exchanger valve (option) |
| 35 | Loader bucket cylinder-RH |
| 36 | Quick coupler-loader |
| 37 | Quick coupler-backhoe |
| 38 | Solenoid valve |
| 39 | Stop valve (option) |
| G | Gauge port |

■ H930C/H940C(Mechanical control, #0001~)




- | | |
|----|------------------------------|
| 1 | Main pump |
| 2 | Main control valve (loader) |
| 3 | Main control valve (backhoe) |
| 4 | Steering unit |
| 5 | Ride control valve (option) |
| 6 | Pilot check valve (option) |
| 7 | Double pilot check valve |
| 8 | Breaker valve (option) |
| 9 | By-pass check valve |
| 10 | Air breather |
| 11 | Boom cylinder |
| 12 | Dipper cylinder |
| 13 | Bucket cylinder |
| 14 | Swing cylinder |
| 15 | Extension cylinder (option) |
| 16 | Stabilizer cylinder-RH |
| 17 | Stabilizer cylinder-LH |
| 18 | Loader boom cylinder-RH |
| 19 | Loader boom cylinder-LH |
| 20 | Clam cylinder-LH (option) |
| 21 | Clam cylinder-RH(option) |
| 22 | Loader bucket cylinder-LH |
| 23 | Loader bucket cylinder-RH |
| 24 | Oil cooler |
| 25 | Return filter |
| 26 | Stop valve (option) |
| 27 | Quick coupler valve |
| 28 | Quick coupler-loader |
| G | Gauge port |

H930C/H940C(Pilot control, #0001 ~)





- | | |
|----|----------------------------------|
| 1 | Main pump |
| 2 | Main control valve (loader) |
| 3 | Main control valve (backhoe) |
| 4 | Steering unit |
| 5 | Remote control valve-LH |
| 6 | Remote control valve-RH |
| 7 | Stabilizer lever |
| 8 | Pilot supply unit |
| 9 | 5- cartridge sol valve (option) |
| 10 | Line filter |
| 11 | Accumulator |
| 12 | Ride control valve (option) |
| 13 | Pilot check valve (option) |
| 14 | Remote control lever (loader) |
| 15 | Swing damping valve (option) |
| 16 | Double pilot check valve |
| 17 | Breaker valve (option) |
| 18 | Stop valve (option) |
| 19 | By-pass check valve |
| 20 | Air breather |
| 21 | Boom cylinder |
| 22 | Dipper cylinder |
| 23 | Bucket cylinder |
| 24 | Swing cylinder |
| 25 | Extension cylinder (option) |
| 26 | Stabilizer cylinder-RH |
| 27 | Stabilizer cylinder-LH |
| 28 | Loader boom cylinder-LH |
| 29 | Loader boom cylinder-RH |
| 30 | Clam cylinder-LH (option) |
| 31 | Clam cylinder-RH (option) |
| 32 | Loader bucket cylinder-LH |
| 33 | Loader bucket cylinder-RH |
| 34 | Return filter |
| 35 | Pattern exchanger valve (option) |
| G | Oil cooler |
| | Gauge port |

■ H930S/H940S(Mechanical control, #0001~)



- | | |
|----|------------------------------|
| 1 | Main pump |
| 2 | Main control valve (loader) |
| 3 | Main control valve (backhoe) |
| 4 | Steering unit |
| 5 | Ride control valve (option) |
| 6 | Pilot check valve (option) |
| 7 | Double pilot check valve |
| 8 | Breaker valve (option) |
| 9 | By-pass check valve |
| 10 | Air breather |
| 11 | Boom cylinder |
| 12 | Dipper cylinder |
| 13 | Bucket cylinder |
| 14 | Swing cylinder |
| 15 | Extension cylinder (option) |
| 16 | Stabilizer cylinder-RH |
| 17 | Stabilizer cylinder-LH |
| 18 | Loader boom cylinder-RH |
| 19 | Loader boom cylinder-LH |
| 20 | Clam cylinder-LH (option) |
| 21 | Clam cylinder-RH(option) |
| 22 | Loader bucket cylinder-LH |
| 23 | Loader bucket cylinder-RH |
| 24 | Oil cooler |
| 25 | Return filter |
| 26 | Stop valve (option) |
| 27 | Quick coupler valve |
| 28 | Quick coupler-loader |
| 29 | Clamp cylinder |
| G | Gauge port |

H930S/H940S(Pilot control, #0001~)



1	Main pump
2	Main control valve (loader)
3	Main control valve (backhoe)
4	Steering unit
5	Remote control valve-LH
6	Remote control valve-RH
7	Stabilizer lever
8	Pilot supply unit
9	5-cartridge sol valve (option)
10	Line filter
11	Accumulator
12	Ride control valve (option)
13	Pilot check valve (option)
14	Remote control lever (loader)
15	Swing damping valve (option)
16	Double pilot check valve
17	Breaker valve (option)
18	Stop valve (option)
19	By-pass check valve
20	Air breather
21	Boom cylinder
22	Dipper cylinder
23	Bucket cylinder
24	Swing cylinder
25	Extension cylinder (option)
26	Stabilizer cylinder-RH
27	Stabilizer cylinder-LH
28	Loader boom cylinder-LH
29	Loader boom cylinder-RH
30	Clam cylinder-LH (option)
31	Clam cylinder-RH (option)
32	Loader bucket cylinder-LH
33	Loader bucket cylinder-RH
34	Return filter
35	Pattern exchanger valve (option)
36	Oil cooler
G	Clamp cylinder
G	Gauge port